




To access the Laser Desktop, switch the monitor, keyboard, and mouse using the selector switch located on the lower right-side panel.



Locate the Switch resting on top of the Desktop

Press the Button to switch between Laser and PC desktop

