

## DEVICE LIST 7/16/2008

Total Manufacturers 194

Total Devices 44860

<a href="#">ABOV</a>	<a href="#">ACT</a>	<a href="#">ACTRANS</a>	
<a href="#">ADI</a>			
<a href="#">ADVANCE GROUP</a>	<a href="#">AEROFLEX</a>	<a href="#">ALI (Acer)</a>	
<a href="#">ALL 24 SERIES (ISP)</a>		<a href="#">ALLIANCE</a>	
<a href="#">ALTERA</a>			
<a href="#">AMD</a>	<a href="#">AMI SEMICONDUCTOR</a>		
<a href="#">AMIC</a>			
<a href="#">ANACHIP</a>	<a href="#">ANALOG</a>	<a href="#">APLUS FLASH</a>	
<a href="#">ARTSCHIP</a>			
<a href="#">ASAHI KASEI (AKM)</a>	<a href="#">ASD</a>	<a href="#">ASI</a>	
<a href="#">ASP</a>			
<a href="#">ATC</a>	<a href="#">ATMEL</a>	<a href="#">ATMEL W&amp;M</a>	<a href="#">ATMEL-</a>
<a href="#">CUSTOMER</a>			
<a href="#">AUSTIN</a>	<a href="#">BELLING-SYSTRON</a>	<a href="#">BENCHMARQ</a>	
<a href="#">BMT</a>			
<a href="#">BOSEN</a>	<a href="#">BRIGHT</a>	<a href="#">CATALYST</a>	
<a href="#">CERAMATE</a>			
<a href="#">CHINA CORE</a>	<a href="#">CHINGIS</a>	<a href="#">CHIPCON</a>	
<a href="#">CHIPSWINNER</a>			
<a href="#">CORERIVER</a>	<a href="#">CWI</a>	<a href="#">CYGNAL</a>	
<a href="#">CYPRESS</a>			
<a href="#">DALLAS</a>	<a href="#">DENSE-PAC</a>	<a href="#">DEUTRON</a>	
<a href="#">EFST</a>			
<a href="#">ELECTRONIC ARRAYS</a>		<a href="#">ELPIDA</a>	
<a href="#">EM</a>			
<a href="#">EMTC</a>	<a href="#">EON</a>	<a href="#">EPSON</a>	
<a href="#">ESMT</a>			
<a href="#">EXCELSEMI</a>	<a href="#">EXEL</a>	<a href="#">FAIRCHILD</a>	
<a href="#">FORCE TECHNOLOGIES</a>		<a href="#">FORWARD</a>	

[FREESCALE](#)[Fremont Micro Devices](#)[FUJITSU](#)[GENCORE](#)[GENERAL\(GI\)](#)[GENERIC](#)[GOAL](#)[GOULD](#)[GREENWICH](#)[HAIER](#)[HARRIS](#)[HITACHI](#)[HOLTEK](#)[HONGKONG](#)[HYNIX](#)[HYNIX](#)[\(HYUNDAI\)](#)[HYNIX-CUSTOMER](#)[HYUNDAI](#)[ICE](#)[ICMIC](#)[ICSI](#)[ICT](#)[IMT](#)[INFINEON](#)[INTEL](#)[INTEL-CUSTOMER](#)[INTELSIL](#)[ISSI](#)[ITHINKO](#)[LATTICE](#)[LG Semicon](#)[LINKSMART](#)[MACRONIX](#)[MAGNACHIP](#)[MAXIM](#)[MAXWELL](#)[MEGAWIN](#)[MEMOCOM](#)[MICON](#)[MICROCHIP](#)[MICRON](#)[MICRONAS](#)[MICRON-CUSTOMER](#)[MITSUBISHI](#)[MMI](#)[MOSEL-VITELIC](#)[MOSTEK](#)[MOTOROLA](#)[MYSON](#)[MYSON-CUSTOMER](#)[NEC](#)[NEXFLASH](#)[NJRC](#)[NOVATEK](#)[NSC](#)[NTE](#)[NUMONYX](#)[NXP](#)[OKI](#)[PARALLAX](#)[PFLASH\(MSTAR\)](#)[PHILIPS](#)[PJ](#)[PMC](#)[POLYSTAK](#)[PSS](#)[PTC](#)[QIXIN](#)[Quick Pulse](#)[RAMTRON](#)[RATO](#)[RAYDIUM](#)[RENASAS](#)[RICOH](#)[ROCKWELL](#)

[ROHM](#)  
[SAIFUN](#)                    [SAMSUNG](#)                    [SAMSUNG-CUSTOMER](#)  
[SANYO](#)  
[SCENIX](#)                    [SEEQ](#)                    [SEIKO](#)                    [SGS-](#)  
[THOMSON](#)  
[SHARP](#)                    [SHARP-CUSTOMER](#)                    [SIEMENS](#)  
[SIGNETICS](#)  
[Silicon Laboratories](#)                    [SILICON7](#)  
[SIMTEK](#)  
[SIRF](#)                    [SMOS](#)                    [SONIX](#)  
[SONY](#)  
[SPACE ELECTRONICS\[SEi\]](#)                    [SPANSION](#)  
[SPANSION-CUSTOMER](#)                    [SSSC](#)  
[SST](#)  
[ST](#)                    [STC](#)                    [ST-CUSTOMER](#)  
[SUMMIT](#)  
[SUNPLUS](#)                    [SYNCMOS](#)                    [SYNERTEK](#)  
[SYNTEK](#)  
[TECHCODE](#)                    [TEKMOS](#)                    [TEMIC](#)                    [TEST-](#)  
[LOGIC](#)  
[TI](#)                    [TMC](#)                    [TOPRO](#)  
[TOSHIBA](#)  
[TOSHIBA-CUSTOMER](#)                    [TURBO IC](#)                    [UBICOM](#)  
[UMC](#)  
[UTRON](#)                    [VANTIS](#)                    [VERSACHIPS](#)  
[VLSI](#)  
[WELTREND](#)                    [WHITE ELECTRONIC DESIGNS](#)  
[WINBOND](#)  
[WISTRON](#)                    [WSI](#)                    [XELTEK](#)  
[XICOR](#)  
[XILINX](#)                    [XILINX-CUSTOMER](#)                    [YMC](#)  
[YSS](#)  
[ZILOG](#)                    [ZMD](#)

**ABOV**

## MICROCONTROLLER

MC80F0104 +B003) ]	MC80F0104@SOP16 [ (SA404
MC80F0104@TSSOP16 [ (SA026) ]	
MC80F0204	
MC80F0204@SOP20 [ (SA404+B003) ]	MC80F0208@MQFP44 [ (SA675-
B005) ]	
MC80F0208@SDIP42 [ (SA028) ]	MC80F0216@MQFP44 [ (SA675-
B005) ]	
MC80F0216@SDIP42 [ (SA028) ]	MC80F0224@MQFP44 [ (SA675-
B005) ]	
MC80F0224@SDIP42 [ (SA028) ]	
MC80F0304	
MC80F0304@SOP28 [ (SA404+B003) ]	
MC80F0308	
MC80F0308@SOP28 [ (SA404+B003) ]	
MC80F0316	
MC80F0316@SOP28 [ (SA404+B003) ]	
MC80F0424K@SDIP64(*) [ (SA752+B290) ]	
MC80F0424L@LQFP64(*) [ (SA732+B291) ]	
MC80F0424LG@LQFP64 [ (PEP+S616) ]	
MC80F0424Q@MQFP64(*) [ (SA758+B289) ]	
MC80F0432K@SDIP64(*) [ (SA752+B290) ]	
MC80F0432L@LQFP64(*) [ (SA732+B291) ]	
MC80F0432LG@LQFP64 [ (PEP+S616) ]	
MC80F0432Q@MQFP64(*) [ (SA758+B289) ]	
MC80F0448K@SDIP64(*) [ (SA752+B292) ]	
MC80F0448L@LQFP64(*) [ (SA732+B291) ]	
MC80F0448LG@LQFP64 [ (PEP+S616) ]	
MC80F0448Q@MQFP64(*) [ (SA758+B289) ]	
MC80F0504	MC80F0504@SOP16
[ (SA715) ]	
MC80F0504@SSOP16 [ (SA626A) ]	
MC80F0504[153mil]@SOP16 [ (SA602) ]	
MC80F0604	MC80F0604@SOP20
[ (SA715) ]	
MC80F0604@SSOP20 [ (SA626A) ]	
MC80F0704	
MC80F0704@QFN28 [ (SA697) ]	MC80F0704@SOP28
[ (SA715) ]	
MC80F0708	MC80F0708@QFN28
[ (SA697) ]	

MC80F0708@SOP28 [ (SA715) ]  
 [ (SA653) ]  
 MC80F0804@SOP32 [ (SA715) ]  
 [ (SA653) ]  
 MC80F0808@SOP32 [ (SA715) ]  
 B005) ]  
 MC80F7308@SDIP42 [ (SA028) ]  
 B005) ]

MC80F0804@SDIP32  
 MC80F0808@SDIP32  
 MC80F7108@TQFP44 [ (SA675-  
 MC80F7408@TQFP44 [ (SA675-

## ACT

### E (E) PROM/FRAM/NVRAM

93LC46(08bit) [ (SA602A) ]	93LC46(08bit)@SOIC8
93LC46(16bit) [ (SA602A) ]	93LC46(16bit)@SOIC8
93LC56(08bit) [ (SA602A) ]	93LC56(08bit)@SOIC8
93LC56(16bit) [ (SA602A) ]	93LC56(16bit)@SOIC8
93LC66(08bit) [ (SA602A) ]	93LC66(08bit)@SOIC8
93LC66(16bit) [ (SA602A) ]	93LC66(16bit)@SOIC8
93LC86(08bit) [ (SA602A) ]	93LC86(08bit)@SOIC8
93LC86(16bit) [ (SA602A) ]	93LC86(16bit)@SOIC8

## ACTRANS

### E (E) PROM/FRAM/NVRAM

AC25010@SOIC8 [ (SA602A) ] [ (SA602A) ]	AC25512@SOIC8
AC25LC010@SOIC8 [ (SA602A) ] [ (SA602A) ]	AC25LC512@SOIC8
AC39LV010@FBGA48 [ (SA642B-B026A-Y072F001) ]	
AC39LV010@PLCC32 [ (SA015A1T) ]	AC39LV010@VSOP32

[ (SA620) ]  
 AC39LV020@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AC39LV020@PLCC32 [ (SA015A1T) ] AC39LV020@VSOP32  
 [ (SA620) ]  
 AC39LV040@PLCC32 [ (SA015A1T) ] AC39LV040@VSOP32  
 [ (SA620) ]  
 AC39LV080@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AC39LV080@TSOP40 [ (SA409T) ] AC39LV088@TSOP48 [ (SA247-  
 B005) ]  
 AC39LV512@PLCC32 [ (SA015A1T) ] AC39LV512@VSOP32  
 [ (SA620) ]  
 AC39VF800@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AC39VF800@TSOP48 [ (SA247-B005) ]

## ADI

### MICROCONTROLLER

ADE7166F16@LQFP64 [ (PEP+S616) ]  
 ADE7166F16@LQFP64(\*) [ (SA732+B237) ]  
 ADE7169F16@LQFP64 [ (PEP+S616) ]  
 ADE7169F16@LQFP64(\*) [ (SA732+B237) ]  
 ADE7566F16@LQFP64 [ (PEP+S616) ]  
 ADE7566F16@LQFP64(\*) [ (SA732+B237) ]  
 ADE7569F16@LQFP64 [ (PEP+S616) ]  
 ADE7569F16@LQFP64(\*) [ (SA732+B237) ]  
 ADM1026@LQFP48 [ (SA248+B005) ] ADM1062@LFCSP40 [ (SA750  
 +B006) ]  
 ADM1062@LQFP48 [ (SA248+B005) ] ADM1066@LFCSP40 [ (SA750  
 +B006) ]  
 ADM1066@LQFP48 [ (SA248+B005) ] ADUC814@SSOP28 [ (SA643  
 +B005) ]  
 ADuC831BCP@LFCSP56 [ (SA706+B296) ]  
 ADuC831BS@MQFP52 [ (SA662+B042) ]  
 ADuC832BCP@LFCSP56 [ (SA706+B296) ]  
 ADuC832BS@MQFP52 [ (SA662+B042) ]  
 ADuC834BCP@LFCSP56 [ (SA706+B296) ]  
 ADuC834BS@MQFP52 [ (SA662+B042) ]  
 ADuC836BCP@LFCSP56 [ (SA706+B296) ]  
 ADuC836BS@MQFP52 [ (SA662+B042) ]  
 ADuC841BCP62@LFCSP56 [ (SA706+B296) ]  
 ADuC841BS62@MQFP52 [ (SA662+B042) ]

ADuC842BCP62@LFCSP56 [ (SA706+B296) ]  
 ADuC842BS62@MQFP52 [ (SA662+B042) ]  
 ADuC843BCP62@LFCSP56 [ (SA706+B296) ]  
 ADuC843BS62@MQFP52 [ (SA662+B042) ]  
 ADuC845BCP62@LFCSP56 [ (SA706+B297) ]  
 ADuC845BS62@MQFP52 [ (SA662+B042) ]  
 ADuC847BCP62@LFCSP56 [ (SA706+B297) ]  
 ADuC847BS62@MQFP52 [ (SA662+B042) ]  
 ADuC848BCP62@LFCSP56 [ (SA706+B297) ]  
 ADuC848BS62@MQFP52 [ (SA662+B042) ]

## ADVANCE GROUP

### E (E) PROM/FRAM/NVRAM

AF24BC01 [ (SA602A) ]	AF24BC01@SOIC8
AF24BC01@TSOP8 [ (SA026) ]	
AF24BC02	
AF24BC02@SOIC8 [ (SA602A) ] [ (SA026) ]	AF24BC02@TSOP8
AF24BC04 [ (SA602A) ]	AF24BC04@SOIC8
AF24BC04@TSOP8 [ (SA026) ]	
AF24BC08	
AF24BC08@SOIC8 [ (SA602A) ] [ (SA026) ]	AF24BC08@TSOP8
AF24BC16 [ (SA602A) ]	AF24BC16@SOIC8
AF24BC16@TSOP8 [ (SA026) ]	
AF24C128	
AF24C128@SOIC8 [ (SA602A) ] [ (SA026) ]	AF24C128@TSOP8
AF24C256 [ (SA602A) ]	AF24C256@SOIC8
AF24C256@TSOP8 [ (SA026) ]	
AF24C32	
AF24C32@SOIC8 [ (SA602A) ] [ (SA026) ]	AF24C32@TSOP8
AF24C64 [ (SA602A) ]	AF24C64@SOIC8
AF24C64@TSOP8 [ (SA026) ]	AF93C46

(08bit)	
AF93C46(08bit)@SOIC8 [(SA602A)]	AF93C46(08bit)@TSOP8
[(SA026)]	
AF93C46(16bit)	AF93C46(16bit)@SOIC8
[(SA602A)]	
AF93C46(16bit)@TSOP8 [(SA026)]	AF93C56
(08bit)	
AF93C56(08bit)@SOIC8 [(SA602A)]	AF93C56(08bit)@TSOP8
[(SA026)]	
AF93C56(16bit)	AF93C56(16bit)@SOIC8
[(SA602A)]	
AF93C56(16bit)@TSOP8 [(SA026)]	AF93C66
(08bit)	
AF93C66(08bit)@SOIC8 [(SA602A)]	AF93C66(08bit)@TSOP8
[(SA026)]	
AF93C66(16bit)	AF93C66(16bit)@SOIC8
[(SA602A)]	
AF93C66(16bit)@TSOP8 [(SA026)]	AF93C86
(08bit)	
AF93C86(08bit)@SOIC8 [(SA602A)]	AF93C86(08bit)@TSOP8
[(SA026)]	
AF93C86(16bit)	AF93C86(16bit)@SOIC8
[(SA602A)]	
AF93C86(16bit)@TSOP8 [(SA026)]	

## MICROCONTROLLER

A1000A2	A1000A2@PLCC44
[(SA244)]	
A1000A2@PQFP44 [(SA245A)]	
A1000A3	A1000A3@PQFP44
A1000A3@PLCC44 [(SA244)]	
[(SA245A)]	
AG1001@SDIP42 [(SA028)]	
AG88F516	AG88F516@PLCC44
AG88F516@LQFP44 [(SA245A)]	
[(SA244)]	
AG88F516@PQFP64 [(PEP+S616)]	AG88F92@PQFP64 [(PEP
+S616)]	
AG88F92@PQFP80 [(PEP+S640B)]	
AG89F516	AG89F516@PQFP44
AG89F516@PLCC44 [(SA244)]	



[ ( SA245A ) ]	
AG89F54	AG89F54@PLCC44
[ ( SA244 ) ]	
AG89F54@PQFP44 [ ( SA245A ) ]	
AG89P51	
AG89P51@PLCC44 [ ( SA244 ) ]	AG89P51@PQFP44
[ ( SA675 ) ]	
AG89P516	AG89P516@PLCC44
[ ( SA244 ) ]	
AG89P516@PQFP44 [ ( SA675 ) ]	
AG89P51A	
AG89P51A@PLCC44 [ ( SA244 ) ]	AG89P51A@PQFP44
[ ( SA675 ) ]	
AG89P52	AG89P52@PLCC44
[ ( SA244 ) ]	
AG89P52@PQFP44 [ ( SA675 ) ]	

## **AEROFLEX**

### **E ( E ) PROM / FRAM / NVRAM**

ACT-F128K32@PGA66 ( SAD ) [ ( PEP+S667+B6601 ) ]  
ACT-F512K32@PGA66 ( \* ) [ ( PEP+S667+B6601 ) ]

## **ALI(Acer)**

### **E ( E ) PROM / FRAM / NVRAM**

M8720	M8720@PLCC32
[ ( SA015A1T ) ]	

### **MICROCONTROLLER**

M6759  
M6759@PLCC44 [ordering number is marked above]  
M6759@TQFP44 [ordering number is marked above]

## **ALL 24 SERIES(ISP)**

**E (E) PROM/FRAM/NVRAM**24C01 (ISP) [ ISP-HEADER01 ]  
HEADER01 ]24C04 (ISP) [ ISP-HEADER01 ]  
HEADER01 ]24C128 (ISP) [ ISP-HEADER01 ]  
HEADER01 ]24C256 (ISP) [ ISP-HEADER01 ]  
HEADER01 ]

24C64 (ISP) [ ISP-HEADER01 ]

24C02 (ISP) [ ISP-

24C08 (ISP) [ ISP-

24C16 (ISP) [ ISP-

24C32 (ISP) [ ISP-

**ALLIANCE****E (E) PROM/FRAM/NVRAM**AS29F200@PSOP44 [ (SA638-B006) ]  
B005) ]AS29F200B@PSOP44 [ (SA638-B006) ]  
B005) ]AS29F200T@PSOP44 [ (SA638-B006) ]  
B005) ]

AS29F200@TSOP48 [ (SA247-

AS29F200B@TSOP48 [ (SA247-

AS29F200T@TSOP48 [ (SA247-

**ALTERA****E (E) PROM/FRAM/NVRAM**EPC1 (LC)@PLCC20 [ (SA001A) ]  
[ (SA001A) ]EPC1 (PC)  
(PI)EPC1441 (LC)@PLCC20 [ (SA001A) ]  
[ (SA001A) ]EPC1441 (PC)  
(PI)EPC1441 (TC)@TQFP32 [ (SA663) ]  
[ (SA663) ]

EPC16QC100@PQFP100 (\*) [ (TA017-B006) ]

EPC16QI100@PQFP100 (\*) [ (TA017-B006) ]

EPC1 (LI)@PLCC20

EPC1

EPC1441 (LI)@PLCC20

EPC1441

EPC1441 (TI)@TQFP32

EPC16UC88@BGA88 [(SA642A-B146A-Y096F001Y)]  
 EPC16UC88AA@BGA88 [(SA642A-B146A-Y096F001Y)]  
 EPC16UC88AB@BGA88 [(SA642A-B146A-Y096F001Y)]  
 EPC16UC88N@BGA88 [(SA642A-B146A-Y096F001Y)]  
 EPC16UI88AA@BGA88 [(SA642A-B146A-Y096F001Y)]  
 EPC2(LC)@PLCC20 [(SA001A)] EPC2(LI)@PLCC20  
 [(SA001A)]  
 EPC2(TC)@TQFP32 [(SA663)] EPC2(TI)@TQFP32  
 [(SA663)]  
 EPC4QC100@PQFP100(\*) [(TA017-B006)]  
 EPC4QC100N@PQFP100(\*) [(TA017-B006)]  
 EPC4QI100@PQFP100(\*) [(TA017-B006)]  
 EPC8QC100@PQFP100(\*) [(TA017-B006)]  
 EPC8QC100DM@PQFP100(\*) [(TA017-B006)]  
 EPC8QI100@PQFP100(\*) [(TA017-B006)]  
 EPCS16SI16@SOIC16 [(SA404)] EPCS16SI8N@SOIC8  
 [(SA602A)]  
 EPCS1SI8@SOIC8 [(SA602A)] EPCS4SI8@SOIC8  
 [(SA602A)]  
 EPCS64SI16@SOIC16 [(SA404)]

## PLD

EP1800@PLCC68 [(PEP+S414T)] EP1810@PLCC68 [(PEP  
 +S414T)]  
 EP1810T@PLCC68 [(PEP+S414T)] EP1830@PLCC68 [(PEP  
 +S414T)]  
 EP310 EP310@PLCC20  
 [(SA001A)]  
 EP320 EP320@PLCC20  
 [(SA001A)]  
 EP330 EP330@PLCC20  
 [(SA001A)]  
 EP600 EP600@PLCC28  
 [(SA008A)]  
 EP600@SOIC24 [(SA404)]  
 EP600I EP600I@SOIC24  
 EP600I@PLCC28 [(SA008A)] [(SA404)]  
 EP610 EP610@PLCC28  
 [(SA008A)]  
 EP610@SOIC24 [(SA404)]

EP610A

EP610A@PLCC28 [(SA008A)]  
[(SA404)]

EP610A@SOIC24

EP610I  
[(SA008A)]

EP610I@PLCC28

EP610I@SOIC24 [(SA404)]

EP610T

EP610T@PLCC28 [(SA008A)]  
[(SA404)]

EP610T@SOIC24

EP630  
[(SA008A)]

EP630@PLCC28

EP630@SOIC24 [(SA404)]

EP900

EP900@PLCC44 [(SA244)]

EP900I

EP900I@PLC44 [(SA244)]

EP910

EP910@PLCC44 [(SA244)]

EP910A

EP910A@PLCC44 [(SA244)]

EP910I

EP910I@PLCC44 [(SA244)]

EP910T

EP910T@PLCC44 [(SA244)]

EPM1270@FBGA256(\*) [(SA800-B209)]

EPM1270@FBGA256(ISP) [ISP-HEADER01]

EPM1270@TQFP144(\*) [(SA681-B14405)]

EPM1270@TQFP144(ISP) [ISP-HEADER01]

EPM1270ES@FBGA256(ISP) [ISP-HEADER01]

EPM1270ES@TQFP144(ISP) [ISP-HEADER01]

EPM1270G@FBGA256(\*) [(SA800-B209)]

EPM1270G@FBGA256(ISP) [ISP-HEADER01]

EPM1270G@TQFP144(\*) [(SA681-B14405)]

EPM1270G@TQFP144(ISP) [ISP-HEADER01]

EPM2210@FBGA256(\*) [(SA800-B209)]

EPM2210@FBGA256(ISP) [ISP-HEADER01]

EPM2210@FBGA324(ISP) [ISP-HEADER01]

EPM2210G@FBGA256(\*) [(SA800-B209)]

EPM2210G@FBGA256(ISP) [ISP-HEADER01]

EPM2210G@FBGA324(ISP) [ISP-HEADER01]

EPM240@FBGA100(\*) [(SA800B-B293-W100F001Y)]

EPM240@TQFP100 [(PEP+S604)]

EPM240@TQFP100(\*) [(TA053-

B006)]

EPM240@TQFP100 (ISP) [ISP-HEADER01]  
 EPM240G@FBGA100 (\*) [(SA800B-B293-W100F001Y)]  
 EPM240G@TQFP100 [(PEP+S604)]  
 EPM240G@TQFP100 (\*) [(TA053-B006)]  
 EPM240G@TQFP100 (ISP) [ISP-HEADER01]  
 EPM3032A@PLCC44 [(SA244)]  
 EPM3032A@PLCC44 (ISP) [ISP-HEADER01]  
 EPM3032A@TQFP44 [(SA245A)]  
 EPM3032A@TQFP44 (ISP) [ISP-HEADER01]  
 EPM3064A@PLCC44 [(SA244)] EPM3064A@TQFP100 [(PEP  
 +S604)]  
 EPM3064A@TQFP44 [(SA245A)]  
 EPM3128A@FBGA256 (ISP) [ISP-HEADER01]  
 EPM3128A@TQFP100 [(PEP-S604)]  
 EPM3128A@TQFP100 (\*) [(TA062-B006)]  
 EPM3128A@TQFP100 (ISP) [ISP-HEADER01]  
 EPM3128A@TQFP144 (\*) [(SA681-B14409)]  
 EPM3128A@TQFP144 (ISP) [ISP-HEADER01]  
 EPM3256A@PQFP208 (\*) [(TA078-B084)]  
 EPM3256A@PQFP208 (ISP) [ISP-HEADER01]  
 EPM3256A@TQFP144 (ISP) [ISP-HEADER01]  
 EPM3512A@FBGA256 (ISP) [ISP-HEADER01]  
 EPM3512A@PQFP208 (ISP) [ISP-HEADER01]  
 EPM5032A EPM5032A@PLCC28  
 [(SA008A)]  
 EPM5064A@PLCC44 [(SA244)] EPM5128A@PLCC68 [(PEP  
 +S414T)]  
 EPM5130A@PLCC84 [(PEP+S416T)] EPM5130A@PQFP100 [(PEP  
 +S427)]  
 EPM570@FBGA256 (\*) [(SA800-B209)]  
 EPM570@FBGA256 (ISP) [ISP-HEADER01]  
 EPM570@TQFP100 [(PEP+S604)] EPM570@TQFP100 (\*) [(TA053-  
 B006)]  
 EPM570@TQFP100 (ISP) [ISP-HEADER01]  
 EPM570@TQFP144 (\*) [(SA681-B14405)]  
 EPM570@TQFP144 (ISP) [ISP-HEADER01]  
 EPM570G@FBGA256 (\*) [(SA800-B209)]  
 EPM570G@FBGA256 (ISP) [ISP-HEADER01]  
 EPM570G@TQFP100 [(PEP+S604)]  
 EPM570G@TQFP100 (\*) [(TA053-B006)]  
 EPM570G@TQFP100 (ISP) [ISP-HEADER01]  
 EPM570G@TQFP144 (\*) [(SA681-B14405)]  
 EPM570G@TQFP144 (ISP) [ISP-HEADER01]

EPM7032@PLCC44 [(SA244)]		EPM7032@TQFP44
[(SA245A)]		
EPM7032AE@JLCC44 (7032 mode)	[(SA244)]	
EPM7032AE@PLCC44 (7032 mode)	[(SA244)]	
EPM7032AE@PLCC44 (7032AE mode)	[(SA244)]	
EPM7032AE@PLCC44 (7032S mode)	[(SA244)]	
EPM7032AE@PQFP44 (7032 mode)	[(SA245A)]	
EPM7032AE@TQFP44 (7032 mode)	[(SA245A)]	
EPM7032AE@TQFP44 (7032AE mode)	[(SA245A)]	
EPM7032AE@TQFP44 (7032S mode)	[(SA245A)]	
EPM7032B@FBGA49 (7032AEmode) (ISP)	[ISP-HEADER01]	
EPM7032B@FBGA49 (7032B mode) (ISP)	[ISP-HEADER01]	
EPM7032B@FBGA49 (7032S mode) (ISP)	[ISP-HEADER01]	
EPM7032B@PLCC44 (7032AE mode)	[(SA244)]	
EPM7032B@PLCC44 (7032B mode)	[(SA244)]	
EPM7032B@PLCC44 (7032S mode)	[(SA244)]	
EPM7032B@TQFP44 (7032AE mode)	[(SA245A)]	
EPM7032B@TQFP44 (7032B mode)	[(SA245A)]	
EPM7032B@TQFP44 (7032S mode)	[(SA245A)]	
EPM7032B@TQFP48 (7032AE mode)	[(SA248)]	
EPM7032B@TQFP48 (7032B mode)	[(SA248)]	
EPM7032B@TQFP48 (7032S mode)	[(SA248)]	
EPM7032S@PLCC44 (7032 mode)	[(SA244)]	
EPM7032S@PLCC44 (7032S mode)	[(SA244)]	
EPM7032S@TQFP44 (7032 mode)	[(SA245A)]	
EPM7032S@TQFP44 (7032S mode)	[(SA245A)]	
EPM7032V@PLCC44 [(SA244)]		EPM7032V@TQFP44
[(SA245A)]		
EPM7064@PLCC44 [(SA244)]		EPM7064@PLCC68 [(PEP
+S414T)]		
EPM7064@PLCC84 [(PEP+S416T)]		EPM7064@PQFP100 [(PEP
+S427)]		
EPM7064@TQFP44 [(SA245A)]		
EPM7064AE@FBGA100 (7064S) (ISP)	[ISP-HEADER01]	
EPM7064AE@FBGA100 (7064AE mode)	[(SA800+B325)]	
EPM7064AE@FBGA100 (7064AE) (ISP)	[ISP-HEADER01]	
EPM7064AE@FBGA100 (7064S mode)	[(SA800+B325)]	
EPM7064AE@PLCC44 (7064S) (ISP)	[ISP-HEADER01]	
EPM7064AE@PLCC44 (7064AE mode)	[(SA244)]	
EPM7064AE@PLCC44 (7064AE) (ISP)	[ISP-HEADER01]	
EPM7064AE@PLCC44 (7064S mode)	[(SA244)]	
EPM7064AE@PLCC84 (7064S) (ISP)	[ISP-HEADER01]	
EPM7064AE@PLCC84 (7064AE mode)	[(PEP+S416T)]	

EPM7064AE@PLCC84	(7064AE)	(ISP)	[ISP-HEADER01]
EPM7064AE@PLCC84	(7064S	mode)	[(PEP+S416T)]
EPM7064AE@TQFP100	(7064S)	(ISP)	[ISP-HEADER01]
EPM7064AE@TQFP100	(7064AE	mode)	[(PEP+S604)]
EPM7064AE@TQFP100	(7064AE)	(ISP)	[ISP-HEADER01]
EPM7064AE@TQFP100	(7064S	mode)	[(PEP+S604)]
EPM7064AE@TQFP44	(7064S)	(ISP)	[ISP-HEADER01]
EPM7064AE@TQFP44	(7064AE	mode)	[(SA245A)]
EPM7064AE@TQFP44	(7064AE)	(ISP)	[ISP-HEADER01]
EPM7064AE@TQFP44	(7064S	mode)	[(SA245A)]
EPM7064B@FBGA100	(7064B)	(ISP)	[ISP-HEADER01]
EPM7064B@FBGA100	(7064S)	(ISP)	[ISP-HEADER01]
EPM7064B@FBGA100	(7064AE)	(ISP)	[ISP-HEADER01]
EPM7064B@FBGA49	(7064B)	(ISP)	[ISP-HEADER01]
EPM7064B@FBGA49	(7064S)	(ISP)	[ISP-HEADER01]
EPM7064B@FBGA49	(7064AE)	(ISP)	[ISP-HEADER01]
EPM7064B@PLCC44	(7064AE	mode)	[(SA244)]
EPM7064B@PLCC44	(7064B	mode)	[(SA244)]
EPM7064B@PLCC44	(7064S	mode)	[(SA244)]
EPM7064B@TQFP100	(7064B)	(ISP)	[ISP-HEADER01]
EPM7064B@TQFP100	(7064S)	(ISP)	[ISP-HEADER01]
EPM7064B@TQFP100	(7064AE	mode)	[(PEP+S604)]
EPM7064B@TQFP100	(7064AE)	(ISP)	[ISP-HEADER01]
EPM7064B@TQFP100	(7064B	mode)	[(PEP+S604)]
EPM7064B@TQFP100	(7064S	mode)	[(PEP+S604)]
EPM7064B@TQFP44	(7064AE	mode)	[(SA245A)]
EPM7064B@TQFP44	(7064B	mode)	[(SA245A)]
EPM7064B@TQFP44	(7064S	mode)	[(SA245A)]
EPM7064B@TQFP48	(7064AE	mode)	[(SA248)]
EPM7064B@TQFP48	(7064B	mode)	[(SA248)]
EPM7064B@TQFP48	(7064S	mode)	[(SA248)]
EPM7064S@PLCC44	(7064	mode)	[(SA244)]
EPM7064S@PLCC44	(7064S	mode)	[(SA244)]
EPM7064S@PLCC68	(7064	mode)	[(PEP+S414T)]
EPM7064S@PLCC68	(7064S	mode)	[(PEP+S414T)]
EPM7064S@PLCC84	(7064	mode)	[(PEP+S416T)]
EPM7064S@PLCC84	(7064S	mode)	[(PEP+S416T)]
EPM7064S@PQFP100	(7064	mode)	[(PEP+S427)]
EPM7064S@PQFP100	(7064S	mode)	[(PEP+S427)]
EPM7064S@TQFP100	(7064	mode)	[(PEP+S604)]
EPM7064S@TQFP100	(7064S	mode)	[(PEP+S604)]
EPM7064S@TQFP44	(7064	mode)	[(SA245A)]
EPM7064S@TQFP44	(7064S	mode)	[(SA245A)]

EPM7096@PLCC68 [(PEP+S414T)]	EPM7096@PLCC84 [(PEP+S416T)]
EPM7096@PQFP100 [(PEP+S427)]	EPM7128A@PLCC84 [(PEP+S416T)]
EPM7128A@PLCC84 (7128E mode) [(PEP+S416T)]	
EPM7128A@PQFP100 [(PEP+S427)]	
EPM7128A@PQFP100 (7128E mode) [(PEP+S427)]	
EPM7128A@PQFP160(*)	EPM7128A@TQFP100 [(PEP+S604)]
EPM7128AE@FBGA100 (7128AE mode) [(SA800+B325)]	
EPM7128AE@PLCC44 (7128AE mode) [ordering number is marked above]	
EPM7128AE@PLCC84 (7128AE mode) [(PEP+S416T)]	
EPM7128AE@TQFP100 (7128AE mode) [(PEP+S604)]	
EPM7128AE@TQFP44 (7128AE mode) [ordering number is marked above]	
EPM7128B@TQFP100 (7128A mode) [(PEP+S604)]	
EPM7128B@TQFP100 (7128AE mode) [(PEP+S604)]	
EPM7128B@TQFP100 (7128B mode) [(PEP+S604)]	
EPM7128B@TQFP100 (7128S mode) [(PEP+S604)]	
EPM7128E@PLCC84 [(PEP+S416T)]	EPM7128E@PQFP100 [(PEP+S427)]
EPM7128E@PQFP160(*)	
EPM7128S@PLCC84 (7128E mode) [(PEP+S416T)]	
EPM7128S@PQFP100 [(PEP+S427)]	
EPM7128S@PQFP100 (7128E mode) [(PEP+S427)]	
EPM7128S@PQFP160(*)	EPM7128S@TQFP100 [(PEP+S604)]
EPM7128SLC84@PLCC84 [(PEP+S416T)]	
EPM7128SLI84@PLCC84 [(PEP+S416T)]	
EPM7160E@PLCC84 [(PEP+S416T)]	EPM7160E@PQFP100 [(PEP+S427)]
EPM7160E@PQFP160(*)	

## AMD

### E (E) PROM/FRAM/NVRAM

1736 [(SA602A)]	1736@SOIC8
1765 [(SA602A)]	1765@SOIC8
AM25FL005D@SOIC8 [(SA602A)]	AM25FL005D@USON8
[(SA683)]	



AM25FL010D@SOIC8 [(SA602A)]	AM25FL010D@USON8
[(SA683)]	
AM25FL016A@SOIC16 [(SA404)]	
AM25FL016A@SOIC16(ISP) [ISP-HEADER01]	
AM25FL016A@WSON8 [(SA684)]	
AM25FL016A@WSON8(ISP) [ISP-HEADER01]	
AM25FL020D@SOIC8 [(SA602A)]	AM25FL020D@USON8
[(SA683)]	
AM25FL032A@SOIC16 [(SA404)]	
AM25FL032A@SOIC16(ISP) [ISP-HEADER01]	
AM25FL032A@WSON8 [(SA684)]	
AM25FL032A@WSON8(ISP) [ISP-HEADER01]	
AM25FL040D@SOIC8 [(SA602A)]	AM25FL040D@USON8
[(SA683)]	
AM25FL080D@SOIC8 [(SA602A)]	AM25FL080D@USON8
[(SA683)]	
AM27128	AM27128
(DC)	
AM27128(DC)@PLCC32 [(SA015A1T)]	AM27128@PLCC32
[(SA015A1T)]	
AM27128A	AM27128A
(F)	
AM27128A(F)@PLCC32 [(SA015A1T)]	AM27128A
(PC)	
AM27128A(PC)@PLCC32 [(SA015A1T)]	AM27128A@PLCC32
[(SA015A1T)]	
AM2716	
AM2716B	
AM27256	AM27256@PLCC32
[(SA015A1T)]	
AM27256AP	AM27256AP@PLCC32
[(SA015A1T)]	
AM27256F	AM27256F@PLCC32
[(SA015A1T)]	
AM27256PC	AM27256PC@PLCC32
[(SA015A1T)]	
AM2732	
AM2732A	
AM2732B	
AM27512	
AM27512@PLCC32 [(SA015A1T)]	
AM27512DC	
AM27512DC@PLCC32 [(SA015A1T)]	

AM27512F	
AM27512F@PLCC32 [(SA015A1T)]	
AM27512PC	
AM27512PC@PLCC32 [(SA015A1T)]	
AM27513	
AM2764	AM2764@PLCC32
[(SA015A1T)]	
AM2764A	AM2764A
(DC)	
AM2764A(DC)@PLCC32 [(SA015A1T)]	AM2764A
(DCB)	
AM2764A(DI)	AM2764A
(DIB)	
AM2764A(F)	AM2764A(F)@PLCC32
[(SA015A1T)]	
AM2764A(JC)	AM2764A
(LC)	
AM2764A(LCB)	AM2764A
(LE)	
AM2764A(LEB)	AM2764A
(PC)	
AM2764A(PC)@PLCC32 [(SA015A1T)]	AM2764A@PLCC32
[(SA015A1T)]	
AM27C010	AM27C010@PLCC32
[(SA015A1T)]	
AM27C010@TSOP32 [(SA410T)]	
AM27C020	
AM27C020@PLCC32 [(SA015A1T)]	AM27C020@TSOP32
[(SA410T)]	
AM27C040	AM27C040@PLCC32
[(SA015A1T)]	
AM27C040@TSOP32 [(SA410T)]	
AM27C080	
AM27C080@PLCC32 [(SA015A1T)]	AM27C080@TSOP32
[(SA410T)]	
AM27C100	AM27C100@PLCC32
[(SA015A1T)]	
AM27C100@TSOP32 [(SA410T)]	
AM27C1024	
AM27C1024@PLCC44 [(SA244)]	
AM27C128	
AM27C128@PLCC32 [(SA015A1T)]	
AM27C2048	

AM27C2048@PLCC44 [(SA244)]	AM27C2048@TSOP40
[(SA409T)]	
AM27C256	AM27C256
(F)	
AM27C256(F)@PLCC32 [(SA015A1T)]	AM27C256
(PC)	
AM27C256(PC)@PLCC32 [(SA015A1T)]	AM27C256@PLCC32
[(SA015A1T)]	
AM27C400	AM27C400@PLCC44
[(SA244)]	
AM27C4096	AM27C4096@PLCC44
[(SA244)]	
AM27C512	AM27C512
(P)	
AM27C512(P)@PLCC32 [(SA015A1T)]	AM27C512@PLCC32
[(SA015A1T)]	
AM27C64	AM27C64@PLCC32
[(SA015A1T)]	
AM27H010	AM27H010@PLCC32
[(SA015A1T)]	
AM27H010@TSOP32 [(SA410T)]	
AM27H256	
AM27H256@PLCC32 [(SA015A1T)]	
AM27HB010	
AM27HB010@PLCC32 [(SA015A1T)]	AM27HB010@TSOP32
[(SA410T)]	
AM27LV010	AM27LV010@PLCC32
[(SA015A1T)]	
AM27LV010@TSOP32 [(SA410T)]	
AM27LV010B	
AM27LV010B@PLCC32 [(SA015A1T)]	AM27LV010B@TSOP32
[(SA410T)]	
AM27LV020	AM27LV020@PLCC32
[(SA015A1T)]	
AM27LV020@TSOP32 [(SA410T)]	
AM27LV020B	
AM27LV020B@PLCC32 [(SA015A1T)]	AM27LV020B@TSOP32
[(SA410T)]	
AM2816A	
AM2817A	
AM2817A@PLCC32 [(SA015A1T)]	AM2817A@SOIC28
[(SA404)]	
AM2864A	AM2864A

(E)	
AM2864A(E)@PLCC32 [(SA015A1T)]	AM2864A@PLCC32
[(SA015A1T)]	
AM2864B	AM2864B
(E)	
AM2864B(E)@PLCC32 [(SA015A1T)]	AM2864B@PLCC32
[(SA015A1T)]	
AM28F001	AM28F001@PLCC32
[(SA015A1T)]	
AM28F001@TSOP32 [(SA410T)]	
AM28F010	
AM28F010@PLCC32 [(SA015A1T)]	AM28F010@TSOP32
[(SA410T)]	
AM28F010A	AM28F010A@PLCC32
[(SA015A1T)]	
AM28F010A@TSOP32 [(SA410T)]	
AM28F020	
AM28F020@PLCC32 [(SA015A1T)]	AM28F020@TSOP32
[(SA410T)]	
AM28F020A	AM28F020A@PLCC32
[(SA015A1T)]	
AM28F020A@TSOP32 [(SA410T)]	
AM28F256	
AM28F256@PLCC32 [(SA015A1T)]	AM28F256@TSOP32
[(SA410T)]	
AM28F256A	AM28F256A@PLCC32
[(SA015A1T)]	
AM28F256A@TSOP32 [(SA410T)]	
AM28F512	
AM28F512(F)	AM28F512(F)@PLCC32
[(SA015A1T)]	
AM28F512(F)@TSOP32 [(SA410T)]	AM28F512@PLCC32
[(SA015A1T)]	
AM28F512@TSOP32 [(SA410T)]	
AM28F512A	
AM28F512A(F)	AM28F512A(F)@PLCC32
[(SA015A1T)]	
AM28F512A(F)@TSOP32 [(SA410T)]	AM28F512A@PLCC32
[(SA015A1T)]	
AM28F512A@TSOP32 [(SA410T)]	
AM29BL162CB@SSOP56 [(SA629A-B022)]	
AM29BL802CB@SSOP56 [(SA629A-B022)]	
AM29DL161DB@FBGA48 [(SA642B-B026A-Y072F001)]	

AM29DL161DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL161DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL161DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL161DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL161DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL161DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL161DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL161DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL161DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL162CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL162DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL162DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL162DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL162DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL162DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL162DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL162DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DB@FBGA48 [ ( SA642HH-B026A-T048F001Y ) ]  
AM29DL163DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL163DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL163DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163DT@FBGA48 [ ( SA642HH-B026A-T048F001Y ) ]  
AM29DL163DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL163DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL163DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]

AM29DL164DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL164DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL164DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL164DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GB@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL320GB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL320GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL320GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GT@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL320GT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL320GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL321CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL321CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322CB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322CT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL322GB@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL322GB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL322GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL322GT@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL322GT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL322GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323CB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323CT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]

AM29DL323DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323GB@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL323GB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL323GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323GT@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL323GT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL323GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL324DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL324DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL324GB@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL324GB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL324GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL324GT@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL324GT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL324GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL400BB@PSOP44 [ ( SA638-B006 ) ]  
AM29DL400BB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL400BT@PLCC44 [ ( SA638-B006 ) ]  
AM29DL400BT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL640D@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL640D@TSOP48 [ ( SA247-B005 ) ]  
AM29DL640G@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL640G@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL640G@TSOP48 [ ( SA247-B005 ) ]  
AM29DL642G@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL800B@PSOP44 [ ( SA638-B006 ) ]      AM29DL800B@TSOP48 [ ( SA247-B005 ) ]  
AM29DL800BB@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29DL800BB@PSOP44 [ ( SA638 ) ]  
AM29DL800BB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL800BT@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29DL800BT@PSOP44 [ ( SA638 ) ]  
AM29DL800BT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL800T@PSOP44 [ ( SA638-B006 ) ]      AM29DL800T@TSOP48 [ ( SA247-B005 ) ]

AM29DS163CB@TSOP48 [ (SA247-B005) ]  
AM29DS163CT@TSOP48 [ (SA247-B005) ]  
AM29DS163DB@FBGA48 [ (SA642B-B026A-Y072F001) ]  
AM29DS163DB@TSOP48 [ (SA247-B005) ]  
AM29DS163DT@FBGA48 [ (SA642B-B026A-Y072F001) ]  
AM29DS163DT@TSOP48 [ (SA247-B005) ]  
AM29DS323DB@FBGA48 [ (SA642B-B026A-Y072F001) ]  
AM29DS323DB@TSOP48 [ (SA247-B005) ]  
AM29DS323DT@FBGA48 [ (SA642B-B026A-Y072F001) ]  
AM29DS323DT@TSOP48 [ (SA247-B005) ]  
AM29F002B AM29F002B@PLCC32  
[ (SA015A1T) ]  
AM29F002B@TSOP32 [ (SA410T) ]  
AM29F002BB  
AM29F002BB@PLCC32 [ (SA015A1T) ] AM29F002BB@TSOP32  
[ (SA410T) ]  
AM29F002BT AM29F002BT@PLCC32  
[ (SA015A1T) ]  
AM29F002BT@TSOP32 [ (SA410T) ]  
AM29F002NB  
AM29F002NB@PLCC32 [ (SA015A1T) ] AM29F002NB@TSOP32  
[ (SA410T) ]  
AM29F002NBB AM29F002NBB@PLCC32  
[ (SA015A1T) ]  
AM29F002NBB@TSOP32 [ (SA410T) ]  
AM29F002NBT  
AM29F002NBT@PLCC32 [ (SA015A1T) ] AM29F002NBT@TSOP32  
[ (SA410T) ]  
AM29F002NT AM29F002NT@PLCC32  
[ (SA015A1T) ]  
AM29F002NT@TSOP32 [ (SA410T) ]  
AM29F002T  
AM29F002T@PLCC32 [ (SA015A1T) ] AM29F002T@TSOP32  
[ (SA410T) ]  
AM29F004BB@PLCC32 [ (SA015A1T) ] AM29F004BB@TSOP32  
[ (SA410T) ]  
AM29F004BT@PLCC32 [ (SA015A1T) ] AM29F004BT@TSOP32  
[ (SA410T) ]  
AM29F010 AM29F010@PLCC32  
[ (SA015A1T) ]  
AM29F010@TSOP32 [ (SA410T) ]  
AM29F010A  
AM29F010A@PLCC32 [ (SA015A1T) ] AM29F010A@TSOP32



[ (SA410T) ]	
AM29F010B	AM29F010B@PLCC32
[ (SA015A1T) ]	
AM29F010B@TSOP32 [ (SA410T) ]	AM29F016@PSOP44
[ (SA638) ]	
AM29F016@TSOP40 [ (SA409T) ]	AM29F016@TSOP48 [ (SA247-B005) ]
AM29F016B(REVERSE)@TSOP48 [ (SA247-B005) ]	
AM29F016B@PSOP44 [ (SA638) ]	AM29F016B@TSOP40
[ (SA409T) ]	
AM29F016B@TSOP48 [ (SA247-B005) ]	
AM29F016D(REVERSE)@TSOP48 [ (SA247-B005) ]	
AM29F016D@PSOP44 [ (SA638) ]	AM29F016D@TSOP40
[ (SA409T) ]	
AM29F016D@TSOP48 [ (SA247-B005) ]	AM29F017B@TSOP48 [ (SA247-B005) ]
AM29F017D@TSOP40 [ (SA409T) ]	AM29F017D@TSOP48 [ (SA247-B005) ]
AM29F032B@PSOP44 [ (SA638) ]	AM29F032B@TSOP40
[ (SA409T) ]	
AM29F040	AM29F040@PLCC32
[ (SA015A1T) ]	
AM29F040@TSOP32 [ (SA410T) ]	
AM29F040A	
AM29F040A@PLCC32 [ (SA015A1T) ]	AM29F040A@TSOP32
[ (SA410T) ]	
AM29F040B	
AM29F040B(Reverse)@TSOP32 [ (SA410T) ]	
AM29F040B@PLCC32 [ (SA015A1T) ]	AM29F040B@TSOP32
[ (SA410T) ]	
AM29F080@PSOP44 [ (SA638) ]	AM29F080@TSOP40
[ (SA409T) ]	
AM29F080B@PSOP44 [ (SA638) ]	AM29F080B@TSOP40
[ (SA409T) ]	
AM29F100BE@PSOP44 [ (SA638-B006) ]	AM29F100BE@TSOP48 [ (SA247-B005) ]
AM29F100BS@PSOP44 [ (SA638-B006) ]	AM29F100BS@TSOP48 [ (SA247-B005) ]
AM29F100TE@PSOP44 [ (SA638-B006) ]	AM29F100TE@TSOP48 [ (SA247-B005) ]
AM29F100TS@PSOP44 [ (SA638-B006) ]	AM29F100TS@TSOP48 [ (SA247-B005) ]
AM29F160DB@TSOP48 [ (SA247-B005) ]	AM29F160DT@TSOP48 [ (SA247-

B005) ]  
AM29F200AB@PSOP44 [ ( SA638-B006 ) ] AM29F200AB@TSOP48 [ ( SA247-  
B005 ) ]  
AM29F200AT@PSOP44 [ ( SA638-B006 ) ] AM29F200AT@TSOP48 [ ( SA247-  
B005 ) ]  
AM29F200BB@PSOP44 [ ( SA638-B006 ) ] AM29F200BB@TSOP48 [ ( SA247-  
B005 ) ]  
AM29F200BE@PSOP44 [ ( SA638-B006 ) ] AM29F200BE@TSOP48 [ ( SA247-  
B005 ) ]  
AM29F200BS@PSOP44 [ ( SA638-B006 ) ] AM29F200BS@TSOP48 [ ( SA247-  
B005 ) ]  
AM29F200BT@PSOP44 [ ( SA638-B006 ) ] AM29F200BT@TSOP48 [ ( SA247-  
B005 ) ]  
AM29F200TE@PSOP44 [ ( SA638-B006 ) ] AM29F200TE@TSOP48 [ ( SA247-  
B005 ) ]  
AM29F200TS@PSOP44 [ ( SA638-B006 ) ] AM29F200TS@TSOP48 [ ( SA247-  
B005 ) ]  
AM29F400AB@PSOP44 [ ( SA638-B006 ) ] AM29F400AB@TSOP48 [ ( SA247-  
B005 ) ]  
AM29F400AT@PSOP44 [ ( SA638-B006 ) ] AM29F400AT@TSOP48 [ ( SA247-  
B005 ) ]  
AM29F400BB@PSOP44 [ ( SA638-B006 ) ] AM29F400BB@TSOP48 [ ( SA247-  
B005 ) ]  
AM29F400BBE@PSOP44 [ ( SA638-B006 ) ]  
AM29F400BBE@TSOP48 [ ( SA247-B005 ) ]  
AM29F400BBF@PSOP44 [ ( SA638-B006 ) ]  
AM29F400BBF@TSOP48 [ ( SA247-B005 ) ]  
AM29F400BBS@PSOP44 [ ( SA638-B006 ) ]  
AM29F400BBS@TSOP48 [ ( SA247-B005 ) ]  
AM29F400BE@PSOP44 [ ( SA638-B006 ) ] AM29F400BE@TSOP48 [ ( SA247-  
B005 ) ]  
AM29F400BF@PSOP44 [ ( SA638-B006 ) ] AM29F400BF@TSOP48 [ ( SA247-  
B005 ) ]  
AM29F400BS@PSOP44 [ ( SA638-B006 ) ] AM29F400BS@TSOP48 [ ( SA247-  
B005 ) ]  
AM29F400BT@PSOP44 [ ( SA638-B006 ) ] AM29F400BT@TSOP48 [ ( SA247-  
B005 ) ]  
AM29F400BTE@PSOP44 [ ( SA638-B006 ) ]  
AM29F400BTE@TSOP48 [ ( SA247-B005 ) ]  
AM29F400BTF@PSOP44 [ ( SA638-B006 ) ]  
AM29F400BTF@TSOP48 [ ( SA247-B005 ) ]  
AM29F400BTS@PSOP44 [ ( SA638-B006 ) ]  
AM29F400BTS@TSOP48 [ ( SA247-B005 ) ]

AM29F800B@PSOP44 [(SA638-B006) ] B005) ]	AM29F800B@TSOP48 [(SA247-
AM29F800BB@PSOP44 [(SA638-B006) ] B005) ]	AM29F800BB@TSOP48 [(SA247-
AM29F800BBF@PSOP44 [(SA638-B006) ]	
AM29F800BBF@TSOP48 [(SA247-B005) ]	
AM29F800BF@PSOP44 [(SA638-B006) ] B005) ]	AM29F800BF@TSOP48 [(SA247-
AM29F800BT@PSOP44 [(SA638-B006) ] B005) ]	AM29F800BT@TSOP48 [(SA247-
AM29F800BTF@PSOP44 [(SA638-B006) ]	
AM29F800BTF@TSOP48 [(SA247-B005) ]	
AM29F800T@PSOP44 [(SA638-B006) ] B005) ]	AM29F800T@TSOP48 [(SA247-
AM29F800TB@PSOP44 [(SA638-B006) ] B005) ]	AM29F800TB@TSOP48 [(SA247-
AM29F800TF@PSOP44 [(SA638-B006) ] B005) ]	AM29F800TF@TSOP48 [(SA247-
AM29LL800B@TSOP48 [(SA247-B005) ]	
AM29LL800BB@TSOP48 [(SA247-B005) ]	
AM29LL800BT@TSOP48 [(SA247-B005) ]	
AM29LL800T@TSOP48 [(SA247-B005) ] [(SA015A1T) ]	AM29LV001BB@PLCC32
AM29LV001BB@TSOP32 [(SA410T) ] [(SA015A1T) ]	AM29LV001BT@PLCC32
AM29LV001BT@TSOP32 [(SA410T) ] [(SA409T) ]	AM29LV002@TSOP40
AM29LV002B@TSOP40 [(SA409T) ] [(SA409T) ]	AM29LV002BB@TSOP40
AM29LV002BT@TSOP40 [(SA409T) ] [(SA638) ]	AM29LV004B@PSOP44
AM29LV004B@TSOP40 [(SA409T) ] [(SA409T) ]	AM29LV004BB@TSOP40
AM29LV004BT@TSOP40 [(SA409T) ] [(SA638) ]	AM29LV004T@PSOP44
AM29LV004T@TSOP40 [(SA409T) ] [(SA638) ]	AM29LV008B@PSOP44
AM29LV008B@TSOP40 [(SA409T) ] [(SA409T) ]	AM29LV008BB@TSOP40
AM29LV008BT@TSOP40 [(SA409T) ] [(SA638) ]	AM29LV008T@PSOP44
AM29LV008T@TSOP40 [(SA409T) ] [(SA015A1T) ]	AM29LV010B@PLCC32

AM29LV010B@TSOP32 [ (SA410T) ] AM29LV017B@TSOP40  
[ (SA409T) ]  
AM29LV017D@FBGA48 [ (SA642B-B026A-Y072F001) ]  
AM29LV017D@TSOP40 [ (SA409T) ] AM29LV020B@PLCC32  
[ (SA015A1T) ]  
AM29LV020B@TSOP32 [ (SA410T) ]  
AM29LV033C@FBGA63 [ (SA642A-B026A-Y096N001) ]  
AM29LV033C@TSOP40 [ (SA409T) ]  
AM29LV033MU@FBGA48 [ (SA642B-B026A-Y072F001) ]  
AM29LV033MU@TSOP40 [ (SA409T) ] AM29LV040B@PLCC32  
[ (SA015A1T) ]  
AM29LV040B@TSOP32 [ (SA410T) ] AM29LV040E@PLCC32  
[ (SA015A1T) ]  
AM29LV040E@TSOP32 [ (SA410T) ] AM29LV040J@PLCC32  
[ (SA015A1T) ]  
AM29LV040J@TSOP32 [ (SA410T) ]  
AM29LV065D@FBGA63 [ (SA642C-B026A-Y056F001) ]  
AM29LV065D@TSOP48 [ (SA247-B005) ]  
AM29LV065MU@FBGA63 [ (SA642C-B026A-Y056F001) ]  
AM29LV065MU@TSOP48 [ (SA247-B005) ]  
AM29LV080@TSOP40 [ (SA409T) ] AM29LV081@TSOP40  
[ (SA409T) ]  
AM29LV081B@TSOP40 [ (SA409T) ] AM29LV116BB@TSOP40  
[ (SA409T) ]  
AM29LV116BT@TSOP40 [ (SA409T) ] AM29LV116DB@TSOP40  
[ (SA409T) ]  
AM29LV116DT@TSOP40 [ (SA409T) ]  
AM29LV128MH@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
AM29LV128MH@TSOP56 [ (SA628-B067) ]  
AM29LV128ML@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
AM29LV128ML@TSOP56 [ (SA628-B067) ]  
AM29LV160BB@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
AM29LV160BB@PSOP44 [ (SA638) ]  
AM29LV160BB@TSOP48 [ (SA247-B005) ]  
AM29LV160BT@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
AM29LV160BT@PSOP44 [ (SA638) ]  
AM29LV160BT@TSOP48 [ (SA247-B005) ]  
AM29LV160DB(REVERSE)@TSOP48 [ (SA247-B005) ]  
AM29LV160DB@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
AM29LV160DB@PSOP44 [ (SA638) ]  
AM29LV160DB@TSOP48 [ (SA247-B005) ]  
AM29LV160DT(REVERSE)@TSOP48 [ (SA247-B005) ]  
AM29LV160DT@FBGA48 [ (SA642B-B026A-Y072F001N) ]

AM29LV160DT@PSOP44 [ ( SA638 ) ]  
AM29LV160DT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160MB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29LV160MB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV160MB@PSOP44 [ ( SA638 ) ]  
AM29LV160MB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160MT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29LV160MT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV160MT@PSOP44 [ ( SA638 ) ]  
AM29LV160MT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200B@PSOP44 [ ( SA638-B006 ) ]      AM29LV200B@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BB@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BE@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BE@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BF@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BF@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BS@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BS@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BT@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200T@PSOP44 [ ( SA638-B006 ) ]      AM29LV200T@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TE@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200TE@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TF@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200TF@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TS@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200TS@TSOP48 [ ( SA247-B005 ) ]  
AM29LV256MH@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
AM29LV256MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV256ML@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
AM29LV256ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320DB@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29LV320DB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320DT@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29LV320DT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320FB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320FT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320MB@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AM29LV320MB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV320MB@TSOP48 [ ( SA247-B005 ) ]

AM29LV320MH@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV320MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320ML@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV320ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320MT@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AM29LV320MT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV320MT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400B@PSOP44 [ ( SA638-B006 ) ]      AM29LV400B@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400BB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29LV400BB@PSOP44 [ ( SA638-B006 ) ]  
AM29LV400BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400BT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29LV400BT@PSOP44 [ ( SA638-B006 ) ]  
AM29LV400BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400T@PSOP44 [ ( SA638-B006 ) ]      AM29LV400T@TSOP48 [ ( SA247-B005 ) ]  
AM29LV640DH@SSOP56 [ ( SA629A-B020 ) ]  
AM29LV640DL@SSOP56 [ ( SA629A-B020 ) ]  
AM29LV640DU@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640DU@FBGA64 [ ( SA655D-B044A-W064F001 ) ]  
AM29LV640GU@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640GU@FBGA64 [ ( SA655D-B044A-W064F001 ) ]  
AM29LV640MB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29LV640MB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV640MB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV640MH@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV640MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV640ML@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV640ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV640MT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29LV640MT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV640MT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV640MU@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29LV640MU@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV641DH@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641DHR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641DL@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641DLR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GH@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GHR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GL@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GLR@TSOP48 [ ( SA247-B005 ) ]

AM29LV641MH@TSOP48 [ (SA247-B005) ]  
AM29LV641ML@TSOP48 [ (SA247-B005) ]  
AM29LV642G@FBGA64 [ (SA655A-B038A-T064N001) ]  
AM29LV652D@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
AM29LV800B@PSOP44 [ (SA638-B006) ]      AM29LV800B@TSOP48 [ (SA247-B005) ]  
AM29LV800BB@FBGA48 [ (SA642N-B026A-W048F001Y) ]  
AM29LV800BB@PSOP44 [ (SA638-B006) ]  
AM29LV800BB@TSOP48 [ (SA247-B005) ]  
AM29LV800BT@FBGA48 [ (SA642N-B026A-W048F001Y) ]  
AM29LV800BT@PSOP44 [ (SA638-B006) ]  
AM29LV800BT@TSOP48 [ (SA247-B005) ]  
AM29LV800DB(WB)@FBGA48 [ (SA642N-B026A-W048F001Y) ]  
AM29LV800DB(WC)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
AM29LV800DB@PSOP44 [ (SA638) ]  
AM29LV800DB@TSOP48 [ (SA247-B005) ]  
AM29LV800DT(WB)@FBGA48 [ (SA642N-B026A-W048F001Y) ]  
AM29LV800DT(WC)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
AM29LV800DT@PSOP44 [ (SA638) ]  
AM29LV800DT@TSOP48 [ (SA247-B005) ]  
AM29LV800T@PSOP44 [ (SA638-B006) ]      AM29LV800T@TSOP48 [ (SA247-B005) ]  
AM29N163DT@FBGA47 [ (SA733A-B206A-M056F001N) ]  
AM29N323DT@FBGA47 [ (SA733A-B206A-M056F001N) ]  
AM29N643GT@FBGA44 [ (SA733A-B206A-M056F001Y) ]  
AM29PDS322DB@FBGA48 [ (SA642E-B026A-T072F001) ]  
AM29PDS322DT@FBGA48 [ (SA642E-B026A-T072F001) ]  
AM29PL160CB@PSOP44 [ (SA638-B006) ]  
AM29PL160CB@TSOP48 [ (SA247-B005) ]  
AM29PL160CT@PSOP44 [ (SA638-B006) ]  
AM29PL160CT@TSOP48 [ (SA247-B005) ]  
AM29SL160CB@FBGA48 [ (SA642B-B026A-Y072F001) ]  
AM29SL160CB@TSOP48 [ (SA247-B005) ]  
AM29SL160CT@FBGA48 [ (SA642B-B026A-Y072F001) ]  
AM29SL160CT@TSOP48 [ (SA247-B005) ]  
AM29SL400CB@TSOP48 [ (SA247-B005) ]  
AM29SL400CT@TSOP48 [ (SA247-B005) ]  
AM29SL800BB@TSOP48 [ (SA247-B005) ]  
AM29SL800BT@TSOP48 [ (SA247-B005) ]  
AM29SL800CB@TSOP48 [ (SA247-B005) ]  
AM29SL800CT@TSOP48 [ (SA247-B005) ]  
AM29SL800DB@TSOP48 [ (SA247-B005) ]  
AM29SL800DBUF@FBGA48 [ (SA716A-B119B-M048F001Y) ]

AM29SL800DBVG@FBGA48 [(SA716A-B119B-M048F001Y)]  
AM29SL800DBVU@FBGA48 [(SA642Z-B026A-W048F001Y)]  
AM29SL800DBWA@FBGA48 [(SA642G-B026A-T048F001Y)]  
AM29SL800DBWC@FBGA48 [(SA642R-B026A-W080F001N)]  
AM29SL800DT@TSOP48 [(SA247-B005)]  
AM29SL800DTUF@FBGA48 [(SA716A-B119B-M048F001Y)]  
AM29SL800DTV@FBGA48 [(SA716A-B119B-M048F001Y)]  
AM29SL800DTVU@FBGA48 [(SA642Z-B026A-W048F001Y)]  
AM29SL800DTWA@FBGA48 [(SA642G-B026A-T048F001Y)]  
AM29SL800DTWC@FBGA48 [(SA642R-B026A-W080F001N)]  
AM9716  
AM9732  
AM9732A  
AM9764  
AM9764@PLCC32 [(SA015A1T)]  
BS128HD8V(AM29BDS128HD)@FBGA80 [(SA642A-B080A-Y096N001)]  
BS128HD9V(AM29BDS128HD)@FBGA80 [(SA642A-B080A-Y096N001)]  
BS128HE8V(AM29BDS128HE)@FBGA80 [(SA642A-B080A-Y096N001)]  
BS128HE9V(AM29BDS128HE)@FBGA80 [(SA642A-B080A-Y096N001)]  
BS128HF8V(AM29BDS128HF)@FBGA80 [(SA642A-B080A-Y096N001)]  
BS128HF9V(AM29BDS128HF)@FBGA80 [(SA642A-B080A-Y096N001)]  
BS640HD8V(AM29BDS640HD)@FBGA64 [(SA642A-B080A-Y096F001)]  
BS640HD9V(AM29BDS640HD)@FBGA64 [(SA642A-B080A-Y096F001)]  
BS640HE8V(AM29BDS640HE)@FBGA64 [(SA642A-B080A-Y096F001)]  
BS640HE9V(AM29BDS640HE)@FBGA64 [(SA642A-B080A-Y096F001)]  
BS640HF8V(AM29BDS640HF)@FBGA64 [(SA642A-B080A-Y096F001)]  
BS640HF9V(AM29BDS640HF)@FBGA64 [(SA642A-B080A-Y096F001)]  
DS42514(AM29DL163DB)@FBGA69 [(SA642B-B032A-Y072F001)]  
DS42515(AM29DL164)@FBGA69 [(SA642B-B032A-Y072F001)]  
DS42516(AM29DL324)@FBGA73 [(SA642A-B032A-Y096F001)]  
DS42546(AM29DL163)@FBGA69 [(SA642B-B032A-Y072F001)]  
DS42553(AM29DL323)@FBGA73 [(SA642A-B032A-Y096F001)]  
DS42585(AM29DL323D)@FBGA73 [(SA642A-B032A-Y096F001)]  
DS42587(AM29DL324D)@FBGA73 [(SA642A-B032A-Y096F001)]  
DS42629(AM29DL640G)@VFBGA48 [(SA634A-B005A-Y048F001)]  
DS42677(AM29LV128MH/L)@FBGA88 [(SA642A-B058A-Y096N001)]  
DS42678(AM29LV320MT)@FBGA67 [(SA642E-B041A-T072F001)]  
DS42689(AM29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
DS42690(AM29LV320MB)@FBGA64 [(SA655E-B090A-T064F001Y)]  
DS42695(AM29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
DS42696(AM29LV320MB)@FBGA64 [(SA655F-B099A-W064F001Y)]  
DS42701(AM29LV640MU)@FBGA88 [(SA642W-B116A-W088F001Y)]  
DS42725(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]



DS42772A(AM29LV640M)@FBGA88 [(SA642W-B116A-W088F001Y)]  
M410000000(AM41DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000001(AM41DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000002(AM41DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000003(AM41DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000004(AM41DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000005(AM41DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000006(AM41DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000007(AM41DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000008(AM41DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000009(AM41DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000A(AM41DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000B(AM41DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000C(AM41DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000D(AM41DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000E(AM41DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000F(AM41DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000G(AM41DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000000H(AM41DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000001W(AM41DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000001X(AM41DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000001Y(AM41DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000001Z(AM41DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000020(AM41DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000021(AM41DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000022(AM41DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000023(AM41DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000024(AM41DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000025(AM41DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000026(AM41DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000027(AM41DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002L(AM41DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002M(AM41DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002N(AM41DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002O(AM41DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002P(AM41DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002Q(AM41DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002R(AM41DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002S(AM41DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002T(AM41DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002U(AM41DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002V(AM41DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002W(AM41DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]

M41000003D (AM41DL3208GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M41000003E (AM41DL3208GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M41000003F (AM41DL3208GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M41000003G (AM41DL3208GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M410000095 (AM41LV3204MT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M410000096 (AM41LV3204MB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M41000009B (AM41DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M41000009C (AM41DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M41000009D (AM41DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000000 (AM42DL640AG)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000001 (AM42DL640AG)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000004 (AM42DL1642DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M420000005 (AM42DL1642DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M420000006 (AM42DL1642DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M420000007 (AM42DL1642DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000I (AM42DL1612DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000J (AM42DL1612DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000K (AM42DL1612DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000L (AM42DL1612DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000M (AM42DL1622DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000N (AM42DL1622DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000O (AM42DL1622DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000P (AM42DL1622DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000Q (AM42DL1632DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000R (AM42DL1632DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000S (AM42DL1632DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000T (AM42DL1632DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000U (AM42DL1642DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000V (AM42DL1642DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000W (AM42DL1642DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000X (AM42DL1642DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001A (AM42DL1614DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001B (AM42DL1614DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001C (AM42DL1614DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001D (AM42DL1614DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001E (AM42DL1624DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001F (AM42DL1624DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001G (AM42DL1624DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001H (AM42DL1624DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001I (AM42DL1634DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001J (AM42DL1634DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001K (AM42DL1634DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001L (AM42DL1634DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]

M42000001M (AM42DL1644DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001N (AM42DL1644DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001O (AM42DL1644DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001P (AM42DL1644DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M420000022 (AM42DL3224GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000023 (AM42DL3224GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000024 (AM42DL3224GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000025 (AM42DL3224GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000026 (AM42DL3234GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000027 (AM42DL3234GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000028 (AM42DL3234GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000029 (AM42DL3234GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M42000002A (AM42DL3244GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M42000002B (AM42DL3244GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M42000002C (AM42DL3244GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M42000002D (AM42DL3244GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M42000002U (AM42DL6404G)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M42000002V (AM42DL6404G)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M42000002Y (AM42BDS6408GT)@FBGA93 [ ( SA642A-B072A-Y096F001 ) ]  
M42000002Z (AM42BDS6408GB)@FBGA93 [ ( SA642A-B072A-Y096F001 ) ]  
M420000030 (AM42BDS6408GT)@FBGA93 [ ( SA642A-B072A-Y096F001 ) ]  
M420000031 (AM42BDS6408GB)@FBGA93 [ ( SA642A-B072A-Y096F001 ) ]  
M420000032 (AM42BDS6408GT)@FBGA93 [ ( SA642A-B072A-Y096F001 ) ]  
M420000033 (AM42BDS6408GB)@FBGA93 [ ( SA642A-B072A-Y096F001 ) ]  
M420000034 (AM42BDS6408GT)@FBGA93 [ ( SA642A-B072A-Y096F001 ) ]  
M420000035 (AM42BDS6408GB)@FBGA93 [ ( SA642A-B072A-Y096F001 ) ]  
M42000004Y (AM42BDS640AGT)@FBGA93 [ ( SA642A-B072A-Y096F001 ) ]  
M42000004Z (AM42BDS640AGB)@FBGA93 [ ( SA642A-B072A-Y096F001 ) ]  
M420000050 (AM42BDS640AGT)@FBGA93 [ ( SA642A-B072A-Y096F001 ) ]  
M420000051 (AM42BDS640AGB)@FBGA93 [ ( SA642A-B072A-Y096F001 ) ]  
M420000052 (AM42BDS640AGT)@FBGA93 [ ( SA642A-B072A-Y096F001 ) ]  
M420000053 (AM42BDS640AGB)@FBGA93 [ ( SA642A-B072A-Y096F001 ) ]  
M420000054 (AM42BDS640AGT)@FBGA93 [ ( SA642A-B072A-Y096F001 ) ]  
M420000055 (AM42BDS640AGB)@FBGA93 [ ( SA642A-B072A-Y096F001 ) ]  
M42000005M (AM42DL6402G)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M42000005N (AM42DL6402G)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M42000005W (AM42DL3224GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M42000005X (AM42DL3224GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M42000005Y (AM42DL3234GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M42000005Z (AM42DL3234GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000060 (AM42DL3244GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000061 (AM42DL3244GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000070 (AM42BDS6408HE8)@BGA89 [ ( SA642A-B072A-Y096F001 ) ]

M420000071 (AM42BDS6408HE9)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000072 (AM42BDS6408HD8)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000073 (AM42BDS6408HD9)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000074 (AM42BDS6408HE3)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000075 (AM42BDS6408HE4)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000076 (AM42BDS6408HD3)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000077 (AM42BDS6408HD4)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000078 (AM42DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000079 (AM42DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000000 (AM45DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000001 (AM45DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000008 (AM45DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000009 (AM45DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000A (AM45DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000B (AM45DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000S (AM45DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000T (AM45DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000U (AM45DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000V (AM45DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001C (AM45DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001D (AM45DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001E (AM45DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001F (AM45DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001W (AM45DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001X (AM45DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001Y (AM45DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001Z (AM45DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M490000000 (AM49DL640BG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M490000001 (AM49DL640BG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000G (AM49DL320BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000H (AM49DL320BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000J (AM49DL322BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000K (AM49DL322BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000L (AM49DL322BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000M (AM49DL322BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000N (AM49DL323BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000O (AM49DL323BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000P (AM49DL323BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000Q (AM49DL323BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000R (AM49DL324BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000S (AM49DL324BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000T (AM49DL324BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000U (AM49DL324BGB)@FBGA73 [(SA642A-B032A-Y096F001)]

M49000001A (AM49DL320BGB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000001B (AM49DL320BGB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000001Y (AM49PDL640AG)@FBGA73 [ ( SA642A-B032A-Y096N001 ) ]  
M49000001Z (AM49PDL640AG)@FBGA73 [ ( SA642A-B032A-Y096N001 ) ]  
M490000025 (AM49DL640AG)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M490000026 (AM49DL640AG)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M490000028 (AM49PDL127BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M490000029 (AM49PDL127BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M49000002I (AM49PDL127AH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M49000002J (AM49PDL127AH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M49000002T (AM49LV6408MT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000002U (AM49LV6408MB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000002V (AM49LV6408MT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000002X (AM49LV6408MB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M490000030 (AM49PDL129BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M490000031 (AM49PDL129BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M490000032 (AM49DL3208GB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M490000032 (AM49DL3208GT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M490000034 (AM49DL3208GT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M490000035 (AM49DL3208GB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003A (AM49DL640BH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003B (AM49DL640BH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003C (AM49DL640BH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003D (AM49DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003E (AM49DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003F (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003G (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003H (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003I (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003J (AM49DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003X (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003Y (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003Z (AM49LV6408MT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000004A (AM49LV6408MB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000004B (AM49BDS640AH)@FBGA89 [ ( SA642A-B072A-Y096F001 ) ]  
M49000004C (AM49BDS640AH)@FBGA89 [ ( SA642A-B072A-Y096F001 ) ]  
M49000004D (AM49BDS640AH)@FBGA89 [ ( SA642A-B072A-Y096F001 ) ]  
M49000004E (AM49BDS640AH)@FBGA89 [ ( SA642A-B072A-Y096F001 ) ]  
M49000004H (AM49LV128BMH)@FBGA64 [ ( SA642C-B039A-Y056F001 ) ]  
M49000004J (AM49LV128BML)@FBGA64 [ ( SA642C-B039A-Y056F001 ) ]  
M49000004K (AM49LV128BMH)@FBGA64 [ ( SA642C-B039A-Y056F001 ) ]  
M49000004L (AM49LV128BML)@FBGA64 [ ( SA642C-B039A-Y056F001 ) ]  
M49000004S (AM49LV128BMaH)@FBGA64 [ ( SA642C-B039A-Y056F001 ) ]

M49000004T(AM49LV128BMaL)@FBGA64 [(SA642C-B039A-Y056F001)]  
 M49000004U(AM49LV128BMaH)@FBGA64 [(SA642C-B039A-Y056F001)]  
 M49000004V(AM49LV128BMaL)@FBGA64 [(SA642C-B039A-Y056F001)]  
 M4900000K(AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
 M4900000L(AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
 M500000000(AM50DL128BG)@FBGA73 [(SA642A-B039A-Y096F001)]  
 M500000001(AM50DL128BG)@FBGA73 [(SA642A-B039A-Y096F001)]  
 M500000008(AM50DL128CG)@FBGA88 [(SA642A-B062A-Y096F001)]  
 M500000009(AM50DL128CG)@FBGA88 [(SA642A-B062A-Y096F001)]  
 M50000004J(AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
 M50000004K(AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
 M50000004L(AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
 M50000004M(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
 M50000004N(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
 M50000004P(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
 M550000000(AM55DL128C8G)@FBGA93 [(SA642A-B078A-Y096N001)]  
 M550000001(AM55DL128C8G)@FBGA93 [(SA642A-B078A-Y096N001)]  
 PDL127H53V(AM29PDL127H53)@FBGA80 [(SA642A-B070A-Y096N001)]  
 PDL127H63V(AM29PDL127H63)@FBGA80 [(SA642A-B070A-Y096N001)]  
 PDL127H68V(AM29PDL127H68)@FBGA80 [(SA642A-B070A-Y096N001)]  
 PDL127H88V(AM29PDL127H88)@FBGA80 [(SA642A-B070A-Y096N001)]  
 PDL129H53V(AM29PDL129H53)@FBGA80 [(SA642A-B070A-Y096N001)]  
 PDL129H63V(AM29PDL129H63)@FBGA80 [(SA642A-B070A-Y096N001)]  
 PDL129H68V(AM29PDL129H68)@FBGA80 [(SA642A-B070A-Y096N001)]  
 PDL129H88V(AM29PDL129H88)@FBGA80 [(SA642A-B070A-Y096N001)]

## BPROM

AM27LS19	AM27LS19@PLCC20
[(SA001A)]	
AM27LS19@SOIC16 [(SA404)]	
AM27PS191	
AM27PS191@PLCC28 [(SA008A)]	AM27PS191@PLCC32
[(SA015A1T)]	
AM27PS191@SOIC24 [(SA404)]	
AM27PS191A	
AM27PS191A@PLCC28 [(SA008A)]	AM27PS191A@PLCC32
[(SA015A1T)]	
AM27PS191A@SOIC24 [(SA404)]	
AM27PS291	
AM27PS291@PLCC28 [(SA008A)]	AM27PS291@PLCC32
[(SA015A1T)]	

AM27PS291@SOIC24 [(SA404)]	
AM27PS291A	
AM27PS291A@PLCC28 [(SA008A)]	AM27PS291A@PLCC32
[(SA015A1T)]	
AM27PS291A@SOIC24 [(SA404)]	
AM27PS41	
AM27PS41@PLCC28 [(SA008A)]	AM27PS41@SOIC20
[(SA404)]	
AM27S13	AM27S13@PLCC20
[(SA001A)]	
AM27S13@SOIC16 [(SA404)]	
AM27S13A	
AM27S13A@PLCC20 [(SA001A)]	AM27S13A@SOIC16
[(SA404)]	
AM27S18	AM27S18@PLCC20
[(SA001A)]	
AM27S18@SOIC16 [(SA404)]	
AM27S180	
AM27S180@PLCC28 [(SA008A)]	AM27S180@PLCC32
[(SA015A1T)]	
AM27S180@SOIC24 [(SA404)]	
AM27S180A	
AM27S180A@PLCC28 [(SA008A)]	AM27S180A@PLCC32
[(SA015A1T)]	
AM27S180A@SOIC24 [(SA404)]	
AM27S181	
AM27S181@PLCC28 [(SA008A)]	AM27S181@PLCC32
[(SA015A1T)]	
AM27S181@SOIC24 [(SA404)]	
AM27S181A	
AM27S181A@PLCC28 [(SA008A)]	AM27S181A@PLCC32
[(SA015A1T)]	
AM27S181A@SOIC24 [(SA404)]	
AM27S184	
AM27S184@PLCC28 [(SA008A)]	AM27S184@SOIC18
[(SA404)]	
AM27S185	AM27S185@PLCC28
[(SA008A)]	
AM27S185@SOIC18 [(SA404)]	
AM27S185A	
AM27S185A@PLCC28 [(SA008A)]	AM27S185A@SOIC18
[(SA404)]	
AM27S18A	AM27S18A@PLCC20

[ (SA001A) ]	
AM27S18A@SOIC16 [ (SA404) ]	
AM27S19	
AM27S19@PLCC20 [ (SA001A) ]	AM27S19@SOIC16
[ (SA404) ]	
AM27S190	AM27S190@PLCC28
[ (SA008A) ]	
AM27S190@PLCC32 [ (SA015A1T) ]	AM27S190@SOIC24
[ (SA404) ]	
AM27S190A	AM27S190A@PLCC28
[ (SA008A) ]	
AM27S190A@PLCC32 [ (SA015A1T) ]	AM27S190A@SOIC24
[ (SA404) ]	
AM27S191	AM27S191@PLCC28
[ (SA008A) ]	
AM27S191@PLCC32 [ (SA015A1T) ]	AM27S191@SOIC24
[ (SA404) ]	
AM27S191A	AM27S191A@PLCC28
[ (SA008A) ]	
AM27S191A@PLCC32 [ (SA015A1T) ]	AM27S191A@SOIC24
[ (SA404) ]	
AM27S191SA	AM27S191SA@PLCC28
[ (SA008A) ]	
AM27S191SA@PLCC32 [ (SA015A1T) ]	AM27S191SA@SOIC24
[ (SA404) ]	
AM27S19A	AM27S19A@PLCC20
[ (SA001A) ]	
AM27S19A@SOIC16 [ (SA404) ]	
AM27S19SA	
AM27S19SA@PLCC20 [ (SA001A) ]	AM27S19SA@SOIC16
[ (SA404) ]	
AM27S20	AM27S20@PLCC20
[ (SA001A) ]	
AM27S20@SOIC16 [ (SA404) ]	
AM27S21	
AM27S21@PLCC20 [ (SA001A) ]	AM27S21@SOIC16
[ (SA404) ]	
AM27S21A	AM27S21A@PLCC20
[ (SA001A) ]	
AM27S21A@SOIC16 [ (SA404) ]	
AM27S23	
AM27S23@PLCC20 [ (SA001A) ]	AM27S23@SOIC20
[ (SA404) ]	



AM27S23A [ (SA001A) ] AM27S23A@SOIC20 [ (SA404) ] AM27S25 AM27S25@PLCC28 [ (SA008A) ] [ (SA015A1T) ] AM27S25@SOIC24 [ (SA404) ] AM27S25A AM27S25A@PLCC28 [ (SA008A) ] [ (SA015A1T) ] AM27S25A@SOIC24 [ (SA404) ] AM27S25SA AM27S25SA@PLCC28 [ (SA008A) ] [ (SA015A1T) ] AM27S25SA@SOIC24 [ (SA404) ] AM27S27 AM27S27@SOIC24 [ (SA404) ] AM27S27A AM27S27A@SOIC24 [ (SA404) ] AM27S280 AM27S280@PLCC28 [ (SA008A) ] [ (SA015A1T) ] AM27S280@SOIC24 [ (SA404) ] AM27S281 AM27S281@PLCC28 [ (SA008A) ] [ (SA015A1T) ] AM27S281@SOIC24 [ (SA404) ] AM27S281A AM27S281A@PLCC28 [ (SA008A) ] [ (SA015A1T) ] AM27S281A@SOIC24 [ (SA404) ] AM27S29 AM27S29@PLCC20 [ (SA001A) ] [ (SA404) ] AM27S291 [ (SA008A) ] AM27S291@PLCC32 [ (SA015A1T) ] [ (SA404) ] AM27S291A [ (SA008A) ] AM27S291A@PLCC32 [ (SA015A1T) ] [ (SA404) ] AM27S291SA	AM27S23A@PLCC20    AM27S25@PLCC32   AM27S25A@PLCC32   AM27S25SA@PLCC32       AM27S280@PLCC32    AM27S281@PLCC32   AM27S281A@PLCC32   AM27S29@SOIC20  AM27S291@PLCC28  AM27S291@SOIC24  AM27S291A@PLCC28  AM27S291A@SOIC24  AM27S291SA@PLCC28
-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

[ (SA008A) ]	
AM27S291SA@PLCC32 [ (SA015A1T) ]	AM27S291SA@SOIC24
[ (SA404) ]	
AM27S29A	AM27S29A@PLCC20
[ (SA001A) ]	
AM27S29A@SOIC20 [ (SA404) ]	
AM27S29SA	
AM27S29SA@PLCC20 [ (SA001A) ]	AM27S29SA@SOIC20
[ (SA404) ]	
AM27S31	AM27S31@PLCC28
[ (SA008A) ]	
AM27S31@PLCC32 [ (SA015A1T) ]	AM27S31@SOIC24
[ (SA404) ]	
AM27S31A	AM27S31A@PLCC28
[ (SA008A) ]	
AM27S31A@PLCC32 [ (SA015A1T) ]	AM27S31A@SOIC24
[ (SA404) ]	
AM27S33	AM27S33@PLCC20
[ (SA001A) ]	
AM27S33@SOIC18 [ (SA404) ]	
AM27S33A	
AM27S33A@PLCC20 [ (SA001A) ]	AM27S33A@SOIC18
[ (SA404) ]	
AM27S35	AM27S35@PLCC28
[ (SA008A) ]	
AM27S35@PLCC32 [ (SA015A1T) ]	AM27S35@SOIC24
[ (SA404) ]	
AM27S35A	AM27S35A@PLCC28
[ (SA008A) ]	
AM27S35A@PLCC32 [ (SA015A1T) ]	AM27S35A@SOIC24
[ (SA404) ]	
AM27S37	AM27S37@PLCC28
[ (SA008A) ]	
AM27S37@PLCC32 [ (SA015A1T) ]	AM27S37@SOIC24
[ (SA404) ]	
AM27S37A	AM27S37A@PLCC28
[ (SA008A) ]	
AM27S37A@PLCC32 [ (SA015A1T) ]	AM27S37A@SOIC24
[ (SA404) ]	
AM27S41	AM27S41@PLCC28
[ (SA008A) ]	
AM27S41@SOIC20 [ (SA404) ]	
AM27S41A	

AM27S41A@PLCC28 [(SA008A)]	AM27S41A@SOIC20
[(SA404)]	
AM27S43	AM27S43@PLCC28
[(SA008A)]	
AM27S43@PLCC32 [(SA015A1T)]	AM27S43@SOIC24
[(SA404)]	
AM27S43A	AM27S43A@PLCC28
[(SA008A)]	
AM27S43A@PLCC32 [(SA015A1T)]	AM27S43A@SOIC24
[(SA404)]	
AM27S45	AM27S45@PLCC28
[(SA008A)]	
AM27S45@PLCC32 [(SA015A1T)]	AM27S45@SOIC24
[(SA404)]	
AM27S45A	AM27S45A@PLCC28
[(SA008A)]	
AM27S45A@PLCC32 [(SA015A1T)]	AM27S45A@SOIC24
[(SA404)]	
AM27S45SA	AM27S45SA@PLCC28
[(SA008A)]	
AM27S45SA@PLCC32 [(SA015A1T)]	AM27S45SA@SOIC24
[(SA404)]	
AM27S47	AM27S47@PLCC28
[(SA008A)]	
AM27S47@PLCC32 [(SA015A1T)]	AM27S47@SOIC24
[(SA404)]	
AM27S47A	AM27S47A@PLCC28
[(SA008A)]	
AM27S47A@PLCC32 [(SA015A1T)]	AM27S47A@SOIC24
[(SA404)]	
AM27S47SA	AM27S47SA@PLCC28
[(SA008A)]	
AM27S47SA@PLCC32 [(SA015A1T)]	AM27S47SA@SOIC24
[(SA404)]	
AM27S49	AM27S49@PLCC28
[(SA008A)]	
AM27S49@PLCC32 [(SA015A1T)]	AM27S49@SOIC24
[(SA404)]	
AM27S49A	AM27S49A@PLCC28
[(SA008A)]	
AM27S49A@PLCC32 [(SA015A1T)]	AM27S49A@SOIC24
[(SA404)]	
AM27S49SA	AM27S49SA@PLCC28

[ (SA008A) ]  
 AM27S49SA@PLCC32 [ (SA015A1T) ]  
 [ (SA404) ]

AM27S49SA@SOIC24

## PLD

AMPAL22V10  
 [ (SA008A) ]  
 AMPAL22V10@SOIC24 [ (SA404) ]  
 AMPAL22V10A  
 AMPAL22V10A@PLCC28 [ (SA008A) ]  
 [ (SA404) ]  
 AMPAL23S8  
 [ (SA404) ]  
 M4-128/64@PQFP100 [ (PEP+S427) ]  
 +S604) ]  
 M4-128N/64@PLCC84 [ (PEP+S416T) ]  
 +S427) ]  
 M4A3-128/64@TQFP100 [ (PEP+S604) ]  
 M4A3-128N/64@PLCC84 [ (PEP+S416T) ]  
 M4A3-32/32@PLCC44 [ (SA244) ]  
 [ (SA245A) ]  
 M4A3-32/32@TQFP48 [ (SA248) ]  
 [ (SA244) ]  
 M4A3-64/32@TQFP44 [ (SA245A) ]  
 [ (SA248) ]  
 M4A3-64/64@TQFP100 [ (PEP+S604) ]  
 +S604) ]  
 M4A5-128/64@PQFP100 [ (PEP+S427) ]  
 +S604) ]  
 M4A5-128N/64@PLCC84 [ (PEP+S416T) ]  
 M4A5-32/32@PLCC44 [ (SA244) ]  
 [ (SA245A) ]  
 M4A5-32/32@TQFP48 [ (SA248) ]  
 [ (SA244) ]  
 M4A5-64/32@TQFP44 [ (SA245A) ]  
 [ (SA248) ]  
 M4A5-96/48@TQFP100 [ (PEP+S604) ]  
 +S427) ]  
 M4LV-128/64@TQFP100 [ (PEP+S604) ]  
 M4LV-128N/64@PLCC84 [ (PEP+S416T) ]  
 MACH110@PLCC44 [ (SA244) ]

AMPAL22V10@PLCC28  
 AMPAL22V10A@SOIC24  
 AMPAL23S8@SOIC20  
 M4-128/64@TQFP100 [ (PEP  
 M4A3-128/64@PQFP100 [ (PEP  
 M4A3-32/32@TQFP44  
 M4A3-64/32@PLCC44  
 M4A3-64/32@TQFP48  
 M4A3-96/48@TQFP100 [ (PEP  
 M4A5-128/64@TQFP100 [ (PEP  
 M4A5-32/32@TQFP44  
 M4A5-64/32@PLCC44  
 M4A5-64/32@TQFP48  
 M4LV-128/64@PQFP100 [ (PEP  
 MACH111@PLCC44

[ (SA244) ]	
MACH111@TQFP44 [ (SA245A) ]	MACH120@PLCC68 [ (PEP
+S414T) ]	
MACH130@PLCC84 [ (PEP+S416T) ]	MACH131/1@PLCC84 [ (PEP
+S416T) ]	
MACH131@PLCC84 [ (PEP+S416T) ]	MACH131SP@PQFP100 [ (PEP
+S427) ]	
MACH131SP@TQFP100 [ (PEP+S604) ]	MACH210@PLCC44
[ (SA244) ]	
MACH210@TQFP44 [ (SA245A) ]	MACH210A@PLCC44
[ (SA244) ]	
MACH210A@TQFP44 [ (SA245A) ]	MACH210AQ@PLCC44
[ (SA244) ]	
MACH210AQ@TQFP44 [ (SA245A) ]	MACH211@PLCC44
[ (SA244) ]	
MACH211@TQFP44 [ (SA245A) ]	MACH211SP@PLCC44
[ (SA244) ]	
MACH211SP@TQFP44 [ (SA245A) ]	MACH220@PLCC68 [ (PEP
+S414T) ]	
MACH221@PLCC68 [ (PEP+S414T) ]	MACH230@PLCC84 [ (PEP
+S416T) ]	
MACH231@PLCC84 [ (PEP+S416T) ]	MACH231SP@PLCC84 [ (PEP
+S416T) ]	
MACH231SP@PQFP100 [ (PEP+S427) ]	MACH231SP@TQFP100 [ (PEP
+S604) ]	
MACH435@PLCC84 [ (PEP+S416T) ]	MACH436@PLCC84 [ (PEP
+S416T) ]	
MACH446@PQFP100 [ (PEP+S427) ]	MACH446@TQFP100 [ (PEP
+S604) ]	
MACHLV210@PLCC44 [ (SA244) ]	MACHLV436@PLCC84 [ (PEP
+S416T) ]	
MACHLV446@PQFP100 [ (PEP+S427) ]	MACHLV446@TQFP100 [ (PEP
+S604) ]	
PAL16L8-4	PAL16L8-4@PLCC20
[ (SA001A) ]	
PAL16L8-4@SOIC20 [ (SA404) ]	PAL16L8-
5	
PAL16L8-5@PLCC20 [ (SA001A) ]	PAL16L8-5@SOIC20
[ (SA404) ]	
PAL16L8-7	PAL16L8-7@PLCC20
[ (SA001A) ]	
PAL16L8-7@SOIC20 [ (SA404) ]	
PAL16L8A	

PAL16L8A@PLCC20 [(SA001A)]	PAL16L8-
H10	
PAL16L8-H10@PLCC20 [(SA001A)]	PAL16L8-H10@SOIC20
[(SA404)]	
PAL16R4-4	PAL16R4-4@PLCC20
[(SA001A)]	
PAL16R4-4@SOIC20 [(SA404)]	PAL16R4-
5	
PAL16R4-5@PLCC20 [(SA001A)]	PAL16R4-5@SOIC20
[(SA404)]	
PAL16R4-7	PAL16R4-7@PLCC20
[(SA001A)]	
PAL16R4-7@SOIC20 [(SA404)]	PAL16R4-
H10	
PAL16R4-H10@PLCC20 [(SA001A)]	PAL16R4-H10@SOIC20
[(SA404)]	
PAL16R6-4	PAL16R6-4@PLCC20
[(SA001A)]	
PAL16R6-4@SOIC20 [(SA404)]	PAL16R6-
5	
PAL16R6-5@PLCC20 [(SA001A)]	PAL16R6-5@SOIC20
[(SA404)]	
PAL16R6-7	PAL16R6-7@PLCC20
[(SA001A)]	
PAL16R6-7@SOIC20 [(SA404)]	PAL16R6-
H10	
PAL16R6-H10@PLCC20 [(SA001A)]	PAL16R6-H10@SOIC20
[(SA404)]	
PAL16R8-4	PAL16R8-4@PLCC20
[(SA001A)]	
PAL16R8-4@SOIC20 [(SA404)]	PAL16R8-
5	
PAL16R8-5@PLCC20 [(SA001A)]	PAL16R8-5@SOIC20
[(SA404)]	
PAL16R8-7	PAL16R8-7@PLCC20
[(SA001A)]	
PAL16R8-7@SOIC20 [(SA404)]	PAL16R8-
H10	
PAL16R8-H10@PLCC20 [(SA001A)]	PAL16R8-H10@SOIC20
[(SA404)]	
PAL20L8-10/2	PAL20L8-10/2@PLCC28
[(SA008A)]	
PAL20L8-10/2@SOIC24 [(SA404)]	PAL20L8-

5

PAL20L8-5@PLCC28 [(SA008A)]

[(SA404)]

PAL20L8-7

[(SA008A)]

PAL20L8-7@SOIC24 [(SA404)]

10/2

PAL20R4-10/2@PLCC28 [(SA008A)]

[(SA404)]

PAL20R4-5

[(SA008A)]

PAL20R4-5@SOIC24 [(SA404)]

7

PAL20R4-7@PLCC28 [(SA008A)]

[(SA404)]

PAL20R6-10/2

[(SA008A)]

PAL20R6-10/2@SOIC24 [(SA404)]

5

PAL20R6-5@PLCC28 [(SA008A)]

[(SA404)]

PAL20R6-7

[(SA008A)]

PAL20R6-7@SOIC24 [(SA404)]

10/2

PAL20R8-10/2@PLCC28 [(SA008A)]

[(SA404)]

PAL20R8-5

[(SA008A)]

PAL20R8-5@SOIC24 [(SA404)]

7

PAL20R8-7@PLCC28 [(SA008A)]

[(SA404)]

PAL20RA10

PAL22V10

PAL22V10@PLCC28 [(SA008A)]

[(SA404)]

PAL22V10A

[(SA008A)]

PAL22V10A@SOIC24 [(SA404)]

PAL29M16H

PALC16L8Q

[(SA001A)]

PAL20L8-5@SOIC24

PAL20L8-7@PLCC28

PAL20R4-

PAL20R4-10/2@SOIC24

PAL20R4-5@PLCC28

PAL20R4-

PAL20R4-7@SOIC24

PAL20R6-10/2@PLCC28

PAL20R6-

PAL20R6-5@SOIC24

PAL20R6-7@PLCC28

PAL20R8-

PAL20R8-10/2@SOIC24

PAL20R8-5@PLCC28

PAL20R8-

PAL20R8-7@SOIC24

PAL22V10@SOIC24

PAL22V10A@PLCC28

PALC16L8Q@PLCC20

PALC16L8Z	PALC16L8Z@PLCC20
[ (SA001A) ]	
PALC16R4Q	PALC16R4Q@PLCC20
[ (SA001A) ]	
PALC16R4Z	PALC16R4Z@PLCC20
[ (SA001A) ]	
PALC16R6Q	PALC16R6Q@PLCC20
[ (SA001A) ]	
PALC16R6Z	PALC16R6Z@PLCC20
[ (SA001A) ]	
PALC16R8Q	PALC16R8Q@PLCC20
[ (SA001A) ]	
PALC16R8Z	PALC16R8Z@PLCC20
[ (SA001A) ]	
PALCE16V8H	PALCE16V8H@PLCC20
[ (SA001A) ]	
PALCE16V8H@SOIC20 [ (SA404) ]	
PALCE16V8Q	
PALCE16V8Q@PLCC20 [ (SA001A) ]	PALCE16V8Q@SOIC20
[ (SA404) ]	
PALCE16V8Z	PALCE16V8Z@PLCC20
[ (SA001A) ]	
PALCE16V8Z@SOIC20 [ (SA404) ]	
PALCE20RA10	
PALCE20RA10@PLCC28 [ (SA008A) ]	PALCE20RA10@SOIC24
[ (SA404) ]	
PALCE20RA10H	PALCE20RA10H@PLCC28
[ (SA008A) ]	
PALCE20RA10H@SOIC24 [ (SA404) ]	
PALCE20RA10Q	
PALCE20RA10Q@PLCC28 [ (SA008A) ]	PALCE20RA10Q@SOIC24
[ (SA404) ]	
PALCE20V8H	PALCE20V8H@PLCC28
[ (SA008A) ]	
PALCE20V8H@SOIC24 [ (SA404) ]	
PALCE20V8Q	
PALCE20V8Q@PLCC28 [ (SA008A) ]	PALCE20V8Q@SOIC24
[ (SA404) ]	
PALCE22V10H	PALCE22V10H@PLCC28
[ (SA008A) ]	
PALCE22V10H@SOIC24 [ (SA404) ]	
PALCE22V10Q	
PALCE22V10Q@PLCC28 [ (SA008A) ]	PALCE22V10Q@SOIC24



[(SA404)]	
PALCE22V10Z	PALCE22V10Z@PLCC28
[(SA008A)]	
PALCE22V10Z@SOIC24 [(SA404)]	
PALCE26V12H/4	
PALCE26V12H/4@PLCC28 [(SA008A)]	PALCE26V12H/4@SOIC28
[(SA404)]	
PALCE26V12H-15	
[(SA008A)]	PALCE26V12H-15@PLCC28
PALCE26V12H-15@SOIC28 [(SA404)]	PALCE26V12H-
20	
PALCE26V12H-20@PLCC28 [(SA008A)]	PALCE26V12H-20@SOIC28
[(SA404)]	
PALCE26V12H-25	
[(SA008A)]	PALCE26V12H-25@PLCC28
PALCE26V12H-25@SOIC28 [(SA404)]	
PALCE29M16H	
PALCE29M16H@PLCC28 [(SA008A)]	PALCE29M16H@SOIC24
[(SA404)]	
PALCE29MA16H	
[(SA008A)]	PALCE29MA16H@PLCC28
PALCE29MA16H@SOIC24 [(SA404)]	
PALCE610	
PALCE610@PLCC28 [(SA008A)]	PALCE610@SOIC24
[(SA404)]	
PALCE610H	
[(SA008A)]	PALCE610H@PLCC28
PALCE610H@SOIC24 [(SA404)]	
PALCE630H	
PALCE630H@SOIC24 [(SA404)]	PALCE630H-P28
[(SA008A)]	
PALLV16V8	
[(SA001A)]	PALLV16V8@PLCC20
PALLV16V8@SOIC20 [(SA404)]	
PALLV16V8Z	
PALLV16V8Z@PLCC20 [(SA001A)]	PALLV16V8Z@SOIC20
[(SA404)]	

## MICROCONTROLLER

AM8751H

AM8753H

AM87C51  
[ (SA244) ]  
AM87C51@TQFP44 [ (SA245A) ]  
AM87C521  
AM87C521@PLCC44 [ (SA244) ]  
[ (SA245A) ]  
AM87C541  
[ (SA244) ]  
AM87C541@TQFP44 [ (SA245A) ]

AM87C51@PLCC44  
  
AM87C521@TQFP44  
  
AM87C541@PLCC44

## AMI SEMICONDUCTOR

### E (E) PROM / FRAM / NVRAM

N256S0818HDA  
[ (SA602A) ]  
N256S0818HDA@TSSOP8 [ (SA026) ]  
N256S0830HDA  
N256S0830HDA@SOIC8 [ (SA602A) ]  
[ (SA026) ]  
N64S0818HDA  
[ (SA602A) ]  
N64S0818HDA@TSSOP8 [ (SA026) ]  
N64S0830HDA  
N64S0830HDA@SOIC8 [ (SA602A) ]  
[ (SA026) ]

N256S0818HDA@SOIC8  
  
  
N256S0830HDA@TSSOP8  
  
N64S0818HDA@SOIC8  
  
N64S0830HDA@TSSOP8

## AMIC

### E (E) PROM / FRAM / NVRAM

A25L010  
[ (SA602A) ]  
A25L010[209mil]@SOP8 [ (SA605A) ]  
A25L016  
A25L016@SOP8 [ (SA023A) ]  
A25L020  
A25L020[150mil]@SOP8 [ (SA602A) ]  
[ (SA605A) ]  
A25L032

A25L010[150mil]@SOP8  
  
  
A25L020[209mil]@SOP8  
  
A25L032@SOP8

[(SA023A)]  
 A25L040P A25L040P@QFN8  
 [(SA683)]  
 A25L040P@SOP16 [(SA404)] A25L040P@SOP8  
 [(SA602A)]  
 A25L05P(Bottom) A25L05P(Bottom)@QFN8  
 [(SA683)]  
 A25L05P(Bottom)[150mil]@SOP8 [(SA602A)]  
 A25L05P(Bottom)[209mil]@SOP8 [(SA605A)]  
 A25L05P(Top) A25L05P(Top)@QFN8  
 [(SA683)]  
 A25L05P(Top)[150mil]@SOP8 [(SA602A)]  
 A25L05P(Top)[209mil]@SOP8 [(SA605A)]  
 A25L080P A25L080P@QFN8  
 [(SA683)]  
 A25L080P@SOP16 [(SA404)] A25L080P@SOP8  
 [(SA023A)]  
 A25L10P(Bottom) A25L10P(Bottom)@QFN8  
 [(SA683)]  
 A25L10P(Bottom)[150mil]@SOP8 [(SA602A)]  
 A25L10P(Bottom)[209mil]@SOP8 [(SA605A)]  
 A25L10P(Top) A25L10P(Top)@QFN8  
 [(SA683)]  
 A25L10P(Top)[150mil]@SOP8 [(SA602A)]  
 A25L10P(Top)[209mil]@SOP8 [(SA605A)]  
 A25L16P(Bottom)@QFN8 [(SA683)]  
 A25L16P(Bottom)@QFN8(ISP) [ISP-HEADER01]  
 A25L16P(Bottom)@SOP16 [(SA404)]  
 A25L16P(Bottom)@SOP16(ISP) [ISP-HEADER01]  
 A25L16P(Bottom)@SOP8 [(SA023A)]  
 A25L16P(Bottom)@SOP8(ISP) [ISP-HEADER01]  
 A25L16P(Top)@QFN8 [(SA683)]  
 A25L16P(Top)@QFN8(ISP) [ISP-HEADER01]  
 A25L16P(Top)@SOP16 [(SA404)]  
 A25L16P(Top)@SOP16(ISP) [ISP-HEADER01]  
 A25L16P(Top)@SOP8 [(SA023A)]  
 A25L16P(Top)@SOP8(ISP) [ISP-HEADER01]  
 A25L20P(Bottom) A25L20P(Bottom)@QFN8  
 [(SA683)]  
 A25L20P(Bottom)[150mil]@SOP8 [(SA602A)]  
 A25L20P(Bottom)[209mil]@SOP8 [(SA605A)]  
 A25L20P(Top) A25L20P(Top)@QFN8  
 [(SA683)]

A25L20P(Top)[150mil]@SOP8 [(SA602A)]	
A25L20P(Top)[209mil]@SOP8 [(SA605A)]	
A25L40P(Bottom Boot)	
A25L40P(Bottom Boot)@QFN8 [(SA683)]	
A25L40P(Bottom Boot)@SOP16 [(SA404)]	
A25L40P(Bottom Boot)@SOP8 [(SA602A)]	
A25L40P(Top Boot)	A25L40P(Top Boot)@QFN8
[(SA683)]	
A25L40P(Top Boot)@SOP16 [(SA404)]	
A25L40P(Top Boot)@SOP8 [(SA602A)]	
A25L42P(Bottom Boot)	
A25L42P(Bottom Boot)@QFN8 [(SA683)]	
A25L42P(Bottom Boot)@SOP16 [(SA404)]	
A25L42P(Bottom Boot)@SOP8 [(SA602A)]	
A25L42P(Top Boot)	A25L42P(Top Boot)@QFN8
[(SA683)]	
A25L42P(Top Boot)@SOP16 [(SA404)]	
A25L42P(Top Boot)@SOP8 [(SA602A)]	
A25L512	A25L512[150mil]@SOP8
[(SA602A)]	
A25L512[209mil]@SOP8 [(SA605A)]	
A25L80P	
A25L80P@QFN8 [(SA683)]	A25L80P@SOP16
[(SA404)]	
A25L80P@SOP8 [(SA023A)]	A25L82P(Bottom
Boot)	
A25L82P(Bottom Boot)@QFN8 [(SA683)]	
A25L82P(Bottom Boot)@SOP16 [(SA404)]	
A25L82P(Bottom Boot)@SOP8 [(SA023A)]	
A25L82P(Top Boot)	A25L82P(Top Boot)@QFN8
[(SA683)]	
A25L82P(Top Boot)@SOP16 [(SA404)]	
A25L82P(Top Boot)@SOP8 [(SA023A)]	
A25LS080P	A25LS080P@QFN8
[(SA683)]	
A25LS080P@SOP16 [(SA404)]	A25LS080P@SOP8
[(SA023A)]	
A27020	A27020@PLCC32
[(SA015A1T)]	
A27020@TSOP32 [(SA410T)]	
A27020L	
A27020L@PLCC32 [(SA015A1T)]	A27020L@TSOP32
[(SA410T)]	

A275308 [ (SA015A1T) ]	A275308@PLCC32
A276308 (E)	A276308
A276308(E)@PLCC32 [ (SA015A1T) ] [ (SA404) ]	A276308(E)@SOIC28
A276308@PLCC32 [ (SA015A1T) ] [ (SA404) ]	A276308@SOIC28
A276308A (L)	A276308A
A276308A(L)@PLCC32 [ (SA015A1T) ] [ (SA404) ]	A276308A(L)@SOIC28
A276308A@PLCC32 [ (SA015A1T) ] [ (SA404) ]	A276308A@SOIC28
A277308 [ (SA015A1T) ]	A277308@PLCC32
A277308A [ (SA015A1T) ]	A277308A@PLCC32
A278308 [ (SA015A1T) ]	A278308@PLCC32
A278308A (L)	A278308A
A278308A(L)@PLCC32 [ (SA015A1T) ] [ (SA015A1T) ]	A278308A@PLCC32
A279308 [ (SA015A1T) ]	A279308@PLCC32
A290011T [ (SA015A1T) ]	A290011T@PLCC32
A290011T@TSOP32 [ (SA410T) ]	
A290011U A290011U@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	A290011U@TSOP32
A29001T [ (SA015A1T) ]	A29001T@PLCC32
A29001T@TSOP32 [ (SA410T) ]	
A29001U A29001U@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	A29001U@TSOP32
A290021T [ (SA015A1T) ]	A290021T@PLCC32
A290021T@TSOP32 [ (SA410T) ]	
A290021U A290021U@PLCC32 [ (SA015A1T) ]	A290021U@TSOP32

[ (SA410T) ]	
A29002T	A29002T@PLCC32
[ (SA015A1T) ]	
A29002T@TSOP32 [ (SA410T) ]	
A29002U	
A29002U@PLCC32 [ (SA015A1T) ]	A29002U@TSOP32
[ (SA410T) ]	
A29010	A29010@PLCC32
[ (SA015A1T) ]	
A29010@TSOP32 [ (SA410T) ]	
A29040	
A29040@PLCC32 [ (SA015A1T) ]	A29040@TSOP32
[ (SA410T) ]	
A29040A	A29040A@PLCC32
[ (SA015A1T) ]	
A29040A@TSOP32 [ (SA410T) ]	
A29040B	
A29040B@PLCC32 [ (SA015A1T) ]	A29040B@TSOP32
[ (SA410T) ]	
A29400TM@PSOP44 [ (SA638) ]	A29400TV@TSOP48 [ (SA247-
B005) ]	
A29400UM@PSOP44 [ (SA638) ]	A29400UV@TSOP48 [ (SA247-
B005) ]	
A29512	A29512@PLCC32
[ (SA015A1T) ]	
A29512@TSOP32 [ (SA410T) ]	
A29512A	
A29512A@PLCC32 [ (SA015A1T) ]	A29512A@TSOP32
[ (SA410T) ]	
A29800TM@PSOP44 [ (SA638) ]	A29800TV@TSOP48 [ (SA247-
B005) ]	
A29800UM@PSOP44 [ (SA638) ]	A29800UV@TSOP48 [ (SA247-
B005) ]	
A29DL162TG@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
A29DL162TV@TSOP48 [ (SA247-B005) ]	
A29DL162UG@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
A29DL162UV@TSOP48 [ (SA247-B005) ]	
A29DL163TG@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
A29DL163TV@TSOP48 [ (SA247-B005) ]	
A29DL163UG@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
A29DL163UV@TSOP48 [ (SA247-B005) ]	
A29DL164TG@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
A29DL164TV@TSOP48 [ (SA247-B005) ]	

A29DL164UG@FBGA48 [(SA642G-B026A-T048F001Y)]  
 A29DL164UV@TSOP48 [(SA247-B005)]  
 A29DL320FTV@TSOP48 [(SA247-B005)]  
 A29DL320FUV@TSOP48 [(SA247-B005)]  
 A29DL322TG@FBGA48 [(SA642G-B026A-T048F001Y)]  
 A29DL322TV@TSOP48 [(SA247-B005)]  
 A29DL322UG@FBGA48 [(SA642G-B026A-T048F001Y)]  
 A29DL322UV@TSOP48 [(SA247-B005)]  
 A29DL323TG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]  
 A29DL323TG@FBGA63 [(SA642A-B026A-Y096F001)]  
 A29DL323TV(New)@TSOP48 [(SA247-B005)]  
 A29DL323TV@TSOP48 [(SA247-B005)]  
 A29DL323UG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]  
 A29DL323UG@FBGA63 [(SA642A-B026A-Y096F001)]  
 A29DL323UV(New)@TSOP48 [(SA247-B005)]  
 A29DL323UV@TSOP48 [(SA247-B005)]  
 A29DL324TG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]  
 A29DL324TG@FBGA63 [(SA642A-B026A-Y096F001)]  
 A29DL324TV(New)@TSOP48 [(SA247-B005)]  
 A29DL324TV@TSOP48 [(SA247-B005)]  
 A29DL324UG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]  
 A29DL324UG@FBGA63 [(SA642A-B026A-Y096F001)]  
 A29DL324UV(New)@TSOP48 [(SA247-B005)]  
 A29DL324UV@TSOP48 [(SA247-B005)]      A29L004ATL@PLCC32  
 [(SA015A1T)]  
 A29L004ATV@TSOP32 [(SA410T)]      A29L004ATW@TSOP40  
 [(SA409T)]  
 A29L004ATY@VSOP32 [(SA620)]      A29L004AUL@PLCC32  
 [(SA015A1T)]  
 A29L004AUV@TSOP32 [(SA410T)]      A29L004AUW@TSOP40  
 [(SA409T)]  
 A29L004AUY@VSOP32 [(SA620)]      A29L004T@PLCC32  
 [(SA015A1T)]  
 A29L004T@TSOP32 [(SA410T)]      A29L004T@TSOP40  
 [(SA409T)]  
 A29L004T@VSOP32 [(SA620)]      A29L004U@PLCC32  
 [(SA015A1T)]  
 A29L004U@TSOP32 [(SA410T)]      A29L004U@TSOP40  
 [(SA409T)]  
 A29L004U@VSOP32 [(SA620)]      A29L008ATV@TSOP40  
 [(SA409T)]  
 A29L008AUV@TSOP40 [(SA409T)]      A29L008T@TSOP40  
 [(SA409T)]

A29L008U@TSOP40 [(SA409T)]  
A29L040  
A29L040@PLCC32 [(SA015A1T)] A29L040@TSOP32  
[(SA410T)]  
A29L040@VSOP32 [(SA620)]  
A29L160ATG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L160ATM@PSOP44 [(SA638)] A29L160ATV@TSOP48 [(SA247-  
B005)]  
A29L160AUG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L160AUM@PSOP44 [(SA638)] A29L160AUV@TSOP48 [(SA247-  
B005)]  
A29L160BTG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L160BTGB@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L160BTM@PSOP44 [(SA638)] A29L160BTV@TSOP48 [(SA247-  
B005)]  
A29L160BUG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L160BUGB@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L160BUM@PSOP44 [(SA638)] A29L160BUV@TSOP48 [(SA247-  
B005)]  
A29L160HTG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L160HTV@TSOP48 [(SA247-B005)]  
A29L160HUG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L160HUV@TSOP48 [(SA247-B005)]  
A29L160TG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L160TM@PSOP44 [(SA638)] A29L160TV@TSOP48 [(SA247-  
B005)]  
A29L160UG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L160UM@PSOP44 [(SA638)] A29L160UV@TSOP48 [(SA247-  
B005)]  
A29L320ATG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L320ATV@TSOP48 [(SA247-B005)]  
A29L320AUG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L320AUV@TSOP48 [(SA247-B005)]  
A29L400ATG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L400ATM@PSOP44 [(SA638)] A29L400ATV@TSOP48 [(SA247-  
B005)]  
A29L400AUG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29L400AUM@PSOP44 [(SA638)] A29L400AUV@TSOP48 [(SA247-  
B005)]  
A29L400TG@FBGA48 [(SA642B-B026A-Y072F001)]  
A29L400TM@PSOP44 [(SA638)] A29L400TV@TSOP48 [(SA247-  
B005)]  
A29L400UG@FBGA48 [(SA642B-B026A-Y072F001)]



A29L400UM@PSOP44 [(SA638)]	A29L400UV@TSOP48 [(SA247-B005)]
A29L800ATG@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29L800ATM@PSOP44 [(SA638)]	A29L800ATV@TSOP48 [(SA247-B005)]
A29L800AUG@FBGA48 [(SA642G-B026A-T048F001Y)]	
A29L800AUM@PSOP44 [(SA638)]	A29L800AUV@TSOP48 [(SA247-B005)]
A29L800HTG@FBGA48 [(SA642B-B026A-Y072F001)]	
A29L800HTM@PSOP44 [(SA638)]	A29L800HTV@TSOP48 [(SA247-B005)]
A29L800HUG@FBGA48 [(SA642B-B026A-Y072F001)]	
A29L800HUM@PSOP44 [(SA638)]	A29L800HUV@TSOP48 [(SA247-B005)]
A29L800TG@FBGA48 [(SA642B-B026A-Y072F001)]	
A29L800TM@PSOP44 [(SA638)]	A29L800TV@TSOP48 [(SA247-B005)]
A29L800UG@FBGA48 [(SA642B-B026A-Y072F001)]	
A29L800UM@PSOP44 [(SA638)]	A29L800UV@TSOP48 [(SA247-B005)]
A49LF004@PLCC32 [(SA015A1T)]	A49LF004@VSOP32
[(SA620)]	
A49LF004M@PLCC32 [(SA015A1T)]	A49LF004M@VSOP32
[(SA620)]	
A49LF040ATL@PLCC32 [(SA015A1T)]	A49LF040ATX@VSOP32
[(SA620)]	
A49LF040ATY@VSOP32 [(SA620)]	A49LF040TL@PLCC32
[(SA015A1T)]	
A49LF040TX@VSOP32 [(SA620)]	A50FW040@PLCC32
[(SA015A1T)]	
A50FW040@VSOP32 [(SA620)]	A50FW040M@PLCC32
[(SA015A1T)]	
A50FW040M@VSOP32 [(SA620)]	A50LPW040@PLCC32
[(SA015A1T)]	
A50LPW040@TSOP32 [(SA410T)]	
A617308	
A617308@TSOP32 [(SA410T)]	
A61L5308	
A61L5308@TSOP28 [(SA430T)]	A623308
(M)	
A623308(R)@TSOP28 [(SA430T)]	A623308(V)@TSOP28
[(SA430T)]	
A625308(M)	A625308(R)@TSOP28

[ ( SA430T ) ]  
 A625308 ( V ) @ TSOP28 [ ( SA430T ) ]  
 A62L256  
 A62L256 ( M ) A62L256 ( R ) @ TSOP28  
 [ ( SA430T ) ]  
 A62L256 ( V ) @ TSOP28 [ ( SA430T ) ] A62S6308  
 ( M )  
 A62S6308 ( X ) @ TSOP32 [ ( SA410T ) ] A62S7308A  
 ( M )  
 A62S7308A ( X ) @ TSOP32 [ ( SA410T ) ] A62S8308A  
 ( M )  
 A62S8308A ( X ) @ TSOP32 [ ( SA410T ) ] A62W5308  
 ( M )  
 A62W5308 ( R ) @ TSOP28 [ ( SA430T ) ] A62W5308 ( V ) @ TSOP28  
 [ ( SA430T ) ]  
 A81L801TG@FBGA69 [ ( SA642A-B078A-Y096F001Y ) ]  
 A81L801UG@FBGA69 [ ( SA642A-B078A-Y096F001Y ) ]  
 A82DL1622TG@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
 A82DL1622UG@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
 A82DL1624TG@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
 A82DL1624UG@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
 A82DL1632TG@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
 A82DL1632UG@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
 A82DL1634TG@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
 A82DL1634UG@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
 A82DL1642TG@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
 A82DL1642UG@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
 A82DL1644TG@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
 A82DL1644UG@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
 A82DL32216TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
 A82DL32216UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
 A82DL3224TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
 A82DL3224UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
 A82DL3228TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
 A82DL3228UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
 A82DL32316TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
 A82DL32316UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
 A82DL3234TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
 A82DL3234UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
 A82DL3238TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
 A82DL3238UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
 A82DL32416TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
 A82DL32416UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]

A82DL3244TG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL3244UG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL3248TG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL3248UG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]

## ANACHIP

### E (E) PROM / FRAM / NVRAM

27CX010	27CX010@PLCC32
[ (SA015A1T) ]	
27CX010@TSOP32 [ (SA410T) ]	
27CX161	
27CX162	
27CX256	
27CX321	
27CX322	
27CX641	
27CX642	
93C46	93C46@SOIC8
[ (SA602A) ]	
93C46A	93C46A@SOIC8
[ (SA602A) ]	
93C56A	93C56A@SOIC8
[ (SA602A) ]	
93C66A	93C66A@SOIC8
[ (SA602A) ]	
93CX46	93CX46@SOIC8
[ (SA602A) ]	
93CX56	93CX56@SOIC8
[ (SA602A) ]	
93CX66	93CX66@SOIC8
[ (SA602A) ]	
AM24LC02	AM24LC02@SOIC8
[ (SA602A) ]	
AM24LC02@TSSOP8 [ (SA026) ]	
AM24LC04	
AM24LC04@SOIC8 [ (SA602A) ]	AM24LC04@TSSOP8
[ (SA026) ]	
AM24LC08	AM24LC08@SOIC8
[ (SA602A) ]	
AM24LC08@TSSOP8 [ (SA026) ]	

AM24LC16	
AM24LC16@SOIC8 [(SA602A)]	AM24LC16@TSSOP8
[(SA026)]	
AM24LC21	AM24LC21@SOIC8
[(SA602A)]	
AM24LC21@TSSOP8 [(SA026)]	
AM24LC21B	
AM24LC21B@SOIC8 [(SA602A)]	AM24LC21B@TSSOP8
[(SA026)]	
AM93LC46(08bit)	AM93LC46(08bit)@SOIC8
[(SA602A)]	
AM93LC46(08bit)@TSOP8 [(SA026)]	AM93LC46
(16bit)	
AM93LC46(16bit)@SOIC8 [(SA602A)]	AM93LC46(16bit)@TSOP8
[(SA026)]	
AM93LC56(08bit)	AM93LC56(08bit)@SOIC8
[(SA602A)]	
AM93LC56(08bit)@TSOP8 [(SA026)]	AM93LC56
(16bit)	
AM93LC56(16bit)@SOIC8 [(SA602A)]	AM93LC56(16bit)@TSOP8
[(SA026)]	
AM93LC66(08bit)	AM93LC66(08bit)@SOIC8
[(SA602A)]	
AM93LC66(08bit)@TSOP8 [(SA026)]	AM93LC66
(16bit)	
AM93LC66(16bit)@SOIC8 [(SA602A)]	AM93LC66(16bit)@TSOP8
[(SA026)]	
AM93LC86(08bit)	AM93LC86(08bit)@SOIC8
[(SA602A)]	
AM93LC86(08bit)@TSOP8 [(SA026)]	AM93LC86
(16bit)	
AM93LC86(16bit)@SOIC8 [(SA602A)]	AM93LC86(16bit)@TSOP8
[(SA026)]	

## PLD

PA7024	PA7024(J)@PLCC28
[(SA008A)]	
PA7024(JN)@PLCC28 [(SA008A)]	PA7024@SOIC24
[(SA404)]	
PA7128	PA7128@PLCC28
[(SA008A)]	

PA7128@SOIC28 [(SA404)]	
PA7140	
PA7140@PLCC44 [(SA244)]	PA7140@TQFP44
[(SA245A)]	
PA7536	
[(SA008A)]	PA7536@PLCC28
PA7536@SOIC28 [(SA404)]	
PA7540	
PA7540(J)@PLCC28 [(SA008A)]	PA7540(JN)@PLCC28
[(SA008A)]	
PA7572	
[(SA244)]	PA7572@PLCC44
PA7572@TQFP44 [(SA245A)]	
PEEL16CV8	
PEEL16CV8@PLCC20 [(SA001A)]	PEEL16CV8@SOIC20
[(SA404)]	
PEEL16CV8@TSOP20 [(SA026)]	
PEEL18CV8	
PEEL18CV8@PLCC20 [(SA001A)]	PEEL18CV8@SOIC20
[(SA404)]	
PEEL18CV8@TSOP20 [(SA026)]	
PEEL18CV8Z	
PEEL18CV8Z@PLCC20 [(SA001A)]	PEEL18CV8Z@SOIC20
[(SA404)]	
PEEL18CV8Z@TSOP20 [(SA026)]	
PEEL18LV8Z	
PEEL18LV8Z@PLCC20 [(SA001A)]	PEEL18LV8Z@SOIC20
[(SA404)]	
PEEL18LV8Z@TSOP20 [(SA026)]	
PEEL22CV10A	
PEEL22CV10A@PLCC28 [(SA008A)]	PEEL22CV10A@SOIC24
[(SA404)]	
PEEL22CV10A@TSOP24 [(SA026)]	PEEL22CV10A
+	
PEEL22CV10A+@PLCC28 [(SA008A)]	PEEL22CV10A+@SOIC24
[(SA404)]	
PEEL22CV10A+@TSOP24 [(SA026)]	PEEL22CV10A+
+	
PEEL22CV10A++@PLCC28 [(SA008A)]	PEEL22CV10A++@SOIC24
[(SA404)]	
PEEL22CV10A++@TSOP24 [(SA026)]	
PEEL22CV10AZ	
PEEL22CV10AZ@PLCC28 [(SA008A)]	PEEL22CV10AZ@SOIC24

[ (SA404) ]	PEEL22CV10AZ
PEEL22CV10AZ@TSOP24 [ (SA026) ]	PEEL22CV10AZ
+	
PEEL22CV10AZ+@PLCC28 [ (SA008A) ]	PEEL22CV10AZ+@SOIC24
[ (SA404) ]	
PEEL22CV10AZ+@TSOP24 [ (SA026) ]	PEEL22CV10AZ+
+	
PEEL22CV10AZ++@PLCC28 [ (SA008A) ]	PEEL22CV10AZ++@SOIC24
[ (SA404) ]	
PEEL22CV10AZ++@TSOP24 [ (SA026) ]	
PEEL22CV8	
PEEL22CV8@PLCC24 [ (SA008A) ]	PEEL22CV8@SOIC24
[ (SA404) ]	
PEEL22LV10AZ	PEEL22LV10AZ@PLCC28
[ (SA008A) ]	
PEEL22LV10AZ@SOIC24 [ (SA404) ]	PEEL22LV10AZ@TSOP24
[ (SA026) ]	
PEEL22LV10AZ+	PEEL22LV10AZ+@PLCC28
[ (SA008A) ]	
PEEL22LV10AZ+@SOIC24 [ (SA404) ]	PEEL22LV10AZ+@TSOP24
[ (SA026) ]	
PEEL22LV10AZ++	PEEL22LV10AZ++@PLCC28
[ (SA008A) ]	
PEEL22LV10AZ++@SOIC24 [ (SA404) ]	PEEL22LV10AZ++@TSOP24
[ (SA026) ]	

## ANALOG

### MICROCONTROLLER

ADUC812BS@LFCSP56 [ (PEP+S706) ]	ADUC812BS@MQFP52 [ (PEP
+S662) ]	
ADUC816BS@LFCSP56 [ (PEP+S706) ]	ADUC816BS@MQFP52 [ (PEP
+S662) ]	
ADUC824BS@LFCSP56 [ (PEP+S706) ]	ADUC824BS@MQFP52 [ (PEP
+S662) ]	

## APLUS FLASH

### E ( E ) PROM / FRAM / NVRAM

AF24BC01 [ (SA602A) ]	AF24BC01@SOIC8
AF24BC01@TSSOP8 [ (SA026) ]	
AF24BC02 AF24BC02@SOIC8 [ (SA602A) ] [ (SA026) ]	AF24BC02@TSSOP8
AF24BC04 [ (SA602A) ]	AF24BC04@SOIC8
AF24BC04@TSSOP8 [ (SA026) ]	
AF24BC08 AF24BC08@SOIC8 [ (SA602A) ] [ (SA026) ]	AF24BC08@TSSOP8
AF24BC128 [ (SA602A) ]	AF24BC128@SOIC8
AF24BC128@TSOP8 [ (SA026) ]	
AF24BC16 AF24BC16@SOIC8 [ (SA602A) ] [ (SA026) ]	AF24BC16@TSSOP8
AF24BC256 [ (SA602A) ]	AF24BC256@SOIC8
AF24BC256@TSOP8 [ (SA026) ]	
AF24BC32 AF24BC32@SOIC8 [ (SA602A) ] [ (SA026) ]	AF24BC32@TSOP8
AF24BC64 [ (SA602A) ]	AF24BC64@SOIC8
AF24BC64@TSOP8 [ (SA026) ]	
AF24C128 AF24C128@SOIC8 [ (SA602A) ] [ (SA026) ]	AF24C128@TSOP8
AF24C256 [ (SA602A) ]	AF24C256@SOIC8
AF24C256@TSOP8 [ (SA026) ]	
AF24C32 AF24C32@SOIC8 [ (SA602A) ] [ (SA026) ]	AF24C32@TSOP8
AF24C64 [ (SA602A) ]	AF24C64@SOIC8
AF24C64@TSOP8 [ (SA026) ]	
AF25BC128 AF25BC128@SOIC8 [ (SA602A) ] [ (SA026) ]	AF25BC128@TSOP8
AF25BC256	AF25BC256@SOIC8

[ (SA602A) ]	
AF25BC256@TSOP8 [ (SA026) ]	AF93BC46
(08bit)	
AF93BC46(08bit)@SOIC8 [ (SA602A) ]	AF93BC46(08bit)@TSOP8
[ (SA026) ]	
AF93BC46(16bit)	AF93BC46(16bit)@SOIC8
[ (SA602A) ]	
AF93BC46(16bit)@TSOP8 [ (SA026) ]	AF93BC56
(08bit)	
AF93BC56(08bit)@SOIC8 [ (SA602A) ]	AF93BC56(08bit)@TSOP8
[ (SA026) ]	
AF93BC56(16bit)	AF93BC56(16bit)@SOIC8
[ (SA602A) ]	
AF93BC56(16bit)@TSOP8 [ (SA026) ]	AF93BC66
(08bit)	
AF93BC66(08bit)@SOIC8 [ (SA602A) ]	AF93BC66(08bit)@TSOP8
[ (SA026) ]	
AF93BC66(16bit)	AF93BC66(16bit)@SOIC8
[ (SA602A) ]	
AF93BC66(16bit)@TSOP8 [ (SA026) ]	AF93BC86
(08bit)	
AF93BC86(08bit)@SOIC8 [ (SA602A) ]	AF93BC86(08bit)@TSOP8
[ (SA026) ]	
AF93BC86(16bit)	AF93BC86(16bit)@SOIC8
[ (SA602A) ]	
AF93BC86(16bit)@TSOP8 [ (SA026) ]	AF93C46
(08bit)	
AF93C46(08bit)@SOIC8 [ (SA602A) ]	AF93C46(08bit)@TSOP8
[ (SA026) ]	
AF93C46(16bit)	AF93C46(16bit)@SOIC8
[ (SA602A) ]	
AF93C46(16bit)@TSOP8 [ (SA026) ]	AF93C56
(08bit)	
AF93C56(08bit)@SOIC8 [ (SA602A) ]	AF93C56(08bit)@TSOP8
[ (SA026) ]	
AF93C56(16bit)	AF93C56(16bit)@SOIC8
[ (SA602A) ]	
AF93C56(16bit)@TSOP8 [ (SA026) ]	AF93C66
(08bit)	
AF93C66(08bit)@SOIC8 [ (SA602A) ]	AF93C66(08bit)@TSOP8
[ (SA026) ]	
AF93C66(16bit)	AF93C66(16bit)@SOIC8
[ (SA602A) ]	



AF93C66(16bit)@TSOP8 [(SA026)]  
 (08bit)  
 AF93C86(08bit)@SOIC8 [(SA602A)]  
 [(SA026)]  
 AF93C86(16bit)  
 [(SA602A)]  
 AF93C86(16bit)@TSOP8 [(SA026)]

AF93C86  
 AF93C86(08bit)@TSOP8  
 AF93C86(16bit)@SOIC8

## ARTSCHIP

### E ( E ) PROM / FRAM / NVRAM

24AA02  
 [(SA666)]  
 24AA02@SOIC8 [(SA602A)]  
 [(SA698)]  
 24AA02@TSSOP8 [(SA026)]  
 24LC01A  
 24LC01A@SOIC8 [(SA602A)]  
 [(SA698)]  
 24LC01A@TSSOP8 [(SA026)]  
 24LC01B  
 24LC01B@SOIC8 [(SA602A)]  
 [(SA698)]  
 24LC01B@TSSOP8 [(SA026)]  
 24LC02A  
 24LC02A@SOIC8 [(SA602A)]  
 [(SA698)]  
 24LC02A@TSSOP8 [(SA026)]  
 24LC02B  
 24LC02B@MSOP8 [(SA666)]  
 [(SA602A)]  
 24LC02B@SOT5 [(SA698)]  
 [(SA026)]  
 24LC04A  
 [(SA602A)]  
 24LC04A@SOT5 [(SA698)]  
 [(SA026)]  
 24LC04B  
 [(SA666)]  
 24LC04B@SOIC8 [(SA602A)]  
 [(SA698)]

24AA02@MSOP8  
 24AA02@SOT5  
 24LC01A@SOT5  
 24LC01B@SOT5  
 24LC02A@SOT5  
 24LC02B@SOIC8  
 24LC02B@TSSOP8  
 24LC04A@SOIC8  
 24LC04A@TSSOP8  
 24LC04B@MSOP8  
 24LC04B@SOT5

24LC04B@TSSOP8 [(SA026)]	
24LC08A	
24LC08A@SOIC8 [(SA602A)]	24LC08A@SOT5
[(SA698)]	
24LC08A@TSSOP8 [(SA026)]	
24LC08B	
24LC08B@MSOP8 [(SA666)]	24LC08B@SOIC8
[(SA602A)]	
24LC08B@SOT5 [(SA698)]	24LC08B@TSSOP8
[(SA026)]	
24LC16A	
[(SA602A)]	24LC16A@SOIC8
24LC16A@SOT5 [(SA698)]	24LC16A@TSSOP8
[(SA026)]	
24LC32	24LC32@SOIC14
[(SA026)]	
24LC32@SOIC8 [(SA602A)]	24LC32@TSSOP8
[(SA026)]	
24LC64	24LC64@SOIC14
[(SA026)]	
24LC64@SOIC8 [(SA602A)]	24LC64@TSSOP8
[(SA026)]	

## **ASAHI KASEI(AKM)**

### **E ( E ) PROM / FRAM / NVRAM**

AK27CX161	
AK27CX162	
AK27CX321	
AK27CX322	
AK27CX641	
AK27CX642	
AK6002A(F)@SOP8 [(SA602A)]	AK6002A(V)@TSSOP8
[(SA026)]	
AK6003A(V)@TSSOP8 [(SA026)]	AK6004A(F)@SOP8
[(SA602A)]	
AK6004A(M)@SSOP8 [(SA605A)]	AK6008A(F)@SOP8
[(SA602A)]	
AK6010A(F)@SOP8 [(SA602A)]	AK6012A(F)@SOP8
[(SA602A)]	
AK6416A(M)@SSOP8 [(SA026)]	AK6416C(F)@SOP8

[ ( SA602A ) ]	
AK6420A ( F ) @SOP8 [ ( SA602A ) ]	AK6420A ( M ) @SSOP8
[ ( SA605A ) ]	
AK6420B ( H ) @MSOP8 [ ( SA666 ) ]	AK6440A ( F ) @SOP8
[ ( SA602A ) ]	
AK6440A ( M ) @SSOP8 [ ( SA605A ) ]	AK6440B ( H ) @MSOP8
[ ( SA666 ) ]	
AK6480A ( F ) @SOP8 [ ( SA602A ) ]	AK6480A ( M ) @SSOP8
[ ( SA605A ) ]	
AK6480B ( H ) @MSOP8 [ ( SA666 ) ]	AK6480C ( F ) @SOP8
[ ( SA602A ) ]	
AK6480C ( H ) @MSOP8 [ ( SA666 ) ]	AK6480C ( L )
@SON8	
AK6480C ( M ) @SSOP8 [ ( SA605A ) ]	AK6481C ( H ) @MSOP8
[ ( SA666 ) ]	
AK6481C ( M ) @SSOP8 [ ( SA605A ) ]	AK6508C ( T ) @MSOP8
[ ( SA666 ) ]	
AK6508C ( U ) @USON8	AK6510C ( L )
@SONW8	
AK6510C ( M ) @SSOP8 [ ( SA026 ) ]	AK6512C ( L )
@SONW8	
AK6512C ( M ) @SSOP8 [ ( SA026 ) ]	AK6514C ( F ) @SOP8
[ ( SA602A ) ]	
AK6514C ( N ) @QFN20 [ ( SA692 ) ]	AK6516C ( F ) @SOP8
[ ( SA602A ) ]	
AK93C10A ( F ) @SOP8 [ ( SA602A ) ]	AK93C41A ( V ) @TSSOP8
[ ( SA026 ) ]	
AK93C45	AK93C45 ( F ) @SOP8
[ ( SA602A ) ]	
AK93C45A ( F ) @SOP8 [ ( SA602A ) ]	AK93C45A ( NF ) @SOP8
[ ( SA602A ) ]	
AK93C45A ( V ) @TSSOP8 [ ( SA026 ) ]	AK93C45B ( H ) @MSOP8
[ ( SA666 ) ]	
AK93C45B ( L ) @SON8	AK93C45C ( T ) @MSOP8
[ ( SA666 ) ]	
AK93C45C ( U ) @USON8	
AK93C45L	
AK93C45L ( F ) @SOP8 [ ( SA602A ) ]	
AK93C46	
AK93C46 ( F ) @SOP8 [ ( SA602A ) ]	AK93C46A ( F ) @SOP8
[ ( SA602A ) ]	
AK93C46A ( NF ) @SOP8 [ ( SA602A ) ]	AK93C46A ( V ) @TSSOP8
[ ( SA026 ) ]	

AK93C46B(H)@MSOP8 [(SA666)] @SON8	AK93C46B(L)
AK93C46C(T)@MSOP8 [(SA666)] @USON8	AK93C46C(U)
AK93C46L [(SA602A)]	AK93C46L(F)@SOP8
AK93C51A(V)@TSSOP8 [(SA026)] AK93C55	
AK93C55(F)@SOP8 [(SA602A)] [(SA602A)]	AK93C55A(F)@SOP8
AK93C55A(NF)@SOP8 [(SA602A)] [(SA026)]	AK93C55A(V)@TSSOP8
AK93C55B(H)@MSOP8 [(SA666)] @SON8	AK93C55B(L)
AK93C55C(T)@MSOP8 [(SA666)] @USON8	AK93C55C(U)
AK93C55L [(SA602A)]	AK93C55L(F)@SOP8
AK93C56 [(SA602A)]	AK93C56(F)@SOP8
AK93C56A(F)@SOP8 [(SA602A)] [(SA602A)]	AK93C56A(NF)@SOP8
AK93C56A(V)@TSSOP8 [(SA026)] [(SA666)]	AK93C56B(H)@MSOP8
AK93C56B(L)@SON8 [(SA666)]	AK93C56C(T)@MSOP8
AK93C56C(U)@USON8 AK93C56L	
AK93C56L(F)@SOP8 [(SA602A)] [(SA026)]	AK93C61A(V)@TSSOP8
AK93C65 [(SA602A)]	AK93C65(F)@SOP8
AK93C65A(F)@SOP8 [(SA602A)] [(SA602A)]	AK93C65A(NF)@SOP8
AK93C65A(V)@TSSOP8 [(SA026)] [(SA666)]	AK93C65B(H)@MSOP8
AK93C65B(L)@SON8 [(SA666)]	AK93C65C(T)@MSOP8
AK93C65C(U)@USON8 AK93C65L	
AK93C65L(F)@SOP8 [(SA602A)] AK93C66	
AK93C66(F)@SOP8 [(SA602A)]	AK93C66A(F)@SOP8

[ ( SA602A ) ]	
AK93C66A(NF)@SOP8 [ ( SA602A ) ]	AK93C66A(V)@TSSOP8
[ ( SA026 ) ]	
AK93C66B(H)@MSOP8 [ ( SA666 ) ]	AK93C66B(L)
@SON8	
AK93C66C(T)@MSOP8 [ ( SA666 ) ]	AK93C66C(U)
@USON8	
AK93C66L	AK93C66L(F)@SOP8
[ ( SA602A ) ]	
AK93C75	AK93C75(F)@SOP8
[ ( SA602A ) ]	
AK93C75A(F)@SOP8 [ ( SA602A ) ]	AK93C75A(NF)@SOP8
[ ( SA602A ) ]	
AK93C75A(V)@TSSOP8 [ ( SA026 ) ]	AK93C75B(H)@MSOP8
[ ( SA666 ) ]	
AK93C75L	AK93C75L(F)@SOP8
[ ( SA602A ) ]	
AK93C85	AK93C85(F)@SOP8
[ ( SA602A ) ]	
AK93C85L	AK93C85L(F)@SOP8
[ ( SA602A ) ]	
AK93C95A(F)@SOP8 [ ( SA602A ) ]	AK9822(M)@SSOP8
[ ( SA026 ) ]	
AK9824(M)@SSOP8 [ ( SA026 ) ]	AK9844@SOIC14
[ ( SA602 ) ]	

## ASD

### E ( E ) PROM / FRAM / NVRAM

AE29F1008  
AE29F2008

## ASI

### E ( E ) PROM / FRAM / NVRAM

AS58C1001	AS58C1001@PLCC32
[ ( SA015A1T ) ]	
AS58C1001@SSOP32 [ ( SA438T ) ]	

## ASP

### MICROCONTROLLER

AP827C51 [ (SA244) ]	AP827C51@PLCC44
AP827C52 [ (SA244) ]	AP827C52@PLCC44
AP827C54 [ (SA244) ]	AP827C54@PLCC44
AP827C58 [ (SA244) ]	AP827C58@PLCC44

## ATC

### E (E) PROM/FRAM/NVRAM

ATC24C02 [ (SA602A) ]	ATC24C02@SOIC8
ATC24C02@TSSOP8 [ (SA026) ]	
ATC24C04 [ (SA026) ]	ATC24C04@TSSOP8
ATC24C04@SOIC8 [ (SA602A) ]	
ATC24C08 [ (SA602A) ]	ATC24C08@SOIC8
ATC24C08@TSSOP8 [ (SA026) ]	
ATC24C16 [ (SA026) ]	ATC24C16@TSSOP8
ATC24C16@SOIC8 [ (SA602A) ]	
ATC24LC02 [ (SA602A) ]	ATC24LC02@SOIC8
ATC24LC02@TSSOP8 [ (SA026) ]	
ATC24LC02A [ (SA026) ]	ATC24LC02A@TSSOP8
ATC24LC02A@SOIC8 [ (SA602A) ]	
ATC24LC04 [ (SA602A) ]	ATC24LC04@SOIC8
ATC24LC04@TSSOP8 [ (SA026) ]	
ATC24LC08	

ATC24LC08@SOIC8 [(SA602A)]	ATC24LC08@TSSOP8
[(SA026)]	
ATC24LC16	ATC24LC16@SOIC8
[(SA602A)]	
ATC24LC16@TSSOP8 [(SA026)]	ATC93C46
(08bit)	
ATC93C46(08bit)@SOIC8 [(SA602A)]	ATC93C46
(16bit)	
ATC93C46(16bit)@SOIC8 [(SA602A)]	
ATC93C46R(08bit)@SOIC8 [(SA602A)]	
ATC93C46R(16bit)@SOIC8 [(SA602A)]	
ATC93C56(08bit)	ATC93C56(08bit)@SOIC8
[(SA602A)]	
ATC93C56(16bit)	ATC93C56(16bit)@SOIC8
[(SA602A)]	
ATC93C56R(08bit)@SOIC8 [(SA602A)]	
ATC93C56R(16bit)@SOIC8 [(SA602A)]	
ATC93C66(08bit)	ATC93C66(08bit)@SOIC8
[(SA602A)]	
ATC93C66(16bit)	ATC93C66(16bit)@SOIC8
[(SA602A)]	
ATC93C66R(08bit)@SOIC8 [(SA602A)]	
ATC93C66R(16bit)@SOIC8 [(SA602A)]	
ATC93LC46(08bit)	
ATC93LC46(08bit)@SOIC8 [(SA602A)]	
ATC93LC46(16bit)	
ATC93LC46(16bit)@SOIC8 [(SA602A)]	
ATC93LC46R(08bit)@SOIC8 [(SA602A)]	
ATC93LC46R(16bit)@SOIC8 [(SA602A)]	
ATC93LC56(08bit)	
ATC93LC56(08bit)@SOIC8 [(SA602A)]	
ATC93LC56(16bit)	
ATC93LC56(16bit)@SOIC8 [(SA602A)]	
ATC93LC56R(08bit)@SOIC8 [(SA602A)]	
ATC93LC56R(16bit)@SOIC8 [(SA602A)]	
ATC93LC66(08bit)	
ATC93LC66(08bit)@SOIC8 [(SA602A)]	
ATC93LC66(16bit)	
ATC93LC66(16bit)@SOIC8 [(SA602A)]	
ATC93LC66R(08bit)@SOIC8 [(SA602A)]	
ATC93LC66R(16bit)@SOIC8 [(SA602A)]	

**ATMEL****E ( E ) PROM / FRAM / NVRAM**

AT17C002@PLCC20 [(SA001A)]	AT17C002@PLCC44
[(SA244)]	
AT17C002@SOIC20 [(SA404)]	AT17C002@TQFP44
[(SA245A)]	
AT17C002A@PLCC20 [(SA001A)]	AT17C002A@TQFP32
[(SA663)]	
AT17C010	AT17C010@PLCC20
[(SA001A)]	
AT17C010A	AT17C010A@PLCC20
[(SA001A)]	
AT17C040@PLCC44 [(SA244)]	AT17C040@TQFP44
[(SA245A)]	
AT17C128	AT17C128@PLCC20
[(SA001A)]	
AT17C128@SOIC20 [(SA404)]	AT17C128@SOIC8
[(SA602A)]	
AT17C128A@PLCC20 [(SA001A)]	
AT17C256	
AT17C256@PLCC20 [(SA001A)]	AT17C256@SOIC20
[(SA404)]	
AT17C256@SOIC8 [(SA602A)]	AT17C256A@PLCC20
[(SA001A)]	
AT17C512	AT17C512@PLCC20
[(SA001A)]	
AT17C512A	AT17C512A@PLCC20
[(SA001A)]	
AT17C65	AT17C65@PLCC20
[(SA001A)]	
AT17C65@SOIC20 [(SA404)]	AT17C65@SOIC8
[(SA602A)]	
AT17C65A@PLCC20 [(SA001A)]	AT17F040@LAP8
[(SA760)]	
AT17F040@PLCC20 [(SA001A)]	
AT17F040@PLCC20 (Virtex Pinout) [(SA001A)]	
AT17F040A@LAP8 [(SA760)]	AT17F040A@PLCC20
[(SA001A)]	
AT17F040A@TQFP32 [(SA663)]	AT17F080@LAP8
[(SA760)]	
AT17F080@PLCC20 [(SA001A)]	AT17F080@PLCC44



[(SA244)]	
AT17F080@TQFP44 [(SA245A)]	AT17F080A@LAP8
[(SA760)]	
AT17F080A@PLCC20 [(SA001A)]	AT17F080A@TQFP32
[(SA001A)]	
AT17F16@LAP8 [(SA760)]	AT17F16@PLCC20
[(SA001A)]	
AT17F16@PLCC44 [(SA244)]	AT17F16@TQFP44
[(SA245A)]	
AT17F16A@LAP8 [(SA760)]	AT17F16A@PLCC20
[(SA001A)]	
AT17F32@PLCC44 [(SA244)]	AT17F32A@PLCC44
[(SA244)]	
AT17LV002@PLCC20 [(SA001A)]	AT17LV002@PLCC44
[(SA244)]	
AT17LV002@SOIC20 [(SA404)]	AT17LV002@TQFP44
[(SA245A)]	
AT17LV002A@PLCC20 [(SA001A)]	AT17LV002A@TQFP32
[(SA663)]	
AT17LV010	AT17LV010@PLCC20
[(SA001A)]	
AT17LV010A	AT17LV010A@PLCC20
[(SA001A)]	
AT17LV040@PLCC44 [(SA244)]	AT17LV040@TQFP44
[(SA245A)]	
AT17LV128	AT17LV128@PLCC20
[(SA001A)]	
AT17LV128@SOIC20 [(SA404)]	AT17LV128@SOIC8
[(SA602A)]	
AT17LV128A@PLCC20 [(SA001A)]	
AT17LV256	
AT17LV256@PLCC20 [(SA001A)]	AT17LV256@SOIC20
[(SA404)]	
AT17LV256@SOIC8 [(SA602A)]	AT17LV256A@PLCC20
[(SA001A)]	
AT17LV512	AT17LV512@PLCC20
[(SA001A)]	
AT17LV512A	AT17LV512A@PLCC20
[(SA001A)]	
AT17LV65	AT17LV65@PLCC20
[(SA001A)]	
AT17LV65@SOIC20 [(SA404)]	AT17LV65@SOIC8
[(SA602A)]	

AT17LV65A@PLCC20 [(SA001A)]	AT17N002@SOIC20
[(SA404)]	
AT17N002@TQFP44 [(SA245A)]	
AT17N010	
AT17N010@SOIC20 [(SA404)]	AT17N040@TQFP44
[(SA245A)]	
AT17N256	AT17N256@SOIC20
[(SA404)]	
AT17N256@SOIC8 [(SA602A)]	
AT17N512	
AT17N512@SOIC20 [(SA404)]	
AT24C01	
AT24C01@MSOP8 [(SA666)]	AT24C01@SOIC8
[(SA602A)]	
AT24C01@TSSOP8 [(SA026)]	
AT24C01A	
AT24C01A@MAP8 [(SA724)]	AT24C01A@SOIC8
[(SA602A)]	
AT24C01A@SOT23-5 [(SA717)]	AT24C01A@TSSOP8
[(SA026)]	
AT24C01B	
AT24C01B@dBGA2	
AT24C01B@MAP8 [(SA724)]	AT24C01B@SOIC8
[(SA602A)]	
AT24C01B@SOT23 [(SA717)]	AT24C01B@TSSOP8
[(SA026)]	
AT24C02	AT24C02@SOIC8
[(SA602A)]	
AT24C02@TSSOP8 [(SA026)]	
AT24C02A	
AT24C02A@SOIC8 [(SA602A)]	AT24C02A@TSSOP8
[(SA026)]	
AT24C02B	
AT24C02B@dBGA2	
AT24C02B@MAP8 [(SA724)]	AT24C02B@SOIC8
[(SA602A)]	
AT24C02B@SOT23 [(SA717)]	AT24C02B@TSSOP8
[(SA026)]	
AT24C04	AT24C04@MAP8
[(SA724)]	
AT24C04@SOIC8 [(SA602A)]	AT24C04@SOT23-5
[(SA717)]	
AT24C04@TSSOP8 [(SA026)]	

AT24C04A

AT24C04A@MAP8 [(SA724)]

[(SA602A)]

AT24C04A@TSSOP8 [(SA026)]

AT24C08

AT24C08@MAP8 [(SA724)]

[(SA602A)]

AT24C08@TSSOP8 [(SA026)]

AT24C08A

AT24C08A@MAP8 [(SA724)]

[(SA602A)]

AT24C08A@TSSOP8 [(SA026)]

AT24C1024

AT24C1024@LAP8 [(SA724)]

[(SA684)]

AT24C1024@SOIC8 [(SA023A)]

(1.8V)

AT24C1024B(1.8V)@LAP8 [(SA724)]

[(SA684)]

AT24C1024B(1.8V)@SOIC8 [(SA023A)]

AT24C1024B(1.8V)@TSSOP8 [(SA026)]

AT24C1024B(2.5V)

[(SA724)]

AT24C1024B(2.5V)@SAP8 [(SA684)]

AT24C1024B(2.5V)@SOIC8 [(SA023A)]

AT24C1024B(2.5V)@TSSOP8 [(SA026)]

AT24C11

[(SA602A)]

AT24C11@TSSOP8 [(SA026)]

(1.8V)

AT24C128(1.8V)@MAP8 [(SA724)]

[(SA683)]

AT24C128(1.8V)@SOIC8 [(SA602A)]

[(SA026)]

AT24C128(2.7V)

[(SA724)]

AT24C128(2.7V)@SAP8 [(SA683)]

[(SA602A)]

AT24C128(2.7V)@TSSOP8 [(SA026)]

AT24C128B

AT24C128B@MAP8 [(SA724)]

[(SA683)]

AT24C128B@SOIC8 [(SA602A)]

AT24C04A@SOIC8

AT24C08@SOIC8

AT24C08A@SOIC8

AT24C1024@SAP8

AT24C1024B

AT24C1024B(1.8V)@SAP8

AT24C1024B(2.5V)@LAP8

AT24C11@SOIC8

AT24C128

AT24C128(1.8V)@SAP8

AT24C128(1.8V)@TSSOP8

AT24C128(2.7V)@MAP8

AT24C128(2.7V)@SOIC8

AT24C128B@SAP8

AT24C128B@TSSOP8

[(SA026)]	
AT24C16	AT24C16@SOIC8
[(SA602A)]	
AT24C16@TSSOP8 [(SA026)]	
AT24C164	
AT24C164@SOIC8 [(SA602A)]	
AT24C16A	
AT24C16A@MAP8 [(SA724)]	AT24C16A@SOIC8
[(SA602A)]	
AT24C16A@TSSOP8 [(SA026)]	
AT24C16B	
AT24C16B@MAP8 [(SA724)]	AT24C16B@SOIC8
[(SA602A)]	
AT24C16B@TSSOP8 [(SA026)]	
AT24C21	
AT24C21@SOIC8 [(SA602A)]	AT24C256
(1.8V)	
AT24C256(1.8V)@MAP8 [(SA724)]	AT24C256(1.8V)@SAP8
[(SA683)]	
AT24C256(1.8V)@SOIC8 [(SA602A)]	AT24C256(1.8V)@TSSOP8
[(SA026)]	
AT24C256(2.7V)	
[(SA724)]	AT24C256(2.7V)@MAP8
AT24C256(2.7V)@SAP8 [(SA683)]	AT24C256(2.7V)@SOIC8
[(SA602A)]	
AT24C256(2.7V)@TSSOP8 [(SA026)]	
AT24C256B	
AT24C256B@MAP8 [(SA724)]	AT24C256B@SAP8
[(SA683)]	
AT24C256B@SOIC8 [(SA602A)]	AT24C256B@TSSOP8
[(SA026)]	
AT24C32	AT24C32@SOIC8
[(SA602A)]	
AT24C32@TSSOP8 [(SA026)]	
AT24C32A	
AT24C32A@MAP8 [(SA724)]	AT24C32A@SOIC8
[(SA602A)]	
AT24C32A@TSSOP8 [(SA026)]	
AT24C32C	
AT24C32C@dBGA8 [(BBBB)]	AT24C32C@MAP8
[(SA724)]	
AT24C32C@SAP8 [(SA683)]	AT24C32C@SOIC8
[(SA602A)]	

AT24C32C@TSSOP8 [(SA026)] (1.8V)	AT24C512
AT24C512(1.8V)@LAP8 [(SA684)] [(SA683)]	AT24C512(1.8V)@SAP8
AT24C512(1.8V)@SOIC8 [(SA602A)] [(SA026)]	AT24C512(1.8V)@TSSOP8
AT24C512(2.7V) [(SA684)]	AT24C512(2.7V)@LAP8
AT24C512(2.7V)@SAP8 [(SA683)] [(SA602A)]	AT24C512(2.7V)@SOIC8
AT24C512(2.7V)@TSSOP8 [(SA026)]	
AT24C512B	
AT24C512B@LAP8 [(SA684)] [(SA683)]	AT24C512B@SAP8
AT24C512B@SOIC8 [(SA602A)] [(SA026)]	AT24C512B@TSSOP8
AT24C64 [(SA602A)]	AT24C64@SOIC8
AT24C64@TSSOP8 [(SA026)]	
AT24C64A	
AT24C64A@MAP8 [(SA724)] [(SA602A)]	AT24C64A@SOIC8
AT24C64A@TSSOP8 [(SA026)]	
AT24C64B	
AT24C64B@SOIC8 [(SA602A)] [(SA026)]	AT24C64B@TSSOP8
AT24C64C [(BBBB)]	AT24C64C@DBG8
AT24C64C@MAP8 [(SA724)] [(SA683)]	AT24C64C@SAP8
AT24C64C@SOIC8 [(SA602A)] [(SA026)]	AT24C64C@TSSOP8
AT24CS128 [(SA602A)]	AT24CS128@SOIC8
AT24HC02B [(SA602A)]	AT24HC02B@SOIC8
AT24HC02B@TSSOP8 [(SA026)] [(SA602A)]	AT24RF08AN@SOIC8
AT24RF08AT@TSSOP14 [(SA026)] [(SA602A)]	AT24RF08BN@SOIC8
AT24RF08BT@TSSOP14 [(SA026)] [(SA602A)]	AT24RF08CN@SOIC8
AT24RF08CT@TSSOP14 [(SA026)]	

AT25010	
AT25010@SOIC8 [(SA602A)]	
AT25010A	
AT25010A@SOIC8 [(SA602A)]	AT25010A@TSSOP8
[(SA026)]	
AT25020	AT25020@SOIC8
[(SA602A)]	
AT25020A	AT25020A@SOIC8
[(SA602A)]	
AT25020A@TSSOP8 [(SA026)]	
AT25040	
AT25040(ISP) [ISP-HEADER01]	AT25040@SOIC8
[(SA602A)]	
AT25040@SOIC8(ISP) [ISP-HEADER01]	
AT25040A	AT25040A(ISP) [ISP-
HEADER01]	
AT25040A@SOIC8 [(SA602A)]	
AT25040A@SOIC8(ISP) [ISP-HEADER01]	
AT25080	AT25080@SOIC8
[(SA602A)]	
AT25080@TSSOP14 [(SA026)]	AT25080@TSSOP20
[(SA026)]	
AT25080A	AT25080A@SOIC8
[(SA602A)]	
AT25080A@TSSOP14 [(SA026)]	
AT25128	
AT25128@SOIC16 [(SA602)]	AT25128@SOIC8
[(SA602A)]	
AT25128@TSSOP14 [(SA026)]	AT25128@TSSOP20
[(SA026)]	
AT25128A	AT25128A@dBGA8
[(BBBB)]	
AT25128A@SAP8 [(SA683)]	AT25128A@SOIC8(4.0)
[(SA602A)]	
AT25128A@SOIC8(5.4) [(SA605A)]	AT25128A@TSSOP14
[(SA026)]	
AT25128A@TSSOP8 [(SA026)]	
AT25160	
AT25160@SOIC8 [(SA602A)]	AT25160@TSSOP14
[(SA026)]	
AT25160@TSSOP20 [(SA026)]	
AT25160A	
AT25160A@SOIC8 [(SA602A)]	AT25160A@TSSOP14

[(SA026)]	
AT25256	AT25256@SOIC16
[(SA602)]	
AT25256@SOIC8 [(SA602A)]	AT25256@TSSOP14
[(SA026)]	
AT25256@TSSOP20 [(SA026)]	
AT25256A	
AT25256A@dBGA8 [(BBBB)]	AT25256A@SAP8
[(SA683)]	
AT25256A@SOIC8(4.0) [(SA602A)]	AT25256A@SOIC8(5.4)
[(SA605A)]	
AT25256A@TSSOP14 [(SA026)]	AT25256A@TSSOP8
[(SA026)]	
AT25320	AT25320@SOIC8
[(SA602A)]	
AT25320@TSSOP14 [(SA026)]	AT25320@TSSOP20
[(SA026)]	
AT25320A	AT25320A@SOIC8
[(SA602A)]	
AT25320A@TSSOP14 [(SA026)]	
AT25640	
AT25640@SOIC8 [(SA602A)]	AT25640@TSSOP14
[(SA026)]	
AT25640@TSSOP20 [(SA026)]	
AT25640A	
AT25640A@SOIC8 [(SA602A)]	AT25640A@TSSOP14
[(SA026)]	
AT25DF041A@MLF8 [(SA683)]	AT25DF041A@SOIC8(4.0)
[(SA602A)]	
AT25DF041A@SOIC8(5.4) [(SA605A)]	AT25DF641@SOIC16
[(SA404)]	
AT25DF641@VDFN8 [(SA683)]	
AT25F1024	
AT25F1024(W)@SOIC8 [(SA605A)]	AT25F1024(W)@VQFPN8
[(SA684)]	
AT25F1024@SOIC8 [(SA602A)]	AT25F1024@VQFPN8
[(SA683)]	
AT25F1024A	AT25F1024A(W)@SOIC8
[(SA605A)]	
AT25F1024A(W)@VQFPN8 [(SA684)]	AT25F1024A@SOIC8
[(SA602A)]	
AT25F1024A@VQFPN8 [(SA683)]	
AT25F2048	

AT25F2048(W)@SOIC8 [(SA605A)]	AT25F2048(W)@VQFPN8
[(SA684)]	
AT25F2048@SOIC8 [(SA602A)]	AT25F2048@VQFPN8
[(SA683)]	
AT25F2048A	AT25F2048A(W)@SOIC8
[(SA605A)]	
AT25F2048A(W)@VQFPN8 [(SA684)]	AT25F2048A@SOIC8
[(SA602A)]	
AT25F2048A@VQFPN8 [(SA683)]	
AT25F4096	
AT25F4096(W)@SOIC8 [(SA605A)]	AT25F4096(W)@VQFPN8
[(SA684)]	
AT25F4096@SOIC8 [(SA602A)]	AT25F4096@VQFPN8
[(SA683)]	
AT25F4096A	AT25F4096A(W)@SOIC8
[(SA605A)]	
AT25F4096A(W)@VQFPN8 [(SA684)]	AT25F4096A@SOIC8
[(SA602A)]	
AT25F4096A@VQFPN8 [(SA683)]	
AT25F512	
AT25F512(W)@SOIC8 [(SA605A)]	AT25F512(W)@VQFPN8
[(SA684)]	
AT25F512@SOIC8 [(SA602A)]	AT25F512@VQFPN8
[(SA683)]	
AT25F512A	AT25F512A(W)@SOIC8
[(SA605A)]	
AT25F512A(W)@VQFPN8 [(SA684)]	AT25F512A@SOIC8
[(SA602A)]	
AT25F512A@VQFPN8 [(SA683)]	AT25FS010@SAP8
[(SA683)]	
AT25FS010@SOIC8 [(SA602A)]	AT25FS040@SAP8
[(SA683)]	
AT25FS040@SOIC8 [(SA602A)]	
AT25HP256	
AT25HP256(W)@VQFPN8 [(SA684)]	AT25HP256@SOIC16
[(SA404)]	
AT25HP256@SOIC8 [(SA602A)]	AT25HP256@VQFPN8
[(SA683)]	
AT25HP512	AT25HP512(W)@VQFPN8
[(SA684)]	
AT25HP512@SOIC16 [(SA404)]	AT25HP512@SOIC8
[(SA602A)]	
AT25HP512@VQFPN8 [(SA683)]	AT25P1024@SOIC20



[(SA404)]	
AT25P1024@VQFPN8 [(SA684)]	AT26DF041@MLF8
[(SA683)]	
AT26DF041@SOIC8(4.0) [(SA602A)]	AT26DF041@SOIC8(5.4)
[(SA605A)]	
AT26DF081@SOIC8(4.0) [(SA602A)]	AT26DF081@SOIC8(5.4)
[(SA605A)]	
AT26DF081A@SOIC8(4.0) [(SA602A)]	AT26DF081A@SOIC8(5.4)
[(SA605A)]	
AT26DF161@MLF8 [(SA683)]	AT26DF161@SOIC8
[(SA605A)]	
AT26DF161A@MLF8 [(SA683)]	AT26DF161A@SOIC8
[(SA605A)]	
AT26DF321@MLF8(5*6mm) [(SA683)]	AT26DF321@MLF8(6*8mm)
[(SA684)]	
AT26DF321@SOIC16 [(SA404)]	AT26DF321@SOIC8
[(SA605A)]	
AT26F004@MLF8 [(SA683)]	AT26F004@SOIC8(4.0)
[(SA602A)]	
AT26F004@SOIC8(5.4) [(SA605A)]	
AT27011	
AT27011@PLCC32 [(SA015A1T)]	
AT27256	
AT2732A	
AT27BV010	
AT27BV010@PLCC32 [(SA015A1T)]	AT27BV010@TSOP32
[(SA620)]	
AT27BV020	AT27BV020@PLCC32
[(SA015A1T)]	
AT27BV020@TSOP32 [(SA620)]	
AT27BV040	
AT27BV040@PLCC32 [(SA015A1T)]	AT27BV040@TSOP32
[(SA620)]	
AT27BV1024@PLCC44 [(SA244)]	AT27BV1024@TSOP40
[(SA623)]	
AT27BV256	AT27BV256@PLCC32
[(SA015A1T)]	
AT27BV256@TSOP28 [(SA430T)]	
AT27BV4096	
AT27BV4096@PLCC44 [(SA244)]	AT27BV4096@TSOP40
[(SA623)]	
AT27BV512	AT27BV512@PLCC32
[(SA015A1T)]	

AT27BV512@SOIC28 [(SA630)]	AT27BV512@TSOP28
[(SA430T)]	
AT27BV520@SOIC20 [(SA404)]	AT27BV520@TSOP28
[(SA430T)]	
AT27BV520@TSSOP20 [(SA026)]	
AT27C010	
AT27C010@PLCC32 [(SA015A1T)]	AT27C010@TSOP32
[(SA410T)]	
AT27C010L	AT27C010L@PLCC32
[(SA015A1T)]	
AT27C010L@TSOP32 [(SA410T)]	
AT27C020	
AT27C020@PLCC32 [(SA015A1T)]	AT27C020@TSOP32
[(SA410T)]	
AT27C040	AT27C040@PLCC32
[(SA015A1T)]	
AT27C040@TSOP32 [(SA410T)]	
AT27C080	
AT27C080@PLCC32 [(SA015A1T)]	AT27C080@TSOP32
[(SA410T)]	
AT27C1024	AT27C1024@PLCC44
[(SA244)]	
AT27C1024@TSOP40 [(SA623)]	
AT27C1024L	
AT27C1024L@PLCC44 [(SA244)]	
AT27C128	
AT27C128@PLCC32 [(SA015A1T)]	
AT27C2048	
AT27C2048@PLCC44 [(SA244)]	AT27C2048@TSOP40
[(SA623)]	
AT27C256	AT27C256@PLCC32
[(SA015A1T)]	
AT27C256R	AT27C256R@PLCC32
[(SA015A1T)]	
AT27C256R@SOIC28 [(SA630)]	AT27C256R@TSOP28
[(SA430T)]	
AT27C4096	AT27C4096@PLCC44
[(SA244)]	
AT27C4096@TSOP40 [(SA623)]	
AT27C512	
AT27C512@PLCC32 [(SA015A1T)]	
AT27C512R	
AT27C512R@PLCC32 [(SA015A1T)]	AT27C512R@SOIC28

[ (SA630) ]  
AT27C512R@TSOP28 [ (SA430T) ]  
AT27C513  
AT27C513@PLCC32 [ (SA015A1T) ] AT27C513@SOIC28  
[ (SA630) ]  
AT27C513R AT27C513R@PLCC32  
[ (SA015A1T) ]  
AT27C513R@SOIC28 [ (SA630) ]  
AT27C515  
AT27C515@PLCC32 [ (SA015A1T) ]  
AT27C516  
AT27C516@PLCC44 [ (SA244) ] AT27C516@TSOP40  
[ (SA623) ]  
AT27C520@SOIC20 [ (SA404) ] AT27C520@TSOP28  
[ (SA430T) ]  
AT27C520@TSSOP20 [ (SA026) ]  
AT27C64  
AT27C800 AT27C800@PLCC44  
[ (SA244) ]  
AT27C800@PSOP44 [ (SA638) ]  
AT27HC1024  
AT27HC1024@PLCC44 [ (SA244) ]  
AT27HC256  
AT27HC256@PLCC32 [ (SA015A1T) ]  
AT27HC256L  
AT27HC256L@PLCC32 [ (SA015A1T) ]  
AT27HC256R  
AT27HC256R@PLCC32 [ (SA015A1T) ]  
AT27HC256RL  
AT27HC256RL@PLCC32 [ (SA015A1T) ]  
AT27HC64  
AT27HC64@PLCC32 [ (SA015A1T) ]  
AT27HC641  
AT27HC641@PLCC28 [ (SA008A) ]  
AT27HC641R  
AT27HC641R@PLCC28 [ (SA008A) ]  
AT27HC642  
AT27HC642@PLCC28 [ (SA008A) ]  
AT27HC642R  
AT27HC642R@PLCC28 [ (SA008A) ]  
AT27HC64L  
AT27HC64L@PLCC32 [ (SA015A1T) ]  
AT27LV010

AT27LV010@PLCC32 [(SA015A1T)]	AT27LV010@TSOP32
[(SA620)]	
AT27LV010A	AT27LV010A@PLCC32
[(SA015A1T)]	
AT27LV010A@TSOP32 [(SA620)]	
AT27LV020A	
AT27LV020A@PLCC32 [(SA015A1T)]	AT27LV020A@TSOP32
[(SA620)]	
AT27LV040	AT27LV040@PLCC32
[(SA015A1T)]	
AT27LV040@TSOP32 [(SA620)]	
AT27LV040A	
AT27LV040A@PLCC32 [(SA015A1T)]	AT27LV040A@TSOP32
[(SA620)]	
AT27LV1024	AT27LV1024@PLCC44
[(SA244)]	
AT27LV256A	AT27LV256A@PLCC32
[(SA015A1T)]	
AT27LV256A@SOIC28 [(SA630)]	AT27LV256A@TSOP28
[(SA430T)]	
AT27LV256R	AT27LV256R@PLCC32
[(SA015A1T)]	
AT27LV256R@SOIC28 [(SA630)]	AT27LV256R@TSOP28
[(SA430T)]	
AT27LV4096	AT27LV4096@PLCC44
[(SA244)]	
AT27LV512A	AT27LV512A@PLCC32
[(SA015A1T)]	
AT27LV512A@SOIC28 [(SA630)]	AT27LV512A@TSOP28
[(SA430T)]	
AT27LV512R	AT27LV512R@PLCC32
[(SA015A1T)]	
AT27LV512R@TSOP28 [(SA430T)]	AT27LV520@SOIC20
[(SA404)]	
AT27LV520@TSOP28 [(SA430T)]	AT27LV520@TSSOP20
[(SA026)]	
AT27LV800	AT27LV800@PSOP44
[(SA638)]	
AT28BV16	AT28BV16@PLCC32
[(SA015A1T)]	
AT28BV16@SOIC24 [(SA404)]	AT28BV16@TSOP28
[(SA430T)]	
AT28BV256	AT28BV256@PLCC32

[ (SA015A1T) ]	
AT28BV256@SOIC28 [ (SA404) ]	AT28BV256@TSOP28
[ (SA430T) ]	
AT28BV64	AT28BV64@PLCC32
[ (SA015A1T) ]	
AT28BV64@SOIC28 [ (SA404) ]	AT28BV64@TSOP28
[ (SA430T) ]	
AT28BV64B	AT28BV64B@PLCC32
[ (SA015A1T) ]	
AT28BV64B@SOIC28 [ (SA404) ]	AT28BV64B@TSOP28
[ (SA430T) ]	
AT28C010	AT28C010@PLCC32
[ (SA015A1T) ]	
AT28C010@PLCC44 [ (SA244) ]	AT28C010@TSOP32
[ (SA410T) ]	
AT28C010E	AT28C010E@PLCC32
[ (SA015A1T) ]	
AT28C010E@PLCC44 [ (SA244) ]	AT28C010E@TSOP32
[ (SA410T) ]	
AT28C04	AT28C04@PLCC32
[ (SA015A1T) ]	
AT28C040	AT28C040@PLCC32
[ (SA015A1T) ]	
AT28C04E	AT28C04E@PLCC32
[ (SA015A1T) ]	
AT28C04F	AT28C04F@PLCC32
[ (SA015A1T) ]	
AT28C16	AT28C16@PLCC32
[ (SA015A1T) ]	
AT28C16@SOIC24 [ (SA404) ]	AT28C16@TSOP28
[ (SA430T) ]	
AT28C16E	AT28C16E@PLCC32
[ (SA015A1T) ]	
AT28C16F	AT28C16F@PLCC32
[ (SA015A1T) ]	
AT28C17	AT28C17@PLCC32
[ (SA015A1T) ]	
AT28C17@SOIC28 [ (SA404) ]	
AT28C17E	
AT28C17E@PLCC32 [ (SA015A1T) ]	
AT28C17F	
AT28C17F@PLCC32 [ (SA015A1T) ]	
AT28C256	

AT28C256@PLCC32 [ (SA015A1T) ]	AT28C256@SOIC28
[ (SA404) ]	
AT28C256@TSOP28 [ (SA430T) ]	
AT28C256E	
AT28C256E@PLCC32 [ (SA015A1T) ]	
AT28C256F	
AT28C256F@PLCC32 [ (SA015A1T) ]	
AT28C64	
AT28C64@PLCC32 [ (SA015A1T) ]	AT28C64@SOIC28
[ (SA404) ]	
AT28C64@TSOP28 [ (SA430T) ]	
AT28C64B	
AT28C64B@PLCC32 [ (SA015A1T) ]	AT28C64B@SOIC28
[ (SA404) ]	
AT28C64B@TSOP28 [ (SA430T) ]	
AT28C64E	
AT28C64E@PLCC32 [ (SA015A1T) ]	AT28C64E@TSOP28
[ (SA430T) ]	
AT28C64F	AT28C64F@PLCC32
[ (SA015A1T) ]	
AT28C64F@TSOP28 [ (SA430T) ]	
AT28C64X	
AT28C64X@PLCC32 [ (SA015A1T) ]	AT28C64X@SOIC28
[ (SA404) ]	
AT28C64X@TSOP28 [ (SA430T) ]	
AT28HC04	
AT28HC16	
AT28HC16L	
AT28HC191	
AT28HC191L	
AT28HC256	AT28HC256@PLCC32
[ (SA015A1T) ]	
AT28HC256@TSOP28 [ (SA430T) ]	
AT28HC256E	
AT28HC256E@PLCC32 [ (SA015A1T) ]	
AT28HC256F	
AT28HC256F@PLCC32 [ (SA015A1T) ]	
AT28HC256L	
AT28HC256L@PLCC32 [ (SA015A1T) ]	
AT28HC256LE	
AT28HC256LE@PLCC32 [ (SA015A1T) ]	
AT28HC291	
AT28HC291@PLCC28 [ (SA008A) ]	

AT28HC291L	
AT28HC291L@PLCC28 [(SA008A)]	
AT28HC64	
AT28HC64@PLCC32 [(SA015A1T)]	AT28HC64@TSOP28
[(SA430T)]	
AT28HC64B	AT28HC64B@PLCC32
[(SA015A1T)]	
AT28HC64B@SOIC28 [(SA404)]	AT28HC64B@TSOP28
[(SA430T)]	
AT28HC64BF	AT28HC64BF@PLCC32
[(SA015A1T)]	
AT28HC64BF@SOIC28 [(SA404)]	AT28HC64BF@TSOP28
[(SA430T)]	
AT28HC64L	AT28HC64L@PLCC32
[(SA015A1T)]	
AT28HC64L@TSOP28 [(SA430T)]	
AT28LV010	
AT28LV010@PLCC32 [(SA015A1T)]	AT28LV010@TSOP32
[(SA410T)]	
AT28LV256	AT28LV256@PLCC32
[(SA015A1T)]	
AT28LV256@TSOP28 [(SA430T)]	
AT28LV64	
AT28LV64@PLCC32 [(SA015A1T)]	
AT28LV64B	
AT28LV64B@PLCC32 [(SA015A1T)]	AT28LV64B@SOIC28
[(SA404)]	
AT28LV64B@TSOP28 [(SA430T)]	
AT28MC010	
AT28MC010@PLCC32 [(SA015A1T)]	AT28MC010@PLCC44
[(SA244)]	
AT28MC010@TSOP32 [(SA410T)]	
AT28MC020	
AT28MC020@PLCC32 [(SA015A1T)]	AT28MC020@PLCC44
[(SA244)]	
AT28MC020@TSOP32 [(SA410T)]	
AT28MC040	
AT28MC040@PLCC32 [(SA015A1T)]	AT28MC040@PLCC44
[(SA244)]	
AT28MC040@TSOP32 [(SA410T)]	
AT28PC64	
AT28PC64@PLCC32 [(SA015A1T)]	AT28PC64@TSOP28
[(SA430T)]	

AT28PC64E [ (SA015A1T) ]	AT28PC64E@PLCC32
AT28PC64E@TSOP28 [ (SA430T) ] [ (SA015A1T) ]	AT29BV010A@PLCC32
AT29BV010A@TSOP32 [ (SA410T) ] [ (SA015A1T) ]	AT29BV020@PLCC32
AT29BV020@TSOP32 [ (SA410T) ] [ (SA410T) ]	AT29BV040A@TSOP32
AT29C010 [ (SA015A1T) ]	AT29C010@PLCC32
AT29C010@TSOP32 [ (SA410T) ]	
AT29C010A AT29C010A@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AT29C010A@TSOP32
AT29C020 [ (SA015A1T) ]	AT29C020@PLCC32
AT29C020@TSOP32 [ (SA410T) ]	
AT29C040 AT29C040@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AT29C040@TSOP32
AT29C040A [ (SA015A1T) ]	AT29C040A@PLCC32
AT29C040A@TSOP32 [ (SA410T) ] [ (SA244) ]	AT29C1024@PLCC44
AT29C1024@TSOP48 [ (SA247-B005) ]	
AT29C256 AT29C256@PLCC32 [ (SA015A1T) ] [ (SA430T) ]	AT29C256@TSOP28
AT29C257 [ (SA015A1T) ]	AT29C257@PLCC32
AT29C512 [ (SA015A1T) ]	AT29C512@PLCC32
AT29C512@TSOP32 [ (SA410T) ]	
AT29LV010 AT29LV010@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AT29LV010@TSOP32
AT29LV010A@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AT29LV010A@TSOP32
AT29LV020 [ (SA015A1T) ]	AT29LV020@PLCC32
AT29LV020@TSOP32 [ (SA410T) ] [ (SA410T) ]	AT29LV040@TSOP32
AT29LV040A	AT29LV040A@PLCC32



[ (SA015A1T) ]	
AT29LV040A@TSOP32 [ (SA410T) ]	AT29LV1024@PLCC44
[ (SA244) ]	
AT29LV1024@TSOP48 [ (SA247-B005) ]	
AT29LV256	
AT29LV256@PLCC32 [ (SA015A1T) ]	AT29LV256@TSOP28
[ (SA430T) ]	
AT29LV512	AT29LV512@PLCC32
[ (SA015A1T) ]	
AT29LV512@TSOP32 [ (SA410T) ]	
AT32C16	
AT32C16@PLCC44 [ (SA244) ]	
AT34C02	
AT34C02@SOIC8 [ (SA602A) ]	AT34C02@TSSOP8
[ (SA026) ]	
AT34C02B	AT34C02B@SOIC8
[ (SA602A) ]	
AT34C02B@TSSOP8 [ (SA026) ]	
AT34C02C	
AT34C02C@dBGA8 [ (BBBB) ]	AT34C02C@MAP8
[ (SA724) ]	
AT34C02C@SOIC8 [ (SA602A) ]	AT34C02C@TSSOP8
[ (SA026) ]	
AT45BCM021D(page256)@SOIC8 [ (SA605A) ]	
AT45BCM021D(page256)@SOIC8(ISP) [ ISP-HEADER01 ]	
AT45BCM021D(page264)@SOIC8 [ (SA605A) ]	
AT45BCM021D(page264)@SOIC8(ISP) [ ISP-HEADER01 ]	
AT45D011@PLCC32 [ (SA015A1T) ]	AT45D011@SOIC8
[ (SA605A) ]	
AT45D011@TSSOP14 [ (SA026) ]	AT45D021@PLCC32
[ (SA015A1T) ]	
AT45D021@SOIC28 [ (SA630) ]	AT45D021@TSOP28
[ (SA430T) ]	
AT45D041@PLCC32 [ (SA015A1T) ]	AT45D041@SOIC28
[ (SA630) ]	
AT45D041@TSOP28 [ (SA430T) ]	AT45D081@SOIC28
[ (SA630) ]	
AT45D081@TSOP32 [ (SA410T) ]	AT45D161@PLCC32
[ (SA015A1T) ]	
AT45D161@SOIC28 [ (SA630) ]	AT45D161@TSOP28
[ (SA430T) ]	
AT45DB011@PLCC32 [ (SA015A1T) ]	AT45DB011@SOIC8
[ (SA605A) ]	

AT45DB011@TSSOP14 [(SA026)] AT45DB011B@PLCC32  
[(SA015A1T)]  
AT45DB011B@PLCC32(ISP) [ISP-HEADER01]  
AT45DB011B@SOIC8 [(SA605A)]  
AT45DB011B@SOIC8(ISP) [ISP-HEADER01]  
AT45DB011B@TSSOP14 [(SA026)]  
AT45DB011B@TSSOP14(ISP) [ISP-HEADER01]  
AT45DB011D(page264)@QFN8 [ordering number is marked above]  
AT45DB011D(page264)@QFN8(ISP) [ISP-HEADER01]  
AT45DB011D(page264)@SOIC8 [ordering number is marked above]  
AT45DB011D(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB021@PLCC32 [(SA015A1T)] AT45DB021@SOIC28  
[(SA630)]  
AT45DB021@TSOP28 [(SA430T)] AT45DB021A@PLCC32  
[(SA015A1T)]  
AT45DB021A@PLCC32(ISP) [ISP-HEADER01]  
AT45DB021A@SOIC28 [(SA630)]  
AT45DB021A@SOIC28(ISP) [ISP-HEADER01]  
AT45DB021A@TSOP28 [(SA430T)]  
AT45DB021A@TSOP28(ISP) [ISP-HEADER01]  
AT45DB021B@CBGA9 [(SA677A-B089A-K080F001N)]  
AT45DB021B@CBGA9(ISP) [ISP-HEADER01]  
AT45DB021B@SOIC28 [(SA630)]  
AT45DB021B@SOIC28(ISP) [ISP-HEADER01]  
AT45DB021B@SOIC8 [(SA023A)]  
AT45DB021B@SOIC8(ISP) [ISP-HEADER01]  
AT45DB021B@TSOP28 [(SA430T)]  
AT45DB021B@TSOP28(ISP) [ISP-HEADER01]  
AT45DB021D6(page264)@CASON8 [ordering number is marked above]  
AT45DB021D6(page264)@CASON8(ISP) [ISP-HEADER01]  
AT45DB021D6(page264)@SOIC8 [ordering number is marked above]  
AT45DB021D6(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB041@PLCC32 [(SA015A1T)] AT45DB041@SOIC28  
[(SA630)]  
AT45DB041@TSOP28 [(SA430T)] AT45DB041A@PLCC32  
[(SA015A1T)]  
AT45DB041A@PLCC32(ISP) [ISP-HEADER01]  
AT45DB041A@SOIC28 [(SA630)]  
AT45DB041A@SOIC28(ISP) [ISP-HEADER01]  
AT45DB041A@TSOP28 [(SA430T)]  
AT45DB041A@TSOP28(ISP) [ISP-HEADER01]  
AT45DB041B@CASON8 [(SA684)] AT45DB041B@CASON8(ISP)  
[(SA684)]

AT45DB041B@CBGA14 [(SA677A-B089A-K080F001N)]  
AT45DB041B@CBGA14(ISP) [ISP-HEADER01]  
AT45DB041B@SOIC28 [(SA630)]  
AT45DB041B@SOIC28(ISP) [ISP-HEADER01]  
AT45DB041B@SOIC8 [(SA605A)]  
AT45DB041B@SOIC8(ISP) [ISP-HEADER01]  
AT45DB041B@TSOP28 [(SA430T)]  
AT45DB041B@TSOP28(ISP) [ISP-HEADER01]  
AT45DB041D(page256)@QFN8 [(SA683)]  
AT45DB041D(page256)@QFN8(ISP) [ISP-HEADER01]  
AT45DB041D(page256)@SOIC8 [(SA605A)]  
AT45DB041D(page256)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB041D(page264)@QFN8 [(SA683)]  
AT45DB041D(page264)@QFN8(ISP) [ISP-HEADER01]  
AT45DB041D(page264)@SOIC8 [(SA605A)]  
AT45DB041D(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB081@SOIC28 [(SA630)] AT45DB081@TSOP32  
[(SA410T)]  
AT45DB081A@PLCC32 [(SA015A1T)]  
AT45DB081A@PLCC32(ISP) [ISP-HEADER01]  
AT45DB081A@SOIC28 [(SA630)]  
AT45DB081A@SOIC28(ISP) [ISP-HEADER01]  
AT45DB081A@TSOP28 [(SA430T)]  
AT45DB081A@TSOP28(ISP) [ISP-HEADER01]  
AT45DB081B@CASON8 [(SA684)] AT45DB081B@CASON8(ISP)  
[(SA684)]  
AT45DB081B@CBGA14 [(SA677A-B089A-K080F001N)]  
AT45DB081B@CBGA14(ISP) [ISP-HEADER01]  
AT45DB081B@SOIC28 [(SA630)]  
AT45DB081B@SOIC28(ISP) [ISP-HEADER01]  
AT45DB081B@SOIC8 [(SA605A)]  
AT45DB081B@SOIC8(ISP) [ISP-HEADER01]  
AT45DB081B@TSOP28 [(SA430T)]  
AT45DB081B@TSOP28(ISP) [ISP-HEADER01]  
AT45DB081D(page256)@MLF8 [(SA683)]  
AT45DB081D(page256)@QFN8(ISP) [ISP-HEADER01]  
AT45DB081D(page256)@SOIC8 [(SA023A)]  
AT45DB081D(page256)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB081D(page264)@MLF8 [(SA683)]  
AT45DB081D(page264)@QFN8(ISP) [ISP-HEADER01]  
AT45DB081D(page264)@SOIC8 [(SA023A)]  
AT45DB081D(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB161@PLCC32 [(SA015A1T)] AT45DB161@SOIC28

[ (SA630) ]  
AT45DB161@TSOP28 [ (SA430T) ]  
AT45DB161B@CAS0N8 (ISP) [ ISP-HEADER01 ]  
AT45DB161B@CAS0N8 [ (SA684) ] AT45DB161B@SOIC28  
[ (SA630) ]  
AT45DB161B@SOIC28 (ISP) [ ISP-HEADER01 ]  
AT45DB161B@TSOP28 [ (SA430T) ]  
AT45DB161B@TSOP28 (ISP) [ ISP-HEADER01 ]  
AT45DB161D(page512)@QFN8 [ (SA683) ]  
AT45DB161D(page512)@QFN8 (ISP) [ ISP-HEADER01 ]  
AT45DB161D(page512)@SOIC8 [ (SA605A) ]  
AT45DB161D(page512)@SOIC8 (ISP) [ ISP-HEADER01 ]  
AT45DB161D(page512)@TSOP28 [ (SA430T) ]  
AT45DB161D(page512)@TSOP28 (ISP) [ ISP-HEADER01 ]  
AT45DB161D(page528)@QFN8 [ (SA683) ]  
AT45DB161D(page528)@QFN8 (ISP) [ ISP-HEADER01 ]  
AT45DB161D(page528)@SOIC8 [ (SA605A) ]  
AT45DB161D(page528)@SOIC8 (ISP) [ ISP-HEADER01 ]  
AT45DB161D(page528)@TSOP28 [ (SA430T) ]  
AT45DB161D(page528)@TSOP28 (ISP) [ ISP-HEADER01 ]  
AT45DB321@TSOP32 [ (SA410T) ] AT45DB321B@SOIC28  
[ (SA630) ]  
AT45DB321B@SOIC28 (ISP) [ ISP-HEADER01 ]  
AT45DB321B@TSOP32 [ (SA410T) ]  
AT45DB321B@TSOP32 (ISP) [ ISP-HEADER01 ]  
AT45DB321C@CAS0N8 [ (SA684) ]  
AT45DB321C@CAS0N8 (ISP) [ ISP-HEADER01 ]  
AT45DB321C@SOIC28 [ (SA630) ]  
AT45DB321C@SOIC28 (ISP) [ ISP-HEADER01 ]  
AT45DB321C@TSOP28 [ (SA430T) ]  
AT45DB321C@TSOP28 (ISP) [ ISP-HEADER01 ]  
AT45DB321D(page512)@QFN8 [ (SA683) ]  
AT45DB321D(page512)@QFN8 (ISP) [ ISP-HEADER01 ]  
AT45DB321D(page512)@SOIC8 [ (SA023A) ]  
AT45DB321D(page512)@SOIC8 (ISP) [ ISP-HEADER01 ]  
AT45DB321D(page512)@TSOP28 [ (SA430T) ]  
AT45DB321D(page512)@TSOP28 (ISP) [ ISP-HEADER01 ]  
AT45DB321D(page528)@QFN8 [ (SA683) ]  
AT45DB321D(page528)@QFN8 (ISP) [ ISP-HEADER01 ]  
AT45DB321D(page528)@SOIC8 [ (SA023A) ]  
AT45DB321D(page528)@SOIC8 (ISP) [ ISP-HEADER01 ]  
AT45DB321D(page528)@TSOP28 [ (SA430T) ]  
AT45DB321D(page528)@TSOP28 (ISP) [ ISP-HEADER01 ]

AT45DB642@TSOP40 [(SA409T)]  
 AT45DB642@TSOP40(ISP) [ISP-HEADER01]  
 AT45DB642D(page1024)@CAS0N8 [(SA684)]  
 AT45DB642D(page1024)@CAS0N8(ISP) [(ISP-HEADER01)]  
 AT45DB642D(page1024)@TSOP28 [(SA430)]  
 AT45DB642D(page1024)@TSOP28(ISP) [(ISP-HEADER01)]  
 AT45DB642D(page1056)@CAS0N8 [(SA684)]  
 AT45DB642D(page1056)@CAS0N8(ISP) [(ISP-HEADER01)]  
 AT45DB642D(page1056)@TSOP28 [(SA430)]  
 AT45DB642D(page1056)@TSOP28(ISP) [(ISP-HEADER01)]  
 AT45DCB002 [(CARD005-B005)] AT45DCB002(ISP) [ISP-  
 HEADER01]  
 AT45DCB004 [(CARD005-B005)] AT45DCB004(ISP) [ISP-  
 HEADER01]  
 AT45DCB004C [(CARD005-B005)] AT45DCB004C(ISP) [ISP-  
 HEADER01]  
 AT45DCB008 [(CARD005-B005)] AT45DCB008(ISP) [ISP-  
 HEADER01]  
 AT45DCB008D4(page1024) [(CARD005-B005)]  
 AT45DCB008D4(page1024)(ISP) [(ISP-HEADER01)]  
 AT45DCB008D6(page1056) [(CARD005-B005)]  
 AT45DCB008D6(page1056)(ISP) [(ISP-HEADER01)]  
 AT49BV001 AT49BV001@PLCC32  
 [(SA015A1T)]  
 AT49BV001@TSOP32 [(SA410T)] AT49BV001@VSOP32  
 [(SA620)]  
 AT49BV001A AT49BV001A@PLCC32  
 [(SA015A1T)]  
 AT49BV001A@TSOP32 [(SA410T)] AT49BV001A@VSOP32  
 [(SA620)]  
 AT49BV001AN AT49BV001AN@PLCC32  
 [(SA015A1T)]  
 AT49BV001AN@TSOP32 [(SA410T)] AT49BV001AN@VSOP32  
 [(SA620)]  
 AT49BV001ANT AT49BV001ANT@PLCC32  
 [(SA015A1T)]  
 AT49BV001ANT@TSOP32 [(SA410T)] AT49BV001ANT@VSOP32  
 [(SA620)]  
 AT49BV001AT AT49BV001AT@PLCC32  
 [(SA015A1T)]  
 AT49BV001AT@TSOP32 [(SA410T)] AT49BV001AT@VSOP32  
 [(SA620)]  
 AT49BV001N AT49BV001N@PLCC32

[ (SA015A1T) ]	
AT49BV001N@TSOP32 [ (SA410T) ]	AT49BV001N@VSOP32
[ (SA620) ]	
AT49BV001NT	AT49BV001NT@PLCC32
[ (SA015A1T) ]	
AT49BV001NT@TSOP32 [ (SA410T) ]	AT49BV001NT@VSOP32
[ (SA620) ]	
AT49BV001T	AT49BV001T@PLCC32
[ (SA015A1T) ]	
AT49BV001T@TSOP32 [ (SA410T) ]	AT49BV001T@VSOP32
[ (SA620) ]	
AT49BV002	AT49BV002@PLCC32
[ (SA015A1T) ]	
AT49BV002@TSOP32 [ (SA410T) ]	AT49BV002@VSOP32
[ (SA620) ]	
AT49BV002A	AT49BV002A@PLCC32
[ (SA015A1T) ]	
AT49BV002A@TSOP32 [ (SA410T) ]	AT49BV002A@VSOP32
[ (SA620) ]	
AT49BV002AN	AT49BV002AN@PLCC32
[ (SA015A1T) ]	
AT49BV002AN@TSOP32 [ (SA410T) ]	AT49BV002AN@VSOP32
[ (SA620) ]	
AT49BV002ANT	AT49BV002ANT@PLCC32
[ (SA015A1T) ]	
AT49BV002ANT@TSOP32 [ (SA410T) ]	AT49BV002ANT@VSOP32
[ (SA620) ]	
AT49BV002AT	AT49BV002AT@PLCC32
[ (SA015A1T) ]	
AT49BV002AT@TSOP32 [ (SA410T) ]	AT49BV002AT@VSOP32
[ (SA620) ]	
AT49BV002N	AT49BV002N@PLCC32
[ (SA015A1T) ]	
AT49BV002N@TSOP32 [ (SA410T) ]	AT49BV002N@VSOP32
[ (SA620) ]	
AT49BV002NT	AT49BV002NT@PLCC32
[ (SA015A1T) ]	
AT49BV002NT@TSOP32 [ (SA410T) ]	AT49BV002NT@VSOP32
[ (SA620) ]	
AT49BV002T	AT49BV002T@PLCC32
[ (SA015A1T) ]	
AT49BV002T@TSOP32 [ (SA410T) ]	AT49BV002T@VSOP32
[ (SA620) ]	

AT49BV008@TSOP40 [(SA409T)]	AT49BV008A@TSOP40
[(SA409T)]	
AT49BV008A@uBGA48 [(SA634)]	AT49BV008AT@TSOP40
[(SA409T)]	
AT49BV008AT@uBGA48 [(SA634)]	
AT49BV010	
AT49BV010@PLCC32 [(SA015A1T)]	AT49BV010@TSOP32
[(SA410T)]	
AT49BV020	AT49BV020@PLCC32
[(SA015A1T)]	
AT49BV020@TSOP32 [(SA410T)]	
AT49BV040	
AT49BV040@PLCC32 [(SA015A1T)]	AT49BV040@TSOP32
[(SA410T)]	
AT49BV040A@PLCC32 [(SA015A1T)]	AT49BV040A@TSOP32
[(SA410T)]	
AT49BV040A@VSOP32 [(SA620)]	
AT49BV040B@PLCC32 [(SA015A1T-B001)]	
AT49BV040B@TSOP32 [(SA410T-B003)]	
AT49BV040B@VSOP32 [(SA620-B005)]	
AT49BV040T	
AT49BV040T@PLCC32 [(SA015A1T)]	AT49BV040T@TSOP32
[(SA410T)]	
AT49BV080@PSOP44 [(SA638)]	AT49BV080@TSOP40
[(SA409T)]	
AT49BV080T@PSOP44 [(SA638)]	AT49BV080T@TSOP40
[(SA409T)]	
AT49BV1024A@TSOP40 [(SA623)]	AT49BV160@TSOP48 [(SA247-
B005)]	
AT49BV160@uBGA48 [(SA634A-B005A-Y048F001)]	
AT49BV1604@TSOP48 [(SA247-B005)]	
AT49BV1604@uBGA48 [(SA634A-B005A-Y048F001)]	
AT49BV1604A@TSOP48 [(SA247-B005)]	
AT49BV1604A@uBGA48 [(SA634A-B005A-Y048F001)]	
AT49BV1604AT@TSOP48 [(SA247-B005)]	
AT49BV1604AT@uBGA48 [(SA634A-B005A-Y048F001)]	
AT49BV1604T@TSOP48 [(SA247-B005)]	
AT49BV1604T@uBGA48 [(SA634A-B005A-Y048F001)]	
AT49BV160C@TSOP48 [(SA247-B005)]	
AT49BV160C@uBGA48 [(SA634A-B005A-Y048F001)]	
AT49BV160CT@TSOP48 [(SA247-B005)]	
AT49BV160CT@uBGA48 [(SA634A-B005A-Y048F001)]	
AT49BV160D@TSOP48 [(SA247-B005)]	

AT49BV160DT@TSOP48 [ (SA247-B005) ]  
AT49BV160S@FBGA64 [ (SA705A-B147A-W064F001Y) ]  
AT49BV160ST@FBGA64 [ (SA705A-B147A-W064F001Y) ]  
AT49BV160T@TSOP48 [ (SA247-B005) ]  
AT49BV160T@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV161@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV161@TSOP48 [ (SA247-B005) ]  
AT49BV1614@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1614@TSOP48 [ (SA247-B005) ]  
AT49BV1614A@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1614A@TSOP48 [ (SA247-B005) ]  
AT49BV1614AT@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1614AT@TSOP48 [ (SA247-B005) ]  
AT49BV1614T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1614T@TSOP48 [ (SA247-B005) ]  
AT49BV1618@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1618@TSOP48 [ (SA247-B005) ]  
AT49BV1618T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1618T@TSOP48 [ (SA247-B005) ]  
AT49BV161T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV161T@TSOP48 [ (SA247-B005) ]  
AT49BV162A@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV162A@TSOP48 [ (SA247-B005) ]  
AT49BV162AT@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV162AT@TSOP48 [ (SA247-B005) ]  
AT49BV163A@CBGA48 [ (SA642G-B026A-T048F001Y) ]  
AT49BV163A@TSOP48 [ (SA247-B005) ]  
AT49BV163AT@CBGA48 [ (SA642G-B026A-T048F001Y) ]  
AT49BV163AT@TSOP48 [ (SA247-B005) ]  
AT49BV163D@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
AT49BV163D@TSOP48 [ (SA247-B005) ]  
AT49BV163DT@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
AT49BV163DT@TSOP48 [ (SA247-B005) ]  
AT49BV2048@PSOP44 [ (SA638) ] AT49BV2048@TSOP48 [ (SA247-B005) ]  
AT49BV2048A@PSOP44 [ (SA638) ]  
AT49BV2048A@TSOP48 [ (SA247-B005) ]  
AT49BV2048B@TSOP48 [ (SA247-B005) ]  
AT49BV320@TSOP48 [ (SA247-B005) ]  
AT49BV320@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV320C@TSOP48 [ (SA247-B005) ]  
AT49BV320C@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV320CT@TSOP48 [ (SA247-B005) ]



AT49BV320CT@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV320D@FBGA48 [ (SA634A-B005A-Y048F001Y) ]  
AT49BV320D@TSOP48 [ (SA247-B005) ]  
AT49BV320DT@FBGA48 [ (SA634A-B005A-Y048F001Y) ]  
AT49BV320DT@TSOP48 [ (SA247-B005) ]  
AT49BV320S@FBGA64 [ (SA705A-B147A-W064F001Y) ]  
AT49BV320ST@FBGA64 [ (SA705A-B147A-W064F001Y) ]  
AT49BV320T@TSOP48 [ (SA247-B005) ]  
AT49BV320T@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV321@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV321@TSOP48 [ (SA247-B005) ]  
AT49BV3218@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV3218@TSOP48 [ (SA247-B005) ]  
AT49BV3218T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV3218T@TSOP48 [ (SA247-B005) ]  
AT49BV321T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV321T@TSOP48 [ (SA247-B005) ]  
AT49BV322A@FBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV322A@TSOP48 [ (SA247-B005) ]  
AT49BV322AT@FBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV322AT@TSOP48 [ (SA247-B005) ]  
AT49BV322D@FBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49BV322D@TSOP48 [ (SA247-B005) ]  
AT49BV322DT@FBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49BV322DT@TSOP48 [ (SA247-B005) ]  
AT49BV4096@PSOP44 [ (SA638) ]                   AT49BV4096@TSOP48 [ (SA247-  
B005) ]  
AT49BV4096A@PSOP44 [ (SA638) ]  
AT49BV4096A@TSOP48 [ (SA247-B005) ]  
AT49BV4096A@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV512                                           AT49BV512@PLCC32  
[ (SA015A1T) ]  
AT49BV512@TSOP32 [ (SA410T) ]                   AT49BV512@VSOP32  
[ (SA620) ]  
AT49BV640D@FBGA48 [ (SA634A-B005A-Y048F001Y) ]  
AT49BV640D@TSOP56 [ (SA628-B131) ]  
AT49BV640DT@FBGA48 [ (SA634A-B005A-Y048F001Y) ]  
AT49BV640DT@TSOP56 [ (SA628-B131) ]  
AT49BV640S@FBGA64 [ (SA705A-B147A-W064F001Y) ]  
AT49BV640ST@FBGA64 [ (SA705A-B147A-W064F001Y) ]  
AT49BV6416@TSOP48 [ (SA247-B005) ]  
AT49BV6416T@TSOP48 [ (SA247-B005) ]  
AT49BV642D@TSOP48 [ (SA247-B005) ]

AT49BV642DT@TSOP48 [ (SA247-B005) ]  
 AT49BV8004@CBGA48 [ (SA642B-B026A-Y072F001) ]  
 AT49BV8004@TSOP48 [ (SA247-B005) ]  
 AT49BV8004T@CBGA48 [ (SA642B-B026A-Y072F001) ]  
 AT49BV8004T@TSOP48 [ (SA247-B005) ]  
 AT49BV8011@CBGA48 [ (SA642B-B026A-Y072F001) ]  
 AT49BV8011@TSOP48 [ (SA247-B005) ]  
 AT49BV8011T@CBGA48 [ (SA642B-B026A-Y072F001) ]  
 AT49BV8011T@TSOP48 [ (SA247-B005) ]  
 AT49BV802A@CBGA48 [ (SA642B-B026A-Y072F001) ]  
 AT49BV802A@TSOP48 [ (SA247-B005) ]  
 AT49BV802AT@CBGA48 [ (SA642B-B026A-Y072F001) ]  
 AT49BV802AT@TSOP48 [ (SA247-B005) ]  
 AT49BV802D@CBGA48 [ (SA642G-B026A-T048F001Y) ]  
 AT49BV802D@TSOP48 [ (SA247) ]  
 AT49BV802DT@CBGA48 [ (SA642G-B026A-T048F001Y) ]  
 AT49BV802DT@TSOP48 [ (SA247) ] AT49BV8192@PSOP44  
 [ (SA638) ]  
 AT49BV8192@TSOP48 [ (SA247-B005) ]  
 AT49BV8192A@TSOP48 [ (SA247-B005) ]  
 AT49BV8192A@uBGA48 [ (SA634A-B005A-Y048F001) ]  
 AT49BV8192AT@TSOP48 [ (SA247-B005) ]  
 AT49BV8192AT@uBGA48 [ (SA634A-B005A-Y048F001) ]  
 AT49BV8192T@PSOP44 [ (SA638) ]  
 AT49BV8192T@TSOP48 [ (SA247-B005) ]  
 AT49F001 AT49F001@PLCC32  
 [ (SA015A1T) ]  
 AT49F001@TSOP32 [ (SA410T) ] AT49F001@VSOP32  
 [ (SA620) ]  
 AT49F001A AT49F001A@PLCC32  
 [ (SA015A1T) ]  
 AT49F001A@TSOP32 [ (SA410T) ] AT49F001A@VSOP32  
 [ (SA620) ]  
 AT49F001AN AT49F001AN@PLCC32  
 [ (SA015A1T) ]  
 AT49F001AN@TSOP32 [ (SA410T) ] AT49F001AN@VSOP32  
 [ (SA620) ]  
 AT49F001ANT AT49F001ANT@PLCC32  
 [ (SA015A1T) ]  
 AT49F001ANT@TSOP32 [ (SA410T) ] AT49F001ANT@VSOP32  
 [ (SA620) ]  
 AT49F001AT AT49F001AT@PLCC32  
 [ (SA015A1T) ]

AT49F001AT@TSOP32 [(SA410T)]	AT49F001AT@VSOP32
[(SA620)]	
AT49F001N	AT49F001N@PLCC32
[(SA015A1T)]	
AT49F001N@TSOP32 [(SA410T)]	AT49F001N@VSOP32
[(SA620)]	
AT49F001NT	AT49F001NT@PLCC32
[(SA015A1T)]	
AT49F001NT@TSOP32 [(SA410T)]	AT49F001NT@VSOP32
[(SA620)]	
AT49F001T	AT49F001T@PLCC32
[(SA015A1T)]	
AT49F001T@TSOP32 [(SA410T)]	AT49F001T@VSOP32
[(SA620)]	
AT49F002	AT49F002@PLCC32
[(SA015A1T)]	
AT49F002@TSOP32 [(SA410T)]	AT49F002@VSOP32
[(SA620)]	
AT49F002A	AT49F002A@PLCC32
[(SA015A1T)]	
AT49F002A@TSOP32 [(SA410T)]	AT49F002A@VSOP32
[(SA620)]	
AT49F002AN	AT49F002AN@PLCC32
[(SA015A1T)]	
AT49F002AN@TSOP32 [(SA410T)]	AT49F002AN@VSOP32
[(SA620)]	
AT49F002ANT	AT49F002ANT@PLCC32
[(SA015A1T)]	
AT49F002ANT@TSOP32 [(SA410T)]	AT49F002ANT@VSOP32
[(SA620)]	
AT49F002AT	AT49F002AT@PLCC32
[(SA015A1T)]	
AT49F002AT@TSOP32 [(SA410T)]	AT49F002AT@VSOP32
[(SA620)]	
AT49F002N	AT49F002N@PLCC32
[(SA015A1T)]	
AT49F002N@TSOP32 [(SA410T)]	AT49F002N@VSOP32
[(SA620)]	
AT49F002NT	AT49F002NT@PLCC32
[(SA015A1T)]	
AT49F002NT@TSOP32 [(SA410T)]	AT49F002NT@VSOP32
[(SA620)]	
AT49F002T	AT49F002T@PLCC32

[ (SA015A1T) ]	
AT49F002T@TSOP32 [ (SA410T) ]	AT49F002T@VSOP32
[ (SA620) ]	
AT49F008@TSOP40 [ (SA409T) ]	AT49F008A@TSOP40
[ (SA409T) ]	
AT49F008AT@TSOP40 [ (SA409T) ]	
AT49F010	
AT49F010@PLCC32 [ (SA015A1T) ]	AT49F010@TSOP32
[ (SA410T) ]	
AT49F020	AT49F020@PLCC32
[ (SA015A1T) ]	
AT49F020@TSOP32 [ (SA410T) ]	
AT49F040	
AT49F040@PLCC32 [ (SA015A1T) ]	AT49F040@TSOP32
[ (SA410T) ]	
AT49F040A	AT49F040A@PLCC32
[ (SA015A1T) ]	
AT49F040A@TSOP32 [ (SA410T) ]	AT49F080@PSOP44
[ (SA638) ]	
AT49F080@TSOP40 [ (SA409T) ]	AT49F080T@PSOP44
[ (SA638) ]	
AT49F080T@TSOP40 [ (SA409T) ]	AT49F1024@TSOP40
[ (SA623) ]	
AT49F1024A@TSOP40 [ (SA623) ]	AT49F1025@PLCC44
[ (SA244) ]	
AT49F1604@TSOP48 [ (SA247-B005) ]	
AT49F1604@uBGA48 [ (SA634A-B005A-Y048F001) ]	
AT49F1604T@TSOP48 [ (SA247-B005) ]	
AT49F1604T@uBGA48 [ (SA634A-B005A-Y048F001) ]	
AT49F1614@CBGA48 [ (SA642F-B026A-T064F001) ]	
AT49F1614@TSOP48 [ (SA247-B005) ]	
AT49F1614T@CBGA48 [ (SA642F-B026A-T064F001) ]	
AT49F1614T@TSOP48 [ (SA247-B005) ]	AT49F2048@PSOP44
[ (SA638) ]	
AT49F2048@TSOP48 [ (SA247-B005) ]	AT49F2048A@PSOP44
[ (SA638) ]	
AT49F2048A@TSOP48 [ (SA247-B005) ]	AT49F4096@PSOP44
[ (SA638) ]	
AT49F4096@TSOP48 [ (SA247-B005) ]	
AT49F4096A@CBGA48 [ (SA642F-B026A-T064F001) ]	
AT49F4096A@PSOP44 [ (SA638) ]	AT49F4096A@TSOP48 [ (SA247-B005) ]
AT49F4096A@uBGA48 [ (SA634A-B005A-Y048F001) ]	

AT49F512 [ (SA015A1T) ]	AT49F512@PLCC32
AT49F512@TSOP32 [ (SA410T) ] [ (SA620) ]	AT49F512@VSOP32
AT49F516@PLCC44 [ (SA244) ] [ (SA623) ]	AT49F516@TSOP40
AT49F8004@CBGA48 [ (SA642B-B026A-Y072F001) ]	
AT49F8004@TSOP48 [ (SA247-B005) ]	
AT49F8004T@CBGA48 [ (SA642B-B026A-Y072F001) ]	
AT49F8004T@TSOP48 [ (SA247-B005) ]	
AT49F8011@CBGA48 [ (SA642B-B026A-Y072F001) ]	
AT49F8011@TSOP48 [ (SA247-B005) ]	
AT49F8011T@CBGA48 [ (SA642B-B026A-Y072F001) ]	
AT49F8011T@TSOP48 [ (SA247-B005) ]	AT49F8192@PSOP44
[ (SA638) ]	
AT49F8192@TSOP48 [ (SA247-B005) ]	AT49F8192A@PSOP44
[ (SA638) ]	
AT49F8192A@TSOP48 [ (SA247-B005) ]	AT49F8192AT@PSOP44
[ (SA638) ]	
AT49F8192AT@TSOP48 [ (SA247-B005) ]	
AT49F8192T@PSOP44 [ (SA638) ]	AT49F8192T@TSOP48 [ (SA247-
B005) ]	
AT49HBV010 [ (SA015A1T) ]	AT49HBV010@PLCC32
AT49HBV010@TSOP32 [ (SA410T) ]	
AT49HF010	
AT49HF010@PLCC32 [ (SA015A1T) ]	AT49HF010@TSOP32
[ (SA410T) ]	
AT49HLV010	AT49HLV010@PLCC32
[ (SA015A1T) ]	
AT49HLV010@TSOP32 [ (SA410T) ]	AT49LH002@PLCC32
[ (SA015A1T) ]	
AT49LH002@TSOP40 [ (SA409T) ]	AT49LH004@PLCC32
[ (SA015A1T) ]	
AT49LH004@TSOP40 [ (SA409T) ]	AT49LH00B4@PLCC32
[ (SA015A1T) ]	
AT49LH00B4@TSOP40 [ (SA409T) ]	AT49LL020@PLCC32
[ (SA015A1T) ]	
AT49LL020@TSOP40 [ (SA409T) ]	AT49LL040@PLCC32
[ (SA015A1T) ]	
AT49LL040@TSOP40 [ (SA409T) ]	AT49LL080@PLCC32
[ (SA015A1T) ]	
AT49LL080@TSOP40 [ (SA409T) ]	

AT49LV001	
AT49LV001@PLCC32 [(SA015A1T)]	AT49LV001@TSOP32
[(SA410T)]	
AT49LV001@VSOP32 [(SA620)]	
AT49LV001N	
AT49LV001N@PLCC32 [(SA015A1T)]	AT49LV001N@TSOP32
[(SA410T)]	
AT49LV001N@VSOP32 [(SA620)]	
AT49LV001NT	
AT49LV001NT@PLCC32 [(SA015A1T)]	AT49LV001NT@TSOP32
[(SA410T)]	
AT49LV001NT@VSOP32 [(SA620)]	
AT49LV001T	
AT49LV001T@PLCC32 [(SA015A1T)]	AT49LV001T@TSOP32
[(SA410T)]	
AT49LV001T@VSOP32 [(SA620)]	
AT49LV002	
AT49LV002@PLCC32 [(SA015A1T)]	AT49LV002@TSOP32
[(SA410T)]	
AT49LV002@VSOP32 [(SA620)]	
AT49LV002N	
AT49LV002N@PLCC32 [(SA015A1T)]	AT49LV002N@TSOP32
[(SA410T)]	
AT49LV002N@VSOP32 [(SA620)]	
AT49LV002NT	
AT49LV002NT@PLCC32 [(SA015A1T)]	AT49LV002NT@TSOP32
[(SA410T)]	
AT49LV002NT@VSOP32 [(SA620)]	
AT49LV002T	
AT49LV002T@PLCC32 [(SA015A1T)]	AT49LV002T@TSOP32
[(SA410T)]	
AT49LV002T@VSOP32 [(SA620)]	AT49LV008@TSOP40
[(SA409T)]	
AT49LV008A@TSOP40 [(SA409T)]	AT49LV008A@uBGA48
[(SA634)]	
AT49LV008AT@TSOP40 [(SA409T)]	AT49LV008AT@uBGA48
[(SA634)]	
AT49LV010	AT49LV010@PLCC32
[(SA015A1T)]	
AT49LV010@TSOP32 [(SA410T)]	
AT49LV020	
AT49LV020@PLCC32 [(SA015A1T)]	AT49LV020@TSOP32
[(SA410T)]	

AT49LV040 AT49LV040@PLCC32  
[ (SA015A1T) ]  
AT49LV040@TSOP32 [ (SA410T) ]  
AT49LV040T  
AT49LV040T@PLCC32 [ (SA015A1T) ] AT49LV040T@TSOP32  
[ (SA410T) ]  
AT49LV080@PSOP44 [ (SA638) ] AT49LV080@TSOP40  
[ (SA409T) ]  
AT49LV080T@PSOP44 [ (SA638) ] AT49LV080T@TSOP40  
[ (SA409T) ]  
AT49LV1024@TSOP40 [ (SA623) ] AT49LV1024A@TSOP40  
[ (SA623) ]  
AT49LV1025@PLCC44 [ (SA244) ] AT49LV160@TSOP48 [ (SA247-  
B005) ]  
AT49LV160@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LV1604@TSOP48 [ (SA247-B005) ]  
AT49LV1604@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LV1604T@TSOP48 [ (SA247-B005) ]  
AT49LV1604T@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LV161@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV161@TSOP48 [ (SA247-B005) ]  
AT49LV1614@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV1614@TSOP48 [ (SA247-B005) ]  
AT49LV1614A@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV1614A@TSOP48 [ (SA247-B005) ]  
AT49LV1614AT@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV1614AT@TSOP48 [ (SA247-B005) ]  
AT49LV1614T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV1614T@TSOP48 [ (SA247-B005) ]  
AT49LV161T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV161T@TSOP48 [ (SA247-B005) ] AT49LV2048@PSOP44  
[ (SA638) ]  
AT49LV2048@TSOP48 [ (SA247-B005) ] AT49LV2048A@PSOP44  
[ (SA638) ]  
AT49LV2048A@TSOP48 [ (SA247-B005) ]  
AT49LV2048B@TSOP48 [ (SA247-B005) ]  
AT49LV320@TSOP48 [ (SA247-B005) ]  
AT49LV320@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LV320T@TSOP48 [ (SA247-B005) ]  
AT49LV320T@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LV321@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV321@TSOP48 [ (SA247-B005) ]  
AT49LV3218@CBGA48 [ (SA642F-B026A-T064F001) ]

AT49LV3218@TSOP48 [ (SA247-B005) ]  
AT49LV3218T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV3218T@TSOP48 [ (SA247-B005) ]  
AT49LV321T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV321T@TSOP48 [ (SA247-B005) ]  
AT49LV4096A@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV4096A@PSOP44 [ (SA638) ]  
AT49LV4096A@TSOP48 [ (SA247-B005) ]  
AT49LV4096A@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LV8011@CBGA48 [ (SA642B-B026A-Y072F001) ]  
AT49LV8011@TSOP48 [ (SA247-B005) ]  
AT49LV8011T@CBGA48 [ (SA642B-B026A-Y072F001) ]  
AT49LV8011T@TSOP48 [ (SA247-B005) ]  
AT49LV8192@PSOP44 [ (SA638) ] AT49LV8192@TSOP48 [ (SA247-B005) ]  
AT49LV8192A@TSOP48 [ (SA247-B005) ]  
AT49LV8192A@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LV8192AT@TSOP48 [ (SA247-B005) ]  
AT49LV8192AT@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LW040@PLCC32 [ (SA015A1T) ] AT49LW040@TSOP40 [ (SA409T) ]  
AT49LW080@PLCC32 [ (SA015A1T) ] AT49LW080@TSOP40 [ (SA409T) ]  
AT49SV163D@FBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV163D@TSOP48 [ (SA247-B005) ]  
AT49SV163DT@FBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV163DT@TSOP48 [ (SA247-B005) ]  
AT49SV322A@CBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV322A@TSOP48 [ (SA247-B005) ]  
AT49SV322AT@CBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV322AT@TSOP48 [ (SA247-B005) ]  
AT49SV322D@FBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV322D@TSOP48 [ (SA247-B005) ]  
AT49SV322DT@FBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV322DT@TSOP48 [ (SA247-B005) ]  
AT49SV802A@CBGA48 [ (SA642G-B026A-T048F001Y) ]  
AT49SV802A@TSOP48 [ (SA247-B005) ]  
AT49SV802AT@CBGA48 [ (SA642G-B026A-T048F001Y) ]  
AT49SV802AT@TSOP48 [ (SA247-B005) ]  
AT52BC1660A@FBGA66 [ (SA642R-B023A-T096F001Y) ]  
AT52BC1660AT@FBGA66 [ (SA642R-B023A-T096F001Y) ]  
AT52BC1661A@FBGA66 [ (SA642R-B023A-T096F001Y) ]  
AT52BC1661AT@FBGA66 [ (SA642R-B023A-T096F001Y) ]



AT52BC3221A@FBGA66 [ (SA642R-B023A-T080F001Y) ]  
 AT52BC3221AT@FBGA66 [ (SA642R-B023A-T080F001Y) ]  
 AT52BC3221D@FBGA66 [ (SA642R-B023A-T080F001Y) ]  
 AT52BC3221DT@FBGA66 [ (SA642R-B023A-T080F001Y) ]  
 AT52BC6402A@FBGA66 [ (SA642B-B023A-Y072F001Y) ]  
 AT52BC6402AT@FBGA66 [ (SA642B-B023A-Y072F001Y) ]  
 AT52BR1662@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR1662A@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR1662AT@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR1662T@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR1664@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR1664A@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR1664AT@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR1664T@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR1672@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR1672T@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR1674@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR1674T@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR3224@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR3224A@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR3224AT@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR3224T@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR3228@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR3228A@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR3228AT@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR3228T@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR3244@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR3244T@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR3248@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR3248T@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR6408A@CSP66 [ (SA642E-B023A-T072F001Y) ]  
 AT52BR6408AT@CSP66 [ (SA642E-B023A-T072F001Y) ]  
 AT59C11 AT59C11@SOIC8  
 [ (SA602A) ]  
 AT59C12 AT59C12@SOIC8  
 [ (SA602A) ]  
 AT59C13 AT59C13@SOIC8  
 [ (SA602A) ]  
 AT59C22 AT59C22@SOIC8  
 [ (SA602A) ]  
 AT93C46(08bit) AT93C46(08bit)@SOIC8  
 [ (SA602A) ]  
 AT93C46(08bit)@TSSOP8 [ (SA026) ] AT93C46

(16bit)	
AT93C46(16bit)@SOIC8 [(SA602A)]	AT93C46(16bit)@TSSOP8
[(SA026)]	
AT93C46A	AT93C46A@SOIC8
[(SA602A)]	
AT93C46A@TSSOP8 [(SA026)]	
AT93C46C	
AT93C46C@SOIC8 [(SA602A)]	AT93C46C@TSSOP8
[(SA026)]	
AT93C46D(08bit)	AT93C46D(08bit)@dBGA8
[(BBBB)]	
AT93C46D(08bit)@MAP8 [(SA724)]	AT93C46D(08bit)@SOIC8
[(SA602A)]	
AT93C46D(08bit)@TSSOP8 [(SA026)]	AT93C46D
(16bit)	
AT93C46D(16bit)@dBGA8 [(BBBB)]	AT93C46D(16bit)@MAP8
[(SA724)]	
AT93C46D(16bit)@SOIC8 [(SA602A)]	AT93C46D(16bit)@TSSOP8
[(SA026)]	
AT93C46E	AT93C46E@SOIC8
[(SA602A)]	
AT93C46E@TSSOP8 [(SA026)]	AT93C56
(08bit)	
AT93C56(08bit)@SOIC8 [(SA602A)]	AT93C56
(16bit)	
AT93C56(16bit)@SOIC8 [(SA602A)]	AT93C56A
(08bit)	
AT93C56A(08bit)@SOIC8 [(SA602A)]	AT93C56A(08bit)@TSSOP8
[(SA026)]	
AT93C56A(16bit)	AT93C56A(16bit)@SOIC8
[(SA602A)]	
AT93C56A(16bit)@TSSOP8 [(SA026)]	
AT93C57	
AT93C57@SOIC8 [(SA602A)]	AT93C66
(08bit)	
AT93C66(08bit)@SOIC8 [(SA602A)]	AT93C66
(16bit)	
AT93C66(16bit)@SOIC8 [(SA602A)]	AT93C66A
(08bit)	
AT93C66A(08bit)@SOIC8 [(SA602A)]	AT93C66A(08bit)@TSSOP8
[(SA026)]	
AT93C66A(16bit)	AT93C66A(16bit)@SOIC8
[(SA602A)]	

AT93C66A(16bit)@TSSOP8 [(SA026)] (08bit)	AT93C86
AT93C86(08bit)@SOIC8 [(SA602A)] [(SA026)]	AT93C86(08bit)@TSSOP8
AT93C86(16bit) [(SA602A)]	AT93C86(16bit)@SOIC8
AT93C86(16bit)@TSSOP8 [(SA026)] (08bit)	AT93C86A
AT93C86A(08bit)@SOIC8 [(SA602A)] [(SA026)]	AT93C86A(08bit)@TSSOP8
AT93C86A(16bit) [(SA602A)]	AT93C86A(16bit)@SOIC8
AT93C86A(16bit)@TSSOP8 [(SA026)]	

**DRAM & SRAM**

AT3864L [(SA643)]	AT3864L@TSOP28
AT38H256 [(SA643)]	AT38H256@TSOP28

**PLD**

AT22LV10 [(SA008A)]	AT22LV10@PLCC28
AT22LV10@SOIC24 [(SA404)]	
AT22LV10L	
AT22LV10L@PLCC28 [(SA008A)] [(SA404)]	AT22LV10L@SOIC24
AT22V10 [(SA008A)]	AT22V10@PLCC28
AT22V10@SOIC24 [(SA404)]	
AT22V10L	
AT22V10L@PLCC28 [(SA008A)] [(SA404)]	AT22V10L@SOIC24
ATF1500A@PLCC44 [(SA244)] [(SA245A)]	ATF1500A@TQFP44
ATF1500ABV@PLCC44 [(SA244)] [(SA245A)]	ATF1500ABV@TQFP44
ATF1500ABVL@PLCC44 [(SA244)] [(SA245A)]	ATF1500ABVL@TQFP44

ATF1500AL@PLCC44 [(SA244)] ATF1500AL@TQFP44  
[(SA245A)]  
ATF1502AS@PLCC44 [(SA244)] ATF1502AS@PQFP44  
[(SA675)]  
ATF1502AS@TQFP44 [(SA245A)] ATF1502ASL@PLCC44  
[(SA244)]  
ATF1502ASL@PQFP44 [(SA675)] ATF1502ASL@TQFP44  
[(SA245A)]  
ATF1502ASV@PLCC44 [(SA244)] ATF1502ASV@PQFP44  
[(SA675)]  
ATF1502ASV@TQFP44 [(SA245A)] ATF1502ASVL@PLCC44  
[(SA244)]  
ATF1502ASVL@PQFP44 [(SA675)] ATF1502ASVL@TQFP44  
[(SA245A)]  
ATF1504AS@PLCC44 [(SA244)]  
ATF1504AS@PLCC44(ISP) [ISP-HEADER01]  
ATF1504AS@PLCC68 [(PEP+S414T)]  
ATF1504AS@PLCC68(ISP) [ISP-HEADER01]  
ATF1504AS@PLCC84 [(PEP+S416T)]  
ATF1504AS@PLCC84(ISP) [ISP-HEADER01]  
ATF1504AS@PQFP100 [(PEP+S427)]  
ATF1504AS@PQFP100(ISP) [ISP-HEADER01]  
ATF1504AS@TQFP100 [(PEP+S604)]  
ATF1504AS@TQFP100(ISP) [ISP-HEADER01]  
ATF1504AS@TQFP44 [(SA245A)]  
ATF1504AS@TQFP44(ISP) [ISP-HEADER01]  
ATF1504ASV(L)@PLCC44 [(SA244)]  
ATF1504ASV(L)@PLCC44(ISP) [ISP-HEADER01]  
ATF1504ASV(L)@PLCC68 [(PEP+S414T)]  
ATF1504ASV(L)@PLCC68(ISP) [ISP-HEADER01]  
ATF1504ASV(L)@PLCC84 [(PEP+S416T)]  
ATF1504ASV(L)@PLCC84(ISP) [ISP-HEADER01]  
ATF1504ASV(L)@PQFP100 [(PEP+S427)]  
ATF1504ASV(L)@PQFP100(ISP) [ISP-HEADER01]  
ATF1504ASV(L)@TQFP100 [(PEP+S604)]  
ATF1504ASV(L)@TQFP100(ISP) [ISP-HEADER01]  
ATF1504ASV(L)@TQFP44 [(SA245A)]  
ATF1504ASV(L)@TQFP44(ISP) [ISP-HEADER01]  
ATF1508@PLCC68 [(PEP+S414T)]  
ATF1508@PLCC68(ISP) [ISP-HEADER01]  
ATF1508@PLCC84 [(PEP+S416T)]  
ATF1508@PLCC84(ISP) [ISP-HEADER01]  
ATF1508@PQFP100 [(PEP+S427)]

ATF1508@PQFP100(ISP) [ISP-HEADER01]  
ATF1508@TQFP100 [(PEP+S604)]  
ATF1508@TQFP100(ISP) [ISP-HEADER01]  
ATF1508AS(L)@PLCC84 [(PEP+S416T)]  
ATF1508AS(L)@PLCC84(ISP) [ISP-HEADER01]  
ATF1508AS(L)@PQFP100 [(PEP+S427)]  
ATF1508AS(L)@PQFP100(ISP) [ISP-HEADER01]  
ATF1508AS(L)@TQFP100 [(PEP+S604)]  
ATF1508AS(L)@TQFP100(ISP) [ISP-HEADER01]  
ATF1508ASV(L)@PLCC84 [(PEP+S416T)]  
ATF1508ASV(L)@PLCC84(ISP) [ISP-HEADER01]  
ATF1508ASV(L)@PQFP100 [(PEP+S427)]  
ATF1508ASV(L)@PQFP100(ISP) [ISP-HEADER01]  
ATF1508ASV(L)@TQFP100 [(PEP+S604)]  
ATF1508ASV(L)@TQFP100(ISP) [ISP-HEADER01]  
ATF16LV8C ATF16LV8C@PLCC20  
[(SA001A)]  
ATF16LV8C@SOIC20 [(SA404)] ATF16LV8C@TSOP20  
[(SA026)]  
ATF16LV8CEXT ATF16LV8CEXT@PLCC20  
[(SA001A)]  
ATF16LV8CEXT@SOIC20 [(SA404)] ATF16LV8CEXT@TSOP20  
[(SA026)]  
ATF16V8B ATF16V8B@PLCC20  
[(SA001A)]  
ATF16V8B@SOIC20 [(SA404)] ATF16V8B@TSOP20  
[(SA026)]  
ATF16V8BL ATF16V8BL@PLCC20  
[(SA001A)]  
ATF16V8BL@SOIC20 [(SA404)] ATF16V8BL@TSOP20  
[(SA026)]  
ATF16V8BQ ATF16V8BQ@PLCC20  
[(SA001A)]  
ATF16V8BQ@SOIC20 [(SA404)] ATF16V8BQ@TSOP20  
[(SA026)]  
ATF16V8BQL ATF16V8BQL@PLCC20  
[(SA001A)]  
ATF16V8BQL@SOIC20 [(SA404)] ATF16V8BQL@TSOP20  
[(SA026)]  
ATF16V8C ATF16V8C@PLCC20  
[(SA001A)]  
ATF16V8C@SOIC20 [(SA404)] ATF16V8C@TSOP20  
[(SA026)]

ATF16V8CEXT [ (SA001A) ]	ATF16V8CEXT@PLCC20
ATF16V8CEXT@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16V8CEXT@TSOP20
ATF16V8CZ [ (SA001A) ]	ATF16V8CZ@PLCC20
ATF16V8CZ@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16V8CZ@TSOP20
ATF20V8B [ (SA008A) ]	ATF20V8B@PLCC28
ATF20V8B@SOIC24 [ (SA404) ]	
ATF20V8BL ATF20V8BL@PLCC28 [ (SA008A) ] [ (SA404) ]	ATF20V8BL@SOIC24
ATF20V8BQ [ (SA008A) ]	ATF20V8BQ@PLCC28
ATF20V8BQ@SOIC24 [ (SA404) ]	
ATF20V8BQL ATF20V8BQL@PLCC28 [ (SA008A) ] [ (SA404) ]	ATF20V8BQL@SOIC24
ATF22LV10C (UES)	ATF22LV10C
ATF22LV10C(UES)@PLCC28 [ (SA008A) ]	
ATF22LV10C(UES)@SOIC24 [ (SA404) ]	
ATF22LV10C(UES)@TSSOP24 [ (SA643) ]	
ATF22LV10C@PLCC28 [ (SA008A) ] [ (SA404) ]	ATF22LV10C@SOIC24
ATF22LV10C@TSSOP24 [ (SA643) ]	
ATF22LV10CEXT ATF22LV10CEXT@PLCC28 [ (SA008A) ] [ (SA404) ]	ATF22LV10CEXT@SOIC24
ATF22LV10CEXT@TSSOP24 [ (SA643) ]	
ATF22LV10CQ ATF22LV10CQ(UES)	
ATF22LV10CQ(UES)@PLCC28 [ (SA008A) ]	
ATF22LV10CQ(UES)@SOIC24 [ (SA404) ]	
ATF22LV10CQ(UES)@TSSOP24 [ (SA643) ]	
ATF22LV10CQ@PLCC28 [ (SA008A) ] [ (SA404) ]	ATF22LV10CQ@SOIC24
ATF22LV10CQ@TSSOP24 [ (SA643) ]	
ATF22LV10CQZ ATF22LV10CQZ(UES)	
ATF22LV10CQZ(UES)@PLCC28 [ (SA008A) ]	

ATF22LV10CQZ(UES)@SOIC24 [(SA404)]  
ATF22LV10CQZ(UES)@TSSOP24 [(SA643)]  
ATF22LV10CQZ@PLCC28 [(SA008A)] ATF22LV10CQZ@SOIC24  
[(SA404)]  
ATF22LV10CQZ@TSSOP24 [(SA643)]  
ATF22LV10CZ  
ATF22LV10CZ(UES)  
ATF22LV10CZ(UES)@PLCC28 [(SA008A)]  
ATF22LV10CZ(UES)@SOIC24 [(SA404)]  
ATF22LV10CZ(UES)@TSSOP24 [(SA643)]  
ATF22LV10CZ@PLCC28 [(SA008A)] ATF22LV10CZ@SOIC24  
[(SA404)]  
ATF22LV10CZ@TSSOP24 [(SA643)]  
ATF22V10B  
ATF22V10B(UES) ATF22V10B(UES)@PLCC28  
[(SA008A)]  
ATF22V10B(UES)@SOIC24 [(SA404)] ATF22V10B@PLCC28  
[(SA008A)]  
ATF22V10B@SOIC24 [(SA404)]  
ATF22V10BL  
ATF22V10BL(UES)  
ATF22V10BL(UES)@PLCC28 [(SA008A)]  
ATF22V10BL(UES)@SOIC24 [(SA404)] ATF22V10BL@PLCC28  
[(SA008A)]  
ATF22V10BL@SOIC24 [(SA404)]  
ATF22V10BQ  
ATF22V10BQ(UES)  
ATF22V10BQ(UES)@PLCC28 [(SA008A)]  
ATF22V10BQ(UES)@SOIC24 [(SA404)] ATF22V10BQ@PLCC28  
[(SA008A)]  
ATF22V10BQ@SOIC24 [(SA404)]  
ATF22V10BQL  
ATF22V10BQL(UES)  
ATF22V10BQL(UES)@PLCC28 [(SA008A)]  
ATF22V10BQL(UES)@SOIC24 [(SA404)]  
ATF22V10BQL@PLCC28 [(SA008A)] ATF22V10BQL@SOIC24  
[(SA404)]  
ATF22V10C ATF22V10C  
(UES)  
ATF22V10C(UES)@PLCC28 [(SA008A)] ATF22V10C(UES)@SOIC24  
[(SA404)]  
ATF22V10C(UES)@TSSOP24 [(SA643)] ATF22V10C@PLCC28  
[(SA008A)]

ATF22V10C@SOIC24 [(SA404)]  
[(SA643)]  
ATF22V10CEXT  
[(SA008A)]  
ATF22V10CEXT@SOIC24 [(SA404)]  
[(SA643)]  
ATF22V10CQ  
(UES)  
ATF22V10CQ(UES)@PLCC28 [(SA008A)]  
ATF22V10CQ(UES)@SOIC24 [(SA404)]  
ATF22V10CQ(UES)@TSSOP24 [(SA643)]  
ATF22V10CQ@PLCC28 [(SA008A)]  
[(SA404)]  
ATF22V10CQ@TSSOP24 [(SA643)]  
ATF22V10CQZ  
ATF22V10CQZ(UES)  
ATF22V10CQZ(UES)@PLCC28 [(SA008A)]  
ATF22V10CQZ(UES)@SOIC24 [(SA404)]  
ATF22V10CQZ(UES)@TSSOP24 [(SA643)]  
ATF22V10CQZ@PLCC28 [(SA008A)]  
[(SA404)]  
ATF22V10CQZ@TSSOP24 [(SA643)]  
ATF22V10CZ  
ATF22V10CZ(UES)  
ATF22V10CZ(UES)@PLCC28 [(SA008A)]  
ATF22V10CZ(UES)@SOIC24 [(SA404)]  
ATF22V10CZ(UES)@TSSOP24 [(SA643)]  
ATF22V10CZ@PLCC28 [(SA008A)]  
[(SA404)]  
ATF22V10CZ@TSSOP24 [(SA643)]  
(F2500C)  
ATF2500C(F2500C)@PLCC44 [(SA244)]  
ATF2500C(F2500C)@TQFP44 [(SA245A)]  
ATF2500C(V2500)  
[(SA244)]  
ATF2500C(V2500)@TQFP44 [(SA245A)]  
ATF2500C(V2500B)  
ATF2500C(V2500B)@PLCC44 [(SA244)]  
ATF2500C(V2500B)@TQFP44 [(SA245A)]  
ATF2500CL(F2500C)  
ATF2500CL(F2500C)@PLCC44 [(SA244)]  
ATF2500CL(F2500C)@TQFP44 [(SA245A)]  
ATF2500CL(V2500)

ATF22V10C@TSSOP24  
ATF22V10CEXT@PLCC28  
ATF22V10CEXT@TSSOP24  
ATF22V10CQ  
ATF22V10CQ@SOIC24  
ATF22V10CQZ@SOIC24  
ATF22V10CZ@SOIC24  
ATF2500C  
ATF2500C(V2500)@PLCC44



ATF2500CL(V2500)@PLCC44 [(SA244)]  
 ATF2500CL(V2500)@TQFP44 [(SA245A)]  
 ATF2500CL(V2500B)  
 ATF2500CL(V2500B)@PLCC44 [(SA244)]  
 ATF2500CL(V2500B)@TQFP44 [(SA245A)]  
 ATF2500CQ(F2500C)  
 ATF2500CQ(F2500C)@PLCC44 [(SA244)]  
 ATF2500CQ(F2500C)@TQFP44 [(SA245A)]  
 ATF2500CQ(V2500B)  
 ATF2500CQ(V2500B)@PLCC44 [(SA244)]  
 ATF2500CQ(V2500B)@TQFP44 [(SA245A)]  
 ATF2500CQL(F2500C)  
 ATF2500CQL(F2500C)@PLCC44 [(SA244)]  
 ATF2500CQL(F2500C)@TQFP44 [(SA245A)]  
 ATF2500CQL(V2500B)  
 ATF2500CQL(V2500B)@PLCC44 [(SA244)]  
 ATF2500CQL(V2500B)@TQFP44 [(SA245A)]  
 ATF750C (ATF750C mode) ATF750C (ATV750 mode)  
 ATF750C (ATV750B mode)  
 ATF750C@PLCC28 (ATF750C mode) [(SA008A)]  
 ATF750C@PLCC28 (ATV750 mode) [(SA008A)]  
 ATF750C@PLCC28 (ATV750B mode) [(SA008A)]  
 ATF750C@SOIC24 (ATF750C mode) [(SA404)]  
 ATF750C@SOIC24 (ATV750 mode) [(SA404)]  
 ATF750C@SOIC24 (ATV750B mode) [(SA404)]  
 ATF750CEXT (ATF750C mode)  
 ATF750CEXT@PLCC28 (ATF750C mode) [(SA008A)]  
 ATF750CEXT@SOIC24 (ATF750C mode) [(SA404)]  
 ATF750CL (ATV750 mode) ATF750CL (ATV750B mode)  
 ATF750CL@PLCC28 (ATV750 mode) [(SA008A)]  
 ATF750CL@PLCC28 (ATV750B mode) [(SA008A)]  
 ATF750CL@SOIC24 (ATV750 mode) [(SA404)]  
 ATF750CL@SOIC24 (ATV750B mode) [(SA404)]  
 ATF750LVC (ATF750C mode) ATF750LVC (ATV750 mode)  
 ATF750LVC (ATV750B mode)  
 ATF750LVC@PLCC28 (ATF750C mode) [(SA008A)]  
 ATF750LVC@PLCC28 (ATV750 mode) [(SA008A)]  
 ATF750LVC@PLCC28 (ATV750B mode) [(SA008A)]  
 ATF750LVC@SOIC24 (ATF750C mode) [(SA404)]  
 ATF750LVC@SOIC24 (ATV750 mode) [(SA404)]

ATF750LVC@SOIC24 (ATV750B mode) [(SA404)]  
 ATF750LVCEXT (ATF750C mode)  
 ATF750LVCEXT@PLCC28(ATF750Cmode) [(SA008A)]  
 ATF750LVCEXT@SOIC24(ATF750Cmode) [(SA404)]  
 ATF750LVCL (ATF750C mode) ATF750LVCL (ATV750 mode)  
 ATF750LVCL (ATV750B mode)  
 ATF750LVCL@PLCC28 (ATF750C mode) [(SA008A)]  
 ATF750LVCL@PLCC28 (ATV750 mode) [(SA008A)]  
 ATF750LVCL@PLCC28 (ATV750B mode) [(SA008A)]  
 ATF750LVCL@SOIC24 (ATF750C mode) [(SA404)]  
 ATF750LVCL@SOIC24 (ATV750 mode) [(SA404)]  
 ATF750LVCL@SOIC24 (ATV750B mode) [(SA404)]  
 ATV22V10 ATV22V10@PLCC28 [(SA008A)]  
 ATV22V10@SOIC24 [(SA404)]  
 ATV2500  
 ATV2500@PLCC44 [(SA244)]  
 ATV2500B  
 ATV2500B@PLCC44 [(SA244)]  
 ATV2500BL  
 ATV2500BL@PLCC44 [(SA244)]  
 ATV2500BQ  
 ATV2500BQ@PLCC44 [(SA244)]  
 ATV2500BQL  
 ATV2500BQL@PLCC44 [(SA244)]  
 ATV2500H  
 ATV2500H@PLCC44 [(SA244)]  
 ATV2500L  
 ATV2500L@PLCC44 [(SA244)]  
 ATV750  
 ATV750@PLCC28 [(SA008A)] ATV750@SOIC24 [(SA404)]  
 ATV750B ATV750B@PLCC28 [(SA008A)]  
 ATV750B@SOIC24 [(SA404)]  
 ATV750BL  
 ATV750BL@PLCC28 [(SA008A)] ATV750BL@SOIC24 [(SA404)]  
 ATV750L ATV750L@PLCC28 [(SA008A)]  
 ATV750L@SOIC24 [(SA404)]

**MICROCONTROLLER**

AT80F51	AT80F51@PLCC44
[ (SA244) ]	
AT80F51@TQFP44 [ (SA245A) ]	
AT80F52	
AT80F52@PLCC44 [ (SA244) ]	AT80F52@TQFP44
[ (SA245A) ]	
AT87F51	AT87F51@PLCC44
[ (SA244) ]	
AT87F51@TQFP44 [ (SA245A) ]	
AT87F51RC	
AT87F51RC@PLCC44 [ (SA244) ]	AT87F51RC@TQFP44
[ (SA245A) ]	
AT87F52	AT87F52@PLCC44
[ (SA244) ]	
AT87F52@TQFP44 [ (SA245A) ]	
AT87F55	
AT87F55@PLCC44 [ (SA244) ]	AT87F55@TQFP44
[ (SA245A) ]	
AT87F55WD	AT87F55WD@PLCC44
[ (SA244) ]	
AT87F55WD@TQFP44 [ (SA245A) ]	
AT87LV51	
AT87LV51@PLCC44 [ (SA244) ]	AT87LV51@TQFP44
[ (SA245A) ]	
AT87LV52	AT87LV52@PLCC44
[ (SA244) ]	
AT87LV52@TQFP44 [ (SA245A) ]	
AT89C1051	
AT89C1051@SOIC20 [ (SA404) ]	
AT89C1051U	
AT89C1051U@SOIC20 [ (SA404) ]	
AT89C2051	
AT89C2051@SOIC20 [ (SA404) ]	
AT89C2051X2	
AT89C2051X2@SOIC20 [ (SA404) ]	
AT89C4051	
AT89C4051@SOIC20 [ (SA404) ]	
AT89C51	
AT89C51@PLCC44 [ (SA244) ]	AT89C51@TQFP44
[ (SA245A) ]	

AT89C5130A@PLCC52 [(PEP+S415T)] [(SA686)]	AT89C5130A@QFN32
AT89C5130A@SOIC28 [(SA404)] +S625A]	AT89C5130A@VQFP64 [(PEP
AT89C5130AM@PLCC52 [(PEP+S415T)] [(SA686)]	AT89C5130AM@QFN32
AT89C5130AM@SOIC28 [(SA404)] +S625A]	AT89C5130AM@VQFP64 [(PEP
AT89C5131@MLF48 [(SA696)] +S415T)]	AT89C5131@PLCC52 [(PEP
AT89C5131@SOIC28 [(SA404)] +S616)]	AT89C5131@VQFP64 [(PEP
AT89C5131A@PLCC52 [(PEP+S415T)] [(SA701)]	AT89C5131A@QFN32
AT89C5131A@SOIC28 [(SA404)] +S616)]	AT89C5131A@VQFP64 [(PEP
AT89C5131AL@PLCC52 [(PEP+S415T)] [(SA701)]	AT89C5131AL@QFN32
AT89C5131AL@SOIC28 [(SA404)] +S616)]	AT89C5131AL@VQFP64 [(PEP
AT89C5131AM@PLCC52 [(PEP+S415T)] [(SA701)]	AT89C5131AM@QFN32
AT89C5131AM@SOIC28 [(SA404)] +S616)]	AT89C5131AM@VQFP64 [(PEP
AT89C5132@TQFP80 [(PEP+S704)] [(SA244)]	AT89C51AC2@PLCC44
AT89C51AC2@TQFP44 [(SA245A)] [(SA244)]	AT89C51AC3@PLCC44
AT89C51AC3@PLCC52 [(PEP+S415T)] [(SA245A)]	AT89C51AC3@TQFP44
AT89C51AC3@TQFP64 [(PEP+S616)] [(SA244)]	AT89C51CC01@PLCC44
AT89C51CC01@TQFP44 [(SA245A)] [(SA244)]	AT89C51CC03C@PLCC44
AT89C51CC03C@PLCC52 [(PEP+S415T)]	
AT89C51CC03C@TQFP44 [(SA245A)] +S616)]	AT89C51CC03C@TQFP64 [(PEP
AT89C51CC03U@PLCC44 [(SA244)]	
AT89C51CC03U@PLCC52 [(PEP+S415T)]	
AT89C51CC03U@TQFP44 [(SA245A)] +S616)]	AT89C51CC03U@TQFP64 [(PEP
AT89C51ED2 [(SA244)]	AT89C51ED2@PLCC44

AT89C51ED2@PLCC68 [(PEP+S414T)]  
AT89C51ED2@PLCC68(\*) [(SA648-B6808)]  
AT89C51ED2@TQFP44 [(SA245A)] AT89C51ED2@TQFP64 [(PEP  
+S616)]  
AT89C51ED2@TQFP64(\*) [(TA054-B006)]  
AT89C51IC2@PLCC44 [(SA244)] AT89C51IC2@TQFP44  
[(SA245A)]  
AT89C51ID2 AT89C51ID2@PLCC44  
[(SA244)]  
AT89C51ID2@PLCC68 [(PEP+S414T)]  
AT89C51ID2@PLCC68(\*) [(SA648-B6808)]  
AT89C51ID2@TQFP44 [(SA245A)] AT89C51ID2@TQFP64 [(PEP  
+S616)]  
AT89C51ID2@TQFP64(\*) [(TA054-B006)]  
AT89C51RB2 AT89C51RB2@PLCC44  
[(SA244)]  
AT89C51RB2@TQFP44 [(SA245A)]  
AT89C51RC  
AT89C51RC@PLCC44 [(SA244)] AT89C51RC@TQFP44  
[(SA245A)]  
AT89C51RC2 AT89C51RC2@PLCC44  
[(SA244)]  
AT89C51RC2@TQFP44 [(SA245A)]  
AT89C51RD2  
AT89C51RD2@PLCC44 [(SA244)] AT89C51RD2@PLCC68 [(PEP  
+S414T)]  
AT89C51RD2@PLCC68(\*) [(SA648-B6808)]  
AT89C51RD2@TQFP44 [(SA245A)] AT89C51RD2@TQFP64 [(PEP  
+S616)]  
AT89C51RD2@TQFP64(\*) [(TA054-B006)]  
AT89C51RE2@PLCC44 [(SA244)] AT89C51RE2@TQFP44  
[(SA675)]  
AT89C51RE2@VQFP64 [(SA732+B317)]  
AT89C51SND1C@BGA81(\*) [(SA664E-B156A-P081F001Y)]  
AT89C51SND1C@PLCC84 [(PEP+S416T)]  
AT89C51SND1C@TQFP80 [(PEP+S704)]  
AT89C51SND2C@BGA100 [(SA664K-B242A-W100F001Y)]  
AT89C52 AT89C52@PLCC44  
[(SA244)]  
AT89C52@TQFP44 [(SA245A)]  
AT89C55  
AT89C55@PLCC44 [(SA244)] AT89C55@TQFP44  
[(SA245A)]

AT89C55WD AT89C55WD@PLCC44  
[ (SA244) ]  
AT89C55WD@TQFP44 [ (SA245A) ]  
AT89LP2051  
AT89LP2051@SOIC20 [ (SA404) ] AT89LP2051@TSSOP20  
[ (SA026) ]  
AT89LP2052 AT89LP2052(ISP) [ ISP-  
HEADER01 ]  
AT89LP2052@SOIC20 [ (SA404) ]  
AT89LP2052@SOIC20(ISP) [ ISP-HEADER01 ]  
AT89LP2052@TSSOP20 [ (SA026) ]  
AT89LP2052@TSSOP20(ISP) [ ISP-HEADER01 ]  
AT89LP213 AT89LP213(ISP) [ ISP-  
HEADER01 ]  
AT89LP213@TSSOP14 [ (SA026) ]  
AT89LP213@TSSOP14(ISP) [ ISP-HEADER01 ]  
AT89LP214 AT89LP214(ISP) [ ISP-  
HEADER01 ]  
AT89LP214@TSSOP14 [ (SA026) ]  
AT89LP214@TSSOP14(ISP) [ ISP-HEADER01 ]  
AT89LP216 AT89LP216(ISP) [ ISP-  
HEADER01 ]  
AT89LP216@TSSOP16 [ (SA026) ]  
AT89LP216@TSSOP16(ISP) [ ISP-HEADER01 ]  
AT89LP4051 AT89LP4051@SOIC20  
[ (SA404) ]  
AT89LP4051@TSSOP20 [ (SA026) ]  
AT89LP4052  
AT89LP4052(ISP) [ ISP-HEADER01 ] AT89LP4052@SOIC20  
[ (SA404) ]  
AT89LP4052@SOIC20(ISP) [ ISP-HEADER01 ]  
AT89LP4052@TSSOP20 [ (SA026) ]  
AT89LP4052@TSSOP20(ISP) [ ISP-HEADER01 ]  
AT89LS51 AT89LS51(ISP) [ ISP-  
HEADER01 ]  
AT89LS51@PLCC44 [ (SA244) ]  
AT89LS51@PLCC44(ISP) [ ISP-HEADER01 ]  
AT89LS51@TQFP44 [ (SA245A) ]  
AT89LS51@TQFP44(ISP) [ ISP-HEADER01 ]  
AT89LS52 AT89LS52(ISP) [ ISP-  
HEADER01 ]  
AT89LS52@PLCC44 [ (SA244) ]  
AT89LS52@PLCC44(ISP) [ ISP-HEADER01 ]

AT89LS52@TQFP44 [(SA245A)]  
AT89LS52@TQFP44(ISP) [ISP-HEADER01]  
AT89LS53 AT89LS53(ISP) [ISP-  
HEADER01]  
AT89LS53@PLCC44 [(SA244)]  
AT89LS53@PLCC44(ISP) [ISP-HEADER01]  
AT89LS53@TQFP44 [(SA245A)]  
AT89LS53@TQFP44(ISP) [ISP-HEADER01]  
AT89LS8252 AT89LS8252(ISP) [ISP-  
HEADER01]  
AT89LS8252@PLCC44 [(SA244)]  
AT89LS8252@PLCC44(ISP) [ISP-HEADER01]  
AT89LS8252@TQFP44 [(SA245A)]  
AT89LS8252@TQFP44(ISP) [ISP-HEADER01]  
AT89LV51 AT89LV51@PLCC44  
[(SA244)]  
AT89LV51@TQFP44 [(SA245A)]  
AT89LV52  
AT89LV52@PLCC44 [(SA244)] AT89LV52@TQFP44  
[(SA245A)]  
AT89LV55 AT89LV55@PLCC44  
[(SA244)]  
AT89LV55@TQFP44 [(SA245A)]  
AT89S2051  
AT89S2051@SOIC20 [(SA404)]  
AT89S4051  
AT89S4051@SOIC20 [(SA404)]  
AT89S51  
AT89S51(ISP) [ISP-HEADER01] AT89S51@PLCC44  
[(SA244)]  
AT89S51@PLCC44(ISP) [ISP-HEADER01]  
AT89S51@TQFP44 [(SA245A)]  
AT89S51@TQFP44(ISP) [ISP-HEADER01]  
AT89S52 AT89S52(ISP) [ISP-  
HEADER01]  
AT89S52@PLCC44 [(SA244)]  
AT89S52@PLCC44(ISP) [ISP-HEADER01]  
AT89S52@TQFP44 [(SA245A)]  
AT89S52@TQFP44(ISP) [ISP-HEADER01]  
AT89S53 AT89S53(ISP) [ISP-  
HEADER01]  
AT89S53@PLCC44 [(SA244)]  
AT89S53@PLCC44(ISP) [ISP-HEADER01]

AT89S53@TQFP44 [(SA245A)]  
AT89S53@TQFP44(ISP) [ISP-HEADER01]  
AT89S54 AT89S54@PLCC44  
[(SA244)]  
AT89S54@TQFP44 [(SA245A)]  
AT89S58 AT89S58@TQFP44  
AT89S58@PLCC44 [(SA244)]  
[(SA245A)]  
AT89S64 AT89S64@PLCC44  
[(SA244)]  
AT89S64@TQFP44 [(SA245A)]  
AT89S8252 AT89S8252@PLCC44  
AT89S8252(ISP) [ISP-HEADER01]  
[(SA244)]  
AT89S8252@PLCC44(ISP) [ISP-HEADER01]  
AT89S8252@TQFP44 [(SA245A)]  
AT89S8252@TQFP44(ISP) [ISP-HEADER01]  
AT89S8253 AT89S8253(ISP) [ISP-  
HEADER01]  
AT89S8253@PLCC44 [(SA244)]  
AT89S8253@PLCC44(ISP) [ISP-HEADER01]  
AT89S8253@TQFP44 [(SA245A)]  
AT89S8253@TQFP44(ISP) [ISP-HEADER01]  
AT90CAN128@QFN64(ISP) [ISP-HEADER01]  
AT90CAN128@TQFP64(ISP) [ISP-HEADER01]  
AT90CAN128-AI@TQFP64 [(S625A)] AT90CAN128-AU@TQFP64  
[(S625A)]  
AT90CAN32@QFN64 [(PEP+S702)]  
AT90CAN32@QFN64(ISP) [ISP-HEADER01]  
AT90CAN32@TQFP64 [(PEP+S625A)]  
AT90CAN32@TQFP64(ISP) [ISP-HEADER01]  
AT90CAN64@QFN64(ISP) [ISP-HEADER01]  
AT90CAN64@TQFP64(ISP) [ISP-HEADER01]  
AT90LS2323 AT90LS2323(ISP) [ISP-  
HEADER01]  
AT90LS2323@SOIC8 [(SA605A)]  
AT90LS2323@SOIC8(ISP) [ISP-HEADER01]  
AT90LS2333 AT90LS2333(ISP) [ISP-  
HEADER01]  
AT90LS2333@TQFP32 [(SA663)]  
AT90LS2333@TQFP32(ISP) [ISP-HEADER01]  
AT90LS2343 AT90LS2343(ISP) [ISP-  
HEADER01]



AT90LS2343@SOIC8 [(SA605A)]  
AT90LS2343@SOIC8(ISP) [ISP-HEADER01]  
AT90LS4433 AT90LS4433(ISP) [ISP-  
HEADER01]  
AT90LS4433@TQFP32 [(SA663)]  
AT90LS4433@TQFP32(ISP) [ISP-HEADER01]  
AT90LS4434 AT90LS4434(ISP) [ISP-  
HEADER01]  
AT90LS4434@PLCC44 [(SA244)]  
AT90LS4434@PLCC44(ISP) [ISP-HEADER01]  
AT90LS4434@TQFP44 [(SA245A)]  
AT90LS4434@TQFP44(ISP) [ISP-HEADER01]  
AT90LS8535 AT90LS8535(ISP) [ISP-  
HEADER01]  
AT90LS8535@PLCC44 [(SA244)]  
AT90LS8535@PLCC44(ISP) [ISP-HEADER01]  
AT90LS8535@TQFP44 [(SA245A)]  
AT90LS8535@TQFP44(ISP) [ISP-HEADER01]  
AT90PWM1@SOIC24 [(SA404)] AT90PWM2@SOIC24  
[(SA404)]  
AT90PWM2@SOIC24(ISP) [ISP-HEADER01]  
AT90PWM216@SOIC24 [(SA404)] AT90PWM2B@SOIC24  
[(SA404)]  
AT90PWM2B@SOIC24(ISP) [ISP-HEADER01]  
AT90PWM3@QFN32 [(SA701)]  
AT90PWM3@QFN32(ISP) [ISP-HEADER01]  
AT90PWM3@SOIC32 [(SA715)]  
AT90PWM3@SOIC32(ISP) [ISP-HEADER01]  
AT90PWM316@QFN32 [(SA701)] AT90PWM316@SOIC32  
[(SA715)]  
AT90PWM3B@QFN32 [(SA701)]  
AT90PWM3B@QFN32(ISP) [ISP-HEADER01]  
AT90PWM3B@SOIC32 [(SA715)]  
AT90PWM3B@SOIC32(ISP) [ISP-HEADER01]  
AT90S1200 AT90S1200(ISP) [ISP-  
HEADER01]  
AT90S1200@SOIC20 [(SA404)]  
AT90S1200@SOIC20(ISP) [ISP-HEADER01]  
AT90S1200@SSOP20 [(SA626A)]  
AT90S1200@SSOP20(ISP) [ISP-HEADER01]  
AT90S1200A AT90S1200A(ISP) [ISP-  
HEADER01]  
AT90S1200A@SOIC20 [(SA404)]

AT90S1200A@SOIC20(ISP) [ISP-HEADER01]  
AT90S1200A@SSOP20 [(SA626A)]  
AT90S1200A@SSOP20(ISP) [ISP-HEADER01]  
AT90S2313 AT90S2313(ISP) [ISP-  
HEADER01]  
AT90S2313@SOIC20 [(SA404)]  
AT90S2313@SOIC20(ISP) [ISP-HEADER01]  
AT90S2323 AT90S2323(ISP) [ISP-  
HEADER01]  
AT90S2323@SOIC8 [(SA605A)]  
AT90S2323@SOIC8(ISP) [ISP-HEADER01]  
AT90S2333 AT90S2333(ISP) [ISP-  
HEADER01]  
AT90S2333@TQFP32 [(SA663)]  
AT90S2333@TQFP32(ISP) [ISP-HEADER01]  
AT90S2343 AT90S2343(ISP) [ISP-  
HEADER01]  
AT90S2343@SOIC8 [(SA605A)]  
AT90S2343@SOIC8(ISP) [ISP-HEADER01]  
AT90S4414 AT90S4414(ISP) [ISP-  
HEADER01]  
AT90S4414@PLCC44 [(SA244)]  
AT90S4414@PLCC44(ISP) [ISP-HEADER01]  
AT90S4414@TQFP44 [(SA245A)]  
AT90S4414@TQFP44(ISP) [ISP-HEADER01]  
AT90S4433 AT90S4433(ISP) [ISP-  
HEADER01]  
AT90S4433@TQFP32 [(SA663)]  
AT90S4433@TQFP32(ISP) [ISP-HEADER01]  
AT90S4434 AT90S4434(ISP) [ISP-  
HEADER01]  
AT90S4434@PLCC44 [(SA244)]  
AT90S4434@PLCC44(ISP) [ISP-HEADER01]  
AT90S4434@TQFP44 [(SA245A)]  
AT90S4434@TQFP44(ISP) [ISP-HEADER01]  
AT90S8515 AT90S8515(ISP) [ISP-  
HEADER01]  
AT90S8515@PLCC44 [(SA244)]  
AT90S8515@PLCC44(ISP) [ISP-HEADER01]  
AT90S8515@TQFP44 [(SA245A)]  
AT90S8515@TQFP44(ISP) [ISP-HEADER01]  
AT90S8535 AT90S8535(ISP) [ISP-  
HEADER01]

AT90S8535@PLCC44 [(SA244)]  
AT90S8535@PLCC44(ISP) [ISP-HEADER01]  
AT90S8535@TQFP44 [(SA245A)]  
AT90S8535@TQFP44(ISP) [ISP-HEADER01]  
AT90USB1286@QFN64 [(PEP+S702)]  
AT90USB1286@QFN64(ISP) [ISP-HEADER01]  
AT90USB1286@TQFP64 [(PEP+S625A)]  
AT90USB1286@TQFP64(ISP) [ISP-HEADER01]  
AT90USB1287@QFN64 [(PEP+S702)]  
AT90USB1287@QFN64(ISP) [ISP-HEADER01]  
AT90USB1287@TQFP64 [(PEP+S625A)]  
AT90USB1287@TQFP64(ISP) [ISP-HEADER01]  
AT90USB162@QFN32 [(SA686)] AT90USB162@VQFP32  
[(SA663)]  
AT90USB646@QFN64 [(PEP+S702)]  
AT90USB646@QFN64(ISP) [ISP-HEADER01]  
AT90USB646@TQFP64 [(PEP+S625A)]  
AT90USB646@TQFP64(ISP) [ISP-HEADER01]  
AT90USB647@QFN64 [(PEP+S702)]  
AT90USB647@QFN64(ISP) [ISP-HEADER01]  
AT90USB647@TQFP64 [(PEP+S625A)]  
AT90USB647@TQFP64(ISP) [ISP-HEADER01]  
AT90USB82@QFN32 [(SA686)]  
AT91FR40162@FBGA121 [(SA664B-B100A-W121F001)]  
AT91FR40162S@FBGA121 [(SA664B-B100A-W121F001Y)]  
AT91FR4042@FBGA121 [(SA664B-B100A-W121F001)]  
AT91SAM7S128@LQFP64 [(PEP+S616)]  
AT91SAM7S128@LQFP64(\*) [(TA059-B006)]  
AT91SAM7S128@QFN64 [(PEP+S702)]  
AT91SAM7S128@QFN64(\*) [(SA734-B318)]  
AT91SAM7S256@LQFP64 [(PEP+S616)]  
AT91SAM7S256@LQFP64(\*) [(TA059-B006)]  
AT91SAM7S256@QFN64 [(PEP+S702)]  
AT91SAM7S256@QFN64(\*) [(SA734-B318)]  
AT91SAM7S32@LQFP48 [(SA248)] AT91SAM7S321@LQFP64 [(PEP  
+S616)]  
AT91SAM7S321@LQFP64(\*) [(TA059-B006)]  
AT91SAM7S321@QFN64(\*) [(SA734-B318)]  
AT91SAM7S64@LQFP64 [(PEP+S616)]  
AT91SAM7S64@LQFP64(\*) [(TA059-B006)]  
AT91SAM7S64@QFN64(\*) [(SA734-B318)]  
AT91SAM7SE512AU@LQFP128(\*) [(SA720-B203)]  
AT91SAM7X128@LQFP100 [(PEP+S604)]

AT91SAM7X128AU@LQFP100(\*) [(SA718+B185)]  
 AT91SAM7X256@LQFP100 [(PEP+S604)]  
 AT91SAM7X256AU@LQFP100(\*) [(SA718+B185)]  
 AT91SAM7XC128AU@LQFP100(\*) [(SA718+B185)]  
 AT91SAM7XC256AU@LQFP100(\*) [(SA718+B185)]  
 ATAM862@SSO24 [(SA026)] ATAM893@SSO20  
 [(SA026)]  
 ATAM894@SSO24 [(SA026)] ATMEGA103@TQFP64 [(PEP  
 +S625A)]  
 ATMEGA103L@TQFP64 [(PEP+S625A)] ATMEGA128@QFN64 [(PEP  
 +S702)]  
 ATMEGA128@QFN64(\*) [(SA734+B211)]  
 ATMEGA128@QFN64(ISP) [ISP-HEADER01]  
 ATMEGA128@TQFP64 [(PEP+S625A)]  
 ATMEGA128@TQFP64(\*) [(SA668+B211)]  
 ATMEGA128@TQFP64(ISP) [ISP-HEADER01]  
 ATMEGA128@TQFP64(JTAG) [ISP-HEADER01]  
 ATMEGA1280@TQFP100(\*) [(TA065+B006)]  
 ATMEGA1280@TQFP100(ISP) [ISP-HEADER01]  
 ATMEGA1280V@TQFP100(\*) [(TA065+B006)]  
 ATMEGA1280V@TQFP100(ISP) [ISP-HEADER01]  
 ATMEGA1281@QFN64 [(PEP+S702)] ATMEGA1281@TQFP64 [(PEP  
 +S625A)]  
 ATMEGA1281@TQFP64(\*) [(TA057-B006)]  
 ATMEGA128L@QFN64 [(PEP+S702)]  
 ATMEGA128L@QFN64(ISP) [ISP-HEADER01]  
 ATMEGA128L@TQFP64 [(PEP+S625A)]  
 ATMEGA128L@TQFP64(\*) [(SA668+B211)]  
 ATMEGA128L@TQFP64(ISP) [ISP-HEADER01]  
 ATMEGA128L@TQFP64(JTAG) [ISP-HEADER01]  
 ATMEGA16 ATMEGA16  
 (fast)  
 ATMEGA16(fast)@MLF44 [(SA712)] ATMEGA16(fast)@TQFP44  
 [(SA245A)]  
 ATMEGA16(ISP) [ISP-HEADER01] ATMEGA16(JTAG) [ISP-  
 HEADER01]  
 ATMEGA16@MLF44 [(SA712)]  
 ATMEGA16@MLF44(ISP) [ISP-HEADER01]  
 ATMEGA16@QFN44(JTAG) [ISP-HEADER01]  
 ATMEGA16@TQFP44 [(SA245A)]  
 ATMEGA16@TQFP44(ISP) [ISP-HEADER01]  
 ATMEGA16@TQFP44(JTAG) [ISP-HEADER01]  
 ATMEGA161 ATMEGA161@TQFP44

[ (SA245A) ]  
 ATMEGA161L ATMEGA161L@TQFP44  
 [ (SA245A) ]  
 ATMEGA162 ATMEGA162(ISP) [ISP-  
 HEADER01]  
 ATMEGA162@PLCC44(ISP) [ISP-HEADER01]  
 ATMEGA162@TQFP44 [ (SA245A) ]  
 ATMEGA162@TQFP44(ISP) [ISP-HEADER01]  
 ATMEGA162V ATMEGA162V@TQFP44  
 [ (SA245A) ]  
 ATMEGA163 ATMEGA163@TQFP44  
 [ (SA245A) ]  
 ATMEGA163L ATMEGA163L@TQFP44  
 [ (SA245A) ]  
 ATMEGA164P ATMEGA164P@MLP44  
 [ (SA712) ]  
 ATMEGA164P@TQFP44 [ (SA245A) ]  
 ATMEGA164PL ATMEGA164PL@TQFP44  
 ATMEGA164PL@MLP44 [ (SA712) ]  
 [ (SA245A) ]  
 ATMEGA165@QFN64 [ (PEP+S702) ]  
 ATMEGA165@QFN64(ISP) [ISP-HEADER01]  
 ATMEGA165@TQFP64 [ (PEP+S625A) ]  
 ATMEGA165@TQFP64(ISP) [ISP-HEADER01]  
 ATMEGA168 ATMEGA168(ISP) [ISP-  
 HEADER01]  
 ATMEGA168@MLP32 [ (SA686) ]  
 ATMEGA168@MLP32(ISP) [ISP-HEADER01]  
 ATMEGA168@TQFP32 [ (SA663) ]  
 ATMEGA168@TQFP32(ISP) [ISP-HEADER01]  
 ATMEGA168P ATMEGA168P(ISP) [ISP-  
 HEADER01]  
 ATMEGA168P@MLP32 [ (SA686) ]  
 ATMEGA168P@MLP32(ISP) [ISP-HEADER01]  
 ATMEGA168P@TQFP32 [ (SA663) ]  
 ATMEGA168P@TQFP32(ISP) [ISP-HEADER01]  
 ATMEGA168PV ATMEGA168PV(ISP) [ISP-  
 HEADER01]  
 ATMEGA168PV@MLP32 [ (SA686) ]  
 ATMEGA168PV@MLP32(ISP) [ISP-HEADER01]  
 ATMEGA168PV@TQFP32 [ (SA663) ]  
 ATMEGA168PV@TQFP32(ISP) [ISP-HEADER01]  
 ATMEGA168V ATMEGA168V(ISP) [ISP-

HEADER01 ]  
ATMEGA168V@MLP32 [ (SA686) ]  
ATMEGA168V@MLP32(ISP) [ ISP-HEADER01 ]  
ATMEGA168V@TQFP32 [ (SA663) ]  
ATMEGA168V@TQFP32(ISP) [ ISP-HEADER01 ]  
ATMEGA169@MLF64 [ (PEP+S702) ]  
ATMEGA169@MLF64(ISP) [ ISP-HEADER01 ]  
ATMEGA169@TQFP64 [ (PEP+S625A) ]  
ATMEGA169@TQFP64(ISP) [ ISP-HEADER01 ]  
ATMEGA169PV@MLF64 [ (PEP+S702) ]  
ATMEGA169PV@MLF64(ISP) [ ISP-HEADER01 ]  
ATMEGA169PV@TQFP64 [ (PEP+S625A) ]  
ATMEGA169PV@TQFP64(ISP) [ ISP-HEADER01 ]  
ATMEGA169V@MLF64 [ (PEP+S702) ]                   ATMEGA169V@TQFP64 [ (PEP  
+S625A) ]  
ATMEGA16L                                           ATMEGA16L  
(fast)  
ATMEGA16L(fast)@MLF44 [ (SA712) ]  
ATMEGA16L(fast)@TQFP44 [ (SA245A) ]  
ATMEGA16L(ISP) [ ISP-HEADER01 ]                   ATMEGA16L(JTAG) [ ISP-  
HEADER01 ]  
ATMEGA16L@MLF44 [ (SA712) ]  
ATMEGA16L@MLF44(ISP) [ ISP-HEADER01 ]  
ATMEGA16L@QFN44(JTAG) [ ISP-HEADER01 ]  
ATMEGA16L@TQFP44 [ (SA245A) ]  
ATMEGA16L@TQFP44(ISP) [ ISP-HEADER01 ]  
ATMEGA16L@TQFP44(JTAG) [ ISP-HEADER01 ]  
ATMEGA2560@TQFP100(\*) [ (TA065+B006) ]  
ATMEGA2560@TQFP100(ISP) [ ISP-HEADER01 ]  
ATMEGA2560V@TQFP100(\*) [ (TA065+B006) ]  
ATMEGA2560V@TQFP100(ISP) [ ISP-HEADER01 ]  
ATMEGA2561@QFN64 [ (PEP+S702) ]  
ATMEGA2561@QFN64(ISP) [ ISP-HEADER01 ]  
ATMEGA2561@TQFP64 [ (PEP+S625A) ]  
ATMEGA2561@TQFP64(\*) [ (TA057-B006) ]  
ATMEGA2561@TQFP64(ISP) [ ISP-HEADER01 ]  
ATMEGA2561V@QFN64 [ (PEP+S702) ]  
ATMEGA2561V@QFN64(ISP) [ ISP-HEADER01 ]  
ATMEGA2561V@TQFP64 [ (PEP+S625A) ]  
ATMEGA2561V@TQFP64(\*) [ (TA057-B006) ]  
ATMEGA2561V@TQFP64(ISP) [ ISP-HEADER01 ]  
ATMEGA32                                           ATMEGA32(ISP) [ ISP-  
HEADER01 ]

ATMEGA32(JTAG) [ISP-HEADER01] ATMEGA32  
(new)  
ATMEGA32(new)(fast)  
ATMEGA32(new)(fast)@MLF44 [(SA712)]  
ATMEGA32(new)(fast)@PLCC44 [(SA244)]  
ATMEGA32(new)(fast)@TQFP44 [(SA245A)]  
ATMEGA32(new)@MLF44 [(SA712)] ATMEGA32(new)@PLCC44  
[(SA244)]  
ATMEGA32(new)@TQFP44 [(SA245A)] ATMEGA32@MLF44  
[(SA712)]  
ATMEGA32@MLF44(ISP) [ISP-HEADER01]  
ATMEGA32@PLCC44 [(SA244)]  
ATMEGA32@QFN44(JTAG) [ISP-HEADER01]  
ATMEGA32@TQFP44 [(SA245A)]  
ATMEGA32@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA32@TQFP44(JTAG) [ISP-HEADER01]  
ATMEGA323 ATMEGA323@TQFP44  
[(SA245A)]  
ATMEGA323L ATMEGA323L@TQFP44  
[(SA245A)]  
ATMEGA324P ATMEGA324P@MLP44  
[(SA712)]  
ATMEGA324P@TQFP44 [(SA245A)]  
ATMEGA324PL ATMEGA324PL@TQFP44  
[(SA245A)]  
ATMEGA325@TQFP64 [(PEP+S625A)]  
ATMEGA3250@TQFP100(\*) [(TA065-B006)]  
ATMEGA3250@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA325P@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA325V@QFN64 [(PEP+S702)]  
ATMEGA325V@QFN64(ISP) [ISP-HEADER01]  
ATMEGA328P ATMEGA328P(ISP) [ISP-  
HEADER01]  
ATMEGA328P@MLP32 [(SA686)]  
ATMEGA328P@MLP32(ISP) [ISP-HEADER01]  
ATMEGA328P@TQFP32 [(SA663)]  
ATMEGA328P@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA328PV ATMEGA328PV(ISP) [ISP-  
HEADER01]  
ATMEGA328PV@MLP32 [(SA686)]  
ATMEGA328PV@MLP32(ISP) [ISP-HEADER01]  
ATMEGA328PV@TQFP32 [(SA663)]

ATMEGA328PV@TQFP32(ISP) [ISP-HEADER01]  
 ATMEGA329@QFN64 [(PEP+S702)]  
 ATMEGA329@QFN64(ISP) [ISP-HEADER01]  
 ATMEGA329@TQFP64 [(PEP+S625A)]  
 ATMEGA3290@TQFP100(\*) [(TA065-B006)]  
 ATMEGA3290@TQFP100(ISP) [ISP-HEADER01]  
 ATMEGA3290P@TQFP100(\*) [(TA065-B006)]  
 ATMEGA329P@QFN64 [(PEP+S702)] ATMEGA329P@TQFP64 [(PEP+S625A)]  
 ATMEGA329P@TQFP64(ISP) [ISP-HEADER01]  
 ATMEGA32L ATMEGA32L(ISP) [ISP-HEADER01]  
 ATMEGA32L(JTAG) [ISP-HEADER01] ATMEGA32L  
 (new)  
 ATMEGA32L(new)(fast)  
 ATMEGA32L(new)(fast)@MLF44 [(SA712)]  
 ATMEGA32L(new)(fast)@PLCC44 [(SA244)]  
 ATMEGA32L(new)(fast)@TQFP44 [(SA245A)]  
 ATMEGA32L(new)@MLF44 [(SA712)] ATMEGA32L(new)@PLCC44  
 [(SA244)]  
 ATMEGA32L(new)@TQFP44 [(SA245A)] ATMEGA32L@MLF44  
 [(SA712)]  
 ATMEGA32L@MLF44(ISP) [ISP-HEADER01]  
 ATMEGA32L@PLCC44 [(SA244)]  
 ATMEGA32L@QFN44(JTAG) [ISP-HEADER01]  
 ATMEGA32L@TQFP44 [(SA245A)]  
 ATMEGA32L@TQFP44(ISP) [ISP-HEADER01]  
 ATMEGA32L@TQFP44(JTAG) [ISP-HEADER01]  
 ATMEGA406@LQFP48 [(SA248)]  
 ATMEGA48  
 ATMEGA48(ISP) [ISP-HEADER01] ATMEGA48@MLP32  
 [(SA686)]  
 ATMEGA48@MLP32(ISP) [ISP-HEADER01]  
 ATMEGA48@TQFP32 [(SA663)]  
 ATMEGA48@TQFP32(ISP) [ISP-HEADER01]  
 ATMEGA48P ATMEGA48P@MLP32  
 [(SA686)]  
 ATMEGA48P@TQFP32 [(SA663)]  
 ATMEGA48PV  
 ATMEGA48PV@MLP32 [(SA686)] ATMEGA48PV@TQFP32  
 [(SA663)]  
 ATMEGA48V ATMEGA48V(ISP) [ISP-HEADER01]



ATMEGA48V@MLP32 [(SA686)]  
ATMEGA48V@MLP32(ISP) [ISP-HEADER01]  
ATMEGA48V@TQFP32 [(SA663)]  
ATMEGA48V@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA603@TQFP64 [(PEP+S625A)] ATMEGA603L@TQFP64 [(PEP+S625A)]  
ATMEGA64@QFN64 [(PEP+S702)]  
ATMEGA64@QFN64(ISP) [ISP-HEADER01]  
ATMEGA64@QFN64(JTAG) [ISP-HEADER01]  
ATMEGA64@TQFP64 [(PEP+S625A)]  
ATMEGA64@TQFP64(\*) [(SA668+B211)]  
ATMEGA64@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA64@TQFP64(JTAG) [ISP-HEADER01]  
ATMEGA640@TQFP100(\*) [(TA065+B006)]  
ATMEGA644 ATMEGA644(ISP) [ISP-HEADER01]  
ATMEGA644(JTAG) [ISP-HEADER01] ATMEGA644@MLF44  
[(SA712)]  
ATMEGA644@MLF44(ISP) [ISP-HEADER01]  
ATMEGA644@QFN44(JTAG) [ISP-HEADER01]  
ATMEGA644@TQFP44 [(SA245A)]  
ATMEGA644@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA644@TQFP44(JTAG) [ISP-HEADER01]  
ATMEGA644P ATMEGA644P(ISP) [ISP-HEADER01]  
ATMEGA644P@MLF44 [(SA712)]  
ATMEGA644P@MLF44(ISP) [ISP-HEADER01]  
ATMEGA644P@TQFP44 [(SA245A)]  
ATMEGA644P@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA644PV ATMEGA644PV(ISP) [ISP-HEADER01]  
ATMEGA644PV@MLF44 [(SA712)]  
ATMEGA644PV@MLF44(ISP) [ISP-HEADER01]  
ATMEGA644PV@TQFP44 [(SA245A)]  
ATMEGA644PV@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA644V ATMEGA644V(ISP) [ISP-HEADER01]  
ATMEGA644V@MLF44 [(SA712)]  
ATMEGA644V@MLF44(ISP) [ISP-HEADER01]  
ATMEGA644V@TQFP44 [(SA245A)]  
ATMEGA644V@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA645@QFN64 [(PEP+S702)]  
ATMEGA645@QFN64(ISP) [ISP-HEADER01]

```

ATMEGA645@TQFP64 [(PEP+S625A)]
ATMEGA645@TQFP64(ISP) [ISP-HEADER01]
ATMEGA6450@TQFP100(*) [(TA065-B006)]
ATMEGA6450@TQFP100(ISP) [ISP-HEADER01]
ATMEGA649@TQFP64 [(PEP+S625A)]
ATMEGA649@TQFP64(ISP) [ISP-HEADER01]
ATMEGA6490@TQFP100(*) [(TA065-B006)]
ATMEGA6490@TQFP100(ISP) [ISP-HEADER01]
ATMEGA649V@QFN64 [(PEP+S702)]
ATMEGA649V@QFN64(ISP) [ISP-HEADER01]
ATMEGA64L@QFN64 [(PEP+S702)]
ATMEGA64L@QFN64(ISP) [ISP-HEADER01]
ATMEGA64L@QFN64(JTAG) [ISP-HEADER01]
ATMEGA64L@TQFP64 [(PEP+S625A)]
ATMEGA64L@TQFP64(*) [(SA668+B211)]
ATMEGA64L@TQFP64(ISP) [ISP-HEADER01]
ATMEGA64L@TQFP64(JTAG) [ISP-HEADER01]
ATMEGA8                                ATMEGA8
(fast)
ATMEGA8(fast)@TQFP32 [(SA663)]        ATMEGA8(ISP) [ISP-
HEADER01]
ATMEGA8@MLF32 [(SA686)]
ATMEGA8@MLF32(ISP) [ISP-HEADER01]
ATMEGA8@TQFP32 [(SA663)]
ATMEGA8@TQFP32(ISP) [ISP-HEADER01]
ATMEGA8515                              ATMEGA8515
(fast)
ATMEGA8515(fast)@PLCC44 [(SA244)]
ATMEGA8515(fast)@TQFP44 [(SA245A)]
ATMEGA8515(ISP) [ISP-HEADER01]        ATMEGA8515@PLCC44
[(SA244)]
ATMEGA8515@PLCC44(ISP) [ISP-HEADER01]
ATMEGA8515@TQFP44 [(SA245A)]
ATMEGA8515@TQFP44(ISP) [ISP-HEADER01]
ATMEGA8515L                              ATMEGA8515L
(fast)
ATMEGA8515L(fast)@PLCC44 [(SA244)]
ATMEGA8515L(fast)@TQFP44 [(SA245A)]
ATMEGA8515L(ISP) [ISP-HEADER01]        ATMEGA8515L@PLCC44
[(SA244)]
ATMEGA8515L@PLCC44(ISP) [ISP-HEADER01]
ATMEGA8515L@TQFP44 [(SA245A)]
ATMEGA8515L@TQFP44(ISP) [ISP-HEADER01]

```

ATMEGA8535	ATMEGA8535
(fast)	
ATMEGA8535(fast)@MLF44 [(SA712)]	
ATMEGA8535(fast)@PLCC44 [(SA244)]	
ATMEGA8535(fast)@TQFP44 [(SA245A)]	
ATMEGA8535(ISP) [ISP-HEADER01]	ATMEGA8535@PLCC44
[(SA244)]	
ATMEGA8535@PLCC44(ISP) [ISP-HEADER01]	
ATMEGA8535@TQFP44 [(SA245A)]	
ATMEGA8535@TQFP44(ISP) [ISP-HEADER01]	
ATMEGA8535L	ATMEGA8535L
(fast)	
ATMEGA8535L(fast)@MLF44 [(SA712)]	
ATMEGA8535L(fast)@PLCC44 [(SA244)]	
ATMEGA8535L(fast)@TQFP44 [(SA245A)]	
ATMEGA8535L(ISP) [ISP-HEADER01]	ATMEGA8535L@PLCC44
[(SA244)]	
ATMEGA8535L@PLCC44(ISP) [ISP-HEADER01]	
ATMEGA8535L@TQFP44 [(SA245A)]	
ATMEGA8535L@TQFP44(ISP) [ISP-HEADER01]	
ATMEGA88	ATMEGA88(ISP) [ISP-
HEADER01]	
ATMEGA88@MLP32 [(SA686)]	
ATMEGA88@MLP32(ISP) [ISP-HEADER01]	
ATMEGA88@TQFP32 [(SA663)]	
ATMEGA88@TQFP32(ISP) [ISP-HEADER01]	
ATMEGA88P	ATMEGA88P@MLP32
[(SA686)]	
ATMEGA88P@TQFP32 [(SA663)]	
ATMEGA88PV	
ATMEGA88PV@MLP32 [(SA686)]	ATMEGA88PV@TQFP32
[(SA663)]	
ATMEGA88V	ATMEGA88V(ISP) [ISP-
HEADER01]	
ATMEGA88V@MLP32 [(SA686)]	
ATMEGA88V@MLP32(ISP) [ISP-HEADER01]	
ATMEGA88V@TQFP32 [(SA663)]	
ATMEGA88V@TQFP32(ISP) [ISP-HEADER01]	
ATMEGA8L	ATMEGA8L
(fast)	
ATMEGA8L(fast)@TQFP32 [(SA663)]	ATMEGA8L(ISP) [ISP-
HEADER01]	
ATMEGA8L@MLF32 [(SA686)]	

ATMEGA8L@MLF32(ISP) [ISP-HEADER01]  
 ATMEGA8L@TQFP32 [(SA663)]  
 ATMEGA8L@TQFP32(ISP) [ISP-HEADER01]  
 ATtiny10 ATtiny10(ISP) [ISP-  
 HEADER01]  
 ATtiny10@SOIC8 [(SA605A)]  
 ATtiny10@SOIC8(ISP) [ISP-HEADER01]  
 ATtiny11 ATtiny11(ISP) [ISP-  
 HEADER01]  
 ATtiny11@SOIC8 [(SA605A)]  
 ATtiny11@SOIC8(ISP) [ISP-HEADER01]  
 ATtiny11L ATtiny11L(ISP) [ISP-  
 HEADER01]  
 ATtiny11L@SOIC8 [(SA605A)]  
 ATtiny11L@SOIC8(ISP) [ISP-HEADER01]  
 ATtiny12 ATtiny12(ISP) [ISP-  
 HEADER01]  
 ATtiny12@SOIC8 [(SA605A)]  
 ATtiny12@SOIC8(ISP) [ISP-HEADER01]  
 ATtiny12L ATtiny12L(ISP) [ISP-  
 HEADER01]  
 ATtiny12L@SOIC8 [(SA605A)]  
 ATtiny12L@SOIC8(ISP) [ISP-HEADER01]  
 ATtiny12V ATtiny12V(ISP) [ISP-  
 HEADER01]  
 ATtiny12V@SOIC8 [(SA605A)]  
 ATtiny12V@SOIC8(ISP) [ISP-HEADER01]  
 ATtiny13 ATtiny13  
 (Fuse)  
 ATtiny13(Fuse)@QFN20 [(SA692)]  
 ATtiny13(Fuse)@SOIC8(3.9\*6.2) [(SA602A)]  
 ATtiny13(Fuse)@SOIC8(5.5\*8.0) [(SA605A)]  
 ATtiny13(ISP) [ISP-HEADER01] ATtiny13@QFN20  
 [(SA692)]  
 ATtiny13@QFN20(ISP) [ISP-HEADER01]  
 ATtiny13@SOIC8(3.9\*6.2) [(SA602A)]  
 ATtiny13@SOIC8(3.9\*6.2)(ISP) [ISP-HEADER01]  
 ATtiny13@SOIC8(5.5\*8.0) [(SA605A)]  
 ATtiny13@SOIC8(5.5\*8.0)(ISP) [ISP-HEADER01]  
 ATtiny13V ATtiny13V  
 (Fuse)  
 ATtiny13V(Fuse)@QFN20 [(SA692)]  
 ATtiny13V(Fuse)@SOIC8(3.9\*6.2) [(SA602A)]

ATtiny13V(Fuse)@SOIC8(5.5\*8.0) [(SA605A)]  
ATtiny13V(ISP) [ISP-HEADER01] ATtiny13V@QFN20  
[(SA692)]  
ATtiny13V@QFN20(ISP) [ISP-HEADER01]  
ATtiny13V@SOIC8(3.9\*6.2) [(SA602A)]  
ATtiny13V@SOIC8(3.9\*6.2)(ISP) [ISP-HEADER01]  
ATtiny13V@SOIC8(5.5\*8.0) [(SA605A)]  
ATtiny13V@SOIC8(5.5\*8.0)(ISP) [ISP-HEADER01]  
ATtiny15 ATtiny15(ISP) [ISP-  
HEADER01]  
ATtiny15@SOIC8 [(SA605A)]  
ATtiny15@SOIC8(ISP) [ISP-HEADER01]  
ATtiny15L ATtiny15L(ISP) [ISP-  
HEADER01]  
ATtiny15L@SOIC8 [(SA605A)]  
ATtiny15L@SOIC8(ISP) [ISP-HEADER01]  
ATtiny2313 ATtiny2313(ISP) [ISP-  
HEADER01]  
ATtiny2313@SOIC20 [(SA404)]  
ATtiny2313@SOIC20(ISP) [ISP-HEADER01]  
ATtiny2313V ATtiny2313V(ISP) [ISP-  
HEADER01]  
ATtiny2313V@SOIC20 [(SA404)]  
ATtiny2313V@SOIC20(ISP) [ISP-HEADER01]  
ATtiny24 ATtiny24(ISP) [ISP-  
HEADER01]  
ATtiny24@QFN20 [(SA692)]  
ATtiny24@QFN20(ISP) [ISP-HEADER01]  
ATtiny24@SOIC14 [(SA602)]  
ATtiny24@SOIC14(ISP) [ISP-HEADER01]  
ATtiny24V ATtiny24V(ISP) [ISP-  
HEADER01]  
ATtiny24V@QFN20 [(SA692)]  
ATtiny24V@QFN20(ISP) [ISP-HEADER01]  
ATtiny24V@SOIC14 [(SA602)]  
ATtiny24V@SOIC14(ISP) [ISP-HEADER01]  
ATtiny25 ATtiny25(ISP) [ISP-  
HEADER01]  
ATtiny25@QFN20 [(SA692)]  
ATtiny25@QFN20(ISP) [ISP-HEADER01]  
ATtiny25@SOIC8 [(SA023A)]  
ATtiny25@SOIC8(ISP) [ISP-HEADER01]  
ATtiny26 ATtiny26(ISP) [ISP-

HEADER01]  
ATtiny26(new)  
ATtiny26(new)(ISP) [ISP-HEADER01]  
ATtiny26(new)@QFN32 [(SA686)]                    ATtiny26(new)@SOIC20  
[(SA404)]  
ATtiny26(new)@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26(new)@TSSOP20 [(SA026)]  
ATtiny26(new)@TSSOP20(ISP) [ISP-HEADER01]  
ATtiny26@QFN32 [(SA686)]                    ATtiny26@SOIC20  
[(SA404)]  
ATtiny26@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26@TSSOP20 [(SA026)]  
ATtiny26@TSSOP20(ISP) [ISP-HEADER01]  
ATtiny261                    ATtiny261@MLP32  
[(SA686)]  
ATtiny261@SOIC20 [(SA404)]  
ATtiny261V                    ATtiny261V@SOIC20  
ATtiny261V@MLP32 [(SA686)]  
[(SA404)]  
ATtiny26L                    ATtiny26L(ISP) [ISP-  
HEADER01]  
ATtiny26L(new)  
ATtiny26L(new)(ISP) [ISP-HEADER01]  
ATtiny26L(new)@QFN32 [(SA686)]                    ATtiny26L(new)@SOIC20  
[(SA404)]  
ATtiny26L(new)@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26L(new)@TSSOP20 [(SA026)]  
ATtiny26L(new)@TSSOP20(ISP) [ISP-HEADER01]  
ATtiny26L@QFN32 [(SA686)]                    ATtiny26L@SOIC20  
[(SA404)]  
ATtiny26L@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26L@TSSOP20 [(SA026)]  
ATtiny26L@TSSOP20(ISP) [ISP-HEADER01]  
ATtiny28L                    ATtiny28L@TQFP32  
[(SA663)]  
ATtiny28V                    ATtiny28V@TQFP32  
[(SA663)]  
ATtiny44                    ATtiny44(ISP) [ISP-  
HEADER01]  
ATtiny44@QFN20 [(SA692)]  
ATtiny44@QFN20(ISP) [ISP-HEADER01]  
ATtiny44@SOIC14 [(SA602)]  
ATtiny44@SOIC14(ISP) [ISP-HEADER01]

ATtiny45  
 ATtiny45(ISP)(12V) [ISP-HEADER01]  
 ATtiny45(ISP)(5V) [ISP-HEADER01]      ATtiny45@QFN20  
 [(SA692)]  
 ATtiny45@QFN20(ISP)(12V) [ISP-HEADER01]  
 ATtiny45@QFN20(ISP)(5V) [ISP-HEADER01]  
 ATtiny45@SOIC8 [(S605)]  
 ATtiny45@SOIC8(ISP)(12V) [ISP-HEADER01]  
 ATtiny45@SOIC8(ISP)(5V) [ISP-HEADER01]  
 ATtiny461                                      ATtiny461@MLP32  
 [(SA686)]  
 ATtiny461@SOIC20 [(SA404)]  
 ATtiny461V  
 ATtiny461V@MLP32 [(SA686)]                      ATtiny461V@SOIC20  
 [(SA404)]  
 ATtiny84                                      ATtiny84(ISP) [ISP-  
 HEADER01]  
 ATtiny84@QFN20 [(SA692)]  
 ATtiny84@QFN20(ISP) [ISP-HEADER01]  
 ATtiny84@SOIC14 [(SA602)]  
 ATtiny84@SOIC14(ISP) [ISP-HEADER01]  
 ATtiny85  
 ATtiny85(ISP)(12V) [ISP-HEADER01]  
 ATtiny85(ISP)(5V) [ISP-HEADER01]      ATtiny85@QFN20  
 [(SA692)]  
 ATtiny85@QFN20(ISP)(12V) [ISP-HEADER01]  
 ATtiny85@QFN20(ISP)(5V) [ISP-HEADER01]  
 ATtiny85@SOIC8 [(S605)]  
 ATtiny85@SOIC8(ISP)(12V) [ISP-HEADER01]  
 ATtiny85@SOIC8(ISP)(5V) [ISP-HEADER01]  
 ATtiny861                                      ATtiny861@MLP32  
 [(SA686)]  
 ATtiny861@SOIC20 [(SA404)]  
 ATtiny861V  
 ATtiny861V@MLP32 [(SA686)]                      ATtiny861V@SOIC20  
 [(SA404)]  
 T89C51SND1@TQFP80 [(PEP+S704)]  
 T89F64  
 T89F64@PLCC44 [(SA244)]                      T89F64@TQFP44  
 [(SA245A)]

**ATMEL W&M**

## MICROCONTROLLER

AT89C5115@PLCC28 [(SA008A)]	AT89C5115@SOIC28
[(SA404)]	
AT89C5115@TQFP32 [(SA663)]	AT89C51CC02@PLCC28
[(SA008A)]	
AT89C51CC02@SOIC28 [(SA404)]	AT89C51CC02@TQFP32
[(SA663)]	
T89C5115@PLCC28 [(SA008A)]	T89C5115@SOIC28
[(SA404)]	
T89C5115@TQFP32 [(SA663)]	T89C51AC2@PLCC44
[(SA244)]	
T89C51AC2@TQFP44 [(SA245A)]	T89C51CC01@PLCC44
[(SA244)]	
T89C51CC01@TQFP44 [(SA245A)]	T89C51CC02@PLCC28
[(SA008A)]	
T89C51CC02@SOIC24 [(SA404)]	T89C51CC02@SOIC28
[(SA404)]	
T89C51CC02@TQFP32 [(SA663)]	T89C51IB2@PLCC44
[(SA244)]	
T89C51IB2@TQFP44 [(SA245A)]	T89C51IC2@PLCC44
[(SA244)]	
T89C51IC2@TQFP44 [(SA245A)]	
T89C51RB2	
T89C51RB2@PLCC44 [(SA244)]	T89C51RB2@TQFP44
[(SA245A)]	
T89C51RC2	T89C51RC2@PLCC44
[(SA244)]	
T89C51RC2@TQFP44 [(SA245A)]	
T89C51RD2	
T89C51RD2@PLCC44 [(SA244)]	T89C51RD2@PLCC68 [(PEP
+S414T)]	
T89C51RD2@TQFP44 [(SA245A)]	
T89F64	
T89F64@PLCC44 [(SA244)]	T89F64@TQFP44
[(SA245A)]	
TS87C51RB2	TS87C51RB2@PLCC44
[(SA244)]	
TS87C51RB2@TQFP44 [(SA245A)]	
TS87C51RC2	
TS87C51RC2@PLCC44 [(SA244)]	TS87C51RC2@TQFP44
[(SA245A)]	



TS87C51RD2 [ (SA244) ]	TS87C51RD2@PLCC44
TS87C51RD2@TQFP44 [ (SA245A) ]	
TS87C51U2 TS87C51U2@PLCC44 [ (SA244) ] [ (SA245A) ]	TS87C51U2@TQFP44
TS87C52X2 [ (SA244) ]	TS87C52X2@PLCC44
TS87C52X2@TQFP44 [ (SA245A) ]	
TS87C54X2 TS87C54X2@PLCC44 [ (SA244) ] [ (SA245A) ]	TS87C54X2@TQFP44
TS87C58X2 [ (SA244) ]	TS87C58X2@PLCC44
TS87C58X2@TQFP44 [ (SA245A) ] [ (SA244) ]	TSC87251A1@PLCC44
TSC87251G1 [ (SA244) ]	TSC87251G1@PLCC44
TSC87251G1A [ (SA244) ]	TSC87251G1A@PLCC44
TSC87251G2D [ (SA244) ]	TSC87251G2D@PLCC44
TSC87251G2D@TQFP44 [ (SA245A) ]	
TSC87C51 TSC87C51@PLCC44 [ (SA244) ] [ (SA245A) ]	TSC87C51@TQFP44

## ATMEL-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

AT24C01  
AT24C02  
AT24C04  
AT24C08  
AT24C16

## AUSTIN

### E ( E ) PROM / FRAM / NVRAM

AS8E512K8  
[ ( SA661 ) ]

AS8E512K8@SOJ32

## **BELLING-SYSTRON**

### **MICROCONTROLLER**

CM5001

## **BENCHMARQ**

### **E ( E ) PROM / FRAM / NVRAM**

BQ4010  
BQ4010Y  
BQ4011  
BQ4011Y  
BQ4013  
BQ4013Y  
BQ4014  
BQ4014Y  
BQ4015  
BQ4015Y  
BQ4832Y  
BQ4842Y

## **BMT**

### **E ( E ) PROM / FRAM / NVRAM**

BM29LV160B@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
BM29LV160B@TSOP48 [ ( SA247-B005 ) ]  
BM29LV160T@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
BM29LV160T@TSOP48 [ ( SA247-B005 ) ]

## **BOSEN**

**E (E) PROM/FRAM/NVRAM**

M28W320FST@FBGA47 [ (SA714B-B026A-T048F001Y) ]  
 M28W640FSB@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
 PC28F640P30B@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
 PC28F640P30T@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
 S29GL128PFFIS1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
 S29GL512PFFI02@FBGA64 [ (SA655F-B287A-W064F001Y) ]  
 S29GL512PTFI02@TSOP56 [ (SA628-B257) ]  
 S71WS256NC0BAWA7@FBGA84 [ (SA642A-B139A-Y096F001Y) ]  
 S71WS256NC0BAWAM@FBGA84 [ (SA642A-B139A-Y096F001Y) ]  
 S71WS256NC0BFWA7@FBGA84 [ (SA642A-B139A-Y096F001Y) ]  
 S71WS256NC0BFWAM@FBGA84 [ (SA642A-B139A-Y096F001Y) ]  
 SST39VF800@TSOP48 [ (SA247) ]  
 SST39VF800A@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 SST39VF800A@TSOP48 [ (SA247) ]                      SST39VF800Q@TSOP48  
 [ (SA247) ]

**BRIGHT****E (E) PROM/FRAM/NVRAM**

BM29F040 [ (SA015A1T) ]	BM29F040@PLCC32
BM29F040@TSOP32 [ (SA410T) ]	BM29F400B@PSOP44 [ (SA638- B006) ]
BM29F400B@TSOP48 [ (SA247-B005) ]	BM29F400T@PSOP44 [ (SA638- B006) ]
BM29F400T@TSOP48 [ (SA247-B005) ]	

**CATALYST****E (E) PROM/FRAM/NVRAM**

CAT1021(L) (P)	CAT1021
CAT1021(R)@MSOP8 [ (SA026) ] [ (SA602A) ]	CAT1021(S)@SOIC8
CAT1021(U)@TSSOP8 [ (SA026) ] [ (SA602A) ]	CAT1021(V)@SOIC8

CAT1021(Y)@TSSOP8 [(SA026)] [(SA026)]	CAT1021(Z)@MSOP8
CAT1022(L) (P)	CAT1022
CAT1022(R)@MSOP8 [(SA026)] [(SA602A)]	CAT1022(S)@SOIC8
CAT1022(U)@TSSOP8 [(SA026)] [(SA602A)]	CAT1022(V)@SOIC8
CAT1022(Y)@TSSOP8 [(SA026)] [(SA026)]	CAT1022(Z)@MSOP8
CAT1023(L) (P)	CAT1023
CAT1023(R)@MSOP8 [(SA026)] [(SA602A)]	CAT1023(S)@SOIC8
CAT1023(U)@TSSOP8 [(SA026)] [(SA602A)]	CAT1023(V)@SOIC8
CAT1023(Y)@TSSOP8 [(SA026)] [(SA026)]	CAT1023(Z)@MSOP8
CAT1024(L) (P)	CAT1024
CAT1024(R)@MSOP8 [(SA026)] [(SA602A)]	CAT1024(S)@SOIC8
CAT1024(U)@TSSOP8 [(SA026)] [(SA602A)]	CAT1024(V)@SOIC8
CAT1024(Y)@TSSOP8 [(SA026)] [(SA026)]	CAT1024(Z)@MSOP8
CAT1025(L) (P)	CAT1025
CAT1025(R)@MSOP8 [(SA026)] [(SA602A)]	CAT1025(S)@SOIC8
CAT1025(U)@TSSOP8 [(SA026)] [(SA602A)]	CAT1025(V)@SOIC8
CAT1025(Y)@TSSOP8 [(SA026)] [(SA026)]	CAT1025(Z)@MSOP8
CAT1026(L) (P)	CAT1026
CAT1026(R)@MSOP8 [(SA026)] [(SA602A)]	CAT1026(S)@SOIC8
CAT1026(U)@TSSOP8 [(SA026)] [(SA602A)]	CAT1026(V)@SOIC8
CAT1026(Y)@TSSOP8 [(SA026)] [(SA026)]	CAT1026(Z)@MSOP8
CAT1027(L)	CAT1027

(P)	
CAT1027(R)@MSOP8 [(SA026)]	CAT1027(S)@SOIC8
[(SA602A)]	
CAT1027(U)@TSSOP8 [(SA026)]	CAT1027(V)@SOIC8
[(SA602A)]	
CAT1027(Y)@TSSOP8 [(SA026)]	CAT1027(Z)@MSOP8
[(SA026)]	
CAT1161(J)@SOIC8 [(SA602A)]	CAT1161
(P)	
CAT1162(J)@SOIC8 [(SA602A)]	CAT1162
(P)	
CAT1163(J)@SOIC8 [(SA602A)]	CAT1163
(P)	
CAT2210	CAT2210@SOIC16
[(SA404)]	
CAT2210I	CAT2210I@SOIC16
[(SA404)]	
CAT2212	CAT2212@SOIC20
[(SA404)]	
CAT2212I	CAT2212I@SOIC20
[(SA404)]	
CAT22C10	CAT22C10@SOIC16
[(SA404)]	
CAT22C10I	CAT22C10I@SOIC16
[(SA404)]	
CAT22C12	CAT22C12@SOIC20
[(SA404)]	
CAT22C12I	CAT22C12I@SOIC20
[(SA404)]	
CAT24AC128	CAT24AC128@SOIC8
[(SA602A)]	
CAT24AC128@TSSOP14 [(SA026)]	
CAT24C00	
CAT24C00@SOIC8 [(SA602A)]	CAT24C00@TSSOP8
[(SA026)]	
CAT24C01	CAT24C01@SOIC14
[(SA602)]	
CAT24C01@SOIC8 [(SA602A)]	CAT24C01@TSSOP8
[(SA026)]	
CAT24C01B(J)@SOIC8 [(SA602A)]	CAT24C01B
(L)	
CAT24C01B(P)	CAT24C01B(R)@MSOP8
[(SA026)]	

CAT24C01B(U)@TSSOP8 [(SA026)]	CAT24C01B(W)@SOIC8
[(SA602A)]	
CAT24C01B(Y)@TSSOP8 [(SA026)]	CAT24C01B(Z)@MSOP8
[(SA026)]	
CAT24C02	CAT24C02@SOIC14
[(SA602)]	
CAT24C02@SOIC8 [(SA602A)]	CAT24C02@TSSOP8
[(SA026)]	
CAT24C021	
CAT24C022	
CAT24C023	
CAT24C03	
CAT24C03@SOIC8 [(SA602A)]	CAT24C03@TSSOP8
[(SA026)]	
CAT24C04	CAT24C04@SOIC14
[(SA602)]	
CAT24C04@SOIC8 [(SA602A)]	CAT24C04@TSSOP8
[(SA026)]	
CAT24C041	
CAT24C042	
CAT24C043	
CAT24C05	
CAT24C05@SOIC8 [(SA602A)]	CAT24C05@TSSOP8
[(SA026)]	
CAT24C08	CAT24C08@SOIC14
[(SA602)]	
CAT24C08@SOIC8 [(SA602A)]	CAT24C08@TSSOP8
[(SA026)]	
CAT24C081	
CAT24C082	
CAT24C083	
CAT24C08I	
CAT24C08I@SOIC8 [(SA602A)]	
CAT24C09	
CAT24C09@SOIC8 [(SA602A)]	CAT24C09@TSSOP8
[(SA026)]	
CAT24C128	CAT24C128@SOIC8
[(SA602A)]	
CAT24C16	CAT24C16@SOIC14
[(SA602)]	
CAT24C16@SOIC8 [(SA602A)]	CAT24C16@TSSOP8
[(SA026)]	
CAT24C161	

CAT24C162	
CAT24C163	
CAT24C164	
CAT24C164@SOIC8 [(SA602A)]	CAT24C164@TSSOP8
[(SA026)]	
CAT24C16I	CAT24C16I@SOIC8
[(SA602A)]	
CAT24C208(J)@SOIC8 [(SA602A)]	CAT24C208
(L)	
CAT24C208(P)	CAT24C208(R)@MSOP8
[(SA666)]	
CAT24C208(U)@TSSOP8 [(SA026)]	CAT24C208(W)@SOIC8
[(SA602A)]	
CAT24C208(Y)@TSSOP8 [(SA026)]	CAT24C208(Z)@MSOP8
[(SA666)]	
CAT24C21	CAT24C21@SOIC8
[(SA602A)]	
CAT24C21@TSSOP8 [(SA026)]	
CAT24C256	
CAT24C256@SOIC8 [(SA602A)]	CAT24C256@TDFN8
[(SA683)]	
CAT24C256@TSSOP8 [(SA026)]	
CAT24C32	
CAT24C32@SOIC8 [(SA602A)]	
CAT24C44	
CAT24C44@SOIC8 [(SA602A)]	
CAT24C64	
CAT24C64@SOIC8 [(SA602A)]	
CAT24F32	
CAT24F32@SOIC8 [(SA602A)]	CAT24F32@TSSOP8
[(SA026)]	
CAT24F32A	CAT24F32A@SOIC8
[(SA602A)]	
CAT24F32A@TSSOP8 [(SA026)]	
CAT24FC01	
CAT24FC01@SOIC14 [(SA602)]	CAT24FC01@SOIC8
[(SA602A)]	
CAT24FC01@TSSOP8 [(SA026)]	
CAT24FC02	
CAT24FC02@SOIC14 [(SA602)]	CAT24FC02@SOIC8
[(SA602A)]	
CAT24FC02@TSSOP8 [(SA026)]	
CAT24FC16	

CAT24FC16@SOIC14 [(SA602)]	CAT24FC16@SOIC8
[(SA602A)]	
CAT24FC16@TSSOP8 [(SA026)]	
CAT24FC17	
CAT24FC17@SOIC8 [(SA602A)]	CAT24FC17@TSSOP8
[(SA026)]	
CAT24FC256	CAT24FC256@SOIC8
[(SA602A)]	
CAT24FC256@TDFN8 [(SA683)]	CAT24FC256@TSSOP8
[(SA026)]	
CAT24FC32	CAT24FC32@SOIC8
[(SA602A)]	
CAT24FC32@TDFN8 [(SA683)]	CAT24FC32@TSSOP8
[(SA026)]	
CAT24FC64	CAT24FC64@SOIC8
[(SA602A)]	
CAT24FC64@TDFN8 [(SA683)]	CAT24FC64@TSSOP8
[(SA026)]	
CAT24FC65	CAT24FC65@SOIC8
[(SA602A)]	
CAT24FC65@TDFN8 [(SA683)]	CAT24FC65@TSSOP8
[(SA026)]	
CAT24FC66	CAT24FC66@SOIC8
[(SA602A)]	
CAT24FC66@TDFN8 [(SA683)]	CAT24FC66@TSSOP8
[(SA026)]	
CAT24LC02	CAT24LC02@SOIC8
[(SA602A)]	
CAT24LC02@TSSOP8 [(SA026)]	
CAT24WC01	
CAT24WC01@SOIC8 [(SA602A)]	CAT24WC01@TSSOP8
[(SA026)]	
CAT24WC02	CAT24WC02@SOIC8
[(SA602A)]	
CAT24WC02@TSSOP8 [(SA026)]	
CAT24WC03	
CAT24WC03@SOIC8 [(SA602A)]	CAT24WC03@TSSOP8
[(SA026)]	
CAT24WC04	CAT24WC04@SOIC8
[(SA602A)]	
CAT24WC04@TSSOP8 [(SA026)]	
CAT24WC05	
CAT24WC05@SOIC8 [(SA602A)]	CAT24WC05@TSSOP8



[ ( SA026 ) ]	
CAT24WC08	CAT24WC08@SOIC8
[ ( SA602A ) ]	
CAT24WC08@TSSOP8 [ ( SA026 ) ]	
CAT24WC09	
CAT24WC09@SOIC8 [ ( SA602A ) ]	CAT24WC09@TSSOP8
[ ( SA026 ) ]	
CAT24WC128	CAT24WC128@SOIC8
[ ( SA602A ) ]	
CAT24WC129	CAT24WC129@SOIC8
[ ( SA602A ) ]	
CAT24WC16	CAT24WC16@SOIC8
[ ( SA602A ) ]	
CAT24WC16@TSSOP8 [ ( SA026 ) ]	
CAT24WC164	
CAT24WC164@SOIC8 [ ( SA602A ) ]	CAT24WC164@TSSOP8
[ ( SA026 ) ]	
CAT24WC17	CAT24WC17@SOIC8
[ ( SA602A ) ]	
CAT24WC17@TSSOP8 [ ( SA026 ) ]	
CAT24WC256	
CAT24WC256@SOIC8 [ ( SA602A ) ]	CAT24WC256@TDFN8
[ ( SA683 ) ]	
CAT24WC256@TSSOP8 [ ( SA026 ) ]	
CAT24WC257	
CAT24WC257@SOIC8 [ ( SA605A ) ]	
CAT24WC32	
CAT24WC32@SOIC8 [ ( SA602A ) ]	
CAT24WC33	
CAT24WC33@SOIC8 [ ( SA602A ) ]	
CAT24WC64	
CAT24WC64@SOIC8 [ ( SA602A ) ]	
CAT24WC65	
CAT24WC65@SOIC8 [ ( SA602A ) ]	
CAT24WC66	
CAT24WC66@SOIC8 [ ( SA602A ) ]	
CAT25010	
CAT25010(S)@SOIC8 [ ( SA605A ) ]	CAT25010(U)@TSSOP8
[ ( SA602A ) ]	
CAT25020	CAT25020(S)@SOIC8
[ ( SA605A ) ]	
CAT25020(U)@TSSOP8 [ ( SA602A ) ]	
CAT25040	

CAT25040(S)@SOIC8 [(SA605A)]	CAT25040(U)@TSSOP8
[(SA602A)]	
CAT25080	CAT25080@SOIC8
[(SA602A)]	
CAT25080@TDFN8 [(SA724)]	CAT25080@TSSOP8
[(SA026)]	
CAT25080@UDFN8 [(BBBB)]	
CAT25128	
CAT25128@SOIC8 [(SA602A)]	CAT25128@TDFN8
[(SA724)]	
CAT25128@TSSOP8 [(SA026)]	
CAT25160	
CAT25160@SOIC8 [(SA602A)]	CAT25160@TDFN8
[(SA724)]	
CAT25160@TSSOP8 [(SA026)]	CAT25160@UDFN8
[(BBBB)]	
CAT25256	CAT25256@SOIC8
[(SA602A)]	
CAT25256@TDFN8 [(SA602A)]	CAT25256@TSSOP8
[(SA026)]	
CAT25320	CAT25320@SOIC8
[(SA602A)]	
CAT25320@TDFN8 [(SA724)]	CAT25320@TSSOP8
[(SA026)]	
CAT25640	CAT25640@SOIC8
[(SA602A)]	
CAT25640@TDFN8 [(SA724)]	CAT25640@TSSOP8
[(SA026)]	
CAT25C01	CAT25C01@SOIC16
[(SA602)]	
CAT25C01@SOIC8 [(SA602A)]	CAT25C01@TSSOP14
[(SA026)]	
CAT25C01@TSSOP8 [(SA026)]	
CAT25C02	
CAT25C02@SOIC16 [(SA602)]	CAT25C02@SOIC8
[(SA602A)]	
CAT25C02@TSSOP14 [(SA026)]	CAT25C02@TSSOP8
[(SA026)]	
CAT25C03	CAT25C03@SOIC8
[(SA602A)]	
CAT25C03@TSSOP14 [(SA026)]	CAT25C03@TSSOP8
[(SA026)]	
CAT25C04	CAT25C04@SOIC16

[ (SA602) ]	
CAT25C04@SOIC8 [ (SA602A) ]	CAT25C04@TSSOP14
[ (SA026) ]	
CAT25C04@TSSOP8 [ (SA026) ]	
CAT25C05	
CAT25C05@SOIC8 [ (SA602A) ]	CAT25C05@TSSOP14
[ (SA026) ]	
CAT25C05@TSSOP8 [ (SA026) ]	
CAT25C08	
CAT25C08@SOIC16 [ (SA602) ]	CAT25C08@SOIC8
[ (SA602A) ]	
CAT25C08@TSSOP14 [ (SA026) ]	CAT25C08@TSSOP8
[ (SA026) ]	
CAT25C09	CAT25C09@SOIC8
[ (SA602A) ]	
CAT25C09@TSSOP14 [ (SA026) ]	CAT25C09@TSSOP8
[ (SA026) ]	
CAT25C11	CAT25C11@SOIC8
[ (SA602A) ]	
CAT25C11@TSSOP14 [ (SA026) ]	CAT25C11@TSSOP8
[ (SA026) ]	
CAT25C128	CAT25C128@SOIC16
[ (SA602) ]	
CAT25C128@SOIC8 [ (SA602A) ]	CAT25C128@TSSOP14
[ (SA026) ]	
CAT25C128@TSSOP20 [ (SA026) ]	
CAT25C16	
CAT25C16@SOIC16 [ (SA602) ]	CAT25C16@SOIC8
[ (SA602A) ]	
CAT25C16@TSSOP14 [ (SA026) ]	CAT25C16@TSSOP8
[ (SA026) ]	
CAT25C17	CAT25C17@SOIC8
[ (SA602A) ]	
CAT25C17@TSSOP14 [ (SA026) ]	CAT25C17@TSSOP8
[ (SA026) ]	
CAT25C256	CAT25C256@SOIC16
[ (SA602) ]	
CAT25C256@SOIC8 [ (SA602A) ]	CAT25C256@TSSOP14
[ (SA026) ]	
CAT25C256@TSSOP20 [ (SA026) ]	
CAT25C32	
CAT25C32@SOIC8 [ (SA602A) ]	CAT25C32@TSSOP14
[ (SA026) ]	

CAT25C32@TSSOP20 [(SA026)]	
CAT25C33	
CAT25C33@SOIC8 [(SA602A)]	CAT25C33@TSSOP14
[(SA026)]	
CAT25C64	CAT25C64@SOIC8
[(SA602A)]	
CAT25C64@TSSOP14 [(SA026)]	CAT25C64@TSSOP20
[(SA026)]	
CAT25C65	CAT25C65@SOIC8
[(SA602A)]	
CAT25C65@TSSOP14 [(SA026)]	
CAT27010	
CAT27010@PLCC32 [(SA015A1T)]	CAT27010@TSOP32
[(SA410T)]	
CAT27128A	
CAT27256	
CAT27512	CAT27512@PLCC32
[(SA015A1T)]	
CAT2764A	
CAT27C16A	
CAT27C210	CAT27C210@PLCC44
[(SA244)]	
CAT27HC256	CAT27HC256@PLCC32
[(SA015A1T)]	
CAT27HC256I	CAT27HC256I@PLCC32
[(SA015A1T)]	
CAT28C16A	CAT28C16A@PLCC32
[(SA015A1T)]	
CAT28C16AI	CAT28C16AI@PLCC32
[(SA015A1T)]	
CAT28C17A	CAT28C17A@PLCC32
[(SA015A1T)]	
CAT28C17AI	CAT28C17AI@PLCC32
[(SA015A1T)]	
CAT28C256	CAT28C256@PLCC32
[(SA015A1T)]	
CAT28C256@TSOP28 [(SA430T)]	
CAT28C256I	
CAT28C256I@PLCC32 [(SA015A1T)]	CAT28C256I@TSOP28
[(SA430T)]	
CAT28C257	CAT28C257@PLCC32
[(SA015A1T)]	
CAT28C257@TSOP28 [(SA430T)]	

CAT28C512	
CAT28C512@PLCC32 [(SA015A1T)]	CAT28C512@TSOP32
[(SA410T)]	
CAT28C512@TSOP40 [(SA409T)]	CAT28C513@PLCC32
[(SA015A1T)]	
CAT28C64A	CAT28C64A@PLCC32
[(SA015A1T)]	
CAT28C64A@SOIC28 [(SA404)]	
CAT28C64AI	
CAT28C64AI@PLCC32 [(SA015A1T)]	CAT28C64AI@SOIC28
[(SA404)]	
CAT28C64B	CAT28C64B@PLCC32
[(SA015A1T)]	
CAT28C64B@TSOP28 [(SA430T)]	
CAT28C64BI	
CAT28C64BI@PLCC32 [(SA015A1T)]	CAT28C64BI@TSOP28
[(SA430T)]	
CAT28C65B	CAT28C65B@PLCC32
[(SA015A1T)]	
CAT28C65B@TSOP28 [(SA430T)]	
CAT28C65BI	
CAT28C65BI@PLCC32 [(SA015A1T)]	CAT28C65BI@TSOP28
[(SA430T)]	
CAT28F001N-B@PLCC32 [(SA015A1T)]	CAT28F001N-T@PLCC32
[(SA015A1T)]	
CAT28F001P-B	CAT28F001P-
T	
CAT28F001T-B@TSOP32 [(SA410T)]	CAT28F001T-T@TSOP32
[(SA410T)]	
CAT28F002	CAT28F002@TSOP40
[(SA409T)]	
CAT28F010	CAT28F010@PLCC32
[(SA015A1T)]	
CAT28F010@TSOP32 [(SA410T)]	
CAT28F010I	
CAT28F010I@PLCC32 [(SA015A1T)]	CAT28F010I@TSOP32
[(SA410T)]	
CAT28F020	CAT28F020@PLCC32
[(SA015A1T)]	
CAT28F020@TSOP32 [(SA410T)]	
CAT28F020I	
CAT28F020I@PLCC32 [(SA015A1T)]	CAT28F020I@TSOP32
[(SA410T)]	

CAT28F102	CAT28F102@PLCC44
[ (SA244) ]	
CAT28F102@TSOP40 [ (SA409T) ]	
CAT28F512	
CAT28F512@PLCC32 [ (SA015A1T) ]	CAT28F512@TSOP32
[ (SA410T) ]	
CAT28F512I	CAT28F512I@PLCC32
[ (SA015A1T) ]	
CAT28F512I@TSOP32 [ (SA410T) ]	
CAT28LV256	
CAT28LV256@PLCC32 [ (SA015A1T) ]	CAT28LV256@TSOP28
[ (SA430T) ]	
CAT28LV64	CAT28LV64@PLCC32
[ (SA015A1T) ]	
CAT28LV64@TSOP28 [ (SA430T) ]	
CAT28LV65	
CAT28LV65@PLCC32 [ (SA015A1T) ]	CAT28LV65@TSOP28
[ (SA430T) ]	
CAT33C101(08bit)	
CAT33C101(08bit)@SOIC8 [ (SA602A) ]	
CAT33C101(16bit)	
CAT33C101(16bit)@SOIC8 [ (SA602A) ]	
CAT33C101H(08bit)	
CAT33C101H(08bit)@SOIC8 [ (SA602A) ]	
CAT33C101H(16bit)	
CAT33C101H(16bit)@SOIC8 [ (SA602A) ]	
CAT33C101I(08bit)	
CAT33C101I(08bit)@SOIC8 [ (SA602A) ]	
CAT33C101I(16bit)	
CAT33C101I(16bit)@SOIC8 [ (SA602A) ]	
CAT33C104(08bit)	
CAT33C104(08bit)@SOIC8 [ (SA602A) ]	
CAT33C104(16bit)	
CAT33C104(16bit)@SOIC8 [ (SA602A) ]	
CAT33C104I(08bit)	
CAT33C104I(08bit)@SOIC8 [ (SA602A) ]	
CAT33C104I(16bit)	
CAT33C104I(16bit)@SOIC8 [ (SA602A) ]	
CAT34AC02	CAT34AC02@SOIC8
[ (SA602A) ]	
CAT34AC02@TSSOP8 [ (SA026) ]	
CAT34C02	
CAT34C02@SOIC8 [ (SA602A) ]	CAT34C02@TDFN8

[ (SA694) ]	
CAT34C02@TSSOP8 [ (SA026) ]	
CAT34FC02	
CAT34FC02@SOIC8 [ (SA602A) ]	CAT34FC02@TDFN8
[ (SA694) ]	
CAT34FC02@TSSOP8 [ (SA026) ]	
CAT34RC02	
CAT34RC02@SOIC8 [ (SA602A) ]	CAT34RC02@TDFN8
[ (SA694) ]	
CAT34RC02@TSSOP8 [ (SA026) ]	
CAT34WC02	
CAT34WC02@SOIC8 [ (SA602A) ]	CAT34WC02@TDFN8
[ (SA694) ]	
CAT34WC02@TSSOP8 [ (SA026) ]	
CAT35C102	
CAT35C102H	
CAT35C102I	
CAT35C104(08bit)	
CAT35C104(08bit)@SOIC8 [ (SA602A) ]	
CAT35C104(16bit)	
CAT35C104(16bit)@SOIC8 [ (SA602A) ]	
CAT35C104H(08bit)	
CAT35C104H(08bit)@SOIC8 [ (SA602A) ]	
CAT35C104I(08bit)	
CAT35C104I(08bit)@SOIC8 [ (SA602A) ]	
CAT35C104I(16bit)	
CAT35C104I(16bit)@SOIC8 [ (SA602A) ]	
CAT59C11	CAT59C11@SOIC8
[ (SA602A) ]	
CAT59C11A	CAT59C11A@SOIC8
[ (SA602A) ]	
CAT59C11H	CAT59C11H@SOIC8
[ (SA602A) ]	
CAT59C11I	CAT59C11I@SOIC8
[ (SA602A) ]	
CAT64LC10(J)@SOIC8 [ (SA602A) ]	CAT64LC10
(P)	
CAT64LC10(S)@SOIC8 [ (SA602A) ]	CAT64LC10(U)@TSSOP8
[ (SA026) ]	
CAT64LC10(UR)@TSSOP8 [ (SA026) ]	CAT64LC20(J)@SOIC8
[ (SA602A) ]	
CAT64LC20(P)	CAT64LC20(S)@SOIC8
[ (SA602A) ]	

CAT64LC20(U)@TSSOP8 [(SA026)]	CAT64LC20(UR)@TSSOP8
[(SA026)]	
CAT64LC40(J)@SOIC8 [(SA602A)]	CAT64LC40
(P)	
CAT64LC40(S)@SOIC8 [(SA602A)]	CAT64LC40(U)@TSSOP8
[(SA026)]	
CAT64LC40(UR)@TSSOP8 [(SA026)]	CAT93C46
(08bit)	
CAT93C46(08bit)(J)@SOIC8 [(SA602A)]	
CAT93C46(08bit)(K)@SOIC8 [(SA605A)]	
CAT93C46(08bit)(S)@SOIC8 [(SA602A)]	
CAT93C46(08bit)(U)@TSSOP8 [(SA026)]	
CAT93C46(16bit)	
CAT93C46(16bit)(J)@SOIC8 [(SA602A)]	
CAT93C46(16bit)(K)@SOIC8 [(SA605A)]	
CAT93C46(16bit)(S)@SOIC8 [(SA602A)]	
CAT93C46(16bit)(U)@TSSOP8 [(SA026)]	
CAT93C46A	CAT93C56
(08bit)	
CAT93C56(08bit)@SOIC8 [(SA602A)]	CAT93C56
(16bit)	
CAT93C56(16bit)@SOIC8 [(SA602A)]	
CAT93C56A	
CAT93C57	CAT93C66
(08bit)	
CAT93C66(08bit)@SOIC8 [(SA602A)]	CAT93C66(08bit)@TSSOP8
[(SA026)]	
CAT93C66(16bit)	CAT93C66(16bit)@SOIC8
[(SA602A)]	
CAT93C66(16bit)@TSSOP8 [(SA026)]	
CAT93C66A	
CAT93C76(08bit)	
CAT93C76(08bit)(J)@SOIC8 [(SA602A)]	
CAT93C76(08bit)(K)@SOIC8 [(SA605A)]	
CAT93C76(08bit)(S)@SOIC8 [(SA602A)]	
CAT93C76(08bit)(U)@TSSOP8 [(SA026)]	
CAT93C76(16bit)	
CAT93C76(16bit)(J)@SOIC8 [(SA602A)]	
CAT93C76(16bit)(K)@SOIC8 [(SA605A)]	
CAT93C76(16bit)(S)@SOIC8 [(SA602A)]	
CAT93C76(16bit)(U)@TSSOP8 [(SA026)]	
CAT93C86(08bit)	
CAT93C86(08bit)(J)@SOIC8 [(SA602A)]	



CAT93C86(08bit)(K)@SOIC8 [(SA605A)]  
CAT93C86(08bit)(S)@SOIC8 [(SA602A)]  
CAT93C86(08bit)(U)@TSSOP8 [(SA026)]  
CAT93C86(16bit)  
CAT93C86(16bit)(J)@SOIC8 [(SA602A)]  
CAT93C86(16bit)(K)@SOIC8 [(SA605A)]  
CAT93C86(16bit)(S)@SOIC8 [(SA602A)]  
CAT93C86(16bit)(U)@TSSOP8 [(SA026)]  
CAT93H46(08bit)  
CAT93H46(08bit)(J)@SOIC8 [(SA602A)]  
CAT93H46(08bit)(K)@SOIC8 [(SA605A)]  
CAT93H46(08bit)(S)@SOIC8 [(SA602A)]  
CAT93H46(08bit)(U)@TSSOP8 [(SA026)]  
CAT93H46(16bit)  
CAT93H46(16bit)(J)@SOIC8 [(SA602A)]  
CAT93H46(16bit)(K)@SOIC8 [(SA605A)]  
CAT93H46(16bit)(S)@SOIC8 [(SA602A)]  
CAT93H46(16bit)(U)@TSSOP8 [(SA026)]  
CAT93HC46(08bit)  
CAT93HC46(08bit)(J)@SOIC8 [(SA602A)]  
CAT93HC46(08bit)(K)@SOIC8 [(SA605A)]  
CAT93HC46(08bit)(S)@SOIC8 [(SA602A)]  
CAT93HC46(08bit)(U)@TSSOP8 [(SA026)]  
CAT93HC46(16bit)  
CAT93HC46(16bit)(J)@SOIC8 [(SA602A)]  
CAT93HC46(16bit)(K)@SOIC8 [(SA605A)]  
CAT93HC46(16bit)(S)@SOIC8 [(SA602A)]  
CAT93HC46(16bit)(U)@TSSOP8 [(SA026)]

## DRAM & SRAM

CAT71C256	CAT71C256@TSOP28
[(SA643)]	
CAT71C256L	CAT71C256L@TSOP28
[(SA643)]	

## CERAMATE

### E(E) PROM/FRAM/NVRAM

24LC02	24LC02@SOIC8
--------	--------------

[ (SA602A) ]	
24LC02@TSSOP8 [ (SA026) ]	
24LC08	
24LC08@SOIC8 [ (SA602A) ]	24LC08@TSSOP8
[ (SA026) ]	
24LC16	24LC16@SOIC8
[ (SA602A) ]	
24LC16@TSSOP8 [ (SA026) ]	
24LLC02	
24LLC02@SOIC8 [ (SA602A) ]	24LLC02@TSSOP8
[ (SA026) ]	
24LLC08	24LLC08@SOIC8
[ (SA602A) ]	
24LLC08@TSSOP8 [ (SA026) ]	
93LC46	
93LC46@SOIC8 [ (SA602A) ]	
93LC46R	
93LC46R@SOIC8 [ (SA602A) ]	
93LC56	
93LC56@SOIC8 [ (SA602A) ]	
93LC66	
93LC66@SOIC8 [ (SA602A) ]	

## CHINA CORE

### MICROCONTROLLER

CCM89C51	CCM89C51@PLCC44
[ (SA244) ]	
CCM89C51@TQFP44 [ (SA245A) ]	
CCM89C52	
CCM89C52@PLCC44 [ (SA244) ]	CCM89C52@TQFP44
[ (SA245A) ]	

## CHINGIS

### E ( E ) PROM / FRAM / NVRAM

PM24C64	PM24C64@SOIC8
[ (SA602A) ]	

PM24C64@TSOP8 [(SA026)]	PM25LV010(B)@SOIC8
[(SA023A)]	
PM25LV010(Q)@WSON8 [(SA683)]	PM25LV010(S)@SOIC8
[(SA602A)]	
PM25LV010A@SOIC8 [(SA602A)]	PM25LV010A@WSON8
[(SA683)]	
PM25LV016@SOIC8 [(SA605A)]	PM25LV016@WSON8
[(SA683)]	
PM25LV016A@SOIC8 [(SA605A)]	PM25LV016A@WSON8
[(SA683)]	
PM25LV020(B)@SOIC8 [(SA023A)]	PM25LV020(Q)@WSON8
[(SA683)]	
PM25LV020(S)@SOIC8 [(SA602A)]	PM25LV040(B)@SOIC8
[(SA023A)]	
PM25LV040(Q)@WSON8 [(SA683)]	PM25LV040(S)@SOIC8
[(SA602A)]	
PM25LV080@SOIC8 [(SA605A)]	PM25LV080@WSON8
[(SA683)]	
PM25LV080A@SOIC8 [(SA605A)]	PM25LV080A@WSON8
[(SA683)]	
PM25LV512(B)@SOIC8 [(SA023A)]	PM25LV512(Q)@WSON8
[(SA683)]	
PM25LV512(S)@SOIC8 [(SA602A)]	
PM29F002B	
PM29F002B@PLCC32 [(SA015A1T)]	
PM29F002T	
PM29F002T@PLCC32 [(SA015A1T)]	
PM29F004B	
PM29F004B@PLCC32 [(SA015A1T)]	
PM29F004T	
PM29F004T@PLCC32 [(SA015A1T)]	
PM29LV002B	
PM29LV002B@PLCC32 [(SA015A1T)]	PM29LV002B@VSOP32
[(SA620)]	
PM29LV002T	PM29LV002T@PLCC32
[(SA015A1T)]	
PM29LV002T@VSOP32 [(SA620)]	PM29LV004B@PLCC32
[(SA015A1T)]	
PM29LV004B@VSOP32 [(SA620)]	PM29LV004T@PLCC32
[(SA015A1T)]	
PM29LV004T@VSOP32 [(SA620)]	PM29LV104RB@PLCC32
[(SA015A1T)]	
PM29LV104RB@VSOP32 [(SA620)]	PM29LV104RT@PLCC32

[ (SA015A1T) ]	
PM29LV104RT@VSOP32 [ (SA620) ]	
PM37LV512	
PM37LV512@PLCC32 [ (SA015A1T) ]	PM37LV512@VSOP32
[ (SA620) ]	
PM39F010	
[ (SA015A1T) ]	
PM39F010@VSOP32 [ (SA620) ]	PM39F010@PLCC32
PM39F020	
PM39F020@PLCC32 [ (SA015A1T) ]	PM39F020@VSOP32
[ (SA620) ]	
PM39F040	
[ (SA015A1T) ]	
PM39F040@VSOP32 [ (SA620) ]	PM39LV010@PLCC32
[ (SA015A1T) ]	
PM39LV010@VSOP32 [ (SA620) ]	PM39LV010R@PLCC32
[ (SA015A1T) ]	
PM39LV010R@VSOP32 [ (SA620) ]	PM39LV020@PLCC32
[ (SA015A1T) ]	
PM39LV020@VSOP32 [ (SA620) ]	PM39LV040@PLCC32
[ (SA015A1T) ]	
PM39LV040@VSOP32 [ (SA620) ]	PM39LV512@PLCC32
[ (SA015A1T) ]	
PM39LV512@VSOP32 [ (SA620) ]	PM39LV512R@PLCC32
[ (SA015A1T) ]	
PM39LV512R@VSOP32 [ (SA620) ]	PM49FL002T@PLCC32
[ (SA015A1T) ]	
PM49FL002T@VSOP32 [ (SA620) ]	
PM49FL004T(Low)@PLCC32 [ (SA015A1T-B001) ]	
PM49FL004T(Low)@VSOP32 [ (SA620-B005) ]	
PM49FL004T@PLCC32 [ (SA015A1T) ]	PM49FL004T@VSOP32
[ (SA620) ]	
PM49FL008T@PLCC32 [ (SA015A1T) ]	PM49FL008T@VSOP32
[ (SA620) ]	
PM49LP002T@PLCC32 [ (SA015A1T) ]	PM49LP002T@VSOP32
[ (SA620) ]	

## CHIPCON

### MICROCONTROLLER

CC1010@TQFP64 [ (PEP+S616) ]

CC1010@TQFP64 (ISP) [ ISP-HEADER01 ]

## CHIPSWINNER

### E ( E ) PROM / FRAM / NVRAM

CW24C02 [ ( SA602A ) ]	CW24C02@SOIC8
CW24C04 [ ( SA602A ) ]	CW24C04@SOIC8
CW24C08 [ ( SA602A ) ]	CW24C08@SOIC8
CW24C16 [ ( SA602A ) ]	CW24C16@SOIC8
CW24C32 [ ( SA602A ) ]	CW24C32@SOIC8
CW24C64 [ ( SA602A ) ]	CW24C64@SOIC8

### MICROCONTROLLER

CW88CS028@SDIP28 [ ( SA653 ) ] [ ( SA653 ) ]	CW88CS032@SDIP32
CW88CS128@SDIP28 [ ( SA653 ) ] [ ( SA653 ) ]	CW88CS132@SDIP32
CW89F1050	
CW89F2050	
CW89F4050@SDIP28 [ ( SA653 ) ] [ ( SA404 ) ]	CW89F4050@SOP28
CW89F52 [ ( SA675 ) ]	CW89F52@LQFP44
CW89F54 [ ( SA675 ) ]	CW89F54@LQFP44

## CORERIVER

### E ( E ) PROM / FRAM / NVRAM

CR24C02LI	CR24C02WI@SOIC8
-----------	-----------------

[ ( SA602 ) ]

CR24C08LI

CR24C08WI@SOIC8

[ ( SA602 ) ]

CR24C16LI

CR24C16WI@SOIC8

[ ( SA602 ) ]

CR24C256LI

CR24C256WI@SOIC8

[ ( SA602 ) ]

CR24C32LI

CR24C32WI@SOIC8

[ ( SA602 ) ]

CR24C64LI

CR24C64WI@SOIC8

[ ( SA602 ) ]

## MICROCONTROLLER

GC87C520A0

GC87C520A0@MQFP44

[ ( SA675 ) ]

GC87C520A0@PLCC44 [ ( SA244 ) ]

## CWI

### E ( E ) PROM / FRAM / NVRAM

39LV040@VSOP32 [ ( SA620 ) ]

## CYGNAL

### MICROCONTROLLER

C8051F000@TQFP64 [ ( PEP+S616 ) ]

C8051F001@TQFP48

[ ( SA248 ) ]

C8051F002@TQFP32 [ ( SA663 ) ]

C8051F005@TQFP64 [ ( PEP

+S616 ) ]

C8051F006@TQFP48 [ ( SA248 ) ]

C8051F007@TQFP32

[ ( SA663 ) ]

C8051F010@TQFP64 [ ( PEP+S616 ) ]

C8051F011@TQFP48

[ ( SA248 ) ]

C8051F012@TQFP32 [ ( SA663 ) ]

C8051F015@TQFP64 [ ( PEP

+S616 ) ]

C8051F016@TQFP48 [ ( SA248 ) ]

C8051F017@TQFP32

[ (SA663) ]  
C8051F018@TQFP64 [ (PEP+S616) ] C8051F019@TQFP48  
[ (SA248) ]  
C8051F020@TQFP100 [ (PEP+S604) ]  
C8051F020@TQFP100 (ISP) [ ISP-HEADER01 ]  
C8051F021@TQFP64 [ (PEP+S616) ]  
C8051F021@TQFP64 (\*) [ (TA050-B005) ]  
C8051F021@TQFP64 (ISP) [ ISP-HEADER01 ]  
C8051F022@TQFP100 [ (PEP+S604) ]  
C8051F022@TQFP100 (ISP) [ ISP-HEADER01 ]  
C8051F023@TQFP64 [ (PEP+S616) ]  
C8051F023@TQFP64 (\*) [ (TA050-B005) ]  
C8051F023@TQFP64 (ISP) [ ISP-HEADER01 ]  
C8051F040@TQFP100 [ (PEP+S604) ]  
C8051F040@TQFP100 (ISP) [ ISP-HEADER01 ]  
C8051F041@TQFP64 [ (PEP+S616) ]  
C8051F041@TQFP64 (\*) [ (TA050-B005) ]  
C8051F041@TQFP64 (ISP) [ ISP-HEADER01 ]  
C8051F042@TQFP100 [ (PEP+S604) ]  
C8051F042@TQFP100 (ISP) [ ISP-HEADER01 ]  
C8051F043@TQFP64 [ (PEP+S616) ]  
C8051F043@TQFP64 (\*) [ (TA050-B005) ]  
C8051F043@TQFP64 (ISP) [ ISP-HEADER01 ]  
C8051F044@TQFP100 [ (PEP+S604) ]  
C8051F044@TQFP100 (ISP) [ ISP-HEADER01 ]  
C8051F045@TQFP64 [ (PEP+S616) ]  
C8051F045@TQFP64 (\*) [ (TA050-B005) ]  
C8051F045@TQFP64 (ISP) [ ISP-HEADER01 ]  
C8051F046@TQFP100 [ (PEP+S604) ]  
C8051F046@TQFP100 (ISP) [ ISP-HEADER01 ]  
C8051F047@TQFP64 [ (PEP+S616) ]  
C8051F047@TQFP64 (\*) [ (TA050-B005) ]  
C8051F047@TQFP64 (ISP) [ ISP-HEADER01 ]  
C8051F060@TQFP100 [ (PEP+S604) ] C8051F061@TQFP64 [ (PEP  
+S616) ]  
C8051F062@TQFP100 [ (PEP+S604) ] C8051F063@TQFP64 [ (PEP  
+S616) ]  
C8051F064@TQFP100 [ (PEP+S604) ] C8051F065@TQFP64 [ (PEP  
+S616) ]  
C8051F066@TQFP100 [ (PEP+S604) ] C8051F067@TQFP64 [ (PEP  
+S616) ]  
C8051F120@TQFP100 [ (PEP+S604) ]  
C8051F120-GQ@TQFP100 [ (PEP+S604) ]

C8051F121@TQFP64 [(PEP+S616)]	C8051F121-GQ@TQFP64 [(PEP+S616)]
C8051F122@TQFP100 [(PEP+S604)]	
C8051F122-GQ@TQFP100 [(PEP+S604)]	
C8051F123@TQFP64 [(PEP+S616)]	C8051F123-GQ@TQFP64 [(PEP+S616)]
C8051F124@TQFP100 [(PEP+S604)]	
C8051F124-GQ@TQFP100 [(PEP+S604)]	
C8051F125@TQFP64 [(PEP+S616)]	C8051F125-GQ@TQFP64 [(PEP+S616)]
C8051F126@TQFP100 [(PEP+S604)]	
C8051F126-GQ@TQFP100 [(PEP+S604)]	
C8051F127@TQFP64 [(PEP+S616)]	C8051F127-GQ@TQFP64 [(PEP+S616)]
C8051F130@TQFP100 [(PEP+S604)]	
C8051F130-GQ@TQFP100 [(PEP+S604)]	
C8051F131@TQFP64 [(PEP+S616)]	C8051F131-GQ@TQFP64 [(PEP+S616)]
C8051F132@TQFP100 [(PEP+S604)]	
C8051F132-GQ@TQFP100 [(PEP+S604)]	
C8051F133@TQFP64 [(PEP+S616)]	C8051F133-GQ@TQFP64 [(PEP+S616)]
C8051F206@TQFP48 [(SA248)]	C8051F220@TQFP48
[(SA248)]	
C8051F221@TQFP32 [(SA663)]	C8051F226@TQFP48
[(SA248)]	
C8051F230@TQFP48 [(SA248)]	C8051F231@TQFP32
[(SA663)]	
C8051F236@TQFP48 [(SA248)]	C8051F300
[(SA695A)]	
C8051F301 [(SA695A)]	C8051F302
[(SA695A)]	
C8051F303 [(SA695A)]	C8051F304
[(SA695A)]	
C8051F305 [(SA695A)]	C8051F310@TQFP32
[(SA663)]	
C8051F310-GQ@TQFP32 [(SA663)]	C8051F311@QFN28 [(SA697-B006)]
B006)]	
C8051F311-GM@QFN28 [(SA697-B006)]	
C8051F312@TQFP32 [(SA663)]	C8051F312-GQ@TQFP32
[(SA663)]	
C8051F313@QFN28 [(SA697-B006)]	
C8051F313-GM@QFN28 [(SA697-B006)]	



C8051F314@TQFP32 [(SA663)]	C8051F314-GQ@TQFP32
[(SA663)]	
C8051F315@QFN28 [(SA697-B006)]	
C8051F315-GM@QFN28 [(SA697-B006)]	
C8051F316-GM@QFN24 [(SA710-B006)]	
C8051F317-GM@QFN24 [(SA710-B006)]	
C8051F320@TQFP32 [(SA663)]	C8051F321@QFN28 [(SA697-
B006)]	
C8051F326@QFN28 [(SA697-B006)]	
C8051F326-GQ@QFN28 [(SA697-B006)]	
C8051F327@QFN28 [(SA697-B006)]	
C8051F327-GQ@QFN28 [(SA697-B006)]	
C8051F330@MLP20 [(SA692)]	
C8051F330D	
C8051F331@MLP20 [(SA692)]	C8051F332-GM@MLP20
[(SA692)]	
C8051F333-GM@MLP20 [(SA692)]	C8051F334-GM@MLP20
[(SA692)]	
C8051F335-GM@MLP20 [(SA692)]	C8051F336-GM@QFN20
[(SA692)]	
C8051F337-GM@QFN20 [(SA692)]	C8051F338-GM@QFN24
[(SA710)]	
C8051F339-GM@QFN24 [(SA710)]	C8051F340-GQ@TQFP48
[(SA248)]	
C8051F341-GQ@TQFP48 [(SA248)]	C8051F342-GQ@LQFP32
[(SA663)]	
C8051F343-GQ@LQFP32 [(SA663)]	C8051F344-GQ@TQFP48
[(SA248)]	
C8051F345-GQ@TQFP48 [(SA248)]	C8051F346-GQ@LQFP32
[(SA663)]	
C8051F347-GQ@LQFP32 [(SA663)]	C8051F350-GQ@LQFP32
[(SA663)]	
C8051F351-GM@QFN28 [(SA697-B006)]	
C8051F352-GQ@LQFP32 [(SA663)]	
C8051F353-GM@QFN28 [(SA697-B006)]	
C8051F360@QFP48 [(SA248)]	C8051F361@QFP32
[(SA663)]	
C8051F362@QFN28 [(SA697)]	C8051F363@QFP48
[(SA248)]	
C8051F364@QFP32 [(SA663)]	C8051F365@QFN28
[(SA697)]	
C8051F366@QFP32 [(SA663)]	C8051F367@QFN28
[(SA697)]	

C8051F368@QFP32 [(SA663)]	C8051F369@QFN28
[(SA697)]	
C8051F410-GQ@LQFP32 [ordering number is marked above]	
C8051F411-GM@QFN28 [ordering number is marked above]	
C8051F412-GQ@LQFP32 [ordering number is marked above]	
C8051F413-GM@QFN28 [ordering number is marked above]	
C8051F520-IM@QFN10 [(SA695A)]	C8051F521-IM@QFN10
[(SA695A)]	
C8051F523-IM@QFN10 [(SA695A)]	C8051F524-IM@QFN10
[(SA695A)]	
C8051F526-IM@QFN10 [(SA695A)]	C8051F527-IM@QFN10
[(SA695A)]	
C8051F530-IM@QFN20 [(SA692)]	C8051F530-IT@TSSOP20
[(SA026)]	
C8051F531-IM@QFN20 [(SA692)]	C8051F531-IT@TSSOP20
[(SA026)]	
C8051F533-IM@QFN20 [(SA692)]	C8051F533-IT@TSSOP20
[(SA026)]	
C8051F534-IM@QFN20 [(SA692)]	C8051F534-IT@TSSOP20
[(SA026)]	
C8051F536-IM@QFN20 [(SA692)]	C8051F536-IT@TSSOP20
[(SA026)]	
C8051F537-IM@QFN20 [(SA692)]	C8051F537-IT@TSSOP20
[(SA026)]	
SI8250@LQFP32 [(SA663)]	SI8250@QFN28
[(SA697)]	
SI8251@LQFP32 [(SA663)]	SI8251@QFN28
[(SA697)]	
SI8252@LQFP32 [(SA663)]	SI8252@QFN28
[(SA697)]	

## CYPRESS

### E(E) PROM/FRAM/NVRAM

CY14B256L@SOIC32 [(SA715)]	
CY27C010	
CY27C010@PLCC32 [(SA015A1T)]	CY27C010@TSOP32
[(SA410T)]	
CY27C020	CY27C020@PLCC32
[(SA015A1T)]	
CY27C020@TSOP32 [(SA410T)]	

CY27C040  
CY27C040@PLCC32 [ (SA015A1T) ]  
[ (SA410T) ]  
CY27C128  
[ (SA015A1T) ]  
CY27C256  
[ (SA015A1T) ]  
CY27C256@TSOP28 [ (SA430T) ]  
CY27C512  
CY27C512@PLCC32 [ (SA015A1T) ]  
[ (SA430T) ]  
CY27H010  
[ (SA015A1T) ]  
CY27H010@TSOP32 [ (SA410T) ]  
CY27H256  
CY27H256@PLCC32 [ (SA015A1T) ]  
[ (SA430T) ]  
CY27H512  
[ (SA015A1T) ]  
CY27H512@TSOP28 [ (SA430T) ]  
CY7C225A  
CY7C225A@PLCC28 [ (SA008A) ]  
CY7C243  
CY7C243@PLCC28 [ (SA008A) ]  
CY7C244  
CY7C244@PLCC28 [ (SA008A) ]  
CY7C245  
CY7C245@PLCC28 [ (SA008A) ]  
CY7C245A  
CY7C245A@PLCC28 [ (SA008A) ]  
CY7C251  
CY7C251@PLCC32 [ (SA015A1T) ]  
CY7C254  
CY7C254@PLCC32 [ (SA015A1T) ]  
CY7C256  
CY7C256@PLCC32 [ (SA015A1T) ]  
CY7C261  
CY7C261@PLCC28 [ (SA008A) ]  
CY7C263  
CY7C263@PLCC28 [ (SA008A) ]  
CY7C264  
CY7C264@PLCC28 [ (SA008A) ]  
CY7C265

CY27C040@TSOP32

CY27C128@PLCC32

CY27C256@PLCC32

CY27C512@TSOP28

CY27H010@PLCC32

CY27H256@TSOP28

CY27H512@PLCC32

CY7C265@PLCC28 [(SA008A)]  
CY7C266  
CY7C266@PLCC32 [(SA015A1T)]  
CY7C268  
CY7C268@PLCC32 [(SA015A1T)]  
CY7C271  
CY7C271@PLCC32 [(SA015A1T)]  
CY7C271A  
CY7C271A@PLCC32 [(SA015A1T)]  
CY7C274  
CY7C274@PLCC32 [(SA015A1T)]  
[(SA244)]  
CY7C276(25JC)@PLCC44 [(SA244)]  
[(SA244)]  
CY7C281  
[(SA008A)]  
CY7C281A  
[(SA008A)]  
CY7C282  
[(SA008A)]  
CY7C282A  
[(SA008A)]  
CY7C285  
[(SA015A1T)]  
CY7C286  
[(SA015A1T)]  
CY7C287  
[(SA015A1T)]  
CY7C291  
[(SA008A)]  
CY7C291A  
[(SA008A)]  
CY7C292  
[(SA008A)]  
CY7C292A  
[(SA008A)]  
CY7C293A  
[(SA008A)]  
CY8C9520@SSOP28 [(SA626A)]  
[(SA669)]  
CY8C9560@TQFP100 [(PEP+S604)]

CY7C276(25HC)@PLCC44  
CY7C276(30JC)@PLCC44  
CY7C281@PLCC28  
CY7C281A@PLCC28  
CY7C282@PLCC28  
CY7C282A@PLCC28  
CY7C285@PLCC32  
CY7C286@PLCC32  
CY7C287@PLCC32  
CY7C291@PLCC28  
CY7C291A@PLCC28  
CY7C292@PLCC28  
CY7C292A@PLCC28  
CY7C293A@PLCC28  
CY8C9540@SSOP48

**DRAM & SRAM**

CY62128@SOIC32 [(SA687)]	CY62128@SOJ32
[(SA661)]	
CY62128@VSOP32 [(SA620)]	CY62128L@SOIC32
[(SA687)]	
CY62128L@SOJ32 [(SA661)]	CY62128L@VSOP32
[(SA620)]	
CY62128LL@SOIC32 [(SA687)]	CY62128LL@SOJ32
[(SA661)]	
CY62128LL@VSOP32 [(SA620)]	CY7C1020@TSOP44
[(SA645)]	
CY7C1021@TSOP44 [(SA645)]	CY7C1049@SOJ36
[(SA027)]	
CY7C1049@TSOP44 [(SA645)]	
CY7C107	
CY7C107@SOJ28 [(SA661)]	
CY7C147	
CY7C167	CY7C167@PLCC20
[(SA001A)]	
CY7C167A	CY7C167A@PLCC20
[(SA001A)]	
CY7C185	CY7C185@SOIC28
[(SA404)]	
CY7C185@SOJ28 [(SA646)]	
CY7C186	
CY7C187	CY7C187@SOJ24
[(SA646)]	
CY7C187A	CY7C187A@SOJ24
[(SA646)]	
CY7C193	CY7C193@SOJ28
[(SA646)]	
CY7C199	CY7C199@PLCC28
[(SA008A)]	
CY7C199@SOJ28 [(SA646)]	CY7C199@TSOP28
[(SA430T)]	

**PLD**

CY22381@SOIC8 [(SA602A)]	CY22392@TSSOP16
[(SA026)]	
CY22393@TSSOP16 [(SA026)]	CY22394@TSSOP16

[(SA026)]  
 CY22395@TSSOP16 [(SA026)] CY2291@SOIC20  
 [(SA404)]  
 CY2292@SOIC16 [(SA602)] CY2295@SSOP28  
 [(SA626A)]  
 CY37032@PLCC44 [(SA244)] CY37032@TQFP44  
 [(SA245A)]  
 CY37032V@PLCC44 [(SA244)] CY37032V@TQFP44  
 [(SA245A)]  
 CY37064@PLCC44 [(SA244)]  
 CY37064@PLCC44(ISP) [ISP-HEADER01]  
 CY37064@PLCC84 [(PEP+S416T)]  
 CY37064@PLCC84(ISP) [ISP-HEADER01]  
 CY37064@TQFP100 [PEP+S604(TQFP100/D100)]  
 CY37064@TQFP100(ISP) [ISP-HEADER01]  
 CY37064@TQFP44 [(SA245A)]  
 CY37064@TQFP44(ISP) [ISP-HEADER01]  
 CY37064V@PLCC44 [(SA244)]  
 CY37064V@PLCC44(ISP) [ISP-HEADER01]  
 CY37064V@PLCC84 [(PEP+S416T)]  
 CY37064V@PLCC84(ISP) [ISP-HEADER01]  
 CY37064V@TQFP100 [PEP+S604(TQFP100/D100)]  
 CY37064V@TQFP100(ISP) [ISP-HEADER01]  
 CY37064V@TQFP44 [(SA245A)]  
 CY37064V@TQFP44(ISP) [ISP-HEADER01]  
 CY37128@PLCC84 [(PEP+S416T)] CY37128@TQFP100 [(PEP  
 +S604)]  
 CY37128@TQFP160(ISP) [ISP-HEADER01]  
 CY37128V@PLCC84 [(PEP+S416T)] CY37128V@TQFP100 [(PEP  
 +S604)]  
 CY37128V@TQFP160(ISP) [ISP-HEADER01]  
 CY37192@TQFP160(ISP) [ISP-HEADER01]  
 CY37192V@TQFP160(ISP) [ISP-HEADER01]  
 CY37256@BGA256(ISP) [ISP-HEADER01]  
 CY37256@TQFP160(ISP) [ISP-HEADER01]  
 CY37256@TQFP208(ISP) [ISP-HEADER01]  
 CY37256V@BGA256(ISP) [ISP-HEADER01]  
 CY37256V@TQFP160(ISP) [ISP-HEADER01]  
 CY37256V@TQFP208(ISP) [ISP-HEADER01]  
 CY37384@BGA256(ISP) [ISP-HEADER01]  
 CY37384@TQFP208(ISP) [ISP-HEADER01]  
 CY37384V@BGA256(ISP) [ISP-HEADER01]  
 CY37384V@TQFP208(ISP) [ISP-HEADER01]

CY37512@BGA256(ISP) [ISP-HEADER01]	
CY37512@BGA352(ISP) [ISP-HEADER01]	
CY37512@TQFP208(ISP) [ISP-HEADER01]	
CY37512V@BGA256(ISP) [ISP-HEADER01]	
CY37512V@BGA352(ISP) [ISP-HEADER01]	
CY37512V@TQFP208(ISP) [ISP-HEADER01]	
CY7C342B@PLCC68 [(PEP+S414T)]	CY7C343B@PLCC44
[(SA244)]	
CY7C344B	CY7C344B@PLCC28
[(SA008A)]	
CY7C346B@PLCC84 [(PEP+S416T)]	CY7C346B@PQFP100 [(PEP
+S427)]	
CY7C371@PLCC44 [(SA244)]	CY7C371@TQFP44
[(SA245A)]	
CY7C371I@PLCC44 [(SA244)]	CY7C371I@TQFP44
[(SA245A)]	
CY7C372@PLCC44 [(SA244)]	CY7C372@TQFP44
[(SA245A)]	
CY7C372I@PLCC44 [(SA244)]	CY7C372I@TQFP44
[(SA245A)]	
CY7C373@PLCC84 [(PEP+S416T)]	CY7C373@TQFP100 [(PEP
+S604)]	
CY7C373I@PLCC84 [(PEP+S416T)]	CY7C373I@TQFP100 [(PEP
+S604)]	
CY7C374@PLCC84 [(PEP+S416T)]	CY7C374@TQFP100 [(PEP
+S604)]	
CY7C374I@PLCC84 [(PEP+S416T)]	CY7C374I@TQFP100 [(PEP
+S604)]	
CY7C374U@PLCC84 [(PEP+S416T)]	CY7C374U@TQFP100 [(PEP
+S604)]	
PALC16L8	PALC16L8@PLCC20
[(SA001A)]	
PALC16L8L	PALC16L8L@PLCC20
[(SA001A)]	
PALC16R4	PALC16R4@PLCC20
[(SA001A)]	
PALC16R4L	PALC16R4L@PLCC20
[(SA001A)]	
PALC16R6	PALC16R6@PLCC20
[(SA001A)]	
PALC16R6L	PALC16R6L@PLCC20
[(SA001A)]	
PALC16R8	PALC16R8@PLCC20

[(SA001A)]  
 PALC16R8L PALC16R8L@PLCC20  
 [(SA001A)]  
 PALC22V10  
 PALC22V10@PLCC28 [ordering number is marked above]  
 PALC22V10A  
 PALC22V10A@PLCC28 [ordering number is marked above]  
 PALC22V10B  
 PALC22V10B@PLCC28 [ordering number is marked above]  
 PALC22V10D PALC22V10D@PLCC28  
 [(SA008A)]  
 PALC22V10L  
 PALC22V10L@PLCC28 [ordering number is marked above]  
 PALCE16V8 PALCE16V8@PLCC20  
 [(SA001A)]  
 PALCE20V8 PALCE20V8@PLCC28  
 [(SA008A)]  
 PALCE20V8L PALCE20V8L@PLCC28  
 [(SA008A)]  
 PALCE22V10 PALCE22V10@PLCC28  
 [(SA008A)]

## MICROCONTROLLER

CG6457AM@SSOP20 [(SA626A)]  
 CG6457AM@SSOP20(ISP) [ISP-HEADER01]  
 CG6462AM@SOIC8 [(SA602A)]  
 CG6462AM@SOIC8(ISP) [ISP-HEADER01]  
 CY7C53120E2@SOIC32 [(SA687)] CY7C53120E2@TQFP44  
 [(SA245A)]  
 CY7C53120E4@SOIC32 [(SA687)] CY7C53120E4@TQFP44  
 [(SA245A)]  
 CY7C60113@SSOP28 [(SA626A)]  
 CY7C60123  
 CY7C60123@SSOP48 [(SA669)]  
 CY7C60223  
 CY7C60223@QSOP24 [(SA643)] CY7C60223@SOIC24  
 [(SA404)]  
 CY7C60323@MLF32 [(SA686)]  
 CY7C60323@MLF32(ISP) [ISP-HEADER01]  
 CY7C60323@SSOP28 [(SA626A)]  
 CY7C60323@SSOP28(ISP) [ISP-HEADER01]



CY7C60333@MLF32 [(SA686)]	
CY7C60333@MLF32(ISP) [ISP-HEADER01]	
CY7C63000	CY7C63000@SOIC20
[(SA404)]	
CY7C63000A	CY7C63000A@SOIC20
[(SA404)]	
CY7C63001	CY7C63001@SOIC20
[(SA404)]	
CY7C63001A	CY7C63001A@SOIC20
[(SA404)]	
CY7C63100	CY7C63100@SOIC24
[(SA404)]	
CY7C63100A	CY7C63100A@SOIC24
[(SA404)]	
CY7C63101	CY7C63101@SOIC24
[(SA404)]	
CY7C63101A	CY7C63101A@SOIC24
[(SA404)]	
CY7C63200	CY7C63200@SOIC18
[(SA404)]	
CY7C63200A	CY7C63200A@SOIC18
[(SA404)]	
CY7C63201	CY7C63201@SOIC18
[(SA404)]	
CY7C63201A	CY7C63201A@SOIC18
[(SA404)]	
CY7C63221	
CY7C63221A	
CY7C63231	CY7C63231@SOIC18
[(SA404)]	
CY7C63231A	CY7C63231A@SOIC18
[(SA404)]	
CY7C63310	CY7C63310@SOIC16
[(SA602)]	
CY7C63411(dip40)	CY7C63411
(dip48)	
CY7C63411@SSOP48 [(SA669)]	CY7C63412
(dip40)	
CY7C63412(dip48)	CY7C63412@SSOP48
[(SA669)]	
CY7C63413(dip40)	CY7C63413
(dip48)	
CY7C63413@SSOP48 [(SA669)]	CY7C63511

(dip48)	
CY7C63511@SSOP48 [(SA669)]	CY7C63512
(dip48)	
CY7C63512@SSOP48 [(SA669)]	CY7C63513
(dip48)	
CY7C63513@SSOP48 [(SA669)]	
CY7C63722	
CY7C63722@SOIC18 [(SA404)]	
CY7C63722C	
CY7C63722C@SOIC18 [(SA404)]	
CY7C63723	
CY7C63723@SOIC18 [(SA404)]	
CY7C63723C	
CY7C63723C@SOIC18 [(SA404)]	
CY7C63742	
CY7C63742@QSOP24 [(SA674)]	CY7C63742@SOIC24
[(SA404)]	
CY7C63742C	CY7C63742C@QSOP24
[(SA674)]	
CY7C63742C@SOIC24 [(SA404)]	
CY7C63743	
CY7C63743@QSOP24 [(SA674)]	CY7C63743@SOIC24
[(SA404)]	
CY7C63743C	CY7C63743C@QSOP24
[(SA674)]	
CY7C63743C@SOIC24 [(SA404)]	
CY7C63801	
CY7C63801@SOIC16 [(SA602)]	CY7C63803@SOIC16
[(SA602)]	
CY7C63813	CY7C63813@SOIC18
[(SA404)]	
CY7C63823	CY7C63823@QSOP24
[(SA643)]	
CY7C63823@SOIC24 [(SA404)]	CY7C63833@QFN32
[(SA686)]	
CY7C63903@SSOP28 [(SA626A)]	
CY7C63913	
CY7C63923@SSOP48 [(SA669)]	
CY7C64011	
CY7C64011@SOIC28 [(SA404)]	
CY7C64011C	
CY7C64011C@SOIC28 [(SA404)]	
CY7C64012	

CY7C64012@SOIC28 [(SA404)]  
CY7C64012C  
CY7C64012C@SOIC28 [(SA404)]  
CY7C64013  
CY7C64013@SOIC28 [(SA404)]  
CY7C64013C  
CY7C64013C@SOIC28 [(SA404)]  
CY7C64111  
CY7C64111@SSOP48 [(SA669)]  
CY7C64111C  
CY7C64111C@SSOP48 [(SA669)]  
CY7C64112  
CY7C64112@SSOP48 [(SA669)]  
CY7C64112C  
CY7C64112C@SSOP48 [(SA669)]  
CY7C64113  
CY7C64113@SSOP48 [(SA669)]  
CY7C64113C  
CY7C64113C@SSOP48 [(SA669)]  
CY7C64215@MLF56 [(PEP  
+S706)]  
CY7C64215@MLF56(\*) [(SA706+B268)]  
CY7C64215@MLF56(ISP) [ISP-HEADER01]  
CY7C64215@SSOP28 [(SA626A)]  
CY7C64215@SSOP28(ISP) [ISP-HEADER01]  
CY7C65013  
[(SA669)]  
CY7C65013C  
[(SA669)]  
CY7C65113  
[(SA404)]  
CY7C65113C  
[(SA404)]  
CY7C66011  
[(SA669)]  
CY7C66011C  
[(SA669)]  
CY7C66012  
[(SA669)]  
CY7C66012C  
[(SA669)]  
CY7C66013  
[(SA669)]  
CY7C66013C  
CY7C65013@SSOP48  
CY7C65013C@SSOP48  
CY7C65113@SOIC28  
CY7C65113C@SOIC28  
CY7C66011@SSOP48  
CY7C66011C@SSOP48  
CY7C66012@SSOP48  
CY7C66012C@SSOP48  
CY7C66013@SSOP48  
CY7C66013C@SSOP48

[ (SA669) ]  
CY7C66111@QFN56 [ (PEP+S706) ]  
CY7C66111@SSOP56(\*) [ (SA772-B183) ]  
CY7C66111@TSOP56(\*) [ (SA628+B183) ]  
CY7C66111C@QFN56 [ (PEP+S706) ]  
CY7C66111C@SSOP56(\*) [ (SA772-B183) ]  
CY7C66111C@TSOP56(\*) [ (SA628+B183) ]  
CY7C66112@QFN56 [ (PEP+S706) ]  
CY7C66112@SSOP56(\*) [ (SA772-B183) ]  
CY7C66112@TSOP56(\*) [ (SA628+B183) ]  
CY7C66112C@QFN56 [ (PEP+S706) ]  
CY7C66112C@SSOP56(\*) [ (SA772-B183) ]  
CY7C66112C@TSOP56(\*) [ (SA628+B183) ]  
CY7C66113@QFN56 [ (PEP+S706) ]  
CY7C66113@SSOP56(\*) [ (SA772-B183) ]  
CY7C66113@TSOP56(\*) [ (SA628+B183) ]  
CY7C66113C@QFN56 [ (PEP+S706) ]  
CY7C66113C@SSOP56(\*) [ (SA772-B183) ]  
CY7C66113C@TSOP56(\*) [ (SA628+B183) ]  
CY8C20000@MLF48 [ (SA696) ]  
CY8C20000@MLF48(ISP) [ ISP-HEADER01 ]  
CY8C20234@MLF16 [ (SA743) ]  
CY8C20234@MLF16(ISP) [ ISP-HEADER01 ]  
CY8C20334@MLF24 [ (SA710) ]  
CY8C20334@MLF24(ISP) [ ISP-HEADER01 ]  
CY8C20434@MLF32 [ (SA686) ]  
CY8C20434@MLF32(ISP) [ ISP-HEADER01 ]  
CY8C21123@SOIC8 [ (SA602A) ]  
CY8C21123@SOIC8(ISP) [ ISP-HEADER01 ]  
CY8C21223@SOIC16 [ (SA602) ]  
CY8C21223@SOIC16(ISP) [ ISP-HEADER01 ]  
CY8C21234@SOIC16 [ (SA602) ]  
CY8C21234@SOIC16(ISP) [ ISP-HEADER01 ]  
CY8C21323@MLF24 [ (BBBB) ]  
CY8C21323@MLF24(ISP) [ ISP-HEADER01 ]  
CY8C21323@SSOP20 [ (SA626A) ]  
CY8C21323@SSOP20(ISP) [ ISP-HEADER01 ]  
CY8C21334@SSOP20 [ (SA626A) ]  
CY8C21334@SSOP20(ISP) [ ISP-HEADER01 ]  
CY8C21434@MLF32 [ (SA686) ]  
CY8C21434@MLF32(ISP) [ ISP-HEADER01 ]  
CY8C21534@SSOP28 [ (SA626A) ]  
CY8C21534@SSOP28(ISP) [ ISP-HEADER01 ]

CY8C21634@MLF32 [(SA686)]  
CY8C21634@MLF32(ISP) [ISP-HEADER01]  
CY8C22113 CY8C22113(ISP) [ISP-  
HEADER01]  
CY8C22113@SOIC8 [(SA602A)]  
CY8C22113@SOIC8(ISP) [ISP-HEADER01]  
CY8C22213 CY8C22213(ISP) [ISP-  
HEADER01]  
CY8C22213@MLF32 [(SA686)]  
CY8C22213@MLF32(ISP) [ISP-HEADER01]  
CY8C22213@SOIC20 [(SA404)]  
CY8C22213@SOIC20(ISP) [ISP-HEADER01]  
CY8C22213@SSOP20 [(SA626A)]  
CY8C22213@SSOP20(ISP) [ISP-HEADER01]  
CY8C24123 CY8C24123(ISP) [ISP-  
HEADER01]  
CY8C24123@SOIC8 [(SA602A)]  
CY8C24123@SOIC8(ISP) [ISP-HEADER01]  
CY8C24123A CY8C24123A(ISP) [ISP-  
HEADER01]  
CY8C24123A@SOIC8 [(SA602A)]  
CY8C24123A@SOIC8(ISP) [ISP-HEADER01]  
CY8C24223 CY8C24223(ISP) [ISP-  
HEADER01]  
CY8C24223@SOIC20 [(SA404)]  
CY8C24223@SOIC20(ISP) [ISP-HEADER01]  
CY8C24223@SSOP20 [(SA626A)]  
CY8C24223@SSOP20(ISP) [ISP-HEADER01]  
CY8C24223A CY8C24223A(ISP) [ISP-  
HEADER01]  
CY8C24223A@SOIC20 [(SA404)]  
CY8C24223A@SOIC20(ISP) [ISP-HEADER01]  
CY8C24223A@SSOP20 [(SA626A)]  
CY8C24223A@SSOP20(ISP) [ISP-HEADER01]  
CY8C24423 CY8C24423(ISP) [ISP-  
HEADER01]  
CY8C24423@MLF32 [(SA686)]  
CY8C24423@MLF32(ISP) [ISP-HEADER01]  
CY8C24423@SOIC28 [(SA404)]  
CY8C24423@SOIC28(ISP) [ISP-HEADER01]  
CY8C24423@SSOP28 [(SA626A)]  
CY8C24423@SSOP28(ISP) [ISP-HEADER01]  
CY8C24423A CY8C24423A(ISP) [ISP-

HEADER01 ]  
CY8C24423A@MLF32 [(SA686)]  
CY8C24423A@MLF32(ISP) [ISP-HEADER01]  
CY8C24423A@SOIC28 [(SA404)]  
CY8C24423A@SOIC28(ISP) [ISP-HEADER01]  
CY8C24423A@SSOP28 [(SA626A)]  
CY8C24423A@SSOP28(ISP) [ISP-HEADER01]  
CY8C24533 CY8C24533(ISP) [ISP-  
HEADER01 ]  
CY8C24533@SOIC28 [(SA404)]  
CY8C24533@SOIC28(ISP) [ISP-HEADER01]  
CY8C24533@SSOP28 [(SA626A)]  
CY8C24533@SSOP28(ISP) [ISP-HEADER01]  
CY8C24533A CY8C24533A(ISP) [ISP-  
HEADER01 ]  
CY8C24533A@SOIC28 [(SA404)]  
CY8C24533A@SOIC28(ISP) [ISP-HEADER01]  
CY8C24533A@SSOP28 [(SA626A)]  
CY8C24533A@SSOP28(ISP) [ISP-HEADER01]  
CY8C24633 CY8C24633(ISP) [ISP-  
HEADER01 ]  
CY8C24633@SOIC28 [(SA404)]  
CY8C24633@SOIC28(ISP) [ISP-HEADER01]  
CY8C24633@SSOP28 [(SA626A)]  
CY8C24633@SSOP28(ISP) [ISP-HEADER01]  
CY8C24633A CY8C24633A(ISP) [ISP-  
HEADER01 ]  
CY8C24633A@SOIC28 [(SA404)]  
CY8C24633A@SOIC28(ISP) [ISP-HEADER01]  
CY8C24633A@SSOP28 [(SA626A)]  
CY8C24633A@SSOP28(ISP) [ISP-HEADER01]  
CY8C24794@MLF56 [(PEP+S706)]  
CY8C24794@MLF56(\*) [(SA706+B268)]  
CY8C24794@MLF56(ISP) [ISP-HEADER01]  
CY8C24894@MLF56 [(PEP+S706)]  
CY8C24894@MLF56(\*) [(SA706+B268)]  
CY8C24894@MLF56(ISP) [ISP-HEADER01]  
CY8C24994@MLF68 [(PEP+S762)]  
CY8C24994@MLF68(ISP) [ISP-HEADER01]  
CY8C25122 CY8C25122(ISP) [ISP-  
HEADER01 ]  
CY8C26233 CY8C26233(ISP) [ISP-  
HEADER01 ]

CY8C26233@SOIC20 [(SA404)]  
CY8C26233@SOIC20(ISP) [ISP-HEADER01]  
CY8C26233@SSOP20 [(SA626A)]  
CY8C26233@SSOP20(ISP) [ISP-HEADER01]  
CY8C26443 CY8C26443(ISP) [ISP-  
HEADER01]  
CY8C26443@SOIC28 [(SA404)]  
CY8C26443@SOIC28(ISP) [ISP-HEADER01]  
CY8C26443@SSOP28 [(SA626A)]  
CY8C26443@SSOP28(ISP) [ISP-HEADER01]  
CY8C26643 CY8C26643(ISP) [ISP-  
HEADER01]  
CY8C26643@SSOP48 [(SA669)]  
CY8C26643@SSOP48(ISP) [ISP-HEADER01]  
CY8C26643@TQFP44 [(SA245A)]  
CY8C26643@TQFP44(ISP) [ISP-HEADER01]  
CY8C27143 CY8C27143(ISP) [ISP-  
HEADER01]  
CY8C27243 CY8C27243(ISP) [ISP-  
HEADER01]  
CY8C27243@SOIC20 [(SA404)]  
CY8C27243@SOIC20(ISP) [ISP-HEADER01]  
CY8C27243@SSOP20 [(SA626A)]  
CY8C27243@SSOP20(ISP) [ISP-HEADER01]  
CY8C27443 CY8C27443(ISP) [ISP-  
HEADER01]  
CY8C27443@SOIC28 [(SA404)]  
CY8C27443@SOIC28(ISP) [ISP-HEADER01]  
CY8C27443@SSOP28 [(SA626A)]  
CY8C27443@SSOP28(ISP) [ISP-HEADER01]  
CY8C27466 CY8C27466(ISP) [ISP-  
HEADER01]  
CY8C27466@SSOP28 [(SA626A)]  
CY8C27466@SSOP28(ISP) [ISP-HEADER01]  
CY8C27543@TQFP44 [(SA245A)]  
CY8C27543@TQFP44(ISP) [ISP-HEADER01]  
CY8C27566@TQFP44 [(SA245A)]  
CY8C27566@TQFP44(ISP) [ISP-HEADER01]  
CY8C27643@MLF48 [(SA696)]  
CY8C27643@MLF48(ISP) [ISP-HEADER01]  
CY8C27643@SSOP48 [(SA669)]  
CY8C27643@SSOP48(ISP) [ISP-HEADER01]  
CY8C27666@MLF48 [(SA696)]

CY8C27666@MLF48(ISP) [ISP-HEADER01]  
 CY8C27666@SSOP48 [(SA669)]  
 CY8C27666@SSOP48(ISP) [ISP-HEADER01]  
 CY8C27866@TQFP100 [(PEP+S604)]  
 CY8C27866@TQFP100(\*) [(TA052-B006)]  
 CY8C27866@TQFP100(ISP) [ISP-HEADER01]  
 CY8C29466 CY8C29466(ISP) [ISP-  
 HEADER01]  
 CY8C29466@SSOP28 [(SA626A)]  
 CY8C29466@SSOP28(ISP) [ISP-HEADER01]  
 CY8C29566@TQFP44 [(SA245A)]  
 CY8C29566@TQFP44(ISP) [ISP-HEADER01]  
 CY8C29666@MLF48 [(SA696)]  
 CY8C29666@MLF48(ISP) [ISP-HEADER01]  
 CY8C29666@SSOP48 [(SA669)]  
 CY8C29666@SSOP48(ISP) [ISP-HEADER01]  
 CY8C29866@TQFP100 [(PEP+S604)]  
 CY8C29866@TQFP100(\*) [(TA052-B006)]  
 CY8C29866@TQFP100(ISP) [ISP-HEADER01]

## DALLAS

### E(E)PROM/FRAM/NVRAM

DS1073M-100	DS1073M-
60	
DS1073M-66	DS1073M-
80	
DS1073Z-100@SOIC8 [(SA602A)]	DS1073Z-60@SOIC8
[(SA602A)]	
DS1073Z-66@SOIC8 [(SA602A)]	DS1073Z-80@SOIC8
[(SA602A)]	
DS1077LZ-40@SOIC8 [(SA602A)]	DS1077LZ-50@SOIC8
[(SA602A)]	
DS1077LZ-60@SOIC8 [(SA602A)]	DS1077LZ-66@SOIC8
[(SA602A)]	
DS1077Z-40@SOIC8 [(SA602A)]	DS1077Z-50@SOIC8
[(SA602A)]	
DS1077Z-60@SOIC8 [(SA602A)]	DS1077Z-66@SOIC8
[(SA602A)]	
DS1220AB	
DS1220AD	



DS1220Y  
DS1225AB  
DS1225AD  
DS1225D  
DS1225E  
DS1225Y  
DS1230AB  
DS1230W  
DS1230Y  
DS1235AB  
DS1235Y  
DS1243Y  
DS1244  
DS1244Y  
DS1245AB  
DS1245EE  
DS1245P  
DS1245W  
DS1245Y  
DS1248P  
DS1248W  
DS1248Y  
DS1249AB  
DS1249W  
DS1249Y  
DS1250AB  
DS1250W  
DS1250Y  
DS1251AB  
DS1251W  
DS1251Y  
DS1256P  
DS1256W  
DS1256Y  
DS1265AB  
DS1265W  
DS1265Y  
DS1270AB  
DS1270W  
DS1270Y  
DS1284  
DS1284N  
DS1284Q@PLCC28 [(SA008A)]

DS1284QN@PLCC28

[ (SA008A) ]

DS1286

DS1286I

DS1287

DS1287A

DS12887

DS12887A

DS12C887

DS12C887A

DS1330AB

DS1330WP

DS1330Y

DS1345AB

DS1345P

DS1345W

DS1345Y

DS1350AB

DS1350P

DS1350W

DS1350Y

DS1386

(32K)

DS1386(8K)

DS14285

DS14287

DS1485

DS1485@SOIC28 [ (SA630) ]

DS1486

DS1488

DS1553

DS1553W

DS1554

DS1554W

DS1556

DS1630AB

DS1630Y

DS1642

DS1643

DS1644

DS1644P [ordering number is marked above]

DS1644PS [ (PEP+S414T) ]

DS1645AB

DS1645EE

DS1645Y

DS1646  
 DS1647  
 DS1647LPM  
 DS1650AB  
 DS1650Y DS1687-  
 3  
 DS1687-5 DS17287-  
 3  
 DS17287-5  
 DS1742  
 DS1742W  
 DS1743  
 DS1743P  
 DS1743W  
 DS1743WP  
 DS1744  
 DS1744P  
 DS1744W  
 DS1744WP  
 DS1746  
 DS1747  
 DS1747P [ordering number is marked above]  
 DS1747PS [(PEP+S414T)]  
 DS1747W  
 DS1747WP [ordering number is marked above]  
 DS1747WPS [(PEP+S414T)] DS17487-  
 3  
 DS17487-5 DS17887-  
 3  
 DS17887-5 DS2406@TO-  
 92  
 DS2406P@TSOC6 DS2430A@TO-  
 92  
 DS2430AP@TSOC6 [(SA602A)] DS2431@TO-  
 92  
 DS2431P@TSOC6 [(SA602A)] DS2432P@TSOC6  
 [(SA602A)]  
 DS2433@PR-35 DS2433S(3.9)@SOIC8  
 [(SA602A)]  
 DS2433S(5.5)@SOIC8 [(SA605A)]  
 DS2502  
 DS2502P@TSOC6 [(SA602A)] DS2502S@SOIC8  
 [(SA602A)]

DS2502UNW	DS2502UNW@SOIC8
[ (SA602A) ]	
DS2502UNW@TSOC6 [ (SA602A) ]	
DS2506	
DS2506S@SOIC8 [ (SA023A) ]	
DS4510@uSOP10	
DS4520@TSSOP16 [ (SA026) ]	DS4550@TSSOP20
[ (SA026) ]	

## MICROCONTROLLER

DS5000[32K]	DS5000
[8K]	
DS5000T[32K]	DS5000T
[8K]	
DS87C520	DS87C520@PLCC44
[ (SA244) ]	
DS87C520@TQFP44 [ (SA245A) ]	DS87C530@PLCC52 [ (PEP
+S415T) ]	
DS87C550@PLCC68 [ (PEP+S414T) ]	
DS89C420	
DS89C420(rev.A)	DS89C420(rev.A)@PLCC44
[ (SA244) ]	
DS89C420(rev.A)@TQFP44 [ (SA245A) ]	
DS89C420@PLCC44 [ (SA244) ]	DS89C420@TQFP44
[ (SA245A) ]	
DS89C430	DS89C430@PLCC44
[ (SA244) ]	
DS89C430@TQFP44 [ (SA245A) ]	
DS89C440	
DS89C440@PLCC44 [ (SA244) ]	DS89C440@TQFP44
[ (SA245A) ]	
DS89C450	DS89C450@PLCC44
[ (SA244) ]	
DS89C450@TQFP44 [ (SA245A) ]	

## DENSE-PAC

### E(E) PROM/FRAM/NVRAM

DPV27C101	DPV27C101@PLCC32
-----------	------------------

[ (SA015A1T) ]  
 DPV27C256  
 [ (SA015A1T) ]  
 DPV27C512  
 [ (SA015A1T) ]

DPV27C256@PLCC32  
  
 DPV27C512@PLCC32

## DEUTRON

### E (E) PROM/FRAM/NVRAM

AC25LV010  
 [ (SA602A) ]  
 AC25LV512  
 [ (SA602A) ]  
 P439LV010@PLCC32 [ (SA015A1T) ]  
 [ (SA620) ]  
 P439LV040@PLCC32 [ (SA015A1T) ]  
 [ (SA620) ]  
 P439LV088@TSOP48 [ (SA247-B005) ]  
 B005) ]

AC25LV010@SOIC8  
  
 AC25LV512@SOIC8  
  
 P439LV010@VSOP32  
  
 P439LV040@VSOP32  
  
 P439VF800@TSOP48 [ (SA247-  
 B005) ]

## EFST

### E (E) PROM/FRAM/NVRAM

EM25LV010@SOIC8 [ (SA602A) ]  
 [ (SA684) ]  
 EM25LV512@SOIC8 [ (SA602A) ]  
 [ (SA684) ]  
 F25L004A@SOIC8 [ (SA602A) ]  
 F49B002UA  
 F49B002UA@PLCC32 [ (SA015A1T) ]  
 [ (SA015A1T) ]  
 F49L004BA@TSOP40 [ (SA409T) ]  
 [ (SA015A1T) ]  
 F49L004UA@TSOP40 [ (SA409T) ]  
 [ (SA015A1T) ]  
 F49L040A@VSOP32 [ (SA620) ]  
 B005) ]  
 F49L400UA@TSOP48 [ (SA247-B005) ]

EM25LV010@VFQFPN8  
  
 EM25LV512@VFQFPN8  
  
 F49L004BA@PLCC32  
  
 F49L004UA@PLCC32  
  
 F49L040A@PLCC32  
  
 F49L400BA@TSOP48 [ (SA247-  
 B005) ]  
  
 F49L800BA@TSOP48

[ ( SA247 ) ]  
F49L800UA@TSOP48 [ ( SA247 ) ]

## **ELECTRONIC ARRAYS**

### **E ( E ) PROM / FRAM / NVRAM**

EA2716

## **ELPIDA**

### **E ( E ) PROM / FRAM / NVRAM**

EHD0010A1MA@FBGA137 [ ( SA700C-B327A-Y137F001Y ) ]  
EHD013011MA@FBGA137 [ ( SA700C-B327A-Y137F001Y ) ]

## **EM**

### **MICROCONTROLLER**

EM6503@SOIC24 [ ( SA404 ) ]  
EM6503@SOIC24 ( ISP ) [ ISP-HEADER01 ]  
EM6504@SOIC24 [ ( SA404 ) ]  
EM6504@SOIC24 ( ISP ) [ ISP-HEADER01 ]  
EM6505@SOIC24 [ ( SA404 ) ]  
EM6505@SOIC24 ( ISP ) [ ISP-HEADER01 ]  
EM6517@SOIC28 [ ( SA404 ) ]  
EM6517@SOIC28 ( ISP ) [ ISP-HEADER01 ]  
EM6520@TQFP44 [ ( SA245A ) ]  
EM6520@TQFP44 ( ISP ) [ ISP-HEADER01 ]  
EM6521@TQFP52 [ ( PEP+S673 ) ]  
EM6521@TQFP52 ( ISP ) [ ISP-HEADER01 ]  
EM6522@TQFP64 [ ( PEP+S616 ) ]  
EM6522@TQFP64 ( ISP ) [ ISP-HEADER01 ]  
EM6540@SOIC18 [ ( SA404 ) ]  
EM6540@SOIC18 ( ISP ) [ ISP-HEADER01 ]  
EM6580  
HEADER01 ]  
EM6580@SOIC14 [ ( SA602 ) ]  
EM6580 ( ISP ) [ ISP-

EM6580@SOIC14(ISP) [ISP-HEADER01]  
 EM6580@SOIC8 [(SA602A)] EM6580@SOIC8(ISP) [ISP-  
 HEADER01]  
 EM6580@TSSOP14 [(SA026)]  
 EM6580@TSSOP14(ISP) [ISP-HEADER01]  
 EM6812\_2K EM6812\_2K(ISP) [ISP-  
 HEADER01]  
 EM6812\_2K@SOIC24 [(SA404)]  
 EM6812\_2K@SOIC24(ISP) [ISP-HEADER01]  
 EM6812\_2K@TSSOP24 [(SA026)]  
 EM6812\_2K@TSSOP24(ISP) [ISP-HEADER01]  
 EM6812\_4K EM6812\_4K(ISP) [ISP-  
 HEADER01]  
 EM6812\_4K@SOIC24 [(SA404)]  
 EM6812\_4K@SOIC24(ISP) [ISP-HEADER01]  
 EM6812\_4K@TSSOP24 [(SA026)]  
 EM6812\_4K@TSSOP24(ISP) [ISP-HEADER01]  
 EM6812\_8K EM6812\_8K(ISP) [ISP-  
 HEADER01]  
 EM6812\_8K@SOIC24 [(SA404)]  
 EM6812\_8K@SOIC24(ISP) [ISP-HEADER01]  
 EM6812\_8K@TSSOP24 [(SA026)]  
 EM6812\_8K@TSSOP24(ISP) [ISP-HEADER01]

## EMTC

### E (E) PROM/FRAM/NVRAM

EM24C02 EM24C02@SOIC8  
 [(SA602A)]  
 EM24C02@TSSOP8 [(SA026)]  
 EM24C04 EM24C04@TSSOP8  
 EM24C04@SOIC8 [(SA602A)]  
 [(SA026)]  
 EM24C08 EM24C08@SOIC8  
 [(SA602A)]  
 EM24C08@TSSOP8 [(SA026)]  
 EM24C16 EM24C16@TSSOP8  
 EM24C16@SOIC8 [(SA602A)]  
 [(SA026)]  
 EM25SL512@SOIC8 [(SA602A)]  
 EM29SF002AB

EM29SF002AB@PLCC32 [(SA015A1T)]	EM29SF002AB@TSOP32
[(SA410T)]	
EM29SF002AT	EM29SF002AT@PLCC32
[(SA015A1T)]	
EM29SF002AT@TSOP32 [(SA410T)]	
EM29SF002NAB	
EM29SF002NAB@PLCC32 [(SA015A1T)]	EM29SF002NAB@TSOP32
[(SA410T)]	
EM29SF002NAT	EM29SF002NAT@PLCC32
[(SA015A1T)]	
EM29SF002NAT@TSOP32 [(SA410T)]	

## EON

### E (E) PROM/FRAM/NVRAM

EN25B05(Bottom Boot)@SOP8(4.0) [(SA602A)]  
 EN25B05(Bottom Boot)@SOP8(5.4) [(SA605A)]  
 EN25B05(Bottom Boot)@VDFN8 [(SA683)]  
 EN25B05(Top Boot)@SOP8(4.0) [(SA602A)]  
 EN25B05(Top Boot)@SOP8(5.4) [(SA605A)]  
 EN25B05(Top Boot)@VDFN8 [(SA683)]  
 EN25B10(Bottom Boot)@SOP8(4.0) [(SA602A)]  
 EN25B10(Bottom Boot)@SOP8(5.4) [(SA605A)]  
 EN25B10(Bottom Boot)@VDFN8 [(SA683)]  
 EN25B10(Top Boot)@SOP8(4.0) [(SA602A)]  
 EN25B10(Top Boot)@SOP8(5.4) [(SA605A)]  
 EN25B10(Top Boot)@VDFN8 [(SA683)]  
 EN25B16(Bottom Boot)@SOP8 [(SA605A)]  
 EN25B16(Bottom Boot)@SOP8(ISP) [ISP-HEADER01]  
 EN25B16(Bottom Boot)@VFQFN8(ISP) [ISP-HEADER01]  
 EN25B16(Bottom Boot)@VFQFPN8 [(SA684)]  
 EN25B16(Top Boot)@SOP8 [(SA605A)]  
 EN25B16(Top Boot)@SOP8(ISP) [ISP-HEADER01]  
 EN25B16(Top Boot)@VFQFN8(ISP) [ISP-HEADER01]  
 EN25B16(Top Boot)@VFQFPN8 [(SA684)]  
 EN25B20(Bottom Boot)@SOP8(4.0) [(SA602A)]  
 EN25B20(Bottom Boot)@SOP8(5.4) [(SA605A)]  
 EN25B20(Bottom Boot)@VDFN8 [(SA683)]  
 EN25B20(Top Boot)@SOP8(4.0) [(SA602A)]  
 EN25B20(Top Boot)@SOP8(5.4) [(SA605A)]  
 EN25B20(Top Boot)@VDFN8 [(SA683)]



EN25B32(Bottom Boot)@SOIC16 [(SA404)]  
 EN25B32(Bottom Boot)@SOIC16(ISP) [(SA404)]  
 EN25B32(Bottom Boot)@SOP8 [(SA605A)]  
 EN25B32(Bottom Boot)@SOP8(ISP) [(SA605A)]  
 EN25B32(Bottom Boot)@VDFN8 [(SA684)]  
 EN25B32(Bottom Boot)@VDFN8(ISP) [(SA684)]  
 EN25B32(Top Boot)@SOIC16 [(SA404)]  
 EN25B32(Top Boot)@SOIC16(ISP) [(SA404)]  
 EN25B32(Top Boot)@SOP8 [(SA605A)]  
 EN25B32(Top Boot)@SOP8(ISP) [(SA605A)]  
 EN25B32(Top Boot)@VDFN8 [(SA684)]  
 EN25B32(Top Boot)@VDFN8(ISP) [(SA684)]  
 EN25B40(Bottom Boot)@SOP8(4.0) [(SA602A)]  
 EN25B40(Bottom Boot)@SOP8(5.4) [(SA605A)]  
 EN25B40(Bottom Boot)@VDFN8 [(SA683)]  
 EN25B40(Top Boot)@SOP8(4.0) [(SA602A)]  
 EN25B40(Top Boot)@SOP8(5.4) [(SA605A)]  
 EN25B40(Top Boot)@VDFN8 [(SA683)]  
 EN25B64(Bottom Boot)@SOIC16 [(SA404)]  
 EN25B64(Bottom Boot)@SOIC16(ISP) [ISP-HEADER01]  
 EN25B64(Bottom Boot)@VDFN8 [(SA683)]  
 EN25B64(Bottom Boot)@VDFN8(ISP) [ISP-HEADER01]  
 EN25B64(Top Boot)@SOIC16 [(SA404)]  
 EN25B64(Top Boot)@SOIC16(ISP) [ISP-HEADER01]  
 EN25B64(Top Boot)@VDFN8 [(SA683)]  
 EN25B64(Top Boot)@VDFN8(ISP) [ISP-HEADER01]  
 EN25B80(Bottom Boot)@SOP8(4.0) [(SA602A)]  
 EN25B80(Bottom Boot)@SOP8(5.4) [(SA605A)]  
 EN25B80(Bottom Boot)@VDFN8 [(SA683)]  
 EN25B80(Top Boot)@SOP8(4.0) [(SA602A)]  
 EN25B80(Top Boot)@SOP8(5.4) [(SA605A)]  
 EN25B80(Top Boot)@VDFN8 [(SA683)]  
 EN25F10@SOP8 [(SA605A)]                      EN25F10@VDFN8  
 [(SA683)]  
 EN25F20@SOP8 [(SA605A)]                      EN25F20@VDFN8  
 [(SA683)]  
 EN25F40@SOP8(150mil) [(SA602A)]              EN25F40@SOP8(209mil)  
 [(SA605A)]  
 EN25F40@VDFN8 [(SA683)]                      EN25F80@SOP8  
 [(SA605A)]  
 EN25F80@VDFN8 [(SA683)]                      EN25LV010@SOIC8  
 [(SA602A)]  
 EN25LV010@VFQFPN8 [(SA684)]                EN25LV020@SOIC8

[ (SA602A) ]	
EN25LV020@VFQFPN8 [ (SA684) ]	EN25LV040@SOIC8
[ (SA602A) ]	
EN25LV040@VFQFPN8 [ (SA684) ]	EN25LV080@SOIC8
[ (SA602A) ]	
EN25LV080@VFQFPN8 [ (SA684) ]	EN25LV160@SOIC8
[ (SA602A) ]	
EN25LV160@SOIC8 (ISP) [ ISP-HEADER01 ]	
EN25LV160@VFQFPN8 [ (SA683) ]	
EN25LV160@VFQFPN8 (ISP) [ ISP-HEADER01 ]	
EN25LV512@SOIC8 [ (SA602A) ]	EN25LV512@VFQFPN8
[ (SA684) ]	
EN25P05@SOP8 (4.0) [ (SA602A) ]	EN25P05@SOP8 (5.4)
[ (SA605A) ]	
EN25P05@VDFN8 [ (SA683) ]	EN25P10@SOP8 (4.0)
[ (SA602A) ]	
EN25P10@SOP8 (5.4) [ (SA605A) ]	EN25P10@VDFN8
[ (SA683) ]	
EN25P16@SOP8 [ (SA605A) ]	EN25P16@SOP8 (ISP) [ ISP-
HEADER01 ]	
EN25P16@VFQFPN8 [ (SA684) ]	
EN25P16@VFQFPN8 (ISP) [ ISP-HEADER01 ]	
EN25P20@SOP8 (4.0) [ (SA602A) ]	EN25P20@SOP8 (5.4)
[ (SA605A) ]	
EN25P20@VDFN8 [ (SA683) ]	EN25P32@SOIC16
[ (SA404) ]	
EN25P32@SOIC16 (ISP) [ (SA404) ]	EN25P32@SOP8
[ (SA605A) ]	
EN25P32@SOP8 (ISP) [ (SA605A) ]	EN25P32@VDFN8
[ (SA684) ]	
EN25P32@VDFN8 (ISP) [ (SA684) ]	EN25P40@SOP8 (4.0)
[ (SA602A) ]	
EN25P40@SOP8 (5.4) [ (SA605A) ]	EN25P40@VDFN8
[ (SA683) ]	
EN25P64@SOIC16 [ (SA404) ]	
EN25P64@SOIC16 (ISP) [ ISP-HEADER01 ]	
EN25P64@VDFN8 [ (SA683) ]	
EN25P64@VDFN8 (ISP) [ ISP-HEADER01 ]	
EN25P80@SOP8 (4.0) [ (SA602A) ]	EN25P80@SOP8 (5.4)
[ (SA605A) ]	
EN25P80@VDFN8 [ (SA683) ]	EN25S16@SOP8
[ (SA605A) ]	
EN25S16@VFQFPN8 [ (SA684) ]	EN25T16@SOP8

[ (SA605A) ]	
EN25T16@VFQFPN8 [ (SA684) ]	
EN25T80	EN25T80@VDFN8
EN25T80@SOP8 [ (SA605A) ]	
[ (SA683) ]	
EN27C010	EN27C010@PLCC32
[ (SA015A1T) ]	
EN27C512	EN27C512@PLCC32
[ (SA015A1T) ]	
EN29F002AB	EN29F002AB@PLCC32
[ (SA015A1T) ]	
EN29F002AB@TSOP32 [ (SA410T) ]	
EN29F002ANB	
EN29F002ANB@PLCC32 [ (SA015A1T) ]	EN29F002ANB@TSOP32
[ (SA410T) ]	
EN29F002ANT	EN29F002ANT@PLCC32
[ (SA015A1T) ]	
EN29F002ANT@TSOP32 [ (SA410T) ]	
EN29F002AT	
EN29F002AT@PLCC32 [ (SA015A1T) ]	EN29F002AT@TSOP32
[ (SA410T) ]	
EN29F002B	EN29F002B@PLCC32
[ (SA015A1T) ]	
EN29F002B@TSOP32 [ (SA410T) ]	
EN29F002NB	
EN29F002NB@PLCC32 [ (SA015A1T) ]	EN29F002NB@TSOP32
[ (SA410T) ]	
EN29F002NT	EN29F002NT@PLCC32
[ (SA015A1T) ]	
EN29F002NT@TSOP32 [ (SA410T) ]	
EN29F002T	
EN29F002T@PLCC32 [ (SA015A1T) ]	EN29F002T@TSOP32
[ (SA410T) ]	
EN29F010	EN29F010@PLCC32
[ (SA015A1T) ]	
EN29F010@TSOP32 [ (SA410T) ]	EN29F010@VSOP32
[ (SA620) ]	
EN29F040	EN29F040@PLCC32
[ (SA015A1T) ]	
EN29F040@TSOP32 [ (SA410T) ]	
EN29F040A	
EN29F040A@PLCC32 [ (SA015A1T) ]	EN29F040A@TSOP32
[ (SA410T) ]	

EN29F080@TSOP40 [(SA409T)]  
 EN29F512  
 EN29F512@PLCC32 [(SA015A1T)] EN29F512@TSOP32  
 [(SA410T)]  
 EN29F512@VSOP32 [(SA620)] EN29F800B@TSOP48 [(SA247-  
 B005)]  
 EN29F800T@TSOP48 [(SA247-B005)] EN29LV010@PLCC32  
 [(SA015A1T)]  
 EN29LV010@TSOP32 [(SA410T)] EN29LV010@VSOP32  
 [(SA620)]  
 EN29LV040@PLCC32 [(SA015A1T)] EN29LV040@TSOP32  
 [(SA410T)]  
 EN29LV040@VSOP32 [(SA620)] EN29LV040A@PLCC32  
 [(SA015A1T)]  
 EN29LV040A@TSOP32 [(SA410T)] EN29LV040A@VSOP32  
 [(SA620)]  
 EN29LV160AB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV160AB@TSOP48 [(SA247-B005)]  
 EN29LV160AT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV160AT@TSOP48 [(SA247-B005)]  
 EN29LV160B@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV160B@TSOP48 [(SA247-B005)]  
 EN29LV160T@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV160T@TSOP48 [(SA247-B005)]  
 EN29LV320AB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV320AB@TSOP48 [(SA247-B005)]  
 EN29LV320AT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV320AT@TSOP48 [(SA247-B005)]  
 EN29LV320B@FBGA48 [(SA642G-B026A-T048F001)]  
 EN29LV320B@TSOP48 [(SA247-B005)]  
 EN29LV320T@FBGA48 [(SA642G-B026A-T048F001)]  
 EN29LV320T@TSOP48 [(SA247-B005)]  
 EN29LV400AB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV400AB@TSOP48 [(SA247-B005)]  
 EN29LV400AT@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV400AT@TSOP48 [(SA247-B005)]  
 EN29LV400B@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV400B@TSOP48 [(SA247-B005)]  
 EN29LV400T@FBGA48 [(SA642G-B026A-T048F001Y)]  
 EN29LV400T@TSOP48 [(SA247-B005)] EN29LV512@PLCC32  
 [(SA015A1T)]  
 EN29LV512@TSOP32 [(SA410T)] EN29LV512@VSOP32  
 [(SA620)]

EN29LV640B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV640B@TSOP48 [ ( SA247-B005 ) ]  
EN29LV640H@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV640H@TSOP48 [ ( SA247-B005 ) ]  
EN29LV640L@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV640L@TSOP48 [ ( SA247-B005 ) ]  
EN29LV640T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV640T@TSOP48 [ ( SA247-B005 ) ]  
EN29LV641H@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
EN29LV641H@TSOP48 [ ( SA247-B005 ) ]  
EN29LV641L@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
EN29LV641L@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800AB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800AB@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800AT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800AT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800B@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800BB@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
EN29LV800BB@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800BT@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
EN29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800T@TSOP48 [ ( SA247-B005 ) ]  
EN29SL160B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL160B@TSOP48 [ ( SA247-B005 ) ]  
EN29SL160T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL160T@TSOP48 [ ( SA247-B005 ) ]  
EN29SL400B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL400B@TSOP48 [ ( SA247-B005 ) ]  
EN29SL400T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL400T@TSOP48 [ ( SA247-B005 ) ]  
EN29SL800B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL800B@TSOP48 [ ( SA247-B005 ) ]  
EN29SL800T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL800T@TSOP48 [ ( SA247-B005 ) ]

## EPSON

### E ( E ) PROM / FRAM / NVRAM

S1H0H324B2B1@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0H324B2T1@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0H326B2B1@FBGA66 [ ( SA642E-B023A-T072F001 ) ]

S1H0H326B2T1@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
 S1H0H328B2B2@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
 S1H0H328B2T2@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
 S1H0J642B2B3@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
 S1H0J642B2T3@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
 S1H0J646B2B3@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
 S1H0J646B2T3@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
 S1H0J648B2B2@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
 S1H0J648B2T2@FBGA68 [ ( SA642E-B023A-T072F001 ) ]

## ESMT

### E ( E ) PROM / FRAM / NVRAM

EM25LV010@SOIC8 [ ( SA602A ) ]	EM25LV010@VFQFPN8
[ ( SA684 ) ]	
EM25LV512@SOIC8 [ ( SA602A ) ]	EM25LV512@VFQFPN8
[ ( SA684 ) ]	
F25L004AB	
F25L004AB@SOIC8 ( 150mil ) [ ( SA602A ) ]	
F25L004AB@SOIC8 ( 200mil ) [ ( SA605A ) ]	
F25L004AT	
F25L004AT@SOIC8 ( 150mil ) [ ( SA602A ) ]	
F25L004AT@SOIC8 ( 200mil ) [ ( SA605A ) ]	
F25L008AB@SOIC8 [ ( SA605A ) ]	F25L008AT@SOIC8
[ ( SA605A ) ]	
F25L016AB@SOIC8 [ ( SA605A ) ]	F25L016AT@SOIC8
[ ( SA605A ) ]	
F25L04UA@SOIC8 [ ( SA602A ) ]	
F25L16PA ( AAI - PROGRAM ) @SOIC8 [ ( SA605A ) ]	
F25L16PA ( PAGE - PROGRAM ) @SOIC8 [ ( SA605A ) ]	
F49B002UA	F49B002UA@PLCC32
[ ( SA015A1T ) ]	
F49L004BA@PLCC32 [ ( SA015A1T ) ]	F49L004BA@TSOP40
[ ( SA409T ) ]	
F49L004UA@PLCC32 [ ( SA015A1T ) ]	F49L004UA@TSOP40
[ ( SA409T ) ]	
F49L040A@PLCC32 [ ( SA015A1T ) ]	F49L040A@VSOP32
[ ( SA620 ) ]	
F49L160BA@TSOP48 [ ( SA247 ) ]	F49L160UA@TSOP48
[ ( SA247 ) ]	
F49L320BA@TSOP48 [ ( SA247 ) ]	F49L320UA@TSOP48

[ (SA247) ]  
 F49L400BA@TSOP48 [ (SA247-B005) ]      F49L400UA@TSOP48 [ (SA247-B005) ]  
 F49L800BA@TSOP48 [ (SA247) ]      F49L800UA@TSOP48  
 [ (SA247) ]

## EXCELSEMI

### E (E) PROM/FRAM/NVRAM

ES25M16      ES25M16@SOP16  
 [ (SA404) ]  
 ES25M16@SOP8[150 mil] [ (SA602A) ]      ES25M16@SOP8[208 mil]  
 [ (SA605A) ]  
 ES25M40      ES25M40@SOP16  
 [ (SA404) ]  
 ES25M40@SOP8[150 mil] [ (SA602A) ]      ES25M40@SOP8[208 mil]  
 [ (SA605A) ]  
 ES25M80      ES25M80@SOP16  
 [ (SA404) ]  
 ES25M80@SOP8[150 mil] [ (SA602A) ]      ES25M80@SOP8[208 mil]  
 [ (SA605A) ]  
 ES25P16@SOP8 [ (SA605A) ]      ES25P40@SOP8  
 [ (SA605A) ]  
 ES25P80@SOP8 [ (SA605A) ]  
 ES29LV160DB@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 ES29LV160DB@PSOP44 [ (SA638) ]  
 ES29LV160DB@TSOP48 [ (SA247-B005) ]  
 ES29LV160DT@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 ES29LV160DT@PSOP44 [ (SA638) ]  
 ES29LV160DT@TSOP48 [ (SA247-B005) ]  
 ES29LV160EB@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 ES29LV160EB@TSOP48 [ (SA247-B005) ]  
 ES29LV160ET@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 ES29LV160ET@TSOP48 [ (SA247-B005) ]  
 ES29LV160FB@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 ES29LV160FB@TSOP48 [ (SA247-B005) ]  
 ES29LV160FT@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 ES29LV160FT@TSOP48 [ (SA247-B005) ]  
 ES29LV320DB@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 ES29LV320DB@TSOP48 [ (SA247-B005) ]  
 ES29LV320DT@FBGA48 [ (SA642G-B026A-T048F001Y) ]

ES29LV320DT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320EB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320EB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320ET@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320ET@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320FB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320FB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320FT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320FT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV400DB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV400DB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV400DT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV400DT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV400EB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV400EB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV400ET@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV400ET@TSOP48 [ ( SA247-B005 ) ]  
ES29LV800DB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV800DB@PSOP44 [ ( SA638 ) ]  
ES29LV800DB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV800DT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV800DT@PSOP44 [ ( SA638 ) ]  
ES29LV800DT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV800EB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV800EB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV800ET@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV800ET@TSOP48 [ ( SA247-B005 ) ]

## **EXEL**

### **E ( E ) PROM / FRAM / NVRAM**

XL24C01A  
XL24C02  
XL24C04  
XL24C16  
XL24C16@SOIC8 [ ( SA602A ) ]  
XL24C32  
XL28C256  
[ ( SA015A1T ) ]  
XL28C256@TSOP28 [ ( SA430T ) ]  
XL9010  
XL28C256@PLCC32



XL9010(F) [(SA602A)]	
XL9020	
XL9020(F) [(SA602A)]	
XL9040	
XL9040(F) [(SA602A)]	
XL9346	
XL9346@SOIC8 [(SA602A)]	
XL93CS56	
XL93CS56@SOIC8 [(SA602A)]	XL93CS56@TSSOP8
[(SA026)]	
XL93CS66	XL93CS66@SOIC8
[(SA602A)]	
XL93CS66@TSSOP8 [(SA026)]	
XL93LC46	
XL93LC46@SOIC8 [(SA602A)]	
XL93LC46A	
XL93LC46A@SOIC8 [(SA602A)]	
XL93LC56	
XL93LC56@SOIC8 [(SA602A)]	
XL93LC56A	
XL93LC56A@SOIC8 [(SA602A)]	
XL93LC66A	
XL93LC66A@SOIC8 [(SA602A)]	
XL9764	
XLE28C16A	XLE28C16A@PLCC32
[(SA015A1T)]	
XLE28C16B	XLE28C16B@PLCC32
[(SA015A1T)]	
XLE28C16B@SOIC24 [(SA404)]	
XLM28C16A	
XLM28C16A@PLCC32 [(SA015A1T)]	
XLM46C15	
XLM46P15	
XLS2804A	
XLS2816A	XLS2816A@PLCC32
[(SA015A1T)]	
XLS2817A	
XLS28C16A	
XLS28C16A@PLCC32 [(SA015A1T)]	
XLS28C16B	
XLS28C16B@PLCC32 [(SA015A1T)]	XLS28C16B@SOIC24
[(SA404)]	
XLS28C64B	XLS28C64B@PLCC32

[ ( SA015A1T ) ]  
XLS28C64B@SOIC28 [ ( SA404 ) ]  
XLS46C15  
XLS46P15  
XLS93C46  
XLS93C46@SOIC8 [ ( SA602A ) ]  
XLS93C56  
XLS93C56@SOIC8 [ ( SA602A ) ]  
XLS93C66  
XLS93C66@SOIC8 [ ( SA602A ) ]  
XLS93CS46  
XLS93CS46@SOIC8 [ ( SA602A ) ]  
[ ( SA026 ) ]  
XLS93LC06  
[ ( SA602A ) ]  
XLS93LC66  
[ ( SA602A ) ]

XLS93CS46@TSSOP8  
XLS93LC06@SOIC8  
XLS93LC66@SOIC8

## PLD

XLE78C800P-25  
35  
XLE78C800P-45  
25  
XLE78C800S-35  
45  
XLM78C800S-35  
45  
XLS78C800P-25  
35  
XLS78C800P-45  
25  
XLS78C800S-35  
45

XLE78C800P-  
XLE78C800S-  
XLE78C800S-  
XLM78C800S-  
XLS78C800P-  
XLS78C800S-  
XLS78C800S-

## FAIRCHILD

### E ( E ) PROM / FRAM / NVRAM

FM24C02 ( M8 ) @SOIC8 [ ( SA602A ) ]  
[ ( SA026 ) ]

FM24C02 ( MT8 ) @TSSOP8

FM24C02(N) [(SA602A)]	FM24C03(M8)@SOIC8
FM24C03(MT8)@TSSOP8 [(SA026)] (N)	FM24C03
FM24C04(M8)@SOIC8 [(SA602A)] [(SA026)]	FM24C04(MT8)@TSSOP8
FM24C04(N) [(SA602A)]	FM24C05(M8)@SOIC8
FM24C05(MT8)@TSSOP8 [(SA026)] (N)	FM24C05
FM24C08(M8)@SOIC8 [(SA602A)] [(SA026)]	FM24C08(MT8)@TSSOP8
FM24C08(N) [(SA602A)]	FM24C09(M8)@SOIC8
FM24C09(MT8)@TSSOP8 [(SA026)] (N)	FM24C09
FM24C128(MT8)@TSSOP8 [(SA026)] [(SA602A)]	FM24C128(MW8)@SOIC8
FM24C128(N) [(SA602A)]	FM24C16(M8)@SOIC8
FM24C16(MT8)@TSSOP8 [(SA026)] (N)	FM24C16
FM24C17(M8)@SOIC8 [(SA602A)] [(SA026)]	FM24C17(MT8)@TSSOP8
FM24C17(N) [(SA602A)]	FM24C256(M8)@SOIC8
FM24C256(N) [(SA602A)]	FM24C32(M8)@SOIC8
FM24C32(N)	
FM27C010	
FM27C010@PLCC32 [(SA015A1T)] [(SA410T)]	FM27C010@TSOP32
FM27C040 [(SA015A1T)]	FM27C040@PLCC32
FM27C040@TSOP32 [(SA410T)]	
FM27C256	
FM27C256@PLCC32 [(SA015A1T)]	
FM27C256Q	
FM27C256Q@PLCC32 [(SA015A1T)]	
FM27C512	
FM27C512@PLCC32 [(SA015A1T)]	
FM93C06(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C06(M8)(16bit)@SOIC8 [(SA602A)]	

FM93C06(MT8)(08bit)@TSSOP8 [(SA026)]  
 FM93C06(MT8)(16bit)@TSSOP8 [(SA026)]  
 FM93C06(N)(08bit) FM93C06(N)  
 (16bit)  
 FM93C14(16bit) FM93C46(M8)@SOIC8  
 [(SA602A)]  
 FM93C46(MT8)@TSSOP8 [(SA026)] FM93C46  
 (N)  
 FM93C46A(M8)(08bit)@SOIC8 [(SA602A)]  
 FM93C46A(M8)(16bit)@SOIC8 [(SA602A)]  
 FM93C46A(MT8)(08bit)@TSSOP8 [(SA026)]  
 FM93C46A(MT8)(16bit)@TSSOP8 [(SA026)]  
 FM93C46A(N)(08bit) FM93C46A(N)  
 (16bit)  
 FM93C56(M8)@SOIC8 [(SA602A)] FM93C56(MT8)@TSSOP8  
 [(SA026)]  
 FM93C56(N)  
 FM93C56A(M8)(08bit)@SOIC8 [(SA602A)]  
 FM93C56A(M8)(16bit)@SOIC8 [(SA602A)]  
 FM93C56A(MT8)(08bit)@TSSOP8 [(SA026)]  
 FM93C56A(MT8)(16bit)@TSSOP8 [(SA026)]  
 FM93C56A(N)(08bit) FM93C56A(N)  
 (16bit)  
 FM93C66(M8)@SOIC8 [(SA602A)] FM93C66(MT8)@TSSOP8  
 [(SA026)]  
 FM93C66(N)  
 FM93C66A(M8)(08bit)@SOIC8 [(SA602A)]  
 FM93C66A(M8)(16bit)@SOIC8 [(SA602A)]  
 FM93C66A(MT8)(08bit)@TSSOP8 [(SA026)]  
 FM93C66A(MT8)(16bit)@TSSOP8 [(SA026)]  
 FM93C66A(N)(08bit) FM93C66A(N)  
 (16bit)  
 FM93C76(M8)(16bit)@SOIC8 [(SA602A)]  
 FM93C76(MT8)(16bit)@TSSOP8 [(SA026)]  
 FM93C76(N)(16bit)  
 FM93C76A(M8)(08bit)@SOIC8 [(SA602A)]  
 FM93C76A(M8)(16bit)@SOIC8 [(SA602A)]  
 FM93C76A(MT8)(08bit)@TSSOP8 [(SA026)]  
 FM93C76A(MT8)(16bit)@TSSOP8 [(SA026)]  
 FM93C76A(N)(08bit) FM93C76A(N)  
 (16bit)  
 FM93C86(M8)(16bit)@SOIC8 [(SA602A)]  
 FM93C86(MT8)(16bit)@TSSOP8 [(SA026)]

FM93C86(N)(16bit)	
FM93C86A(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C86A(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C86A(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C86A(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C86A(N)(08bit)	FM93C86A(N)
(16bit)	
FM93CS06(M8)@SOIC8 [(SA602A)]	FM93CS06(MT8)@TSSOP8
[(SA026)]	
FM93CS06(N)	FM93CS46(M8)@SOIC8
[(SA602A)]	
FM93CS46(MT8)@TSSOP8 [(SA026)]	FM93CS46
(N)	
FM93CS56(M8)@SOIC8 [(SA602A)]	FM93CS56(MT8)@TSSOP8
[(SA026)]	
FM93CS56(N)	FM93CS66(M8)@SOIC8
[(SA602A)]	
FM93CS66(MT8)@TSSOP8 [(SA026)]	FM93CS66
(N)	
FM93S46(M8)@SOIC8 [(SA602A)]	FM93S46(MT8)@TSSOP8
[(SA026)]	
FM93S46(N)	FM93S56(M8)@SOIC8
[(SA602A)]	
FM93S56(MT8)@TSSOP8 [(SA026)]	FM93S56
(N)	
FM93S66(M8)@SOIC8 [(SA602A)]	FM93S66(MT8)@TSSOP8
[(SA026)]	
FM93S66(N)	
MM2716	
MM2716E	NM24C02(M8)@SOIC8
[(SA602A)]	
NM24C02(MT8)@TSSOP8 [(SA026)]	NM24C02
(N)	
NM24C02L(M8)@SOIC8 [(SA602A)]	NM24C02L(MT8)@TSSOP8
[(SA026)]	
NM24C02L(N)	NM24C03(M8)@SOIC8
[(SA602A)]	
NM24C03(MT8)@TSSOP8 [(SA026)]	NM24C03
(N)	
NM24C04(M8)@SOIC8 [(SA602A)]	NM24C04(MT8)@TSSOP8
[(SA026)]	
NM24C04(N)	NM24C05(M8)@SOIC8
[(SA602A)]	

NM24C05 (MT8)@TSSOP8 [(SA026)] (N)	NM24C05
NM24C08 (M8)@SOIC8 [(SA602A)] [(SA026)]	NM24C08 (MT8)@TSSOP8
NM24C08 (N) [(SA602A)]	NM24C09 (M8)@SOIC8
NM24C09 (MT8)@TSSOP8 [(SA026)] (N)	NM24C09
NM24C16 (M8)@SOIC8 [(SA602A)] [(SA026)]	NM24C16 (MT8)@TSSOP8
NM24C16 (N) [(SA602A)]	NM24C17 (M8)@SOIC8
NM24C17 (MT8)@TSSOP8 [(SA026)] (N)	NM24C17
NM24C65 (M8)SOIC8 [(SA602A)] (N)	NM24C65
NM27C010 [(SA015A1T)]	NM27C010@PLCC32
NM27C010@TSOP32 [(SA410T)]	
NM27C020 NM27C020@PLCC32 [(SA015A1T)] [(SA410T)]	NM27C020@TSOP32
NM27C020Q [(SA015A1T)]	NM27C020Q@PLCC32
NM27C020Q@TSOP32 [(SA410T)]	
NM27C040 NM27C040@PLCC32 [(SA015A1T)] [(SA410T)]	NM27C040@TSOP32
NM27C128 [(SA015A1T)]	NM27C128@PLCC32
NM27C210 [(SA244)]	NM27C210@PLCC44
NM27C240 [(SA244)]	NM27C240@PLCC44
NM27C256 [(SA015A1T)]	NM27C256@PLCC32
NM27C512 [(SA015A1T)]	NM27C512@PLCC32
NM27C64Q [(SA015A1T)]	NM27C64Q@PLCC32
NM27LC256 [(SA015A1T)]	NM27LC256@PLCC32
NM27LC512	NM27LC512@PLCC32

[ (SA015A1T) ]	
NM27LV010	NM27LV010@PLCC32
[ (SA015A1T) ]	
NM27LV010@TSOP32 [ (SA410T) ]	
NM27LV210	
NM27LV210@PLCC44 [ (SA244) ]	
NM27LV512	
NM27LV512@PLCC32 [ (SA015A1T) ]	
NM27P040	
NM27P040@PLCC32 [ (SA015A1T) ]	NM27P040@TSOP32
[ (SA410T) ]	
NM27P210	NM27P210@PLCC44
[ (SA244) ]	
NM27P512	NM27P512@PLCC32
[ (SA015A1T) ]	
NM93C66(M8)(16bit)@SOIC8 [ (SA602A) ]	
NM93C66(MT8)(16bit)@TSSOP8 [ (SA026) ]	
NM93C66(N)(16bit)	NM93CS06(M8)@SOIC8
[ (SA602A) ]	
NM93CS06(MT8)@TSSOP8 [ (SA026) ]	NM93CS06
(N)	
NM93CS46(M8)@SOIC8 [ (SA602A) ]	NM93CS46(MT8)@TSSOP8
[ (SA026) ]	
NM93CS46(N)	NM93CS56(M8)@SOIC8
[ (SA602A) ]	
NM93CS56(MT8)@TSSOP8 [ (SA026) ]	NM93CS56
(N)	
NM93CS66(M8)@SOIC8 [ (SA602A) ]	NM93CS66(MT8)@TSSOP8
[ (SA026) ]	
NM93CS66(N)	
NMC2732	
NMC27C010	NMC27C010@PLCC32
[ (SA015A1T) ]	
NMC27C010@TSOP32 [ (SA410T) ]	
NMC27C1024	
NMC27C1024@PLCC44 [ (SA244) ]	
NMC27C128B	
NMC27C128B@PLCC32 [ (SA015A1T) ]	
NMC27C128BN	
NMC27C128BN@PLCC32 [ (SA015A1T) ]	
NMC27C128BQ	
NMC27C128BQ@PLCC32 [ (SA015A1T) ]	
NMC27C128CQ	

NMC27C16  
 NMC27C16BQ  
 NMC27C16BQE  
 NMC27C16H  
 NMC27C16HQ  
 NMC27C16Q  
 NMC27C256 NMC27C256@PLCC32  
 [ (SA015A1T) ]  
 NMC27C256B NMC27C256B@PLCC32  
 [ (SA015A1T) ]  
 NMC27C256Q NMC27C256Q@PLCC32  
 [ (SA015A1T) ]  
 NMC27C32  
 NMC27C32B  
 NMC27C32BQ  
 NMC27C32E  
 NMC27C32EH  
 NMC27C32H  
 NMC27C512 NMC27C512@PLCC32  
 [ (SA015A1T) ]  
 NMC27C512A NMC27C512A@PLCC32  
 [ (SA015A1T) ]  
 NMC27C512AN NMC27C512AN@PLCC32  
 [ (SA015A1T) ]  
 NMC27C64 NMC27C64  
 (BN)  
 NMC27C64(N)  
 NMC27CP128  
 NMC87C257Q NMC87C257Q@PLCC32  
 [ (SA015A1T) ]  
 NMC87C257V NMC87C257V@PLCC32  
 [ (SA015A1T) ]  
 NMC9346(M8)(16bit)@SOIC8 [(SA602A)]  
 NMC9346(MT8)(16bit)@TSSOP8 [(SA026)]  
 NMC9346(N)(16bit)  
 NMC93C46(M8)(16bit)@SOIC8 [(SA602A)]  
 NMC93C46(MT8)(16bit)@TSSOP8 [(SA026)]  
 NMC93C46(N)(16bit)  
 NMC93C46A(M8)(16bit)@SOIC8 [(SA602A)]  
 NMC93C46A(MT8)(16bit)@TSSOP8 [(SA026)]  
 NMC93C46A(N)(16bit)  
 NMC93C56(M8)(16bit)@SOIC8 [(SA602A)]  
 NMC93C56(MT8)(16bit)@TSSOP8 [(SA026)]



NMC93C56(N)(16bit)	
NMC93C66(M8)(16bit)@SOIC8 [(SA602A)]	
NMC93C66(MT8)(16bit)@TSSOP8 [(SA026)]	
NMC93C66(N)(16bit)	NMC93CS06(M8)@SOIC8
[(SA602A)]	
NMC93CS06(MT8)@TSSOP8 [(SA026)]	NMC93CS06
(N)	
NMC93CS46(M8)@SOIC8 [(SA602A)]	NMC93CS46(MT8)@TSSOP8
[(SA026)]	
NMC93CS46(N)	NMC93CS56(M8)@SOIC8
[(SA602A)]	
NMC93CS56(MT8)@TSSOP8 [(SA026)]	NMC93CS56
(N)	
NMC93CS66(M8)@SOIC8 [(SA602A)]	NMC93CS66(MT8)@TSSOP8
[(SA026)]	
NMC93CS66(N)	
NMC9817	

## DRAM & SRAM

F1600	F1600@SOJ24
[(SA646)]	
F1601	F1601@SOJ24
[(SA646)]	
F1620	
F1621	

## MICROCONTROLLER

ACE1001(M8)@SOIC8 [(SA602A)]	ACE1001(M8X)@SOIC8
[(SA602A)]	
ACE1001(MT8)@TSSOP8 [(SA026)]	ACE1001(MT8X)@TSSOP8
[(SA026)]	
ACE1001E(M8)@SOIC8 [(SA602A)]	ACE1001E(M8X)@SOIC8
[(SA602A)]	
ACE1001E(MT8)@TSSOP8 [(SA026)]	ACE1001E(MT8X)@TSSOP8
[(SA026)]	
ACE1001L(M8)@SOIC8 [(SA602A)]	ACE1001L(M8X)@SOIC8
[(SA602A)]	
ACE1001L(MT8)@TSSOP8 [(SA026)]	ACE1001L(MT8X)@TSSOP8
[(SA026)]	

ACE1101(EMT8)@TSSOP8 [(SA026)]	ACE1101(EMT8X)@TSSOP8
[(SA026)]	
ACE1101(EN)	ACE1101
(EN14)	
ACE1101(LMT8)@TSSOP8 [(SA026)]	ACE1101(LMT8X)@TSSOP8
[(SA026)]	
ACE1101(LN)	ACE1101
(LN14)	
ACE1101(MT8)@TSSOP8 [(SA026)]	ACE1101(MT8X)@TSSOP8
[(SA026)]	
ACE1101(N)	ACE1101
(N14)	
ACE1101(VMT8)@TSSOP8 [(SA026)]	ACE1101(VMT8X)@TSSOP8
[(SA026)]	
ACE1101(VN)	ACE1101
(VN14)	
ACE1101B(EMT8)@TSSOP8 [(SA026)]	ACE1101B(EMT8X)@TSSOP8
[(SA026)]	
ACE1101B(EN)	ACE1101B
(EN14)	
ACE1101B(MT8)@TSSOP8 [(SA026)]	ACE1101B(MT8X)@TSSOP8
[(SA026)]	
ACE1101B(N)	ACE1101B
(N14)	
ACE1101B(VMT8)@TSSOP8 [(SA026)]	ACE1101B(VMT8X)@TSSOP8
[(SA026)]	
ACE1101B(VN)	ACE1101B
(VN14)	
ACE1202(dip14)	ACE1202
(dip8)	
ACE1202(M14)@SOIC14 [(SA602)]	ACE1202(M8)@SOIC8
[(SA602A)]	
ACE12022(dip14)	ACE12022
(dip8)	
ACE12022(M14)@SOIC14 [(SA602)]	ACE12022(M8)@SOIC8
[(SA602A)]	
ACE12022B(dip14)	ACE12022B
(dip8)	
ACE12022B(M14)@SOIC14 [(SA602)]	ACE12022B(M8)@SOIC8
[(SA602A)]	
ACE12022BE(dip14)	ACE12022BE
(dip8)	
ACE12022BE(M14)@SOIC14 [(SA602)]	ACE12022BE(M8)@SOIC8

[ (SA602A) ]	
ACE12022BV(dip14)	ACE12022BV
(dip8)	
ACE12022BV(M14)@SOIC14 [ (SA602) ]	ACE12022BV(M8)@SOIC8
[ (SA602A) ]	
ACE12022E(dip14)	ACE12022E
(dip8)	
ACE12022E(M14)@SOIC14 [ (SA602) ]	ACE12022E(M8)@SOIC8
[ (SA602A) ]	
ACE1202B(dip14)	ACE1202B
(dip8)	
ACE1202B(M14)@SOIC14 [ (SA602) ]	ACE1202B(M8)@SOIC8
[ (SA602A) ]	
ACE1202BE(dip14)	ACE1202BE
(dip8)	
ACE1202BE(M14)@SOIC14 [ (SA602) ]	ACE1202BE(M8)@SOIC8
[ (SA602A) ]	
ACE1202BV(dip14)	ACE1202BV
(dip8)	
ACE1202BV(M14)@SOIC14 [ (SA602) ]	ACE1202BV(M8)@SOIC8
[ (SA602A) ]	
ACE1202E(dip14)	ACE1202E
(dip8)	
ACE1202E(M14)@SOIC14 [ (SA602) ]	ACE1202E(M8)@SOIC8
[ (SA602A) ]	
ACE1202L(dip14)	ACE1202L
(dip8)	
ACE1202L(M14)@SOIC14 [ (SA602) ]	ACE1202L(M8)@SOIC8
[ (SA602A) ]	
ACE1202V(dip8)	ACE1202V(M14)@SOIC14
[ (SA602) ]	
ACE1202V(M8)@SOIC8 [ (SA602A) ]	ACE1501(EM)@SOIC14
[ (SA602) ]	
ACE1501(EM8)@SOIC8 [ (SA602A) ]	ACE1501(EM8X)@SOIC8
[ (SA602A) ]	
ACE1501(EMT)@TSOP14 [ (SA026) ]	ACE1501(EMT8)@TSSOP8
[ (SA026) ]	
ACE1501(EMT8X)@TSSOP8 [ (SA026) ]	ACE1501(EMTX)@TSOP14
[ (SA026) ]	
ACE1501(EMX)@SOIC14 [ (SA602) ]	ACE1501
(EN)	
ACE1501(EN14)	ACE1501(VM)@SOIC14
[ (SA602) ]	

ACE1501(VM8)@SOIC8 [(SA602A)]	ACE1501(VM8X)@SOIC8
[(SA602A)]	
ACE1501(VMT)@TSOP14 [(SA026)]	ACE1501(VMT8)@TSSOP8
[(SA026)]	
ACE1501(VMT8X)@TSSOP8 [(SA026)]	ACE1501(VMTX)@TSOP14
[(SA026)]	
ACE1501(VMX)@SOIC14 [(SA602)]	ACE1501
(VN)	
ACE1501(VN14)	ACE1502(EM)@SOIC14
[(SA602)]	
ACE1502(EM8)@SOIC8 [(SA602A)]	ACE1502(EMT)@TSOP14
[(SA026)]	
ACE1502(EMT8)@TSSOP8 [(SA026)]	ACE1502
(EN)	
ACE1502(EN14)	ACE1502(VM)@SOIC14
[(SA602)]	
ACE1502(VM8)@SOIC8 [(SA602A)]	ACE1502(VMT)@TSOP14
[(SA026)]	
ACE1502(VMT8)@TSSOP8 [(SA026)]	ACE1502
(VN)	
ACE1502(VN14)	ACE8000(M8)@SOIC8
[(SA602A)]	
ACE8000(M8X)@SOIC8 [(SA602A)]	ACE8000E(M8)@SOIC8
[(SA602A)]	
ACE8000E(M8X)@SOIC8 [(SA602A)]	ACE8001(M8)@SOIC8
[(SA602A)]	
ACE8001(M8X)@SOIC8 [(SA602A)]	ACE8001(MT8)@TSSOP8
[(SA026)]	
ACE8001(MT8X)@TSSOP8 [(SA026)]	ACE8001E(M8)@SOIC8
[(SA602A)]	
ACE8001E(M8X)@SOIC8 [(SA602A)]	ACE8001E(MT8)@TSSOP8
[(SA026)]	
ACE8001E(MT8X)@TSSOP8 [(SA026)]	FMS7401L(EM8X)@SOIC8
[(SA602A)]	
FMS7401L(EMT8X)@TSSOP8 [(SA026)]	FMS7401L(EMTX)@TSSOP14
[(SA026)]	
FMS7401L(EMX)@SOIC14 [(SA602)]	FMS7401L
(EN)	
FMS7401L(EN14)	FMS7401L
(VN)	
FMS7401L(VN14)	

**FORCE TECHNOLOGIES****E ( E ) PROM / FRAM / NVRAM**

FT24C01 [ ( SA602A ) ]	FT24C01@SOIC8
FT24C01@TSOP8 [ ( SA026 ) ]	
FT24C01A FT24C01A@SOIC8 [ ( SA602A ) ]	FT24C01A@TSOP8
[ ( SA026 ) ]	
FT24C02 [ ( SA602A ) ]	FT24C02@SOP8
FT24C02@TSSOP8 [ ( SA026 ) ]	
FT24C02A FT24C02A@SOP8 [ ( SA602A ) ]	FT24C02A@TSSOP8
[ ( SA026 ) ]	
FT24C04 [ ( SA602A ) ]	FT24C04@SOP8
FT24C04@TSSOP8 [ ( SA026 ) ]	
FT24C04A FT24C04A@SOP8 [ ( SA602A ) ]	FT24C04A@TSSOP8
[ ( SA026 ) ]	
FT24C08 [ ( SA602A ) ]	FT24C08@SOIC8
FT24C08@TSOP8 [ ( SA026 ) ]	
FT24C08A FT24C08A@SOIC8 [ ( SA602A ) ]	FT24C08A@TSOP8
[ ( SA026 ) ]	
FT24C128 [ ( SA602A ) ]	FT24C128@SOIC8
FT24C128@TSOP8 [ ( SA026 ) ]	
FT24C128A FT24C128A@SOIC8 [ ( SA602A ) ]	FT24C128A@TSOP8
[ ( SA026 ) ]	
FT24C16 [ ( SA602A ) ]	FT24C16@SOIC8
FT24C16@TSOP8 [ ( SA026 ) ]	
FT24C16A FT24C16A@SOIC8 [ ( SA602A ) ]	FT24C16A@TSOP8
[ ( SA026 ) ]	
FT24C256 [ ( SA602A ) ]	FT24C256@SOIC8
FT24C256@TSOP8 [ ( SA026 ) ]	

FT24C256A	
FT24C256A@SOIC8 [(SA602A)]	FT24C256A@TSOP8
[(SA026)]	
FT24C32	FT24C32@SOIC8
[(SA602A)]	
FT24C32@TSOP8 [(SA026)]	
FT24C32A	
FT24C32A@SOIC8 [(SA602A)]	FT24C32A@TSOP8
[(SA026)]	
FT24C64	FT24C64@SOIC8
[(SA602A)]	
FT24C64@TSOP8 [(SA026)]	
FT24C64A	
FT24C64A@SOIC8 [(SA602A)]	FT24C64A@TSOP8
[(SA026)]	
FT27C010	FT27C010@PLCC32
[(SA015A1T)]	
FT27C010@TSOP32 [(SA410T)]	
FT27C020	
FT27C020@PLCC32 [(SA015A1T)]	FT27C020@TSOP32
[(SA410T)]	
FT27C040	FT27C040@PLCC32
[(SA015A1T)]	
FT27C040@TSOP32 [(SA410T)]	
FT27C16	
FT27C256	FT27C256@PLCC32
[(SA015A1T)]	
FT27C64	FT27C64@PLCC32
[(SA015A1T)]	
FT27HC256	FT27HC256@PLCC32
[(SA015A1T)]	
FT27HC64	FT27HC64@PLCC32
[(SA015A1T)]	
FT28C010	FT28C010@JLCC32
[(SA412A)]	
FT28C010@PLCC32 [(SA015A1T)]	FT28C010@PLCC44
[(SA244)]	
FT28C010@TSOP32 [(SA410T)]	
FT28C010E	
FT28C010E@JLCC32 [(SA412A)]	FT28C010E@PLCC32
[(SA015A1T)]	
FT28C010E@PLCC44 [(SA244)]	FT28C010E@TSOP32
[(SA410T)]	

FT28C020	FT28C020@JLCC32
[ (SA412A) ]	
FT28C020@PLCC32 [ (SA015A1T) ]	FT28C020@PLCC44
[ (SA244) ]	
FT28C020@TSOP32 [ (SA410T) ]	
FT28C040	
FT28C040@JLCC32 [ (SA412A) ]	FT28C040@PLCC32
[ (SA015A1T) ]	
FT28C040@PLCC44 [ (SA244) ]	FT28C040@TSOP32
[ (SA410T) ]	
FT28C16	FT28C16@PLCC32
[ (SA015A1T) ]	
FT28C256	FT28C256@JLCC32
[ (SA412A) ]	
FT28C256@PLCC32 [ (SA015A1T) ]	FT28C256@SOIC28
[ (SA404) ]	
FT28C256@TSOP28 [ (SA430T) ]	
FT28C256B	
FT28C256B@JLCC32 [ (SA412A) ]	FT28C256B@PLCC32
[ (SA015A1T) ]	
FT28C256B@SOIC28 [ (SA404) ]	FT28C256B@TSOP28
[ (SA430T) ]	
FT28C64	FT28C64@PLCC32
[ (SA015A1T) ]	
FT28C64@SOIC28 [ (SA404) ]	FT28C64@TSOP28
[ (SA430T) ]	
FT28C64B	FT28C64B@JLCC32
[ (SA412A) ]	
FT28C64B@PLCC32 [ (SA015A1T) ]	FT28C64B@SOIC28
[ (SA404) ]	
FT28C64B@TSOP28 [ (SA430T) ]	
FT28C64X	
FT28C64X@PLCC32 [ (SA015A1T) ]	FT28C64X@SOIC28
[ (SA404) ]	
FT28C64X@TSOP28 [ (SA430T) ]	
FT28HC64	
FT28HC64@PLCC32 [ (SA015A1T) ]	FT28HC64@TSOP28
[ (SA430T) ]	
FT58C1001	FT58C1001@SSOP32
[ (SA438T) ]	
FT58C1001@VSOP32 [ (SA620) ]	

# FORWARD

## E ( E ) PROM / FRAM / NVRAM

24LC01	24LC01@SOIC8
[ ( SA602A ) ]	
24LC02	24LC02@SOIC8
[ ( SA602A ) ]	
24LC04	24LC04@SOIC8
[ ( SA602A ) ]	
24LC08	24LC08@SOIC8
[ ( SA602A ) ]	
24LC16	24LC16@SOIC8
[ ( SA602A ) ]	
24LC32	24LC32@SOIC8
[ ( SA602A ) ]	
24LC64	24LC64@SOIC8
[ ( SA602A ) ]	

# FREESCALE

## MICROCONTROLLER

68HC711E9MFN2@PLCC52	[ ( SA647-B5202 ) ]
68HC711E9MFNE2@PLCC52	[ ( SA647-B5202 ) ]
68HC711E9VFN2@PLCC52	[ ( SA647-B5202 ) ]
68HC711E9VFNE2@PLCC52	[ ( SA647-B5202 ) ]
DSP56F801 ( FA60 ) @TQFP48	[ ( SA248 ) ]
DSP56F801 ( FA60E ) @TQFP48	[ ( SA248 ) ]
DSP56F801 ( FA80 ) @TQFP48	[ ( SA248 ) ]
DSP56F801 ( FA80E ) @TQFP48	[ ( SA248 ) ]
DSP56F802 ( TA60 ) @TQFP32	[ ( SA663 ) ]
DSP56F802 ( TA60E ) @TQFP32	[ ( SA663 ) ]
DSP56F802 ( TA80 ) @TQFP32	[ ( SA663 ) ]
DSP56F802 ( TA80E ) @TQFP32	[ ( SA663 ) ]
DSP56F803 ( BU80 ) @TQFP100 ( JTAG )	[ ISP-HEADER01 ]
DSP56F803 ( BU80E ) @TQFP100 ( JTAG )	[ ISP-HEADER01 ]
DSP56F805 ( FV80 ) @TQFP144 ( JTAG )	[ ISP-HEADER01 ]
DSP56F805 ( FV80E ) @TQFP144 ( JTAG )	[ ISP-HEADER01 ]
DSP56F807 ( PY80 ) @LQFP160 ( JTAG )	[ ISP-HEADER01 ]
DSP56F807 ( PY80E ) @LQFP160 ( JTAG )	[ ISP-HEADER01 ]



DSP56F807(VF80)@LQFP160(JTAG) [ISP-HEADER01]  
 DSP56F807(VF80E)@LQFP160(JTAG) [ISP-HEADER01]  
 DSP56F826(BU80)@TQFP100(JTAG) [ISP-HEADER01]  
 DSP56F826(BU80E)@TQFP100(JTAG) [ISP-HEADER01]  
 DSP56F827(FG80)@TQFP128(JTAG) [ISP-HEADER01]  
 DSP56F827(FG80E)@TQFP128(JTAG) [ISP-HEADER01]  
 MC56F8011VFAE@QFP32 [(SA663+B005)]  
 MC56F8013VFAE@QFP32 [(SA663+B005)]  
 MC56F8014VFAE@QFP32 [(SA663+B005)]  
 MC56F8023MFAE@QFP32 [(SA663+B005)]  
 MC56F8023VFAE@QFP32 [(SA663+B005)]  
 MC56F8025VLD@QFP44 [(SA245A+B005)]  
 MC56F8036MFAE@QFP48 [(SA248+B005)]  
 MC56F8036VFAE@QFP48 [(SA248+B005)]  
 MC56F8037VLH@QFP64 [(PEP+S616)]  
 MC56F8122VFA@TQFP48 [(SA248+B005)]  
 MC56F8122VFAE@TQFP48 [(SA248+B005)]  
 MC56F8123VFB@TQFP64 [(PEP+S616)]  
 MC56F8123VFBE@TQFP64 [(PEP+S616)]  
 MC56F8322MFA60@TQFP48 [(SA248+B005)]  
 MC56F8322MFAE@TQFP48 [(SA248+B005)]  
 MC56F8322VFA60@TQFP48 [(SA248+B005)]  
 MC56F8322VFAE@TQFP48 [(SA248+B005)]  
 MC56F8323MFB60@TQFP64 [(PEP+S616)]  
 MC56F8323MFBE@TQFP64 [(PEP+S616)]  
 MC56F8323VFB60@TQFP64 [(PEP+S616)]  
 MC56F8323VFBE@TQFP64 [(PEP+S616)]  
 MC68705R3  
 MC68705R5  
 MC68705U3  
 MC68705U5  
 MC68HC11A0 MC68HC11A0@PLCC52 [(PEP  
 +S415T)]  
 MC68HC11A1 MC68HC11A1@PLCC52 [(PEP  
 +S415T)]  
 MC68HC11A8 MC68HC11A8@PLCC52 [(PEP  
 +S415T)]  
 MC68HC11E1@PLCC52 [(PEP+S415T)]  
 MC68HC11E1@PLCC52(\*) [(SA647-B5202)]  
 MC68HC11E20@PLCC52 [(PEP+S415T)]  
 MC68HC11E20@PLCC52(\*) [(SA647-B5202)]  
 MC68HC11E9@PLCC52 [(PEP+S415T)]  
 MC68HC11E9@PLCC52(\*) [(SA647-B5202)]

MC68HC11F1@PLCC68 [(PEP+S414T)]            MC68HC11K1@PLCC84 [(PEP  
+S416T)]  
MC68HC11P1@PLCC84(\*) [(SA649-B8405)]  
MC68HC705B16N@PLCC52 [(PEP+S415T)]  
MC68HC705B16N@TQFP64 [(PEP+S625A)]  
MC68HC705B16N@TQFP64(\*) [(SA668+B204)]  
MC68HC705B5@PLCC52 [(PEP+S415T)]  
MC68HC705C4  
MC68HC705C4@PLCC44 [(SA244)]  
MC68HC705C4A  
MC68HC705C4A@PLCC44 [(SA244)]  
MC68HC705C8  
MC68HC705C8@PLCC44 [(SA244)]            MC68HC705C8@SDIP42  
[SA028]  
MC68HC705C8@TQFP44 [(SA245A)]  
MC68HC705C8A  
MC68HC705C8A@PLCC44 [(SA244)]            MC68HC705C8A@SDIP42  
[SA028]  
MC68HC705C8A@TQFP44 [(SA245A)]  
MC68HC705C9A  
MC68HC705C9A@PLCC44 [(SA244)]            MC68HC705C9A@TQFP44  
[(SA245A)]  
MC68HC705J1A(CDW)@SOIC20 [(SA404)]  
MC68HC705J1A(CSD)@SSOP20 [(SA626A)]  
MC68HC705J1A(P)                            MC68HC705J2  
(Emulation)  
MC68HC705J2(Emulation)@SOIC20 [(SA404)]  
MC68HC705J2(Emulation)@SSOP20 [(SA626A)]  
MC68HC705J2(Native)  
MC68HC705J2(Native)@SOIC20 [(SA404)]  
MC68HC705J2(Native)@SSOP20 [(SA626A)]  
MC68HC705KJ1                                MC68HC705KJ1@SOIC16  
[(SA404)]  
MC68HC705P6(CDW)@SOIC28 [(SA404)]  
MC68HC705P6(CP)  
MC68HC705P6A(CDW)@SOIC28 [(SA404)]  
MC68HC705P6A(CP)  
MC68HC705P9  
MC68HC705P9@SOIC28 [(SA404)]  
MC68HC705SR3  
MC68HC705SR3@SDIP42 [(SA028)]            MC68HC705SR3@TQFP44  
[(SA245A)]  
MC68HC711D3                                MC68HC711D3@PLCC44

[ (SA244) ]  
MC68HC711D3@TQFP44 [ (SA675) ]  
MC68HC711E20@PLCC52 [ (PEP+S415T) ]  
MC68HC711E20@TQFP64 [ (PEP+S625A) ]  
MC68HC711E9(4.5V)@PLCC52 [ (SA647-B5202) ]  
MC68HC711E9@PLCC52(\*) [ (SA647-B5202) ]  
MC68HC711E9CFN(4.5V)@PLCC52 [ (SA647-B5202) ]  
MC68HC711E9CFN2@PLCC52 [ (SA647-B5202) ]  
MC68HC711E9CFN3@PLCC52 [ (SA647-B5202) ]  
MC68HC711E9CFNE2@PLCC52 [ (SA647-B5202) ]  
MC68HC711E9CFNE3@PLCC52 [ (SA647-B5202) ]  
MC68HC711E9-FN@PLCC52(\*) [ (SA647-B5202) ]  
MC68HC711K4@PLCC84 [ (PEP+S416T) ]  
MC68HC711K4@TQFP80(\*) [ (TA031-B006) ]  
MC68HC711KA2@PLCC68 [ (PEP+S414T) ]  
MC68HC711KA4@PLCC68 [ (PEP+S414T) ]  
MC68HC711KS2@PLCC68 [ (PEP+S414T) ]  
MC68HC711L6@TQFP64 [ (SA668+B188) ]  
MC68HC711P2@PLCC84(\*) [ (SA649-B8405) ]  
MC68HC811E2@PLCC52 [ (PEP+S415T) ]  
MC68HC811E2CP2  
MC68HC811E2MP2  
MC68HC811E2P2  
MC68HC811E2VP2  
MC68HC812A4CPV@TQFP112(\*) [ (SA719+B210) ]  
MC68HC812A4CPVE@TQFP112(\*) [ (SA719+B210) ]  
MC68HC812A4MPV@TQFP112(\*) [ (SA719+B210) ]  
MC68HC812A4MPVE@TQFP112(\*) [ (SA719+B210) ]  
MC68HC908AB32CFU@TQFP64(\*) [ (TA011-B006) ]  
MC68HC908AB32MFU@TQFP64(\*) [ (TA011-B006) ]  
MC68HC908AP16CB(S)@SDIP42 [ (SA028) ]  
MC68HC908AP16CB@SDIP42 [ (SA028) ]  
MC68HC908AP16CFA(S)@LQFP48 [ (SA248) ]  
MC68HC908AP16CFA@LQFP48 [ (SA248) ]  
MC68HC908AP16CFB(S)@TQFP44 [ (SA675) ]  
MC68HC908AP16CFB@TQFP44 [ (SA675) ]  
MC68HC908AP32CB(S)@SDIP42 [ (SA028) ]  
MC68HC908AP32CB@SDIP42 [ (SA028) ]  
MC68HC908AP32CFA(S)@LQFP48 [ (SA248) ]  
MC68HC908AP32CFA@LQFP48 [ (SA248) ]  
MC68HC908AP32CFB(S)@TQFP44 [ (SA675) ]  
MC68HC908AP32CFB@TQFP44 [ (SA675) ]  
MC68HC908AP64CB@SDIP42 [ (SA028) ]

MC68HC908AP64CFA@LQFP48 [(SA248)]  
MC68HC908AP64CFB@TQFP44 [(SA675)]  
MC68HC908AP8CB(S)@SDIP42 [(SA028)]  
MC68HC908AP8CB@SDIP42 [(SA028)]  
MC68HC908AP8CFA(S)@@LQFP48 [(SA248)]  
MC68HC908AP8CFA@@LQFP48 [(SA248)]  
MC68HC908AP8CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP8CFB@TQFP44 [(SA675)]  
MC68HC908AS32A(CFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS32A(MFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS32A(VFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS60(CFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS60(CFU)@TQFP64 [(TA011-B006)]  
MC68HC908AS60(MFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS60(MFU)@TQFP64 [(TA011-B006)]  
MC68HC908AS60(VFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS60(VFU)@TQFP64 [(TA011-B006)]  
MC68HC908AS60A(CFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS60A(CFU)@TQFP64 [(TA011-B006)]  
MC68HC908AS60A(MFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS60A(MFU)@TQFP64 [(TA011-B006)]  
MC68HC908AS60A(VFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS60A(VFU)@TQFP64 [(TA011-B006)]  
MC68HC908AZ32A(CFU)@TQFP64 [(TA011-B006)]  
MC68HC908AZ32A(MFU)@TQFP64 [(TA011-B006)]  
MC68HC908AZ32A(VFU)@TQFP64 [(TA011-B006)]  
MC68HC908AZ60(CFU)@TQFP64 [(TA011-B006)]  
MC68HC908AZ60(MFU)@TQFP64 [(TA011-B006)]  
MC68HC908AZ60(VFU)@TQFP64 [(TA011-B006)]  
MC68HC908AZ60A(CFU)@TQFP64 [(TA011-B006)]  
MC68HC908AZ60A(MFU)@TQFP64 [(TA011-B006)]  
MC68HC908AZ60A(VFU)@TQFP64 [(TA011-B006)]  
MC68HC908BD48IB@SDIP42 [(SA028)]  
MC68HC908BD48IFB@TQFP44 [(SA675)]  
MC68HC908EY16CFA@TQFP32 [(SA663)]  
MC68HC908EY16MFA@TQFP32 [(SA663)]  
MC68HC908EY16VFA@TQFP32 [(SA663)]  
MC68HC908EY8CFA@TQFP32 [(SA663)]      MC68HC908EY8MFA@TQFP32  
[(SA663)]  
MC68HC908EY8VFA@TQFP32 [(SA663)]  
MC68HC908GP32  
MC68HC908GP32@SDIP42 [(SA028)]      MC68HC908GP32@TQFP44  
[(SA675)]

MC68HC908GR16CFA@TQFP48 [(SA248)]	
MC68HC908GR16CFJ@TQFP32 [(SA663)]	
MC68HC908GR16MFA@TQFP48 [(SA248)]	
MC68HC908GR16MFJ@TQFP32 [(SA663)]	
MC68HC908GR16VFA@TQFP48 [(SA248)]	
MC68HC908GR16VFJ@TQFP32 [(SA663)]	
MC68HC908GR4CDW@SOIC28 [(SA404)]	MC68HC908GR4CFA@TQFP32
[(SA663)]	
MC68HC908GR4CP	MC68HC908GR4MDW@SOIC28
[(SA404)]	
MC68HC908GR4MFA@TQFP32 [(SA663)]	
MC68HC908GR4MP	
MC68HC908GR4VDW@SOIC28 [(SA404)]	MC68HC908GR4VFA@TQFP32
[(SA663)]	
MC68HC908GR4VP	MC68HC908GR8CDW@SOIC28
[(SA404)]	
MC68HC908GR8CFA@TQFP32 [(SA663)]	
MC68HC908GR8CP	
MC68HC908GR8MDW@SOIC28 [(SA404)]	MC68HC908GR8MFA@TQFP32
[(SA663)]	
MC68HC908GR8MP	MC68HC908GR8VDW@SOIC28
[(SA404)]	
MC68HC908GR8VFA@TQFP32 [(SA663)]	
MC68HC908GR8VP	
MC68HC908GT16@SDIP42 [(SA028)]	MC68HC908GT16@TQFP44
[(SA675)]	
MC68HC908GT8CB@SDIP42 [(SA028)]	MC68HC908GT8CFB@TQFP44
[(SA675)]	
MC68HC908GZ16(CFA)@TQFP48 [(SA248)]	
MC68HC908GZ16(CFJ)@TQFP32 [(SA663)]	
MC68HC908GZ16(MFA)@TQFP48 [(SA248)]	
MC68HC908GZ16(MFJ)@TQFP32 [(SA663)]	
MC68HC908GZ16(VFA)@TQFP48 [(SA248)]	
MC68HC908GZ16(VFJ)@TQFP32 [(SA663)]	
MC68HC908GZ32(CFA)@TQFP48 [(SA248)]	
MC68HC908GZ32(CFJ)@TQFP32 [(SA663)]	
MC68HC908GZ32(MFA)@TQFP48 [(SA248)]	
MC68HC908GZ32(MFJ)@TQFP32 [(SA663)]	
MC68HC908GZ32(VFA)@TQFP48 [(SA248)]	
MC68HC908GZ32(VFJ)@TQFP32 [(SA663)]	
MC68HC908GZ48(CFA)@TQFP48 [(SA248)]	
MC68HC908GZ48(CFJ)@TQFP32 [(SA663)]	
MC68HC908GZ48(MFA)@TQFP48 [(SA248)]	

MC68HC908GZ48(MFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ48(VFA)@TQFP48 [(SA248)]  
 MC68HC908GZ48(VFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ60(CFA)@TQFP48 [(SA248)]  
 MC68HC908GZ60(CFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ60(MFA)@TQFP48 [(SA248)]  
 MC68HC908GZ60(MFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ60(VFA)@TQFP48 [(SA248)]  
 MC68HC908GZ60(VFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ8(CFA)@TQFP48 [(SA248)]  
 MC68HC908GZ8(CFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ8(MFA)@TQFP48 [(SA248)]  
 MC68HC908GZ8(MFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ8(VFA)@TQFP48 [(SA248)]  
 MC68HC908GZ8(VFJ)@TQFP32 [(SA663)]  
 MC68HC908JB12(DW)@SOIC28 [(SA404)]  
 MC68HC908JB12(JDW)@SOIC20 [(SA404)]  
 MC68HC908JB16(DW)@SOIC28 [(SA404)]  
 MC68HC908JB16(FA)@QFP32 [(SA663)]  
 MC68HC908JB16(JDW)@SOIC20 [(SA404)]  
 MC68HC908JB8  
 [(SA404)]  
 MC68HC908JB8@SOIC28 [(SA404)]  
 [(SA675)]  
 MC68HC908JK1CDW@SOIC20 [(SA404)]  
 MC68HC908JK1CP  
 MC68HC908JK1ECDW@SOIC20 [(SA404)]  
 MC68HC908JK1ECP  
 MC68HC908JK1EMDW@SOIC20 [(SA404)]  
 MC68HC908JK1EMP  
 [(SA404)]  
 MC68HC908JK1MP  
 [(SA404)]  
 MC68HC908JK3CP  
 MC68HC908JK3ECDW@SOIC20 [(SA404)]  
 MC68HC908JK3ECP  
 MC68HC908JK3EMDW@SOIC20 [(SA404)]  
 MC68HC908JK3EMP  
 [(SA404)]  
 MC68HC908JK3MP  
 MC68HC908JK8  
 MC68HC908JK8@SOIC20 [(SA404)]  
 [(SA404)]

MC68HC908JB8@SOIC20  
 MC68HC908JB8@TQFP44  
 MC68HC908JK1MDW@SOIC20  
 MC68HC908JK3CDW@SOIC20  
 MC68HC908JK3MDW@SOIC20  
 MC68HC908JL3CDW@SOIC28

MC68HC908JL3CFA@TQFP48 [ ( SA248 ) ]  
MC68HC908JL3CP  
MC68HC908JL3ECDW@SOIC28 [ ( SA404 ) ]  
MC68HC908JL3ECFA@TQFP48 [ ( SA248 ) ]  
MC68HC908JL3ECP  
MC68HC908JL3EMDW@SOIC28 [ ( SA404 ) ]  
MC68HC908JL3EMFA@TQFP48 [ ( SA248 ) ]  
MC68HC908JL3EMP  
[ ( SA404 ) ]  
MC68HC908JL3MFA@TQFP48 [ ( SA248 ) ]  
MC68HC908JL3MP  
MC68HC908JL8 ( dip20 )  
( dip28 )  
MC68HC908JL8@LQFP32 [ ( SA663 ) ]  
[ ( SA653 ) ]  
MC68HC908JL8@SOIC20 [ ( SA404 ) ]  
[ ( SA404 ) ]  
MC68HC908KX2 ( CDW ) @SOIC16 [ ( SA404 ) ]  
MC68HC908KX2 ( CP )  
MC68HC908KX2 ( MDW ) @SOIC16 [ ( SA404 ) ]  
MC68HC908KX2 ( MP )  
MC68HC908KX2 ( VDW ) @SOIC16 [ ( SA404 ) ]  
MC68HC908KX2 ( VP )  
MC68HC908KX8 ( CDW ) @SOIC16 [ ( SA404 ) ]  
MC68HC908KX8 ( CP )  
MC68HC908KX8 ( MDW ) @SOIC16 [ ( SA404 ) ]  
MC68HC908KX8 ( MP )  
MC68HC908KX8 ( VDW ) @SOIC16 [ ( SA404 ) ]  
MC68HC908KX8 ( VP )  
@SOIC20  
MC68HC908LB8CDWE@SOIC20 [ ( SA404 ) ]  
MC68HC908LB8CPE  
( S )  
MC68HC908LB8MDWE ( S ) @SOIC20  
MC68HC908LB8MDWE@SOIC20 [ ( SA404 ) ]  
MC68HC908LB8MPE  
( S )  
MC68HC908LB8VDWE ( S ) @SOIC20  
MC68HC908LB8VDWE@SOIC20 [ ( SA404 ) ]  
MC68HC908LB8VPE  
( S )  
MC68HC908LD60IFU@QFP64 [ ( PEP+S625 ) ]  
MC68HC908LD64IFU@QFP64 [ ( PEP+S625 ) ]

MC68HC908JL3MDW@SOIC28

MC68HC908JL8

MC68HC908JL8@SDIP32

MC68HC908JL8@SOIC28

MC68HC908LB8CDWE ( S )

MC68HC908LB8CPE

MC68HC908LB8MPE

MC68HC908LB8VPE

MC68HC908LJ12CFB@TQFP52 [(PEP-S673)]  
MC68HC908LJ12CFBE@TQFP52 [(PEP-S673)]  
MC68HC908LJ12CFU@TQFP64 [(PEP-S625A)]  
MC68HC908LJ12CFU@TQFP64(\*) [(SA757-B331)]  
MC68HC908LJ12CFUE@TQFP64 [(PEP-S625A)]  
MC68HC908LJ12CFUE@TQFP64(\*) [(SA757-B331)]  
MC68HC908LJ12CPB@TQFP64 [(PEP-S616)]  
MC68HC908LJ12CPBE@TQFP64 [(PEP-S616)]  
MC68HC908LJ24CFQ@TQFP80 [(PEP-S615B)]  
MC68HC908LJ24CFQE@TQFP80 [(PEP-S615B)]  
MC68HC908LJ24CFU@TQFP64 [(PEP-S625A)]  
MC68HC908LJ24CFU@TQFP64(\*) [(SA757-B331)]  
MC68HC908LJ24CFUE@TQFP64 [(PEP-S625A)]  
MC68HC908LJ24CFUE@TQFP64(\*) [(SA757-B331)]  
MC68HC908LJ24CPB@TQFP64 [(PEP-S616)]  
MC68HC908LJ24CPBE@TQFP64 [(PEP-S616)]  
MC68HC908LJ24CPK@TQFP80 [(PEP-S640B)]  
MC68HC908LJ24CPKE@TQFP80 [(PEP-S640B)]  
MC68HC908LK24CFQ@TQFP80 [(PEP-S615B)]  
MC68HC908LK24CFQE@TQFP80 [(PEP-S615B)]  
MC68HC908LK24CFU@TQFP64 [(PEP-S625A)]  
MC68HC908LK24CFU@TQFP64(\*) [(SA757-B331)]  
MC68HC908LK24CFUE@TQFP64 [(PEP-S625A)]  
MC68HC908LK24CFUE@TQFP64(\*) [(SA757-B331)]  
MC68HC908LK24CPB@TQFP64 [(PEP-S616)]  
MC68HC908LK24CPBE@TQFP64 [(PEP-S616)]  
MC68HC908LK24CPK@TQFP80 [(PEP-S640B)]  
MC68HC908LK24CPKE@TQFP80 [(PEP-S640B)]  
MC68HC908LV8CPBE@TQFP52 [(PEP+S673)]  
MC68HC908MR16(CB)@SDIP56 [(PEP+S627)]  
MC68HC908MR16(CFU)@TQFP64 [(PEP+S625A)]  
MC68HC908MR16(VB)@SDIP56 [(PEP+S627)]  
MC68HC908MR16(VFU)@TQFP64 [(PEP+S625A)]  
MC68HC908MR32(CB)@SDIP56 [(PEP+S627)]  
MC68HC908MR32(CFU)@TQFP64 [(PEP+S625A)]  
MC68HC908MR32(VB)@SDIP56 [(PEP+S627)]  
MC68HC908MR32(VFU)@TQFP64 [(PEP+S625A)]  
MC68HC908QB4(CDT)@TSSOP16 [(SA026)]  
MC68HC908QB4(CDW)@SOIC16 [(SA404)]  
MC68HC908QB4(CP)  
MC68HC908QB4(MDT)@TSSOP16 [(SA026)]  
MC68HC908QB4(MDW)@SOIC16 [(SA404)]  
MC68HC908QB4(MP)



MC68HC908QB4 (VDT)@TSSOP16 [(SA026)]  
MC68HC908QB4 (VDW)@SOIC16 [(SA404)]  
MC68HC908QB4 (VP)  
MC68HC908QB8 (CDT)@TSSOP16 [(SA026)]  
MC68HC908QB8 (CDW)@SOIC16 [(SA404)]  
MC68HC908QB8 (CP)  
MC68HC908QB8 (MDT)@TSSOP16 [(SA026)]  
MC68HC908QB8 (MDW)@SOIC16 [(SA404)]  
MC68HC908QB8 (MP)  
MC68HC908QB8 (VDT)@TSSOP16 [(SA026)]  
MC68HC908QB8 (VDW)@SOIC16 [(SA404)]  
MC68HC908QB8 (VP)  
MC68HC908QC16 (CDR)@TSSOP28 [(SA643)]  
MC68HC908QC16 (CDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16 (CDS)@TSSOP20 [(SA643)]  
MC68HC908QC16 (CDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QC16 (CDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16 (CDX)@SOIC16 [(SA404)]  
MC68HC908QC16 (CDXE)@SOIC16 [(SA404)]  
MC68HC908QC16 (CDY)@SOIC20 [(SA404)]  
MC68HC908QC16 (CDYE)@SOIC20 [(SA404)]  
MC68HC908QC16 (CDZ)@SOIC28 [(SA404)]  
MC68HC908QC16 (CDZE)@SOIC28 [(SA404)]  
MC68HC908QC16 (MDR)@TSSOP28 [(SA643)]  
MC68HC908QC16 (MDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16 (MDS)@TSSOP20 [(SA643)]  
MC68HC908QC16 (MDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QC16 (MDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16 (MDX)@SOIC16 [(SA404)]  
MC68HC908QC16 (MDXE)@SOIC16 [(SA404)]  
MC68HC908QC16 (MDY)@SOIC20 [(SA404)]  
MC68HC908QC16 (MDYE)@SOIC20 [(SA404)]  
MC68HC908QC16 (MDZ)@SOIC28 [(SA404)]  
MC68HC908QC16 (MDZE)@SOIC28 [(SA404)]  
MC68HC908QC16 (VDR)@TSSOP28 [(SA643)]  
MC68HC908QC16 (VDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16 (VDS)@TSSOP20 [(SA643)]  
MC68HC908QC16 (VDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QC16 (VDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16 (VDX)@SOIC16 [(SA404)]

MC68HC908QC16(VDXE)@SOIC16 [(SA404)]  
MC68HC908QC16(VDY)@SOIC20 [(SA404)]  
MC68HC908QC16(VDYE)@SOIC20 [(SA404)]  
MC68HC908QC16(VDZ)@SOIC28 [(SA404)]  
MC68HC908QC16(VDZE)@SOIC28 [(SA404)]  
MC68HC908QC4(CDR)@TSSOP28 [(SA643)]  
MC68HC908QC4(CDRE)@TSSOP28 [(SA643)]  
MC68HC908QC4(CDS)@TSSOP20 [(SA643)]  
MC68HC908QC4(CDSE)@TSSOP20 [(SA643)]  
MC68HC908QC4(CDT)@TSSOP16 [(SA643)]  
MC68HC908QC4(CDTE)@TSSOP16 [(SA643)]  
MC68HC908QC4(CDX)@SOIC16 [(SA404)]  
MC68HC908QC4(CDXE)@SOIC16 [(SA404)]  
MC68HC908QC4(CDY)@SOIC20 [(SA404)]  
MC68HC908QC4(CDYE)@SOIC20 [(SA404)]  
MC68HC908QC4(CDZ)@SOIC28 [(SA404)]  
MC68HC908QC4(CDZE)@SOIC28 [(SA404)]  
MC68HC908QC4(MDR)@TSSOP28 [(SA643)]  
MC68HC908QC4(MDRE)@TSSOP28 [(SA643)]  
MC68HC908QC4(MDS)@TSSOP20 [(SA643)]  
MC68HC908QC4(MDSE)@TSSOP20 [(SA643)]  
MC68HC908QC4(MDT)@TSSOP16 [(SA643)]  
MC68HC908QC4(MDTE)@TSSOP16 [(SA643)]  
MC68HC908QC4(MDX)@SOIC16 [(SA404)]  
MC68HC908QC4(MDXE)@SOIC16 [(SA404)]  
MC68HC908QC4(MDY)@SOIC20 [(SA404)]  
MC68HC908QC4(MDYE)@SOIC20 [(SA404)]  
MC68HC908QC4(MDZ)@SOIC28 [(SA404)]  
MC68HC908QC4(MDZE)@SOIC28 [(SA404)]  
MC68HC908QC4(VDR)@TSSOP28 [(SA643)]  
MC68HC908QC4(VDRE)@TSSOP28 [(SA643)]  
MC68HC908QC4(VDS)@TSSOP20 [(SA643)]  
MC68HC908QC4(VDSE)@TSSOP20 [(SA643)]  
MC68HC908QC4(VDT)@TSSOP16 [(SA643)]  
MC68HC908QC4(VDTE)@TSSOP16 [(SA643)]  
MC68HC908QC4(VDX)@SOIC16 [(SA404)]  
MC68HC908QC4(VDXE)@SOIC16 [(SA404)]  
MC68HC908QC4(VDY)@SOIC20 [(SA404)]  
MC68HC908QC4(VDYE)@SOIC20 [(SA404)]  
MC68HC908QC4(VDZ)@SOIC28 [(SA404)]  
MC68HC908QC4(VDZE)@SOIC28 [(SA404)]  
MC68HC908QC8(CDR)@TSSOP28 [(SA643)]  
MC68HC908QC8(CDRE)@TSSOP28 [(SA643)]

MC68HC908QC8 (CDS)@TSSOP20 [(SA643)]  
MC68HC908QC8 (CDSE)@TSSOP20 [(SA643)]  
MC68HC908QC8 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QC8 (CDTE)@TSSOP16 [(SA643)]  
MC68HC908QC8 (CDX)@SOIC16 [(SA404)]  
MC68HC908QC8 (CDXE)@SOIC16 [(SA404)]  
MC68HC908QC8 (CDY)@SOIC20 [(SA404)]  
MC68HC908QC8 (CDYE)@SOIC20 [(SA404)]  
MC68HC908QC8 (CDZ)@SOIC28 [(SA404)]  
MC68HC908QC8 (CDZE)@SOIC28 [(SA404)]  
MC68HC908QC8 (MDR)@TSSOP28 [(SA643)]  
MC68HC908QC8 (MDRE)@TSSOP28 [(SA643)]  
MC68HC908QC8 (MDS)@TSSOP20 [(SA643)]  
MC68HC908QC8 (MDSE)@TSSOP20 [(SA643)]  
MC68HC908QC8 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QC8 (MDTE)@TSSOP16 [(SA643)]  
MC68HC908QC8 (MDX)@SOIC16 [(SA404)]  
MC68HC908QC8 (MDXE)@SOIC16 [(SA404)]  
MC68HC908QC8 (MDY)@SOIC20 [(SA404)]  
MC68HC908QC8 (MDYE)@SOIC20 [(SA404)]  
MC68HC908QC8 (MDZ)@SOIC28 [(SA404)]  
MC68HC908QC8 (MDZE)@SOIC28 [(SA404)]  
MC68HC908QC8 (VDR)@TSSOP28 [(SA643)]  
MC68HC908QC8 (VDRE)@TSSOP28 [(SA643)]  
MC68HC908QC8 (VDS)@TSSOP20 [(SA643)]  
MC68HC908QC8 (VDSE)@TSSOP20 [(SA643)]  
MC68HC908QC8 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QC8 (VDTE)@TSSOP16 [(SA643)]  
MC68HC908QC8 (VDX)@SOIC16 [(SA404)]  
MC68HC908QC8 (VDXE)@SOIC16 [(SA404)]  
MC68HC908QC8 (VDY)@SOIC20 [(SA404)]  
MC68HC908QC8 (VDYE)@SOIC20 [(SA404)]  
MC68HC908QC8 (VDZ)@SOIC28 [(SA404)]  
MC68HC908QC8 (VDZE)@SOIC28 [(SA404)]  
MC68HC908QF4 (CFJ)@TQFP32 [(SA663)]  
MC68HC908QF4 (FJ)@TQFP32 [(SA663)]  
MC68HC908QL2 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QL2 (CDW)@SOIC16 [(SA404)]  
MC68HC908QL2 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QL2 (MDW)@SOIC16 [(SA404)]  
MC68HC908QL2 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QL2 (VDW)@SOIC16 [(SA404)]  
MC68HC908QL3 (CDT)@TSSOP16 [(SA643)]

MC68HC908QL3(CDW)@SOIC16 [(SA404)]  
MC68HC908QL3(MDT)@TSSOP16 [(SA643)]  
MC68HC908QL3(MDW)@SOIC16 [(SA404)]  
MC68HC908QL3(VDT)@TSSOP16 [(SA643)]  
MC68HC908QL3(VDW)@SOIC16 [(SA404)]  
MC68HC908QL4(CDT)@TSSOP16 [(SA643)]  
MC68HC908QL4(CDW)@SOIC16 [(SA404)]  
MC68HC908QL4(MDT)@TSSOP16 [(SA643)]  
MC68HC908QL4(MDW)@SOIC16 [(SA404)]  
MC68HC908QL4(VDT)@TSSOP16 [(SA643)]  
MC68HC908QL4(VDW)@SOIC16 [(SA404)]  
MC68HC908QT1CDW@SOIC8 [(SA605A)]  
MC68HC908QT1CP  
MC68HC908QT1MDW@SOIC8 [(SA605A)]  
MC68HC908QT1MP  
MC68HC908QT1VDW@SOIC8 [(SA605A)]  
MC68HC908QT1VP  
MC68HC908QT2CDW@SOIC8 [(SA605A)]  
MC68HC908QT2CP  
MC68HC908QT2MDW@SOIC8 [(SA605A)]  
MC68HC908QT2MP  
MC68HC908QT2VDW@SOIC8 [(SA605A)]  
MC68HC908QT2VP  
MC68HC908QT4CDW@SOIC8 [(SA605A)]  
MC68HC908QT4CP  
MC68HC908QT4MDW@SOIC8 [(SA605A)]  
MC68HC908QT4MP  
MC68HC908QT4VDW@SOIC8 [(SA605A)]  
MC68HC908QT4VP  
MC68HC908QY1CDT@TSSOP16 [(SA026)]  
MC68HC908QY1CDW@SOIC16 [(SA404)]  
MC68HC908QY1CP  
MC68HC908QY1MDT@TSSOP16 [(SA026)]  
MC68HC908QY1MDW@SOIC16 [(SA404)]  
MC68HC908QY1MP  
MC68HC908QY1VDT@TSSOP16 [(SA026)]  
MC68HC908QY1VDW@SOIC16 [(SA404)]  
MC68HC908QY1VP  
MC68HC908QY2CDT@TSSOP16 [(SA026)]  
MC68HC908QY2CDW@SOIC16 [(SA404)]  
MC68HC908QY2CP  
MC68HC908QY2MDT@TSSOP16 [(SA026)]  
MC68HC908QY2MDW@SOIC16 [(SA404)]

MC68HC908QY2MP  
MC68HC908QY2VDT@TSSOP16 [(SA026)]  
MC68HC908QY2VDW@SOIC16 [(SA404)]  
MC68HC908QY2VP  
MC68HC908QY4CDT@TSSOP16 [(SA026)]  
MC68HC908QY4CDW@SOIC16 [(SA404)]  
MC68HC908QY4CP  
MC68HC908QY4MDT@TSSOP16 [(SA026)]  
MC68HC908QY4MDW@SOIC16 [(SA404)]  
MC68HC908QY4MP  
MC68HC908QY4VDT@TSSOP16 [(SA026)]  
MC68HC908QY4VDW@SOIC16 [(SA404)]  
MC68HC908QY4VP  
MC68HC908QY8(CDT)@TSSOP16 [(SA026)]  
MC68HC908QY8(CDW)@SOIC16 [(SA404)]  
MC68HC908QY8(CP)  
MC68HC908QY8(MDT)@TSSOP16 [(SA026)]  
MC68HC908QY8(MDW)@SOIC16 [(SA404)]  
MC68HC908QY8(MP)  
MC68HC908QY8(VDT)@TSSOP16 [(SA026)]  
MC68HC908QY8(VDW)@SOIC16 [(SA404)]  
MC68HC908QY8(VP)  
MC68HC908RF2(CFA)@TQFP32 [(SA663)]  
MC68HC908RF2(MFA)@TQFP32 [(SA663)]  
MC68HC908SR12(CB)@SDIP42 [(SA028)]  
MC68HC908SR12(CFA)@TQFP48 [(SA248)]  
MC68HC908SR12(MB)@SDIP42 [(SA028)]  
MC68HC908SR12(MFA)@TQFP48 [(SA248)]  
MC68HC912B32(CFU8)@TQFP80 [(TA045-B006)]  
MC68HC912B32(MFU8)@TQFP80 [(TA045-B006)]  
MC68HC912B32(VFU8)@TQFP80 [(TA045-B006)]  
MC68HC912BC32(CFU8)@TQFP80 [(TA045-B006)]  
MC68HC912BC32(MFU8)@TQFP80 [(TA045-B006)]  
MC68HC912BC32(VFU8)@TQFP80 [(TA045-B006)]  
MC68HCP11E1@PLCC52 [(PEP+S415T)]  
MC68HCP11E1@PLCC52(\*) [(SA647-B5202)]  
MC68HRC908JK1CDW@SOIC20 [(SA404)]  
MC68HRC908JK1CP  
MC68HRC908JK1ECDW@SOIC20 [(SA404)]  
MC68HRC908JK1ECP  
MC68HRC908JK1EMDW@SOIC20 [(SA404)]  
MC68HRC908JK1EMP  
MC68HRC908JK1MDW@SOIC20 [(SA404)]

MC68HRC908JK1MP  
 MC68HRC908JK3CDW@SOIC20 [(SA404)]  
 MC68HRC908JK3CP  
 MC68HRC908JK3ECDW@SOIC20 [(SA404)]  
 MC68HRC908JK3ECP  
 MC68HRC908JK3EMDW@SOIC20 [(SA404)]  
 MC68HRC908JK3EMP  
 MC68HRC908JK3MDW@SOIC20 [(SA404)]  
 MC68HRC908JK3MP  
 MC68HRC908JK8  
 MC68HRC908JK8@SOIC20 [(SA404)]  
 MC68HRC908JL3CDW@SOIC28 [(SA404)]  
 MC68HRC908JL3CFA@TQFP48 [(SA248)]  
 MC68HRC908JL3CP  
 MC68HRC908JL3ECDW@SOIC28 [(SA404)]  
 MC68HRC908JL3ECFA@TQFP48 [(SA248)]  
 MC68HRC908JL3ECP  
 MC68HRC908JL3EMDW@SOIC28 [(SA404)]  
 MC68HRC908JL3EMFA@TQFP48 [(SA248)]  
 MC68HRC908JL3EMP  
 MC68HRC908JL3MDW@SOIC28 [(SA404)]  
 MC68HRC908JL3MFA@TQFP48 [(SA248)]  
 MC68HRC908JL3MP  
 (dip20)  
 MC68HRC908JL8(dip28)  
 [(SA663)]  
 MC68HRC908JL8@SDIP32 [(SA653)]  
 [(SA404)]  
 MC68HRC908JL8@SOIC28 [(SA404)]  
 MC68HSC705C8A  
 MC68HSC705C8A@PLCC44 [(SA244)]  
 [SA028]  
 MC68HSC705C8A@TQFP44 [(SA245A)]  
 MC68S711E9@PLCC52(\*) [(SA647-B5202)]  
 MC68S711E9-FN@PLCC52(\*) [(SA647-B5202)]  
 MC908AB32CFUE@TQFP64(\*) [(TA011-B006)]  
 MC908AB32MFUE@TQFP64(\*) [(TA011-B006)]  
 MC908AP16CBE@SDIP42 [(SA028)]  
 [(SA248)]  
 MC908AP16CFBE@TQFP44 [(SA675)]  
 [(SA028)]  
 MC908AP32CFAE@LQFP48 [(SA248)]  
 [(SA675)]

MC68HRC908JL8

MC68HRC908JL8@LQFP32

MC68HRC908JL8@SOIC20

MC68HSC705C8A@SDIP42

MC908AP16CFAE@LQFP48

MC908AP32CBE@SDIP42

MC908AP32CFBE@TQFP44

MC908AP64CBE@SDIP42 [(SA028)]	MC908AP64CFAE@LQFP48
[(SA248)]	
MC908AP64CFBE@TQFP44 [(SA675)]	MC908AP8CBE@SDIP42
[(SA028)]	
MC908AP8CFAE@@LQFP48 [(SA248)]	MC908AP8CFBE@TQFP44
[(SA675)]	
MC908BD48IBE@SDIP42 [(SA028)]	MC908BD48IFBE@TQFP44
[(SA675)]	
MC908EY16ACFJE@TQFP32 [(SA663)]	MC908EY16AKFJE@TQFP32
[(SA663)]	
MC908EY16AMFJE@TQFP32 [(SA663)]	MC908EY16AVFJE@TQFP32
[(SA663)]	
MC908EY8ACFJE@TQFP32 [(SA663)]	MC908EY8AKFJE@TQFP32
[(SA663)]	
MC908EY8AMFJE@TQFP32 [(SA663)]	MC908EY8AVFJE@TQFP32
[(SA663)]	
MC908JL16CDWE@SOIC28 [(SA404)]	MC908JL16CFJE@LQFP32
[(SA663)]	
MC908JL16CPE	MC908JL16CSPE@SDIP32
[(SA653)]	
MC908QT1ACDWE@SOIC8 [(SA605A)]	
MC908QT1ACPE	
MC908QT1AMDWE@SOIC8 [(SA605A)]	
MC908QT1AMPE	
MC908QT1AVDWE@SOIC8 [(SA605A)]	
MC908QT1AVPE	
MC908QT2ACDWE@SOIC8 [(SA605A)]	
MC908QT2ACPE	
MC908QT2AMDWE@SOIC8 [(SA605A)]	
MC908QT2AMPE	
MC908QT2AVDWE@SOIC8 [(SA605A)]	
MC908QT2AVPE	
MC908QT4ACDWE@SOIC8 [(SA605A)]	
MC908QT4ACPE	
MC908QT4AMDWE@SOIC8 [(SA605A)]	
MC908QT4AMPE	
MC908QT4AVDWE@SOIC8 [(SA605A)]	
MC908QT4AVPE	
MC908QY1ACDTE@TSSOP16 [(SA026)]	MC908QY1ACDWE@SOIC16
[(SA404)]	
MC908QY1ACPE	MC908QY1AMDTE@TSSOP16
[(SA026)]	
MC908QY1AMDWE@SOIC16 [(SA404)]	

MC908QY1AMPE  
MC908QY1AVDTE@TSSOP16 [(SA026)] MC908QY1AVDWE@SOIC16  
[(SA404)]  
MC908QY1AVPE MC908QY2ACDTE@TSSOP16  
[(SA026)]  
MC908QY2ACDWE@SOIC16 [(SA404)]  
MC908QY2ACPE  
MC908QY2AMDTE@TSSOP16 [(SA026)] MC908QY2AMDWE@SOIC16  
[(SA404)]  
MC908QY2AMPE MC908QY2AVDTE@TSSOP16  
[(SA026)]  
MC908QY2AVDWE@SOIC16 [(SA404)]  
MC908QY2AVPE  
MC908QY4ACDTE@TSSOP16 [(SA026)] MC908QY4ACDWE@SOIC16  
[(SA404)]  
MC908QY4ACPE MC908QY4AMDTE@TSSOP16  
[(SA026)]  
MC908QY4AMDWE@SOIC16 [(SA404)]  
MC908QY4AMPE  
MC908QY4AVDTE@TSSOP16 [(SA026)] MC908QY4AVDWE@SOIC16  
[(SA404)]  
MC908QY4AVPE  
MC912D60ACFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60ACPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60AMFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60AMPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60AVFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60AVPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60CCFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60CCPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60CMFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60CMPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60CVFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60CVPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60PCFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60PCPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60PMFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60PMPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60PVFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60PVPV8@TQFP112(\*) [(TA035+B084)]  
MC912DG128ACPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128AMPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128AVPV@TQFP112(\*) [(TA035+B084)]



MC912DG128CCPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128CMPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128CVPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128PCPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128PMPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128PVPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128ACPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128AMPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128AVPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128CCPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128CMPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128CVPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128PCPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128PMPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128PVPV@TQFP112(\*) [(TA035+B084)]  
MC9RS08KA1CPC [(SA726+B179)]  
MC9RS08KA1CSC@SOIC8 [(SA602A+B179)]  
MC9RS08KA2CPC [(SA726+B179)]  
MC9RS08KA2CSC@SOIC8 [(SA602A+B179)]  
MC9S08AC16CFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC16CFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC16MFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC16MFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC16VFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC16VFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC8CFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC8CFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC8MFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC8MFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC8VFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC8VFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW16CFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW16CFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW16CFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW16CPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW16MFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW16MFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW16MFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW16MPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW32CFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW32CFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW32CFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW32CPUE@QFP64(\*) [(SA732+B196)]

MC9S08AW32MFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW32MFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW32MFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW32MPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW48CFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW48CFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW48CFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW48CPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW48MFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW48MFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW48MFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW48MPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW60CFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW60CFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW60CFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW60CPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW60MFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW60MFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW60MFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW60MPUE@QFP64(\*) [(SA732+B196)]  
MC9S08GB32ACFU@LQFP64 [(TA066-B006)]  
MC9S08GB32ACFUE@LQFP64 [(TA066-B006)]  
MC9S08GB32CFU@LQFP64 [(TA066-B006)]  
MC9S08GB32CFUE@LQFP64 [(TA066-B006)]  
MC9S08GB60ACFU@LQFP64 [(TA066-B006)]  
MC9S08GB60ACFUE@LQFP64 [(TA066-B006)]  
MC9S08GB60CFU@LQFP64 [(TA066-B006)]  
MC9S08GB60CFUE@LQFP64 [(TA066-B006)]  
MC9S08GT16ACB@SDIP42 [(SA028-B167)]  
MC9S08GT16ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT16ACFC@MLF32 [(SA686-B231)]  
MC9S08GT16ACFCE@MLF32 [(SA686-B231)]  
MC9S08GT16ACFD@QFN48 [(SA696-B166)]  
MC9S08GT16AMB@SDIP42 [(SA028-B167)]  
MC9S08GT16AMFB@LQFP44 [(SA675-B168)]  
MC9S08GT16AMFC@MLF32 [(SA686-B231)]  
MC9S08GT16AMFCE@MLF32 [(SA686-B231)]  
MC9S08GT16AMFD@QFN48 [(SA696-B166)]  
MC9S08GT16CB@SDIP42 [(SA028-B167)]  
MC9S08GT16CBE@SDIP42 [(SA028-B167)]  
MC9S08GT16CFB@LQFP44 [(SA675-B168)]  
MC9S08GT16CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT16CFD@QFN48 [(SA696-B166)]

MC9S08GT16CFDE@QFN48 [(SA696-B166)]  
MC9S08GT32ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT32ACFBE@LQFP44 [(SA675-B168)]  
MC9S08GT32ACFD@QFN48 [(SA696-B166)]  
MC9S08GT32ACFDE@QFN48 [(SA696-B166)]  
MC9S08GT32CB@SDIP42 [(SA028-B167)]  
MC9S08GT32CBE@SDIP42 [(SA028-B167)]  
MC9S08GT32CFB@LQFP44 [(SA675-B168)]  
MC9S08GT32CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT32CFD@QFN48 [(SA696-B166)]  
MC9S08GT32CFDE@QFN48 [(SA696-B166)]  
MC9S08GT60ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT60ACFBE@LQFP44 [(SA675-B168)]  
MC9S08GT60ACFD@QFN48 [(SA696-B166)]  
MC9S08GT60ACFDE@QFN48 [(SA696-B166)]  
MC9S08GT60CB@SDIP42 [(SA028-B167)]  
MC9S08GT60CBE@SDIP42 [(SA028-B167)]  
MC9S08GT60CFB@LQFP44 [(SA675-B168)]  
MC9S08GT60CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT60CFD@QFN48 [(SA696-B166)]  
MC9S08GT60CFDE@QFN48 [(SA696-B166)]  
MC9S08GT8ACB@SDIP42 [(SA028-B167)]  
MC9S08GT8ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT8ACFC@MLF32 [(SA686-B231)]  
MC9S08GT8ACFCE@MLF32 [(SA686-B231)]  
MC9S08GT8ACFD@QFN48 [(SA696-B166)]  
MC9S08GT8AMB@SDIP42 [(SA028-B167)]  
MC9S08GT8AMFB@LQFP44 [(SA675-B168)]  
MC9S08GT8AMFC@MLF32 [(SA686-B231)]  
MC9S08GT8AMFCE@MLF32 [(SA686-B231)]  
MC9S08GT8AMFD@QFN48 [(SA696-B166)]  
MC9S08JM32CGTE@QFN48(\*) [(SA696+B310)]  
MC9S08JM32CLDE@QFP44(\*) [(SA245A+B4405)]  
MC9S08JM32CLHE@QFP64(\*) [(SA732+B311)]  
MC9S08JM32CQHE@TQFP64(\*) [(SA668+B311)]  
MC9S08JM60CGTE@QFN48(\*) [(SA696+B310)]  
MC9S08JM60CLDE@QFP44(\*) [(SA245A+B4405)]  
MC9S08JM60CLHE@QFP64(\*) [(SA732+B311)]  
MC9S08JM60CQHE@TQFP64(\*) [(SA668+B311)]  
MC9S08QA2CDN@SOIC8 [(SA602A+B179)]  
MC9S08QA2CDNE@SOIC8 [(SA602A+B179)]  
MC9S08QA2CFQ@DFN8 [(SA744+B248)]  
MC9S08QA2CFQE@DFN8 [(SA744+B248)]

MC9S08QA2CPA  
MC9S08QA2CPAE  
MC9S08QA2MDN@SOIC8 [ (SA602A+B179) ]  
MC9S08QA2MDNE@SOIC8 [ (SA602A+B179) ]  
MC9S08QA2MFQ@DFN8 [ (SA744+B248) ]  
MC9S08QA2MFQE@DFN8 [ (SA744+B248) ]  
MC9S08QA2MPA  
MC9S08QA2MPAE  
MC9S08QA2VDN@SOIC8 [ (SA602A+B179) ]  
MC9S08QA2VDNE@SOIC8 [ (SA602A+B179) ]  
MC9S08QA2VFQ@DFN8 [ (SA744+B248) ]  
MC9S08QA2VFQE@DFN8 [ (SA744+B248) ]  
MC9S08QA2VPA  
MC9S08QA2VPAE  
MC9S08QA4CDN@SOIC8 [ (SA602A+B179) ]  
MC9S08QA4CDNE@SOIC8 [ (SA602A+B179) ]  
MC9S08QA4CFQ@DFN8 [ (SA744+B248) ]  
MC9S08QA4CFQE@DFN8 [ (SA744+B248) ]  
MC9S08QA4CPA  
MC9S08QA4CPAE  
MC9S08QA4MDN@SOIC8 [ (SA602A+B179) ]  
MC9S08QA4MDNE@SOIC8 [ (SA602A+B179) ]  
MC9S08QA4MFQ@DFN8 [ (SA744+B248) ]  
MC9S08QA4MFQE@DFN8 [ (SA744+B248) ]  
MC9S08QA4MPA  
MC9S08QA4MPAE  
MC9S08QA4VDN@SOIC8 [ (SA602A+B179) ]  
MC9S08QA4VDNE@SOIC8 [ (SA602A+B179) ]  
MC9S08QA4VFQ@DFN8 [ (SA744+B248) ]  
MC9S08QA4VFQE@DFN8 [ (SA744+B248) ]  
MC9S08QA4VPA  
MC9S08QA4VPAE  
MC9S08QD2CPC [ (SA726+B179) ]  
MC9S08QD2CSC@SOIC8 [ (SA602A+B179) ]  
MC9S08QD2MPC [ (SA726+B179) ]  
MC9S08QD2MSC@SOIC8 [ (SA602A+B179) ]  
MC9S08QD2VPC [ (SA726+B179) ]  
MC9S08QD2VSC@SOIC8 [ (SA602A+B179) ]  
MC9S08QD4CPC [ (SA726+B179) ]  
MC9S08QD4CSC@SOIC8 [ (SA602A+B179) ]  
MC9S08QD4MPC [ (SA726+B179) ]  
MC9S08QD4MSC@SOIC8 [ (SA602A+B179) ]  
MC9S08QD4VPC [ (SA726+B179) ]

MC9S08QD4VSC@SOIC8 [(SA602A+B179)]	
MC9S08QG4CDNE@SOIC8 [(SA602A+B179)]	
MC9S08QG4CDTE@TSSOP16 [(SA026+B182)]	
MC9S08QG4CFFE@QFN16 [(SA747+B247)]	
MC9S08QG4CFQE@DFN8 [(SA744+B248)]	
MC9S08QG4CPAE [(SA726+B179)]	
MC9S08QG8CDNE@SOIC8 [(SA602A+B179)]	
MC9S08QG8CDTE@TSSOP16 [(SA026+B182)]	
MC9S08QG8CFFE@QFN16 [(SA747+B247)]	
MC9S08QG8CFQE@DFN8 [(SA744+B248)]	
MC9S08QG8CPBE [(SA726+B182)]	MC9S08RC16CFG@LQFP44
[(SA245A)]	
MC9S08RC16CFJ@LQFP32 [(SA663)]	MC9S08RC16FG@LQFP44
[(SA245A)]	
MC9S08RC16FJ@LQFP32 [(SA663)]	MC9S08RC32CFG@LQFP44
[(SA245A)]	
MC9S08RC32CFJ@LQFP32 [(SA663)]	MC9S08RC32FG@LQFP44
[(SA245A)]	
MC9S08RC32FJ@LQFP32 [(SA663)]	MC9S08RC60CFG@LQFP44
[(SA245A)]	
MC9S08RC60CFJ@LQFP32 [(SA663)]	MC9S08RC60FG@LQFP44
[(SA245A)]	
MC9S08RC60FJ@LQFP32 [(SA663)]	MC9S08RC8CFG@LQFP44
[(SA245A)]	
MC9S08RC8CFJ@LQFP32 [(SA663)]	MC9S08RC8FG@LQFP44
[(SA245A)]	
MC9S08RC8FJ@LQFP32 [(SA663)]	MC9S08RD16CDW@SOIC28
[(SA404)]	
MC9S08RD16CFG@LQFP44 [(SA245A)]	MC9S08RD16CFJ@LQFP32
[(SA663)]	
MC9S08RD16CP	MC9S08RD16DW@SOIC28
[(SA404)]	
MC9S08RD16FG@LQFP44 [(SA245A)]	MC9S08RD16FJ@LQFP32
[(SA663)]	
MC9S08RD16P	MC9S08RD32CDW@SOIC28
[(SA404)]	
MC9S08RD32CFG@LQFP44 [(SA245A)]	MC9S08RD32CFJ@LQFP32
[(SA663)]	
MC9S08RD32CP	MC9S08RD32DW@SOIC28
[(SA404)]	
MC9S08RD32FG@LQFP44 [(SA245A)]	MC9S08RD32FJ@LQFP32
[(SA663)]	
MC9S08RD32P	MC9S08RD60CDW@SOIC28

[ ( SA404 ) ]	
MC9S08RD60CFG@LQFP44 [ ( SA245A ) ]	MC9S08RD60CFJ@LQFP32
[ ( SA663 ) ]	
MC9S08RD60CP	MC9S08RD60DW@SOIC28
[ ( SA404 ) ]	
MC9S08RD60FG@LQFP44 [ ( SA245A ) ]	MC9S08RD60FJ@LQFP32
[ ( SA663 ) ]	
MC9S08RD60P	MC9S08RD8CDW@SOIC28
[ ( SA404 ) ]	
MC9S08RD8CFG@LQFP44 [ ( SA245A ) ]	MC9S08RD8CFJ@LQFP32
[ ( SA663 ) ]	
MC9S08RD8CP	MC9S08RD8DW@SOIC28
[ ( SA404 ) ]	
MC9S08RD8FG@LQFP44 [ ( SA245A ) ]	MC9S08RD8FJ@LQFP32
[ ( SA663 ) ]	
MC9S08RD8P	MC9S08RE16CFG@LQFP44
[ ( SA245A ) ]	
MC9S08RE16CFJ@LQFP32 [ ( SA663 ) ]	MC9S08RE16FG@LQFP44
[ ( SA245A ) ]	
MC9S08RE16FJ@LQFP32 [ ( SA663 ) ]	MC9S08RE32CFG@LQFP44
[ ( SA245A ) ]	
MC9S08RE32CFJ@LQFP32 [ ( SA663 ) ]	MC9S08RE32FG@LQFP44
[ ( SA245A ) ]	
MC9S08RE32FJ@LQFP32 [ ( SA663 ) ]	MC9S08RE60CFG@LQFP44
[ ( SA245A ) ]	
MC9S08RE60CFJ@LQFP32 [ ( SA663 ) ]	MC9S08RE60FG@LQFP44
[ ( SA245A ) ]	
MC9S08RE60FJ@LQFP32 [ ( SA663 ) ]	MC9S08RE8CFG@LQFP44
[ ( SA245A ) ]	
MC9S08RE8CFJ@LQFP32 [ ( SA663 ) ]	MC9S08RE8FG@LQFP44
[ ( SA245A ) ]	
MC9S08RE8FJ@LQFP32 [ ( SA663 ) ]	MC9S08RG32CFG@LQFP44
[ ( SA245A ) ]	
MC9S08RG32CFJ@LQFP32 [ ( SA663 ) ]	MC9S08RG32FG@LQFP44
[ ( SA245A ) ]	
MC9S08RG32FJ@LQFP32 [ ( SA663 ) ]	MC9S08RG60CFG@LQFP44
[ ( SA245A ) ]	
MC9S08RG60CFJ@LQFP32 [ ( SA663 ) ]	MC9S08RG60FG@LQFP44
[ ( SA245A ) ]	
MC9S08RG60FJ@LQFP32 [ ( SA663 ) ]	
MC9S08SG4CSC@SOIC8 [ ( SA602A+B179 ) ]	
MC9S08SG4CTG@TSSOP16 [ ( SA026+B182 ) ]	
MC9S08SG4MSC@SOIC8 [ ( SA602A+B179 ) ]	

MC9S08SG4MTG@TSSOP16 [(SA026+B182)]  
MC9S08SG4VSC@SOIC8 [(SA602A+B179)]  
MC9S08SG4VTG@TSSOP16 [(SA026+B182)]  
MC9S08SG8CSC@SOIC8 [(SA602A+B179)]  
MC9S08SG8CTG@TSSOP16 [(SA026+B182)]  
MC9S08SG8MSC@SOIC8 [(SA602A+B179)]  
MC9S08SG8MTG@TSSOP16 [(SA026+B182)]  
MC9S08SG8VSC@SOIC8 [(SA602A+B179)]  
MC9S08SG8VTG@TSSOP16 [(SA026+B182)]  
MC9S08SH4CSC@SOIC8 [(SA602A+B179)]  
MC9S08SH4CTG@TSSOP16 [(SA026+B182)]  
MC9S08SH4MSC@SOIC8 [(SA602A+B179)]  
MC9S08SH4MTG@TSSOP16 [(SA026+B182)]  
MC9S08SH4VSC@SOIC8 [(SA602A+B179)]  
MC9S08SH4VTG@TSSOP16 [(SA026+B182)]  
MC9S08SH8CSC@SOIC8 [(SA602A+B179)]  
MC9S08SH8CTG@TSSOP16 [(SA026+B182)]  
MC9S08SH8MSC@SOIC8 [(SA602A+B179)]  
MC9S08SH8MTG@TSSOP16 [(SA026+B182)]  
MC9S08SH8VSC@SOIC8 [(SA602A+B179)]  
MC9S08SH8VTG@TSSOP16 [(SA026+B182)]  
MC9S12A128BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256MPV@TQFP112(\*) [(TA037-B084)]

MC9S12A256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A64CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A64FU@TQFP80(\*) [(TA015-B006)]  
MC9S12A64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A64MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A64PV@TQFP112(\*) [(TA037-B084)]  
MC9S12A64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A64VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12C128CFA@TQFP48 [(SA248)]  
MC9S12C128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C128CPB@TQFP52 [(PEP+S673)]  
MC9S12C128MFA@TQFP48 [(SA248)]  
MC9S12C128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C128MPB@TQFP52 [(PEP+S673)]  
MC9S12C128VFA@TQFP48 [(SA248)]  
MC9S12C128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C128VPB@TQFP52 [(PEP+S673)]  
MC9S12C32CFA16@TQFP48 [(SA248)] MC9S12C32CFA25@TQFP48  
[(SA248)]  
MC9S12C32CFU16@TQFP80(\*) [(TA015-B006)]  
MC9S12C32CFU25@TQFP80(\*) [(TA015-B006)]  
MC9S12C32CPB16@TQFP52 [(PEP+S673)]  
MC9S12C32CPB25@TQFP52 [(PEP+S673)]  
MC9S12C32MFA16@TQFP48 [(SA248)] MC9S12C32MFA25@TQFP48  
[(SA248)]  
MC9S12C32MFU16@TQFP80(\*) [(TA015-B006)]  
MC9S12C32MFU25@TQFP80(\*) [(TA015-B006)]  
MC9S12C32MPB16@TQFP52 [(PEP+S673)]  
MC9S12C32MPB25@TQFP52 [(PEP+S673)]  
MC9S12C32VFA16@TQFP48 [(SA248)] MC9S12C32VFA25@TQFP48  
[(SA248)]  
MC9S12C32VFU16@TQFP80(\*) [(TA015-B006)]  
MC9S12C32VFU25@TQFP80(\*) [(TA015-B006)]  
MC9S12C32VPB16@TQFP52 [(PEP+S673)]  
MC9S12C32VPB25@TQFP52 [(PEP+S673)]  
MC9S12C64CFA@TQFP48 [(SA248)]  
MC9S12C64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C64CPB@TQFP52 [(PEP+S673)] MC9S12C64MFA@TQFP48  
[(SA248)]  
MC9S12C64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C64MPB@TQFP52 [(PEP+S673)] MC9S12C64VFA@TQFP48



[ ( SA248 ) ]  
MC9S12C64VFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12C64VPB@TQFP52 [ ( PEP+S673 ) ] MC9S12C96CFA@TQFP48  
[ ( SA248 ) ]  
MC9S12C96CFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12C96CPB@TQFP52 [ ( PEP+S673 ) ] MC9S12C96MFA@TQFP48  
[ ( SA248 ) ]  
MC9S12C96MFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12C96MPB@TQFP52 [ ( PEP+S673 ) ] MC9S12C96VFA@TQFP48  
[ ( SA248 ) ]  
MC9S12C96VFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12C96VPB@TQFP52 [ ( PEP+S673 ) ]  
MC9S12D64CFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12D64CPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12D64FU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12D64MFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12D64MPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12D64PV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12D64VFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12D64VPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DB128BCPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DB128BMPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DB128BVPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DB128CPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DB128MPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DB128VPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DG128BCFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12DG128BCPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DG128BMFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12DG128BMPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DG128BVFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12DG128BVPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DG128CFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12DG128CPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DG128ECFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12DG128ECPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DG128EMFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12DG128EMPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DG128EVFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12DG128EVPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DG128MFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12DG128MPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DG128VFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]

MC9S12DG128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256VVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128ECFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128ECPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128EMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128EMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128EVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128EVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128VVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BVPV@TQFP112(\*) [(TA037-B084)]

MC9S12DJ256CCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64FU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64PV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128ECPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128EMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128EVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DT256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CVPV@TQFP112(\*) [(TA037-B084)]

MC9S12DT256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DT256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DT256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12E128CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E128MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E128VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E256CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E256MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E256VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E32CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E32CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E32MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E32MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E32VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E32VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E64MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E64MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E64VFU@TQFP80(\*) [(SA722-B239)]

MC9S12E64VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12GC128CFA@TQFP48 [(SA248)]  
MC9S12GC128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC128CPB@TQFP52 [(PEP+S673)]  
MC9S12GC128MFA@TQFP48 [(SA248)]  
MC9S12GC128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC128MPB@TQFP52 [(PEP+S673)]  
MC9S12GC128VFA@TQFP48 [(SA248)]  
MC9S12GC128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC128VPB@TQFP52 [(PEP+S673)]  
MC9S12GC16CFA@TQFP48 [(SA248)]  
MC9S12GC16CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16CPB@TQFP52 [(PEP+S673)]  
MC9S12GC16MFA@TQFP48 [(SA248)]  
MC9S12GC16MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16MPB@TQFP52 [(PEP+S673)]  
MC9S12GC16VFA@TQFP48 [(SA248)]  
MC9S12GC16VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16VPB@TQFP52 [(PEP+S673)]  
MC9S12GC32CFA@TQFP48 [(SA248)]  
MC9S12GC32CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32CPB@TQFP52 [(PEP+S673)]  
MC9S12GC32MFA@TQFP48 [(SA248)]  
MC9S12GC32MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32MPB@TQFP52 [(PEP+S673)]  
MC9S12GC32VFA@TQFP48 [(SA248)]  
MC9S12GC32VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32VPB@TQFP52 [(PEP+S673)]  
MC9S12GC64CFA@TQFP48 [(SA248)]  
MC9S12GC64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC64CPB@TQFP52 [(PEP+S673)]  
MC9S12GC64MFA@TQFP48 [(SA248)]  
MC9S12GC64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC64MPB@TQFP52 [(PEP+S673)]  
MC9S12GC64VFA@TQFP48 [(SA248)]  
MC9S12GC64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC64VPB@TQFP52 [(PEP+S673)]  
MC9S12GC96CFA@TQFP48 [(SA248)]  
MC9S12GC96CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96CPB@TQFP52 [(PEP+S673)]  
MC9S12GC96MFA@TQFP48 [(SA248)]

MC9S12GC96MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96MPB@TQFP52 [(PEP+S673)]  
MC9S12GC96VFA@TQFP48 [(SA248)]  
MC9S12GC96VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96VPB@TQFP52 [(PEP+S673)]  
MC9S12HN64CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64CAL@LQFP112(\*) [(SA719-B240)]

MC9S12HZ64CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12NE64CPV@LQFP112(\*) [(SA719-B246)]  
MC9S12NE64CPVE@LQFP112(\*) [(SA719-B246)]  
MC9S12NE64VTU@TQFP80(\*) [(TA048-B006)]  
MC9S12NE64VTUE@TQFP80(\*) [(TA048-B006)]  
MC9S12UF32PB@QFP64(\*) [(SA732+B200)]  
MC9S12UF32PBE@QFP64(\*) [(SA732+B200)]  
MC9S12UF32PU@QFP100(\*) [(SA718+B201)]  
MC9S12XA128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256VAG@LQFP144(\*) [(SA681-B14412)]

MC9S12XA256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256VFB@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512VFB@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256VAA@TQFP80(\*) [(TA015-B006)]



MC9S12XB256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256VfV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD64CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128CPV@TQFP112(\*) [(TA037-B084)]

MC9S12XDG128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512VFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256VFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256CFV@LQFP144(\*) [(SA681-B14412)]

MC9S12XDT256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256VfV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384CPU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384MPU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384VfV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384VPU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512MPV@TQFP112(\*) [(TA037-B084)]

MC9S12XDT512VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512VFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XHZ256CAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ256CAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ256MAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ256MAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ256VAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ256VAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ384CAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ384CAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ384MAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ384MAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ384VAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ384VAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ512CAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ512CAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ512MAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ512MAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ512VAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ512VAL@TQFP112(\*) [(SA719-B264)]  
MCHC908JW32FAE@LQFP48 [(SA248+B005)]  
MCHC908JW32FC@TQFN48 [(SA696+B006)]  
P912XDG128CAA@TQFP80(\*) [(TA015-B006)]  
P912XDG128CAL@TQFP112(\*) [(TA037-B084)]  
P912XDG128CFU@TQFP80(\*) [(TA015-B006)]  
P912XDG128CPV@TQFP112(\*) [(TA037-B084)]  
P912XDG128MAA@TQFP80(\*) [(TA015-B006)]  
P912XDG128MAL@TQFP112(\*) [(TA037-B084)]  
P912XDG128MFU@TQFP80(\*) [(TA015-B006)]  
P912XDG128MPV@TQFP112(\*) [(TA037-B084)]  
P912XDG128VAA@TQFP80(\*) [(TA015-B006)]  
P912XDG128VAL@TQFP112(\*) [(TA037-B084)]  
P912XDG128VFU@TQFP80(\*) [(TA015-B006)]  
P912XDG128VPV@TQFP112(\*) [(TA037-B084)]  
P9RS08KA1CPC [(SA726+B179)]  
P9RS08KA1CSC@SOIC8 [(SA602A+B179)]  
P9RS08KA2CPC [(SA726+B179)]  
P9RS08KA2CSC@SOIC8 [(SA602A+B179)]  
PC56F8011VFAE@QFP32 [(SA663+B005)]

PC56F8013VFAE@QFP32 [ (SA663+B005) ]  
PC56F8014VFAE@QFP32 [ (SA663+B005) ]  
PC68HC908GP32 PC68HC908GP32@SDIP42  
[ (SA028) ]  
PC68HC908GP32@TQFP44 [ (SA675) ]  
PC9S12UF32PB@QFP64(\*) [ (SA732+B200) ]  
PC9S12UF32PBE@QFP64(\*) [ (SA732+B200) ]  
PC9S12UF32PU@QFP100(\*) [ (SA718+B201) ]  
PC9S12XF128@QFP112(\*) [ (SA719-B253) ]  
PC9S12XF128@QFP144(\*) [ (SA681-B14411) ]  
PC9S12XF128@QFP64(\*) [ (SA732-B252) ]  
PC9S12XF256@QFP112(\*) [ (SA719-B253) ]  
PC9S12XF256@QFP144(\*) [ (SA681-B14411) ]  
PC9S12XF256@QFP64(\*) [ (SA732-B252) ]  
PC9S12XF384@QFP112(\*) [ (SA719-B253) ]  
PC9S12XF384@QFP144(\*) [ (SA681-B14411) ]  
PC9S12XF384@QFP64(\*) [ (SA732-B252) ]  
PC9S12XF512@QFP112(\*) [ (SA719-B253) ]  
PC9S12XF512@QFP144(\*) [ (SA681-B14411) ]  
PC9S12XF512@QFP64(\*) [ (SA732-B252) ]  
PC9S12XHZ256CAG@LQFP144(\*) [ (SA681-B14414) ]  
PC9S12XHZ256CAL@TQFP112(\*) [ (SA719-B264) ]  
PC9S12XHZ256MAG@LQFP144(\*) [ (SA681-B14414) ]  
PC9S12XHZ256MAL@TQFP112(\*) [ (SA719-B264) ]  
PC9S12XHZ256VAG@LQFP144(\*) [ (SA681-B14414) ]  
PC9S12XHZ256VAL@TQFP112(\*) [ (SA719-B264) ]  
PC9S12XHZ384CAG@LQFP144(\*) [ (SA681-B14414) ]  
PC9S12XHZ384CAL@TQFP112(\*) [ (SA719-B264) ]  
PC9S12XHZ384MAG@LQFP144(\*) [ (SA681-B14414) ]  
PC9S12XHZ384MAL@TQFP112(\*) [ (SA719-B264) ]  
PC9S12XHZ384VAG@LQFP144(\*) [ (SA681-B14414) ]  
PC9S12XHZ384VAL@TQFP112(\*) [ (SA719-B264) ]  
PC9S12XHZ512CAG@LQFP144(\*) [ (SA681-B14414) ]  
PC9S12XHZ512CAL@TQFP112(\*) [ (SA719-B264) ]  
PC9S12XHZ512MAG@LQFP144(\*) [ (SA681-B14414) ]  
PC9S12XHZ512MAL@TQFP112(\*) [ (SA719-B264) ]  
PC9S12XHZ512VAG@LQFP144(\*) [ (SA681-B14414) ]  
PC9S12XHZ512VAL@TQFP112(\*) [ (SA719-B264) ]  
S9S08AW16ACFT@QFN48(\*) [ (SA696+B198) ]  
S9S08AW16ACLS@QFP44(\*) [ (SA245+B4404) ]  
S9S08AW16AMFT@QFN48(\*) [ (SA696+B198) ]  
S9S08AW16AMLS@QFP44(\*) [ (SA245+B4404) ]  
S9S08AW16AVFT@QFN48(\*) [ (SA696+B198) ]

S9S08AW16AVLS@QFP44(\*) [(SA245+B4404)]  
 S9S08AW8ACFT@QFN48(\*) [(SA696+B198)]  
 S9S08AW8ACLS@QFP44(\*) [(SA245+B4404)]  
 S9S08AW8AMFT@QFN48(\*) [(SA696+B198)]  
 S9S08AW8AMLS@QFP44(\*) [(SA245+B4404)]  
 S9S08AW8AVFT@QFN48(\*) [(SA696+B198)]  
 S9S08AW8AVLS@QFP44(\*) [(SA245+B4404)]  
 XC68HC705P6A(CDW)@SOIC28 [(SA404)]  
 XC68HC711D3 XC68HC711D3@PLCC44  
 [(SA244)]  
 XC68HC711D3@TQFP44 [(SA675)]  
 XC68HC908MR32(CB)@SDIP56 [(PEP+S627)]  
 XC68HC908MR32(CFU)@TQFP64 [(PEP+S625A)]  
 XC68HC908MR32(VB)@SDIP56 [(PEP+S627)]  
 XC68HC908MR32(VFU)@TQFP64 [(PEP+S625A)]  
 XC68HSC705C9A XC68HSC705C9A@PLCC44  
 [(SA244)]  
 XC68HSC705C9A@TQFP44 [(SA245A)]

## Fremont Micro Devices

### E (E) PROM/FRAM/NVRAM

FT24C02 FT24C02@SOP8  
 [(SA602A)]  
 FT24C02@TSSOP8 [(SA026)]  
 FT24C02A FT24C02A@TSSOP8  
 FT24C02A@SOP8 [(SA602A)]  
 [(SA026)]  
 FT24C04 FT24C04@SOP8  
 [(SA602A)]  
 FT24C04@TSSOP8 [(SA026)]  
 FT24C04A FT24C04A@TSSOP8  
 FT24C04A@SOP8 [(SA602A)]  
 [(SA026)]  
 FT24C08 FT24C08@SOP8  
 [(SA602A)]  
 FT24C08@TSSOP8 [(SA026)]  
 FT24C08A FT24C08A@TSSOP8  
 FT24C08A@SOP8 [(SA602A)]  
 [(SA026)]  
 FT24C1024 FT24C1024@SOP8

[ (SA023A) ]	
FT24C1024@TSSOP8 [ (SA026) ]	
FT24C1024A	
FT24C1024A@SOP8 [ (SA023A) ]	FT24C1024A@TSSOP8
[ (SA026) ]	
FT24C128	FT24C128@SOP8
[ (SA602A) ]	
FT24C128@TSSOP8 [ (SA026) ]	
FT24C128A	
FT24C128A@SOP8 [ (SA602A) ]	FT24C128A@TSSOP8
[ (SA026) ]	
FT24C16	FT24C16@SOP8
[ (SA602A) ]	
FT24C16@TSSOP8 [ (SA026) ]	
FT24C16A	
FT24C16A@SOP8 [ (SA602A) ]	FT24C16A@TSSOP8
[ (SA026) ]	
FT24C256	FT24C256@SOP8
[ (SA602A) ]	
FT24C256@TSSOP8 [ (SA026) ]	
FT24C256A	
FT24C256A@SOP8 [ (SA602A) ]	FT24C256A@TSSOP8
[ (SA026) ]	
FT24C32	FT24C32@SOP8
[ (SA602A) ]	
FT24C32@TSSOP8 [ (SA026) ]	
FT24C32A	
FT24C32A@SOP8 [ (SA602A) ]	FT24C32A@TSSOP8
[ (SA026) ]	
FT24C512	FT24C512@SOP8
[ (SA602A) ]	
FT24C512@TSSOP8 [ (SA026) ]	
FT24C512A	
FT24C512A@SOP8 [ (SA602A) ]	FT24C512A@TSSOP8
[ (SA026) ]	
FT24C64	FT24C64@SOP8
[ (SA602A) ]	
FT24C64@TSSOP8 [ (SA026) ]	
FT24C64A	
FT24C64A@SOP8 [ (SA602A) ]	FT24C64A@TSSOP8
[ (SA026) ]	
FT34C02	FT34C02@SOP8
[ (SA602A) ]	

FT34C02@TSSOP8 [(SA026)]	
FT34C02A	
FT34C02A@SOP8 [(SA602A)]	FT34C02A@TSSOP8
[(SA026)]	
FT93C46(08bit)	FT93C46(08bit)@SOP8
[(SA602A)]	
FT93C46(08bit)@TSSOP8 [(SA026)]	FT93C46
(16bit)	
FT93C46(16bit)@SOP8 [(SA602A)]	FT93C46(16bit)@TSSOP8
[(SA026)]	
FT93C46A(08bit)	FT93C46A(08bit)@SOP8
[(SA602A)]	
FT93C46A(08bit)@TSSOP8 [(SA026)]	FT93C46A
(16bit)	
FT93C46A(16bit)@SOP8 [(SA602A)]	FT93C46A(16bit)@TSSOP8
[(SA026)]	
FT93C56(08bit)	FT93C56(08bit)@SOP8
[(SA602A)]	
FT93C56(08bit)@TSSOP8 [(SA026)]	FT93C56
(16bit)	
FT93C56(16bit)@SOP8 [(SA602A)]	FT93C56(16bit)@TSSOP8
[(SA026)]	
FT93C56A(08bit)	FT93C56A(08bit)@SOP8
[(SA602A)]	
FT93C56A(08bit)@TSSOP8 [(SA026)]	FT93C56A
(16bit)	
FT93C56A(16bit)@SOP8 [(SA602A)]	FT93C56A(16bit)@TSSOP8
[(SA026)]	
FT93C66(08bit)	FT93C66(08bit)@SOP8
[(SA602A)]	
FT93C66(08bit)@TSSOP8 [(SA026)]	FT93C66
(16bit)	
FT93C66(16bit)@SOP8 [(SA602A)]	FT93C66(16bit)@TSSOP8
[(SA026)]	
FT93C66A(08bit)	FT93C66A(08bit)@SOP8
[(SA602A)]	
FT93C66A(08bit)@TSSOP8 [(SA026)]	FT93C66A
(16bit)	
FT93C66A(16bit)@SOP8 [(SA602A)]	FT93C66A(16bit)@TSSOP8
[(SA026)]	
FT93C86(08bit)	FT93C86(08bit)@SOP8
[(SA602A)]	
FT93C86(08bit)@TSSOP8 [(SA026)]	FT93C86



(16bit)

FT93C86(16bit)@SOP8 [(SA602A)]	FT93C86(16bit)@TSSOP8
[(SA026)]	
FT93C86A(08bit)	FT93C86A(08bit)@SOP8
[(SA602A)]	
FT93C86A(08bit)@TSSOP8 [(SA026)]	FT93C86A
(16bit)	
FT93C86A(16bit)@SOP8 [(SA602A)]	FT93C86A(16bit)@TSSOP8
[(SA026)]	

## FUJITSU

### E (E) PROM / FRAM / NVRAM

MB84VD21081@FBGA61 [(SA642C-B032A-Y056F001)]  
 MB84VD21081EM@FBGA56 [(SA642C-B032A-Y056F001)]  
 MB84VD21082@FBGA61 [(SA642C-B032A-Y056F001)]  
 MB84VD21082EM@FBGA56 [(SA642C-B032A-Y056F001)]  
 MB84VD21083@FBGA61 [(SA642C-B032A-Y056F001)]  
 MB84VD21083EM@FBGA56 [(SA642C-B032A-Y056F001)]  
 MB84VD21084@FBGA61 [(SA642C-B032A-Y056F001)]  
 MB84VD21084EM@FBGA56 [(SA642C-B032A-Y056F001)]  
 MB84VD21091@FBGA61 [(SA642C-B032A-Y056F001)]  
 MB84VD21091EM@FBGA56 [(SA642C-B032A-Y056F001)]  
 MB84VD21092@FBGA61 [(SA642C-B032A-Y056F001)]  
 MB84VD21092EM@FBGA56 [(SA642C-B032A-Y056F001)]  
 MB84VD21093@FBGA61 [(SA642C-B032A-Y056F001)]  
 MB84VD21093EM@FBGA56 [(SA642C-B032A-Y056F001)]  
 MB84VD21094@FBGA61 [(SA642C-B032A-Y056F001)]  
 MB84VD21094EM@FBGA56 [(SA642C-B032A-Y056F001)]  
 MB84VD21181DA@FBGA69 [(SA642C-B032A-Y056F001)]  
 MB84VD21181EG@FBGA56 [(SA642C-B032A-Y056F001)]  
 MB84VD21181EM@FBGA56 [(SA642C-B032A-Y056F001)]  
 MB84VD21182DA@FBGA69 [(SA642C-B032A-Y056F001)]  
 MB84VD21182EG@FBGA56 [(SA642C-B032A-Y056F001)]  
 MB84VD21182EM@FBGA56 [(SA642C-B032A-Y056F001)]  
 MB84VD21183DA@FBGA69 [(SA642C-B032A-Y056F001)]  
 MB84VD21183EG@FBGA56 [(SA642C-B032A-Y056F001)]  
 MB84VD21183EM@FBGA56 [(SA642C-B032A-Y056F001)]  
 MB84VD21184DA@FBGA69 [(SA642C-B032A-Y056F001)]  
 MB84VD21184EG@FBGA56 [(SA642C-B032A-Y056F001)]  
 MB84VD21184EM@FBGA56 [(SA642C-B032A-Y056F001)]

MB84VD21191DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21191EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21191EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21192DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21192EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21192EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD22180FA@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22180FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22181A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22181EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22181EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22181FM@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22182A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22182EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22182EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22183A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22183EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22183EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22184EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184FM@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22190FA@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22190FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22191A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22191EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22191EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22191FM@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22192A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22192EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22192EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22193A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22193EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22193EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22194A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22194EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22194EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]

MB84VD22194FM@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22280FE@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22282EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22283EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22284EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22290FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22292EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22293EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22294EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22386EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22387EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22388EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22396EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22397EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22398EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD23180FM@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD23280EA@FBGA101 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23280EE@FBGA101 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23280FA@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23381EJ@FBGA101 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23381FJ@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23381HJ@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD23481FJ@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VF5F5FF4J2@BGA107 [ ( SA642D-B062A-Y088F001 ) ]  
MB84VP23481FK@FBGA65 [ ( SA642JJ-B032A-W064F001Y ) ]  
MB84VP24481HK@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
MB84VP24491HK@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
MB85R256@SOP28 [ ( SA630 ) ] MB85R256@TSOP28  
[ ( SA430T ) ]  
MB85R256A@SOP28 [ ( SA630 ) ] MB85R256A@TSOP28  
[ ( SA430T ) ]  
MBM271001 MBM271001@PLCC32  
[ ( SA015A1T ) ]  
MBM271001@TSOP32 [ ( SA410T ) ]  
MBM27128  
MBM27128@PLCC32 [ ( SA015A1T ) ]  
MBM2716  
MBM2716H  
MBM27256  
MBM27256@PLCC32 [ ( SA015A1T ) ]  
MBM2732  
MBM2732A  
MBM2764

MBM2764@PLCC32 [(SA015A1T)]  
MBM27C1000  
MBM27C1000@PLCC32 [(SA015A1T)] MBM27C1000@TSOP32  
[(SA410T)]  
MBM27C1001 MBM27C1001@PLCC32  
[(SA015A1T)]  
MBM27C1001@TSOP32 [(SA410T)]  
MBM27C1024  
MBM27C1024@PLCC44 [(SA244)]  
MBM27C1028  
MBM27C1028@PLCC32 [(SA015A1T)]  
MBM27C128  
MBM27C128@PLCC32 [(SA015A1T)]  
MBM27C128P  
MBM27C128P@PLCC32 [(SA015A1T)]  
MBM27C2000  
MBM27C2000@PLCC32 [(SA015A1T)] MBM27C2000@TSOP32  
[(SA410T)]  
MBM27C2001 MBM27C2001@PLCC32  
[(SA015A1T)]  
MBM27C2001@TSOP32 [(SA410T)]  
MBM27C2048  
MBM27C256 MBM27C256@PLCC32  
[(SA015A1T)]  
MBM27C256A MBM27C256A@PLCC32  
[(SA015A1T)]  
MBM27C256AP MBM27C256AP@PLCC32  
[(SA015A1T)]  
MBM27C256H MBM27C256H@PLCC32  
[(SA015A1T)]  
MBM27C32A  
MBM27C4001  
MBM27C4001@PLCC32 [(SA015A1T)] MBM27C4001@TSOP32  
[(SA410T)]  
MBM27C4096  
MBM27C512  
MBM27C512@PLCC32 [(SA015A1T)]  
MBM27C512P  
MBM27C512P@PLCC32 [(SA015A1T)]  
MBM27C64  
MBM27C64@PLCC32 [(SA015A1T)]  
MBM28C64  
MBM28C65

MBM28F010

MBM28F010@PLCC32 [ (SA015A1T) ] MBM28F010@TSOP32  
[ (SA410T) ]

MBM29DL161BD@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL161BD@TSOP48 [ (SA247-B005) ]

MBM29DL161BE@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL161TD@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL161TD@TSOP48 [ (SA247-B005) ]

MBM29DL161TE@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL162BD@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL162BD@TSOP48 [ (SA247-B005) ]

MBM29DL162BE@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL162BE@TSOP48 [ (SA247-B005) ]

MBM29DL162TD@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL162TD@TSOP48 [ (SA247-B005) ]

MBM29DL162TE@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL162TE@TSOP48 [ (SA247-B005) ]

MBM29DL163BD@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL163BD@TSOP48 [ (SA247-B005) ]

MBM29DL163BE@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL163BE@TSOP48 [ (SA247-B005) ]

MBM29DL163TD@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL163TD@TSOP48 [ (SA247-B005) ]

MBM29DL163TE@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL163TE@TSOP48 [ (SA247-B005) ]

MBM29DL164BD@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL164BD@TSOP48 [ (SA247-B005) ]

MBM29DL164BE@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL164BE@TSOP48 [ (SA247-B005) ]

MBM29DL164TD@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL164TD@TSOP48 [ (SA247-B005) ]

MBM29DL164TE@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL164TE@TSOP48 [ (SA247-B005) ]

MBM29DL320BF@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL320BF@TSOP48 [ (SA247-B005) ]

MBM29DL320TF@FBGA48 [ (SA642B-B026A-Y072F001) ]

MBM29DL320TF@TSOP48 [ (SA247-B005) ]

MBM29DL321BD@FBGA63 [ (SA642E-B026A-T072N001) ]

MBM29DL321BD@TSOP48 [ (SA247-B005) ]

MBM29DL321BE@FBGA63 [ (SA642B-B026A-Y072F001) ]

MBM29DL321TD@FBGA63 [ (SA642E-B026A-T072N001) ]

MBM29DL321TD@TSOP48 [ (SA247-B005) ]

MBM29DL321TE@FBGA63 [ (SA642B-B026A-Y072F001) ]

MBM29DL322BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL322BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL322TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL323BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL323TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL324BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL324BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL324TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL324TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL32BF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL32BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL32TF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL32TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL34BF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL34BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL34TF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL34TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL400BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL400BC@PSOP44 [ ( SA638 ) ]  
MBM29DL400BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL400BT@TSOP48 [ ( SA247-B005 ) ]

MBM29DL400TC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
 MBM29DL400TC@PSOP44 [ ( SA638 ) ]  
 MBM29DL400TC@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DL640E@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
 MBM29DL640E@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DL64DF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 MBM29DL64DF@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DL800B@PSOP44 [ ( SA638-B006 ) ]  
 MBM29DL800B@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DL800BA@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
 MBM29DL800BA@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DL800BB@PSOP44 [ ( SA638-B006 ) ]  
 MBM29DL800BB@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DL800BT@PSOP44 [ ( SA638-B006 ) ]  
 MBM29DL800BT@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DL800T@PSOP44 [ ( SA638-B006 ) ]  
 MBM29DL800T@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DL800TA@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
 MBM29DL800TA@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DS163BE@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
 MBM29DS163BE@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DS163TE@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
 MBM29DS163TE@TSOP48 [ ( SA247-B005 ) ]  
 MBM29F001B MBM29F001B@PLCC32  
 [ ( SA015A1T ) ]  
 MBM29F001B@TSOP32 [ ( SA410T ) ]  
 MBM29F001T MBM29F001T@TSOP32  
 MBM29F001T@PLCC32 [ ( SA015A1T ) ]  
 [ ( SA410T ) ]  
 MBM29F002B MBM29F002B@PLCC32  
 [ ( SA015A1T ) ]  
 MBM29F002B@TSOP32 [ ( SA410T ) ]  
 MBM29F002NB MBM29F002NB@TSOP32  
 MBM29F002NB@PLCC32 [ ( SA015A1T ) ]  
 [ ( SA410T ) ]  
 MBM29F002NT MBM29F002NT@PLCC32  
 [ ( SA015A1T ) ]  
 MBM29F002NT@TSOP32 [ ( SA410T ) ]  
 MBM29F002T MBM29F002T@TSOP32  
 MBM29F002T@PLCC32 [ ( SA015A1T ) ]  
 [ ( SA410T ) ]  
 MBM29F010 MBM29F010@PLCC32  
 [ ( SA015A1T ) ]

MBM29F010@TSOP32 [(SA410T)]	
MBM29F010A	
MBM29F010A@PLCC32 [(SA015A1T)]	MBM29F010A@TSOP32
[(SA410T)]	
MBM29F016@PSOP44 [(SA638)]	MBM29F016@TSOP40
[(SA409T)]	
MBM29F016@TSOP48 [(SA247-B005)]	MBM29F016A@PSOP44
[(SA638)]	
MBM29F016A@TSOP40 [(SA409T)]	MBM29F016A@TSOP48 [(SA247-
B005)]	
MBM29F016B@PSOP44 [(SA638)]	MBM29F016B@TSOP40
[(SA409T)]	
MBM29F016B@TSOP48 [(SA247-B005)]	MBM29F017B@TSOP48 [(SA247-
B005)]	
MBM29F017D@TSOP40 [(SA409T)]	MBM29F017D@TSOP48 [(SA247-
B005)]	
MBM29F032B@PSOP44 [(SA638)]	MBM29F032B@TSOP40
[(SA409T)]	
MBM29F033C@TSOP40 [(SA409T)]	
MBM29F040	
MBM29F040@PLCC32 [(SA015A1T)]	MBM29F040@TSOP32
[(SA410T)]	
MBM29F040B	MBM29F040B@PLCC32
[(SA015A1T)]	
MBM29F040B@TSOP32 [(SA410T)]	MBM29F040C@PLCC32
[(SA015A1T)]	
MBM29F040C@TSOP32 [(SA410T)]	MBM29F080@PSOP44
[(SA638)]	
MBM29F080@TSOP40 [(SA409T)]	MBM29F080A@TSOP48 [(SA247-
B005)]	
MBM29F080B@PSOP44 [(SA638)]	MBM29F080B@TSOP40
[(SA409T)]	
MBM29F100B@PSOP44 [(SA638-B006)]	MBM29F100B@TSOP48 [(SA247-
B005)]	
MBM29F100T@PSOP44 [(SA638-B006)]	MBM29F100T@TSOP48 [(SA247-
B005)]	
MBM29F160BE@TSOP48 [(SA247-B005)]	
MBM29F160TE@TSOP48 [(SA247-B005)]	
MBM29F200AB@PSOP44 [(SA638-B006)]	
MBM29F200AB@TSOP48 [(SA247-B005)]	
MBM29F200AT@PSOP44 [(SA638-B006)]	
MBM29F200AT@TSOP48 [(SA247-B005)]	
MBM29F200B@PSOP44 [(SA638-B006)]	MBM29F200B@TSOP48 [(SA247-



B005 ) ]	
MBM29F200T@PSOP44 [ ( SA638-B006 ) ]	MBM29F200T@TSOP48 [ ( SA247-
B005 ) ]	
MBM29F400AB@PSOP44 [ ( SA638-B006 ) ]	
MBM29F400AB@TSOP48 [ ( SA247-B005 ) ]	
MBM29F400AT@PSOP44 [ ( SA638-B006 ) ]	
MBM29F400AT@TSOP48 [ ( SA247-B005 ) ]	
MBM29F400B@PSOP44 [ ( SA638-B006 ) ]	MBM29F400B@TSOP48 [ ( SA247-
B005 ) ]	
MBM29F400BB@PSOP44 [ ( SA638-B006 ) ]	
MBM29F400BB@TSOP48 [ ( SA247-B005 ) ]	
MBM29F400BT@PSOP44 [ ( SA638-B006 ) ]	
MBM29F400BT@TSOP48 [ ( SA247-B005 ) ]	
MBM29F400T@PSOP44 [ ( SA638-B006 ) ]	MBM29F400T@TSOP48 [ ( SA247-
B005 ) ]	
MBM29F800B@PSOP44 [ ( SA638-B006 ) ]	MBM29F800B@TSOP48 [ ( SA247-
B005 ) ]	
MBM29F800BA@PSOP44 [ ( SA638-B006 ) ]	
MBM29F800BA@TSOP48 [ ( SA247-B005 ) ]	
MBM29F800BB@PSOP44 [ ( SA638-B006 ) ]	
MBM29F800BB@TSOP48 [ ( SA247-B005 ) ]	
MBM29F800BT@PSOP44 [ ( SA638-B006 ) ]	
MBM29F800BT@TSOP48 [ ( SA247-B005 ) ]	
MBM29F800T@PSOP44 [ ( SA638-B006 ) ]	MBM29F800T@TSOP48 [ ( SA247-
B005 ) ]	
MBM29F800TA@PSOP44 [ ( SA638-B006 ) ]	
MBM29F800TA@TSOP48 [ ( SA247-B005 ) ]	
MBM29LL800B@TSOP48 [ ( SA247-B005 ) ]	
MBM29LL800BB@TSOP48 [ ( SA247-B005 ) ]	
MBM29LL800BT@TSOP48 [ ( SA247-B005 ) ]	
MBM29LL800T@TSOP48 [ ( SA247-B005 ) ]	
MBM29LV001B@PLCC32 [ ( SA015A1T ) ]	MBM29LV001BB@PLCC32
[ ( SA015A1T ) ]	
MBM29LV001BB@TSOP32 [ ( SA410T ) ]	MBM29LV001BC@PLCC32
[ ( SA015A1T ) ]	
MBM29LV001BC@TSOP32 [ ( SA410T ) ]	MBM29LV001BT@PLCC32
[ ( SA015A1T ) ]	
MBM29LV001BT@TSOP32 [ ( SA410T ) ]	MBM29LV001T@TSOP32
[ ( SA410T ) ]	
MBM29LV001TC@PLCC32 [ ( SA015A1T ) ]	MBM29LV001TC@TSOP32
[ ( SA410T ) ]	
MBM29LV002B@TSOP40 [ ( SA409T ) ]	MBM29LV002T@TSOP40
[ ( SA409T ) ]	

MBM29LV004B@PSOP44 [ (SA638) ] [ (SA409T) ]	MBM29LV004B@TSOP40
MBM29LV004BB@TSOP40 [ (SA409T) ] [ (SA409T) ]	MBM29LV004BT@TSOP40
MBM29LV004T@PSOP44 [ (SA638) ] [ (SA409T) ]	MBM29LV004T@TSOP40
MBM29LV008B@PSOP44 [ (SA638) ] [ (SA409T) ]	MBM29LV008B@TSOP40
MBM29LV008BB@TSOP40 [ (SA409T) ] [ (SA409T) ]	MBM29LV008BT@TSOP40
MBM29LV008T@PSOP44 [ (SA638) ] [ (SA409T) ]	MBM29LV008T@TSOP40
MBM29LV016/B@TSOP40 [ (SA409T) ] [ (SA409T) ]	MBM29LV016/T@TSOP40
MBM29LV016B@TSOP40 [ (SA409T) ]	
MBM29LV017@FBGA48 [ (SA6420-B026A-T064F001) ]	
MBM29LV017@TSOP40 [ (SA409T) ] [ (SA409T) ]	MBM29LV017B@TSOP40
MBM29LV017E@TSOP40 [ (SA409T) ] [ (SA409T) ]	MBM29LV033C@TSOP40
MBM29LV080@TSOP40 [ (SA409T) ] [ (SA409T) ]	MBM29LV081@TSOP40
MBM29LV081B@TSOP40 [ (SA409T) ] [ (SA409T) ]	MBM29LV116B@TSOP40
MBM29LV160B@SON46 [ (SA631) ] ( * )	MBM29LV160B@SON46
MBM29LV160BB@PSOP44 [ (SA638-B006) ]	
MBM29LV160BB@TSOP48 [ (SA247-B005) ]	
MBM29LV160BE@FBGA48 [ (SA642B-B026A-Y072F001) ]	
MBM29LV160BE@TSOP48 [ (SA247-B005) ]	
MBM29LV160BM@FBGA48 [ (SA642B-B026A-Y072F001) ]	
MBM29LV160BM@TSOP48 [ (SA247-B005) ]	
MBM29LV160BT@PSOP44 [ (SA638-B006) ]	
MBM29LV160BT@TSOP48 [ (SA247-B005) ]	
MBM29LV160T@SON46 [ (SA631) ] ( * )	MBM29LV160T@SON46
MBM29LV160TE@FBGA48 [ (SA642B-B026A-Y072F001) ]	
MBM29LV160TE@TSOP48 [ (SA247-B005) ]	
MBM29LV160TM@FBGA48 [ (SA642B-B026A-Y072F001) ]	
MBM29LV160TM@TSOP48 [ (SA247-B005) ]	
MBM29LV200B@PSOP44 [ (SA638-B006) ]	
MBM29LV200B@TSOP48 [ (SA247-B005) ]	
MBM29LV200BB@PSOP44 [ (SA638-B006) ]	

MBM29LV200BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200BC@PSOP44 [ ( SA638 ) ]  
MBM29LV200BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV200BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV200T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200TC@PSOP44 [ ( SA638 ) ]  
MBM29LV200TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV320BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV320BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV320TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV320TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400B@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400B@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29LV400BC@PSOP44 [ ( SA638 ) ]  
MBM29LV400BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400TC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29LV400TC@PSOP44 [ ( SA638 ) ]  
MBM29LV400TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV650UE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV651UE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV652UE@FGBA63 [ ( SA642C-B026A-Y056F001 ) ]  
MBM29LV800B@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800B@SON46 [ ( SA631 ) ] MBM29LV800B@SON46  
( \* )  
MBM29LV800B@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BA@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800BA@PSOP44 [ ( SA638 ) ]  
MBM29LV800BA@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800BE@PSOP44 [ ( SA638 ) ]  
MBM29LV800BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BT@PSOP44 [ ( SA638-B006 ) ]

MBM29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800T@SON46 [ ( SA631 ) ] MBM29LV800T@SON46  
( \* )  
MBM29LV800T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800TA@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800TA@PSOP44 [ ( SA638 ) ]  
MBM29LV800TA@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800TE@PSOP44 [ ( SA638 ) ]  
MBM29LV800TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29PDS323B@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29PDS323T@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29PL160BD@PSOP44 [ ( SA638 ) ]  
MBM29PL160BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL160TD@PSOP44 [ ( SA638 ) ]  
MBM29PL160TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL32BM@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
MBM29PL32BM@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL32TM@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
MBM29PL32TM@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL64LM@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL64LM@TSOP56 [ ( SA628-B067 ) ]  
MBM29QM12DH@FBGA88 [ ( SA642J-B101A-W080F001 ) ]  
MBM29QM12DH@TSOP56 [ ( SA628-B097 ) ]  
MBM29SL160BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29SL160BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29SL160TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29SL160TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29SL800BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29SL800BT@TSOP48 [ ( SA247-B005 ) ]  
MSP55LV256@PSOP44 [ ( SA638 ) ]

## DRAM & SRAM

MB81C78A MB81C78A@SOIC28  
[ ( SA630 ) ]

## MICROCONTROLLER

MB89F051@LQFP64 MB89F202@SDIP32

[(SA653)]  
 MB89F202@SSOP34 [(SA689)] MB89F202RA@QFP32  
 [(SA663)]  
 MB89F202RA@SDIP32 [(SA653)] MB89F202RA@SSOP34  
 [(SA689)]  
 MB89F482AS@LQFP44 [(SA245A)] MB89F482AS@SDIP42  
 [(SA028)]  
 MB89F482AW@LQFP44 [(SA245A)] MB89F482AW@SDIP42  
 [(SA028)]  
 MB89F482HS@LQFP44 [(SA245A)] MB89F482HS@SDIP42  
 [(SA028)]  
 MB89F482HW@LQFP44 [(SA245A)] MB89F482HW@SDIP42  
 [(SA028)]  
 MB89F497@TQFP80 [(PEP+S704)] MB89F497A@TQFP80 [(PEP  
 +S704)]  
 MB89F499@PQFP100 [(PEP+S427)] MB89F538@SDIP64 [(PEP  
 +S600A)]  
 MB89F538-101PFM@TQFP64 [(PEP+S680)]  
 MB89F538-101PFM@TQFP64(\*) [(SA739+B255)]  
 MB89F538-201PFM@TQFP64 [(PEP+S680)]  
 MB89F538-201PFM@TQFP64(\*) [(SA739+B255)]  
 MB89F538L-101PFM@TQFP64 [(PEP+S680)]  
 MB89F538L-101PFM@TQFP64(\*) [(SA739+B255)]  
 MB89F538L-201PFM@TQFP64 [(PEP+S680)]  
 MB89F538L-201PFM@TQFP64(\*) [(SA739+B255)]  
 MB89P131APFM@TQFP48 [(SA745)] MB89P131PFM@TQFP48  
 [(SA745)]  
 MB89P133APFM@TQFP48 [(SA745)] MB89P133PFM@TQFP48  
 [(SA745)]  
 MB89P135APFM@TQFP48 [(SA745)] MB89P135PFM@TQFP48  
 [(SA745)]  
 MB89P165-101(PF)@QFP80 [(PEP+S611A)]  
 MB89P165-101(PFM)@LQFP80 [(PEP+S704)]  
 MB89P165-101(PFV)@LQFP80 [(PEP+S640B)]  
 MB89P165-102(PF)@QFP80 [(PEP+S611A)]  
 MB89P165-102(PFM)@LQFP80 [(PEP+S704)]  
 MB89P165-102(PFV)@LQFP80 [(PEP+S640B)]  
 MB89P165-103(PF)@QFP80 [(PEP+S611A)]  
 MB89P165-103(PFM)@LQFP80 [(PEP+S704)]  
 MB89P165-103(PFV)@LQFP80 [(PEP+S640B)]  
 MB89P165-104(PF)@QFP80 [(PEP+S611A)]  
 MB89P165-104(PFM)@LQFP80 [(PEP+S704)]  
 MB89P165-104(PFV)@LQFP80 [(PEP+S640B)]

MB89P165-105(PF)@QFP80 [(PEP+S611A)]  
 MB89P165-105(PFM)@LQFP80 [(PEP+S704)]  
 MB89P165-105(PFV)@LQFP80 [(PEP+S640B)]  
 MB89P165-201(PF)@QFP80 [(PEP+S611A)]  
 MB89P165-201(PFM)@LQFP80 [(PEP+S704)]  
 MB89P165-201(PFV)@LQFP80 [(PEP+S640B)]  
 MB89P165-202(PF)@QFP80 [(PEP+S611A)]  
 MB89P165-202(PFM)@LQFP80 [(PEP+S704)]  
 MB89P165-202(PFV)@LQFP80 [(PEP+S640B)]  
 MB89P165-203(PF)@QFP80 [(PEP+S611A)]  
 MB89P165-203(PFM)@LQFP80 [(PEP+S704)]  
 MB89P165-203(PFV)@LQFP80 [(PEP+S640B)]  
 MB89P195 MB89P195(F)@SOIC28  
 [(SA630)]  
 MB89P195AP MB89P195AP(F)@SOIC28  
 [(SA630)]  
 MB89P195P MB89P195P(F)@SOIC28  
 [(SA630)]  
 MB89P475-101P-SH@SDIP48 [(SA627-B5604)]  
 MB89P475-102P-SH@SDIP48 [(SA627-B5604)]  
 MB89P475-201P-SH@SDIP48 [(SA627-B5604)]  
 MB89P475-202P-SH@SDIP48 [(SA627-B5604)]  
 MB89P485LPFM-101@TQFP64 [(PEP+S680)]  
 MB89P485LPFM-101@TQFP64(\*) [(TA055-B006)]  
 MB89P485LPFM-102@TQFP64 [(PEP+S680)]  
 MB89P485LPFM-102@TQFP64(\*) [(TA055-B006)]  
 MB89P485LPFM-103@TQFP64 [(PEP+S680)]  
 MB89P485LPFM-103@TQFP64(\*) [(TA055-B006)]  
 MB89P485LPFM-104@TQFP64 [(PEP+S680)]  
 MB89P485LPFM-104@TQFP64(\*) [(TA055-B006)]  
 MB89P485PFM-101@TQFP64 [(PEP+S680)]  
 MB89P485PFM-101@TQFP64(\*) [(TA055-B006)]  
 MB89P485PFM-102@TQFP64 [(PEP+S680)]  
 MB89P485PFM-102@TQFP64(\*) [(TA055-B006)]  
 MB89P485PFM-103@TQFP64 [(PEP+S680)]  
 MB89P485PFM-103@TQFP64(\*) [(TA055-B006)]  
 MB89P485PFM-104@TQFP64 [(PEP+S680)]  
 MB89P485PFM-104@TQFP64(\*) [(TA055-B006)]  
 MB89P857@SDIP64 [(PEP+S600A)]  
 MB89P935CP  
 MB89P935CP--G-SH@SDIP32 [(SA653)]  
 MB90867A@LQFP100 [(PEP+S427)] MB90867A@TQFP100 [(PEP  
 +S604)]

MB90867AS@LQFP100 [(PEP+S427) +S604)]	MB90867AS@TQFP100 [(PEP
MB90F334APFF@LQFP120 [(TA051-B006)]	
MB90F334APMC@LQFP120 [(TA036-B006)]	
MB90F342A@LQFP100 [(PEP+S604) +S427)]	MB90F342A@QFP100 [(PEP
MB90F342A@QFP100(*) [(TA075) +S604)]	MB90F342AS@LQFP100 [(PEP
MB90F342AS@QFP100 [(PEP+S427) [(TA075)]	MB90F342AS@QFP100(*)
MB90F342CA@LQFP100 [(PEP+S604) +S427)]	MB90F342CA@QFP100 [(PEP
MB90F342CA@QFP100(*) [(TA075) +S604)]	MB90F342CAS@LQFP100 [(PEP
MB90F342CAS@QFP100 [(PEP+S427) [(TA075)]	MB90F342CAS@QFP100(*)
MB90F343A@LQFP100 [(PEP+S604) +S427)]	MB90F343A@QFP100 [(PEP
MB90F343A@QFP100(*) [(TA075) +S604)]	MB90F343AS@LQFP100 [(PEP
MB90F343AS@QFP100 [(PEP+S427) [(TA075)]	MB90F343AS@QFP100(*)
MB90F343CA@LQFP100 [(PEP+S604) +S427)]	MB90F343CA@QFP100 [(PEP
MB90F343CA@QFP100(*) [(TA075) +S604)]	MB90F343CAS@LQFP100 [(PEP
MB90F343CAS@QFP100 [(PEP+S427) [(TA075)]	MB90F343CAS@QFP100(*)
MB90F345A@LQFP100 [(PEP+S604) +S427)]	MB90F345A@QFP100 [(PEP
MB90F345A@QFP100(*) [(TA075) +S604)]	MB90F345AS@LQFP100 [(PEP
MB90F345AS@QFP100 [(PEP+S427) [(TA075)]	MB90F345AS@QFP100(*)
MB90F345CA@LQFP100 [(PEP+S604) +S427)]	MB90F345CA@QFP100 [(PEP
MB90F345CA@QFP100(*) [(TA075) +S604)]	MB90F345CAS@LQFP100 [(PEP
MB90F345CAS@QFP100 [(PEP+S427) [(TA075)]	MB90F345CAS@QFP100(*)
MB90F346A@LQFP100 [(PEP+S604) +S427)]	MB90F346A@QFP100 [(PEP
MB90F346A@QFP100(*) [(TA075)]	MB90F346AS@LQFP100 [(PEP

+S604) ]	
MB90F346AS@QFP100 [ (PEP+S427) ]	MB90F346AS@QFP100( * )
[ (TA075) ]	
MB90F346CA@LQFP100 [ (PEP+S604) ]	MB90F346CA@QFP100 [ (PEP
+S427) ]	
MB90F346CA@QFP100( * ) [ (TA075) ]	MB90F346CAS@LQFP100 [ (PEP
+S604) ]	
MB90F346CAS@QFP100 [ (PEP+S427) ]	MB90F346CAS@QFP100( * )
[ (TA075) ]	
MB90F347@LQFP100 [ (PEP+S604) ]	MB90F347@QFP100 [ (PEP
+S427) ]	
MB90F347@QFP100( * ) [ (TA075) ]	MB90F347A@LQFP100 [ (PEP
+S604) ]	
MB90F347A@QFP100 [ (PEP+S427) ]	MB90F347A@QFP100( * )
[ (TA075) ]	
MB90F347AS@LQFP100 [ (PEP+S604) ]	MB90F347AS@QFP100 [ (PEP
+S427) ]	
MB90F347AS@QFP100( * ) [ (TA075) ]	MB90F347C@LQFP100 [ (PEP
+S604) ]	
MB90F347C@QFP100 [ (PEP+S427) ]	MB90F347C@QFP100( * )
[ (TA075) ]	
MB90F347CA@LQFP100 [ (PEP+S604) ]	MB90F347CA@QFP100 [ (PEP
+S427) ]	
MB90F347CA@QFP100( * ) [ (TA075) ]	MB90F347CAS@LQFP100 [ (PEP
+S604) ]	
MB90F347CAS@QFP100 [ (PEP+S427) ]	MB90F347CAS@QFP100( * )
[ (TA075) ]	
MB90F347CS@LQFP100 [ (PEP+S604) ]	MB90F347CS@QFP100 [ (PEP
+S427) ]	
MB90F347CS@QFP100( * ) [ (TA075) ]	MB90F347S@LQFP100 [ (PEP
+S604) ]	
MB90F347S@QFP100 [ (PEP+S427) ]	MB90F347S@QFP100( * )
[ (TA075) ]	
MB90F349A@LQFP100 [ (PEP+S604) ]	MB90F349A@QFP100 [ (PEP
+S427) ]	
MB90F349A@QFP100( * ) [ (TA075) ]	MB90F349AS@LQFP100 [ (PEP
+S604) ]	
MB90F349AS@QFP100 [ (PEP+S427) ]	MB90F349AS@QFP100( * )
[ (TA075) ]	
MB90F349CA@LQFP100 [ (PEP+S604) ]	MB90F349CA@QFP100 [ (PEP
+S427) ]	
MB90F349CA@QFP100( * ) [ (TA075) ]	MB90F349CAS@LQFP100 [ (PEP
+S604) ]	



MB90F349CAS@QFP100 [(PEP+S427)] MB90F349CAS@QFP100(\*)  
[(TA075)]  
MB90F352PFM@LQFP64 [(PEP+S680)]  
MB90F352PFM@LQFP64(\*) [(SA739+B260)]  
MB90F352SPFM@LQFP64 [(PEP+S680)]  
MB90F352SPFM@LQFP64(\*) [(SA739+B260)]  
MB90F372@LQFP144(\*) [(SA748+B14410)]  
MB90F377@LQFP144(\*) [(SA748+B14410)]  
MB90F387PMT@LQFP48 [(SA248)] MB90F387SPMT@LQFP48  
[(SA248)]  
MB90F394H@LQFP120(\*) [(TA036-B006)]  
MB90F395H@LQFP120(\*) [(TA036-B006)]  
MB90F423GA@LQFP100 [(PEP+S604)] MB90F423GA@QFP100 [(PEP  
+S427)]  
MB90F423GA@TQFP100(\*) [(SA718+BBBB)]  
MB90F423GB@LQFP100 [(PEP+S604)] MB90F423GB@QFP100 [(PEP  
+S427)]  
MB90F423GB@TQFP100(\*) [(SA718+BBBB)]  
MB90F423GC@LQFP100 [(PEP+S604)] MB90F423GC@QFP100 [(PEP  
+S427)]  
MB90F423GC@TQFP100(\*) [(SA718+BBBB)]  
MB90F428GA@LQFP100 [(PEP+S604)] MB90F428GA@QFP100 [(PEP  
+S427)]  
MB90F428GA@TQFP100(\*) [(SA718+BBBB)]  
MB90F428GB@LQFP100 [(PEP+S604)] MB90F428GB@QFP100 [(PEP  
+S427)]  
MB90F428GB@TQFP100(\*) [(SA718+BBBB)]  
MB90F428GC@LQFP100 [(PEP+S604)] MB90F428GC@QFP100 [(PEP  
+S427)]  
MB90F428GC@TQFP100(\*) [(SA718+BBBB)]  
MB90F438LPF@LQFP100 [(PEP+S427)]  
MB90F438LPFV@TQFP100 [(PEP+S604)]  
MB90F438LSPF@LQFP100 [(PEP+S427)]  
MB90F438LSPFV@TQFP100 [(PEP+S604)]  
MB90F439PF@LQFP100 [(PEP+S427)] MB90F439PFV@TQFP100 [(PEP  
+S604)]  
MB90F439SPF@LQFP100 [(PEP+S427)]  
MB90F439SPFV@TQFP100 [(PEP+S604)]  
MB90F455PMT@LQFP48 [(SA248)] MB90F455SPMT@LQFP48  
[(SA248)]  
MB90F456PMT@LQFP48 [(SA248)] MB90F456SPMT@LQFP48  
[(SA248)]  
MB90F457PMT@LQFP48 [(SA248)] MB90F457SPMT@LQFP48

[(SA248)]  
 MB90F462AP@SDIP64 [(PEP+S600A)]  
 MB90F462AP@SDIP64(\*) [(SA752+B307)]  
 MB90F462APF@QFP64 [(PEP+S735)] MB90F462APFM@LQFP64 [(PEP+S680)]  
 MB90F462APFM@LQFP64(\*) [(SA739+B245)]  
 MB90F462P@SDIP64 [(PEP+S600A)]  
 MB90F462P@SDIP64(\*) [(SA752+B307)]  
 MB90F462PF@QFP64 [(PEP+S735)] MB90F462PFM@LQFP64 [(PEP+S680)]  
 MB90F462PFM@LQFP64(\*) [(SA739+B245)]  
 MB90F463AP@SDIP64 [(PEP+S600A)]  
 MB90F463AP@SDIP64(\*) [(SA752+B307)]  
 MB90F463APF@QFP64 [(PEP+S735)] MB90F463APFM@LQFP64 [(PEP+S680)]  
 MB90F463APFM@LQFP64(\*) [(SA739+B245)]  
 MB90F474HPF@LQFP100 [(PEP+S427)] MB90F474HPFV@QFP100 [(PEP+S604)]  
 MB90F474LPF@LQFP100 [(PEP+S427)] MB90F474LPFV@QFP100 [(PEP+S604)]  
 MB90F481PF@LQFP100 [(PEP+S427)] MB90F481PFV@TQFP100 [(PEP+S604)]  
 MB90F482PF@LQFP100 [(PEP+S427)] MB90F482PFV@TQFP100 [(PEP+S604)]  
 MB90F488BPF@LQFP100 [(PEP+S427)]  
 MB90F488BPFV@TQFP100 [(PEP+S604)]  
 MB90F488BPFV@TQFP100(\*) [(SA773-B223A)]  
 MB90F489BPF@LQFP100 [(PEP+S427)]  
 MB90F489BPFV@TQFP100 [(PEP+S604)]  
 MB90F489BPFV@TQFP100(\*) [(SA773-B223A)]  
 MB90F497G@LQFP64 [(PEP+S680)] MB90F497G@LQFP64(\*)  
 [(TA070)]  
 MB90F497G@QFP64 [(PEP+S618)] MB90F497G@QFP64(\*)  
 [(TA070)]  
 MB90F498G@LQFP64 [(PEP+S680)] MB90F498G@LQFP64(\*)  
 [(TA070)]  
 MB90F498G@QFP64 [(PEP+S618)] MB90F498G@QFP64(\*)  
 [(TA070)]  
 MB90F543GPF@LQFP100 [(PEP+S427)]  
 MB90F543GPFV@TQFP100 [(PEP+S604)]  
 MB90F543GSPF@LQFP100 [(PEP+S427)]  
 MB90F543GSPFV@TQFP100 [(PEP+S604)]  
 MB90F543PF@LQFP100 [(PEP+S427)] MB90F543PFV@TQFP100 [(PEP

+S604) ]  
 MB90F546GPF@LQFP100 [(PEP+S427)]  
 MB90F546GPFV@TQFP100 [(PEP+S604)]  
 MB90F546GSPF@LQFP100 [(PEP+S427)]  
 MB90F546GSPFV@TQFP100 [(PEP+S604)]  
 MB90F548GPF@LQFP100 [(PEP+S427)]  
 MB90F548GPFV@TQFP100 [(PEP+S604)]  
 MB90F548GSPF@LQFP100 [(PEP+S427)]  
 MB90F548GSPFV@TQFP100 [(PEP+S604)]  
 MB90F549GPF@LQFP100 [(PEP+S427)]  
 MB90F549GPFV@TQFP100 [(PEP+S604)]  
 MB90F549GSPF@LQFP100 [(PEP+S427)]  
 MB90F549GSPFV@TQFP100 [(PEP+S604)]  
 MB90F549PF@LQFP100 [(PEP+S427)] MB90F549PFV@TQFP100 [(PEP  
 +S604) ]  
 MB90F553APF@QFP100 [(PEP+S427)]  
 MB90F553APFV@LQFP100 [(PEP+S604)]  
 MB90F562@LQFP64 [(PEP+S680)] MB90F562@LQFP64(\*)  
 [(TA070)]  
 MB90F562@QFP64 [(PEP+S618)] MB90F562@QFP64(\*)  
 [(TA070)]  
 MB90F562B@LQFP64 [(PEP+S680)] MB90F562B@LQFP64(\*)  
 [(TA070)]  
 MB90F562B@QFP64 [(PEP+S618)]  
 MB90F562B@QFP64(\*) [(SA758+B322)]  
 MB90F562B@SDIP64(\*) [(SA752+B307)]  
 MB90F568@LQFP64 [(PEP+S680)] MB90F568@QFP64 [(PEP  
 +S618) ]  
 MB90F568T@LQFP64 [(PEP+S680)] MB90F568T@QFP64 [(PEP  
 +S618) ]  
 MB90F583CAPF@LQFP100 [(PEP+S427)]  
 MB90F583CAPFV@TQFP100 [(PEP+S604)]  
 MB90F583CAPFV@TQFP100(\*) [(SA718+B223)]  
 MB90F583CPF@LQFP100 [(PEP+S427)]  
 MB90F583CPFV@TQFP100 [(PEP+S604)]  
 MB90F583CPFV@TQFP100(\*) [(SA718+B223)]  
 MB90F591APF@QFP100 [(PEP+S427)] MB90F591GPF@QFP100 [(PEP  
 +S427) ]  
 MB90F594APF@QFP100 [(PEP+S427)] MB90F594GPF@QFP100 [(PEP  
 +S427) ]  
 MB90F598GPF@PQFP100 [(PEP+S427)] MB90F598PF@PQFP100 [(PEP  
 +S427) ]  
 MB90F822PF@PQFP80 [(PEP+S611A)]

MB90F822PF@PQFP80(\*) [(SA756+B314)]  
MB90F822PFM@LQFP80 [(PEP+S704)] MB90F822PFV@LQFP80 [(PEP+S640B)]  
MB90F823PF@PQFP80 [(PEP+S611A)]  
MB90F823PF@PQFP80(\*) [(SA756+B314)]  
MB90F823PFM@LQFP80 [(PEP+S704)] MB90F823PFV@LQFP80 [(PEP+S640B)]  
MB90F867A@LQFP100 [(PEP+S427)] MB90F867A@TQFP100 [(PEP+S604)]  
MB90F867AS@LQFP100 [(PEP+S427)] MB90F867AS@TQFP100 [(PEP+S604)]  
MB90F882@LQFP100 [(PEP+S604)] MB90F884@LQFP100 [(PEP+S604)]  
MB90F897PMT@LQFP48 [(SA248)] MB90F897SPMT@LQFP48 [(SA248)]  
MB90F927@LQFP100 [(PEP+S604)] MB90F927@QFP100 [(PEP+S427)]  
MB90F927@QFP100(\*) [(SA753+B270)]  
MB90F927S@LQFP100 [(PEP+S604)] MB90F927S@QFP100 [(PEP+S427)]  
MB90F927S@QFP100(\*) [(SA753+B270)]  
MB90F947APF@QFP100(\*) [(SA753+B312)]  
MB90F947PF@QFP100(\*) [(SA753+B312)]  
MB90F949APF@QFP100(\*) [(SA753+B312)]  
MB90F949PF@QFP100(\*) [(SA753+B312)]  
MB90P663APFM@QFP64 [(PEP+S680)]  
MB95F108AHSPFM@LQFP64 [(PEP+S680)]  
MB95F108AHSPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108AHSPFV@LQFP64 [(PEP+S616)]  
MB95F108AHSPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108AHWPFM@LQFP64 [(PEP+S680)]  
MB95F108AHWPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108AHWPFV@LQFP64 [(PEP+S616)]  
MB95F108AHWPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108AKSPFM@LQFP64 [(PEP+S680)]  
MB95F108AKSPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108AKSPFV@LQFP64 [(PEP+S616)]  
MB95F108AKSPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108AKWPFM@LQFP64 [(PEP+S680)]  
MB95F108AKWPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108AKWPFV@LQFP64 [(PEP+S616)]  
MB95F108AKWPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108AMPFM@LQFP64 [(PEP+S680)]

MB95F108AMPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108AMPFV@LQFP64 [(PEP+S616)]  
MB95F108AMPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108AMWPFM@LQFP64 [(PEP+S680)]  
MB95F108AMWPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108AMWPFV@LQFP64 [(PEP+S616)]  
MB95F108AMWPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108ASPFM@LQFP64 [(PEP+S680)]  
MB95F108ASPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108ASPFV@LQFP64 [(PEP+S616)]  
MB95F108ASPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108ATSPFM@LQFP64 [(PEP+S680)]  
MB95F108ATSPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108ATSPFV@LQFP64 [(PEP+S616)]  
MB95F108ATSPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108ATWPFM@LQFP64 [(PEP+S680)]  
MB95F108ATWPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108ATWPFV@LQFP64 [(PEP+S616)]  
MB95F108ATWPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108AWPFM@LQFP64 [(PEP+S680)]  
MB95F108AWPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108AWPFV@LQFP64 [(PEP+S616)]  
MB95F108AWPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108HSPFM@LQFP64 [(PEP+S680)]  
MB95F108HSPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108HSPFV@LQFP64 [(PEP+S616)]  
MB95F108HSPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108HWPFM@LQFP64 [(PEP+S680)]  
MB95F108HWPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108HWPFV@LQFP64 [(PEP+S616)]  
MB95F108HWPFV@LQFP64(\*) [(SA732+B259)]  
MB95F118AS@LCC48 [(SA248)] MB95F118AS@LQFP52 [(PEP  
+S673)]  
MB95F118AS@LQFP52(\*) [(SA740+B267)]  
MB95F118AS@TQFP48 [(SA248)] MB95F118AW@LCC48  
[(SA248)]  
MB95F118AW@LQFP52 [(PEP+S673)]  
MB95F118AW@LQFP52(\*) [(SA740+B267)]  
MB95F118AW@TQFP48 [(SA248)] MB95F118HS@LQFP52 [(PEP  
+S673)]  
MB95F118HS@LQFP52(\*) [(SA740+B267)]  
MB95F118HW@LQFP52 [(PEP+S673)]  
MB95F118HW@LQFP52(\*) [(SA740+B267)]

MB95F118MS@LQFP52 [(PEP+S673)]  
MB95F118MS@LQFP52(\*) [(SA740+B267)]  
MB95F118MW@LQFP52 [(PEP+S673)]  
MB95F118MW@LQFP52(\*) [(SA740+B267)]  
MB95F118NS@LQFP52 [(PEP+S673)]  
MB95F118NS@LQFP52(\*) [(SA740+B267)]  
MB95F118NW@LQFP52 [(PEP+S673)]  
MB95F118NW@LQFP52(\*) [(SA740+B267)]  
MB95F118TS@LQFP52 [(PEP+S673)]  
MB95F118TS@LQFP52(\*) [(SA740+B267)]  
MB95F118TW@LQFP52 [(PEP+S673)]  
MB95F118TW@LQFP52(\*) [(SA740+B267)]  
MB95F128D@LQFP100 [(PEP+S604)]  
MB95F128D@LQFP100(\*) [(SA718+B324)]  
MB95F128D@QFP100 [(PEP+S427)]  
MB95F128D@QFP100(\*) [(SA753+B261)]  
MB95F128E@LQFP100 [(PEP+S604)]  
MB95F128E@LQFP100(\*) [(SA718+B324)]  
MB95F128E@QFP100 [(PEP+S427)]  
MB95F128E@QFP100(\*) [(SA753+B261)]  
MB95F128H@LQFP100 [(PEP+S604)]  
MB95F128H@LQFP100(\*) [(SA718+B324)]  
MB95F128H@QFP100 [(PEP+S427)]  
MB95F128H@QFP100(\*) [(SA753+B261)]  
MB95F128J@LQFP100(\*) [(SA718+B324)]  
MB95F128J@QFP100(\*) [(SA753+B261)]  
MB95F128M@LQFP100(\*) [(SA718+B324)]  
MB95F128M@QFP100(\*) [(SA753+B261)]  
MB95F128N@LQFP100(\*) [(SA718+B324)]  
MB95F128N@QFP100(\*) [(SA753+B261)]  
MB95F128T@LQFP100 [(PEP+S604)]  
MB95F128T@LQFP100(\*) [(SA718+B324)]  
MB95F128T@QFP100 [(PEP+S427)]  
MB95F128T@QFP100(\*) [(SA753+B261)]  
MB95F133HBS@SSOP30 [(SA689)] MB95F133HBW@SSOP30  
[(SA689)]  
MB95F133HS@SOP28 [(SA630)] MB95F133HW@SOP28  
[(SA630)]  
MB95F133JBS@SSOP30 [(SA689)] MB95F133JBW@SSOP30  
[(SA689)]  
MB95F133JS@SOP28 [(SA630)] MB95F133JW@SOP28  
[(SA630)]  
MB95F133MBS@SSOP30 [(SA689)] MB95F133MBW@SSOP30

[(SA689)]	
MB95F133MS@SOP28 [(SA630)]	MB95F133MW@SOP28
[(SA630)]	
MB95F133NBS@SSOP30 [(SA689)]	MB95F133NBW@SSOP30
[(SA689)]	
MB95F133NS@SOP28 [(SA630)]	MB95F133NW@SOP28
[(SA630)]	
MB95F133TBS@SSOP30 [(SA689)]	MB95F133TBW@SSOP30
[(SA689)]	
MB95F133TS@SOP28 [(SA630)]	MB95F133TW@SOP28
[(SA630)]	
MB95F134HBS@SSOP30 [(SA689)]	MB95F134HBW@SSOP30
[(SA689)]	
MB95F134HS@SOP28 [(SA630)]	MB95F134HW@SOP28
[(SA630)]	
MB95F134JBS@SSOP30 [(SA689)]	MB95F134JBW@SSOP30
[(SA689)]	
MB95F134JS@SOP28 [(SA630)]	MB95F134JW@SOP28
[(SA630)]	
MB95F134MBS@SSOP30 [(SA689)]	MB95F134MBW@SSOP30
[(SA689)]	
MB95F134MS@SOP28 [(SA630)]	MB95F134MW@SOP28
[(SA630)]	
MB95F134NBS@SSOP30 [(SA689)]	MB95F134NBW@SSOP30
[(SA689)]	
MB95F134NS@SOP28 [(SA630)]	MB95F134NW@SOP28
[(SA630)]	
MB95F134TBS@SSOP30 [(SA689)]	MB95F134TBW@SSOP30
[(SA689)]	
MB95F134TS@SOP28 [(SA630)]	MB95F134TW@SOP28
[(SA630)]	
MB95F136HBS@SSOP30 [(SA689)]	MB95F136HBW@SSOP30
[(SA689)]	
MB95F136HS@SOP28 [(SA630)]	MB95F136HW@SOP28
[(SA630)]	
MB95F136JBS@SSOP30 [(SA689)]	MB95F136JBW@SSOP30
[(SA689)]	
MB95F136JS@SOP28 [(SA630)]	MB95F136JW@SOP28
[(SA630)]	
MB95F136MBS@SSOP30 [(SA689)]	MB95F136MBW@SSOP30
[(SA689)]	
MB95F136MS@SOP28 [(SA630)]	MB95F136MW@SOP28
[(SA630)]	

MB95F136NBS@SSOP30 [(SA689)] MB95F136NBW@SSOP30  
[(SA689)]  
MB95F136NS@SOP28 [(SA630)] MB95F136NW@SOP28  
[(SA630)]  
MB95F136TBS@SSOP30 [(SA689)] MB95F136TBW@SSOP30  
[(SA689)]  
MB95F136TS@SOP28 [(SA630)] MB95F136TW@SOP28  
[(SA630)]  
MB95F156MPMC@LQFP52 [(PEP+S673)]  
MB95F156MPMC@LQFP52(\*) [(SA740+B304)]  
MB95F156MPMT@LQFP48 [(SA248)]  
MB95F156MPMT@LQFP48(\*) [(SA248+B4803)]  
MB95F156NPMC@LQFP52 [(PEP+S673)]  
MB95F156NPMC@LQFP52(\*) [(SA740+B304)]  
MB95F156NPMT@LQFP48 [(SA248)]  
MB95F156NPMT@LQFP48(\*) [(SA248+B4803)]  
MB95F168JPMC@LQFP64 [(PEP+S680)]  
MB95F168JPMC@LQFP64(\*) [(SA739+B288)]  
MB95F168JPMC1@LQFP64 [(PEP+S616)]  
MB95F168JPMC1@LQFP64(\*) [(SA732+B288)]  
MB95F168MPMC@LQFP64 [(PEP+S680)]  
MB95F168MPMC@LQFP64(\*) [(SA739+B288)]  
MB95F168MPMC1@LQFP64 [(PEP+S616)]  
MB95F168MPMC1@LQFP64(\*) [(SA732+B288)]  
MB95F168NPMC@LQFP64 [(PEP+S680)]  
MB95F168NPMC@LQFP64(\*) [(SA739+B288)]  
MB95F168NPMC1@LQFP64 [(PEP+S616)]  
MB95F168NPMC1@LQFP64(\*) [(SA732+B288)]  
MB95F176JSPMC@LQFP64 [(PEP+S680)]  
MB95F176JSPMC@LQFP64(\*) [(SA739+B305)]  
MB95F176JSPMC1@LQFP64 [(PEP+S616)]  
MB95F176JSPMC1@LQFP64(\*) [(SA739+B305)]  
MB95F176JWPMC@LQFP64 [(PEP+S680)]  
MB95F176JWPMC@LQFP64(\*) [(SA732+B305)]  
MB95F176JWPMC1@LQFP64 [(PEP+S616)]  
MB95F176JWPMC1@LQFP64(\*) [(SA732+B305)]  
MBL8742H  
MBL8742N  
MBL8749H  
MBL8749N

## GENCORE



## MICROCONTROLLER

GC87C520A0 [ (SA244) ]	GC87C520A0@PLCC44
GC87C520A0@TQFP44 [ (SA245A) ]	
GC87C520G0 GC87C520G0@PLCC44 [ (SA244) ] [ (SA245A) ]	GC87C520G0@TQFP44

## GENERAL(GI)

### E ( E ) PROM / FRAM / NVRAM

27256  
27C128  
27C128@PLCC32 [ (SA015A1T) ]  
27C256  
27C256@PLCC32 [ (SA015A1T) ]  
27C512  
27C513  
27C64  
27C64@PLCC32 [ (SA015A1T) ]  
27HC191  
27HC291  
27HC64  
27HC641  
27HC641L  
27HC64L  
28C04  
28C04A  
28C04F  
28C16  
28C16A  
28C16F  
28C17  
28C17F  
ER5911  
ER5911@SOIC8 [ (SA602A) ]  
GI5911  
GI5911@SOIC8 [ (SA602A) ]  
GI59C11

GI59C11@SOIC8 [ (SA602A) ]  
GI59C12  
GI59C12@SOIC8 [ (SA602A) ]  
GR27C513

## GENERIC

### E (E) PROM / FRAM / NVRAM

27128 (21V) (12.5V)	27128A
2716 (25V) (12.5V)	27256
2732 (25V) (21V)	2732A
2732B (12.5V) (12.5V)	27512
27512 (21V) (21V)	2764
2764A (12.5V) (12.5V)	27C128
27C128 (21V) (25V)	27C16
27C256 (12.5V) (25V)	27C32
27C512 (12.5V) (12.5V)	27C64
27C64 (21V)	

## GOAL

### MICROCONTROLLER

VRS1000 [ (SA244) ]	VRS1000@PLCC44
VRS1000@TQFP44 [ (SA245A) ]	
VRS1050 VRS1050@PLCC44 [ (SA244) ] [ (SA675) ]	VRS1050@TQFP44
VRS1100	VRS1100@PLCC44

[ ( SA244 ) ]  
VRS1100@TQFP44 [ ( SA245A ) ]  
VRS540  
VRS540@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]  
VRS550  
[ ( SA244 ) ]  
VRS550@TQFP44 [ ( SA245A ) ]  
VRS560  
VRS560@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]  
VRS570  
[ ( SA244 ) ]  
VRS570@TQFP44 [ ( SA245A ) ]  
VRS580  
VRS580@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]  
VRS700  
[ ( SA244 ) ]  
VRS700@TQFP44 [ ( SA245A ) ]  
VRS900  
VRS900@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]

VRS540@TQFP44  
  
VRS550@PLCC44  
  
VRS560@TQFP44  
  
VRS570@PLCC44  
  
VRS580@TQFP44  
  
VRS700@PLCC44  
  
VRS900@TQFP44

## GOULD

### PLD

PEEL18CV8  
[ ( SA001A ) ]  
PEEL18CV8@SOIC20 [ ( SA404 ) ]  
[ ( SA026 ) ]

PEEL18CV8@PLCC20  
  
PEEL18CV8@TSOP20

## GREENWICH

### E ( E ) PROM / FRAM / NVRAM

GR27128  
GR27256  
GR27512

GR2764

**HAIER****MICROCONTROLLER**

HCM87CP311SP@SDIP42 [(SA028)]  
 HR6P60P2DL  
 HR6P60P2SL@SOP20 [(SA404)] HR6P60P2SL@SSOP20  
 [(SA626A)]  
 HR6P62P4D  
 HR6P62P4DH  
 HR6P62P4DHL HR6P62P4DHL  
 (INTOSC)  
 HR6P62P4SH@SOP20 [(SA404+B003)]  
 HR6P62P4SHL(INTOSC)@SOP20 [(SA404+B003)]  
 HR6P62P4SHL@SOP20 [(SA404+B003)]  
 HR6P62P4XHL(INTOSC)@SOP18 [(SA404+B003)]  
 HR6P62P4XHL@SOP18 [(SA404+B003)] HR6P62P4YHL@SOIC14  
 [(SA602)]  
 HR6P67P4D  
 HR6P67P4DL  
 HR6P67P4DL(REVERSE)  
 HR6P67P4SL(REVERSE)@SOP14 [(SA404+B003)]  
 HR6P67P4SL@SOP14 [(SA404+B003)]  
 HR6P71F8D  
 HR6P71F8D(REVERSE)  
 HR6P71F8S(REVERSE)@SOP20 [(SA404)]  
 HR6P71F8S@SOP20 [(SA404)]  
 HR6P72P4D  
 HR6P72P4DL HR6P72P4S@SOP28 [(SA404  
 +B003)]  
 HR6P72P4SL@SOP28 [(SA404+B003)]  
 HR6P73P8DB  
 HR6P73P8DBL HR6P73P8SB@SOP28 [(SA404  
 +B003)]  
 HR6P73P8SBL@SOP28 [(SA404-B003)]  
 HR6P73PGD  
 HR6P73PGDH  
 HR6P73PGDHL  
 HR6P73PGS@SOP28 [(SA404+B003)] HR6P73PGSH@SOP28 [(SA404  
 +B003)]

HR6P73PGSHL@SOP28 [ (SA404-B003) ]  
HR6P76PGD  
HR6P76PGDL  
+B003) ]  
HR6P76PGSL@SOP28 [ (SA404-B003) ]  
HR6P77PGD  
HR6P77PGDL  
+B005) ]  
HR6P77PGLL@LQFP44 [ (SA245-B005) ]  
+B006) ]  
HR6P90FGD  
[ (SA404) ]  
HR6P90FHD  
[ (SA404) ]  
HR6P91FGS@SOP32 [ (SA715) ]  
[ (SA715) ]  
HR6P92FGD  
[ (SA245A) ]  
HR6P92FHD  
[ (SA245A) ]  
HR6P95F8D  
[ (SA404) ]  
HR7T46P8V@SDIP42 [ (SA028) ]  
+B005) ]  
HR7T47P8L@LQFP44 [ (SA245A) ]  
+B005) ]

HR6P76PGS@SOP28 [ (SA404  
HR6P77PGL@LQFP44 [ (SA245  
HR6P78P4SL@SOP32 [ (SA715  
HR6P90FGS@SOP28  
HR6P90FHS@SOP28  
HR6P91FHS@SOP32  
HR6P92FGL@LQFP44  
HR6P92FHL@LQFP44  
HR6P95F8S@SOP28  
HR7T46PGV@SDIP42 [ (SA028  
HR7T47PGL@LQFP44 [ (SA245A

## HARRIS

### BPROM

7610A  
7611A

### DRAM & SRAM

HM6516  
[ (SA015A1T) ]  
HM65162  
[ (SA015A1T) ]  
HM65642

HM6516@PLCC32  
HM65162@PLCC32  
HM65642@TSOP28

[ ( SA643 ) ]

# HITACHI

## E ( E ) PROM / FRAM / NVRAM

HN27128AG

HN27128AP

HN27256G

HN27256P

HN27512G

HN27512P

HN27C101AG

HN27C101AP

HN27C101G

HN27C101P

HN27C1024HG

HN27C1024HG@PLCC44

[ ( SA244 ) ]

HN27C256AG

HN27C256FP

HN27C256G

HN27C256HG

HN27C301AG

HN27C301AP

HN27C301G

HN27C301P

HN27C4000FP

HN27C4000G

HN27C4001

HN27C4001@TSOP32

[ ( SA410T ) ]

HN27C4001G

HN27C4096A

HN27C4096A@PLCC44 [ ( SA244 ) ]

HN27C4096FP

HN27C4096FP@PLCC44 [ ( SA244 ) ]

HN27C4096G

HN27C4096G@PLCC44 [ ( SA244 ) ]

HN27C512G

HN27C512G@PLCC32 [ ( SA015A1T ) ]

HN27C64G

HN28F101

HN28F101@PLCC32

[ ( SA015A1T ) ]

HN28F101@SOP32 [(SA438T)]	HN28F101@TSOP32
[(SA410T)]	
HN29A128A0A@CSP95 [(SA642A-B066A-Y096N001)]	
HN29A128A0A@TSOP48 [(SA247-B005)]	
HN29V128A0A@CSP95 [(SA642A-B066A-Y096N001)]	
HN29V128A0A@TSOP48 [(SA247-B005)]	
HN29V128A0E@CSP95 [(SA642A-B066A-Y096N001)]	
HN29V51211@TSOP48 [(SA247-B005)]	
HN462716G	
HN462732G	HN48016
(P)	
HN4827128G	
HN4827128P	
HN482732AG	
HN482764G	
HN482764P	HN58064(FP)@SOIC28
[(SA404)]	
HN58064(P)	HN58C1001(FP)@SSOP32
[(SA438T)]	
HN58C1001(P)	HN58C1001(T)@VSOP32
[(SA620)]	
HN58C256A(FP)@SOP28 [(SA630)]	HN58C256A
(P)	
HN58C256A(T)@TSOP28 [(SA643)]	HN58C257A(T)@TSOP32
[(SA620)]	
HN58C65(FP)@SOIC28 [(SA404)]	HN58C65
(P)	
HN58C66	HN58C66@SOP28
[(SA630)]	
HN58C66@TSOP28 [(SA430T)]	
HN58V24256	
HN58V24256@SOIC8 [(SA602A)]	HN58V24256@TSSOP14
[(SA026)]	
HN58V24512	HN58V24512@SOIC8
[(SA602A)]	
HN58V256A	HN58V256A@TSOP28
[(SA430T)]	
HN58V65A	HN58V65A@SOIC28
[(SA630)]	
HN58V65A@TSOP28 [(SA430T)]	
HN58V66A	
HN58V66A@SOIC28 [(SA630)]	HN58V66A@TSOP28
[(SA430T)]	

HN58W241000 [ ( SA602A ) ]	HN58W241000@SOIC8
HN58X2402 [ ( SA602A ) ]	HN58X2402@SOIC8
HN58X2402@TSSOP8 [ ( SA026 ) ]	
HN58X2404 HN58X2404@SOIC8 [ ( SA602A ) ]	HN58X2404@TSSOP8
[ ( SA026 ) ]	
HN58X2408 [ ( SA602A ) ]	HN58X2408@SOIC8
HN58X2408@TSSOP8 [ ( SA026 ) ]	
HN58X24128 HN58X24128@SOIC8 [ ( SA602A ) ]	
HN58X2416 HN58X2416@SOIC8 [ ( SA602A ) ]	HN58X2416@TSSOP8
[ ( SA026 ) ]	
HN58X24256 [ ( SA602A ) ]	HN58X24256@SOIC8
HN58X2432 [ ( SA602A ) ]	HN58X2432@SOIC8
HN58X2432@TSSOP8 [ ( SA026 ) ]	
HN58X24512 HN58X24512@SOIC8 [ ( SA602A ) ]	
HN58X2464 HN58X2464@SOIC8 [ ( SA602A ) ]	HN58X2464@TSSOP8
[ ( SA026 ) ]	
HN58X2502@SOIC8 [ ( SA602A ) ]	HN58X2502@TSSOP8
[ ( SA026 ) ]	
HN58X2504@SOIC8 [ ( SA602A ) ]	HN58X2504@TSSOP8
[ ( SA026 ) ]	
HN58X25128@SOIC8 [ ( SA602A ) ]	HN58X25128@TSSOP14
[ ( SA026 ) ]	
HN58X25256@SOIC8 [ ( SA602A ) ]	HN58X25256@TSSOP14
[ ( SA026 ) ]	
HN58X2532@SOIC8 [ ( SA602A ) ]	HN58X2532@TSSOP8
[ ( SA026 ) ]	
HN58X2564@SOIC8 [ ( SA602A ) ]	HN58X2564@TSSOP8
[ ( SA026 ) ]	
HT29VB800@TSOP48 [ ( SA247-B005 ) ]	HT29VT800@TSOP48 [ ( SA247-B005 ) ]
HT29WB800@TSOP48 [ ( SA247-B005 ) ]	HT29WT800@TSOP48 [ ( SA247-B005 ) ]
V128128A0E@CSP95 [ ( SA642A-B105A-Y096N001 ) ]	



**DRAM & SRAM**

HM6116	HM6116@PLCC32
[ (SA015A1T) ]	
HM6116A	HM6116A@PLCC32
[ (SA015A1T) ]	
HM6208	HM6208@SOJ24
[ (SA646) ]	
HM6208H	HM6208H@SOJ24
[ (SA646) ]	
HM62256	HM62256@TSOP28
[ (SA643) ]	
HM62256B	HM62256B@TSOP28
[ (SA643) ]	
HM624256	HM624256@SOJ28
[ (SA646) ]	
HM6264A	HM6264A@TSOP28
[ (SA643) ]	
HM6267	
HM6268	
HM628128	HM628128@TSOP32
[ (SA410T) ]	
HM628128A	HM628128A@TSOP32
[ (SA410T) ]	
HM62832	HM62832@TSOP28
[ (SA643) ]	
HM62832H	HM62832H@TSOP28
[ (SA643) ]	
HM628512	HM628512@TSOP32
[ (SA729) ]	
HM6287	
HM6287HP	
HM6288	HM6288@SOJ22
[ (SA646) ]	
HM65256B	HM65256B@TSOP28
[ (SA643) ]	
HM658128	HM658128@TSOP32
[ (SA410T) ]	
HM66204	HM66204@TSOP32
[ (SA410T) ]	
HM6707	HM6707@SOJ24

[ ( SA646 ) ]	
HM6707A	HM6707A@SOJ24
[ ( SA646 ) ]	
HM6708	HM6708@SOJ24
[ ( SA646 ) ]	
HM6708A	HM6708A@SOJ24
[ ( SA646 ) ]	
HM6716	HM6716@PLCC32
[ ( SA015A1T ) ]	
HM6787	
HM6787HP	
HM6788	HM6788@SOJ22
[ ( SA646 ) ]	
HM6788H	HM6788H@SOJ22
[ ( SA646 ) ]	
HM6788HA	HM6788HA@SOJ22
[ ( SA646 ) ]	

## MICROCONTROLLER

HD4074344@SDIP28 [ ( SA022A ) ]	HD4074344@SOIC28
[ ( SA404 ) ]	
HD4074394@SDIP28 [ ( SA022A ) ]	HD4074394@SOIC28
[ ( SA404 ) ]	
HD63701V0C	
HD63701V0P	
HD63701X0C@SDIP64 ( * ) [ ( SA752+B265 ) ]	
HD63701X0P@SDIP64 ( * ) [ ( SA752+B265 ) ]	
HD63701Y0	
HD63701Y0C	
HD63701Y0C@SDIP64 ( * ) [ ( SA752+B265 ) ]	
HD63701Y0P@SDIP64 ( * ) [ ( SA752+B265 ) ]	
HD637A01V0C	
HD637A01V0P	
HD637A01X0C@SDIP64 ( * ) [ ( SA752+B265 ) ]	
HD637A01X0P@SDIP64 ( * ) [ ( SA752+B265 ) ]	
HD637A01Y0C@SDIP64 ( * ) [ ( SA752+B265 ) ]	
HD637A01Y0P@SDIP64 ( * ) [ ( SA752+B265 ) ]	
HD637B01V0C	
HD637B01V0P	
HD637B01X0C@SDIP64 ( * ) [ ( SA752+B265 ) ]	
HD637B01X0P@SDIP64 ( * ) [ ( SA752+B265 ) ]	

HD637B01Y0C@SDIP64(\*) [(SA752+B265)]  
HD637B01Y0P@SDIP64(\*) [(SA752+B265)]  
HD6472357F@PQFP128(\*) [(SA720+B262)]  
HD6472655F@PQFP128(\*) [(SA720+B175)]  
HD6472655TE@TQFP128(\*) [(SA721+B174)]  
HD6472655VF@PQFP128(\*) [(SA720+B175)]  
HD6472655VTE@TQFP128(\*) [(SA721+B174)]  
HD6473228P@SDIP64(\*) [(SA736-B229)]  
HD6473238P@SDIP64(\*) [(SA736-B229)]  
HD6473258P@SDIP64(\*) [(SA736-B229)]  
HD6473308@PLCC84(\*) [(SA649-B8406)]  
HD6473644@TQFP64 [(PEP+S621)]  
HD64738024F(FP-80B)(\*) [(TA006-B006)]  
HD64738024H(FP-80A)(\*) [(TA008-B006)]  
HD64738024W(TFP-80C)(\*) [(TA007-B006)]  
HD6473877H@TQFP100(\*) [(SA718+B202)]  
HD6475328@PLCC84(\*) [(SA649-B8404)]  
HD6475348@PLCC84(\*) [(SA649-B8404)]  
HD6477034F@QFP112(\*) [(SA738+B213)]  
HD64F2110BFA@QFP100 [(SA718-B299)]  
HD64F2110BTE@QFP100 [(SA718-B299)]  
HD64F2110BVFA@QFP100 [(SA718-B299)]  
HD64F2110BVTE@QFP100 [(SA718-B299)]  
HD64F2138AFA@TQFP80 [(PEP+S615B)]  
HD64F2138ATF@TQFP80 [(PEP+S640B)]  
HD64F2140BVFA@TQFP100 [(PEP+S604)]  
HD64F2140BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2140BVTE@TQFP100 [(PEP+S604)]  
HD64F2140BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2141BVFA@TQFP100 [(PEP+S604)]  
HD64F2141BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2141BVTE@TQFP100 [(PEP+S604)]  
HD64F2141BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2142RFA@TQFP100 [(PEP+S604)]  
HD64F2142RFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2142RTE@TQFP100 [(PEP+S604)]  
HD64F2142RTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2142RVFA@TQFP100 [(PEP+S604)]  
HD64F2142RVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2142RVTE@TQFP100 [(PEP+S604)]  
HD64F2142RVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144AFA@TQFP100 [(PEP+S604)]  
HD64F2144AFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]

HD64F2144ATE@TQFP100 [(PEP+S604)]  
HD64F2144ATE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144AVFA@TQFP100 [(PEP+S604)]  
HD64F2144AVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144AVTE@TQFP100 [(PEP+S604)]  
HD64F2144AVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144FA@TQFP100 [(PEP+S604)]  
HD64F2144FA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144TE@TQFP100 [(PEP+S604)]  
HD64F2144TE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144VFA@TQFP100 [(PEP+S604)]  
HD64F2144VFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144VTE@TQFP100 [(PEP+S604)]  
HD64F2144VTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2145BVFA@TQFP100 [(PEP+S604)]  
HD64F2145BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2145BVTE@TQFP100 [(PEP+S604)]  
HD64F2145BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147AFA@TQFP100 [(PEP+S604)]  
HD64F2147AFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147ATE@TQFP100 [(PEP+S604)]  
HD64F2147ATE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147AVFA@TQFP100 [(PEP+S604)]  
HD64F2147AVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147AVTE@TQFP100 [(PEP+S604)]  
HD64F2147AVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147NFA@TQFP100 [(PEP+S604)]  
HD64F2147NFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147NTE@TQFP100 [(PEP+S604)]  
HD64F2147NTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147NVFA@TQFP100 [(PEP+S604)]  
HD64F2147NVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147NVTE@TQFP100 [(PEP+S604)]  
HD64F2147NVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148AFA@TQFP100 [(PEP+S604)]  
HD64F2148AFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148ATE@TQFP100 [(PEP+S604)]  
HD64F2148ATE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148AVFA@TQFP100 [(PEP+S604)]  
HD64F2148AVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148AVTE@TQFP100 [(PEP+S604)]  
HD64F2148AVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BFA@TQFP100 [(PEP+S604)]

HD64F2148BFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BTE@TQFP100 [(PEP+S604)]  
HD64F2148BTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BVFA@TQFP100 [(PEP+S604)]  
HD64F2148BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BVTE@TQFP100 [(PEP+S604)]  
HD64F2148BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148FA@TQFP100 [(PEP+S604)]  
HD64F2148FA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148TE@TQFP100 [(PEP+S604)]  
HD64F2148TE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148VFA@TQFP100 [(PEP+S604)]  
HD64F2148VFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148VTE@TQFP100 [(PEP+S604)]  
HD64F2148VTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2149YFA@TQFP100 [(PEP+S604)]  
HD64F2149YFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2149YTE@TQFP100 [(PEP+S604)]  
HD64F2149YTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2166VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2167VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2168VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2177VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2265FA13@TQFP100 [(PEP+S604)]  
HD64F2265FA20@TQFP100 [(PEP+S604)]  
HD64F2265TE13@TQFP100 [(PEP+S604)]  
HD64F2265TE20@TQFP100 [(PEP+S604)]  
HD64F2265TF13@TQFP100 [(PEP+S604)]  
HD64F2265TF20@TQFP100 [(PEP+S604)]  
HD64F2266FA13@TQFP100 [(PEP+S604)]  
HD64F2266FA20@TQFP100 [(PEP+S604)]  
HD64F2266TE13@TQFP100 [(PEP+S604)]  
HD64F2266TE20@TQFP100 [(PEP+S604)]  
HD64F2266TF13@TQFP100 [(PEP+S604)]  
HD64F2266TF20@TQFP100 [(PEP+S604)]  
HD64F2268FA13@TQFP100 [(PEP+S604)]  
HD64F2268FA20@TQFP100 [(PEP+S604)]  
HD64F2268TE13@TQFP100 [(PEP+S604)]  
HD64F2268TE20@TQFP100 [(PEP+S604)]  
HD64F2268TF13@TQFP100 [(PEP+S604)]  
HD64F2268TF20@TQFP100 [(PEP+S604)]  
HD64F2280@PQFP100(\*) [(TA046-B006)]  
HD64F2282@PQFP100(\*) [(TA046-B006)]

HD64F2326VF@PQFP128(\*) [(SA720+B281)]  
HD64F2326VTE@TQFP120(\*) [(SA721+B282)]  
HD64F2328BVF@PQFP128(\*) [(SA720+B281)]  
HD64F2328BVTE@TQFP120(\*) [(SA721+B282)]  
HD64F2328VF@PQFP128(\*) [(SA720+B281)]  
HD64F2328VTE@TQFP120(\*) [(SA721+B282)]  
HD64F2329BVF@PQFP128(\*) [(SA720+B281)]  
HD64F2329BVTE@TQFP120(\*) [(SA721+B282)]  
HD64F2329EVF@PQFP128(\*) [(SA720+B281)]  
HD64F2329EVTE@TQFP120(\*) [(SA721+B282)]  
HD64F2329VF@PQFP128(\*) [(SA720+B281)]  
HD64F2329VTE@TQFP120(\*) [(SA721+B282)]  
HD64F2338VF@TQFP144(\*) [(SA681+B14415)]  
HD64F2339EVF@TQFP144(\*) [(SA681+B14415)]  
HD64F2339VF@TQFP144(\*) [(SA681+B14415)]  
HD64F2357F@PQFP128(\*) [(SA720+B193)]  
HD64F2357TE@QFP120(\*) [(SA721+B194)]  
HD64F2377@TQFP144(\*) [(SA681-B14408)]  
HD64F2377R@TQFP144(\*) [(SA681-B14408)]  
HD64F2378@TQFP144(\*) [(SA681-B14408)]  
HD64F2378R@TQFP144(\*) [(SA681-B14408)]  
HD64F2398F@PQFP128(\*) [(SA720+B193)]  
HD64F2398TE@QFP120(\*) [(SA721+B194)]  
HD64F2505FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2506FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2551FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2552FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2556FC20@QFP144(\*) [(SA681+B14403)]  
HD64F2612FA20@TQFP80(\*) [(SA722+B176)]  
HD64F2615F20@TQFP80(\*) [(SA722+B176)]  
HD64F2615F24@TQFP80(\*) [(SA722+B176)]  
HD64F2646RFC20@QFP144(\*) [(SA681+B14404)]  
HD64F2648RFC20@QFP144(\*) [(SA681+B14404)]  
HD64F2649FC20@QFP144(\*) [(SA681+B14404)]  
HD64F2667VFQ33@QFP144(\*) [(SA681+B14402)]  
HD64F3024F@TQFP100(\*) [(TA029-B006)]  
HD64F3024FP@PQFP100(\*) [(TA030-B006)]  
HD64F3024TE@TQFP100(\*) [(TA029-B006)]  
HD64F3026F@TQFP100(\*) [(TA029-B006)]  
HD64F3026FP@PQFP100(\*) [(TA030-B006)]  
HD64F3026TE@TQFP100(\*) [(TA029-B006)]  
HD64F3048BF@TQFP100(\*) [(TA029-B006)]  
HD64F3048BTE@TQFP100(\*) [(TA029-B006)]

HD64F3048BVF@TQFP100(\*) [(TA029-B006)]  
HD64F3048BVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3048F@TQFP100(\*) [(TA067+B006)]  
HD64F3048TF@TQFP100(\*) [(TA067+B006)]  
HD64F3048VF@TQFP100(\*) [(TA067+B006)]  
HD64F3048VTF@TQFP100(\*) [(TA067+B006)]  
HD64F3052BF@TQFP100(\*) [(TA029-B006)]  
HD64F3052BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3052BVF@TQFP100(\*) [(TA029-B006)]  
HD64F3052BVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3052F@TQFP100(\*) [(TA029-B006)]  
HD64F3052TE@TQFP100(\*) [(TA029-B006)]  
HD64F3062BF@TQFP100(\*) [(TA029-B006)]  
HD64F3062BFP@PQFP100(\*) [(TA030-B006)]  
HD64F3062BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3062F@TQFP100(\*) [(TA029-B006)]  
HD64F3062FP@PQFP100(\*) [(TA030-B006)]  
HD64F3062RF@TQFP100(\*) [(TA029-B006)]  
HD64F3062RFP@PQFP100(\*) [(TA030-B006)]  
HD64F3062RTE@TQFP100(\*) [(TA029-B006)]  
HD64F3062RVF@TQFP100(\*) [(TA029-B006)]  
HD64F3062RVFP@PQFP100(\*) [(TA030-B006)]  
HD64F3062RVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3062TE@TQFP100(\*) [(TA029-B006)]  
HD64F3064BF@TQFP100(\*) [(TA029-B006)]  
HD64F3064BFP@PQFP100(\*) [(TA030-B006)]  
HD64F3064BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3064F@TQFP100(\*) [(TA029-B006)]  
HD64F3064FP@PQFP100(\*) [(TA030-B006)]  
HD64F3064TE@TQFP100(\*) [(TA029-B006)]  
HD64F3067F@TQFP100(\*) [(TA029-B006)]  
HD64F3067FP@PQFP100(\*) [(TA030-B006)]  
HD64F3067RF@TQFP100(\*) [(TA029-B006)]  
HD64F3067RFP@PQFP100(\*) [(TA030-B006)]  
HD64F3067RTE@TQFP100(\*) [(TA029-B006)]  
HD64F3067RVF@TQFP100(\*) [(TA029-B006)]  
HD64F3067RVFP@PQFP100(\*) [(TA030-B006)]  
HD64F3067RVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3067TE@TQFP100(\*) [(TA029-B006)]  
HD64F3068F@TQFP100(\*) [(TA029-B006)]  
HD64F3068TE@TQFP100(\*) [(TA029-B006)]  
HD64F3069F@TQFP100(\*) [(SA718+B271)]  
HD64F3069RF@TQFP100(\*) [(SA718+B271)]

HD64F3069RTE@TQFP100(\*) [(SA718+B271)]  
HD64F3069TE@TQFP100(\*) [(SA718+B271)]  
HD64F3334YCP16@PLCC84(\*) [(SA649-B8402)]  
HD64F3334YF16@TQFP80(\*) [(TA018-B006)]  
HD64F3334YFLH16@TQFP80(\*) [(TA018-B006)]  
HD64F3334YTF16@TQFP80(\*) [(TA019-B006)]  
HD64F3334YTFLH16@TQFP80(\*) [(TA019-B006)]  
HD64F3337YCP16@PLCC84(\*) [(SA649-B8402)]  
HD64F3337YF16@TQFP80(\*) [(TA018-B006)]  
HD64F3337YFLH16@TQFP80(\*) [(TA018-B006)]  
HD64F3337YTF16@TQFP80(\*) [(TA019-B006)]  
HD64F3337YTFLH16@TQFP80(\*) [(TA019-B006)]  
HD64F3394YCP16@PLCC84(\*) [(SA649-B8402)]  
HD64F3394YF16@TQFP80(\*) [(TA018-B006)]  
HD64F3394YFLH16@TQFP80(\*) [(TA018-B006)]  
HD64F3394YTF16@TQFP80(\*) [(TA019-B006)]  
HD64F3394YTFLH16@TQFP80(\*) [(TA019-B006)]  
HD64F3397CP17@PLCC84(\*) [(SA649-B8402)]  
HD64F3397F17@TQFP80(\*) [(TA018-B006)]  
HD64F3397FLH17@TQFP80(\*) [(TA018-B006)]  
HD64F3397TF17@TQFP80(\*) [(TA019-B006)]  
HD64F3397TFLH17@TQFP80(\*) [(TA019-B006)]  
HD64F3434F@QFP100(\*) [(SA718+B306)]  
HD64F3434TF@QFP100(\*) [(SA718+B306)]  
HD64F3437F@QFP100(\*) [(SA718+B306)]  
HD64F3437TF@QFP100(\*) [(SA718+B306)]  
HD64F36012FX@TQFP48 [(SA671)] HD64F36012FY@TQFP48  
[(SA248)]  
HD64F36012GFP@TQFP64 [(SA732+B313)]  
HD64F36012GFX@TQFP48 [(SA671)] HD64F36012GFY@TQFP48  
[(SA248)]  
HD64F36014FX@TQFP48 [(SA671)] HD64F36014FY@TQFP48  
[(SA248)]  
HD64F36014GFP@TQFP64 [(SA732+B313)]  
HD64F36014GFX@TQFP48 [(SA671)] HD64F36014GFY@TQFP48  
[(SA248)]  
HD64F36022FX@TQFP48 [(SA671)] HD64F36022FY@TQFP48  
[(SA248)]  
HD64F36022GFP@TQFP64 [(SA732+B313)]  
HD64F36022GFX@TQFP48 [(SA671)] HD64F36022GFY@TQFP48  
[(SA248)]  
HD64F36024FX@TQFP48 [(SA671)] HD64F36024FY@TQFP48  
[(SA248)]



HD64F36024GFP@TQFP64 [(SA732+B313)]  
HD64F36024GFX@TQFP48 [(SA671)] HD64F36024GFY@TQFP48  
[(SA248)]  
HD64F36034FZ@TQFP64(\*) [(TA043-B006)]  
HD64F36034GFZ@TQFP64(\*) [(TA043-B006)]  
HD64F36034GH@TQFP64(\*) [(TA042-B006)]  
HD64F36034H@TQFP64(\*) [(TA042-B006)]  
HD64F36037FZ@TQFP64(\*) [(TA043-B006)]  
HD64F36037GFZ@TQFP64(\*) [(TA043-B006)]  
HD64F36037GH@TQFP64(\*) [(TA042-B006)]  
HD64F36037H@TQFP64(\*) [(TA042-B006)]  
HD64F36054FZ@TQFP64(\*) [(TA043-B006)]  
HD64F36054GFZ@TQFP64(\*) [(TA043-B006)]  
HD64F36054GH@TQFP64(\*) [(TA042-B006)]  
HD64F36054H@TQFP64(\*) [(TA042-B006)]  
HD64F36057FZ@TQFP64(\*) [(TA043-B006)]  
HD64F36057GFZ@TQFP64(\*) [(TA043-B006)]  
HD64F36057GH@TQFP64(\*) [(TA042-B006)]  
HD64F36057H@TQFP64(\*) [(TA042-B006)]  
HD64F36064GFP@TQFP64(\*) [(TA043-B006)]  
HD64F36064GH@TQFP64(\*) [(TA042-B006)]  
HD64F36074GFZ@QFP64(\*) [(SA757-B235)]  
HD64F36074GFZW@QFP64(\*) [(SA757-B235)]  
HD64F36074GH@QFP64(\*) [(SA757-B235)]  
HD64F36074GHW@QFP64(\*) [(SA757-B235)]  
HD64F36074LFZ@LQFP64(\*) [(SA732-B235)]  
HD64F36074LFZW@LQFP64(\*) [(SA732-B235)]  
HD64F36074LH@LQFP64(\*) [(SA732-B235)]  
HD64F36074LHW@LQFP64(\*) [(SA732-B235)]  
HD64F36077GFZ@QFP64(\*) [(SA757-B235)]  
HD64F36077GFZW@QFP64(\*) [(SA757-B235)]  
HD64F36077GH@QFP64(\*) [(SA757-B235)]  
HD64F36077GHW@QFP64(\*) [(SA757-B235)]  
HD64F36077LFZ@LQFP64(\*) [(SA732-B235)]  
HD64F36077LFZW@LQFP64(\*) [(SA732-B235)]  
HD64F36077LH@LQFP64(\*) [(SA732-B235)]  
HD64F36077LHW@LQFP64(\*) [(SA732-B235)]  
HD64F36078GFZ@QFP64(\*) [(SA757-B235)]  
HD64F36078GFZW@QFP64(\*) [(SA757-B235)]  
HD64F36078GH@QFP64(\*) [(SA757-B235)]  
HD64F36078GHW@QFP64(\*) [(SA757-B235)]  
HD64F36078LFZ@LQFP64(\*) [(SA732-B235)]  
HD64F36078LFZW@LQFP64(\*) [(SA732-B235)]

HD64F36078LH@LQFP64(\*) [(SA732-B235)]  
 HD64F36078LHW@LQFP64(\*) [(SA732-B235)]  
 HD64F36079GFZ@QFP64(\*) [(SA757-B235)]  
 HD64F36079GFZW@QFP64(\*) [(SA757-B235)]  
 HD64F36079GH@QFP64(\*) [(SA757-B235)]  
 HD64F36079GHW@QFP64(\*) [(SA757-B235)]  
 HD64F36079LFZ@LQFP64(\*) [(SA732-B235)]  
 HD64F36079LFZW@LQFP64(\*) [(SA732-B235)]  
 HD64F36079LH@LQFP64(\*) [(SA732-B235)]  
 HD64F36079LHW@LQFP64(\*) [(SA732-B235)]  
 HD64F3642AH@QFP64(\*) [(SA668+B275)]  
 HD64F3642AP@SDIP64(\*) [(SA736+B274)]  
 HD64F3642AW@QFP80(\*) [(SA731+B276)]  
 HD64F3643H@QFP64(\*) [(SA668+B275)]  
 HD64F3643P@SDIP64(\*) [(SA736+B274)]  
 HD64F3643W@QFP80(\*) [(SA731+B276)]  
 HD64F3644H@QFP64(\*) [(SA668+B275)]  
 HD64F3644P@SDIP64(\*) [(SA736+B274)]  
 HD64F3644W@QFP80(\*) [(SA731+B276)]  
 HD64F3664BP@SDIP42 [(SA028)] HD64F3664FP@TQFP64 [(PEP  
 +S616)]  
 HD64F3664FP@TQFP64(\*) [(SA732+B224)]  
 HD64F3664FX@TQFP48 [(SA671)] HD64F3664FY@TQFP48  
 [(SA248)]  
 HD64F3664H@TQFP64 [(PEP+S621)] HD64F3684FP@TQFP64 [(PEP  
 +S616)]  
 HD64F3684FP@TQFP64(\*) [(TA043-B006)]  
 HD64F3684GFP@TQFP64 [(PEP+S616)]  
 HD64F3684GFP@TQFP64(\*) [(TA043-B006)]  
 HD64F3684GH@TQFP64 [(PEP+S621)]  
 HD64F3684GH@TQFP64(\*) [(TA042-B006)]  
 HD64F3684H@TQFP64 [(PEP+S621)]  
 HD64F3684H@TQFP64(\*) [(TA042-B006)]  
 HD64F3687FP@TQFP64 [(PEP+S616)]  
 HD64F3687FP@TQFP64(\*) [(TA043-B006)]  
 HD64F3687GFP@TQFP64 [(PEP+S616)]  
 HD64F3687GFP@TQFP64(\*) [(TA043-B006)]  
 HD64F3687GH@TQFP64 [(PEP+S621)]  
 HD64F3687GH@TQFP64(\*) [(TA042-B006)]  
 HD64F3687H@TQFP64 [(PEP+S621)]  
 HD64F3687H@TQFP64(\*) [(TA042-B006)]  
 HD64F36902G@LQFP32 [(SA663)] HD64F36902G@SOP32  
 [(SA682)]

HD64F36912G@LQFP32 [(SA663)] HD64F36912G@SOP32  
 [(SA682)]  
 HD64F3694FP@TQFP64 [(PEP+S616)] HD64F3694FX@TQFP48  
 [(SA671)]  
 HD64F3694FY@TQFP48 [(SA248)] HD64F3694GFP@TQFP64 [(PEP  
 +S616)]  
 HD64F3694GFX@TQFP48 [(SA671)] HD64F3694GFY@TQFP48  
 [(SA248)]  
 HD64F3694GH@TQFP64 [(PEP+S621)] HD64F3694H@TQFP64 [(PEP  
 +S621)]  
 HD64F38002FPA@TQFP64 [(PEP+S625A)]  
 HD64F38002FPE@TQFP64 [(PEP+S616)]  
 HD64F38004FPA@TQFP64 [(PEP+S625A)]  
 HD64F38004FPE@TQFP64 [(PEP+S616)]  
 HD64F38024F(FP-80B)@PQFP80 [(PEP+S611A)]  
 HD64F38024F(FP-80B)@PQFP80(\*) [(TA003-B006)]  
 HD64F38024H(FP-80A)@TQFP80 [(PEP+S615B)]  
 HD64F38024H(FP-80A)@TQFP80(\*) [(TA005-B006)]  
 HD64F38024RF(FP-80B)@PQFP80 [(PEP+S611A)]  
 HD64F38024RF(FP-80B)@PQFP80(\*) [(TA003-B006)]  
 HD64F38024RH(FP-80A)@TQFP80 [(PEP+S615B)]  
 HD64F38024RH(FP-80A)@TQFP80(\*) [(TA005-B006)]  
 HD64F38024RW(TFP-80C)@TQFP80 [(PEP+S640B)]  
 HD64F38024RW(TFP-80C)@TQFP80(\*) [(TA004-B006)]  
 HD64F38024W(TFP-80C)@TQFP80 [(PEP+S640B)]  
 HD64F38024W(TFP-80C)@TQFP80(\*) [(TA004-B006)]  
 HD64F38102FPA@TQFP64 [(PEP+S625A)]  
 HD64F38102FPE@TQFP64 [(PEP+S616)]  
 HD64F38104FPA@TQFP64 [(PEP+S625A)]  
 HD64F38104FPE@TQFP64 [(PEP+S616)]  
 HD64F38124F(FP-80B)@PQFP80 [(PEP+S611A)]  
 HD64F38124F(FP-80B)@PQFP80(\*) [(TA003-B006)]  
 HD64F38124H(FP-80A)@TQFP80 [(PEP+S615B)]  
 HD64F38124H(FP-80A)@TQFP80(\*) [(TA005-B006)]  
 HD64F38124W(TFP-80C)@TQFP80 [(PEP+S640B)]  
 HD64F38124W(TFP-80C)@TQFP80(\*) [(TA004-B006)]  
 HD64F39802G@SDIP32 [(SA653)]  
 HD64F7044F@QFP112(\*) [(SA755+B278)]  
 HD64F7046F@QFP80(\*) [(TA014+B006)]  
 HD64F7047@QFP100(\*) [(SA718+B172)]

**HOLTEK**

**E ( E ) PROM / FRAM / NVRAM**

HT24C01 [ ( SA602A ) ]	HT24C01@SOIC8
HT24C02 [ ( SA602A ) ]	HT24C02@SOIC8
HT24C04 [ ( SA602A ) ]	HT24C04@SOIC8
HT24C08 HT24C16	
HT24LC01 [ ( SA602A ) ]	HT24LC01@SOIC8
HT24LC01@TSSOP8 [ ( SA026 ) ]	
HT24LC02 HT24LC02@SOIC8 [ ( SA602A ) ]	HT24LC02@TSSOP8
[ ( SA026 ) ]	
HT24LC04 [ ( SA602A ) ]	HT24LC04@SOIC8
HT24LC08 [ ( SA602A ) ]	HT24LC08@SOIC8
HT24LC16 [ ( SA602A ) ]	HT24LC16@SOIC8
HT24LC32 [ ( SA602A ) ]	HT24LC32@SOIC8
HT24LC64 [ ( SA602A ) ]	HT24LC64@SOIC8
HT25LC512@SOIC8 [ ( SA602A ) ]	
HT27C010 HT27C010@PLCC32 [ ( SA015A1T ) ]	HT27C010@TSOP32
[ ( SA410T ) ]	
HT27C020 [ ( SA015A1T ) ]	HT27C020@PLCC32
HT27C020@TSOP32 [ ( SA410T ) ]	
HT27C040 HT27C040@PLCC32 [ ( SA015A1T ) ]	HT27C040@TSOP32
[ ( SA410T ) ]	
HT27C4096 [ ( SA244 ) ]	HT27C4096@PLCC44
HT27C512 [ ( SA015A1T ) ]	HT27C512@PLCC32
HT27C512@TSOP28 [ ( SA430T ) ]	
HT27LC010	

HT27LC010@PLCC32 [(SA015A1T)]	HT27LC010@TSOP32
[(SA410T)]	
HT27LC020	HT27LC020@PLCC32
[(SA015A1T)]	
HT27LC020@TSOP32 [(SA410T)]	
HT27LC040	
HT27LC040@PLCC32 [(SA015A1T)]	HT27LC040@TSOP32
[(SA410T)]	
HT27LC4096	HT27LC4096@PLCC44
[(SA244)]	
HT27LC512	HT27LC512@PLCC32
[(SA015A1T)]	
HT27LC512@TSOP28 [(SA430T)]	HT93C46
(16bit)	
HT93C46(16bit)@SOP8-A [(SA602A)]	HT93C46(16bit)@SOP8-B
[(SA602A)]	
HT93C46(16bit)@TSSOP8 [(SA026)]	HT93C56
(16bit)	
HT93C56(16bit)@SOP8-A [(SA602A)]	HT93C56(16bit)@SOP8-B
[(SA602A)]	
HT93C56(16bit)@TSSOP8 [(SA026)]	HT93C66
(16bit)	
HT93C66(16bit)@SOP8-A [(SA602A)]	HT93C66(16bit)@SOP8-B
[(SA602A)]	
HT93C66(16bit)@TSSOP8 [(SA026)]	HT93LC46A
(08bit)	
HT93LC46A(08bit)@SOP8-A [(SA602A)]	
HT93LC46A(08bit)@SOP8-B [(SA602A)]	
HT93LC46A(08bit)@TSSOP8 [(SA026)]	
HT93LC46A(16bit)	
HT93LC46A(16bit)@SOP8-A [(SA602A)]	
HT93LC46A(16bit)@SOP8-B [(SA602A)]	
HT93LC46A(16bit)@TSSOP8 [(SA026)]	
HT93LC46B(08bit)	
HT93LC46B(08bit)@SOP8-A [(SA602A)]	
HT93LC46B(08bit)@SOP8-B [(SA602A)]	
HT93LC46B(08bit)@TSSOP8 [(SA026)]	
HT93LC46B(16bit)	
HT93LC46B(16bit)@SOP8-A [(SA602A)]	
HT93LC46B(16bit)@SOP8-B [(SA602A)]	
HT93LC46B(16bit)@TSSOP8 [(SA026)]	
HT93LC56A(08bit)	
HT93LC56A(08bit)@SOP8-A [(SA602A)]	

HT93LC56A(08bit)@SOP8-B [(SA602A)]  
 HT93LC56A(08bit)@TSSOP8 [(SA026)]  
 HT93LC56A(16bit)  
 HT93LC56A(16bit)@SOP8-A [(SA602A)]  
 HT93LC56A(16bit)@SOP8-B [(SA602A)]  
 HT93LC56A(16bit)@TSSOP8 [(SA026)]  
 HT93LC56B(08bit)  
 HT93LC56B(08bit)@SOP8-A [(SA602A)]  
 HT93LC56B(08bit)@SOP8-B [(SA026)]  
 HT93LC56B(08bit)@TSSOP8 [(SA026)]  
 HT93LC56B(16bit)  
 HT93LC56B(16bit)@SOP8-A [(SA602A)]  
 HT93LC56B(16bit)@SOP8-B [(SA602A)]  
 HT93LC56B(16bit)@TSSOP8 [(SA026)]  
 HT93LC66A(08bit)  
 HT93LC66A(08bit)@SOP8-A [(SA602A)]  
 HT93LC66A(08bit)@SOP8-B [(SA602A)]  
 HT93LC66A(08bit)@TSSOP8 [(SA026)]  
 HT93LC66A(16bit)  
 HT93LC66A(16bit)@SOP8-A [(SA602A)]  
 HT93LC66A(16bit)@SOP8-B [(SA602A)]  
 HT93LC66A(16bit)@TSSOP8 [(SA026)]  
 HT93LC66B(08bit)  
 HT93LC66B(08bit)@SOP8-A [(SA602A)]  
 HT93LC66B(08bit)@SOP8-B [(SA026)]  
 HT93LC66B(08bit)@TSSOP8 [(SA026)]  
 HT93LC66B(16bit)  
 HT93LC66B(16bit)@SOP8-A [(SA602A)]  
 HT93LC66B(16bit)@SOP8-B [(SA602A)]  
 HT93LC66B(16bit)@TSSOP8 [(SA026)]  
 HT93LC76(08bit)  
 HT93LC76(08bit)@SOP8-A [(SA602A)]  
 HT93LC76(08bit)@SOP8-B [(SA602A)]  
 HT93LC76(08bit)@TSSOP8 [(SA026)] HT93LC76  
 (16bit)  
 HT93LC76(16bit)@SOP8-A [(SA602A)]  
 HT93LC76(16bit)@SOP8-B [(SA602A)]  
 HT93LC76(16bit)@TSSOP8 [(SA026)] HT93LC86  
 (08bit)  
 HT93LC86(08bit)@SOP8-A [(SA602A)]  
 HT93LC86(08bit)@SOP8-B [(SA602A)]  
 HT93LC86(08bit)@TSSOP8 [(SA026)] HT93LC86  
 (16bit)

HT93LC86(16bit)@SOP8-A [(SA602A)]  
 HT93LC86(16bit)@SOP8-B [(SA602A)]  
 HT93LC86(16bit)@TSSOP8 [(SA026)]

## MICROCONTROLLER

HT46R22 [(SA404)]	HT46R22@SOP24
HT46R23(dip24) (dip28)	HT46R23
HT46R23@SOP24 [(SA404)] [(SA404)]	HT46R23@SOP28
HT46R24 [(SA404)]	HT46R24@SOP28
HT46R24@SSOP48 [(SA669)] (dip18)	HT46R46
HT46R46(dip20) [(SA404)]	HT46R46@SOP18
HT46R46@SOP20 [(SA404)] (dip18)	HT46R46E
HT46R46E@SOP18 [(SA404)] H	HT46R46-
HT46R46-H@SOP18 [(SA404)] (dip18)	HT46R47
HT46R47(dip20) [(SA404)]	HT46R47@SOP18
HT46R47@SOP20 [(SA404)] [(SA674)]	HT46R47@SSOP20
HT46R47E(dip18) [(SA404)]	HT46R47E@SOP18
HT46R47-H [(SA404)]	HT46R47-H@SOP18
HT46R48(dip20) (dip24)	HT46R48
HT46R48@SOP20 [(SA404)] [(SA404)]	HT46R48@SOP24
HT46R48@SSOP24 [(SA674)] (dip24)	HT46R48E
HT46R48E@SOP24 [(SA404)] [(SA674)]	HT46R48E@SSOP24
HT46R51A(dip18) [(SA404)]	HT46R51A@SOP20

HT46R51A@SSOP20 [(SA674)] (dip18)	HT46R52A
HT46R52A@SOP20 [(SA404)] [(SA674)]	HT46R52A@SSOP20
HT46R53A(dip28) [(SA404)]	HT46R53A@SOP28
HT46R54A(dip28) [(SA404)]	HT46R54A@SOP28
HT46R62@SSOP56 [(SA669)] +S427)]	HT46R63@PQFP100 [(PEP
HT46R63@SSOP56 [(SA669)] +S427)]	HT46R64@PQFP100 [(PEP
HT46R64@SSOP56 [(SA669)] +S427)]	HT46R65@PQFP100 [(PEP
HT46R65@SSOP56 [(SA669)] [(SA669)]	HT46R71D@SSOP48
HT46RB70 [(SA404)]	HT46RB70@SOP28
HT46RB70@SSOP48 [(SA669)] (dip24)	HT46RU22
HT46RU22@SOP24 [(SA404)] [(SA674)]	HT46RU22@SSOP24
HT47R10A@QFP44 [(SA245)] HT48R05A	
HT48R05A@SOP16 [(SA026)] [(SA404)]	HT48R05A@SOP18
HT48R06A [(SA026)]	HT48R06A@SOP16
HT48R06A@SOP18 [(SA404)] HT48R07A	
HT48R07A@SOP24 [(SA404)] [(SA674)]	HT48R07A@SSOP24
HT48R08A [(SA026)]	HT48R08A@SOP16
HT48R08A@SOP18 [(SA404)] HT48R09A	
HT48R09A@SOP24 [(SA404)] [(SA674)]	HT48R09A@SSOP24
HT48R10A [(SA404)]	HT48R10A@SOP24
HT48R30A(dip24) (dip28)	HT48R30A
HT48R30A@SOP24 [(SA404)]	HT48R30A@SOP28



[(SA404)]	
HT48R50A	HT48R50A@SOP28
[(SA404)]	
HT48R50A@SSOP48 [(SA669)]	HT48R52A@QFP44
[(SA245A)]	
HT48R70A@PQFP64 [(PEP+S618)]	HT48R70A@SSOP48
[(SA669)]	
HT48RA0-1	HT48RA0-1@SOP24
[(SA404)]	
HT48RA0-2	HT48RA0-2@SOP20
[(SA404)]	
HT48RA0-2@SSOP20 [(SA674)]	HT48RA0-
3	
HT48RA0-3@SOP20 [(SA404)]	HT48RA1@SOP28
[(SA404)]	
HT48RA1@SSOP28 [(SA626A)]	HT48RA3
(dip28)	
HT48RA3@SOP28 [(SA404)]	HT48RA3@SSOP28
[(SA626A)]	
HT48RA5(dip28)	HT48RA5@SOP28
[(SA404)]	
HT48RA5@SSOP28 [(SA626A)]	
HT48RB50	
HT48RB50@SOP28 [(SA404)]	HT48RB50@SSOP48
[(SA669)]	
HT48RB8@SOP28 [(SA404)]	HT48RB8@SSOP48
[(SA669)]	
HT49R30A@SSOP48 [(SA669)]	HT49R50A@SSOP48
[(SA669)]	
HT49RV5@SSOP56 [(SA669)]	HT49RV7@PQFP100 [(PEP
+S427)]	
HT82A821R@SOP24 [(SA404)]	HT82A821R@SSOP24
[(SA674)]	
HT82A822R@SSOP48 [(SA669)]	HT82A832R@QFP48
[(SA248)]	
HT82A832R@SSOP48 [(SA669)]	
HT82K68E	
HT82K68E@SOP20 [(SA404)]	HT82K68E@SOP28
[(SA404)]	
HT82K68E@SSOP48 [(SA669)]	HT82K94E@SSOP48
[(SA669)]	
HT82K96E(dip20)	HT82K96E
(dip40)	

HT82K96E@SOP20 [(SA404)]	HT82K96E@SOP28
[(SA404)]	
HT82K96E@SSOP48 [(SA669)]	HT82M99E
(dip18)	
HT82M99E(dip20)	HT82M99E@SOP18
[(SA404)]	
HT82M99E@SOP20 [(SA404)]	HT82M9AE@SOP20
[(SA404)]	
HT82M9AE@SOP24 [(SA404)]	HT82M9AE@SSOP20
[(SA674)]	
HT82M9AE@SSOP24 [(SA674)]	HT82M9BE@SOP24
[(SA404)]	
HT82M9BE@SOP28 [(SA404)]	HT82M9BE@SSOP24
[(SA674)]	
HT82M9BE@SSOP28 [(SA626A)]	HT95A100@SOP28
[(SA404)]	
HT95A10P@SOP28 [(SA404)]	HT95A200@SSOP48
[(SA669)]	
HT95A20P@SSOP48 [(SA669)]	HT95A300@SSOP48
[(SA669)]	
HT95A30P@SSOP48 [(SA669)]	HT95A400@PQFP64 [(PEP
+S618)]	
HT95A40P@PQFP64 [(PEP+S618)]	HT95L000@SSOP56
[(SA669)]	
HT95L00P@SSOP56 [(SA669)]	HT95L100@PQFP64 [(PEP
+S618)]	
HT95L10P@PQFP64 [(PEP+S618)]	

## HONGKONG

### E ( E ) PROM / FRAM / NVRAM

HK1215  
HK1225  
HK1235  
HK1245  
HK1255  
HK1265  
HK1275  
HK1285  
HK1295  
HK12A5

HK12B5  
OKS1225  
OKS1235  
OKS1245  
OKS1255  
OKS1265  
OKS1275  
OKS1285  
OKS1295  
OKS12A5  
OKS12B5

## **HYNIX**

### **E ( E ) PROM / FRAM / NVRAM**

H8BCS0SI0MAP@FBGA149 [ ( SA700I-B308-T149F001Y ) ]  
H8BCS0SJ0MCP@FBGA137 [ ( SA700E-B327A-M137F001Y ) ]  
HY2764  
HY27C64A  
HY27SF081G2A@FBGA63 [ ( SA642KK-B026A-W048F001Y ) ]  
HY27UA081G1M@TSOP48 [ ( SA247-B005 ) ]  
HY27UF081G2A@FBGA63 [ ( SA642KK-B026-W048F001Y ) ]  
HY27UF081G2A@TSOP48 [ ( SA247-B005 ) ]  
HY27UF081G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UF082G2A@TSOP48 [ ( SA247-B005 ) ]  
HY27UF082G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UF084G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UG082G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UG088G5M@TSOP48 [ ( SA247+B005 ) ]  
HY27US08121A@FBGA63 [ ( SA642KK-B026-W048F001Y ) ]  
HY27US08121A@TSOP48 [ ( SA247-B005 ) ]  
HY27US08121B@TSOP48 [ ( SA247-B005 ) ]  
HY27US08121M@TSOP48 [ ( SA247-B005 ) ]  
HY27US08281A@TSOP48 [ ( SA247-B005 ) ]  
HY27US08561A@FBGA63 [ ( SA642KK-B026A-W048F001Y ) ]  
HY27US08561A@TSOP48 [ ( SA247-B005 ) ]  
HY27US08561M@TSOP48 [ ( SA247-B005 ) ]  
HY27UT084G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UT088G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UU088G5M@TSOP48 [ ( SA247+B005 ) ]  
HY27UV08BG5M@TSOP48 [ ( SA247-B005 ) ]

HY29DL162BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29DL162BT@TSOP48 [ (SA247-B005) ]  
 HY29DL162TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29DL162TT@TSOP48 [ (SA247-B005) ]  
 HY29DL163BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29DL163BT@TSOP48 [ (SA247-B005) ]  
 HY29DL163TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29DL163TT@TSOP48 [ (SA247-B005) ]  
 HY29DS162BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29DS162BT@TSOP48 [ (SA247-B005) ]  
 HY29DS162TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29DS162TT@TSOP48 [ (SA247-B005) ]  
 HY29DS163BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29DS163BT@TSOP48 [ (SA247-B005) ]  
 HY29DS163TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29DS163TT@TSOP48 [ (SA247-B005) ]  
 HY29F002T HY29F002T@PLCC32  
 [ (SA015A1T) ]  
 HY29F002T@TSOP32 [ (SA410T) ]  
 HY29F040  
 HY29F040@PLCC32 [ (SA015A1T) ] HY29F040@TSOP32  
 [ (SA410T) ]  
 HY29F040A HY29F040A@PLCC32  
 [ (SA015A1T) ]  
 HY29F040A@TSOP32 [ (SA410T) ] HY29F080@TSOP40  
 [ (SA409T) ]  
 HY29F200B@PSOP44 [ (SA638-B006) ] HY29F200B@TSOP48 [ (SA247-  
 B005) ]  
 HY29F200T@PSOP44 [ (SA638-B006) ] HY29F200T@TSOP48 [ (SA247-  
 B005) ]  
 HY29F400ABG@PSOP44 [ (SA638) ]  
 HY29F400ABT@TSOP48 [ (SA247-B005) ]  
 HY29F400ATG@PSOP44 [ (SA638) ]  
 HY29F400ATT@TSOP48 [ (SA247-B005) ]  
 HY29F400BG@PSOP44 [ (SA638) ] HY29F400BT@TSOP48 [ (SA247-  
 B005) ]  
 HY29F400TG@PSOP44 [ (SA638) ] HY29F400TT@TSOP48 [ (SA247-  
 B005) ]  
 HY29F800ABG@PSOP44 [ (SA638) ]  
 HY29F800ABT@TSOP48 [ (SA247-B005) ]  
 HY29F800ATG@PSOP44 [ (SA638) ]  
 HY29F800ATT@TSOP48 [ (SA247-B005) ]  
 HY29F800BG@PSOP44 [ (SA638) ] HY29F800BT@TSOP48 [ (SA247-

B005) ]  
 HY29F800TG@PSOP44 [ (SA638) ] HY29F800TT@TSOP48 [ (SA247-  
 B005) ]  
 HY29LV160BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29LV160BT@TSOP48 [ (SA247-B005) ]  
 HY29LV160TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29LV160TT@TSOP48 [ (SA247-B005) ]  
 HY29LV320BF@FBGA48 [ (SA642E-B026A-T072F001) ]  
 HY29LV320BF@FBGA63 [ (SA642E-B026A-T072F001) ]  
 HY29LV320BT@TSOP48 [ (SA247-B005) ]  
 HY29LV320TF@FBGA48 [ (SA642E-B026A-T072F001) ]  
 HY29LV320TF@FBGA63 [ (SA642E-B026A-T072F001) ]  
 HY29LV320TT@TSOP48 [ (SA247-B005) ]  
 HY29LV400BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29LV400BT@TSOP48 [ (SA247-B005) ]  
 HY29LV400TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29LV400TT@TSOP48 [ (SA247-B005) ]  
 HY29LV800BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29LV800BG@PSOP44 [ (SA638) ]  
 HY29LV800BT@TSOP48 [ (SA247-B005) ]  
 HY29LV800TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29LV800TG@PSOP44 [ (SA638) ]  
 HY29LV800TT@TSOP48 [ (SA247-B005) ]  
 HY93C46 HY93C46@SOIC8  
 [ (SA602A) ]  
 HY93C56 HY93C56@SOIC8  
 [ (SA602A) ]  
 HY93C66 HY93C66@SOIC8  
 [ (SA602A) ]  
 HY93C76 HY93C76@SOIC8  
 [ (SA602A) ]  
 HY93C86 HY93C86@SOIC8  
 [ (SA602A) ]  
 HYC0SEH0AF3P@FBGA137 [ (SA700E-B153A-M137F001Y) ]  
 HYC0SEH0MF3P@FBGA137 [ (SA700E-B153A-M137F001Y) ]  
 HYC0UEE0MF2P@FBGA107 [ (SA642V-B133-T096F001Y) ]  
 HYC0UEF0AF3P@FBGA137 [ (SA700E-B153A-M137F001Y) ]  
 HYC0UEF0MF3P@FBGA137 [ (SA700E-B153A-M137F001Y) ]  
 HYC0UEH0MF3P@FBGA137 [ (SA700E-B153A-M137F001Y) ]  
 HYD0SFE0BF1P@BGA149 [ (SA700I-B308-T149F001Y) ]  
 HYD0SFG0MF1P@BGA149 [ (SA700I-B308-T149F001Y) ]  
 HYG0SEG0MF2P@FBGA107 [ (SA642V-B133-T096F001Y) ]  
 HYG0SGH0MF3P@FBGA137 [ (SA700E-B153A-M137F001Y) ]

HYG0SGJ0MF3P@FBGA137 [(SA700E-B153A-M137F001Y)]  
 HYG0UEG0MF2P@FBGA107 [(SA642V-B133-T096F001Y)]  
 HYG0UGH0MF3P@FBGA137 [(SA700E-B153A-M137F001Y)]  
 HYH0SSJ0MF3P@FBGA137 [(SA700E-B327A-M137F001Y)]  
 HYI0UGG0AF1P@FBGA149 [(SA700I-B295-T149F001Y)]  
 HYI0UIJ0MF3P@FBGA137 [(SA700E-B153A-M137F001Y)]

## DRAM & SRAM

HY62256A [(SA643)]	HY62256A@TSOP28
HY6264A [(SA643)]	HY6264A@TSOP28
HY628100A [(SA438T)]	HY628100A@SOP32
HY628100A@TSOP32 [(SA410T)]	
HY628100B HY628100B@SOP32 [(SA438T)]	HY628100B@TSOP32
[(SA410T)]	
HY628400 [(SA438T)]	HY628400@SOP32
HY628400@TSOP32 [(SA410T)]	
HY628400A HY628400A@SOP32 [(SA438T)]	HY628400A@TSOP32
[(SA410T)]	
HY62CT08081E [(SA438T)]	HY62CT08081E@SOP28
HY62CT08081E@TSOP28 [(SA643)]	
HY62KT08081E HY62KT08081E@SOP28 [(SA438T)]	HY62KT08081E@TSOP28
[(SA643)]	
HY62U8100B [(SA438T)]	HY62U8100B@SOP32
HY62U8100B@TSOP32 [(SA410T)]	
HY62U8200B HY62U8200B@SOP32 [(SA438T)]	HY62U8200B@TSOP32
[(SA410T)]	
HY62U8400A [(SA438T)]	HY62U8400A@SOP32
HY62U8400A@TSOP32 [(SA410T)]	
HY62UT08081E HY62UT08081E@SOP28 [(SA438T)]	HY62UT08081E@TSOP28

[ (SA643) ]	
HY62V8100B	HY62V8100B@SOP32
[ (SA438T) ]	
HY62V8100B@TSOP32 [ (SA410T) ]	
HY62V8200B	
HY62V8200B@SOP32 [ (SA438T) ]	HY62V8200B@TSOP32
[ (SA410T) ]	
HY62V8400A	HY62V8400A@SOP32
[ (SA438T) ]	
HY62V8400A@TSOP32 [ (SA410T) ]	
HY62VT08081E	
HY62VT08081E@SOP28 [ (SA438T) ]	HY62VT08081E@TSOP28
[ (SA643) ]	
HY62WT08081E	HY62WT08081E@SOP28
[ (SA438T) ]	
HY62WT08081E@TSOP28 [ (SA643) ]	

## MICROCONTROLLER

GMS34004TK	
GMS34004TM	
GMS34004TW	
GMS34112TK	
GMS34112TK@SOIC20 [ (SA404) ]	GMS34112TK@SSOP20
[ (SA626A) ]	
GMS34140TK	GMS34140TK@SOIC24
[ (SA404) ]	
GMS77C1000	GMS77C1000@SOIC20
[ (SA404) ]	
GMS77C1001	GMS77C1001@SOIC20
[ (SA404) ]	
GMS81004(dip20)	GMS81004
(dip24)	
GMS81004(dip28)	GMS81004@PLCC44
[ (SA244) ]	
GMS81004@SOIC20 [ (SA404) ]	GMS81004@SOIC24
[ (SA404) ]	
GMS81004@SOIC28 [ (SA404) ]	GMS81008
(dip20)	
GMS81008(dip24)	GMS81008
(dip28)	
GMS81008@PLCC44 [ (SA244) ]	GMS81008@SOIC20

[ (SA404) ]	
GMS81008@SOIC24 [ (SA404) ]	GMS81008@SOIC28
[ (SA404) ]	
GMS81016(dip20)	GMS81016
(dip24)	
GMS81016(dip28)	GMS81016@PLCC44
[ (SA244) ]	
GMS81016@SOIC20 [ (SA404) ]	GMS81016@SOIC24
[ (SA404) ]	
GMS81016@SOIC28 [ (SA404) ]	GMS81024
(dip20)	
GMS81024(dip24)	GMS81024
(dip28)	
GMS81024@PLCC44 [ (SA244) ]	GMS81024@SOIC20
[ (SA404) ]	
GMS81024@SOIC24 [ (SA404) ]	GMS81024@SOIC28
[ (SA404) ]	
GMS81032(dip20)	GMS81032
(dip24)	
GMS81032(dip28)	GMS81032@PLCC44
[ (SA244) ]	
GMS81032@SOIC20 [ (SA404) ]	GMS81032@SOIC24
[ (SA404) ]	
GMS81032@SOIC28 [ (SA404) ]	
GMS81504AT	
GMS81504T	
GMS81516	
GMS81516@LQFP64 [ (PEP+S616) ]	GMS81516@MQFP64 [ (PEP
+S618) ]	
GMS81516@SDIP64 [ (PEP+S600A) ]	
GMS81516AT	
GMS81516AT@LQFP64 [ (PEP+S616) ]	GMS81516AT@MQFP64 [ (PEP
+S618) ]	
GMS81516AT@SDIP64 [ (PEP+S600A) ]	
GMS81516BT	
GMS81516BT@LQFP64 [ (PEP+S616) ]	GMS81516BT@MQFP64 [ (PEP
+S618) ]	
GMS81516BT@SDIP64 [ (PEP+S600A) ]	
GMS81524	
GMS81524@LQFP64 [ (PEP+S616) ]	GMS81524@MQFP64 [ (PEP
+S618) ]	
GMS81524@SDIP64 [ (PEP+S600A) ]	
GMS81524AT	



GMS81524AT@LQFP64 [ ( PEP+S616 ) ] +S618 ) ]	GMS81524AT@MQFP64 [ ( PEP
GMS81524AT@SDIP64 [ ( PEP+S600A ) ]	
GMS81524BT	
GMS81524BT@LQFP64 [ ( PEP+S616 ) ] +S618 ) ]	GMS81524BT@MQFP64 [ ( PEP
GMS81524BT@SDIP64 [ ( PEP+S600A ) ]	
GMS81604T	
GMS81604T@PLCC44 [ ( SA244 ) ] [ ( SA028 ) ]	GMS81604T@SDIP42
GMS81608T [ ( SA244 ) ]	GMS81608T@PLCC44
GMS81608T@SDIP42 [ ( SA028 ) ] ( dip28 )	GMS81C5016
GMS81C5016(dip40) [ ( SA244 ) ]	GMS81C5016@PLCC44
GMS81C5016@SOIC28 [ ( SA404 ) ] [ ( SA245A ) ]	GMS81C5016@TQFP44
GMS81C5024(dip28) ( dip40 )	GMS81C5024
GMS81C5024@PLCC44 [ ( SA244 ) ] [ ( SA404 ) ]	GMS81C5024@SOIC28
GMS81C5024@TQFP44 [ ( SA245A ) ] ( dip28 )	GMS81C5032
GMS81C5032(dip40) [ ( SA244 ) ]	GMS81C5032@PLCC44
GMS81C5032@SOIC28 [ ( SA404 ) ] [ ( SA245A ) ]	GMS81C5032@TQFP44
GMS82516T +S616 ) ]	GMS82516T@LQFP64 [ ( PEP
GMS82516T@MQFP64 [ ( PEP+S618 ) ] +S600A ) ]	GMS82516T@SDIP64 [ ( PEP
GMS82524T +S616 ) ]	GMS82524T@LQFP64 [ ( PEP
GMS82524T@MQFP64 [ ( PEP+S618 ) ] +S600A ) ]	GMS82524T@SDIP64 [ ( PEP
GMS84512T@SDIP52 [ ( PEP+S600A ) ] +S600A ) ]	GMS84524T@SDIP52 [ ( PEP
GMS87C1102 [ ( SA404 ) ]	GMS87C1102@SOP16
GMS87C1202 [ ( SA404 ) ]	GMS87C1202@SOP20
GMS87C1404	GMS87C1404@SDIP28

[ (SA022A) ]	
GMS87C1408	GMS87C1408@SDIP28
[ (SA022A) ]	
GMS87C2020@LQFP64 [ (PEP+S616) ]	GMS87C2020@MQFP64 [ (PEP
+S618) ]	
GMS87C2020@SDIP64 [ (PEP+S600A) ]	GMS87C5032
(dip28)	
GMS87C5032(dip40)	GMS87C5032@PLCC44
[ (SA244) ]	
GMS87C5032@SOIC28 [ (SA404) ]	GMS87C5032@TQFP44
[ (SA245A) ]	
GMS87C5108@PQFP80 [ (PEP+S611A) ]	GMS87C7008@LQFP64 [ (PEP
+S616) ]	
GMS87C7008@MQFP64 [ (PEP+S618) ]	GMS87C7008@SDIP64 [ (PEP
+S600A) ]	
GMS87C7016@LQFP64 [ (PEP+S616) ]	GMS87C7016@MQFP64 [ (PEP
+S618) ]	
GMS87C7016@SDIP64 [ (PEP+S600A) ]	
GMS97C1051	
GMS97C1051@SOIC20 [ (SA404) ]	
GMS97C2051	
GMS97C2051@SOIC20 [ (SA404) ]	
GMS97C51	
GMS97C51@PLCC44 [ (SA244) ]	GMS97C51@TQFP44
[ (SA245A) ]	
GMS97C52	GMS97C52@PLCC44
[ (SA244) ]	
GMS97C52@TQFP44 [ (SA245A) ]	
GMS97C54	
GMS97C54@PLCC44 [ (SA244) ]	GMS97C54@TQFP44
[ (SA245A) ]	
GMS97C56	GMS97C56@PLCC44
[ (SA244) ]	
GMS97C56@TQFP44 [ (SA245A) ]	
GMS97C58	
GMS97C58@PLCC44 [ (SA244) ]	GMS97C58@TQFP44
[ (SA245A) ]	
GMS97L1051	GMS97L1051@SOIC20
[ (SA404) ]	
GMS97L2051	GMS97L2051@SOIC20
[ (SA404) ]	
GMS97L51	GMS97L51@PLCC44
[ (SA244) ]	

GMS97L51@TQFP44 [(SA245A)]	
GMS97L52	GMS97L52@TQFP44
GMS97L52@PLCC44 [(SA244)]	
[(SA245A)]	
GMS97L54	GMS97L54@PLCC44
[(SA244)]	
GMS97L54@TQFP44 [(SA245A)]	
GMS97L56	GMS97L56@TQFP44
GMS97L56@PLCC44 [(SA244)]	
[(SA245A)]	
GMS97L58	GMS97L58@PLCC44
[(SA244)]	
GMS97L58@TQFP44 [(SA245A)]	
GMS99C52	GMS99C52@TQFP44
GMS99C52@PLCC44 [(SA244)]	
[(SA245A)]	
GMS99C58	GMS99C58@PLCC44
[(SA244)]	
GMS99C58@TQFP44 [(SA245A)]	HMS81004E
(dip20)	
HMS81004E(dip24)	HMS81004E
(dip28)	
HMS81004E@PLCC44 [(SA244)]	HMS81004E@SOIC20
[(SA404)]	
HMS81004E@SOIC24 [(SA404)]	HMS81004E@SOIC28
[(SA404)]	
HMS81008E(dip20)	HMS81008E
(dip24)	
HMS81008E(dip28)	HMS81008E@PLCC44
[(SA244)]	
HMS81008E@SOIC20 [(SA404)]	HMS81008E@SOIC24
[(SA404)]	
HMS81008E@SOIC28 [(SA404)]	HMS81016E
(dip20)	
HMS81016E(dip24)	HMS81016E
(dip28)	
HMS81016E@PLCC44 [(SA244)]	HMS81016E@SOIC20
[(SA404)]	
HMS81016E@SOIC24 [(SA404)]	HMS81016E@SOIC28
[(SA404)]	
HMS81020ET(dip20)	HMS81020ET
(dip24)	
HMS81020ET(dip28)	HMS81020ET@SOIC20

[ (SA404) ]	
HMS81020ET@SOIC24 [ (SA404) ]	HMS81020ET@SOIC28
[ (SA404) ]	
HMS81020TL(dip20)	HMS81020TL
(dip24)	
HMS81020TL(dip28)	HMS81020TL@SOIC20
[ (SA404) ]	
HMS81020TL@SOIC24 [ (SA404) ]	HMS81020TL@SOIC28
[ (SA404) ]	
HMS81024E(dip20)	HMS81024E
(dip24)	
HMS81024E(dip28)	HMS81024E@PLCC44
[ (SA244) ]	
HMS81024E@SOIC20 [ (SA404) ]	HMS81024E@SOIC24
[ (SA404) ]	
HMS81024E@SOIC28 [ (SA404) ]	HMS81032
(dip20)	
HMS81032(dip24)	HMS81032
(dip28)	
HMS81032@SOIC20 [ (SA404) ]	HMS81032@SOIC24
[ (SA404) ]	
HMS81032@SOIC28 [ (SA404) ]	HMS81032ET
(dip20)	
HMS81032ET(dip24)	HMS81032ET
(dip28)	
HMS81032ET@SOIC20 [ (SA404) ]	HMS81032ET@SOIC24
[ (SA404) ]	
HMS81032ET@SOIC28 [ (SA404) ]	HMS81032T
(dip20)	
HMS81032T(dip24)	HMS81032T
(dip28)	
HMS81032T@SOIC20 [ (SA404) ]	HMS81032T@SOIC24
[ (SA404) ]	
HMS81032T@SOIC28 [ (SA404) ]	HMS81032TL
(dip20)	
HMS81032TL(dip24)	HMS81032TL
(dip28)	
HMS81032TL@SOIC20 [ (SA404) ]	HMS81032TL@SOIC24
[ (SA404) ]	
HMS81032TL@SOIC28 [ (SA404) ]	
HMS87C1102A	
HMS87C1102A@SOP16 [ (SA404) ]	
HMS87C1104A	

HMS87C1104A@SOP16 [(SA404)]	
HMS87C1202A	
HMS87C1202A@SOP20 [(SA404)]	
HMS87C1204A	
HMS87C1204A@SOP20 [(SA404)]	
HMS87C1302A@SDIP24 [(SA022A-B005)]	
HMS87C1302A@SOP24 [(SA404)]	
HMS87C1304A@SDIP24 [(SA022A-B005)]	
HMS87C1304A@SOP24 [(SA404)]	
HMS87C1404B	
HMS87C1404B@SDIP28 [(SA022A)]	HMS87C1404B@SOIC28
[(SA404)]	
HMS87C1408B	HMS87C1408B@SDIP28
[(SA022A)]	
HMS87C1408B@SOIC28 [(SA404)]	
HMS87C1416B	
HMS87C1416B@SDIP28 [(SA022A)]	HMS87C1416B@SOIC28
[(SA404)]	
HMS87C1508B	
HMS87C1516B	
HMS87C1608B	
HMS87C1616B	
HMS87C1708B@SDIP42 [(SA028)]	HMS87C1716B@SDIP42
[(SA028)]	
HMS87C1808B@TQFP44 [(SA245A)]	HMS87C1816B@TQFP44
[(SA245A)]	
HMS87C5216	HMS87C5216@PLCC44
[(SA244)]	
HMS87C5216@SOIC28 [(SA404)]	HMS87C5216@TQFP44
[(SA245A)]	
HMS99C52	HMS99C52@PLCC44
[(SA244)]	
HMS99C52@TQFP44 [(SA245A)]	
HMS99C58	
HMS99C58@PLCC44 [(SA244)]	HMS99C58@TQFP44
[(SA245A)]	

## **HYNIX(HYUNDAI)**

### **PLD**

HY18CV8	HY18CV8@PLCC20
---------	----------------

[ (SA001A) ]  
HY18CV8@SOIC20 [ (SA404) ]  
[ (SA026) ]

HY18CV8@TSOP20

## **HYNIX-CUSTOMER**

### **E (E) PROM/FRAM/NVRAM**

HY27UF081G2A(DD)@TSOP48 [ (SA247-B005) ]  
HY27UF081G2A(DD5)@TSOP48 [ (SA247+B005) ]  
HY27UF081G2A(MLT)@TSOP48 [ (SA247-B005) ]  
HY27UF081G2A(TZ)@TSOP48 [ (SA247-B005) ]  
HY27UF081G2A(ZX)@TSOP48 [ (SA247-B005) ]  
HY27UF082G2A(MLT)@TSOP48 [ (SA247-B005) ]  
HY27UF082G2M(ZX)@TSOP48 [ (SA247-B005) ]  
HY27UG088G5M(KD)@TSOP48 [ (SA247+B005) ]  
HY27UG088G5M(MLT)@TSOP48 [ (SA247-B005) ]  
HY27US08121A(ASUS)@TSOP48 [ (SA247-B005) ]  
HY27US08121A(DD)@TSOP48 [ (SA247-B005) ]  
HY27US08121A(MLTATL)@TSOP48 [ (SA247-B005) ]  
HY27US08121A(XJ)@TSOP48 [ (SA247-B005) ]  
HY27US08121B(LG)@TSOP48 [ (SA247-B005) ]  
HY27US08281A(WS)@TSOP48 [ (SA247-B005) ]  
HY27UT088G2M(OMB)@TSOP48 [ (SA247-B005) ]

## **HYUNDAI**

### **E (E) PROM/FRAM/NVRAM**

HY2764  
HY27C64A  
HY29DL162BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
HY29DL162BT@TSOP48 [ (SA247-B005) ]  
HY29DL162TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
HY29DL162TT@TSOP48 [ (SA247-B005) ]  
HY29DL163BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
HY29DL163BT@TSOP48 [ (SA247-B005) ]  
HY29DL163TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
HY29DL163TT@TSOP48 [ (SA247-B005) ]  
HY29DS162BF@FBGA48 [ (SA642F-B026A-T064F001) ]

HY29DS162BT@TSOP48 [ (SA247-B005) ]  
 HY29DS162TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29DS162TT@TSOP48 [ (SA247-B005) ]  
 HY29DS163BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29DS163BT@TSOP48 [ (SA247-B005) ]  
 HY29DS163TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29DS163TT@TSOP48 [ (SA247-B005) ]  
 HY29F002T HY29F002T@PLCC32  
 [ (SA015A1T) ]  
 HY29F002T@TSOP32 [ (SA410T) ]  
 HY29F040  
 HY29F040@PLCC32 [ (SA015A1T) ] HY29F040@TSOP32  
 [ (SA410T) ]  
 HY29F040A HY29F040A@PLCC32  
 [ (SA015A1T) ]  
 HY29F040A@TSOP32 [ (SA410T) ] HY29F080@TSOP40  
 [ (SA409T) ]  
 HY29F200B@PSOP44 [ (SA638-B006) ] HY29F200B@TSOP48 [ (SA247-  
 B005) ]  
 HY29F200T@PSOP44 [ (SA638-B006) ] HY29F200T@TSOP48 [ (SA247-  
 B005) ]  
 HY29F400ABG@PSOP44 [ (SA638) ]  
 HY29F400ABT@TSOP48 [ (SA247-B005) ]  
 HY29F400ATG@PSOP44 [ (SA638) ]  
 HY29F400ATT@TSOP48 [ (SA247-B005) ]  
 HY29F400BG@PSOP44 [ (SA638) ] HY29F400BT@TSOP48 [ (SA247-  
 B005) ]  
 HY29F400TG@PSOP44 [ (SA638) ] HY29F400TT@TSOP48 [ (SA247-  
 B005) ]  
 HY29F800ABG@PSOP44 [ (SA638) ]  
 HY29F800ABT@TSOP48 [ (SA247-B005) ]  
 HY29F800ATG@PSOP44 [ (SA638) ]  
 HY29F800ATT@TSOP48 [ (SA247-B005) ]  
 HY29F800BG@PSOP44 [ (SA638) ] HY29F800BT@TSOP48 [ (SA247-  
 B005) ]  
 HY29F800TG@PSOP44 [ (SA638) ] HY29F800TT@TSOP48 [ (SA247-  
 B005) ]  
 HY29LV160BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29LV160BT@TSOP48 [ (SA247-B005) ]  
 HY29LV160TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29LV160TT@TSOP48 [ (SA247-B005) ]  
 HY29LV320BF@FBGA48 [ (SA642E-B026A-T072F001) ]  
 HY29LV320BF@FBGA63 [ (SA642E-B026A-T072F001) ]

HY29LV320BT@TSOP48	[(SA247-B005)]	
HY29LV320TF@FBGA48	[(SA642E-B026A-T072F001)]	
HY29LV320TF@FBGA63	[(SA642E-B026A-T072F001)]	
HY29LV320TT@TSOP48	[(SA247-B005)]	
HY29LV400BF@FBGA48	[(SA642F-B026A-T064F001)]	
HY29LV400BT@TSOP48	[(SA247-B005)]	
HY29LV400TF@FBGA48	[(SA642F-B026A-T064F001)]	
HY29LV400TT@TSOP48	[(SA247-B005)]	
HY29LV800BF@FBGA48	[(SA642F-B026A-T064F001)]	
HY29LV800BG@PSOP44	[(SA638)]	
HY29LV800BT@TSOP48	[(SA247-B005)]	
HY29LV800TF@FBGA48	[(SA642F-B026A-T064F001)]	
HY29LV800TG@PSOP44	[(SA638)]	
HY29LV800TT@TSOP48	[(SA247-B005)]	
HY93C46		HY93C46@SOIC8
[(SA602A)]		
HY93C56		HY93C56@SOIC8
[(SA602A)]		
HY93C66		HY93C66@SOIC8
[(SA602A)]		
HY93C76		HY93C76@SOIC8
[(SA602A)]		
HY93C86		HY93C86@SOIC8
[(SA602A)]		

**DRAM & SRAM**

HY62256A		HY62256A@TSOP28
[(SA643)]		
HY6264A		HY6264A@TSOP28
[(SA643)]		
HY628100A		HY628100A@SOP32
[(SA438T)]		
HY628100A@TSOP32	[(SA410T)]	
HY628100B		
HY628100B@SOP32	[(SA438T)]	HY628100B@TSOP32
[(SA410T)]		
HY628400		HY628400@SOP32
[(SA438T)]		
HY628400@TSOP32	[(SA410T)]	
HY628400A		
HY628400A@SOP32	[(SA438T)]	HY628400A@TSOP32



[(SA410T)]	
HY62CT08081E	HY62CT08081E@SOP28
[(SA438T)]	
HY62CT08081E@TSOP28 [(SA643)]	
HY62KT08081E	
HY62KT08081E@SOP28 [(SA438T)]	HY62KT08081E@TSOP28
[(SA643)]	
HY62U8100B	HY62U8100B@SOP32
[(SA438T)]	
HY62U8100B@TSOP32 [(SA410T)]	
HY62U8200B	
HY62U8200B@SOP32 [(SA438T)]	HY62U8200B@TSOP32
[(SA410T)]	
HY62U8400A	HY62U8400A@SOP32
[(SA438T)]	
HY62U8400A@TSOP32 [(SA410T)]	
HY62UT08081E	
HY62UT08081E@SOP28 [(SA438T)]	HY62UT08081E@TSOP28
[(SA643)]	
HY62V8100B	HY62V8100B@SOP32
[(SA438T)]	
HY62V8100B@TSOP32 [(SA410T)]	
HY62V8200B	
HY62V8200B@SOP32 [(SA438T)]	HY62V8200B@TSOP32
[(SA410T)]	
HY62V8400A	HY62V8400A@SOP32
[(SA438T)]	
HY62V8400A@TSOP32 [(SA410T)]	
HY62VT08081E	
HY62VT08081E@SOP28 [(SA438T)]	HY62VT08081E@TSOP28
[(SA643)]	
HY62WT08081E	HY62WT08081E@SOP28
[(SA438T)]	
HY62WT08081E@TSOP28 [(SA643)]	

## MICROCONTROLLER

GMS34004TK	
GMS34004TM	
GMS34004TW	
GMS34112TK	
GMS34112TK@SOIC20 [(SA404)]	GMS34112TK@SSOP20

[ (SA626A) ]	
GMS34140TK	GMS34140TK@SOIC24
[ (SA404) ]	
GMS77C1000	GMS77C1000@SOIC20
[ (SA404) ]	
GMS77C1001	GMS77C1001@SOIC20
[ (SA404) ]	
GMS81004(dip20)	GMS81004
(dip24)	
GMS81004(dip28)	GMS81004@PLCC44
[ (SA244) ]	
GMS81004@SOIC20 [ (SA404) ]	GMS81004@SOIC24
[ (SA404) ]	
GMS81004@SOIC28 [ (SA404) ]	GMS81008
(dip20)	
GMS81008(dip24)	GMS81008
(dip28)	
GMS81008@PLCC44 [ (SA244) ]	GMS81008@SOIC20
[ (SA404) ]	
GMS81008@SOIC24 [ (SA404) ]	GMS81008@SOIC28
[ (SA404) ]	
GMS81016(dip20)	GMS81016
(dip24)	
GMS81016(dip28)	GMS81016@PLCC44
[ (SA244) ]	
GMS81016@SOIC20 [ (SA404) ]	GMS81016@SOIC24
[ (SA404) ]	
GMS81016@SOIC28 [ (SA404) ]	GMS81024
(dip20)	
GMS81024(dip24)	GMS81024
(dip28)	
GMS81024@PLCC44 [ (SA244) ]	GMS81024@SOIC20
[ (SA404) ]	
GMS81024@SOIC24 [ (SA404) ]	GMS81024@SOIC28
[ (SA404) ]	
GMS81032(dip20)	GMS81032
(dip24)	
GMS81032(dip28)	GMS81032@PLCC44
[ (SA244) ]	
GMS81032@SOIC20 [ (SA404) ]	GMS81032@SOIC24
[ (SA404) ]	
GMS81032@SOIC28 [ (SA404) ]	
GMS81504AT	

GMS81504T  
GMS81516  
GMS81516@LQFP64 [(PEP+S616)]  
+S618)]  
GMS81516@SDIP64 [(PEP+S600A)]  
GMS81516AT  
GMS81516AT@LQFP64 [(PEP+S616)]  
+S618)]  
GMS81516AT@SDIP64 [(PEP+S600A)]  
GMS81516BT  
GMS81516BT@LQFP64 [(PEP+S616)]  
+S618)]  
GMS81516BT@SDIP64 [(PEP+S600A)]  
GMS81524  
GMS81524@LQFP64 [(PEP+S616)]  
+S618)]  
GMS81524@SDIP64 [(PEP+S600A)]  
GMS81524AT  
GMS81524AT@LQFP64 [(PEP+S616)]  
+S618)]  
GMS81524AT@SDIP64 [(PEP+S600A)]  
GMS81524BT  
GMS81524BT@LQFP64 [(PEP+S616)]  
+S618)]  
GMS81524BT@SDIP64 [(PEP+S600A)]  
GMS81604T  
GMS81604T@PLCC44 [(SA244)]  
[(SA028)]  
GMS81608T  
[(SA244)]  
GMS81608T@SDIP42 [(SA028)]  
(dip28)  
GMS81C5016(dip40)  
[(SA244)]  
GMS81C5016@SOIC28 [(SA404)]  
[(SA245A)]  
GMS81C5024(dip28)  
(dip40)  
GMS81C5024@PLCC44 [(SA244)]  
[(SA404)]  
GMS81C5024@TQFP44 [(SA245A)]  
(dip28)  
GMS81C5032(dip40)

GMS81516@MQFP64 [(PEP  
GMS81516AT@MQFP64 [(PEP  
GMS81516BT@MQFP64 [(PEP  
GMS81524@MQFP64 [(PEP  
GMS81524AT@MQFP64 [(PEP  
GMS81524BT@MQFP64 [(PEP  
GMS81604T@SDIP42  
GMS81608T@PLCC44  
GMS81C5016  
GMS81C5016@PLCC44  
GMS81C5016@TQFP44  
GMS81C5024  
GMS81C5024@SOIC28  
GMS81C5032  
GMS81C5032@PLCC44

[ ( SA244 ) ]	
GMS81C5032@SOIC28 [ ( SA404 ) ]	GMS81C5032@TQFP44
[ ( SA245A ) ]	
GMS82516T	GMS82516T@LQFP64 [ ( PEP
+S616 ) ]	
GMS82516T@MQFP64 [ ( PEP+S618 ) ]	GMS82516T@SDIP64 [ ( PEP
+S600A ) ]	
GMS82524T	GMS82524T@LQFP64 [ ( PEP
+S616 ) ]	
GMS82524T@MQFP64 [ ( PEP+S618 ) ]	GMS82524T@SDIP64 [ ( PEP
+S600A ) ]	
GMS84512T@SDIP52 [ ( PEP+S600A ) ]	GMS84524T@SDIP52 [ ( PEP
+S600A ) ]	
GMS87C1102	GMS87C1102@SOP16
[ ( SA404 ) ]	
GMS87C1202	GMS87C1202@SOP20
[ ( SA404 ) ]	
GMS87C1404	GMS87C1404@SDIP28
[ ( SA022A ) ]	
GMS87C1408	GMS87C1408@SDIP28
[ ( SA022A ) ]	
GMS87C2020@LQFP64 [ ( PEP+S616 ) ]	GMS87C2020@MQFP64 [ ( PEP
+S618 ) ]	
GMS87C2020@SDIP64 [ ( PEP+S600A ) ]	GMS87C5032
( dip28 )	
GMS87C5032 ( dip40 )	GMS87C5032@PLCC44
[ ( SA244 ) ]	
GMS87C5032@SOIC28 [ ( SA404 ) ]	GMS87C5032@TQFP44
[ ( SA245A ) ]	
GMS87C5108@PQFP80 [ ( PEP+S611A ) ]	GMS87C7008@LQFP64 [ ( PEP
+S616 ) ]	
GMS87C7008@MQFP64 [ ( PEP+S618 ) ]	GMS87C7008@SDIP64 [ ( PEP
+S600A ) ]	
GMS87C7016@LQFP64 [ ( PEP+S616 ) ]	GMS87C7016@MQFP64 [ ( PEP
+S618 ) ]	
GMS87C7016@SDIP64 [ ( PEP+S600A ) ]	
GMS97C1051	
GMS97C1051@SOIC20 [ ( SA404 ) ]	
GMS97C2051	
GMS97C2051@SOIC20 [ ( SA404 ) ]	
GMS97C51	
GMS97C51@PLCC44 [ ( SA244 ) ]	GMS97C51@TQFP44
[ ( SA245A ) ]	

GMS97C52 [ ( SA244 ) ]	GMS97C52@PLCC44
GMS97C52@TQFP44 [ ( SA245A ) ]	
GMS97C54 GMS97C54@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	GMS97C54@TQFP44
GMS97C56 [ ( SA244 ) ]	GMS97C56@PLCC44
GMS97C56@TQFP44 [ ( SA245A ) ]	
GMS97C58 GMS97C58@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	GMS97C58@TQFP44
GMS97L1051 [ ( SA404 ) ]	GMS97L1051@SOIC20
GMS97L2051 [ ( SA404 ) ]	GMS97L2051@SOIC20
GMS97L51 [ ( SA244 ) ]	GMS97L51@PLCC44
GMS97L51@TQFP44 [ ( SA245A ) ]	
GMS97L52 GMS97L52@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	GMS97L52@TQFP44
GMS97L54 [ ( SA244 ) ]	GMS97L54@PLCC44
GMS97L54@TQFP44 [ ( SA245A ) ]	
GMS97L56 GMS97L56@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	GMS97L56@TQFP44
GMS97L58 [ ( SA244 ) ]	GMS97L58@PLCC44
GMS97L58@TQFP44 [ ( SA245A ) ]	
GMS99C52 GMS99C52@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	GMS99C52@TQFP44
GMS99C58 [ ( SA244 ) ]	GMS99C58@PLCC44
GMS99C58@TQFP44 [ ( SA245A ) ] (dip20)	HMS81004E
HMS81004E(dip24) (dip28)	HMS81004E
HMS81004E@PLCC44 [ ( SA244 ) ] [ ( SA404 ) ]	HMS81004E@SOIC20
HMS81004E@SOIC24 [ ( SA404 ) ]	HMS81004E@SOIC28

[(SA404)]	
HMS81008E(dip20)	HMS81008E
(dip24)	
HMS81008E(dip28)	HMS81008E@PLCC44
[(SA244)]	
HMS81008E@SOIC20 [(SA404)]	HMS81008E@SOIC24
[(SA404)]	
HMS81008E@SOIC28 [(SA404)]	HMS81016E
(dip20)	
HMS81016E(dip24)	HMS81016E
(dip28)	
HMS81016E@PLCC44 [(SA244)]	HMS81016E@SOIC20
[(SA404)]	
HMS81016E@SOIC24 [(SA404)]	HMS81016E@SOIC28
[(SA404)]	
HMS81020ET(dip20)	HMS81020ET
(dip24)	
HMS81020ET(dip28)	HMS81020ET@SOIC20
[(SA404)]	
HMS81020ET@SOIC24 [(SA404)]	HMS81020ET@SOIC28
[(SA404)]	
HMS81020TL(dip20)	HMS81020TL
(dip24)	
HMS81020TL(dip28)	HMS81020TL@SOIC20
[(SA404)]	
HMS81020TL@SOIC24 [(SA404)]	HMS81020TL@SOIC28
[(SA404)]	
HMS81024E(dip20)	HMS81024E
(dip24)	
HMS81024E(dip28)	HMS81024E@PLCC44
[(SA244)]	
HMS81024E@SOIC20 [(SA404)]	HMS81024E@SOIC24
[(SA404)]	
HMS81024E@SOIC28 [(SA404)]	HMS81032
(dip20)	
HMS81032(dip24)	HMS81032
(dip28)	
HMS81032@SOIC20 [(SA404)]	HMS81032@SOIC24
[(SA404)]	
HMS81032@SOIC28 [(SA404)]	HMS81032ET
(dip20)	
HMS81032ET(dip24)	HMS81032ET
(dip28)	

HMS81032ET@SOIC20 [(SA404)]	HMS81032ET@SOIC24
[(SA404)]	
HMS81032ET@SOIC28 [(SA404)]	HMS81032T
(dip20)	
HMS81032T(dip24)	HMS81032T
(dip28)	
HMS81032T@SOIC20 [(SA404)]	HMS81032T@SOIC24
[(SA404)]	
HMS81032T@SOIC28 [(SA404)]	HMS81032TL
(dip20)	
HMS81032TL(dip24)	HMS81032TL
(dip28)	
HMS81032TL@SOIC20 [(SA404)]	HMS81032TL@SOIC24
[(SA404)]	
HMS81032TL@SOIC28 [(SA404)]	
HMS87C1102A	
HMS87C1102A@SOP16 [(SA404)]	
HMS87C1104A	
HMS87C1104A@SOP16 [(SA404)]	
HMS87C1202A	
HMS87C1202A@SOP20 [(SA404)]	
HMS87C1204A	
HMS87C1204A@SOP20 [(SA404)]	
HMS87C1302A@SDIP24 [(SA022A-B005)]	
HMS87C1302A@SOP24 [(SA404)]	
HMS87C1304A@SDIP24 [(SA022A-B005)]	
HMS87C1304A@SOP24 [(SA404)]	
HMS87C1404B	
HMS87C1404B@SDIP28 [(SA022A)]	HMS87C1404B@SOIC28
[(SA404)]	
HMS87C1408B	HMS87C1408B@SDIP28
[(SA022A)]	
HMS87C1408B@SOIC28 [(SA404)]	
HMS87C1416B	
HMS87C1416B@SDIP28 [(SA022A)]	HMS87C1416B@SOIC28
[(SA404)]	
HMS87C1508B	
HMS87C1516B	
HMS87C1608B	
HMS87C1616B	
HMS87C1708B@SDIP42 [(SA028)]	HMS87C1716B@SDIP42
[(SA028)]	
HMS87C1808B@TQFP44 [(SA245A)]	HMS87C1816B@TQFP44

[ (SA245A) ]	
HMS87C5216	HMS87C5216@PLCC44
[ (SA244) ]	
HMS87C5216@SOIC28 [ (SA404) ]	HMS87C5216@TQFP44
[ (SA245A) ]	
HMS99C52	HMS99C52@PLCC44
[ (SA244) ]	
HMS99C52@TQFP44 [ (SA245A) ]	
HMS99C58	
HMS99C58@PLCC44 [ (SA244) ]	HMS99C58@TQFP44
[ (SA245A) ]	

## ICE

### E (E) PROM/FRAM/NVRAM

ICE25P05	ICE25P05@SOIC8
[ (SA602A) ]	
ICE27C010	ICE27C010@PLCC32
[ (SA015A1T) ]	
ICE27C010@TSOP32 [ (SA410T) ]	
ICE27C020	
ICE27C020@PLCC32 [ (SA015A1T) ]	ICE27C020@TSOP32
[ (SA410T) ]	
ICE27C512	ICE27C512@PLCC32
[ (SA015A1T) ]	
ICE27C512@TSOP28 [ (SA430T) ]	
ICE27LC010	
ICE27LC010@PLCC32 [ (SA015A1T) ]	ICE27LC010@TSOP32
[ (SA410T) ]	
ICE27LC020	ICE27LC020@PLCC32
[ (SA015A1T) ]	
ICE27LC020@TSOP32 [ (SA410T) ]	
ICE27LC512	
ICE27LC512@PLCC32 [ (SA015A1T) ]	ICE27LC512@TSOP28
[ (SA430T) ]	
ICE28LF010	ICE28LF010@PLCC32
[ (SA015A1T) ]	
ICE37C512	ICE37C512@PLCC32
[ (SA015A1T) ]	
ICE37C512@TSOP32 [ (SA410T) ]	
ICE37LC512	



ICE37LC512@PLCC32 [ (SA015A1T) ]  
[ (SA410T) ]

ICE37LC512@TSOP32

## ICMIC

### E ( E ) PROM / FRAM / NVRAM

X76F101  
[ (SA602A) ]

X76F101@SOIC8

X76F400@SOIC8 [ (SA602A) ]  
[ (SA026) ]

X76F400@TSSOP8

## ICSI

### E ( E ) PROM / FRAM / NVRAM

IC71V08F32AS04@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32AS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32AS08@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32AS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32BS04@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32BS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32BS08@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32BS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32CS04@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32CS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32CS08@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32CS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32DS04@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32DS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32DS08@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32DS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32ES04@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32ES04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32ES08@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32ES08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32FS04@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32FS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32FS08@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32FS08@FBGA73 [ (SA642A-B032A-Y096F001) ]

IC71V16F32AS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32AS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32AS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32AS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32BS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32BS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32BS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32BS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32CS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32CS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32CS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32CS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32DS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32DS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32DS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32DS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32ES04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32ES04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32ES08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32ES08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32FS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32FS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32FS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32FS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32GS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32GS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32HS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F32HS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F64IP16@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
 IC71V16F64IS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]

## MICROCONTROLLER

IC89LV51A IC89LV51A@PLCC44  
 [ ( SA244 ) ]  
 IC89LV51A@TQFP44 [ ( SA245A ) ]  
 IC89LV52A  
 IC89LV52A@PLCC44 [ ( SA244 ) ] IC89LV52A@TQFP44  
 [ ( SA245A ) ]  
 IS89C51A IS89C51A@PLCC44  
 [ ( SA244 ) ]  
 IS89C51A@TQFP44 [ ( SA245A ) ]

IS89C52A	
IS89C52A@PLCC44 [ (SA244) ]	IS89C52A@TQFP44
[ (SA245A) ]	
IS89C54	IS89C54@PLCC44
[ (SA244) ]	
IS89C54@TQFP44 [ (SA245A) ]	
IS89C58	
IS89C58@PLCC44 [ (SA244) ]	IS89C58@TQFP44
[ (SA245A) ]	
IS89C64	IS89C64@PLCC44
[ (SA244) ]	
IS89C64@TQFP44 [ (SA245A) ]	
IS89E54	
IS89E54@PLCC44 [ (SA244) ]	IS89E54@TQFP44
[ (SA245A) ]	
IS89E58	IS89E58@PLCC44
[ (SA244) ]	
IS89E58@TQFP44 [ (SA245A) ]	
IS89E64	
IS89E64@PLCC44 [ (SA244) ]	IS89E64@TQFP44
[ (SA245A) ]	

## ICT

### E (E) PROM/FRAM/NVRAM

27CX010	27CX010@PLCC32
[ (SA015A1T) ]	
27CX010@TSOP32 [ (SA410T) ]	
27CX161	
27CX162	
27CX256	
27CX321	
27CX322	
27CX641	
27CX642	
93C46	93C46@SOIC8
[ (SA602A) ]	
93C46A	93C46A@SOIC8
[ (SA602A) ]	
93C56A	93C56A@SOIC8
[ (SA602A) ]	

93C66A  
 [ (SA602A) ]  
 93CX46  
 [ (SA602A) ]  
 93CX56  
 [ (SA602A) ]  
 93CX66  
 [ (SA602A) ]

93C66A@SOIC8  
  
 93CX46@SOIC8  
  
 93CX56@SOIC8  
  
 93CX66@SOIC8

## PLD

PA7024  
 [ (SA008A) ]  
 PA7024(JN)@PLCC28 [ (SA008A) ]  
 [ (SA404) ]  
 PA7128  
 [ (SA008A) ]  
 PA7128@SOIC28 [ (SA404) ]  
 PA7140  
 PA7140@PLCC44 [ (SA244) ]  
 [ (SA245A) ]  
 PA7536  
 [ (SA008A) ]  
 PA7536@SOIC28 [ (SA404) ]  
 PA7540  
 PA7540(J)@PLCC28 [ (SA008A) ]  
 [ (SA008A) ]  
 PA7572  
 [ (SA244) ]  
 PA7572@TQFP44 [ (SA245A) ]  
 PEEL16CV8  
 PEEL16CV8@PLCC20 [ (SA001A) ]  
 [ (SA404) ]  
 PEEL16CV8@TSOP20 [ (SA026) ]  
 PEEL18CV8  
 PEEL18CV8@PLCC20 [ (SA001A) ]  
 [ (SA404) ]  
 PEEL18CV8@TSOP20 [ (SA026) ]  
 PEEL18CV8Z  
 PEEL18CV8Z@PLCC20 [ (SA001A) ]  
 [ (SA404) ]  
 PEEL18CV8Z@TSOP20 [ (SA026) ]

PA7024(J)@PLCC28  
  
 PA7024@SOIC24  
  
 PA7128@PLCC28  
  
 PA7140@TQFP44  
  
 PA7536@PLCC28  
  
 PA7540(JN)@PLCC28  
  
 PA7572@PLCC44  
  
 PEEL16CV8@SOIC20  
  
 PEEL18CV8@SOIC20  
  
 PEEL18CV8Z@SOIC20

PEEL18LV8Z

PEEL18LV8Z@PLCC20 [(SA001A)]  
[(SA404)]

PEEL18LV8Z@TSOP20 [(SA026)]

PEEL22CV10

PEEL22CV10@PLCC28 [(SA008A)]

PEEL22CV10A

PEEL22CV10A@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22CV10A@TSOP24 [(SA026)]

+

PEEL22CV10A+@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22CV10A+@TSOP24 [(SA026)]

+

PEEL22CV10A++@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22CV10A++@TSOP24 [(SA026)]

PEEL22CV10AZ

PEEL22CV10AZ@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22CV10AZ@TSOP24 [(SA026)]

+

PEEL22CV10AZ+@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22CV10AZ+@TSOP24 [(SA026)]

+

PEEL22CV10AZ++@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22CV10AZ++@TSOP24 [(SA026)]

PEEL22CV8

PEEL22CV8@PLCC24 [(SA008A)]  
[(SA404)]

PEEL22LV10AZ

[(SA008A)]

PEEL22LV10AZ@SOIC24 [(SA404)]  
[(SA026)]

PEEL22LV10AZ+

[(SA008A)]

PEEL22LV10AZ+@SOIC24 [(SA404)]  
[(SA026)]

PEEL22LV10AZ++

[(SA008A)]

PEEL18LV8Z@SOIC20

PEEL22CV10A@SOIC24

PEEL22CV10A

PEEL22CV10A+@SOIC24

PEEL22CV10A+

PEEL22CV10A++@SOIC24

PEEL22CV10AZ@SOIC24

PEEL22CV10AZ

PEEL22CV10AZ+@SOIC24

PEEL22CV10AZ+

PEEL22CV10AZ++@SOIC24

PEEL22CV8@SOIC24

PEEL22LV10AZ@PLCC28

PEEL22LV10AZ@TSOP24

PEEL22LV10AZ+@PLCC28

PEEL22LV10AZ+@TSOP24

PEEL22LV10AZ++@PLCC28

PEEL22LV10AZ++@SOIC24 [(SA404)]  
[(SA026)]

PEEL22LV10AZ++@TSOP24

## IMT

### E ( E ) PROM / FRAM / NVRAM

IM29F001B [(SA015A1T)]	IM29F001B@PLCC32
IM29F001B@TSOP32 [(SA410T)] [(SA620)]	IM29F001B@VSOP32
IM29F001T [(SA015A1T)]	IM29F001T@PLCC32
IM29F001T@TSOP32 [(SA410T)] [(SA620)]	IM29F001T@VSOP32
IM29F002B [(SA015A1T)]	IM29F002B@PLCC32
IM29F002B@TSOP32 [(SA410T)] [(SA620)]	IM29F002B@VSOP32
IM29F002T [(SA015A1T)]	IM29F002T@PLCC32
IM29F002T@TSOP32 [(SA410T)] [(SA620)]	IM29F002T@VSOP32
IM29F004B [(SA015A1T)]	IM29F004B@PLCC32
IM29F004B@TSOP32 [(SA410T)] [(SA620)]	IM29F004B@VSOP32
IM29F004T [(SA015A1T)]	IM29F004T@PLCC32
IM29F004T@TSOP32 [(SA410T)] [(SA620)]	IM29F004T@VSOP32
IM29LV004B [(SA015A1T)]	IM29LV004B@PLCC32
IM29LV004B@TSOP32 [(SA410T)] [(SA620)]	IM29LV004B@VSOP32
IM29LV004T [(SA015A1T)]	IM29LV004T@PLCC32
IM29LV004T@TSOP32 [(SA410T)] [(SA620)]	IM29LV004T@VSOP32
IM29LV400B@PSOP44 [(SA638)] B005)]	IM29LV400B@TSOP48 [(SA247-
IM29LV400T@PSOP44 [(SA638)]	IM29LV400T@TSOP48 [(SA247-

B005) ]

**INFINEON****MICROCONTROLLER**

SAB-C504-2EM@TQFP44 [(SA245A)]                      SAB-C505A-4EM@TQFP44  
 [(SA245A)]  
 SAB-C505CA-4EM@TQFP44 [(SA245A)]  
 SAB-C505L-4EM@PQFP80 [(PEP+S611A)]  
 SAB-C508-4EM@TQFP64 [(PEP+S625A)]  
 SAB-C508-4EP@SDIP64 [(PEP+S600A)]  
 SAB-C515C-8EM@TQFP80 [(PEP+S615B)]  
 SAB-C540U-1EN@PLCC44 [(SA244)]  
 SAB-C540U-1EP@SDIP52 [(PEP+S600A)]  
 SAB-C541U-1EN@PLCC44 [(SA244)]  
 SAB-C541U-1EP@SDIP52 [(PEP+S600A)]  
 SAB-XC167CI-16F20F@TQFP144 [(SA681-B14401)]  
 SAB-XC167CI-16F40F@TQFP144 [(SA681-B14401)]  
 SAF-C164CI-8EM@TQFP80 [(PEP+S615B)]  
 SAF-C504-2EM@TQFP44 [(SA245A)]                      SAF-C505A-4EM@TQFP44  
 [(SA245A)]  
 SAF-C505CA-4EM@TQFP44 [(SA245A)]  
 SAF-C505L-4EM@PQFP80 [(PEP+S611A)]  
 SAF-C508-4EM@TQFP64 [(PEP+S616)]  
 SAF-C508-4EP@SDIP64 [(PEP+S600A)]  
 SAF-C513AO-2EM@TQFP44 [(SA245A)]                      SAF-C513AO-2EN@PLCC44  
 [(SA244)]  
 SAF-C513AO-2EP  
 SAF-C515C-8EM@TQFP80 [(PEP+S615B)]  
 SAF-XC161CJ-16F20F@TQFP144 [(SA681-B14401)]  
 SAF-XC161CJ-16F40F@TQFP144 [(SA681-B14401)]  
 SAF-XC164CM-4F20F@TQFP64 [(PEP+S616)]  
 SAF-XC164CM-4F40F@TQFP64 [(PEP+S616)]  
 SAF-XC164CM-8F20F@TQFP64 [(PEP+S616)]  
 SAF-XC164CM-8F40F@TQFP64 [(PEP+S616)]  
 SAF-XC164CS-16F20F@TQFP100 [(PEP+S604)]  
 SAF-XC164CS-16F40F@TQFP100 [(PEP+S604)]  
 SAF-XC164CS-8F20F@TQFP100 [(PEP+S604)]  
 SAF-XC164CS-8F40F@TQFP100 [(PEP+S604)]  
 SAF-XC164D-16F20F@TQFP100 [(PEP+S604)]  
 SAF-XC164D-16F40F@TQFP100 [(PEP+S604)]

SAF-XC164D-8F20F@TQFP100 [(PEP+S604)]  
SAF-XC164D-8F40F@TQFP100 [(PEP+S604)]  
SAF-XC164N-16F20F@TQFP100 [(PEP+S604)]  
SAF-XC164N-16F40F@TQFP100 [(PEP+S604)]  
SAF-XC164N-8F20F@TQFP100 [(PEP+S604)]  
SAF-XC164N-8F40F@TQFP100 [(PEP+S604)]  
SAF-XC164S-16F20F@TQFP100 [(PEP+S604)]  
SAF-XC164S-16F40F@TQFP100 [(PEP+S604)]  
SAF-XC164S-8F20F@TQFP100 [(PEP+S604)]  
SAF-XC164S-8F40F@TQFP100 [(PEP+S604)]  
SAF-XC167CI-16F20F@TQFP144 [(SA681-B14401)]  
SAF-XC167CI-16F40F@TQFP144 [(SA681-B14401)]  
SAF-XC846-1FR@TSSOP38 [(SA693)]  
SAF-XC856CLM-13FFI@QFP64(\*) [(SA732+B227)]  
SAF-XC856CLM-16FFI@QFP64(\*) [(SA732+B227)]  
SAF-XC856CLM-9FFI@QFP64(\*) [(SA732+B227)]  
SAF-XC856LM-13FFI@QFP64(\*) [(SA732+B227)]  
SAF-XC856LM-16FFI@QFP64(\*) [(SA732+B227)]  
SAF-XC856LM-9FFI@QFP64(\*) [(SA732+B227)]  
SAF-XC866-1FR@TSSOP38 [(SA693)]  
SAF-XC866-2FR(A STEP)@TSSOP38 [(SA693)]  
SAF-XC866-2FR(BB STEP)@TSSOP38 [(SA693)]  
SAF-XC866-4FR(A STEP)@TSSOP38 [(SA693)]  
SAF-XC866-4FR(BB STEP)@TSSOP38 [(SA693)]  
SAF-XC866L-2FR(A STEP)@TSSOP38 [(SA693)]  
SAF-XC866L-2FR(BB STEP)@TSSOP38 [(SA693)]  
SAF-XC866L-4FR(A STEP)@TSSOP38 [(SA693)]  
SAF-XC866L-4FR(BB STEP)@TSSOP38 [(SA693)]  
SAF-XC878-13FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878-13FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878-16FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878-16FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878CM-13FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878CM-13FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878CM-16FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878CM-16FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878M-13FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878M-13FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878M-16FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878M-16FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC886-6FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886-6FFA(5v)@QFP48 [(SA248)]  
SAF-XC886-6FFI(3.3v)@QFP48 [(SA248)]



SAF-XC886-6FFI(5v)@QFP48 [(SA248)]  
SAF-XC886-8FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886-8FFA(5v)@QFP48 [(SA248)]  
SAF-XC886-8FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886-8FFI(5v)@QFP48 [(SA248)]  
SAF-XC886C-6FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886C-6FFA(5v)@QFP48 [(SA248)]  
SAF-XC886C-6FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886C-6FFI(5v)@QFP48 [(SA248)]  
SAF-XC886C-8FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886C-8FFA(5v)@QFP48 [(SA248)]  
SAF-XC886C-8FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886C-8FFI(5v)@QFP48 [(SA248)]  
SAF-XC886CLM-6FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886CLM-6FFA(5v)@QFP48 [(SA248)]  
SAF-XC886CLM-6FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886CLM-6FFI(5v)@QFP48 [(SA248)]  
SAF-XC886CLM-8FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886CLM-8FFA(5v)@QFP48 [(SA248)]  
SAF-XC886CLM-8FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886CLM-8FFI(5v)@QFP48 [(SA248)]  
SAF-XC886CM-6FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886CM-6FFA(5v)@QFP48 [(SA248)]  
SAF-XC886CM-6FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886CM-6FFI(5v)@QFP48 [(SA248)]  
SAF-XC886CM-8FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886CM-8FFA(5v)@QFP48 [(SA248)]  
SAF-XC886CM-8FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886CM-8FFI(5v)@QFP48 [(SA248)]  
SAF-XC886LM-6FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886LM-6FFA(5v)@QFP48 [(SA248)]  
SAF-XC886LM-6FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886LM-6FFI(5v)@QFP48 [(SA248)]  
SAF-XC886LM-8FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886LM-8FFA(5v)@QFP48 [(SA248)]  
SAF-XC886LM-8FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886LM-8FFI(5v)@QFP48 [(SA248)]  
SAF-XC888-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-8FFA(5v)@QFP64(\*) [(SA732+B227)]

SAF-XC888-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAH-C504-2EM@TQFP44 [(SA245A)] SAH-C505A-4EM@TQFP44  
[(SA245A)]  
SAH-C505CA-4EM@TQFP44 [(SA245A)]  
SAK-C164CI-8EM@TQFP80 [(PEP+S615B)]  
SAK-C504-2EM@TQFP44 [(SA245A)] SAK-C505A-4EM@TQFP44  
[(SA245A)]  
SAK-C505CA-4EM@TQFP44 [(SA245A)]  
SAK-C505L-4EM@PQFP80 [(PEP+S611A)]  
SAK-C515C-8EM@TQFP80 [(PEP+S615B)]

SAK-XC161CJ-16F20F@TQFP144 [(SA681-B14401)]  
SAK-XC161CJ-16F40F@TQFP144 [(SA681-B14401)]  
SAK-XC164CM-4F20F@TQFP64 [(PEP+S616)]  
SAK-XC164CM-4F40F@TQFP64 [(PEP+S616)]  
SAK-XC164CM-8F20F@TQFP64 [(PEP+S616)]  
SAK-XC164CM-8F40F@TQFP64 [(PEP+S616)]  
SAK-XC164CS-16F20F@TQFP100 [(PEP+S604)]  
SAK-XC164CS-16F40F@TQFP100 [(PEP+S604)]  
SAK-XC164CS-8F20F@TQFP100 [(PEP+S604)]  
SAK-XC164CS-8F40F@TQFP100 [(PEP+S604)]  
SAK-XC167CI-16F20F@TQFP144 [(SA681-B14401)]  
SAK-XC167CI-16F40F@TQFP144 [(SA681-B14401)]  
SAK-XC846-1FR@TSSOP38 [(SA693)]            SAK-XC866-1FR@TSSOP38  
[(SA693)]  
SAK-XC866-2FR(A STEP)@TSSOP38 [(SA693)]  
SAK-XC866-2FR(BB STEP)@TSSOP38 [(SA693)]  
SAK-XC866-4FR(A STEP)@TSSOP38 [(SA693)]  
SAK-XC866-4FR(BB STEP)@TSSOP38 [(SA693)]  
SAK-XC866L-2FR(A STEP)@TSSOP38 [(SA693)]  
SAK-XC866L-2FR(BB STEP)@TSSOP38 [(SA693)]  
SAK-XC866L-4FR(A STEP)@TSSOP38 [(SA693)]  
SAK-XC866L-4FR(BB STEP)@TSSOP38 [(SA693)]  
SAK-XC886-6FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886-6FFA(5v)@QFP48 [(SA248)]  
SAK-XC886-6FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886-6FFI(5v)@QFP48 [(SA248)]  
SAK-XC886-8FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886-8FFA(5v)@QFP48 [(SA248)]  
SAK-XC886-8FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886-8FFI(5v)@QFP48 [(SA248)]  
SAK-XC886C-6FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886C-6FFA(5v)@QFP48 [(SA248)]  
SAK-XC886C-6FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886C-6FFI(5v)@QFP48 [(SA248)]  
SAK-XC886C-8FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886C-8FFA(5v)@QFP48 [(SA248)]  
SAK-XC886C-8FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886C-8FFI(5v)@QFP48 [(SA248)]  
SAK-XC886CLM-6FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886CLM-6FFA(5v)@QFP48 [(SA248)]  
SAK-XC886CLM-6FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886CLM-6FFI(5v)@QFP48 [(SA248)]  
SAK-XC886CLM-8FFA(3.3v)@QFP48 [(SA248)]

SAK-XC886CLM-8FFA(5v)@QFP48 [(SA248)]  
SAK-XC886CLM-8FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886CLM-8FFI(5v)@QFP48 [(SA248)]  
SAK-XC886CM-6FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886CM-6FFA(5v)@QFP48 [(SA248)]  
SAK-XC886CM-6FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886CM-6FFI(5v)@QFP48 [(SA248)]  
SAK-XC886CM-8FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886CM-8FFA(5v)@QFP48 [(SA248)]  
SAK-XC886CM-8FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886CM-8FFI(5v)@QFP48 [(SA248)]  
SAK-XC886LM-6FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886LM-6FFA(5v)@QFP48 [(SA248)]  
SAK-XC886LM-6FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886LM-6FFI(5v)@QFP48 [(SA248)]  
SAK-XC886LM-8FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886LM-8FFA(5v)@QFP48 [(SA248)]  
SAK-XC886LM-8FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886LM-8FFI(5v)@QFP48 [(SA248)]  
SAK-XC888-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888C-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888C-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888C-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888C-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888C-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888C-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888C-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888C-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CLM-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CLM-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CLM-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CLM-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CLM-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CLM-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CLM-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CLM-8FFI(5v)@QFP64(\*) [(SA732+B227)]

SAK-XC888CM-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CM-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CM-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CM-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CM-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CM-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CM-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CM-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888LM-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888LM-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888LM-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888LM-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888LM-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888LM-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888LM-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888LM-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAX-XC878-13FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAX-XC878-13FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAX-XC878-16FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAX-XC878-16FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAX-XC878C-13FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAX-XC878C-13FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAX-XC878C-16FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAX-XC878C-16FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAX-XC878CM-13FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAX-XC878CM-13FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAX-XC878CM-16FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAX-XC878CM-16FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAX-XC878L-13FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAX-XC878L-13FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAX-XC878L-16FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAX-XC878L-16FFI(5v)@QFP64(\*) [(SA732+B227)]

## INTEL

### E (E) PROM / FRAM / NVRAM

27010 27010@PLCC32  
[(SA015A1T)]  
27010@TSOP32 [(SA410T)]  
27128  
27128A

27128B  
2716  
27210  
27256  
2732  
2732A  
27512  
2764  
2764A  
27C010 27C010@PLCC32  
[(SA015A1T)]  
27C010@TSOP32 [(SA410T)]  
27C010A  
27C010A@PLCC32 [(SA015A1T)] 27C010A@TSOP32  
[(SA410T)]  
27C020 27C020@PLCC32  
[(SA015A1T)]  
27C020@TSOP32 [(SA410T)]  
27C040  
27C040@PLCC32 [(SA015A1T)] 27C040@TSOP32  
[(SA410T)]  
27C100 27C100@PLCC32  
[(SA015A1T)]  
27C100@TSOP32 [(SA410T)]  
27C128  
27C128@PLCC32 [(SA015A1T)]  
27C210  
27C210@PLCC44 [(SA244)]  
27C220  
27C220@PLCC44 [(SA244)]  
27C240  
27C240@PLCC44 [(SA244)]  
27C256  
27C256@PLCC32 [(SA015A1T)]  
27C400  
27C400@PLCC44 [(SA244)]  
27C512  
27C512@PLCC32 [(SA015A1T)]  
27C64  
27C64@PLCC32 [(SA015A1T)]  
27C800  
27S512  
2816A

2817A

2864A

68C257

68C257@PLCC32

[ (SA015A1T) ]

87C256

87C257

87C257@PLCC32 [ (SA015A1T) ]

87C64

D27011

D27513

D27C011

D27C513

D2816

D28F256

D28F256A

D28F512

DA28F016SA@SSOP56 [ (SA629A-B013) ]

DA28F016SV@SSOP56 [ (SA629A-B013) ]

DA28F320J5(low)@SSOP56 [ (SA629-B013) ]

DA28F320J5@SSOP56 [ (SA629A-B013) ]

DA28F320J5A(low)@SSOP56 [ (SA629-B013) ]

DA28F320J5A@SSOP56 [ (SA629A-B013) ]

DA28F640J5@SSOP56 [ (SA629A-B013) ]

DA28F640J5A@SSOP56 [ (SA629A-B013) ]

DD28F032SA@TSOP56 [ (SA628-B011) ]

DT28F016SA@SSOP56 [ (SA629A-B013) ]

DT28F016SA@TSOP56 [ (SA628-B011) ]

DT28F016SV@SSOP56 [ (SA629A-B013) ]

DT28F016SV@TSOP56 [ (SA628-B011) ]

DT28F160F3B@SSOP56 [ (SA629A-B015) ]

DT28F160F3T@SSOP56 [ (SA629A-B015) ]

DT28F160S3@SSOP56 [ (SA629A-B013) ]

DT28F160S5@SSOP56 [ (SA629A-B013) ]

DT28F320J5@SSOP56 [ (SA629A-B013) ]

DT28F320J5A@SSOP56 [ (SA629A-B013) ]

DT28F320S3@SSOP56 [ (SA629A-B013) ]

DT28F320S5@SSOP56 [ (SA629A-B013) ]

DT28F640J5@SSOP56 [ (SA629A-B013) ]

DT28F640J5A@SSOP56 [ (SA629A-B013) ]

DT28F800F3B@SSOP56 [ (SA629A-B015) ]

DT28F800F3T@SSOP56 [ (SA629A-B015) ]

E28F001BX-B@TSOP32 [ (SA410T) ]

E28F001BX-T@TSOP32

[ (SA410T) ]

E28F002BCT@TSOP40 [(SA409T)] [(SA409T)]	E28F002BEB@TSOP40
E28F002BET@TSOP40 [(SA409T)] [(SA409T)]	E28F002BLB@TSOP40
E28F002BLT@TSOP40 [(SA409T)] [(SA409T)]	E28F002BVB@TSOP40
E28F002BVT@TSOP40 [(SA409T)] [(SA409T)]	E28F002BXB@TSOP40
E28F002BXT@TSOP40 [(SA409T)] [(SA409T)]	E28F004B5B@TSOP40
E28F004B5T@TSOP40 [(SA409T)] [(SA409T)]	E28F004BEB@TSOP40
E28F004BET@TSOP40 [(SA409T)] [(SA409T)]	E28F004BLB@TSOP40
E28F004BLT@TSOP40 [(SA409T)] [(SA409T)]	E28F004BVB@TSOP40
E28F004BVT@TSOP40 [(SA409T)] [(SA409T)]	E28F004BXB@TSOP40
E28F004BXT@TSOP40 [(SA409T)] [(SA409T)]	E28F004S3@TSOP40
E28F004S5@TSOP40 [(SA409T)] [(SA409T)]	E28F004SC@TSOP40
E28F008BEB@TSOP40 [(SA409T)] [(SA409T)]	E28F008BET@TSOP40
E28F008BLB@TSOP40 [(SA409T)] [(SA409T)]	E28F008BLT@TSOP40
E28F008BVB@TSOP40 [(SA409T)] [(SA409T)]	E28F008BVT@TSOP40
E28F008BXB@TSOP40 [(SA409T)] [(SA409T)]	E28F008BXT@TSOP40
E28F008S3@TSOP40 [(SA409T)] [(SA409T)]	E28F008S5@TSOP40
E28F008SA@TSOP40 [(SA409T)] [(SA409T)]	E28F008SA-L@TSOP40
E28F008SC@TSOP40 [(SA409T)] [(SA410T)]	E28F010@TSOP32
E28F016S3@TSOP40 [(SA409T)] [(SA409T)]	E28F016S5@TSOP40
E28F016SA@TSOP56 [(SA628-B011)] [(SA409T)]	E28F016SC@TSOP40
E28F016SV@TSOP56 [(SA628-B011)] [(SA410T)]	E28F020@TSOP32
E28F128J3A@TSOP56 [(SA628-B018)]	E28F200B5B@TSOP48 [(SA247-



B005) ]  
 E28F200B5T@TSOP48 [ (SA247-B005) ]      E28F200BVB@TSOP56 [ (SA628-B012) ]  
 E28F200BVT@TSOP56 [ (SA628-B012) ]      E28F200BVB@TSOP56 [ (SA628-B012) ]  
 E28F200BXT@TSOP56 [ (SA628-B012) ]      E28F200BVB@TSOP56 [ (SA628-B012) ]  
 E28F200CVT@TSOP48 [ (SA247-B005) ]      E28F200CVB@TSOP48 [ (SA247-B005) ]  
 [ (SA410T) ]      E28F256@TSOP32  
 E28F256A@TSOP32 [ (SA410T) ]      E28F320J3A@TSOP56 [ (SA628-B018) ]  
 B018) ]  
 E28F320J5(low)@TSOP56 [ (SA628-B011) ]  
 E28F320J5@TSOP56 [ (SA628-B011) ]  
 E28F320J5A(low)@TSOP56 [ (SA628-B011) ]  
 E28F320J5A@TSOP56 [ (SA628-B011) ]      E28F400B5B@TSOP48 [ (SA247-B005) ]  
 B005) ]  
 E28F400B5T@TSOP48 [ (SA247-B005) ]      E28F400BVB@TSOP56 [ (SA628-B012) ]  
 B012) ]  
 E28F400BVT@TSOP56 [ (SA628-B012) ]      E28F400BVB@TSOP56 [ (SA628-B012) ]  
 B012) ]  
 E28F400BXT@TSOP56 [ (SA628-B012) ]      E28F400BVB@TSOP56 [ (SA628-B012) ]  
 B012) ]  
 E28F400CVT@TSOP48 [ (SA247-B005) ]      E28F400CVB@TSOP48 [ (SA247-B005) ]  
 [ (SA410T) ]      E28F512@TSOP32  
 E28F640J3A@TSOP56 [ (SA628-B018) ]      E28F800B5B@TSOP48 [ (SA247-B005) ]  
 B005) ]  
 E28F800B5T@TSOP48 [ (SA247-B005) ]      E28F800CEB@TSOP48 [ (SA247-B005) ]  
 B005) ]  
 E28F800CET@TSOP48 [ (SA247-B005) ]      E28F800CVB@TSOP48 [ (SA247-B005) ]  
 B005) ]  
 E28F800CVT@TSOP48 [ (SA247-B005) ]      E82802AA@TSOP40  
 [ (SA409T) ]  
 E82802AB@TSOP40 [ (SA409T) ]      E82802AC@TSOP40  
 [ (SA409T) ]  
 F28F010@TSOP32 [ (SA410T) ]      F28F020@TSOP32  
 [ (SA410T) ]  
 F28F256@TSOP32 [ (SA410T) ]      F28F256A@TSOP32  
 [ (SA410T) ]  
 F28F512@TSOP32 [ (SA410T) ]  
 G28F640J5@uBGA56 [ (SA644A-B028A-Y072F001Y) ]  
 G28F640J5A@uBGA56 [ (SA644A-B028A-Y072F001Y) ]  
 GE28F008B3BA@uBGA48 [ (SA634) ]      GE28F008B3TA@uBGA48  
 [ (SA634) ]

GE28F128K18C@FBGA56 [(SA656D-B085A-T056F001Y)]  
GE28F128K3C@FBGA56 [(SA656D-B085A-T056F001Y)]  
GE28F128L18B@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F128L18T@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F128L30B@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F128L30T@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F128W18BC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W18BC@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W18BD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W18BD@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W18TC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W18TC@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W18TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W18TD@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W30BC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W30BC@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W30BD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W30BD@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W30TC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W30TC@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W30TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W30TD@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F160B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3TC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3TD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160C3BC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F160C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F160C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F160C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F160C3TC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F160C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F160C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F160C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F256K18C@FBGA79 [(SA656B-B103A-T063F001Y)]  
GE28F256K3C@FBGA79 [(SA656B-B103A-T063F001Y)]  
GE28F256L18B@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F256L18T@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F256L30B@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F256L30T@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F320B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]

GE28F320B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F320B3TC@uBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320B3TD@uBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3BC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3TC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320J3A@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320J3C@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320W18BC(NO EFP)@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18BC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18TC(NO EFP)@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W18TC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W30BC(NO EFP)@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W30BC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W30TC(NO EFP)@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W30TC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F640B3TC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F640C3BC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F640C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F640C3TC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F640C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F640J3C@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F640K18C@FBGA56 [(SA644A-B025B-Y072F001Y)]  
GE28F640K3C@FBGA56 [(SA644A-B025B-Y072F001Y)]  
GE28F640L18B@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640L18T@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640L30B@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640L30T@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640W18BC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18BC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18TC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]

GE28F640W18TC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W30BC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30BC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30TC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30TC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F800B3BA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F800B3TA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F800C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F800C3BA@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F800C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F800C3TA@VFBGA48 [(SA634A-B005A-Y048F001)]  
GT28F016C3BA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F016C3TA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F032C3BA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F032C3TA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F128W30BC(NO EFP)@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30BC@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30BD(NO EFP)@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30BD@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30TC(NO EFP)@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30TC@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30TD(NO EFP)@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30TD@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F160B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3BA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3TA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F160C3BA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F160C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F160C3TA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F320B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F320B3T@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F320C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F320C3BA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F320C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F320C3TA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F800B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F800B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]  
JS28F128J3C@TSOP56 [(SA628-B018)]  
JS28F128J3D@TSOP56 [(SA628-B018)]

JS28F128P30B@TSOP56 [ ( SA628-B131 ) ]  
 JS28F128P30T@TSOP56 [ ( SA628-B131 ) ]  
 JS28F128P33B@TSOP56 [ ( SA628-B131 ) ]  
 JS28F128P33T@TSOP56 [ ( SA628-B131 ) ]  
 JS28F160B3BD@TSOP48 [ ( SA247-B005 ) ]  
 JS28F160B3TD@TSOP48 [ ( SA247-B005 ) ]  
 JS28F160C3BD@TSOP48 [ ( SA247-B005 ) ]  
 JS28F160C3TD@TSOP48 [ ( SA247-B005 ) ]  
 JS28F256P30B@TSOP56 [ ( SA628-B131 ) ]  
 JS28F256P30T@TSOP56 [ ( SA628-B131 ) ]  
 JS28F256P33B@TSOP56 [ ( SA628-B131 ) ]  
 JS28F256P33T@TSOP56 [ ( SA628-B131 ) ]  
 JS28F320B3BD@TSOP48 [ ( SA247-B005 ) ]  
 JS28F320B3TD@TSOP48 [ ( SA247-B005 ) ]  
 JS28F320C3BD@TSOP48 [ ( SA247-B005 ) ]  
 JS28F320C3TD@TSOP48 [ ( SA247-B005 ) ]  
 JS28F320J3C@TSOP56 [ ( SA628-B018 ) ]  
 JS28F320J3D@TSOP56 [ ( SA628-B018 ) ]  
 JS28F640J3C@TSOP56 [ ( SA628-B018 ) ]  
 JS28F640J3D@TSOP56 [ ( SA628-B018 ) ]  
 JS28F640P30B(Low)@TSOP56 [ ( SA628-B131 ) ]  
 JS28F640P30B@TSOP56 [ ( SA628-B131 ) ]  
 JS28F640P30T@TSOP56 [ ( SA628-B131 ) ]  
 JS28F640P33B@TSOP56 [ ( SA628-B131 ) ]  
 JS28F640P33T@TSOP56 [ ( SA628-B131 ) ]  
 JS28F800C3BD@TSOP48 [ ( SA247-B005 ) ]  
 JS28F800C3TD@TSOP48 [ ( SA247-B005 ) ]  
 JS48F4400P0TB00@TSOP56 [ ( SA628-B164 ) ]  
 JS48F4400P0VB00@TSOP56 [ ( SA628-B164 ) ]  
 JS48F4400P0VT00@TSOP56 [ ( SA628-B164 ) ]  
 JZ48F4000L0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
 JZ48F4000L0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
 JZ48F4000L0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
 JZ48F4000L0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
 LZ38F4060L0YBB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
 LZ38F4060L0YTB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
 LZ38F4070L0YBP1@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
 M28F010 M28F010@PLCC32  
 [ ( SA015A1T ) ]  
 M28F010@TSOP32 [ ( SA410T ) ] N28F001BN-B@PLCC32  
 [ ( SA015A1T ) ]  
 N28F001BN-T@PLCC32 [ ( SA015A1T ) ] N28F001BX-B@PLCC32  
 [ ( SA015A1T ) ]

N28F001BX-T@PLCC32 [(SA015A1T)]	N28F010@PLCC32
[(SA015A1T)]	
N28F020@PLCC32 [(SA015A1T)]	N28F256@PLCC32
[(SA015A1T)]	
N28F256A@PLCC32 [(SA015A1T)]	N28F512@PLCC32
[(SA015A1T)]	
N82802AA@PLCC32 [(SA015A1T)]	N82802AB@PLCC32
[(SA015A1T)]	
N82802AC@PLCC32 [(SA015A1T)]	
NZ48F4000LOYBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]	
NZ48F4000LOYTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]	
NZ48F4000LOZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]	
NZ48F4000LOZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]	
P27011	
P27128A	
P27128A@PLCC32 [(SA015A1T)]	
P27128B	
P27128B@PLCC32 [(SA015A1T)]	
P27256	
P27256@PLCC32 [(SA015A1T)]	
P27512	
P27513	
P2764A	
P2764A@PLCC32 [(SA015A1T)]	
P27C011	
P27C128	P27C128@PLCC32
[(SA015A1T)]	
P27C256	P27C256@PLCC32
[(SA015A1T)]	
P27C513	
P27C64	
P27C64@PLCC32 [(SA015A1T)]	P28F001BX-
B	
P28F001BX-T	P28F002BCT@TSOP40
[(SA409T)]	
P28F010	
P28F020	
P28F256	
P28F256A	
P28F512	
P87C64	
P87C64@PLCC32 [(SA015A1T)]	PA28F004S3@PSOP44
[(SA638)]	

PA28F004S5@PSOP44 [ (SA638) ] [ (SA638) ]	PA28F004SC@PSOP44
PA28F008S3@PSOP44 [ (SA638) ] [ (SA638) ]	PA28F008S5@PSOP44
PA28F008SA@PSOP44 [ (SA638) ] [ (SA638) ]	PA28F008SA-L@PSOP44
PA28F008SC@PSOP44 [ (SA638) ] [ (SA638) ]	PA28F016S3@PSOP44
PA28F016S5@PSOP44 [ (SA638) ] [ (SA638) ]	PA28F016SC@PSOP44
PA28F200B5B@PSOP44 [ (SA638) ] [ (SA638) ]	PA28F200B5T@PSOP44
PA28F200BVB@PSOP44 [ (SA638) ] [ (SA638) ]	PA28F200BVT@PSOP44
PA28F200BXB@PSOP44 [ (SA638) ] [ (SA638) ]	PA28F200BXT@PSOP44
PA28F400B5B@PSOP44 [ (SA638) ] [ (SA638) ]	PA28F400B5T@PSOP44
PA28F400BVB@PSOP44 [ (SA638) ] [ (SA638) ]	PA28F400BVT@PSOP44
PA28F400BXB@PSOP44 [ (SA638) ] [ (SA638) ]	PA28F400BXT@PSOP44
PA28F800B5B@PSOP44 [ (SA638) ] [ (SA638) ]	PA28F800B5T@PSOP44
PA28F800BVB@PSOP44 [ (SA638) ] [ (SA638) ]	PA28F800BVT@PSOP44
PC28F128J3C@FBGA64 [ (SA655A-B054A-T064F001Y) ]	
PC28F128J3D@FBGA64 [ (SA655A-B054A-T064F001Y) ]	
PC28F128P30B@EBGA64 [ (SA655G-B122A-T064F001Y) ]	
PC28F128P30T@EBGA64 [ (SA655G-B122A-T064F001Y) ]	
PC28F128P33B@EBGA64 [ (SA655K-B122A-T064F001Y) ]	
PC28F128P33T@EBGA64 [ (SA655K-B122A-T064F001Y) ]	
PC28F160C3BD@FBGA64 [ (SA655J-B037A-T064F001Y) ]	
PC28F160C3TD@FBGA64 [ (SA655J-B037A-T064F001Y) ]	
PC28F256P30B@EBGA64 [ (SA655G-B122A-T064F001Y) ]	
PC28F256P30T@EBGA64 [ (SA655G-B122A-T064F001Y) ]	
PC28F256P33B@EBGA64 [ (SA655G-B122A-T064F001Y) ]	
PC28F256P33T@EBGA64 [ (SA655G-B122A-T064F001Y) ]	
PC28F320C3BD@FBGA64 [ (SA655J-B037A-T064F001Y) ]	
PC28F320C3TD@FBGA64 [ (SA655J-B037A-T064F001Y) ]	
PC28F320J3C@FBGA64 [ (SA655A-B054A-T064F001Y) ]	
PC28F320J3D@FBGA64 [ (SA655A-B054A-T064F001Y) ]	
PC28F640J3C@FBGA64 [ (SA655A-B054A-T064F001Y) ]	

PC28F640J3D@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
PC28F640P30B@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F640P30T@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F640P33B@EBGA64 [ (SA655K-B122A-T064F001Y) ]  
PC28F640P33T@EBGA64 [ (SA655K-B122A-T064F001Y) ]  
PC28F800C3BD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
PC28F800C3TD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
PC48F3300J0Z00S@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
PC48F4400P0TB00@FBGA64 [ (SA655G-B163A-T064F001Y) ]  
PC48F4400P0VB00@FBGA64 [ (SA655G-B163A-T064F001Y) ]  
PC48F4400P0VT00@FBGA64 [ (SA655G-B163A-T064F001Y) ]  
PF38F1020W0YBQ1@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1020W0YTQ1@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030C0ZBL0@FBGA72 [ (SA642R-B041A-T096F001Y) ]  
PF38F1030C0ZTL0@FBGA72 [ (SA642R-B041A-T096F001Y) ]  
PF38F1030W0YBQ2@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YBQE@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YBQF@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YCQ3@FBGA88 [ (SA642R-B180A-T096F001Y) ]  
PF38F1030W0YCQE@FBGA88 [ (SA642R-B180A-T096F001Y) ]  
PF38F1030W0YTQ2@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YTQE@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YTQF@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YUQ3@FBGA88 [ (SA642R-B180A-T096F001Y) ]  
PF38F1030W0YUQE@FBGA88 [ (SA642R-B180A-T096F001Y) ]  
PF38F1030W0ZBQ0@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0ZTQ0 (SLOW)@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0ZTQ0@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F2020W0ZBQ1@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F2020W0ZTQ1@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F2030W0YBQ1@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F2030W0YBQ2@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F2030W0YBQE@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F2030W0YBQF@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F2030W0YCQ3@FBGA88 [ (SA642R-B180A-T096F001Y) ]  
PF38F2030W0YCQE@FBGA88 [ (SA642R-B180A-T096F001Y) ]  
PF38F2030W0YTQ1@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F2030W0YTQ2@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F2030W0YTQE@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F2030W0YTQF@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F2030W0YUQ3@FBGA88 [ (SA642R-B180A-T096F001Y) ]  
PF38F2030W0YUQE@FBGA88 [ (SA642R-B180A-T096F001Y) ]  
PF38F2030W0ZBQ2@FBGA88 [ (SA642R-B112A-T096F001Y) ]



PF38F2030W0ZTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2040W0YBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2040W0YCQ1@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YCQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YCQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2040W0YUQ1@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YUQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YUQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F2040W0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3040L0YBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F3040L0YBQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0YBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F3040L0YCQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3040L0YCQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3040L0YTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0YTQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0YTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F3040L0YUQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3040L0YUQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3040L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3040L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3040M0Y0CE@FBGA107 [ ( SA664F-B148A-W108F001N ) ]  
PF38F3040M0Y1QE@FBGA88 [ ( SA642R-B303A-T096F001Y ) ]  
PF38F3040M0Y3QE@FBGA88 [ ( SA642R-B303A-T096F001Y ) ]  
PF38F3050L0YBQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0YBQ2@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0YCQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3050L0YCQ2@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3050L0YCQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3050L0YTQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0YTQ2@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0YUQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3050L0YUQ2@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3050L0YUQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3050L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3050L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3050M0Y0QE@FBGA88 [ ( SA642R-B300A-T096F001Y ) ]

PF38F3350LLZDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
PF38F3350W0ZDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
PF38F3350WWZDQ1@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
PF38F4040L0YCQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F4040L0YUQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F4050L0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YBQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YCQ0@FBGA88 [ ( SA642A-B180A-Y096F001Y ) ]  
PF38F4050L0YCQ3@FBGA88 [ ( SA642A-B180A-Y096F001Y ) ]  
PF38F4050L0YCQ4@FBGA88 [ ( SA642A-B180A-Y096F001Y ) ]  
PF38F4050L0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YTQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YUQ0@FBGA88 [ ( SA642A-B180A-Y096F001Y ) ]  
PF38F4050L0YUQ3@FBGA88 [ ( SA642A-B180A-Y096F001Y ) ]  
PF38F4050L0YUQ4@FBGA88 [ ( SA642A-B180A-Y096F001Y ) ]  
PF38F4050L0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050M0Y0C0@FBGA107 [ ( SA664F-B148A-W108F001N ) ]  
PF38F4050M0Y0Q0@FBGA88 [ ( SA642R-B300A-T096F001Y ) ]  
PF38F4050M0Y0QE@FBGA88 [ ( SA642R-B300A-T096F001Y ) ]  
PF38F4055L0YBQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4055L0YTQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4060L0YBB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4060L0YBB1@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4060L0YTB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4060L0YTB1@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4060M0Y0BE@FBGA105 [ ( SA664F-B298A-W108F001Y ) ]  
PF38F4060M0Y0C0@FBGA107 [ ( SA664F-B148A-W108F001N ) ]  
PF38F4070V0YBPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
PF38F4350LLYBQ1@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4350LLYBQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4350LLYTQ1@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4350LLYTQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LLYBQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LLYTQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LVYBQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LVYBQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LVYTQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LVYTQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]

PF38F4455LLYBQ0@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4455LLYBQ1@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4455LLYBQ2@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4455LLYTQ0@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4455LLYTQ1@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4455LLYTQ2@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4460EEYBQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4460EEYTQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4460LLYBB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4462LLYDB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4466LVYBQ0@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4466LVYTQ0@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4470LLYBH0@FBGA137 [ ( SA678B-B159A-P137F001Y ) ]  
PF38F4470LLYFH0@FBGA137 [ ( SA678B-B159A-P137F001Y ) ]  
PF38F4470LLYGH0@FBGA137 [ ( SA678B-B159A-P137F001Y ) ]  
PF38F4470LLYTH0@FBGA137 [ ( SA678B-B159A-P137F001Y ) ]  
PF38F4470VVUBPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
PF38F4470VVUTPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
PF38F4476VVUBPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
PF38F4476VVUTPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
PF38F5050M0Y0C0@FBGA107 [ ( SA664F-B148A-W108F001N ) ]  
PF38F5060M0Y0BE@FBGA105 [ ( SA664F-B298A-W108F001Y ) ]  
PF38F5060M0Y0C0@FBGA107 [ ( SA664F-B148A-W108F001N ) ]  
PF38F5060M0Y0CE@FBGA107 [ ( SA664F-B148A-W108F001N ) ]  
PF38F5070M0Y0B0@FBGA105 [ ( SA664F-B298A-W108F001Y ) ]  
PF38F5070M0Y0BE@FBGA105 [ ( SA664F-B298A-W108F001Y ) ]  
PF38F5070M0Y0CE@FBGA107 [ ( SA664F-B148A-W108F001N ) ]  
PF38F5080M0Y0B0@FBGA105 [ ( SA664F-B298A-W108F001Y ) ]  
PF48F2000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
PF48F2000P0XTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
PF48F2000P0ZBQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
PF48F2000P0ZTQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
PF48F3000L0YBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF48F3000L0YTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF48F3000L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF48F3000L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF48F3000M0Y0QE@FBGA88 [ ( SA642R-B300A-T096F001Y ) ]  
PF48F3000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
PF48F3000P0XTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
PF48F3000P0ZBQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
PF48F3000P0ZTQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
PF48F3000W0YBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF48F3000W0YTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]

PF48F3000W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF48F3000W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF48F3300W0YBQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
PF48F3300W0YDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
PF48F3300W0YTQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
PF48F4000L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF48F4000L0YTB0@FBGA103 [(SA664F-B157A-W108F001Y)]  
PF48F4000L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF48F4000M0Y0CE@FBGA107 [(SA664F-B148A-W108F001N)]  
PF48F4000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F4000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F4000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F4000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F4040LVYBQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F4040LVYBQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F4040LVYTQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F4040LVYTQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F4400P0TBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F4400P0VBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F4400P0VTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F5000M0Y0BE@FBGA105 [(SA664F-B298A-W108F001Y)]  
PF48F5000M0Y0C0@FBGA107 [(SA664F-B148A-W108F001N)]  
PF48F5000M0Y1B0@FBGA105 [(SA664F-B301A-W108F001N)]  
PH28F128W18BC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18BC@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18BD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F128W18BD@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F128W18TC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18TC@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F128W18TD@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F160B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
PH28F160B3TD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
PH28F160C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F160C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F160C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F160C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
PH28F320B3TD@uBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F320C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F320C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]

PH28F320W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F320W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F320W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F320W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F640W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F640W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F640W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F640W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
QB25F016S33B60@SOIC8 [(SA605A)] QB25F016S33T60@SOIC8  
[(SA605A)]  
QB25F160S33B60@SOIC16 [(SA404)] QB25F160S33T60@SOIC16  
[(SA404)]  
QB25F320S33B60@SOIC16 [(SA404)] QB25F320S33T60@SOIC16  
[(SA404)]  
QB25F640S33B60@SOIC16 [(SA404)] QB25F640S33T60@SOIC16  
[(SA404)]  
QH25F016S33B60@SOIC8 [(SA605A)] QH25F016S33T60@SOIC8  
[(SA605A)]  
QH25F160S33B60@SOIC16 [(SA404)] QH25F160S33T60@SOIC16  
[(SA404)]  
QH25F320S33B60@SOIC16 [(SA404)] QH25F320S33T60@SOIC16  
[(SA404)]  
QH25F640S33B60@SOIC16 [(SA404)] QH25F640S33T60@SOIC16  
[(SA404)]  
RC28F128J3A@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F128J3C@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F128J3D@FBGA64 [(SA655A-B054A-T064F001Y)]  
RC28F128K18C@FBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F128K3C@FBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F128P30B@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F128P30T@EBGA64 [(SA655G-B122A-T064F001Y)]  
RC28F128P33B@EBGA64 [(SA655K-B122A-T064F001Y)]  
RC28F128P33T@EBGA64 [(SA655K-B122A-T064F001Y)]  
RC28F160C3BA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F160C3BC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F160C3BD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F160C3TA@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F160C3TC@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F160C3TD@FBGA64 [(SA655J-B037A-T064F001Y)]  
RC28F256J3A@FBGA96 [(SA642A-B273-Y096N001N)]  
RC28F256J3C@FBGA64 [(SA655M-B054A-T064F001Y)]  
RC28F256K18C@FBGA64 [(SA655L-B286A-T064F001Y)]  
RC28F256K3C@FBGA64 [(SA655L-B286A-T064F001Y)]

RC28F256P30B@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F256P30T@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F256P33B@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F256P33T@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F320C3BA@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320C3BC@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320C3BD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320C3TA@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320C3TC@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320C3TD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320J3A@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
RC28F320J3C@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
RC28F320J3D@FBGA64 [ ( SA655A-B054A-T064F001Y ) ]  
RC28F640C3BC@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F640C3TC@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F640J3A@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
RC28F640J3C@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
RC28F640J3D@FBGA64 [ ( SA655A-B054A-T064F001Y ) ]  
RC28F640K18C@FBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F640K3C@FBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F640P30B@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F640P30T@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F640P33B@EBGA64 [ ( SA655K-B122A-T064F001Y ) ]  
RC28F640P33T@EBGA64 [ ( SA655K-B122A-T064F001Y ) ]  
RC28F800C3BA@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F800C3BD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F800C3TA@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F800C3TD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC48F3300J0Z00S@FBGA64 [ ( SA655A-B054A-T064F001Y ) ]  
RC48F4400P0TB00@FBGA64 [ ( SA655G-B163A-T064F001Y ) ]  
RC48F4400P0VB00@FBGA64 [ ( SA655G-B163A-T064F001Y ) ]  
RC48F4400P0VT00@FBGA64 [ ( SA655G-B163A-T064F001Y ) ]  
RD28F1602C3B@FBGA72 [ ( SA642E-B041A-T072F001 ) ]  
RD28F1602C3T@FBGA72 [ ( SA642E-B041A-T072F001 ) ]  
RD28F1604C3B@FBGA72 [ ( SA642E-B041A-T072F001 ) ]  
RD28F1604C3T@FBGA72 [ ( SA642E-B041A-T072F001 ) ]  
RD28F3204C3B@FBGA72 [ ( SA642E-B041A-T072F001 ) ]  
RD28F3204C3T@FBGA72 [ ( SA642E-B041A-T072F001 ) ]  
RD28F3204W18B(NO EFP)@FBGA96 [ ( SA642L-B082A-W080F001Y ) ]  
RD28F3204W18B@FBGA96 [ ( SA642L-B082A-W080F001Y ) ]  
RD28F3204W18T(NO EFP)@FBGA96 [ ( SA642L-B082A-W080F001Y ) ]  
RD28F3204W18T@FBGA96 [ ( SA642L-B082A-W080F001Y ) ]  
RD28F3204W30B(NO EFP)@FBGA96 [ ( SA642L-B082A-W080F001Y ) ]

RD28F3204W30B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3208C3B@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F3208C3T@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F6408W18B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W18B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W18T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W18T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD38F1010C0ZB@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1010C0ZT@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1010W0YTL0@FBGA67 [(SA642E-B041A-T072F001N)]  
RD38F1020C0ZB@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1020C0ZT@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1020W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2010W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2010W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2010W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2010W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2020W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2020W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2020W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2020W0ZBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2020W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2020W0ZTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YBQE@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YBQF@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]

RD38F2030W0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YTQE@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YTQF@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0ZBQ0(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZBQ1(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0ZTQ0(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZTQ1(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2040W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2040W0YBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2040W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2040W0YTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2040W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2040W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2220WWYBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2220WWYDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2220WWYTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2220WWZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2220WWZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2220WWZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2230WWYBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2230WWYDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2230WWYTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2230WWZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2230WWZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2230WWZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWYBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWYDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWYTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWZDQ1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
RD38F2240WWZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F3040L0YBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3040L0YBQ1@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3040L0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F3040L0YCQ0@FBGA88 [(SA642R-B180A-T096F001Y)]  
RD38F3040L0YTQ0@FBGA88 [(SA642I-B112A-W080F001)]



RD38F3040L0YTQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3040L0YTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F3040L0YUQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
RD38F3040L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3040L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0YBQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0YBQ2@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0YCQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
RD38F3050L0YTQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0YTQ2@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0YUQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
RD38F3050L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F3050L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F3340LLYDQ1@FBGA88 [ ( SA642A-B091A-Y096F001 ) ]  
RD38F3350LLZDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD38F3350W0ZDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD38F3350WWZDQ1@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD38F4050L0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YBQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YCQ0@FBGA88 [ ( SA642A-B180A-Y096F001Y ) ]  
RD38F4050L0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YTQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YUQ0@FBGA88 [ ( SA642A-B180A-Y096F001Y ) ]  
RD38F4050L0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4055L0YBQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4055L0YTQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4055L0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4055L0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4070V0YBPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
RD38F4350LLYBQ1@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4350LLYTQ1@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4450LVYBQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4450LVYBQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4450LVYTQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4450LVYTQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4455LLYBQ0@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]

RD38F4455LLYBQ1@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
RD38F4455LLYBQ2@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
RD38F4455LLYTQ0@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
RD38F4455LLYTQ1@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
RD38F4455LLYTQ2@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
RD38F4460LVYBB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
RD38F4460LVYGB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
RD38F4460LVYTB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
RD38F4470LLYBH0@FBGA137 [ ( SA678B-B159A-P137F001Y ) ]  
RD38F4470LLYFH0@FBGA137 [ ( SA678B-B159A-P137F001Y ) ]  
RD38F4470LLYGH0@FBGA137 [ ( SA678B-B159A-P137F001Y ) ]  
RD38F4470LLYTH0@FBGA137 [ ( SA678B-B159A-P137F001Y ) ]  
RD38F4470VVUBPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
RD38F4470VVUTPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
RD38F4476VVUBPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
RD38F4476VVUTPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
RD48F2000L0YBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F2000L0YTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F2000L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F2000L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F2000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F2000P0XTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F2000P0ZBQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F2000P0ZTQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F2000W0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F2000W0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F2000W0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F2000W0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F2100W0YBQ0@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]  
RD48F2100W0YDQE@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]  
RD48F2100W0YTQ0@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]  
RD48F2200W0YBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0YDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0YTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0ZBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0ZDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0ZTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F3000L0YBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F3000L0YTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F3000L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F3000L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F3000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F3000P0XTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]

RD48F3000P0ZBQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F3000P0ZTQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F3000W0YBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD48F3000W0YTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD48F3000W0ZBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD48F3000W0ZTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD48F3300W0YBQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD48F3300W0YDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD48F3300W0YTQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD48F4000L0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F4000L0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F4000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F4000P0XTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F4000P0ZBQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F4000P0ZTQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F4040LVYBQ0 (BEEP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVYBQ0 (BP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVYTQ0 (BEEP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVYTQ0 (BP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVZBQ0 (BEEP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVZBQ0 (BP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVZTQ0 (BEEP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVZTQ0 (BP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4400P0TBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F4400P0VBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F4400P0VTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
TB28F004S3@PSOP44 [ ( SA638 ) ] TB28F004S5@PSOP44  
[ ( SA638 ) ]  
TB28F004SC@PSOP44 [ ( SA638 ) ] TB28F008S3@PSOP44  
[ ( SA638 ) ]  
TB28F008S5@PSOP44 [ ( SA638 ) ] TB28F008SA@PSOP44  
[ ( SA638 ) ]  
TB28F008SA-L@PSOP44 [ ( SA638 ) ] TB28F008SC@PSOP44  
[ ( SA638 ) ]  
TB28F016S3@PSOP44 [ ( SA638 ) ] TB28F016S5@PSOP44  
[ ( SA638 ) ]  
TB28F016SC@PSOP44 [ ( SA638 ) ] TB28F200B5B@PSOP44  
[ ( SA638 ) ]  
TB28F200B5T@PSOP44 [ ( SA638 ) ] TB28F200BVB@PSOP44  
[ ( SA638 ) ]  
TB28F200BVT@PSOP44 [ ( SA638 ) ] TB28F200BXB@PSOP44  
[ ( SA638 ) ]  
TB28F200BXT@PSOP44 [ ( SA638 ) ] TB28F400B5B@PSOP44

[ ( SA638 ) ]		
TB28F400B5T@PSOP44 [ ( SA638 ) ]		TB28F400BVB@PSOP44
[ ( SA638 ) ]		
TB28F400BVT@PSOP44 [ ( SA638 ) ]		TB28F400BXB@PSOP44
[ ( SA638 ) ]		
TB28F400BXT@PSOP44 [ ( SA638 ) ]		TB28F800B5B@PSOP44
[ ( SA638 ) ]		
TB28F800B5T@PSOP44 [ ( SA638 ) ]		TB28F800BVB@PSOP44
[ ( SA638 ) ]		
TB28F800BVT@PSOP44 [ ( SA638 ) ]		TE28F002BEB@TSOP40
[ ( SA409T ) ]		
TE28F002BET@TSOP40 [ ( SA409T ) ]		TE28F002BVB@TSOP40
[ ( SA409T ) ]		
TE28F002BVT@TSOP40 [ ( SA409T ) ]		TE28F002BXB@TSOP40
[ ( SA409T ) ]		
TE28F002BXT@TSOP40 [ ( SA409T ) ]		TE28F004BEB@TSOP40
[ ( SA409T ) ]		
TE28F004BET@TSOP40 [ ( SA409T ) ]		TE28F004BVB@TSOP40
[ ( SA409T ) ]		
TE28F004BVT@TSOP40 [ ( SA409T ) ]		TE28F004BXB@TSOP40
[ ( SA409T ) ]		
TE28F004BXT@TSOP40 [ ( SA409T ) ]		TE28F004S3@TSOP40
[ ( SA409T ) ]		
TE28F004S5@TSOP40 [ ( SA409T ) ]		TE28F004SC@TSOP40
[ ( SA409T ) ]		
TE28F008B3B@TSOP40 [ ( SA409T ) ]		TE28F008B3BA@TSOP40
[ ( SA409T ) ]		
TE28F008B3T@TSOP40 [ ( SA409T ) ]		TE28F008B3TA@TSOP40
[ ( SA409T ) ]		
TE28F008BEB@TSOP40 [ ( SA409T ) ]		TE28F008BET@TSOP40
[ ( SA409T ) ]		
TE28F008BVB@TSOP40 [ ( SA409T ) ]		TE28F008BVT@TSOP40
[ ( SA409T ) ]		
TE28F008C3BA@TSOP40 [ ( SA409T ) ]		TE28F008C3TA@TSOP40
[ ( SA409T ) ]		
TE28F008S3@TSOP40 [ ( SA409T ) ]		TE28F008S5@TSOP40
[ ( SA409T ) ]		
TE28F008SA@TSOP40 [ ( SA409T ) ]		TE28F008SA-L@TSOP40
[ ( SA409T ) ]		
TE28F008SC@TSOP40 [ ( SA409T ) ]		TE28F016B3B@TSOP40
[ ( SA409T ) ]		
TE28F016B3T@TSOP40 [ ( SA409T ) ]		TE28F016C3BA@TSOP40
[ ( SA409T ) ]		

TE28F016C3TA@TSOP40 [ (SA409T) ]                   TE28F016S3@TSOP40  
[ (SA409T) ]  
TE28F016S5@TSOP40 [ (SA409T) ]                   TE28F016SC@TSOP40  
[ (SA409T) ]  
TE28F128J3C@TSOP56 [ (SA628-B018) ]  
TE28F128J3D@TSOP56 [ (SA628-B018) ]  
TE28F128P30B@TSOP56 [ (SA628-B131) ]  
TE28F128P30T@TSOP56 [ (SA628-B131) ]  
TE28F128P33B@TSOP56 [ (SA628-B131) ]  
TE28F128P33T@TSOP56 [ (SA628-B131) ]  
TE28F160B3B@TSOP48 [ (SA247-B005) ]  
TE28F160B3BA@TSOP48 [ (SA247-B005) ]  
TE28F160B3BC@TSOP48 [ (SA247-B005) ]  
TE28F160B3BD@TSOP48 [ (SA247-B005) ]  
TE28F160B3T@TSOP48 [ (SA247-B005) ]  
TE28F160B3TA@TSOP48 [ (SA247-B005) ]  
TE28F160B3TC@TSOP48 [ (SA247-B005) ]  
TE28F160B3TD@TSOP48 [ (SA247-B005) ]  
TE28F160C3BA@TSOP48 [ (SA247-B005) ]  
TE28F160C3BC@TSOP48 [ (SA247-B005) ]  
TE28F160C3BD@TSOP48 [ (SA247-B005) ]  
TE28F160C3TA@TSOP48 [ (SA247-B005) ]  
TE28F160C3TC@TSOP48 [ (SA247-B005) ]  
TE28F160C3TD@TSOP48 [ (SA247-B005) ]  
TE28F160F3B@TSOP56 [ (SA628-B014) ]  
TE28F160F3T@TSOP56 [ (SA628-B014) ]  
TE28F160S3@TSOP56 [ (SA628-B011) ]               TE28F160S5@TSOP56 [ (SA628-  
B011) ]  
TE28F200B5B@TSOP48 [ (SA247-B005) ]  
TE28F200B5T@TSOP48 [ (SA247-B005) ]  
TE28F200BVB@TSOP56 [ (SA628-B012) ]  
TE28F200BVT@TSOP56 [ (SA628-B012) ]  
TE28F200BXB@TSOP56 [ (SA628-B012) ]  
TE28F200BXT@TSOP56 [ (SA628-B012) ]  
TE28F200CEB@TSOP56 [ (SA628-B012) ]  
TE28F200CET@TSOP56 [ (SA628-B012) ]  
TE28F200CVB@TSOP48 [ (SA247-B005) ]  
TE28F200CVT@TSOP48 [ (SA247-B005) ]  
TE28F256J3C@TSOP56 [ (SA628-B018) ]  
TE28F256P30B@TSOP56 [ (SA628-B131) ]  
TE28F256P30T@TSOP56 [ (SA628-B131) ]  
TE28F256P33B@TSOP56 [ (SA628-B131) ]  
TE28F256P33T@TSOP56 [ (SA628-B131) ]

TE28F320B3B@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3BA@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3BC@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3BD@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3T@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3TA@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3TC@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3TD@TSOP48 [ ( SA247-B005 ) ]  
TE28F320C3BA@TSOP48 [ ( SA247-B005 ) ]  
TE28F320C3BC@TSOP48 [ ( SA247-B005 ) ]  
TE28F320C3BD@TSOP48 [ ( SA247-B005 ) ]  
TE28F320C3TA@TSOP48 [ ( SA247-B005 ) ]  
TE28F320C3TC@TSOP48 [ ( SA247-B005 ) ]  
TE28F320C3TD@TSOP48 [ ( SA247-B005 ) ]  
TE28F320J3C@TSOP56 [ ( SA628-B018 ) ]  
TE28F320J3D@TSOP56 [ ( SA628-B018 ) ]  
TE28F400B3B@TSOP48 [ ( SA247-B005 ) ]  
TE28F400B3T@TSOP48 [ ( SA247-B005 ) ]  
TE28F400B5B@TSOP48 [ ( SA247-B005 ) ]  
TE28F400B5T@TSOP48 [ ( SA247-B005 ) ]  
TE28F400BVB@TSOP56 [ ( SA628-B012 ) ]  
TE28F400BVT@TSOP56 [ ( SA628-B012 ) ]  
TE28F400BXB@TSOP56 [ ( SA628-B012 ) ]  
TE28F400BXT@TSOP56 [ ( SA628-B012 ) ]  
TE28F400CEB@TSOP48 [ ( SA247-B005 ) ]  
TE28F400CET@TSOP48 [ ( SA247-B005 ) ]  
TE28F400CVB@TSOP48 [ ( SA247-B005 ) ]  
TE28F400CVT@TSOP48 [ ( SA247-B005 ) ]  
TE28F640B3BC@TSOP48 [ ( SA247-B005 ) ]  
TE28F640B3TC@TSOP48 [ ( SA247-B005 ) ]  
TE28F640C3BC@TSOP48 [ ( SA247-B005 ) ]  
TE28F640C3TC@TSOP48 [ ( SA247-B005 ) ]  
TE28F640J3C@TSOP56 [ ( SA628-B018 ) ]  
TE28F640J3D@TSOP56 [ ( SA628-B018 ) ]  
TE28F640P30B@TSOP56 [ ( SA628-B131 ) ]  
TE28F640P30T@TSOP56 [ ( SA628-B131 ) ]  
TE28F640P33B@TSOP56 [ ( SA628-B131 ) ]  
TE28F640P33T@TSOP56 [ ( SA628-B131 ) ]  
TE28F800B3B@TSOP48 [ ( SA247-B005 ) ]  
TE28F800B3BA@TSOP48 [ ( SA247-B005 ) ]  
TE28F800B3T@TSOP48 [ ( SA247-B005 ) ]  
TE28F800B3TA@TSOP48 [ ( SA247-B005 ) ]  
TE28F800B5B@TSOP48 [ ( SA247-B005 ) ]

TE28F800B5T@TSOP48 [(SA247-B005)]  
TE28F800C3BA@TSOP48 [(SA247-B005)]  
TE28F800C3BD@TSOP48 [(SA247-B005)]  
TE28F800C3TA@TSOP48 [(SA247-B005)]  
TE28F800C3TD@TSOP48 [(SA247-B005)]  
TE28F800CEB@TSOP48 [(SA247-B005)]  
TE28F800CET@TSOP48 [(SA247-B005)]  
TE28F800CVB@TSOP48 [(SA247-B005)]  
TE28F800CVT@TSOP48 [(SA247-B005)]  
TE28F800F3B@TSOP56 [(SA628-B014)]  
TE28F800F3T@TSOP56 [(SA628-B014)]  
TE48F4400P0TB00@TSOP56 [(SA628-B164)]  
TE48F4400P0VB00@TSOP56 [(SA628-B164)]  
TE48F4400P0VT00@TSOP56 [(SA628-B164)]

## PLD

5C031 [(SA001A)]	5C031@PLCC20
5C032 [(SA001A)]	5C032@PLCC20
5C090 [(SA244)]	5C090@PLCC44
5C180@PLCC68 [(PEP+S414T)]	
85C090 85C090-P44 [(SA244)]	
85C220 85C220@PLCC20 [(SA001A)]	
IPLD910 IPLD910-P44 [(SA244)]	

## MICROCONTROLLER

8741 8741AH 8741AH@PLCC44 [(SA244)] [(SA245A)]	8741AH@TQFP44
8742 8742AH 8742AH@PLCC44 [(SA244)] [(SA245A)]	8742AH@TQFP44

8744	
8744H	
8748	8748
(25V)	
8748H	
8749	
8749H	
8751	
8751BH	8751BH@PLCC44
[(SA244)]	
8751H	8751H-
8	
8752BH	8752BH@PLCC44
[(SA244)]	
8796BH@PLCC68 [(PEP+S414T)]	8796BH@PLCC68(*) [(SA648-
B6803)]	
8796JF@PLCC68 [(PEP+S414T)]	8796JF@PLCC68(*) [(SA648-
B6803)]	
8797BH@PGA68 [(PEP+S612)]	8797BH@PGA68(*) [(SA650-
B6804)]	
8797BH@PLCC68 [(PEP+S414T)]	8797BH@PLCC68(*) [(SA648-
B6803)]	
8797JF@PGA68 [(PEP+S612)]	8797JF@PGA68(*) [(SA650-
B6804)]	
8797JF@PLCC68 [(PEP+S414T)]	8797JF@PLCC68(*) [(SA648-
B6803)]	
8798	
87C151SA	
87C151SA@PLCC44 [(SA244)]	
87C151SB	
87C151SB@PLCC44 [(SA244)]	87C194@PLCC52 [(PEP
+S415T)]	
87C196CA@PLCC68 [(PEP+S414T)]	
87C196CA@PLCC68(*) [(SA648-B6805)]	
87C196JQ@PLCC52 [(PEP+S415T)]	
87C196JQ@PLCC52(*) [(SA647-B5201)]	
87C196JR@PLCC52 [(PEP+S415T)]	
87C196JR@PLCC52(*) [(SA647-B5201)]	
87C196JT@PLCC52 [(PEP+S415T)]	
87C196JT@PLCC52(*) [(SA647-B5201)]	
87C196JV@PLCC52 [(PEP+S415T)]	
87C196JV@PLCC52(*) [(SA647-B5201)]	
87C196KB@PGA68(*) [(S667+B309)]	87C196KB@PLCC68 [(PEP



+S414T) ]  
 87C196KB@PLCC68(\*) [(SA648-B6801)]  
 87C196KC@PGA68(\*) [(S667+B309)] 87C196KC@PLCC68 [(PEP  
 +S414T) ]  
 87C196KC@PLCC68(\*) [(SA648-B6801)]  
 87C196KD@PGA68(\*) [(S667+B309)] 87C196KD@PLCC68 [(PEP  
 +S414T) ]  
 87C196KD@PLCC68(\*) [(SA648-B6801)]  
 87C196KQ@PLCC68 [(PEP+S414T) ]  
 87C196KQ@PLCC68(\*) [(SA648-B6802) ]  
 87C196KR@PLCC68 [(PEP+S414T) ]  
 87C196KR@PLCC68(\*) [(SA648-B6802) ]  
 87C196KS@PLCC68 [(PEP+S414T) ]  
 87C196KS@PLCC68(\*) [(SA648-B6802) ]  
 87C196KT@PLCC68 [(PEP+S414T) ]  
 87C196KT@PLCC68(\*) [(SA648-B6802) ]  
 87C196LA@PLCC52 [(PEP+S415T) ]  
 87C196LA@PLCC52(\*) [(SA647-B5201) ]  
 87C196MC@PLCC84 [(PEP+S416T) ]  
 87C196MC@PLCC84(\*) [(SA649-B8401) ]  
 87C196MC@PQFP80 [(PEP+S611A) ]  
 87C196MC@PQFP80(\*) [(TA026-B006) ]  
 87C196MC@SDIP64 [(PEP+S600A) ] 87C196MC@SDIP64(\*)  
 [(SA651) ]  
 87C196MH@PLCC84 [(PEP+S416T) ]  
 87C196MH@PLCC84(\*) [(SA649-B8401) ]  
 87C196MH@PQFP80 [(PEP+S611A) ]  
 87C196MH@PQFP80(\*) [(TA026-B006) ]  
 87C196MH@SDIP64 [(PEP+S600A) ] 87C196MH@SDIP64(\*)  
 [(SA651) ]  
 87C198@PLCC52 [(PEP+S415T) ]  
 87C251SA  
 87C251SA@PLCC44 [(SA244) ]  
 87C251SB  
 87C251SB@PLCC44 [(SA244) ]  
 87C251SP  
 87C251SP@PLCC44 [(SA244) ]  
 87C251SQ  
 87C251SQ@PLCC44 [(SA244) ]  
 87C42  
 87C42@PLCC44 [(SA244) ] 87C42@TQFP44  
 [(SA245A) ]  
 87C51 87C51@PLCC44

[ (SA244) ]	
87C51@TQFP44 [ (SA245A) ]	
87C51FA	
87C51FA@PLCC44 [ (SA244) ]	87C51FA@TQFP44
[ (SA245A) ]	
87C51FB	
[ (SA244) ]	
87C51FB@TQFP44 [ (SA245A) ]	87C51FB@PLCC44
87C51FC	
87C51FC@PLCC44 [ (SA244) ]	87C51FC@TQFP44
[ (SA245A) ]	
87C51GB@PLCC68 [ (PEP+S414T) ]	
87C51RA	
87C51RA@PLCC44 [ (SA244) ]	87C51RA@TQFP44
[ (SA245A) ]	
87C51RB	
[ (SA244) ]	
87C51RB@TQFP44 [ (SA245A) ]	87C51RB@PLCC44
87C51RC	
87C51RC@PLCC44 [ (SA244) ]	87C51RC@TQFP44
[ (SA245A) ]	
87C52	
[ (SA244) ]	
87C52@TQFP44 [ (SA245A) ]	87C52@PLCC44
87C54	
87C54@PLCC44 [ (SA244) ]	87C54@TQFP44
[ (SA245A) ]	
87C58	
[ (SA244) ]	
87C58@TQFP44 [ (SA245A) ]	87C58@PLCC44
87L42	
87L42@PLCC44 [ (SA244) ]	87L42@TQFP44
[ (SA245A) ]	
87L51FA@PLCC44 [ (SA244) ]	87L51FA@TQFP44
[ (SA245A) ]	
87L51FB@PLCC44 [ (SA244) ]	87L51FB@TQFP44
[ (SA245A) ]	
87L51FC@PLCC44 [ (SA244) ]	87L51FC@TQFP44
[ (SA245A) ]	
87L52@PLCC44 [ (SA244) ]	87L52@TQFP44
[ (SA245A) ]	
87L54@PLCC44 [ (SA244) ]	87L54@TQFP44
[ (SA245A) ]	

87L58@PLCC44 [ (SA244) ]  
[ (SA245A) ]

87L58@TQFP44

## INTEL-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

87J01H(YCL)@FBGA129 [ (SA678A-B151A-Y129F001Y) ]  
87J01L(YCL)@FBGA129 [ (SA678A-B150A-Y129F001Y) ]  
TE28F800C3TD@TSOP48 [ (SA247-B005) ]

## INTELSIL

### E ( E ) PROM / FRAM / NVRAM

HS-6617RH [ (SA404) ]	HS-6617RH@SOIC24
HS-6617RH-T [ (SA404) ]	HS-6617RH-T@SOIC24
HS-6883RH [ (SA404) ]	HS-6883RH@SOIC24
HS-6883RH-T [ (SA404) ]	HS-6883RH-T@SOIC24

## ISSI

### E ( E ) PROM / FRAM / NVRAM

IS24C01 [ (SA666) ]	IS24C01@MSOP8
IS24C01@SOIC8 [ (SA602A) ] [ (SA026) ]	IS24C01@TSSOP8
IS24C01B [ (SA666) ]	IS24C01B@MSOP8
IS24C01B@SOIC8 [ (SA602A) ] [ (SA026) ]	IS24C01B@TSSOP8
IS24C02 [ (SA666) ]	IS24C02@MSOP8
IS24C02@SOIC8 [ (SA602A) ]	IS24C02@TSSOP8

[ (SA026) ]	
IS24C02A	
IS24C02A@DFN8	
IS24C02A@MSOP8 [ (SA666) ]	IS24C02A@SOIC8
[ (SA602A) ]	
IS24C02A@TSSOP8 [ (SA026) ]	
IS24C02B	
IS24C02B@DFN8	IS24C02B@MSOP8
[ (SA666) ]	
IS24C02B@SOIC8 [ (SA602A) ]	IS24C02B@TSSOP8
[ (SA026) ]	
IS24C04	IS24C04@MSOP8
[ (SA666) ]	
IS24C04@SOIC8 [ (SA602A) ]	IS24C04@TSSOP8
[ (SA026) ]	
IS24C04A	
IS24C04A@DFN8	
IS24C04A@MSOP8 [ (SA666) ]	IS24C04A@SOIC8
[ (SA602A) ]	
IS24C04A@TSSOP8 [ (SA026) ]	
IS24C08	
IS24C08@MSOP8 [ (SA666) ]	IS24C08@SOIC8
[ (SA602A) ]	
IS24C08@TSSOP8 [ (SA026) ]	
IS24C08A	
IS24C08A@DFN8	IS24C08A@MSOP8
[ (SA666) ]	
IS24C08A@SOIC8 [ (SA602A) ]	IS24C08A@TSSOP8
[ (SA026) ]	
IS24C128	IS24C128@SOIC8
[ (SA602A) ]	
IS24C128@TSSOP14 [ (SA026) ]	
IS24C16	
IS24C16@MSOP8 [ (SA666) ]	IS24C16@SOIC8
[ (SA602A) ]	
IS24C16@TSSOP8 [ (SA026) ]	
IS24C16A	
IS24C16A@MSOP8 [ (SA666) ]	IS24C16A@SOIC8
[ (SA602A) ]	
IS24C16A@TSSOP8 [ (SA026) ]	
IS24C256	
IS24C256@SOIC8 [ (SA602A) ]	IS24C256@TSSOP14
[ (SA026) ]	

IS24C256A	IS24C256A@SOIC8
[(SA602A)]	
IS24C256A@TSSOP14 [(SA026)]	
IS24C32	
IS24C32@SOIC8 [(SA602A)]	IS24C32@TSSOP8
[(SA026)]	
IS24C32A	IS24C32A@MSOP8
[(SA666)]	
IS24C32A@SOIC8 [(SA602A)]	IS24C32A@TSSOP8
[(SA026)]	
IS24C32B	IS24C32B@SOIC8
[(SA602A)]	
IS24C32B@TSSOP8 [(SA026)]	
IS24C64	
IS24C64@SOIC8 [(SA602A)]	IS24C64@TSSOP8
[(SA026)]	
IS24C64A	IS24C64A@MSOP8
[(SA666)]	
IS24C64A@SOIC8 [(SA602A)]	IS24C64A@TSSOP8
[(SA026)]	
IS24C64B	IS24C64B@SOIC8
[(SA602A)]	
IS24C64B@TSSOP8 [(SA026)]	
IS24L128	
IS24L128@SOIC8(150mil) [(SA602A)]	
IS24L128@SOIC8(200mil) [(SA605A)]	
IS24L256	
IS24L256@SOIC8(150mil) [(SA602A)]	
IS24L256@SOIC8(200mil) [(SA605A)]	
IS25C01	IS25C01@SOIC8
[(SA602A)]	
IS25C01@TSSOP8 [(SA026)]	
IS25C02	
IS25C02@SOIC8 [(SA602A)]	IS25C02@TSSOP8
[(SA026)]	
IS25C04	IS25C04@SOIC8
[(SA602A)]	
IS25C04@TSSOP8 [(SA026)]	
IS25C08	
IS25C08@SOIC8 [(SA602A)]	IS25C08@TSSOP8
[(SA026)]	
IS25C128@SOIC8 [(SA602A)]	IS25C128@TSSOP8
[(SA026)]	

IS25C16	IS25C16@SOIC8
[ (SA602A) ]	
IS25C16@TSSOP8 [ (SA026) ]	IS25C256@SOIC8
[ (SA602A) ]	
IS25C256@TSSOP8 [ (SA026) ]	
IS25C32A	
IS25C32A@SOIC8 [ (SA602A) ]	IS25C32A@TSSOP8
[ (SA026) ]	
IS25C64A	IS25C64A@SOIC8
[ (SA602A) ]	
IS25C64A@TSSOP8 [ (SA026) ]	
IS27C010	
IS27C010@PLCC32 [ (SA015A1T) ]	IS27C010@TSOP32
[ (SA410T) ]	
IS27C020	IS27C020@PLCC32
[ (SA015A1T) ]	
IS27C020@TSOP32 [ (SA410T) ]	
IS27C256	
IS27C256@PLCC32 [ (SA015A1T) ]	
IS27C512	
IS27C512@PLCC32 [ (SA015A1T) ]	IS27C512@TSOP28
[ (SA430T) ]	
IS27HC010	IS27HC010@PLCC32
[ (SA015A1T) ]	
IS27HC010@TSOP32 [ (SA410T) ]	
IS27HC020	
IS27HC020@PLCC32 [ (SA015A1T) ]	IS27HC020@TSOP32
[ (SA410T) ]	
IS27HC256	IS27HC256@PLCC32
[ (SA015A1T) ]	
IS27HC512	IS27HC512@PLCC32
[ (SA015A1T) ]	
IS27HC512@TSOP28 [ (SA430T) ]	
IS27LV010	
IS27LV010@PLCC32 [ (SA015A1T) ]	IS27LV010@TSOP32
[ (SA410T) ]	
IS27LV512	IS27LV512@PLCC32
[ (SA015A1T) ]	
IS27LV512@TSOP28 [ (SA430T) ]	
IS28F010	
IS28F010@PLCC32 [ (SA015A1T) ]	IS28F010@TSOP32
[ (SA410T) ]	
IS28F010A	IS28F010A@PLCC32

[ (SA015A1T) ]  
IS28F010A@TSOP32 [ (SA410T) ]  
IS28F020  
IS28F020@PLCC32 [ (SA015A1T) ] IS28F020@TSOP32  
[ (SA410T) ]  
IS29F010 IS29F010@PLCC32  
[ (SA015A1T) ]  
IS29F010@TSOP32 [ (SA410T) ]  
IS34C02  
IS34C02@MSOP8 [ (SA666) ] IS34C02@SOIC8  
[ (SA602A) ]  
IS34C02@TSSOP8 [ (SA026) ]  
IS34C02B@DFN8  
IS34C02B@TSSOP8 [ (SA026) ]  
IS71V08F32AS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32BS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32CS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32DS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32ES08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32ESB08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32EST08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32FS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32GSB08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32GST08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F64GS08@FBGA101 [ (SA642C-B032A-Y056F001) ]  
IS71V08F64GS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32AS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32B04@FBGA56 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32B04@FBGA59 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32BS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32CS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32DS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32ES08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32ESB08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32EST08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32FS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32GSB08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32GST08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32T04@FBGA56 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32T04@FBGA59 [ (SA642A-B032A-Y096F001) ]  
IS71V16F64GS08@FBGA101 [ (SA642C-B032A-Y056F001) ]  
IS71V16F64GS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71VPCF32AS04@FBGA73 [ (SA642A-B032A-Y096F001) ]

IS71VPCF32BS04@FBGA73	[(SA642A-B032A-Y096F001)]
IS71VPCF32CS04@FBGA73	[(SA642A-B032A-Y096F001)]
IS71VPCF32DS04@FBGA73	[(SA642A-B032A-Y096F001)]
IS71VPCF32ES04@FBGA73	[(SA642A-B032A-Y096F001)]
IS71VPCF32FS04@FBGA73	[(SA642A-B032A-Y096F001)]
IS71VPCF64GS08@FBGA73	[(SA642C-B032A-Y056F001)]
IS75V16F64GS16@FBGA65	[(SA642C-B032A-Y056F001)]
IS75V16F64GS32@FBGA65	[(SA642C-B032A-Y056F001)]
IS93C46	IS93C46@SOIC8
[(SA602A)]	
IS93C46A(08bit)	IS93C46A(08bit)@SOIC8
[(SA602A)]	
IS93C46A(08bit)@TSSOP8	[(SA026)]
(16bit)	IS93C46A
IS93C46A(16bit)@SOIC8	[(SA602A)]
[(SA026)]	IS93C46A(16bit)@TSSOP8
IS93C46B	IS93C46B@SOIC8
[(SA602A)]	
IS93C46B@TSSOP8	[(SA026)]
(08bit)	IS93C46D
IS93C46D(08bit)@SOIC8	[(SA602A)]
[(SA026)]	IS93C46D(08bit)@TSSOP8
IS93C46D(16bit)	IS93C46D(16bit)@SOIC8
[(SA602A)]	
IS93C46D(16bit)@TSSOP8	[(SA026)]
IS93C56	
IS93C56@SOIC8	[(SA602A)]
(08bit)	IS93C56A
IS93C56A(08bit)@SOIC8	[(SA602A)]
[(SA026)]	IS93C56A(08bit)@TSSOP8
IS93C56A(16bit)	IS93C56A(16bit)@SOIC8
[(SA602A)]	
IS93C56A(16bit)@TSSOP8	[(SA026)]
IS93C66	
IS93C66@SOIC8	[(SA602A)]
(08bit)	IS93C66A
IS93C66A(08bit)@SOIC8	[(SA602A)]
[(SA026)]	IS93C66A(08bit)@TSSOP8
IS93C66A(16bit)	IS93C66A(16bit)@SOIC8
[(SA602A)]	
IS93C66A(16bit)@TSSOP8	[(SA026)]
(08bit)	IS93C76A
IS93C76A(08bit)@SOIC8	[(SA602A)]
	IS93C76A(08bit)@TSSOP8



[(SA026)]	
IS93C76A(16bit)	IS93C76A(16bit)@SOIC8
[(SA602A)]	
IS93C76A(16bit)@TSSOP8 [(SA026)]	IS93C86A
(08bit)	
IS93C86A(08bit)@SOIC8 [(SA602A)]	IS93C86A(08bit)@TSSOP8
[(SA026)]	
IS93C86A(16bit)	IS93C86A(16bit)@SOIC8
[(SA602A)]	
IS93C86A(16bit)@TSSOP8 [(SA026)]	

## DRAM & SRAM

IS61C1024	IS61C1024(300m)@SOJ32
[(SA646)]	
IS61C1024(400m)@SOJ32 [(SA661)]	IS61C1024@TSOP32
[(SA410T)]	
IS61C1024L	IS61C1024L(300m)@SOJ32
[(SA646)]	
IS61C1024L(400m)@SOJ32 [(SA661)]	IS61C1024L@TSOP32
[(SA410T)]	
IS61C256AH	IS61C256AH@SOJ28
[(SA646)]	
IS61C256AH@TSOP28 [(SA430T)]	
IS61C512	
IS61C512(300m)@SOJ32 [(SA646)]	IS61C512(400m)@SOJ32
[(SA661)]	
IS61C512@TSOP32 [(SA410T)]	
IS61C64AH	
IS61C64AH@SOJ28 [(SA646)]	IS61C64AH@TSOP28
[(SA430T)]	
IS61LV256	IS61LV256@SOJ28
[(SA646)]	
IS61LV256@TSOP28 [(SA430T)]	
IS61M256	
IS61M256@SOJ28 [(SA646)]	IS61M256@TSOP28
[(SA430T)]	
IS62C1024	IS62C1024(300m)@SOJ32
[(SA646)]	
IS62C1024(400m)@SOJ32 [(SA661)]	IS62C1024@TSOP32
[(SA410T)]	
IS62C256	IS62C256@SOJ28

[ (SA646) ]	
IS62C256@TSOP28 [ (SA430T) ]	
IS62C512	
IS62C512(300m)@SOJ32 [ (SA646) ]	IS62C512(400m)@SOJ32
[ (SA661) ]	
IS62C512@TSOP32 [ (SA410T) ]	
IS62C64	
IS62C64@SOJ28 [ (SA646) ]	IS62C64@TSOP28
[ (SA430T) ]	
IS62LV256	
[ (SA646) ]	
IS62LV256@TSOP28 [ (SA430T) ]	IS62LV256@SOJ28

## MICROCONTROLLER

IS89C51A	IS89C51A@PLCC44
[ (SA244) ]	
IS89C51A@TQFP44 [ (SA245A) ]	
IS89C52A	
IS89C52A@PLCC44 [ (SA244) ]	IS89C52A@TQFP44
[ (SA245A) ]	

## ITHINKO

### MICROCONTROLLER

AX5012	AX5012(5.0V)@SOP24
[ (SA404) ]	
AX5012(5.5V)@SOP24 [ (SA404) ]	AX5012(6.0V)@SOP24
[ (SA404) ]	
AX5012@SOP24 [ (SA404) ]	
AX5012@SOP32	

## LATTICE

### PLD

GAL16LV8	GAL16LV8@PLCC20
[ (SA001A) ]	

GAL16LV8C [ (SA001A) ]	GAL16LV8C@PLCC20
GAL16LV8D [ (SA001A) ]	GAL16LV8D@PLCC20
GAL16LV8Z [ (SA001A) ]	GAL16LV8Z@PLCC20
GAL16LV8ZD [ (SA001A) ]	GAL16LV8ZD@PLCC20
GAL16V8 [ (SA001A) ]	GAL16V8@PLCC20
GAL16V8@SOIC20 [ (SA404) ]	
GAL16V8A GAL16V8A@PLCC20 [ (SA001A) ] [ (SA404) ]	GAL16V8A@SOIC20
GAL16V8B [ (SA001A) ]	GAL16V8B@PLCC20
GAL16V8B@SOIC20 [ (SA404) ]	
GAL16V8C GAL16V8C@PLCC20 [ (SA001A) ] [ (SA404) ]	GAL16V8C@SOIC20
GAL16V8D [ (SA001A) ]	GAL16V8D@PLCC20
GAL16V8D@SOIC20 [ (SA404) ]	
GAL16V8Z GAL16V8Z@PLCC20 [ (SA001A) ] [ (SA404) ]	GAL16V8Z@SOIC20
GAL18V10 [ (SA001A) ]	GAL18V10@PLCC20
GAL18V10B [ (SA001A) ]	GAL18V10B@PLCC20
GAL20LV8 [ (SA008A) ]	GAL20LV8@PLCC28
GAL20LV8Z [ (SA008A) ]	GAL20LV8Z@PLCC28
GAL20LV8ZD [ (SA008A) ]	GAL20LV8ZD@PLCC28
GAL20RA10 [ (SA008A) ]	GAL20RA10@PLCC28
GAL20RA10B [ (SA008A) ]	GAL20RA10B@PLCC28
GAL20V8 [ (SA008A) ]	GAL20V8@PLCC28
GAL20V8A	GAL20V8A@PLCC28

[ (SA008A) ] GAL20V8B	GAL20V8B@PLCC28
[ (SA008A) ] GAL20V8C	GAL20V8C@PLCC28
[ (SA008A) ] GAL20V8Z	GAL20V8Z@PLCC28
[ (SA008A) ] GAL20XV10	GAL20XV10@PLCC28
[ (SA008A) ] GAL20XV10B	GAL20XV10B@PLCC28
[ (SA008A) ] GAL22LV10C	GAL22LV10C@PLCC28
[ (SA008A) ] GAL22LV10C@SOIC24 [ (SA404) ]	GAL22LV10C@TSOP24
[ (SA643) ] GAL22LV10D	GAL22LV10D@PLCC28
[ (SA008A) ] GAL22LV10D@SOIC24 [ (SA404) ]	GAL22LV10D@TSOP24
[ (SA643) ] GAL22LV10Z	GAL22LV10Z@PLCC28
[ (SA008A) ] GAL22LV10Z@SOIC24 [ (SA404) ]	GAL22LV10Z@TSOP24
[ (SA643) ] GAL22LV10ZD	GAL22LV10ZD@PLCC28
[ (SA008A) ] GAL22LV10ZD@SOIC24 [ (SA404) ]	GAL22LV10ZD@TSOP24
[ (SA643) ] GAL22V10	GAL22V10@PLCC28
[ (SA008A) ] GAL22V10@SOIC24 [ (SA404) ]	
GAL22V10A	
GAL22V10A@PLCC28 [ (SA008A) ]	GAL22V10A@SOIC24
[ (SA404) ] GAL22V10B	GAL22V10B@PLCC28
[ (SA008A) ] GAL22V10B@SOIC24 [ (SA404) ]	
GAL22V10BQ	
GAL22V10BQ@PLCC28 [ (SA008A) ]	GAL22V10BQ@SOIC24
[ (SA404) ] GAL22V10C	GAL22V10C@PLCC28
[ (SA008A) ] GAL22V10C@SOIC24 [ (SA404) ]	
GAL22V10D	

GAL22V10D@PLCC28 [(SA008A)]	GAL22V10D@SOIC24
[(SA404)]	
GAL26CLV12	GAL26CLV12@PLCC28
[(SA008A)]	
GAL26CLV12@SOIC28 [(SA404)]	GAL26CLV12@TSOP28
[(SA643)]	
GAL26CLV12B	GAL26CLV12B@PLCC28
[(SA008A)]	
GAL26CLV12B@SOIC28 [(SA404)]	GAL26CLV12B@TSOP28
[(SA643)]	
GAL26CLV12C	GAL26CLV12C@PLCC28
[(SA008A)]	
GAL26CLV12C@SOIC28 [(SA404)]	GAL26CLV12C@TSOP28
[(SA643)]	
GAL26CLV12D	GAL26CLV12D@PLCC28
[(SA008A)]	
GAL26CLV12D@SOIC28 [(SA404)]	GAL26CLV12D@TSOP28
[(SA643)]	
GAL26CLV12Z	GAL26CLV12Z@PLCC28
[(SA008A)]	
GAL26CLV12Z@SOIC28 [(SA404)]	GAL26CLV12Z@TSOP28
[(SA643)]	
GAL26CLV12ZD	GAL26CLV12ZD@PLCC28
[(SA008A)]	
GAL26CLV12ZD@SOIC28 [(SA404)]	GAL26CLV12ZD@TSOP28
[(SA643)]	
GAL26CV12	GAL26CV12@PLCC28
[(SA008A)]	
GAL26CV12B	GAL26CV12B@PLCC28
[(SA008A)]	
GAL26CV12C	GAL26CV12C@PLCC28
[(SA008A)]	
GAL26V12C	GAL26V12C@PLCC28
[(SA008A)]	
GAL6001B	GAL6001B@PLCC28
[(SA008A)]	
GAL6002B	GAL6002B@PLCC28
[(SA008A)]	
ispGAL22LV10	ispGAL22LV10(ISP) [ISP-
HEADER01]	
ispGAL22LV10@PLCC28 [(SA008A)]	
ispGAL22LV10@PLCC28(ISP) [ISP-HEADER01]	
ispGAL22LV10@SSOP28 [(SA626A)]	

ispGAL22LV10@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22LV10A  
ispGAL22LV10A(ISP) [ISP-HEADER01]  
ispGAL22LV10A@PLCC28 [(SA008A)]  
ispGAL22LV10A@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10A@SSOP28 [(SA626A)]  
ispGAL22LV10A@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22LV10B  
ispGAL22LV10B(ISP) [ISP-HEADER01]  
ispGAL22LV10B@PLCC28 [(SA008A)]  
ispGAL22LV10B@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10B@SSOP28 [(SA626A)]  
ispGAL22LV10B@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22LV10C  
ispGAL22LV10C(ISP) [ISP-HEADER01]  
ispGAL22LV10C@PLCC28 [(SA008A)]  
ispGAL22LV10C@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10C@SSOP28 [(SA626A)]  
ispGAL22LV10C@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22LV10D  
ispGAL22LV10D(ISP) [ISP-HEADER01]  
ispGAL22LV10D@PLCC28 [(SA008A)]  
ispGAL22LV10D@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10D@SSOP28 [(SA626A)]  
ispGAL22LV10D@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22V10AB@PLCC28 [(SA008A)]      ispGAL22V10AB@QFN32  
[(SA686)]  
ispGAL22V10AC@PLCC28 [(SA008A)]      ispGAL22V10AC@QFN32  
[(SA686)]  
ispGAL22V10AV@PLCC28 [(SA008A)]      ispGAL22V10AV@QFN32  
[(SA686)]  
ispGAL22V10C(UES)@PLCC28 [(SA008A)]  
ispGAL22V10C@PLCC28 [(SA008A)]  
ispGDX120A@TQFP176(ISP) [ISP-HEADER01]  
ispGDX160@MQUAD208(ISP) [ISP-HEADER01]  
ispGDX160V@MQUAD208(ISP) [ISP-HEADER01]  
ispGDX160VA@PBGA208(ISP) [ISP-HEADER01]  
ispGDX160VA@PBGA272(ISP) [ISP-HEADER01]  
ispGDX160VA@PQFP208(ISP) [ISP-HEADER01]  
ispGDX240VA@PBGA388(ISP) [ISP-HEADER01]  
ispGDX80A@TQFP100(ISP) [ISP-HEADER01]  
ispGDX80VA@CBGA100(ISP) [ISP-HEADER01]  
ispGDX80VA@TQFP100 [(PEP+S604)]      ispLSI1016@PLCC44

[ (SA244) ]  
ispLSI1016@TQFP44 [ (SA245A) ]                   ispLSI1016E@PLCC44  
[ (SA244) ]  
ispLSI1016E@TQFP44 [ (SA245A) ]                   ispLSI1016EA@PLCC44  
[ (SA244) ]  
ispLSI1016EA@TQFP44 [ (SA245A) ]                   ispLSI1024@PLCC68 [ (PEP  
+S414T) ]  
ispLSI1024E@PLCC68 [ (PEP+S414T) ]  
ispLSI1024EA@PLCC68 [ (PEP+S414T) ]  
ispLSI1032@PGA84 [ (PEP+S667+B8403) ]  
ispLSI1032@PLCC84 [ (PEP+S416T) ]                   ispLSI1032@TQFP100 [ (PEP  
+S604) ]  
ispLSI1032E@PLCC84 [ (PEP+S416T) ]                   ispLSI1032E@TQFP100 [ (PEP  
+S604) ]  
ispLSI1032EA@TQFP100 [ (PEP+S604) ]  
ispLSI1048EA@PQFP128(ISP) [ ISP-HEADER01 ]  
ispLSI2032@PLCC44 [ (SA244) ]                   ispLSI2032@TQFP44  
[ (SA245A) ]  
ispLSI2032A@PLCC44 [ (SA244) ]                   ispLSI2032A@TQFP44  
[ (SA245A) ]  
ispLSI2032A@TQFP48 [ (SA248) ]                   ispLSI2032E@PLCC44  
[ (SA244) ]  
ispLSI2032E@TQFP44 [ (SA245A) ]                   ispLSI2032E@TQFP48  
[ (SA248) ]  
ispLSI2032V@PLCC44 [ (SA244) ]                   ispLSI2032V@TQFP44  
[ (SA245A) ]  
ispLSI2032V@TQFP48 [ (SA248) ]  
ispLSI2032VE@CBGA49(ISP) [ ISP-HEADER01 ]  
ispLSI2032VE@PLCC44 [ (SA244) ]                   ispLSI2032VE@TQFP44  
[ (SA245A) ]  
ispLSI2064@PLCC84 [ (PEP+S416T) ]                   ispLSI2064@TQFP100 [ (PEP  
+S604) ]  
ispLSI2064A@PLCC44 [ (SA244) ]                   ispLSI2064A@PLCC84 [ (PEP  
+S416T) ]  
ispLSI2064A@TQFP100 [ (PEP+S604) ]                   ispLSI2064A@TQFP44  
[ (SA245A) ]  
ispLSI2064E@PQFP100 [ (PEP+S427) ]                   ispLSI2064E@TQFP100 [ (PEP  
+S604) ]  
ispLSI2064V@PLCC44 [ (SA244) ]                   ispLSI2064V@PLCC84 [ (PEP  
+S416T) ]  
ispLSI2064V@TQFP100 [ (PEP+S604) ]                   ispLSI2064V@TQFP44  
[ (SA245A) ]  
ispLSI2064VE@CBGA100(ISP) [ ISP-HEADER01 ]

ispLSI2064VE@PLCC44 [(SA244)]  
ispLSI2064VE@PLCC84 [(PEP+S416T)]  
ispLSI2064VE@TQFP100 [(PEP+S604)]  
ispLSI2064VE@TQFP44 [(SA245A)]  
ispLSI2096E@PQFP128(ISP) [ISP-HEADER01]  
ispLSI2096E@TQFP128(ISP) [ISP-HEADER01]  
ispLSI2096V@PQFP128(ISP) [ISP-HEADER01]  
ispLSI2096V@TQFP128(ISP) [ISP-HEADER01]  
ispLSI2096VE@PQFP128(ISP) [ISP-HEADER01]  
ispLSI2096VE@TQFP128(ISP) [ISP-HEADER01]  
ispLSI2128A@PLCC84 [(PEP+S416T)]  
ispLSI2128A@PQFP160(ISP) [ISP-HEADER01]  
ispLSI2128A@TQFP100 [(PEP+S604)]  
ispLSI2128E@TQFP176(ISP) [ISP-HEADER01]  
ispLSI2128V@PLCC84 [(PEP+S416T)]  
ispLSI2128V@PQFP160(ISP) [ISP-HEADER01]  
ispLSI2128V@TQFP100 [(PEP+S604)]  
ispLSI2128V@TQFP176(ISP) [ISP-HEADER01]  
ispLSI2128VE@CBGA100(ISP) [ISP-HEADER01]  
ispLSI2128VE@PBGA208(ISP) [ISP-HEADER01]  
ispLSI2128VE@PLCC84 [(PEP+S416T)]  
ispLSI2128VE@PQFP160(ISP) [ISP-HEADER01]  
ispLSI2128VE@TQFP100 [(PEP+S604)]  
ispLSI2128VE@TQFP176(ISP) [ISP-HEADER01]  
ispLSI2192VE@PBGA144(ISP) [ISP-HEADER01]  
ispLSI2192VE@TQFP128(ISP) [ISP-HEADER01]  
ispLSI5128VE@TQFP128(ISP) [ISP-HEADER01]  
ispLSI5256A@PBGA272(ISP) [ISP-HEADER01]  
ispLSI5256V@PBGA272(ISP) [ISP-HEADER01]  
ispLSI5256VE@PBGA256(ISP) [ISP-HEADER01]  
ispLSI5256VE@PBGA272(ISP) [ISP-HEADER01]  
ispLSI5256VE@TQFP100 [(PEP+S604)]  
ispLSI5256VE@TQFP128(ISP) [ISP-HEADER01]  
ispLSI5384A@PBGA272(ISP) [ISP-HEADER01]  
ispLSI5384V@PBGA272(ISP) [ISP-HEADER01]  
ispLSI5384VE@PBGA256(ISP) [ISP-HEADER01]  
ispLSI5384VE@PBGA272(ISP) [ISP-HEADER01]  
ispLSI5384VE@PQFP208(ISP) [ISP-HEADER01]  
ispLSI5512A@PBGA272(ISP) [ISP-HEADER01]  
ispLSI5512V@PBGA272(ISP) [ISP-HEADER01]  
ispLSI5512VE@PBGA256(ISP) [ISP-HEADER01]  
ispLSI5512VE@PBGA272(ISP) [ISP-HEADER01]  
ispLSI5512VE@PBGA388(ISP) [ISP-HEADER01]



ispLSI5512VE@PQFP208(ISP) [ISP-HEADER01]  
ispLSI81080V@PBGA272(ISP) [ISP-HEADER01]  
ispLSI81080V@PBGA492(ISP) [ISP-HEADER01]  
ispLSI8600V@PBGA272(ISP) [ISP-HEADER01]  
ispLSI8600V@PBGA492(ISP) [ISP-HEADER01]  
ispLSI8840@SBGA352(ISP) [ISP-HEADER01]  
ispLSI8840@SBGA432(ISP) [ISP-HEADER01]  
ispLSI8840V@PBGA272(ISP) [ISP-HEADER01]  
ispLSI8840V@PBGA492(ISP) [ISP-HEADER01]  
LC4032B@TQFP44 [(SA245A)]  
LC4032B@TQFP44(ISP) [ISP-HEADER01]  
LC4032B@TQFP48 [(SA248)]  
LC4032B@TQFP48(ISP) [ISP-HEADER01]  
LC4032C@TQFP44 [(SA245A)]  
LC4032C@TQFP44(ISP) [ISP-HEADER01]  
LC4032C@TQFP48 [(SA248)]  
LC4032C@TQFP48(ISP) [ISP-HEADER01]  
LC4032V@TQFP44 [(SA245A)]  
LC4032V@TQFP44(ISP) [ISP-HEADER01]  
LC4032V@TQFP48 [(SA248)]  
LC4032V@TQFP48(ISP) [ISP-HEADER01]  
LC4032ZC@csBGA56 [(SA699+B161)]  
LC4032ZC@csBGA56(ISP) [ISP-HEADER01]  
LC4032ZC@TQFP48 [(SA248)]  
LC4032ZC@TQFP48(ISP) [ISP-HEADER01]  
LC4064B@TQFP100 [(PEP+S604)]  
LC4064B@TQFP100(\*) [(TA074+B006)]  
LC4064B@TQFP100(ISP) [ISP-HEADER01]  
LC4064B@TQFP44 [(SA245A)]  
LC4064B@TQFP44(ISP) [ISP-HEADER01]  
LC4064B@TQFP48 [(SA248)]  
LC4064B@TQFP48(ISP) [ISP-HEADER01]  
LC4064C@TQFP100 [(PEP+S604)]  
LC4064C@TQFP100(\*) [(TA074+B006)]  
LC4064C@TQFP100(ISP) [ISP-HEADER01]  
LC4064C@TQFP44 [(SA245A)]  
LC4064C@TQFP44(ISP) [ISP-HEADER01]  
LC4064C@TQFP48 [(SA248)]  
LC4064C@TQFP48(ISP) [ISP-HEADER01]  
LC4064V@TQFP100 [(PEP+S604)]  
LC4064V@TQFP100(\*) [(TA074+B006)]  
LC4064V@TQFP100(ISP) [ISP-HEADER01]  
LC4064V@TQFP44 [(SA245A)]

LC4064V@TQFP44 (ISP) [ISP-HEADER01]  
LC4064V@TQFP48 [(SA248)]  
LC4064V@TQFP48 (ISP) [ISP-HEADER01]  
LC4064ZC@csBGA56 [(SA699+B161)]  
LC4064ZC@csBGA56 (ISP) [ISP-HEADER01]  
LC4064ZC@TQFP100 [(PEP+S604)]  
LC4064ZC@TQFP100 (\*) [(TA074+B006)]  
LC4064ZC@TQFP100 (ISP) [ISP-HEADER01]  
LC4064ZC@TQFP48 [(SA248)]  
LC4064ZC@TQFP48 (ISP) [ISP-HEADER01]  
LC4128B@TQFP100 [(PEP+S604)]  
LC4128B@TQFP100 (\*) [(TA074+B006)]  
LC4128B@TQFP100 (ISP) [ISP-HEADER01]  
LC4128B@TQFP128 (\*) [(SA721+B195)]  
LC4128B@TQFP128 (ISP) [ISP-HEADER01]  
LC4128C@TQFP100 [(PEP+S604)]  
LC4128C@TQFP100 (\*) [(TA074+B006)]  
LC4128C@TQFP100 (ISP) [ISP-HEADER01]  
LC4128C@TQFP128 (\*) [(SA721+B195)]  
LC4128C@TQFP128 (ISP) [ISP-HEADER01]  
LC4128V@TQFP100 [(PEP+S604)]  
LC4128V@TQFP100 (\*) [(TA074+B006)]  
LC4128V@TQFP100 (ISP) [ISP-HEADER01]  
LC4128V@TQFP128 (\*) [(SA721+B195)]  
LC4128V@TQFP128 (ISP) [ISP-HEADER01]  
LC4128V@TQFP144 (\*) [(SA681+B14406)]  
LC4128V@TQFP144 (ISP) [ISP-HEADER01]  
LC4128ZC@csBGA132 (ISP) [ISP-HEADER01]  
LC4128ZC@TQFP100 [(PEP+S604)]  
LC4128ZC@TQFP100 (\*) [(TA074+B006)]  
LC4128ZC@TQFP100 (ISP) [ISP-HEADER01]  
LC4128ZC@TQFP128 (\*) [(SA721+B195)]  
LC4128ZC@TQFP128 (ISP) [ISP-HEADER01]  
LC4256B(128I/O)@FBGA256A [(SA800+B269)]  
LC4256B(128I/O)@FBGA256A (ISP) [ISP-HEADER01]  
LC4256B(160I/O)@FBGA256B [(SA800+B269)]  
LC4256B(160I/O)@FBGA256B (ISP) [ISP-HEADER01]  
LC4256B@TQFP100 [(PEP+S604)]  
LC4256B@TQFP100 (\*) [(TA074+B006)]  
LC4256B@TQFP100 (ISP) [ISP-HEADER01]  
LC4256B@TQFP176 (ISP) [ISP-HEADER01]  
LC4256C(128I/O)@FBGA256A [(SA800+B269)]  
LC4256C(128I/O)@FBGA256A (ISP) [ISP-HEADER01]

LC4256C(160I/O)@FBGA256B [(SA800+B269)]  
LC4256C(160I/O)@FBGA256B(ISP) [ISP-HEADER01]  
LC4256C@TQFP100 [(PEP+S604)]  
LC4256C@TQFP100(\*) [(TA074+B006)]  
LC4256C@TQFP100(ISP) [ISP-HEADER01]  
LC4256C@TQFP176(ISP) [ISP-HEADER01]  
LC4256V(128I/O)@FBGA256A [(SA800+B269)]  
LC4256V(128I/O)@FBGA256A(ISP) [ISP-HEADER01]  
LC4256V(160I/O)@FBGA256B [(SA800+B269)]  
LC4256V(160I/O)@FBGA256B(ISP) [ISP-HEADER01]  
LC4256V@TQFP100 [(PEP+S604)]  
LC4256V@TQFP100(\*) [(TA074+B006)]  
LC4256V@TQFP100(ISP) [ISP-HEADER01]  
LC4256V@TQFP144(\*) [(SA681+B14406)]  
LC4256V@TQFP176(ISP) [ISP-HEADER01]  
LC4256ZC@csBGA132(ISP) [ISP-HEADER01]  
LC4256ZC@TQFP100 [(PEP+S604)]  
LC4256ZC@TQFP100(\*) [(TA074+B006)]  
LC4256ZC@TQFP100(ISP) [ISP-HEADER01]  
LC4256ZC@TQFP176(ISP) [ISP-HEADER01]  
LC4384B@FBGA256 [(SA800+B269)]  
LC4384B@FBGA256(ISP) [ISP-HEADER01]  
LC4384B@TQFP176(ISP) [ISP-HEADER01]  
LC4384C@FBGA256 [(SA800+B269)]  
LC4384C@FBGA256(ISP) [ISP-HEADER01]  
LC4384C@TQFP176(ISP) [ISP-HEADER01]  
LC4384V@FBGA256 [(SA800+B269)]  
LC4384V@FBGA256(ISP) [ISP-HEADER01]  
LC4384V@TQFP176(ISP) [ISP-HEADER01]  
LC4512B@FBGA256 [(SA800+B269)]  
LC4512B@FBGA256(ISP) [ISP-HEADER01]  
LC4512B@TQFP176(ISP) [ISP-HEADER01]  
LC4512C@FBGA256 [(SA800+B269)]  
LC4512C@FBGA256(ISP) [ISP-HEADER01]  
LC4512C@TQFP176(ISP) [ISP-HEADER01]  
LC4512V@FBGA256 [(SA800+B269)]  
LC4512V@FBGA256(ISP) [ISP-HEADER01]  
LC4512V@TQFP176(ISP) [ISP-HEADER01]  
LC51024MB@fpBGA484(ISP) [ISP-HEADER01]  
LC51024MB@fpBGA672(ISP) [ISP-HEADER01]  
LC51024MC@fpBGA484(ISP) [ISP-HEADER01]  
LC51024MC@fpBGA672(ISP) [ISP-HEADER01]  
LC51024MV@fpBGA484(ISP) [ISP-HEADER01]

LC51024MV@fpBGA672(ISP) [ISP-HEADER01]  
LC5128B@TQFP128(ISP) [ISP-HEADER01]  
LC5256B@fpBGA256(ISP) [ISP-HEADER01]  
LC5256B@PQFP208(ISP) [ISP-HEADER01]  
LC5256B@TQFP128(ISP) [ISP-HEADER01]  
LC5256MB@fpBGA256(ISP) [ISP-HEADER01]  
LC5256MC@fpBGA256(ISP) [ISP-HEADER01]  
LC5256MV@fpBGA256(ISP) [ISP-HEADER01]  
LC5384B@fpBGA256(ISP) [ISP-HEADER01]  
LC5384B@PQFP208(ISP) [ISP-HEADER01]  
LC5512B@fpBGA256(ISP) [ISP-HEADER01]  
LC5512B@fpBGA484(ISP) [ISP-HEADER01]  
LC5512B@PQFP208(ISP) [ISP-HEADER01]  
LC5512MB@fpBGA256(ISP) [ISP-HEADER01]  
LC5512MB@fpBGA484(ISP) [ISP-HEADER01]  
LC5512MB@PQFP208(ISP) [ISP-HEADER01]  
LC5512MC@fpBGA256(ISP) [ISP-HEADER01]  
LC5512MC@fpBGA484(ISP) [ISP-HEADER01]  
LC5512MC@PQFP208(ISP) [ISP-HEADER01]  
LC5512MV@fpBGA256(ISP) [ISP-HEADER01]  
LC5512MV@fpBGA484(ISP) [ISP-HEADER01]  
LC5512MV@PQFP208(ISP) [ISP-HEADER01]  
LC5768MB@fpBGA256(ISP) [ISP-HEADER01]  
LC5768MB@fpBGA484(ISP) [ISP-HEADER01]  
LC5768MC@fpBGA256(ISP) [ISP-HEADER01]  
LC5768MC@fpBGA484(ISP) [ISP-HEADER01]  
LC5768MV@fpBGA256(ISP) [ISP-HEADER01]  
LC5768MV@fpBGA484(ISP) [ISP-HEADER01]  
LCMX01200C-FT256(\*) [(SA800-B208)]  
LCMX01200C-FT256(ISP) [ISP-HEADER01]  
LCMX01200C-FT324(ISP) [ISP-HEADER01]  
LCMX01200C-FTN256(\*) [(SA800-B208)]  
LCMX01200C-FTN256(ISP) [ISP-HEADER01]  
LCMX01200C-FTN324(ISP) [ISP-HEADER01]  
LCMX01200C-M100(ISP) [ISP-HEADER01]  
LCMX01200C-M132(ISP) [ISP-HEADER01]  
LCMX01200C-MN100(ISP) [ISP-HEADER01]  
LCMX01200C-MN132(ISP) [ISP-HEADER01]  
LCMX01200C-T100 [(PEP+S604)]  
LCMX01200C-T100(ISP) [ISP-HEADER01]  
LCMX01200C-T144(\*) [(SA681+B14417)]  
LCMX01200C-T144(ISP) [ISP-HEADER01]  
LCMX01200C-TN100 [(PEP+S604)]

LCMXO1200C-TN100(ISP) [ISP-HEADER01]  
LCMXO1200C-TN144(\*) [(SA681+B14417)]  
LCMXO1200C-TN144(ISP) [ISP-HEADER01]  
LCMXO1200E-FT256(\*) [(SA800-B208)]  
LCMXO1200E-FT256(ISP) [ISP-HEADER01]  
LCMXO1200E-FT324(ISP) [ISP-HEADER01]  
LCMXO1200E-FTN256(\*) [(SA800-B208)]  
LCMXO1200E-FTN256(ISP) [ISP-HEADER01]  
LCMXO1200E-FTN324(ISP) [ISP-HEADER01]  
LCMXO1200E-M100(ISP) [ISP-HEADER01]  
LCMXO1200E-M132(ISP) [ISP-HEADER01]  
LCMXO1200E-MN100(ISP) [ISP-HEADER01]  
LCMXO1200E-MN132(ISP) [ISP-HEADER01]  
LCMXO1200E-T100 [(PEP+S604)]  
LCMXO1200E-T100(ISP) [ISP-HEADER01]  
LCMXO1200E-T144(\*) [(SA681+B14417)]  
LCMXO1200E-T144(ISP) [ISP-HEADER01]  
LCMXO1200E-TN100 [(PEP+S604)]  
LCMXO1200E-TN100(ISP) [ISP-HEADER01]  
LCMXO1200E-TN144(\*) [(SA681+B14417)]  
LCMXO1200E-TN144(ISP) [ISP-HEADER01]  
LCMXO22800C-FT256(\*) [(SA800-B208)]  
LCMXO22800C-FTN256(\*) [(SA800-B208)]  
LCMXO22800E-FT256(\*) [(SA800-B208)]  
LCMXO22800E-FTN256(\*) [(SA800-B208)]  
LCMXO2280C-FT256(ISP) [ISP-HEADER01]  
LCMXO2280C-FT324(ISP) [ISP-HEADER01]  
LCMXO2280C-FTN256(ISP) [ISP-HEADER01]  
LCMXO2280C-FTN324(ISP) [ISP-HEADER01]  
LCMXO2280C-M100(ISP) [ISP-HEADER01]  
LCMXO2280C-M132(ISP) [ISP-HEADER01]  
LCMXO2280C-MN100(ISP) [ISP-HEADER01]  
LCMXO2280C-MN132(ISP) [ISP-HEADER01]  
LCMXO2280C-T100 [(PEP+S604)]  
LCMXO2280C-T100(ISP) [ISP-HEADER01]  
LCMXO2280C-T144(\*) [(SA681+B14417)]  
LCMXO2280C-T144(ISP) [ISP-HEADER01]  
LCMXO2280C-TN100 [(PEP+S604)]  
LCMXO2280C-TN100(ISP) [ISP-HEADER01]  
LCMXO2280C-TN144(\*) [(SA681+B14417)]  
LCMXO2280C-TN144(ISP) [ISP-HEADER01]  
LCMXO2280E-FT256(ISP) [ISP-HEADER01]  
LCMXO2280E-FT324(ISP) [ISP-HEADER01]

LCMXO2280E-FTN256 (ISP) [ISP-HEADER01]  
LCMXO2280E-FTN324 (ISP) [ISP-HEADER01]  
LCMXO2280E-M100 (ISP) [ISP-HEADER01]  
LCMXO2280E-M132 (ISP) [ISP-HEADER01]  
LCMXO2280E-MN100 (ISP) [ISP-HEADER01]  
LCMXO2280E-MN132 (ISP) [ISP-HEADER01]  
LCMXO2280E-T100 [(PEP+S604)]  
LCMXO2280E-T100 (ISP) [ISP-HEADER01]  
LCMXO2280E-T144 (\*) [(SA681+B14417)]  
LCMXO2280E-T144 (ISP) [ISP-HEADER01]  
LCMXO2280E-TN100 [(PEP+S604)]  
LCMXO2280E-TN100 (ISP) [ISP-HEADER01]  
LCMXO2280E-TN144 (\*) [(SA681+B14417)]  
LCMXO2280E-TN144 (ISP) [ISP-HEADER01]  
LCMXO256C-FT256 (ISP) [ISP-HEADER01]  
LCMXO256C-FT324 (ISP) [ISP-HEADER01]  
LCMXO256C-FTN256 (ISP) [ISP-HEADER01]  
LCMXO256C-FTN324 (ISP) [ISP-HEADER01]  
LCMXO256C-M100 (ISP) [ISP-HEADER01]  
LCMXO256C-M132 (ISP) [ISP-HEADER01]  
LCMXO256C-MN100 (ISP) [ISP-HEADER01]  
LCMXO256C-MN132 (ISP) [ISP-HEADER01]  
LCMXO256C-T100 [(PEP+S604)]  
LCMXO256C-T100 (ISP) [ISP-HEADER01]  
LCMXO256C-T144 (\*) [(SA681+B14417)]  
LCMXO256C-T144 (ISP) [ISP-HEADER01]  
LCMXO256C-TN100 [(PEP+S604)]  
LCMXO256C-TN100 (ISP) [ISP-HEADER01]  
LCMXO256C-TN144 (\*) [(SA681+B14417)]  
LCMXO256C-TN144 (ISP) [ISP-HEADER01]  
LCMXO256E-FT256 (ISP) [ISP-HEADER01]  
LCMXO256E-FT324 (ISP) [ISP-HEADER01]  
LCMXO256E-FTN256 (ISP) [ISP-HEADER01]  
LCMXO256E-FTN324 (ISP) [ISP-HEADER01]  
LCMXO256E-M100 (ISP) [ISP-HEADER01]  
LCMXO256E-M132 (ISP) [ISP-HEADER01]  
LCMXO256E-MN100 (ISP) [ISP-HEADER01]  
LCMXO256E-MN132 (ISP) [ISP-HEADER01]  
LCMXO256E-T100 [(PEP+S604)]  
LCMXO256E-T100 (ISP) [ISP-HEADER01]  
LCMXO256E-T144 (\*) [(SA681+B14417)]  
LCMXO256E-T144 (ISP) [ISP-HEADER01]  
LCMXO256E-TN100 [(PEP+S604)]

LCMXO256E-TN100(ISP) [ISP-HEADER01]  
LCMXO256E-TN144(\*) [(SA681+B14417)]  
LCMXO256E-TN144(ISP) [ISP-HEADER01]  
LCMXO640C-FT256(\*) [(SA800-B208)]  
LCMXO640C-FT256(ISP) [ISP-HEADER01]  
LCMXO640C-FT324(ISP) [ISP-HEADER01]  
LCMXO640C-FTN256(\*) [(SA800-B208)]  
LCMXO640C-FTN256(ISP) [ISP-HEADER01]  
LCMXO640C-FTN324(ISP) [ISP-HEADER01]  
LCMXO640C-M100(ISP) [ISP-HEADER01]  
LCMXO640C-M132(ISP) [ISP-HEADER01]  
LCMXO640C-MN100(ISP) [ISP-HEADER01]  
LCMXO640C-MN132(ISP) [ISP-HEADER01]  
LCMXO640C-T100 [(PEP+S604)]  
LCMXO640C-T100(ISP) [ISP-HEADER01]  
LCMXO640C-T144(\*) [(SA681+B14417)]  
LCMXO640C-T144(ISP) [ISP-HEADER01]  
LCMXO640C-TN100 [(PEP+S604)]  
LCMXO640C-TN100(ISP) [ISP-HEADER01]  
LCMXO640C-TN144(\*) [(SA681+B14417)]  
LCMXO640C-TN144(ISP) [ISP-HEADER01]  
LCMXO640E-FT256(\*) [(SA800-B208)]  
LCMXO640E-FT256(ISP) [ISP-HEADER01]  
LCMXO640E-FT324(ISP) [ISP-HEADER01]  
LCMXO640E-FTN256(\*) [(SA800-B208)]  
LCMXO640E-FTN256(ISP) [ISP-HEADER01]  
LCMXO640E-FTN324(ISP) [ISP-HEADER01]  
LCMXO640E-M100(ISP) [ISP-HEADER01]  
LCMXO640E-M132(ISP) [ISP-HEADER01]  
LCMXO640E-MN100(ISP) [ISP-HEADER01]  
LCMXO640E-MN132(ISP) [ISP-HEADER01]  
LCMXO640E-T100 [(PEP+S604)]  
LCMXO640E-T100(ISP) [ISP-HEADER01]  
LCMXO640E-T144(\*) [(SA681+B14417)]  
LCMXO640E-T144(ISP) [ISP-HEADER01]  
LCMXO640E-TN100 [(PEP+S604)]  
LCMXO640E-TN100(ISP) [ISP-HEADER01]  
LCMXO640E-TN144(\*) [(SA681+B14417)]  
LCMXO640E-TN144(ISP) [ISP-HEADER01]  
LFXP10C-3F256C [(SA800A+B184)]  
LFXP10C-3F256C(ISP) [ISP-HEADER01]  
LFXP10C-3F256I [(SA800A+B184)]  
LFXP10C-3F256I(ISP) [ISP-HEADER01]

LFXP10C-3F388C(ISP) [ISP-HEADER01]  
LFXP10C-3F388I(ISP) [ISP-HEADER01]  
LFXP10C-3FN256C [(SA800A+B184)]  
LFXP10C-3FN256C(ISP) [ISP-HEADER01]  
LFXP10C-3FN256I [(SA800A+B184)]  
LFXP10C-3FN256I(ISP) [ISP-HEADER01]  
LFXP10C-3FN388C(ISP) [ISP-HEADER01]  
LFXP10C-3FN388I(ISP) [ISP-HEADER01]  
LFXP10C-4F256C [(SA800A+B184)]  
LFXP10C-4F256C(ISP) [ISP-HEADER01]  
LFXP10C-4F256I [(SA800A+B184)]  
LFXP10C-4F256I(ISP) [ISP-HEADER01]  
LFXP10C-4F388C(ISP) [ISP-HEADER01]  
LFXP10C-4F388I(ISP) [ISP-HEADER01]  
LFXP10C-4FN256C [(SA800A+B184)]  
LFXP10C-4FN256C(ISP) [ISP-HEADER01]  
LFXP10C-4FN256I [(SA800A+B184)]  
LFXP10C-4FN256I(ISP) [ISP-HEADER01]  
LFXP10C-4FN388C(ISP) [ISP-HEADER01]  
LFXP10C-4FN388I(ISP) [ISP-HEADER01]  
LFXP10C-5F256C [(SA800A+B184)]  
LFXP10C-5F256C(ISP) [ISP-HEADER01]  
LFXP10C-5F256I [(SA800A+B184)]  
LFXP10C-5F256I(ISP) [ISP-HEADER01]  
LFXP10C-5F388C(ISP) [ISP-HEADER01]  
LFXP10C-5F388I(ISP) [ISP-HEADER01]  
LFXP10C-5FN256C [(SA800A+B184)]  
LFXP10C-5FN256C(ISP) [ISP-HEADER01]  
LFXP10C-5FN256I [(SA800A+B184)]  
LFXP10C-5FN256I(ISP) [ISP-HEADER01]  
LFXP10C-5FN388C(ISP) [ISP-HEADER01]  
LFXP10C-5FN388I(ISP) [ISP-HEADER01]  
LFXP10E-3F256C [(SA800A+B184)]  
LFXP10E-3F256C(ISP) [ISP-HEADER01]  
LFXP10E-3F256I [(SA800A+B184)]  
LFXP10E-3F256I(ISP) [ISP-HEADER01]  
LFXP10E-3F388C(ISP) [ISP-HEADER01]  
LFXP10E-3F388I(ISP) [ISP-HEADER01]  
LFXP10E-3FN256C [(SA800A+B184)]  
LFXP10E-3FN256C(ISP) [ISP-HEADER01]  
LFXP10E-3FN256I [(SA800A+B184)]  
LFXP10E-3FN256I(ISP) [ISP-HEADER01]  
LFXP10E-3FN388C(ISP) [ISP-HEADER01]



LFXP10E-3FN388I(ISP) [ISP-HEADER01]  
LFXP10E-4F256C [(SA800A+B184)]  
LFXP10E-4F256C(ISP) [ISP-HEADER01]  
LFXP10E-4F256I [(SA800A+B184)]  
LFXP10E-4F256I(ISP) [ISP-HEADER01]  
LFXP10E-4F388C(ISP) [ISP-HEADER01]  
LFXP10E-4F388I(ISP) [ISP-HEADER01]  
LFXP10E-4FN256C [(SA800A+B184)]  
LFXP10E-4FN256C(ISP) [ISP-HEADER01]  
LFXP10E-4FN256I [(SA800A+B184)]  
LFXP10E-4FN256I(ISP) [ISP-HEADER01]  
LFXP10E-4FN388C(ISP) [ISP-HEADER01]  
LFXP10E-4FN388I(ISP) [ISP-HEADER01]  
LFXP10E-5F256C [(SA800A+B184)]  
LFXP10E-5F256C(ISP) [ISP-HEADER01]  
LFXP10E-5F256I [(SA800A+B184)]  
LFXP10E-5F256I(ISP) [ISP-HEADER01]  
LFXP10E-5F388C(ISP) [ISP-HEADER01]  
LFXP10E-5F388I(ISP) [ISP-HEADER01]  
LFXP10E-5FN256C [(SA800A+B184)]  
LFXP10E-5FN256C(ISP) [ISP-HEADER01]  
LFXP10E-5FN256I [(SA800A+B184)]  
LFXP10E-5FN256I(ISP) [ISP-HEADER01]  
LFXP10E-5FN388C(ISP) [ISP-HEADER01]  
LFXP10E-5FN388I(ISP) [ISP-HEADER01]  
LFXP15C-3F256C [(SA800A+B184)]  
LFXP15C-3F256C(ISP) [ISP-HEADER01]  
LFXP15C-3F256I [(SA800A+B184)]  
LFXP15C-3F256I(ISP) [ISP-HEADER01]  
LFXP15C-3F388C(ISP) [ISP-HEADER01]  
LFXP15C-3F388I(ISP) [ISP-HEADER01]  
LFXP15C-3F484C(ISP) [ISP-HEADER01]  
LFXP15C-3F484I(ISP) [ISP-HEADER01]  
LFXP15C-3FN256C [(SA800A+B184)]  
LFXP15C-3FN256C(ISP) [ISP-HEADER01]  
LFXP15C-3FN256I [(SA800A+B184)]  
LFXP15C-3FN256I(ISP) [ISP-HEADER01]  
LFXP15C-3FN388C(ISP) [ISP-HEADER01]  
LFXP15C-3FN388I(ISP) [ISP-HEADER01]  
LFXP15C-3FN484C(ISP) [ISP-HEADER01]  
LFXP15C-3FN484I(ISP) [ISP-HEADER01]  
LFXP15C-4F256C [(SA800A+B184)]  
LFXP15C-4F256C(ISP) [ISP-HEADER01]

LFXP15C-4F256I [(SA800A+B184)]  
LFXP15C-4F256I(ISP) [ISP-HEADER01]  
LFXP15C-4F388C(ISP) [ISP-HEADER01]  
LFXP15C-4F388I(ISP) [ISP-HEADER01]  
LFXP15C-4F484C(ISP) [ISP-HEADER01]  
LFXP15C-4F484I(ISP) [ISP-HEADER01]  
LFXP15C-4FN256C [(SA800A+B184)]  
LFXP15C-4FN256C(ISP) [ISP-HEADER01]  
LFXP15C-4FN256I [(SA800A+B184)]  
LFXP15C-4FN256I(ISP) [ISP-HEADER01]  
LFXP15C-4FN388C(ISP) [ISP-HEADER01]  
LFXP15C-4FN388I(ISP) [ISP-HEADER01]  
LFXP15C-4FN484C(ISP) [ISP-HEADER01]  
LFXP15C-4FN484I(ISP) [ISP-HEADER01]  
LFXP15C-5F256C [(SA800A+B184)]  
LFXP15C-5F256C(ISP) [ISP-HEADER01]  
LFXP15C-5F256I [(SA800A+B184)]  
LFXP15C-5F256I(ISP) [ISP-HEADER01]  
LFXP15C-5F388C(ISP) [ISP-HEADER01]  
LFXP15C-5F388I(ISP) [ISP-HEADER01]  
LFXP15C-5F484C(ISP) [ISP-HEADER01]  
LFXP15C-5F484I(ISP) [ISP-HEADER01]  
LFXP15C-5FN256C [(SA800A+B184)]  
LFXP15C-5FN256C(ISP) [ISP-HEADER01]  
LFXP15C-5FN256I [(SA800A+B184)]  
LFXP15C-5FN256I(ISP) [ISP-HEADER01]  
LFXP15C-5FN388C(ISP) [ISP-HEADER01]  
LFXP15C-5FN388I(ISP) [ISP-HEADER01]  
LFXP15C-5FN484C(ISP) [ISP-HEADER01]  
LFXP15C-5FN484I(ISP) [ISP-HEADER01]  
LFXP15E-3F256C [(SA800A+B184)]  
LFXP15E-3F256C(ISP) [ISP-HEADER01]  
LFXP15E-3F256I [(SA800A+B184)]  
LFXP15E-3F256I(ISP) [ISP-HEADER01]  
LFXP15E-3F388C(ISP) [ISP-HEADER01]  
LFXP15E-3F388I(ISP) [ISP-HEADER01]  
LFXP15E-3F484C(ISP) [ISP-HEADER01]  
LFXP15E-3F484I(ISP) [ISP-HEADER01]  
LFXP15E-3FN256C [(SA800A+B184)]  
LFXP15E-3FN256C(ISP) [ISP-HEADER01]  
LFXP15E-3FN256I [(SA800A+B184)]  
LFXP15E-3FN256I(ISP) [ISP-HEADER01]  
LFXP15E-3FN388C(ISP) [ISP-HEADER01]

LFXP15E-3FN388I(ISP) [ISP-HEADER01]  
LFXP15E-3FN484C(ISP) [ISP-HEADER01]  
LFXP15E-3FN484I(ISP) [ISP-HEADER01]  
LFXP15E-4F256C [(SA800A+B184)]  
LFXP15E-4F256C(ISP) [ISP-HEADER01]  
LFXP15E-4F256I [(SA800A+B184)]  
LFXP15E-4F256I(ISP) [ISP-HEADER01]  
LFXP15E-4F388C(ISP) [ISP-HEADER01]  
LFXP15E-4F388I(ISP) [ISP-HEADER01]  
LFXP15E-4F484C(ISP) [ISP-HEADER01]  
LFXP15E-4F484I(ISP) [ISP-HEADER01]  
LFXP15E-4FN256C [(SA800A+B184)]  
LFXP15E-4FN256C(ISP) [ISP-HEADER01]  
LFXP15E-4FN256I [(SA800A+B184)]  
LFXP15E-4FN256I(ISP) [ISP-HEADER01]  
LFXP15E-4FN388C(ISP) [ISP-HEADER01]  
LFXP15E-4FN388I(ISP) [ISP-HEADER01]  
LFXP15E-4FN484C(ISP) [ISP-HEADER01]  
LFXP15E-4FN484I(ISP) [ISP-HEADER01]  
LFXP15E-5F256C [(SA800A+B184)]  
LFXP15E-5F256C(ISP) [ISP-HEADER01]  
LFXP15E-5F256I [(SA800A+B184)]  
LFXP15E-5F256I(ISP) [ISP-HEADER01]  
LFXP15E-5F388C(ISP) [ISP-HEADER01]  
LFXP15E-5F388I(ISP) [ISP-HEADER01]  
LFXP15E-5F484C(ISP) [ISP-HEADER01]  
LFXP15E-5F484I(ISP) [ISP-HEADER01]  
LFXP15E-5FN256C [(SA800A+B184)]  
LFXP15E-5FN256C(ISP) [ISP-HEADER01]  
LFXP15E-5FN256I [(SA800A+B184)]  
LFXP15E-5FN256I(ISP) [ISP-HEADER01]  
LFXP15E-5FN388C(ISP) [ISP-HEADER01]  
LFXP15E-5FN388I(ISP) [ISP-HEADER01]  
LFXP15E-5FN484C(ISP) [ISP-HEADER01]  
LFXP15E-5FN484I(ISP) [ISP-HEADER01]  
LFXP20C-3F256C [(SA800A+B184)]  
LFXP20C-3F256C(ISP) [ISP-HEADER01]  
LFXP20C-3F256I [(SA800A+B184)]  
LFXP20C-3F256I(ISP) [ISP-HEADER01]  
LFXP20C-3F388C(ISP) [ISP-HEADER01]  
LFXP20C-3F388I(ISP) [ISP-HEADER01]  
LFXP20C-3F484C(ISP) [ISP-HEADER01]  
LFXP20C-3F484I(ISP) [ISP-HEADER01]

LFXP20C-3FN256C [(SA800A+B184)]  
LFXP20C-3FN256C(ISP) [ISP-HEADER01]  
LFXP20C-3FN256I [(SA800A+B184)]  
LFXP20C-3FN256I(ISP) [ISP-HEADER01]  
LFXP20C-3FN388C(ISP) [ISP-HEADER01]  
LFXP20C-3FN388I(ISP) [ISP-HEADER01]  
LFXP20C-3FN484C(ISP) [ISP-HEADER01]  
LFXP20C-3FN484I(ISP) [ISP-HEADER01]  
LFXP20C-4F256C [(SA800A+B184)]  
LFXP20C-4F256C(ISP) [ISP-HEADER01]  
LFXP20C-4F256I [(SA800A+B184)]  
LFXP20C-4F256I(ISP) [ISP-HEADER01]  
LFXP20C-4F388C(ISP) [ISP-HEADER01]  
LFXP20C-4F388I(ISP) [ISP-HEADER01]  
LFXP20C-4F484C(ISP) [ISP-HEADER01]  
LFXP20C-4F484I(ISP) [ISP-HEADER01]  
LFXP20C-4FN256C [(SA800A+B184)]  
LFXP20C-4FN256C(ISP) [ISP-HEADER01]  
LFXP20C-4FN256I [(SA800A+B184)]  
LFXP20C-4FN256I(ISP) [ISP-HEADER01]  
LFXP20C-4FN388C(ISP) [ISP-HEADER01]  
LFXP20C-4FN388I(ISP) [ISP-HEADER01]  
LFXP20C-4FN484C(ISP) [ISP-HEADER01]  
LFXP20C-4FN484I(ISP) [ISP-HEADER01]  
LFXP20C-5F256C [(SA800A+B184)]  
LFXP20C-5F256C(ISP) [ISP-HEADER01]  
LFXP20C-5F256I [(SA800A+B184)]  
LFXP20C-5F256I(ISP) [ISP-HEADER01]  
LFXP20C-5F388C(ISP) [ISP-HEADER01]  
LFXP20C-5F388I(ISP) [ISP-HEADER01]  
LFXP20C-5F484C(ISP) [ISP-HEADER01]  
LFXP20C-5F484I(ISP) [ISP-HEADER01]  
LFXP20C-5FN256C [(SA800A+B184)]  
LFXP20C-5FN256C(ISP) [ISP-HEADER01]  
LFXP20C-5FN256I [(SA800A+B184)]  
LFXP20C-5FN256I(ISP) [ISP-HEADER01]  
LFXP20C-5FN388C(ISP) [ISP-HEADER01]  
LFXP20C-5FN388I(ISP) [ISP-HEADER01]  
LFXP20C-5FN484C(ISP) [ISP-HEADER01]  
LFXP20C-5FN484I(ISP) [ISP-HEADER01]  
LFXP20E-3F256C [(SA800A+B184)]  
LFXP20E-3F256C(ISP) [ISP-HEADER01]  
LFXP20E-3F256I [(SA800A+B184)]

LFXP20E-3F256I(ISP) [ISP-HEADER01]  
LFXP20E-3F388C(ISP) [ISP-HEADER01]  
LFXP20E-3F388I(ISP) [ISP-HEADER01]  
LFXP20E-3F484C(ISP) [ISP-HEADER01]  
LFXP20E-3F484I(ISP) [ISP-HEADER01]  
LFXP20E-3FN256C [(SA800A+B184)]  
LFXP20E-3FN256C(ISP) [ISP-HEADER01]  
LFXP20E-3FN256I [(SA800A+B184)]  
LFXP20E-3FN256I(ISP) [ISP-HEADER01]  
LFXP20E-3FN388C(ISP) [ISP-HEADER01]  
LFXP20E-3FN388I(ISP) [ISP-HEADER01]  
LFXP20E-3FN484C(ISP) [ISP-HEADER01]  
LFXP20E-3FN484I(ISP) [ISP-HEADER01]  
LFXP20E-4F256C [(SA800A+B184)]  
LFXP20E-4F256C(ISP) [ISP-HEADER01]  
LFXP20E-4F256I [(SA800A+B184)]  
LFXP20E-4F256I(ISP) [ISP-HEADER01]  
LFXP20E-4F388C(ISP) [ISP-HEADER01]  
LFXP20E-4F388I(ISP) [ISP-HEADER01]  
LFXP20E-4F484C(ISP) [ISP-HEADER01]  
LFXP20E-4F484I(ISP) [ISP-HEADER01]  
LFXP20E-4FN256C [(SA800A+B184)]  
LFXP20E-4FN256C(ISP) [ISP-HEADER01]  
LFXP20E-4FN256I [(SA800A+B184)]  
LFXP20E-4FN256I(ISP) [ISP-HEADER01]  
LFXP20E-4FN388C(ISP) [ISP-HEADER01]  
LFXP20E-4FN388I(ISP) [ISP-HEADER01]  
LFXP20E-4FN484C(ISP) [ISP-HEADER01]  
LFXP20E-4FN484I(ISP) [ISP-HEADER01]  
LFXP20E-5F256C [(SA800A+B184)]  
LFXP20E-5F256C(ISP) [ISP-HEADER01]  
LFXP20E-5F256I [(SA800A+B184)]  
LFXP20E-5F256I(ISP) [ISP-HEADER01]  
LFXP20E-5F388C(ISP) [ISP-HEADER01]  
LFXP20E-5F388I(ISP) [ISP-HEADER01]  
LFXP20E-5F484C(ISP) [ISP-HEADER01]  
LFXP20E-5F484I(ISP) [ISP-HEADER01]  
LFXP20E-5FN256C [(SA800A+B184)]  
LFXP20E-5FN256C(ISP) [ISP-HEADER01]  
LFXP20E-5FN256I [(SA800A+B184)]  
LFXP20E-5FN256I(ISP) [ISP-HEADER01]  
LFXP20E-5FN388C(ISP) [ISP-HEADER01]  
LFXP20E-5FN388I(ISP) [ISP-HEADER01]

LFXP20E-5FN484C( ISP) [ ISP-HEADER01 ]  
LFXP20E-5FN484I( ISP) [ ISP-HEADER01 ]  
LFXP3C-3Q208C( ISP) [ ISP-HEADER01 ]  
LFXP3C-3Q208I( ISP) [ ISP-HEADER01 ]  
LFXP3C-3QN208C( ISP) [ ISP-HEADER01 ]  
LFXP3C-3QN208I( ISP) [ ISP-HEADER01 ]  
LFXP3C-3T100C( ISP) [ ISP-HEADER01 ]  
LFXP3C-3T100I( ISP) [ ISP-HEADER01 ]  
LFXP3C-3T144C( ISP) [ ISP-HEADER01 ]  
LFXP3C-3T144I( ISP) [ ISP-HEADER01 ]  
LFXP3C-3TN100C( ISP) [ ISP-HEADER01 ]  
LFXP3C-3TN100I( ISP) [ ISP-HEADER01 ]  
LFXP3C-3TN144C( ISP) [ ISP-HEADER01 ]  
LFXP3C-3TN144I( ISP) [ ISP-HEADER01 ]  
LFXP3C-4Q208C( ISP) [ ISP-HEADER01 ]  
LFXP3C-4Q208I( ISP) [ ISP-HEADER01 ]  
LFXP3C-4QN208C( ISP) [ ISP-HEADER01 ]  
LFXP3C-4QN208I( ISP) [ ISP-HEADER01 ]  
LFXP3C-4T100C( ISP) [ ISP-HEADER01 ]  
LFXP3C-4T100I( ISP) [ ISP-HEADER01 ]  
LFXP3C-4T144C( ISP) [ ISP-HEADER01 ]  
LFXP3C-4T144I( ISP) [ ISP-HEADER01 ]  
LFXP3C-4TN100C( ISP) [ ISP-HEADER01 ]  
LFXP3C-4TN100I( ISP) [ ISP-HEADER01 ]  
LFXP3C-4TN144C( ISP) [ ISP-HEADER01 ]  
LFXP3C-4TN144I( ISP) [ ISP-HEADER01 ]  
LFXP3C-5Q208C( ISP) [ ISP-HEADER01 ]  
LFXP3C-5Q208I( ISP) [ ISP-HEADER01 ]  
LFXP3C-5QN208C( ISP) [ ISP-HEADER01 ]  
LFXP3C-5QN208I( ISP) [ ISP-HEADER01 ]  
LFXP3C-5T100C( ISP) [ ISP-HEADER01 ]  
LFXP3C-5T100I( ISP) [ ISP-HEADER01 ]  
LFXP3C-5T144C( ISP) [ ISP-HEADER01 ]  
LFXP3C-5T144I( ISP) [ ISP-HEADER01 ]  
LFXP3C-5TN100C( ISP) [ ISP-HEADER01 ]  
LFXP3C-5TN100I( ISP) [ ISP-HEADER01 ]  
LFXP3C-5TN144C( ISP) [ ISP-HEADER01 ]  
LFXP3C-5TN144I( ISP) [ ISP-HEADER01 ]  
LFXP3E-3Q208C( ISP) [ ISP-HEADER01 ]  
LFXP3E-3Q208I( ISP) [ ISP-HEADER01 ]  
LFXP3E-3QN208C( ISP) [ ISP-HEADER01 ]  
LFXP3E-3QN208I( ISP) [ ISP-HEADER01 ]  
LFXP3E-3T100C( ISP) [ ISP-HEADER01 ]

LFXP3E-3T100I (ISP) [ISP-HEADER01]  
LFXP3E-3T144C (ISP) [ISP-HEADER01]  
LFXP3E-3T144I (ISP) [ISP-HEADER01]  
LFXP3E-3TN100C (ISP) [ISP-HEADER01]  
LFXP3E-3TN100I (ISP) [ISP-HEADER01]  
LFXP3E-3TN144C (ISP) [ISP-HEADER01]  
LFXP3E-3TN144I (ISP) [ISP-HEADER01]  
LFXP3E-4Q208C (ISP) [ISP-HEADER01]  
LFXP3E-4Q208I (ISP) [ISP-HEADER01]  
LFXP3E-4QN208C (ISP) [ISP-HEADER01]  
LFXP3E-4QN208I (ISP) [ISP-HEADER01]  
LFXP3E-4T100C (ISP) [ISP-HEADER01]  
LFXP3E-4T100I (ISP) [ISP-HEADER01]  
LFXP3E-4T144C (ISP) [ISP-HEADER01]  
LFXP3E-4T144I (ISP) [ISP-HEADER01]  
LFXP3E-4TN100C (ISP) [ISP-HEADER01]  
LFXP3E-4TN100I (ISP) [ISP-HEADER01]  
LFXP3E-4TN144C (ISP) [ISP-HEADER01]  
LFXP3E-4TN144I (ISP) [ISP-HEADER01]  
LFXP3E-5Q208C (ISP) [ISP-HEADER01]  
LFXP3E-5Q208I (ISP) [ISP-HEADER01]  
LFXP3E-5QN208C (ISP) [ISP-HEADER01]  
LFXP3E-5QN208I (ISP) [ISP-HEADER01]  
LFXP3E-5T100C (ISP) [ISP-HEADER01]  
LFXP3E-5T100I (ISP) [ISP-HEADER01]  
LFXP3E-5T144C (ISP) [ISP-HEADER01]  
LFXP3E-5T144I (ISP) [ISP-HEADER01]  
LFXP3E-5TN100C (ISP) [ISP-HEADER01]  
LFXP3E-5TN100I (ISP) [ISP-HEADER01]  
LFXP3E-5TN144C (ISP) [ISP-HEADER01]  
LFXP3E-5TN144I (ISP) [ISP-HEADER01]  
LFXP6C-3F256C [(SA800A+B184)]  
LFXP6C-3F256C (ISP) [ISP-HEADER01]  
LFXP6C-3F256I [(SA800A+B184)]  
LFXP6C-3F256I (ISP) [ISP-HEADER01]  
LFXP6C-3FN256C [(SA800A+B184)]  
LFXP6C-3FN256C (ISP) [ISP-HEADER01]  
LFXP6C-3FN256I [(SA800A+B184)]  
LFXP6C-3FN256I (ISP) [ISP-HEADER01]  
LFXP6C-3Q208C (ISP) [ISP-HEADER01]  
LFXP6C-3Q208I (ISP) [ISP-HEADER01]  
LFXP6C-3QN208C (ISP) [ISP-HEADER01]  
LFXP6C-3QN208I (ISP) [ISP-HEADER01]

LFXP6C-3T144C(\*) [(SA681+B14407)]  
LFXP6C-3T144C(ISP) [ISP-HEADER01]  
LFXP6C-3T144I(\*) [(SA681+B14407)]  
LFXP6C-3T144I(ISP) [ISP-HEADER01]  
LFXP6C-3TN144C(\*) [(SA681+B14407)]  
LFXP6C-3TN144C(ISP) [ISP-HEADER01]  
LFXP6C-3TN144I(\*) [(SA681+B14407)]  
LFXP6C-3TN144I(ISP) [ISP-HEADER01]  
LFXP6C-4F256C [(SA800A+B184)]  
LFXP6C-4F256C(ISP) [ISP-HEADER01]  
LFXP6C-4F256I [(SA800A+B184)]  
LFXP6C-4F256I(ISP) [ISP-HEADER01]  
LFXP6C-4FN256C [(SA800A+B184)]  
LFXP6C-4FN256C(ISP) [ISP-HEADER01]  
LFXP6C-4FN256I [(SA800A+B184)]  
LFXP6C-4FN256I(ISP) [ISP-HEADER01]  
LFXP6C-4Q208C(ISP) [ISP-HEADER01]  
LFXP6C-4Q208I(ISP) [ISP-HEADER01]  
LFXP6C-4QN208C(ISP) [ISP-HEADER01]  
LFXP6C-4QN208I(ISP) [ISP-HEADER01]  
LFXP6C-4T144C(ISP) [ISP-HEADER01]  
LFXP6C-4T144I(ISP) [ISP-HEADER01]  
LFXP6C-4TN144C(ISP) [ISP-HEADER01]  
LFXP6C-4TN144I(ISP) [ISP-HEADER01]  
LFXP6C-5F256C [(SA800A+B184)]  
LFXP6C-5F256C(ISP) [ISP-HEADER01]  
LFXP6C-5F256I [(SA800A+B184)]  
LFXP6C-5F256I(ISP) [ISP-HEADER01]  
LFXP6C-5FN256C [(SA800A+B184)]  
LFXP6C-5FN256C(ISP) [ISP-HEADER01]  
LFXP6C-5FN256I [(SA800A+B184)]  
LFXP6C-5FN256I(ISP) [ISP-HEADER01]  
LFXP6C-5Q208C(ISP) [ISP-HEADER01]  
LFXP6C-5Q208I(ISP) [ISP-HEADER01]  
LFXP6C-5QN208C(ISP) [ISP-HEADER01]  
LFXP6C-5QN208I(ISP) [ISP-HEADER01]  
LFXP6C-5T144C(ISP) [ISP-HEADER01]  
LFXP6C-5T144I(ISP) [ISP-HEADER01]  
LFXP6C-5TN144C(ISP) [ISP-HEADER01]  
LFXP6C-5TN144I(ISP) [ISP-HEADER01]  
LFXP6E-3F256C [(SA800A+B184)]  
LFXP6E-3F256C(ISP) [ISP-HEADER01]  
LFXP6E-3F256I [(SA800A+B184)]



LFXP6E-3F256I(ISP) [ISP-HEADER01]  
LFXP6E-3FN256C [(SA800A+B184)]  
LFXP6E-3FN256C(ISP) [ISP-HEADER01]  
LFXP6E-3FN256I [(SA800A+B184)]  
LFXP6E-3FN256I(ISP) [ISP-HEADER01]  
LFXP6E-3Q208C(ISP) [ISP-HEADER01]  
LFXP6E-3Q208I(ISP) [ISP-HEADER01]  
LFXP6E-3QN208C(ISP) [ISP-HEADER01]  
LFXP6E-3QN208I(ISP) [ISP-HEADER01]  
LFXP6E-3T144C(ISP) [ISP-HEADER01]  
LFXP6E-3T144I(ISP) [ISP-HEADER01]  
LFXP6E-3TN144C(ISP) [ISP-HEADER01]  
LFXP6E-3TN144I(ISP) [ISP-HEADER01]  
LFXP6E-4F256C [(SA800A+B184)]  
LFXP6E-4F256C(ISP) [ISP-HEADER01]  
LFXP6E-4F256I [(SA800A+B184)]  
LFXP6E-4F256I(ISP) [ISP-HEADER01]  
LFXP6E-4FN256C [(SA800A+B184)]  
LFXP6E-4FN256C(ISP) [ISP-HEADER01]  
LFXP6E-4FN256I [(SA800A+B184)]  
LFXP6E-4FN256I(ISP) [ISP-HEADER01]  
LFXP6E-4Q208C(ISP) [ISP-HEADER01]  
LFXP6E-4Q208I(ISP) [ISP-HEADER01]  
LFXP6E-4QN208C(ISP) [ISP-HEADER01]  
LFXP6E-4QN208I(ISP) [ISP-HEADER01]  
LFXP6E-4T144C(ISP) [ISP-HEADER01]  
LFXP6E-4T144I(ISP) [ISP-HEADER01]  
LFXP6E-4TN144C(ISP) [ISP-HEADER01]  
LFXP6E-4TN144I(ISP) [ISP-HEADER01]  
LFXP6E-5F256C [(SA800A+B184)]  
LFXP6E-5F256C(ISP) [ISP-HEADER01]  
LFXP6E-5F256I [(SA800A+B184)]  
LFXP6E-5F256I(ISP) [ISP-HEADER01]  
LFXP6E-5FN256C [(SA800A+B184)]  
LFXP6E-5FN256C(ISP) [ISP-HEADER01]  
LFXP6E-5FN256I [(SA800A+B184)]  
LFXP6E-5FN256I(ISP) [ISP-HEADER01]  
LFXP6E-5Q208C(ISP) [ISP-HEADER01]  
LFXP6E-5Q208I(ISP) [ISP-HEADER01]  
LFXP6E-5QN208C(ISP) [ISP-HEADER01]  
LFXP6E-5QN208I(ISP) [ISP-HEADER01]  
LFXP6E-5T144C(ISP) [ISP-HEADER01]  
LFXP6E-5T144I(ISP) [ISP-HEADER01]

LFXP6E-5TN144C(ISP) [ISP-HEADER01]  
 LFXP6E-5TN144I(ISP) [ISP-HEADER01]  
 LX128B(EB)@fpBGA208(ISP) [ISP-HEADER01]  
 LX128B-2R@fpBGA208(ISP) [ISP-HEADER01]  
 LX128C(EC)@fpBGA208(ISP) [ISP-HEADER01]  
 LX128C-2R@fpBGA208(ISP) [ISP-HEADER01]  
 LX128V(EV)@fpBGA208(ISP) [ISP-HEADER01]  
 LX128V-2R@fpBGA208(ISP) [ISP-HEADER01]  
 LX256B(EB)@fpBGA484(ISP) [ISP-HEADER01]  
 LX256B-2R@fpBGA484(ISP) [ISP-HEADER01]  
 LX256C(EC)@fpBGA484(ISP) [ISP-HEADER01]  
 LX256C-2R@fpBGA484(ISP) [ISP-HEADER01]  
 LX256V(EV)@fpBGA484(ISP) [ISP-HEADER01]  
 LX256V-2R@fpBGA484(ISP) [ISP-HEADER01]  
 LX64B(EB)@fpBGA100(ISP) [ISP-HEADER01]  
 LX64B-2R@fpBGA100(ISP) [ISP-HEADER01]  
 LX64C(EC)@fpBGA100(ISP) [ISP-HEADER01]  
 LX64C-2R@fpBGA100(ISP) [ISP-HEADER01]  
 LX64V(EV)@fpBGA100(ISP) [ISP-HEADER01]  
 LX64V-2R@fpBGA100(ISP) [ISP-HEADER01]  
 M4-128/64@PQFP100 [(PEP+S427)] M4-128/64@TQFP100 [(PEP+S604)]  
 M4-128N/64@PLCC84 [(PEP+S416T)] M4A3-128/64@PQFP100 [(PEP+S427)]  
 M4A3-128/64@TQFP100 [(PEP+S604)]  
 M4A3-128N/64@PLCC84 [(PEP+S416T)]  
 M4A3-32/32@PLCC44 [(SA244)] M4A3-32/32@TQFP44  
 [(SA245A)]  
 M4A3-32/32@TQFP48 [(SA248)] M4A3-64/32@PLCC44  
 [(SA244)]  
 M4A3-64/32@TQFP44 [(SA245A)] M4A3-64/32@TQFP48  
 [(SA248)]  
 M4A3-64/64@TQFP100 [(PEP+S604)] M4A3-96/48@TQFP100 [(PEP+S604)]  
 M4A5-128/64@PQFP100 [(PEP+S427)] M4A5-128/64@TQFP100 [(PEP+S604)]  
 M4A5-128N/64@PLCC84 [(PEP+S416T)]  
 M4A5-32/32@PLCC44 [(SA244)] M4A5-32/32@TQFP44  
 [(SA245A)]  
 M4A5-32/32@TQFP48 [(SA248)] M4A5-64/32@PLCC44  
 [(SA244)]  
 M4A5-64/32@TQFP44 [(SA245A)] M4A5-64/32@TQFP48  
 [(SA248)]

M4A5-96/48@TQFP100 [(PEP+S604)  
+S427)]  
M4LV-128/64@TQFP100 [(PEP+S604)]  
M4LV-128N/64@PLCC84 [(PEP+S416T)]  
MACH110@PLCC44 [(SA244)]  
[(SA244)]  
MACH111@TQFP44 [(SA245A)]  
+S414T)]  
MACH130@PLCC84 [(PEP+S416T)]  
+S416T)]  
MACH131@PLCC84 [(PEP+S416T)]  
+S427)]  
MACH131SP@TQFP100 [(PEP+S604)]  
[(SA244)]  
MACH210@TQFP44 [(SA245A)]  
[(SA244)]  
MACH210A@TQFP44 [(SA245A)]  
[(SA244)]  
MACH210AQ@TQFP44 [(SA245A)]  
[(SA244)]  
MACH211@TQFP44 [(SA245A)]  
[(SA244)]  
MACH211SP@TQFP44 [(SA245A)]  
+S414T)]  
MACH221@PLCC68 [(PEP+S414T)]  
+S416T)]  
MACH231@PLCC84 [(PEP+S416T)]  
+S416T)]  
MACH231SP@PQFP100 [(PEP+S427)]  
+S604)]  
MACH435@PLCC84 [(PEP+S416T)]  
+S416T)]  
MACH446@PQFP100 [(PEP+S427)]  
+S604)]  
MACHLV210@PLCC44 [(SA244)]  
+S416T)]  
MACHLV446@PQFP100 [(PEP+S427)]  
+S604)]  
PAL29M16H  
PALCE20RA10  
PALCE20RA10@PLCC28 [(SA008A)]  
[(SA404)]  
PALCE20RA10H  
M4LV-128/64@PQFP100 [(PEP  
MACH111@PLCC44  
MACH120@PLCC68 [(PEP  
MACH131/1@PLCC84 [(PEP  
MACH131SP@PQFP100 [(PEP  
MACH210@PLCC44  
MACH210A@PLCC44  
MACH210AQ@PLCC44  
MACH211@PLCC44  
MACH211SP@PLCC44  
MACH220@PLCC68 [(PEP  
MACH230@PLCC84 [(PEP  
MACH231SP@PLCC84 [(PEP  
MACH231SP@TQFP100 [(PEP  
MACH436@PLCC84 [(PEP  
MACH446@TQFP100 [(PEP  
MACHLV436@PLCC84 [(PEP  
MACHLV446@TQFP100 [(PEP  
PALCE20RA10@SOIC24  
PALCE20RA10H@PLCC28

[(SA008A)]	
PALCE20RA10H@SOIC24 [(SA404)]	
PALCE20RA10Q	
PALCE20RA10Q@PLCC28 [(SA008A)]	PALCE20RA10Q@SOIC24
[(SA404)]	
PALCE22V10H	
[(SA008A)]	PALCE22V10H@PLCC28
PALCE22V10H@SOIC24 [(SA404)]	
PALCE22V10Q	
PALCE22V10Q@PLCC28 [(SA008A)]	PALCE22V10Q@SOIC24
[(SA404)]	
PALCE22V10Z	
[(SA008A)]	PALCE22V10Z@PLCC28
PALCE22V10Z@SOIC24 [(SA404)]	
PALCE26V12H/4	
PALCE26V12H/4@PLCC28 [(SA008A)]	PALCE26V12H/4@SOIC28
[(SA404)]	
PALCE26V12H-15	
[(SA008A)]	PALCE26V12H-15@PLCC28
PALCE26V12H-15@SOIC28 [(SA404)]	PALCE26V12H-
20	
PALCE26V12H-20@PLCC28 [(SA008A)]	PALCE26V12H-20@SOIC28
[(SA404)]	
PALCE26V12H-25	
[(SA008A)]	PALCE26V12H-25@PLCC28
PALCE26V12H-25@SOIC28 [(SA404)]	
PALCE29M16H	
PALCE29M16H@PLCC28 [(SA008A)]	PALCE29M16H@SOIC24
[(SA404)]	
PALCE29MA16H	
[(SA008A)]	PALCE29MA16H@PLCC28
PALCE29MA16H@SOIC24 [(SA404)]	
PALCE610	
PALCE610@PLCC28 [(SA008A)]	PALCE610@SOIC24
[(SA404)]	
PALCE610H	
[(SA008A)]	PALCE610H@PLCC28
PALCE610H@SOIC24 [(SA404)]	
PALCE630H	
PALCE630H@PLCC28 [(SA008A)]	PALCE630H@SOIC24
[(SA404)]	

**LG Semicon****DRAM & SRAM**

GM76C256CL [ (SA430T) ]	GM76C256CL@SSOP28
GM76C256CL@TSOP28 [ (SA630) ]	
GM76C256CLL GM76C256CLL@SSOP28 [ (SA430T) ] [ (SA630) ]	GM76C256CLL@TSOP28
GM76C8128CL [ (SA438T) ]	GM76C8128CL@SSOP32
GM76C8128CL@TSOP32 [ (SA410T) ] [ (SA620) ]	GM76C8128CL@VSOP32
GM76C8128CLL [ (SA438T) ]	GM76C8128CLL@SSOP32
GM76C8128CLL@TSOP32 [ (SA410T) ] [ (SA620) ]	GM76C8128CLL@VSOP32
GM76C88AL [ (SA430T) ]	GM76C88AL@SSOP28
GM76C88AL@TSOP28 [ (SA643) ]	
GM76U256CL GM76U256CL@SSOP28 [ (SA430T) ] [ (SA643) ]	GM76U256CL@TSOP28
GM76U256CLL [ (SA430T) ]	GM76U256CLL@SSOP28
GM76U256CLL@TSOP28 [ (SA643) ]	
GM76U8128CL GM76U8128CL@SSOP32 [ (SA438T) ] [ (SA410T) ]	GM76U8128CL@TSOP32
GM76U8128CL@VSOP32 [ (SA620) ]	
GM76U8128CLL GM76U8128CLL@SSOP32 [ (SA438T) ] [ (SA410T) ]	GM76U8128CLL@TSOP32
GM76U8128CLL@VSOP32 [ (SA620) ]	
GM76U8128DL GM76U8128DL@SSOP32 [ (SA438T) ] [ (SA410T) ]	GM76U8128DL@TSOP32
GM76U8128DL@VSOP32 [ (SA620) ]	
GM76U8128DLL GM76U8128DLL@SSOP32 [ (SA438T) ] [ (SA410T) ]	GM76U8128DLL@TSOP32
GM76U8128DLL@VSOP32 [ (SA620) ]	

GM76U8512L	
GM76U8512L@SSOP32 [ (SA438T) ]	GM76U8512L@TSOP32
[ (SA410T) ]	
GM76U8512L@VSOP32 [ (SA620) ]	
GM76U8512LL	
GM76U8512LL@SSOP32 [ (SA438T) ]	GM76U8512LL@TSOP32
[ (SA410T) ]	
GM76U8512LL@VSOP32 [ (SA620) ]	
GM76V256CL	
GM76V256CL@SSOP28 [ (SA430T) ]	GM76V256CL@TSOP28
[ (SA630) ]	
GM76V256CLL	
GM76V256CLL@SSOP28 [ (SA430T) ]	GM76V256CLL@SSOP28
[ (SA630) ]	
GM76V256CLL@TSOP28 [ (SA630) ]	
GM76V8128CL	
GM76V8128CL@SSOP32 [ (SA438T) ]	GM76V8128CL@TSOP32
[ (SA410T) ]	
GM76V8128CL@VSOP32 [ (SA620) ]	
GM76V8128CLL	
GM76V8128CLL@SSOP32 [ (SA438T) ]	GM76V8128CLL@TSOP32
[ (SA410T) ]	
GM76V8128CLL@VSOP32 [ (SA620) ]	
GM76V8128DL	
GM76V8128DL@SSOP32 [ (SA438T) ]	GM76V8128DL@TSOP32
[ (SA410T) ]	
GM76V8128DL@VSOP32 [ (SA620) ]	
GM76V8128DLL	
GM76V8128DLL@SSOP32 [ (SA438T) ]	GM76V8128DLL@TSOP32
[ (SA410T) ]	
GM76V8128DLL@VSOP32 [ (SA620) ]	
GM76V8512L	
GM76V8512L@SSOP32 [ (SA438T) ]	GM76V8512L@TSOP32
[ (SA410T) ]	
GM76V8512L@VSOP32 [ (SA620) ]	
GM76V8512LL	
GM76V8512LL@SSOP32 [ (SA438T) ]	GM76V8512LL@TSOP32
[ (SA410T) ]	
GM76V8512LL@VSOP32 [ (SA620) ]	
GM77C8128A	
GM77C8128A@SSOP32 [ (SA438T) ]	GM77C8128A@TSOP32
[ (SA410T) ]	
GM77C8128A@VSOP32 [ (SA620) ]	

## MICROCONTROLLER

GMS34004TK	
GMS34004TM	
GMS34004TW	
GMS34112TK	
GMS34112TK@SOIC20 [(SA404)]	GMS34112TK@SSOP20
[(SA626A)]	
GMS34140TK	GMS34140TK@SOIC24
[(SA404)]	
GMS77C1000	GMS77C1000@SOIC20
[(SA404)]	
GMS77C1001	GMS77C1001@SOIC20
[(SA404)]	
GMS81004(dip20)	GMS81004
(dip24)	
GMS81004(dip28)	GMS81004@PLCC44
[(SA244)]	
GMS81004@SOIC20 [(SA404)]	GMS81004@SOIC24
[(SA404)]	
GMS81004@SOIC28 [(SA404)]	GMS81008
(dip20)	
GMS81008(dip24)	GMS81008
(dip28)	
GMS81008@PLCC44 [(SA244)]	GMS81008@SOIC20
[(SA404)]	
GMS81008@SOIC24 [(SA404)]	GMS81008@SOIC28
[(SA404)]	
GMS81016(dip20)	GMS81016
(dip24)	
GMS81016(dip28)	GMS81016@PLCC44
[(SA244)]	
GMS81016@SOIC20 [(SA404)]	GMS81016@SOIC24
[(SA404)]	
GMS81016@SOIC28 [(SA404)]	GMS81024
(dip20)	
GMS81024(dip24)	GMS81024
(dip28)	
GMS81024@PLCC44 [(SA244)]	GMS81024@SOIC20
[(SA404)]	
GMS81024@SOIC24 [(SA404)]	GMS81024@SOIC28
[(SA404)]	

GMS81032(dip20)	GMS81032
(dip24)	
GMS81032(dip28)	GMS81032@PLCC44
[(SA244)]	
GMS81032@SOIC20 [(SA404)]	GMS81032@SOIC24
[(SA404)]	
GMS81032@SOIC28 [(SA404)]	
GMS81504AT	
GMS81504T	
GMS81516	
GMS81516@LQFP64 [(PEP+S616)]	GMS81516@MQFP64 [(PEP
+S618)]	
GMS81516@SDIP64 [(PEP+S600A)]	
GMS81516AT	
GMS81516AT@LQFP64 [(PEP+S616)]	GMS81516AT@MQFP64 [(PEP
+S618)]	
GMS81516AT@SDIP64 [(PEP+S600A)]	
GMS81516BT	
GMS81516BT@LQFP64 [(PEP+S616)]	GMS81516BT@MQFP64 [(PEP
+S618)]	
GMS81516BT@SDIP64 [(PEP+S600A)]	
GMS81524	
GMS81524@LQFP64 [(PEP+S616)]	GMS81524@MQFP64 [(PEP
+S618)]	
GMS81524@SDIP64 [(PEP+S600A)]	
GMS81524AT	
GMS81524AT@LQFP64 [(PEP+S616)]	GMS81524AT@MQFP64 [(PEP
+S618)]	
GMS81524AT@SDIP64 [(PEP+S600A)]	
GMS81524BT	
GMS81524BT@LQFP64 [(PEP+S616)]	GMS81524BT@MQFP64 [(PEP
+S618)]	
GMS81524BT@SDIP64 [(PEP+S600A)]	
GMS81604T	
GMS81604T@PLCC44 [(SA244)]	GMS81604T@SDIP42
[(SA028)]	
GMS81608T	GMS81608T@PLCC44
[(SA244)]	
GMS81608T@SDIP42 [(SA028)]	GMS81C5016
(dip28)	
GMS81C5016(dip40)	GMS81C5016@PLCC44
[(SA244)]	
GMS81C5016@SOIC28 [(SA404)]	GMS81C5016@TQFP44



[ (SA245A) ]	
GMS81C5024(dip28)	GMS81C5024
(dip40)	
GMS81C5024@PLCC44 [ (SA244) ]	GMS81C5024@SOIC28
[ (SA404) ]	
GMS81C5024@TQFP44 [ (SA245A) ]	GMS81C5032
(dip28)	
GMS81C5032(dip40)	GMS81C5032@PLCC44
[ (SA244) ]	
GMS81C5032@SOIC28 [ (SA404) ]	GMS81C5032@TQFP44
[ (SA245A) ]	
GMS82516T	GMS82516T@LQFP64 [ (PEP
+S616) ]	
GMS82516T@MQFP64 [ (PEP+S618) ]	GMS82516T@SDIP64 [ (PEP
+S600A) ]	
GMS82524T	GMS82524T@LQFP64 [ (PEP
+S616) ]	
GMS82524T@MQFP64 [ (PEP+S618) ]	GMS82524T@SDIP64 [ (PEP
+S600A) ]	
GMS84512T@SDIP52 [ (PEP+S600A) ]	GMS84524T@SDIP52 [ (PEP
+S600A) ]	
GMS87C1102	GMS87C1102@SOP16
[ (SA404) ]	
GMS87C1202	GMS87C1202@SOP20
[ (SA404) ]	
GMS87C1404	GMS87C1404@SDIP28
[ (SA022A) ]	
GMS87C1408	GMS87C1408@SDIP28
[ (SA022A) ]	
GMS87C2020@LQFP64 [ (PEP+S616) ]	GMS87C2020@MQFP64 [ (PEP
+S618) ]	
GMS87C2020@SDIP64 [ (PEP+S600A) ]	GMS87C5032
(dip28)	
GMS87C5032(dip40)	GMS87C5032@PLCC44
[ (SA244) ]	
GMS87C5032@SOIC28 [ (SA404) ]	GMS87C5032@TQFP44
[ (SA245A) ]	
GMS87C5108@PQFP80 [ (PEP+S611A) ]	GMS87C7008@LQFP64 [ (PEP
+S616) ]	
GMS87C7008@MQFP64 [ (PEP+S618) ]	GMS87C7008@SDIP64 [ (PEP
+S600A) ]	
GMS87C7016@LQFP64 [ (PEP+S616) ]	GMS87C7016@MQFP64 [ (PEP
+S618) ]	

GMS87C7016@SDIP64 [ ( PEP+S600A ) ]	
GMS97C1051	
GMS97C1051@SOIC20 [ ( SA404 ) ]	
GMS97C2051	
GMS97C2051@SOIC20 [ ( SA404 ) ]	
GMS97C51	
GMS97C51@PLCC44 [ ( SA244 ) ]	GMS97C51@TQFP44
[ ( SA245A ) ]	
GMS97C52	GMS97C52@PLCC44
[ ( SA244 ) ]	
GMS97C52@TQFP44 [ ( SA245A ) ]	
GMS97C54	
GMS97C54@PLCC44 [ ( SA244 ) ]	GMS97C54@TQFP44
[ ( SA245A ) ]	
GMS97C56	GMS97C56@PLCC44
[ ( SA244 ) ]	
GMS97C56@TQFP44 [ ( SA245A ) ]	
GMS97C58	
GMS97C58@PLCC44 [ ( SA244 ) ]	GMS97C58@TQFP44
[ ( SA245A ) ]	
GMS97L1051	GMS97L1051@SOIC20
[ ( SA404 ) ]	
GMS97L2051	GMS97L2051@SOIC20
[ ( SA404 ) ]	
GMS97L51	GMS97L51@PLCC44
[ ( SA244 ) ]	
GMS97L51@TQFP44 [ ( SA245A ) ]	
GMS97L52	
GMS97L52@PLCC44 [ ( SA244 ) ]	GMS97L52@TQFP44
[ ( SA245A ) ]	
GMS97L54	GMS97L54@PLCC44
[ ( SA244 ) ]	
GMS97L54@TQFP44 [ ( SA245A ) ]	
GMS97L56	
GMS97L56@PLCC44 [ ( SA244 ) ]	GMS97L56@TQFP44
[ ( SA245A ) ]	
GMS97L58	GMS97L58@PLCC44
[ ( SA244 ) ]	
GMS97L58@TQFP44 [ ( SA245A ) ]	
GMS99C52	
GMS99C52@PLCC44 [ ( SA244 ) ]	GMS99C52@TQFP44
[ ( SA245A ) ]	
GMS99C58	GMS99C58@PLCC44

[ ( SA244 ) ]

GMS99C58@TQFP44 [ ( SA245A ) ]

**LINKSMART****E ( E ) PROM / FRAM / NVRAM**

L24C02

[ ( SA602A ) ]

L24C02@TSOP8 [ ( SA026 ) ]

L24C04

L24C04@SSOP8 [ ( SA602A ) ]

[ ( SA026 ) ]

L29004C

[ ( SA015A1T ) ]

L29004C@TSOP32 [ ( SA620 ) ]

B005 ]

L29S160F-B@TSOP48 [ ( SA247-B005 ) ]

[ ( SA638 ) ]

L29S400F@TSOP48 [ ( SA247-B005 ) ]

[ ( SA638 ) ]

L29S400F-B@TSOP48 [ ( SA247-B005 ) ]

B005 ]

L29S800F-B@TSOP48 [ ( SA247-B005 ) ]

B005 ]

L29W800E-B@TSOP48 [ ( SA247-B005 ) ]

LST28001

LST28001@PLCC32 [ ( SA015A1T ) ]

[ ( SA620 ) ]

LST28002

[ ( SA015A1T ) ]

LST28002@TSOP32 [ ( SA620 ) ]

LST28004

LST28004@PLCC32 [ ( SA015A1T ) ]

[ ( SA620 ) ]

L24C02@SSOP8

L24C04@TSOP8

L29004C@PLCC32

L29S160F@TSOP48 [ ( SA247-

L29S400F@PSOP44

L29S400F-B@PSOP44

L29S800F@TSOP48 [ ( SA247-

L29W800E@TSOP48 [ ( SA247-

LST28001@TSOP32

LST28002@PLCC32

LST28004@TSOP32

**MACRONIX****E ( E ) PROM / FRAM / NVRAM**

KH25L1005  
HEADER01 ] KH25L1005 (ISP) [ ISP-

KH25L1005@SON8 [(SA683)]  
KH25L1005@SON8 (ISP) [ ISP-HEADER01 ]  
KH25L1005@SOP8 [(SA602A)]  
KH25L1005@SOP8 (ISP) [ ISP-HEADER01 ]

KH25L1005A KH25L1005A@SON8  
[(SA683)]

KH25L1005A@SOP8 [(SA602A)]  
KH25L12805D@SON8 (Fast Mode) [(SA684)]  
KH25L12805D@SOP16 (Fast Mode) [(SA404)]  
KH25L12805N@SOP16 [(SA404)]  
KH25L12805N@SOP16 (Fast Mode) [(SA404)]

KH25L1602@SOP28 [(SA630)] KH25L1605@SON8  
[(SA684)]

KH25L1605@SON8 (Fast Mode) [(SA684)]  
KH25L1605@SOP16 [(SA404)]  
KH25L1605@SOP16 (Fast Mode) [(SA404)]  
KH25L1605A@SON8 [(SA684)]  
KH25L1605A@SON8 (Fast Mode) [(SA684)]  
KH25L1605A@SOP16 [(SA404)]  
KH25L1605A@SOP16 (Fast Mode) [(SA404)]  
KH25L1605A@SOP8 [(SA023A)]  
KH25L1605A@SOP8 (Fast Mode) [(SA023A)]  
KH25L1605D@SON8 [(SA684)]  
KH25L1605D@SON8 (Fast Mode) [(SA683)]  
KH25L1605D@SOP16 [(SA404)]  
KH25L1605D@SOP16 (Fast Mode) [(SA404)]  
KH25L1605D@SOP8 (150) (Fast Mode) [(SA602A)]  
KH25L1605D@SOP8 (200) (Fast Mode) [(SA605B)]

KH25L1636DM1I@SOP8 [(SA602A)] KH25L1636DM2I@SOP8  
[(SA605B)]

KH25L1636DMI@SOP16 [(SA404)] KH25L1636DZNI@WSON8  
[(SA683)]

KH25L2005 KH25L2005 (ISP) [ ISP-

HEADER01 ]

KH25L2005@SON8 [(SA683)]  
KH25L2005@SON8 (ISP) [ ISP-HEADER01 ]  
KH25L2005@SOP8 [(SA602A)]  
KH25L2005@SOP8 (ISP) [ ISP-HEADER01 ]

KH25L2025 KH25L2025@SON8  
[(SA683)]

KH25L2025@SOP8 [(SA602A)] KH25L3202@SOP32

[(SA438T)]  
 KH25L3205@SOP16 [(SA404)]  
 KH25L3205@SOP16(Fast Mode) [(SA404)]  
 KH25L3205@SOP8 [(SA023A)]  
 KH25L3205@SOP8(Fast Mode) [(SA023A)]  
 KH25L3205A@SON8 [(SA684)]  
 KH25L3205A@SON8(Fast Mode) [(SA684)]  
 KH25L3205A@SOP16 [(SA404)]  
 KH25L3205A@SOP16(Fast Mode) [(SA404)]  
 KH25L3205A@SOP8 [(SA023A)]  
 KH25L3205A@SOP8(Fast Mode) [(SA023A)]  
 KH25L3205D@SON8(Fast Mode) [(SA683)]  
 KH25L3205D@SOP16 [(SA404)]  
 KH25L3205D@SOP16(Fast Mode) [(SA404)]  
 KH25L3205D@SOP8 [(SA023A)]  
 KH25L3205D@SOP8(Fast Mode) [(SA605B)]  
 KH25L3236DM2I@SOP8 [(SA605B)]                    KH25L3236DMI@SOP16  
 [(SA404)]  
 KH25L3236DZNI@WSON8 [(SA683)]  
 KH25L4005  
 KH25L4005(150mil)@SOP8 [(SA602A)]  
 KH25L4005(150mil)@SOP8(ISP) [ISP-HEADER01]  
 KH25L4005(209mil)@SOP8 [(SA023A)]  
 KH25L4005(209mil)@SOP8(ISP) [ISP-HEADER01]  
 KH25L4005(ISP) [ISP-HEADER01]                    KH25L4005@SON8  
 [(SA683)]  
 KH25L4005@SON8(ISP) [ISP-HEADER01]  
 KH25L4005A  
 KH25L4005A(150mil)@SOP8 [(SA602A)]  
 KH25L4005A(150mil)@SOP8(ISP) [ISP-HEADER01]  
 KH25L4005A(209mil)@SOP8 [(SA023A)]  
 KH25L4005A(209mil)@SOP8(ISP) [ISP-HEADER01]  
 KH25L4005A(ISP) [ISP-HEADER01]                    KH25L4005A@SON8  
 [(SA683)]  
 KH25L4005A@SON8(ISP) [ISP-HEADER01]  
 KH25L4025A  
 KH25L4025A(150mil)@SOP8 [(SA602A)]  
 KH25L4025A(209mil)@SOP8 [(SA023A)]  
 KH25L4025A@SON8 [(SA683)]                    KH25L512@SON8  
 [(SA683)]  
 KH25L512@SOP8 [(SA602A)]  
 KH25L512A  
 KH25L512A@SON8 [(SA683)]                    KH25L512A@SOP8

[(SA602A)]  
 KH25L6402@SOP32 [(SA438T)] KH25L6402A@SOP28  
 [(SA630)]  
 KH25L6405@SOP16 [(SA404)]  
 KH25L6405@SOP16(Fast Mode) [(SA404)]  
 KH25L6405@SOP8 [(SA023A)]  
 KH25L6405@SOP8(Fast Mode) [(SA023A)]  
 KH25L6405D@SON8(Fast Mode) [(SA684)]  
 KH25L6405D@SOP16 [(SA404)]  
 KH25L6405D@SOP16(Fast Mode) [(SA404)]  
 KH25L6405D@SOP8 [(SA023A)]  
 KH25L8005  
 KH25L8005(150mil)@SOP8 [(SA602A)]  
 KH25L8005(150mil)@SOP8(ISP) [ISP-HEADER01]  
 KH25L8005(209mil)@SOP8 [(SA023A)]  
 KH25L8005(209mil)@SOP8(ISP) [ISP-HEADER01]  
 KH25L8005(ISP) [ISP-HEADER01] KH25L8005@SON8  
 [(SA683)]  
 KH25L8005@SON8(ISP) [ISP-HEADER01]  
 KH25L802@SOP28 [(SA630)]  
 KH25L8025  
 KH25L8025(150mil)@SOP8 [(SA602A)]  
 KH25L8025(209mil)@SOP8 [(SA023A)]  
 KH25L8025@SON8 [(SA683)]  
 KH25L8036D  
 KH25L8036D@SOP16 [(SA404)]  
 KH25L8036D@SOP8[150 mil] [(SA602A)]  
 KH25L8036D@SOP8[200 mil] [(SA023A)]  
 KH25L8036D@WSON8 [(SA683)] KH29LV004CB@PLCC32  
 [(SA015A1T)]  
 KH29LV004CB@TSOP40 [(SA409T)] KH29LV004CT@PLCC32  
 [(SA015A1T)]  
 KH29LV004CT@TSOP40 [(SA409T)] KH29LV008CB@TSOP40  
 [(SA409T)]  
 KH29LV008CT@TSOP40 [(SA409T)]  
 KH29LV040C  
 KH29LV040C@PLCC32 [(SA015A1T)]  
 KH29LV160CBT@TSOP48 [(SA247-B005)]  
 KH29LV160CTT@TSOP48 [(SA247-B005)]  
 KH29LV320CBT@TSOP48 [(SA247-B005)]  
 KH29LV320CTT@TSOP48 [(SA247-B005)]  
 KH29LV320DBT@TSOP48 [(SA247-B005)]  
 KH29LV320DTT@TSOP48 [(SA247-B005)]

KH29LV400CBT@TSOP48 [(SA247-B005)]  
 KH29LV400CTT@TSOP48 [(SA247-B005)]  
 KH29LV640DBT@TSOP48 [(SA247-B005)]  
 KH29LV640DTT@TSOP48 [(SA247-B005)]  
 KH29LV800CBT@TSOP48 [(SA247-B005)]  
 KH29LV800CTT@TSOP48 [(SA247-B005)]  
 MX25L1005 MX25L1005(ISP) [ISP-  
 HEADER01]  
 MX25L1005@SON8 [(SA683)]  
 MX25L1005@SON8(ISP) [ISP-HEADER01]  
 MX25L1005@SOP8 [(SA602A)]  
 MX25L1005@SOP8(ISP) [ISP-HEADER01]  
 MX25L1005A MX25L1005A@SON8  
 [(SA683)]  
 MX25L1005A@SOP8 [(SA602A)]  
 MX25L12805D@SON8(Fast Mode) [(SA684)]  
 MX25L12805D@SOP16(Fast Mode) [(SA404)]  
 MX25L12805N@SOP16 [(SA404)]  
 MX25L12805N@SOP16(Fast Mode) [(SA404)]  
 MX25L1602@SOP28 [(SA630)] MX25L1605@SON8  
 [(SA684)]  
 MX25L1605@SON8(Fast Mode) [(SA684)]  
 MX25L1605@SOP16 [(SA404)]  
 MX25L1605@SOP16(Fast Mode) [(SA404)]  
 MX25L1605A@SON8 [(SA684)]  
 MX25L1605A@SON8(Fast Mode) [(SA684)]  
 MX25L1605A@SOP16 [(SA404)]  
 MX25L1605A@SOP16(Fast Mode) [(SA404)]  
 MX25L1605A@SOP8 [(SA023A)]  
 MX25L1605A@SOP8(Fast Mode) [(SA023A)]  
 MX25L1605D@SON8 [(SA684)]  
 MX25L1605D@SON8(Fast Mode) [(SA683)]  
 MX25L1605D@SOP16 [(SA404)]  
 MX25L1605D@SOP16(Fast Mode) [(SA404)]  
 MX25L1605D@SOP8(150)(Fast Mode) [(SA602A)]  
 MX25L1605D@SOP8(200)(Fast Mode) [(SA605B)]  
 MX25L1635DM1I@SOP8 [(SA602A)] MX25L1635DM2I@SOP8  
 [(SA605B)]  
 MX25L1635DMI@SOP16 [(SA404)] MX25L1635DZNI@WSON8  
 [(SA683)]  
 MX25L1636DM1I@SOP8 [(SA602A)] MX25L1636DM2I@SOP8  
 [(SA605B)]  
 MX25L1636DMI@SOP16 [(SA404)] MX25L1636DZNI@WSON8

[(SA683)]  
 MX25L2005 MX25L2005(ISP) [ISP-  
 HEADER01]  
 MX25L2005@SON8 [(SA683)]  
 MX25L2005@SON8(ISP) [ISP-HEADER01]  
 MX25L2005@SOP8 [(SA602A)]  
 MX25L2005@SOP8(ISP) [ISP-HEADER01]  
 MX25L2025 MX25L2025@SON8  
 [(SA683)]  
 MX25L2025@SOP8 [(SA602A)] MX25L3202@SOP32  
 [(SA438T)]  
 MX25L3205@SOP16 [(SA404)]  
 MX25L3205@SOP16(Fast Mode) [(SA404)]  
 MX25L3205@SOP8 [(SA023A)]  
 MX25L3205@SOP8(Fast Mode) [(SA023A)]  
 MX25L3205A@SON8 [(SA684)]  
 MX25L3205A@SON8(Fast Mode) [(SA684)]  
 MX25L3205A@SOP16 [(SA404)]  
 MX25L3205A@SOP16(Fast Mode) [(SA404)]  
 MX25L3205A@SOP16(Parallel Mode) [(SA404)]  
 MX25L3205A@SOP8 [(SA023A)]  
 MX25L3205A@SOP8(Fast Mode) [(SA023A)]  
 MX25L3205D@SON8(Fast Mode) [(SA683)]  
 MX25L3205D@SOP16 [(SA404)]  
 MX25L3205D@SOP16(Fast Mode) [(SA404)]  
 MX25L3205D@SOP8 [(SA023A)]  
 MX25L3205D@SOP8(Fast Mode) [(SA605B)]  
 MX25L3235DM2I@SOP8 [(SA605B)] MX25L3235DMI@SOP16  
 [(SA404)]  
 MX25L3235DZNI@WSON8 [(SA683)] MX25L3236DM2I@SOP8  
 [(SA605B)]  
 MX25L3236DMI@SOP16 [(SA404)] MX25L3236DZNI@WSON8  
 [(SA683)]  
 MX25L4005  
 MX25L4005(150mil)@SOP8 [(SA602A)]  
 MX25L4005(150mil)@SOP8(ISP) [ISP-HEADER01]  
 MX25L4005(209mil)@SOP8 [(SA023A)]  
 MX25L4005(209mil)@SOP8(ISP) [ISP-HEADER01]  
 MX25L4005(ISP) [ISP-HEADER01] MX25L4005@SON8  
 [(SA683)]  
 MX25L4005@SON8(ISP) [ISP-HEADER01]  
 MX25L4005A  
 MX25L4005A(150mil)@SOP8 [(SA602A)]



MX25L4005A(150mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L4005A(209mil)@SOP8 [(SA023A)]  
MX25L4005A(209mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L4005A(ISP) [ISP-HEADER01] MX25L4005A@SON8  
[(SA683)]  
MX25L4005A@SON8(ISP) [ISP-HEADER01]  
MX25L4025A  
MX25L4025A(150mil)@SOP8 [(SA602A)]  
MX25L4025A(209mil)@SOP8 [(SA023A)]  
MX25L4025A@SON8 [(SA683)] MX25L512@SON8  
[(SA683)]  
MX25L512@SOP8 [(SA602A)]  
MX25L512A  
MX25L512A@SON8 [(SA683)] MX25L512A@SOP8  
[(SA602A)]  
MX25L6402@SOP32 [(SA438T)] MX25L6402A@SOP28  
[(SA630)]  
MX25L6405@SOP16 [(SA404)]  
MX25L6405@SOP16(Fast Mode) [(SA404)]  
MX25L6405@SOP8 [(SA023A)]  
MX25L6405@SOP8(Fast Mode) [(SA023A)]  
MX25L6405D@SON8(Fast Mode) [(SA684)]  
MX25L6405D@SOP16 [(SA404)]  
MX25L6405D@SOP16(Fast Mode) [(SA404)]  
MX25L6405D@SOP8 [(SA023A)]  
MX25L8005  
MX25L8005(150mil)@SOP8 [(SA602A)]  
MX25L8005(150mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L8005(209mil)@SOP8 [(SA023A)]  
MX25L8005(209mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L8005(ISP) [ISP-HEADER01] MX25L8005@SON8  
[(SA683)]  
MX25L8005@SON8(ISP) [ISP-HEADER01]  
MX25L802@SOP28 [(SA630)]  
MX25L8025  
MX25L8025(150mil)@SOP8 [(SA602A)]  
MX25L8025(209mil)@SOP8 [(SA023A)]  
MX25L8025@SON8 [(SA683)]  
MX25L8036D  
MX25L8036D@SOP16 [(SA602A)]  
MX25L8036D@SOP8[150 mil] [(SA602A)]  
MX25L8036D@SOP8[200 mil] [(SA023A)]  
MX25L8036D@WSON8 [(SA683)]

MX26C1000B  
 MX26C1000B@PLCC32 [(SA015A1T)]                      MX26C1000B@SOIC32  
 [(SA603)]  
 MX26C1000B@TSOP32 [(SA410T)]  
 MX26C2000B  
 MX26C2000B@PLCC32 [(SA015A1T)]                      MX26C2000B@SOIC32  
 [(SA603)]  
 MX26C2000B@TSOP32 [(SA410T)]  
 MX26C512A  
 MX26C512A@PLCC32 [(SA015A1T)]                      MX26C512A@SOIC28  
 [(SA630)]  
 MX26C512A@TSOP28 [(SA430T)]  
 MX26F128J3TC@TSOP56 [(SA628-B018)]  
 MX26F128J3XC@CSP64 [(SA655A-B054A-T064F001)]  
 MX26F640J3TC@TSOP56 [(SA628-B018)]  
 MX26F640J3XC@CSP64 [(SA655A-B054A-T064F001)]  
 MX26L12711MC@PSOP44 [(SA638)]                      MX26L12811MC@PSOP44  
 [(SA638)]  
 MX26L6419T@TSOP48 [(SA247-B005)]                      MX26L6420@PSOP44  
 [(SA638)]  
 MX26L6420@TSOP48 [(SA247-B005)]                      MX26LV004B@PLCC32  
 [(SA015A1T)]  
 MX26LV004B@TSOP40 [(SA409T)]                      MX26LV004T@PLCC32  
 [(SA015A1T)]  
 MX26LV004T@TSOP40 [(SA409T)]                      MX26LV008B@TSOP40  
 [(SA409T)]  
 MX26LV008T@TSOP40 [(SA409T)]  
 MX26LV040(QC)@PLCC32 [(SA015A1T)]  
 MX26LV040(TC)@TSOP32 [(SA410T)]  
 MX26LV160BT@TSOP48 [(SA247-B005)]  
 MX26LV160BX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
 MX26LV160BX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
 MX26LV160TT@TSOP48 [(SA247-B005)]  
 MX26LV160TX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
 MX26LV160TX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
 MX26LV400BT@TSOP48 [(SA247-B005)]  
 MX26LV400BX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
 MX26LV400BX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
 MX26LV400TT@TSOP48 [(SA247-B005)]  
 MX26LV400TX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
 MX26LV400TX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
 MX26LV800BM@PSOP44 [(SA638)]  
 MX26LV800BT@TSOP48 [(SA247-B005)]

MX26LV800BX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]	
MX26LV800BX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]	
MX26LV800TM@PSOP44 [(SA638)]	
MX26LV800TT@TSOP48 [(SA247-B005)]	
MX26LV800TX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]	
MX26LV800TX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]	
MX27C1000	MX27C1000@PLCC32
[(SA015A1T)]	
MX27C1000@SOIC32 [(SA603)]	MX27C1000@TSOP32
[(SA410T)]	
MX27C1000A	MX27C1000A@PLCC32
[(SA015A1T)]	
MX27C1000A@SOIC32 [(SA603)]	MX27C1000A@TSOP32
[(SA410T)]	
MX27C1001	MX27C1001@PLCC32
[(SA015A1T)]	
MX27C1001@SOIC32 [(SA603)]	MX27C1001@TSOP32
[(SA410T)]	
MX27C1024	MX27C1024@PLCC44
[(SA244)]	
MX27C1024@TSOP40 [(SA409T)]	
MX27C1024A	
MX27C1024A@PLCC44 [(SA244)]	MX27C1024A@TSOP40
[(SA409T)]	
MX27C1024B	MX27C1024B@PLCC44
[(SA244)]	
MX27C1024B@TSOP40 [(SA409T)]	
MX27C1100	
MX27C2000	MX27C2000@PLCC32
[(SA015A1T)]	
MX27C2000@SOIC32 [(SA603)]	MX27C2000@TSOP32
[(SA410T)]	
MX27C2000A	MX27C2000A@PLCC32
[(SA015A1T)]	
MX27C2000A@SOIC32 [(SA603)]	MX27C2000A@TSOP32
[(SA410T)]	
MX27C2048	MX27C2048@PLCC44
[(SA244)]	
MX27C2048@TSOP40 [(SA409T)]	
MX27C2100	
MX27C256	MX27C256@PLCC32
[(SA015A1T)]	
MX27C4000	MX27C4000@PLCC32

[ (SA015A1T) ]	
MX27C4000@SOIC32 [ (SA603) ]	MX27C4000@TSOP32
[ (SA410T) ]	
MX27C4000A	MX27C4000A@PLCC32
[ (SA015A1T) ]	
MX27C4000A@SOIC32 [ (SA603) ]	MX27C4000A@TSOP32
[ (SA410T) ]	
MX27C4096	MX27C4096@PLCC44
[ (SA244) ]	
MX27C4100	
MX27C4111	
MX27C512	MX27C512@PLCC32
[ (SA015A1T) ]	
MX27C516	MX27C516@PLCC44
[ (SA244) ]	
MX27C516@TSOP40 [ (SA409T) ]	
MX27C8000	
MX27C8000@PLCC32 [ (SA015A1T) ]	MX27C8000@SOIC32
[ (SA603) ]	
MX27C8000@TSOP32 [ (SA410T) ]	
MX27C8000A	
MX27C8000A@PLCC32 [ (SA015A1T) ]	MX27C8000A@SOIC32
[ (SA603) ]	
MX27C8000A@TSOP32 [ (SA410T) ]	
MX27C8100	
MX27C8100@PSOP44 [ (SA638) ]	
MX27C8111	
MX27C8111@PSOP44 [ (SA638) ]	
MX27L1000	
MX27L1000@PLCC32 [ (SA015A1T) ]	MX27L1000@TSOP32
[ (SA410T) ]	
MX27L2000	MX27L2000@PLCC32
[ (SA015A1T) ]	
MX27L2000@TSOP32 [ (SA410T) ]	
MX27L256	
MX27L256@PLCC32 [ (SA015A1T) ]	MX27L256@TSOP32
[ (SA430T) ]	
MX27L4000	MX27L4000@PLCC32
[ (SA015A1T) ]	
MX27L4000@TSOP32 [ (SA410T) ]	
MX27L4096	
MX27L4096@PLCC44 [ (SA244) ]	
MX27L512	

MX27L512@PLCC32 [(SA015A1T)]	MX27L512@TSOP28
[(SA430T)]	
MX28F002B@TSOP40 [(SA409T)]	MX28F002T@TSOP40
[(SA409T)]	
MX28F1000	MX28F1000@PLCC32
[(SA015A1T)]	
MX28F1000@SOP32 [(SA603)]	MX28F1000@TSOP32
[(SA410T)]	
MX28F1000P	MX28F1000P@PLCC32
[(SA015A1T)]	
MX28F1000P@TSOP32 [(SA410T)]	
MX28F160C3BT@TSOP48 [(SA247-B005)]	
MX28F160C3BX@uBGA48 [(SA634A-B005A-Y048F001)]	
MX28F160C3TT@TSOP48 [(SA247-B005)]	
MX28F160C3TX@uBGA48 [(SA634A-B005A-Y048F001)]	
MX28F2000	MX28F2000@PLCC32
[(SA015A1T)]	
MX28F2000@TSOP32 [(SA410T)]	
MX28F2000P	
MX28F2000P@PLCC32 [(SA015A1T)]	MX28F2000P@TSOP32
[(SA410T)]	
MX28F2100B@PSOP44 [(SA638)]	MX28F2100B@TSOP48 [(SA247-B005)]
MX28F2100T@PSOP44 [(SA638)]	MX28F2100T@TSOP48 [(SA247-B005)]
MX28F4000	MX28F4000@PLCC32
[(SA015A1T)]	
MX28F4000@TSOP32 [(SA410T)]	
MX28F640C3BT@TSOP48 [(SA247-B005)]	
MX28F640C3BX@uBGA48 [(SA634A-B005A-Y048F001)]	
MX28F640C3TT@TSOP48 [(SA247-B005)]	
MX28F640C3TX@uBGA48 [(SA634A-B005A-Y048F001)]	
MX29F001B	MX29F001B@PLCC32
[(SA015A1T)]	
MX29F001B@TSOP32 [(SA410T)]	
MX29F001T	
MX29F001T@PLCC32 [(SA015A1T)]	MX29F001T@TSOP32
[(SA410T)]	
MX29F002B	MX29F002B@PLCC32
[(SA015A1T)]	
MX29F002B@TSOP32 [(SA410T)]	
MX29F002NB	
MX29F002NB@PLCC32 [(SA015A1T)]	MX29F002NB@TSOP32

[ (SA410T) ]	
MX29F002NT	MX29F002NT@PLCC32
[ (SA015A1T) ]	
MX29F002NT@TSOP32 [ (SA410T) ]	
MX29F002T	
MX29F002T@PLCC32 [ (SA015A1T) ]	MX29F002T@TSOP32
[ (SA410T) ]	
MX29F004B	MX29F004B@PLCC32
[ (SA015A1T) ]	
MX29F004B@TSOP32 [ (SA410T) ]	
MX29F004T	
MX29F004T@PLCC32 [ (SA015A1T) ]	MX29F004T@TSOP32
[ (SA410T) ]	
MX29F016@PSOP44 [ (SA638) ]	MX29F016@TSOP40
[ (SA409T) ]	
MX29F016@TSOP48 [ (SA247-B005) ]	
MX29F022B	
MX29F022B@PLCC32 [ (SA015A1T) ]	MX29F022B@TSOP32
[ (SA410T) ]	
MX29F022NB	MX29F022NB@PLCC32
[ (SA015A1T) ]	
MX29F022NB@TSOP32 [ (SA410T) ]	
MX29F022NT	
MX29F022NT@PLCC32 [ (SA015A1T) ]	MX29F022NT@TSOP32
[ (SA410T) ]	
MX29F022T	MX29F022T@PLCC32
[ (SA015A1T) ]	
MX29F022T@TSOP32 [ (SA410T) ]	
MX29F040	
MX29F040@PLCC32 [ (SA015A1T) ]	MX29F040@TSOP32
[ (SA410T) ]	
MX29F040C	MX29F040C@PLCC32
[ (SA015A1T) ]	
MX29F040C@TSOP32 [ (SA410T) ]	MX29F080@PSOP44
[ (SA638) ]	
MX29F080@TSOP40 [ (SA409T) ]	MX29F100B@PSOP44 [ (SA638-B006) ]
B006) ]	
MX29F100B@TSOP48 [ (SA247-B005) ]	MX29F100T@PSOP44 [ (SA638-B006) ]
B006) ]	
MX29F100T@TSOP48 [ (SA247-B005) ]	MX29F1610@PSOP44
[ (SA638) ]	
MX29F1610@TSOP48 [ (SA247-B005) ]	MX29F1610A@PSOP44
[ (SA638) ]	

MX29F1610A@TSOP48 [(SA247-B005)]      MX29F1610B@TSOP48 [(SA247-B005)]  
MX29F1611@PSOP44 [(SA638)]  
MX29F1615  
MX29F200B@PSOP44 [(SA638-B006)]      MX29F200B@TSOP48 [(SA247-B005)]  
MX29F200CB@PSOP44 [(SA638)]      MX29F200CB@TSOP48 [(SA247-B005)]  
MX29F200CT@PSOP44 [(SA638)]      MX29F200CT@TSOP48 [(SA247-B005)]  
MX29F200T@PSOP44 [(SA638-B006)]      MX29F200T@TSOP48 [(SA247-B005)]  
MX29F4000      MX29F400B@PSOP44 [(SA638-B006)]  
MX29F400B@TSOP48 [(SA247-B005)]      MX29F400CB@PSOP44  
[(SA638)]  
MX29F400CB@TSOP48 [(SA247-B005)]      MX29F400CT@PSOP44  
[(SA638)]  
MX29F400CT@TSOP48 [(SA247-B005)]      MX29F400T@PSOP44 [(SA638-B006)]  
MX29F400T@TSOP48 [(SA247-B005)]      MX29F800B@PSOP44 [(SA638-B006)]  
MX29F800B@TSOP48 [(SA247-B005)]      MX29F800T@PSOP44 [(SA638-B006)]  
MX29F800T@TSOP48 [(SA247-B005)]      MX29L1611@PSOP44  
[(SA638)]  
MX29L1611@TSOP48 [(SA247-B005)]  
MX29L1611G  
MX29L3211@PSOP44 [(SA638)]      MX29L3211@TSOP48 [(SA247-B005)]  
MX29LA128MB@TSOP56 [(SA628-B102)]  
MX29LA128MT@TSOP56 [(SA628-B102)]  
MX29LA129MH@TSOP56 [(SA628-B018)]  
MX29LA129ML@TSOP56 [(SA628-B018)]  
MX29LA320MB@CFBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LA320MB@TSOP48 [(SA247-B005)]  
MX29LA320MT@CFBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LA320MT@TSOP48 [(SA247-B005)]  
MX29LA321MB@FBGA64 [(SA655A-B054A-T064F001Y)]  
MX29LA321MB@TSOP56 [(SA628-B018)]  
MX29LA321MH@FBGA64 [(SA655A-B054A-T064F001Y)]  
MX29LA321MH@TSOP56 [(SA628-B018)]  
MX29LA321ML@FBGA64 [(SA655A-B054A-T064F001Y)]

MX29LA321ML@TSOP56 [ (SA628-B018) ]	
MX29LA321MT@FBGA64 [ (SA655A-B054A-T064F001Y) ]	
MX29LA321MT@TSOP56 [ (SA628-B018) ]	
MX29LV002CB@PLCC32 [ (SA015A1T) ]	MX29LV002CB@TSOP32
[ (SA410T) ]	
MX29LV002CT@PLCC32 [ (SA015A1T) ]	MX29LV002CT@TSOP32
[ (SA410T) ]	
MX29LV002NCB@PLCC32 [ (SA015A1T) ]	MX29LV002NCB@TSOP32
[ (SA410T) ]	
MX29LV002NCT@PLCC32 [ (SA015A1T) ]	MX29LV002NCT@TSOP32
[ (SA410T) ]	
MX29LV004B@PLCC32 [ (SA015A1T) ]	MX29LV004B@TSOP40
[ (SA409T) ]	
MX29LV004CB@PLCC32 [ (SA015A1T) ]	MX29LV004CB@TSOP40
[ (SA409T) ]	
MX29LV004CT@PLCC32 [ (SA015A1T) ]	MX29LV004CT@TSOP40
[ (SA409T) ]	
MX29LV004T@PLCC32 [ (SA015A1T) ]	MX29LV004T@TSOP40
[ (SA409T) ]	
MX29LV008B@TSOP40 [ (SA409T) ]	MX29LV008BB@TSOP40
[ (SA409T) ]	
MX29LV008BT@TSOP40 [ (SA409T) ]	MX29LV008CB@TSOP40
[ (SA409T) ]	
MX29LV008CT@TSOP40 [ (SA409T) ]	MX29LV008T@TSOP40
[ (SA409T) ]	
MX29LV017AT@TSOP40 [ (SA409T) ]	
MX29LV017AX@CSP48 [ (SA642G-B026A-T048F001) ]	
MX29LV017BT@TSOP40 [ (SA409T) ]	
MX29LV017BX@CSP48 [ (SA642G-B026A-T048F001) ]	
MX29LV033T@TSOP40 [ (SA409T) ]	MX29LV040@PLCC32
[ (SA015A1T) ]	
MX29LV040@TSOP32 [ (SA410T) ]	MX29LV040C@PLCC32
[ (SA015A1T) ]	
MX29LV040C@TSOP32 [ (SA410T) ]	
MX29LV065BT@TSOP48 [ (SA247-B005) ]	
MX29LV065BXB@FBGA63 [ (SA642M-B026A-W048F001) ]	
MX29LV065M@TSOP48 [ (SA247-B005) ]	MX29LV081@TSOP40
[ (SA409T) ]	
MX29LV128DB@TSOP48 [ (SA247-B005) ]	
MX29LV128DB@TSOP56 [ (SA628-B102) ]	
MX29LV128DT@TSOP48 [ (SA247-B005) ]	
MX29LV128DT@TSOP56 [ (SA628-B102) ]	
MX29LV128MB@TSOP56 [ (SA628-B102) ]	



MX29LV128MH@TSOP56 [(SA628-B102)]  
MX29LV128ML@TSOP56 [(SA628-B102)]  
MX29LV128MT@TSOP56 [(SA628-B102)]  
MX29LV160AB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160AB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160AB@PSOP44 [(SA638)]  
MX29LV160AB@TSOP48 [(SA247-B005)]  
MX29LV160AT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160AT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160AT@PSOP44 [(SA638)]  
MX29LV160AT@TSOP48 [(SA247-B005)]  
MX29LV160B(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160B(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160B@PSOP44 [(SA638)]                   MX29LV160B@TSOP48 [(SA247-B005)]  
MX29LV160BB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BB@PSOP44 [(SA638)]  
MX29LV160BB@TSOP48 [(SA247-B005)]  
MX29LV160BT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BT@PSOP44 [(SA638)]  
MX29LV160BT@TSOP48 [(SA247-B005)]  
MX29LV160CBM@PSOP44 [(SA638)]  
MX29LV160CBT@TSOP48 [(SA247-B005)]  
MX29LV160CBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160CBXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160CTM@PSOP44 [(SA638)]  
MX29LV160CTT@TSOP48 [(SA247-B005)]  
MX29LV160CTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160DBT@TSOP48 [(SA247-B005)]  
MX29LV160DBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160DTT@TSOP48 [(SA247-B005)]  
MX29LV160DTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160T(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160T(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160T@PSOP44 [(SA638)]                   MX29LV160T@TSOP48 [(SA247-B005)]  
MX29LV320ABT@TSOP48 [(SA247-B005)]  
MX29LV320ABXB@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320ABXE@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320ATT@TSOP48 [(SA247-B005)]

MX29LV320ATXB@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV320ATXE@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV320BT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320BXB@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV320BXE@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV320CBB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320CBE@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320CBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320CTB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320CTE@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320CTT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320DBB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320DBE@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320DBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320DTB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320DTE@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320DTT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320MB@CFBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320MB@PSOP44 [ ( SA638 ) ]  
MX29LV320MB@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320MH@TSOP56 [ ( SA628-B067 ) ]  
MX29LV320ML@TSOP56 [ ( SA628-B067 ) ]  
MX29LV320MT@CFBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320MT@PSOP44 [ ( SA638 ) ]  
MX29LV320MT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320TT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320TXB@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV320TXE@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV321DBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV321DBXB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV321DTT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV321DTXB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV400B@PSOP44 [ ( SA638 ) ]                      MX29LV400B@TSOP48 [ ( SA247-B005 ) ]  
MX29LV400BX(0.3)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV400BX(0.4)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV400CBM@PSOP44 [ ( SA638 ) ]  
MX29LV400CBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV400CBXB(0.3)@CSP48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV400CBXE(0.4)@CSP48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV400CTM@PSOP44 [ ( SA638 ) ]  
MX29LV400CTT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV400CTXB(0.3)@CSP48 [ ( SA642G-B026A-T048F001Y ) ]

MX29LV400CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV400T@PSOP44 [(SA638)] MX29LV400T@TSOP48 [(SA247-B005)]  
MX29LV400TX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV400TX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV640BBT@TSOP48 [(SA247-B005)]  
MX29LV640BBXB@FBGA63 [(SA642M-B026A-W048F001Y)]  
MX29LV640BT@TSOP48 [(SA247-B005)]  
MX29LV640BTT@TSOP48 [(SA247-B005)]  
MX29LV640BTXB@FBGA63 [(SA642M-B026A-W048F001Y)]  
MX29LV640BUT@TSOP48 [(SA247-B005)]  
MX29LV640BUXB@FBGA63 [(SA642M-B026A-W048F001)]  
MX29LV640BXB@FBGA63 [(SA642C-B026A-Y056F001)]  
MX29LV640BXC@FBGA64 [(SA655A-B044A-T064F001)]  
MX29LV640DBT@TSOP48 [(SA247-B005)]  
MX29LV640DBX@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV640DTT@TSOP48 [(SA247-B005)]  
MX29LV640DTX@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV640MB@FBGA63 [(SA642M-B026A-W048F001Y)]  
MX29LV640MB@TSOP48 [(SA247-B005)]  
MX29LV640MH@FBGA64 [(SA655F-B099A-W064F001Y)]  
MX29LV640MH@TSOP56 [(SA628-B067)]  
MX29LV640ML@FBGA64 [(SA655F-B099A-W064F001Y)]  
MX29LV640ML@TSOP56 [(SA628-B067)]  
MX29LV640MT@FBGA63 [(SA642M-B026A-W048F001Y)]  
MX29LV640MT@TSOP48 [(SA247-B005)]  
MX29LV640TT@TSOP48 [(SA247-B005)]  
MX29LV640TXB@FBGA63 [(SA642C-B026A-Y056F001)]  
MX29LV640TXC@FBGA64 [(SA655A-B044A-T064F001)]  
MX29LV641MH@TSOP48 [(SA247-B005)]  
MX29LV641ML@TSOP48 [(SA247-B005)]  
MX29LV800AB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800AB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800AB@PSOP44 [(SA638)]  
MX29LV800AB@TSOP48 [(SA247-B005)]  
MX29LV800AT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800AT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800AT@PSOP44 [(SA638)]  
MX29LV800AT@TSOP48 [(SA247-B005)]  
MX29LV800B(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800B(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800B@PSOP44 [(SA638)] MX29LV800B@TSOP48 [(SA247-B005)]

MX29LV800CBM@PSOP44 [(SA638)]  
MX29LV800CBT(Low)@TSOP48 [(SA247-B005)]  
MX29LV800CBT@TSOP48 [(SA247-B005)]  
MX29LV800CBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800CBXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800CTM@PSOP44 [(SA638)]  
MX29LV800CTT(Low)@TSOP48 [(SA247-B005)]  
MX29LV800CTT@TSOP48 [(SA247-B005)]  
MX29LV800CTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800T(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800T(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800T@PSOP44 [(SA638)]                      MX29LV800T@TSOP48 [(SA247-B005)]  
MX29LW160BT@TSOP48 [(SA247-B005)]  
MX29LW160BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW160BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW160TT@TSOP48 [(SA247-B005)]  
MX29LW160TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW160TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW161BT@TSOP48 [(SA247-B005)]  
MX29LW161BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW161BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW161TT@TSOP48 [(SA247-B005)]  
MX29LW161TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW161TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW320BT@TSOP48 [(SA247-B005)]  
MX29LW320BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW320BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW320TT@TSOP48 [(SA247-B005)]  
MX29LW320TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW320TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW321BT@TSOP48 [(SA247-B005)]  
MX29LW321BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW321BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW321TT@TSOP48 [(SA247-B005)]  
MX29LW321TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW321TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29SL800CB@TSOP48 [(SA247-B005)]  
MX29SL800CBXB(0.30)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29SL800CBXE(0.40)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29SL800CBXH(0.30)@CSP48 [(SA716A-B119B-M048F001Y)]  
MX29SL800CT@TSOP48 [(SA247-B005)]

MX29SL800CTXB(0.30)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29SL800CTXE(0.40)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29SL800CTXH(0.30)@CSP48 [(SA716A-B119B-M048F001Y)]  
 MX69F1602C3BX@FBGA72 [(SA642E-B041A-T072F001)]  
 MX69F1602C3TX@FBGA72 [(SA642E-B041A-T072F001)]  
 MX69F1604C3BX@FBGA72 [(SA642E-B041A-T072F001)]  
 MX69F1604C3TX@FBGA72 [(SA642E-B041A-T072F001)]  
 MX69LW162BxB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW162TXB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW164BxB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW164TXB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW322BxB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW322TXB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW324BxB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW324TXB@CSP69 [(SA642A-B032A-Y096F001)]

## MICROCONTROLLER

MX10E8050I  
 [(SA244)]  
 MX10E8050I@TQFP44 [(SA245A)]  
 [(SA244)]  
 MX10EXA@TQFP44 [(SA245A)]  
 MX10F201FC@TQFP100(\*) [(TA010-B006)]  
 MX10F202FC@TQFP100(\*) [(TA010-B006)]  
 MX10FLCD  
 MX10FMAXD  
 MX10FMAXD@PLCC44 [(SA244)]  
 [(SA245A)]  
 MX10E8050I@PLCC44  
 MX10EXA@PLCC44  
 MX10FMAXD@TQFP44

## MAGNACHIP

### MICROCONTROLLER

GMS34004TK  
 GMS34004TM  
 GMS34004TW  
 GMS34112TK  
 GMS34112TK@SOIC20 [(SA404)]  
 [(SA626A)]  
 GMS34140TK  
 GMS34112TK@SSOP20  
 GMS34140TK@SOIC24

[ (SA404) ]	
GMS77C1000	GMS77C1000@SOIC20
[ (SA404) ]	
GMS77C1001	GMS77C1001@SOIC20
[ (SA404) ]	
GMS81604T	GMS81604T@PLCC44
[ (SA244) ]	
GMS81604T@SDIP42 [ (SA028) ]	
GMS81608T	
GMS81608T@PLCC44 [ (SA244) ]	GMS81608T@SDIP42
[ (SA028) ]	
GMS87C1102	GMS87C1102@SOP16
[ (SA404) ]	
GMS87C1202	GMS87C1202@SOP20
[ (SA404) ]	
GMS87C1404	GMS87C1404@SDIP28
[ (SA022A) ]	
GMS87C1408	GMS87C1408@SDIP28
[ (SA022A) ]	
GMS87C2020@LQFP64 [ (PEP+S616) ]	GMS87C2020@MQFP64 [ (PEP
+S618) ]	
GMS87C2020@SDIP64 [ (PEP+S600A) ]	GMS87C5108@PQFP80 [ (PEP
+S611A) ]	
GMS87C7008@LQFP64 [ (PEP+S616) ]	GMS87C7008@MQFP64 [ (PEP
+S618) ]	
GMS87C7008@SDIP64 [ (PEP+S600A) ]	GMS87C7016@LQFP64 [ (PEP
+S616) ]	
GMS87C7016@MQFP64 [ (PEP+S618) ]	GMS87C7016@SDIP64 [ (PEP
+S600A) ]	
HMS87C1404B	HMS87C1404B@SDIP28
[ (SA022A) ]	
HMS87C1404B@SOIC28 [ (SA404) ]	
HMS87C1408B	
HMS87C1408B@SDIP28 [ (SA022A) ]	HMS87C1408B@SOIC28
[ (SA404) ]	
HMS87C1416B	HMS87C1416B@SDIP28
[ (SA022A) ]	
HMS87C1416B@SOIC28 [ (SA404) ]	
HMS87C1508B	
HMS87C1516B	
HMS87C1608B	
HMS87C1616B	HMS87C1708B@SDIP42
[ (SA028) ]	

HMS87C1716B@SDIP42 [(SA028)]	HMS87C1808B@TQFP44
[(SA245A)]	
HMS87C1816B@TQFP44 [(SA245A)]	
MC80F0504	
MC80F0504@SOP16 [(SA715)]	MC80F0504@SSOP16
[(SA626A)]	
MC80F0504[153mil]@SOP16 [(SA602)]	
MC80F0604	MC80F0604@SOP20
[(SA715)]	
MC80F0604@SSOP20 [(SA626A)]	
MC80F0704	
MC80F0704@QFN28 [(SA697)]	MC80F0704@SOP28
[(SA715)]	
MC80F0708	MC80F0708@QFN28
[(SA697)]	
MC80F0708@SOP28 [(SA715)]	MC80F0804@SDIP32
[(SA653)]	
MC80F0804@SOP32 [(SA715)]	MC80F0808@SDIP32
[(SA653)]	
MC80F0808@SOP32 [(SA715)]	

## MAXIM

### [E \(E\) PROM / FRAM / NVRAM](#)

DS1220AB  
DS1220AD  
DS1220Y  
DS1225AB  
DS1225AD  
DS1225D  
DS1225E  
DS1225Y  
DS1230AB  
DS1230W  
DS1230Y  
DS1235AB  
DS1235Y  
DS1243Y  
DS1244  
DS1244Y  
DS1245AB

DS1245EE

DS1245P

DS1245W

DS1245Y

DS1248P

DS1248W

DS1248Y

DS1249AB

DS1249W

DS1249Y

DS1250AB

DS1250W

DS1250Y

DS1251AB

DS1251W

DS1251Y

DS1256P

DS1256W

DS1256Y

DS1265AB

DS1265W

DS1265Y

DS1270AB

DS1270W

DS1270Y

DS1284

DS1284N

DS1284Q@PLCC28 [(SA008A)]

DS1284QN@PLCC28

[(SA008A)]

DS1286

DS1286I

DS1287

DS1287A

DS12887

DS12887A

DS12C887

DS12C887A

DS1386(32K)

DS1386

(8K)

DS1485

DS1485@SOIC28

[(SA630)]

DS1488

DS1553



DS1553W  
DS1554  
DS1554W  
DS1556  
DS1642  
DS1643  
DS1644  
DS1644P [ordering number is marked above]  
DS1644PS [(PEP+S414T)]  
DS1645AB  
DS1645EE  
DS1645Y  
DS1646  
DS1647  
DS1647LPM  
DS1650AB  
DS1650Y DS1687-  
3  
DS1687-5 DS17287-  
3  
DS17287-5  
DS1742  
DS1742W  
DS1743  
DS1743P  
DS1743W  
DS1743WP  
DS1744  
DS1744P  
DS1744W  
DS1744WP  
DS1746  
DS1747  
DS1747P [ordering number is marked above]  
DS1747PS [(PEP+S414T)]  
DS1747W  
DS1747WP [ordering number is marked above]  
DS1747WPS [(PEP+S414T)] DS17487-  
3  
DS17487-5 DS17887-  
3  
DS17887-5 DS2430A@TO-  
92

DS2430AP@TSOC6 [(SA602A)]

92

DS2431P@TSOC6 [(SA602A)]

[(SA602A)]

DS2433@PR-35

[(SA602A)]

DS2433S(5.5)@SOIC8 [(SA605A)]

DS2502

DS2502P@TSOC6 [(SA602A)]

[(SA602A)]

DS2502UNW

[(SA602A)]

DS2502UNW@TSOC6 [(SA602A)]

DS2506

DS2506S@SOIC8 [(SA023A)]

DS4510@uSOP10

DS4520@TSSOP16 [(SA026)]

[(SA026)]

DS2431@TO-

DS2432P@TSOC6

DS2433S(3.9)@SOIC8

DS2502S@SOIC8

DS2502UNW@SOIC8

DS4550@TSSOP20

**MICROCONTROLLER**

DS87C520

[(SA244)]

DS87C520@TQFP44 [(SA245A)]

+S415T)]

DS87C550@PLCC68 [(PEP+S414T)]

A)

DS89C420(rev.A)@PLCC44 [(SA244)]

DS89C420(rev.A)@TQFP44 [(SA245A)]

MAX7652CCB@TQFP64 [(PEP+S616)]

+S616)]

DS87C520@PLCC44

DS87C530@PLCC52 [(PEP

DS89C420(rev.

MAX7652ECB@TQFP64 [(PEP

**MAXWELL****E(E) PROM/FRAM/NVRAM**

27C010T@LDFP32 [(SA438T)]

28C010

28C010@PLCC32 [(SA015A1T)]

[(SA438T)]

28C010T

28C010@TSOP32

28C010T@PLCC32

[ (SA015A1T) ]  
28C010T@TSOP32 [ (SA438T) ]  
28C011  
28C011@PLCC32 [ (SA015A1T) ] 28C011@TSOP32  
[ (SA438T) ]  
28C011T 28C011T@PLCC32  
[ (SA015A1T) ]  
28C011T@TSOP32 [ (SA438T) ]

## MEGAWIN

### E ( E ) PROM / FRAM / NVRAM

MM25SB512@SOIC8 [ (SA602A) ]  
MM29F040  
MM29F040@PLCC32 [ (SA015A1T) ] MM29F040@TSOP32  
[ (SA410T) ]  
MM29LF040 MM29LF040@PLCC32  
[ (SA015A1T) ]  
MM29LF040@TSOP32 [ (SA410T) ]

### MICROCONTROLLER

MPC89L516X2 MPC89L516X2@PLCC44  
[ (SA244) ]  
MPC89L516X2@TQFP44 [ (SA245A) ]  
MPC89L556X2  
MPC89L556X2@PLCC44 [ (SA244) ] MPC89L556X2@TQFP44  
[ (SA245A) ]

## MEMOCOM

### E ( E ) PROM / FRAM / NVRAM

KI01602AB (Ga1) @FBGA66 [ (SA642R-B023A-T096F001Y) ]  
KI01602AB (Gb1) @FBGA66 [ (SA642E-B023A-T072001Y) ]  
KI01602AT (Ga1) @FBGA66 [ (SA642R-B023A-T096F001Y) ]  
KI01602AT (Gb1) @FBGA66 [ (SA642E-B023A-T072001Y) ]  
KI01604AB (Ga1) @FBGA58 [ (SA642R-B023A-T096F001Y) ]

KI01604AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
 KI01604AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI01604AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
 KI01608AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI01608AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
 KI01608AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI01608AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
 KI03204AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI03204AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
 KI03204AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI03204AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
 KI03208AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI03208AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
 KI03208AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
 KI03208AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
 KIP2832AU(Ha1)@FBGA88 [(SA642R-B300A-T096F001Y)]  
 KIP2864AU(Ha1)@FBGA88 [(SA642R-B300A-T096F001Y)]  
 KS01602AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS01602AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS01604AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS01604AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS03204AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS03204AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS03208AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS03208AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KSP2832AU(Hs1)@FBGA64 [(SA642A-B079-Y096F001Y)]  
 KSP2864AU(Hs1)@FBGA64 [(SA642A-B079-Y096F001Y)]

## MICON

### MICROCONTROLLER

MDT10P21(dip18)	MDT10P21
(dip20)	
MDT10P21(dip22)	MDT10P21@SOP18
[(SA404A)]	
MDT10P21@SOP20 [(SA404A)]	MDT10P21@SOP24
[(SA404A)]	
MDT10P22(dip18)	MDT10P22
(dip20)	
MDT10P22(dip22)	MDT10P22@SOP18
[(SA404A)]	

MDT10P22@SOP20 [(SA404A)]	MDT10P22@SOP24
[(SA404A)]	
MDT10P23(dip18)	MDT10P23
(dip20)	
MDT10P23(dip22)	MDT10P23@SOP18
[(SA404A)]	
MDT10P23@SOP20 [(SA404A)]	MDT10P23@SOP24
[(SA404A)]	
MDT10P61	MDT10P61@SOP18
[(SA404A)]	
MDT10P61@SSOP20 [(SA626A)]	
MDT2005	
MDT2005@SOP18 [(SA404A)]	MDT2005@SSOP20
[(SA626A)]	
MDT2010	MDT2010@SOP18
[(SA404A)]	
MDT2010@SSOP20 [(SA626A)]	
MDT2020	
MDT2020@SOP28 [(SA404A)]	MDT2020@SSOP28
[(SA626A)]	
MDT2030	MDT2030@SOP18
[(SA404A)]	
MDT2030@SSOP20 [(SA626A)]	
MDT2050	
MDT2050@SOP18 [(SA404A)]	MDT2050@SSOP20
[(SA626A)]	
MDT2051	MDT2051@SOP18
[(SA404A)]	
MDT2051@SSOP20 [(SA626A)]	
MDT2060	
MDT2060@SOP18 [(SA404A)]	MDT2060@SSOP20
[(SA626A)]	

## MICROCHIP

### E ( E ) PROM / FRAM / NVRAM

24AA00	24AA00@SOIC8
[(SA602A)]	
24AA00@TSSOP8 [(SA026)]	
24AA01	
24AA01@SOIC8 [(SA602A)]	24AA01@TSSOP8

[(SA026)]	
24AA014	24AA014@SOIC8
[(SA602A)]	
24AA014@TSSOP8 [(SA026)]	
24AA02	
24AA02@DFN8 [(SA694)]	24AA02@MSOP8
[(SA666)]	
24AA02@SOIC8 [(SA602A)]	24AA02@SOT-23-5
[(SA717)]	
24AA02@TSSOP8 [(SA026)]	
24AA024	
24AA024@DFN8 [(SA694)]	24AA024@MSOP8
[(SA666)]	
24AA024@SOIC8 [(SA602A)]	24AA024@TSSOP8
[(SA026)]	
24AA025	24AA025@DFN8
[(SA694)]	
24AA025@MSOP8 [(SA666)]	24AA025@SOIC8
[(SA602A)]	
24AA025@TSSOP8 [(SA026)]	
24AA04	
24AA04@SOIC8 [(SA602A)]	24AA04@TSSOP8
[(SA026)]	
24AA08	24AA08@SOIC8
[(SA602A)]	
24AA08@TSSOP8 [(SA026)]	
24AA1025	
24AA1025@SOIC8 [(SA602A)]	24AA1025@TSSOP8
[(SA026)]	
24AA128	24AA128@MSOP8
[(SA666)]	
24AA128@SOIC8 [(SA602A)]	24AA128@TSSOP14
[(SA026)]	
24AA128@TSSOP8 [(SA026)]	
24AA16	
24AA16@SOIC8 [(SA602A)]	24AA16@TSSOP8
[(SA026)]	
24AA164	24AA164@SOIC8
[(SA602A)]	
24AA164@TSSOP8 [(SA026)]	
24AA174	
24AA174@SOIC8 [(SA602A)]	24AA174@TSSOP8
[(SA026)]	

24AA256	24AA256@MSOP8
[(SA666)]	
24AA256@SOIC8 [(SA605A)]	24AA256@TSSOP14
[(SA026)]	
24AA256@TSSOP8 [(SA026)]	
24AA32	
24AA32(Rotated)@TSSOP8 [(SA026)]	24AA32@MSOP8
[(SA666)]	
24AA32@SOIC8 [(SA602A)]	24AA32@TSSOP8
[(SA026)]	
24AA32A	
24AA32A(Rotated)@TSSOP8 [(SA026)]	
24AA32A@MSOP8 [(SA666)]	24AA32A@SOIC8
[(SA602A)]	
24AA32A@TSSOP8 [(SA026)]	
24AA512	
24AA512@DFN8 [(SA683)]	24AA512@SOIC8
[(SA605A)]	
24AA512@TSSOP14 [(SA602)]	
24AA515	
24AA515@SOIC8 [(SA605A)]	
24AA52	
24AA52@DFN8 [(SA694)]	24AA52@MSOP8
[(SA666)]	
24AA52@SOIC8 [(SA602A)]	24AA52@TSSOP8
[(SA026)]	
24AA64	24AA64(Rotated)@TSSOP8
[(SA026)]	
24AA64@MSOP8 [(SA666)]	24AA64@SOIC8
[(SA602A)]	
24AA64@TSSOP8 [(SA026)]	
24AA65	
24AA65@SOIC8 [(SA602A)]	24AA65@TSSOP8
[(SA026)]	
24C00	24C00@SOIC8
[(SA602A)]	
24C00@TSSOP8 [(SA026)]	
24C01	
24C01A	24C01A@SOIC8
[(SA602A)]	
24C01C	24C01C@SOIC8
[(SA602A)]	
24C01C@TSSOP8 [(SA026)]	

24C02	
24C02A	24C02A@SOIC8
[ (SA602A) ]	
24C02C	24C02C@SOIC8
[ (SA602A) ]	
24C02C@TSSOP8 [ (SA026) ]	
24C04	
24C04A	24C04A@SOIC8
[ (SA602A) ]	
24C04A@TSSOP8 [ (SA026) ]	
24C08	
24C08@SOIC8 [ (SA602A) ]	
24C08B	
24C08B@SOIC8 [ (SA602A) ]	
24C16	
24C16@SOIC8 [ (SA602A) ]	
24C16B	
24C16B@SOIC8 [ (SA602A) ]	
24C32	
24C32@SOIC8 [ (SA602A) ]	
24C64	
24C64@SOIC8 [ (SA602A) ]	24C64@TSSOP8
[ (SA026) ]	
24C65	24C65@SOIC8
[ (SA602A) ]	
24FC1025	24FC1025@SOIC8
[ (SA602A) ]	
24FC1025@TSSOP8 [ (SA026) ]	
24FC128	
24FC128@MSOP8 [ (SA666) ]	24FC128@SOIC8
[ (SA602A) ]	
24FC128@TSSOP14 [ (SA026) ]	24FC128@TSSOP8
[ (SA026) ]	
24FC256	24FC256@MSOP8
[ (SA666) ]	
24FC256@SOIC8 [ (SA605A) ]	24FC256@TSSOP14
[ (SA026) ]	
24FC256@TSSOP8 [ (SA026) ]	
24FC32	
24FC32@SOIC8 [ (SA602A) ]	
24FC512	
24FC512@DFN8 [ (SA683) ]	24FC512@SOIC8
[ (SA605A) ]	



24FC512@TSSOP14 [(SA602)]	
24FC515	
24FC515@SOIC8 [(SA605A)]	
24FC65	
24FC65@SOIC8 [(SA605A)]	
24LC00	
24LC00@SOIC8 [(SA602A)]	24LC00@TSSOP8
[(SA026)]	
24LC01	
24LC014	
24LC014@SOIC8 [(SA602A)]	24LC014@TSSOP8
[(SA026)]	
24LC01B	24LC01B@SOIC8
[(SA602A)]	
24LC01B@TSSOP8 [(SA026)]	
24LC02	
24LC024	24LC024@SOIC8
[(SA602A)]	
24LC024@TSSOP8 [(SA026)]	
24LC025	
24LC025@SOIC8 [(SA602A)]	24LC025@TSSOP8
[(SA026)]	
24LC02B	24LC02B@DFN8
[(SA694)]	
24LC02B@MSOP8 [(SA666)]	24LC02B@SOIC8
[(SA602A)]	
24LC02B@SOT-23-5 [(SA717)]	24LC02B@TSSOP8
[(SA026)]	
24LC04	
24LC04B	
24LC04B@SOIC8 [(SA602A)]	24LC04B@TSSOP8
[(SA026)]	
24LC08	
24LC08B	
24LC08B@SOIC8 [(SA602A)]	24LC08B@TSSOP8
[(SA026)]	
24LC1025	24LC1025@SOIC8
[(SA602A)]	
24LC1025@TSSOP8 [(SA026)]	
24LC128	
24LC128@MSOP8 [(SA666)]	24LC128@SOIC8
[(SA605A)]	
24LC128@TSSOP14 [(SA026)]	24LC128@TSSOP8

[ (SA026) ]	
24LC16	24LC16@MSOP8
[ (SA605A) ]	
24LC16@SOIC8 [ (SA602A) ]	
24LC164	
24LC164@SOIC8 [ (SA602A) ]	
24LC16B	
24LC16B@SOIC8 [ (SA602A) ]	24LC16B@TSSOP8
[ (SA026) ]	
24LC174	24LC174@SOIC8
[ (SA602A) ]	
24LC21	24LC21@SOIC8
[ (SA602A) ]	
24LC21A	24LC21A@SOIC8
[ (SA602A) ]	
24LC22A	24LC22A@SOIC8
[ (SA602A) ]	
24LC256	24LC256@MSOP8
[ (SA666) ]	
24LC256@SOIC8 [ (SA605A) ]	24LC256@TSSOP14
[ (SA026) ]	
24LC256@TSSOP8 [ (SA026) ]	
24LC32	
24LC32@SOIC8 [ (SA602A) ]	
24LC32A	
24LC32A@SOIC8 [ (SA602A) ]	24LC32A@TSSOP8
[ (SA026) ]	
24LC512	24LC512@DFN8
[ (SA683) ]	
24LC512@SOIC8 [ (SA605A) ]	24LC512@TSSOP14
[ (SA602) ]	
24LC515	24LC515@SOIC8
[ (SA605A) ]	
24LC64	24LC64 (Rotated)@TSSOP8
[ (SA026) ]	
24LC64@MSOP8 [ (SA605A) ]	24LC64@SOIC8
[ (SA602A) ]	
24LC64@TSSOP8 [ (SA026) ]	
24LC65	
24LC65@SOIC8 [ (SA602A) ]	
24LCS21	
24LCS21@SOIC8 [ (SA602A) ]	
24LCS21A	

24LCS21A@SOIC8 [(SA602A)]	
24LCS22	
24LCS22@SOIC8 [(SA602A)]	
24LCS22A	
24LCS22A@SOIC8 [(SA602A)]	
24LCS52	
24LCS52@DFN8 [(SA694)]	24LCS52@MSOP8
[(SA666)]	
24LCS52@SOIC8 [(SA602A)]	24LCS52@TSSOP8
[(SA026)]	
25AA010A	25AA010A@DFN8
[(SA683)]	
25AA010A@MSOP8 [(SA605A)]	25AA010A@SOIC8
[(SA602A)]	
25AA010A@SOT-23 [(SA698)]	25AA010A@TSSOP8
[(SA026)]	
25AA010A[X-Rotated]@TSSOP8 [(SA026)]	
25AA020A	25AA020A@DFN8
[(SA683)]	
25AA020A@MSOP8 [(SA605A)]	25AA020A@SOIC8
[(SA602A)]	
25AA020A@SOT-23 [(SA698)]	25AA020A@TSSOP8
[(SA026)]	
25AA020A[X-Rotated]@TSSOP8 [(SA026)]	
25AA040	25AA040@SOIC8
[(SA602A)]	
25AA040@TSSOP8 [(SA026)]	
25AA040A	
25AA040A@DFN8 [(SA683)]	25AA040A@MSOP8
[(SA605A)]	
25AA040A@SOIC8 [(SA602A)]	25AA040A@SOT-23
[(SA698)]	
25AA040A@TSSOP8 [(SA026)]	
25AA040A[X-Rotated]@TSSOP8 [(SA026)]	
25AA080	25AA080@SOIC8
[(SA602A)]	
25AA080A	25AA080A@MSOP8
[(SA605A)]	
25AA080A@SOIC8 [(SA602A)]	25AA080A@TSSOP8
[(SA026)]	
25AA080B	25AA080B@MSOP8
[(SA605A)]	
25AA080B@SOIC8 [(SA602A)]	25AA080B@TSSOP8

[(SA026)]	
25AA1024	25AA1024@DFN8
[(SA683)]	
25AA1024@SOIC8 [(SA602A)]	25AA1024@SOIJ8
[(SA605)]	
25AA160	25AA160@SOIC8
[(SA602A)]	
25AA160A	25AA160A@MSOP8
[(SA605A)]	
25AA160A@SOIC8 [(SA602A)]	25AA160A@TSSOP8
[(SA026)]	
25AA160B	25AA160B@MSOP8
[(SA605A)]	
25AA160B@SOIC8 [(SA602A)]	25AA160B@TSSOP8
[(SA026)]	
25AA256	25AA256@DFN8
[(SA683)]	
25AA256@SOIC8(4.0) [(SA602A)]	25AA256@SOIC8(5.4)
[(SA605A)]	
25AA256@TSSOP8 [(SA026)]	
25AA256[X-Rotated]@TSSOP8 [(SA026)]	
25AA320	25AA320@SOIC8
[(SA602A)]	
25AA320@TSSOP14 [(SA026)]	25AA320@TSSOP8
[(SA026)]	
25AA512	25AA512@DFN8
[(SA683)]	
25AA512@SOIC8 [(SA602A)]	25AA512@SOIJ8
[(SA605)]	
25AA640	25AA640@SOIC8
[(SA602A)]	
25AA640@TSSOP8 [(SA026)]	
25C040	
25C040@SOIC8 [(SA602A)]	25C040@TSSOP8
[(SA026)]	
25C080	25C080@SOIC8
[(SA602A)]	
25C160	25C160@SOIC8
[(SA602A)]	
25C320	25C320@SOIC8
[(SA602A)]	
25C320@TSSOP14 [(SA026)]	25C320@TSSOP8
[(SA026)]	

25C640	25C640@SOIC8
[(SA602A)]	
25C640@TSSOP8 [(SA026)]	
25LC010A	
25LC010A@DFN8 [(SA683)]	25LC010A@MSOP8
[(SA605A)]	
25LC010A@SOIC8 [(SA602A)]	25LC010A@SOT-23
[(SA698)]	
25LC010A@TSSOP8 [(SA026)]	
25LC010A[X-Rotated]@TSSOP8 [(SA026)]	
25LC020A	25LC020A@DFN8
[(SA683)]	
25LC020A@MSOP8 [(SA605A)]	25LC020A@SOIC8
[(SA602A)]	
25LC020A@SOT-23 [(SA698)]	25LC020A@TSSOP8
[(SA026)]	
25LC020A[X-Rotated]@TSSOP8 [(SA026)]	
25LC040	25LC040@SOIC8
[(SA602A)]	
25LC040@TSSOP8 [(SA026)]	
25LC040A	
25LC040A@DFN8 [(SA683)]	25LC040A@MSOP8
[(SA605A)]	
25LC040A@SOIC8 [(SA602A)]	25LC040A@SOT-23
[(SA698)]	
25LC040A@TSSOP8 [(SA026)]	
25LC040A[X-Rotated]@TSSOP8 [(SA026)]	
25LC080	25LC080@SOIC8
[(SA602A)]	
25LC080A	25LC080A@MSOP8
[(SA605A)]	
25LC080A@SOIC8 [(SA602A)]	25LC080A@TSSOP8
[(SA026)]	
25LC080B	25LC080B@MSOP8
[(SA605A)]	
25LC080B@SOIC8 [(SA602A)]	25LC080B@TSSOP8
[(SA026)]	
25LC1024	25LC1024@DFN8
[(SA683)]	
25LC1024@SOIC8 [(SA602A)]	25LC1024@SOIJ8
[(SA605)]	
25LC160	25LC160@SOIC8
[(SA602A)]	

25LC160A [ (SA605A) ]	25LC160A@MSOP8
25LC160A@SOIC8 [ (SA602A) ] [ (SA026) ]	25LC160A@TSSOP8
25LC160B [ (SA605A) ]	25LC160B@MSOP8
25LC160B@SOIC8 [ (SA602A) ] [ (SA026) ]	25LC160B@TSSOP8
25LC256 [ (SA683) ]	25LC256@DFN8
25LC256@SOIC8(4.0) [ (SA602A) ] [ (SA605A) ]	25LC256@SOIC8(5.4)
25LC256@TSSOP8 [ (SA026) ]	
25LC256[X-Rotated]@TSSOP8 [ (SA026) ]	
25LC320 [ (SA602A) ]	25LC320(SN)@SOIC8
25LC320@TSSOP14 [ (SA026) ] [ (SA026) ]	25LC320@TSSOP8
25LC512 [ (SA683) ]	25LC512@DFN8
25LC512@SOIC8 [ (SA602A) ] [ (SA605) ]	25LC512@SOIJ8
25LC640 [ (SA602A) ]	25LC640@SOIC8
25LC640@TSSOP8 [ (SA026) ]	
27256	
27256@PLCC32 [ (SA015A1T) ]	
27C128	
27C128@PLCC32 [ (SA015A1T) ]	
27C128A	
27C128A@PLCC32 [ (SA015A1T) ]	
27C256	
27C256@PLCC32 [ (SA015A1T) ]	
27C32A	
27C512 [ (SA015A1T) ]	27C512@PLCC32
27C512A [ (SA015A1T) ]	27C512A@PLCC32
27C513	
27C64	
27C64@PLCC32 [ (SA015A1T) ] [ (SA404) ]	27C64@SOIC28
27HC1616	27HC1616@PLCC44

[(SA244)]	
27HC1616L	27HC1616L@PLCC44
[(SA244)]	
27HC191	27HC191@PLCC28
[(SA008A)]	
27HC191@SOIC24 [(SA404)]	
27HC256	
27HC256@PLCC32 [(SA015A1T)]	
27HC256L	
27HC256L@PLCC32 [(SA015A1T)]	
27HC291	
27HC291@PLCC28 [(SA008A)]	27HC291@SOIC24
[(SA404)]	
27HC416	
27HC64	
27HC64@PLCC32 [(SA015A1T)]	27HC64@SOIC28
[(SA404)]	
27HC641	27HC641@PLCC28
[(SA008A)]	
27HC641@SOIC24 [(SA404)]	
27HC641L	
27HC641L@PLCC28 [(SA008A)]	27HC641L@SOIC24
[(SA404)]	
27HC64L	27HC64L@PLCC32
[(SA015A1T)]	
27HC64L@SOIC28 [(SA404)]	
27LV256	
27LV256@PLCC32 [(SA015A1T)]	
27LV64	
2817	
2864	
2864@PLCC32 [(SA015A1T)]	
28C04	
28C04@PLCC32 [(SA015A1T)]	28C04@SOIC24
[(SA404)]	
28C04A	28C04A@PLCC32
[(SA015A1T)]	
28C04A@SOIC24 [(SA404)]	
28C04AF	
28C04AF@PLCC32 [(SA015A1T)]	28C04AF@SOIC24
[(SA404)]	
28C04F	28C04F@PLCC32
[(SA015A1T)]	

28C04F@SOIC24 [(SA404)]  
28C16  
28C16@PLCC32 [(SA015A1T)] 28C16@SOIC24  
[(SA404)]  
28C16A 28C16A@PLCC32  
[(SA015A1T)]  
28C16A@SOIC24 [(SA404)]  
28C16AF  
28C16AF@PLCC32 [(SA015A1T)] 28C16AF@SOIC24  
[(SA404)]  
28C16F 28C16F@PLCC32  
[(SA015A1T)]  
28C16F@SOIC24 [(SA404)]  
28C17  
28C17@PLCC32 [(SA015A1T)] 28C17@SOIC28  
[(SA404)]  
28C17A 28C17A@PLCC32  
[(SA015A1T)]  
28C17A@SOIC28 [(SA404)]  
28C17AF  
28C17AF@PLCC32 [(SA015A1T)] 28C17AF@SOIC28  
[(SA404)]  
28C17F 28C17F@PLCC32  
[(SA015A1T)]  
28C17F@SOIC28 [(SA404)]  
28C256  
28C256@PLCC32 [(SA015A1T)]  
28C256F  
28C256F@PLCC32 [(SA015A1T)]  
28C64A  
28C64A@PLCC32 [(SA015A1T)] 28C64A@SOIC28  
[(SA404)]  
28C64A@TSOP32 [(SA410T)]  
28C64AF  
28C64AF@PLCC32 [(SA015A1T)] 28C64AF@SOIC28  
[(SA404)]  
28LV64A 28LV64A@PLCC32  
[(SA015A1T)]  
28LV64A@SOIC28 [(SA404)]  
28PC64  
28PC64@PLCC32 [(SA015A1T)]  
59C11  
59C11@SOIC8 [(SA602A)]



85C72	
85C72@SOIC8 [(SA602A)]	
85C82	
85C82@SOIC8 [(SA602A)]	
85C92	
85C92@SOIC8 [(SA602A)]	93AA46
(08bit)	
93AA46(08bit)@SOIC8 [(SA602A)]	93AA46
(16bit)	
93AA46(16bit)@SOIC8 [(SA602A)]	93AA46A
(08bit)	
93AA46A(08bit)@DFN8 [(BBBB)]	93AA46A(08bit)@MSOP8
[(SA666)]	
93AA46A(08bit)@SOIC8 [(SA602A)]	93AA46A(08bit)@SOT-23
[(SA717)]	
93AA46A(08bit)@TSSOP8 [(SA026)]	93AA46B
(16bit)	
93AA46B(16bit)@DFN8 [(BBBB)]	93AA46B(16bit)@MSOP8
[(SA666)]	
93AA46B(16bit)@SOIC8 [(SA602A)]	93AA46B(16bit)@SOT-23
[(SA717)]	
93AA46B(16bit)@TSSOP8 [(SA026)]	93AA46C
(08bit)	
93AA46C(08bit)@DFN8 [(BBBB)]	93AA46C(08bit)@MSOP8
[(SA666)]	
93AA46C(08bit)@SOIC8 [(SA602A)]	93AA46C(08bit)@TSSOP8
[(SA026)]	
93AA46C(16bit)	93AA46C(16bit)@DFN8
[(BBBB)]	
93AA46C(16bit)@MSOP8 [(SA666)]	93AA46C(16bit)@SOIC8
[(SA602A)]	
93AA46C(16bit)@TSSOP8 [(SA026)]	93AA56
(08bit)	
93AA56(08bit)@SOIC8 [(SA602A)]	93AA56
(16bit)	
93AA56(16bit)@SOIC8 [(SA602A)]	93AA56A
(08bit)	
93AA56A(08bit)@DFN8 [(BBBB)]	93AA56A(08bit)@MSOP8
[(SA666)]	
93AA56A(08bit)@SOIC8 [(SA602A)]	93AA56A(08bit)@SOT-23
[(SA717)]	
93AA56A(08bit)@TSSOP8 [(SA026)]	93AA56B
(16bit)	

93AA56B(16bit)@DFN8 [(BBBB)]	93AA56B(16bit)@MSOP8
[(SA666)]	
93AA56B(16bit)@SOIC8 [(SA602A)]	93AA56B(16bit)@SOT-23
[(SA717)]	
93AA56B(16bit)@TSSOP8 [(SA026)]	93AA56C
(08bit)	
93AA56C(08bit)@DFN8 [(BBBB)]	93AA56C(08bit)@MSOP8
[(SA666)]	
93AA56C(08bit)@SOIC8 [(SA602A)]	93AA56C(08bit)@TSSOP8
[(SA026)]	
93AA56C(16bit)	93AA56C(16bit)@DFN8
[(BBBB)]	
93AA56C(16bit)@MSOP8 [(SA666)]	93AA56C(16bit)@SOIC8
[(SA602A)]	
93AA56C(16bit)@TSSOP8 [(SA026)]	93AA66
(08bit)	
93AA66(08bit)@SOIC8 [(SA602A)]	93AA66
(16bit)	
93AA66(16bit)@SOIC8 [(SA602A)]	93AA66A
(08bit)	
93AA66A(08bit)@DFN8 [(BBBB)]	93AA66A(08bit)@MSOP8
[(SA666)]	
93AA66A(08bit)@SOIC8 [(SA602A)]	93AA66A(08bit)@SOT-23
[(SA717)]	
93AA66A(08bit)@TSSOP8 [(SA026)]	93AA66B
(16bit)	
93AA66B(16bit)@DFN8 [(BBBB)]	93AA66B(16bit)@MSOP8
[(SA666)]	
93AA66B(16bit)@SOIC8 [(SA602A)]	93AA66B(16bit)@SOT-23
[(SA717)]	
93AA66B(16bit)@TSSOP8 [(SA026)]	93AA66C
(08bit)	
93AA66C(08bit)@DFN8 [(BBBB)]	93AA66C(08bit)@MSOP8
[(SA666)]	
93AA66C(08bit)@SOIC8 [(SA602A)]	93AA66C(08bit)@TSSOP8
[(SA026)]	
93AA66C(16bit)	93AA66C(16bit)@DFN8
[(BBBB)]	
93AA66C(16bit)@MSOP8 [(SA666)]	93AA66C(16bit)@SOIC8
[(SA602A)]	
93AA66C(16bit)@TSSOP8 [(SA026)]	93AA76
(08bit)	
93AA76(08bit)@SOIC8 [(SA602A)]	93AA76

(16bit)	
93AA76(16bit)@SOIC8 [(SA602A)]	93AA76A
(08bit)	
93AA76A(08bit)@DFN8 [(BBBB)]	93AA76A(08bit)@MSOP8
[(SA666)]	
93AA76A(08bit)@SOIC8 [(SA602A)]	93AA76A(08bit)@SOT-23
[(SA717)]	
93AA76A(08bit)@TSSOP8 [(SA026)]	93AA76B
(16bit)	
93AA76B(16bit)@DFN8 [(BBBB)]	93AA76B(16bit)@MSOP8
[(SA666)]	
93AA76B(16bit)@SOIC8 [(SA602A)]	93AA76B(16bit)@SOT-23
[(SA717)]	
93AA76B(16bit)@TSSOP8 [(SA026)]	93AA76C
(08bit)	
93AA76C(08bit)@DFN8 [(BBBB)]	93AA76C(08bit)@MSOP8
[(SA666)]	
93AA76C(08bit)@SOIC8 [(SA602A)]	93AA76C(08bit)@TSSOP8
[(SA026)]	
93AA76C(16bit)	93AA76C(16bit)@DFN8
[(BBBB)]	
93AA76C(16bit)@MSOP8 [(SA666)]	93AA76C(16bit)@SOIC8
[(SA602A)]	
93AA76C(16bit)@TSSOP8 [(SA026)]	93AA86
(08bit)	
93AA86(08bit)@SOIC8 [(SA602A)]	93AA86
(16bit)	
93AA86(16bit)@SOIC8 [(SA602A)]	93AA86A
(08bit)	
93AA86A(08bit)@DFN8 [(BBBB)]	93AA86A(08bit)@MSOP8
[(SSA666)]	
93AA86A(08bit)@SOIC8 [(SA602A)]	93AA86A(08bit)@SOT-23
[(SA717)]	
93AA86A(08bit)@TSSOP8 [(SA026)]	93AA86B
(16bit)	
93AA86B(16bit)@DFN8 [(BBBB)]	93AA86B(16bit)@MSOP8
[(SA666)]	
93AA86B(16bit)@SOIC8 [(SA602A)]	93AA86B(16bit)@SOT-23
[(SA717)]	
93AA86B(16bit)@TSSOP8 [(SA026)]	93AA86C
(08bit)	
93AA86C(08bit)@DFN8 [(BBBB)]	93AA86C(08bit)@MSOP8
[(SA666)]	

93AA86C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93AA86C(08bit)@TSSOP8
93AA86C(16bit) [(BBBB)]	93AA86C(16bit)@DFN8
93AA86C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93AA86C(16bit)@SOIC8
93AA86C(16bit)@TSSOP8 [(SA026)] (08bit)	93C06
93C06(08bit)@SOIC8 [(SA602A)] (16bit)	93C06
93C06(16bit)@SOIC8 [(SA602A)] (08bit)	93C46
93C46(08bit)@SOIC8 [(SA602A)] (16bit)	93C46
93C46(16bit)@SOIC8 [(SA602A)] (08bit)	93C46A
93C46A(08bit)@DFN8 [(BBBB)] [(SA666)]	93C46A(08bit)@MSOP8
93C46A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93C46A(08bit)@SOT-23
93C46A(08bit)@TSSOP8 [(SA026)] (16bit)	93C46B
93C46B(16bit)@DFN8 [(BBBB)] [(SA666)]	93C46B(16bit)@MSOP8
93C46B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93C46B(16bit)@SOT-23
93C46B(16bit)@TSSOP8 [(SA026)] (08bit)	93C46C
93C46C(08bit)@DFN8 [(BBBB)] [(SA666)]	93C46C(08bit)@MSOP8
93C46C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93C46C(08bit)@TSSOP8
93C46C(16bit) [(BBBB)]	93C46C(16bit)@DFN8
93C46C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93C46C(16bit)@SOIC8
93C46C(16bit)@TSSOP8 [(SA026)] (08bit)	93C56
93C56(08bit)@SOIC8 [(SA602A)] (16bit)	93C56
93C56(16bit)@SOIC8 [(SA602A)] (08bit)	93C56A
93C56A(08bit)@DFN8 [(BBBB)]	93C56A(08bit)@MSOP8

[(SA666)]	
93C56A(08bit)@SOIC8 [(SA602A)]	93C56A(08bit)@SOT-23
[(SA717)]	
93C56A(08bit)@TSSOP8 [(SA026)]	93C56B
(16bit)	
93C56B(16bit)@DFN8 [(BBBB)]	93C56B(16bit)@MSOP8
[(SA666)]	
93C56B(16bit)@SOIC8 [(SA602A)]	93C56B(16bit)@SOT-23
[(SA717)]	
93C56B(16bit)@TSSOP8 [(SA026)]	93C56C
(08bit)	
93C56C(08bit)@DFN8 [(BBBB)]	93C56C(08bit)@MSOP8
[(SA666)]	
93C56C(08bit)@SOIC8 [(SA602A)]	93C56C(08bit)@TSSOP8
[(SA026)]	
93C56C(16bit)	93C56C(16bit)@DFN8
[(BBBB)]	
93C56C(16bit)@MSOP8 [(SA666)]	93C56C(16bit)@SOIC8
[(SA602A)]	
93C56C(16bit)@TSSOP8 [(SA026)]	93C66
(08bit)	
93C66(08bit)@SOIC8 [(SA602A)]	93C66
(16bit)	
93C66(16bit)@SOIC8 [(SA602A)]	93C66A
(08bit)	
93C66A(08bit)@DFN8 [(BBBB)]	93C66A(08bit)@MSOP8
[(SA666)]	
93C66A(08bit)@SOIC8 [(SA602A)]	93C66A(08bit)@SOT-23
[(SA717)]	
93C66A(08bit)@TSSOP8 [(SA026)]	93C66B
(16bit)	
93C66B(16bit)@DFN8 [(BBBB)]	93C66B(16bit)@MSOP8
[(SA666)]	
93C66B(16bit)@SOIC8 [(SA602A)]	93C66B(16bit)@SOT-23
[(SA717)]	
93C66B(16bit)@TSSOP8 [(SA026)]	93C66C
(08bit)	
93C66C(08bit)@DFN8 [(BBBB)]	93C66C(08bit)@MSOP8
[(SA666)]	
93C66C(08bit)@SOIC8 [(SA602A)]	93C66C(08bit)@TSSOP8
[(SA026)]	
93C66C(16bit)	93C66C(16bit)@DFN8
[(BBBB)]	

93C66C(16bit)@MSOP8 [(SA666)]	93C66C(16bit)@SOIC8
[(SA602A)]	
93C66C(16bit)@TSSOP8 [(SA026)]	93C76
(08bit)	
93C76(08bit)@SOIC8 [(SA602A)]	93C76
(16bit)	
93C76(16bit)@SOIC8 [(SA602A)]	93C76A
(08bit)	
93C76A(08bit)@DFN8 [(BBBB)]	93C76A(08bit)@MSOP8
[(SA666)]	
93C76A(08bit)@SOIC8 [(SA602A)]	93C76A(08bit)@SOT-23
[(SA717)]	
93C76A(08bit)@TSSOP8 [(SA026)]	93C76B
(16bit)	
93C76B(16bit)@DFN8 [(BBBB)]	93C76B(16bit)@MSOP8
[(SA666)]	
93C76B(16bit)@SOIC8 [(SA602A)]	93C76B(16bit)@SOT-23
[(SA717)]	
93C76B(16bit)@TSSOP8 [(SA026)]	93C76C
(08bit)	
93C76C(08bit)@DFN8 [(BBBB)]	93C76C(08bit)@MSOP8
[(SA666)]	
93C76C(08bit)@SOIC8 [(SA602A)]	93C76C(08bit)@TSSOP8
[(SA026)]	
93C76C(16bit)	93C76C(16bit)@DFN8
[(BBBB)]	
93C76C(16bit)@MSOP8 [(SA666)]	93C76C(16bit)@SOIC8
[(SA602A)]	
93C76C(16bit)@TSSOP8 [(SA026)]	93C86
(08bit)	
93C86(08bit)@SOIC8 [(SA602A)]	93C86
(16bit)	
93C86(16bit)@SOIC8 [(SA602A)]	93C86A
(08bit)	
93C86A(08bit)@DFN8 [(BBBB)]	93C86A(08bit)@MSOP8
[(SSA666)]	
93C86A(08bit)@SOIC8 [(SA602A)]	93C86A(08bit)@SOT-23
[(SA717)]	
93C86A(08bit)@TSSOP8 [(SA026)]	93C86B
(16bit)	
93C86B(16bit)@DFN8 [(BBBB)]	93C86B(16bit)@MSOP8
[(SA666)]	
93C86B(16bit)@SOIC8 [(SA602A)]	93C86B(16bit)@SOT-23

[(SA717)]	
93C86B(16bit)@TSSOP8 [(SA026)]	93C86C
(08bit)	
93C86C(08bit)@DFN8 [(BBBB)]	93C86C(08bit)@MSOP8
[(SA666)]	
93C86C(08bit)@SOIC8 [(SA602A)]	93C86C(08bit)@TSSOP8
[(SA026)]	
93C86C(16bit)	93C86C(16bit)@DFN8
[(BBBB)]	
93C86C(16bit)@MSOP8 [(SA666)]	93C86C(16bit)@SOIC8
[(SA602A)]	
93C86C(16bit)@TSSOP8 [(SA026)]	93LC46
(08bit)	
93LC46(08bit)@SOIC8 [(SA602A)]	93LC46
(16bit)	
93LC46(16bit)@SOIC8 [(SA602A)]	93LC46A
(08bit)	
93LC46A(08bit)@DFN8 [(BBBB)]	93LC46A(08bit)@MSOP8
[(SA666)]	
93LC46A(08bit)@SOIC8 [(SA602A)]	93LC46A(08bit)@SOT-23
[(SA717)]	
93LC46A(08bit)@TSSOP8 [(SA026)]	93LC46B
(16bit)	
93LC46B(16bit)@DFN8 [(BBBB)]	93LC46B(16bit)@MSOP8
[(SA666)]	
93LC46B(16bit)@SOIC8 [(SA602A)]	93LC46B(16bit)@SOT-23
[(SA717)]	
93LC46B(16bit)@TSSOP8 [(SA026)]	
93LC46BX	
93LC46BX@SOIC8 [(SA602A)]	93LC46C
(08bit)	
93LC46C(08bit)@DFN8 [(BBBB)]	93LC46C(08bit)@MSOP8
[(SA666)]	
93LC46C(08bit)@SOIC8 [(SA602A)]	93LC46C(08bit)@TSSOP8
[(SA026)]	
93LC46C(16bit)	93LC46C(16bit)@DFN8
[(BBBB)]	
93LC46C(16bit)@MSOP8 [(SA666)]	93LC46C(16bit)@SOIC8
[(SA602A)]	
93LC46C(16bit)@TSSOP8 [(SA026)]	93LC56
(08bit)	
93LC56(08bit)@SOIC8 [(SA602A)]	93LC56
(16bit)	

93LC56(16bit)@SOIC8 [(SA602A)] (08bit)	93LC56A
93LC56A(08bit)@DFN8 [(BBBB)] [(SA666)]	93LC56A(08bit)@MSOP8
93LC56A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93LC56A(08bit)@SOT-23
93LC56A(08bit)@TSSOP8 [(SA026)] (16bit)	93LC56B
93LC56B(16bit)@DFN8 [(BBBB)] [(SA666)]	93LC56B(16bit)@MSOP8
93LC56B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93LC56B(16bit)@SOT-23
93LC56B(16bit)@TSSOP8 [(SA026)]	
93LC56BX	
93LC56BX@SOIC8 [(SA602A)] (08bit)	93LC56C
93LC56C(08bit)@DFN8 [(BBBB)] [(SA666)]	93LC56C(08bit)@MSOP8
93LC56C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93LC56C(08bit)@TSSOP8
93LC56C(16bit) [(BBBB)]	93LC56C(16bit)@DFN8
93LC56C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93LC56C(16bit)@SOIC8
93LC56C(16bit)@TSSOP8 [(SA026)] (08bit)	93LC66
93LC66(08bit)@SOIC8 [(SA602A)] (16bit)	93LC66
93LC66(16bit)@SOIC8 [(SA602A)] (08bit)	93LC66A
93LC66A(08bit)@DFN8 [(BBBB)] [(SA666)]	93LC66A(08bit)@MSOP8
93LC66A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93LC66A(08bit)@SOT-23
93LC66A(08bit)@TSSOP8 [(SA026)] (16bit)	93LC66B
93LC66B(16bit)@DFN8 [(BBBB)] [(SA666)]	93LC66B(16bit)@MSOP8
93LC66B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93LC66B(16bit)@SOT-23
93LC66B(16bit)@TSSOP8 [(SA026)]	
93LC66BX	
93LC66BX@SOIC8 [(SA602A)]	93LC66C



(08bit)	
93LC66C(08bit)@DFN8 [(BBBB)]	93LC66C(08bit)@MSOP8
[(SA666)]	
93LC66C(08bit)@SOIC8 [(SA602A)]	93LC66C(08bit)@TSSOP8
[(SA026)]	
93LC66C(16bit)	93LC66C(16bit)@DFN8
[(BBBB)]	
93LC66C(16bit)@MSOP8 [(SA666)]	93LC66C(16bit)@SOIC8
[(SA602A)]	
93LC66C(16bit)@TSSOP8 [(SA026)]	93LC76
(08bit)	
93LC76(08bit)@SOIC8 [(SA602A)]	93LC76
(16bit)	
93LC76(16bit)@SOIC8 [(SA602A)]	93LC76A
(08bit)	
93LC76A(08bit)@DFN8 [(BBBB)]	93LC76A(08bit)@MSOP8
[(SA666)]	
93LC76A(08bit)@SOIC8 [(SA602A)]	93LC76A(08bit)@SOT-23
[(SA717)]	
93LC76A(08bit)@TSSOP8 [(SA026)]	93LC76B
(16bit)	
93LC76B(16bit)@DFN8 [(BBBB)]	93LC76B(16bit)@MSOP8
[(SA666)]	
93LC76B(16bit)@SOIC8 [(SA602A)]	93LC76B(16bit)@SOT-23
[(SA717)]	
93LC76B(16bit)@TSSOP8 [(SA026)]	93LC76C
(08bit)	
93LC76C(08bit)@DFN8 [(BBBB)]	93LC76C(08bit)@MSOP8
[(SA666)]	
93LC76C(08bit)@SOIC8 [(SA602A)]	93LC76C(08bit)@TSSOP8
[(SA026)]	
93LC76C(16bit)	93LC76C(16bit)@DFN8
[(BBBB)]	
93LC76C(16bit)@MSOP8 [(SA666)]	93LC76C(16bit)@SOIC8
[(SA602A)]	
93LC76C(16bit)@TSSOP8 [(SA026)]	93LC86
(08bit)	
93LC86(08bit)@SOIC8 [(SA602A)]	93LC86
(16bit)	
93LC86(16bit)@SOIC8 [(SA602A)]	93LC86A
(08bit)	
93LC86A(08bit)@DFN8 [(BBBB)]	93LC86A(08bit)@MSOP8
[(SSA666)]	

93LC86A(08bit)@SOIC8 [(SA602A)]	93LC86A(08bit)@SOT-23
[(SA717)]	
93LC86A(08bit)@TSSOP8 [(SA026)]	93LC86B
(16bit)	
93LC86B(16bit)@DFN8 [(BBBB)]	93LC86B(16bit)@MSOP8
[(SA666)]	
93LC86B(16bit)@SOIC8 [(SA602A)]	93LC86B(16bit)@SOT-23
[(SA717)]	
93LC86B(16bit)@TSSOP8 [(SA026)]	93LC86C
(08bit)	
93LC86C(08bit)@DFN8 [(BBBB)]	93LC86C(08bit)@MSOP8
[(SA666)]	
93LC86C(08bit)@SOIC8 [(SA602A)]	93LC86C(08bit)@TSSOP8
[(SA026)]	
93LC86C(16bit)	93LC86C(16bit)@DFN8
[(BBBB)]	
93LC86C(16bit)@MSOP8 [(SA666)]	93LC86C(16bit)@SOIC8
[(SA602A)]	
93LC86C(16bit)@TSSOP8 [(SA026)]	
93LCS46	
93LCS46@SOIC14 [(SA026)]	93LCS46@SOIC8
[(SA602A)]	
93LCS56	93LCS56@SOIC14
[(SA026)]	
93LCS56@SOIC8 [(SA602A)]	
93LCS66	
93LCS66@SOIC14 [(SA026)]	93LCS66@SOIC8
[(SA602A)]	
ER5911	ER5911@SOIC8
[(SA602A)]	
HCS101	HCS101SN@SOIC8
[(SA602A)]	
HCS200	HCS200SN@SOIC8
[(SA602A)]	
HCS300	HCS300SN@SOIC8
[(SA602A)]	
HCS301	HCS301SN@SOIC8
[(SA602A)]	
HCS320	HCS320SN@SOIC8
[(SA602A)]	
HCS360	HCS360SN@SOIC8
[(SA602A)]	
HCS361	HCS361SN@SOIC8

[ (SA602A) ]

**MICROCONTROLLER**

MCP25020

MCP25020(150mil)@SOIC14 [ (SA602) ]

MCP25020(150mil)@SOIC14(ISP) [ ISP-HEADER01 ]

MCP25020(208mil)@SOIC14 [ (SA404) ]

MCP25020(208mil)@SOIC14(ISP) [ ISP-HEADER01 ]

MCP25020(ISP) [ ISP-HEADER01 ]

MCP25025

MCP25025(150mil)@SOIC14 [ (SA602) ]

MCP25025(150mil)@SOIC14(ISP) [ ISP-HEADER01 ]

MCP25025(208mil)@SOIC14 [ (SA404) ]

MCP25025(208mil)@SOIC14(ISP) [ ISP-HEADER01 ]

MCP25025(ISP) [ ISP-HEADER01 ]

MCP25050

MCP25050(150mil)@SOIC14 [ (SA602) ]

MCP25050(150mil)@SOIC14(ISP) [ ISP-HEADER01 ]

MCP25050(208mil)@SOIC14 [ (SA404) ]

MCP25050(208mil)@SOIC14(ISP) [ ISP-HEADER01 ]

MCP25050(ISP) [ ISP-HEADER01 ]

MCP25055

MCP25055(150mil)@SOIC14 [ (SA602) ]

MCP25055(150mil)@SOIC14(ISP) [ ISP-HEADER01 ]

MCP25055(208mil)@SOIC14 [ (SA404) ]

MCP25055(208mil)@SOIC14(ISP) [ ISP-HEADER01 ]

MCP25055(ISP) [ ISP-HEADER01 ]

PIC10F200

PIC10F200(ISP) [ ISP-HEADER01 ] PIC10F200@SOT6

[ (SA717) ]

PIC10F200@SOT6(ISP) [ ISP-HEADER01 ]

PIC10F202 PIC10F202(ISP) [ ISP-  
HEADER01 ]

PIC10F202@SOT6 [ (SA717) ]

PIC10F202@SOT6(ISP) [ ISP-HEADER01 ]

PIC10F204 PIC10F204(ISP) [ ISP-  
HEADER01 ]

PIC10F204@SOT6 [ (SA717) ]

PIC10F204@SOT6(ISP) [ ISP-HEADER01 ]

PIC10F206 PIC10F206(ISP) [ ISP-  
HEADER01 ]

PIC10F206@SOT6 [(SA717)]  
PIC10F206@SOT6(ISP) [ISP-HEADER01]  
PIC10F220 PIC10F220(ISP) [ISP-  
HEADER01]  
PIC10F220@SOT6 [(SA717)]  
PIC10F220@SOT6(ISP) [ISP-HEADER01]  
PIC10F222 PIC10F222(ISP) [ISP-  
HEADER01]  
PIC10F222@SOT6 [(SA717)]  
PIC10F222@SOT6(ISP) [ISP-HEADER01]  
PIC12C508 PIC12C508(ISP) [ISP-  
HEADER01]  
PIC12C508@SOIC8 [(SA605A)]  
PIC12C508@SOIC8(ISP) [ISP-HEADER01]  
PIC12C508A PIC12C508A(ISP) [ISP-  
HEADER01]  
PIC12C508A(SM)@SOIC8 [(SA605A)]  
PIC12C508A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C508A(SN)@SOIC8 [(SA602A)]  
PIC12C508A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509 PIC12C509(ISP) [ISP-  
HEADER01]  
PIC12C509(SM)@SOIC8 [(SA605A)]  
PIC12C509(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509(SN)@SOIC8 [(SA602A)]  
PIC12C509(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509A PIC12C509A(ISP) [ISP-  
HEADER01]  
PIC12C509A(SM)@SOIC8 [(SA605A)]  
PIC12C509A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509A(SN)@SOIC8 [(SA602A)]  
PIC12C509A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509A@DFN8 [(SA683)]  
PIC12C509A@DFN8(ISP) [ISP-HEADER01]  
PIC12C671 PIC12C671(ISP) [ISP-  
HEADER01]  
PIC12C671@DFN8 [(SA683)]  
PIC12C671@DFN8(ISP) [ISP-HEADER01]  
PIC12C671@SOIC8 [(SA605A)]  
PIC12C671@SOIC8(ISP) [ISP-HEADER01]  
PIC12C672 PIC12C672(ISP) [ISP-  
HEADER01]  
PIC12C672@DFN8 [(SA683)]

PIC12C672@DFN8 (ISP) [ISP-HEADER01]  
PIC12C672@SOIC8 [(SA605A)]  
PIC12C672@SOIC8 (ISP) [ISP-HEADER01]  
PIC12CE518 PIC12CE518 (ISP) [ISP-  
HEADER01]  
PIC12CE518@SOIC8 [(SA605A)]  
PIC12CE518@SOIC8 (ISP) [ISP-HEADER01]  
PIC12CE519 PIC12CE519 (ISP) [ISP-  
HEADER01]  
PIC12CE519 (SM)@SOIC8 [(SA605A)]  
PIC12CE519 (SM)@SOIC8 (ISP) [ISP-HEADER01]  
PIC12CE519 (SN)@SOIC8 [(SA602A)]  
PIC12CE519 (SN)@SOIC8 (ISP) [ISP-HEADER01]  
PIC12CE673 PIC12CE673 (ISP) [ISP-  
HEADER01]  
PIC12CE673@SOIC8 [(SA605A)]  
PIC12CE673@SOIC8 (ISP) [ISP-HEADER01]  
PIC12CE674 PIC12CE674 (ISP) [ISP-  
HEADER01]  
PIC12CE674@SOIC8 [(SA605A)]  
PIC12CE674@SOIC8 (ISP) [ISP-HEADER01]  
PIC12F508 PIC12F508 (ISP) [ISP-  
HEADER01]  
PIC12F508@MSOP8 [(SA666)]  
PIC12F508@MSOP8 (ISP) [ISP-HEADER01]  
PIC12F508@SOIC8 [(SA602)]  
PIC12F508@SOIC8 (ISP) [ISP-HEADER01]  
PIC12F509 PIC12F509 (ISP) [ISP-  
HEADER01]  
PIC12F509@MSOP8 [(SA666)]  
PIC12F509@MSOP8 (ISP) [ISP-HEADER01]  
PIC12F509@SOIC8 [(SA602)]  
PIC12F509@SOIC8 (ISP) [ISP-HEADER01]  
PIC12F510 PIC12F510 (ISP) [ISP-  
HEADER01]  
PIC12F510@MSOP8 [(SA666)]  
PIC12F510@MSOP8 (ISP) [ISP-HEADER01]  
PIC12F510@SOIC8 [(SA605A)]  
PIC12F510@SOIC8 (ISP) [ISP-HEADER01]  
PIC12F609 PIC12F609 (ISP) [ISP-  
HEADER01]  
PIC12F609@DFN8 [(BBBB)]  
PIC12F609@DFN8 (ISP) [ISP-HEADER01]

PIC12F609@SOIC8 [(SA602A)]  
PIC12F609@SOIC8(ISP) [ISP-HEADER01]  
PIC12F615 PIC12F615(ISP) [ISP-  
HEADER01]  
PIC12F615@DFN8 [(BBBB)]  
PIC12F615@DFN8(ISP) [ISP-HEADER01]  
PIC12F615@SOIC8 [(SA602A)]  
PIC12F615@SOIC8(ISP) [ISP-HEADER01]  
PIC12F629 PIC12F629(ISP) [ISP-  
HEADER01]  
PIC12F629(SM)@SOIC8 [(SA605A)]  
PIC12F629(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F629(SN)@SOIC8 [(SA602A)]  
PIC12F629(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F629@DFN8 [(SA683)]  
PIC12F629@DFN8(ISP) [ISP-HEADER01]  
PIC12F635 PIC12F635(ISP) [ISP-  
HEADER01]  
PIC12F635(MD)@DFN8 [(SA744)]  
PIC12F635(MD)@DFN8(ISP) [ISP-HEADER01]  
PIC12F635(MF)@DFN8 [(SA683)]  
PIC12F635(MF)@DFN8(ISP) [ISP-HEADER01]  
PIC12F635(SM)@SOIC8 [(SA605A)]  
PIC12F635(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F635(SN)@SOIC8 [(SA602A)]  
PIC12F635(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F675 PIC12F675(ISP) [ISP-  
HEADER01]  
PIC12F675(SM)@SOIC8 [(SA605A)]  
PIC12F675(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F675(SN)@SOIC8 [(SA602A)]  
PIC12F675(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F675@DFN8 [(SA683)]  
PIC12F675@DFN8(ISP) [ISP-HEADER01]  
PIC12F675@SSOP20 [(SA626A)]  
PIC12F675@SSOP20(ISP) [ISP-HEADER01]  
PIC12F683 PIC12F683(ISP) [ISP-  
HEADER01]  
PIC12F683(MD)@DFN8 [(SA744)]  
PIC12F683(MD)@DFN8(ISP) [ISP-HEADER01]  
PIC12F683(MF)@DFN8 [(SA683)]  
PIC12F683(MF)@DFN8(ISP) [ISP-HEADER01]  
PIC12F683(SM)@SOIC8 [(SA605A)]

PIC12F683(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F683(SN)@SOIC8 [(SA602A)]  
PIC12F683(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12HV609 PIC12HV609(ISP) [ISP-  
HEADER01]  
PIC12HV609@DFN8 [(BBBB)]  
PIC12HV609@DFN8(ISP) [ISP-HEADER01]  
PIC12HV609@SOIC8 [(SA602A)]  
PIC12HV609@SOIC8(ISP) [ISP-HEADER01]  
PIC12HV615 PIC12HV615(ISP) [ISP-  
HEADER01]  
PIC12HV615@DFN8 [(BBBB)]  
PIC12HV615@DFN8(ISP) [ISP-HEADER01]  
PIC12HV615@SOIC8 [(SA602A)]  
PIC12HV615@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC508 PIC12LC508(ISP) [ISP-  
HEADER01]  
PIC12LC508@SOIC8 [(SA605A)]  
PIC12LC508@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC508A PIC12LC508A(ISP) [ISP-  
HEADER01]  
PIC12LC508A(SM)@SOIC8 [(SA605A)]  
PIC12LC508A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC508A(SN)@SOIC8 [(SA602A)]  
PIC12LC508A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509 PIC12LC509(ISP) [ISP-  
HEADER01]  
PIC12LC509(SM)@SOIC8 [(SA605A)]  
PIC12LC509(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509(SN)@SOIC8 [(SA602A)]  
PIC12LC509(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509A PIC12LC509A(ISP) [ISP-  
HEADER01]  
PIC12LC509A(SM)@SOIC8 [(SA605A)]  
PIC12LC509A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509A(SN)@SOIC8 [(SA602A)]  
PIC12LC509A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC671 PIC12LC671(ISP) [ISP-  
HEADER01]  
PIC12LC671@DFN8 [(SA683)]  
PIC12LC671@DFN8(ISP) [ISP-HEADER01]  
PIC12LC671@SOIC8 [(SA605A)]  
PIC12LC671@SOIC8(ISP) [ISP-HEADER01]

PIC12LC672 HEADER01 ]	PIC12LC672(ISP) [ISP-
PIC12LC672@DFN8 [(SA683)]	
PIC12LC672@DFN8(ISP) [ISP-HEADER01 ]	
PIC12LC672@SOIC8 [(SA605A)]	
PIC12LC672@SOIC8(ISP) [ISP-HEADER01 ]	
PIC12LF508 HEADER01 ]	PIC12LF508(ISP) [ISP-
PIC12LF508@MSOP8 [(SA666)]	
PIC12LF508@MSOP8(ISP) [ISP-HEADER01 ]	
PIC12LF508@SOIC8 [(SA602)]	
PIC12LF508@SOIC8(ISP) [ISP-HEADER01 ]	
PIC12LF509 HEADER01 ]	PIC12LF509(ISP) [ISP-
PIC12LF509@MSOP8 [(SA666)]	
PIC12LF509@MSOP8(ISP) [ISP-HEADER01 ]	
PIC12LF509@SOIC8 [(SA602)]	
PIC12LF509@SOIC8(ISP) [ISP-HEADER01 ]	
PIC14000 HEADER01 ]	PIC14000(ISP) [ISP-
PIC14000@SOIC28 [(SA404)]	
PIC14000@SOIC28(ISP) [ISP-HEADER01 ]	
PIC14000@SSOP28 [(SA626A)]	
PIC14000@SSOP28(ISP) [ISP-HEADER01 ]	
PIC16C432 HEADER01 ]	PIC16C432(ISP) [ISP-
PIC16C432@SSOP20 [(SA626A)]	
PIC16C432@SSOP20(ISP) [ISP-HEADER01 ]	
PIC16C433 HEADER01 ]	PIC16C433(ISP) [ISP-
PIC16C433@SOIC18 [(SA404)]	
PIC16C433@SOIC18(ISP) [ISP-HEADER01 ]	
PIC16C505 [(SA602)]	PIC16C505@SOIC14
PIC16C52 [(SA404)]	PIC16C52@SOIC18
PIC16C54 [(SA404)]	PIC16C54@SOIC18
PIC16C54A [(SA404)]	PIC16C54A@SOIC18
PIC16C54A@SSOP20 [(SA626A)]	
PIC16C54B	
PIC16C54B@SOIC18 [(SA404)]	PIC16C54B@SSOP20



[(SA626A)]  
 PIC16C54C PIC16C54C@SOIC18  
 [(SA404)]  
 PIC16C54C@SSOP20 [(SA626A)]  
 PIC16C55  
 PIC16C55@SOIC28 [(SA404)]  
 PIC16C554  
 PIC16C554(ISP) [ISP-HEADER01] PIC16C554@SOIC18  
 [(SA404)]  
 PIC16C554@SOIC18(ISP) [ISP-HEADER01]  
 PIC16C554@SSOP20 [(SA626A)]  
 PIC16C554@SSOP20(ISP) [ISP-HEADER01]  
 PIC16C556 PIC16C556(ISP) [ISP-  
 HEADER01]  
 PIC16C556@SOIC18 [(SA404)]  
 PIC16C556@SOIC18(ISP) [ISP-HEADER01]  
 PIC16C558 PIC16C558(ISP) [ISP-  
 HEADER01]  
 PIC16C558@SOIC18 [(SA404)]  
 PIC16C558@SOIC18(ISP) [ISP-HEADER01]  
 PIC16C558@SSOP20 [(SA626A)]  
 PIC16C558@SSOP20(ISP) [ISP-HEADER01]  
 PIC16C55A PIC16C55A@SOIC28  
 [(SA404)]  
 PIC16C55A@SSOP28 [(SA626A)]  
 PIC16C56  
 PIC16C56@SOIC18 [(SA404)]  
 PIC16C56A  
 PIC16C56A@SOIC18 [(SA404)] PIC16C56A@SSOP20  
 [(SA626A)]  
 PIC16C57 PIC16C57@SOIC28  
 [(SA404)]  
 PIC16C57@SSOP28 [(SA626A)]  
 PIC16C57C  
 PIC16C57C@SOIC28 [(SA404)] PIC16C57C@SSOP28  
 [(SA626A)]  
 PIC16C58 PIC16C58@SOIC18  
 [(SA404)]  
 PIC16C58A PIC16C58A@SOIC18  
 [(SA404)]  
 PIC16C58A@SSOP20 [(SA626A)]  
 PIC16C58B  
 PIC16C58B@SOIC18 [(SA404)] PIC16C58B@SSOP20

[ (SA626A) ]  
PIC16C61 PIC16C61(ISP) [ISP-  
HEADER01]  
PIC16C61@SOIC18 [ (SA404) ]  
PIC16C61@SOIC18(ISP) [ISP-HEADER01]  
PIC16C62 PIC16C62(ISP) [ISP-  
HEADER01]  
PIC16C62@SOIC28 [ (SA404) ]  
PIC16C62@SOIC28(ISP) [ISP-HEADER01]  
PIC16C62@SSOP28 [ (SA626A) ]  
PIC16C62@SSOP28(ISP) [ISP-HEADER01]  
PIC16C620 PIC16C620(ISP) [ISP-  
HEADER01]  
PIC16C620@SOIC18 [ (SA404) ]  
PIC16C620@SOIC18(ISP) [ISP-HEADER01]  
PIC16C620A PIC16C620A(ISP) [ISP-  
HEADER01]  
PIC16C620A@SOIC18 [ (SA404) ]  
PIC16C620A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C620A@SSOP20 [ (SA626A) ]  
PIC16C620A@SSOP20(ISP) [ISP-HEADER01]  
PIC16C621 PIC16C621(ISP) [ISP-  
HEADER01]  
PIC16C621@SOIC18 [ (SA404) ]  
PIC16C621@SOIC18(ISP) [ISP-HEADER01]  
PIC16C621A PIC16C621A(ISP) [ISP-  
HEADER01]  
PIC16C621A@SOIC18 [ (SA404) ]  
PIC16C621A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C621A@SSOP20 [ (SA626A) ]  
PIC16C621A@SSOP20(ISP) [ISP-HEADER01]  
PIC16C622 PIC16C622(ISP) [ISP-  
HEADER01]  
PIC16C622@SOIC18 [ (SA404) ]  
PIC16C622@SOIC18(ISP) [ISP-HEADER01]  
PIC16C622A PIC16C622A(ISP) [ISP-  
HEADER01]  
PIC16C622A@SOIC18 [ (SA404) ]  
PIC16C622A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C622A@SSOP20 [ (SA626A) ]  
PIC16C622A@SSOP20(ISP) [ISP-HEADER01]  
PIC16C625 PIC16C625(ISP) [ISP-  
HEADER01]

PIC16C625@SOIC18 [(SA404)]  
PIC16C625@SOIC18(ISP) [ISP-HEADER01]  
PIC16C62A PIC16C62A(ISP) [ISP-  
HEADER01]  
PIC16C62A@SOIC28 [(SA404)]  
PIC16C62A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C62A@SSOP28 [(SA626A)]  
PIC16C62A@SSOP28(ISP) [ISP-HEADER01]  
PIC16C62B PIC16C62B(ISP) [ISP-  
HEADER01]  
PIC16C62B@SOIC28 [(SA404)]  
PIC16C62B@SOIC28(ISP) [ISP-HEADER01]  
PIC16C62B@SSOP28 [(SA626A)]  
PIC16C62B@SSOP28(ISP) [ISP-HEADER01]  
PIC16C63 PIC16C63(ISP) [ISP-  
HEADER01]  
PIC16C63@SOIC28 [(SA404)]  
PIC16C63@SOIC28(ISP) [ISP-HEADER01]  
PIC16C63A PIC16C63A(ISP) [ISP-  
HEADER01]  
PIC16C63A@SOIC28 [(SA404)]  
PIC16C63A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C63A@SSOP28 [(SA626A)]  
PIC16C63A@SSOP28(ISP) [ISP-HEADER01]  
PIC16C64 PIC16C64(ISP) [ISP-  
HEADER01]  
PIC16C64@PLCC44 [(SA244)]  
PIC16C64@PLCC44(ISP) [ISP-HEADER01]  
PIC16C64@TQFP44 [(SA245A)]  
PIC16C64@TQFP44(ISP) [ISP-HEADER01]  
PIC16C641 PIC16C641@SOIC28  
[(SA404)]  
PIC16C641@SSOP28 [(SA626A)]  
PIC16C642 PIC16C642@SSOP28  
[(SA626A)]  
PIC16C64A PIC16C64A(ISP) [ISP-  
HEADER01]  
PIC16C64A@PLCC44 [(SA244)]  
PIC16C64A@PLCC44(ISP) [ISP-HEADER01]  
PIC16C64A@TQFP44 [(SA245A)]  
PIC16C64A@TQFP44(ISP) [ISP-HEADER01]  
PIC16C65 PIC16C65(ISP) [ISP-

HEADER01 ]  
PIC16C65@PLCC44 [ (SA244) ]  
PIC16C65@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16C65@TQFP44 [ (SA245A) ]  
PIC16C65@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16C65A PIC16C65A(ISP) [ ISP-  
HEADER01 ]  
PIC16C65A@PLCC44 [ (SA244) ]  
PIC16C65A@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16C65A@TQFP44 [ (SA245A) ]  
PIC16C65A@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16C65B PIC16C65B(ISP) [ ISP-  
HEADER01 ]  
PIC16C65B@PLCC44 [ (SA244) ]  
PIC16C65B@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16C65B@TQFP44 [ (SA245A) ]  
PIC16C65B@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16C66 PIC16C66(ISP) [ ISP-  
HEADER01 ]  
PIC16C66@SOIC28 [ (SA404) ]  
PIC16C66@SOIC28(ISP) [ ISP-HEADER01 ]  
PIC16C661 PIC16C661@PLCC44  
[ (SA244) ]  
PIC16C661@TQFP44 [ (SA245A) ]  
PIC16C662  
PIC16C662@PLCC44 [ (SA244) ] PIC16C662@TQFP44  
[ (SA245A) ]  
PIC16C67 PIC16C67(ISP) [ ISP-  
HEADER01 ]  
PIC16C67@PLCC44 [ (SA244) ]  
PIC16C67@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16C67@TQFP44 [ (SA245A) ]  
PIC16C67@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16C70 PIC16C70(ISP) [ ISP-  
HEADER01 ]  
PIC16C70@SOIC18 [ (SA404) ]  
PIC16C70@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16C71 PIC16C71(ISP) [ ISP-  
HEADER01 ]  
PIC16C71@SOIC18 [ (SA404) ]  
PIC16C71@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16C710 PIC16C710(ISP) [ ISP-  
HEADER01 ]

PIC16C710@SOIC18 [(SA404)]  
PIC16C710@SOIC18(ISP) [ISP-HEADER01]  
PIC16C710@SSOP20 [(SA626A)]  
PIC16C710@SSOP20(ISP) [ISP-HEADER01]  
PIC16C711 PIC16C711(ISP) [ISP-  
HEADER01]  
PIC16C711@SOIC18 [(SA404)]  
PIC16C711@SOIC18(ISP) [ISP-HEADER01]  
PIC16C711@SSOP20 [(SA626A)]  
PIC16C711@SSOP20(ISP) [ISP-HEADER01]  
PIC16C712 PIC16C712(ISP) [ISP-  
HEADER01]  
PIC16C712@SOIC18 [(SA404)]  
PIC16C712@SOIC18(ISP) [ISP-HEADER01]  
PIC16C712@SSOP20 [(SA626A)]  
PIC16C712@SSOP20(ISP) [ISP-HEADER01]  
PIC16C715 PIC16C715@SOIC18  
[(SA404)]  
PIC16C715@SSOP20 [(SA626A)]  
PIC16C716 PIC16C716@SOIC18  
PIC16C716(ISP) [ISP-HEADER01]  
[(SA404)]  
PIC16C716@SOIC18(ISP) [ISP-HEADER01]  
PIC16C716@SSOP20 [(SA626A)]  
PIC16C716@SSOP20(ISP) [ISP-HEADER01]  
PIC16C717 PIC16C717(ISP) [ISP-  
HEADER01]  
PIC16C717@SOIC18 [(SA404)]  
PIC16C717@SOIC18(ISP) [ISP-HEADER01]  
PIC16C717@SSOP20 [(SA626A)]  
PIC16C717@SSOP20(ISP) [ISP-HEADER01]  
PIC16C71A PIC16C71A(ISP) [ISP-  
HEADER01]  
PIC16C71A@SOIC18 [(SA404)]  
PIC16C71A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C72 PIC16C72(ISP) [ISP-  
HEADER01]  
PIC16C72@SOIC28 [(SA404)]  
PIC16C72@SOIC28(ISP) [ISP-HEADER01]  
PIC16C72@SSOP28 [(SA626A)]  
PIC16C72@SSOP28(ISP) [ISP-HEADER01]  
PIC16C72A PIC16C72A(ISP) [ISP-  
HEADER01]

PIC16C72A@SOIC28 [(SA404)]  
PIC16C72A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C72A@SSOP28 [(SA626A)]  
PIC16C72A@SSOP28(ISP) [ISP-HEADER01]  
PIC16C73 PIC16C73(ISP) [ISP-  
HEADER01]  
PIC16C73@SOIC28 [(SA404)]  
PIC16C73@SOIC28(ISP) [ISP-HEADER01]  
PIC16C73A PIC16C73A(ISP) [ISP-  
HEADER01]  
PIC16C73A@SOIC28 [(SA404)]  
PIC16C73A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C73B PIC16C73B(ISP) [ISP-  
HEADER01]  
PIC16C73B@SOIC28 [(SA404)]  
PIC16C73B@SOIC28(ISP) [ISP-HEADER01]  
PIC16C73B@SSOP28 [(SA626A)]  
PIC16C73B@SSOP28(ISP) [ISP-HEADER01]  
PIC16C74 PIC16C74(ISP) [ISP-  
HEADER01]  
PIC16C74@PLCC44 [(SA244)]  
PIC16C74@PLCC44(ISP) [ISP-HEADER01]  
PIC16C74@TQFP44 [(SA245A)]  
PIC16C74@TQFP44(ISP) [ISP-HEADER01]  
PIC16C745 PIC16C745(ISP) [ISP-  
HEADER01]  
PIC16C745@SOIC28 [(SA404)]  
PIC16C745@SOIC28(ISP) [ISP-HEADER01]  
PIC16C74A PIC16C74A(ISP) [ISP-  
HEADER01]  
PIC16C74A@PLCC44 [(SA244)]  
PIC16C74A@PLCC44(ISP) [ISP-HEADER01]  
PIC16C74A@TQFP44 [(SA245A)]  
PIC16C74A@TQFP44(ISP) [ISP-HEADER01]  
PIC16C74B PIC16C74B(ISP) [ISP-  
HEADER01]  
PIC16C74B@MQFP44 [(SA675)]  
PIC16C74B@MQFP44(ISP) [ISP-HEADER01]  
PIC16C74B@PLCC44 [(SA244)]  
PIC16C74B@PLCC44(ISP) [ISP-HEADER01]  
PIC16C74B@TQFP44 [(SA245A)]  
PIC16C74B@TQFP44(ISP) [ISP-HEADER01]  
PIC16C76 PIC16C76(ISP) [ISP-

HEADER01 ]  
PIC16C76@SOIC28 [(SA404)]  
PIC16C76@SOIC28(ISP) [ISP-HEADER01]  
PIC16C765 PIC16C765(ISP) [ISP-  
HEADER01]  
PIC16C765@PLCC44 [(SA244)]  
PIC16C765@PLCC44(ISP) [ISP-HEADER01]  
PIC16C765@TQFP44 [(SA245A)]  
PIC16C765@TQFP44(ISP) [ISP-HEADER01]  
PIC16C77 PIC16C77(ISP) [ISP-  
HEADER01]  
PIC16C77@PLCC44 [(SA244)]  
PIC16C77@PLCC44(ISP) [ISP-HEADER01]  
PIC16C77@TQFP44 [(SA245A)]  
PIC16C77@TQFP44(ISP) [ISP-HEADER01]  
PIC16C770 PIC16C770(ISP) [ISP-  
HEADER01]  
PIC16C770@SOIC20 [(SA404)]  
PIC16C770@SOIC20(ISP) [ISP-HEADER01]  
PIC16C770@SSOP20 [(SA626A)]  
PIC16C770@SSOP20(ISP) [ISP-HEADER01]  
PIC16C771 PIC16C771(ISP) [ISP-  
HEADER01]  
PIC16C771@SOIC20 [(SA404)]  
PIC16C771@SOIC20(ISP) [ISP-HEADER01]  
PIC16C771@SSOP20 [(SA626A)]  
PIC16C771@SSOP20(ISP) [ISP-HEADER01]  
PIC16C773 PIC16C773(ISP) [ISP-  
HEADER01]  
PIC16C773@SOIC28 [(SA404)]  
PIC16C773@SOIC28(ISP) [ISP-HEADER01]  
PIC16C773@SSOP28 [(SA626A)]  
PIC16C773@SSOP28(ISP) [ISP-HEADER01]  
PIC16C774 PIC16C774(ISP) [ISP-  
HEADER01]  
PIC16C774@PLCC44 [(SA244)]  
PIC16C774@PLCC44(ISP) [ISP-HEADER01]  
PIC16C774@TQFP44 [(SA675)]  
PIC16C774@TQFP44(ISP) [ISP-HEADER01]  
PIC16C781 PIC16C781(ISP) [ISP-  
HEADER01]  
PIC16C781@SOIC20 [(SA404)]  
PIC16C781@SOIC20(ISP) [ISP-HEADER01]

PIC16C781@SSOP20 [(SA626A)]  
PIC16C781@SSOP20(ISP) [ISP-HEADER01]  
PIC16C782 PIC16C782(ISP) [ISP-  
HEADER01]  
PIC16C782@SOIC20 [(SA404)]  
PIC16C782@SOIC20(ISP) [ISP-HEADER01]  
PIC16C782@SSOP20 [(SA626A)]  
PIC16C782@SSOP20(ISP) [ISP-HEADER01]  
PIC16C84 PIC16C84(ISP) [ISP-  
HEADER01]  
PIC16C84@SOIC18 [(SA404)]  
PIC16C84@SOIC18(ISP) [ISP-HEADER01]  
PIC16C923@PLCC68 [(PEP+S414T)]  
PIC16C923@PLCC68(\*) [(SA648-B6807)]  
PIC16C923@PLCC68(ISP) [ISP-HEADER01]  
PIC16C923@SDIP64 [(PEP+S600A)]  
PIC16C923@SDIP64(ISP) [ISP-HEADER01]  
PIC16C923@TQFP64 [(PEP+S616)]  
PIC16C923@TQFP64(ISP) [ISP-HEADER01]  
PIC16C924@PLCC68 [(PEP+S414T)]  
PIC16C924@PLCC68(\*) [(SA648-B6807)]  
PIC16C924@PLCC68(ISP) [ISP-HEADER01]  
PIC16C924@SDIP64 [(PEP+S600A)]  
PIC16C924@SDIP64(ISP) [ISP-HEADER01]  
PIC16C924@TQFP64 [(PEP+S616)]  
PIC16C924@TQFP64(ISP) [ISP-HEADER01]  
PIC16C925@PLCC68 [(PEP+S414T)]  
PIC16C925@PLCC68(\*) [(SA648-B6807)]  
PIC16C925@PLCC68(ISP) [ISP-HEADER01]  
PIC16C925@TQFP64 [(PEP+S616)]  
PIC16C925@TQFP64(ISP) [ISP-HEADER01]  
PIC16C926@PLCC68 [(PEP+S414T)]  
PIC16C926@PLCC68(\*) [(SA648-B6807)]  
PIC16C926@PLCC68(ISP) [ISP-HEADER01]  
PIC16C926@TQFP64 [(PEP+S616)]  
PIC16C926@TQFP64(ISP) [ISP-HEADER01]  
PIC16CE623 PIC16CE623(ISP) [ISP-  
HEADER01]  
PIC16CE623@SOIC18 [(SA404)]  
PIC16CE623@SOIC18(ISP) [ISP-HEADER01]  
PIC16CE624 PIC16CE624(ISP) [ISP-  
HEADER01]  
PIC16CE624@SOIC18 [(SA404)]



PIC16CE624@SOIC18(ISP) [ISP-HEADER01]  
PIC16CE625 PIC16CE625(ISP) [ISP-  
HEADER01]  
PIC16CE625@SOIC18 [(SA404)]  
PIC16CE625@SOIC18(ISP) [ISP-HEADER01]  
PIC16CE625@SSOP20 [(SA626A)]  
PIC16CE625@SSOP20(ISP) [ISP-HEADER01]  
PIC16CR83 PIC16CR83(ISP) [ISP-  
HEADER01]  
PIC16CR83@SOIC18 [(SA404)]  
PIC16CR83@SOIC18(ISP) [ISP-HEADER01]  
PIC16CR84 PIC16CR84(ISP) [ISP-  
HEADER01]  
PIC16CR84@SOIC18 [(SA404)]  
PIC16CR84@SOIC18(ISP) [ISP-HEADER01]  
PIC16F505 PIC16F505(ISP) [ISP-  
HEADER01]  
PIC16F505@SOIC14 [(SA602)]  
PIC16F505@SOIC14(ISP) [ISP-HEADER01]  
PIC16F505@TSSOP14 [(SA026)]  
PIC16F505@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F506 PIC16F506(ISP) [ISP-  
HEADER01]  
PIC16F506@SOIC14 [(SA602)]  
PIC16F506@SOIC14(ISP) [ISP-HEADER01]  
PIC16F506@TSSOP14 [(SA026)]  
PIC16F506@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F54 PIC16F54(ISP) [ISP-  
HEADER01]  
PIC16F54@SOIC18 [(SA404)]  
PIC16F54@SOIC18(ISP) [ISP-HEADER01]  
PIC16F54@SSOP20 [(SA626A)]  
PIC16F54@SSOP20(ISP) [ISP-HEADER01]  
PIC16F57 PIC16F57(ISP) [ISP-  
HEADER01]  
PIC16F57@SOIC28 [(SA404)]  
PIC16F57@SOIC28(ISP) [ISP-HEADER01]  
PIC16F57@SSOP28 [(SA626A)]  
PIC16F57@SSOP28(ISP) [ISP-HEADER01]  
PIC16F59 PIC16F59(ISP) [ISP-  
HEADER01]  
PIC16F59@PLCC44 [(SA244)]  
PIC16F59@PLCC44(ISP) [ISP-HEADER01]

PIC16F59@TQFP44 [(SA245A)]  
PIC16F59@TQFP44(ISP) [ISP-HEADER01]  
PIC16F610 PIC16F610(ISP) [ISP-  
HEADER01]  
PIC16F610@QFN16 [(SA727)]  
PIC16F610@QFN16(ISP) [ISP-HEADER01]  
PIC16F610@SOIC14 [(SA602)]  
PIC16F610@SOIC14(ISP) [ISP-HEADER01]  
PIC16F610@TSSOP14 [(SA026)]  
PIC16F610@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F616 PIC16F616(ISP) [ISP-  
HEADER01]  
PIC16F616@QFN16 [(SA727)]  
PIC16F616@QFN16(ISP) [ISP-HEADER01]  
PIC16F616@SOIC14 [(SA602)]  
PIC16F616@SOIC14(ISP) [ISP-HEADER01]  
PIC16F616@TSSOP14 [(SA026)]  
PIC16F616@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F627 PIC16F627(ISP) [ISP-  
HEADER01]  
PIC16F627@SOIC18 [(SA404)]  
PIC16F627@SOIC18(ISP) [ISP-HEADER01]  
PIC16F627@SSOP20 [(SA626A)]  
PIC16F627@SSOP20(ISP) [ISP-HEADER01]  
PIC16F627A PIC16F627A(ISP) [ISP-  
HEADER01]  
PIC16F627A@SOIC18 [(SA404)]  
PIC16F627A@SOIC18(ISP) [ISP-HEADER01]  
PIC16F627A@SSOP20 [(SA626A)]  
PIC16F627A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F628 PIC16F628(ISP) [ISP-  
HEADER01]  
PIC16F628@SOIC18 [(SA404)]  
PIC16F628@SOIC18(ISP) [ISP-HEADER01]  
PIC16F628@SSOP20 [(SA626A)]  
PIC16F628@SSOP20(ISP) [ISP-HEADER01]  
PIC16F628A PIC16F628A(ISP) [ISP-  
HEADER01]  
PIC16F628A@SOIC18 [(SA404)]  
PIC16F628A@SOIC18(ISP) [ISP-HEADER01]  
PIC16F628A@SSOP20 [(SA626A)]  
PIC16F628A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F630 PIC16F630(ISP) [ISP-

HEADER01 ]  
PIC16F630@SOIC14 [(SA602)]  
PIC16F630@SOIC14(ISP) [ISP-HEADER01]  
PIC16F630@TSSOP14 [(SA026)]  
PIC16F630@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F631 PIC16F631(ISP) [ISP-  
HEADER01]  
PIC16F631@QFN20 [(SA692)]  
PIC16F631@QFN20(ISP) [ISP-HEADER01]  
PIC16F631@SOIC20 [(SA404)]  
PIC16F631@SOIC20(ISP) [ISP-HEADER01]  
PIC16F631@SSOP20 [(SA626A)]  
PIC16F631@SSOP20(ISP) [ISP-HEADER01]  
PIC16F636 PIC16F636(ISP) [ISP-  
HEADER01]  
PIC16F636@SOIC14 [(SA602)]  
PIC16F636@SOIC14(ISP) [ISP-HEADER01]  
PIC16F636@TSSOP14 [(SA026)]  
PIC16F636@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F639 PIC16F639(ISP) [ISP-  
HEADER01]  
PIC16F639@QFN20 [(SA692)]  
PIC16F639@QFN20(ISP) [ISP-HEADER01]  
PIC16F639@SOIC20 [(SA404)]  
PIC16F639@SOIC20(ISP) [ISP-HEADER01]  
PIC16F639@SSOP20 [(SA626A)]  
PIC16F639@SSOP20(ISP) [ISP-HEADER01]  
PIC16F648A PIC16F648A(ISP) [ISP-  
HEADER01]  
PIC16F648A@SOIC18 [(SA404)]  
PIC16F648A@SOIC18(ISP) [ISP-HEADER01]  
PIC16F648A@SSOP20 [(SA626A)]  
PIC16F648A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F676 PIC16F676(ISP) [ISP-  
HEADER01]  
PIC16F676@SOIC14 [(SA602)]  
PIC16F676@SOIC14(ISP) [ISP-HEADER01]  
PIC16F676@TSSOP14 [(SA026)]  
PIC16F676@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F677 PIC16F677(ISP) [ISP-  
HEADER01]  
PIC16F677@QFN20 [(SA692)]  
PIC16F677@QFN20(ISP) [ISP-HEADER01]

PIC16F677@SOIC20 [(SA404)]  
PIC16F677@SOIC20(ISP) [ISP-HEADER01]  
PIC16F677@SSOP20 [(SA626A)]  
PIC16F677@SSOP20(ISP) [ISP-HEADER01]  
PIC16F684 PIC16F684(ISP) [ISP-  
HEADER01]  
PIC16F684@SOIC14 [(SA602)]  
PIC16F684@SOIC14(ISP) [ISP-HEADER01]  
PIC16F684@TSSOP14 [(SA026)]  
PIC16F684@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F685 PIC16F685(ISP) [ISP-  
HEADER01]  
PIC16F685@QFN20 [(SA692)]  
PIC16F685@QFN20(ISP) [ISP-HEADER01]  
PIC16F685@SOIC20 [(SA404)]  
PIC16F685@SOIC20(ISP) [ISP-HEADER01]  
PIC16F685@SSOP20 [(SA626A)]  
PIC16F685@SSOP20(ISP) [ISP-HEADER01]  
PIC16F687 PIC16F687(ISP) [ISP-  
HEADER01]  
PIC16F687@QFN20 [(SA692)]  
PIC16F687@QFN20(ISP) [ISP-HEADER01]  
PIC16F687@SOIC20 [(SA404)]  
PIC16F687@SOIC20(ISP) [ISP-HEADER01]  
PIC16F687@SSOP20 [(SA626A)]  
PIC16F687@SSOP20(ISP) [ISP-HEADER01]  
PIC16F688 PIC16F688(ISP) [ISP-  
HEADER01]  
PIC16F688@SOIC14 [(SA602)]  
PIC16F688@SOIC14(ISP) [ISP-HEADER01]  
PIC16F688@TSSOP14 [(SA026)]  
PIC16F688@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F689 PIC16F689(ISP) [ISP-  
HEADER01]  
PIC16F689@QFN20 [(SA692)]  
PIC16F689@QFN20(ISP) [ISP-HEADER01]  
PIC16F689@SOIC20 [(SA404)]  
PIC16F689@SOIC20(ISP) [ISP-HEADER01]  
PIC16F689@SSOP20 [(SA626A)]  
PIC16F689@SSOP20(ISP) [ISP-HEADER01]  
PIC16F690 PIC16F690(ISP) [ISP-  
HEADER01]  
PIC16F690@QFN20 [(SA692)]

PIC16F690@QFN20(ISP) [ISP-HEADER01]  
PIC16F690@SOIC20 [(SA404)]  
PIC16F690@SOIC20(ISP) [ISP-HEADER01]  
PIC16F690@SSOP20 [(SA626A)]  
PIC16F690@SSOP20(ISP) [ISP-HEADER01]  
PIC16F716 PIC16F716(ISP) [ISP-  
HEADER01]  
PIC16F716@SOIC18 [(SA404)]  
PIC16F716@SOIC18(ISP) [ISP-HEADER01]  
PIC16F716@SSOP20 [(SA626A)]  
PIC16F716@SSOP20(ISP) [ISP-HEADER01]  
PIC16F72 PIC16F72(ISP) [ISP-  
HEADER01]  
PIC16F72@QFN28 [(SA685-B006)]  
PIC16F72@QFN28(ISP) [ISP-HEADER01]  
PIC16F72@SOIC28 [(SA404)]  
PIC16F72@SOIC28(ISP) [ISP-HEADER01]  
PIC16F72@SSOP28 [(SA626A)]  
PIC16F72@SSOP28(ISP) [ISP-HEADER01]  
PIC16F722 PIC16F722@QFN28 [(SA685-  
B006)]  
PIC16F722@SOIC28 [(SA404)] PIC16F722@SSOP28  
[(SA626A)]  
PIC16F723 PIC16F723@QFN28 [(SA685-  
B006)]  
PIC16F723@SOIC28 [(SA404)] PIC16F723@SSOP28  
[(SA626A)]  
PIC16F724 PIC16F724@QFN44  
[(SA737)]  
PIC16F724@TQFP44 [(SA245A)]  
PIC16F726 PIC16F726@SOIC28  
PIC16F726@QFN28 [(SA685-B006)]  
[(SA404)]  
PIC16F726@SSOP28 [(SA626A)]  
PIC16F727 PIC16F727@TQFP44  
PIC16F727@QFN44 [(SA737)]  
[(SA245A)]  
PIC16F73 PIC16F73(ISP) [ISP-  
HEADER01]  
PIC16F73@SOIC28 [(SA404)]  
PIC16F73@SOIC28(ISP) [ISP-HEADER01]  
PIC16F73@SSOP28 [(SA626A)]  
PIC16F73@SSOP28(ISP) [ISP-HEADER01]

PIC16F737 PIC16F737(ISP) [ISP-  
HEADER01]  
PIC16F737@SOIC28 [(SA404)]  
PIC16F737@SOIC28(ISP) [ISP-HEADER01]  
PIC16F737@SSOP28 [(SA626A)]  
PIC16F737@SSOP28(ISP) [ISP-HEADER01]  
PIC16F74 PIC16F74(ISP) [ISP-  
HEADER01]  
PIC16F74@PLCC44 [(SA244)]  
PIC16F74@PLCC44(ISP) [ISP-HEADER01]  
PIC16F74@TQFP44 [(SA245A)]  
PIC16F74@TQFP44(ISP) [ISP-HEADER01]  
PIC16F747 PIC16F747(ISP) [ISP-  
HEADER01]  
PIC16F747@TQFP44 [(SA245A)]  
PIC16F747@TQFP44(ISP) [ISP-HEADER01]  
PIC16F76 PIC16F76(ISP) [ISP-  
HEADER01]  
PIC16F76@SOIC28 [(SA404)]  
PIC16F76@SOIC28(ISP) [ISP-HEADER01]  
PIC16F76@SSOP28 [(SA626A)]  
PIC16F76@SSOP28(ISP) [ISP-HEADER01]  
PIC16F767 PIC16F767(ISP) [ISP-  
HEADER01]  
PIC16F767@SOIC28 [(SA404)]  
PIC16F767@SOIC28(ISP) [ISP-HEADER01]  
PIC16F767@SSOP28 [(SA626A)]  
PIC16F767@SSOP28(ISP) [ISP-HEADER01]  
PIC16F77 PIC16F77(ISP) [ISP-  
HEADER01]  
PIC16F77@PLCC44 [(SA244)]  
PIC16F77@PLCC44(ISP) [ISP-HEADER01]  
PIC16F77@TQFP44 [(SA245A)]  
PIC16F77@TQFP44(ISP) [ISP-HEADER01]  
PIC16F777 PIC16F777(ISP) [ISP-  
HEADER01]  
PIC16F777@TQFP44 [(SA245A)]  
PIC16F777@TQFP44(ISP) [ISP-HEADER01]  
PIC16F785 PIC16F785(ISP) [ISP-  
HEADER01]  
PIC16F785@QFN20 [(SA692)]  
PIC16F785@QFN20(ISP) [ISP-HEADER01]  
PIC16F785@SOIC20 [(SA404)]

PIC16F785@SOIC20(ISP) [ISP-HEADER01]  
PIC16F785@SSOP20 [(SA626A)]  
PIC16F785@SSOP20(ISP) [ISP-HEADER01]  
PIC16F818 PIC16F818(ISP) [ISP-  
HEADER01]  
PIC16F818@QFN28 [(SA685-B006)]  
PIC16F818@QFN28(ISP) [ISP-HEADER01]  
PIC16F818@SOIC18 [(SA404)]  
PIC16F818@SOIC18(ISP) [ISP-HEADER01]  
PIC16F818@SSOP20 [(SA626A)]  
PIC16F818@SSOP20(ISP) [ISP-HEADER01]  
PIC16F819 PIC16F819(ISP) [ISP-  
HEADER01]  
PIC16F819@QFN28 [(SA685-B006)]  
PIC16F819@QFN28(ISP) [ISP-HEADER01]  
PIC16F819@SOIC18 [(SA404)]  
PIC16F819@SOIC18(ISP) [ISP-HEADER01]  
PIC16F819@SSOP20 [(SA626A)]  
PIC16F819@SSOP20(ISP) [ISP-HEADER01]  
PIC16F83 PIC16F83(ISP) [ISP-  
HEADER01]  
PIC16F83@SOIC18 [(SA404)]  
PIC16F83@SOIC18(ISP) [ISP-HEADER01]  
PIC16F84 PIC16F84(ISP) [ISP-  
HEADER01]  
PIC16F84@SOIC18 [(SA404)]  
PIC16F84@SOIC18(ISP) [ISP-HEADER01]  
PIC16F84A PIC16F84A(ISP) [ISP-  
HEADER01]  
PIC16F84A@SOIC18 [(SA404)]  
PIC16F84A@SOIC18(ISP) [ISP-HEADER01]  
PIC16F84A@SSOP20 [(SA626A)]  
PIC16F84A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F87 PIC16F87(ISP) [ISP-  
HEADER01]  
PIC16F87@QFN28 [(SA685-B006)]  
PIC16F87@QFN28(ISP) [ISP-HEADER01]  
PIC16F87@SOIC18 [(SA404)]  
PIC16F87@SOIC18(ISP) [ISP-HEADER01]  
PIC16F87@SSOP20 [(SA626A)]  
PIC16F87@SSOP20(ISP) [ISP-HEADER01]  
PIC16F870 PIC16F870(ISP) [ISP-  
HEADER01]

PIC16F870@SOIC28 [(SA404)]  
PIC16F870@SOIC28(ISP) [ISP-HEADER01]  
PIC16F870@SSOP28 [(SA626A)]  
PIC16F870@SSOP28(ISP) [ISP-HEADER01]  
PIC16F871 PIC16F871(ISP) [ISP-  
HEADER01]  
PIC16F871@PLCC44 [(SA244)]  
PIC16F871@PLCC44(ISP) [ISP-HEADER01]  
PIC16F871@TQFP44 [(SA245A)]  
PIC16F871@TQFP44(ISP) [ISP-HEADER01]  
PIC16F872 PIC16F872(ISP) [ISP-  
HEADER01]  
PIC16F872@SOIC28 [(SA404)]  
PIC16F872@SOIC28(ISP) [ISP-HEADER01]  
PIC16F872@SSOP28 [(SA626A)]  
PIC16F872@SSOP28(ISP) [ISP-HEADER01]  
PIC16F873 PIC16F873(ISP) [ISP-  
HEADER01]  
PIC16F873@SOIC28 [(SA404)]  
PIC16F873@SOIC28(ISP) [ISP-HEADER01]  
PIC16F873A  
PIC16F873A(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F873A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F873A@QFN28 [(SA697-B006)]  
PIC16F873A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F873A@SOIC28 [(SA404)]  
PIC16F873A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F873A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F873A@SSOP28 [(SA626A)]  
PIC16F873A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F873A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F874 PIC16F874(ISP) [ISP-  
HEADER01]  
PIC16F874@PLCC44 [(SA244)]



PIC16F874@PLCC44(ISP) [ISP-HEADER01]  
PIC16F874@TQFP44 [(SA245A)]  
PIC16F874@TQFP44(ISP) [ISP-HEADER01]  
PIC16F874A  
PIC16F874A(ISP)(High-V) [ISP-HEADER01]  
PIC16F874A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F874A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F874A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F874A@PLCC44 [(SA244)]  
PIC16F874A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16F874A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F874A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F874A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F874A@TQFP44 [(SA245A)]  
PIC16F874A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F874A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F874A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F874A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876 PIC16F876(ISP) [ISP-  
HEADER01]  
PIC16F876@SOIC28 [(SA404)]  
PIC16F876@SOIC28(ISP) [ISP-HEADER01]  
PIC16F876A  
PIC16F876A(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876A@QFN28 [(SA697-B006)]  
PIC16F876A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876A@SOIC28 [(SA404)]  
PIC16F876A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876A@SSOP28 [(SA626A)]  
PIC16F876A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877 PIC16F877(ISP) [ISP-

HEADER01 ]  
PIC16F877@PLCC44 [(SA244)]  
PIC16F877@PLCC44(ISP) [ISP-HEADER01]  
PIC16F877@TQFP44 [(SA245A)]  
PIC16F877@TQFP44(ISP) [ISP-HEADER01]  
PIC16F877A  
PIC16F877A(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F877A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F877A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877A@PLCC44 [(SA244)]  
PIC16F877A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877A@TQFP44 [(SA245A)]  
PIC16F877A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F88 PIC16F88(ISP) [ISP-  
HEADER01]  
PIC16F88@QFN28 [(SA685-B006)]  
PIC16F88@QFN28(ISP) [ISP-HEADER01]  
PIC16F88@SOIC18 [(SA404)]  
PIC16F88@SOIC18(ISP) [ISP-HEADER01]  
PIC16F88@SSOP20 [(SA626A)]  
PIC16F88@SSOP20(ISP) [ISP-HEADER01]  
PIC16F882  
PIC16F882(ISP)(High-V) [ISP-HEADER01]  
PIC16F882(ISP)(Low-V) [ISP-HEADER01]  
PIC16F882@QFN28 [(SA697-B005)]  
PIC16F882@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F882@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F882@SOIC28 [(SA404)]  
PIC16F882@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F882@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F882@SSOP28 [(SA626A)]  
PIC16F882@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F882@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883  
PIC16F883(ISP)(High-V) [ISP-HEADER01]  
PIC16F883(ISP)(Low-V) [ISP-HEADER01]

PIC16F883@QFN28 [(SA697-B005)]  
PIC16F883@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F883@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883@SOIC28 [(SA404)]  
PIC16F883@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F883@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883@SSOP28 [(SA626A)]  
PIC16F883@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F883@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884  
PIC16F884(ISP)(High-V) [ISP-HEADER01]  
PIC16F884(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884@QFN44 [(SA712)]  
PIC16F884@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC16F884@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884@QFN44(ML) [(SA737)]  
PIC16F884@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]  
PIC16F884@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884@TQFP44 [(SA245A)]  
PIC16F884@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F884@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886  
PIC16F886(ISP)(High-V) [ISP-HEADER01]  
PIC16F886(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886@QFN28 [(SA697-B005)]  
PIC16F886@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F886@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886@SOIC28 [(SA404)]  
PIC16F886@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F886@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886@SSOP28 [(SA626A)]  
PIC16F886@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F886@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887  
PIC16F887(ISP)(High-V) [ISP-HEADER01]  
PIC16F887(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887@QFN44 [(SA712)]  
PIC16F887@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC16F887@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887@QFN44(ML) [(SA737)]  
PIC16F887@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]  
PIC16F887@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887@TQFP44 [(SA245A)]

PIC16F887@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F887@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F913 PIC16F913(ISP) [ISP-  
HEADER01]  
PIC16F913@QFN28 [(SA697-B006)]  
PIC16F913@QFN28(ISP) [ISP-HEADER01]  
PIC16F913@SOIC28 [(SA404)]  
PIC16F913@SOIC28(ISP) [ISP-HEADER01]  
PIC16F913@SSOP28 [(SA626A)]  
PIC16F913@SSOP28(ISP) [ISP-HEADER01]  
PIC16F914 PIC16F914(ISP) [ISP-  
HEADER01]  
PIC16F914@QFN44 [(SA712)]  
PIC16F914@QFN44(ISP) [ISP-HEADER01]  
PIC16F914@QFN44(ML) [(SA737)]  
PIC16F914@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16F914@TQFP44 [(SA245A)]  
PIC16F914@TQFP44(ISP) [ISP-HEADER01]  
PIC16F916 PIC16F916(ISP) [ISP-  
HEADER01]  
PIC16F916@QFN28 [(SA697-B006)]  
PIC16F916@QFN28(ISP) [ISP-HEADER01]  
PIC16F916@SOIC28 [(SA404)]  
PIC16F916@SOIC28(ISP) [ISP-HEADER01]  
PIC16F916@SSOP28 [(SA626A)]  
PIC16F916@SSOP28(ISP) [ISP-HEADER01]  
PIC16F917 PIC16F917(ISP) [ISP-  
HEADER01]  
PIC16F917@QFN44 [(SA712)]  
PIC16F917@QFN44(ISP) [ISP-HEADER01]  
PIC16F917@QFN44(ML) [(SA737)]  
PIC16F917@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16F917@TQFP44 [(SA245A)]  
PIC16F917@TQFP44(ISP) [ISP-HEADER01]  
PIC16F946@TQFP64 [(PEP+S616)]  
PIC16F946@TQFP64(ISP) [ISP-HEADER01]  
PIC16HV540 PIC16HV540@SOIC18  
[(SA404)]  
PIC16HV540@SSOP20 [(SA626A)]  
PIC16HV610  
PIC16HV610(ISP) [ISP-HEADER01] PIC16HV610@QFN16  
[(SA727)]  
PIC16HV610@QFN16(ISP) [ISP-HEADER01]

PIC16HV610@SOIC14 [(SA602)]  
PIC16HV610@SOIC14(ISP) [ISP-HEADER01]  
PIC16HV610@TSSOP14 [(SA026)]  
PIC16HV610@TSSOP14(ISP) [ISP-HEADER01]  
PIC16HV616 PIC16HV616(ISP) [ISP-  
HEADER01]  
PIC16HV616@QFN16 [(SA727)]  
PIC16HV616@QFN16(ISP) [ISP-HEADER01]  
PIC16HV616@SOIC14 [(SA602)]  
PIC16HV616@SOIC14(ISP) [ISP-HEADER01]  
PIC16HV616@TSSOP14 [(SA026)]  
PIC16HV616@TSSOP14(ISP) [ISP-HEADER01]  
PIC16HV785 PIC16HV785(ISP) [ISP-  
HEADER01]  
PIC16HV785@QFN20 [(SA692)]  
PIC16HV785@QFN20(ISP) [ISP-HEADER01]  
PIC16HV785@SOIC20 [(SA404)]  
PIC16HV785@SOIC20(ISP) [ISP-HEADER01]  
PIC16HV785@SSOP20 [(SA626A)]  
PIC16HV785@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC505 PIC16LC505@SOIC14  
[(SA602)]  
PIC16LC54A PIC16LC54A@SOIC18  
[(SA404)]  
PIC16LC54A@SSOP20 [(SA626A)]  
PIC16LC54C PIC16LC54C@SSOP20  
[(SA626A)]  
PIC16LC54C@SOIC18 [(SA404)]  
PIC16LC554 PIC16LC554(ISP) [ISP-  
HEADER01]  
PIC16LC554@SOIC18 [(SA404)]  
PIC16LC554@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC558 PIC16LC558(ISP) [ISP-  
HEADER01]  
PIC16LC558@SOIC18 [(SA404)]  
PIC16LC558@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC56A PIC16LC56A@SOIC18  
[(SA404)]  
PIC16LC56A@SSOP20 [(SA626A)]  
PIC16LC58A PIC16LC58A@SSOP20  
[(SA626A)]  
PIC16LC58A@SOIC18 [(SA404)]  
PIC16LC58B PIC16LC58B@SOIC18

[ (SA404) ]  
PIC16LC58B@SSOP20 [ (SA626A) ]  
PIC16LC620  
PIC16LC620(ISP) [ ISP-HEADER01 ]                    PIC16LC620@SOIC18  
[ (SA404) ]  
PIC16LC620@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LC620A                                            PIC16LC620A(ISP) [ ISP-  
HEADER01 ]  
PIC16LC620A@SOIC18 [ (SA404) ]  
PIC16LC620A@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LC620A@SSOP20 [ (SA626A) ]  
PIC16LC620A@SSOP20(ISP) [ ISP-HEADER01 ]  
PIC16LC621A                                            PIC16LC621A(ISP) [ ISP-  
HEADER01 ]  
PIC16LC621A@SOIC18 [ (SA404) ]  
PIC16LC621A@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LC621A@SSOP20 [ (SA626A) ]  
PIC16LC621A@SSOP20(ISP) [ ISP-HEADER01 ]  
PIC16LC622                                            PIC16LC622(ISP) [ ISP-  
HEADER01 ]  
PIC16LC622@SOIC18 [ (SA404) ]  
PIC16LC622@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LC62A                                            PIC16LC62A(ISP) [ ISP-  
HEADER01 ]  
PIC16LC62A@SOIC28 [ (SA404) ]  
PIC16LC62A@SOIC28(ISP) [ ISP-HEADER01 ]  
PIC16LC62A@SSOP28 [ (SA626A) ]  
PIC16LC62A@SSOP28(ISP) [ ISP-HEADER01 ]  
PIC16LC62B                                            PIC16LC62B(ISP) [ ISP-  
HEADER01 ]  
PIC16LC62B@SOIC28 [ (SA404) ]  
PIC16LC62B@SOIC28(ISP) [ ISP-HEADER01 ]  
PIC16LC62B@SSOP28 [ (SA626A) ]  
PIC16LC62B@SSOP28(ISP) [ ISP-HEADER01 ]  
PIC16LC63                                            PIC16LC63(ISP) [ ISP-  
HEADER01 ]  
PIC16LC63@SOIC28 [ (SA404) ]  
PIC16LC63@SOIC28(ISP) [ ISP-HEADER01 ]  
PIC16LC63A                                            PIC16LC63A(ISP) [ ISP-  
HEADER01 ]  
PIC16LC63A@SOIC28 [ (SA404) ]  
PIC16LC63A@SOIC28(ISP) [ ISP-HEADER01 ]  
PIC16LC63A@SSOP28 [ (SA626A) ]

PIC16LC63A@SSOP28 (ISP) [ISP-HEADER01]  
PIC16LC64A PIC16LC64A (ISP) [ISP-  
HEADER01]  
PIC16LC64A@PLCC44 [(SA244)]  
PIC16LC64A@PLCC44 (ISP) [ISP-HEADER01]  
PIC16LC64A@TQFP44 [(SA245A)]  
PIC16LC64A@TQFP44 (ISP) [ISP-HEADER01]  
PIC16LC65A PIC16LC65A (ISP) [ISP-  
HEADER01]  
PIC16LC65A@PLCC44 [(SA244)]  
PIC16LC65A@PLCC44 (ISP) [ISP-HEADER01]  
PIC16LC65A@TQFP44 [(SA245A)]  
PIC16LC65A@TQFP44 (ISP) [ISP-HEADER01]  
PIC16LC65B PIC16LC65B (ISP) [ISP-  
HEADER01]  
PIC16LC65B@PLCC44 [(SA244)]  
PIC16LC65B@PLCC44 (ISP) [ISP-HEADER01]  
PIC16LC65B@TQFP44 [(SA245A)]  
PIC16LC65B@TQFP44 (ISP) [ISP-HEADER01]  
PIC16LC66 PIC16LC66 (ISP) [ISP-  
HEADER01]  
PIC16LC66@SOIC28 [(SA404)]  
PIC16LC66@SOIC28 (ISP) [ISP-HEADER01]  
PIC16LC67 PIC16LC67 (ISP) [ISP-  
HEADER01]  
PIC16LC67@PLCC44 [(SA244)]  
PIC16LC67@PLCC44 (ISP) [ISP-HEADER01]  
PIC16LC67@TQFP44 [(SA245A)]  
PIC16LC67@TQFP44 (ISP) [ISP-HEADER01]  
PIC16LC71 PIC16LC71 (ISP) [ISP-  
HEADER01]  
PIC16LC71@SOIC18 [(SA404)]  
PIC16LC71@SOIC18 (ISP) [ISP-HEADER01]  
PIC16LC710 PIC16LC710 (ISP) [ISP-  
HEADER01]  
PIC16LC710@SOIC18 [(SA404)]  
PIC16LC710@SOIC18 (ISP) [ISP-HEADER01]  
PIC16LC710@SSOP20 [(SA626A)]  
PIC16LC710@SSOP20 (ISP) [ISP-HEADER01]  
PIC16LC711 PIC16LC711 (ISP) [ISP-  
HEADER01]  
PIC16LC711@SOIC18 [(SA404)]  
PIC16LC711@SOIC18 (ISP) [ISP-HEADER01]

PIC16LC711@SSOP20 [(SA626A)]  
PIC16LC711@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC712 PIC16LC712(ISP) [ISP-  
HEADER01]  
PIC16LC712@SOIC18 [(SA404)]  
PIC16LC712@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC712@SSOP20 [(SA626A)]  
PIC16LC712@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC715 PIC16LC715@SOIC18  
[(SA404)]  
PIC16LC716 PIC16LC716(ISP) [ISP-  
HEADER01]  
PIC16LC716@SOIC18 [(SA404)]  
PIC16LC716@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC716@SSOP20 [(SA626A)]  
PIC16LC716@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC717 PIC16LC717(ISP) [ISP-  
HEADER01]  
PIC16LC717@SOIC18 [(SA404)]  
PIC16LC717@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC717@SSOP20 [(SA626A)]  
PIC16LC717@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC72 PIC16LC72(ISP) [ISP-  
HEADER01]  
PIC16LC72@SOIC28 [(SA404)]  
PIC16LC72@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC72@SSOP28 [(SA626A)]  
PIC16LC72@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC72A PIC16LC72A(ISP) [ISP-  
HEADER01]  
PIC16LC72A@SOIC28 [(SA404)]  
PIC16LC72A@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC72A@SSOP28 [(SA626A)]  
PIC16LC72A@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC73A PIC16LC73A(ISP) [ISP-  
HEADER01]  
PIC16LC73A@SOIC28 [(SA404)]  
PIC16LC73A@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC73B PIC16LC73B(ISP) [ISP-  
HEADER01]  
PIC16LC73B@SOIC28 [(SA404)]  
PIC16LC73B@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC73B@SSOP28 [(SA626A)]



PIC16LC73B@SSOP28 (ISP) [ISP-HEADER01]  
PIC16LC74 PIC16LC74 (ISP) [ISP-  
HEADER01]  
PIC16LC74@PLCC44 [(SA244)]  
PIC16LC74@PLCC44 (ISP) [ISP-HEADER01]  
PIC16LC74@TQFP44 [(SA245A)]  
PIC16LC74@TQFP44 (ISP) [ISP-HEADER01]  
PIC16LC74A PIC16LC74A (ISP) [ISP-  
HEADER01]  
PIC16LC74A@PLCC44 [(SA244)]  
PIC16LC74A@PLCC44 (ISP) [ISP-HEADER01]  
PIC16LC74A@TQFP44 [(SA245A)]  
PIC16LC74A@TQFP44 (ISP) [ISP-HEADER01]  
PIC16LC74B PIC16LC74B (ISP) [ISP-  
HEADER01]  
PIC16LC74B@MQFP44 [(SA675)]  
PIC16LC74B@MQFP44 (ISP) [ISP-HEADER01]  
PIC16LC74B@PLCC44 [(SA244)]  
PIC16LC74B@PLCC44 (ISP) [ISP-HEADER01]  
PIC16LC74B@TQFP44 [(SA245A)]  
PIC16LC74B@TQFP44 (ISP) [ISP-HEADER01]  
PIC16LC76 PIC16LC76 (ISP) [ISP-  
HEADER01]  
PIC16LC76@SOIC28 [(SA404)]  
PIC16LC76@SOIC28 (ISP) [ISP-HEADER01]  
PIC16LC77 PIC16LC77 (ISP) [ISP-  
HEADER01]  
PIC16LC77@PLCC44 [(SA244)]  
PIC16LC77@PLCC44 (ISP) [ISP-HEADER01]  
PIC16LC773 PIC16LC773 (ISP) [ISP-  
HEADER01]  
PIC16LC773@SOIC28 [(SA404)]  
PIC16LC773@SOIC28 (ISP) [ISP-HEADER01]  
PIC16LC773@SSOP28 [(SA626A)]  
PIC16LC773@SSOP28 (ISP) [ISP-HEADER01]  
PIC16LC774 PIC16LC774 (ISP) [ISP-  
HEADER01]  
PIC16LC774@PLCC44 [(SA244)]  
PIC16LC774@PLCC44 (ISP) [ISP-HEADER01]  
PIC16LC774@TQFP44 [(SA675)]  
PIC16LC774@TQFP44 (ISP) [ISP-HEADER01]  
PIC16LC84 PIC16LC84 (ISP) [ISP-  
HEADER01]

PIC16LC84@SOIC18 [(SA404)]  
PIC16LC84@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC923@PLCC68 [(PEP+S414T)]  
PIC16LC923@PLCC68(\*) [(SA648-B6807)]  
PIC16LC923@PLCC68(ISP) [ISP-HEADER01]  
PIC16LC923@SDIP64 [(PEP+S600A)]  
PIC16LC923@SDIP64(ISP) [ISP-HEADER01]  
PIC16LC923@TQFP64 [(PEP+S616)]  
PIC16LC923@TQFP64(ISP) [ISP-HEADER01]  
PIC16LC924@PLCC68 [(PEP+S414T)]  
PIC16LC924@PLCC68(\*) [(SA648-B6807)]  
PIC16LC924@PLCC68(ISP) [ISP-HEADER01]  
PIC16LC924@SDIP64 [(PEP+S600A)]  
PIC16LC924@SDIP64(ISP) [ISP-HEADER01]  
PIC16LC924@TQFP64 [(PEP+S616)]  
PIC16LC924@TQFP64(ISP) [ISP-HEADER01]  
PIC16LC925@PLCC68 [(PEP+S414T)]  
PIC16LC925@PLCC68(\*) [(SA648-B6807)]  
PIC16LC925@PLCC68(ISP) [ISP-HEADER01]  
PIC16LC925@TQFP64 [(PEP+S616)]  
PIC16LC925@TQFP64(ISP) [ISP-HEADER01]  
PIC16LC926@PLCC68 [(PEP+S414T)]  
PIC16LC926@PLCC68(\*) [(SA648-B6807)]  
PIC16LC926@PLCC68(ISP) [ISP-HEADER01]  
PIC16LC926@TQFP64 [(PEP+S616)]  
PIC16LC926@TQFP64(ISP) [ISP-HEADER01]  
PIC16LCE623@SOIC18 [(SA404)]  
PIC16LCE623@SOIC18(ISP) [ISP-HEADER01]  
PIC16LCE623@SSOP20 [(SA626A)]  
PIC16LCE623@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF505 PIC16LF505(ISP) [ISP-  
HEADER01]  
PIC16LF505@SOIC14 [(SA602)]  
PIC16LF505@SOIC14(ISP) [ISP-HEADER01]  
PIC16LF505@TSSOP14 [(SA026)]  
PIC16LF505@TSSOP14(ISP) [ISP-HEADER01]  
PIC16LF506 PIC16LF506(ISP) [ISP-  
HEADER01]  
PIC16LF506@SOIC14 [(SA602)]  
PIC16LF506@SOIC14(ISP) [ISP-HEADER01]  
PIC16LF506@TSSOP14 [(SA026)]  
PIC16LF506@TSSOP14(ISP) [ISP-HEADER01]  
PIC16LF54 PIC16LF54(ISP) [ISP-

HEADER01 ]  
PIC16LF54@SOIC18 [ (SA404) ]  
PIC16LF54@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LF54@SSOP20 [ (SA626A) ]  
PIC16LF54@SSOP20(ISP) [ ISP-HEADER01 ]  
PIC16LF57 PIC16LF57(ISP) [ ISP-  
HEADER01 ]  
PIC16LF57@SOIC28 [ (SA404) ]  
PIC16LF57@SOIC28(ISP) [ ISP-HEADER01 ]  
PIC16LF57@SSOP28 [ (SA626A) ]  
PIC16LF57@SSOP28(ISP) [ ISP-HEADER01 ]  
PIC16LF59 PIC16LF59(ISP) [ ISP-  
HEADER01 ]  
PIC16LF59@PLCC44 [ (SA244) ]  
PIC16LF59@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16LF59@TQFP44 [ (SA245A) ]  
PIC16LF59@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16LF627 PIC16LF627(ISP) [ ISP-  
HEADER01 ]  
PIC16LF627@SOIC18 [ (SA404) ]  
PIC16LF627@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LF627@SSOP20 [ (SA626A) ]  
PIC16LF627@SSOP20(ISP) [ ISP-HEADER01 ]  
PIC16LF627A PIC16LF627A(ISP) [ ISP-  
HEADER01 ]  
PIC16LF627A@SOIC18 [ (SA404) ]  
PIC16LF627A@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LF627A@SSOP20 [ (SA626A) ]  
PIC16LF627A@SSOP20(ISP) [ ISP-HEADER01 ]  
PIC16LF628 PIC16LF628(ISP) [ ISP-  
HEADER01 ]  
PIC16LF628@SOIC18 [ (SA404) ]  
PIC16LF628@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LF628@SSOP20 [ (SA626A) ]  
PIC16LF628@SSOP20(ISP) [ ISP-HEADER01 ]  
PIC16LF628A PIC16LF628A(ISP) [ ISP-  
HEADER01 ]  
PIC16LF628A@SOIC18 [ (SA404) ]  
PIC16LF628A@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LF628A@SSOP20 [ (SA626A) ]  
PIC16LF628A@SSOP20(ISP) [ ISP-HEADER01 ]  
PIC16LF631 PIC16LF631(ISP) [ ISP-  
HEADER01 ]

PIC16LF631@QFN20 [(SA692)]  
PIC16LF631@QFN20(ISP) [ISP-HEADER01]  
PIC16LF631@SOIC20 [(SA404)]  
PIC16LF631@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF631@SSOP20 [(SA626A)]  
PIC16LF631@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF639 PIC16LF639(ISP) [ISP-  
HEADER01]  
PIC16LF639@QFN20 [(SA692)]  
PIC16LF639@QFN20(ISP) [ISP-HEADER01]  
PIC16LF639@SOIC20 [(SA404)]  
PIC16LF639@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF639@SSOP20 [(SA626A)]  
PIC16LF639@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF648A PIC16LF648A(ISP) [ISP-  
HEADER01]  
PIC16LF648A@SOIC18 [(SA404)]  
PIC16LF648A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF648A@SSOP20 [(SA626A)]  
PIC16LF648A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF677 PIC16LF677(ISP) [ISP-  
HEADER01]  
PIC16LF677@QFN20 [(SA692)]  
PIC16LF677@QFN20(ISP) [ISP-HEADER01]  
PIC16LF677@SOIC20 [(SA404)]  
PIC16LF677@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF677@SSOP20 [(SA626A)]  
PIC16LF677@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF685 PIC16LF685(ISP) [ISP-  
HEADER01]  
PIC16LF685@QFN20 [(SA692)]  
PIC16LF685@QFN20(ISP) [ISP-HEADER01]  
PIC16LF685@SOIC20 [(SA404)]  
PIC16LF685@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF685@SSOP20 [(SA626A)]  
PIC16LF685@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF687 PIC16LF687(ISP) [ISP-  
HEADER01]  
PIC16LF687@QFN20 [(SA692)]  
PIC16LF687@QFN20(ISP) [ISP-HEADER01]  
PIC16LF687@SOIC20 [(SA404)]  
PIC16LF687@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF687@SSOP20 [(SA626A)]

PIC16LF687@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF689 PIC16LF689(ISP) [ISP-  
HEADER01]  
PIC16LF689@QFN20 [(SA692)]  
PIC16LF689@QFN20(ISP) [ISP-HEADER01]  
PIC16LF689@SOIC20 [(SA404)]  
PIC16LF689@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF689@SSOP20 [(SA626A)]  
PIC16LF689@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF690 PIC16LF690(ISP) [ISP-  
HEADER01]  
PIC16LF690@QFN20 [(SA692)]  
PIC16LF690@QFN20(ISP) [ISP-HEADER01]  
PIC16LF690@SOIC20 [(SA404)]  
PIC16LF690@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF690@SSOP20 [(SA626A)]  
PIC16LF690@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF716 PIC16LF716(ISP) [ISP-  
HEADER01]  
PIC16LF716@SOIC18 [(SA404)]  
PIC16LF716@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF716@SSOP20 [(SA626A)]  
PIC16LF716@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF72 PIC16LF72(ISP) [ISP-  
HEADER01]  
PIC16LF72@QFN28 [(SA685-B006)]  
PIC16LF72@QFN28(ISP) [ISP-HEADER01]  
PIC16LF72@SOIC28 [(SA404)]  
PIC16LF72@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF72@SSOP28 [(SA626A)]  
PIC16LF72@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF722 PIC16LF722@QFN28 [(SA685-  
B006)]  
PIC16LF722@SOIC28 [(SA404)] PIC16LF722@SSOP28  
[(SA626A)]  
PIC16LF723 PIC16LF723@QFN28 [(SA685-  
B006)]  
PIC16LF723@SOIC28 [(SA404)] PIC16LF723@SSOP28  
[(SA626A)]  
PIC16LF724 PIC16LF724@QFN44  
[(SA737)]  
PIC16LF724@TQFP44 [(SA245A)]  
PIC16LF726

PIC16LF726@QFN28 [(SA685-B006)] PIC16LF726@SOIC28  
[(SA404)]  
PIC16LF726@SSOP28 [(SA626A)]  
PIC16LF727  
PIC16LF727@QFN44 [(SA737)] PIC16LF727@TQFP44  
[(SA245A)]  
PIC16LF73 PIC16LF73(ISP) [ISP-  
HEADER01]  
PIC16LF73@SOIC28 [(SA404)]  
PIC16LF73@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF73@SSOP28 [(SA626A)]  
PIC16LF73@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF737 PIC16LF737(ISP) [ISP-  
HEADER01]  
PIC16LF737@SOIC28 [(SA404)]  
PIC16LF737@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF737@SSOP28 [(SA626A)]  
PIC16LF737@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF74 PIC16LF74(ISP) [ISP-  
HEADER01]  
PIC16LF74@PLCC44 [(SA244)]  
PIC16LF74@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF74@TQFP44 [(SA245A)]  
PIC16LF74@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF747 PIC16LF747(ISP) [ISP-  
HEADER01]  
PIC16LF747@TQFP44 [(SA245A)]  
PIC16LF747@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF76 PIC16LF76(ISP) [ISP-  
HEADER01]  
PIC16LF76@SOIC28 [(SA404)]  
PIC16LF76@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF76@SSOP28 [(SA626A)]  
PIC16LF76@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF767 PIC16LF767(ISP) [ISP-  
HEADER01]  
PIC16LF767@SOIC28 [(SA404)]  
PIC16LF767@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF767@SSOP28 [(SA626A)]  
PIC16LF767@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF77 PIC16LF77(ISP) [ISP-  
HEADER01]  
PIC16LF77@PLCC44 [(SA244)]

PIC16LF77@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF77@TQFP44 [(SA245A)]  
PIC16LF77@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF777 PIC16LF777(ISP) [ISP-  
HEADER01]  
PIC16LF777@TQFP44 [(SA245A)]  
PIC16LF777@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF818 PIC16LF818(ISP) [ISP-  
HEADER01]  
PIC16LF818@QFN28 [(SA685-B006)]  
PIC16LF818@QFN28(ISP) [ISP-HEADER01]  
PIC16LF818@SOIC18 [(SA404)]  
PIC16LF818@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF818@SSOP20 [(SA626A)]  
PIC16LF818@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF819 PIC16LF819(ISP) [ISP-  
HEADER01]  
PIC16LF819@QFN28 [(SA685-B006)]  
PIC16LF819@QFN28(ISP) [ISP-HEADER01]  
PIC16LF819@SOIC18 [(SA404)]  
PIC16LF819@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF819@SSOP20 [(SA626A)]  
PIC16LF819@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF83 PIC16LF83(ISP) [ISP-  
HEADER01]  
PIC16LF83@SOIC18 [(SA404)]  
PIC16LF83@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF84 PIC16LF84(ISP) [ISP-  
HEADER01]  
PIC16LF84@SOIC18 [(SA404)]  
PIC16LF84@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF84A PIC16LF84A(ISP) [ISP-  
HEADER01]  
PIC16LF84A@SOIC18 [(SA404)]  
PIC16LF84A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF84A@SSOP20 [(SA626A)]  
PIC16LF84A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF87 PIC16LF87(ISP) [ISP-  
HEADER01]  
PIC16LF87@QFN28 [(SA685-B006)]  
PIC16LF87@QFN28(ISP) [ISP-HEADER01]  
PIC16LF87@SOIC18 [(SA404)]  
PIC16LF87@SOIC18(ISP) [ISP-HEADER01]

PIC16LF87@SSOP20 [(SA626A)]  
PIC16LF87@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF870 PIC16LF870(ISP) [ISP-  
HEADER01]  
PIC16LF870@SOIC28 [(SA404)]  
PIC16LF870@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF870@SSOP28 [(SA626A)]  
PIC16LF870@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF871 PIC16LF871(ISP) [ISP-  
HEADER01]  
PIC16LF871@PLCC44 [(SA244)]  
PIC16LF871@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF871@TQFP44 [(SA245A)]  
PIC16LF871@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF872 PIC16LF872(ISP) [ISP-  
HEADER01]  
PIC16LF872@SOIC28 [(SA404)]  
PIC16LF872@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF872@SSOP28 [(SA626A)]  
PIC16LF872@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF873 PIC16LF873(ISP) [ISP-  
HEADER01]  
PIC16LF873@SOIC28 [(SA404)]  
PIC16LF873@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF873A  
PIC16LF873A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF873A@QFN28 [(SA697-B006)]  
PIC16LF873A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF873A@SOIC28 [(SA404)]  
PIC16LF873A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF873A@SSOP28 [(SA626A)]  
PIC16LF873A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]



PIC16LF873A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF874 PIC16LF874(ISP) [ISP-  
HEADER01]  
PIC16LF874@PLCC44 [(SA244)]  
PIC16LF874@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF874@TQFP44 [(SA245A)]  
PIC16LF874@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF874A  
PIC16LF874A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF874A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF874A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF874A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF874A@PLCC44 [(SA244)]  
PIC16LF874A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF874A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF874A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF874A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF874A@TQFP44 [(SA245A)]  
PIC16LF874A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF874A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF874A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF874A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876 PIC16LF876(ISP) [ISP-  
HEADER01]  
PIC16LF876@SOIC28 [(SA404)]  
PIC16LF876@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF876A  
PIC16LF876A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876A@QFN28 [(SA697-B006)]  
PIC16LF876A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876A@SOIC28 [(SA404)]  
PIC16LF876A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876A@SSOP28 [(SA626A)]  
PIC16LF876A@SSOP28(ISP)(High-V) [ISP-HEADER01]

PIC16LF876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF877 PIC16LF877(ISP) [ISP-  
HEADER01]  
PIC16LF877@PLCC44 [(SA244)]  
PIC16LF877@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF877@TQFP44 [(SA245A)]  
PIC16LF877@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF877A  
PIC16LF877A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF877A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF877A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF877A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF877A@PLCC44 [(SA244)]  
PIC16LF877A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF877A@TQFP44 [(SA245A)]  
PIC16LF877A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF88 PIC16LF88(ISP) [ISP-  
HEADER01]  
PIC16LF88@QFN28 [(SA685-B006)]  
PIC16LF88@QFN28(ISP) [ISP-HEADER01]  
PIC16LF88@SOIC18 [(SA404)]  
PIC16LF88@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF88@SSOP20 [(SA626A)]  
PIC16LF88@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF913 PIC16LF913(ISP) [ISP-  
HEADER01]  
PIC16LF913@QFN28 [(SA697-B006)]  
PIC16LF913@QFN28(ISP) [ISP-HEADER01]  
PIC16LF913@SOIC28 [(SA404)]  
PIC16LF913@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF913@SSOP28 [(SA626A)]  
PIC16LF913@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF914 PIC16LF914(ISP) [ISP-  
HEADER01]  
PIC16LF914@QFN44 [(SA712)]

PIC16LF914@QFN44(ISP) [ISP-HEADER01]  
 PIC16LF914@QFN44(ML) [(SA737)]  
 PIC16LF914@QFN44(ML)(ISP) [ISP-HEADER01]  
 PIC16LF914@TQFP44 [(SA245A)]  
 PIC16LF914@TQFP44(ISP) [ISP-HEADER01]  
 PIC16LF916 PIC16LF916(ISP) [ISP-  
 HEADER01]  
 PIC16LF916@QFN28 [(SA697-B006)]  
 PIC16LF916@QFN28(ISP) [ISP-HEADER01]  
 PIC16LF916@SOIC28 [(SA404)]  
 PIC16LF916@SOIC28(ISP) [ISP-HEADER01]  
 PIC16LF916@SSOP28 [(SA626A)]  
 PIC16LF916@SSOP28(ISP) [ISP-HEADER01]  
 PIC16LF917 PIC16LF917(ISP) [ISP-  
 HEADER01]  
 PIC16LF917@QFN44 [(SA712)]  
 PIC16LF917@QFN44(ISP) [ISP-HEADER01]  
 PIC16LF917@QFN44(ML) [(SA737)]  
 PIC16LF917@QFN44(ML)(ISP) [ISP-HEADER01]  
 PIC16LF917@TQFP44 [(SA245A)]  
 PIC16LF917@TQFP44(ISP) [ISP-HEADER01]  
 PIC16LF946@TQFP64 [(PEP+S616)]  
 PIC16LF946@TQFP64(ISP) [ISP-HEADER01]  
 PIC16LV54A PIC16LV54A@SOIC18  
 [(SA404)]  
 PIC16LV54A@SSOP20 [(SA626A)]  
 PIC16LV58A PIC16LV58A@SSOP20  
 PIC16LV58A@SOIC18 [(SA404)]  
 [(SA626A)]  
 PIC17C42 PIC17C42@PLCC44  
 [(SA244)]  
 PIC17C42@TQFP44 [(SA245A)]  
 PIC17C42A PIC17C42A@TQFP44  
 PIC17C42A@PLCC44 [(SA244)]  
 [(SA245A)]  
 PIC17C43 PIC17C43@PLCC44  
 [(SA244)]  
 PIC17C43@TQFP44 [(SA245A)]  
 PIC17C44 PIC17C44@TQFP44  
 PIC17C44@PLCC44 [(SA244)]  
 [(SA245A)]  
 PIC17C752@PLCC68 [(PEP+S414T)] PIC17C752@TQFP64 [(PEP  
 +S616)]

PIC17C756@PLCC68 [(PEP+S414T) +S616)]	PIC17C756@TQFP64 [(PEP
PIC17C756A@PLCC68 [(PEP+S414T) +S616)]	PIC17C756A@TQFP64 [(PEP
PIC17C762@PLCC84 [(PEP+S416T) +S416T)]	PIC17C766@PLCC84 [(PEP
PIC17LC42 [(SA244)]	PIC17LC42@PLCC44
PIC17LC42@TQFP44 [(SA245A)]	
PIC17LC42A PIC17LC42A@PLCC44 [(SA244)] [(SA245A)]	PIC17LC42A@TQFP44
PIC17LC43 [(SA244)]	PIC17LC43@PLCC44
PIC17LC43@TQFP44 [(SA245A)]	
PIC17LC44 PIC17LC44@PLCC44 [(SA244)] [(SA245A)]	PIC17LC44@TQFP44
PIC17LC752@PLCC68 [(PEP+S414T) +S616)]	PIC17LC752@TQFP64 [(PEP
PIC17LC756@PLCC68 [(PEP+S414T) +S616)]	PIC17LC756@TQFP64 [(PEP
PIC17LC756A@PLCC68 [(PEP+S414T) +S616)]	PIC17LC756A@TQFP64 [(PEP
PIC17LC762@PLCC84 [(PEP+S416T) +S416T)]	PIC17LC766@PLCC84 [(PEP
PIC18C242 [(SA404)]	PIC18C242@SOIC28
PIC18C252 [(SA404)]	PIC18C252@SOIC28
PIC18C442 [(SA244)]	PIC18C442@PLCC44
PIC18C442@TQFP44 [(SA245A)]	
PIC18C452 PIC18C452@PLCC44 [(SA244)] [(SA245A)]	PIC18C452@TQFP44
PIC18C658@PLCC68 [(PEP+S414T) +S616)]	PIC18C658@TQFP64 [(PEP
PIC18C858@PLCC84 [(PEP+S416T) +S640B)]	PIC18C858@TQFP80 [(PEP
PIC18F1220 HEADER01]	PIC18F1220(ISP) [ISP-
PIC18F1220@SOIC18 [(SA404)]	

PIC18F1220@SOIC18(ISP) [ISP-HEADER01]  
PIC18F1220@SSOP20 [(SA626A)]  
PIC18F1220@SSOP20(ISP) [ISP-HEADER01]  
PIC18F1230 PIC18F1230(ISP) [ISP-  
HEADER01]  
PIC18F1230@QFN28 [(SA685-B006)]  
PIC18F1230@QFN28(ISP) [ISP-HEADER01]  
PIC18F1230@SOIC18 [(SA404)]  
PIC18F1230@SOIC18(ISP) [ISP-HEADER01]  
PIC18F1230@SSOP20 [(SA626A)]  
PIC18F1230@SSOP20(ISP) [ISP-HEADER01]  
PIC18F1320 PIC18F1320(ISP) [ISP-  
HEADER01]  
PIC18F1320@SOIC18 [(SA404)]  
PIC18F1320@SOIC18(ISP) [ISP-HEADER01]  
PIC18F1320@SSOP20 [(SA626A)]  
PIC18F1320@SSOP20(ISP) [ISP-HEADER01]  
PIC18F1330 PIC18F1330(ISP) [ISP-  
HEADER01]  
PIC18F1330@QFN28 [(SA685-B006)]  
PIC18F1330@QFN28(ISP) [ISP-HEADER01]  
PIC18F1330@SOIC18 [(SA404)]  
PIC18F1330@SOIC18(ISP) [ISP-HEADER01]  
PIC18F1330@SSOP20 [(SA626A)]  
PIC18F1330@SSOP20(ISP) [ISP-HEADER01]  
PIC18F1330-ICD@QFN28 [(SA685-B006)]  
PIC18F1330-ICD@QFN28(ISP) [ISP-HEADER01]  
PIC18F2220 PIC18F2220(ISP) [ISP-  
HEADER01]  
PIC18F2220@SOIC28 [(SA404)]  
PIC18F2220@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2221  
PIC18F2221(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2221@QFN28 [(SA685-B006)]  
PIC18F2221@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2221@SOIC28 [(SA404)]  
PIC18F2221@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2320 PIC18F2320(ISP) [ISP-  
HEADER01]  
PIC18F2320@SOIC28 [(SA404)]  
PIC18F2320@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2321  
PIC18F2321(ISP)(Low-V) [ISP-HEADER01]

PIC18F2321@QFN28 [(SA685-B006)]  
PIC18F2321@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2321@SOIC28 [(SA404)]  
PIC18F2321@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2331 PIC18F2331(ISP) [ISP-  
HEADER01]  
PIC18F2331@SOIC28 [(SA404)]  
PIC18F2331@SOIC28(ISP) [ISP-HEADER01]  
PIC18F23K20  
PIC18F23K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F23K20@QFN28 [(SA685-B006)]  
PIC18F23K20@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F23K20@SOIC28 [(SA404)]  
PIC18F23K20@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F23K20@SSOP28 [(SA626A)]  
PIC18F23K20@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2410  
PIC18F2410(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2410@QFN28 [(SA685-B006)]  
PIC18F2410@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2410@SOIC28 [(SA404)]  
PIC18F2410@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F242 PIC18F242(ISP) [ISP-  
HEADER01]  
PIC18F242@SOIC28 [(SA404)]  
PIC18F242@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2420  
PIC18F2420(ISP)(High-V) [ISP-HEADER01]  
PIC18F2420(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2420@SOIC28 [(SA404)]  
PIC18F2420@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2420@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2423  
PIC18F2423(ISP)(High-V) [ISP-HEADER01]  
PIC18F2423(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2423@QFN28 [(SA685-B006)]  
PIC18F2423@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2423@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2423@SOIC28 [(SA404)]

PIC18F2423@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2423@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2431 PIC18F2431(ISP) [ISP-  
HEADER01]  
PIC18F2431@SOIC28 [(SA404)]  
PIC18F2431@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2439 PIC18F2439(ISP) [ISP-  
HEADER01]  
PIC18F2439@SOIC28 [(SA404)]  
PIC18F2439@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2450  
PIC18F2450(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2450@QFN28 [(SA685-B006)]  
PIC18F2450@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2450@SOIC28 [(SA404)]  
PIC18F2450@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2455  
PIC18F2455(ISP)(High-V) [ISP-HEADER01]  
PIC18F2455(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2455@SOIC28 [(SA404)]  
PIC18F2455@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2455@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2458  
PIC18F2458(ISP)(High-V) [ISP-HEADER01]  
PIC18F2458(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2458@SOIC28 [(SA404)]  
PIC18F2458@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2458@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2458@SSOP28 [(SA626A)]  
PIC18F2458@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2458@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F248 PIC18F248(ISP) [ISP-  
HEADER01]  
PIC18F248@SOIC28 [(SA404)]  
PIC18F248@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2480  
PIC18F2480(ISP)(High-V) [ISP-HEADER01]  
PIC18F2480(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2480@QFN28 [(SA685-B006)]  
PIC18F2480@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2480@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2480@SOIC28 [(SA404)]  
PIC18F2480@SOIC28(ISP)(High-V) [ISP-HEADER01]

PIC18F2480@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24J10 PIC18F24J10(ISP) [ISP-  
HEADER01]  
PIC18F24J10@QFN28 [(SA685-B006)]  
PIC18F24J10@QFN28(ISP) [ISP-HEADER01]  
PIC18F24J10@SOIC28 [(SA404)]  
PIC18F24J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18F24J10@SSOP28 [(SA626A)]  
PIC18F24J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18F24K20  
PIC18F24K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24K20@QFN28 [(SA685-B006)]  
PIC18F24K20@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24K20@SOIC28 [(SA404)]  
PIC18F24K20@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24K20@SSOP28 [(SA626A)]  
PIC18F24K20@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2510 PIC18F2510(ISP) [ISP-  
HEADER01]  
PIC18F2510@QFN28 [(SA685-B006)]  
PIC18F2510@QFN28(ISP) [ISP-HEADER01]  
PIC18F2510@SOIC28 [(SA404)]  
PIC18F2510@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2515  
PIC18F2515(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2515@SOIC28 [(SA404)]  
PIC18F2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F252 PIC18F252(ISP) [ISP-  
HEADER01]  
PIC18F252@SOIC28 [(SA404)]  
PIC18F252@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2520  
PIC18F2520(ISP)(High-V) [ISP-HEADER01]  
PIC18F2520(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2520@SOIC28 [(SA404)]  
PIC18F2520@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2523  
PIC18F2523(ISP)(High-V) [ISP-HEADER01]



PIC18F2523(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2523@QFN28 [(SA685-B006)]  
PIC18F2523@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2523@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2523@SOIC28 [(SA404)]  
PIC18F2523@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2523@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2525  
PIC18F2525(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2525@SOIC28 [(SA404)]  
PIC18F2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2539 PIC18F2539(ISP) [ISP-  
HEADER01]  
PIC18F2539@SOIC28 [(SA404)]  
PIC18F2539@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2550  
PIC18F2550(ISP)(High-V) [ISP-HEADER01]  
PIC18F2550(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2550@SOIC28 [(SA404)]  
PIC18F2550@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2553  
PIC18F2553(ISP)(High-V) [ISP-HEADER01]  
PIC18F2553(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2553@SOIC28 [(SA404)]  
PIC18F2553@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2553@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2553@SSOP28 [(SA626A)]  
PIC18F2553@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2553@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F258 PIC18F258(ISP) [ISP-  
HEADER01]  
PIC18F258@SOIC28 [(SA404)]  
PIC18F258@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2580  
PIC18F2580(ISP)(High-V) [ISP-HEADER01]  
PIC18F2580(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2580@QFN28 [(SA685-B006)]  
PIC18F2580@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2580@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2580@SOIC28 [(SA404)]  
PIC18F2580@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]

PIC18F2585  
PIC18F2585(ISP)(High-V) [ISP-HEADER01]  
PIC18F2585(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2585@SDIP28 [(SA022A)]  
PIC18F2585@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2585@SOIC28 [(SA404)]  
PIC18F2585@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25J10 PIC18F25J10(ISP) [ISP-  
HEADER01]  
PIC18F25J10@QFN28 [(SA685-B006)]  
PIC18F25J10@QFN28(ISP) [ISP-HEADER01]  
PIC18F25J10@SOIC28 [(SA404)]  
PIC18F25J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18F25J10@SSOP28 [(SA626A)]  
PIC18F25J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18F25K20  
PIC18F25K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25K20@QFN28 [(SA685-B006)]  
PIC18F25K20@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25K20@SOIC28 [(SA404)]  
PIC18F25K20@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25K20@SSOP28 [(SA626A)]  
PIC18F25K20@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2610  
PIC18F2610(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2610@SOIC28 [(SA404)]  
PIC18F2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2620  
PIC18F2620(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2620@SOIC28 [(SA404)]  
PIC18F2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2680  
PIC18F2680(ISP)(High-V) [ISP-HEADER01]  
PIC18F2680(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2680@SDIP28 [(SA022A)]  
PIC18F2680@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]

PIC18F2680@SOIC28 [(SA404)]  
PIC18F2680@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2682  
PIC18F2682(ISP)(High-V) [ISP-HEADER01]  
PIC18F2682(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2682@QFN28 [(SA685)]  
PIC18F2682@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2682@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2682@SOIC28 [(SA404)]  
PIC18F2682@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2685  
PIC18F2685(ISP)(High-V) [ISP-HEADER01]  
PIC18F2685(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2685@QFN28 [(SA685)]  
PIC18F2685@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2685@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2685@SOIC28 [(SA404)]  
PIC18F2685@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4220 PIC18F4220(ISP) [ISP-  
HEADER01]  
PIC18F4220@QFN44 [(SA712)]  
PIC18F4220@QFN44(ISP) [ISP-HEADER01]  
PIC18F4220@QFN44(ML) [(SA737)]  
PIC18F4220@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4220@TQFP44 [(SA245A)]  
PIC18F4220@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4221  
PIC18F4221(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4221@QFN44 [(SA712)]  
PIC18F4221@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4221@QFN44(ML) [(SA737)]  
PIC18F4221@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4221@TQFP44 [(SA245A)]  
PIC18F4221@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4320 PIC18F4320(ISP) [ISP-  
HEADER01]  
PIC18F4320@QFN44 [(SA712)]  
PIC18F4320@QFN44(ISP) [ISP-HEADER01]  
PIC18F4320@QFN44(ML) [(SA737)]  
PIC18F4320@QFN44(ML)(ISP) [ISP-HEADER01]

PIC18F4320@TQFP44 [(SA245A)]  
PIC18F4320@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4321  
PIC18F4321(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4321@QFN44 [(SA712)]  
PIC18F4321@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4321@QFN44(ML) [(SA737)]  
PIC18F4321@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4321@TQFP44 [(SA245A)]  
PIC18F4321@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4331 PIC18F4331(ISP) [ISP-  
HEADER01]  
PIC18F4331@TQFP44 [(SA245A)]  
PIC18F4331@TQFP44(ISP) [ISP-HEADER01]  
PIC18F43K20  
PIC18F43K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F43K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F43K20@QFN44 [(SA712)]  
PIC18F43K20@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F43K20@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F43K20@QFN44(ML) [(SA737)]  
PIC18F43K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F43K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18F43K20@TQFP44 [(SA245A)]  
PIC18F43K20@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F43K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410  
PIC18F4410(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410@QFN44 [(SA712)]  
PIC18F4410@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410@QFN44(ML) [(SA737)]  
PIC18F4410@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410@TQFP44 [(SA245A)]  
PIC18F4410@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F442 PIC18F442(ISP) [ISP-  
HEADER01]  
PIC18F442@PLCC44 [(SA244)]  
PIC18F442@PLCC44(ISP) [ISP-HEADER01]  
PIC18F442@TQFP44 [(SA245A)]  
PIC18F442@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4420  
PIC18F4420(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4420@QFN44 [(SA712)]

PIC18F4420@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4420@QFN44(ML) [(SA737)]  
PIC18F4420@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4420@TQFP44 [(SA245A)]  
PIC18F4420@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423  
PIC18F4423(ISP)(High-V) [ISP-HEADER01]  
PIC18F4423(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423@QFN44 [(SA712)]  
PIC18F4423@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4423@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423@QFN44(ML) [(SA737)]  
PIC18F4423@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4423@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423@TQFP44 [(SA245A)]  
PIC18F4423@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4423@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4431 PIC18F4431(ISP) [ISP-  
HEADER01]  
PIC18F4431@TQFP44 [(SA245A)]  
PIC18F4431@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4439 PIC18F4439(ISP) [ISP-  
HEADER01]  
PIC18F4439@TQFP44 [(SA245A)]  
PIC18F4439@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4450  
PIC18F4450(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4450@QFN44 [(SA712)]  
PIC18F4450@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4450@QFN44(ML) [(SA737)]  
PIC18F4450@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4450@TQFP44 [(SA245A)]  
PIC18F4450@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455  
PIC18F4455(ISP)(High-V) [ISP-HEADER01]  
PIC18F4455(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455@QFN44 [(SA712)]  
PIC18F4455@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4455@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455@QFN44(ML) [(SA737)]  
PIC18F4455@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4455@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455@TQFP44 [(SA245A)]

PIC18F4455@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4455@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4458  
PIC18F4458(ISP)(High-V) [ISP-HEADER01]  
PIC18F4458(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4458@QFN44 [(SA737)]  
PIC18F4458@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4458@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4458@TQFP44 [(SA245A)]  
PIC18F4458@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4458@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F448 PIC18F448(ISP) [ISP-  
HEADER01]  
PIC18F448@PLCC44 [(SA244)]  
PIC18F448@PLCC44(ISP) [ISP-HEADER01]  
PIC18F448@TQFP44 [(SA245A)]  
PIC18F448@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4480  
PIC18F4480(ISP)(High-V) [ISP-HEADER01]  
PIC18F4480(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4480@QFN44 [(SA712)]  
PIC18F4480@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4480@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4480@QFN44(ML) [(SA737)]  
PIC18F4480@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4480@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4480@TQFP44 [(SA245A)]  
PIC18F4480@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4480@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F44J10 PIC18F44J10(ISP) [ISP-  
HEADER01]  
PIC18F44J10@QFN44 [(SA712)]  
PIC18F44J10@QFN44(ISP) [ISP-HEADER01]  
PIC18F44J10@QFN44(ML) [(SA709)]  
PIC18F44J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F44J10@TQFP44 [(SA245A)]  
PIC18F44J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18F44K20  
PIC18F44K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F44K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F44K20@QFN44 [(SA712)]  
PIC18F44K20@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F44K20@QFN44(ISP)(Low-V) [ISP-HEADER01]

PIC18F44K20@QFN44(ML) [(SA737)]  
PIC18F44K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F44K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18F44K20@TQFP44 [(SA245A)]  
PIC18F44K20@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F44K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4510 PIC18F4510(ISP) [ISP-  
HEADER01]  
PIC18F4510@QFN44 [(SA712)]  
PIC18F4510@QFN44(ISP) [ISP-HEADER01]  
PIC18F4510@QFN44(ML) [(SA737)]  
PIC18F4510@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4510@TQFP44 [(SA245A)]  
PIC18F4510@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4515  
PIC18F4515(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4515@QFN44 [(SA712)]  
PIC18F4515@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4515@QFN44(ML) [(SA737)]  
PIC18F4515@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4515@TQFP44 [(SA245A)]  
PIC18F4515@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F452 PIC18F452(ISP) [ISP-  
HEADER01]  
PIC18F452@PLCC44 [(SA244)]  
PIC18F452@PLCC44(ISP) [ISP-HEADER01]  
PIC18F452@TQFP44 [(SA245A)]  
PIC18F452@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4520 PIC18F4520(ISP) [ISP-  
HEADER01]  
PIC18F4520@QFN44 [(SA712)]  
PIC18F4520@QFN44(ISP) [ISP-HEADER01]  
PIC18F4520@QFN44(ML) [(SA737)]  
PIC18F4520@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4520@TQFP44 [(SA245A)]  
PIC18F4520@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4523  
PIC18F4523(ISP)(High-V) [ISP-HEADER01]  
PIC18F4523(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4523@QFN44 [(SA712)]  
PIC18F4523@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4523@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4523@QFN44(ML) [(SA737)]

PIC18F4523@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4523@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4523@TQFP44 [(SA245A)]  
PIC18F4523@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4523@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525  
PIC18F4525(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525@QFN44 [(SA712)]  
PIC18F4525@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525@QFN44(ML) [(SA737)]  
PIC18F4525@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525@TQFP44 [(SA245A)]  
PIC18F4525@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4539 PIC18F4539(ISP) [ISP-  
HEADER01]  
PIC18F4539@TQFP44 [(SA245A)]  
PIC18F4539@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4550  
PIC18F4550(ISP)(High-V) [ISP-HEADER01]  
PIC18F4550(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4550@QFN44 [(SA712)]  
PIC18F4550@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4550@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4550@QFN44(ML) [(SA737)]  
PIC18F4550@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4550@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4550@TQFP44 [(SA245A)]  
PIC18F4550@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4550@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4553  
PIC18F4553(ISP)(High-V) [ISP-HEADER01]  
PIC18F4553(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4553@QFN44 [(SA737)]  
PIC18F4553@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4553@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4553@TQFP44 [(SA245A)]  
PIC18F4553@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4553@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F458 PIC18F458(ISP) [ISP-  
HEADER01]  
PIC18F458@PLCC44 [(SA244)]  
PIC18F458@PLCC44(ISP) [ISP-HEADER01]  
PIC18F458@TQFP44 [(SA245A)]



PIC18F458@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4580  
PIC18F4580(ISP)(High-V) [ISP-HEADER01]  
PIC18F4580(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4580@QFN44 [(SA712)]  
PIC18F4580@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4580@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4580@QFN44(ML) [(SA737)]  
PIC18F4580@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4580@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4580@TQFP44 [(SA245A)]  
PIC18F4580@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4580@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585  
PIC18F4585(ISP)(High-V) [ISP-HEADER01]  
PIC18F4585(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585@QFN44 [(SA712)]  
PIC18F4585@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4585@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585@QFN44(ML) [(SA737)]  
PIC18F4585@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4585@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585@TQFP44 [(SA245A)]  
PIC18F4585@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F45J10 PIC18F45J10(ISP) [ISP-  
HEADER01]  
PIC18F45J10@QFN44 [(SA712)]  
PIC18F45J10@QFN44(ISP) [ISP-HEADER01]  
PIC18F45J10@QFN44(ML) [(SA709)]  
PIC18F45J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F45J10@TQFP44 [(SA245A)]  
PIC18F45J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18F45K20  
PIC18F45K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F45K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F45K20@QFN44 [(SA712)]  
PIC18F45K20@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F45K20@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F45K20@QFN44(ML) [(SA737)]  
PIC18F45K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F45K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18F45K20@TQFP44 [(SA245A)]

PIC18F45K20@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F45K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610  
PIC18F4610(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610@QFN44 [(SA712)]  
PIC18F4610@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610@QFN44(ML) [(SA737)]  
PIC18F4610@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610@TQFP44 [(SA245A)]  
PIC18F4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620  
PIC18F4620(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620@QFN44 [(SA712)]  
PIC18F4620@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620@QFN44(ML) [(SA737)]  
PIC18F4620@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620@TQFP44 [(SA245A)]  
PIC18F4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680  
PIC18F4680(ISP)(High-V) [ISP-HEADER01]  
PIC18F4680(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680@QFN44 [(SA712)]  
PIC18F4680@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4680@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680@QFN44(ML) [(SA737)]  
PIC18F4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4680@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680@TQFP44 [(SA245A)]  
PIC18F4680@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682  
PIC18F4682(ISP)(High-V) [ISP-HEADER01]  
PIC18F4682(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682@QFN44 [(SA712)]  
PIC18F4682@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4682@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682@QFN44(ML) [(SA737)]  
PIC18F4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4682@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682@TQFP44 [(SA245A)]  
PIC18F4682@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685

PIC18F4685(ISP)(High-V) [ISP-HEADER01]  
PIC18F4685(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685@QFN44 [(SA712)]  
PIC18F4685@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4685@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685@QFN44(ML) [(SA737)]  
PIC18F4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4685@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685@TQFP44 [(SA245A)]  
PIC18F4685@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6310@TQFP64 [(PEP+S616)]  
PIC18F6310@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6390@TQFP64 [(PEP+S616)]  
PIC18F6390@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6393@TQFP64 [(PEP+S616)]  
PIC18F6393@TQFP64(ISP) [ISP-HEADER01]  
PIC18F63J11@TQFP64 [(PEP+S616)]  
PIC18F63J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F63J90@TQFP64 [(PEP+S616)]  
PIC18F63J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6410@TQFP64 [(PEP+S616)]  
PIC18F6410@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6490@TQFP64 [(PEP+S616)]  
PIC18F6490@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6493@TQFP64 [(PEP+S616)]  
PIC18F6493@TQFP64(ISP) [ISP-HEADER01]  
PIC18F64J11@TQFP64 [(PEP+S616)]  
PIC18F64J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F64J90@TQFP64 [(PEP+S616)]  
PIC18F64J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6520@TQFP64 [(PEP+S616)]  
PIC18F6520@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6525@TQFP64 [(PEP+S616)]  
PIC18F6525@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6527@TQFP64 [(PEP+S616)]  
PIC18F6527@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6527@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6585@PLCC68 [(PEP+S414T)]  
PIC18F6585@PLCC68(ISP) [ISP-HEADER01]  
PIC18F6585@TQFP64 [(PEP+S616)]  
PIC18F6585@TQFP64(ISP) [ISP-HEADER01]  
PIC18F65J10@TQFP64 [(PEP+S616)]

PIC18F65J10@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F65J10@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F65J11@TQFP64 [(PEP+S616)]  
PIC18F65J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F65J15@TQFP64 [(PEP+S616)]  
PIC18F65J15@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F65J15@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F65J50@TQFP64 [(PEP+S616)]  
PIC18F65J50@TQFP64(ISP) [ISP-HEADER01]  
PIC18F65J90@TQFP64 [(PEP+S616)]  
PIC18F65J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6620@TQFP64 [(PEP+S616)]  
PIC18F6620@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6621@TQFP64 [(PEP+S616)]  
PIC18F6621@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6622@TQFP64 [(PEP+S616)]  
PIC18F6622@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6622@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6627@TQFP64 [(PEP+S616)]  
PIC18F6627@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6627@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6680@PLCC68 [(PEP+S414T)]  
PIC18F6680@PLCC68(ISP) [ISP-HEADER01]  
PIC18F6680@TQFP64 [(PEP+S616)]  
PIC18F6680@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J10@TQFP64 [(PEP+S616)]  
PIC18F66J10@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F66J10@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F66J11@TQFP64 [(PEP+S616)]  
PIC18F66J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J15@TQFP64 [(PEP+S616)]  
PIC18F66J15@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F66J15@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F66J16@TQFP64 [(PEP+S616)]  
PIC18F66J16@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J50@TQFP64 [(PEP+S616)]  
PIC18F66J50@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J55@TQFP64 [(PEP+S616)]  
PIC18F66J55@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J60@TQFP64 [(PEP+S616)]  
PIC18F66J60@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J65@TQFP64 [(PEP+S616)]  
PIC18F66J65@TQFP64(ISP) [ISP-HEADER01]

PIC18F6720@TQFP64 [(PEP+S616)]  
PIC18F6720@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6722@TQFP64 [(PEP+S616)]  
PIC18F6722@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6722@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F67J10@TQFP64 [(PEP+S616)]  
PIC18F67J10@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F67J10@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F67J11@TQFP64 [(PEP+S616)]  
PIC18F67J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F67J50@TQFP64 [(PEP+S616)]  
PIC18F67J50@TQFP64(ISP) [ISP-HEADER01]  
PIC18F67J60@TQFP64 [(PEP+S616)]  
PIC18F67J60@TQFP64(ISP) [ISP-HEADER01]  
PIC18F8310@TQFP80 [(PEP+S640B)]  
PIC18F8310@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8390@TQFP80 [(PEP+S640B)]  
PIC18F8390@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8393@TQFP80 [(PEP+S640B)]  
PIC18F8393@TQFP80(ISP) [ISP-HEADER01]  
PIC18F83J11@TQFP80 [(PEP+S640B)]  
PIC18F83J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F83J90@TQFP80 [(PEP+S640B)]  
PIC18F83J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8410@TQFP80 [(PEP+S640B)]  
PIC18F8410@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8490@TQFP80 [(PEP+S640B)]  
PIC18F8490@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8493@TQFP80 [(PEP+S640B)]  
PIC18F8493@TQFP80(ISP) [ISP-HEADER01]  
PIC18F84J11@TQFP80 [(PEP+S640B)]  
PIC18F84J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F84J90@TQFP80 [(PEP+S640B)]  
PIC18F84J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8520@TQFP80 [(PEP+S640B)]  
PIC18F8520@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8525@TQFP80 [(PEP+S640B)]  
PIC18F8525@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8527@TQFP80 [(PEP+S640B)]  
PIC18F8527@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8527@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F8585@TQFP80 [(PEP+S640B)]  
PIC18F8585@TQFP80(ISP) [ISP-HEADER01]

PIC18F85J10@TQFP80 [(PEP+S640B)]  
PIC18F85J10@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F85J10@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F85J11@TQFP80 [(PEP+S640B)]  
PIC18F85J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F85J15@TQFP80 [(PEP+S640B)]  
PIC18F85J15@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F85J15@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F85J50@TQFP80 [(PEP+S640B)]  
PIC18F85J50@TQFP80(ISP) [ISP-HEADER01]  
PIC18F85J90@TQFP80 [(PEP+S640B)]  
PIC18F85J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8620@TQFP80 [(PEP+S640B)]  
PIC18F8620@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8621@TQFP80 [(PEP+S640B)]  
PIC18F8621@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8622@TQFP80 [(PEP+S640B)]  
PIC18F8622@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F8627@TQFP80 [(PEP+S640B)]  
PIC18F8627@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F8680@TQFP80 [(PEP+S640B)]  
PIC18F8680@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J10@TQFP80 [(PEP+S640B)]  
PIC18F86J10@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F86J10@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F86J11@TQFP80 [(PEP+S640B)]  
PIC18F86J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J15@TQFP80 [(PEP+S640B)]  
PIC18F86J15@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F86J15@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F86J16@TQFP80 [(PEP+S640B)]  
PIC18F86J16@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J50@TQFP80 [(PEP+S640B)]  
PIC18F86J50@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J55@TQFP80 [(PEP+S640B)]  
PIC18F86J55@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J60@TQFP80 [(PEP+S640B)]  
PIC18F86J60@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J65@TQFP80 [(PEP+S640B)]  
PIC18F86J65@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8720@TQFP80 [(PEP+S640B)]

PIC18F8720@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8722@TQFP80 [(PEP+S640B)]  
PIC18F8722@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8722@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F87J10@TQFP80 [(PEP+S640B)]  
PIC18F87J10@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F87J10@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F87J11@TQFP80 [(PEP+S640B)]  
PIC18F87J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F87J50@TQFP80 [(PEP+S640B)]  
PIC18F87J50@TQFP80(ISP) [ISP-HEADER01]  
PIC18F87J60@TQFP80 [(PEP+S640B)]  
PIC18F87J60@TQFP80(ISP) [ISP-HEADER01]  
PIC18F96J60@TQFP100 [(PEP+S604)]  
PIC18F96J60@TQFP100(ISP) [ISP-HEADER01]  
PIC18F96J65@TQFP100 [(PEP+S604)]  
PIC18F96J65@TQFP100(ISP) [ISP-HEADER01]  
PIC18F97J60@TQFP100 [(PEP+S604)]  
PIC18F97J60@TQFP100(ISP) [ISP-HEADER01]  
PIC18LC452 PIC18LC452@PLCC44  
[(SA244)]  
PIC18LC452@TQFP44 [(SA245A)]  
PIC18LF1220  
PIC18LF1220(ISP) [ISP-HEADER01] PIC18LF1220@SOIC18  
[(SA404)]  
PIC18LF1220@SOIC18(ISP) [ISP-HEADER01]  
PIC18LF1220@SSOP20 [(SA626A)]  
PIC18LF1220@SSOP20(ISP) [ISP-HEADER01]  
PIC18LF1320 PIC18LF1320(ISP) [ISP-  
HEADER01]  
PIC18LF1320@SOIC18 [(SA404)]  
PIC18LF1320@SOIC18(ISP) [ISP-HEADER01]  
PIC18LF1320@SSOP20 [(SA626A)]  
PIC18LF1320@SSOP20(ISP) [ISP-HEADER01]  
PIC18LF2220 PIC18LF2220(ISP) [ISP-  
HEADER01]  
PIC18LF2220@SOIC28 [(SA404)]  
PIC18LF2220@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2221  
PIC18LF2221(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2221@QFN28 [(SA685-B006)]  
PIC18LF2221@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2221@SOIC28 [(SA404)]

PIC18LF2221@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2320 PIC18LF2320(ISP) [ISP-  
HEADER01]  
PIC18LF2320@SOIC28 [(SA404)]  
PIC18LF2320@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2321  
PIC18LF2321(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2321@QFN28 [(SA685-B006)]  
PIC18LF2321@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2321@SOIC28 [(SA404)]  
PIC18LF2321@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2331 PIC18LF2331(ISP) [ISP-  
HEADER01]  
PIC18LF2331@SOIC28 [(SA404)]  
PIC18LF2331@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2410  
PIC18LF2410(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2410@QFN28 [(SA685-B006)]  
PIC18LF2410@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2410@SOIC28 [(SA404)]  
PIC18LF2410@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF242 PIC18LF242(ISP) [ISP-  
HEADER01]  
PIC18LF242@SOIC28 [(SA404)]  
PIC18LF242@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2420  
PIC18LF2420(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2420(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2420@SOIC28 [(SA404)]  
PIC18LF2420@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2420@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2431 PIC18LF2431(ISP) [ISP-  
HEADER01]  
PIC18LF2431@SOIC28 [(SA404)]  
PIC18LF2431@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2439 PIC18LF2439(ISP) [ISP-  
HEADER01]  
PIC18LF2439@SOIC28 [(SA404)]  
PIC18LF2439@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2450  
PIC18LF2450(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2450@QFN28 [(SA685-B006)]  
PIC18LF2450@QFN28(ISP)(Low-V) [ISP-HEADER01]



PIC18LF2450@SOIC28 [(SA404)]  
PIC18LF2450@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2455  
PIC18LF2455(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2455(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2455@SOIC28 [(SA404)]  
PIC18LF2455@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2455@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF248 PIC18LF248(ISP) [ISP-  
HEADER01]  
PIC18LF248@SOIC28 [(SA404)]  
PIC18LF248@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2480  
PIC18LF2480(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2480(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2480@QFN28 [(SA685-B006)]  
PIC18LF2480@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2480@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2480@SOIC28 [(SA404)]  
PIC18LF2480@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2480@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF24J10 PIC18LF24J10(ISP) [ISP-  
HEADER01]  
PIC18LF24J10@QFN28 [(SA685-B006)]  
PIC18LF24J10@QFN28(ISP) [ISP-HEADER01]  
PIC18LF24J10@SOIC28 [(SA404)]  
PIC18LF24J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF24J10@SSOP28 [(SA626A)]  
PIC18LF24J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18LF2510 PIC18LF2510(ISP) [ISP-  
HEADER01]  
PIC18LF2510@QFN28 [(SA685-B006)]  
PIC18LF2510@QFN28(ISP) [ISP-HEADER01]  
PIC18LF2510@SOIC28 [(SA404)]  
PIC18LF2510@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2515  
PIC18LF2515(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2515@SOIC28 [(SA404)]  
PIC18LF2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF252 PIC18LF252(ISP) [ISP-  
HEADER01]  
PIC18LF252@SOIC28 [(SA404)]  
PIC18LF252@SOIC28(ISP) [ISP-HEADER01]

PIC18LF2520  
PIC18LF2520(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2520(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2520@SOIC28 [(SA404)]  
PIC18LF2520@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2525  
PIC18LF2525(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2525@SOIC28 [(SA404)]  
PIC18LF2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2539 PIC18LF2539(ISP) [ISP-  
HEADER01]  
PIC18LF2539@SOIC28 [(SA404)]  
PIC18LF2539@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2550  
PIC18LF2550(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2550(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2550@SOIC28 [(SA404)]  
PIC18LF2550@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF258 PIC18LF258(ISP) [ISP-  
HEADER01]  
PIC18LF258@SOIC28 [(SA404)]  
PIC18LF258@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2580  
PIC18LF2580(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2580(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2580@QFN28 [(SA685-B006)]  
PIC18LF2580@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2580@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2580@SOIC28 [(SA404)]  
PIC18LF2580@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2585  
PIC18LF2585(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2585@SDIP28 [(SA022A)]  
PIC18LF2585@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2585@SOIC28 [(SA404)]  
PIC18LF2585@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF25J10 PIC18LF25J10(ISP) [ISP-

HEADER01]

PIC18LF25J10@QFN28 [(SA685-B006)]

PIC18LF25J10@QFN28(ISP) [ISP-HEADER01]

PIC18LF25J10@SOIC28 [(SA404)]

PIC18LF25J10@SOIC28(ISP) [ISP-HEADER01]

PIC18LF25J10@SSOP28 [(SA626A)]

PIC18LF25J10@SSOP28(ISP) [ISP-HEADER01]

PIC18LF2610

PIC18LF2610(ISP)(Low-V) [ISP-HEADER01]

PIC18LF2610@SOIC28 [(SA404)]

PIC18LF2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]

PIC18LF2620

PIC18LF2620(ISP)(Low-V) [ISP-HEADER01]

PIC18LF2620@SOIC28 [(SA404)]

PIC18LF2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]

PIC18LF2680

PIC18LF2680(ISP)(High-V) [ISP-HEADER01]

PIC18LF2680(ISP)(Low-V) [ISP-HEADER01]

PIC18LF2680@SDIP28 [(SA022A)]

PIC18LF2680@SDIP28(ISP)(High-V) [ISP-HEADER01]

PIC18LF2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]

PIC18LF2680@SOIC28 [(SA404)]

PIC18LF2680@SOIC28(ISP)(High-V) [ISP-HEADER01]

PIC18LF2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]

PIC18LF2682

PIC18LF2682(ISP)(High-V) [ISP-HEADER01]

PIC18LF2682(ISP)(Low-V) [ISP-HEADER01]

PIC18LF2682@QFN28 [(SA685)]

PIC18LF2682@QFN28(ISP)(High-V) [ISP-HEADER01]

PIC18LF2682@QFN28(ISP)(Low-V) [ISP-HEADER01]

PIC18LF2682@SOIC28 [(SA404)]

PIC18LF2682@SOIC28(ISP)(High-V) [ISP-HEADER01]

PIC18LF2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]

PIC18LF2685

PIC18LF2685(ISP)(High-V) [ISP-HEADER01]

PIC18LF2685(ISP)(Low-V) [ISP-HEADER01]

PIC18LF2685@QFN28 [(SA685)]

PIC18LF2685@QFN28(ISP)(High-V) [ISP-HEADER01]

PIC18LF2685@QFN28(ISP)(Low-V) [ISP-HEADER01]

PIC18LF2685@SOIC28 [(SA404)]

PIC18LF2685@SOIC28(ISP)(High-V) [ISP-HEADER01]

PIC18LF2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]

PIC18LF4220

PIC18LF4220(ISP) [ISP-

HEADER01 ]  
PIC18LF4220@QFN44 [ (SA712) ]  
PIC18LF4220@QFN44(ISP) [ ISP-HEADER01 ]  
PIC18LF4220@QFN44(ML) [ (SA737) ]  
PIC18LF4220@QFN44(ML)(ISP) [ ISP-HEADER01 ]  
PIC18LF4220@TQFP44 [ (SA245A) ]  
PIC18LF4220@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC18LF4221  
PIC18LF4221(ISP)(Low-V) [ ISP-HEADER01 ]  
PIC18LF4221@QFN44 [ (SA712) ]  
PIC18LF4221@QFN44(ISP)(Low-V) [ ISP-HEADER01 ]  
PIC18LF4221@QFN44(ML) [ (SA737) ]  
PIC18LF4221@QFN44(ML)(ISP)(L-V) [ ISP-HEADER01 ]  
PIC18LF4221@TQFP44 [ (SA245A) ]  
PIC18LF4221@TQFP44(ISP)(Low-V) [ ISP-HEADER01 ]  
PIC18LF4320 PIC18LF4320(ISP) [ ISP-  
HEADER01 ]  
PIC18LF4320@QFN44 [ (SA712) ]  
PIC18LF4320@QFN44(ISP) [ ISP-HEADER01 ]  
PIC18LF4320@QFN44(ML) [ (SA737) ]  
PIC18LF4320@QFN44(ML)(ISP) [ ISP-HEADER01 ]  
PIC18LF4320@TQFP44 [ (SA245A) ]  
PIC18LF4320@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC18LF4321  
PIC18LF4321(ISP)(Low-V) [ ISP-HEADER01 ]  
PIC18LF4321@QFN44 [ (SA712) ]  
PIC18LF4321@QFN44(ISP)(Low-V) [ ISP-HEADER01 ]  
PIC18LF4321@QFN44(ML) [ (SA737) ]  
PIC18LF4321@QFN44(ML)(ISP)(L-V) [ ISP-HEADER01 ]  
PIC18LF4321@TQFP44 [ (SA245A) ]  
PIC18LF4321@TQFP44(ISP)(Low-V) [ ISP-HEADER01 ]  
PIC18LF4331 PIC18LF4331(ISP) [ ISP-  
HEADER01 ]  
PIC18LF4331@TQFP44 [ (SA245A) ]  
PIC18LF4331@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC18LF4410  
PIC18LF4410(ISP)(Low-V) [ ISP-HEADER01 ]  
PIC18LF4410@QFN44 [ (SA712) ]  
PIC18LF4410@QFN44(ISP)(Low-V) [ ISP-HEADER01 ]  
PIC18LF4410@QFN44(ML) [ (SA737) ]  
PIC18LF4410@QFN44(ML)(ISP)(L-V) [ ISP-HEADER01 ]  
PIC18LF4410@TQFP44 [ (SA245A) ]  
PIC18LF4410@TQFP44(ISP)(Low-V) [ ISP-HEADER01 ]

PIC18LF442 PIC18LF442(ISP) [ISP-  
HEADER01]  
PIC18LF442@PLCC44 [(SA244)]  
PIC18LF442@PLCC44(ISP) [ISP-HEADER01]  
PIC18LF442@TQFP44 [(SA245A)]  
PIC18LF442@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4420  
PIC18LF4420(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4420@QFN44 [(SA712)]  
PIC18LF4420@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4420@QFN44(ML) [(SA737)]  
PIC18LF4420@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4420@TQFP44 [(SA245A)]  
PIC18LF4420@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4431 PIC18LF4431(ISP) [ISP-  
HEADER01]  
PIC18LF4431@TQFP44 [(SA245A)]  
PIC18LF4431@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4439 PIC18LF4439(ISP) [ISP-  
HEADER01]  
PIC18LF4439@TQFP44 [(SA245A)]  
PIC18LF4439@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4450  
PIC18LF4450(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4450@QFN44 [(SA712)]  
PIC18LF4450@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4450@QFN44(ML) [(SA737)]  
PIC18LF4450@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4450@TQFP44 [(SA245A)]  
PIC18LF4450@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4455  
PIC18LF4455(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4455(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4455@QFN44 [(SA712)]  
PIC18LF4455@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4455@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4455@QFN44(ML) [(SA737)]  
PIC18LF4455@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4455@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4455@TQFP44 [(SA245A)]  
PIC18LF4455@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4455@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF448 PIC18LF448(ISP) [ISP-

HEADER01 ]  
PIC18LF448@PLCC44 [ (SA244) ]  
PIC18LF448@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC18LF448@TQFP44 [ (SA245A) ]  
PIC18LF448@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC18LF4480  
PIC18LF4480(ISP)(High-V) [ ISP-HEADER01 ]  
PIC18LF4480(ISP)(Low-V) [ ISP-HEADER01 ]  
PIC18LF4480@QFN44 [ (SA712) ]  
PIC18LF4480@QFN44(ISP)(High-V) [ ISP-HEADER01 ]  
PIC18LF4480@QFN44(ISP)(Low-V) [ ISP-HEADER01 ]  
PIC18LF4480@QFN44(ML) [ (SA737) ]  
PIC18LF4480@QFN44(ML)(ISP)(H-V) [ ISP-HEADER01 ]  
PIC18LF4480@QFN44(ML)(ISP)(L-V) [ ISP-HEADER01 ]  
PIC18LF4480@TQFP44 [ (SA245A) ]  
PIC18LF4480@TQFP44(ISP)(High-V) [ ISP-HEADER01 ]  
PIC18LF4480@TQFP44(ISP)(Low-V) [ ISP-HEADER01 ]  
PIC18LF44J10 PIC18LF44J10(ISP) [ ISP-  
HEADER01 ]  
PIC18LF44J10@QFN44 [ (SA712) ]  
PIC18LF44J10@QFN44(ISP) [ ISP-HEADER01 ]  
PIC18LF44J10@QFN44(ML) [ (SA709) ]  
PIC18LF44J10@QFN44(ML)(ISP) [ ISP-HEADER01 ]  
PIC18LF44J10@TQFP44 [ (SA245A) ]  
PIC18LF44J10@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC18LF4510 PIC18LF4510(ISP) [ ISP-  
HEADER01 ]  
PIC18LF4510@QFN44 [ (SA712) ]  
PIC18LF4510@QFN44(ISP) [ ISP-HEADER01 ]  
PIC18LF4510@QFN44(ML) [ (SA737) ]  
PIC18LF4510@QFN44(ML)(ISP) [ ISP-HEADER01 ]  
PIC18LF4510@TQFP44 [ (SA245A) ]  
PIC18LF4510@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC18LF4515  
PIC18LF4515(ISP)(Low-V) [ ISP-HEADER01 ]  
PIC18LF4515@QFN44 [ (SA712) ]  
PIC18LF4515@QFN44(ISP)(Low-V) [ ISP-HEADER01 ]  
PIC18LF4515@QFN44(ML) [ (SA737) ]  
PIC18LF4515@QFN44(ML)(ISP)(L-V) [ ISP-HEADER01 ]  
PIC18LF4515@TQFP44 [ (SA245A) ]  
PIC18LF4515@TQFP44(ISP)(Low-V) [ ISP-HEADER01 ]  
PIC18LF452 PIC18LF452(ISP) [ ISP-  
HEADER01 ]

PIC18LF452@PLCC44 [(SA244)]  
PIC18LF452@PLCC44(ISP) [ISP-HEADER01]  
PIC18LF452@TQFP44 [(SA245A)]  
PIC18LF452@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4520 PIC18LF4520(ISP) [ISP-  
HEADER01]  
PIC18LF4520@QFN44 [(SA712)]  
PIC18LF4520@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4520@QFN44(ML) [(SA737)]  
PIC18LF4520@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4520@TQFP44 [(SA245A)]  
PIC18LF4520@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4525  
PIC18LF4525(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4525@QFN44 [(SA712)]  
PIC18LF4525@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4525@QFN44(ML) [(SA737)]  
PIC18LF4525@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4525@TQFP44 [(SA245A)]  
PIC18LF4525@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4539 PIC18LF4539(ISP) [ISP-  
HEADER01]  
PIC18LF4539@TQFP44 [(SA245A)]  
PIC18LF4539@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4550  
PIC18LF4550(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4550(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4550@QFN44 [(SA712)]  
PIC18LF4550@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4550@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4550@QFN44(ML) [(SA737)]  
PIC18LF4550@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4550@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4550@TQFP44 [(SA245A)]  
PIC18LF4550@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4550@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF458 PIC18LF458(ISP) [ISP-  
HEADER01]  
PIC18LF458@PLCC44 [(SA244)]  
PIC18LF458@PLCC44(ISP) [ISP-HEADER01]  
PIC18LF458@TQFP44 [(SA245A)]  
PIC18LF458@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4580

PIC18LF4580(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4580(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4580@QFN44 [(SA712)]  
PIC18LF4580@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4580@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4580@QFN44(ML) [(SA737)]  
PIC18LF4580@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4580@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4580@TQFP44 [(SA245A)]  
PIC18LF4580@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4580@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4585  
PIC18LF4585(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4585(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4585@QFN44 [(SA712)]  
PIC18LF4585@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4585@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4585@QFN44(ML) [(SA737)]  
PIC18LF4585@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4585@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4585@TQFP44 [(SA245A)]  
PIC18LF4585@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF45J10 PIC18LF45J10(ISP) [ISP-  
HEADER01]  
PIC18LF45J10@QFN44 [(SA712)]  
PIC18LF45J10@QFN44(ISP) [ISP-HEADER01]  
PIC18LF45J10@QFN44(ML) [(SA709)]  
PIC18LF45J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF45J10@TQFP44 [(SA245A)]  
PIC18LF45J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4610  
PIC18LF4610(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4610@QFN44 [(SA712)]  
PIC18LF4610@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4610@QFN44(ML) [(SA737)]  
PIC18LF4610@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4610@TQFP44 [(SA245A)]  
PIC18LF4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4620  
PIC18LF4620(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4620@QFN44 [(SA712)]  
PIC18LF4620@QFN44(ISP)(Low-V) [ISP-HEADER01]



PIC18LF4620@QFN44(ML) [(SA737)]  
PIC18LF4620@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4620@TQFP44 [(SA245A)]  
PIC18LF4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4680  
PIC18LF4680(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4680(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4680@QFN44 [(SA712)]  
PIC18LF4680@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4680@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4680@QFN44(ML) [(SA737)]  
PIC18LF4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4680@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4680@TQFP44 [(SA245A)]  
PIC18LF4680@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4682  
PIC18LF4682(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4682(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4682@QFN44 [(SA712)]  
PIC18LF4682@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4682@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4682@QFN44(ML) [(SA737)]  
PIC18LF4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4682@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4682@TQFP44 [(SA245A)]  
PIC18LF4682@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4685  
PIC18LF4685(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4685(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4685@QFN44 [(SA712)]  
PIC18LF4685@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4685@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4685@QFN44(ML) [(SA737)]  
PIC18LF4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4685@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4685@TQFP44 [(SA245A)]  
PIC18LF4685@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6310@TQFP64 [(PEP+S616)]  
PIC18LF6310@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6390@TQFP64 [(PEP+S616)]

PIC18LF6390@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF6393@TQFP64 [(PEP+S616)]  
PIC18LF6393@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF63J11@TQFP64 [(PEP+S616)]  
PIC18LF63J11@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF63J90@TQFP64 [(PEP+S616)]  
PIC18LF63J90@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF6410@TQFP64 [(PEP+S616)]  
PIC18LF6410@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF6490@TQFP64 [(PEP+S616)]  
PIC18LF6490@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF6493@TQFP64 [(PEP+S616)]  
PIC18LF6493@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF64J11@TQFP64 [(PEP+S616)]  
PIC18LF64J11@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF64J90@TQFP64 [(PEP+S616)]  
PIC18LF64J90@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF6520@TQFP64 [(PEP+S616)]  
PIC18LF6520@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF6525@TQFP64 [(PEP+S616)]  
PIC18LF6525@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF6527@TQFP64 [(PEP+S616)]  
PIC18LF6527@TQFP64 (ISP)(High-V) [ISP-HEADER01]  
PIC18LF6527@TQFP64 (ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6585@PLCC68 [(PEP+S414T)]  
PIC18LF6585@PLCC68 (ISP) [ISP-HEADER01]  
PIC18LF6585@TQFP64 [(PEP+S616)]  
PIC18LF6585@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF65J11@TQFP64 [(PEP+S616)]  
PIC18LF65J11@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF65J90@TQFP64 [(PEP+S616)]  
PIC18LF65J90@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF6620@TQFP64 [(PEP+S616)]  
PIC18LF6620@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF6621@TQFP64 [(PEP+S616)]  
PIC18LF6621@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF6622@TQFP64 [(PEP+S616)]  
PIC18LF6622@TQFP64 (ISP)(High-V) [ISP-HEADER01]  
PIC18LF6622@TQFP64 (ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6627@TQFP64 [(PEP+S616)]  
PIC18LF6627@TQFP64 (ISP)(High-V) [ISP-HEADER01]  
PIC18LF6627@TQFP64 (ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6680@PLCC68 [(PEP+S414T)]

PIC18LF6680@PLCC68 (ISP) [ISP-HEADER01]  
PIC18LF6680@TQFP64 [(PEP+S616)]  
PIC18LF6680@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF6720@TQFP64 [(PEP+S616)]  
PIC18LF6720@TQFP64 (ISP) [ISP-HEADER01]  
PIC18LF6722@TQFP64 [(PEP+S616)]  
PIC18LF6722@TQFP64 (ISP) (High-V) [ISP-HEADER01]  
PIC18LF6722@TQFP64 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF8310@TQFP80 [(PEP+S640B)]  
PIC18LF8310@TQFP80 (ISP) [ISP-HEADER01]  
PIC18LF8390@TQFP80 [(PEP+S640B)]  
PIC18LF8390@TQFP80 (ISP) [ISP-HEADER01]  
PIC18LF8393@TQFP80 [(PEP+S640B)]  
PIC18LF8393@TQFP80 (ISP) [ISP-HEADER01]  
PIC18LF83J11@TQFP80 [(PEP+S640B)]  
PIC18LF83J11@TQFP80 (ISP) [ISP-HEADER01]  
PIC18LF83J90@TQFP80 [(PEP+S640B)]  
PIC18LF83J90@TQFP80 (ISP) [ISP-HEADER01]  
PIC18LF8410@TQFP80 [(PEP+S640B)]  
PIC18LF8410@TQFP80 (ISP) [ISP-HEADER01]  
PIC18LF8490@TQFP80 [(PEP+S640B)]  
PIC18LF8490@TQFP80 (ISP) [ISP-HEADER01]  
PIC18LF8493@TQFP80 [(PEP+S640B)]  
PIC18LF8493@TQFP80 (ISP) [ISP-HEADER01]  
PIC18LF84J11@TQFP80 [(PEP+S640B)]  
PIC18LF84J11@TQFP80 (ISP) [ISP-HEADER01]  
PIC18LF84J90@TQFP80 [(PEP+S640B)]  
PIC18LF84J90@TQFP80 (ISP) [ISP-HEADER01]  
PIC18LF8520@TQFP80 [(PEP+S640B)]  
PIC18LF8520@TQFP80 (ISP) [ISP-HEADER01]  
PIC18LF8525@TQFP80 [(PEP+S640B)]  
PIC18LF8525@TQFP80 (ISP) [ISP-HEADER01]  
PIC18LF8527@TQFP80 [(PEP+S640B)]  
PIC18LF8527@TQFP80 (ISP) (High-V) [ISP-HEADER01]  
PIC18LF8527@TQFP80 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF8585@TQFP80 [(PEP+S640B)]  
PIC18LF8585@TQFP80 (ISP) [ISP-HEADER01]  
PIC18LF85J11@TQFP80 [(PEP+S640B)]  
PIC18LF85J11@TQFP80 (ISP) [ISP-HEADER01]  
PIC18LF85J90@TQFP80 [(PEP+S640B)]  
PIC18LF85J90@TQFP80 (ISP) [ISP-HEADER01]  
PIC18LF8620@TQFP80 [(PEP+S640B)]  
PIC18LF8620@TQFP80 (ISP) [ISP-HEADER01]

PIC18LF8621@TQFP80 [(PEP+S640B)]  
PIC18LF8621@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8622@TQFP80 [(PEP+S640B)]  
PIC18LF8622@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF8627@TQFP80 [(PEP+S640B)]  
PIC18LF8627@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF8680@TQFP80 [(PEP+S640B)]  
PIC18LF8680@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8720@TQFP80 [(PEP+S640B)]  
PIC18LF8720@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8722@TQFP80 [(PEP+S640B)]  
PIC18LF8722@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8722@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC24HJ128GP206@TQFP64 [(PEP+S616)]  
PIC24HJ128GP210@TQFP100 [(PEP+S604)]  
PIC24HJ128GP306@TQFP64 [(PEP+S616)]  
PIC24HJ128GP310@TQFP100 [(PEP+S604)]  
PIC24HJ128GP506@TQFP64 [(PEP+S616)]  
PIC24HJ128GP510@TQFP100 [(PEP+S604)]  
PIC24HJ256GP206@TQFP64 [(PEP+S616)]  
PIC24HJ256GP210@TQFP100 [(PEP+S604)]  
PIC24HJ256GP610@TQFP100 [(PEP+S604)]  
PIC24HJ64GP206@TQFP64 [(PEP+S616)]  
PIC24HJ64GP210@TQFP100 [(PEP+S604)]  
PIC24HJ64GP506@TQFP64 [(PEP+S616)]  
PIC24HJ64GP510@TQFP100 [(PEP+S604)]  
PIC30F2010 PIC30F2010(ISP) [ISP-  
HEADER01]  
PIC30F2010@SDIP28 [(SA022A)]  
PIC30F2010@SDIP28(ISP) [ISP-HEADER01]  
PIC30F2010@SOIC28 [(SA404)]  
PIC30F2010@SOIC28(ISP) [ISP-HEADER01]  
PIC30F2011 PIC30F2011(ISP) [ISP-  
HEADER01]  
PIC30F2011@QFN28 [(SA685-B006)]  
PIC30F2011@QFN28(ISP) [ISP-HEADER01]  
PIC30F2011@SDIP18 [(SA022A)]  
PIC30F2011@SDIP18(ISP) [ISP-HEADER01]  
PIC30F2011@SOIC18 [(SA404)]  
PIC30F2011@SOIC18(ISP) [ISP-HEADER01]  
PIC30F2012 PIC30F2012(ISP) [ISP-

HEADER01]

PIC30F2012@QFN28 [(SA685-B006)]

PIC30F2012@QFN28(ISP) [ISP-HEADER01]

PIC30F2012@SDIP28 [(SA022A)]

PIC30F2012@SDIP28(ISP) [ISP-HEADER01]

PIC30F2012@SOIC28 [(SA404)]

PIC30F2012@SOIC28(ISP) [ISP-HEADER01]

PIC30F3010

PIC30F3010(ISP) [ISP-

HEADER01]

PIC30F3010@QFN44 [(SA737)]

PIC30F3010@QFN44(ISP) [ISP-HEADER01]

PIC30F3010@SDIP28 [(SA022A)]

PIC30F3010@SDIP28(ISP) [ISP-HEADER01]

PIC30F3010@SOIC28 [(SA404)]

PIC30F3010@SOIC28(ISP) [ISP-HEADER01]

PIC30F3011

PIC30F3011(ISP) [ISP-

HEADER01]

PIC30F3011@QFN44 [(SA737)]

PIC30F3011@QFN44(ISP) [ISP-HEADER01]

PIC30F3011@QFP44 [(SA245A)]

PIC30F3011@QFP44(ISP) [ISP-HEADER01]

PIC30F3012

PIC30F3012(ISP) [ISP-

HEADER01]

PIC30F3012@QFN44 [(SA737)]

PIC30F3012@QFN44(ISP) [ISP-HEADER01]

PIC30F3012@SDIP18 [(SA022A)]

PIC30F3012@SDIP18(ISP) [ISP-HEADER01]

PIC30F3012@SOIC18 [(SA404)]

PIC30F3012@SOIC18(ISP) [ISP-HEADER01]

PIC30F3013

PIC30F3013(ISP) [ISP-

HEADER01]

PIC30F3013@QFN44 [(SA737)]

PIC30F3013@QFN44(ISP) [ISP-HEADER01]

PIC30F3013@SDIP28 [(SA022A)]

PIC30F3013@SDIP28(ISP) [ISP-HEADER01]

PIC30F3013@SOIC28 [(SA404)]

PIC30F3013@SOIC28(ISP) [ISP-HEADER01]

PIC30F3014

PIC30F3014(ISP) [ISP-

HEADER01]

PIC30F3014@QFN44 [(SA737)]

PIC30F3014@QFN44(ISP) [ISP-HEADER01]

PIC30F3014@QFP44 [(SA245A)]

PIC30F3014@QFP44(ISP) [ISP-HEADER01]

PIC30F4011 PIC30F4011(ISP) [ISP-  
HEADER01]  
PIC30F4011@QFN44 [(SA737)]  
PIC30F4011@QFN44(ISP) [ISP-HEADER01]  
PIC30F4011@QFP44 [(SA245A)]  
PIC30F4011@QFP44(ISP) [ISP-HEADER01]  
PIC30F4012 PIC30F4012(ISP) [ISP-  
HEADER01]  
PIC30F4012@QFN44 [(SA737)]  
PIC30F4012@QFN44(ISP) [ISP-HEADER01]  
PIC30F4012@SDIP28 [(SA022A)]  
PIC30F4012@SDIP28(ISP) [ISP-HEADER01]  
PIC30F4012@SOIC28 [(SA404)]  
PIC30F4012@SOIC28(ISP) [ISP-HEADER01]  
PIC30F4013 PIC30F4013(ISP) [ISP-  
HEADER01]  
PIC30F4013@QFN44 [(SA737)]  
PIC30F4013@QFN44(ISP) [ISP-HEADER01]  
PIC30F4013@QFP44 [(SA245A)]  
PIC30F4013@QFP44(ISP) [ISP-HEADER01]  
PIC30F5011@QFP64 [(PEP+S616)]  
PIC30F5011@QFP64(ISP) [ISP-HEADER01]  
PIC30F5013@QFP80 [(PEP+S640B)]  
PIC30F5013@QFP80(ISP) [ISP-HEADER01]  
PIC30F5015@QFP64 [(PEP+S616)]  
PIC30F5015@QFP64(ISP) [ISP-HEADER01]  
PIC30F5016@QFP80 [(PEP+S640B)]  
PIC30F5016@QFP80(ISP) [ISP-HEADER01]  
PIC30F6010@QFP80 [(PEP+S640B)]  
PIC30F6010@QFP80(ISP) [ISP-HEADER01]  
PIC30F6010A@QFP80 [(PEP+S640B)]  
PIC30F6010A@QFP80(fast) [(PEP+S640B)]  
PIC30F6010A@QFP80(ISP) [ISP-HEADER01]  
PIC30F6010A@TQFP80 [(PEP+S704)]  
PIC30F6010A@TQFP80(fast) [(PEP+S704)]  
PIC30F6010A@TQFP80(ISP) [ISP-HEADER01]  
PIC30F6011@QFP64 [(PEP+S616)]  
PIC30F6011@QFP64(ISP) [ISP-HEADER01]  
PIC30F6011A@QFP64 [(PEP+S616)]  
PIC30F6011A@QFP64(ISP) [ISP-HEADER01]  
PIC30F6012@QFP64 [(PEP+S616)]  
PIC30F6012@QFP64(ISP) [ISP-HEADER01]  
PIC30F6012A@QFP64 [(PEP+S616)]

PIC30F6012A@QFP64(ISP) [ISP-HEADER01]  
PIC30F6013@QFP80 [(PEP+S640B)]  
PIC30F6013@QFP80(ISP) [ISP-HEADER01]  
PIC30F6013A@QFP80 [(PEP+S640B)]  
PIC30F6013A@QFP80(ISP) [ISP-HEADER01]  
PIC30F6014@QFP80 [(PEP+S640B)]  
PIC30F6014@QFP80(ISP) [ISP-HEADER01]  
PIC30F6014A@QFP80 [(PEP+S640B)]  
PIC30F6014A@QFP80(ISP) [ISP-HEADER01]  
PIC30F6014A@TQFP80 [(PEP+S704)]  
PIC30F6014A@TQFP80(ISP) [ISP-HEADER01]  
PIC30F6015@QFP64 [(PEP+S616)]  
PIC30F6015@QFP64(ISP) [ISP-HEADER01]  
PIC33FJ128GP206@TQFP64 [(PEP+S616)]  
PIC33FJ128GP306@TQFP64 [(PEP+S616)]  
PIC33FJ128GP310@TQFP100 [(PEP+S604)]  
PIC33FJ128GP706@TQFP64 [(PEP+S616)]  
PIC33FJ128GP708@TQFP80 [(PEP+S640B)]  
PIC33FJ128GP710@TQFP100 [(PEP+S604)]  
PIC33FJ128MC506@TQFP64 [(PEP+S616)]  
PIC33FJ128MC510@TQFP100 [(PEP+S604)]  
PIC33FJ128MC706@TQFP64 [(PEP+S616)]  
PIC33FJ128MC708@TQFP80 [(PEP+S640B)]  
PIC33FJ128MC710@TQFP100 [(PEP+S604)]  
PIC33FJ256GP506@TQFP64 [(PEP+S616)]  
PIC33FJ256GP510@TQFP100 [(PEP+S604)]  
PIC33FJ256GP710@TQFP100 [(PEP+S604)]  
PIC33FJ256MC510@TQFP100 [(PEP+S604)]  
PIC33FJ256MC710@TQFP100 [(PEP+S604)]  
PIC33FJ64GP206@TQFP64 [(PEP+S616)]  
PIC33FJ64GP306@TQFP64 [(PEP+S616)]  
PIC33FJ64GP310@TQFP100 [(PEP+S604)]  
PIC33FJ64GP706@TQFP64 [(PEP+S616)]  
PIC33FJ64GP708@TQFP80 [(PEP+S640B)]  
PIC33FJ64GP710@TQFP100 [(PEP+S604)]  
PIC33FJ64MC506@TQFP64 [(PEP+S616)]  
PIC33FJ64MC508@TQFP80 [(PEP+S640B)]  
PIC33FJ64MC510@TQFP100 [(PEP+S604)]  
PIC33FJ64MC706@TQFP64 [(PEP+S616)]  
PIC33FJ64MC710@TQFP100 [(PEP+S604)]  
PS200 PS200(ISP) [ISP-  
HEADER01] HEADER01]  
PS200@SOIC20 [(SA404)] PS200@SOIC20(ISP) [ISP-

HEADER01 ]

PS200@SSOP20 [ (SA626A) ]

PS200@SSOP20(ISP) [ ISP-

HEADER01 ]

rfPIC12C509AF@SSOP20 [ (SA626A) ]

rfPIC12C509AF@SSOP20(ISP) [ ISP-HEADER01 ]

rfPIC12C509AG@SOIC18 [ (SA404) ]

rfPIC12C509AG@SOIC18(ISP) [ ISP-HEADER01 ]

rfPIC12LC509AF@SSOP20 [ (SA626A) ]

rfPIC12LC509AF@SSOP20(ISP) [ ISP-HEADER01 ]

rfPIC12LC509AG@SOIC18 [ (SA404) ]

rfPIC12LC509AG@SOIC18(ISP) [ ISP-HEADER01 ]

**MICRON****E ( E ) PROM / FRAM / NVRAM**MT28F002B1VG-B@TSOP40 [ (SA409T) ]  
[ (SA409T) ]

MT28F002B1VG-T@TSOP40

MT28F002B3VG-B@TSOP40 [ (SA409T) ]  
[ (SA409T) ]

MT28F002B3VG-T@TSOP40

MT28F002B5VG-B@TSOP40 [ (SA409T) ]  
[ (SA409T) ]

MT28F002B5VG-T@TSOP40

MT28F002C1VG-T@TSOP40 [ (SA409T) ]  
[ (SA409T) ]

MT28F002C5VG-T@TSOP40

MT28F002VG-B@TSOP40 [ (SA409T) ]  
[ (SA409T) ]

MT28F002VG-T@TSOP40

MT28F004B1VG-B@TSOP40 [ (SA409T) ]  
[ (SA409T) ]

MT28F004B1VG-T@TSOP40

MT28F004B3VG-B@TSOP40 [ (SA409T) ]  
[ (SA409T) ]

MT28F004B3VG-T@TSOP40

MT28F004B5VG-B@TSOP40 [ (SA409T) ]  
[ (SA409T) ]

MT28F004B5VG-T@TSOP40

MT28F004VG-B@TSOP40 [ (SA409T) ]  
[ (SA409T) ]

MT28F004VG-T@TSOP40

MT28F008B1VG-B@TSOP40 [ (SA409T) ]  
[ (SA409T) ]

MT28F008B1VG-T@TSOP40

MT28F008B3VG-B@TSOP40 [ (SA409T) ]  
[ (SA409T) ]

MT28F008B3VG-T@TSOP40

MT28F008B5VG-B@TSOP40 [ (SA409T) ]  
[ (SA409T) ]

MT28F008B5VG-T@TSOP40

MT28F016S3VG@TSOP40 [ (SA409T) ]  
[ (SA409T) ]

MT28F016S5VG@TSOP40



MT28F1284W18BQ@VFBGA56 [(SA656D-B085A-Y056F001Y)]  
MT28F1284W18TQ@VFBGA56 [(SA656D-B085A-Y056F001Y)]  
MT28F128J3A(FW203)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F128J3A(FW501)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F128J3A(FW502)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F128J3A(FW503)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F128J3A(INTEL)@TSOP56 [(SA628-B018)]  
MT28F128J3A(MICRON)@TSOP56 [(SA628-B018)]  
MT28F160A18FF(BET)(FW712)@FBGA48 [(SA634A-B005A-Y048F001)]  
MT28F160A18FF(TET)(FW713)@FBGA48 [(SA634A-B005A-Y048F001)]  
MT28F160C34FD(BET)(FW614)@FBGA48 [(SA634A-B005A-Y048F001)]  
MT28F160C34FD(TET)(FW615)@FBGA48 [(SA634A-B005A-Y048F001)]  
MT28F160C3FD(BET)(FW610)@FBGA48 [(SA634A-B005A-Y048F001)]  
MT28F160C3FD(BET)(FW612)@FBGA48 [(SA634A-B005A-Y048F001)]  
MT28F160C3FD(TET)(FW611)@FBGA48 [(SA634A-B005A-Y048F001)]  
MT28F160C3FD(TET)(FW613)@FBGA48 [(SA634A-B005A-Y048F001)]  
MT28F162A3FD(BET)@FBGA48 [(SA634A-B005A-Y048F001)]  
MT28F162A3FD(TET)@FBGA48 [(SA634A-B005A-Y048F001)]  
MT28F200B1SGB@PSOP44 [(SA638)] MT28F200B1SGT@PSOP44  
[(SA638)]  
MT28F200B1WGB@TSOP48 [(SA247-B005)]  
MT28F200B1WGT@TSOP48 [(SA247-B005)]  
MT28F200B3SGB@PSOP44 [(SA638)] MT28F200B3SGT@PSOP44  
[(SA638)]  
MT28F200B3WGB@TSOP48 [(SA247-B005)]  
MT28F200B3WGT@TSOP48 [(SA247-B005)]  
MT28F200B5SGB@PSOP44 [(SA638)] MT28F200B5SGT@PSOP44  
[(SA638)]  
MT28F200B5WGB@TSOP48 [(SA247-B005)]  
MT28F200B5WGT@TSOP48 [(SA247-B005)]  
MT28F320A18FF(BET)(FW722)@FBGA48 [(SA634A-B005A-Y048F001)]  
MT28F320A18FF(TET)(FW723)@FBGA48 [(SA634A-B005A-Y048F001)]  
MT28F320J3A(FW201)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F320J3A(FW204)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F320J3A(FW207)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F320J3A(FW208)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F320J3A(INTEL)@TSOP56 [(SA628-B018)]  
MT28F320J3A(MICRON)@TSOP56 [(SA628-B018)]  
MT28F321P18FG(BET)(FW820)@FBGA48 [(SA634A-B005A-Y048F001)]  
MT28F321P18FG(TET)(FW821)@FBGA48 [(SA634A-B005A-Y048F001)]  
MT28F321P20FG(BET)(FW810)@FBGA48 [(SA634A-B005A-Y048F001)]  
MT28F321P20FG(BET)(FW818)@FBGA48 [(SA634A-B005A-Y048F001)]  
MT28F321P20FG(TET)(FW811)@FBGA48 [(SA634A-B005A-Y048F001)]

MT28F321P20FG(TET)(FW819)@FBGA48 [(SA634A-B005A-Y048F001)]  
MT28F322D18FH(BET)(FW536)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322D18FH(BET)(FW538)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322D18FH(BET)(FW542)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322D18FH(BET)(FW556)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322D18FH(BET)(FW559)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322D18FH(TET)(FW535)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322D18FH(TET)(FW537)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322D18FH(TET)(FW543)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322D18FH(TET)(FW557)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322D18FH(TET)(FW558)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322D20FH(BET)(FW547)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322D20FH(BET)(FW549)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322D20FH(BET)(FW550)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322D20FH(BET)(FW552)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322D20FH(TET)(FW546)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322D20FH(TET)(FW548)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322D20FH(TET)(FW551)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322D20FH(TET)(FW553)@FBGA58 [(SA644A-B025A-Y056N001)]  
MT28F322P3FJ(BET)(FW814)@FGBA48 [(SA634A-B005A-Y048F001)]  
MT28F322P3FJ(BET)(FW816)@FGBA48 [(SA634A-B005A-Y048F001)]  
MT28F322P3FJ(TET)(FW815)@FGBA48 [(SA634A-B005A-Y048F001)]  
MT28F322P3FJ(TET)(FW817)@FGBA48 [(SA634A-B005A-Y048F001)]  
MT28F400B1SGB@PSOP44 [(SA638)] MT28F400B1SGT@PSOP44  
[(SA638)]  
MT28F400B1WGB@TSOP48 [(SA247-B005)]  
MT28F400B1WGT@TSOP48 [(SA247-B005)]  
MT28F400B3SGB@PSOP44 [(SA638)] MT28F400B3SGT@PSOP44  
[(SA638)]  
MT28F400B3WGB@TSOP48 [(SA247-B005)]  
MT28F400B3WGT@TSOP48 [(SA247-B005)]  
MT28F400B5SGB@PSOP44 [(SA638)] MT28F400B5SGT@PSOP44  
[(SA638)]  
MT28F400B5WGB@TSOP48 [(SA247-B005)]  
MT28F400B5WGT@TSOP48 [(SA247-B005)]  
MT28F640J3A(FW202)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW205)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW206)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW209)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW505)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW506)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(INTEL)@TSOP56 [(SA628-B018)]  
MT28F640J3A(MICRON)@TSOP56 [(SA628-B018)]

MT28F800B1SGB@PSOP44 [ (SA638) ] MT28F800B1SGT@PSOP44  
[ (SA638) ]  
MT28F800B1WGB@TSOP48 [ (SA247-B005) ]  
MT28F800B1WGT@TSOP48 [ (SA247-B005) ]  
MT28F800B3SGB@PSOP44 [ (SA638) ] MT28F800B3SGT@PSOP44  
[ (SA638) ]  
MT28F800B3WGB@TSOP48 [ (SA247-B005) ]  
MT28F800B3WGT@TSOP48 [ (SA247-B005) ]  
MT28F800B5SGB@PSOP44 [ (SA638) ] MT28F800B5SGT@PSOP44  
[ (SA638) ]  
MT28F800B5WGB@TSOP48 [ (SA247-B005) ]  
MT28F800B5WGT@TSOP48 [ (SA247-B005) ]  
MT29F1G08ABAWP@TSOP48 [ (SA247-B005) ]  
MT29F1G16ABAWP@TSOP48 [ (SA247-B005) ]  
MT29F2G08AAAWG@TSOP48 [ (SA247-B005) ]  
MT29F2G08AABWP@TSOP48 [ (SA247-B005) ]  
MT29F2G08AACWP@TSOP48 [ (SA247-B005) ]  
MT29F4G08AAAWP@TSOP48 [ (SA247-B005) ]  
MT29F4G08BAB@TSOP48 [ (SA247-B005) ]  
MT29F8G08DAA@TSOP48 [ (SA247-B005) ]

## DRAM & SRAM

MTSRAM@FBGA48 [ (SA634A-B005A-Y048F001) ]

## MICRONAS

### MICROCONTROLLER

SDA555XFL@SDIP52 [ (PEP+S627) ]  
SDA555XFL@SDIP52(\*) [ (SA627-B5603) ]

## MICRON-CUSTOMER

### E(E) PROM/FRAM/NVRAM

MT29F4G08AAAWP(sony)@TSOP48 [ (SA247+B005) ]

**mitsubishi****E ( E ) PROM / FRAM / NVRAM**

M5L27128K	
M5L2716	
M5L27256K	
M5L2732	
M5L2732A	
M5L27512	
M5L27512K	
M5L2764K	
M5L27C512A	
M5M27128P	
M5M27256P	
M5M27512P	
M5M2764P	
M5M27C100K	
M5M27C100K@PLCC32 [ ( SA015A1T ) ]	M5M27C100K@TSOP32
[ ( SA410T ) ]	
M5M27C100P	M5M27C100P@PLCC32
[ ( SA015A1T ) ]	
M5M27C100P@TSOP32 [ ( SA410T ) ]	
M5M27C101JK	
M5M27C101JK@PLCC32 [ ( SA015A1T ) ]	M5M27C101JK@TSOP32
[ ( SA410T ) ]	
M5M27C101K	M5M27C101K@PLCC32
[ ( SA015A1T ) ]	
M5M27C101K@TSOP32 [ ( SA410T ) ]	
M5M27C101P	
M5M27C101P@PLCC32 [ ( SA015A1T ) ]	M5M27C101P@TSOP32
[ ( SA410T ) ]	
M5M27C102K	M5M27C102K@PLCC44
[ ( SA244 ) ]	
M5M27C102P	M5M27C102P@PLCC44
[ ( SA244 ) ]	
M5M27C128K	
M5M27C201K	
M5M27C201K@PLCC32 [ ( SA015A1T ) ]	M5M27C201K@TSOP32
[ ( SA410T ) ]	
M5M27C202K	M5M27C202K@PLCC44
[ ( SA244 ) ]	
M5M27C256 ( K )	M5M27C256

(P)  
 M5M27C256A(FP) M5M27C256A  
 (K)  
 M5M27C256A(P)  
 M5M27C401K  
 M5M27C401K@PLCC32 [(SA015A1T)] M5M27C401K@TSOP32  
 [(SA410T)]  
 M5M27C402K M5M27C512  
 (FP) M5M27C512A  
 (K) M5M27C512A  
 M5M27C512A(P)  
 M5M28F101  
 M5M28F101@PLCC32 [(SA015A1T)] M5M28F101@SOP32  
 [(SA438T)]  
 M5M28F101@TSOP32 [(SA410T)]  
 M5M28F101A  
 M5M28F101A@PLCC32 [(SA015A1T)] M5M28F101A@SOIC32  
 [(SA438T)]  
 M5M28F101A@TSOP32 [(SA410T)]  
 M5M29FB160A@TSOP48 [(SA247-B005)]  
 M5M29FB800(FP)@PSOP44 [(SA638)]  
 M5M29FB800(VP)@TSOP48 [(SA247-B005)]  
 M5M29FT160A@TSOP48 [(SA247-B005)]  
 M5M29FT800(FP)@PSOP44 [(SA638)]  
 M5M29FT800(VP)@TSOP48 [(SA247-B005)]  
 M5M29GB160B(VP)@TSOP48 [(SA247-B005)]  
 M5M29GB320(VP)@TSOP48 [(SA247-B005)]  
 M5M29GB320(WG)@CBGA48 [(SA642B-B026A-Y072F001)]  
 M5M29GT160B(VP)@TSOP48 [(SA247-B005)]  
 M5M29GT320(VP)@TSOP48 [(SA247-B005)]  
 M5M29GT320(WG)@CBGA48 [(SA642B-B026A-Y072F001)]  
 M5M29JB160A@TSOP48 [(SA247-B005)]  
 M5M29JT160A@TSOP48 [(SA247-B005)]  
 M6M80011A M6M80011A@SOIC10  
 [(SA023A)]  
 M6M80011A@SOIC16 [(SA023A)]  
 M6M80021  
 M6M80021@SOIC10 [(SA023A)] M6M80021@SOIC16  
 [(SA023A)]  
 M6M80041 M6M80041@SOIC10  
 [(SA023A)]  
 M6MG3B641S16TP@TSOP52 [(SA657-B036)]

M6MG3T641S16TP@TSOP52 [(SA657-B036)]  
 M6MGB321S4TP@TSOP52 [(SA657-B036)]  
 M6MGB321S8TP@TSOP52 [(SA657-B036)]  
 M6MGB32BS4WG@CSP66 [(SA642F-B023A-T064F001)]  
 M6MGB32BS8WG@CSP66 [(SA642F-B023A-T064F001)]  
 M6MGB331S8KT@TSOP52 [(SA657-B036)]  
 M6MGB33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]  
 M6MGB641S16TP@TSOP52 [(SA657-B036)]  
 M6MGB641S4TP@TSOP52 [(SA657-B036)]  
 M6MGB641S8TP@TSOP52 [(SA657-B036)]  
 M6MGB64BS4WG@CSP67 [(SA642F-B023A-T064F001)]  
 M6MGB64BS8WG@CSP67 [(SA642F-B023A-T064F001)]  
 M6MGD137W33(WG)@CSP72 [(SA642F-B056A-T064F001)]  
 M6MGE157S4KT@TSOP52 [(SA657-B055)]  
 M6MGT321S4TP@TSOP52 [(SA657-B036)]  
 M6MGT321S8TP@TSOP52 [(SA657-B036)]  
 M6MGT32BS4WG@CSP66 [(SA642F-B023A-T064F001)]  
 M6MGT32BS8WG@CSP66 [(SA642F-B023A-T064F001)]  
 M6MGT331S8KT@TSOP52 [(SA657-B036)]  
 M6MGT33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]  
 M6MGT641S16TP@TSOP52 [(SA657-B036)]  
 M6MGT641S4TP@TSOP52 [(SA657-B036)]  
 M6MGT641S8TP@TSOP52 [(SA657-B036)]  
 M6MGT64BS4WG@CSP67 [(SA642F-B023A-T064F001)]  
 M6MGT64BS8WG@CSP67 [(SA642F-B023A-T064F001)]

## MICROCONTROLLER

M30240EFCFP@QFP80 (Renesas) [(PCA7302E1F-80)]  
 M30260F3AGP@QFP48 [(SA248)] M30260F3TGP@QFP48  
 [(SA248)]  
 M30260F3VGP@QFP48 [(SA248)] M30260F6AGP@QFP48  
 [(SA248)]  
 M30260F6TGP@QFP48 [(SA248)] M30260F6VGP@QFP48  
 [(SA248)]  
 M30260F8AGP@QFP48 [(SA248)] M30260F8TGP@QFP48  
 [(SA248)]  
 M30260F8VGP@QFP48 [(SA248)] M30262F3GP@QFP48  
 [(SA248)]  
 M30262F4GP@QFP48 [(SA248)] M30262F6GP@QFP48  
 [(SA248)]  
 M30262F8GP@QFP48 [(SA248)] M30263F3AFP@SDIP42

[ (SA028) ]  
M30263F6AFP@SDIP42 [ (SA028) ] M30263F8AFP@SDIP42  
[ (SA028) ]  
M30280F6HP@QFP80(\*) [ (SA731-B230) ]  
M30280F8HP@QFP80(\*) [ (SA731-B230) ]  
M30280FAHP@QFP80(\*) [ (SA731-B230) ]  
M30280FATHP@QFP80(\*) [ (SA731-B230) ]  
M30280FAVHP@QFP80(\*) [ (SA731-B230) ]  
M30280FCHP@QFP80(\*) [ (SA731-B230) ]  
M30281F6HP@QFP64(\*) [ (SA732-B315) ]  
M30281F8HP@QFP64(\*) [ (SA732-B315) ]  
M30281FAHP@QFP64(\*) [ (SA732-B315) ]  
M30281FATHP@QFP64(\*) [ (SA732-B315) ]  
M30281FAVHP@QFP64(\*) [ (SA732-B315) ]  
M30281FCHP@QFP64(\*) [ (SA732-B315) ]  
M30290FAHP@QFP80(\*) [ (SA731-B230) ]  
M30290FATHP@QFP80(\*) [ (SA731-B230) ]  
M30290FAVHP@QFP80(\*) [ (SA731-B230) ]  
M30290FCHP@QFP80(\*) [ (SA731-B230) ]  
M30290FCTHP@QFP80(\*) [ (SA731-B230) ]  
M30290FCVHP@QFP80(\*) [ (SA731-B230) ]  
M30620ECFP@QFP100(Renesas) [ (PCA7412F-100) ]  
M30620ECFS@QFN100(Renesas) [ (PCA7412L-100) ]  
M30620ECGP@LQFP100(Renesas) [ (PCA7412G-100) ]  
M30620FCAFP@PQFP100(\*) [ (TA012-B006) ]  
M30620FCAGP@TQFP100(\*) [ (TA013-B006) ]  
M30620FCFP@PQFP100(\*) [ (TA012-B006) ]  
M30620FCGPG@TQFP100(\*) [ (TA013-B006) ]  
M30621ECGP@QFP80(Renesas) [ (PCA7413F-80) ]  
M30622ECTFP@QFP100(Renesas) [ (PCA7412F-100) ]  
M30622F8PFP@PQFP100(\*) [ (TA012-B006) ]  
M30622F8PGP@TQFP100(\*) [ (TA013-B006) ]  
M30623ECTGP@QFP80(Renesas) [ (PCA7413F-80) ]  
M30624FGAFP@PQFP100(\*) [ (TA012-B006) ]  
M30624FGAGP@TQFP100(\*) [ (TA013-B006) ]  
M30624FGPFP@PQFP100(\*) [ (TA012-B006) ]  
M30624FGPGP@TQFP100(\*) [ (TA013-B006) ]  
M30626FHPFP@PQFP100(\*) [ (TA012-B006) ]  
M30626FHPPGP@TQFP100(\*) [ (TA013-B006) ]  
M30627FHPPGP@PQFP128(\*) [ (SA720-B228) ]  
M3062LFGPFP@PQFP100(\*) [ (TA012-B006) ]  
M3062LFGPGP@TQFP100(\*) [ (TA013-B006) ]  
M306N4FCFP@PQFP100(\*) [ (TA012-B006) ]

M306N4FCGP@QFP100(\*) [(TA013-B006)]  
M306N4FCTFP@PQFP100(\*) [(TA012-B006)]  
M306N4FCTGP@QFP100(\*) [(TA013-B006)]  
M306N4FCVFP@PQFP100(\*) [(TA012-B006)]  
M306N4FCVGP@QFP100(\*) [(TA013-B006)]  
M306N4FGFP@PQFP100(\*) [(TA012-B006)]  
M306N4FGGP@QFP100(\*) [(TA013-B006)]  
M306N4FGTFP@PQFP100(\*) [(TA012-B006)]  
M306N4FGTGP@QFP100(\*) [(TA013-B006)]  
M306N4FGVFP@PQFP100(\*) [(TA012-B006)]  
M306N4FGVGP@QFP100(\*) [(TA013-B006)]  
M306N5FCFP@PQFP100(\*) [(TA012-B006)]  
M306N5FCGP@QFP100(\*) [(TA013-B006)]  
M306N5FCTFP@PQFP100(\*) [(TA012-B006)]  
M306N5FCTGP@QFP100(\*) [(TA013-B006)]  
M306N5FCVFP@PQFP100(\*) [(TA012-B006)]  
M306N5FCVGP@QFP100(\*) [(TA013-B006)]  
M306NKFHGP@QFP100(\*) [(TA013-B006)]  
M306NKFHTGP@QFP100(\*) [(TA013-B006)]  
M306NKFHVGP@QFP100(\*) [(TA013-B006)]  
M306NKFJGP@QFP100(\*) [(TA013-B006)]  
M306NKFJTGP@QFP100(\*) [(TA013-B006)]  
M306NKFJVGP@QFP100(\*) [(TA013-B006)]  
M306NLFHGP@QFP100(\*) [(TA013-B006)]  
M306NLFHTGP@QFP100(\*) [(TA013-B006)]  
M306NLFHVGP@QFP100(\*) [(TA013-B006)]  
M306NLFJGP@QFP100(\*) [(TA013-B006)]  
M306NLFJTGP@QFP100(\*) [(TA013-B006)]  
M306NLFJVGP@QFP100(\*) [(TA013-B006)]  
M306NMFHGP@QFP128(\*) [(SA720-B228)]  
M306NMFHTGP@QFP128(\*) [(SA720-B228)]  
M306NMFHVGP@QFP128(\*) [(SA720-B228)]  
M306NMFJGP@QFP128(\*) [(SA720-B228)]  
M306NMFJTGP@QFP128(\*) [(SA720-B228)]  
M306NMFJVGP@QFP128(\*) [(SA720-B228)]  
M306NNFHGP@QFP128(\*) [(SA720-B228)]  
M306NNFHVGP@QFP128(\*) [(SA720-B228)]  
M306NNFJGP@QFP128(\*) [(SA720-B228)]  
M306NNFJTGP@QFP128(\*) [(SA720-B228)]  
M306NNFJVGP@QFP128(\*) [(SA720-B228)]  
M306NNTFHGP@QFP128(\*) [(SA720-B228)]  
M306V0EEFP@QFP100(Renesas) [(PCA7412F-100)]  
M306V0EEFS@QFN100(Renesas) [(PCA7412L-100)]



M306V2EEFP@QFP100 (Renesas) [(PCA7412F-100)]  
M306V2EEFS@QFN100 (Renesas) [(PCA7412L-100)]  
M34282E2GP [(SA026)] M34283G2GP  
[(SA026)]  
M34283G2GP (ISP) [ISP-HEADER01] M34508G4FP  
[(SA023A)]  
M34508G4GP [(SA026)] M34508G4HFP  
[(SA023A)]  
M34508G4HGP [(SA026)] M34509G4FP [(SA711-  
B005)]  
M34509G4HFP [(SA711-B005)]  
M34513E4FP@LQFP32 (Renesas) [(PCA7442FPG02)]  
M34513E4SP@SDIP32 (Renesas) [(PCA7442SP)]  
M34513E8FP@LQFP32 (Renesas) [(PCA7442FPG02)]  
M34514E8FP@SSOP42 (Renesas) [(PCA7441)]  
M34518E8FP@LQFP32 (Renesas) [(PCA7442FPG02)]  
M34518E8SP@SDIP32 (Renesas) [(PCA7442SP)]  
M34519E8FP@SSOP42 (Renesas) [(PCA7441)]  
M34524EDFP@QFP64 (Renesas) [(PCA7448)]  
M34551E8FP@QFP48 (Renesas) [(PCA7414)]  
M34554EDFP@QFP64 (Renesas) [(PCA7448)]  
M34559G6FP@QFP52 [(PEP-S673)] M3455AG8FP@QFP52 [(PEP-  
S673)]  
M3455AGCFP@QFP52 [(PEP-S673)]  
M34570E8FP@SSOP36 (Renesas) [(PCA7425)]  
M34570EDFP@SSOP36 (Renesas) [(PCA7425)]  
M34583EDFP@LQFP32 (Renesas) [(PCA7442FPG02)]  
M34584EDFP@SSOP42 (Renesas) [(PCA7441)]  
M37136@SDIP52(\*) [(SA627-B5602)]  
M37150EFP@SSOP42 (Renesas) [(PCA7450FP)]  
M37151EFP@SSOP42 (Renesas) [(PCA7450FP)]  
M37160EFP@SSOP42 (Renesas) [(PCA7450FP)]  
M37161EFP@SSOP42 (Renesas) [(PCA7450FP)]  
M37516E6HKP@QFN44 (Renesas) [(PCA7446)]  
M37516E6HP@LQFP48 (Renesas) [(PCA7419)]  
M37540E2FP@SSOP36 (Renesas) [(PCA7435FPG02)]  
M37540E2GP@LQFP32 (Renesas) [(PCA7435GPG03)]  
M37540E2SP@SDIP32 (Renesas) [(PCA7435SPG02)]  
M37540E8FP@SSOP36 (Renesas) [(PCA7435FPG02)]  
M37540E8GP@LQFP32 (Renesas) [(PCA7435GPG03)]  
M37540E8SP@SDIP32 (Renesas) [(PCA7435SPG02)]  
M37544G2A(GP)@LQFP32 [(SA663)]  
M37544G2A(GP)@LQFP32 (ISP) [ISP-HEADER01]

M37544G2A(SP)@SDIP32 [(SA653)]  
M37544G2A(SP)@SDIP32(ISP) [ISP-HEADER01]  
M37545G4(GP)@LQFP32 [(SA663)] M37545G6(GP)@LQFP32  
[(SA663)]  
M37545G8(GP)@LQFP32 [(SA663)] M37546G2(FP)@SSOP36  
[(SA645)]  
M37546G2(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37546G2(GP)@LQFP32 [(SA663)]  
M37546G2(GP)@LQFP32(ISP) [ISP-HEADER01]  
M37546G2(SP)@SDIP32 [(SA653)]  
M37546G2(SP)@SDIP32(ISP) [ISP-HEADER01]  
M37546G4(FP)@SSOP36 [(SA645)]  
M37546G4(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37546G4(GP)@LQFP32 [(SA663)]  
M37546G4(GP)@LQFP32(ISP) [ISP-HEADER01]  
M37546G4(SP)@SDIP32 [(SA653)]  
M37546G4(SP)@SDIP32(ISP) [ISP-HEADER01]  
M37547G2(FP)@SSOP36 [(SA645)]  
M37547G2(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37547G4(FP)@SSOP36 [(SA645)]  
M37547G4(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37548G1(FP)@TSSOP20 [(SA026)] M37548G2(FP)@TSSOP20  
[(SA026)]  
M37548G3(FP)@TSSOP20 [(SA026)] M37549G1FP@SDIP24  
[(SA653)]  
M37549G2FP@SDIP24 [(SA653)] M37549G3FP@SDIP24  
[(SA653)]  
M37560EFDFP@QFP100(Renesas) [(PCA4738F-100A)]  
M37560EFFP@QFN100(Renesas) [(PCA4738L-100A)]  
M37560EFFP@QFP100(Renesas) [(PCA4738F-100A)]  
M37560EFGP@LQFP100(Renesas) [(PCA4738G-100A)]  
M37630E4FP@QFP44(Renesas) [(PCA7430)]  
M37630E4FS@QFN80(Renesas) [(PCA7431)]  
M37640E8FP@QFP80(Renesas) [(PCA7440FP)]  
M37640E8FS@QFN80(Renesas) [(PCA7440FS)]  
M37733EHBFP@QFP80(Renesas) [(PCA4774G05)]  
M37733EHBFS@QFN80(Renesas) [(PCA4708G05)]  
M37735EHBFP@QFP80(Renesas) [(PCA4774G05)]  
M37735EHBFS@QFN80(Renesas) [(PCA4708G05)]  
M37736EHBGP@QFP100(Renesas) [(PCA7422GPG02)]  
M37736EHBGS@QFN100(Renesas) [(PCA7422GSG02)]  
M37751E6CFP@QFP80(Renesas) [(PCA4774G05)]  
M37751E6CFS@QFN80(Renesas) [(PCA4708G05)]

M37751F6CFP@QFP80 (Renesas) [(PCA4774G05)]  
M38027E8DFP@QFP64 (Mitsubishi) [(PCA4738F-64A)]  
M38027E8DSP@DIP64 (Mitsubishi) [(BBBB)]  
M38027E8DXXXFP@QFP64 (Mitsubishi) [(PCA4738F-64A)]  
M38027E8DXXXSP@DIP64 (Mitsubishi) [(BBBB)]  
M38027E8FS@LCC64 (Mitsubishi) [(BBBB)]  
M38027E8SP@DIP64 (Mitsubishi) [(BBBB)]  
M38027E8SS@DIP64 (Mitsubishi) [(BBBB)]  
M38027E8-XXXFP@QFP64 (Mitsubishi) [(PCA4738F-64A)]  
M38027E8-XXXSP@DIP64 (Mitsubishi) [(BBBB)]  
M38027M8-XXXFP@QFP64 (Mitsubishi) [(PCA4738F-64A)]  
M38039FFFP@QFP64 (Renesas) [(PCA4738FF-64)]  
M38039FFHP@LQFP64 (Renesas) [(PCA4738HF-64)]  
M38039FFSP@SDIP64 (Renesas) [(PCA4738SF-64)]  
M38049FFFP@QFP64 (Renesas) [(PCA4738FF-64)]  
M38049FFHP@LQFP64 (Renesas) [(PCA4738HF-64)]  
M38049FFSP@SDIP64 (Renesas) [(PCA4738SF-64)]  
M38223E4FP@QFP80 (Renesas) [(PCA4738F-80A)]  
M38223E4FS@QFN80 (Renesas) [(PCA4738L-80A)]  
M38223E4GP@QFP80 (Renesas) [(PCA4738G-80A)]  
M38223E4HP@LQFP80 (Renesas) [(PCA4738H-80A)]  
M38227ECFP@QFP80 (Renesas) [(PCA4738F-80A)]  
M38227ECFS@QFN80 (Renesas) [(PCA4738L-80A)]  
M38227ECHP@LQFP80 (Renesas) [(PCA4738H-80A)]  
M38234G4 (FP)@PQFP80 [(SA730+B191)]  
M38234G4 (HP)@TQFP80 [(SA731+B192)]  
M38235G6 (FP)@PQFP80 [(SA730+B191)]  
M38235G6 (HP)@TQFP80 [(SA731+B192)]  
M38238G8 (FP)@PQFP80 [(SA730+B191)]  
M38238G8 (HP)@TQFP80 [(SA731+B192)]  
M38239GC (FP)@PQFP80 [(SA730+B191)]  
M38239GC (HP)@TQFP80 [(SA731+B192)]  
M3823AGF (FP)@PQFP80 [(SA730+B191)]  
M3823AGF (HP)@TQFP80 [(SA731+B192)]  
M38267E8FP@QFP100 (Renesas) [(PCA4738F-100A)]  
M38267E8GP@LQFP100 (Renesas) [(PCA4738G-100A)]  
M3826AEFFP@QFP100 (Renesas) [(PCA4738F-100A)]  
M3826AEFFS@QFN100 (Renesas) [(PCA4738L-100A)]  
M3826AEFGP@LQFP100 (Renesas) [(PCA4738G-100A)]  
M38503G4A (FP)@SSOP42 [(SA645)] M38503G4A (SP)@SDIP42  
[(SA028)]  
M38504E6FP@SSOP42 (Renesas) [(PCA4738F-42A)]  
M38504E6SP@SDIP42 (Renesas) [(PCA4738S-42A)]

M38504E6SS@SDIP42 (Renesas) [(PCA4738S-42A)]  
M38507F8(FP)@SSOP42 [(SA645)] M38507F8(SP)@SDIP42  
[(SA028)]  
M38514E6FP@SSOP42 (Renesas) [(PCA4738F-42A)]  
M38514E6SP@SDIP42 (Renesas) [(PCA4738S-42A)]  
M38514E6SS@SDIP42 (Renesas) [(PCA4738S-42A)]  
M38588G6(FP)@SSOP42 [(SA645)] M38588G6(SP)@SDIP42  
[(SA028)]  
M38588G8(FP)@SSOP42 [(SA645)] M38588G8(SP)@SDIP42  
[(SA028)]  
M38588GC(FP)@SSOP42 [(SA645)] M38588GC(SP)@SDIP42  
[(SA028)]  
M38867E8AFS@QFN80 (Renesas) [(PCA4738L-80A)]  
M38867E8AHP@LQFP80 (Renesas) [(PCA4738H-80A)]  
M38869FFAGP@QFP80 (Renesas) [(PCA4738GF-80)]  
M38869FFAHP@LQFP80 (Renesas) [(PCA4738HF-80)]  
M38B79FFFP@QFP100 (Renesas) [(PCA7438FF-100)]  
M38C13E6FP@LQFP64 (Renesas) [(PCA7438F-64A)]  
M38C13E6HP@QFP64 (Renesas) [(PCA7438H-64A)]  
M38C89EFFP@LQFP144 (Renesas) [(PCA7447FP)]  
M38D24G4FP@TQFP64 [(PEP+S625A)] M38D24G4HP@TQFP64 [(PEP  
+S616)]  
M38D24G6FP@TQFP64 [(PEP+S625A)] M38D24G6HP@TQFP64 [(PEP  
+S616)]  
M38D28G8FP@TQFP64 [(PEP+S625A)] M38D28G8HP@TQFP64 [(PEP  
+S616)]  
M38D29GCFP@TQFP64 [(PEP+S625A)] M38D29GCHP@TQFP64 [(PEP  
+S616)]  
M38D29GFFP@TQFP64 [(PEP+S625A)] M38D29GFHP@TQFP64 [(PEP  
+S616)]  
M3NN00FETGP@QFP100(\*) [(TA013-B006)]  
R5F21102DFP@TQFP32 [(SA663+B005)]  
R5F21102DFP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21102FP@TQFP32 [(SA663+B005)]  
R5F21102FP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21103DFP@TQFP32 [(SA663+B005)]  
R5F21103DFP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21103FP@TQFP32 [(SA663+B005)]  
R5F21103FP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21104DFP@TQFP32 [(SA663+B005)]  
R5F21104DFP@TQFP32 (ISP) [ISP-HEADER01]  
R5F21104FP@TQFP32 [(SA663+B005)]  
R5F21104FP@TQFP32 (ISP) [ISP-HEADER01]

R5F21112DFP@TQFP32 [(SA663+B005)]  
R5F21112DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21112FP@TQFP32 [(SA663+B005)]  
R5F21112FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21113DFP@TQFP32 [(SA663+B005)]  
R5F21113DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21113FP@TQFP32 [(SA663+B005)]  
R5F21113FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21114DFP@TQFP32 [(SA663+B005)]  
R5F21114DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21114FP@TQFP32 [(SA663+B005)]  
R5F21114FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21122DFP@TQFP32 [(SA663+B005)]  
R5F21122DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21122FP@TQFP32 [(SA663+B005)]  
R5F21122FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21123DFP@TQFP32 [(SA663+B005)]  
R5F21123DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21123FP@TQFP32 [(SA663+B005)]  
R5F21123FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21124DFP@TQFP32 [(SA663+B005)]  
R5F21124DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21124FP@TQFP32 [(SA663+B005)]  
R5F21124FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21132DFP@TQFP32 [(SA663+B005)]  
R5F21132DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21132FP@TQFP32 [(SA663+B005)]  
R5F21132FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133DFP@TQFP32 [(SA663+B005)]  
R5F21133DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133FP@TQFP32 [(SA663+B005)]  
R5F21133FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21134DFP@TQFP32 [(SA663+B005)]  
R5F21134DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21134FP@TQFP32 [(SA663+B005)]  
R5F21134FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20 [(SA725+B005)]  
R5F21181DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20(single wire) [(SA725+B005)]  
R5F21181DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21181DSP@TSSOP20 [(SA026+B001)]  
R5F21181DSP@TSSOP20(single ISP) [ISP-HEADER01]

R5F21181DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21181DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21181SP@TSSOP20 [(SA026+B001)]  
R5F21181SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21181SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182DD@SDIP20 [(SA725+B005)]  
R5F21182DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(single wire) [(SA725+B005)]  
R5F21182DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21182DSP@TSSOP20 [(SA026+B001)]  
R5F21182DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21182DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182NP@QFN28 [(SA697+B006)]  
R5F21182NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(single wire) [(SA697+B006)]  
R5F21182NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(UART mode) [(SA697+B006)]  
R5F21182SP@TSSOP20 [(SA026+B001)]  
R5F21182SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21182SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21182SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183DD@SDIP20 [(SA725+B005)]  
R5F21183DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(single wire) [(SA725+B005)]  
R5F21183DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21183DSP@TSSOP20 [(SA026+B001)]  
R5F21183DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21183DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183NP@QFN28 [(SA697+B006)]  
R5F21183NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(single wire) [(SA697+B006)]  
R5F21183NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(UART mode) [(SA697+B006)]

R5F21183SP@TSSOP20 [(SA026+B001)]  
R5F21183SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21183SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184DD@SDIP20 [(SA725+B005)]  
R5F21184DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(single wire) [(SA725+B005)]  
R5F21184DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21184DSP@TSSOP20 [(SA026+B001)]  
R5F21184DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21184DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184NP@QFN28 [(SA697+B006)]  
R5F21184NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(single wire) [(SA697+B006)]  
R5F21184NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(UART mode) [(SA697+B006)]  
R5F21184SP@TSSOP20 [(SA026+B001)]  
R5F21184SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21184SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191DD@SDIP20 [(SA725+B005)]  
R5F21191DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(single wire) [(SA725+B005)]  
R5F21191DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21191DSP@TSSOP20 [(SA026+B001)]  
R5F21191DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191SP@TSSOP20 [(SA026+B001)]  
R5F21191SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192DD@SDIP20 [(SA725+B005)]  
R5F21192DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(single wire) [(SA725+B005)]

R5F21192DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21192DSP@TSSOP20 [(SA026+B001)]  
R5F21192DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192NP@QFN28 [(SA697+B006)]  
R5F21192NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(single wire) [(SA697+B006)]  
R5F21192NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(UART mode) [(SA697+B006)]  
R5F21192SP@TSSOP20 [(SA026+B001)]  
R5F21192SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193DD@SDIP20 [(SA725+B005)]  
R5F21193DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(single wire) [(SA725+B005)]  
R5F21193DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21193DSP@TSSOP20 [(SA026+B001)]  
R5F21193DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193NP@QFN28 [(SA697+B006)]  
R5F21193NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(single wire) [(SA697+B006)]  
R5F21193NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(UART mode) [(SA697+B006)]  
R5F21193SP@TSSOP20 [(SA026+B001)]  
R5F21193SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194DD@SDIP20 [(SA725+B005)]  
R5F21194DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(single wire) [(SA725+B005)]  
R5F21194DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21194DSP@TSSOP20 [(SA026+B001)]



R5F21194DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194NP@QFN28 [(SA697+B006)]  
R5F21194NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(single wire) [(SA697+B006)]  
R5F21194NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(UART mode) [(SA697+B006)]  
R5F21194SP@TSSOP20 [(SA026+B001)]  
R5F21194SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1DD@SDIP20 [(SA725+B005)]  
R5F211A1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(single wire) [(SA725+B005)]  
R5F211A1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A1DSP@TSSOP20 [(SA026+B001)]  
R5F211A1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1SP@TSSOP20 [(SA026+B001)]  
R5F211A1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2DD@SDIP20 [(SA725+B005)]  
R5F211A2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(single wire) [(SA725+B005)]  
R5F211A2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A2DSP@TSSOP20 [(SA026+B001)]  
R5F211A2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2NP@QFN28 [(SA697+B006)]  
R5F211A2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(single wire) [(SA697+B006)]  
R5F211A2NP@QFN28(UART ISP) [ISP-HEADER01]

R5F211A2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A2SP@TSSOP20 [(SA026+B001)]  
R5F211A2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3DD@SDIP20 [(SA725+B005)]  
R5F211A3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(single wire) [(SA725+B005)]  
R5F211A3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A3DSP@TSSOP20 [(SA026+B001)]  
R5F211A3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3NP@QFN28 [(SA697+B006)]  
R5F211A3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(single wire) [(SA697+B006)]  
R5F211A3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A3SP@TSSOP20 [(SA026+B001)]  
R5F211A3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4DD@SDIP20 [(SA725+B005)]  
R5F211A4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(single wire) [(SA725+B005)]  
R5F211A4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A4DSP@TSSOP20 [(SA026+B001)]  
R5F211A4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4NP@QFN28 [(SA697+B006)]  
R5F211A4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(single wire) [(SA697+B006)]  
R5F211A4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A4SP@TSSOP20 [(SA026+B001)]  
R5F211A4SP@TSSOP20(single ISP) [ISP-HEADER01]

R5F211A4SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1DD@SDIP20 [(SA725+B005)]  
R5F211B1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B1DSP@TSSOP20 [(SA026+B001)]  
R5F211B1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1SP@TSSOP20 [(SA026+B001)]  
R5F211B1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2DD@SDIP20 [(SA725+B005)]  
R5F211B2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B2DSP@TSSOP20 [(SA026+B001)]  
R5F211B2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2NP@QFN28 [(SA697+B006)]  
R5F211B2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(single wire) [(SA697+B006)]  
R5F211B2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B2SP@TSSOP20 [(SA026+B001)]  
R5F211B2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3DD@SDIP20 [(SA725+B005)]  
R5F211B3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(UART mode) [(SA725+B005)]

R5F211B3DSP@TSSOP20 [(SA026+B001)]  
R5F211B3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3NP@QFN28 [(SA697+B006)]  
R5F211B3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(single wire) [(SA697+B006)]  
R5F211B3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B3SP@TSSOP20 [(SA026+B001)]  
R5F211B3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4DD@SDIP20 [(SA725+B005)]  
R5F211B4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B4DSP@TSSOP20 [(SA026+B001)]  
R5F211B4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4NP@QFN28 [(SA697+B006)]  
R5F211B4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(single wire) [(SA697+B006)]  
R5F211B4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B4SP@TSSOP20 [(SA026+B001)]  
R5F211B4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21244SDFP@TQFP52(parallel) [(PEP+S673)]  
R5F21244SDFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21244SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21244SDFP@TQFP52(single) [(PEP+S673)]  
R5F21244SDFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21244SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21244SDFP@TQFP52(UART) [(PEP+S673)]  
R5F21244SDFP@TQFP52(UART)(\*) [(SA740+B225)]

R5F21244SNFP@TQFP52(parallel) [(PEP+S673)]  
R5F21244SNFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21244SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21244SNFP@TQFP52(single) [(PEP+S673)]  
R5F21244SNFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21244SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21244SNFP@TQFP52(UART) [(PEP+S673)]  
R5F21244SNFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21246SDFP@TQFP52(parallel) [(PEP+S673)]  
R5F21246SDFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21246SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21246SDFP@TQFP52(single) [(PEP+S673)]  
R5F21246SDFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21246SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21246SDFP@TQFP52(UART) [(PEP+S673)]  
R5F21246SDFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21246SNFP@TQFP52(parallel) [(PEP+S673)]  
R5F21246SNFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21246SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21246SNFP@TQFP52(single) [(PEP+S673)]  
R5F21246SNFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21246SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21246SNFP@TQFP52(UART) [(PEP+S673)]  
R5F21246SNFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21247SDFP@TQFP52(parallel) [(PEP+S673)]  
R5F21247SDFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21247SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21247SDFP@TQFP52(single) [(PEP+S673)]  
R5F21247SDFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21247SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21247SDFP@TQFP52(UART) [(PEP+S673)]  
R5F21247SDFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21247SNFP@TQFP52(parallel) [(PEP+S673)]  
R5F21247SNFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21247SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21247SNFP@TQFP52(single) [(PEP+S673)]  
R5F21247SNFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21247SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21247SNFP@TQFP52(UART) [(PEP+S673)]  
R5F21247SNFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21248SDFP@TQFP52(parallel) [(PEP+S673)]  
R5F21248SDFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21248SDFP@TQFP52(single ISP) [ISP-HEADER01]

R5F21248SDFP@TQFP52(single) [(PEP+S673)]  
R5F21248SDFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21248SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21248SDFP@TQFP52(UART) [(PEP+S673)]  
R5F21248SDFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21248SNFP@TQFP52(parallel) [(PEP+S673)]  
R5F21248SNFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21248SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21248SNFP@TQFP52(single) [(PEP+S673)]  
R5F21248SNFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21248SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21248SNFP@TQFP52(UART) [(PEP+S673)]  
R5F21248SNFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21254SDFP@TQFP52 [(PEP+S673)]  
R5F21254SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21254SDFP@TQFP52(single wire) [(PEP+S673)]  
R5F21254SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21254SDFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21254SNFP@TQFP52 [(PEP+S673)]  
R5F21254SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21254SNFP@TQFP52(single wire) [(PEP+S673)]  
R5F21254SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21254SNFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21256SDFP@TQFP52 [(PEP+S673)]  
R5F21256SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21256SDFP@TQFP52(single wire) [(PEP+S673)]  
R5F21256SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21256SDFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21256SNFP@TQFP52 [(PEP+S673)]  
R5F21256SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21256SNFP@TQFP52(single wire) [(PEP+S673)]  
R5F21256SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21256SNFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21257SDFP@TQFP52 [(PEP+S673)]  
R5F21257SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21257SDFP@TQFP52(single wire) [(PEP+S673)]  
R5F21257SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SDFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21257SNFP@TQFP52 [(PEP+S673)]  
R5F21257SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(single wire) [(PEP+S673)]  
R5F21257SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(UART mode) [(PEP+S673)]

R5F21258SDFP@TQFP52 [(PEP+S673)]  
R5F21258SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(single wire) [(PEP+S673)]  
R5F21258SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21258SNFP@TQFP52 [(PEP+S673)]  
R5F21258SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(single wire) [(PEP+S673)]  
R5F21258SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21262DFP@QFP32 [(SA663)]  
R5F21262DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(single wire) [(SA663)]  
R5F21262DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(UART mode) [(SA663)]  
R5F21262JFP@QFP32 [(SA663)]  
R5F21262JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(single wire) [(SA663)]  
R5F21262JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(UART mode) [(SA663)]  
R5F21262KFP@QFP32 [(SA663)]  
R5F21262KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262KFP@QFP32(single wire) [(SA663)]  
R5F21262KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262KFP@QFP32(UART mode) [(SA663)]  
R5F21262NFP@QFP32 [(SA663)]  
R5F21262NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(single wire) [(SA663)]  
R5F21262NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(UART mode) [(SA663)]  
R5F21262SDFP@QFP32 [(SA663)]  
R5F21262SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(single wire) [(SA663)]  
R5F21262SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(UART mode) [(SA663)]  
R5F21262SJFP@QFP32 [(SA663)]  
R5F21262SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(single wire) [(SA663)]  
R5F21262SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(UART mode) [(SA663)]  
R5F21262SKFP@QFP32 [(SA663)]  
R5F21262SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(single wire) [(SA663)]

R5F21262SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(UART mode) [(SA663)]  
R5F21262SNFP@QFP32 [(SA663)]  
R5F21262SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(single wire) [(SA663)]  
R5F21262SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(UART mode) [(SA663)]  
R5F21264DFP@QFP32 [(SA663)]  
R5F21264DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264DFP@QFP32(single wire) [(SA663)]  
R5F21264DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264DFP@QFP32(UART mode) [(SA663)]  
R5F21264JFP@QFP32 [(SA663)]  
R5F21264JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(single wire) [(SA663)]  
R5F21264JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(UART mode) [(SA663)]  
R5F21264KFP@QFP32 [(SA663)]  
R5F21264KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(single wire) [(SA663)]  
R5F21264KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(UART mode) [(SA663)]  
R5F21264NFP@QFP32 [(SA663)]  
R5F21264NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264NFP@QFP32(single wire) [(SA663)]  
R5F21264NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264NFP@QFP32(UART mode) [(SA663)]  
R5F21264SDFP@QFP32 [(SA663)]  
R5F21264SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SDFP@QFP32(single wire) [(SA663)]  
R5F21264SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SDFP@QFP32(UART mode) [(SA663)]  
R5F21264SJFP@QFP32 [(SA663)]  
R5F21264SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(single wire) [(SA663)]  
R5F21264SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(UART mode) [(SA663)]  
R5F21264SKFP@QFP32 [(SA663)]  
R5F21264SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(single wire) [(SA663)]  
R5F21264SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(UART mode) [(SA663)]  
R5F21264SNFP@QFP32 [(SA663)]



R5F21264SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(single wire) [(SA663)]  
R5F21264SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(UART mode) [(SA663)]  
R5F21265DFP@QFP32 [(SA663)]  
R5F21265DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(single wire) [(SA663)]  
R5F21265DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(UART mode) [(SA663)]  
R5F21265JFP@QFP32 [(SA663)]  
R5F21265JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(single wire) [(SA663)]  
R5F21265JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(UART mode) [(SA663)]  
R5F21265KFP@QFP32 [(SA663)]  
R5F21265KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(single wire) [(SA663)]  
R5F21265KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(UART mode) [(SA663)]  
R5F21265NFP@QFP32 [(SA663)]  
R5F21265NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(single wire) [(SA663)]  
R5F21265NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(UART mode) [(SA663)]  
R5F21265SDFP@QFP32 [(SA663)]  
R5F21265SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(single wire) [(SA663)]  
R5F21265SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(UART mode) [(SA663)]  
R5F21265SJFP@QFP32 [(SA663)]  
R5F21265SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(single wire) [(SA663)]  
R5F21265SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(UART mode) [(SA663)]  
R5F21265SKFP@QFP32 [(SA663)]  
R5F21265SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(single wire) [(SA663)]  
R5F21265SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(UART mode) [(SA663)]  
R5F21265SNFP@QFP32 [(SA663)]  
R5F21265SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(single wire) [(SA663)]  
R5F21265SNFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21265SNFP@QFP32(UART mode) [(SA663)]  
R5F21266DFP@QFP32 [(SA663)]  
R5F21266DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(single wire) [(SA663)]  
R5F21266DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(UART mode) [(SA663)]  
R5F21266JFP@QFP32 [(SA663)]  
R5F21266JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(single wire) [(SA663)]  
R5F21266JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(UART mode) [(SA663)]  
R5F21266KFP@QFP32 [(SA663)]  
R5F21266KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(single wire) [(SA663)]  
R5F21266KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(UART mode) [(SA663)]  
R5F21266NFP@QFP32 [(SA663)]  
R5F21266NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(single wire) [(SA663)]  
R5F21266NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(UART mode) [(SA663)]  
R5F21266SDFP@QFP32 [(SA663)]  
R5F21266SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(single wire) [(SA663)]  
R5F21266SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(UART mode) [(SA663)]  
R5F21266SJFP@QFP32 [(SA663)]  
R5F21266SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(single wire) [(SA663)]  
R5F21266SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(UART mode) [(SA663)]  
R5F21266SKFP@QFP32 [(SA663)]  
R5F21266SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(single wire) [(SA663)]  
R5F21266SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(UART mode) [(SA663)]  
R5F21266SNFP@QFP32 [(SA663)]  
R5F21266SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(single wire) [(SA663)]  
R5F21266SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(UART mode) [(SA663)]  
R5F21272DFP@QFP32 [(SA663)]  
R5F21272DFP@QFP32(single ISP) [ISP-HEADER01]

R5F21272DFP@QFP32(single wire) [(SA663)]  
R5F21272DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272DFP@QFP32(UART mode) [(SA663)]  
R5F21272JFP@QFP32 [(SA663)]  
R5F21272JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(single wire) [(SA663)]  
R5F21272JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(UART mode) [(SA663)]  
R5F21272KFP@QFP32 [(SA663)]  
R5F21272KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272KFP@QFP32(single wire) [(SA663)]  
R5F21272KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272KFP@QFP32(UART mode) [(SA663)]  
R5F21272NFP@QFP32 [(SA663)]  
R5F21272NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(single wire) [(SA663)]  
R5F21272NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(UART mode) [(SA663)]  
R5F21272SDFP@QFP32 [(SA663)]  
R5F21272SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(single wire) [(SA663)]  
R5F21272SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(UART mode) [(SA663)]  
R5F21272SJFP@QFP32 [(SA663)]  
R5F21272SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(single wire) [(SA663)]  
R5F21272SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(UART mode) [(SA663)]  
R5F21272SKFP@QFP32 [(SA663)]  
R5F21272SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(single wire) [(SA663)]  
R5F21272SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(UART mode) [(SA663)]  
R5F21272SNFP@QFP32 [(SA663)]  
R5F21272SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(single wire) [(SA663)]  
R5F21272SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(UART mode) [(SA663)]  
R5F21274DFP@QFP32 [(SA663)]  
R5F21274DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(single wire) [(SA663)]  
R5F21274DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(UART mode) [(SA663)]

R5F21274JFP@QFP32 [(SA663)]  
R5F21274JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(single wire) [(SA663)]  
R5F21274JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(UART mode) [(SA663)]  
R5F21274KFP@QFP32 [(SA663)]  
R5F21274KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(single wire) [(SA663)]  
R5F21274KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(UART mode) [(SA663)]  
R5F21274NFP@QFP32 [(SA663)]  
R5F21274NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(single wire) [(SA663)]  
R5F21274NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(UART mode) [(SA663)]  
R5F21274SDFP@QFP32 [(SA663)]  
R5F21274SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(single wire) [(SA663)]  
R5F21274SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(UART mode) [(SA663)]  
R5F21274SJFP@QFP32 [(SA663)]  
R5F21274SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SJFP@QFP32(single wire) [(SA663)]  
R5F21274SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SJFP@QFP32(UART mode) [(SA663)]  
R5F21274SKFP@QFP32 [(SA663)]  
R5F21274SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SKFP@QFP32(single wire) [(SA663)]  
R5F21274SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SKFP@QFP32(UART mode) [(SA663)]  
R5F21274SNFP@QFP32 [(SA663)]  
R5F21274SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SNFP@QFP32(single wire) [(SA663)]  
R5F21274SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SNFP@QFP32(UART mode) [(SA663)]  
R5F21275DFP@QFP32 [(SA663)]  
R5F21275DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275DFP@QFP32(single wire) [(SA663)]  
R5F21275DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275DFP@QFP32(UART mode) [(SA663)]  
R5F21275JFP@QFP32 [(SA663)]  
R5F21275JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(single wire) [(SA663)]

R5F21275JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(UART mode) [(SA663)]  
R5F21275KFP@QFP32 [(SA663)]  
R5F21275KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(single wire) [(SA663)]  
R5F21275KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(UART mode) [(SA663)]  
R5F21275NFP@QFP32 [(SA663)]  
R5F21275NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275NFP@QFP32(single wire) [(SA663)]  
R5F21275NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275NFP@QFP32(UART mode) [(SA663)]  
R5F21275SDFP@QFP32 [(SA663)]  
R5F21275SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(single wire) [(SA663)]  
R5F21275SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(UART mode) [(SA663)]  
R5F21275SJFP@QFP32 [(SA663)]  
R5F21275SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(single wire) [(SA663)]  
R5F21275SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(UART mode) [(SA663)]  
R5F21275SKFP@QFP32 [(SA663)]  
R5F21275SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SKFP@QFP32(single wire) [(SA663)]  
R5F21275SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SKFP@QFP32(UART mode) [(SA663)]  
R5F21275SNFP@QFP32 [(SA663)]  
R5F21275SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SNFP@QFP32(single wire) [(SA663)]  
R5F21275SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SNFP@QFP32(UART mode) [(SA663)]  
R5F21276DFP@QFP32 [(SA663)]  
R5F21276DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(single wire) [(SA663)]  
R5F21276DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(UART mode) [(SA663)]  
R5F21276JFP@QFP32 [(SA663)]  
R5F21276JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(single wire) [(SA663)]  
R5F21276JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(UART mode) [(SA663)]  
R5F21276KFP@QFP32 [(SA663)]

R5F21276KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(single wire) [(SA663)]  
R5F21276KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(UART mode) [(SA663)]  
R5F21276NFP@QFP32 [(SA663)]  
R5F21276NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(single wire) [(SA663)]  
R5F21276NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(UART mode) [(SA663)]  
R5F21276SDFP@QFP32 [(SA663)]  
R5F21276SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SDFP@QFP32(single wire) [(SA663)]  
R5F21276SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SDFP@QFP32(UART mode) [(SA663)]  
R5F21276SJFP@QFP32 [(SA663)]  
R5F21276SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(single wire) [(SA663)]  
R5F21276SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(UART mode) [(SA663)]  
R5F21276SKFP@QFP32 [(SA663)]  
R5F21276SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(single wire) [(SA663)]  
R5F21276SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(UART mode) [(SA663)]  
R5F21276SNFP@QFP32 [(SA663)]  
R5F21276SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(single wire) [(SA663)]  
R5F21276SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(UART mode) [(SA663)]  
R5F21282DSP@SOIC20 [(SA026)]  
R5F21282DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(single wire) [(SA026)]  
R5F21282DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(UART mode) [(SA026)]  
R5F21282JSP@SOIC20 [(SA026)]  
R5F21282JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(single wire) [(SA026)]  
R5F21282JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(UART mode) [(SA026)]  
R5F21282KSP@SOIC20 [(SA026)]  
R5F21282KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(single wire) [(SA026)]  
R5F21282KSP@SOIC20(UART ISP) [ISP-HEADER01]

R5F21282KSP@SOIC20(UART mode) [(SA026)]  
R5F21282NSP@SOIC20 [(SA026)]  
R5F21282NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(single wire) [(SA026)]  
R5F21282NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(UART mode) [(SA026)]  
R5F21282SDSP@SOIC20 [(SA026)]  
R5F21282SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(single wire) [(SA026)]  
R5F21282SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(UART mode) [(SA026)]  
R5F21282SJSP@SOIC20 [(SA026)]  
R5F21282SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(single wire) [(SA026)]  
R5F21282SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(UART mode) [(SA026)]  
R5F21282SKSP@SOIC20 [(SA026)]  
R5F21282SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(single wire) [(SA026)]  
R5F21282SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(UART mode) [(SA026)]  
R5F21282SNSP@SOIC20 [(SA026)]  
R5F21282SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(single wire) [(SA026)]  
R5F21282SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(UART mode) [(SA026)]  
R5F21284DSP@SOIC20 [(SA026)]  
R5F21284DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(single wire) [(SA026)]  
R5F21284DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(UART mode) [(SA026)]  
R5F21284JSP@SOIC20 [(SA026)]  
R5F21284JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(single wire) [(SA026)]  
R5F21284JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(UART mode) [(SA026)]  
R5F21284KSP@SOIC20 [(SA026)]  
R5F21284KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(single wire) [(SA026)]  
R5F21284KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(UART mode) [(SA026)]  
R5F21284NSP@SOIC20 [(SA026)]  
R5F21284NSP@SOIC20(single ISP) [ISP-HEADER01]

R5F21284NSP@SOIC20(single wire) [(SA026)]  
R5F21284NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(UART mode) [(SA026)]  
R5F21284SDSP@SOIC20 [(SA026)]  
R5F21284SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(single wire) [(SA026)]  
R5F21284SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(UART mode) [(SA026)]  
R5F21284SJSP@SOIC20 [(SA026)]  
R5F21284SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(single wire) [(SA026)]  
R5F21284SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(UART mode) [(SA026)]  
R5F21284SKSP@SOIC20 [(SA026)]  
R5F21284SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(single wire) [(SA026)]  
R5F21284SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(UART mode) [(SA026)]  
R5F21284SNSP@SOIC20 [(SA026)]  
R5F21284SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(single wire) [(SA026)]  
R5F21284SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(UART mode) [(SA026)]  
R5F21292DSP@SOIC20 [(SA026)]  
R5F21292DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(single wire) [(SA026)]  
R5F21292DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(UART mode) [(SA026)]  
R5F21292JSP@SOIC20 [(SA026)]  
R5F21292JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(single wire) [(SA026)]  
R5F21292JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(UART mode) [(SA026)]  
R5F21292KSP@SOIC20 [(SA026)]  
R5F21292KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(single wire) [(SA026)]  
R5F21292KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(UART mode) [(SA026)]  
R5F21292NSP@SOIC20 [(SA026)]  
R5F21292NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(single wire) [(SA026)]  
R5F21292NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(UART mode) [(SA026)]



R5F21292SDSP@SOIC20 [(SA026)]  
R5F21292SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(single wire) [(SA026)]  
R5F21292SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(UART mode) [(SA026)]  
R5F21292SJSP@SOIC20 [(SA026)]  
R5F21292SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(single wire) [(SA026)]  
R5F21292SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(UART mode) [(SA026)]  
R5F21292SKSP@SOIC20 [(SA026)]  
R5F21292SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(single wire) [(SA026)]  
R5F21292SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(UART mode) [(SA026)]  
R5F21292SNSP@SOIC20 [(SA026)]  
R5F21292SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(single wire) [(SA026)]  
R5F21292SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(UART mode) [(SA026)]  
R5F21294DSP@SOIC20 [(SA026)]  
R5F21294DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294DSP@SOIC20(single wire) [(SA026)]  
R5F21294DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294DSP@SOIC20(UART mode) [(SA026)]  
R5F21294JSP@SOIC20 [(SA026)]  
R5F21294JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(single wire) [(SA026)]  
R5F21294JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(UART mode) [(SA026)]  
R5F21294KSP@SOIC20 [(SA026)]  
R5F21294KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(single wire) [(SA026)]  
R5F21294KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(UART mode) [(SA026)]  
R5F21294NSP@SOIC20 [(SA026)]  
R5F21294NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(single wire) [(SA026)]  
R5F21294NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(UART mode) [(SA026)]  
R5F21294SDSP@SOIC20 [(SA026)]  
R5F21294SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(single wire) [(SA026)]

R5F21294SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(UART mode) [(SA026)]  
R5F21294SJSP@SOIC20 [(SA026)]  
R5F21294SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SJSP@SOIC20(single wire) [(SA026)]  
R5F21294SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SJSP@SOIC20(UART mode) [(SA026)]  
R5F21294SKSP@SOIC20 [(SA026)]  
R5F21294SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SKSP@SOIC20(single wire) [(SA026)]  
R5F21294SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SKSP@SOIC20(UART mode) [(SA026)]  
R5F21294SNSP@SOIC20 [(SA026)]  
R5F21294SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(single wire) [(SA026)]  
R5F21294SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(UART mode) [(SA026)]  
R5F212A7SDFA@TQFP64 [(SA768+B251)]  
R5F212A7SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212A7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A7SDFP@TQFP64 [(SA732+B251)]  
R5F212A7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212A7SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212A7SNFA@TQFP64 [(SA768+B251)]  
R5F212A7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212A7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A7SNFP@TQFP64 [(SA732+B251)]  
R5F212A7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212A7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212A8SDFA@TQFP64 [(SA768+B251)]  
R5F212A8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212A8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A8SDFP@TQFP64 [(SA732+B251)]

R5F212A8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212A8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212A8SNFA@TQFP64 [(SA768+B251)]  
R5F212A8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212A8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A8SNFP@TQFP64 [(SA732+B251)]  
R5F212A8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212A8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212AASDFA@TQFP64 [(SA768+B251)]  
R5F212AASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212AASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212AASDFP@TQFP64 [(SA732+B251)]  
R5F212AASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212AASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212AASNFA@TQFP64 [(SA768+B251)]  
R5F212AASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212AASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212AASNFP@TQFP64 [(SA732+B251)]  
R5F212AASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212AASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212ACSDFA@TQFP64 [(SA768+B251)]  
R5F212ACSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212ACSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212ACSDFP@TQFP64 [(SA732+B251)]  
R5F212ACSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212ACSDFP@TQFP64(UART ISP) [ISP-HEADER01]

R5F212ACSDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212ACSNFA@TQFP64 [(SA768+B251)]  
R5F212ACSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212ACSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212ACSNFP@TQFP64 [(SA732+B251)]  
R5F212ACSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212ACSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B7SDFA@TQFP64 [(SA768+B251)]  
R5F212B7SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B7SDFP@TQFP64 [(SA732+B251)]  
R5F212B7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B7SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B7SNFA@TQFP64 [(SA768+B251)]  
R5F212B7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B7SNFP@TQFP64 [(SA732+B251)]  
R5F212B7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B8SDFA@TQFP64 [(SA768+B251)]  
R5F212B8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B8SDFP@TQFP64 [(SA732+B251)]  
R5F212B8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B8SNFA@TQFP64 [(SA768+B251)]  
R5F212B8SNFA@TQFP64(single ISP) [ISP-HEADER01]

R5F212B8SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B8SNFP@TQFP64 [(SA732+B251)]  
R5F212B8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BASDFA@TQFP64 [(SA768+B251)]  
R5F212BASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BASDFP@TQFP64 [(SA732+B251)]  
R5F212BASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BASNFA@TQFP64 [(SA768+B251)]  
R5F212BASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BASNFP@TQFP64 [(SA732+B251)]  
R5F212BASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BCSDFA@TQFP64 [(SA768+B251)]  
R5F212BCSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BCSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BCSDFP@TQFP64 [(SA732+B251)]  
R5F212BCSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BCSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BCSNFA@TQFP64 [(SA768+B251)]  
R5F212BCSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BCSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(UART mode) [(SA768+B251)]

R5F212BCSNFP@TQFP64 [(SA732+B251)]  
R5F212BCSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BCSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212C7SDFP@TQFP80 [(SA731+B249)]  
R5F212C7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212C7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212C7SNFP@TQFP80 [(SA731+B249)]  
R5F212C7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212C7SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212C8SDFP@TQFP80 [(SA731+B249)]  
R5F212C8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212C8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212C8SNFP@TQFP80 [(SA731+B249)]  
R5F212C8SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212C8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CASDFP@TQFP80 [(SA731+B249)]  
R5F212CASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212CASDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CASNFP@TQFP80 [(SA731+B249)]  
R5F212CASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212CASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CCSDFP@TQFP80 [(SA731+B249)]  
R5F212CCSDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212CCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CCSNFP@TQFP80 [(SA731+B249)]  
R5F212CCSNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CCSNFP@TQFP80(single wire) [(SA731+B249)]

R5F212CCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D7SDFP@TQFP80 [(SA731+B249)]  
R5F212D7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D7SNFP@TQFP80 [(SA731+B249)]  
R5F212D7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D7SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D7SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D8SDFP@TQFP80 [(SA731+B249)]  
R5F212D8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D8SNFP@TQFP80 [(SA731+B249)]  
R5F212D8SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D8SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DASDFP@TQFP80 [(SA731+B249)]  
R5F212DASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DASDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DASDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DASNFP@TQFP80 [(SA731+B249)]  
R5F212DASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DCSDFP@TQFP80 [(SA731+B249)]  
R5F212DCSDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DCSDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DCSNFP@TQFP80 [(SA731+B249)]  
R5F212DCSNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212G4SDFP@QFP32 [(SA663)]

R5F212G4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SDFP@QFP32(single wire) [(SA663)]  
R5F212G4SNFP@QFP32 [(SA663)]  
R5F212G4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SNFP@QFP32(single wire) [(SA663)]  
R5F212G5SDFP@QFP32 [(SA663)]  
R5F212G5SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SDFP@QFP32(single wire) [(SA663)]  
R5F212G5SNFP@QFP32 [(SA663)]  
R5F212G5SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SNFP@QFP32(single wire) [(SA663)]  
R5F212G6SDFP@QFP32 [(SA663)]  
R5F212G6SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SDFP@QFP32(single wire) [(SA663)]  
R5F212G6SNFP@QFP32 [(SA663)]  
R5F212G6SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SNFP@QFP32(single wire) [(SA663)]  
R5F212H1SDSP@TSSOP20 [(SA026+B001)]  
R5F212H1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SDSP@TSSOP20(single wire [(SA026+B001)]  
R5F212H1SNSP@TSSOP20 [(SA026+B001)]  
R5F212H1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SNSP@TSSOP20(single wire [(SA026+B001)]  
R5F212H2SDSP@TSSOP20 [(SA725+B005)]  
R5F212H2SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H2SDSP@TSSOP20(single wire [(SA026+B001)]  
R5F212H2SNSP@TSSOP20 [(SA725+B005)]  
R5F212H2SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H2SNSP@TSSOP20(single wire [(SA026+B001)]  
R5F212J0SDSP@TSSOP20 [(SA026+B001)]  
R5F212J0SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SDSP@TSSOP20(single wire [(SA026+B001)]  
R5F212J0SNSP@TSSOP20 [(SA026+B001)]  
R5F212J0SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SNSP@TSSOP20(single wire [(SA026+B001)]  
R5F212J1SDSP@TSSOP20 [(SA026+B001)]  
R5F212J1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SDSP@TSSOP20(single wire [(SA026+B001)]  
R5F212J1SNSP@TSSOP20 [(SA026+B001)]  
R5F212J1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SNSP@TSSOP20(single wire [(SA026+B001)]  
R5F212K2SDFP@QFP32 [(SA663+B005)]  
R5F212K2SDFP@QFP32(single ISP) [ISP-HEADER01]



R5F212K2SDFP@QFP32(single wire) [(SA663+B005)]  
R5F212K2SNFP@QFP32 [(SA663+B005)]  
R5F212K2SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K2SNFP@QFP32(single wire) [(SA663+B005)]  
R5F212K4SDFP@QFP32 [(SA663+B005)]  
R5F212K4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K4SDFP@QFP32(single wire) [(SA663+B005)]  
R5F212K4SNFP@QFP32 [(SA663+B005)]  
R5F212K4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K4SNFP@QFP32(single wire) [(SA663+B005)]  
R5F212L2SDFP@QFP32 [(SA663+B005)]  
R5F212L2SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L2SDFP@QFP32(single wire) [(SA663+B005)]  
R5F212L2SNFP@QFP32 [(SA663+B005)]  
R5F212L2SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L2SNFP@QFP32(single wire) [(SA663+B005)]  
R5F212L4SDFP@QFP32 [(SA663+B005)]  
R5F212L4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L4SDFP@QFP32(single wire) [(SA663+B005)]  
R5F212L4SNFP@QFP32 [(SA663+B005)]  
R5F212L4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L4SNFP@QFP32(single wire) [(SA663+B005)]

## MMI

### PLD

PLS167 [(SA008A)]	PLS167@PLCC28
PLS167A [(SA008A)]	PLS167A@PLCC28
PLS167B [(SA008A)]	PLS167B@PLCC28
PLS168 [(SA008A)]	PLS168@PLCC28
PLS168A [(SA008A)]	PLS168A@PLCC28
PLS168B [(SA008A)]	PLS168B@PLCC28

## MOSEL-VITELIC

**E ( E ) PROM / FRAM / NVRAM**

V29C31004B [ ( SA015A1T ) ]	V29C31004B@PLCC32
V29C31004B@TSOP32 [ ( SA410T ) ]	
V29C31004T V29C31004T@PLCC32 [ ( SA015A1T ) ]	V29C31004T@TSOP32
[ ( SA410T ) ]	
V29C51000B [ ( SA015A1T ) ]	V29C51000B@PLCC32
V29C51000T [ ( SA015A1T ) ]	V29C51000T@PLCC32
V29C51001B [ ( SA015A1T ) ]	V29C51001B@PLCC32
V29C51001B@TSOP32 [ ( SA410T ) ]	
V29C51001T V29C51001T@PLCC32 [ ( SA015A1T ) ]	V29C51001T@TSOP32
[ ( SA410T ) ]	
V29C51002B [ ( SA015A1T ) ]	V29C51002B@PLCC32
V29C51002B@TSOP32 [ ( SA410T ) ]	
V29C51002T V29C51002T@PLCC32 [ ( SA015A1T ) ]	V29C51002T@TSOP32
[ ( SA410T ) ]	
V29C51004B [ ( SA015A1T ) ]	V29C51004B@PLCC32
V29C51004B@TSOP32 [ ( SA410T ) ]	
V29C51004T V29C51004T@PLCC32 [ ( SA015A1T ) ]	V29C51004T@TSOP32
[ ( SA410T ) ]	
V29LC51000 [ ( SA015A1T ) ]	V29LC51000@PLCC32
V29LC51001 [ ( SA015A1T ) ]	V29LC51001@PLCC32
V29LC51002 [ ( SA015A1T ) ]	V29LC51002@PLCC32

**MICROCONTROLLER**

MSU1958 [ ( SA244 ) ]	MSU1958@PLCC44
--------------------------	----------------

MSU1958@TQFP44 [ ( SA245A ) ]  
MSU2952  
MSU2952@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]  
MSU2958  
[ ( SA244 ) ]  
MSU2958@TQFP44 [ ( SA245A ) ]  
MSU2964  
MSU2964@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]

MSU2952@TQFP44  
MSU2958@PLCC44  
MSU2964@TQFP44

## **MOSTEK**

### **E ( E ) PROM / FRAM / NVRAM**

ET2716  
ETC2716  
ETC2732  
MK2716  
MK2764  
MK48C02  
MK48C12  
MK48T02  
MK48T08  
MK48T12  
MK48T12B  
MK48T18  
MK48Z02  
MK48Z08  
MK48Z12  
MK48Z12B  
MK48Z18

## **MOTOROLA**

### **E ( E ) PROM / FRAM / NVRAM**

MC68764  
MC68766  
MCM2716

**DRAM & SRAM**

MCM2018A [ ( SA015A1T ) ]	MCM2018A@PLCC32
MCM60256A [ ( SA630 ) ]	MCM60256A@SOIC28
MCM60256AC [ ( SA630 ) ]	MCM60256AC@SOIC28
MCM60256AV [ ( SA630 ) ]	MCM60256AV@SOIC28
MCM60L256A [ ( SA630 ) ]	MCM60L256A@SOIC28
MCM60L256AC [ ( SA630 ) ]	MCM60L256AC@SOIC28
MCM60L256AV [ ( SA630 ) ]	MCM60L256AV@SOIC28
MCM6206 [ ( SA630 ) ]	MCM6206@SOIC28
MCM6206C [ ( SA630 ) ]	MCM6206C@SOIC28
MCM6207 [ ( SA646 ) ]	MCM6207@SOJ24
MCM6207C [ ( SA646 ) ]	MCM6207C@SOJ24
MCM6208 [ ( SA646 ) ]	MCM6208@SOJ24
MCM6208C [ ( SA646 ) ]	MCM6208C@SOJ24
MCM6209 [ ( SA646 ) ]	MCM6209@SOJ28
MCM6209C [ ( SA646 ) ]	MCM6209C@SOJ28
MCM6229 [ ( SA646 ) ]	MCM6229 ( 300m )@SOJ28
MCM6229 ( 400m )@SOJ28 [ ( SA661 ) ]	
MCM6229A MCM6229A ( 300m )@SOJ28 [ ( SA646 ) ]	MCM6229A ( 400m )@SOJ28
[ ( SA661 ) ]	
MCM6264 [ ( SA630 ) ]	MCM6264@SOIC28
MCM6264C	MCM6264C@SOIC28

[ ( SA630 ) ]	
MCM6268	
MCM6269	
MCM6287	MCM6287@SOJ24
[ ( SA646 ) ]	
MCM6288	MCM6288@SOJ22
[ ( SA646 ) ]	
MCM6288B	MCM6288B@SOJ22
[ ( SA646 ) ]	
MCM6288C	MCM6288C@SOJ22
[ ( SA646 ) ]	
MCM6290	MCM6290@SOJ24
[ ( SA646 ) ]	
MCM6290B	MCM6290B@SOJ24
[ ( SA646 ) ]	
MCM6290C	MCM6290C@SOJ24
[ ( SA646 ) ]	
MCM62L07	MCM62L07@SOJ24
[ ( SA646 ) ]	
MCM62L08	MCM62L08@SOJ24
[ ( SA646 ) ]	
MCM62L09	MCM62L09@SOJ28
[ ( SA646 ) ]	
MCM6706	MCM6706@SOIC28
[ ( SA630 ) ]	
MCM6706A	MCM6706A@SOJ28
[ ( SA646 ) ]	
MCM6708A	MCM6708A@SOJ24
[ ( SA646 ) ]	
MCM6709A	MCM6709A@SOJ28
[ ( SA646 ) ]	

## MICROCONTROLLER

68HC711E9MFN2@PLCC52 ( \* ) [ ( SA647-B5202 ) ]  
68HC711E9MFNE2@PLCC52 ( \* ) [ ( SA647-B5202 ) ]  
68HC711E9VFN2@PLCC52 ( \* ) [ ( SA647-B5202 ) ]  
68HC711E9VFNE2@PLCC52 ( \* ) [ ( SA647-B5202 ) ]  
DSP56F801 ( FA60 ) @TQFP48 [ ( SA248 ) ]  
DSP56F801 ( FA60E ) @TQFP48 [ ( SA248 ) ]  
DSP56F801 ( FA80 ) @TQFP48 [ ( SA248 ) ]  
DSP56F801 ( FA80E ) @TQFP48 [ ( SA248 ) ]

DSP56F802(TA60)@TQFP32 [(SA663)]  
DSP56F802(TA60E)@TQFP32 [(SA663)]  
DSP56F802(TA80)@TQFP32 [(SA663)]  
DSP56F802(TA80E)@TQFP32 [(SA663)]  
DSP56F803(BU80)@TQFP100(JTAG) [ISP-HEADER01]  
DSP56F803(BU80E)@TQFP100(JTAG) [ISP-HEADER01]  
DSP56F805(FV80)@TQFP144(JTAG) [ISP-HEADER01]  
DSP56F805(FV80E)@TQFP144(JTAG) [ISP-HEADER01]  
DSP56F807(PY80)@LQFP160(JTAG) [ISP-HEADER01]  
DSP56F807(PY80E)@LQFP160(JTAG) [ISP-HEADER01]  
DSP56F807(VF80)@LQFP160(JTAG) [ISP-HEADER01]  
DSP56F807(VF80E)@LQFP160(JTAG) [ISP-HEADER01]  
DSP56F826(BU80)@TQFP100(JTAG) [ISP-HEADER01]  
DSP56F826(BU80E)@TQFP100(JTAG) [ISP-HEADER01]  
DSP56F827(FG80)@TQFP128(JTAG) [ISP-HEADER01]  
DSP56F827(FG80E)@TQFP128(JTAG) [ISP-HEADER01]  
MC56F8011VF AE@QFP32 [(SA663+B005)]  
MC56F8013VF AE@QFP32 [(SA663+B005)]  
MC56F8014VF AE@QFP32 [(SA663+B005)]  
MC56F8023MF AE@QFP32 [(SA663+B005)]  
MC56F8023VF AE@QFP32 [(SA663+B005)]  
MC56F8025VLD@QFP44 [(SA245A+B005)]  
MC56F8036MF AE@QFP48 [(SA248+B005)]  
MC56F8036VF AE@QFP48 [(SA248+B005)]  
MC56F8037VLH@QFP64 [(PEP+S616)]  
MC56F8122VFA@TQFP48 [(SA248+B005)]  
MC56F8122VF AE@TQFP48 [(SA248+B005)]  
MC56F8123VFB@TQFP64 [(PEP+S616)]  
MC56F8123VFBE@TQFP64 [(PEP+S616)]  
MC56F8322MFA60@TQFP48 [(SA248+B005)]  
MC56F8322MF AE@TQFP48 [(SA248+B005)]  
MC56F8322VFA60@TQFP48 [(SA248+B005)]  
MC56F8322VF AE@TQFP48 [(SA248+B005)]  
MC56F8323MFB60@TQFP64 [(PEP+S616)]  
MC56F8323MFBE@TQFP64 [(PEP+S616)]  
MC56F8323VFB60@TQFP64 [(PEP+S616)]  
MC56F8323VFBE@TQFP64 [(PEP+S616)]  
MC68705R3  
MC68705R5  
MC68705U3  
MC68705U5  
MC68HC11A0  
MC68HC11A0@PLCC52 [(PEP  
+S415T)]

MC68HC11A1 MC68HC11A1@PLCC52 [(PEP  
+S415T)]  
MC68HC11A8 MC68HC11A8@PLCC52 [(PEP  
+S415T)]  
MC68HC11E1@PLCC52 [(PEP+S415T)]  
MC68HC11E1@PLCC52(\*) [(SA647-B5202)]  
MC68HC11E20@PLCC52 [(PEP+S415T)]  
MC68HC11E20@PLCC52(\*) [(SA647-B5202)]  
MC68HC11E9@PLCC52 [(PEP+S415T)]  
MC68HC11E9@PLCC52(\*) [(SA647-B5202)]  
MC68HC11F1@PLCC68 [(PEP+S414T)] MC68HC11K1@PLCC84 [(PEP  
+S416T)]  
MC68HC11P1@PLCC84(\*) [(SA649-B8405)]  
MC68HC705B16N@PLCC52 [(PEP+S415T)]  
MC68HC705B16N@TQFP64 [(PEP+S625A)]  
MC68HC705B16N@TQFP64(\*) [(SA668+B204)]  
MC68HC705B5@PLCC52 [(PEP+S415T)]  
MC68HC705C4  
MC68HC705C4@PLCC44 [(SA244)]  
MC68HC705C4A  
MC68HC705C4A@PLCC44 [(SA244)]  
MC68HC705C8  
MC68HC705C8@PLCC44 [(SA244)] MC68HC705C8@SDIP42  
[SA028]  
MC68HC705C8@TQFP44 [(SA245A)]  
MC68HC705C8A  
MC68HC705C8A@PLCC44 [(SA244)] MC68HC705C8A@SDIP42  
[SA028]  
MC68HC705C8A@TQFP44 [(SA245A)]  
MC68HC705C9A  
MC68HC705C9A@PLCC44 [(SA244)] MC68HC705C9A@TQFP44  
[(SA245A)]  
MC68HC705J1A(CDW)@SOIC20 [(SA404)]  
MC68HC705J1A(CSD)@SSOP20 [(SA626A)]  
MC68HC705J1A(P) MC68HC705J2  
(Emulation)  
MC68HC705J2(Emulation)@SOIC20 [(SA404)]  
MC68HC705J2(Emulation)@SSOP20 [(SA626A)]  
MC68HC705J2(Native)  
MC68HC705J2(Native)@SOIC20 [(SA404)]  
MC68HC705J2(Native)@SSOP20 [(SA626A)]  
MC68HC705KJ1 MC68HC705KJ1@SOIC16  
[(SA404)]

MC68HC705P6(CDW)@SOIC28 [(SA404)]  
MC68HC705P6(CP)  
MC68HC705P6A(CDW)@SOIC28 [(SA404)]  
MC68HC705P6A(CP)  
MC68HC705P9  
MC68HC705P9@SOIC28 [(SA404)]  
MC68HC705SR3  
MC68HC705SR3@SDIP42 [(SA028)] MC68HC705SR3@TQFP44  
[(SA245A)]  
MC68HC711D3 MC68HC711D3@PLCC44  
[(SA244)]  
MC68HC711D3@TQFP44 [(SA675)]  
MC68HC711E20@PLCC52 [(PEP+S415T)]  
MC68HC711E20@TQFP64 [(PEP+S625A)]  
MC68HC711E9(4.5V)@PLCC52 [(SA647-B5202)]  
MC68HC711E9@PLCC52(\*) [(SA647-B5202)]  
MC68HC711E9CFN(4.5V)@PLCC52 [(SA647-B5202)]  
MC68HC711E9CFN2@PLCC52(\*) [(SA647-B5202)]  
MC68HC711E9CFN3@PLCC52(\*) [(SA647-B5202)]  
MC68HC711E9CFNE2@PLCC52(\*) [(SA647-B5202)]  
MC68HC711E9CFNE3@PLCC52(\*) [(SA647-B5202)]  
MC68HC711E9-FN@PLCC52(\*) [(SA647-B5202)]  
MC68HC711K4@PLCC84 [(PEP+S416T)]  
MC68HC711K4@TQFP80(\*) [(TA031-B006)]  
MC68HC711KA2@PLCC68 [(PEP+S414T)]  
MC68HC711KA4@PLCC68 [(PEP+S414T)]  
MC68HC711KS2@PLCC68 [(PEP+S414T)]  
MC68HC711L6@TQFP64 [(SA668+B188)]  
MC68HC711P2@PLCC84(\*) [(SA649-B8405)]  
MC68HC811E2@PLCC52 [(PEP+S415T)]  
MC68HC811E2CP2  
MC68HC811E2MP2  
MC68HC811E2P2  
MC68HC811E2VP2  
MC68HC812A4CPV@TQFP112(\*) [(SA719+B210)]  
MC68HC812A4CPVE@TQFP112(\*) [(SA719+B210)]  
MC68HC812A4MPV@TQFP112(\*) [(SA719+B210)]  
MC68HC812A4MPVE@TQFP112(\*) [(SA719+B210)]  
MC68HC908AB32CFU@TQFP64(\*) [(TA011-B006)]  
MC68HC908AB32MFU@TQFP64(\*) [(TA011-B006)]  
MC68HC908AP16CB(S)@SDIP42 [(SA028)]  
MC68HC908AP16CB@SDIP42 [(SA028)]  
MC68HC908AP16CFA(S)@LQFP48 [(SA248)]



MC68HC908AP16CFA@LQFP48 [(SA248)]  
MC68HC908AP16CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP16CFB@TQFP44 [(SA675)]  
MC68HC908AP32CB(S)@SDIP42 [(SA028)]  
MC68HC908AP32CB@SDIP42 [(SA028)]  
MC68HC908AP32CFA(S)@LQFP48 [(SA248)]  
MC68HC908AP32CFA@LQFP48 [(SA248)]  
MC68HC908AP32CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP32CFB@TQFP44 [(SA675)]  
MC68HC908AP64CB@SDIP42 [(SA028)]  
MC68HC908AP64CFA@LQFP48 [(SA248)]  
MC68HC908AP64CFB@TQFP44 [(SA675)]  
MC68HC908AP8CB(S)@SDIP42 [(SA028)]  
MC68HC908AP8CB@SDIP42 [(SA028)]  
MC68HC908AP8CFA(S)@@LQFP48 [(SA248)]  
MC68HC908AP8CFA@@LQFP48 [(SA248)]  
MC68HC908AP8CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP8CFB@TQFP44 [(SA675)]  
MC68HC908AS32A(CFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS32A(MFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS32A(VFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS60(CFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS60(CFU)@TQFP64(\*) [(TA011-B006)]  
MC68HC908AS60(MFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS60(MFU)@TQFP64(\*) [(TA011-B006)]  
MC68HC908AS60(VFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS60(VFU)@TQFP64(\*) [(TA011-B006)]  
MC68HC908AS60A(CFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS60A(CFU)@TQFP64(\*) [(TA011-B006)]  
MC68HC908AS60A(MFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS60A(MFU)@TQFP64(\*) [(TA011-B006)]  
MC68HC908AS60A(VFN)@PLCC52 [(PEP+S415T)]  
MC68HC908AS60A(VFU)@TQFP64(\*) [(TA011-B006)]  
MC68HC908AZ32A(CFU)@TQFP64(\*) [(TA011-B006)]  
MC68HC908AZ32A(MFU)@TQFP64(\*) [(TA011-B006)]  
MC68HC908AZ32A(VFU)@TQFP64(\*) [(TA011-B006)]  
MC68HC908AZ60(CFU)@TQFP64(\*) [(TA011-B006)]  
MC68HC908AZ60(MFU)@TQFP64(\*) [(TA011-B006)]  
MC68HC908AZ60(VFU)@TQFP64(\*) [(TA011-B006)]  
MC68HC908AZ60A(CFU)@TQFP64(\*) [(TA011-B006)]  
MC68HC908AZ60A(MFU)@TQFP64(\*) [(TA011-B006)]  
MC68HC908AZ60A(VFU)@TQFP64(\*) [(TA011-B006)]  
MC68HC908BD48IB@SDIP42 [(SA028)]

MC68HC908BD48IFB@TQFP44 [(SA675)]	
MC68HC908EY16CFA@TQFP32 [(SA663)]	
MC68HC908EY16MFA@TQFP32 [(SA663)]	
MC68HC908EY16VFA@TQFP32 [(SA663)]	
MC68HC908EY8CFA@TQFP32 [(SA663)]	MC68HC908EY8MFA@TQFP32
[(SA663)]	
MC68HC908EY8VFA@TQFP32 [(SA663)]	
MC68HC908GP32	
MC68HC908GP32@SDIP42 [(SA028)]	MC68HC908GP32@TQFP44
[(SA675)]	
MC68HC908GR16CFA@TQFP48 [(SA248)]	
MC68HC908GR16CFJ@TQFP32 [(SA663)]	
MC68HC908GR16MFA@TQFP48 [(SA248)]	
MC68HC908GR16MFJ@TQFP32 [(SA663)]	
MC68HC908GR16VFA@TQFP48 [(SA248)]	
MC68HC908GR16VFJ@TQFP32 [(SA663)]	
MC68HC908GR4CDW@SOIC28 [(SA404)]	MC68HC908GR4CFA@TQFP32
[(SA663)]	
MC68HC908GR4CP	MC68HC908GR4MDW@SOIC28
[(SA404)]	
MC68HC908GR4MFA@TQFP32 [(SA663)]	
MC68HC908GR4MP	
MC68HC908GR4VDW@SOIC28 [(SA404)]	MC68HC908GR4VFA@TQFP32
[(SA663)]	
MC68HC908GR4VP	MC68HC908GR8CDW@SOIC28
[(SA404)]	
MC68HC908GR8CFA@TQFP32 [(SA663)]	
MC68HC908GR8CP	
MC68HC908GR8MDW@SOIC28 [(SA404)]	MC68HC908GR8MFA@TQFP32
[(SA663)]	
MC68HC908GR8MP	MC68HC908GR8VDW@SOIC28
[(SA404)]	
MC68HC908GR8VFA@TQFP32 [(SA663)]	
MC68HC908GR8VP	
MC68HC908GT16@SDIP42 [(SA028)]	MC68HC908GT16@TQFP44
[(SA675)]	
MC68HC908GT8CB@SDIP42 [(SA028)]	MC68HC908GT8CFB@TQFP44
[(SA675)]	
MC68HC908GZ16(CFA)@TQFP48 [(SA248)]	
MC68HC908GZ16(CFJ)@TQFP32 [(SA663)]	
MC68HC908GZ16(MFA)@TQFP48 [(SA248)]	
MC68HC908GZ16(MFJ)@TQFP32 [(SA663)]	
MC68HC908GZ16(VFA)@TQFP48 [(SA248)]	

MC68HC908GZ16(VFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ32(CFA)@TQFP48 [(SA248)]  
 MC68HC908GZ32(CFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ32(MFA)@TQFP48 [(SA248)]  
 MC68HC908GZ32(MFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ32(VFA)@TQFP48 [(SA248)]  
 MC68HC908GZ32(VFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ48(CFA)@TQFP48 [(SA248)]  
 MC68HC908GZ48(CFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ48(MFA)@TQFP48 [(SA248)]  
 MC68HC908GZ48(MFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ48(VFA)@TQFP48 [(SA248)]  
 MC68HC908GZ48(VFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ60(CFA)@TQFP48 [(SA248)]  
 MC68HC908GZ60(CFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ60(MFA)@TQFP48 [(SA248)]  
 MC68HC908GZ60(MFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ60(VFA)@TQFP48 [(SA248)]  
 MC68HC908GZ60(VFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ8(CFA)@TQFP48 [(SA248)]  
 MC68HC908GZ8(CFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ8(MFA)@TQFP48 [(SA248)]  
 MC68HC908GZ8(MFJ)@TQFP32 [(SA663)]  
 MC68HC908GZ8(VFA)@TQFP48 [(SA248)]  
 MC68HC908GZ8(VFJ)@TQFP32 [(SA663)]  
 MC68HC908JB12(DW)@SOIC28 [(SA404)]  
 MC68HC908JB12(JDW)@SOIC20 [(SA404)]  
 MC68HC908JB16(DW)@SOIC28 [(SA404)]  
 MC68HC908JB16(FA)@QFP32 [(SA663)]  
 MC68HC908JB16(JDW)@SOIC20 [(SA404)]  
 MC68HC908JB8  
 [(SA404)]  
 MC68HC908JB8@SOIC28 [(SA404)]  
 [(SA675)]  
 MC68HC908JK1CDW@SOIC20 [(SA404)]  
 MC68HC908JK1CP  
 MC68HC908JK1ECDW@SOIC20 [(SA404)]  
 MC68HC908JK1ECP  
 MC68HC908JK1EMDW@SOIC20 [(SA404)]  
 MC68HC908JK1EMP  
 [(SA404)]  
 MC68HC908JK1MP  
 [(SA404)]

MC68HC908JB8@SOIC20  
 MC68HC908JB8@TQFP44  
 MC68HC908JK1MDW@SOIC20  
 MC68HC908JK3CDW@SOIC20

MC68HC908JK3CP  
MC68HC908JK3ECDW@SOIC20 [(SA404)]  
MC68HC908JK3ECP  
MC68HC908JK3EMDW@SOIC20 [(SA404)]  
MC68HC908JK3EMP  
[(SA404)]  
MC68HC908JK3MP  
MC68HC908JK8  
MC68HC908JK8@SOIC20 [(SA404)]  
[(SA404)]  
MC68HC908JL3CFA@TQFP48 [(SA248)]  
MC68HC908JL3CP  
MC68HC908JL3ECDW@SOIC28 [(SA404)]  
MC68HC908JL3ECFA@TQFP48 [(SA248)]  
MC68HC908JL3ECP  
MC68HC908JL3EMDW@SOIC28 [(SA404)]  
MC68HC908JL3EMFA@TQFP48 [(SA248)]  
MC68HC908JL3EMP  
[(SA404)]  
MC68HC908JL3MFA@TQFP48 [(SA248)]  
MC68HC908JL3MP  
MC68HC908JL8(dip20)  
(dip28)  
MC68HC908JL8@LQFP32 [(SA663)]  
[(SA653)]  
MC68HC908JL8@SOIC20 [(SA404)]  
[(SA404)]  
MC68HC908KX2(CDW)@SOIC16 [(SA404)]  
MC68HC908KX2(CP)  
MC68HC908KX2(MDW)@SOIC16 [(SA404)]  
MC68HC908KX2(MP)  
MC68HC908KX2(VDW)@SOIC16 [(SA404)]  
MC68HC908KX2(VP)  
MC68HC908KX8(CDW)@SOIC16 [(SA404)]  
MC68HC908KX8(CP)  
MC68HC908KX8(MDW)@SOIC16 [(SA404)]  
MC68HC908KX8(MP)  
MC68HC908KX8(VDW)@SOIC16 [(SA404)]  
MC68HC908KX8(VP)  
@SOIC20  
MC68HC908LB8CDWE@SOIC20 [(SA404)]  
MC68HC908LB8CPE  
(S)

MC68HC908JK3MDW@SOIC20  
MC68HC908JL3CDW@SOIC28  
MC68HC908JL3MDW@SOIC28  
MC68HC908JL8  
MC68HC908JL8@SDIP32  
MC68HC908JL8@SOIC28  
MC68HC908LB8CDWE(S)

MC68HC908LB8MDWE(S)@SOIC20  
MC68HC908LB8MDWE@SOIC20 [(SA404)]  
MC68HC908LB8MPE  
(S) MC68HC908LB8MPE  
MC68HC908LB8VDWE(S)@SOIC20  
MC68HC908LB8VDWE@SOIC20 [(SA404)]  
MC68HC908LB8VPE  
(S) MC68HC908LB8VPE  
MC68HC908LD60IFU@QFP64 [(PEP+S625)]  
MC68HC908LD64IFU@QFP64 [(PEP+S625)]  
MC68HC908LJ12CFB@TQFP52 [(PEP-S673)]  
MC68HC908LJ12CFBE@TQFP52 [(PEP-S673)]  
MC68HC908LJ12CFU@TQFP64 [(PEP-S625A)]  
MC68HC908LJ12CFU@TQFP64(\*) [(SA757-B331)]  
MC68HC908LJ12CFUE@TQFP64 [(PEP-S625A)]  
MC68HC908LJ12CFUE@TQFP64(\*) [(SA757-B331)]  
MC68HC908LJ12CPB@TQFP64 [(PEP-S616)]  
MC68HC908LJ12CPBE@TQFP64 [(PEP-S616)]  
MC68HC908LJ24CFQ@TQFP80 [(PEP-S615B)]  
MC68HC908LJ24CFQE@TQFP80 [(PEP-S615B)]  
MC68HC908LJ24CFU@TQFP64 [(PEP-S625A)]  
MC68HC908LJ24CFU@TQFP64(\*) [(SA757-B331)]  
MC68HC908LJ24CFUE@TQFP64 [(PEP-S625A)]  
MC68HC908LJ24CFUE@TQFP64(\*) [(SA757-B331)]  
MC68HC908LJ24CPB@TQFP64 [(PEP-S616)]  
MC68HC908LJ24CPBE@TQFP64 [(PEP-S616)]  
MC68HC908LJ24CPK@TQFP80 [(PEP-S640B)]  
MC68HC908LJ24CPKE@TQFP80 [(PEP-S640B)]  
MC68HC908LK24CFQ@TQFP80 [(PEP-S615B)]  
MC68HC908LK24CFQE@TQFP80 [(PEP-S615B)]  
MC68HC908LK24CFU@TQFP64 [(PEP-S625A)]  
MC68HC908LK24CFU@TQFP64(\*) [(SA757-B331)]  
MC68HC908LK24CFUE@TQFP64 [(PEP-S625A)]  
MC68HC908LK24CFUE@TQFP64(\*) [(SA757-B331)]  
MC68HC908LK24CPB@TQFP64 [(PEP-S616)]  
MC68HC908LK24CPBE@TQFP64 [(PEP-S616)]  
MC68HC908LK24CPK@TQFP80 [(PEP-S640B)]  
MC68HC908LK24CPKE@TQFP80 [(PEP-S640B)]  
MC68HC908LV8CPBE@TQFP52 [(PEP+S673)]  
MC68HC908MR16(CB)@SDIP56 [(PEP+S627)]  
MC68HC908MR16(CFU)@TQFP64 [(PEP+S625A)]  
MC68HC908MR16(VB)@SDIP56 [(PEP+S627)]  
MC68HC908MR16(VFU)@TQFP64 [(PEP+S625A)]

MC68HC908MR32(CB)@SDIP56 [(PEP+S627)]  
MC68HC908MR32(CFU)@TQFP64 [(PEP+S625A)]  
MC68HC908MR32(VB)@SDIP56 [(PEP+S627)]  
MC68HC908MR32(VFU)@TQFP64 [(PEP+S625A)]  
MC68HC908QB4(CDT)@TSSOP16 [(SA026)]  
MC68HC908QB4(CDW)@SOIC16 [(SA404)]  
MC68HC908QB4(CP)  
MC68HC908QB4(MDT)@TSSOP16 [(SA026)]  
MC68HC908QB4(MDW)@SOIC16 [(SA404)]  
MC68HC908QB4(MP)  
MC68HC908QB4(VDT)@TSSOP16 [(SA026)]  
MC68HC908QB4(VDW)@SOIC16 [(SA404)]  
MC68HC908QB4(VP)  
MC68HC908QB8(CDT)@TSSOP16 [(SA026)]  
MC68HC908QB8(CDW)@SOIC16 [(SA404)]  
MC68HC908QB8(CP)  
MC68HC908QB8(MDT)@TSSOP16 [(SA026)]  
MC68HC908QB8(MDW)@SOIC16 [(SA404)]  
MC68HC908QB8(MP)  
MC68HC908QB8(VDT)@TSSOP16 [(SA026)]  
MC68HC908QB8(VDW)@SOIC16 [(SA404)]  
MC68HC908QB8(VP)  
MC68HC908QC16(CDR)@TSSOP28 [(SA643)]  
MC68HC908QC16(CDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16(CDS)@TSSOP20 [(SA643)]  
MC68HC908QC16(CDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16(CDT)@TSSOP16 [(SA643)]  
MC68HC908QC16(CDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16(CDX)@SOIC16 [(SA404)]  
MC68HC908QC16(CDXE)@SOIC16 [(SA404)]  
MC68HC908QC16(CDY)@SOIC20 [(SA404)]  
MC68HC908QC16(CDYE)@SOIC20 [(SA404)]  
MC68HC908QC16(CDZ)@SOIC28 [(SA404)]  
MC68HC908QC16(CDZE)@SOIC28 [(SA404)]  
MC68HC908QC16(MDR)@TSSOP28 [(SA643)]  
MC68HC908QC16(MDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16(MDS)@TSSOP20 [(SA643)]  
MC68HC908QC16(MDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16(MDT)@TSSOP16 [(SA643)]  
MC68HC908QC16(MDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16(MDX)@SOIC16 [(SA404)]  
MC68HC908QC16(MDXE)@SOIC16 [(SA404)]  
MC68HC908QC16(MDY)@SOIC20 [(SA404)]

MC68HC908QC16(MDYE)@SOIC20 [(SA404)]  
MC68HC908QC16(MDZ)@SOIC28 [(SA404)]  
MC68HC908QC16(MDZE)@SOIC28 [(SA404)]  
MC68HC908QC16(VDR)@TSSOP28 [(SA643)]  
MC68HC908QC16(VDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16(VDS)@TSSOP20 [(SA643)]  
MC68HC908QC16(VDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16(VDT)@TSSOP16 [(SA643)]  
MC68HC908QC16(VDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16(VDX)@SOIC16 [(SA404)]  
MC68HC908QC16(VDXE)@SOIC16 [(SA404)]  
MC68HC908QC16(VDY)@SOIC20 [(SA404)]  
MC68HC908QC16(VDYE)@SOIC20 [(SA404)]  
MC68HC908QC16(VDZ)@SOIC28 [(SA404)]  
MC68HC908QC16(VDZE)@SOIC28 [(SA404)]  
MC68HC908QC4(CDR)@TSSOP28 [(SA643)]  
MC68HC908QC4(CDRE)@TSSOP28 [(SA643)]  
MC68HC908QC4(CDS)@TSSOP20 [(SA643)]  
MC68HC908QC4(CDSE)@TSSOP20 [(SA643)]  
MC68HC908QC4(CDT)@TSSOP16 [(SA643)]  
MC68HC908QC4(CDTE)@TSSOP16 [(SA643)]  
MC68HC908QC4(CDX)@SOIC16 [(SA404)]  
MC68HC908QC4(CDXE)@SOIC16 [(SA404)]  
MC68HC908QC4(CDY)@SOIC20 [(SA404)]  
MC68HC908QC4(CDYE)@SOIC20 [(SA404)]  
MC68HC908QC4(CDZ)@SOIC28 [(SA404)]  
MC68HC908QC4(CDZE)@SOIC28 [(SA404)]  
MC68HC908QC4(MDR)@TSSOP28 [(SA643)]  
MC68HC908QC4(MDRE)@TSSOP28 [(SA643)]  
MC68HC908QC4(MDS)@TSSOP20 [(SA643)]  
MC68HC908QC4(MDSE)@TSSOP20 [(SA643)]  
MC68HC908QC4(MDT)@TSSOP16 [(SA643)]  
MC68HC908QC4(MDTE)@TSSOP16 [(SA643)]  
MC68HC908QC4(MDX)@SOIC16 [(SA404)]  
MC68HC908QC4(MDXE)@SOIC16 [(SA404)]  
MC68HC908QC4(MDY)@SOIC20 [(SA404)]  
MC68HC908QC4(MDYE)@SOIC20 [(SA404)]  
MC68HC908QC4(MDZ)@SOIC28 [(SA404)]  
MC68HC908QC4(MDZE)@SOIC28 [(SA404)]  
MC68HC908QC4(VDR)@TSSOP28 [(SA643)]  
MC68HC908QC4(VDRE)@TSSOP28 [(SA643)]  
MC68HC908QC4(VDS)@TSSOP20 [(SA643)]  
MC68HC908QC4(VDSE)@TSSOP20 [(SA643)]

MC68HC908QC4 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QC4 (VDTE)@TSSOP16 [(SA643)]  
MC68HC908QC4 (VDX)@SOIC16 [(SA404)]  
MC68HC908QC4 (VDXE)@SOIC16 [(SA404)]  
MC68HC908QC4 (VDY)@SOIC20 [(SA404)]  
MC68HC908QC4 (VDYE)@SOIC20 [(SA404)]  
MC68HC908QC4 (VDZ)@SOIC28 [(SA404)]  
MC68HC908QC4 (VDZE)@SOIC28 [(SA404)]  
MC68HC908QC8 (CDR)@TSSOP28 [(SA643)]  
MC68HC908QC8 (CDRE)@TSSOP28 [(SA643)]  
MC68HC908QC8 (CDS)@TSSOP20 [(SA643)]  
MC68HC908QC8 (CDSE)@TSSOP20 [(SA643)]  
MC68HC908QC8 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QC8 (CDTE)@TSSOP16 [(SA643)]  
MC68HC908QC8 (CDX)@SOIC16 [(SA404)]  
MC68HC908QC8 (CDXE)@SOIC16 [(SA404)]  
MC68HC908QC8 (CDY)@SOIC20 [(SA404)]  
MC68HC908QC8 (CDYE)@SOIC20 [(SA404)]  
MC68HC908QC8 (CDZ)@SOIC28 [(SA404)]  
MC68HC908QC8 (CDZE)@SOIC28 [(SA404)]  
MC68HC908QC8 (MDR)@TSSOP28 [(SA643)]  
MC68HC908QC8 (MDRE)@TSSOP28 [(SA643)]  
MC68HC908QC8 (MDS)@TSSOP20 [(SA643)]  
MC68HC908QC8 (MDSE)@TSSOP20 [(SA643)]  
MC68HC908QC8 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QC8 (MDTE)@TSSOP16 [(SA643)]  
MC68HC908QC8 (MDX)@SOIC16 [(SA404)]  
MC68HC908QC8 (MDXE)@SOIC16 [(SA404)]  
MC68HC908QC8 (MDY)@SOIC20 [(SA404)]  
MC68HC908QC8 (MDYE)@SOIC20 [(SA404)]  
MC68HC908QC8 (MDZ)@SOIC28 [(SA404)]  
MC68HC908QC8 (MDZE)@SOIC28 [(SA404)]  
MC68HC908QC8 (VDR)@TSSOP28 [(SA643)]  
MC68HC908QC8 (VDRE)@TSSOP28 [(SA643)]  
MC68HC908QC8 (VDS)@TSSOP20 [(SA643)]  
MC68HC908QC8 (VDSE)@TSSOP20 [(SA643)]  
MC68HC908QC8 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QC8 (VDTE)@TSSOP16 [(SA643)]  
MC68HC908QC8 (VDX)@SOIC16 [(SA404)]  
MC68HC908QC8 (VDXE)@SOIC16 [(SA404)]  
MC68HC908QC8 (VDY)@SOIC20 [(SA404)]  
MC68HC908QC8 (VDYE)@SOIC20 [(SA404)]  
MC68HC908QC8 (VDZ)@SOIC28 [(SA404)]



MC68HC908QC8 (VDZE)@SOIC28 [(SA404)]  
MC68HC908QF4 (CFJ)@TQFP32 [(SA663)]  
MC68HC908QF4 (FJ)@TQFP32 [(SA663)]  
MC68HC908QL2 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QL2 (CDW)@SOIC16 [(SA404)]  
MC68HC908QL2 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QL2 (MDW)@SOIC16 [(SA404)]  
MC68HC908QL2 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QL2 (VDW)@SOIC16 [(SA404)]  
MC68HC908QL3 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QL3 (CDW)@SOIC16 [(SA404)]  
MC68HC908QL3 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QL3 (MDW)@SOIC16 [(SA404)]  
MC68HC908QL3 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QL3 (VDW)@SOIC16 [(SA404)]  
MC68HC908QL4 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QL4 (CDW)@SOIC16 [(SA404)]  
MC68HC908QL4 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QL4 (MDW)@SOIC16 [(SA404)]  
MC68HC908QL4 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QL4 (VDW)@SOIC16 [(SA404)]  
MC68HC908QT1CDW@SOIC8 [(SA605A)]  
MC68HC908QT1CP  
MC68HC908QT1MDW@SOIC8 [(SA605A)]  
MC68HC908QT1MP  
MC68HC908QT1VDW@SOIC8 [(SA605A)]  
MC68HC908QT1VP  
MC68HC908QT2CDW@SOIC8 [(SA605A)]  
MC68HC908QT2CP  
MC68HC908QT2MDW@SOIC8 [(SA605A)]  
MC68HC908QT2MP  
MC68HC908QT2VDW@SOIC8 [(SA605A)]  
MC68HC908QT2VP  
MC68HC908QT4CDW@SOIC8 [(SA605A)]  
MC68HC908QT4CP  
MC68HC908QT4MDW@SOIC8 [(SA605A)]  
MC68HC908QT4MP  
MC68HC908QT4VDW@SOIC8 [(SA605A)]  
MC68HC908QT4VP  
MC68HC908QY1CDT@TSSOP16 [(SA026)]  
MC68HC908QY1CDW@SOIC16 [(SA404)]  
MC68HC908QY1CP  
MC68HC908QY1MDT@TSSOP16 [(SA026)]

MC68HC908QY1MDW@SOIC16 [(SA404)]  
MC68HC908QY1MP  
MC68HC908QY1VDT@TSSOP16 [(SA026)]  
MC68HC908QY1VDW@SOIC16 [(SA404)]  
MC68HC908QY1VP  
MC68HC908QY2CDT@TSSOP16 [(SA026)]  
MC68HC908QY2CDW@SOIC16 [(SA404)]  
MC68HC908QY2CP  
MC68HC908QY2MDT@TSSOP16 [(SA026)]  
MC68HC908QY2MDW@SOIC16 [(SA404)]  
MC68HC908QY2MP  
MC68HC908QY2VDT@TSSOP16 [(SA026)]  
MC68HC908QY2VDW@SOIC16 [(SA404)]  
MC68HC908QY2VP  
MC68HC908QY4CDT@TSSOP16 [(SA026)]  
MC68HC908QY4CDW@SOIC16 [(SA404)]  
MC68HC908QY4CP  
MC68HC908QY4MDT@TSSOP16 [(SA026)]  
MC68HC908QY4MDW@SOIC16 [(SA404)]  
MC68HC908QY4MP  
MC68HC908QY4VDT@TSSOP16 [(SA026)]  
MC68HC908QY4VDW@SOIC16 [(SA404)]  
MC68HC908QY4VP  
MC68HC908QY8(CDT)@TSSOP16 [(SA026)]  
MC68HC908QY8(CDW)@SOIC16 [(SA404)]  
MC68HC908QY8(CP)  
MC68HC908QY8(MDT)@TSSOP16 [(SA026)]  
MC68HC908QY8(MDW)@SOIC16 [(SA404)]  
MC68HC908QY8(MP)  
MC68HC908QY8(VDT)@TSSOP16 [(SA026)]  
MC68HC908QY8(VDW)@SOIC16 [(SA404)]  
MC68HC908QY8(VP)  
MC68HC908RF2(CFA)@TQFP32 [(SA663)]  
MC68HC908RF2(MFA)@TQFP32 [(SA663)]  
MC68HC908SR12(CB)@SDIP42 [(SA028)]  
MC68HC908SR12(CFA)@TQFP48 [(SA248)]  
MC68HC908SR12(MB)@SDIP42 [(SA028)]  
MC68HC908SR12(MFA)@TQFP48 [(SA248)]  
MC68HC912B32(CFU8)@TQFP80(\*) [(TA045-B006)]  
MC68HC912B32(MFU8)@TQFP80(\*) [(TA045-B006)]  
MC68HC912B32(VFU8)@TQFP80(\*) [(TA045-B006)]  
MC68HC912BC32(CFU8)@TQFP80(\*) [(TA045-B006)]  
MC68HC912BC32(MFU8)@TQFP80(\*) [(TA045-B006)]

MC68HC912BC32(VFU8)@TQFP80(\*) [(TA045-B006)]  
 MC68HCP11E1@PLCC52 [(PEP+S415T)]  
 MC68HCP11E1@PLCC52(\*) [(SA647-B5202)]  
 MC68HRC908JK1CDW@SOIC20 [(SA404)]  
 MC68HRC908JK1CP  
 MC68HRC908JK1ECDW@SOIC20 [(SA404)]  
 MC68HRC908JK1ECP  
 MC68HRC908JK1EMDW@SOIC20 [(SA404)]  
 MC68HRC908JK1EMP  
 MC68HRC908JK1MDW@SOIC20 [(SA404)]  
 MC68HRC908JK1MP  
 MC68HRC908JK3CDW@SOIC20 [(SA404)]  
 MC68HRC908JK3CP  
 MC68HRC908JK3ECDW@SOIC20 [(SA404)]  
 MC68HRC908JK3ECP  
 MC68HRC908JK3EMDW@SOIC20 [(SA404)]  
 MC68HRC908JK3EMP  
 MC68HRC908JK3MDW@SOIC20 [(SA404)]  
 MC68HRC908JK3MP  
 MC68HRC908JK8  
 MC68HRC908JK8@SOIC20 [(SA404)]  
 MC68HRC908JL3CDW@SOIC28 [(SA404)]  
 MC68HRC908JL3CFA@TQFP48 [(SA248)]  
 MC68HRC908JL3CP  
 MC68HRC908JL3ECDW@SOIC28 [(SA404)]  
 MC68HRC908JL3ECFA@TQFP48 [(SA248)]  
 MC68HRC908JL3ECP  
 MC68HRC908JL3EMDW@SOIC28 [(SA404)]  
 MC68HRC908JL3EMFA@TQFP48 [(SA248)]  
 MC68HRC908JL3EMP  
 MC68HRC908JL3MDW@SOIC28 [(SA404)]  
 MC68HRC908JL3MFA@TQFP48 [(SA248)]  
 MC68HRC908JL3MP  
 MC68HRC908JL8  
 (dip20)  
 MC68HRC908JL8(dip28)  
 [(SA663)]  
 MC68HRC908JL8@SDIP32 [(SA653)]  
 [(SA404)]  
 MC68HRC908JL8@SOIC28 [(SA404)]  
 MC68HSC705C8A  
 MC68HSC705C8A@PLCC44 [(SA244)]  
 [SA028]  
 MC68HSC705C8A@TQFP44 [(SA245A)]

MC68S711E9@PLCC52(\*) [(SA647-B5202)]  
MC68S711E9-FN@PLCC52(\*) [(SA647-B5202)]  
MC908AB32CFUE@TQFP64(\*) [(TA011-B006)]  
MC908AB32MFUE@TQFP64(\*) [(TA011-B006)]  
MC908AP16CBE@SDIP42 [(SA028)] MC908AP16CFAE@LQFP48  
[(SA248)]  
MC908AP16CFBE@TQFP44 [(SA675)] MC908AP32CBE@SDIP42  
[(SA028)]  
MC908AP32CFAE@LQFP48 [(SA248)] MC908AP32CFBE@TQFP44  
[(SA675)]  
MC908AP64CBE@SDIP42 [(SA028)] MC908AP64CFAE@LQFP48  
[(SA248)]  
MC908AP64CFBE@TQFP44 [(SA675)] MC908AP8CBE@SDIP42  
[(SA028)]  
MC908AP8CFAE@LQFP48 [(SA248)] MC908AP8CFBE@TQFP44  
[(SA675)]  
MC908BD48IBE@SDIP42 [(SA028)] MC908BD48IFBE@TQFP44  
[(SA675)]  
MC908EY16ACFJE@TQFP32 [(SA663)] MC908EY16AKFJE@TQFP32  
[(SA663)]  
MC908EY16AMFJE@TQFP32 [(SA663)] MC908EY16AVFJE@TQFP32  
[(SA663)]  
MC908EY8ACFJE@TQFP32 [(SA663)] MC908EY8AKFJE@TQFP32  
[(SA663)]  
MC908EY8AMFJE@TQFP32 [(SA663)] MC908EY8AVFJE@TQFP32  
[(SA663)]  
MC908JL16CDWE@SOIC28 [(SA404)] MC908JL16CFJE@LQFP32  
[(SA663)]  
MC908JL16CPE MC908JL16CSPE@SDIP32  
[(SA653)]  
MC908QT1ACDWE@SOIC8 [(SA605A)]  
MC908QT1ACPE  
MC908QT1AMDWE@SOIC8 [(SA605A)]  
MC908QT1AMPE  
MC908QT1AVDWE@SOIC8 [(SA605A)]  
MC908QT1AVPE  
MC908QT2ACDWE@SOIC8 [(SA605A)]  
MC908QT2ACPE  
MC908QT2AMDWE@SOIC8 [(SA605A)]  
MC908QT2AMPE  
MC908QT2AVDWE@SOIC8 [(SA605A)]  
MC908QT2AVPE  
MC908QT4ACDWE@SOIC8 [(SA605A)]

MC908QT4ACPE  
 MC908QT4AMDWE@SOIC8 [(SA605A)]  
 MC908QT4AMPE  
 MC908QT4AVDWE@SOIC8 [(SA605A)]  
 MC908QT4AVPE  
 MC908QY1ACDTE@TSSOP16 [(SA026)]      MC908QY1ACDWE@SOIC16  
 [(SA404)]  
 MC908QY1ACPE      MC908QY1AMDTE@TSSOP16  
 [(SA026)]  
 MC908QY1AMDWE@SOIC16 [(SA404)]  
 MC908QY1AMPE  
 MC908QY1AVDTE@TSSOP16 [(SA026)]      MC908QY1AVDWE@SOIC16  
 [(SA404)]  
 MC908QY1AVPE      MC908QY2ACDTE@TSSOP16  
 [(SA026)]  
 MC908QY2ACDWE@SOIC16 [(SA404)]  
 MC908QY2ACPE  
 MC908QY2AMDTE@TSSOP16 [(SA026)]      MC908QY2AMDWE@SOIC16  
 [(SA404)]  
 MC908QY2AMPE      MC908QY2AVDTE@TSSOP16  
 [(SA026)]  
 MC908QY2AVDWE@SOIC16 [(SA404)]  
 MC908QY2AVPE  
 MC908QY4ACDTE@TSSOP16 [(SA026)]      MC908QY4ACDWE@SOIC16  
 [(SA404)]  
 MC908QY4ACPE      MC908QY4AMDTE@TSSOP16  
 [(SA026)]  
 MC908QY4AMDWE@SOIC16 [(SA404)]  
 MC908QY4AMPE  
 MC908QY4AVDTE@TSSOP16 [(SA026)]      MC908QY4AVDWE@SOIC16  
 [(SA404)]  
 MC908QY4AVPE  
 MC912D60ACFU8@TQFP80(\*) [(TA034-B006)]  
 MC912D60ACPV8@TQFP112(\*) [(TA035+B084)]  
 MC912D60AMFU8@TQFP80(\*) [(TA034-B006)]  
 MC912D60AMPV8@TQFP112(\*) [(TA035+B084)]  
 MC912D60AVFU8@TQFP80(\*) [(TA034-B006)]  
 MC912D60AVPV8@TQFP112(\*) [(TA035+B084)]  
 MC912D60CCFU8@TQFP80(\*) [(TA034-B006)]  
 MC912D60CCPV8@TQFP112(\*) [(TA035+B084)]  
 MC912D60CMFU8@TQFP80(\*) [(TA034-B006)]  
 MC912D60CMPV8@TQFP112(\*) [(TA035+B084)]  
 MC912D60CVFU8@TQFP80(\*) [(TA034-B006)]

MC912D60CVPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60PCFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60PCPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60PMFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60PMPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60PVFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60PVPV8@TQFP112(\*) [(TA035+B084)]  
MC912DG128ACPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128AMPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128AVPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128CCPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128CMPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128CVPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128PCPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128PMPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128PVPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128ACPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128AMPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128AVPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128CCPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128CMPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128CVPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128PCPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128PMPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128PVPV@TQFP112(\*) [(TA035+B084)]  
MC9RS08KA1CPC [(SA726+B179)]  
MC9RS08KA1CSC@SOIC8 [(SA602A+B179)]  
MC9RS08KA2CPC [(SA726+B179)]  
MC9RS08KA2CSC@SOIC8 [(SA602A+B179)]  
MC9S08AC16CFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC16CFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC16MFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC16MFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC16VFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC16VFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC8CFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC8CFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC8MFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC8MFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC8VFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC8VFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW16CFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW16CFGE@LQFP44(\*) [(SA245+B4404)]

MC9S08AW16CFUE@LQFP64 (\*) [(SA757+B196)]  
MC9S08AW16CPUE@QFP64 (\*) [(SA732+B196)]  
MC9S08AW16MFDE@QFN48 (\*) [(SA696+B198)]  
MC9S08AW16MFGE@LQFP44 (\*) [(SA245+B4404)]  
MC9S08AW16MFUE@LQFP64 (\*) [(SA757+B196)]  
MC9S08AW16MPUE@QFP64 (\*) [(SA732+B196)]  
MC9S08AW32CFDE@QFN48 (\*) [(SA696+B198)]  
MC9S08AW32CFGE@LQFP44 (\*) [(SA245+B4404)]  
MC9S08AW32CFUE@LQFP64 (\*) [(SA757+B196)]  
MC9S08AW32CPUE@QFP64 (\*) [(SA732+B196)]  
MC9S08AW32MFDE@QFN48 (\*) [(SA696+B198)]  
MC9S08AW32MFGE@LQFP44 (\*) [(SA245+B4404)]  
MC9S08AW32MFUE@LQFP64 (\*) [(SA757+B196)]  
MC9S08AW32MPUE@QFP64 (\*) [(SA732+B196)]  
MC9S08AW48CFDE@QFN48 (\*) [(SA696+B198)]  
MC9S08AW48CFGE@LQFP44 (\*) [(SA245+B4404)]  
MC9S08AW48CFUE@LQFP64 (\*) [(SA757+B196)]  
MC9S08AW48CPUE@QFP64 (\*) [(SA732+B196)]  
MC9S08AW48MFDE@QFN48 (\*) [(SA696+B198)]  
MC9S08AW48MFGE@LQFP44 (\*) [(SA245+B4404)]  
MC9S08AW48MFUE@LQFP64 (\*) [(SA757+B196)]  
MC9S08AW48MPUE@QFP64 (\*) [(SA732+B196)]  
MC9S08AW60CFDE@QFN48 (\*) [(SA696+B198)]  
MC9S08AW60CFGE@LQFP44 (\*) [(SA245+B4404)]  
MC9S08AW60CFUE@LQFP64 (\*) [(SA757+B196)]  
MC9S08AW60CPUE@QFP64 (\*) [(SA732+B196)]  
MC9S08AW60MFDE@QFN48 (\*) [(SA696+B198)]  
MC9S08AW60MFGE@LQFP44 (\*) [(SA245+B4404)]  
MC9S08AW60MFUE@LQFP64 (\*) [(SA757+B196)]  
MC9S08AW60MPUE@QFP64 (\*) [(SA732+B196)]  
MC9S08GB32ACFU@LQFP64 [(TA066-B006)]  
MC9S08GB32ACFUE@LQFP64 [(TA066-B006)]  
MC9S08GB32CFU@LQFP64 [(TA066-B006)]  
MC9S08GB32CFUE@LQFP64 [(TA066-B006)]  
MC9S08GB60ACFU@LQFP64 [(TA066-B006)]  
MC9S08GB60ACFUE@LQFP64 [(TA066-B006)]  
MC9S08GB60CFU@LQFP64 [(TA066-B006)]  
MC9S08GB60CFUE@LQFP64 [(TA066-B006)]  
MC9S08GT16ACB@SDIP42 [(SA028-B167)]  
MC9S08GT16ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT16ACFC@MLF32 [(SA686-B231)]  
MC9S08GT16ACFCE@MLF32 [(SA686-B231)]  
MC9S08GT16ACFD@QFN48 [(SA696-B166)]

MC9S08GT16AMB@SDIP42 [(SA028-B167)]  
MC9S08GT16AMFB@LQFP44 [(SA675-B168)]  
MC9S08GT16AMFC@MLF32 [(SA686-B231)]  
MC9S08GT16AMFCE@MLF32 [(SA686-B231)]  
MC9S08GT16AMFD@QFN48 [(SA696-B166)]  
MC9S08GT16CB@SDIP42 [(SA028-B167)]  
MC9S08GT16CBE@SDIP42 [(SA028-B167)]  
MC9S08GT16CFB@LQFP44 [(SA675-B168)]  
MC9S08GT16CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT16CFD@QFN48 [(SA696-B166)]  
MC9S08GT16CFDE@QFN48 [(SA696-B166)]  
MC9S08GT32ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT32ACFBE@LQFP44 [(SA675-B168)]  
MC9S08GT32ACFD@QFN48 [(SA696-B166)]  
MC9S08GT32ACFDE@QFN48 [(SA696-B166)]  
MC9S08GT32CB@SDIP42 [(SA028-B167)]  
MC9S08GT32CBE@SDIP42 [(SA028-B167)]  
MC9S08GT32CFB@LQFP44 [(SA675-B168)]  
MC9S08GT32CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT32CFD@QFN48 [(SA696-B166)]  
MC9S08GT32CFDE@QFN48 [(SA696-B166)]  
MC9S08GT60ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT60ACFBE@LQFP44 [(SA675-B168)]  
MC9S08GT60ACFD@QFN48 [(SA696-B166)]  
MC9S08GT60ACFDE@QFN48 [(SA696-B166)]  
MC9S08GT60CB@SDIP42 [(SA028-B167)]  
MC9S08GT60CBE@SDIP42 [(SA028-B167)]  
MC9S08GT60CFB@LQFP44 [(SA675-B168)]  
MC9S08GT60CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT60CFD@QFN48 [(SA696-B166)]  
MC9S08GT60CFDE@QFN48 [(SA696-B166)]  
MC9S08GT8ACB@SDIP42 [(SA028-B167)]  
MC9S08GT8ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT8ACFC@MLF32 [(SA686-B231)]  
MC9S08GT8ACFCE@MLF32 [(SA686-B231)]  
MC9S08GT8ACFD@QFN48 [(SA696-B166)]  
MC9S08GT8AMB@SDIP42 [(SA028-B167)]  
MC9S08GT8AMFB@LQFP44 [(SA675-B168)]  
MC9S08GT8AMFC@MLF32 [(SA686-B231)]  
MC9S08GT8AMFCE@MLF32 [(SA686-B231)]  
MC9S08GT8AMFD@QFN48 [(SA696-B166)]  
MC9S08JM32CGTE@QFN48 (\*) [(SA696+B310)]  
MC9S08JM32CLDE@QFP44 (\*) [(SA245A+B4405)]



MC9S08JM32CLHE@QFP64(\*) [(SA732+B311)]  
MC9S08JM32CQHE@TQFP64(\*) [(SA668+B311)]  
MC9S08JM60CGTE@QFN48(\*) [(SA696+B310)]  
MC9S08JM60CLDE@QFP44(\*) [(SA245A+B4405)]  
MC9S08JM60CLHE@QFP64(\*) [(SA732+B311)]  
MC9S08JM60CQHE@TQFP64(\*) [(SA668+B311)]  
MC9S08QA2CDN@SOIC8 [(SA602A+B179)]  
MC9S08QA2CDNE@SOIC8 [(SA602A+B179)]  
MC9S08QA2CFQ@DFN8 [(SA744+B248)]  
MC9S08QA2CFQE@DFN8 [(SA744+B248)]  
MC9S08QA2CPA  
MC9S08QA2CPAE  
MC9S08QA2MDN@SOIC8 [(SA602A+B179)]  
MC9S08QA2MDNE@SOIC8 [(SA602A+B179)]  
MC9S08QA2MFQ@DFN8 [(SA744+B248)]  
MC9S08QA2MFQE@DFN8 [(SA744+B248)]  
MC9S08QA2MPA  
MC9S08QA2MPAE  
MC9S08QA2VDN@SOIC8 [(SA602A+B179)]  
MC9S08QA2VDNE@SOIC8 [(SA602A+B179)]  
MC9S08QA2VFQ@DFN8 [(SA744+B248)]  
MC9S08QA2VFQE@DFN8 [(SA744+B248)]  
MC9S08QA2VPA  
MC9S08QA2VPAE  
MC9S08QA4CDN@SOIC8 [(SA602A+B179)]  
MC9S08QA4CDNE@SOIC8 [(SA602A+B179)]  
MC9S08QA4CFQ@DFN8 [(SA744+B248)]  
MC9S08QA4CFQE@DFN8 [(SA744+B248)]  
MC9S08QA4CPA  
MC9S08QA4CPAE  
MC9S08QA4MDN@SOIC8 [(SA602A+B179)]  
MC9S08QA4MDNE@SOIC8 [(SA602A+B179)]  
MC9S08QA4MFQ@DFN8 [(SA744+B248)]  
MC9S08QA4MFQE@DFN8 [(SA744+B248)]  
MC9S08QA4MPA  
MC9S08QA4MPAE  
MC9S08QA4VDN@SOIC8 [(SA602A+B179)]  
MC9S08QA4VDNE@SOIC8 [(SA602A+B179)]  
MC9S08QA4VFQ@DFN8 [(SA744+B248)]  
MC9S08QA4VFQE@DFN8 [(SA744+B248)]  
MC9S08QA4VPA  
MC9S08QA4VPAE  
MC9S08QD2CPC [(SA726+B179)]

MC9S08QD2CSC@SOIC8 [(SA602A+B179)]	
MC9S08QD2MPC [(SA726+B179)]	
MC9S08QD2MSC@SOIC8 [(SA602A+B179)]	
MC9S08QD2VPC [(SA726+B179)]	
MC9S08QD2VSC@SOIC8 [(SA602A+B179)]	
MC9S08QD4CPC [(SA726+B179)]	
MC9S08QD4CSC@SOIC8 [(SA602A+B179)]	
MC9S08QD4MPC [(SA726+B179)]	
MC9S08QD4MSC@SOIC8 [(SA602A+B179)]	
MC9S08QD4VPC [(SA726+B179)]	
MC9S08QD4VSC@SOIC8 [(SA602A+B179)]	
MC9S08QG4CDNE@SOIC8 [(SA602A+B179)]	
MC9S08QG4CDTE@TSSOP16 [(SA026+B182)]	
MC9S08QG4CFFE@QFN16 [(SA747+B247)]	
MC9S08QG4CFQE@DFN8 [(SA744+B248)]	
MC9S08QG4CPAE [(SA726+B179)]	
MC9S08QG8CDNE@SOIC8 [(SA602A+B179)]	
MC9S08QG8CDTE@TSSOP16 [(SA026+B182)]	
MC9S08QG8CFFE@QFN16 [(SA747+B247)]	
MC9S08QG8CFQE@DFN8 [(SA744+B248)]	
MC9S08QG8CPBE [(SA726+B182)]	MC9S08RC16CFG@LQFP44
[(SA245A)]	
MC9S08RC16CFJ@LQFP32 [(SA663)]	MC9S08RC16FG@LQFP44
[(SA245A)]	
MC9S08RC16FJ@LQFP32 [(SA663)]	MC9S08RC32CFG@LQFP44
[(SA245A)]	
MC9S08RC32CFJ@LQFP32 [(SA663)]	MC9S08RC32FG@LQFP44
[(SA245A)]	
MC9S08RC32FJ@LQFP32 [(SA663)]	MC9S08RC60CFG@LQFP44
[(SA245A)]	
MC9S08RC60CFJ@LQFP32 [(SA663)]	MC9S08RC60FG@LQFP44
[(SA245A)]	
MC9S08RC60FJ@LQFP32 [(SA663)]	MC9S08RC8CFG@LQFP44
[(SA245A)]	
MC9S08RC8CFJ@LQFP32 [(SA663)]	MC9S08RC8FG@LQFP44
[(SA245A)]	
MC9S08RC8FJ@LQFP32 [(SA663)]	MC9S08RD16CDW@SOIC28
[(SA404)]	
MC9S08RD16CFG@LQFP44 [(SA245A)]	MC9S08RD16CFJ@LQFP32
[(SA663)]	
MC9S08RD16CP	MC9S08RD16DW@SOIC28
[(SA404)]	
MC9S08RD16FG@LQFP44 [(SA245A)]	MC9S08RD16FJ@LQFP32

[ ( SA663 ) ]	
MC9S08RD16P	MC9S08RD32CDW@SOIC28
[ ( SA404 ) ]	
MC9S08RD32CFG@LQFP44 [ ( SA245A ) ]	MC9S08RD32CFJ@LQFP32
[ ( SA663 ) ]	
MC9S08RD32CP	MC9S08RD32DW@SOIC28
[ ( SA404 ) ]	
MC9S08RD32FG@LQFP44 [ ( SA245A ) ]	MC9S08RD32FJ@LQFP32
[ ( SA663 ) ]	
MC9S08RD32P	MC9S08RD60CDW@SOIC28
[ ( SA404 ) ]	
MC9S08RD60CFG@LQFP44 [ ( SA245A ) ]	MC9S08RD60CFJ@LQFP32
[ ( SA663 ) ]	
MC9S08RD60CP	MC9S08RD60DW@SOIC28
[ ( SA404 ) ]	
MC9S08RD60FG@LQFP44 [ ( SA245A ) ]	MC9S08RD60FJ@LQFP32
[ ( SA663 ) ]	
MC9S08RD60P	MC9S08RD8CDW@SOIC28
[ ( SA404 ) ]	
MC9S08RD8CFG@LQFP44 [ ( SA245A ) ]	MC9S08RD8CFJ@LQFP32
[ ( SA663 ) ]	
MC9S08RD8CP	MC9S08RD8DW@SOIC28
[ ( SA404 ) ]	
MC9S08RD8FG@LQFP44 [ ( SA245A ) ]	MC9S08RD8FJ@LQFP32
[ ( SA663 ) ]	
MC9S08RD8P	MC9S08RE16CFG@LQFP44
[ ( SA245A ) ]	
MC9S08RE16CFJ@LQFP32 [ ( SA663 ) ]	MC9S08RE16FG@LQFP44
[ ( SA245A ) ]	
MC9S08RE16FJ@LQFP32 [ ( SA663 ) ]	MC9S08RE32CFG@LQFP44
[ ( SA245A ) ]	
MC9S08RE32CFJ@LQFP32 [ ( SA663 ) ]	MC9S08RE32FG@LQFP44
[ ( SA245A ) ]	
MC9S08RE32FJ@LQFP32 [ ( SA663 ) ]	MC9S08RE60CFG@LQFP44
[ ( SA245A ) ]	
MC9S08RE60CFJ@LQFP32 [ ( SA663 ) ]	MC9S08RE60FG@LQFP44
[ ( SA245A ) ]	
MC9S08RE60FJ@LQFP32 [ ( SA663 ) ]	MC9S08RE8CFG@LQFP44
[ ( SA245A ) ]	
MC9S08RE8CFJ@LQFP32 [ ( SA663 ) ]	MC9S08RE8FG@LQFP44
[ ( SA245A ) ]	
MC9S08RE8FJ@LQFP32 [ ( SA663 ) ]	MC9S08RG32CFG@LQFP44
[ ( SA245A ) ]	

MC9S08RG32CFJ@LQFP32 [(SA663)] MC9S08RG32FG@LQFP44  
[(SA245A)]  
MC9S08RG32FJ@LQFP32 [(SA663)] MC9S08RG60CFG@LQFP44  
[(SA245A)]  
MC9S08RG60CFJ@LQFP32 [(SA663)] MC9S08RG60FG@LQFP44  
[(SA245A)]  
MC9S08RG60FJ@LQFP32 [(SA663)]  
MC9S08SG4CSC@SOIC8 [(SA602A+B179)]  
MC9S08SG4CTG@TSSOP16 [(SA026+B182)]  
MC9S08SG4MSC@SOIC8 [(SA602A+B179)]  
MC9S08SG4MTG@TSSOP16 [(SA026+B182)]  
MC9S08SG4VSC@SOIC8 [(SA602A+B179)]  
MC9S08SG4VTG@TSSOP16 [(SA026+B182)]  
MC9S08SG8CSC@SOIC8 [(SA602A+B179)]  
MC9S08SG8CTG@TSSOP16 [(SA026+B182)]  
MC9S08SG8MSC@SOIC8 [(SA602A+B179)]  
MC9S08SG8MTG@TSSOP16 [(SA026+B182)]  
MC9S08SG8VSC@SOIC8 [(SA602A+B179)]  
MC9S08SG8VTG@TSSOP16 [(SA026+B182)]  
MC9S08SH4CSC@SOIC8 [(SA602A+B179)]  
MC9S08SH4CTG@TSSOP16 [(SA026+B182)]  
MC9S08SH4MSC@SOIC8 [(SA602A+B179)]  
MC9S08SH4MTG@TSSOP16 [(SA026+B182)]  
MC9S08SH4VSC@SOIC8 [(SA602A+B179)]  
MC9S08SH4VTG@TSSOP16 [(SA026+B182)]  
MC9S08SH8CSC@SOIC8 [(SA602A+B179)]  
MC9S08SH8CTG@TSSOP16 [(SA026+B182)]  
MC9S08SH8MSC@SOIC8 [(SA602A+B179)]  
MC9S08SH8MTG@TSSOP16 [(SA026+B182)]  
MC9S08SH8VSC@SOIC8 [(SA602A+B179)]  
MC9S08SH8VTG@TSSOP16 [(SA026+B182)]  
MC9S12A128BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128VPV@TQFP112(\*) [(TA037-B084)]

MC9S12A256BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A64CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A64FU@TQFP80(\*) [(TA015-B006)]  
MC9S12A64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A64MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A64PV@TQFP112(\*) [(TA037-B084)]  
MC9S12A64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A64VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12C128CFA@TQFP48 [(SA248)]  
MC9S12C128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C128CPB@TQFP52 [(PEP+S673)]  
MC9S12C128MFA@TQFP48 [(SA248)]  
MC9S12C128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C128MPB@TQFP52 [(PEP+S673)]  
MC9S12C128VFA@TQFP48 [(SA248)]  
MC9S12C128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C128VPB@TQFP52 [(PEP+S673)]  
MC9S12C32CFA16@TQFP48 [(SA248)]           MC9S12C32CFA25@TQFP48  
[(SA248)]  
MC9S12C32CFU16@TQFP80(\*) [(TA015-B006)]  
MC9S12C32CFU25@TQFP80(\*) [(TA015-B006)]  
MC9S12C32CPB16@TQFP52 [(PEP+S673)]  
MC9S12C32CPB25@TQFP52 [(PEP+S673)]  
MC9S12C32MFA16@TQFP48 [(SA248)]           MC9S12C32MFA25@TQFP48  
[(SA248)]  
MC9S12C32MFU16@TQFP80(\*) [(TA015-B006)]  
MC9S12C32MFU25@TQFP80(\*) [(TA015-B006)]  
MC9S12C32MPB16@TQFP52 [(PEP+S673)]  
MC9S12C32MPB25@TQFP52 [(PEP+S673)]  
MC9S12C32VFA16@TQFP48 [(SA248)]           MC9S12C32VFA25@TQFP48  
[(SA248)]

MC9S12C32VFU16@TQFP80(\*) [(TA015-B006)]  
MC9S12C32VFU25@TQFP80(\*) [(TA015-B006)]  
MC9S12C32VPB16@TQFP52 [(PEP+S673)]  
MC9S12C32VPB25@TQFP52 [(PEP+S673)]  
MC9S12C64CFA@TQFP48 [(SA248)]  
MC9S12C64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C64CPB@TQFP52 [(PEP+S673)] MC9S12C64MFA@TQFP48  
[(SA248)]  
MC9S12C64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C64MPB@TQFP52 [(PEP+S673)] MC9S12C64VFA@TQFP48  
[(SA248)]  
MC9S12C64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C64VPB@TQFP52 [(PEP+S673)] MC9S12C96CFA@TQFP48  
[(SA248)]  
MC9S12C96CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C96CPB@TQFP52 [(PEP+S673)] MC9S12C96MFA@TQFP48  
[(SA248)]  
MC9S12C96MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C96MPB@TQFP52 [(PEP+S673)] MC9S12C96VFA@TQFP48  
[(SA248)]  
MC9S12C96VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C96VPB@TQFP52 [(PEP+S673)]  
MC9S12D64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12D64CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12D64FU@TQFP80(\*) [(TA015-B006)]  
MC9S12D64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12D64MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12D64PV@TQFP112(\*) [(TA037-B084)]  
MC9S12D64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12D64VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DB128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DB128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DB128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DB128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DB128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DB128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128CFU@TQFP80(\*) [(TA015-B006)]

MC9S12DG128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128ECFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128ECPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128EMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128EMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128EVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128EVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128ECFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128ECPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128EMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128EMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128EVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128EVPV@TQFP112(\*) [(TA037-B084)]

MC9S12DJ128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64FU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64PV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128ECPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128EMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128EVPV@TQFP112(\*) [(TA037-B084)]



MC9S12DT128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DT256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DT256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DT256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12E128CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E128MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E128VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E256CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E256MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E256VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E32CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E32CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E32MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E32MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E32VFU@TQFP80(\*) [(SA722-B239)]

MC9S12E32VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E64MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E64MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E64VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E64VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12GC128CFA@TQFP48 [(SA248)]  
MC9S12GC128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC128CPB@TQFP52 [(PEP+S673)]  
MC9S12GC128MFA@TQFP48 [(SA248)]  
MC9S12GC128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC128MPB@TQFP52 [(PEP+S673)]  
MC9S12GC128VFA@TQFP48 [(SA248)]  
MC9S12GC128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC128VPB@TQFP52 [(PEP+S673)]  
MC9S12GC16CFA@TQFP48 [(SA248)]  
MC9S12GC16CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16CPB@TQFP52 [(PEP+S673)]  
MC9S12GC16MFA@TQFP48 [(SA248)]  
MC9S12GC16MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16MPB@TQFP52 [(PEP+S673)]  
MC9S12GC16VFA@TQFP48 [(SA248)]  
MC9S12GC16VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16VPB@TQFP52 [(PEP+S673)]  
MC9S12GC32CFA@TQFP48 [(SA248)]  
MC9S12GC32CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32CPB@TQFP52 [(PEP+S673)]  
MC9S12GC32MFA@TQFP48 [(SA248)]  
MC9S12GC32MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32MPB@TQFP52 [(PEP+S673)]  
MC9S12GC32VFA@TQFP48 [(SA248)]  
MC9S12GC32VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32VPB@TQFP52 [(PEP+S673)]  
MC9S12GC64CFA@TQFP48 [(SA248)]  
MC9S12GC64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC64CPB@TQFP52 [(PEP+S673)]

MC9S12GC64MFA@TQFP48 [(SA248)]  
MC9S12GC64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC64MPB@TQFP52 [(PEP+S673)]  
MC9S12GC64VFA@TQFP48 [(SA248)]  
MC9S12GC64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC64VPB@TQFP52 [(PEP+S673)]  
MC9S12GC96CFA@TQFP48 [(SA248)]  
MC9S12GC96CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96CPB@TQFP52 [(PEP+S673)]  
MC9S12GC96MFA@TQFP48 [(SA248)]  
MC9S12GC96MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96MPB@TQFP52 [(PEP+S673)]  
MC9S12GC96VFA@TQFP48 [(SA248)]  
MC9S12GC96VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96VPB@TQFP52 [(PEP+S673)]  
MC9S12HN64CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256CPV@LQFP112(\*) [(SA719-B240)]

MC9S12HZ256MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12NE64CPV@LQFP112(\*) [(SA719-B246)]  
MC9S12NE64CPVE@LQFP112(\*) [(SA719-B246)]  
MC9S12NE64VTU@TQFP80(\*) [(TA048-B006)]  
MC9S12NE64VTUE@TQFP80(\*) [(TA048-B006)]  
MC9S12UF32PB@QFP64(\*) [(SA732+B200)]  
MC9S12UF32PBE@QFP64(\*) [(SA732+B200)]  
MC9S12UF32PU@QFP100(\*) [(SA718+B201)]  
MC9S12XA128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256CFU@TQFP80(\*) [(TA015-B006)]

MC9S12XA256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256VFB@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512VFB@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128VFU@TQFP80(\*) [(TA015-B006)]

MC9S12XB128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256VAV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256VPV@TQFP112(\*) [(TA037-B084)]

MC9S12XD64CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512VFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256VAA@TQFP80(\*) [(TA015-B006)]

MC9S12XDQ256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256VAV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256VAV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384CPU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384MPU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384VAV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384VPU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512CAG@LQFP144(\*) [(SA681-B14412)]



MC9S12XDT512CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512VFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XHZ256CAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ256CAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ256MAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ256MAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ256VAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ256VAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ384CAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ384CAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ384MAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ384MAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ384VAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ384VAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ512CAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ512CAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ512MAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ512MAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ512VAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ512VAL@TQFP112(\*) [(SA719-B264)]  
MCHC908JW32FAE@LQFP48 [(SA248+B005)]  
MCHC908JW32FC@TQFN48 [(SA696+B006)]  
P912XDG128CAA@TQFP80(\*) [(TA015-B006)]  
P912XDG128CAL@TQFP112(\*) [(TA037-B084)]  
P912XDG128CFU@TQFP80(\*) [(TA015-B006)]  
P912XDG128CPV@TQFP112(\*) [(TA037-B084)]  
P912XDG128MAA@TQFP80(\*) [(TA015-B006)]  
P912XDG128MAL@TQFP112(\*) [(TA037-B084)]  
P912XDG128MFU@TQFP80(\*) [(TA015-B006)]

P912XDG128MPV@TQFP112(\*) [(TA037-B084)]  
P912XDG128VAA@TQFP80(\*) [(TA015-B006)]  
P912XDG128VAL@TQFP112(\*) [(TA037-B084)]  
P912XDG128VFU@TQFP80(\*) [(TA015-B006)]  
P912XDG128VPV@TQFP112(\*) [(TA037-B084)]  
P9RS08KA1CPC [(SA726+B179)]  
P9RS08KA1CSC@SOIC8 [(SA602A+B179)]  
P9RS08KA2CPC [(SA726+B179)]  
P9RS08KA2CSC@SOIC8 [(SA602A+B179)]  
PC56F8011VFAB@QFP32 [(SA663+B005)]  
PC56F8013VFAB@QFP32 [(SA663+B005)]  
PC56F8014VFAB@QFP32 [(SA663+B005)]  
PC68HC908GP32 PC68HC908GP32@SDIP42  
[(SA028)]  
PC68HC908GP32@TQFP44 [(SA675)]  
PC9S12UF32PB@QFP64(\*) [(SA732+B200)]  
PC9S12UF32PBE@QFP64(\*) [(SA732+B200)]  
PC9S12UF32PU@QFP100(\*) [(SA718+B201)]  
PC9S12XF128@QFP112(\*) [(SA719-B253)]  
PC9S12XF128@QFP144(\*) [(SA681-B14411)]  
PC9S12XF128@QFP64(\*) [(SA732-B252)]  
PC9S12XF256@QFP112(\*) [(SA719-B253)]  
PC9S12XF256@QFP144(\*) [(SA681-B14411)]  
PC9S12XF256@QFP64(\*) [(SA732-B252)]  
PC9S12XF384@QFP112(\*) [(SA719-B253)]  
PC9S12XF384@QFP144(\*) [(SA681-B14411)]  
PC9S12XF384@QFP64(\*) [(SA732-B252)]  
PC9S12XF512@QFP112(\*) [(SA719-B253)]  
PC9S12XF512@QFP144(\*) [(SA681-B14411)]  
PC9S12XF512@QFP64(\*) [(SA732-B252)]  
PC9S12XHZ256CAG@LQFP144(\*) [(SA681-B14414)]  
PC9S12XHZ256CAL@TQFP112(\*) [(SA719-B264)]  
PC9S12XHZ256MAG@LQFP144(\*) [(SA681-B14414)]  
PC9S12XHZ256MAL@TQFP112(\*) [(SA719-B264)]  
PC9S12XHZ256VAG@LQFP144(\*) [(SA681-B14414)]  
PC9S12XHZ256VAL@TQFP112(\*) [(SA719-B264)]  
PC9S12XHZ384CAG@LQFP144(\*) [(SA681-B14414)]  
PC9S12XHZ384CAL@TQFP112(\*) [(SA719-B264)]  
PC9S12XHZ384MAG@LQFP144(\*) [(SA681-B14414)]  
PC9S12XHZ384MAL@TQFP112(\*) [(SA719-B264)]  
PC9S12XHZ384VAG@LQFP144(\*) [(SA681-B14414)]  
PC9S12XHZ384VAL@TQFP112(\*) [(SA719-B264)]  
PC9S12XHZ512CAG@LQFP144(\*) [(SA681-B14414)]

PC9S12XHZ512CAL@TQFP112(\*) [(SA719-B264)]  
 PC9S12XHZ512MAG@LQFP144(\*) [(SA681-B14414)]  
 PC9S12XHZ512MAL@TQFP112(\*) [(SA719-B264)]  
 PC9S12XHZ512VAG@LQFP144(\*) [(SA681-B14414)]  
 PC9S12XHZ512VAL@TQFP112(\*) [(SA719-B264)]  
 S9S08AW16ACFT@QFN48(\*) [(SA696+B198)]  
 S9S08AW16ACLS@QFP44(\*) [(SA245+B4404)]  
 S9S08AW16AMFT@QFN48(\*) [(SA696+B198)]  
 S9S08AW16AMLS@QFP44(\*) [(SA245+B4404)]  
 S9S08AW16AVFT@QFN48(\*) [(SA696+B198)]  
 S9S08AW16AVLS@QFP44(\*) [(SA245+B4404)]  
 S9S08AW8ACFT@QFN48(\*) [(SA696+B198)]  
 S9S08AW8ACLS@QFP44(\*) [(SA245+B4404)]  
 S9S08AW8AMFT@QFN48(\*) [(SA696+B198)]  
 S9S08AW8AMLS@QFP44(\*) [(SA245+B4404)]  
 S9S08AW8AVFT@QFN48(\*) [(SA696+B198)]  
 S9S08AW8AVLS@QFP44(\*) [(SA245+B4404)]  
 XC68HC705P6A(CDW)@SOIC28 [(SA404)]  
 XC68HC711D3 [(SA244)] XC68HC711D3@PLCC44  
 XC68HC711D3@TQFP44 [(SA675)]  
 XC68HC908MR32(CB)@SDIP56 [(PEP+S627)]  
 XC68HC908MR32(CFU)@TQFP64 [(PEP+S625A)]  
 XC68HC908MR32(VB)@SDIP56 [(PEP+S627)]  
 XC68HC908MR32(VFU)@TQFP64 [(PEP+S625A)]  
 XC68HSC705C9A [(SA244)] XC68HSC705C9A@PLCC44  
 XC68HSC705C9A@TQFP44 [(SA245A)]

## MYSON

### MICROCONTROLLER

CS8954F@PQFP44 [(SA675)] CS8954MV@PLCC44  
 [(SA244)]  
 CS8955F@PQFP44 [(SA675)] CS8955G@LQFP48  
 [(SA248)]  
 CS8955HF@PQFP44 [(SA675)] CS8955HG@LQFP48  
 [(SA248)]  
 CS8955HN CS8955HV@PLCC44  
 [(SA244)]  
 CS8955N CS8955V@PLCC44

[ ( SA244 ) ]  
MTV212MN32  
MTV212MN64I  
MTV212MS32@SDIP42 [ ( SA028 ) ]  
[ ( SA028 ) ]  
MTV212MV32@PLCC44 [ ( SA244 ) ]  
[ ( SA244 ) ]  
MTV230GMF@TQFP44 [ ( SA245A ) ]  
[ ( SA028 ) ]  
MTV230GMV@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]  
MTV230MS@SDIP42 [ ( SA028 ) ]  
[ ( SA244 ) ]  
MTV230PMF@TQFP44 [ ( SA245A ) ]  
[ ( SA028 ) ]  
MTV230PMV@PLCC44 [ ( SA244 ) ]  
MTV312MN64 ( AG  
VERSION )  
MTV312MN64 ( AJ VERSION )  
MTV312MS64 ( AG VERSION ) @SDIP42 [ ( SA028 ) ]  
MTV312MS64 ( AJ VERSION ) @SDIP42 [ ( SA028 ) ]  
MTV312MV64 ( AG VERSION ) @PLCC44 [ ( SA244 ) ]  
MTV312MV64 ( AJ VERSION ) @PLCC44 [ ( SA244 ) ]  
MTV412MF128@PQFP44 [ ( SA245A ) ]  
[ ( SA028 ) ]  
MTV412MV128@PLCC44 [ ( SA244 ) ]  
[ ( SA675 ) ]  
MTV416GMG@TQFP48 [ ( SA248 ) ]  
[ ( SA244 ) ]  
MTV416MF@TQFP44 [ ( SA675 ) ]  
[ ( SA248 ) ]  
MTV416MV@PLCC44 [ ( SA244 ) ]  
[ ( SA675 ) ]  
MTV416PMG@TQFP48 [ ( SA248 ) ]  
[ ( SA244 ) ]  
MTV512MF ( A1 VERSION ) @TQFP44 [ ( SA245A ) ]  
MTV512MF ( A3 VERSION ) @TQFP44 [ ( SA245A ) ]  
MTV512MV ( A1 VERSION ) @PLCC44 [ ( SA244 ) ]  
MTV512MV ( A3 VERSION ) @PLCC44 [ ( SA244 ) ]

## MYSON-CUSTOMER

### MICROCONTROLLER

MTV416GMV@PLCC44 [ (SA245) ]

**NEC****E ( E ) PROM / FRAM / NVRAM**

D2716D

uPD271000

uPD271000@PLCC32 [ (SA015A1T) ]

uPD271000@TSOP32

[ (SA410T) ]

uPD27128

uPD27128

(C)

uPD27128(D)

uPD2716

uPD27256

uPD27256

(C)

uPD27256(D)

uPD27256A

uPD27256A(C)

uPD27256A

(D)

uPD2732

uPD2732A

uPD27512

uPD27512ACT

uPD27512AD

uPD2764

uPD2764C

uPD2764D

uPD27C1000

uPD27C1000@PLCC32

[ (SA015A1T) ]

uPD27C1000@TSOP32 [ (SA410T) ]

uPD27C1000A

uPD27C1000A@PLCC32 [ (SA015A1T) ]

uPD27C1000A@TSOP32

[ (SA410T) ]

uPD27C1000AD

uPD27C1000AD@PLCC32

[ (SA015A1T) ]

uPD27C1000AD@TSOP32 [ (SA410T) ]

uPD27C1001

uPD27C1001@PLCC32 [ (SA015A1T) ]

uPD27C1001@TSOP32

[ (SA410T) ]

uPD27C1001A

uPD27C1001A@PLCC32

[ (SA015A1T) ]	
uPD27C1001A@TSOP32 [ (SA410T) ]	
uPD27C1001D	
uPD27C1001D@PLCC32 [ (SA015A1T) ]	uPD27C1001D@TSOP32
[ (SA410T) ]	
uPD27C1024	
uPD27C1024A	
uPD27C2001	
[ (SA015A1T) ]	
uPD27C2001@TSOP32 [ (SA410T) ]	
uPD27C2001D	
uPD27C2001D@PLCC32 [ (SA015A1T) ]	uPD27C2001D@TSOP32
[ (SA410T) ]	
uPD27C210	
uPD27C256	
uPD27C256A	
uPD27C400	
uPD27C4001	
[ (SA015A1T) ]	
uPD27C4001@TSOP32 [ (SA410T) ]	
uPD27C4096	
uPD27C512	
(C)	
uPD27C64(D)	
uPD27C8000	
uPD27C8001	
[ (SA015A1T) ]	
uPD27C8001@TSOP32 [ (SA410T) ]	
uPD28C04	
uPD28C04@SOIC24 [ (SA404) ]	
uPD28C05	
uPD28C05@SOIC24 [ (SA404) ]	
uPD28C256	
uPD28C64	
[ (SA404) ]	
uPD29F008CB@TSOP40 [ (SA409T) ]	
[ (SA409T) ]	
	uPD27C4001@PLCC32
	uPD27C64
	uPD27C8001@PLCC32
	uPD28C64@SOIC28
	uPD29F008CT@TSOP40

## DRAM & SRAM

PD4361B	PD4361B@SOJ24
[ (SA646) ]	

**MICROCONTROLLER**

uPD70P3000@QFP100 [(PEP+S604)]	uPD70P3002@QFP100 [(PEP
+S604)]	
uPD75P0016@SDIP42 [(SA028)]	uPD75P0016@TQFP44
[(SA245A)]	
uPD75P0076CU@SDIP42 [(SA028)]	uPD75P0076GT@SOP42
[(SA645)]	
uPD75P008CU@SDIP42 [(SA028)]	uPD75P008GB@TQFP44
[(SA245A)]	
uPD75P108CW@SDIP64 [(PEP+S600A)]	uPD75P108GF@PQFP64 [(PEP
+S618)]	
uPD75P116CW@SDIP64 [(PEP+S600A)]	uPD75P116GF@PQFP64 [(PEP
+S618)]	
uPD75P218CW@PQFP64 [(PEP+S618)]	uPD75P218CW@SDIP64 [(PEP
+S600A)]	
uPD75P3018AGC@TQFP80 [(PEP+S615B)]	
uPD75P3018AGK@TQFP80 [(PEP+S640B)]	
uPD75P3018GC@TQFP80 [(PEP+S615B)]	
uPD75P3018GK@TQFP80 [(PEP+S640B)]	
uPD75P3036GC@TQFP80 [(PEP+S615B)]	
uPD75P3036GK@TQFP80 [(PEP+S640B)]	
uPD75P308GF@PQFP80 [(PEP+S611A)]	
uPD75P316AGF@PQFP80 [(PEP+S611A)]	
uPD75P316BGC@PQFP80 [(PEP+S611A)]	
uPD75P316BGK@PQFP80 [(PEP+S611A)]	
uPD75P316GF@PQFP80 [(PEP+S611A)]	uPD75P328GC@QFP80 [(PEP
+S615B)]	
uPD75P54CS	uPD75P54G@SOP20
[(SA626A)]	
uPD75P64CS	uPD75P64G@SOP20
[(SA626A)]	
uPD78F0101HMC(A)@SSOP30 [(SA689)]	
uPD78F0101HMC(A1)@SSOP30 [(SA689)]	
uPD78F0101HMC@SSOP30 [(SA689)]	
uPD78F0102HMC(A)@SSOP30 [(SA689)]	
uPD78F0102HMC(A1)@SSOP30 [(SA689)]	
uPD78F0102HMC@SSOP30 [(SA689)]	
uPD78F0103HMC(A)@SSOP30 [(SA689)]	
uPD78F0103HMC(A1)@SSOP30 [(SA689)]	
uPD78F0103HMC@SSOP30 [(SA689)]	

uPD78F0112HGB(A)@LQFP44 [(SA245A)]  
uPD78F0112HGB(A1)@LQFP44 [(SA245A)]  
uPD78F0112HGB@LQFP44 [(SA245A)]  
uPD78F0113HGB(A)@LQFP44 [(SA245A)]  
uPD78F0113HGB(A1)@LQFP44 [(SA245A)]  
uPD78F0113HGB@LQFP44 [(SA245A)]  
uPD78F0114HDGB(A)@LQFP44 [(SA245A)]  
uPD78F0114HDGB(A1)@LQFP44 [(SA245A)]  
uPD78F0114HDGB@LQFP44 [(SA245A)]  
uPD78F0114HGB(A)@LQFP44 [(SA245A)]  
uPD78F0114HGB(A1)@LQFP44 [(SA245A)]  
uPD78F0114HGB@LQFP44 [(SA245A)]  
uPD78F0122HGB(A)@LQFP52 [(PEP+S673)]  
uPD78F0122HGB(A1)@LQFP52 [(PEP+S673)]  
uPD78F0122HGB@LQFP52 [(PEP+S673)]  
uPD78F0123HGB(A)@LQFP52 [(PEP+S673)]  
uPD78F0123HGB(A1)@LQFP52 [(PEP+S673)]  
uPD78F0123HGB@LQFP52 [(PEP+S673)]  
uPD78F0124HDGB(A)@LQFP52 [(PEP+S673)]  
uPD78F0124HDGB(A1)@LQFP52 [(PEP+S673)]  
uPD78F0124HDGB@LQFP52 [(PEP+S673)]  
uPD78F0124HGB(A)@LQFP52 [(PEP+S673)]  
uPD78F0124HGB(A1)@LQFP52 [(PEP+S673)]  
uPD78F0124HGB@LQFP52 [(PEP+S673)]  
uPD78F0132HGB(A)@LQFP64 [(PEP+S616)]  
uPD78F0132HGB(A1)@LQFP64 [(PEP+S616)]  
uPD78F0132HGB@LQFP64 [(PEP+S616)]  
uPD78F0132HGC(A)@LQFP64 [(PEP+S621)]  
uPD78F0132HGC(A1)@LQFP64 [(PEP+S621)]  
uPD78F0132HGC@LQFP64 [(PEP+S621)]  
uPD78F0132HGK(A)@LQFP64 [(PEP+S680)]  
uPD78F0132HGK(A1)@LQFP64 [(PEP+S680)]  
uPD78F0132HGK@LQFP64 [(PEP+S680)]  
uPD78F0133HGB(A)@LQFP64 [(PEP+S616)]  
uPD78F0133HGB(A1)@LQFP64 [(PEP+S616)]  
uPD78F0133HGB@LQFP64 [(PEP+S616)]  
uPD78F0133HGC(A)@LQFP64 [(PEP+S621)]  
uPD78F0133HGC(A1)@LQFP64 [(PEP+S621)]  
uPD78F0133HGC@LQFP64 [(PEP+S621)]  
uPD78F0133HGK(A)@LQFP64 [(PEP+S680)]  
uPD78F0133HGK(A1)@LQFP64 [(PEP+S680)]  
uPD78F0133HGK@LQFP64 [(PEP+S680)]  
uPD78F0134HGB(A)@LQFP64 [(PEP+S616)]



uPD78F0134HGB(A1)@LQFP64 [(PEP+S616)]  
uPD78F0134HGB@LQFP64 [(PEP+S616)]  
uPD78F0134HGC(A)@LQFP64 [(PEP+S621)]  
uPD78F0134HGC(A1)@LQFP64 [(PEP+S621)]  
uPD78F0134HGC@LQFP64 [(PEP+S621)]  
uPD78F0134HGK(A)@LQFP64 [(PEP+S680)]  
uPD78F0134HGK(A1)@LQFP64 [(PEP+S680)]  
uPD78F0134HGK@LQFP64 [(PEP+S680)]  
uPD78F0134M1GB@LQFP64 [(PEP+S616)]  
uPD78F0134M1GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0134M1GBA@LQFP64 [(PEP+S616)]  
uPD78F0134M1GBA1@LQFP64 [(PEP+S616)]  
uPD78F0134M1GC@LQFP64 [(PEP+S621)]  
uPD78F0134M1GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0134M1GCA@LQFP64 [(PEP+S621)]  
uPD78F0134M1GCA1@LQFP64 [(PEP+S621)]  
uPD78F0134M1GK@TQFP64 [(PEP+S680)]  
uPD78F0134M1GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0134M1GKA@TQFP64 [(PEP+S680)]  
uPD78F0134M1GKA1@TQFP64 [(PEP+S680)]  
uPD78F0134M2GB@LQFP64 [(PEP+S616)]  
uPD78F0134M2GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0134M2GBA1@LQFP64 [(PEP+S616)]  
uPD78F0134M2GC@LQFP64 [(PEP+S621)]  
uPD78F0134M2GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0134M2GCA@LQFP64 [(PEP+S621)]  
uPD78F0134M2GCA1@LQFP64 [(PEP+S621)]  
uPD78F0134M2GK@TQFP64 [(PEP+S680)]  
uPD78F0134M2GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0134M2GKA@TQFP64 [(PEP+S680)]  
uPD78F0134M2GKA1@TQFP64 [(PEP+S680)]  
uPD78F0134M3GB@LQFP64 [(PEP+S616)]  
uPD78F0134M3GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0134M3GBA@LQFP64 [(PEP+S616)]  
uPD78F0134M3GBA1@LQFP64 [(PEP+S616)]  
uPD78F0134M3GC@LQFP64 [(PEP+S621)]  
uPD78F0134M3GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0134M3GCA@LQFP64 [(PEP+S621)]  
uPD78F0134M3GCA1@LQFP64 [(PEP+S621)]  
uPD78F0134M3GK@TQFP64 [(PEP+S680)]  
uPD78F0134M3GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0134M3GKA@TQFP64 [(PEP+S680)]  
uPD78F0134M3GKA1@TQFP64 [(PEP+S680)]

uPD78F0134M4GB@LQFP64 [(PEP+S616)]  
uPD78F0134M4GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0134M4GBA@LQFP64 [(PEP+S616)]  
uPD78F0134M4GBA1@LQFP64 [(PEP+S616)]  
uPD78F0134M4GC@LQFP64 [(PEP+S621)]  
uPD78F0134M4GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0134M4GCA@LQFP64 [(PEP+S621)]  
uPD78F0134M4GCA1@LQFP64 [(PEP+S621)]  
uPD78F0134M4GK@TQFP64 [(PEP+S680)]  
uPD78F0134M4GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0134M4GKA@TQFP64 [(PEP+S680)]  
uPD78F0134M4GKA1@TQFP64 [(PEP+S680)]  
uPD78F0134M5GB@LQFP64 [(PEP+S616)]  
uPD78F0134M5GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0134M5GBA@LQFP64 [(PEP+S616)]  
uPD78F0134M5GBA1@LQFP64 [(PEP+S616)]  
uPD78F0134M5GC@LQFP64 [(PEP+S621)]  
uPD78F0134M5GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0134M5GCA@LQFP64 [(PEP+S621)]  
uPD78F0134M5GCA1@LQFP64 [(PEP+S621)]  
uPD78F0134M5GK@TQFP64 [(PEP+S680)]  
uPD78F0134M5GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0134M5GKA@TQFP64 [(PEP+S680)]  
uPD78F0134M5GKA1@TQFP64 [(PEP+S680)]  
uPD78F0134M6GB@LQFP64 [(PEP+S616)]  
uPD78F0134M6GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0134M6GBA@LQFP64 [(PEP+S616)]  
uPD78F0134M6GBA1@LQFP64 [(PEP+S616)]  
uPD78F0134M6GC@LQFP64 [(PEP+S621)]  
uPD78F0134M6GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0134M6GCA@LQFP64 [(PEP+S621)]  
uPD78F0134M6GCA1@LQFP64 [(PEP+S621)]  
uPD78F0134M6GK@TQFP64 [(PEP+S680)]  
uPD78F0134M6GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0134M6GKA@TQFP64 [(PEP+S680)]  
uPD78F0134M6GKA1@TQFP64 [(PEP+S680)]  
uPD78F0136HGB(A)@LQFP64 [(PEP+S616)]  
uPD78F0136HGB(A1)@LQFP64 [(PEP+S616)]  
uPD78F0136HGB@LQFP64 [(PEP+S616)]  
uPD78F0136HGC(A)@LQFP64 [(PEP+S621)]  
uPD78F0136HGC(A1)@LQFP64 [(PEP+S621)]  
uPD78F0136HGC@LQFP64 [(PEP+S621)]  
uPD78F0136HGK(A)@LQFP64 [(PEP+S680)]

uPD78F0136HGK(A1)@LQFP64 [(PEP+S680)]  
uPD78F0136HGK@LQFP64 [(PEP+S680)]  
uPD78F0138HDGB(A)@LQFP64 [(PEP+S616)]  
uPD78F0138HDGB(A1)@LQFP64 [(PEP+S616)]  
uPD78F0138HDGB@LQFP64 [(PEP+S616)]  
uPD78F0138HDGC(A)@LQFP64 [(PEP+S621)]  
uPD78F0138HDGC(A1)@LQFP64 [(PEP+S621)]  
uPD78F0138HDGC@LQFP64 [(PEP+S621)]  
uPD78F0138HDGK(A)@LQFP64 [(PEP+S680)]  
uPD78F0138HDGK(A1)@LQFP64 [(PEP+S680)]  
uPD78F0138HDGK@LQFP64 [(PEP+S680)]  
uPD78F0138HGB(A)@LQFP64 [(PEP+S616)]  
uPD78F0138HGB(A1)@LQFP64 [(PEP+S616)]  
uPD78F0138HGB@LQFP64 [(PEP+S616)]  
uPD78F0138HGC(A)@LQFP64 [(PEP+S621)]  
uPD78F0138HGC(A1)@LQFP64 [(PEP+S621)]  
uPD78F0138HGC@LQFP64 [(PEP+S621)]  
uPD78F0138HGK(A)@LQFP64 [(PEP+S680)]  
uPD78F0138HGK(A1)@LQFP64 [(PEP+S680)]  
uPD78F0138HGK@LQFP64 [(PEP+S680)]  
uPD78F0138M1GB@LQFP64 [(PEP+S616)]  
uPD78F0138M1GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0138M1GBA@LQFP64 [(PEP+S616)]  
uPD78F0138M1GBA1@LQFP64 [(PEP+S616)]  
uPD78F0138M1GC@LQFP64 [(PEP+S621)]  
uPD78F0138M1GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0138M1GCA@LQFP64 [(PEP+S621)]  
uPD78F0138M1GCA1@LQFP64 [(PEP+S621)]  
uPD78F0138M1GK@TQFP64 [(PEP+S680)]  
uPD78F0138M1GK@TQFP64(\*) [(SA739+B222)]  
uPD78F0138M1GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0138M1GKA@TQFP64 [(PEP+S680)]  
uPD78F0138M1GKA1@TQFP64 [(PEP+S680)]  
uPD78F0138M2GB@LQFP64 [(PEP+S616)]  
uPD78F0138M2GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0138M2GBA@LQFP64 [(PEP+S616)]  
uPD78F0138M2GBA1@LQFP64 [(PEP+S616)]  
uPD78F0138M2GC@LQFP64 [(PEP+S621)]  
uPD78F0138M2GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0138M2GCA@LQFP64 [(PEP+S621)]  
uPD78F0138M2GCA1@LQFP64 [(PEP+S621)]  
uPD78F0138M2GK@TQFP64 [(PEP+S680)]  
uPD78F0138M2GK@TQFP64(\*) [(SA739+B222)]

uPD78F0138M2GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0138M2GKA@TQFP64 [(PEP+S680)]  
uPD78F0138M2GKA1@TQFP64 [(PEP+S680)]  
uPD78F0138M3GB@LQFP64 [(PEP+S616)]  
uPD78F0138M3GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0138M3GBA@LQFP64 [(PEP+S616)]  
uPD78F0138M3GBA1@LQFP64 [(PEP+S616)]  
uPD78F0138M3GC@LQFP64 [(PEP+S621)]  
uPD78F0138M3GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0138M3GCA@LQFP64 [(PEP+S621)]  
uPD78F0138M3GCA1@LQFP64 [(PEP+S621)]  
uPD78F0138M3GK@TQFP64 [(PEP+S680)]  
uPD78F0138M3GK@TQFP64(\*) [(SA739+B222)]  
uPD78F0138M3GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0138M3GKA@TQFP64 [(PEP+S680)]  
uPD78F0138M3GKA1@TQFP64 [(PEP+S680)]  
uPD78F0138M4GB@LQFP64 [(PEP+S616)]  
uPD78F0138M4GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0138M4GBA@LQFP64 [(PEP+S616)]  
uPD78F0138M4GBA1@LQFP64 [(PEP+S616)]  
uPD78F0138M4GC@LQFP64 [(PEP+S621)]  
uPD78F0138M4GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0138M4GCA@LQFP64 [(PEP+S621)]  
uPD78F0138M4GCA1@LQFP64 [(PEP+S621)]  
uPD78F0138M4GK@TQFP64 [(PEP+S680)]  
uPD78F0138M4GK@TQFP64(\*) [(SA739+B222)]  
uPD78F0138M4GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0138M4GKA@TQFP64 [(PEP+S680)]  
uPD78F0138M4GKA1@TQFP64 [(PEP+S680)]  
uPD78F0138M5GB@LQFP64 [(PEP+S616)]  
uPD78F0138M5GB\_A@LQFP64 [(PEP+S616)]  
uPD78F0138M5GBA@LQFP64 [(PEP+S616)]  
uPD78F0138M5GBA1@LQFP64 [(PEP+S616)]  
uPD78F0138M5GC@LQFP64 [(PEP+S621)]  
uPD78F0138M5GC\_A@LQFP64 [(PEP+S621)]  
uPD78F0138M5GCA@LQFP64 [(PEP+S621)]  
uPD78F0138M5GCA1@LQFP64 [(PEP+S621)]  
uPD78F0138M5GK@TQFP64 [(PEP+S680)]  
uPD78F0138M5GK@TQFP64(\*) [(SA739+B222)]  
uPD78F0138M5GK\_A@TQFP64 [(PEP+S680)]  
uPD78F0138M5GKA@TQFP64 [(PEP+S680)]  
uPD78F0138M5GKA1@TQFP64 [(PEP+S680)]  
uPD78F0138M6GB@LQFP64 [(PEP+S616)]

uPD78F0138M6GB\_A@LQFP64 [(PEP+S616)]  
 uPD78F0138M6GBA@LQFP64 [(PEP+S616)]  
 uPD78F0138M6GBA1@LQFP64 [(PEP+S616)]  
 uPD78F0138M6GC@LQFP64 [(PEP+S621)]  
 uPD78F0138M6GC\_A@LQFP64 [(PEP+S621)]  
 uPD78F0138M6GCA@LQFP64 [(PEP+S621)]  
 uPD78F0138M6GCA1@LQFP64 [(PEP+S621)]  
 uPD78F0138M6GK@TQFP64 [(PEP+S680)]  
 uPD78F0138M6GK@TQFP64(\*) [(SA739+B222)]  
 uPD78F0138M6GK\_A@TQFP64 [(PEP+S680)]  
 uPD78F0138M6GKA@TQFP64 [(PEP+S680)]  
 uPD78F0138M6GKA1@TQFP64 [(PEP+S680)]  
 uPD78F013M2GBA@LQFP64 [(PEP+S616)]  
 uPD78F0500FC@FLGA36 [(4X4BGA)] uPD78F0500MC(A)@SSOP30  
 [(SA689)]  
 uPD78F0500MC@SSOP30 [(SA689)] uPD78F0501FC@FLGA36  
 [(4X4BGA)]  
 uPD78F0501MC(A)@SSOP30 [(SA689)] uPD78F0501MC@SSOP30  
 [(SA689)]  
 uPD78F0502FC@FLGA36 [(4X4BGA)] uPD78F0502MC(A)@SSOP30  
 [(SA689)]  
 uPD78F0502MC@SSOP30 [(SA689)] uPD78F0503DFC@FLGA36  
 [(4X4BGA)]  
 uPD78F0503DMC(A)@SSOP30 [(SA689)]  
 uPD78F0503DMC@SSOP30 [(SA689)] uPD78F0503FC@FLGA36  
 [(4X4BGA)]  
 uPD78F0503MC(A)@SSOP30 [(SA689)] uPD78F0503MC@SSOP30  
 [(SA689)]  
 uPD78F0511GA(A)@TQFP48 [(SA248)]  
 uPD78F0511GA(A2)@TQFP48 [(SA248)]  
 uPD78F0511GA@TQFP48 [(SA248)]  
 uPD78F0511GB(A)@TQFP44 [(SA245A)]  
 uPD78F0511GB(A2)@TQFP44 [(SA245A)]  
 uPD78F0511GB@TQFP44 [(SA245A)] uPD78F0511MC@SSOP38  
 [(SA689)]  
 uPD78F0512GA(A)@TQFP48 [(SA248)]  
 uPD78F0512GA(A2)@TQFP48 [(SA248)]  
 uPD78F0512GA@TQFP48 [(SA248)]  
 uPD78F0512GB(A)@TQFP44 [(SA245A)]  
 uPD78F0512GB(A2)@TQFP44 [(SA245A)]  
 uPD78F0512GB@TQFP44 [(SA245A)] uPD78F0512MC@SSOP38  
 [(SA689)]  
 uPD78F0513DGA(A)@TQFP48 [(SA248)]

uPD78F0513DGA(A2)@TQFP48 [(SA248)]  
uPD78F0513DGA@TQFP48 [(SA248)]  
uPD78F0513DGB(A)@TQFP44 [(SA245A)]  
uPD78F0513DGB(A2)@TQFP44 [(SA245A)]  
uPD78F0513DGB@TQFP44 [(SA245A)] uPD78F0513DMC@SSOP38  
[(SA689)]  
uPD78F0513GA(A)@TQFP48 [(SA248)]  
uPD78F0513GA(A2)@TQFP48 [(SA248)]  
uPD78F0513GA@TQFP48 [(SA248)]  
uPD78F0513GB(A)@TQFP44 [(SA245A)]  
uPD78F0513GB(A2)@TQFP44 [(SA245A)]  
uPD78F0513GB@TQFP44 [(SA245A)] uPD78F0513MC@SSOP38  
[(SA689)]  
uPD78F0514GA(A)@TQFP48 [(SA248)]  
uPD78F0514GA(A2)@TQFP48 [(SA248)]  
uPD78F0514GA@TQFP48 [(SA248)]  
uPD78F0514GB(A)@TQFP44 [(SA245A)]  
uPD78F0514GB(A2)@TQFP44 [(SA245A)]  
uPD78F0514GB@TQFP44 [(SA245A)] uPD78F0514MC@SSOP38  
[(SA689)]  
uPD78F0515GA(A)@TQFP48 [(SA248)]  
uPD78F0515GA(A2)@TQFP48 [(SA248)]  
uPD78F0515GA@TQFP48 [(SA248)]  
uPD78F0515GB(A)@TQFP44 [(SA245A)]  
uPD78F0515GB(A2)@TQFP44 [(SA245A)]  
uPD78F0515GB@TQFP44 [(SA245A)] uPD78F0515MC@SSOP38  
[(SA689)]  
uPD78F0521GB(A)@LQFP52 [(PEP+S673)]  
uPD78F0521GB(A2)@LQFP52 [(PEP+S673)]  
uPD78F0521GB@LQFP52 [(PEP+S673)]  
uPD78F0522GB(A)@LQFP52 [(PEP+S673)]  
uPD78F0522GB(A2)@LQFP52 [(PEP+S673)]  
uPD78F0522GB@LQFP52 [(PEP+S673)]  
uPD78F0523DGB(A)@LQFP52 [(PEP+S673)]  
uPD78F0523DGB(A2)@LQFP52 [(PEP+S673)]  
uPD78F0523DGB@LQFP52 [(PEP+S673)]  
uPD78F0523GB(A)@LQFP52 [(PEP+S673)]  
uPD78F0523GB(A2)@LQFP52 [(PEP+S673)]  
uPD78F0523GB@LQFP52 [(PEP+S673)]  
uPD78F0524GB(A)@LQFP52 [(PEP+S673)]  
uPD78F0524GB(A2)@LQFP52 [(PEP+S673)]  
uPD78F0524GB@LQFP52 [(PEP+S673)]  
uPD78F0525GB(A)@LQFP52 [(PEP+S673)]

uPD78F0525GB(A2)@LQFP52 [(PEP+S673)]  
uPD78F0525GB@LQFP52 [(PEP+S673)]  
uPD78F0526GB(A)@LQFP52 [(PEP+S673)]  
uPD78F0526GB(A2)@LQFP52 [(PEP+S673)]  
uPD78F0526GB@LQFP52 [(PEP+S673)]  
uPD78F0527GB(A)@LQFP52 [(PEP+S673)]  
uPD78F0527GB(A2)@LQFP52 [(PEP+S673)]  
uPD78F0527GB@LQFP52 [(PEP+S673)]  
uPD78F0531GB(A)@LQFP64 [(PEP+S616)]  
uPD78F0531GB(A2)@LQFP64 [(PEP+S616)]  
uPD78F0531GB@LQFP64 [(PEP+S616)]  
uPD78F0531GC(A)@LQFP64 [(PEP+S621)]  
uPD78F0531GC(A2)@LQFP64 [(PEP+S621)]  
uPD78F0531GC@LQFP64 [(PEP+S621)]  
uPD78F0531GK(A)@LQFP64 [(PEP+S680)]  
uPD78F0531GK(A2)@LQFP64 [(PEP+S680)]  
uPD78F0531GK@LQFP64 [(PEP+S680)]  
uPD78F0532GB(A)@LQFP64 [(PEP+S616)]  
uPD78F0532GB(A2)@LQFP64 [(PEP+S616)]  
uPD78F0532GB@LQFP64 [(PEP+S616)]  
uPD78F0532GC(A)@LQFP64 [(PEP+S621)]  
uPD78F0532GC(A2)@LQFP64 [(PEP+S621)]  
uPD78F0532GC@LQFP64 [(PEP+S621)]  
uPD78F0532GK(A)@LQFP64 [(PEP+S680)]  
uPD78F0532GK(A2)@LQFP64 [(PEP+S680)]  
uPD78F0532GK@LQFP64 [(PEP+S680)]  
uPD78F0533DGB(A)@LQFP64 [(PEP+S616)]  
uPD78F0533DGB(A2)@LQFP64 [(PEP+S616)]  
uPD78F0533DGB@LQFP64 [(PEP+S616)]  
uPD78F0533DGC(A)@LQFP64 [(PEP+S621)]  
uPD78F0533DGC(A2)@LQFP64 [(PEP+S621)]  
uPD78F0533DGC@LQFP64 [(PEP+S621)]  
uPD78F0533DGK(A)@LQFP64 [(PEP+S680)]  
uPD78F0533DGK(A2)@LQFP64 [(PEP+S680)]  
uPD78F0533DGK@LQFP64 [(PEP+S680)]  
uPD78F0533GB(A)@LQFP64 [(PEP+S616)]  
uPD78F0533GB(A2)@LQFP64 [(PEP+S616)]  
uPD78F0533GB@LQFP64 [(PEP+S616)]  
uPD78F0533GC(A)@LQFP64 [(PEP+S621)]  
uPD78F0533GC(A2)@LQFP64 [(PEP+S621)]  
uPD78F0533GC@LQFP64 [(PEP+S621)]  
uPD78F0533GK(A)@LQFP64 [(PEP+S680)]  
uPD78F0533GK(A2)@LQFP64 [(PEP+S680)]

uPD78F0533GK@LQFP64 [(PEP+S680)]  
uPD78F0534GB(A)@LQFP64 [(PEP+S616)]  
uPD78F0534GB(A2)@LQFP64 [(PEP+S616)]  
uPD78F0534GB@LQFP64 [(PEP+S616)]  
uPD78F0534GC(A)@LQFP64 [(PEP+S621)]  
uPD78F0534GC(A2)@LQFP64 [(PEP+S621)]  
uPD78F0534GC@LQFP64 [(PEP+S621)]  
uPD78F0534GK(A)@LQFP64 [(PEP+S680)]  
uPD78F0534GK(A2)@LQFP64 [(PEP+S680)]  
uPD78F0534GK@LQFP64 [(PEP+S680)]  
uPD78F0535GB(A)@LQFP64 [(PEP+S616)]  
uPD78F0535GB(A2)@LQFP64 [(PEP+S616)]  
uPD78F0535GB@LQFP64 [(PEP+S616)]  
uPD78F0535GC(A)@LQFP64 [(PEP+S621)]  
uPD78F0535GC(A2)@LQFP64 [(PEP+S621)]  
uPD78F0535GC@LQFP64 [(PEP+S621)]  
uPD78F0535GK(A)@LQFP64 [(PEP+S680)]  
uPD78F0535GK(A2)@LQFP64 [(PEP+S680)]  
uPD78F0535GK@LQFP64 [(PEP+S680)]  
uPD78F0536GB(A)@LQFP64 [(PEP+S616)]  
uPD78F0536GB(A2)@LQFP64 [(PEP+S616)]  
uPD78F0536GB@LQFP64 [(PEP+S616)]  
uPD78F0536GC(A)@LQFP64 [(PEP+S621)]  
uPD78F0536GC(A2)@LQFP64 [(PEP+S621)]  
uPD78F0536GC@LQFP64 [(PEP+S621)]  
uPD78F0536GK(A)@LQFP64 [(PEP+S680)]  
uPD78F0536GK(A2)@LQFP64 [(PEP+S680)]  
uPD78F0536GK@LQFP64 [(PEP+S680)]  
uPD78F0537DGB(A)@LQFP64 [(PEP+S616)]  
uPD78F0537DGB(A2)@LQFP64 [(PEP+S616)]  
uPD78F0537DGB@LQFP64 [(PEP+S616)]  
uPD78F0537DGC(A)@LQFP64 [(PEP+S621)]  
uPD78F0537DGC(A2)@LQFP64 [(PEP+S621)]  
uPD78F0537DGC@LQFP64 [(PEP+S621)]  
uPD78F0537DGK(A)@LQFP64 [(PEP+S680)]  
uPD78F0537DGK(A2)@LQFP64 [(PEP+S680)]  
uPD78F0537DGK@LQFP64 [(PEP+S680)]  
uPD78F0537GB(A)@LQFP64 [(PEP+S616)]  
uPD78F0537GB(A2)@LQFP64 [(PEP+S616)]  
uPD78F0537GB@LQFP64 [(PEP+S616)]  
uPD78F0537GC(A)@LQFP64 [(PEP+S621)]  
uPD78F0537GC(A2)@LQFP64 [(PEP+S621)]  
uPD78F0537GC@LQFP64 [(PEP+S621)]



uPD78F0537GK(A)@LQFP64 [(PEP+S680)]  
uPD78F0537GK(A2)@LQFP64 [(PEP+S680)]  
uPD78F0537GK@LQFP64 [(PEP+S680)]  
uPD78F0544GC(A)@LQFP80 [(PEP+S704)]  
uPD78F0544GC(A2)@LQFP80 [(PEP+S704)]  
uPD78F0544GC@LQFP80 [(PEP+S704)]  
uPD78F0544GK(A)@LQFP80 [(PEP+S640B)]  
uPD78F0544GK(A2)@LQFP80 [(PEP+S640B)]  
uPD78F0544GK@LQFP80 [(PEP+S640B)]  
uPD78F0545GC(A)@LQFP80 [(PEP+S704)]  
uPD78F0545GC(A2)@LQFP80 [(PEP+S704)]  
uPD78F0545GC@LQFP80 [(PEP+S704)]  
uPD78F0545GK(A)@LQFP80 [(PEP+S640B)]  
uPD78F0545GK(A2)@LQFP80 [(PEP+S640B)]  
uPD78F0545GK@LQFP80 [(PEP+S640B)]  
uPD78F0546GC(A)@LQFP80 [(PEP+S640B)]  
uPD78F0546GC(A)@LQFP80(\*) [(SA722+B219)]  
uPD78F0546GC@LQFP80 [(PEP+S640B)]  
uPD78F0546GC@LQFP80(\*) [(SA722+B219)]  
uPD78F0546GK(A)@LQFP80 [(PEP+S640B)]  
uPD78F0546GK(A)@LQFP80(\*) [(SA731+B219)]  
uPD78F0546GK(A2)@LQFP80 [(PEP+S640B)]  
uPD78F0546GK@LQFP80 [(PEP+S640B)]  
uPD78F0546GK@LQFP80(\*) [(SA731+B219)]  
uPD78F0547DGC(A)@LQFP80 [(PEP+S704)]  
uPD78F0547DGC(A2)@LQFP80 [(PEP+S704)]  
uPD78F0547DGC@LQFP80 [(PEP+S704)]  
uPD78F0547DGK(A)@LQFP80 [(PEP+S640B)]  
uPD78F0547DGK(A2)@LQFP80 [(PEP+S640B)]  
uPD78F0547DGK@LQFP80 [(PEP+S640B)]  
uPD78F0547GC(A)@LQFP80 [(PEP+S704)]  
uPD78F0547GC(A2)@LQFP80 [(PEP+S704)]  
uPD78F0547GC@LQFP80 [(PEP+S704)]  
uPD78F0547GK(A)@LQFP80 [(PEP+S640B)]  
uPD78F0547GK(A2)@LQFP80 [(PEP+S640B)]  
uPD78F0547GK@LQFP80 [(PEP+S640B)]  
uPD78F0822B(A)@LQFP100 [(PEP+S604)]  
uPD78F0822B(A)@LQFP100(\*) [(SA718+B221)]  
uPD78F0822B@LQFP100 [(PEP+S604)]  
uPD78F0822B@LQFP100(\*) [(SA718+B221)]  
uPD78F9026@SDIP42 [(SA028)] uPD78F9026@TQFP44  
[(SA245A)]  
uPD78F9026A@SDIP42 [(SA028)] uPD78F9026A@TQFP44

[ (SA245A) ]  
uPD78F9026B@SDIP42 [ (SA028) ] uPD78F9026B@TQFP44  
[ (SA245A) ]  
uPD78F9046@SDIP42 [ (SA028) ] uPD78F9046@TQFP44  
[ (SA245A) ]  
uPD78F9046A@SDIP42 [ (SA028) ] uPD78F9046A@TQFP44  
[ (SA245A) ]  
uPD78F9046B@SDIP42 [ (SA028) ] uPD78F9046B@TQFP44  
[ (SA245A) ]  
uPD78F9076@SSOP30 [ (SA689) ] uPD78F9076A@SSOP30  
[ (SA689) ]  
uPD78F9076AMC@SSOP30 [ (SA689) ] uPD78F9076MC@SSOP30  
[ (SA689) ]  
uPD78P054FGC@QFP80 [ (PEP+S615B) ]  
uPD78P054FGC@QFP80(\*) [ (SA722+B328) ]  
uPD78P054FGK@TQFP80 [ (PEP+S640B) ]  
uPD78P054FGK@TQFP80(\*) [ (SA731+B218) ]  
uPD78P054GC@QFP80 [ (PEP+S615B) ]  
uPD78P054GC@QFP80(\*) [ (SA722+B328) ]  
uPD78P054GK@TQFP80 [ (PEP+S640B) ]  
uPD78P054GK@TQFP80(\*) [ (SA731+B218) ]  
uPD78P054YGC@QFP80 [ (PEP+S615B) ]  
uPD78P054YGC@QFP80(\*) [ (SA722+B328) ]  
uPD78P054YGK@TQFP80 [ (PEP+S640B) ]  
uPD78P054YGK@TQFP80(\*) [ (SA731+B218) ]  
uPD78P058FGC@QFP80 [ (PEP+S615B) ]  
uPD78P058FGC@QFP80(\*) [ (SA722+B328) ]  
uPD78P058FGK@TQFP80 [ (PEP+S640B) ]  
uPD78P058FGK@TQFP80(\*) [ (SA731+B218) ]  
uPD78P058GC@QFP80 [ (PEP+S615B) ]  
uPD78P058GC@QFP80(\*) [ (SA722+B328) ]  
uPD78P058GK@TQFP80 [ (PEP+S640B) ]  
uPD78P058GK@TQFP80(\*) [ (SA731+B218) ]  
uPD78P058YGC@QFP80 [ (PEP+S615B) ]  
uPD78P058YGC@QFP80(\*) [ (SA722+B328) ]  
uPD78P058YGK@TQFP80 [ (PEP+S640B) ]  
uPD78P058YGK@TQFP80(\*) [ (SA731+B218) ]  
uPD78P083@SDIP42 [ (SA028) ] uPD78P083@TQFP44  
[ (SA245A) ]  
uPD78P083A@SDIP42 [ (SA028) ] uPD78P083A@TQFP44  
[ (SA245A) ]  
uPD78P4038GC@QFP80 [ (PEP+S615B) ]  
uPD78P4038GC-A@QFP80 [ (PEP+S615B) ]

uPD78P4038GK@TQFP80 [(PEP+S640B)]  
uPD78P4038GK-A@TQFP80 [(PEP+S640B)]  
uPD78P9014CT@SDIP28 [(SA022A)] uPD78P9014GT@SOIC28  
[(SA404)]  
uPD8741A  
uPD8748  
uPD8748H  
uPD8748HD  
uPD8749H

## NEXFLASH

### E(E) PROM/FRAM/NVRAM

NX25B40(Bottom Boot)@MLP8 [(SA683)]  
NX25B40(Bottom Boot)@SOIC8 [(SA602A)]  
NX25B40(Top Boot)@MLP8 [(SA683)]  
NX25B40(Top Boot)@SOIC8 [(SA602A)]  
NX25P10@MLP8 [(SA683)] NX25P10@SOIC8  
[(SA602A)]  
NX25P16@MLP8 [(SA683)] NX25P16@MLP8(ISP) [ISP-  
HEADER01]  
NX25P16@SOIC16 [(SA404)]  
NX25P16@SOIC16(ISP) [ISP-HEADER01]  
NX25P16@SOIC8 [(SA023A)]  
NX25P16@SOIC8(ISP) [ISP-HEADER01]  
NX25P20@MLP8 [(SA683)] NX25P20@SOIC8  
[(SA602A)]  
NX25P32@MLP8 [(SA683)] NX25P32@MLP8(ISP) [ISP-  
HEADER01]  
NX25P32@SOIC16 [(SA404)]  
NX25P32@SOIC16(ISP) [ISP-HEADER01]  
NX25P40@MLP8 [(SA683)] NX25P40@SOIC8  
[(SA602A)]  
NX25P64@MLP8 [(SA683)] NX25P64@MLP8(ISP) [ISP-  
HEADER01]  
NX25P64@SOIC16 [(SA404)]  
NX25P64@SOIC16(ISP) [ISP-HEADER01]  
NX25P80@MLP8 [(SA683)] NX25P80@SOIC8  
[(SA602A)]  
NX29F010 NX29F010@PLCC32  
[(SA015A1T)]

NX29F010@TSOP32 [(SA410T)]

## NJRC

### E (E) PROM/FRAM/NVRAM

NJU26040V  
[(SA626A)]

NJU26040V@SSOP32

## NOVATEK

### MICROCONTROLLER

NT68F631@PLCC44 [(SA244)]  
[(SA028)]

NT68F631@SDIP42

NT68F631ALG@PLCC44 [(SA244)]  
[(SA028)]

NT68F631AUG@SDIP42

NT68F631L@PLCC44 [(SA244)]  
[(SA244)]

NT68F631LG@PLCC44

NT68F631U@SDIP42 [(SA028)]  
[(SA028)]

NT68F631UG@SDIP42

NT68F632@PLCC44 [(SA244)]  
[(SA028)]

NT68F632@SDIP42

NT68F632ALG@PLCC44 [(SA244)]  
[(SA028)]

NT68F632AUG@SDIP42

NT68F632L@PLCC44 [(SA244)]  
[(SA244)]

NT68F632LG@PLCC44

NT68F632U@SDIP42 [(SA028)]  
[(SA028)]

NT68F632UG@SDIP42

NT68F633@PLCC44 [(SA244)]  
[(SA028)]

NT68F633@SDIP42

NT68F633L@PLCC44 [(SA244)]  
[(SA244)]

NT68F633LG@PLCC44

NT68F633U@SDIP42 [(SA028)]  
[(SA028)]

NT68F633UG@SDIP42

NT68F636@PLCC44 [(SA244)]  
[(SA028)]

NT68F636@SDIP42

NT68F636L@PLCC44 [(SA244)]  
[(SA244)]

NT68F636LG@PLCC44

NT68F636U@SDIP42 [(SA028)]

NT68F636UG@SDIP42

[ (SA028) ]	
NT68F63L(0444)@PLCC44 [ (SA244) ]	NT68F63L(0444)@SDIP42
[ (SA028) ]	
NT68F63L(0448)@PLCC44 [ (SA244) ]	NT68F63L(0448)@SDIP42
[ (SA028) ]	
NT68F63L(0523)@PLCC44 [ (SA244) ]	NT68F63L(0523)@SDIP42
[ (SA028) ]	
NT68F63L@PLCC44 [ (SA244) ]	NT68F63LA@PLCC44
[ (SA244) ]	
NT68F63LG@PLCC44 [ (SA244) ]	NT68F63LGG@PLCC44
[ (SA244) ]	
NT68F63U@SDIP42 [ (SA028) ]	NT68F63UA@SDIP42
[ (SA028) ]	
NT68F63UG@SDIP42 [ (SA028) ]	NT68F63UGG@SDIP42
[ (SA028) ]	

## NSC

### E (E) PROM/FRAM/NVRAM

2864	
MM2716	
MM2716E	
NM24C02	
NM24C02@SOIC8 [ (SA602A) ]	NM24C02@TSOP8
[ (SA026) ]	
NM24C02L	NM24C02L@SOIC8
[ (SA602A) ]	
NM24C02L@TSOP8 [ (SA026) ]	
NM24C03	
NM24C03@SOIC8 [ (SA602A) ]	NM24C03@TSOP8
[ (SA026) ]	
NM24C04	NM24C04@SOIC8
[ (SA602A) ]	
NM24C04@TSOP8 [ (SA026) ]	
NM24C05	
NM24C05@SOIC8 [ (SA602A) ]	NM24C05@TSOP8
[ (SA026) ]	
NM24C08	NM24C08@SOIC8
[ (SA602A) ]	
NM24C09	NM24C09@SOIC8
[ (SA602A) ]	

NM24C16	NM24C16@SOIC8
[ (SA602A) ]	
NM24C17	NM24C17@SOIC8
[ (SA602A) ]	
NM25C04	NM25C04@SOIC16
[ (SA602) ]	
NM25C04@SOIC8 [ (SA602A) ]	NM25C04@TSSOP14
[ (SA026) ]	
NM25C04@TSSOP8 [ (SA026) ]	
NM27C010	
NM27C010@PLCC32 [ (SA015A1T) ]	NM27C010@TSOP32
[ (SA410T) ]	
NM27C010Q	NM27C010Q@PLCC32
[ (SA015A1T) ]	
NM27C010Q@TSOP32 [ (SA410T) ]	
NM27C020	
NM27C020@PLCC32 [ (SA015A1T) ]	NM27C020@TSOP32
[ (SA410T) ]	
NM27C020Q	NM27C020Q@PLCC32
[ (SA015A1T) ]	
NM27C020Q@TSOP32 [ (SA410T) ]	
NM27C040	
NM27C040@PLCC32 [ (SA015A1T) ]	NM27C040@TSOP32
[ (SA410T) ]	
NM27C1023	
NM27C128	
NM27C128@PLCC32 [ (SA015A1T) ]	
NM27C210	
NM27C210@PLCC44 [ (SA244) ]	
NM27C210Q	
NM27C210Q@PLCC44 [ (SA244) ]	
NM27C240	
NM27C240@PLCC44 [ (SA244) ]	
NM27C256	
NM27C256@PLCC32 [ (SA015A1T) ]	
NM27C400	
NM27C512	NM27C512@PLCC32
[ (SA015A1T) ]	
NM27C512Q	NM27C512Q@PLCC32
[ (SA015A1T) ]	
NM27C64Q	NM27C64Q@PLCC32
[ (SA015A1T) ]	
NM27CP256	NM27CP256@PLCC32

[ (SA015A1T) ]	
NM27LC010	NM27LC010@PLCC32
[ (SA015A1T) ]	
NM27LC010@TSOP32 [ (SA410T) ]	
NM27LC256	
NM27LC256@PLCC32 [ (SA015A1T) ]	
NM27LC512	
NM27LC512@PLCC32 [ (SA015A1T) ]	
NM27LC64	
NM27LC64@PLCC32 [ (SA015A1T) ]	
NM27LV010	
NM27LV010@PLCC32 [ (SA015A1T) ]	NM27LV010@TSOP32
[ (SA410T) ]	
NM27LV210	NM27LV210@PLCC44
[ (SA244) ]	
NM27LV512	NM27LV512@PLCC32
[ (SA015A1T) ]	
NM27LV512@TSOP32 [ (SA410T) ]	
NM27P040	
NM27P040@PLCC32 [ (SA015A1T) ]	NM27P040@TSOP32
[ (SA410T) ]	
NM27P210	NM27P210@PLCC44
[ (SA244) ]	
NM27P512	NM27P512@PLCC32
[ (SA015A1T) ]	
NM59C11	NM59C11@SOIC8
[ (SA602A) ]	
NM93C06(08bit)	NM93C06(08bit)@SOIC8
[ (SA602A) ]	
NM93C06(16bit)	NM93C06(16bit)@SOIC8
[ (SA602A) ]	
NM93C46	NM93C46@SOIC8
[ (SA602A) ]	
NM93C46A(08bit)	NM93C46A(08bit)@SOIC8
[ (SA602A) ]	
NM93C46A(16bit)	NM93C46A(16bit)@SOIC8
[ (SA602A) ]	
NM93C46AL(08bit)	
NM93C46AL(08bit)@SOIC8 [ (SA602A) ]	
NM93C46AL(16bit)	
NM93C46AL(16bit)@SOIC8 [ (SA602A) ]	
NM93C46ALZ(08bit)	
NM93C46ALZ(08bit)@SOIC8 [ (SA602A) ]	

NM93C46ALZ(16bit)	
NM93C46ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C46L	NM93C46L@SOIC8
[(SA602A)]	
NM93C46LZ	NM93C46LZ@SOIC8
[(SA602A)]	
NM93C56	NM93C56@SOIC8
[(SA602A)]	
NM93C56A(08bit)	NM93C56A(08bit)@SOIC8
[(SA602A)]	
NM93C56A(16bit)	NM93C56A(16bit)@SOIC8
[(SA602A)]	
NM93C56AL(08bit)	
NM93C56AL(08bit)@SOIC8 [(SA602A)]	
NM93C56AL(16bit)	
NM93C56AL(16bit)@SOIC8 [(SA602A)]	
NM93C56ALZ(08bit)	
NM93C56ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C56ALZ(16bit)	
NM93C56ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C56L	NM93C56L@SOIC8
[(SA602A)]	
NM93C56LZ	NM93C56LZ@SOIC8
[(SA602A)]	
NM93C66	NM93C66@SOIC8
[(SA602A)]	
NM93C66A	NM93C66A
(08bit)	
NM93C66A(08bit)@SOIC8 [(SA602A)]	NM93C66A@SOIC8
[(SA602A)]	
NM93C66AL(08bit)	
NM93C66AL(08bit)@SOIC8 [(SA602A)]	
NM93C66AL(16bit)	
NM93C66AL(16bit)@SOIC8 [(SA602A)]	
NM93C66ALZ(08bit)	
NM93C66ALZ(08bit)@SOIC8 [(SA602A)]	
NM93C66ALZ(16bit)	
NM93C66ALZ(16bit)@SOIC8 [(SA602A)]	
NM93C66L	NM93C66L@SOIC8
[(SA602A)]	
NM93C66LZ	NM93C66LZ@SOIC8
[(SA602A)]	
NM93C86(16bit)	NM93C86(16bit)@SOIC8



[ (SA602A) ]	
NM93C86A	NM93C86A
(08bit)	
NM93C86A(08bit)@SOIC8 [ (SA602A) ]	NM93C86A@SOIC8
[ (SA602A) ]	
NM93C86AL(08bit)	
NM93C86AL(08bit)@SOIC8 [ (SA602A) ]	
NM93C86AL(16bit)	
NM93C86AL(16bit)@SOIC8 [ (SA602A) ]	
NM93C86ALZ(08bit)	
NM93C86ALZ(08bit)@SOIC8 [ (SA602A) ]	
NM93C86ALZ(16bit)	
NM93C86ALZ(16bit)@SOIC8 [ (SA602A) ]	
NM93C86L	NM93C86L@SOIC8
[ (SA602A) ]	
NM93C86LZ	NM93C86LZ@SOIC8
[ (SA602A) ]	
NM93CS06(M8)@SOIC8 [ (SA602A) ]	NM93CS06(MT8)@TSSOP8
[ (SA026) ]	
NM93CS06(N)	NM93CS46(M8)@SOIC8
[ (SA602A) ]	
NM93CS46(MT8)@TSSOP8 [ (SA026) ]	NM93CS46
(N)	
NM93CS56(M8)@SOIC8 [ (SA602A) ]	NM93CS56(MT8)@TSSOP8
[ (SA026) ]	
NM93CS56(N)	NM93CS66(M8)@SOIC8
[ (SA602A) ]	
NM93CS66(MT8)@TSSOP8 [ (SA026) ]	NM93CS66
(N)	
NMC2732	
NMC2732B	
NMC2732H	
NMC27C010	
NMC27C010@PLCC32 [ (SA015A1T) ]	NMC27C010@TSOP32
[ (SA410T) ]	
NMC27C1024	NMC27C1024@PLCC44
[ (SA244) ]	
NMC27C128B	NMC27C128B@PLCC32
[ (SA015A1T) ]	
NMC27C128BN	NMC27C128BN@PLCC32
[ (SA015A1T) ]	
NMC27C128BQ	NMC27C128BQ@PLCC32
[ (SA015A1T) ]	

NMC27C128CQ  
NMC27C128Q  
NMC27C16  
NMC27C16BQ  
NMC27C16BQE  
NMC27C16H  
NMC27C16HQ  
NMC27C16Q  
NMC27C210 NMC27C210@PLCC44  
[ ( SA244 ) ]  
NMC27C210Q NMC27C210Q@PLCC44  
[ ( SA244 ) ]  
NMC27C256B NMC27C256B@PLCC32  
[ ( SA015A1T ) ]  
NMC27C256BN  
NMC27C256BQE  
NMC27C256BQM  
NMC27C256Q  
NMC27C256Q@PLCC32 [ ( SA015A1T ) ]  
NMC27C32  
NMC27C32B  
NMC27C32BQ  
NMC27C32E  
NMC27C32EH  
NMC27C32H  
NMC27C512  
NMC27C512@PLCC32 [ ( SA015A1T ) ]  
NMC27C512A  
NMC27C512A@PLCC32 [ ( SA015A1T ) ]  
NMC27C512AN  
NMC27C512AN@PLCC32 [ ( SA015A1T ) ]  
NMC27C64  
NMC27C64@PLCC32 [ ( SA015A1T ) ]  
NMC27C64BN  
NMC27C64N  
NMC27CP128  
NMC27CP256  
NMC27CP64  
NMC59C11 NMC59C11@SOIC8  
[ ( SA602A ) ]  
NMC87C257Q  
NMC87C257Q@PLCC32  
NMC87C257V

NMC87C257V@PLCC32

NMC9306

[ ( SA602A ) ]

NMC9307

[ ( SA602A ) ]

NMC9346

[ ( SA602A ) ]

NMC93C56

[ ( SA602 ) ]

NMC93C56@SOIC8 [ ( SA602A ) ]

NMC93C66

NMC93C66@SOIC14 [ ( SA602 ) ]

NMC93C86A

NMC93C86A@SOIC14 [ ( SA602 ) ]

[ ( SA602A ) ]

NMC93CS06 (M14)@SOIC14 [ ( SA602 ) ]

( N )

NMC93CS46 (M14)@SOIC14 [ ( SA602 ) ]

( N )

NMC93CS56 (M14)@SOIC14 [ ( SA602 ) ]

( N )

NMC93CS66 (M14)@SOIC14 [ ( SA602 ) ]

( N )

NMC93S06 (M14)@SOIC14 [ ( SA602 ) ]

( N )

NMC9817

NMC9817A

NS2816A

NS9816A

NMC9306@SOIC8

NMC9307@SOIC8

NMC9346@SOIC8

NMC93C56@SOIC14

NMC93C86A@SOIC8

NMC93CS06

NMC93CS46

NMC93CS56

NMC93CS66

NMC93S06

## BPROM

DM54LS471

[ ( SA001A ) ]

DM54S188

DM54S188A

DM54S287

DM54S287A

DM54S288

DM54S288A

DM54S387

DM54S387A

DM54LS471@PLCC20

DM54S471	DM54S471@PLCC20
[ (SA001A) ]	
DM54S472	DM54S472@PLCC20
[ (SA001A) ]	
DM54S472A	DM54S472A@PLCC20
[ (SA001A) ]	
DM54S472B	DM54S472B@PLCC20
[ (SA001A) ]	
DM54S473	DM54S473@PLCC20
[ (SA001A) ]	
DM54S473A	DM54S473A@PLCC20
[ (SA001A) ]	
DM54S474	
DM54S474A	
DM54S474B	
DM54S475	
DM54S475A	
DM54S570	
DM54S570A	
DM54S571	
DM54S571A	
DM54S571B	
DM54S572	
DM54S572A	
DM54S573	
DM54S573A	
DM54S573B	
DM74LS471	
DM74LS471@PLCC20 [ (SA001A) ]	
DM74S188	
DM74S188A	
DM74S287	
DM74S287A	
DM74S288	
DM74S288A	
DM74S387	
DM74S387A	
DM74S471	
DM74S471@PLCC20 [ (SA001A) ]	
DM74S472	
DM74S472@PLCC20 [ (SA001A) ]	
DM74S472A	
DM74S472A@PLCC20 [ (SA001A) ]	

DM74S472B  
DM74S472B@PLCC20 [(SA001A)]  
DM74S473  
DM74S473@PLCC20 [(SA001A)]  
DM74S473A  
DM74S473A@PLCC20 [(SA001A)]  
DM74S474  
DM74S474A  
DM74S474B  
DM74S475  
DM74S475A  
DM74S570  
DM74S570A  
DM74S571  
DM74S571A  
DM74S571B  
DM74S572  
DM74S572A  
DM74S573  
DM74S573A  
DM74S573B  
DM77S184  
DM77S185  
DM77S185A  
DM77S185B  
DM87S184  
DM87S185  
DM87S185A  
DM87S185B

## PLD

GAL16V8 [(SA001A)]	GAL16V8@PLCC20
GAL16V8A [(SA001A)]	GAL16V8A@PLCC20
GAL20V8 [(SA008A)]	GAL20V8@PLCC28
GAL20V8A [(SA008A)]	GAL20V8A@PLCC28
GAL20V8QS [(SA008A)]	GAL20V8QS@PLCC28

PAL20RA10

## MICROCONTROLLER

COP820 (CJMHD) [ (SA404) ]	COP820 (CJMHEA)@SOIC28
COP822 (CJMHD) (CMHD)	COP842
COP8640 (CMHD) [ (SA404) ]	COP8640 (CMHEA)@SOIC28
COP8642 (CMHD) (CD)	COP8780
COP8780 (CEL)@PLCC44 [ (SA244) ] (CJ)	COP8780
COP8780 (CN) [ (SA244) ]	COP8780 (CV)@PLCC44
COP8781 (CD) (CJ)	COP8781
COP8781 (CMC)@SOIC28 [ (SA404) ] (CN)	COP8781
COP8781 (CWM)@SOIC28 [ (SA404) ] (CD)	COP8782
COP8782 (CJ) [ (SA404) ]	COP8782 (CMC)@SOIC20
COP8782 (CN) [ (SA404) ]	COP8782 (CWM)@SOIC20
COP87L20 [ (SA404) ]	COP87L20@SOIC28
COP87L22 [ (SA404) ]	COP87L22@SOIC20
COP87L40 [ (SA404) ]	COP87L40@SOIC28
COP87L42 [ (SA404) ]	COP87L42@SOIC20
COP87L84 [ (SA404) ]	COP87L84@SOIC28
COP87L84BC [ (SA404) ]	COP87L84BC@SOIC28
COP87L88 [ (SA244) ]	COP87L88@PLCC44
COP87L88@PLCC68 [ (PEP+S414T) ] [ (SA245A) ]	COP87L88@TQFP44

COP87L88EB@PLCC44 [ (SA244) ] +S414T ]	COP87L88EB@PLCC68 [ (PEP
COP87L88GW@PLCC68 [ (PEP+S414T) ] (CMHD)	COP880
COP880(CMHEL)@PLCC44 [ (SA244) ] (CMHD)	COP881
COP881(CMHEA)@SOIC28 [ (SA404) ] (CFMHD)	COP884
COP884(CFMHEA)@SOIC28 [ (SA404) ] (CGMHD)	COP884
COP884(CGMHEA)@SOIC28 [ (SA404) ] (CLMHD)	COP884
COP884(CLMHEA)@SOIC28 [ (SA404) ] (CSMHD)	COP884
COP884(CSMHEA)@SOIC28 [ (SA404) ] (EGMHD)	COP884
COP884(EGMHEA)@SOIC28 [ (SA404) ] (CFMHD)	COP888
COP888(CFMHEL)@PLCC44 [ (SA244) ] (CGMHD)	COP888
COP888(CGMHEL)@PLCC44 [ (SA244) ] (CLMHD)	COP888
COP888(CLMHEL)@PLCC44 [ (SA244) ] (CSMHD)	COP888
COP888(CSMHEL)@PLCC44 [ (SA244) ] (EGMHD)	COP888
COP888(EGMHEL)@PLCC44 [ (SA244) ]	
COP8ACC720	
COP8ACC720@SOIC20 [ (SA404) ]	
COP8ACC728	
COP8ACC728@SOIC28 [ (SA404) ]	
COP8ALE728	
COP8ALE728@SOIC28 [ (SA404) ]	
COP8AXE9	
COP8AXE9@SOIC28 [ (SA404) ] [ (SA244) ]	COP8CBE9@PLCC44
COP8CBE9@TQFP44 [ (SA245) ] [ (SA244) ]	COP8CBR9@PLCC44
COP8CBR9@PLCC68 [ (PEP+S414T) ] [ (SA245) ]	COP8CBR9@TQFP44
COP8CCE9@PLCC44 [ (SA244) ] [ (SA245) ]	COP8CCE9@TQFP44
COP8CCR9@PLCC44 [ (SA244) ]	COP8CCR9@PLCC68 [ (PEP

+S414T) ]

COP8CCR9@TQFP44 [ (SA245) ]

[ (SA244) ]

COP8CDR9@PLCC68 [ (PEP+S414T) ]

[ (SA245) ]

COP8CXC9@PLCC44 [ (SA244) ]

[ (SA244) ]

COP8SAA716

[ (SA404) ]

COP8SAA720

[ (SA404) ]

COP8SAA728

[ (SA008A) ]

COP8SAA728@SOIC28 [ (SA404) ]

COP8SAA740

COP8SAA740@SOIC40 [ (SA638) ]

[ (SA244) ]

COP8SAA744@TQFP44 [ (SA245A) ]

COP8SAB716

COP8SAB716@SOIC16 [ (SA404) ]

COP8SAB720

COP8SAB720@SOIC20 [ (SA404) ]

COP8SAB728

COP8SAB728@PLCC28 [ (SA008A) ]

[ (SA404) ]

COP8SAB740

[ (SA638) ]

COP8SAB744@PLCC44 [ (SA244) ]

[ (SA245A) ]

COP8SAC716

[ (SA404) ]

COP8SAC720

[ (SA404) ]

COP8SAC728

[ (SA008A) ]

COP8SAC728@SOIC28 [ (SA404) ]

COP8SAC740

COP8SAC740@SOIC40 [ (SA638) ]

[ (SA244) ]

COP8SAC744@TQFP44 [ (SA245A) ]

[ (SA244) ]

COP8SBE9@PLCC68 [ (PEP+S414T) ]

[ (SA244) ]

COP8CDR9@PLCC44

COP8CDR9@TQFP44

COP8CXG9@PLCC44

COP8SAA716@SOIC16

COP8SAA720@SOIC20

COP8SAA728@PLCC28

COP8SAA744@PLCC44

COP8SAB728@SOIC28

COP8SAB740@SOIC40

COP8SAB744@TQFP44

COP8SAC716@SOIC16

COP8SAC720@SOIC20

COP8SAC728@PLCC28

COP8SAC744@PLCC44

COP8SBE9@PLCC44

COP8SBR9@PLCC44



COP8SBR9@PLCC68 [ ( PEP+S414T ) ]  
[ ( SA245 ) ]  
COP8SCE9@PLCC44 [ ( SA244 ) ]  
+S414T ) ]  
COP8SCR9@PLCC44 [ ( SA244 ) ]  
+S414T ) ]  
COP8SCR9@TQFP44 [ ( SA245 ) ]  
[ ( SA244 ) ]  
COP8SDR9@PLCC68 [ ( PEP+S414T ) ]  
[ ( SA245 ) ]  
COP8SGE720  
[ ( SA404 ) ]  
COP8SGE728  
[ ( SA404 ) ]  
COP8SGE740  
[ ( SA638 ) ]  
COP8SGE744@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]  
COP8SGR720  
[ ( SA404 ) ]  
COP8SGR728  
[ ( SA404 ) ]  
COP8SGR740  
[ ( SA638 ) ]  
COP8SGR744@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]  
COP943 ( CMHD )

COP8SBR9@TQFP44  
COP8SCE9@PLCC68 [ ( PEP  
COP8SCR9@PLCC68 [ ( PEP  
COP8SDR9@PLCC44  
COP8SDR9@TQFP44  
COP8SGE720@SOIC20  
COP8SGE728@SOIC28  
COP8SGE740@SOIC40  
COP8SGE744@TQFP44  
COP8SGR720@SOIC20  
COP8SGR728@SOIC28  
COP8SGR740@SOIC40  
COP8SGR744@TQFP44

## **NTE**

### **E ( E ) PROM / FRAM / NVRAM**

NTE2532  
NTE2532A  
NTE25L32

## **NUMONYX**

### **E ( E ) PROM / FRAM / NVRAM**

M25PX32@SOIC16 [(SA404)]  
 [(SA023A)]  
 M25PX32@VFQFPN8 [(SA683)]  
 [(SA404)]  
 M25PX64@VDFPN8 [(SA684)]

M25PX32@SOIC8  
 M25PX64@SOIC16

## NXP

### MICROCONTROLLER

LPC2101FBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2102FBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2103FA44@PLCC44(\*) [(SA244-B4403)]  
 LPC2103FBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2104BBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2105BBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2106BBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2114FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2119FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2124FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2129FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2131FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2131FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2132FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2132FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2134FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2134FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2136FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2136FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2138FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2138FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2141FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2142FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2144FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2146FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2148FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2194HBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2212HBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2214FBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2292HBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2294HBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2364@LQFP100(\*) [(SA718+B243)]

LPC2366@LQFP100(*) [(SA718+B243)]	
LPC2368@LQFP100(*) [(SA718+B243)]	
P83C660X2@PLCC44 [(SA244)]	P83C660X2@TQFP44
[(SA245A)]	
P83C661X2@PLCC44 [(SA244)]	P83C661X2@TQFP44
[(SA245A)]	
P87C054@SDIP42 [(SA028)]	P87C055@SDIP42
[(SA028)]	
P87C451@PLCC68 [(PEP+S414T)]	P87C451@SDIP64 [(PEP
+S600A)]	
P87C453@PLCC68 [(PEP+S414T)]	
P87C51	
P87C51@PLCC44 [(SA244)]	P87C51@TQFP44
[(SA245A)]	
P87C51FA	P87C51FA@PLCC44
[(SA244)]	
P87C51FA@TQFP44 [(SA245A)]	
P87C51FB	
P87C51FB@PLCC44 [(SA244)]	P87C51FB@TQFP44
[(SA245A)]	
P87C51FC	P87C51FC@PLCC44
[(SA244)]	
P87C51FC@TQFP44 [(SA245A)]	P87C51MA2@PLCC44
[(SA244)]	
P87C51MB2@PLCC44 [(SA244)]	P87C51MC2@PLCC44
[(SA244)]	
P87C51RA+	P87C51RA+@PLCC44
[(SA244)]	
P87C51RA+@TQFP44 [(SA245A)]	
P87C51RA2	
P87C51RA2@PLCC44 [(SA244)]	P87C51RA2@TQFP44
[(SA245A)]	
P87C51RB+	P87C51RB+@PLCC44
[(SA244)]	
P87C51RB+@TQFP44 [(SA245A)]	
P87C51RB2	
P87C51RB2@PLCC44 [(SA244)]	P87C51RB2@TQFP44
[(SA245A)]	
P87C51RC+	P87C51RC+@PLCC44
[(SA244)]	
P87C51RC+@TQFP44 [(SA245A)]	
P87C51RC2	
P87C51RC2@PLCC44 [(SA244)]	P87C51RC2@TQFP44

[ ( SA245A ) ]	
P87C51RD+	P87C51RD+@PLCC44
[ ( SA244 ) ]	
P87C51RD+@TQFP44 [ ( SA245A ) ]	
P87C51RD2	
P87C51RD2@PLCC44 [ ( SA244 ) ]	P87C51RD2@TQFP44
[ ( SA245A ) ]	
P87C51SB	P87C51SB@PLCC44
[ ( SA244 ) ]	
P87C51SB@TQFP44 [ ( SA245A ) ]	
P87C51SF	
P87C51SF@PLCC44 [ ( SA244 ) ]	P87C51SF@TQFP44
[ ( SA245A ) ]	
P87C51UB	P87C51UB@PLCC44
[ ( SA244 ) ]	
P87C51UB@TQFP44 [ ( SA245A ) ]	
P87C51UF	
P87C51UF@PLCC44 [ ( SA244 ) ]	P87C51UF@TQFP44
[ ( SA245A ) ]	
P87C51X2	P87C51X2@PLCC44
[ ( SA244 ) ]	
P87C51X2@TQFP44 [ ( SA245A ) ]	
P87C52	
P87C52@PLCC44 [ ( SA244 ) ]	P87C52@TQFP44
[ ( SA245A ) ]	
P87C524	P87C524@PLCC44
[ ( SA244 ) ]	
P87C524@TQFP44 [ ( SA245A ) ]	
P87C528	
P87C528@PLCC44 [ ( SA244 ) ]	P87C528@TQFP44
[ ( SA245A ) ]	
P87C52SB	P87C52SB@PLCC44
[ ( SA244 ) ]	
P87C52SB@TQFP44 [ ( SA245A ) ]	
P87C52SF	
P87C52SF@PLCC44 [ ( SA244 ) ]	P87C52SF@TQFP44
[ ( SA675 ) ]	
P87C52UB	P87C52UB@PLCC44
[ ( SA244 ) ]	
P87C52UB@TQFP44 [ ( SA245A ) ]	
P87C52UF	
P87C52UF@PLCC44 [ ( SA244 ) ]	P87C52UF@TQFP44
[ ( SA245A ) ]	

P87C52X2 [ (SA244) ] P87C52X2@TQFP44 [ (SA245A) ] P87C54 P87C54@PLCC44 [ (SA244) ] [ (SA245A) ] P87C54SB [ (SA244) ] P87C54SB@TQFP44 [ (SA245A) ] P87C54SF P87C54SF@PLCC44 [ (SA244) ] [ (SA245A) ] P87C54UB [ (SA244) ] P87C54UB@TQFP44 [ (SA245A) ] P87C54UF P87C54UF@PLCC44 [ (SA244) ] [ (SA245A) ] P87C54X2 [ (SA244) ] P87C54X2@TQFP44 [ (SA245A) ] P87C550 P87C550@PLCC44 [ (SA244) ] +S414T) ] P87C552@PLCC68 (*) [ (SA648-B6806) ] P87C554@LQFP64 [ (PEP+S616) ] +S414T) ] P87C554@PLCC68 (*) [ (SA648-B6806) ] P87C557E8@PQFP80 [ (PEP+S611A) ] P87C575 P87C575@PLCC44 [ (SA244) ] [ (SA245A) ] P87C576 [ (SA244) ] P87C576@TQFP44 [ (SA245A) ] P87C58 P87C58@PLCC44 [ (SA244) ] [ (SA245A) ] P87C58SB [ (SA244) ] P87C58SB@TQFP44 [ (SA245A) ] P87C58UB P87C58UB@PLCC44 [ (SA244) ]	P87C52X2@PLCC44    P87C54@TQFP44  P87C54SB@PLCC44    P87C54SF@TQFP44  P87C54UB@PLCC44    P87C54UF@TQFP44  P87C54X2@PLCC44    P87C552@PLCC68 [ (PEP P87C554@PLCC68 [ (PEP    P87C575@TQFP44  P87C576@PLCC44    P87C58@TQFP44  P87C58SB@PLCC44   P87C58UB@TQFP44
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

[ (SA245A) ]	
P87C58X2	P87C58X2@PLCC44
[ (SA244) ]	
P87C58X2@TQFP44 [ (SA245A) ]	P87C591@PLCC44
[ (SA244) ]	
P87C591@TQFP44 [ (SA245A) ]	P87C592@PLCC68 [ (PEP
+S414T) ]	
P87C652	P87C652@PLCC44
[ (SA244) ]	
P87C652@TQFP44 [ (SA245A) ]	
P87C654	
P87C654@PLCC44 [ (SA244) ]	P87C654@TQFP44
[ (SA245A) ]	
P87C660X2@PLCC44 [ (SA244) ]	P87C660X2@TQFP44
[ (SA245A) ]	
P87C661X2@PLCC44 [ (SA244) ]	P87C661X2@TQFP44
[ (SA245A) ]	
P87C748	P87C748@PLCC28
[ (SA008A) ]	
P87C749	P87C749@PLCC28
[ (SA008A) ]	
P87C750	P87C750@PLCC28
[ (SA008A) ]	
P87C750@SSOP24 [ (SA626A) ]	
P87C751	
P87C751@PLCC28 [ (SA008A) ]	P87C751@SSOP24
[ (SA626A) ]	
P87C752	P87C752@PLCC28
[ (SA008A) ]	
P87C752@SSOP28 [ (SA626A) ]	
P87C754	
P87C754@PLCC28 [ (SA008A) ]	P87C754@SSOP28
[ (SA626A) ]	
P87CL52X2	P87CL52X2@PLCC44
[ (SA244) ]	
P87CL52X2@TQFP44 [ (SA245A) ]	
P87CL54X2	
P87CL54X2@PLCC44 [ (SA244) ]	P87CL54X2@TQFP44
[ (SA245A) ]	
P87L51FA	P87L51FA@PLCC44
[ (SA244) ]	
P87L51FA@TQFP44 [ (SA245A) ]	
P87L51FB	

P87L51FB@PLCC44 [(SA244)] P87L51FB@TQFP44  
[(SA245A)]  
P87LPC759 P87LPC759(ISP) [ISP-  
HEADER01]  
P87LPC760 P87LPC760(ISP) [ISP-  
HEADER01]  
P87LPC760@TSSOP14 [(SA026)]  
P87LPC760@TSSOP14(ISP) [ISP-HEADER01]  
P87LPC761 P87LPC761(ISP) [ISP-  
HEADER01]  
P87LPC762 P87LPC762(ISP) [ISP-  
HEADER01]  
P87LPC762@PLCC44 [(SA244)]  
P87LPC762@PLCC44(ISP) [ISP-HEADER01]  
P87LPC762@SOIC20 [(SA404)]  
P87LPC762@SOIC20(ISP) [ISP-HEADER01]  
P87LPC764 P87LPC764(ISP) [ISP-  
HEADER01]  
P87LPC764@PLCC44 [(SA244)]  
P87LPC764@PLCC44(ISP) [ISP-HEADER01]  
P87LPC764@SOIC20 [(SA404)]  
P87LPC764@SOIC20(ISP) [ISP-HEADER01]  
P87LPC764@TSSOP20 [(SA643)]  
P87LPC764@TSSOP20(ISP) [ISP-HEADER01]  
P87LPC767 P87LPC767(ISP) [ISP-  
HEADER01]  
P87LPC767@PLCC44 [(SA244)]  
P87LPC767@PLCC44(ISP) [ISP-HEADER01]  
P87LPC767@SOIC20 [(SA404)]  
P87LPC767@SOIC20(ISP) [ISP-HEADER01]  
P87LPC768 P87LPC768(ISP) [ISP-  
HEADER01]  
P87LPC768@SOIC20 [(SA404)]  
P87LPC768@SOIC20(ISP) [ISP-HEADER01]  
P87LPC769 P87LPC769(ISP) [ISP-  
HEADER01]  
P87LPC769@PLCC44 [(SA244)]  
P87LPC769@PLCC44(ISP) [ISP-HEADER01]  
P87LPC769@SOIC20 [(SA404)]  
P87LPC769@SOIC20(ISP) [ISP-HEADER01]  
P87LPC778 P87LPC778(ISP) [ISP-  
HEADER01]  
P87LPC778@TSSOP20 [(SA026)]

P87LPC778@TSSOP20(ISP) [ISP-HEADER01]  
P87LPC779 P87LPC779(ISP) [ISP-  
HEADER01]  
P87LPC779@TSSOP20 [(SA643)]  
P87LPC779@TSSOP20(ISP) [ISP-HEADER01]  
P89C138 P89C138@PLCC44  
[(SA244)]  
P89C138@TQFP44 [(SA245A)]  
P89C238  
P89C238@PLCC44 [(SA244)] P89C238@TQFP44  
[(SA245A)]  
P89C51B P89C51B@PLCC44  
[(SA244)]  
P89C51B@TQFP44 [(SA245A)] P89C51RA  
+  
P89C51RA+@PLCC44 [(SA244)] P89C51RA+@TQFP44  
[(SA245A)]  
P89C51RA2B P89C51RA2B@PLCC44  
[(SA244)]  
P89C51RA2B@TQFP44 [(SA245A)] P89C51RB  
+  
P89C51RB+@PLCC44 [(SA244)] P89C51RB+@TQFP44  
[(SA245A)]  
P89C51RB2B P89C51RB2B@PLCC44  
[(SA244)]  
P89C51RB2B@TQFP44 [(SA245A)]  
P89C51RB2H  
P89C51RB2H@PLCC44 [(SA244)] P89C51RB2H@TQFP44  
[(SA245A)]  
P89C51RC+ P89C51RC+@PLCC44  
[(SA244)]  
P89C51RC+@TQFP44 [(SA245A)]  
P89C51RC2B  
P89C51RC2B@PLCC44 [(SA244)] P89C51RC2B@TQFP44  
[(SA245A)]  
P89C51RC2H P89C51RC2H@PLCC44  
[(SA244)]  
P89C51RC2H@TQFP44 [(SA245A)] P89C51RD  
+  
P89C51RD+@PLCC44 [(SA244)] P89C51RD+@TQFP44  
[(SA245A)]  
P89C51RD2B P89C51RD2B@PLCC44  
[(SA244)]



P89C51RD2B@TQFP44 [(SA245A)]	
P89C51RD2H	
P89C51RD2H@PLCC44 [(SA244)]	P89C51RD2H@TQFP44
[(SA245A)]	
P89C51UB	
[(SA244)]	P89C51UB@PLCC44
P89C51UB@TQFP44 [(SA245A)]	
P89C51UF	
P89C51UF@PLCC44 [(SA244)]	P89C51UF@TQFP44
[(SA245A)]	
P89C51X2	
[(SA244)]	P89C51X2@PLCC44
P89C51X2@TQFP44 [(SA245A)]	
P89C51X2B	
P89C51X2B@PLCC44 [(SA244)]	P89C51X2B@TQFP44
[(SA245A)]	
P89C51X2F	
[(SA244)]	P89C51X2F@PLCC44
P89C51X2F@TQFP44 [(SA245A)]	
P89C52	
P89C52@PLCC44 [(SA244)]	P89C52@TQFP44
[(SA245A)]	
P89C52B	
[(SA244)]	P89C52B@PLCC44
P89C52B@TQFP44 [(SA245A)]	
P89C52UB	
P89C52UB@PLCC44 [(SA244)]	P89C52UB@TQFP44
[(SA245A)]	
P89C52UF	
[(SA244)]	P89C52UF@PLCC44
P89C52UF@TQFP44 [(SA245A)]	
P89C52X2	
P89C52X2@PLCC44 [(SA244)]	P89C52X2@TQFP44
[(SA245A)]	
P89C52X2B	
[(SA244)]	P89C52X2B@PLCC44
P89C52X2B@TQFP44 [(SA245A)]	
P89C52X2F	
P89C52X2F@PLCC44 [(SA244)]	P89C52X2F@TQFP44
[(SA245A)]	
P89C536@PLCC44 [(SA244)]	P89C538@PLCC44
[(SA244)]	
P89C54	P89C54@PLCC44

[ ( SA244 ) ]	
P89C54@TQFP44 [ ( SA245A ) ]	
P89C54B	
P89C54B@PLCC44 [ ( SA244 ) ]	P89C54B@TQFP44
[ ( SA245A ) ]	
P89C54UB	
[ ( SA244 ) ]	
P89C54UB@TQFP44 [ ( SA245A ) ]	P89C54UB@PLCC44
P89C54UF	
P89C54UF@PLCC44 [ ( SA244 ) ]	P89C54UF@TQFP44
[ ( SA245A ) ]	
P89C54X2	
[ ( SA244 ) ]	
P89C54X2@TQFP44 [ ( SA245A ) ]	P89C54X2@PLCC44
P89C54X2B	
P89C54X2B@PLCC44 [ ( SA244 ) ]	P89C54X2B@TQFP44
[ ( SA245A ) ]	
P89C54X2F	
[ ( SA244 ) ]	
P89C54X2F@TQFP44 [ ( SA245A ) ]	P89C54X2F@PLCC44
P89C58	
P89C58@PLCC44 [ ( SA244 ) ]	P89C58@TQFP44
[ ( SA245A ) ]	
P89C58B	
[ ( SA244 ) ]	
P89C58B@TQFP44 [ ( SA245A ) ]	P89C58B@PLCC44
P89C58UB	
P89C58UB@PLCC44 [ ( SA244 ) ]	P89C58UB@TQFP44
[ ( SA245A ) ]	
P89C58UF	
[ ( SA244 ) ]	
P89C58UF@TQFP44 [ ( SA245A ) ]	P89C58UF@PLCC44
P89C58X2	
P89C58X2@PLCC44 [ ( SA244 ) ]	P89C58X2@TQFP44
[ ( SA245A ) ]	
P89C58X2B	
[ ( SA244 ) ]	
P89C58X2B@TQFP44 [ ( SA245A ) ]	P89C58X2B@PLCC44
P89C58X2F	
P89C58X2F@PLCC44 [ ( SA244 ) ]	P89C58X2F@TQFP44
[ ( SA245A ) ]	
P89C60X2	
[ ( SA244 ) ]	
	P89C60X2@PLCC44

P89C60X2@TQFP44 [(SA245A)]  
P89C61X2  
P89C61X2@PLCC44 [(SA244)]  
[(SA245A)]  
P89C660  
[(SA244)]  
P89C660@TQFP44 [(SA245A)]  
P89C662  
P89C662@PLCC44 [(SA244)]  
[(SA245A)]  
P89C664  
[(SA244)]  
P89C664@TQFP44 [(SA245A)]  
P89C668  
P89C668@PLCC44 [(SA244)]  
[(SA245A)]  
P89C669  
[(SA245A)]  
P89C669@PLCC44 [(SA244)]  
P89C738  
P89C738@PLCC44 [(SA244)]  
[(SA245A)]  
P89C838  
[(SA244)]  
P89C838@TQFP44 [(SA245A)]  
[(SA244)]  
P89CV51RB2@TQFP44 [(SA245A)]  
[(SA244)]  
P89CV51RC2@TQFP44 [(SA245A)]  
[(SA244)]  
P89CV51RD2@TQFP44 [(SA245A)]  
[(SA602A)]  
P89LPC901(FD)(ISP) [ISP-HEADER01]  
P89LPC901(FN)  
P89LPC901(FN)(ISP) [ISP-HEADER01]  
P89LPC902(FD) [(SA602A)]  
P89LPC902(FD)(ISP) [ISP-HEADER01]  
P89LPC902(FN)  
P89LPC902(FN)(ISP) [ISP-HEADER01]  
P89LPC903(FD) [(SA602A)]  
P89LPC903(FD)(ISP) [ISP-HEADER01]  
P89LPC904(FD) [(SA605A)]  
P89LPC904(FD)(ISP) [ISP-HEADER01]  
P89C61X2@TQFP44  
P89C660@PLCC44  
P89C662@TQFP44  
P89C664@PLCC44  
P89C668@TQFP44  
P89C669@LQFP44  
P89C738@TQFP44  
P89C838@PLCC44  
P89CV51RB2@PLCC44  
P89CV51RC2@PLCC44  
P89CV51RD2@PLCC44  
P89LPC901(FD)

P89LPC904(FN)  
P89LPC904(FN)(ISP) [ISP-HEADER01]  
P89LPC906(FD) [(SA605A)]  
P89LPC906(FD)(ISP) [ISP-HEADER01]  
P89LPC907(FD) [(SA605A)]  
P89LPC907(FD)(ISP) [ISP-HEADER01]  
P89LPC908(FD) [(SA605A)]  
P89LPC908(FD)(ISP) [ISP-HEADER01]  
P89LPC9102(FTK)@HVSON10 [(SA695A)]  
P89LPC9102(FTK)@HVSON10(ISP) [ISP-HEADER01]  
P89LPC9103(FTK)@HVSON10 [(SA695A)]  
P89LPC9103(FTK)@HVSON10(ISP) [ISP-HEADER01]  
P89LPC9107(FDH)@TSSOP14 [(SA643)]  
P89LPC9107(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC9107(FN)  
P89LPC9107(FN)(ISP) [ISP-HEADER01]  
P89LPC912(FDH)@TSSOP14 [(SA643)]  
P89LPC912(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC913(FDH)@TSSOP14 [(SA643)]  
P89LPC913(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC914(FDH)@TSSOP14 [(SA643)]  
P89LPC914(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC915(FDH)@TSSOP14 [(SA643)]  
P89LPC915(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC916(FDH)@TSSOP16 [(SA643)]  
P89LPC916(FDH)@TSSOP16(ISP) [ISP-HEADER01]  
P89LPC917(FDH)@TSSOP16 [(SA643)]  
P89LPC917(FDH)@TSSOP16(ISP) [ISP-HEADER01]  
P89LPC920(FDH)@TSSOP20 [(SA643)]  
P89LPC920(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC920(FN)  
P89LPC920(FN)(ISP) [ISP-HEADER01]  
P89LPC921(FDH)@TSSOP20 [(SA643)]  
P89LPC921(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC921(FN)  
P89LPC921(FN)(ISP) [ISP-HEADER01]  
P89LPC922(FDH)@TSSOP20 [(SA643)]  
P89LPC922(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC922(FN)  
P89LPC922(FN)(ISP) [ISP-HEADER01]  
P89LPC9221(FDH)@TSSOP20 [(SA643)]  
P89LPC9221(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9221(FN)

P89LPC9221(FN)(ISP) [ISP-HEADER01]  
P89LPC924(FDH)@TSSOP20 [(SA643)]  
P89LPC924(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC924(FN)  
P89LPC924(FN)(ISP) [ISP-HEADER01]  
P89LPC925(FDH)@TSSOP20 [(SA643)]  
P89LPC925(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC925(FN)  
P89LPC925(FN)(ISP) [ISP-HEADER01]  
P89LPC930(BA)@PLCC28 [(SA008A)]  
P89LPC930(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC930(BDH)@TSSOP28 [(SA643)]  
P89LPC930(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC931(BA)@PLCC28 [(SA008A)]  
P89LPC931(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC931(BDH)@TSSOP28 [(SA643)]  
P89LPC931(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932(BA)@PLCC28 [(SA008A)] P89LPC932(BDH)@TSSOP28  
[(SA643)]  
P89LPC932A1(BA)@PLCC28 [(SA008A)]  
P89LPC932A1(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC932A1(BDH)@TSSOP28 [(SA643)]  
P89LPC932A1(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932A1(FDH)@TSSOP28 [(SA643)]  
P89LPC932A1(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932A1(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC932A1(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC933(BDH)@TSSOP28 [(SA643)]  
P89LPC933(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC933(FDH)@TSSOP28 [(SA643)]  
P89LPC933(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC934(BDH)@TSSOP28 [(SA643)]  
P89LPC934(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC934(FDH)@TSSOP28 [(SA643)]  
P89LPC934(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(BA)@PLCC28 [(SA008A)]  
P89LPC935(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(BDH)@TSSOP28 [(SA643)]  
P89LPC935(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(FA)@PLCC28 [(SA008A)]  
P89LPC935(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(FDH)@TSSOP28 [(SA643)]  
P89LPC935(FDH)@TSSOP28(ISP) [ISP-HEADER01]

P89LPC935(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC935(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93501(BA)@PLCC28 [(SA008A)]  
P89LPC93501(BDH)@TSSOP28 [(SA643)]  
P89LPC93501(FA)@PLCC28 [(SA008A)]  
P89LPC93501(FDH)@TSSOP28 [(SA643)]  
P89LPC93501(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9351(BA)@PLCC28 [(SA008A)]  
P89LPC9351(BDH)@TSSOP28 [(SA643)]  
P89LPC9351(FA)@PLCC28 [(SA008A)]  
P89LPC9351(FDH)@TSSOP28 [(SA643)]  
P89LPC9351(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC936(FA)@PLCC28 [(SA008A)]  
P89LPC936(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC936(FDH)@TSSOP28 [(SA643)]  
P89LPC936(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC938(FA)@PLCC28 [(SA008A)]  
P89LPC938(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC938(FDH)@TSSOP28 [(SA643)]  
P89LPC938(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC938(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC938(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93801(BA)@PLCC28 [(SA008A)]  
P89LPC93801(BDH)@TSSOP28 [(SA643)]  
P89LPC93801(FA)@PLCC28 [(SA008A)]  
P89LPC93801(FDH)@TSSOP28 [(SA643)]  
P89LPC93801(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9381(BA)@PLCC28 [(SA008A)]  
P89LPC9381(BDH)@TSSOP28 [(SA643)]  
P89LPC9381(FA)@PLCC28 [(SA008A)]  
P89LPC9381(FDH)@TSSOP28 [(SA643)]  
P89LPC9381(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9401(FBD)@LQFP64 [(PEP+S616)]  
P89LPC9401(FBD)@LQFP64(ISP) [ISP-HEADER01]  
P89LPC9408(FBD)@LQFP64 [(PEP+S625)]  
P89LPC9408(FBD)@LQFP64(ISP) [ISP-HEADER01]  
P89LPC952@LQFP44 [(SA245A)]  
P89LPC952@LQFP44(ISP) [ISP-HEADER01]  
P89LPC952@LQFP48 [(SA248)]  
P89LPC952@LQFP48(ISP) [ISP-HEADER01]  
P89LPC952@PLCC44 [(SA244)]  
P89LPC952@PLCC44(ISP) [ISP-HEADER01]  
P89LPC954@LQFP44 [(SA245A)]

P89LPC954@LQFP44( ISP) [ ISP-HEADER01 ]  
P89LPC954@LQFP48 [ (SA248) ]  
P89LPC954@LQFP48( ISP) [ ISP-HEADER01 ]  
P89LPC954@PLCC44 [ (SA244) ]  
P89LPC954@PLCC44( ISP) [ ISP-HEADER01 ]  
P89LV51RB2 P89LV51RB2@PLCC44  
[ (SA244) ]  
P89LV51RB2@TQFP44 [ (SA245A) ]  
P89LV51RC2  
P89LV51RC2@PLCC44 [ (SA244) ] P89LV51RC2@TQFP44  
[ (SA245A) ]  
P89LV51RD2 P89LV51RD2  
(new)  
P89LV51RD2(new)@PLCC44 [ (SA244) ]  
P89LV51RD2(new)@TQFP44 [ (SA245A) ]  
P89LV51RD2@PLCC44 [ (SA244) ] P89LV51RD2@TQFP44  
[ (SA245A) ]  
P89LV51RD2BA(new)@PLCC44 [ (SA244) ]  
P89LV51RD2BA@PLCC44 [ (SA244) ]  
P89LV51RD2BBC(new)@TQFP44 [ (SA245A) ]  
P89LV51RD2BBC@TQFP44 [ (SA245A) ]  
P89LV51RD2BN  
P89LV51RD2BN(new)  
P89LV51RD2FA(new)@PLCC44 [ (SA244) ]  
P89LV51RD2FA@PLCC44 [ (SA244) ]  
P89LV51RD2FBC(new)@TQFP44 [ (SA245A) ]  
P89LV51RD2FBC@TQFP44 [ (SA245A) ]  
P89LV51RD2FN  
P89LV51RD2FN(new)  
P89V51RB2  
P89V51RB2@PLCC44 [ (SA244) ] P89V51RB2@TQFP44  
[ (SA245A) ]  
P89V51RC2 P89V51RC2@PLCC44  
[ (SA244) ]  
P89V51RC2@TQFP44 [ (SA245A) ]  
P89V51RD2  
P89V51RD2(new) P89V51RD2(new)@PLCC44  
[ (SA244) ]  
P89V51RD2(new)@TQFP44 [ (SA245A) ] P89V51RD2@PLCC44  
[ (SA244) ]  
P89V51RD2@TQFP44 [ (SA245A) ]  
P89V51RD2BA(new)@PLCC44 [ (SA244) ]  
P89V51RD2BA@PLCC44 [ (SA244) ]

P89V51RD2BBC(new)@TQFP44 [(SA245A)]  
P89V51RD2BBC@TQFP44 [(SA245A)]  
P89V51RD2BN  
P89V51RD2BN(new)  
P89V51RD2FA(new)@PLCC44 [(SA244)]  
P89V51RD2FA@PLCC44 [(SA244)]  
P89V51RD2FBC(new)@TQFP44 [(SA245A)]  
P89V51RD2FBC@TQFP44 [(SA245A)]  
P89V51RD2FN  
P89V51RD2FN(new)  
P89V52X2  
P89V52X2(ISP) [ISP-HEADER01] P89V52X2@PLCC44  
[(SA244)]  
P89V52X2@PLCC44(ISP) [ISP-HEADER01]  
P89V52X2@TQFP44 [(SA245A)]  
P89V52X2@TQFP44(ISP) [ISP-HEADER01]  
P89V660@PLCC44 [(SA244)] P89V660@TQFP44  
[(SA245A)]  
P89V662@PLCC44 [(SA244)] P89V662@TQFP44  
[(SA245A)]  
P89V664@PLCC44 [(SA244)] P89V664@TQFP44  
[(SA245A)]  
PXAC37@PLCC44 [(SA244)] PXAC37@TQFP44  
[(SA245A)]  
PXAG17@PLCC44 [(SA244)] PXAG17@TQFP44  
[(SA245A)]  
PXAG27@PLCC44 [(SA244)] PXAG27@TQFP44  
[(SA245A)]  
PXAG37@PLCC44 [(SA244)] PXAG37@TQFP44  
[(SA245A)]  
PXAG39@PLCC44 [(SA244)] PXAG39@TQFP44  
[(SA245A)]  
PXAG49@PLCC44 [(SA244)] PXAG49@TQFP44  
[(SA245A)]  
PXAS37@PLCC68 [(PEP+S414T)] PXAS37@PQFP80 [(PEP  
+S640B)]  
TDA11105PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11106PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11112PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11115PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11116PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11125PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11126PS/N1/3@SDIP64(\*) [(SA736+B215)]



TDA11135PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11136PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11142PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11145PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11146PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11155PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA11156PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12135PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12136PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12155PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12156PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12165PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12166PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12175PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12176PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12185PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12186PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12195PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12196PS/N1/3@SDIP64(\*) [(SA736+B215)]  
UOCIIIN1A-128K@QIP90 [(TA025)]  
UOCIIIN1A-128K@QIP90(facedown) [(TA021A)]  
UOCIIIN1A-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1A-128K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1A-256K@QIP90 [(TA025)]  
UOCIIIN1A-256K@QIP90(facedown) [(TA021A)]  
UOCIIIN1A-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1A-256K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1B-128K@QIP90 [(TA025)]  
UOCIIIN1B-128K@QIP90(facedown) [(TA021A)]  
UOCIIIN1B-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1B-128K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1B-256K@QIP90 [(TA025)]  
UOCIIIN1B-256K@QIP90(facedown) [(TA021A)]  
UOCIIIN1B-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1B-256K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1D-128K@QIP90 [(TA025)]  
UOCIIIN1D-128K@QIP90(facedown) [(TA021A)]  
UOCIIIN1D-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1D-128K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1D-256K@QIP90 [(TA025)]  
UOCIIIN1D-256K@QIP90(facedown) [(TA021A)]  
UOCIIIN1D-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1D-256K@TQFP128(facedown) [(TA024-B115)]

UOCIIIN1E-128K@QIP90 [(TA025)]  
 UOCIIIN1E-128K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1E-128K@TQFP128 [(TA023-B115)]  
 UOCIIIN1E-128K@TQFP128(facedown) [(TA024-B115)]  
 UOCIIIN1E-256K@QIP90 [(TA025)]  
 UOCIIIN1E-256K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1E-256K@TQFP128 [(TA023-B115)]  
 UOCIIIN1E-256K@TQFP128(facedown) [(TA024-B115)]  
 UOCIIIN1F-128K@QIP90 [(TA025)]  
 UOCIIIN1F-128K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1F-128K@TQFP128 [(TA023-B115)]  
 UOCIIIN1F-128K@TQFP128(facedown) [(TA024-B115)]  
 UOCIIIN1F-256K@QIP90 [(TA025)]  
 UOCIIIN1F-256K@QIP90(facedown) [(TA021A)]  
 UOCIIIN1F-256K@TQFP128 [(TA023-B115)]  
 UOCIIIN1F-256K@TQFP128(facedown) [(TA024-B115)]

## OKI

### E (E) PROM/FRAM/NVRAM

MR27C1602B [(SA638)]	MR27C1602B@PSOP44
MR27V1602D [(SA638)]	MR27V1602D@PSOP44
MR27V1602D@TSOP44 [(SA645)] B005)]	MR27V1602D@TSOP48 [(SA247- B005)]
MR27V1602E [(SA638)]	MR27V1602E@PSOP44
MR27V1602E@TSOP44 [(SA645)] B005)]	MR27V1602E@TSOP48 [(SA247- B005)]
MR27V1602F [(SA638)]	MR27V1602F@PSOP44
MR27V1602F@TSOP44 [(SA645)] B005)]	MR27V1602F@TSOP48 [(SA247- B005)]
MR27V1652D [(SA638)]	MR27V1652D@PSOP44
MR27V1652D@TSOP44 [(SA645)] B005)]	MR27V1652D@TSOP48 [(SA247- B005)]
MR27V3202F@TSOP44 [(SA645)] B005)]	MR27V3202F@TSOP48 [(SA247- B005)]
MR27V401D	MR27V401D@PSOP32

[ ( SA638 ) ]	
MR27V401D@TSOP32 [ ( SA620 ) ]	
MR27V401E	
MR27V401E@PSOP32 [ ( SA638 ) ]	MR27V401E@TSOP32
[ ( SA620 ) ]	
MR27V402D	
[ ( SA661 ) ]	
MR27V402D@TSOP44 [ ( SA645 ) ]	
MR27V402E	
MR27V402E@PSOP40 [ ( SA661 ) ]	MR27V402E@TSOP44
[ ( SA645 ) ]	
MR27V6402D@PSOP44 [ ( SA638 ) ]	MR27V6402D@TSOP44
[ ( SA645 ) ]	
MR27V6402D@TSOP48 [ ( SA247-B005 ) ]	MR27V6402G@PSOP44
[ ( SA638 ) ]	
MR27V6402G@TSOP44 [ ( SA645 ) ]	MR27V6402G@TSOP48 [ ( SA247-
B005 ) ]	
MR27V802D	
[ ( SA638 ) ]	MR27V802D@PSOP44
MR27V802D@TSOP44 [ ( SA645 ) ]	
[ ( SA638 ) ]	
MR27V802F@TSOP44 [ ( SA645 ) ]	MR27V802F@PSOP44
B005 ) ]	
MR27V852D	
[ ( SA638 ) ]	MR27V802F@TSOP48 [ ( SA247-
MR27V852D@TSOP44 [ ( SA645 ) ]	
MR27V852E	
MR27V852E@SOJ42 [ ( SA661 ) ]	MR27V852D@PSOP44
( 08bit )	
MSM16812(08bit)@SOIC8 [ ( SA602A ) ]	
MSM271000	
MSM271000@PLCC32 [ ( SA015A1T ) ]	MSM16812
[ ( SA410T ) ]	
MSM27128	
MSM27128A	
MSM27128AS	MSM271000@TSOP32
RS	
MSM2716	
MSM27256	
MSM27256AS	MSM27128AZB-
RS	
MSM2732	
MSM2732A	MSM27256ZB-

MSM27512  
MSM27512AS  
MSM27512ZB-RS  
MSM2764  
MSM2764A  
MSM2764AS  
MSM2764AZB-RS  
MSM2764RS  
MSM27C1024  
MSM27C1024AS  
MSM27C128  
RS  
MSM27C1602CZ  
[ ( SA638 ) ]  
MSM27C1602CZ@TSOP48 [ ( SA247-B005 ) ]  
MSM27C1652CZ  
[ ( SA638 ) ]  
MSM27C1652CZ@TSOP48 [ ( SA247-B005 ) ]  
MSM27C256  
MSM27C256A  
MSM27C256H  
MSM27C256HZB  
MSM27C256ZB  
MSM27C64AS  
MSM27C802CZ  
[ ( SA638 ) ]  
MSM27C802CZ@TSOP44 [ ( SA645 ) ]  
MSM27C852CZ  
MSM27C852CZ@PSOP44 [ ( SA638 ) ]  
[ ( SA645 ) ]  
MSM2816A(RS)  
MSM28C16A

MSM27C128AZB-  
  
MSM27C1602CZ@PSOP44  
  
MSM27C1652CZ@PSOP44  
  
  
  
  
  
  
  
  
  
MSM27C802CZ@PSOP44  
  
  
MSM27C852CZ@TSOP44

## DRAM & SRAM

MSM51256  
[ ( SA630 ) ]  
MSM51257AL  
[ ( SA630 ) ]  
MSM51257ALL  
[ ( SA630 ) ]  
MSM5165AL

MSM51256@SOIC28  
  
MSM51257AL@SOIC28  
  
MSM51257ALL@SOIC28  
  
MSM5165AL@SOIC28

[ ( SA630 ) ]  
MSM5188  
[ ( SA646 ) ]

MSM5188@SOJ22

## **PARALLAX**

### **MICROCONTROLLER**

SX20AC/SS/G@SSOP20 [ ( SA626A ) ]  
[ ( SA626A ) ]  
SX28AC/DP  
G  
SX28AC/SS/G@SSOP28 [ ( SA626A ) ]  
[ ( SA626A ) ]  
SX48BD/G@TQFP48 [ ( SA248 ) ]  
[ ( SA248 ) ]

SX20AC/SS@SSOP20  
  
SX28AC/DP/  
  
SX28AC/SS@SSOP28  
  
SX48BD@TQFP48

## **PFLASH(MSTAR)**

### **E ( E ) PROM / FRAM / NVRAM**

PS25LV010A@SOIC8 [ ( SA602A ) ]  
[ ( SA683 ) ]  
PS25LV020@SOIC8 [ ( SA602A ) ]  
[ ( SA683 ) ]  
PS25LV040@SOIC8 [ ( SA605A ) ]  
[ ( SA683 ) ]  
PS25LV080@SOIC8 [ ( SA605A ) ]  
[ ( SA683 ) ]

PS25LV010A@WSON8  
  
PS25LV020@WSON8  
  
PS25LV040@WSON8  
  
PS25LV080@WSON8

## **PHILIPS**

### **E ( E ) PROM / FRAM / NVRAM**

27C010  
[ ( SA015A1T ) ]  
27C010@TSOP32 [ ( SA410T ) ]  
27C040  
27C040@PLCC32 [ ( SA015A1T ) ]

27C010@PLCC32  
  
  
  
27C040@TSOP32

[(SA410T)]	
27C210	27C210@PLCC44
[(SA244)]	
27C240	27C240@PLCC44
[(SA244)]	
27C256	27C256@PLCC32
[(SA015A1T)]	
27C32	
27C512	
27C512@PLCC32 [(SA015A1T)]	
27C64	
27C64@PLCC32 [(SA015A1T)]	
27C64A	
27C64A@PLCC32 [(SA015A1T)]	
27C64AF	
27C64AF@PLCC32 [(SA015A1T)]	
27HC641	
27HC641@PLCC28 [(SA008A)]	
27PC32	
PCA24S08@SOIC8 [(SA602A)]	PCA24S08@TSSOP8
[(SA026)]	
PCA8574(P)	PCA8574(T)@SOIC16
[(SA404)]	
PCA8574(TS)@SSOP20 [(SA026)]	PCA8574A
(P)	
PCA8574A(T)@SOIC16 [(SA404)]	PCA8574A(TS)@SSOP20
[(SA026)]	
PCA8581	PCA8581@SOIC8
[(SA602A)]	
PCA8581C	PCA8581C@SOIC8
[(SA602A)]	
PCA8582A	PCA8582A@SOIC8
[(SA602A)]	
PCA8582B	PCA8582B@SOIC8
[(SA602A)]	
PCA8582C	PCA8582C@SOIC8
[(SA602A)]	
PCA8582D	PCA8582D@SOIC8
[(SA602A)]	
PCA8582E	PCA8582E@SOIC8
[(SA602A)]	
PCA9500@HQVFN16	PCA9500@SOIC16
[(SA404)]	

PCA9500@TSSOP16 [(SA026)]  
PCA9501@HQVFN20  
PCA9501@SOIC20 [(SA404)]  
[(SA026)]  
PCA9561D@SOP20 [(SA404)]  
[(SA026)]  
PCD8581  
[(SA602A)]  
PCD8581C  
[(SA602A)]  
PCD8582A  
[(SA602A)]  
PCD8582B  
[(SA602A)]  
PCD8582C  
[(SA602A)]  
PCD8582D  
[(SA602A)]  
PCD8582E  
[(SA602A)]  
PCF85102C  
[(SA602A)]  
PCF85103C  
[(SA602A)]  
PCF85116  
[(SA602A)]  
PCF8581  
[(SA602A)]  
PCF8581C  
[(SA602A)]  
PCF8582A  
[(SA602A)]  
PCF8582B  
[(SA602A)]  
PCF8582C  
[(SA602A)]  
PCF8582D  
[(SA602A)]  
PCF8582E  
[(SA602A)]  
PCF8594  
[(SA626A)]  
PCF8594C

PCA9501@TSSOP20  
PCA9561W@TSSOP20  
PCD8581@SOIC8  
PCD8581C@SOIC8  
PCD8582A@SOIC8  
PCD8582B@SOIC8  
PCD8582C@SOIC8  
PCD8582D@SOIC8  
PCD8582E@SOIC8  
PCF85102C@SOIC8  
PCF85103C@SOIC8  
PCF85116@SOIC8  
PCF8581@SOIC8  
PCF8581C@SOIC8  
PCF8582A@SOIC8  
PCF8582B@SOIC8  
PCF8582C@SOIC8  
PCF8582D@SOIC8  
PCF8582E@SOIC8  
PCF8594@SOIC8  
PCF8594C@SOIC8

[ ( SA626A ) ]	
PCF8594D	PCF8594D@SOIC8
[ ( SA626A ) ]	
PCF8594E	PCF8594E@SOIC8
[ ( SA626A ) ]	
PCF8598	PCF8598@SOIC8
[ ( SA626A ) ]	
PCF8598C	PCF8598C@SOIC8
[ ( SA626A ) ]	
PCF8598D	PCF8598D@SOIC8
[ ( SA626A ) ]	
PCF8598E	PCF8598E@SOIC8
[ ( SA626A ) ]	

## BPROM

82S126	
82S126A	
82S129	
82S129A	
82S130	
82S130A	
82S131	
82S131A	
82S140	
82S141	
82S191	
82S191A	
82S191B	
82S191C	
N82LS135	N82LS135@PLCC20
[ ( SA001A ) ]	
N82S123	
N82S123A	
N82S135	N82S135@PLCC20
[ ( SA001A ) ]	
N82S136	
N82S137	
N82S137A	
N82S137B	
N82S137C	
N82S146	



N82S146@PLCC20 [(SA001A)]  
N82S147  
N82S147@PLCC20 [(SA001A)]  
N82S147A  
N82S147A@PLCC20 [(SA001A)]  
N82S147B  
N82S147B@PLCC20 [(SA001A)]  
N82S167  
N82S184  
N82S184A  
N82S185  
N82S185A  
N82S185B  
N82S185C  
N82S23  
N82S23A

**PLD**

82S100	
82S101	
82S105	82S105A@PLCC28
[(SA008A)]	
82S152	82S152@PLCC20
[(SA001A)]	
82S153	82S153@PLCC20
[(SA001A)]	
82S155	82S155@PLCC20
[(SA001A)]	
82S157	82S157@PLCC20
[(SA001A)]	
82S159	82S159@PLCC20
[(SA001A)]	
82S167	82S167@PLCC28
[(SA008A)]	
82S168	82S168@PLCC28
[(SA008A)]	
82S173	82S173@PLCC28
[(SA008A)]	
82S179	82S179@PLCC28
[(SA008A)]	
PLS100	PLS100@PLCC28

[ (SA008A) ]	
PLS101	PLS101@PLCC28
[ (SA008A) ]	
PLS104	PLS104@PLCC28
[ (SA008A) ]	
PLS104A	PLS104A@PLCC28
[ (SA008A) ]	
PLS105	PLS105@PLCC28
[ (SA008A) ]	
PLS105A	PLS105A@PLCC28
[ (SA008A) ]	
PLS152	PLS152@PLCC20
[ (SA001A) ]	
PLS153	PLS153@PLCC20
[ (SA001A) ]	
PLS153A	PLS153A@PLCC20
[ (SA001A) ]	
PLS155	PLS155@PLCC20
[ (SA001A) ]	
PLS157	PLS157@PLCC20
[ (SA001A) ]	
PLS159	PLS159@PLCC20
[ (SA001A) ]	
PLS159A	PLS159A@PLCC20
[ (SA001A) ]	
PLS167	PLS167@PLCC28
[ (SA008A) ]	
PLS167A	PLS167A@PLCC28
[ (SA008A) ]	
PLS168	PLS168@PLCC28
[ (SA008A) ]	
PLS168A	PLS168A@PLCC28
[ (SA008A) ]	
PLS173	PLS173@PLCC28
[ (SA008A) ]	
PLS179	PLS179@PLCC28
[ (SA008A) ]	
PLUS105	PLUS105@PLCC28
[ (SA008A) ]	
PZ3032@PLCC44 [ (SA244) ]	PZ3032@TQFP44
[ (SA245A) ]	
PZ3032CS@PLCC44 [ (SA244) ]	PZ3032CS@TQFP44
[ (SA245A) ]	

PZ3064@PLCC44 [(SA244)] +S414T)]	PZ3064@PLCC68 [(PEP
PZ3064@PLCC84 [(PEP+S416T)] +S427)]	PZ3064@PQFP100 [(PEP
PZ3064@TQFP100 [(PEP+S604)] [(SA245A)]	PZ3064@TQFP44
PZ3128@PLCC84 [(PEP+S416T)] +S427)]	PZ3128@PQFP100 [(PEP
PZ3128@TQFP100 [(PEP+S604)] [(SA244)]	PZ5032@PLCC44
PZ5032@TQFP44 [(SA245A)] [(SA244)]	PZ5032CS@PLCC44
PZ5032CS@TQFP44 [(SA245A)] [(SA244)]	PZ5064@PLCC44
PZ5064@PLCC68 [(PEP+S414T)] +S416T)]	PZ5064@PLCC84 [(PEP
PZ5064@PQFP100 [(PEP+S427)] +S604)]	PZ5064@TQFP100 [(PEP
PZ5064@TQFP44 [(SA245A)] +S416T)]	PZ5128@PLCC84 [(PEP
PZ5128@PQFP100 [(PEP+S427)] +S604)]	PZ5128@TQFP100 [(PEP

## MICROCONTROLLER

LPC2101FBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2102FBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2103FA44@PLCC44(\*) [(SA244-B4403)]  
 LPC2103FBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2104BBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2105BBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2106BBD48@LQFP48(\*) [(SA248-B4801)]  
 LPC2114FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2119FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2124FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2129FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2131FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2131FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2132FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2132FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2134FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2134FBD64@LQFP64(\*\*) [(SA732-B330)]

LPC2136FBD64@LQFP64(*) [(TA027-B4801)]	
LPC2136FBD64@LQFP64(**) [(SA732-B330)]	
LPC2138FBD64@LQFP64(*) [(TA027-B4801)]	
LPC2138FBD64@LQFP64(**) [(SA732-B330)]	
LPC2141FBD64@LQFP64(*) [(TA027-B4801)]	
LPC2142FBD64@LQFP64(*) [(TA027-B4801)]	
LPC2144FBD64@LQFP64(*) [(TA027-B4801)]	
LPC2146FBD64@LQFP64(*) [(TA027-B4801)]	
LPC2148FBD64@LQFP64(*) [(TA027-B4801)]	
LPC2194HBD64@LQFP64(*) [(TA027-B4801)]	
LPC2212HBD144@LQFP144(*) [(TA044-B4802)]	
LPC2214FBD144@LQFP144(*) [(TA044-B4802)]	
LPC2292HBD144@LQFP144(*) [(TA044-B4802)]	
LPC2294HBD144@LQFP144(*) [(TA044-B4802)]	
LPC2364@LQFP100(*) [(SA718+B243)]	
LPC2366@LQFP100(*) [(SA718+B243)]	
LPC2368@LQFP100(*) [(SA718+B243)]	
P83C660X2@PLCC44 [(SA244)]	P83C660X2@TQFP44
[(SA245A)]	
P83C661X2@PLCC44 [(SA244)]	P83C661X2@TQFP44
[(SA245A)]	
P87C054@SDIP42 [(SA028)]	P87C055@SDIP42
[(SA028)]	
P87C451@PLCC68 [(PEP+S414T)]	P87C451@SDIP64 [(PEP
+S600A)]	
P87C453@PLCC68 [(PEP+S414T)]	
P87C51	
P87C51@PLCC44 [(SA244)]	P87C51@TQFP44
[(SA245A)]	
P87C51FA	P87C51FA@PLCC44
[(SA244)]	
P87C51FA@TQFP44 [(SA245A)]	
P87C51FB	
P87C51FB@PLCC44 [(SA244)]	P87C51FB@TQFP44
[(SA245A)]	
P87C51FC	P87C51FC@PLCC44
[(SA244)]	
P87C51FC@TQFP44 [(SA245A)]	P87C51MA2@PLCC44
[(SA244)]	
P87C51MB2@PLCC44 [(SA244)]	P87C51MC2@PLCC44
[(SA244)]	
P87C51RA+	P87C51RA+@PLCC44
[(SA244)]	

P87C51RA+@TQFP44 [(SA245A)]	
P87C51RA2	
P87C51RA2@PLCC44 [(SA244)]	P87C51RA2@TQFP44
[(SA245A)]	
P87C51RB+	P87C51RB+@PLCC44
[(SA244)]	
P87C51RB+@TQFP44 [(SA245A)]	
P87C51RB2	
P87C51RB2@PLCC44 [(SA244)]	P87C51RB2@TQFP44
[(SA245A)]	
P87C51RC+	P87C51RC+@PLCC44
[(SA244)]	
P87C51RC+@TQFP44 [(SA245A)]	
P87C51RC2	
P87C51RC2@PLCC44 [(SA244)]	P87C51RC2@TQFP44
[(SA245A)]	
P87C51RD+	P87C51RD+@PLCC44
[(SA244)]	
P87C51RD+@TQFP44 [(SA245A)]	
P87C51RD2	
P87C51RD2@PLCC44 [(SA244)]	P87C51RD2@TQFP44
[(SA245A)]	
P87C51SB	P87C51SB@PLCC44
[(SA244)]	
P87C51SB@TQFP44 [(SA245A)]	
P87C51SF	
P87C51SF@PLCC44 [(SA244)]	P87C51SF@TQFP44
[(SA245A)]	
P87C51UB	P87C51UB@PLCC44
[(SA244)]	
P87C51UB@TQFP44 [(SA245A)]	
P87C51UF	
P87C51UF@PLCC44 [(SA244)]	P87C51UF@TQFP44
[(SA245A)]	
P87C51X2	P87C51X2@PLCC44
[(SA244)]	
P87C51X2@TQFP44 [(SA245A)]	
P87C52	
P87C52@PLCC44 [(SA244)]	P87C52@TQFP44
[(SA245A)]	
P87C524	P87C524@PLCC44
[(SA244)]	
P87C524@TQFP44 [(SA245A)]	

P87C528

P87C528@PLCC44 [(SA244)]

[(SA245A)]

P87C52SB

[(SA244)]

P87C52SB@TQFP44 [(SA245A)]

P87C52SF

P87C52SF@PLCC44 [(SA244)]

[(SA675)]

P87C52UB

[(SA244)]

P87C52UB@TQFP44 [(SA245A)]

P87C52UF

P87C52UF@PLCC44 [(SA244)]

[(SA245A)]

P87C52X2

[(SA244)]

P87C52X2@TQFP44 [(SA245A)]

P87C54

P87C54@PLCC44 [(SA244)]

[(SA245A)]

P87C54SB

[(SA244)]

P87C54SB@TQFP44 [(SA245A)]

P87C54SF

P87C54SF@PLCC44 [(SA244)]

[(SA245A)]

P87C54UB

[(SA244)]

P87C54UB@TQFP44 [(SA245A)]

P87C54UF

P87C54UF@PLCC44 [(SA244)]

[(SA245A)]

P87C54X2

[(SA244)]

P87C54X2@TQFP44 [(SA245A)]

P87C550

P87C550@PLCC44 [(SA244)]

+S414T)]

P87C552@PLCC68(\*) [(SA648-B6806)]

P87C554@LQFP64 [(PEP+S616)]

+S414T)]

P87C554@PLCC68(\*) [(SA648-B6806)]

P87C528@TQFP44

P87C52SB@PLCC44

P87C52SF@TQFP44

P87C52UB@PLCC44

P87C52UF@TQFP44

P87C52X2@PLCC44

P87C54@TQFP44

P87C54SB@PLCC44

P87C54SF@TQFP44

P87C54UB@PLCC44

P87C54UF@TQFP44

P87C54X2@PLCC44

P87C552@PLCC68 [(PEP

P87C554@PLCC68 [(PEP

P87C557E8@PQFP80 [(PEP+S611A)]

P87C575

P87C575@PLCC44 [(SA244)]

[(SA245A)]

P87C576

[(SA244)]

P87C576@TQFP44 [(SA245A)]

P87C58

P87C58@PLCC44 [(SA244)]

[(SA245A)]

P87C58SB

[(SA244)]

P87C58SB@TQFP44 [(SA245A)]

P87C58UB

P87C58UB@PLCC44 [(SA244)]

[(SA245A)]

P87C58X2

[(SA244)]

P87C58X2@TQFP44 [(SA245A)]

[(SA244)]

P87C591@TQFP44 [(SA245A)]

+S414T)]

P87C652

[(SA244)]

P87C652@TQFP44 [(SA245A)]

P87C654

P87C654@PLCC44 [(SA244)]

[(SA245A)]

P87C660X2@PLCC44 [(SA244)]

[(SA245A)]

P87C661X2@PLCC44 [(SA244)]

[(SA245A)]

P87C748

[(SA008A)]

P87C749

[(SA008A)]

P87C750

[(SA008A)]

P87C750@SSOP24 [(SA626A)]

P87C751

P87C751@PLCC28 [(SA008A)]

[(SA626A)]

P87C752

P87C575@TQFP44

P87C576@PLCC44

P87C58@TQFP44

P87C58SB@PLCC44

P87C58UB@TQFP44

P87C58X2@PLCC44

P87C591@PLCC44

P87C592@PLCC68 [(PEP

P87C652@PLCC44

P87C654@TQFP44

P87C660X2@TQFP44

P87C661X2@TQFP44

P87C748@PLCC28

P87C749@PLCC28

P87C750@PLCC28

P87C751@SSOP24

P87C752@PLCC28

[ (SA008A) ]  
 P87C752@SSOP28 [ (SA626A) ]  
 P87C754  
 P87C754@PLCC28 [ (SA008A) ] P87C754@SSOP28  
 [ (SA626A) ]  
 P87CL52X2 P87CL52X2@PLCC44  
 [ (SA244) ]  
 P87CL52X2@TQFP44 [ (SA245A) ]  
 P87CL54X2  
 P87CL54X2@PLCC44 [ (SA244) ] P87CL54X2@TQFP44  
 [ (SA245A) ]  
 P87L51FA P87L51FA@PLCC44  
 [ (SA244) ]  
 P87L51FA@TQFP44 [ (SA245A) ]  
 P87L51FB  
 P87L51FB@PLCC44 [ (SA244) ] P87L51FB@TQFP44  
 [ (SA245A) ]  
 P87LPC759 P87LPC759 (ISP) [ ISP-  
 HEADER01 ]  
 P87LPC760 P87LPC760 (ISP) [ ISP-  
 HEADER01 ]  
 P87LPC760@TSSOP14 [ (SA026) ]  
 P87LPC760@TSSOP14 (ISP) [ ISP-HEADER01 ]  
 P87LPC761 P87LPC761 (ISP) [ ISP-  
 HEADER01 ]  
 P87LPC762 P87LPC762 (ISP) [ ISP-  
 HEADER01 ]  
 P87LPC762@PLCC44 [ (SA244) ]  
 P87LPC762@PLCC44 (ISP) [ ISP-HEADER01 ]  
 P87LPC762@SOIC20 [ (SA404) ]  
 P87LPC762@SOIC20 (ISP) [ ISP-HEADER01 ]  
 P87LPC764 P87LPC764 (ISP) [ ISP-  
 HEADER01 ]  
 P87LPC764@PLCC44 [ (SA244) ]  
 P87LPC764@PLCC44 (ISP) [ ISP-HEADER01 ]  
 P87LPC764@SOIC20 [ (SA404) ]  
 P87LPC764@SOIC20 (ISP) [ ISP-HEADER01 ]  
 P87LPC764@TSSOP20 [ (SA643) ]  
 P87LPC764@TSSOP20 (ISP) [ ISP-HEADER01 ]  
 P87LPC767 P87LPC767 (ISP) [ ISP-  
 HEADER01 ]  
 P87LPC767@PLCC44 [ (SA244) ]  
 P87LPC767@PLCC44 (ISP) [ ISP-HEADER01 ]



P87LPC767@SOIC20 [(SA404)]  
 P87LPC767@SOIC20(ISP) [ISP-HEADER01]  
 P87LPC768 P87LPC768(ISP) [ISP-  
 HEADER01]  
 P87LPC768@SOIC20 [(SA404)]  
 P87LPC768@SOIC20(ISP) [ISP-HEADER01]  
 P87LPC769 P87LPC769(ISP) [ISP-  
 HEADER01]  
 P87LPC769@PLCC44 [(SA244)]  
 P87LPC769@PLCC44(ISP) [ISP-HEADER01]  
 P87LPC769@SOIC20 [(SA404)]  
 P87LPC769@SOIC20(ISP) [ISP-HEADER01]  
 P87LPC778 P87LPC778(ISP) [ISP-  
 HEADER01]  
 P87LPC778@TSSOP20 [(SA026)]  
 P87LPC778@TSSOP20(ISP) [ISP-HEADER01]  
 P87LPC779 P87LPC779(ISP) [ISP-  
 HEADER01]  
 P87LPC779@TSSOP20 [(SA643)]  
 P87LPC779@TSSOP20(ISP) [ISP-HEADER01]  
 P89C138 P89C138@PLCC44  
 [(SA244)]  
 P89C138@TQFP44 [(SA245A)]  
 P89C238 P89C238@TQFP44  
 P89C238@PLCC44 [(SA244)]  
 [(SA245A)]  
 P89C51B P89C51B@PLCC44  
 [(SA244)]  
 P89C51B@TQFP44 [(SA245A)]  
 P89C51RA  
 + P89C51RA+@PLCC44 [(SA244)]  
 [(SA245A)]  
 P89C51RA2B P89C51RA2B@PLCC44  
 [(SA244)]  
 P89C51RA2B@TQFP44 [(SA245A)]  
 P89C51RB  
 + P89C51RB+@PLCC44 [(SA244)]  
 [(SA245A)]  
 P89C51RB2B P89C51RB2B@PLCC44  
 [(SA244)]  
 P89C51RB2B@TQFP44 [(SA245A)]  
 P89C51RB2H P89C51RB2H@TQFP44  
 P89C51RB2H@PLCC44 [(SA244)]

[ (SA245A) ]	
P89C51RC+	P89C51RC+@PLCC44
[ (SA244) ]	
P89C51RC+@TQFP44 [ (SA245A) ]	
P89C51RC2B	
P89C51RC2B@PLCC44 [ (SA244) ]	P89C51RC2B@TQFP44
[ (SA245A) ]	
P89C51RC2H	P89C51RC2H@PLCC44
[ (SA244) ]	
P89C51RC2H@TQFP44 [ (SA245A) ]	P89C51RD
+	
P89C51RD+@PLCC44 [ (SA244) ]	P89C51RD+@TQFP44
[ (SA245A) ]	
P89C51RD2B	P89C51RD2B@PLCC44
[ (SA244) ]	
P89C51RD2B@TQFP44 [ (SA245A) ]	
P89C51RD2H	
P89C51RD2H@PLCC44 [ (SA244) ]	P89C51RD2H@TQFP44
[ (SA245A) ]	
P89C51UB	P89C51UB@PLCC44
[ (SA244) ]	
P89C51UB@TQFP44 [ (SA245A) ]	
P89C51UF	
P89C51UF@PLCC44 [ (SA244) ]	P89C51UF@TQFP44
[ (SA245A) ]	
P89C51X2	P89C51X2@PLCC44
[ (SA244) ]	
P89C51X2@TQFP44 [ (SA245A) ]	
P89C51X2B	
P89C51X2B@PLCC44 [ (SA244) ]	P89C51X2B@TQFP44
[ (SA245A) ]	
P89C51X2F	P89C51X2F@PLCC44
[ (SA244) ]	
P89C51X2F@TQFP44 [ (SA245A) ]	
P89C52	
P89C52@PLCC44 [ (SA244) ]	P89C52@TQFP44
[ (SA245A) ]	
P89C52B	P89C52B@PLCC44
[ (SA244) ]	
P89C52B@TQFP44 [ (SA245A) ]	
P89C52UB	
P89C52UB@PLCC44 [ (SA244) ]	P89C52UB@TQFP44
[ (SA245A) ]	

P89C52UF [ (SA244) ]	P89C52UF@PLCC44
P89C52UF@TQFP44 [ (SA245A) ]	
P89C52X2 P89C52X2@PLCC44 [ (SA244) ] [ (SA245A) ]	P89C52X2@TQFP44
P89C52X2B [ (SA244) ]	P89C52X2B@PLCC44
P89C52X2B@TQFP44 [ (SA245A) ]	
P89C52X2F P89C52X2F@PLCC44 [ (SA244) ] [ (SA245A) ]	P89C52X2F@TQFP44
P89C536@PLCC44 [ (SA244) ] [ (SA244) ]	P89C538@PLCC44
P89C54 [ (SA244) ]	P89C54@PLCC44
P89C54@TQFP44 [ (SA245A) ]	
P89C54B P89C54B@PLCC44 [ (SA244) ] [ (SA245A) ]	P89C54B@TQFP44
P89C54UB [ (SA244) ]	P89C54UB@PLCC44
P89C54UB@TQFP44 [ (SA245A) ]	
P89C54UF P89C54UF@PLCC44 [ (SA244) ] [ (SA245A) ]	P89C54UF@TQFP44
P89C54X2 [ (SA244) ]	P89C54X2@PLCC44
P89C54X2@TQFP44 [ (SA245A) ]	
P89C54X2B P89C54X2B@PLCC44 [ (SA244) ] [ (SA245A) ]	P89C54X2B@TQFP44
P89C54X2F [ (SA244) ]	P89C54X2F@PLCC44
P89C54X2F@TQFP44 [ (SA245A) ]	
P89C58 P89C58@PLCC44 [ (SA244) ] [ (SA245A) ]	P89C58@TQFP44
P89C58B [ (SA244) ]	P89C58B@PLCC44
P89C58B@TQFP44 [ (SA245A) ]	
P89C58UB P89C58UB@PLCC44 [ (SA244) ]	P89C58UB@TQFP44

[ ( SA245A ) ]	
P89C58UF	P89C58UF@PLCC44
[ ( SA244 ) ]	
P89C58UF@TQFP44 [ ( SA245A ) ]	
P89C58X2	
P89C58X2@PLCC44 [ ( SA244 ) ]	P89C58X2@TQFP44
[ ( SA245A ) ]	
P89C58X2B	P89C58X2B@PLCC44
[ ( SA244 ) ]	
P89C58X2B@TQFP44 [ ( SA245A ) ]	
P89C58X2F	
P89C58X2F@PLCC44 [ ( SA244 ) ]	P89C58X2F@TQFP44
[ ( SA245A ) ]	
P89C60X2	P89C60X2@PLCC44
[ ( SA244 ) ]	
P89C60X2@TQFP44 [ ( SA245A ) ]	
P89C61X2	
P89C61X2@PLCC44 [ ( SA244 ) ]	P89C61X2@TQFP44
[ ( SA245A ) ]	
P89C660	P89C660@PLCC44
[ ( SA244 ) ]	
P89C660@TQFP44 [ ( SA245A ) ]	
P89C662	
P89C662@PLCC44 [ ( SA244 ) ]	P89C662@TQFP44
[ ( SA245A ) ]	
P89C664	P89C664@PLCC44
[ ( SA244 ) ]	
P89C664@TQFP44 [ ( SA245A ) ]	
P89C668	
P89C668@PLCC44 [ ( SA244 ) ]	P89C668@TQFP44
[ ( SA245A ) ]	
P89C669	P89C669@LQFP44
[ ( SA245A ) ]	
P89C669@PLCC44 [ ( SA244 ) ]	
P89C738	
P89C738@PLCC44 [ ( SA244 ) ]	P89C738@TQFP44
[ ( SA245A ) ]	
P89C838	P89C838@PLCC44
[ ( SA244 ) ]	
P89C838@TQFP44 [ ( SA245A ) ]	P89CV51RB2@PLCC44
[ ( SA244 ) ]	
P89CV51RB2@TQFP44 [ ( SA245A ) ]	P89CV51RC2@PLCC44
[ ( SA244 ) ]	

P89CV51RC2@TQFP44 [(SA245A)] P89CV51RD2@PLCC44  
[(SA244)]  
P89CV51RD2@TQFP44 [(SA245A)] P89LPC901(FD)  
[(SA602A)]  
P89LPC901(FD)(ISP) [ISP-HEADER01]  
P89LPC901(FN)  
P89LPC901(FN)(ISP) [ISP-HEADER01]  
P89LPC902(FD) [(SA602A)]  
P89LPC902(FD)(ISP) [ISP-HEADER01]  
P89LPC902(FN)  
P89LPC902(FN)(ISP) [ISP-HEADER01]  
P89LPC903(FD) [(SA602A)]  
P89LPC903(FD)(ISP) [ISP-HEADER01]  
P89LPC904(FD) [(SA605A)]  
P89LPC904(FD)(ISP) [ISP-HEADER01]  
P89LPC904(FN)  
P89LPC904(FN)(ISP) [ISP-HEADER01]  
P89LPC906(FD) [(SA605A)]  
P89LPC906(FD)(ISP) [ISP-HEADER01]  
P89LPC907(FD) [(SA605A)]  
P89LPC907(FD)(ISP) [ISP-HEADER01]  
P89LPC908(FD) [(SA605A)]  
P89LPC908(FD)(ISP) [ISP-HEADER01]  
P89LPC9102(FTK)@HVSON10 [(SA695A)]  
P89LPC9102(FTK)@HVSON10(ISP) [ISP-HEADER01]  
P89LPC9103(FTK)@HVSON10 [(SA695A)]  
P89LPC9103(FTK)@HVSON10(ISP) [ISP-HEADER01]  
P89LPC9107(FDH)@TSSOP14 [(SA643)]  
P89LPC9107(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC9107(FN)  
P89LPC9107(FN)(ISP) [ISP-HEADER01]  
P89LPC912(FDH)@TSSOP14 [(SA643)]  
P89LPC912(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC913(FDH)@TSSOP14 [(SA643)]  
P89LPC913(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC914(FDH)@TSSOP14 [(SA643)]  
P89LPC914(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC915(FDH)@TSSOP14 [(SA643)]  
P89LPC915(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC916(FDH)@TSSOP16 [(SA643)]  
P89LPC916(FDH)@TSSOP16(ISP) [ISP-HEADER01]  
P89LPC917(FDH)@TSSOP16 [(SA643)]  
P89LPC917(FDH)@TSSOP16(ISP) [ISP-HEADER01]

P89LPC920(FDH)@TSSOP20 [(SA643)]  
P89LPC920(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC920(FN)  
P89LPC920(FN)(ISP) [ISP-HEADER01]  
P89LPC921(FDH)@TSSOP20 [(SA643)]  
P89LPC921(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC921(FN)  
P89LPC921(FN)(ISP) [ISP-HEADER01]  
P89LPC922(FDH)@TSSOP20 [(SA643)]  
P89LPC922(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC922(FN)  
P89LPC922(FN)(ISP) [ISP-HEADER01]  
P89LPC9221(FDH)@TSSOP20 [(SA643)]  
P89LPC9221(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9221(FN)  
P89LPC9221(FN)(ISP) [ISP-HEADER01]  
P89LPC924(FDH)@TSSOP20 [(SA643)]  
P89LPC924(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC924(FN)  
P89LPC924(FN)(ISP) [ISP-HEADER01]  
P89LPC925(FDH)@TSSOP20 [(SA643)]  
P89LPC925(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC925(FN)  
P89LPC925(FN)(ISP) [ISP-HEADER01]  
P89LPC930(BA)@PLCC28 [(SA008A)]  
P89LPC930(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC930(BDH)@TSSOP28 [(SA643)]  
P89LPC930(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC931(BA)@PLCC28 [(SA008A)]  
P89LPC931(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC931(BDH)@TSSOP28 [(SA643)]  
P89LPC931(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932(BA)@PLCC28 [(SA008A)] P89LPC932(BDH)@TSSOP28  
[(SA643)]  
P89LPC932A1(BA)@PLCC28 [(SA008A)]  
P89LPC932A1(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC932A1(BDH)@TSSOP28 [(SA643)]  
P89LPC932A1(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932A1(FDH)@TSSOP28 [(SA643)]  
P89LPC932A1(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932A1(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC932A1(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC933(BDH)@TSSOP28 [(SA643)]

P89LPC933(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC933(FDH)@TSSOP28 [(SA643)]  
P89LPC933(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC934(BDH)@TSSOP28 [(SA643)]  
P89LPC934(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC934(FDH)@TSSOP28 [(SA643)]  
P89LPC934(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(BA)@PLCC28 [(SA008A)]  
P89LPC935(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(BDH)@TSSOP28 [(SA643)]  
P89LPC935(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(FA)@PLCC28 [(SA008A)]  
P89LPC935(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(FDH)@TSSOP28 [(SA643)]  
P89LPC935(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC935(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93501(BA)@PLCC28 [(SA008A)]  
P89LPC93501(BDH)@TSSOP28 [(SA643)]  
P89LPC93501(FA)@PLCC28 [(SA008A)]  
P89LPC93501(FDH)@TSSOP28 [(SA643)]  
P89LPC93501(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9351(BA)@PLCC28 [(SA008A)]  
P89LPC9351(BDH)@TSSOP28 [(SA643)]  
P89LPC9351(FA)@PLCC28 [(SA008A)]  
P89LPC9351(FDH)@TSSOP28 [(SA643)]  
P89LPC9351(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC936(FA)@PLCC28 [(SA008A)]  
P89LPC936(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC936(FDH)@TSSOP28 [(SA643)]  
P89LPC936(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC938(FA)@PLCC28 [(SA008A)]  
P89LPC938(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC938(FDH)@TSSOP28 [(SA643)]  
P89LPC938(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC938(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC938(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93801(BA)@PLCC28 [(SA008A)]  
P89LPC93801(BDH)@TSSOP28 [(SA643)]  
P89LPC93801(FA)@PLCC28 [(SA008A)]  
P89LPC93801(FDH)@TSSOP28 [(SA643)]  
P89LPC93801(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9381(BA)@PLCC28 [(SA008A)]

P89LPC9381(BDH)@TSSOP28 [(SA643)]  
 P89LPC9381(FA)@PLCC28 [(SA008A)]  
 P89LPC9381(FDH)@TSSOP28 [(SA643)]  
 P89LPC9381(FHN)@HVQFN28 [(SA685-B006)]  
 P89LPC9401(FBD)@LQFP64 [(PEP+S616)]  
 P89LPC9401(FBD)@LQFP64(ISP) [ISP-HEADER01]  
 P89LPC9408(FBD)@LQFP64 [(PEP+S625)]  
 P89LPC9408(FBD)@LQFP64(ISP) [ISP-HEADER01]  
 P89LPC952@LQFP44 [(SA245A)]  
 P89LPC952@LQFP44(ISP) [ISP-HEADER01]  
 P89LPC952@LQFP48 [(SA248)]  
 P89LPC952@LQFP48(ISP) [ISP-HEADER01]  
 P89LPC952@PLCC44 [(SA244)]  
 P89LPC952@PLCC44(ISP) [ISP-HEADER01]  
 P89LPC954@LQFP44 [(SA245A)]  
 P89LPC954@LQFP44(ISP) [ISP-HEADER01]  
 P89LPC954@LQFP48 [(SA248)]  
 P89LPC954@LQFP48(ISP) [ISP-HEADER01]  
 P89LPC954@PLCC44 [(SA244)]  
 P89LPC954@PLCC44(ISP) [ISP-HEADER01]  
 P89LV51RB2 P89LV51RB2@PLCC44  
 [(SA244)]  
 P89LV51RB2@TQFP44 [(SA245A)]  
 P89LV51RC2 P89LV51RC2@TQFP44  
 P89LV51RC2@PLCC44 [(SA244)]  
 [(SA245A)]  
 P89LV51RD2 P89LV51RD2  
 (new)  
 P89LV51RD2(new)@PLCC44 [(SA244)]  
 P89LV51RD2(new)@TQFP44 [(SA245A)]  
 P89LV51RD2@PLCC44 [(SA244)] P89LV51RD2@TQFP44  
 [(SA245A)]  
 P89LV51RD2BA(new)@PLCC44 [(SA244)]  
 P89LV51RD2BA@PLCC44 [(SA244)]  
 P89LV51RD2BBC(new)@TQFP44 [(SA245A)]  
 P89LV51RD2BBC@TQFP44 [(SA245A)]  
 P89LV51RD2BN  
 P89LV51RD2BN(new)  
 P89LV51RD2FA(new)@PLCC44 [(SA244)]  
 P89LV51RD2FA@PLCC44 [(SA244)]  
 P89LV51RD2FBC(new)@TQFP44 [(SA245A)]  
 P89LV51RD2FBC@TQFP44 [(SA245A)]  
 P89LV51RD2FN



P89LV51RD2FN(new)  
P89V51RB2  
P89V51RB2@PLCC44 [(SA244)]  
[(SA245A)]  
P89V51RC2  
[(SA244)]  
P89V51RC2@TQFP44 [(SA245A)]  
P89V51RD2  
P89V51RD2(new)  
[(SA244)]  
P89V51RD2(new)@TQFP44 [(SA245A)]  
[(SA244)]  
P89V51RD2@TQFP44 [(SA245A)]  
P89V51RD2BA(new)@PLCC44 [(SA244)]  
P89V51RD2BA@PLCC44 [(SA244)]  
P89V51RD2BBC(new)@TQFP44 [(SA245A)]  
P89V51RD2BBC@TQFP44 [(SA245A)]  
P89V51RD2BN  
P89V51RD2BN(new)  
P89V51RD2FA(new)@PLCC44 [(SA244)]  
P89V51RD2FA@PLCC44 [(SA244)]  
P89V51RD2FBC(new)@TQFP44 [(SA245A)]  
P89V51RD2FBC@TQFP44 [(SA245A)]  
P89V51RD2FN  
P89V51RD2FN(new)  
P89V52X2  
P89V52X2(ISP) [ISP-HEADER01]  
[(SA244)]  
P89V52X2@PLCC44(ISP) [ISP-HEADER01]  
P89V52X2@TQFP44 [(SA245A)]  
P89V52X2@TQFP44(ISP) [ISP-HEADER01]  
P89V660@PLCC44 [(SA244)]  
[(SA245A)]  
P89V662@PLCC44 [(SA244)]  
[(SA245A)]  
P89V664@PLCC44 [(SA244)]  
[(SA245A)]  
PSD301@PLCC44 [(SA244)]  
[(SA244)]  
PSD302@PLCC44 [(SA244)]  
[(SA244)]  
PSD303@PLCC44 [(SA244)]  
[(SA244)]  
P89V51RB2@TQFP44  
P89V51RC2@PLCC44  
P89V51RD2(new)@PLCC44  
P89V51RD2@PLCC44  
P89V52X2@PLCC44  
P89V660@TQFP44  
P89V662@TQFP44  
P89V664@TQFP44  
PSD301L@PLCC44  
PSD302L@PLCC44  
PSD303L@PLCC44

PSD311@PLCC44 [ (SA244) ] [ (SA244) ]	PSD311L@PLCC44
PSD312@PLCC44 [ (SA244) ] [ (SA244) ]	PSD312L@PLCC44
PSD313@PLCC44 [ (SA244) ] [ (SA245A) ]	PSD313@TQFP44
PSD313-B@PLCC44 [ (SA244) ] [ (SA245A) ]	PSD313-B@TQFP44
PSD313L@PLCC44 [ (SA244) ] [ (SA245A) ]	PSD313L@TQFP44
PXAC37@PLCC44 [ (SA244) ] [ (SA245A) ]	PXAC37@TQFP44
PXAG17@PLCC44 [ (SA244) ] [ (SA245A) ]	PXAG17@TQFP44
PXAG27@PLCC44 [ (SA244) ] [ (SA245A) ]	PXAG27@TQFP44
PXAG37@PLCC44 [ (SA244) ] [ (SA245A) ]	PXAG37@TQFP44
PXAG39@PLCC44 [ (SA244) ] [ (SA245A) ]	PXAG39@TQFP44
PXAG49@PLCC44 [ (SA244) ] [ (SA245A) ]	PXAG49@TQFP44
PXAS37@PLCC68 [ (PEP+S414T) ] +S640B) ]	PXAS37@PQFP80 [ (PEP
TDA11105PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA11106PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA11112PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA11115PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA11116PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA11125PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA11126PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA11135PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA11136PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA11142PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA11145PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA11146PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA11155PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA11156PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA12135PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA12136PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA12155PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA12156PS/N1/3@SDIP64(*) [ (SA736+B215) ]	
TDA12165PS/N1/3@SDIP64(*) [ (SA736+B215) ]	

TDA12166PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12175PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12176PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12185PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12186PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12195PS/N1/3@SDIP64(\*) [(SA736+B215)]  
TDA12196PS/N1/3@SDIP64(\*) [(SA736+B215)]  
UOCIIIN1A-128K@QIP90 [(TA025)]  
UOCIIIN1A-128K@QIP90(facedown) [(TA021A)]  
UOCIIIN1A-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1A-128K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1A-256K@QIP90 [(TA025)]  
UOCIIIN1A-256K@QIP90(facedown) [(TA021A)]  
UOCIIIN1A-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1A-256K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1B-128K@QIP90 [(TA025)]  
UOCIIIN1B-128K@QIP90(facedown) [(TA021A)]  
UOCIIIN1B-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1B-128K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1B-256K@QIP90 [(TA025)]  
UOCIIIN1B-256K@QIP90(facedown) [(TA021A)]  
UOCIIIN1B-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1B-256K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1D-128K@QIP90 [(TA025)]  
UOCIIIN1D-128K@QIP90(facedown) [(TA021A)]  
UOCIIIN1D-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1D-128K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1D-256K@QIP90 [(TA025)]  
UOCIIIN1D-256K@QIP90(facedown) [(TA021A)]  
UOCIIIN1D-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1D-256K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1E-128K@QIP90 [(TA025)]  
UOCIIIN1E-128K@QIP90(facedown) [(TA021A)]  
UOCIIIN1E-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1E-128K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1E-256K@QIP90 [(TA025)]  
UOCIIIN1E-256K@QIP90(facedown) [(TA021A)]  
UOCIIIN1E-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1E-256K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1F-128K@QIP90 [(TA025)]  
UOCIIIN1F-128K@QIP90(facedown) [(TA021A)]  
UOCIIIN1F-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1F-128K@TQFP128(facedown) [(TA024-B115)]

UOCIIIN1F-256K@QIP90 [(TA025)]  
UOCIIIN1F-256K@QIP90(facedown) [(TA021A)]  
UOCIIIN1F-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1F-256K@TQFP128(facedown) [(TA024-B115)]

## PJ

### E ( E ) PROM / FRAM / NVRAM

PJ24C02 [(SA602A)] PJ24C02@TSSOP8 [(SA026)]	PJ24C02@SOIC8
---------------------------------------------------	---------------

## PMC

### E ( E ) PROM / FRAM / NVRAM

PM24C64 [(SA602A)] PM24C64@TSOP8 [(SA026)] [(SA023A)] PM25LV010(Q)@WSON8 [(SA683)] [(SA602A)] PM25LV010A@SOIC8 [(SA602A)] [(SA683)] PM25LV016@SOIC8 [(SA605A)] [(SA683)] PM25LV016A@SOIC8 [(SA605A)] [(SA683)] PM25LV020(B)@SOIC8 [(SA023A)] [(SA683)] PM25LV020(S)@SOIC8 [(SA602A)] [(SA023A)] PM25LV040(Q)@WSON8 [(SA683)] [(SA602A)] PM25LV080@SOIC8 [(SA605A)] [(SA683)] PM25LV080A@SOIC8 [(SA605A)] [(SA683)] PM25LV512(B)@SOIC8 [(SA023A)]	PM24C64@SOIC8 PM25LV010(B)@SOIC8 PM25LV010(S)@SOIC8 PM25LV010A@WSON8 PM25LV016@WSON8 PM25LV016A@WSON8 PM25LV020(Q)@WSON8 PM25LV040(B)@SOIC8 PM25LV040(S)@SOIC8 PM25LV080@WSON8 PM25LV080A@WSON8 PM25LV512(Q)@WSON8
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

[ (SA683) ]	
PM25LV512(S)@SOIC8 [ (SA602A) ]	
PM29F002B	
PM29F002B@PLCC32 [ (SA015A1T) ]	
PM29F002T	
PM29F002T@PLCC32 [ (SA015A1T) ]	
PM29F004B	
PM29F004B@PLCC32 [ (SA015A1T) ]	
PM29F004T	
PM29F004T@PLCC32 [ (SA015A1T) ]	
PM29LV002B	
PM29LV002B@PLCC32 [ (SA015A1T) ]	PM29LV002B@VSOP32
[ (SA620) ]	
PM29LV002T	PM29LV002T@PLCC32
[ (SA015A1T) ]	
PM29LV002T@VSOP32 [ (SA620) ]	PM29LV004B@PLCC32
[ (SA015A1T) ]	
PM29LV004B@VSOP32 [ (SA620) ]	PM29LV004T@PLCC32
[ (SA015A1T) ]	
PM29LV004T@VSOP32 [ (SA620) ]	PM29LV104RB@PLCC32
[ (SA015A1T) ]	
PM29LV104RB@VSOP32 [ (SA620) ]	PM29LV104RT@PLCC32
[ (SA015A1T) ]	
PM29LV104RT@VSOP32 [ (SA620) ]	
PM37LV512	
PM37LV512@PLCC32 [ (SA015A1T) ]	PM37LV512@VSOP32
[ (SA620) ]	
PM39F010	PM39F010@PLCC32
[ (SA015A1T) ]	
PM39F010@VSOP32 [ (SA620) ]	
PM39F020	
PM39F020@PLCC32 [ (SA015A1T) ]	PM39F020@VSOP32
[ (SA620) ]	
PM39F040	PM39F040@PLCC32
[ (SA015A1T) ]	
PM39F040@VSOP32 [ (SA620) ]	PM39LV010@PLCC32
[ (SA015A1T) ]	
PM39LV010@VSOP32 [ (SA620) ]	PM39LV010R@PLCC32
[ (SA015A1T) ]	
PM39LV010R@VSOP32 [ (SA620) ]	PM39LV020@PLCC32
[ (SA015A1T) ]	
PM39LV020@VSOP32 [ (SA620) ]	PM39LV040@PLCC32
[ (SA015A1T) ]	

PM39LV040@VSOP32 [(SA620)]	PM39LV512@PLCC32
[(SA015A1T)]	
PM39LV512@VSOP32 [(SA620)]	PM39LV512R@PLCC32
[(SA015A1T)]	
PM39LV512R@VSOP32 [(SA620)]	PM49FL002T@PLCC32
[(SA015A1T)]	
PM49FL002T@VSOP32 [(SA620)]	
PM49FL004T(Low)@PLCC32 [(SA015A1T-B001)]	
PM49FL004T(Low)@VSOP32 [(SA620-B005)]	
PM49FL004T@PLCC32 [(SA015A1T)]	PM49FL004T@VSOP32
[(SA620)]	
PM49FL008T@PLCC32 [(SA015A1T)]	PM49FL008T@VSOP32
[(SA620)]	
PM49LP002T@PLCC32 [(SA015A1T)]	PM49LP002T@VSOP32
[(SA620)]	

## POLYSTAK

### E (E) PROM/FRAM/NVRAM

MTCOUF0CF3@FBGA137 [(SA700C-B153A-Y137F001N)]

## PSS

### E (E) PROM/FRAM/NVRAM

PS24C256	PS24C256@SOIC8
[(SA602A)]	
PS29FS001	PS29FS001@PLCC32
[(SA015A1T)]	
PS29FS001@TSOP32 [(SA410T)]	PS29FS001@VSOP32
[(SA620)]	
PS29LP001	PS29LP001@PLCC32
[(SA015A1T)]	
PS29LP001@VSOP32 [(SA620)]	

## PTC

### E (E) PROM/FRAM/NVRAM

PT28C020  
[ (SA015A1T) ]  
PT28C040  
[ (SA015A1T) ]  
PT29C020  
[ (SA015A1T) ]  
PT29C040  
[ (SA015A1T) ]

PT28C020@PLCC32  
  
PT28C040@PLCC32  
  
PT29C020@PLCC32  
  
PT29C040@PLCC32

## MICROCONTROLLER

PT89316  
[ (SA244) ]  
PT89316@TQFP44 [ (SA245A) ]  
PT8932  
PT8932@PLCC44 [ (SA244) ]  
[ (SA245) ]  
PT8936  
[ (SA244) ]  
PT8936@TQFP44 [ (SA245A) ]  
PT8956  
PT8956@PLCC44 [ (SA244) ]  
[ (SA245A) ]

PT89316@PLCC44  
  
  
  
PT8932@TQFP44  
  
  
PT8936@PLCC44  
  
  
PT8956@TQFP44

## QIXIN

### MICROCONTROLLER

LS2051  
[ (SA404) ]

LS2051@SOIC20

## Quick Pulse

### E (E) PROM / FRAM / NVRAM

27010  
27011  
27040

27128A  
27210  
27256  
27512  
2764A

## RAMTRON

### E ( E ) PROM / FRAM / NVRAM

FM1208 [ ( SA404 ) ]	FM1208@SOIC24
FM1608 [ ( SA404 ) ]	FM1608@SOIC28
FM1808 [ ( SA404 ) ]	FM1808@SOIC28
FM18L08 [ ( SA404 ) ]	FM18L08@SOIC28
FM24164 [ ( SA602A ) ]	FM24164@SOIC8
FM24C04 ( P ) [ ( SA602A ) ]	FM24C04 ( S ) @SOP8
FM24C04A ( P ) [ ( SA602A ) ]	FM24C04A ( S ) @SOP8
FM24C16 ( P ) [ ( SA602A ) ]	FM24C16 ( S ) @SOP8
FM24C16A ( P ) [ ( SA602A ) ]	FM24C16A ( S ) @SOP8
FM24C256@SOIC8 [ ( SA605A ) ] [ ( SA602A ) ]	FM24C512@SOIC8
FM24C64 [ ( SA602A ) ]	FM24C64@SOIC8
FM24CL04 [ ( SA602A ) ]	FM24CL04@SOIC8
FM24CL16 [ ( SA602A ) ]	FM24CL16@SOIC8
FM24CL64@SOIC8 [ ( SA602A ) ]	
FM25040 FM25040@SOIC8 [ ( SA602A ) ]	
FM25160 FM25160@SOIC8 [ ( SA602A ) ]	
FM25640	



FM25640@SOIC8 [(SA602A)]	
FM25C160	
FM25C160@SOIC8 [(SA602A)]	FM25CL04@SOIC8
[(SA602A)]	
FM25CL64	FM25CL64@SOIC8
[(SA602A)]	
FM25L16	FM25L16@SOIC8
[(SA602A)]	
FM25L256	FM25L256@SOIC8
[(SA602A)]	
FM25L256@TDFN8 [(BBBB)]	
FM25L512	
FM25L512@SOIC8 [(SA602A)]	FM25W256@SOIC8
[(SA602A)]	
FM30C256@SOIC20 [(SA404)]	FM3104@SOIC14
[(SA602)]	
FM3116@SOIC14 [(SA602)]	FM31256@SOIC14
[(SA602)]	
FM3164@SOIC14 [(SA602)]	FM32256G@SOIC14
[(SA602)]	
FM32256S@SOIC14 [(SA602)]	FM3264G@SOIC14
[(SA602)]	
FM3264S@SOIC14 [(SA602)]	
FM3808	
FM3808@TSOP32 [(SA620)]	

## MICROCONTROLLER

VMX51C900	VMX51C900@PLCC44
[(SA244)]	
VMX51C900@TQFP44 [(SA245A)]	
VRS1000	
VRS1000@PLCC44 [(SA244)]	VRS1000@TQFP44
[(SA245A)]	
VRS1100	VRS1100@PLCC44
[(SA244)]	
VRS1100@TQFP44 [(SA245A)]	
VRS51C1000	
VRS51C1000@PLCC44 [(SA244)]	VRS51C1000@TQFP44
[(SA245A)]	
VRS51C1100	VRS51C1100@PLCC44
[(SA244)]	

VRS51C1100@TQFP44 [(SA245A)]	
VRS51C540	
VRS51C540@PLCC44 [(SA244)]	VRS51C540@TQFP44
[(SA245A)]	
VRS51C550	VRS51C550@PLCC44
[(SA244)]	
VRS51C550@TQFP44 [(SA245A)]	
VRS51C560	
VRS51C560@PLCC44 [(SA244)]	VRS51C560@TQFP44
[(SA245A)]	
VRS51C570	VRS51C570@PLCC44
[(SA244)]	
VRS51C570@TQFP44 [(SA245A)]	
VRS51C580	
VRS51C580@PLCC44 [(SA244)]	VRS51C580@TQFP44
[(SA245A)]	
VRS51C700	VRS51C700@PLCC44
[(SA244)]	
VRS51C700@TQFP44 [(SA245A)]	
VRS51L1050	
VRS51L1050@PLCC44 [(SA244)]	VRS51L1050@TQFP44
[(SA245A)]	
VRS51L540	VRS51L540@PLCC44
[(SA244)]	
VRS51L540@TQFP44 [(SA245A)]	
VRS51L550	
VRS51L550@PLCC44 [(SA244)]	VRS51L550@TQFP44
[(SA245A)]	
VRS51L560	VRS51L560@PLCC44
[(SA244)]	
VRS51L560@TQFP44 [(SA245A)]	
VRS51L570	
VRS51L570@PLCC44 [(SA244)]	VRS51L570@TQFP44
[(SA245A)]	
VRS51L580	VRS51L580@PLCC44
[(SA244)]	
VRS51L580@TQFP44 [(SA245A)]	
VRS51X540	
VRS51X540@PLCC44 [(SA244)]	VRS51X540@TQFP44
[(SA245A)]	
VRS51X550	VRS51X550@PLCC44
[(SA244)]	
VRS51X550@TQFP44 [(SA245A)]	

VRS51X560	
VRS51X560@PLCC44 [(SA244)]	VRS51X560@TQFP44
[(SA245A)]	
VRS51X570	
[(SA244)]	VRS51X570@PLCC44
VRS51X570@TQFP44 [(SA245A)]	
VRS51X580	
VRS51X580@PLCC44 [(SA244)]	VRS51X580@TQFP44
[(SA245A)]	
VRS540	VRS540@PLCC44
[(SA244)]	
VRS540@TQFP44 [(SA245A)]	
VRS550	
VRS550@PLCC44 [(SA244)]	VRS550@TQFP44
[(SA245A)]	
VRS560	VRS560@PLCC44
[(SA244)]	
VRS560@TQFP44 [(SA245A)]	
VRS570	
VRS570@PLCC44 [(SA244)]	VRS570@TQFP44
[(SA245A)]	
VRS580	VRS580@PLCC44
[(SA244)]	
VRS580@TQFP44 [(SA245A)]	
VRS700	
VRS700@PLCC44 [(SA244)]	VRS700@TQFP44
[(SA245A)]	
VRS900	VRS900@PLCC44
[(SA244)]	
VRS900@TQFP44 [(SA245A)]	

## **RATO**

### **E(E) PROM/FRAM/NVRAM**

RT24A02	RT24A02@SOIC8
[(SA602A)]	
RT24A02@TSSOP8 [(SA026)]	
RT24A04	
RT24A04@SOIC8 [(SA602A)]	RT24A04@TSSOP8
[(SA026)]	
RT24A08	RT24A08@SOIC8

[ (SA602A) ]	
RT24A08@TSSOP8 [ (SA026) ]	
RT24A16	
RT24A16@SOIC8 [ (SA602A) ]	RT24A16@TSSOP8
[ (SA026) ]	
RT93C46B(16bit)	RT93C46B(16bit)@SOIC8
[ (SA602A) ]	
RT93C46B(16bit)@TSSOP8 [ (SA026) ]	RT93LC46
(08bit)	
RT93LC46(08bit)@SOIC8 [ (SA602A) ]	RT93LC46(08bit)@TSSOP8
[ (SA026) ]	
RT93LC46(16bit)	RT93LC46(16bit)@SOIC8
[ (SA602A) ]	
RT93LC46(16bit)@TSSOP8 [ (SA026) ]	

## RAYDIUM

### E (E) PROM/FRAM/NVRAM

RM24C02@SOP8 [ (SA602A) ]	RM24C04@SOP8
[ (SA602A) ]	
RM24C08@SOP8 [ (SA602A) ]	RM24C128@SOP8
[ (SA602A) ]	
RM24C16@SOP8 [ (SA602A) ]	RM24C32@SOP8
[ (SA602A) ]	
RM24C64@SOP8 [ (SA602A) ]	

## RENESAS

### E (E) PROM/FRAM/NVRAM

HN29A128A0A@CSP95 [ (SA642S-B066A-T064F001Y) ]	
HN29A128A0A@TSOP48 [ (SA247-B005) ]	
HN29V128A0A@CSP95 [ (SA642S-B066A-T064F001Y) ]	
HN29V128A0A@TSOP48 [ (SA247-B005) ]	
HN29V256A0B@CSP95 [ (SA642S-B066A-T064F001Y) ]	
HN29V256A1B@CSP95 [ (SA642S-B066A-T064F001Y) ]	
HN58C256A(FP)@SOP28 [ (SA630) ]	HN58C256A
(P)	
HN58C256A(T)@TSOP28 [ (SA643) ]	HN58C257A(T)@TSOP32

[ ( SA620 ) ]	
HN58V24256	HN58V24256@SOIC8
[ ( SA602A ) ]	
HN58V24256@TSSOP14 [ ( SA026 ) ]	
HN58V24512	
HN58V24512@SOIC8 [ ( SA602A ) ]	
HN58W241000	
HN58W241000@SOIC8 [ ( SA602A ) ]	
HN58X2402	
HN58X2402@SOIC8 [ ( SA602A ) ]	HN58X2402@TSSOP8
[ ( SA026 ) ]	
HN58X2404	HN58X2404@SOIC8
[ ( SA602A ) ]	
HN58X2404@TSSOP8 [ ( SA026 ) ]	
HN58X2408	
HN58X2408@SOIC8 [ ( SA602A ) ]	HN58X2408@TSSOP8
[ ( SA026 ) ]	
HN58X24128	HN58X24128@SOIC8
[ ( SA602A ) ]	
HN58X2416	HN58X2416@SOIC8
[ ( SA602A ) ]	
HN58X2416@TSSOP8 [ ( SA026 ) ]	
HN58X24256	
HN58X24256@SOIC8 [ ( SA602A ) ]	
HN58X2432	
HN58X2432@SOIC8 [ ( SA602A ) ]	HN58X2432@TSSOP8
[ ( SA026 ) ]	
HN58X24512	HN58X24512@SOIC8
[ ( SA602A ) ]	
HN58X2464	HN58X2464@SOIC8
[ ( SA602A ) ]	
HN58X2464@TSSOP8 [ ( SA026 ) ]	HN58X2502@SOIC8
[ ( SA602A ) ]	
HN58X2502@TSSOP8 [ ( SA026 ) ]	HN58X2504@SOIC8
[ ( SA602A ) ]	
HN58X2504@TSSOP8 [ ( SA026 ) ]	HN58X25128@SOIC8
[ ( SA602A ) ]	
HN58X25128@TSSOP14 [ ( SA026 ) ]	HN58X25256@SOIC8
[ ( SA602A ) ]	
HN58X25256@TSSOP14 [ ( SA026 ) ]	HN58X2532@SOIC8
[ ( SA602A ) ]	
HN58X2532@TSSOP8 [ ( SA026 ) ]	HN58X2564@SOIC8
[ ( SA602A ) ]	

HN58X2564@TSSOP8 [(SA026)]  
M5L2732  
M5L2732A  
M5M29KB331(AVP)@TSOP48 [(SA247-B005)]  
M5M29KB641(AVP)@TSOP48 [(SA247-B005)]  
M5M29KE131BTP@TSOP52 [(SA657-B117)]  
M5M29KE131BV@TSOP48 [(SA247-B005)]  
M5M29KT331(AVP)@TSOP48 [(SA247-B005)]  
M5M29KT641(AVP)@TSOP48 [(SA247-B005)]  
M6MG3B641S16TP@TSOP52 [(SA657-B036)]  
M6MG3T641S16TP@TSOP52 [(SA657-B036)]  
M6MGB321S4TP@TSOP52 [(SA657-B036)]  
M6MGB321S8TP@TSOP52 [(SA657-B036)]  
M6MGB32BS4WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGB32BS8WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGB331S8KT@TSOP52 [(SA657-B036)]  
M6MGB33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGB641S16TP@TSOP52 [(SA657-B036)]  
M6MGB641S4TP@TSOP52 [(SA657-B036)]  
M6MGB641S8TP@TSOP52 [(SA657-B036)]  
M6MGB647M34CKT@TSOP52 [(SA657-B036)]  
M6MGB64BM17AWG@CSP67 [(SA642F-B064A-T064F001)]  
M6MGB64BM34CDG@CSP88 [(SA642CC-B124A-W080F001N)]  
M6MGB64BM34CWG@CSP67 [(SA642F-B064A-T064F001)]  
M6MGB64BS4WG@CSP67 [(SA642F-B023A-T064F001)]  
M6MGB64BS8WG@CSP67 [(SA642F-B023A-T064F001)]  
M6MGD137W33(WG)@CSP72 [(SA642F-B056A-T064F001)]  
M6MGD13TW34DWG@CSP72 [(SA642F-B064A-T064F001)]  
M6MGD13TW34DWG@CSP72(fast speed) [(SA642F-B064A-T064F001)]  
M6MGE157S4KT@TSOP52 [(SA657-B055)]  
M6MGT321S4TP@TSOP52 [(SA657-B036)]  
M6MGT321S8TP@TSOP52 [(SA657-B036)]  
M6MGT32BS4WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGT32BS8WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGT331S8KT@TSOP52 [(SA657-B036)]  
M6MGT33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGT641S16TP@TSOP52 [(SA657-B036)]  
M6MGT641S4TP@TSOP52 [(SA657-B036)]  
M6MGT641S8TP@TSOP52 [(SA657-B036)]  
M6MGT647M34CKT@TSOP52 [(SA657-B036)]  
M6MGT64BM17AWG@CSP67 [(SA642F-B064A-T064F001)]  
M6MGT64BM34CDG@CSP88 [(SA642CC-B124A-W080F001N)]  
M6MGT64BM34CWG@CSP67 [(SA642F-B064A-T064F001)]

M6MGT64BS4WG@CSP67 [(SA642F-B023A-T064F001)]  
M6MGT64BS8WG@CSP67 [(SA642F-B023A-T064F001)]  
V128128A0E@CSP95 [(SA642A-B105A-Y096N001)]

## DRAM & SRAM

R1LV0408C@SOP32 [(SA438T)] R1LV0408C@STSOP32  
[(SA620)]  
R1LV0408C@TSOP32 [(SA410T)]

## MICROCONTROLLER

HD4074344@SDIP28 [(SA022A)] HD4074344@SOIC28  
[(SA404)]  
HD4074394@SDIP28 [(SA022A)] HD4074394@SOIC28  
[(SA404)]  
HD6472357F@PQFP128(\*) [(SA720+B262)]  
HD6472655F@PQFP128(\*) [(SA720+B175)]  
HD6472655TE@TQFP128(\*) [(SA721+B174)]  
HD6472655VF@PQFP128(\*) [(SA720+B175)]  
HD6472655VTE@TQFP128(\*) [(SA721+B174)]  
HD6473228P@SDIP64(\*) [(SA736-B229)]  
HD6473238P@SDIP64(\*) [(SA736-B229)]  
HD6473258P@SDIP64(\*) [(SA736-B229)]  
HD6473308@PLCC84(\*) [(SA649-B8406)]  
HD6473644@TQFP64 [(PEP+S621)]  
HD64738024F(FP-80B)(\*) [(TA006-B006)]  
HD64738024H(FP-80A)(\*) [(TA008-B006)]  
HD64738024W(TFP-80C)(\*) [(TA007-B006)]  
HD6473877H@TQFP100(\*) [(SA718+B202)]  
HD6475328@PLCC84(\*) [(SA649-B8404)]  
HD6475348@PLCC84(\*) [(SA649-B8404)]  
HD6477034F@QFP112(\*) [(SA738+B213)]  
HD64F2110BFA@QFP100(\*) [(SA718-B299)]  
HD64F2110BTE@QFP100(\*) [(SA718-B299)]  
HD64F2110BVFA@QFP100(\*) [(SA718-B299)]  
HD64F2110BVTE@QFP100(\*) [(SA718-B299)]  
HD64F2138AFA@TQFP80 [(PEP+S615B)]  
HD64F2138ATF@TQFP80 [(PEP+S640B)]  
HD64F2140BVFA@TQFP100 [(PEP+S604)]  
HD64F2140BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]

HD64F2140BVTE@TQFP100 [(PEP+S604)]  
HD64F2140BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2141BVFA@TQFP100 [(PEP+S604)]  
HD64F2141BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2141BVTE@TQFP100 [(PEP+S604)]  
HD64F2141BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2142RFA@TQFP100 [(PEP+S604)]  
HD64F2142RFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2142RTE@TQFP100 [(PEP+S604)]  
HD64F2142RTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2142RVFA@TQFP100 [(PEP+S604)]  
HD64F2142RVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2142RVTE@TQFP100 [(PEP+S604)]  
HD64F2142RVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144AFA@TQFP100 [(PEP+S604)]  
HD64F2144AFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144ATE@TQFP100 [(PEP+S604)]  
HD64F2144ATE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144AVFA@TQFP100 [(PEP+S604)]  
HD64F2144AVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144AVTE@TQFP100 [(PEP+S604)]  
HD64F2144AVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144FA@TQFP100 [(PEP+S604)]  
HD64F2144FA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144TE@TQFP100 [(PEP+S604)]  
HD64F2144TE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144VFA@TQFP100 [(PEP+S604)]  
HD64F2144VFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144VTE@TQFP100 [(PEP+S604)]  
HD64F2144VTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2145BVFA@TQFP100 [(PEP+S604)]  
HD64F2145BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2145BVTE@TQFP100 [(PEP+S604)]  
HD64F2145BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147AFA@TQFP100 [(PEP+S604)]  
HD64F2147AFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147ATE@TQFP100 [(PEP+S604)]  
HD64F2147ATE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147AVFA@TQFP100 [(PEP+S604)]  
HD64F2147AVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147AVTE@TQFP100 [(PEP+S604)]  
HD64F2147AVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147NFA@TQFP100 [(PEP+S604)]



HD64F2147NFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147NTE@TQFP100 [(PEP+S604)]  
HD64F2147NTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147NVFA@TQFP100 [(PEP+S604)]  
HD64F2147NVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147NVTE@TQFP100 [(PEP+S604)]  
HD64F2147NVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148AFA@TQFP100 [(PEP+S604)]  
HD64F2148AFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148ATE@TQFP100 [(PEP+S604)]  
HD64F2148ATE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148AVFA@TQFP100 [(PEP+S604)]  
HD64F2148AVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148AVTE@TQFP100 [(PEP+S604)]  
HD64F2148AVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BFA@TQFP100 [(PEP+S604)]  
HD64F2148BFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BTE@TQFP100 [(PEP+S604)]  
HD64F2148BTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BVFA@TQFP100 [(PEP+S604)]  
HD64F2148BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BVTE@TQFP100 [(PEP+S604)]  
HD64F2148BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148FA@TQFP100 [(PEP+S604)]  
HD64F2148FA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148TE@TQFP100 [(PEP+S604)]  
HD64F2148TE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148VFA@TQFP100 [(PEP+S604)]  
HD64F2148VFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148VTE@TQFP100 [(PEP+S604)]  
HD64F2148VTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2149YFA@TQFP100 [(PEP+S604)]  
HD64F2149YFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2149YTE@TQFP100 [(PEP+S604)]  
HD64F2149YTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2166VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2167VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2168VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2177VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2265FA13@TQFP100 [(PEP+S604)]  
HD64F2265FA20@TQFP100 [(PEP+S604)]  
HD64F2265TE13@TQFP100 [(PEP+S604)]  
HD64F2265TE20@TQFP100 [(PEP+S604)]

HD64F2265TF13@TQFP100 [(PEP+S604)]  
HD64F2265TF20@TQFP100 [(PEP+S604)]  
HD64F2266FA13@TQFP100 [(PEP+S604)]  
HD64F2266FA20@TQFP100 [(PEP+S604)]  
HD64F2266TE13@TQFP100 [(PEP+S604)]  
HD64F2266TE20@TQFP100 [(PEP+S604)]  
HD64F2266TF13@TQFP100 [(PEP+S604)]  
HD64F2266TF20@TQFP100 [(PEP+S604)]  
HD64F2268FA13@TQFP100 [(PEP+S604)]  
HD64F2268FA20@TQFP100 [(PEP+S604)]  
HD64F2268TE13@TQFP100 [(PEP+S604)]  
HD64F2268TE20@TQFP100 [(PEP+S604)]  
HD64F2268TF13@TQFP100 [(PEP+S604)]  
HD64F2268TF20@TQFP100 [(PEP+S604)]  
HD64F2280@PQFP100(\*) [(TA046-B006)]  
HD64F2282@PQFP100(\*) [(TA046-B006)]  
HD64F2326VF@PQFP128(\*) [(SA720+B281)]  
HD64F2326VTE@TQFP120(\*) [(SA721+B282)]  
HD64F2328BVF@PQFP128(\*) [(SA720+B281)]  
HD64F2328BVTE@TQFP120(\*) [(SA721+B282)]  
HD64F2328VF@PQFP128(\*) [(SA720+B281)]  
HD64F2328VTE@TQFP120(\*) [(SA721+B282)]  
HD64F2329BVF@PQFP128(\*) [(SA720+B281)]  
HD64F2329BVTE@TQFP120(\*) [(SA721+B282)]  
HD64F2329EVF@PQFP128(\*) [(SA720+B281)]  
HD64F2329EVTE@TQFP120(\*) [(SA721+B282)]  
HD64F2329VF@PQFP128(\*) [(SA720+B281)]  
HD64F2329VTE@TQFP120(\*) [(SA721+B282)]  
HD64F2338VF@TQFP144(\*) [(SA681+B14415)]  
HD64F2339EVF@TQFP144(\*) [(SA681+B14415)]  
HD64F2339VF@TQFP144(\*) [(SA681+B14415)]  
HD64F2357F@PQFP128(\*) [(SA720+B193)]  
HD64F2357TE@QFP120(\*) [(SA721+B194)]  
HD64F2377@TQFP144(\*) [(SA681-B14408)]  
HD64F2377R@TQFP144(\*) [(SA681-B14408)]  
HD64F2378@TQFP144(\*) [(SA681-B14408)]  
HD64F2378R@TQFP144(\*) [(SA681-B14408)]  
HD64F2398F@PQFP128(\*) [(SA720+B193)]  
HD64F2398TE@QFP120(\*) [(SA721+B194)]  
HD64F2505FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2506FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2551FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2552FC26@QFP144(\*) [(SA681+B14403)]

HD64F2556FC20@QFP144(\*) [(SA681+B14403)]  
HD64F2612FA20@TQFP80(\*) [(SA722+B176)]  
HD64F2615F20@TQFP80(\*) [(SA722+B176)]  
HD64F2615F24@TQFP80(\*) [(SA722+B176)]  
HD64F2646RFC20@QFP144(\*) [(SA681+B14404)]  
HD64F2648RFC20@QFP144 [(SA681+B14404)]  
HD64F2649FC20@QFP144(\*) [(SA681+B14404)]  
HD64F2667VFQ33@QFP144(\*) [(SA681+B14402)]  
HD64F3024F@TQFP100(\*) [(TA029-B006)]  
HD64F3024FP@PQFP100(\*) [(TA030-B006)]  
HD64F3024TE@TQFP100(\*) [(TA029-B006)]  
HD64F3026F@TQFP100(\*) [(TA029-B006)]  
HD64F3026FP@PQFP100(\*) [(TA030-B006)]  
HD64F3026TE@TQFP100(\*) [(TA029-B006)]  
HD64F3048BF@TQFP100(\*) [(TA029-B006)]  
HD64F3048BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3048BVF@TQFP100(\*) [(TA029-B006)]  
HD64F3048BVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3048F@TQFP100(\*) [(TA067+B006)]  
HD64F3048TF@TQFP100(\*) [(TA067+B006)]  
HD64F3048VF@TQFP100(\*) [(TA067+B006)]  
HD64F3048VTF@TQFP100(\*) [(TA067+B006)]  
HD64F3052BF@TQFP100(\*) [(TA029-B006)]  
HD64F3052BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3052BVF@TQFP100(\*) [(TA029-B006)]  
HD64F3052BVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3052F@TQFP100(\*) [(TA029-B006)]  
HD64F3052TE@TQFP100(\*) [(TA029-B006)]  
HD64F3062BF@TQFP100(\*) [(TA029-B006)]  
HD64F3062BFP@PQFP100(\*) [(TA030-B006)]  
HD64F3062BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3062F@TQFP100(\*) [(TA029-B006)]  
HD64F3062FP@PQFP100(\*) [(TA030-B006)]  
HD64F3062RF@TQFP100(\*) [(TA029-B006)]  
HD64F3062RFP@PQFP100(\*) [(TA030-B006)]  
HD64F3062RTE@TQFP100(\*) [(TA029-B006)]  
HD64F3062RVF@TQFP100(\*) [(TA029-B006)]  
HD64F3062RVFP@PQFP100(\*) [(TA030-B006)]  
HD64F3062RVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3062TE@TQFP100(\*) [(TA029-B006)]  
HD64F3064BF@TQFP100(\*) [(TA029-B006)]  
HD64F3064BFP@PQFP100(\*) [(TA030-B006)]  
HD64F3064BTE@TQFP100(\*) [(TA029-B006)]

HD64F3064F@TQFP100(\*) [(TA029-B006)]  
HD64F3064FP@PQFP100(\*) [(TA030-B006)]  
HD64F3064TE@TQFP100(\*) [(TA029-B006)]  
HD64F3067F@TQFP100(\*) [(TA029-B006)]  
HD64F3067FP@PQFP100(\*) [(TA030-B006)]  
HD64F3067RF@TQFP100(\*) [(TA029-B006)]  
HD64F3067RFP@PQFP100(\*) [(TA030-B006)]  
HD64F3067RTE@TQFP100(\*) [(TA029-B006)]  
HD64F3067RVF@TQFP100(\*) [(TA029-B006)]  
HD64F3067RVFP@PQFP100(\*) [(TA030-B006)]  
HD64F3067RVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3067TE@TQFP100(\*) [(TA029-B006)]  
HD64F3068F@TQFP100(\*) [(TA029-B006)]  
HD64F3068TE@TQFP100(\*) [(TA029-B006)]  
HD64F3069F@TQFP100(\*) [(SA718+B271)]  
HD64F3069RF@TQFP100(\*) [(SA718+B271)]  
HD64F3069RTE@TQFP100(\*) [(SA718+B271)]  
HD64F3069TE@TQFP100(\*) [(SA718+B271)]  
HD64F3334YCP16@PLCC84(\*) [(SA649-B8402)]  
HD64F3334YF16@TQFP80(\*) [(TA018-B006)]  
HD64F3334YFLH16@TQFP80(\*) [(TA018-B006)]  
HD64F3334YTF16@TQFP80(\*) [(TA019-B006)]  
HD64F3334YTFLH16@TQFP80(\*) [(TA019-B006)]  
HD64F3337YCP16@PLCC84(\*) [(SA649-B8402)]  
HD64F3337YF16@TQFP80(\*) [(TA018-B006)]  
HD64F3337YFLH16@TQFP80(\*) [(TA018-B006)]  
HD64F3337YTF16@TQFP80(\*) [(TA019-B006)]  
HD64F3337YTFLH16@TQFP80(\*) [(TA019-B006)]  
HD64F3394YCP16@PLCC84(\*) [(SA649-B8402)]  
HD64F3394YF16@TQFP80(\*) [(TA018-B006)]  
HD64F3394YFLH16@TQFP80(\*) [(TA018-B006)]  
HD64F3394YTF16@TQFP80(\*) [(TA019-B006)]  
HD64F3394YTFLH16@TQFP80(\*) [(TA019-B006)]  
HD64F3397CP17@PLCC84(\*) [(SA649-B8402)]  
HD64F3397F17@TQFP80(\*) [(TA018-B006)]  
HD64F3397FLH17@TQFP80(\*) [(TA018-B006)]  
HD64F3397TF17@TQFP80(\*) [(TA019-B006)]  
HD64F3397TFLH17@TQFP80(\*) [(TA019-B006)]  
HD64F3434F@QFP100(\*) [(SA718+B306)]  
HD64F3434TF@QFP100(\*) [(SA718+B306)]  
HD64F3437F@QFP100(\*) [(SA718+B306)]  
HD64F3437TF@QFP100(\*) [(SA718+B306)]  
HD64F36012FX@TQFP48 [(SA671)] HD64F36012FY@TQFP48

[ (SA248) ]  
HD64F36012GFP@TQFP64(\*) [ (SA732+B313) ]  
HD64F36012GFX@TQFP48 [ (SA671) ] HD64F36012GFY@TQFP48  
[ (SA248) ]  
HD64F36014FX@TQFP48 [ (SA671) ] HD64F36014FY@TQFP48  
[ (SA248) ]  
HD64F36014GFP@TQFP64(\*) [ (SA732+B313) ]  
HD64F36014GFX@TQFP48 [ (SA671) ] HD64F36014GFY@TQFP48  
[ (SA248) ]  
HD64F36022FX@TQFP48 [ (SA671) ] HD64F36022FY@TQFP48  
[ (SA248) ]  
HD64F36022GFP@TQFP64(\*) [ (SA732+B313) ]  
HD64F36022GFX@TQFP48 [ (SA671) ] HD64F36022GFY@TQFP48  
[ (SA248) ]  
HD64F36024FX@TQFP48 [ (SA671) ] HD64F36024FY@TQFP48  
[ (SA248) ]  
HD64F36024GFP@TQFP64(\*) [ (SA732+B313) ]  
HD64F36024GFX@TQFP48 [ (SA671) ] HD64F36024GFY@TQFP48  
[ (SA248) ]  
HD64F36034FZ@TQFP64(\*) [ (TA043-B006) ]  
HD64F36034GFZ@TQFP64(\*) [ (TA043-B006) ]  
HD64F36034GH@TQFP64(\*) [ (TA042-B006) ]  
HD64F36034H@TQFP64(\*) [ (TA042-B006) ]  
HD64F36037FZ@TQFP64(\*) [ (TA043-B006) ]  
HD64F36037GFZ@TQFP64(\*) [ (TA043-B006) ]  
HD64F36037GH@TQFP64(\*) [ (TA042-B006) ]  
HD64F36037H@TQFP64(\*) [ (TA042-B006) ]  
HD64F36054FZ@TQFP64(\*) [ (TA043-B006) ]  
HD64F36054GFZ@TQFP64(\*) [ (TA043-B006) ]  
HD64F36054GH@TQFP64(\*) [ (TA042-B006) ]  
HD64F36054H@TQFP64(\*) [ (TA042-B006) ]  
HD64F36057FZ@TQFP64(\*) [ (TA043-B006) ]  
HD64F36057GFZ@TQFP64(\*) [ (TA043-B006) ]  
HD64F36057GH@TQFP64(\*) [ (TA042-B006) ]  
HD64F36057H@TQFP64(\*) [ (TA042-B006) ]  
HD64F36064GFP@TQFP64(\*) [ (TA043-B006) ]  
HD64F36064GH@TQFP64(\*) [ (TA042-B006) ]  
HD64F36074GFZ@QFP64(\*) [ (SA757-B235) ]  
HD64F36074GFZW@QFP64(\*) [ (SA757-B235) ]  
HD64F36074GH@QFP64(\*) [ (SA757-B235) ]  
HD64F36074GHW@QFP64(\*) [ (SA757-B235) ]  
HD64F36074LFZ@LQFP64(\*) [ (SA732-B235) ]  
HD64F36074LFZW@LQFP64(\*) [ (SA732-B235) ]

HD64F36074LH@LQFP64(\*) [(SA732-B235)]  
HD64F36074LHW@LQFP64(\*) [(SA732-B235)]  
HD64F36077GFZ@QFP64(\*) [(SA757-B235)]  
HD64F36077GFZW@QFP64(\*) [(SA757-B235)]  
HD64F36077GH@QFP64(\*) [(SA757-B235)]  
HD64F36077GHW@QFP64(\*) [(SA757-B235)]  
HD64F36077LFZ@LQFP64(\*) [(SA732-B235)]  
HD64F36077LFZW@LQFP64(\*) [(SA732-B235)]  
HD64F36077LH@LQFP64(\*) [(SA732-B235)]  
HD64F36077LHW@LQFP64(\*) [(SA732-B235)]  
HD64F36078GFZ@QFP64(\*) [(SA757-B235)]  
HD64F36078GFZW@QFP64(\*) [(SA757-B235)]  
HD64F36078GH@QFP64(\*) [(SA757-B235)]  
HD64F36078GHW@QFP64(\*) [(SA757-B235)]  
HD64F36078LFZ@LQFP64(\*) [(SA732-B235)]  
HD64F36078LFZW@LQFP64(\*) [(SA732-B235)]  
HD64F36078LH@LQFP64(\*) [(SA732-B235)]  
HD64F36078LHW@LQFP64(\*) [(SA732-B235)]  
HD64F36079GFZ@QFP64(\*) [(SA757-B235)]  
HD64F36079GFZW@QFP64(\*) [(SA757-B235)]  
HD64F36079GH@QFP64(\*) [(SA757-B235)]  
HD64F36079GHW@QFP64(\*) [(SA757-B235)]  
HD64F36079LFZ@LQFP64(\*) [(SA732-B235)]  
HD64F36079LFZW@LQFP64(\*) [(SA732-B235)]  
HD64F36079LH@LQFP64(\*) [(SA732-B235)]  
HD64F36079LHW@LQFP64(\*) [(SA732-B235)]  
HD64F3642AH@QFP64(\*) [(SA668+B275)]  
HD64F3642AP@SDIP64(\*) [(SA736+B274)]  
HD64F3642AW@QFP80(\*) [(SA731+B276)]  
HD64F3643H@QFP64(\*) [(SA668+B275)]  
HD64F3643P@SDIP64(\*) [(SA736+B274)]  
HD64F3643W@QFP80(\*) [(SA731+B276)]  
HD64F3644H@QFP64(\*) [(SA668+B275)]  
HD64F3644P@SDIP64(\*) [(SA736+B274)]  
HD64F3644W@QFP80(\*) [(SA731+B276)]  
HD64F3664BP@SDIP42 [(SA028)] HD64F3664FP@TQFP64 [(PEP  
+S616)]  
HD64F3664FP@TQFP64(\*) [(SA732+B224)]  
HD64F3664FX@TQFP48 [(SA671)] HD64F3664FY@TQFP48  
[(SA248)]  
HD64F3664H@TQFP64 [(PEP+S621)] HD64F3684FP@TQFP64 [(PEP  
+S616)]  
HD64F3684FP@TQFP64(\*) [(TA043-B006)]

HD64F3684GFP@TQFP64 [(PEP+S616)]  
 HD64F3684GFP@TQFP64(\*) [(TA043-B006)]  
 HD64F3684GH@TQFP64 [(PEP+S621)]  
 HD64F3684GH@TQFP64(\*) [(TA042-B006)]  
 HD64F3684H@TQFP64 [(PEP+S621)]  
 HD64F3684H@TQFP64(\*) [(TA042-B006)]  
 HD64F3687FP@TQFP64 [(PEP+S616)]  
 HD64F3687FP@TQFP64(\*) [(TA043-B006)]  
 HD64F3687GFP@TQFP64 [(PEP+S616)]  
 HD64F3687GFP@TQFP64(\*) [(TA043-B006)]  
 HD64F3687GH@TQFP64 [(PEP+S621)]  
 HD64F3687GH@TQFP64(\*) [(TA042-B006)]  
 HD64F3687H@TQFP64 [(PEP+S621)]  
 HD64F3687H@TQFP64(\*) [(TA042-B006)]  
 HD64F36902G@LQFP32 [(SA663)] HD64F36902G@SOP32  
 [(SA682)]  
 HD64F36912G@LQFP32 [(SA663)] HD64F36912G@SOP32  
 [(SA682)]  
 HD64F3694FP@TQFP64 [(PEP+S616)] HD64F3694FX@TQFP48  
 [(SA671)]  
 HD64F3694FY@TQFP48 [(SA248)] HD64F3694GFP@TQFP64 [(PEP  
 +S616)]  
 HD64F3694GFX@TQFP48 [(SA671)] HD64F3694GFY@TQFP48  
 [(SA248)]  
 HD64F3694GH@TQFP64 [(PEP+S621)] HD64F3694H@TQFP64 [(PEP  
 +S621)]  
 HD64F38002FPA@TQFP64 [(PEP+S625A)]  
 HD64F38002FPE@TQFP64 [(PEP+S616)]  
 HD64F38004FPA@TQFP64 [(PEP+S625A)]  
 HD64F38004FPE@TQFP64 [(PEP+S616)]  
 HD64F38024F(FP-80B)@PQFP80 [(PEP+S611A)]  
 HD64F38024F(FP-80B)@PQFP80(\*) [(TA003-B006)]  
 HD64F38024H(FP-80A)@TQFP80 [(PEP+S615B)]  
 HD64F38024H(FP-80A)@TQFP80(\*) [(TA005-B006)]  
 HD64F38024RF(FP-80B)@PQFP80 [(PEP+S611A)]  
 HD64F38024RF(FP-80B)@PQFP80(\*) [(TA003-B006)]  
 HD64F38024RH(FP-80A)@TQFP80 [(PEP+S615B)]  
 HD64F38024RH(FP-80A)@TQFP80(\*) [(TA005-B006)]  
 HD64F38024RW(TFP-80C)@TQFP80 [(PEP+S640B)]  
 HD64F38024RW(TFP-80C)@TQFP80(\*) [(TA004-B006)]  
 HD64F38024W(TFP-80C)@TQFP80 [(PEP+S640B)]  
 HD64F38024W(TFP-80C)@TQFP80(\*) [(TA004-B006)]  
 HD64F38102FPA@TQFP64 [(PEP+S625A)]

HD64F38102FPE@TQFP64 [(PEP+S616)]	
HD64F38104FPA@TQFP64 [(PEP+S625A)]	
HD64F38104FPE@TQFP64 [(PEP+S616)]	
HD64F38124F(FP-80B)@PQFP80 [(PEP+S611A)]	
HD64F38124F(FP-80B)@PQFP80(*) [(TA003-B006)]	
HD64F38124H(FP-80A)@TQFP80 [(PEP+S615B)]	
HD64F38124H(FP-80A)@TQFP80(*) [(TA005-B006)]	
HD64F38124W(TFP-80C)@TQFP80 [(PEP+S640B)]	
HD64F38124W(TFP-80C)@TQFP80(*) [(TA004-B006)]	
HD64F39802G@SDIP32 [(SA653)]	
HD64F7044F@QFP112(*) [(SA755+B278)]	
HD64F7046F@QFP80(*) [(TA014+B006)]	
HD64F7047@QFP100(*) [(SA718+B172)]	
M30260F3AGP@QFP48 [(SA248)]	M30260F3TGP@QFP48
[(SA248)]	
M30260F3VGP@QFP48 [(SA248)]	M30260F6AGP@QFP48
[(SA248)]	
M30260F6TGP@QFP48 [(SA248)]	M30260F6VGP@QFP48
[(SA248)]	
M30260F8AGP@QFP48 [(SA248)]	M30260F8TGP@QFP48
[(SA248)]	
M30260F8VGP@QFP48 [(SA248)]	M30262F3GP@QFP48
[(SA248)]	
M30262F4GP@QFP48 [(SA248)]	M30262F6GP@QFP48
[(SA248)]	
M30262F8GP@QFP48 [(SA248)]	M30263F3AFP@SDIP42
[(SA028)]	
M30263F6AFP@SDIP42 [(SA028)]	M30263F8AFP@SDIP42
[(SA028)]	
M30280F6HP@QFP80 [(SA731-B230)]	M30280F8HP@QFP80 [(SA731-
B230)]	
M30280FAHP@QFP80 [(SA731-B230)]	M30280FATHP@QFP80 [(SA731-
B230)]	
M30280FAVHP@QFP80 [(SA731-B230)]	M30280FCHP@QFP80 [(SA731-
B230)]	
M30281F6HP@QFP64 [(SA732-B315)]	M30281F8HP@QFP64 [(SA732-
B315)]	
M30281FAHP@QFP64 [(SA732-B315)]	M30281FATHP@QFP64 [(SA732-
B315)]	
M30281FAVHP@QFP64 [(SA732-B315)]	M30281FCHP@QFP64 [(SA732-
B315)]	
M30290FAHP@QFP80 [(SA731-B230)]	M30290FATHP@QFP80 [(SA731-
B230)]	



M30290FAVHP@QFP80 [(SA731-B230)] M30290FCHP@QFP80 [(SA731-B230)]  
M30290FCTHP@QFP80 [(SA731-B230)] M30290FCVHP@QFP80 [(SA731-B230)]  
M30620FCAFP@PQFP100(\*) [(TA012-B006)]  
M30620FCAGP@TQFP100(\*) [(TA013-B006)]  
M30620FCFP@PQFP100(\*) [(TA012-B006)]  
M30620FCGPG@TQFP100(\*) [(TA013-B006)]  
M30622F8PFP@PQFP100(\*) [(TA012-B006)]  
M30622F8PGP@TQFP100(\*) [(TA013-B006)]  
M30624FGAFP@PQFP100(\*) [(TA012-B006)]  
M30624FGAGP@TQFP100(\*) [(TA013-B006)]  
M30624FGPFP@PQFP100(\*) [(TA012-B006)]  
M30624FGPGP@TQFP100(\*) [(TA013-B006)]  
M30626FHPFP@PQFP100(\*) [(TA012-B006)]  
M30626FHPP@TQFP100(\*) [(TA013-B006)]  
M30627FHPP@PQFP128(\*) [(SA720-B228)]  
M3062LFGPFP@PQFP100(\*) [(TA012-B006)]  
M3062LFGPGP@TQFP100(\*) [(TA013-B006)]  
M306N4FCFP@PQFP100(\*) [(TA012-B006)]  
M306N4FCGP@QFP100(\*) [(TA013-B006)]  
M306N4FCTFP@PQFP100(\*) [(TA012-B006)]  
M306N4FCTGP@QFP100(\*) [(TA013-B006)]  
M306N4FCVFP@PQFP100(\*) [(TA012-B006)]  
M306N4FCVGP@QFP100(\*) [(TA013-B006)]  
M306N4FGFP@PQFP100(\*) [(TA012-B006)]  
M306N4FGGP@QFP100(\*) [(TA013-B006)]  
M306N4FGTFP@PQFP100(\*) [(TA012-B006)]  
M306N4FGTGP@QFP100(\*) [(TA013-B006)]  
M306N4FGVFP@PQFP100(\*) [(TA012-B006)]  
M306N4FGVGP@QFP100(\*) [(TA013-B006)]  
M306N5FCFP@PQFP100(\*) [(TA012-B006)]  
M306N5FCGP@QFP100(\*) [(TA013-B006)]  
M306N5FCTFP@PQFP100(\*) [(TA012-B006)]  
M306N5FCTGP@QFP100(\*) [(TA013-B006)]  
M306N5FCVFP@PQFP100(\*) [(TA012-B006)]  
M306N5FCVGP@QFP100(\*) [(TA013-B006)]  
M306NKFHGP@QFP100(\*) [(TA013-B006)]  
M306NKFHTGP@QFP100(\*) [(TA013-B006)]  
M306NKFHVGP@QFP100(\*) [(TA013-B006)]  
M306NKFJGP@QFP100(\*) [(TA013-B006)]  
M306NKFJTGP@QFP100(\*) [(TA013-B006)]  
M306NKFJVGP@QFP100(\*) [(TA013-B006)]

M306NLFHGP@QFP100(\*) [(TA013-B006)]  
M306NLFHTGP@QFP100(\*) [(TA013-B006)]  
M306NLFHVGP@QFP100(\*) [(TA013-B006)]  
M306NLFJGP@QFP100(\*) [(TA013-B006)]  
M306NLFJTGP@QFP100(\*) [(TA013-B006)]  
M306NLFJVGP@QFP100(\*) [(TA013-B006)]  
M306NMFHGP@QFP128(\*) [(SA720-B228)]  
M306NMFHTGP@QFP128(\*) [(SA720-B228)]  
M306NMFHVGP@QFP128(\*) [(SA720-B228)]  
M306NMFJGP@QFP128(\*) [(SA720-B228)]  
M306NMFJTGP@QFP128(\*) [(SA720-B228)]  
M306NMFJVGP@QFP128(\*) [(SA720-B228)]  
M306NNFHGP@QFP128(\*) [(SA720-B228)]  
M306NNFHVGP@QFP128(\*) [(SA720-B228)]  
M306NNFJGP@QFP128(\*) [(SA720-B228)]  
M306NNFJTGP@QFP128(\*) [(SA720-B228)]  
M306NNFJVGP@QFP128(\*) [(SA720-B228)]  
M306NNTFHGP@QFP128(\*) [(SA720-B228)]  
M34282E2GP [(SA026)] M34283G2GP  
[(SA026)]  
M34283G2GP(ISP) [ISP-HEADER01] M34508G4FP  
[(SA023A)]  
M34508G4GP [(SA026)] M34508G4HFP  
[(SA023A)]  
M34508G4HGP [(SA026)] M34509G4FP [(SA711-  
B005)]  
M34509G4HFP [(SA711-B005)] M34559G6FP@QFP52 [(PEP-  
S673)]  
M3455AG8FP@QFP52 [(PEP-S673)] M3455AGCFP@QFP52 [(PEP-  
S673)]  
M37544G2A(GP)@LQFP32 [(SA663)]  
M37544G2A(GP)@LQFP32(ISP) [ISP-HEADER01]  
M37544G2A(SP)@SDIP32 [(SA653)]  
M37544G2A(SP)@SDIP32(ISP) [ISP-HEADER01]  
M37545G4(GP)@LQFP32 [(SA663)] M37545G6(GP)@LQFP32  
[(SA663)]  
M37545G8(GP)@LQFP32 [(SA663)] M37546G2(FP)@SSOP36  
[(SA645)]  
M37546G2(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37546G2(GP)@LQFP32 [(SA663)]  
M37546G2(GP)@LQFP32(ISP) [ISP-HEADER01]  
M37546G2(SP)@SDIP32 [(SA653)]  
M37546G2(SP)@SDIP32(ISP) [ISP-HEADER01]

M37546G4(FP)@SSOP36 [(SA645)]  
M37546G4(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37546G4(GP)@LQFP32 [(SA663)]  
M37546G4(GP)@LQFP32(ISP) [ISP-HEADER01]  
M37546G4(SP)@SDIP32 [(SA653)]  
M37546G4(SP)@SDIP32(ISP) [ISP-HEADER01]  
M37547G2(FP)@SSOP36 [(SA645)]  
M37547G2(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37547G4(FP)@SSOP36 [(SA645)]  
M37547G4(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37548G1(FP)@TSSOP20 [(SA026)] M37548G2(FP)@TSSOP20  
[(SA026)]  
M37548G3(FP)@TSSOP20 [(SA026)] M37549G1FP@SDIP24  
[(SA653)]  
M37549G2FP@SDIP24 [(SA653)] M37549G3FP@SDIP24  
[(SA653)]  
M38234G4(FP)@PQFP80 [(SA730+B191)]  
M38234G4(HP)@TQFP80 [(SA731+B192)]  
M38235G6(FP)@PQFP80 [(SA730+B191)]  
M38235G6(HP)@TQFP80 [(SA731+B192)]  
M38238G8(FP)@PQFP80 [(SA730+B191)]  
M38238G8(HP)@TQFP80 [(SA731+B192)]  
M38239GC(FP)@PQFP80 [(SA730+B191)]  
M38239GC(HP)@TQFP80 [(SA731+B192)]  
M3823AGF(FP)@PQFP80 [(SA730+B191)]  
M3823AGF(HP)@TQFP80 [(SA731+B192)]  
M38503G4A(FP)@SSOP42 [(SA645)] M38503G4A(SP)@SDIP42  
[(SA028)]  
M38507F8(FP)@SSOP42 [(SA645)] M38507F8(SP)@SDIP42  
[(SA028)]  
M38588G6(FP)@SSOP42 [(SA645)] M38588G6(SP)@SDIP42  
[(SA028)]  
M38588G8(FP)@SSOP42 [(SA645)] M38588G8(SP)@SDIP42  
[(SA028)]  
M38588GC(FP)@SSOP42 [(SA645)] M38588GC(SP)@SDIP42  
[(SA028)]  
M38859@TQFP80 [(PEP+S640B)] M38D24G4FP@TQFP64 [(PEP  
+S625A)]  
M38D24G4HP@TQFP64 [(PEP+S616)] M38D24G6FP@TQFP64 [(PEP  
+S625A)]  
M38D24G6HP@TQFP64 [(PEP+S616)] M38D28G8FP@TQFP64 [(PEP  
+S625A)]  
M38D28G8HP@TQFP64 [(PEP+S616)] M38D29GCFP@TQFP64 [(PEP

+S625A) ]  
M38D29GCHP@TQFP64 [ (PEP+S616) ] M38D29GFFP@TQFP64 [ (PEP  
+S625A) ]  
M38D29GFHP@TQFP64 [ (PEP+S616) ]  
M3NN00FETGP@QFP100(\*) [ (TA013-B006) ]  
R5F21102DFP@TQFP32 [ (SA663+B005) ]  
R5F21102DFP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21102FP@TQFP32 [ (SA663+B005) ]  
R5F21102FP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21103DFP@TQFP32 [ (SA663+B005) ]  
R5F21103DFP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21103FP@TQFP32 [ (SA663+B005) ]  
R5F21103FP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21104DFP@TQFP32 [ (SA663+B005) ]  
R5F21104DFP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21104FP@TQFP32 [ (SA663+B005) ]  
R5F21104FP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21112DFP@TQFP32 [ (SA663+B005) ]  
R5F21112DFP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21112FP@TQFP32 [ (SA663+B005) ]  
R5F21112FP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21113DFP@TQFP32 [ (SA663+B005) ]  
R5F21113DFP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21113FP@TQFP32 [ (SA663+B005) ]  
R5F21113FP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21114DFP@TQFP32 [ (SA663+B005) ]  
R5F21114DFP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21114FP@TQFP32 [ (SA663+B005) ]  
R5F21114FP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21122DFP@TQFP32 [ (SA663+B005) ]  
R5F21122DFP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21122FP@TQFP32 [ (SA663+B005) ]  
R5F21122FP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21123DFP@TQFP32 [ (SA663+B005) ]  
R5F21123DFP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21123FP@TQFP32 [ (SA663+B005) ]  
R5F21123FP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21124DFP@TQFP32 [ (SA663+B005) ]  
R5F21124DFP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21124FP@TQFP32 [ (SA663+B005) ]  
R5F21124FP@TQFP32(ISP) [ ISP-HEADER01 ]  
R5F21132DFP@TQFP32 [ (SA663+B005) ]  
R5F21132DFP@TQFP32(ISP) [ ISP-HEADER01 ]

R5F21132FP@TQFP32 [(SA663+B005)]  
R5F21132FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133DFP@TQFP32 [(SA663+B005)]  
R5F21133DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133FP@TQFP32 [(SA663+B005)]  
R5F21133FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21134DFP@TQFP32 [(SA663+B005)]  
R5F21134DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21134FP@TQFP32 [(SA663+B005)]  
R5F21134FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20 [(SA725+B005)]  
R5F21181DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20(single wire) [(SA725+B005)]  
R5F21181DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21181DSP@TSSOP20 [(SA026+B001)]  
R5F21181DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21181DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21181DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21181SP@TSSOP20 [(SA026+B001)]  
R5F21181SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21181SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182DD@SDIP20 [(SA725+B005)]  
R5F21182DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(single wire) [(SA725+B005)]  
R5F21182DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21182DSP@TSSOP20 [(SA026+B001)]  
R5F21182DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21182DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182NP@QFN28 [(SA697+B006)]  
R5F21182NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(single wire) [(SA697+B006)]  
R5F21182NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(UART mode) [(SA697+B006)]  
R5F21182SP@TSSOP20 [(SA026+B001)]  
R5F21182SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182SP@TSSOP20(single wire) [(SA026+B001)]

R5F21182SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21182SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183DD@SDIP20 [(SA725+B005)]  
R5F21183DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(single wire) [(SA725+B005)]  
R5F21183DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21183DSP@TSSOP20 [(SA026+B001)]  
R5F21183DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21183DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183NP@QFN28 [(SA697+B006)]  
R5F21183NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(single wire) [(SA697+B006)]  
R5F21183NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(UART mode) [(SA697+B006)]  
R5F21183SP@TSSOP20 [(SA026+B001)]  
R5F21183SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21183SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184DD@SDIP20 [(SA725+B005)]  
R5F21184DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(single wire) [(SA725+B005)]  
R5F21184DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21184DSP@TSSOP20 [(SA026+B001)]  
R5F21184DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21184DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184NP@QFN28 [(SA697+B006)]  
R5F21184NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(single wire) [(SA697+B006)]  
R5F21184NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(UART mode) [(SA697+B006)]  
R5F21184SP@TSSOP20 [(SA026+B001)]  
R5F21184SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21184SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191DD@SDIP20 [(SA725+B005)]

R5F21191DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(single wire) [(SA725+B005)]  
R5F21191DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21191DSP@TSSOP20 [(SA026+B001)]  
R5F21191DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191SP@TSSOP20 [(SA026+B001)]  
R5F21191SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192DD@SDIP20 [(SA725+B005)]  
R5F21192DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(single wire) [(SA725+B005)]  
R5F21192DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21192DSP@TSSOP20 [(SA026+B001)]  
R5F21192DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192NP@QFN28 [(SA697+B006)]  
R5F21192NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(single wire) [(SA697+B006)]  
R5F21192NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(UART mode) [(SA697+B006)]  
R5F21192SP@TSSOP20 [(SA026+B001)]  
R5F21192SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193DD@SDIP20 [(SA725+B005)]  
R5F21193DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(single wire) [(SA725+B005)]  
R5F21193DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21193DSP@TSSOP20 [(SA026+B001)]  
R5F21193DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193DSP@TSSOP20(UART ISP) [ISP-HEADER01]

R5F21193DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193NP@QFN28 [(SA697+B006)]  
R5F21193NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(single wire) [(SA697+B006)]  
R5F21193NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(UART mode) [(SA697+B006)]  
R5F21193SP@TSSOP20 [(SA026+B001)]  
R5F21193SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194DD@SDIP20 [(SA725+B005)]  
R5F21194DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(single wire) [(SA725+B005)]  
R5F21194DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21194DSP@TSSOP20 [(SA026+B001)]  
R5F21194DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194NP@QFN28 [(SA697+B006)]  
R5F21194NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(single wire) [(SA697+B006)]  
R5F21194NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(UART mode) [(SA697+B006)]  
R5F21194SP@TSSOP20 [(SA026+B001)]  
R5F21194SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1DD@SDIP20 [(SA725+B005)]  
R5F211A1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(single wire) [(SA725+B005)]  
R5F211A1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A1DSP@TSSOP20 [(SA026+B001)]  
R5F211A1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1SP@TSSOP20 [(SA026+B001)]  
R5F211A1SP@TSSOP20(single ISP) [ISP-HEADER01]



R5F211A1SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2DD@SDIP20 [(SA725+B005)]  
R5F211A2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(single wire) [(SA725+B005)]  
R5F211A2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A2DSP@TSSOP20 [(SA026+B001)]  
R5F211A2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2NP@QFN28 [(SA697+B006)]  
R5F211A2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(single wire) [(SA697+B006)]  
R5F211A2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A2SP@TSSOP20 [(SA026+B001)]  
R5F211A2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3DD@SDIP20 [(SA725+B005)]  
R5F211A3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(single wire) [(SA725+B005)]  
R5F211A3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A3DSP@TSSOP20 [(SA026+B001)]  
R5F211A3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3NP@QFN28 [(SA697+B006)]  
R5F211A3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(single wire) [(SA697+B006)]  
R5F211A3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A3SP@TSSOP20 [(SA026+B001)]  
R5F211A3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(UART mode) [(SA026+B001)]

R5F211A4DD@SDIP20 [(SA725+B005)]  
R5F211A4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(single wire) [(SA725+B005)]  
R5F211A4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A4DSP@TSSOP20 [(SA026+B001)]  
R5F211A4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4NP@QFN28 [(SA697+B006)]  
R5F211A4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(single wire) [(SA697+B006)]  
R5F211A4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A4SP@TSSOP20 [(SA026+B001)]  
R5F211A4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1DD@SDIP20 [(SA725+B005)]  
R5F211B1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B1DSP@TSSOP20 [(SA026+B001)]  
R5F211B1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1SP@TSSOP20 [(SA026+B001)]  
R5F211B1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2DD@SDIP20 [(SA725+B005)]  
R5F211B2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B2DSP@TSSOP20 [(SA026+B001)]  
R5F211B2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(single wire) [(SA026+B001)]

R5F211B2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2NP@QFN28 [(SA697+B006)]  
R5F211B2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(single wire) [(SA697+B006)]  
R5F211B2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B2SP@TSSOP20 [(SA026+B001)]  
R5F211B2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3DD@SDIP20 [(SA725+B005)]  
R5F211B3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B3DSP@TSSOP20 [(SA026+B001)]  
R5F211B3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3NP@QFN28 [(SA697+B006)]  
R5F211B3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(single wire) [(SA697+B006)]  
R5F211B3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B3SP@TSSOP20 [(SA026+B001)]  
R5F211B3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4DD@SDIP20 [(SA725+B005)]  
R5F211B4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B4DSP@TSSOP20 [(SA026+B001)]  
R5F211B4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4NP@QFN28 [(SA697+B006)]

R5F211B4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(single wire) [(SA697+B006)]  
R5F211B4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B4SP@TSSOP20 [(SA026+B001)]  
R5F211B4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21244SDFP@TQFP52(parallel) [(PEP+S673)]  
R5F21244SDFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21244SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21244SDFP@TQFP52(single) [(PEP+S673)]  
R5F21244SDFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21244SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21244SDFP@TQFP52(UART) [(PEP+S673)]  
R5F21244SDFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21244SNFP@TQFP52(parallel) [(PEP+S673)]  
R5F21244SNFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21244SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21244SNFP@TQFP52(single) [(PEP+S673)]  
R5F21244SNFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21244SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21244SNFP@TQFP52(UART) [(PEP+S673)]  
R5F21244SNFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21246SDFP@TQFP52(parallel) [(PEP+S673)]  
R5F21246SDFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21246SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21246SDFP@TQFP52(single) [(PEP+S673)]  
R5F21246SDFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21246SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21246SDFP@TQFP52(UART) [(PEP+S673)]  
R5F21246SDFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21246SNFP@TQFP52(parallel) [(PEP+S673)]  
R5F21246SNFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21246SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21246SNFP@TQFP52(single) [(PEP+S673)]  
R5F21246SNFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21246SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21246SNFP@TQFP52(UART) [(PEP+S673)]  
R5F21246SNFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21247SDFP@TQFP52(parallel) [(PEP+S673)]  
R5F21247SDFP@TQFP52(parallel)(\*) [(SA740+B225)]

R5F21247SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21247SDFP@TQFP52(single) [(PEP+S673)]  
R5F21247SDFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21247SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21247SDFP@TQFP52(UART) [(PEP+S673)]  
R5F21247SDFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21247SNFP@TQFP52(parallel) [(PEP+S673)]  
R5F21247SNFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21247SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21247SNFP@TQFP52(single) [(PEP+S673)]  
R5F21247SNFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21247SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21247SNFP@TQFP52(UART) [(PEP+S673)]  
R5F21247SNFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21248SDFP@TQFP52(parallel) [(PEP+S673)]  
R5F21248SDFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21248SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21248SDFP@TQFP52(single) [(PEP+S673)]  
R5F21248SDFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21248SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21248SDFP@TQFP52(UART) [(PEP+S673)]  
R5F21248SDFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21248SNFP@TQFP52(parallel) [(PEP+S673)]  
R5F21248SNFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21248SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21248SNFP@TQFP52(single) [(PEP+S673)]  
R5F21248SNFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21248SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21248SNFP@TQFP52(UART) [(PEP+S673)]  
R5F21248SNFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21254SDFP@TQFP52 [(PEP+S673)]  
R5F21254SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21254SDFP@TQFP52(single wire) [(PEP+S673)]  
R5F21254SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21254SDFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21254SNFP@TQFP52 [(PEP+S673)]  
R5F21254SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21254SNFP@TQFP52(single wire) [(PEP+S673)]  
R5F21254SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21254SNFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21256SDFP@TQFP52 [(PEP+S673)]  
R5F21256SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21256SDFP@TQFP52(single wire) [(PEP+S673)]

R5F21256SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21256SDFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21256SNFP@TQFP52 [(PEP+S673)]  
R5F21256SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21256SNFP@TQFP52(single wire) [(PEP+S673)]  
R5F21256SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21256SNFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21257SDFP@TQFP52 [(PEP+S673)]  
R5F21257SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21257SDFP@TQFP52(single wire) [(PEP+S673)]  
R5F21257SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SDFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21257SNFP@TQFP52 [(PEP+S673)]  
R5F21257SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(single wire) [(PEP+S673)]  
R5F21257SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21258SDFP@TQFP52 [(PEP+S673)]  
R5F21258SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(single wire) [(PEP+S673)]  
R5F21258SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21258SNFP@TQFP52 [(PEP+S673)]  
R5F21258SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(single wire) [(PEP+S673)]  
R5F21258SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(UART mode) [(PEP+S673)]  
R5F21262DFP@QFP32 [(SA663)]  
R5F21262DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(single wire) [(SA663)]  
R5F21262DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(UART mode) [(SA663)]  
R5F21262JFP@QFP32 [(SA663)]  
R5F21262JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(single wire) [(SA663)]  
R5F21262JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(UART mode) [(SA663)]  
R5F21262KFP@QFP32 [(SA663)]  
R5F21262KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262KFP@QFP32(single wire) [(SA663)]  
R5F21262KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262KFP@QFP32(UART mode) [(SA663)]  
R5F21262NFP@QFP32 [(SA663)]

R5F21262NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(single wire) [(SA663)]  
R5F21262NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(UART mode) [(SA663)]  
R5F21262SDFP@QFP32 [(SA663)]  
R5F21262SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(single wire) [(SA663)]  
R5F21262SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(UART mode) [(SA663)]  
R5F21262SJFP@QFP32 [(SA663)]  
R5F21262SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(single wire) [(SA663)]  
R5F21262SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(UART mode) [(SA663)]  
R5F21262SKFP@QFP32 [(SA663)]  
R5F21262SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(single wire) [(SA663)]  
R5F21262SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(UART mode) [(SA663)]  
R5F21262SNFP@QFP32 [(SA663)]  
R5F21262SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(single wire) [(SA663)]  
R5F21262SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(UART mode) [(SA663)]  
R5F21264DFP@QFP32 [(SA663)]  
R5F21264DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264DFP@QFP32(single wire) [(SA663)]  
R5F21264DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264DFP@QFP32(UART mode) [(SA663)]  
R5F21264JFP@QFP32 [(SA663)]  
R5F21264JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(single wire) [(SA663)]  
R5F21264JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(UART mode) [(SA663)]  
R5F21264KFP@QFP32 [(SA663)]  
R5F21264KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(single wire) [(SA663)]  
R5F21264KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(UART mode) [(SA663)]  
R5F21264NFP@QFP32 [(SA663)]  
R5F21264NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264NFP@QFP32(single wire) [(SA663)]  
R5F21264NFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21264NFP@QFP32(UART mode) [(SA663)]  
R5F21264SDFP@QFP32 [(SA663)]  
R5F21264SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SDFP@QFP32(single wire) [(SA663)]  
R5F21264SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SDFP@QFP32(UART mode) [(SA663)]  
R5F21264SJFP@QFP32 [(SA663)]  
R5F21264SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(single wire) [(SA663)]  
R5F21264SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(UART mode) [(SA663)]  
R5F21264SKFP@QFP32 [(SA663)]  
R5F21264SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(single wire) [(SA663)]  
R5F21264SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(UART mode) [(SA663)]  
R5F21264SNFP@QFP32 [(SA663)]  
R5F21264SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(single wire) [(SA663)]  
R5F21264SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(UART mode) [(SA663)]  
R5F21265DFP@QFP32 [(SA663)]  
R5F21265DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(single wire) [(SA663)]  
R5F21265DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(UART mode) [(SA663)]  
R5F21265JFP@QFP32 [(SA663)]  
R5F21265JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(single wire) [(SA663)]  
R5F21265JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(UART mode) [(SA663)]  
R5F21265KFP@QFP32 [(SA663)]  
R5F21265KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(single wire) [(SA663)]  
R5F21265KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(UART mode) [(SA663)]  
R5F21265NFP@QFP32 [(SA663)]  
R5F21265NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(single wire) [(SA663)]  
R5F21265NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(UART mode) [(SA663)]  
R5F21265SDFP@QFP32 [(SA663)]  
R5F21265SDFP@QFP32(single ISP) [ISP-HEADER01]



R5F21265SDFP@QFP32(single wire) [(SA663)]  
R5F21265SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(UART mode) [(SA663)]  
R5F21265SJFP@QFP32 [(SA663)]  
R5F21265SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(single wire) [(SA663)]  
R5F21265SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(UART mode) [(SA663)]  
R5F21265SKFP@QFP32 [(SA663)]  
R5F21265SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(single wire) [(SA663)]  
R5F21265SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(UART mode) [(SA663)]  
R5F21265SNFP@QFP32 [(SA663)]  
R5F21265SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(single wire) [(SA663)]  
R5F21265SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(UART mode) [(SA663)]  
R5F21266DFP@QFP32 [(SA663)]  
R5F21266DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(single wire) [(SA663)]  
R5F21266DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(UART mode) [(SA663)]  
R5F21266JFP@QFP32 [(SA663)]  
R5F21266JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(single wire) [(SA663)]  
R5F21266JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(UART mode) [(SA663)]  
R5F21266KFP@QFP32 [(SA663)]  
R5F21266KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(single wire) [(SA663)]  
R5F21266KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(UART mode) [(SA663)]  
R5F21266NFP@QFP32 [(SA663)]  
R5F21266NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(single wire) [(SA663)]  
R5F21266NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(UART mode) [(SA663)]  
R5F21266SDFP@QFP32 [(SA663)]  
R5F21266SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(single wire) [(SA663)]  
R5F21266SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(UART mode) [(SA663)]

R5F21266SJFP@QFP32 [(SA663)]  
R5F21266SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(single wire) [(SA663)]  
R5F21266SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(UART mode) [(SA663)]  
R5F21266SKFP@QFP32 [(SA663)]  
R5F21266SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(single wire) [(SA663)]  
R5F21266SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(UART mode) [(SA663)]  
R5F21266SNFP@QFP32 [(SA663)]  
R5F21266SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(single wire) [(SA663)]  
R5F21266SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(UART mode) [(SA663)]  
R5F21272DFP@QFP32 [(SA663)]  
R5F21272DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272DFP@QFP32(single wire) [(SA663)]  
R5F21272DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272DFP@QFP32(UART mode) [(SA663)]  
R5F21272JFP@QFP32 [(SA663)]  
R5F21272JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(single wire) [(SA663)]  
R5F21272JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(UART mode) [(SA663)]  
R5F21272KFP@QFP32 [(SA663)]  
R5F21272KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272KFP@QFP32(single wire) [(SA663)]  
R5F21272KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272KFP@QFP32(UART mode) [(SA663)]  
R5F21272NFP@QFP32 [(SA663)]  
R5F21272NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(single wire) [(SA663)]  
R5F21272NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(UART mode) [(SA663)]  
R5F21272SDFP@QFP32 [(SA663)]  
R5F21272SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(single wire) [(SA663)]  
R5F21272SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(UART mode) [(SA663)]  
R5F21272SJFP@QFP32 [(SA663)]  
R5F21272SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(single wire) [(SA663)]

R5F21272SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(UART mode) [(SA663)]  
R5F21272SKFP@QFP32 [(SA663)]  
R5F21272SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(single wire) [(SA663)]  
R5F21272SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(UART mode) [(SA663)]  
R5F21272SNFP@QFP32 [(SA663)]  
R5F21272SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(single wire) [(SA663)]  
R5F21272SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(UART mode) [(SA663)]  
R5F21274DFP@QFP32 [(SA663)]  
R5F21274DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(single wire) [(SA663)]  
R5F21274DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(UART mode) [(SA663)]  
R5F21274JFP@QFP32 [(SA663)]  
R5F21274JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(single wire) [(SA663)]  
R5F21274JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(UART mode) [(SA663)]  
R5F21274KFP@QFP32 [(SA663)]  
R5F21274KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(single wire) [(SA663)]  
R5F21274KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(UART mode) [(SA663)]  
R5F21274NFP@QFP32 [(SA663)]  
R5F21274NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(single wire) [(SA663)]  
R5F21274NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(UART mode) [(SA663)]  
R5F21274SDFP@QFP32 [(SA663)]  
R5F21274SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(single wire) [(SA663)]  
R5F21274SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(UART mode) [(SA663)]  
R5F21274SJFP@QFP32 [(SA663)]  
R5F21274SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SJFP@QFP32(single wire) [(SA663)]  
R5F21274SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SJFP@QFP32(UART mode) [(SA663)]  
R5F21274SKFP@QFP32 [(SA663)]

R5F21274SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SKFP@QFP32(single wire) [(SA663)]  
R5F21274SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SKFP@QFP32(UART mode) [(SA663)]  
R5F21274SNFP@QFP32 [(SA663)]  
R5F21274SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SNFP@QFP32(single wire) [(SA663)]  
R5F21274SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SNFP@QFP32(UART mode) [(SA663)]  
R5F21275DFP@QFP32 [(SA663)]  
R5F21275DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275DFP@QFP32(single wire) [(SA663)]  
R5F21275DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275DFP@QFP32(UART mode) [(SA663)]  
R5F21275JFP@QFP32 [(SA663)]  
R5F21275JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(single wire) [(SA663)]  
R5F21275JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(UART mode) [(SA663)]  
R5F21275KFP@QFP32 [(SA663)]  
R5F21275KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(single wire) [(SA663)]  
R5F21275KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(UART mode) [(SA663)]  
R5F21275NFP@QFP32 [(SA663)]  
R5F21275NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275NFP@QFP32(single wire) [(SA663)]  
R5F21275NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275NFP@QFP32(UART mode) [(SA663)]  
R5F21275SDFP@QFP32 [(SA663)]  
R5F21275SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(single wire) [(SA663)]  
R5F21275SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(UART mode) [(SA663)]  
R5F21275SJFP@QFP32 [(SA663)]  
R5F21275SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(single wire) [(SA663)]  
R5F21275SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(UART mode) [(SA663)]  
R5F21275SKFP@QFP32 [(SA663)]  
R5F21275SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SKFP@QFP32(single wire) [(SA663)]  
R5F21275SKFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21275SKFP@QFP32(UART mode) [(SA663)]  
R5F21275SNFP@QFP32 [(SA663)]  
R5F21275SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SNFP@QFP32(single wire) [(SA663)]  
R5F21275SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SNFP@QFP32(UART mode) [(SA663)]  
R5F21276DFP@QFP32 [(SA663)]  
R5F21276DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(single wire) [(SA663)]  
R5F21276DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(UART mode) [(SA663)]  
R5F21276JFP@QFP32 [(SA663)]  
R5F21276JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(single wire) [(SA663)]  
R5F21276JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(UART mode) [(SA663)]  
R5F21276KFP@QFP32 [(SA663)]  
R5F21276KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(single wire) [(SA663)]  
R5F21276KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(UART mode) [(SA663)]  
R5F21276NFP@QFP32 [(SA663)]  
R5F21276NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(single wire) [(SA663)]  
R5F21276NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(UART mode) [(SA663)]  
R5F21276SDFP@QFP32 [(SA663)]  
R5F21276SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SDFP@QFP32(single wire) [(SA663)]  
R5F21276SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SDFP@QFP32(UART mode) [(SA663)]  
R5F21276SJFP@QFP32 [(SA663)]  
R5F21276SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(single wire) [(SA663)]  
R5F21276SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(UART mode) [(SA663)]  
R5F21276SKFP@QFP32 [(SA663)]  
R5F21276SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(single wire) [(SA663)]  
R5F21276SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(UART mode) [(SA663)]  
R5F21276SNFP@QFP32 [(SA663)]  
R5F21276SNFP@QFP32(single ISP) [ISP-HEADER01]

R5F21276SNFP@QFP32(single wire) [(SA663)]  
R5F21276SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(UART mode) [(SA663)]  
R5F21282DSP@SOIC20 [(SA026)]  
R5F21282DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(single wire) [(SA026)]  
R5F21282DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(UART mode) [(SA026)]  
R5F21282JSP@SOIC20 [(SA026)]  
R5F21282JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(single wire) [(SA026)]  
R5F21282JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(UART mode) [(SA026)]  
R5F21282KSP@SOIC20 [(SA026)]  
R5F21282KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(single wire) [(SA026)]  
R5F21282KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(UART mode) [(SA026)]  
R5F21282NSP@SOIC20 [(SA026)]  
R5F21282NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(single wire) [(SA026)]  
R5F21282NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(UART mode) [(SA026)]  
R5F21282SDSP@SOIC20 [(SA026)]  
R5F21282SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(single wire) [(SA026)]  
R5F21282SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(UART mode) [(SA026)]  
R5F21282SJSP@SOIC20 [(SA026)]  
R5F21282SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(single wire) [(SA026)]  
R5F21282SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(UART mode) [(SA026)]  
R5F21282SKSP@SOIC20 [(SA026)]  
R5F21282SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(single wire) [(SA026)]  
R5F21282SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(UART mode) [(SA026)]  
R5F21282SNSP@SOIC20 [(SA026)]  
R5F21282SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(single wire) [(SA026)]  
R5F21282SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(UART mode) [(SA026)]

R5F21284DSP@SOIC20 [(SA026)]  
R5F21284DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(single wire) [(SA026)]  
R5F21284DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(UART mode) [(SA026)]  
R5F21284JSP@SOIC20 [(SA026)]  
R5F21284JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(single wire) [(SA026)]  
R5F21284JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(UART mode) [(SA026)]  
R5F21284KSP@SOIC20 [(SA026)]  
R5F21284KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(single wire) [(SA026)]  
R5F21284KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(UART mode) [(SA026)]  
R5F21284NSP@SOIC20 [(SA026)]  
R5F21284NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(single wire) [(SA026)]  
R5F21284NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(UART mode) [(SA026)]  
R5F21284SDSP@SOIC20 [(SA026)]  
R5F21284SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(single wire) [(SA026)]  
R5F21284SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(UART mode) [(SA026)]  
R5F21284SJSP@SOIC20 [(SA026)]  
R5F21284SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(single wire) [(SA026)]  
R5F21284SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(UART mode) [(SA026)]  
R5F21284SKSP@SOIC20 [(SA026)]  
R5F21284SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(single wire) [(SA026)]  
R5F21284SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(UART mode) [(SA026)]  
R5F21284SNSP@SOIC20 [(SA026)]  
R5F21284SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(single wire) [(SA026)]  
R5F21284SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(UART mode) [(SA026)]  
R5F21292DSP@SOIC20 [(SA026)]  
R5F21292DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(single wire) [(SA026)]

R5F21292DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(UART mode) [(SA026)]  
R5F21292JSP@SOIC20 [(SA026)]  
R5F21292JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(single wire) [(SA026)]  
R5F21292JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(UART mode) [(SA026)]  
R5F21292KSP@SOIC20 [(SA026)]  
R5F21292KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(single wire) [(SA026)]  
R5F21292KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(UART mode) [(SA026)]  
R5F21292NSP@SOIC20 [(SA026)]  
R5F21292NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(single wire) [(SA026)]  
R5F21292NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(UART mode) [(SA026)]  
R5F21292SDSP@SOIC20 [(SA026)]  
R5F21292SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(single wire) [(SA026)]  
R5F21292SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(UART mode) [(SA026)]  
R5F21292SJSP@SOIC20 [(SA026)]  
R5F21292SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(single wire) [(SA026)]  
R5F21292SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(UART mode) [(SA026)]  
R5F21292SKSP@SOIC20 [(SA026)]  
R5F21292SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(single wire) [(SA026)]  
R5F21292SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(UART mode) [(SA026)]  
R5F21292SNSP@SOIC20 [(SA026)]  
R5F21292SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(single wire) [(SA026)]  
R5F21292SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(UART mode) [(SA026)]  
R5F21294DSP@SOIC20 [(SA026)]  
R5F21294DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294DSP@SOIC20(single wire) [(SA026)]  
R5F21294DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294DSP@SOIC20(UART mode) [(SA026)]  
R5F21294JSP@SOIC20 [(SA026)]



R5F21294JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(single wire) [(SA026)]  
R5F21294JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(UART mode) [(SA026)]  
R5F21294KSP@SOIC20 [(SA026)]  
R5F21294KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(single wire) [(SA026)]  
R5F21294KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(UART mode) [(SA026)]  
R5F21294NSP@SOIC20 [(SA026)]  
R5F21294NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(single wire) [(SA026)]  
R5F21294NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(UART mode) [(SA026)]  
R5F21294SDSP@SOIC20 [(SA026)]  
R5F21294SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(single wire) [(SA026)]  
R5F21294SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(UART mode) [(SA026)]  
R5F21294SJSP@SOIC20 [(SA026)]  
R5F21294SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SJSP@SOIC20(single wire) [(SA026)]  
R5F21294SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SJSP@SOIC20(UART mode) [(SA026)]  
R5F21294SKSP@SOIC20 [(SA026)]  
R5F21294SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SKSP@SOIC20(single wire) [(SA026)]  
R5F21294SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SKSP@SOIC20(UART mode) [(SA026)]  
R5F21294SNSP@SOIC20 [(SA026)]  
R5F21294SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(single wire) [(SA026)]  
R5F21294SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(UART mode) [(SA026)]  
R5F212A7SDFA@TQFP64 [(SA768+B251)]  
R5F212A7SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212A7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A7SDFP@TQFP64 [(SA732+B251)]  
R5F212A7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212A7SDFP@TQFP64(UART ISP) [ISP-HEADER01]

R5F212A7SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212A7SNFA@TQFP64 [(SA768+B251)]  
R5F212A7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212A7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A7SNFP@TQFP64 [(SA732+B251)]  
R5F212A7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212A7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212A8SDFA@TQFP64 [(SA768+B251)]  
R5F212A8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212A8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A8SDFP@TQFP64 [(SA732+B251)]  
R5F212A8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212A8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212A8SNFA@TQFP64 [(SA768+B251)]  
R5F212A8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212A8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A8SNFP@TQFP64 [(SA732+B251)]  
R5F212A8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212A8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212AASDFA@TQFP64 [(SA768+B251)]  
R5F212AASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212AASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212AASDFP@TQFP64 [(SA732+B251)]  
R5F212AASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212AASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212AASNFA@TQFP64 [(SA768+B251)]  
R5F212AASNFA@TQFP64(single ISP) [ISP-HEADER01]

R5F212AASNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212AASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212AASNFP@TQFP64 [(SA732+B251)]  
R5F212AASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212AASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212ACSDFA@TQFP64 [(SA768+B251)]  
R5F212ACSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212ACSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212ACSDFP@TQFP64 [(SA732+B251)]  
R5F212ACSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212ACSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212ACSNFA@TQFP64 [(SA768+B251)]  
R5F212ACSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212ACSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212ACSNFP@TQFP64 [(SA732+B251)]  
R5F212ACSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212ACSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B7SDFA@TQFP64 [(SA768+B251)]  
R5F212B7SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B7SDFP@TQFP64 [(SA732+B251)]  
R5F212B7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B7SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B7SNFA@TQFP64 [(SA768+B251)]  
R5F212B7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(UART mode) [(SA768+B251)]

R5F212B7SNFP@TQFP64 [(SA732+B251)]  
R5F212B7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B8SDFA@TQFP64 [(SA768+B251)]  
R5F212B8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B8SDFP@TQFP64 [(SA732+B251)]  
R5F212B8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B8SNFA@TQFP64 [(SA768+B251)]  
R5F212B8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B8SNFP@TQFP64 [(SA732+B251)]  
R5F212B8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BASDFA@TQFP64 [(SA768+B251)]  
R5F212BASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BASDFP@TQFP64 [(SA732+B251)]  
R5F212BASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BASNFA@TQFP64 [(SA768+B251)]  
R5F212BASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BASNFP@TQFP64 [(SA732+B251)]  
R5F212BASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(single wire) [(SA732+B251)]

R5F212BASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BCSDFA@TQFP64 [(SA768+B251)]  
R5F212BCSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BCSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BCSDFP@TQFP64 [(SA732+B251)]  
R5F212BCSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BCSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BCSNFA@TQFP64 [(SA768+B251)]  
R5F212BCSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BCSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BCSNFP@TQFP64 [(SA732+B251)]  
R5F212BCSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BCSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212C7SDFP@TQFP80 [(SA731+B249)]  
R5F212C7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212C7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212C7SNFP@TQFP80 [(SA731+B249)]  
R5F212C7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212C7SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212C8SDFP@TQFP80 [(SA731+B249)]  
R5F212C8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212C8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212C8SNFP@TQFP80 [(SA731+B249)]  
R5F212C8SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212C8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CASDFP@TQFP80 [(SA731+B249)]

R5F212CASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212CASDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CASNFP@TQFP80 [(SA731+B249)]  
R5F212CASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212CASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CCSDFP@TQFP80 [(SA731+B249)]  
R5F212CCSDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212CCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CCSNFP@TQFP80 [(SA731+B249)]  
R5F212CCSNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CCSNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212CCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D7SDFP@TQFP80 [(SA731+B249)]  
R5F212D7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D7SNFP@TQFP80 [(SA731+B249)]  
R5F212D7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D7SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D7SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D8SDFP@TQFP80 [(SA731+B249)]  
R5F212D8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D8SNFP@TQFP80 [(SA731+B249)]  
R5F212D8SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D8SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DASDFP@TQFP80 [(SA731+B249)]  
R5F212DASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DASDFP@TQFP80(UART ISP) [ISP-HEADER01]

R5F212DASDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DASNFP@TQFP80 [(SA731+B249)]  
R5F212DASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DCSDFP@TQFP80 [(SA731+B249)]  
R5F212DCSDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DCSDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DCSNFP@TQFP80 [(SA731+B249)]  
R5F212DCSNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212G4SDFP@QFP32 [(SA663)]  
R5F212G4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SDFP@QFP32(single wire) [(SA663)]  
R5F212G4SNFP@QFP32 [(SA663)]  
R5F212G4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SNFP@QFP32(single wire) [(SA663)]  
R5F212G5SDFP@QFP32 [(SA663)]  
R5F212G5SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SDFP@QFP32(single wire) [(SA663)]  
R5F212G5SNFP@QFP32 [(SA663)]  
R5F212G5SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SNFP@QFP32(single wire) [(SA663)]  
R5F212G6SDFP@QFP32 [(SA663)]  
R5F212G6SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SDFP@QFP32(single wire) [(SA663)]  
R5F212G6SNFP@QFP32 [(SA663)]  
R5F212G6SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SNFP@QFP32(single wire) [(SA663)]  
R5F212H1SDSP@TSSOP20 [(SA026+B001)]  
R5F212H1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SDSP@TSSOP20(single wire [(SA026+B001)]  
R5F212H1SNSP@TSSOP20 [(SA026+B001)]  
R5F212H1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SNSP@TSSOP20(single wire [(SA026+B001)]  
R5F212H2SDSP@TSSOP20 [(SA725+B005)]  
R5F212H2SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H2SDSP@TSSOP20(single wire [(SA026+B001)]

R5F212H2SNSP@TSSOP20 [(SA725+B005)]  
R5F212H2SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H2SNSP@TSSOP20(single wire [(SA026+B001)])  
R5F212J0SDSP@TSSOP20 [(SA026+B001)]  
R5F212J0SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SDSP@TSSOP20(single wire [(SA026+B001)])  
R5F212J0SNSP@TSSOP20 [(SA026+B001)]  
R5F212J0SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SNSP@TSSOP20(single wire [(SA026+B001)])  
R5F212J1SDSP@TSSOP20 [(SA026+B001)]  
R5F212J1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SDSP@TSSOP20(single wire [(SA026+B001)])  
R5F212J1SNSP@TSSOP20 [(SA026+B001)]  
R5F212J1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SNSP@TSSOP20(single wire [(SA026+B001)])  
R5F212K2SDFP@QFP32 [(SA663+B005)]  
R5F212K2SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K2SDFP@QFP32(single wire [(SA663+B005)])  
R5F212K2SNFP@QFP32 [(SA663+B005)]  
R5F212K2SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K2SNFP@QFP32(single wire [(SA663+B005)])  
R5F212K4SDFP@QFP32 [(SA663+B005)]  
R5F212K4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K4SDFP@QFP32(single wire [(SA663+B005)])  
R5F212K4SNFP@QFP32 [(SA663+B005)]  
R5F212K4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K4SNFP@QFP32(single wire [(SA663+B005)])  
R5F212L2SDFP@QFP32 [(SA663+B005)]  
R5F212L2SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L2SDFP@QFP32(single wire [(SA663+B005)])  
R5F212L2SNFP@QFP32 [(SA663+B005)]  
R5F212L2SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L2SNFP@QFP32(single wire [(SA663+B005)])  
R5F212L4SDFP@QFP32 [(SA663+B005)]  
R5F212L4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L4SDFP@QFP32(single wire [(SA663+B005)])  
R5F212L4SNFP@QFP32 [(SA663+B005)]  
R5F212L4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L4SNFP@QFP32(single wire [(SA663+B005)])

**RICOH**



## **E ( E ) PROM / FRAM / NVRAM**

RD27C256  
RD27C32  
RD27C64

## **PLD**

EPL16P8 [ ( SA001A ) ]	EPL16P8@PLCC20
EPL16RP4 [ ( SA001A ) ]	EPL16RP4@PLCC20
EPL16RP6 [ ( SA001A ) ]	EPL16RP6@PLCC20
EPL16RP8 [ ( SA001A ) ]	EPL16RP8@PLCC20

## **ROCKWELL**

### **E ( E ) PROM / FRAM / NVRAM**

R2764  
R2764C  
R2764P  
R27C64  
R2816  
R5213  
R52B13  
R52B33

## **ROHM**

### **E ( E ) PROM / FRAM / NVRAM**

BR24C01@SOP8 [ ( SA602A ) ] [ ( SA026 ) ]	BR24C01@TSSOP8
BR24C01@TSSOP8 ( 3 * 3mm ) [ ( SA666 ) ]	
BR24C01A	
BR24C01A ( F ) [ ( SA602A ) ]	BR24C01A ( FJ )

[ (SA602A) ]	
BR24C01A(FV) [ (SA026) ]	
BR24C02	
BR24C02(F) [ (SA602A) ]	BR24C02(FJ)
[ (SA602A) ]	
BR24C02(FV) [ (SA026) ]	BR24C02@SOP8
[ (SA602A) ]	
BR24C02@TSSOP8 [ (SA026) ]	BR24C02@TSSOP8 (3*3mm)
[ (SA666) ]	
BR24C04	
[ (SA602A) ]	BR24C04(F)
BR24C04(FJ) [ (SA602A) ]	
[ (SA026) ]	BR24C04(FV)
BR24C04@SOP8 [ (SA602A) ]	
[ (SA026) ]	BR24C04@TSSOP8
BR24C04@TSSOP8 (3*3mm) [ (SA666) ]	
BR24C08	
BR24C08(F) [ (SA602A) ]	BR24C08(FJ)
[ (SA602A) ]	
BR24C08(FV) [ (SA026) ]	BR24C08@SOP8
[ (SA602A) ]	
BR24C08@TSSOP8 [ (SA026) ]	BR24C08@TSSOP8 (3*3mm)
[ (SA666) ]	
BR24C16	
[ (SA602A) ]	BR24C16(F)
BR24C16(FJ) [ (SA602A) ]	
[ (SA026) ]	BR24C16(FV)
BR24C21	
[ (SA602A) ]	BR24C21(F)
BR24C21(FJ) [ (SA602A) ]	
[ (SA026) ]	BR24C21(FV)
BR24C32	
[ (SA602A) ]	BR24C32(F)
BR24C64	
[ (SA602A) ]	BR24C64(F)
BR24E16	
[ (SA602A) ]	BR24E16(F)
BR24E16(FJ) [ (SA602A) ]	
[ (SA026) ]	BR24E16(FV)
BR24L01A	
[ (SA602A) ]	BR24L01A(F)
BR24L01A(FJ) [ (SA602A) ]	
[ (SA026) ]	BR24L01A(FV)

BR24L01A(FVM) [(SA666)]	
BR24L02	
BR24L02(F) [(SA602A)]	BR24L02(FJ)
[(SA602A)]	
BR24L02(FV) [(SA026)]	BR24L02(FVM)
[(SA666)]	
BR24L04	
BR24L04(F)	
[(SA602A)]	
BR24L04(FJ) [(SA602A)]	BR24L04(FV)
[(SA026)]	
BR24L04(FVM) [(SA666)]	
BR24L08	
BR24L08(F) [(SA602A)]	BR24L08(FJ)
[(SA602A)]	
BR24L08(FV) [(SA026)]	BR24L08(FVM)
[(SA666)]	
BR24L16	
BR24L16(F)	
[(SA602A)]	
BR24L16(FJ) [(SA602A)]	BR24L16(FV)
[(SA026)]	
BR24L16(FVM) [(SA666)]	
BR24L32	
BR24L32(F) [(SA602A)]	BR24L32(FJ)
[(SA602A)]	
BR24L32(FV) [(SA026)]	
BR24L64	
BR24L64(F) [(SA602A)]	BR24L64(FJ)
[(SA602A)]	
BR24L64(FV) [(SA026)]	BR25010@SOIC8
[(SA602A)]	
BR25010@TSSOP8 [(SA026)]	BR25020@SOIC8
[(SA602A)]	
BR25020@TSSOP8 [(SA026)]	BR25040@SOIC8
[(SA602A)]	
BR25040@TSSOP8 [(SA026)]	BR25080@SOIC8
[(SA602A)]	
BR25080@TSSOP8 [(SA026)]	BR25160@SOIC8
[(SA602A)]	
BR25160@TSSOP8 [(SA026)]	BR25320@SOIC8
[(SA602A)]	
BR25L010	
BR25L010(F)	
[(SA602A)]	
BR25L010(FJ) [(SA602A)]	BR25L010(FV)

[ (SA026) ]	
BR25L010(FVM) [ (SA666) ]	
BR25L020	
BR25L020(F) [ (SA602A) ]	BR25L020(FJ)
[ (SA602A) ]	
BR25L020(FV) [ (SA026) ]	BR25L020(FVM)
[ (SA666) ]	
BR25L040	
[ (SA602A) ]	BR25L040(F)
BR25L040(FJ) [ (SA602A) ]	BR25L040(FV)
[ (SA026) ]	
BR25L040(FVM) [ (SA666) ]	
BR25L080	
BR25L080(F) [ (SA602A) ]	BR25L080(FJ)
[ (SA602A) ]	
BR25L080(FV) [ (SA026) ]	
BR25L160	
BR25L160(F) [ (SA602A) ]	BR25L160(FJ)
[ (SA602A) ]	
BR25L160(FV) [ (SA026) ]	
BR25L320	
BR25L320(F) [ (SA602A) ]	BR25L320(FJ)
[ (SA602A) ]	
BR25L320(FV) [ (SA026) ]	
BR25L640	
BR25L640(F) [ (SA602A) ]	BR25L640(FJ)
[ (SA602A) ]	
BR25L640(FV) [ (SA026) ]	
BR34L02	
BR34L02(F) [ (SA602A) ]	BR34L02(FJ)
[ (SA602A) ]	
BR34L02(FV) [ (SA026) ]	BR34L02(FVM)
[ (SA666) ]	
BR9010	BR9010(F)
[ (SA602A) ]	
BR9010(FV) [ (SA026) ]	BR9010(RFV)
[ (SA026) ]	
BR9010(RFVM) [ (SA666) ]	
BR9016	
BR9016(F) [ (SA602A) ]	BR9016(RFV)
[ (SA026) ]	
BR9016A(F) [ (SA602A) ]	BR9016A(RFV)
[ (SA026) ]	

BR9016A(RFVM) [(SA666)]	
BR9020	
BR9020(F) [(SA602A)]	BR9020(FV)
[(SA026)]	
BR9020(RFV) [(SA026)]	BR9020(RFVM)
[(SA666)]	
BR9040	
[(SA602A)]	BR9040(F)
BR9040(FV) [(SA026)]	BR9040(RFV)
[(SA026)]	
BR9040(RFVM) [(SA666)]	
BR9080	
BR9080(F) [(SA602A)]	BR9080(RFV)
[(SA026)]	
BR9080A	BR9080A(F)
[(SA602A)]	
BR9080A(FV) [(SA026)]	BR9080A(RFV)
[(SA026)]	
BR9080A(RFVM) [(SA666)]	BR93A46(F)
[(SA602A)]	
BR93A46(FJ) [(SA602A)]	BR93A46(RF)
[(SA602A)]	
BR93A46(RFJ) [(SA602A)]	BR93A56(F)
[(SA602A)]	
BR93A56(FJ) [(SA602A)]	BR93A56(RF)
[(SA602A)]	
BR93A56(RFJ) [(SA602A)]	BR93A66(F)
[(SA602A)]	
BR93A66(FJ) [(SA602A)]	BR93A66(RF)
[(SA602A)]	
BR93A66(RFJ) [(SA602A)]	BR93A86(F)
[(SA602A)]	
BR93A86(FJ) [(SA602A)]	BR93A86(RF)
[(SA602A)]	
BR93A86(RFJ) [(SA602A)]	
BR93C46	
BR93C46(F) [(SA602A)]	BR93C46(FJ)
[(SA602A)]	
BR93C46(FV) [(SA026)]	BR93C46(RF)
[(SA602A)]	
BR93C46(RFJ) [(SA602A)]	
BR93C56	
BR93C56(F) [(SA602A)]	BR93C56(FJ)

[ (SA602A) ]	
BR93C56 (FV) [ (SA026) ]	BR93C56 (RF)
[ (SA602A) ]	
BR93C56 (RFJ) [ (SA602A) ]	
BR93C66	
BR93C66 (F) [ (SA602A) ]	BR93C66 (FJ)
[ (SA602A) ]	
BR93C66 (FV) [ (SA026) ]	BR93C66 (RF)
[ (SA602A) ]	
BR93C66 (RFJ) [ (SA602A) ]	BR93H46 (RF)
[ (SA602A) ]	
BR93H46 (RFJ) [ (SA602A) ]	BR93H56 (RF)
[ (SA602A) ]	
BR93H56 (RFJ) [ (SA602A) ]	BR93H66 (RF)
[ (SA602A) ]	
BR93H66 (RFJ) [ (SA602A) ]	BR93H76 (RF)
[ (SA602A) ]	
BR93H76 (RFJ) [ (SA602A) ]	BR93H86 (RF)
[ (SA602A) ]	
BR93H86 (RFJ) [ (SA602A) ]	
BR93L46	
BR93L46 (F) [ (SA602A) ]	BR93L46 (FJ)
[ (SA602A) ]	
BR93L46 (FV) [ (SA026) ]	BR93L46 (RF)
[ (SA602A) ]	
BR93L46 (RFJ) [ (SA602A) ]	
BR93L56	
BR93L56 (F) [ (SA602A) ]	BR93L56 (FJ)
[ (SA602A) ]	
BR93L56 (FV) [ (SA026) ]	BR93L56 (RF)
[ (SA602A) ]	
BR93L56 (RFJ) [ (SA602A) ]	
BR93L66	
BR93L66 (F) [ (SA602A) ]	BR93L66 (FJ)
[ (SA602A) ]	
BR93L66 (FV) [ (SA026) ]	BR93L66 (RF)
[ (SA602A) ]	
BR93L66 (RFJ) [ (SA602A) ]	BR93L76 (F)
[ (SA602A) ]	
BR93L76 (FJ) [ (SA602A) ]	BR93L76 (RF)
[ (SA602A) ]	
BR93L76 (RFJ) [ (SA602A) ]	BR93L76 (RFV)
[ (SA026A) ]	

BR93L76 (RFVJ) [(SA666A)]	BR93L76 (RFVM)
[(SA666A)]	
BR93L76 (RFVT) [(SA026A)]	BR93L86 (F)
[(SA602A)]	
BR93L86 (FJ) [(SA602A)]	BR93L86 (RF)
[(SA602A)]	
BR93L86 (RFJ) [(SA602A)]	BR93L86 (RFV)
[(SA026A)]	
BR93L86 (RFVJ) [(SA666A)]	BR93L86 (RFVM)
[(SA666A)]	
BR93L86 (RFVT) [(SA026A)]	
BR93LC46	
BR93LC46 (F) [(SA602A)]	BR93LC46 (FJ)
[(SA602A)]	
BR93LC46 (FV) [(SA026)]	BR93LC46 (RF)
[(SA602A)]	
BR93LC46 (RFJ) [(SA602A)]	
BR93LC56	
BR93LC56 (F) [(SA602A)]	BR93LC56 (FJ)
[(SA602A)]	
BR93LC56 (FV) [(SA026)]	BR93LC56 (RF)
[(SA602A)]	
BR93LC56 (RFJ) [(SA602A)]	
BR93LC66	
BR93LC66 (F) [(SA602A)]	BR93LC66 (FJ)
[(SA602A)]	
BR93LC66 (FV) [(SA026)]	BR93LC66 (RF)
[(SA602A)]	
BR93LC66 (RFJ) [(SA602A)]	BR93LL46 (F)
[(SA602A)]	
BR93LL46 (FV) [(SA026)]	BR95010 (3*3)@TSSOP8
[(SA666)]	
BR95010@SO8 [(SA602A)]	BR95010@TSSOP8
[(SA026)]	
BR95020 (3*3)@TSSOP8 [(SA666)]	BR95020@SO8
[(SA602A)]	
BR95020@TSSOP8 [(SA026)]	BR95040 (3*3)@TSSOP8
[(SA666)]	
BR95040@SO8 [(SA602A)]	BR95040@TSSOP8
[(SA026)]	
BR95080@SO8 [(SA602A)]	BR95080@TSSOP8
[(SA026)]	
BR95160@SO8 [(SA602A)]	BR95160@TSSOP8

[ ( SA026 ) ]

**SAIFUN****E ( E ) PROM / FRAM / NVRAM**

SA24C1024 [ ( SA602A ) ]	SA24C1024@SOIC8
SA24C512 [ ( SA602A ) ]	SA24C512@SOIC8
SA24C512@TSSOP8 [ ( SA026 ) ] ( H )	SA25C1024
SA25C1024 ( H ) @CSP8 [ ( SA683 ) ] [ ( SA602A ) ]	SA25C1024 ( H ) @SOIC8
SA25C1024 ( L ) [ ( SA683 ) ]	SA25C1024 ( L ) @CSP8
SA25C1024 ( L ) @SOIC8 [ ( SA602A ) ] ( H )	SA25C512
SA25C512 ( H ) @CSP8 [ ( SA683 ) ] [ ( SA602A ) ]	SA25C512 ( H ) @SOIC8
SA25C512 ( L ) [ ( SA683 ) ]	SA25C512 ( L ) @CSP8
SA25C512 ( L ) @SOIC8 [ ( SA602A ) ]	
SA25F005	
SA25F005@MLF8 [ ( SA683 ) ] [ ( SA602A ) ]	SA25F005@SOIC8
SA25F010 [ ( SA683 ) ]	SA25F010@MLF8
SA25F010@SOIC8 [ ( SA602A ) ]	
SA25F020	
SA25F020@MLF8 [ ( SA683 ) ] [ ( SA602A ) ]	SA25F020@SOIC8
SA25F040 [ ( SA683 ) ]	SA25F040@MLF8
SA25F040@SOIC8 [ ( SA602A ) ]	
SA25F080	
SA25F080@MLF8 [ ( SA683 ) ] [ ( SA602A ) ]	SA25F080@SOIC8
SA25F160	
HEADER01 ]	SA25F160 ( ISP ) [ ISP-
SA25F160@MLF8 [ ( SA683 ) ]	
SA25F160@MLF8 ( ISP ) [ ISP-HEADER01 ]	



SA25F160@SOIC16 [(SA602)]  
SA25F160@SOIC16(ISP) [ISP-HEADER01]

## SAMSUNG

### E ( E ) PROM / FRAM / NVRAM

K5A3240CBM@TFBGA69 [(SA642A-B032A-Y096F001Y)]  
K5A3240CTM@TFBGA69 [(SA642A-B032A-Y096F001Y)]  
K5A3240YBB@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3240YBC@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3240YTB@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3240YTC@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3280YBB@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3280YBC@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3280YTB@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3280YTC@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3281CBM@TFBGA69 [(SA642A-B032A-Y096F001Y)]  
K5A3281CTM@TFBGA69 [(SA642A-B032A-Y096F001Y)]  
K5A3340YBB@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3340YBC@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3340YTB@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3340YTC@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3380YBB@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3380YBC@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3380YTB@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A3380YTC@TBGA69 [(SA642A-B032A-Y096F001)]  
K5A6317CBM@FBGA69 [(SA642A-B032A-Y096F001Y)]  
K5A6317CTM@FBGA69 [(SA642A-B032A-Y096F001Y)]  
K5D1212DCM@FBGA149 [(SA664G-B143A-Y144F001Y)]  
K5D1213ACM@FBGA137 [(SA700E-B153A-M137F001Y)]  
K5D1257ACB-D090@FBGA107 [(SA642V-B133-T096F001Y)]  
K5D1257DCA-D090@FBGA107 [(SA642V-B133-T096F001Y)]  
K5D1257DCMD090@FBGA107 [(SA642V-B133-T096F001Y)]  
K5D1258ACB@FBGA137 [(SA700G-B153A-Y137F001Y)]  
K5D1258DCM@FBGA137 [(SA700E-B153A-M137F001Y)]  
K5D1G12DCM@FBGA107 [(SA642V-B133-T096F001Y)]  
K5D1G13ACD@FBGA137 [(SA700E-B153A-M137F001Y)]  
K5D1G13ACH@FBGA137 [(SA700E-B153A-M137F001Y)]  
K5D1G58ACA@FBGA137 [(SA700E-B153A-M137F001Y)]  
K5D5613HCMD075@FBGA137 [(SA700E-B153-M137F001Y)]  
K5D5613VCMD075@FBGA137 [(SA700E-B153-M137F001Y)]

K5D5629ACCD090@FBGA107 [ (SA642V-B133-T096F001Y) ]  
K5D5657ACAD090@FBGA107 [ (SA642V-B133-T096F001Y) ]  
K5D5657ACBD090@FBGA107 [ (SA642V-B133-T096F001Y) ]  
K5D5657DCAD090@FBGA107 [ (SA642V-B133-T096F001Y) ]  
K5E1257ACM@FBGA107 [ (SA642V-B133-T096F001Y) ]  
K5E1G12ACC@FBGA107 [ (SA642V-B133-T096F001Y) ]  
K5J6316CBM@FBGA69 [ (SA642A-B032A-Y096F001) ]  
K5J6316CTM@FBGA69 [ (SA642A-B032A-Y096F001) ]  
K5J6332CBM@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
K5J6332CTM@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
K5L2731CAA@FBGA64 [ (SA642A-B079A-Y096F001Y) ]  
K5L2731CAM@FBGA64 [ (SA642A-B079A-Y096F001Y) ]  
K5L2763CAA@FBGA64 [ (SA642A-B079A-Y096F001Y) ]  
K5L2763CAM@FBGA64 [ (SA642A-B079A-Y096F001Y) ]  
K5L2864ABM@FBGA115 [ (SA664A-B189A-W115F001Y) ]  
K5L2864ATM@FBGA115 [ (SA664A-B189A-W115F001Y) ]  
K5L2931CAM@FBGA73 [ (SA642A-B079A-Y096F001Y) ]  
K5L3216CAM@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
K5L3316CAM@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
K5L6331CAA@FBGA56 [ (SA642P-B032A-W056F001Y) ]  
K5L6631CAA@FBGA56 [ (SA642P-B032A-W056F001Y) ]  
K8D1716UBC@FBGA48 [ (SA642N-B026A-W048F001N) ]  
K8D1716UBC@TSOP48 [ (SA247-B005) ]  
K8D1716UTC@FBGA48 [ (SA642N-B026A-W048F001N) ]  
K8D1716UTC@TSOP48 [ (SA247-B005) ]  
K8D3216UBC@FBGA48 [ (SA642B-B026A-Y072F001) ]  
K8D3216UBC@TSOP48 [ (SA247-B005) ]  
K8D3216UTC@FBGA48 [ (SA642B-B026A-Y072F001) ]  
K8D3216UTC@TSOP48 [ (SA247-B005) ]  
K8D3316UBC@FBGA48 [ (SA642B-B026A-Y072F001) ]  
K8D3316UBC@TSOP48 [ (SA247-B005) ]  
K8D3316UTC@FBGA48 [ (SA642B-B026A-Y072F001) ]  
K8D3316UTC@TSOP48 [ (SA247-B005) ]  
K8D6316UBM@FBGA48 [ (SA642N-B026A-W048F001Y) ]  
K8D6316UBM@TSOP48 [ (SA247-B005) ]  
K8D6316UTM@FBGA48 [ (SA642N-B026A-W048F001Y) ]  
K8D6316UTM@TSOP48 [ (SA247-B005) ]  
K8P3215UQB@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
K8P3215UQB@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
K8P3215UQB@TSOP48 [ (SA247-B005) ]      K8P5615UQA@TSOP56 [ (SA628-B102) ]  
K8P6415UQB@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
K8P6415UQB@FBGA64 [ (SA655F-B099A-W064F001Y) ]

K8P6415UQB@TSOP48 [ (SA247-B005) ]      K8Q2815UQB@TSOP56 [ (SA628+B102) ]  
K9F1208R0C@FBGA63 [ (SA642LL-B280-M063F001N) ]  
K9F1208U0A@TSOP48 [ (SA247-B005) ]  
K9F1208U0B@FBGA63 [ (SA642LL-B026-M063F001N) ]  
K9F1208U0B@TSOP48 [ (SA247-B005) ]  
K9F1208U0C@FBGA63 [ (SA642LL-B026-M063F001N) ]  
K9F1208U0C@TSOP48 [ (SA247-B005) ]      K9F1208U0M@TSOP48 [ (SA247-B005) ]  
K9F1216U0A@TSOP48 [ (SA247-B005) ]      K9F1G08Q0M@TSOP48 [ (SA247-B005) ]  
K9F1G08R0A-JIB0@FBGA63 [ (SA642V-B026-T096F001) ]  
K9F1G08R0B@FBGA63 [ (SA642KK-B026A-W048F001Y) ]  
K9F1G08U0A@FBGA63 [ (SA642NN-B026A-W063F001Y) ]  
K9F1G08U0A@TSOP48 [ (SA247-B005) ]      K9F1G08U0B@TSOP48 [ (SA247-B005) ]  
K9F1G08U0M@TSOP48 [ (SA247-B005) ]  
K9F1G16D0M(PCB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16D0M(PIB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16D0M(YCB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16D0M(YIB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16Q0M(PCB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16Q0M(PIB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16Q0M(YCB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16Q0M(YIB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16U0M(PCB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16U0M(PIB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16U0M(YCB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16U0M(YIB0)@TSOP48 [ (SA247-B005) ]  
K9F2808U0C@TSOP48 [ (SA247-B005) ]  
K9F2G08R0A@FBGA63 [ (SA642V-B280A-T096F001) ]  
K9F2G08U0A@TSOP48 [ (SA247-B005) ]      K9F2G08U0M@TSOP48 [ (SA247-B005) ]  
K9F4008W0A@TSOP44 [ (SA645) ]      K9F4G08U0A@TSOP48 [ (SA247-B005) ]  
K9F4G08U0M@TSOP48 [ (SA247-B005) ]  
K9F5608R0D@FBGA63 [ (SA642KK-B026-W048F001Y) ]  
K9F5608U0B(partition)@TSOP48 [ (SA247-B005) ]  
K9F5608U0B@TSOP48 [ (SA247-B005) ]  
K9F5608U0C(partition)@FBGA63 [ (SA642KK-B026-W048F001Y) ]  
K9F5608U0C(partition)@TSOP48 [ (SA247-B005) ]  
K9F5608U0C@FBGA63 [ (SA642KK-B026-W048F001Y) ]  
K9F5608U0C@TSOP48 [ (SA247-B005) ]

K9F5608U0D(partition)@FBGA63 [(SA642KK-B026-W048F001Y)]  
K9F5608U0D(partition)@TSOP48 [(SA247-B005)]  
K9F5608U0D@FBGA63 [(SA642KK-B026-W048F001Y)]  
K9F5608U0D@TSOP48 [(SA247-B005)] K9F6408U0C@TSOP44 [(SA645-B005)]  
K9F8G08U0A@TSOP48 [(SA247-B005)] K9F8G08U0M@TSOP48 [(SA247-B005)]  
K9G4G08U0A@TSOP48 [(SA247-B005)] K9G8G08U0M@TSOP48 [(SA247-B005)]  
K9GAG08U0M@TSOP48 [(SA247-B005)] K9HBG08U1M@TSOP48 [(SA247-B005)]  
K9K1208D0C@FBGA63 [(SA642KK-B026-W048F001Y)]  
K9K1208U0A@TSOP48 [(SA247-B005)] K9K1208U0M@TSOP48 [(SA247-B005)]  
K9K1216Q0C@FBGA63 [(SA664A-B114-W115F001)]  
K9K1G08U0B-JIB0@FBGA63 [(SA642LL-B026A-M063F001Y)]  
K9K1G08U0M@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(PCB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(PIB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(YCB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(YIB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M@TSOP48 [(SA247-B005)]  
K9K2G08U0M(PCB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08U0M(PIB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08U0M(YCB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08U0M(YIB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08U0M@TSOP48 [(SA247-B005)] K9K4G08Q0M@TSOP48 [(SA247-B005)]  
K9K4G08U0M@TSOP48 [(SA247-B005)]  
K9K4G16Q0M(PCB0)@TSOP48 [(SA247-B005)]  
K9K4G16Q0M(PIB0)@TSOP48 [(SA247-B005)]  
K9K4G16Q0M(YCB0)@TSOP48 [(SA247-B005)]  
K9K4G16Q0M(YIB0)@TSOP48 [(SA247-B005)]  
K9K4G16U0M(PCB0)@TSOP48 [(SA247-B005)]  
K9K4G16U0M(PIB0)@TSOP48 [(SA247-B005)]  
K9K4G16U0M(YCB0)@TSOP48 [(SA247-B005)]  
K9K4G16U0M(YIB0)@TSOP48 [(SA247-B005)]  
K9K8G08U0A@TSOP48 [(SA247-B005)] K9L8G08U0M@TSOP48 [(SA247-B005)]  
K9LAG08U0M@TSOP48 [(SA247-B005)] K9LAG08U1M@TSOP48 [(SA247-B005)]  
K9T1G08U0M@TSOP48 [(SA247-B005)]  
K9W8G08U1M(PCB0)@TSOP48 [(SA247-B005)]

K9W8G08U1M(PIB0)@TSOP48 [(SA247-B005)]  
 K9WAG08U1A@TSOP48 [(SA247+B005)]  
 KAD060300B@TBGA69 [(SA642A-B039A-Y096F001)]  
 KAD060300C@TBGA69 [(SA642A-B039A-Y096F001)]  
 KAD060700D@TBGA69 [(SA642A-B039A-Y096F001Y)]  
 KAD070300B@TBGA69 [(SA642A-B039A-Y096F001)]  
 KAD070300C@TBGA69 [(SA642A-B039A-Y096F001)]  
 KAD070700D@TBGA69 [(SA642A-B039A-Y096F001Y)]  
 KAD090300B@TBGA69 [(SA642A-B039A-Y096F001)]  
 KAD100300B@TBGA69 [(SA642A-B039A-Y096F001)]  
 KAG00K007A-DGG5@FBGA107 [(SA642V-B133-T096F001Y)]  
 KAL00R00KM-DG55@FBGA137 [(SA700B-B153A-P137F001Y)]  
 KAL00T00UM@FBGA137 [(SA700C-B153A-M137F001Y)]  
 KAL00X00UA-DJYY@FBGA137 [(SA700E-B153A-M137F001Y)]  
 KAL00X00UM-DJYY@FBGA137 [(SA700E-B153A-M137F001Y)]  
 KAP17WG00M(Nor)@FBGA167 [(SA700A-B149A-P164F001Y)]  
 KBE00500AM-D437@FBGA137 [(SA700E-B153A-M137F001Y)]  
 KBE00F003A-D411@FBGA107 [(SA642V-B133-T096F001Y)]  
 KBE00G005M-D411@FBGA137 [(SA700E-B153A-M137F001Y)]  
 KBE00S005M-D411@FBGA137 [(SA700D-B153A-Y130F001Y)]  
 KBE00S00AM-D411@FBGA137 [(SA700D-B153A-Y130F001Y)]  
 KFG1216Q2B-DEB8@FBGA63 [(SA664L-B266-W063F001Y)]  
 KFG1216U2A-DIB5@FBGA63 [(SA664L-B266-W063F001Y)]  
 KFG1216U2A-DIB6@FBGA63 [(SA664L-B266-W063F001Y)]  
 KFG1216U2B-DIB5@FBGA63 [(SA664L-B266-W063F001Y)]  
 KFG1216U2B-DIB6@FBGA63 [(SA664L-B266-W063F001Y)]  
 KFG5616D1M@FBGA63 [(SA642A-B026A-Y096N001)]  
 KFG5616Q1M@FBGA63 [(SA642A-B026A-Y096N001)]  
 KFG5616U1M@FBGA63 [(SA642A-B026A-Y096N001)]  
 KM2816A  
 KM2816AI  
 KM2817A  
 KM2817AI  
 KM2864A  
 KM2864AH  
 KM2865A  
 KM2865AH  
 KM28C16  
 [(SA015A1T)]  
 KM28C16I  
 [(SA015A1T)]  
 KM28C17  
 [(SA015A1T)]

KM28C16@PLCC32

KM28C16I@PLCC32

KM28C17@PLCC32

KM28C17I	KM28C17I@PLCC32
[ (SA015A1T) ]	
KM28C256	KM28C256@PLCC32
[ (SA015A1T) ]	
KM28C256I	KM28C256I@PLCC32
[ (SA015A1T) ]	
KM28C64	KM28C64@PLCC32
[ (SA015A1T) ]	
KM28C64A	KM28C64A@PLCC32
[ (SA015A1T) ]	
KM28C64B	KM28C64B@PLCC32
[ (SA015A1T) ]	
KM28C64I	KM28C64I@PLCC32
[ (SA015A1T) ]	
KM28C65	KM28C65@PLCC32
[ (SA015A1T) ]	
KM28C65A	KM28C65A@PLCC32
[ (SA015A1T) ]	
KM28C65I	KM28C65I@PLCC32
[ (SA015A1T) ]	
KM29U128T@TSOP48 [ (SA247-B005) ]	KM29W32000AIT@TSOP44
[ (SA645) ]	
KM29W32000AT@TSOP44 (DWB) [ (SA645) ]	
KM29W32000AT@TSOP44 (ZMQ) [ (SA645) ]	
KM93C06 (08bit)	KM93C06
(16bit)	
KM93C06 (G) (08bit)@SOIC8 [ (SA602A) ]	
KM93C06 (G) (16bit)@SOIC8 [ (SA602A) ]	
KM93C06 (GD) (08bit)@SOIC8 [ (SA602A) ]	
KM93C06 (GD) (16bit)@SOIC8 [ (SA602A) ]	
KM93C07 (08bit)	KM93C07
(16bit)	
KM93C07 (G) (08bit)@SOIC8 [ (SA602A) ]	
KM93C07 (G) (16bit)@SOIC8 [ (SA602A) ]	
KM93C07 (GD) (08bit)@SOIC8 [ (SA602A) ]	
KM93C07 (GD) (16bit)@SOIC8 [ (SA602A) ]	
KM93C46V	KM93C46V (G)@SOIC8
[ (SA602A) ]	
KM93C46V (GD)@SOIC8 [ (SA602A) ]	
KM93C47V	
KM93C47V (G)@SOIC8 [ (SA602A) ]	KM93C47V (GD)@SOIC8
[ (SA602A) ]	
KM93C56V	KM93C56V (G)@SOIC8

[ (SA602A) ]	
KM93C56V(GD)@SOIC8 [ (SA602A) ]	
KM93C57V	
KM93C57V(G)@SOIC8 [ (SA602A) ]	KM93C57V(GD)@SOIC8
[ (SA602A) ]	
KM93C66V	
[ (SA602A) ]	
KM93C66V(GD)@SOIC8 [ (SA602A) ]	KM93C66V(G)@SOIC8
KM93C67V	
KM93C67V(G)@SOIC8 [ (SA602A) ]	KM93C67V(GD)@SOIC8
[ (SA602A) ]	
KS24C010	
[ (SA602A) ]	
KS24C010@TSSOP8 [ (SA026) ]	
KS24C011	
KS24C011@SOIC8 [ (SA602A) ]	KS24C011@TSSOP8
[ (SA026) ]	
KS24C020	
[ (SA602A) ]	
KS24C020@TSSOP8 [ (SA026) ]	
KS24C021	
KS24C021@SOIC8 [ (SA602A) ]	KS24C021@TSSOP8
[ (SA026) ]	
KS24C040	
[ (SA602A) ]	
KS24C040@TSSOP8 [ (SA026) ]	
KS24C041	
KS24C041@SOIC8 [ (SA602A) ]	KS24C041@TSSOP8
[ (SA026) ]	
KS24C080	
[ (SA602A) ]	
KS24C080@TSSOP8 [ (SA026) ]	
KS24C081	
KS24C081@SOIC8 [ (SA602A) ]	KS24C081@TSSOP8
[ (SA026) ]	
S524A40X10	
[ (SA602A) ]	
S524A40X10@TSSOP8 [ (SA026) ]	S524A40X10@SOP8
S524A40X11	
S524A40X11@SOP8 [ (SA602A) ]	S524A40X11@TSSOP8
[ (SA026) ]	
S524A40X20	
[ (SA602A) ]	
	S524A40X20@SOP8

S524A40X20@TSSOP8 [(SA026)]  
S524A40X21  
S524A40X21@SOP8 [(SA602A)]  
[(SA026)]  
S524A40X40  
[(SA602A)]  
S524A40X40@TSSOP8 [(SA026)]  
S524A40X41  
S524A40X41@SOP8 [(SA602A)]  
[(SA026)]  
S524A60X51  
[(SA602A)]  
S524A60X51@TSSOP8 [(SA026)]  
S524A60X81  
S524A60X81@SOP8 [(SA602A)]  
[(SA026)]  
S524AB0X91  
[(SA602A)]  
S524AB0X91@TSSOP8 [(SA026)]  
S524AB0XB1  
S524AB0XB1@SOP8 [(SA602A)]  
[(SA026)]  
S524AD0XD1  
[(SA602A)]  
S524AD0XD1@TSSOP8 [(SA026)]  
S524AD0XF1  
S524AD0XF1@SOP8 [(SA602A)]  
[(SA026)]  
S524C20D11  
[(SA602A)]  
S524C20D11@TSSOP8 [(SA026)]  
S524C20D21  
S524C20D21@SOP8 [(SA602A)]  
[(SA026)]  
S524C80D41  
[(SA602A)]  
S524C80D41@TSSOP8 [(SA026)]  
S524C80D81  
S524C80D81@SOP8 [(SA602A)]  
[(SA026)]  
S524L50X51  
[(SA602A)]  
S524L50X51@TSSOP8 [(SA026)]

S524A40X21@TSSOP8  
  
S524A40X40@SOP8  
  
S524A40X41@TSSOP8  
  
S524A60X51@SOP8  
  
S524A60X81@TSSOP8  
  
S524AB0X91@SOP8  
  
S524AB0XB1@TSSOP8  
  
S524AD0XD1@SOP8  
  
S524AD0XF1@TSSOP8  
  
S524C20D11@SOP8  
  
S524C20D21@TSSOP8  
  
S524C80D41@SOP8  
  
S524C80D81@TSSOP8  
  
S524L50X51@SOP8



S524LB0X91  
S524LB0X91@SOP8 [ (SA602A) ]  
[ (SA026) ]  
S524LB0XB1  
[ (SA602A) ]  
S524LB0XB1@TSSOP8 [ (SA026) ]

S524LB0X91@TSSOP8  
  
S524LB0XB1@SOP8

**DRAM & SRAM**

KM61257  
[ (SA646) ]  
KM61257L  
[ (SA646) ]  
KM6165  
[ (SA646) ]  
KM6165L  
[ (SA646) ]  
KM62256A  
[ (SA630) ]  
KM62256AL  
[ (SA630) ]  
KM6264A  
[ (SA630) ]  
KM6264AL  
[ (SA630) ]  
KM64257  
[ (SA646) ]  
KM64257L  
[ (SA646) ]  
KM6465LP  
[ (SA646) ]  
KM6465P  
KM68257LP  
KM68257LP@SOIC28 [ (SA630) ]  
KM68257P  
KM68257P@SOIC28 [ (SA630) ]  
KM6865LP  
KM6865LP@SOIC28 [ (SA630) ]  
KM6865P  
KM6865P@SOIC28 [ (SA630) ]

KM61257@SOJ24  
  
KM61257L@SOJ24  
  
KM6165@SOJ24  
  
KM6165L@SOJ24  
  
KM62256A@SOIC28  
  
KM62256AL@SOIC28  
  
KM6264A@SOIC28  
  
KM6264AL@SOIC28  
  
KM64257@SOJ24  
  
KM64257L@SOJ24  
  
KM6465LP@SOJ22

**PLD**

CPL16L8 [ (SA001A) ]	CPL16L8@PLCC20
CPL16L8L [ (SA001A) ]	CPL16L8L@PLCC20
CPL16R4 [ (SA001A) ]	CPL16R4@PLCC20
CPL16R4L [ (SA001A) ]	CPL16R4L@PLCC20
CPL16R6 [ (SA001A) ]	CPL16R6@PLCC20
CPL16R6L [ (SA001A) ]	CPL16R6L@PLCC20
CPL16R8 [ (SA001A) ]	CPL16R8@PLCC20
CPL16R8L [ (SA001A) ]	CPL16R8L@PLCC20
CPL20L10 [ (SA008A) ]	CPL20L10@PLCC28
CPL20L10L [ (SA008A) ]	CPL20L10L@PLCC28

**MICROCONTROLLER**

S3F84I8@QFP44 [ (SA245A) ] [ (SA028) ]	S3F84I8@SDIP42
S3F84I9@QFP44 [ (SA245A) ] [ (SA028) ]	S3F84I9@SDIP42
S3F84P4 +B003) ]	S3F84P4@SOP8 [ (SA602A
S3F9444 +B003) ]	S3F9444@SOP8 [ (SA602A
S3F9454(dip16) (dip20)	S3F9454
S3F9454@SOP20 [ (SA404+B005) ] [ (SA245A) ]	S3F9488@QFP44
S3F9488@SDIP32 [ (SA653) ] [ (SA028) ]	S3F9488@SDIP42
S3F9488@SOP32 [ (SA630) ] [ (SA653) ]	S3F9498@SDIP30
S3F9498@SDIP32 [ (SA653) ]	S3F9498@SOP28

[ (SA630) ]	S3P414@QFP44
S3F9498@SOP32 [ (SA630) ]	
[ (SA675) ]	
S3P434@QFP44 [ (SA675) ]	S3P7048@QFP44
[ (SA675) ]	
S3P7048@SDIP42 [ (SA028) ]	S3P70F4@SDIP30
[ (SA653) ]	
S3P70F4@SOP32 [ (SA630) ]	S3P7235@PQFP80 [ (PEP
+S611A) ]	
S3P7238@PQFP80 [ (PEP+S611A) ]	S3P72F5@PQFP100 [ (PEP
+S427) ]	
S3P72K8@PQFP80 [ (PEP+S611A) ]	S3P72N5@PQFP80 [ (PEP
+S611A) ]	
S3P72N8@PQFP80 [ (PEP+S611A) ]	S3P72P9@PQFP100 [ (PEP
+S427) ]	
S3P72Q5@PQFP100 [ (PEP+S427) ]	S3P7324@PQFP64 [ (PEP
+S611A) ]	
S3P7335@PQFP80 [ (PEP+S611A) ]	S3P7414@SDIP42
[ (SA028) ]	
S3P7424@SDIP30 [ (SA653) ]	S3P7424@SOP28
[ (SA630) ]	
S3P7434@SDIP42 [ (SA028) ]	S3P7528@QFP44
[ (SA675) ]	
S3P7528@SDIP42 [ (SA028) ]	S3P7538@SDIP30
[ (SA653) ]	
S3P7538@SOP32 [ (SA630) ]	S3P7565@PQFP100 [ (PEP
+S427) ]	
S3P8469@PQFP64 [ (PEP+S611A) ]	S3P8469@SDIP64 [ (PEP
+S600A) ]	
S3P848A@PQFP64 [ (PEP+S611A) ]	S3P848A@SDIP64 [ (PEP
+S600A) ]	
S3P863A@SDIP42 [ (SA028) ]	S3P863A@TQFP44
[ (SA245A) ]	
S3P9004	S3P9004@TQFP44
[ (SA245A) ]	
S3P9014	S3P9014@TQFP44
[ (SA245A) ]	
S3P9428@SDIP30 [ (SA653) ]	S3P9428@SOP28
[ (SA630) ]	
S3P9428@SOP32 [ (SA630) ]	S3P9434
(dip16)	
S3P9434(dip18)	S3P9434
(dip20)	

S3P9434@SOP20 [ (SA404) ]

## SAMSUNG-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

K5D1G13ACD(Y-G8)@FBGA137 [ (SA700E-B153A-M137F001Y) ]  
K5D1G13ACD(Y-M8)@FBGA137 [ (SA700E-B153A-M137F001Y) ]  
K5D1G58ACA(YYD)@FBGA137 [ (SA700E-B153A-M137F001Y) ]  
K9F1208U0A(DD)@TSOP48 [ (SA247-B005) ]  
K9F1208U0A(MLTATL)@TSOP48 [ (SA247-B005) ]  
K9F1208U0B(DD)@TSOP48 [ (SA247-B005) ]  
K9F1208U0B(HC)@TSOP48 [ (SA247-B005) ]  
K9F1208U0B(LM)@TSOP48 [ (SA247-B005) ]  
K9F1208U0C(DD)@TSOP48 [ (SA247-B005) ]  
K9F1208U0M(DD)@TSOP48 [ (SA247-B005) ]  
K9F1208U0M(YCB0)@TSOP48 [ (SA247-B005) ]  
K9F1208U0M(YIB0)@TSOP48 [ (SA247-B005) ]  
K9F1G08Q0M(YCB0)@TSOP48 [ (SA247-B005) ]  
K9F1G08Q0M(YIB0)@TSOP48 [ (SA247-B005) ]  
K9F1G08U0A(DD)@TSOP48 [ (SA247-B005) ]  
K9F1G08U0A(MLTATL)@TSOP48 [ (SA247-B005) ]  
K9F1G08U0A(TZ)@TSOP48 [ (SA247-B005) ]  
K9F1G08U0B(TZ)@TSOP48 [ (SA247-B005) ]  
K9F1G08U0M(DD5)@TSOP48 [ (SA247+B005) ]  
K9F1G08U0M(YCB0)@TSOP48 [ (SA247-B005) ]  
K9F1G08U0M(YIB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16D0M(PCB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16D0M(PIB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16D0M(YCB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16D0M(YIB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16Q0M(PCB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16Q0M(PIB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16Q0M(YCB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16Q0M(YIB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16U0M(PCB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16U0M(PIB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16U0M(YCB0)@TSOP48 [ (SA247-B005) ]  
K9F1G16U0M(YIB0)@TSOP48 [ (SA247-B005) ]  
K9F2G08U0A(MLTATL)@TSOP48 [ (SA247-B005) ]  
K9F2G08U0A(YYD)@TSOP48 [ (SA247-B005) ]  
K9F2G08U0A(ZX)@TSOP48 [ (SA247-B005) ]

K9F2G08U0M(PCB0)(DD)@TSOP48 [(SA247-B005)]  
K9F2G08U0M(ShangHai)@TSOP48 [(SA247-B005)]  
K9F2G08U0M(YYD)@TSOP48 [(SA247-B005)]  
K9F4G08U0A(JB)@TSOP48 [(SA247+B005)]  
K9F4G08U0A(MLTATL)@TSOP48 [(SA247-B005)]  
K9F4G08U0A(WS)@TSOP48 [(SA247-B005)]  
K9F4G08U0M(DD5)@TSOP48 [(SA247+B005)]  
K9F4G08U0M(PCB0)(DD)@TSOP48 [(SA247-B005)]  
K9F4G08U0M(SH-EV)@TSOP48 [(SA247-B005)]  
K9F5608U0B(DD)@TSOP48 [(SA247-B005)]  
K9F5608U0B(QJ)@TSOP48 [(SA247-B005)]  
K9F5608U0C(DD)@TSOP48 [(SA247-B005)]  
K9F5608U0D(ASUS)@TSOP48 [(SA245-B005)]  
K9F5608U0D(DD)@TSOP48 [(SA247-B005)]  
K9F5608U0D(RS)@TSOP48 [(SA247-B005)]  
K9F6408U0B(SH51)@TSOP44 [(SA645-B005)]  
K9F6408U0C(SH51)@TSOP44 [(SA645-B005)]  
K9F8G08U0A(ZX)@TSOP48 [(SA247-B005)]  
K9G4G08U0A(OMB)@TSOP48 [(SA247-B005)]  
K9G8G08U0M(DD)@TSOP48 [(SA247-B005)]  
K9G8G08U0M(DD5)@TSOP48 [(SA247-B005)]  
K9G8G08U0M(KD)@TSOP48 [(SA247-B005)]  
K9GAG08U0M(DD)@TSOP48 [(SA247-B005)]  
K9GAG08U0M(DD5)@TSOP48 [(SA247-B005)]  
K9K1208D0C(XM)@FBGA63 [(SA664A-B114-W115F001)]  
K9K1G08U0A(MLTATL)@TSOP48 [(SA247-B005)]  
K9K1G08U0B-JIB0(Wistron)@FBGA63 [(SA642LL-B026A-M063F001Y)]  
K9K1G08U0M@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(PCB0)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(PIB0)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(YCB0)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(YIB0)@TSOP48 [(SA247-B005)]  
K9K2G08U0M(PCB0)@TSOP48 [(SA247-B005)]  
K9K2G08U0M(PIB0)@TSOP48 [(SA247-B005)]  
K9K2G08U0M(YCB0)@TSOP48 [(SA247-B005)]  
K9K2G08U0M(YIB0)@TSOP48 [(SA247-B005)]  
K9K4G08U0M(YYD)@TSOP48 [(SA247-B005)]  
K9K8G08U0A(AMOI)@TSOP48 [(SA247+B005)]  
K9K8G08U0A(DD)@TSOP48 [(SA247-B005)]  
K9K8G08U0A(DD5)@TSOP48 [(SA247+B005)]  
K9K8G08U0A(FX)@TSOP48 [(SA247+B005)]  
K9K8G08U0A(MLTATL)@TSOP48 [(SA247-B005)]  
K9K8G08U0A(SY)@TSOP48 [(SA247+B005)]

K9LAG08U0M(DD)@TSOP48 [(SA247-B005)]  
 K9LAG08U0M(KD)@TSOP48 [(SA247-B005)]  
 K9NBG08U5M(DD)@TSOP48 [(SA247-B005)]  
 K9W8G08U1M(DD)@TSOP48 [(SA247-B005)]  
 K9WAG08U1A(DD)@TSOP48 [(SA247-B005)]  
 K9WAG08U1A(JB)@TSOP48 [(SA247+B005)]  
 K9WAG08U1A(MLT)@TSOP48 [(SA247+B005)]  
 K9WAG08U1M(DD5)@TSOP48 [(SA247+B005)]  
 KAD070300C@TBGA69 [(SA642A-B039A-Y096F001)]  
 KBE00F003A-D411(AMOI)@FBGA107 [(SA642V-B133-T096F001Y)]  
 KM29W32000AT(SH51)@TSOP44 [(SA645-B005)]

## SANYO

### E (E) PROM/FRAM/NVRAM

LE24C041 [(SA654)]	LE24C041@MFP8
LE24C042 [(SA654)]	LE24C042@MFP8
LE24C081 [(SA654)]	LE24C081@MFP8
LE24C082 [(SA654)]	LE24C082@MFP8
LE24C161 [(SA654)]	LE24C161@MFP8
LE24C162 [(SA654)]	LE24C162@MFP8
LE24C322@MFP8 [(SA654)] [(SA698)]	LE24C322@WLP6
LE24L322@MFP8 [(SA654)] [(SA654)]	LE25FU106BMA@MFP8
LE25FU106BTT@MSOP8 [(SA654)] [(SA602A)]	LE25FU406BMA@MFP8
LE25FU406BTT@MSOP8 [(SA654)] [(SA654)]	LE25FV055T@MSOP8
LE25FV101T@MSOP8 [(SA654)] [(SA654)]	LE25FV105T@MSOP8
LE25FV201T@MSOP8 [(SA654)] [(SA654)]	LE25FV401T@MSOP8
LE25FV411T@MSOP8 [(SA654)] [(SA620)]	LE25FV451T@VSOP32

LE25FW056FN@VSON8 [(SA683)]	LE25FW056MA@MFP8
[(SA602A)]	
LE25FW106M@SOP8 [(SA602A)]	LE25FW106T@MSOP8
[(SA654)]	
LE25FW1606FN@VSON8 [(SA683)]	LE25FW203ATT@MSOP8
[(SA654)]	
LE25FW206M@SOP8 [(SA602A)]	LE25FW206T@MSOP8
[(SA654)]	
LE25FW406BMA@MFP8 [(SA602A)]	LE25FW406BTT@MSOP8
[(SA654)]	
LE25FW406M@SOP8 [(SA602A)]	LE25FW406T@MSOP8
[(SA654)]	
LE25FW806M@SOP8 [(SA602A)]	LE25FW806T@MSOP8
[(SA654)]	
LE26CW006@WLP6 [(SA698)]	LE28BW168T@TSOP48 [(SA247-
B005)]	
LE28C1001AM@SOP32 [(SA687)]	LE28C1001AT@TSOP32
[(SA410T)]	
LE28C1001ATS@VSOP32 [(SA620)]	LE28C1001DT@TSOP32
[(SA410T)]	
LE28C1001DTS@VSOP32 [(SA620)]	LE28CV1001AT@TSOP32
[(SA410T)]	
LE28CV1001ATS@VSOP32 [(SA620)]	LE28CV1001DT@TSOP32
[(SA410T)]	
LE28CV1001DTS@VSOP32 [(SA620)]	LE28CW1001DT@TSOP32
[(SA410T)]	
LE28CW1001DTS@VSOP32 [(SA620)]	
LE28DW1621T@FBGA63 [(SA642A-B026A-Y096F001)]	
LE28DW1621T@TSOP48 [(SA247-B005)]	
LE28DW3218AM@PSOP44 [(SA638-B005)]	
LE28DW8102T@TSOP48 [(SA637)]	
LE28DW8163T@TSOP48 [(SA247-B005)]	
LE28F1101T@TSOP40 [(SA623)]	LE28F1601T@TSOP40
[(SA409T)]	
LE28F2001ATS@TSOP32 [(SA410T)]	LE28F4001ATS@TSOP32
[(SA410T)]	
LE28F4001M@SSOP32 [(SA438T)]	LE28F8001T@TSOP40
[(SA409T)]	
LE28FU4101T@TSOP48 [(SA247-B005)]	
LE28FV1101T@TSOP40 [(SA623)]	LE28FV1601T@TSOP40
[(SA409T)]	
LE28FV2001ATS@TSOP32 [(SA410T)]	LE28FV4001ATS@TSOP32
[(SA410T)]	

LE28FV4001CTS@TSOP32 [(SA410T)]            LE28FV4001M@SSOP32  
[(SA438T)]  
LE28FV4001T@TSOP40 [(SA409T)]  
LE28FV4101T@TSOP48 [(SA247-B005)]  
LE28FV8001T@TSOP40 [(SA409T)]  
LE28FW1633FB@FBGA48 [(SA642G-B026A-T048F001Y)]  
LE28FW1633FT@FBGA48 [(SA642G-B026A-T048F001Y)]  
LE28FW1633TB@TSOP48 [(SA247-B005)]  
LE28FW1633TT@TSOP48 [(SA247-B005)]  
LE28FW4101T@TSOP48 [(SA247-B005)]  
LE28FW8201T@TSOP48 [(SA247-B005)]  
LE28FW8203TB@FBGA48 [(SA642B-B026A-Y072F001)]  
LE28FW8203TB@TSOP48 [(SA247-B005)]  
LE28FW8203TT@FBGA48 [(SA642B-B026A-Y072F001)]  
LE28FW8203TT@TSOP48 [(SA247-B005)]

## SCENIX

### MICROCONTROLLER

SX20AC/SS/G@SSOP20 [(SA626A)] [(SA626A)]	SX20AC/SS@SSOP20
SX28AC/DP G	SX28AC/DP/
SX28AC/SS/G@SSOP28 [(SA626A)] [(SA626A)]	SX28AC/SS@SSOP28
SX48BD/G@TQFP48 [(SA248)] [(SA248)]	SX48BD@TQFP48

## SEEQ

### E (E) PROM / FRAM / NVRAM

27128  
27256  
2764  
27C256  
2804  
2804A  
2816A



2816AH  
5213  
52B13  
52B13H  
52B23  
52B23H  
52B33  
52B33H  
5516A  
5516AH  
5517A  
5517AH  
DE2817A  
DE2817A@PLCC32 [(SA015A1T)]  
DE2817AH  
DE2817AH@PLCC32 [(SA015A1T)]  
DQ2817A  
DQ2817A@PLCC32 [(SA015A1T)]  
DQ2817AH  
DQ2817AH@PLCC32 [(SA015A1T)]  
DQ2864  
DQ2864@PLCC32 [(SA015A1T)]  
DQ2864H  
DQ2864H@PLCC32 [(SA015A1T)]  
DQ28C256  
DQ28C256@PLCC32 [(SA015A1T)]  
DQ28C64  
DQ28C64@PLCC32 [(SA015A1T)]  
DQ28C64A  
DQ28C64A@PLCC32 [(SA015A1T)]  
DQ28C65  
DQ28C65@PLCC32 [(SA015A1T)]  
DQ52B13  
DQ52B13H  
E28C64  
E28C64@PLCC32 [(SA015A1T)]  
E52B13  
E52B13H  
E52B23  
E52B23H  
E52B33  
E52B33H  
M28C64

M28C64@PLCC32 [ (SA015A1T) ]  
M52B13  
M52B13H  
M52B23  
M52B23H  
M52B33  
M52B33H  
PQ2864  
PQ2864@PLCC32 [ (SA015A1T) ]  
PQ2864H  
PQ2864H@PLCC32 [ (SA015A1T) ]  
PQ28C64  
PQ28C64@PLCC32 [ (SA015A1T) ]  
PQ28C65  
PQ28C65@PLCC32 [ (SA015A1T) ]

## PLD

PALCE26V12H/4 [ (SA008A) ]	PALCE26V12H/4@PLCC28
PALCE26V12H/4@SOIC28 [ (SA404) ] 15	PALCE26V12H-
PALCE26V12H-15@PLCC28 [ (SA008A) ] [ (SA404) ]	PALCE26V12H-15@SOIC28
PALCE26V12H-20 [ (SA008A) ]	PALCE26V12H-20@PLCC28
PALCE26V12H-20@SOIC28 [ (SA404) ] 25	PALCE26V12H-
PALCE26V12H-25@PLCC28 [ (SA008A) ] [ (SA404) ]	PALCE26V12H-25@SOIC28

## SEIKO

### E (E) PROM / FRAM / NVRAM

S-22H10 [ (SA404) ]	S-22H10@SOP18
S-22H12 [ (SA404) ]	S-22H12@SOP18
S-22S10 [ (SA404) ]	S-22S10@SOP18

S-22S12 [ (SA404) ]	S-22S12@SOP18
S-24C01A(DP) (DPA)	S-24C01A
S-24C01A(FJA)@SOIC8 [ (SA602A) ] (DP)	S-24C01B
S-24C01B(FJ)@SOIC8 [ (SA602A) ] (DP)	S-24C02A
S-24C02A(DPA) [ (SA602A) ]	S-24C02A(FJA)@SOIC8
S-24C02B(DP) [ (SA602A) ]	S-24C02B(FJ)@SOIC8
S-24C04A(DP) (DPA)	S-24C04A
S-24C04A(FJA)@SOIC8 [ (SA602A) ] (DP)	S-24C04B
S-24C04B(FJ)@SOIC8 [ (SA602A) ] (DPA)	S-24C08A
S-24C08A(FJA)@SOIC8 [ (SA602A) ] (DPA)	S-24C16A
S-24C16A(FJA)@SOIC8 [ (SA602A) ] (DP)	S-24CS01A
S-24CS01A(FJ)@SOIC8 [ (SA602A) ] [ (SA026) ]	S-24CS01A(FT)@TSSOP8
S-24CS02A(DP) [ (SA602A) ]	S-24CS02A(FJ)@SOIC8
S-24CS02A(FT)@TSSOP8 [ (SA026) ] (DP)	S-24CS04A
S-24CS04A(FJ)@SOIC8 [ (SA602A) ] [ (SA026) ]	S-24CS04A(FT)@TSSOP8
S-24CS08A(DP) [ (SA602A) ]	S-24CS08A(FJ)@SOIC8
S-24CS08A(FT)@TSSOP8 [ (SA026) ] (DP)	S-24CS16A
S-24CS16A(FJ)@SOIC8 [ (SA602A) ] [ (SA026) ]	S-24CS16A(FT)@TSSOP8
S-24CS64A(FJ)@SOIC8 [ (SA602A) ] [ (SA026) ]	S-24CS64A(FT)@TSSOP8
S-2817A@SOP28 [ (SA630) ] [ (SA602A) ]	S-29130A(DFJA)@SOIC8
S-29130A(DPA) [ (SA602A) ]	S-29130A(FJA)@SOIC8
S-29131A(DPA)	S-29131A(FJA)@SOIC8

[ ( SA602A ) ]	
S-29190A(DPA)	S-29190A(FJA)@SOIC8
[ ( SA602A ) ]	
S-29191A(DPA)	S-29191A(FJA)@SOIC8
[ ( SA602A ) ]	
S-29194A(DPA)	S-29194A(FJA)@SOIC8
[ ( SA602A ) ]	
S-29220A(DFJA)@SOIC8 [ ( SA602A ) ]	S-29220A
(DPA)	
S-29220A(FJA)@SOIC8 [ ( SA602A ) ]	S-29221A
(DPA)	
S-29221A(FJA)@SOIC8 [ ( SA602A ) ]	S-29230A(DFJA)@SOIC8
[ ( SA602A ) ]	
S-29230A(DPA)	S-29230A(FJA)@SOIC8
[ ( SA602A ) ]	
S-29231A(DPA)	S-29231A(FJA)@SOIC8
[ ( SA602A ) ]	
S-29290A(DPA)	S-29290A(FJA)@SOIC8
[ ( SA602A ) ]	
S-29291A(DPA)	S-29291A(FJA)@SOIC8
[ ( SA602A ) ]	
S-29294A(DPA)	S-29294A(FJA)@SOIC8
[ ( SA602A ) ]	
S-29330A(DFJA)@SOIC8 [ ( SA602A ) ]	S-29330A
(DPA)	
S-29330A(FJA)@SOIC8 [ ( SA602A ) ]	S-29331A
(DPA)	
S-29331A(FJA)@SOIC8 [ ( SA602A ) ]	S-29390A
(DPA)	
S-29390A(FJA)@SOIC8 [ ( SA602A ) ]	S-29391A
(DPA)	
S-29391A(FJA)@SOIC8 [ ( SA602A ) ]	S-29394A
(DPA)	
S-29394A(FJA)@SOIC8 [ ( SA602A ) ]	S-
29430A	
S-29430A@SOIC8 [ ( SA602A ) ]	S-
29530A	
S-29530A@SOIC8 [ ( SA602A ) ]	S-
29630A	
S-29630A@SOIC8 [ ( SA602A ) ]	S-29L130A(DFE)@SOIC8
[ ( SA602A ) ]	
S-29L130A(FE)@SOIC8 [ ( SA602A ) ]	S-29L130A(FS)@SSOP8
[ ( SA026 ) ]	

S-29L131A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29L131A(FS)@SSOP8
S-29L194A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29L194A(FS)@TSSOP8
S-29L220A(DFE)@SOIC8 [(SA602A)] [(SA602A)]	S-29L220A(FE)@SOIC8
S-29L220A(FS)@SSOP8 [(SA026)] [(SA602A)]	S-29L221A(DFE)@SOIC8
S-29L221A(FS)@SSOP8 [(SA026)] [(SA602A)]	S-29L294A(DFE)@SOIC8
S-29L294A(FS)@TSSOP8 [(SA026)] [(SA602A)]	S-29L330A(DFE)@SOIC8
S-29L330A(FE)@SOIC8 [(SA602A)] [(SA026)]	S-29L330A(FS)@SSOP8
S-29L331A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29L331A(FS)@SSOP8
S-29L394A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29L394A(FS)@TSSOP8
S-29U130A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29U130A(FS)@SSOP8
S-29U131A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29U131A(FS)@SSOP8
S-29U194A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29U194A(FS)@TSSOP8
S-29U220A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29U220A(FS)@SSOP8
S-29U221A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29U221A(FS)@SSOP8
S-29U294A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29U294A(FS)@TSSOP8
S-29U330A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29U330A(FS)@SSOP8
S-29U331A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29U331A(FS)@SSOP8
S-29U394A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29U394A(FS)@TSSOP8
S-29Z330A(DFJA)@SOIC8 [(SA602A)] [(SA026)]	S-29Z330A(FS)@SSOP8
S-29Z430A(DFJA)@SOIC8 [(SA602A)] [(SA026)]	S-29Z430A(FS)@SSOP8
S-93A46A(D0A)@SOIC8 [(SA602A)] [(SA602A)]	S-93A56A(D0A)@SOIC8
S-93A66A(D0A)@SOIC8 [(SA602A)]	S-93A66A(FJ)@SOIC8

[ (SA602A) ]	
S-93C46A(DFJ)@SOIC8 [ (SA602A) ]	S-93C46A
(DP)	
S-93C46A(FJ)@SOIC8 [ (SA602A) ]	S-93C46A(FT)@TSSOP8
[ (SA026) ]	
S-93C46B(DP)	S-93C46B(FJ)@SOIC8
[ (SA602A) ]	
S-93C46B(FT)@TSSOP8 [ (SA026) ]	S-93C56A(DFJ)@SOIC8
[ (SA602A) ]	
S-93C56A(DP)	S-93C56A(FJ)@SOIC8
[ (SA602A) ]	
S-93C56A(FT)@TSSOP8 [ (SA026) ]	S-93C56B
(DP)	
S-93C56B(FJ)@SOIC8 [ (SA602A) ]	S-93C56B(FT)@TSSOP8
[ (SA026) ]	
S-93C66A(DFJ)@SOIC8 [ (SA602A) ]	S-93C66A
(DP)	
S-93C66A(FJ)@SOIC8 [ (SA602A) ]	S-93C66A(FT)@TSSOP8
[ (SA026) ]	
S-93C66B(DP)	S-93C66B(FJ)@SOIC8
[ (SA602A) ]	
S-93C66B(FT)@TSSOP8 [ (SA026) ]	S-93C76A
(DP)	
S-93C76A(FJ)@SOIC8 [ (SA602A) ]	S-93C76A(FT)@TSSOP8
[ (SA026) ]	
S-93C86A(DP)	S-93C86A(FJ)@SOIC8
[ (SA602A) ]	
S-93C86A(FT)@TSSOP8 [ (SA026) ]	S-93C86B@SOIC8
[ (SA602A) ]	
S-93C86B@TSSOP8 [ (SA026) ]	S-93L46A(D0I)@SOIC8
[ (SA602A) ]	
S-93L56A(D0I)@SOIC8 [ (SA602A) ]	S-93L66A(D0I)@SOIC8
[ (SA602A) ]	
S-93L76A(D0I)@SOIC8 [ (SA602A) ]	

## SGS-THOMSON

### E (E) PROM / FRAM / NVRAM

ET2716  
ETC2716  
ETC2732

M24128  
M24128@SOIC8 [(SA602A)]  
M24164  
M24164@SOIC8 [(SA602A)]  
M24256  
M24256[3.9]@SOIC8 [(SA602A)] [(SA605A)] M24256[5.5]@SOIC8  
M24512 [(SA605A)] M24512@SOIC8  
M24512@TSOP8 [(SA026)]  
M24C04  
M24C04@SOIC8 [(SA602A)]  
M24C08  
M24C08@SOIC8 [(SA602A)]  
M24C08W  
M24C08W@SOIC8 [(SA602A)] [(SA026)] M24C08W@TSOP8  
M24C64(BN) [(SA026)] M24C64(DL)@TSSOP14  
M24C64(DW)@TSSOP8 [(SA602A)] [(SA605A)] M24C64(MN)@SOIC8  
M24C64(MW)@SOIC8 [(SA602A)]  
M27128A  
M2716  
M27256  
M27256A  
M2732A  
M27512  
M2764  
M2764A  
M27C1000  
M27C1000@PLCC32 [(SA015A1T)] [(SA410T)] M27C1000@TSOP32  
M27C1001 [(SA015A1T)] M27C1001@PLCC32  
M27C1001@TSOP32 [(SA410T)]  
M27C1024  
M27C1024@PLCC44 [(SA244)]  
M27C160  
M27C160@PLCC44 [(SA244)] [(SA638)] M27C160@PSOP44  
M27C2001 [(SA015A1T)] M27C2001@PLCC32

M27C2001@TSOP32 [(SA410T)]	
M27C202	
M27C202@PLCC44 [(SA244)]	M27C202@TSOP40
[(SA409T)]	
M27C256B	
[(SA015A1T)]	M27C256B@PLCC32
M27C400	
M27C4001	
M27C4001@PLCC32 [(SA015A1T)]	M27C4001@TSOP32
[(SA410T)]	
M27C4002	
[(SA244)]	M27C4002@PLCC44
M27C405	
[(SA015A1T)]	M27C405@PLCC32
M27C405@TSOP32 [(SA410T)]	
M27C512	
M27C512@PLCC32 [(SA015A1T)]	
M27C516	
M27C516@PLCC44 [(SA244)]	
M27C64A	
M27C64A@PLCC32 [(SA015A1T)]	
M27C800	
M27C800@PLCC44 [(SA244)]	M27C800@PSOP44
[(SA638)]	
M27C801	
[(SA015A1T)]	M27C801@PLCC32
M27C801@TSOP32 [(SA410T)]	
M27HC641	
M27HC641@PLCC28 [(SA008A)]	
M27HC642	
M27HC642@PLCC28 [(SA008A)]	
M27V101	
M27V101@PLCC32 [(SA015A1T)]	M27V101@TSOP32
[(SA410T)]	
M27V201	
[(SA015A1T)]	M27V201@PLCC32
M27V201@TSOP32 [(SA410T)]	
M27V401	
M27V401@PLCC32 [(SA015A1T)]	M27V401@TSOP32
[(SA410T)]	
M27V402	
[(SA244)]	M27V402@PLCC44
M27V402@TSOP40 [(SA409T)]	



M27V512	
M27V512@PLCC32 [(SA015A1T)]	M27V512@TSOP28
[(SA430T)]	
M27V800	M27V800@PLCC44
[(SA244)]	
M27V801	M27V801@PLCC32
[(SA015A1T)]	
M27V801@TSOP32 [(SA410T)]	
M27W201	
M27W201@PLCC32 [(SA015A1T)]	M27W201@TSOP32
[(SA410T)]	
M28010	M28010@PLCC32
[(SA015A1T)]	
M28010@TSOP32 [(SA410T)]	M28C16@PLCC32
[(SA015A1T)]	
M28C64C	M28C64C@PLCC32
[(SA015A1T)]	
M28C64C@SOIC28 [(SA404)]	M28C64C@TSOP28
[(SA430T)]	
M28F101	M28F101@PLCC32
[(SA015A1T)]	
M28F101@TSOP32 [(SA410T)]	
M28F102	
M28F102@PLCC44 [(SA244)]	M28F102@TSOP40
[(SA409T)]	
M28F201	M28F201@PLCC32
[(SA015A1T)]	
M28F201@TSOP32 [(SA410T)]	M28F211@TSOP40
[(SA409T)]	
M28F220@PSOP44 [(SA638)]	M28F220@TSOP48 [(SA247-
B005)]	
M28F256	M28F256@PLCC32
[(SA015A1T)]	
M28F256@TSOP32 [(SA410T)]	M28F411@TSOP40
[(SA409T)]	
M28F512	M28F512@PLCC32
[(SA015A1T)]	
M28F512@TSOP32 [(SA410T)]	
M29F002B	
M29F002B@PLCC32 [(SA015A1T)]	M29F002B@TSOP32
[(SA410T)]	
M29F002T	M29F002T@PLCC32
[(SA015A1T)]	

M29F002T@TSOP32 [(SA410T)]  
M29F040  
M29F040@PLCC32 [(SA015A1T)]  
[(SA410T)]  
M29F040B  
[(SA015A1T)]  
M29F040B@TSOP32 [(SA410T)]  
B006)]  
M29F100B@TSOP48 [(SA247-B005)]  
B006)]  
M29F100T@TSOP48 [(SA247-B005)]  
[(SA244)]  
M29F102B@TSOP40 [(SA623)]  
[(SA244)]  
M29F102BB@TSOP40 [(SA623)]  
B006)]  
M29F200B@TSOP48 [(SA247-B005)]  
B006)]  
M29F200T@TSOP48 [(SA247-B005)]  
B006)]  
M29F400B@TSOP48 [(SA247-B005)]  
B006)]  
M29F400T@TSOP48 [(SA247-B005)]  
[(SA015A1T)]  
M29V040@TSOP32 [(SA410T)]  
[(SA409T)]  
M29W008T@TSOP40 [(SA409T)]  
[(SA015A1T)]  
M29W040@TSOP32 [(SA410T)]  
[(SA638)]  
M29W400B@TSOP48 [(SA247-B005)]  
[(SA638)]  
M29W400T@TSOP48 [(SA247-B005)]  
[(SA015A1T)]  
M29W512B@TSOP32 [(SA620)]  
[(SA638)]  
M29W800B@TSOP48 [(SA247-B005)]  
[(SA638)]  
M29W800T@TSOP48 [(SA247-B005)]  
M48T35  
M48T35@SOIC28 [(SA404)]  
M48T35Y  
M48T35Y@SOIC28 [(SA404)]

M29F040@TSOP32  
M29F040B@PLCC32  
M29F100B@PSOP44 [(SA638-  
M29F100T@PSOP44 [(SA638-  
M29F102B@PLCC44  
M29F102BB@PLCC44  
M29F200B@PSOP44 [(SA638-  
M29F200T@PSOP44 [(SA638-  
M29F400B@PSOP44 [(SA638-  
M29F400T@PSOP44 [(SA638-  
M29V040@PLCC32  
M29W008B@TSOP40  
M29W040@PLCC32  
M29W400B@PSOP44  
M29W400T@PLCC44  
M29W512B@PLCC32  
M29W800B@PSOP44  
M29W800T@PSOP44

M48T59  
M48T59@SOIC28 [(SA404)]  
M48T59Y  
M48T59Y@SOIC28 [(SA404)]  
M48Z128  
M48Z128Y  
M48Z30  
M48Z30Y  
M48Z32  
M48Z32Y  
[(SA015A1T)]  
M50FW080@TSOP40 [(SA409T)]  
[(SA620)]  
M87C257  
[(SA015A1T)]  
M93C06(08bit)  
[(SA602A)]  
M93C06(16bit)  
[(SA602A)]  
M93S46  
[(SA602A)]  
M93S46@TSSOP8 [(SA026)]  
M95P02  
M95P02@SOIC8 [(SA602A)]  
M95P04  
M95P04@SOIC8 [(SA602A)]  
M95P08  
M95P08@SOIC8 [(SA602A)]  
MK48C02  
MK48C02B  
MK48C12  
MK48C12B  
MK48T02  
MK48T02B  
MK48T08  
MK48T12  
MK48T12B  
MK48T18  
MK48Z02  
MK48Z02B  
MK48Z08  
MK48Z12  
MK48Z12B

M50FW080@PLCC32

M50FW080@VSOP32

M87C257@PLCC32

M93C06(08bit)@SOIC8

M93C06(16bit)@SOIC8

M93S46@SOIC8

MK48Z18	
MKI48Z02	
MKI48Z02B	
MKI48Z12	
MKI48Z12B	
MKI48Z18	
ST24C01	ST24C01@SOIC8
[ (SA602A) ]	
ST24C02A	ST24C02A@SOIC8
[ (SA602A) ]	
ST24C16	ST24C16@SOIC8
[ (SA602A) ]	
ST24W01	ST24W01@SOIC8
[ (SA602A) ]	
ST24W02	ST24W02@SOIC8
[ (SA602A) ]	
ST24W04C	ST24W04C@SOIC8
[ (SA602A) ]	
ST27128A	
ST27256	
ST2764A	
ST27C256	
ST93C06(08bit)	ST93C06(08bit)@SOIC8
[ (SA602A) ]	
ST93C06(16bit)	ST93C06(16bit)@SOIC8
[ (SA602A) ]	
ST93CS46	ST93CS46@SOIC8
[ (SA602A) ]	
TS27C256	
TS27C64	
TS27C64@PLCC32 [ (SA015A1T) ]	
TS27C64A	
TS27C64A@PLCC32 [ (SA015A1T) ]	
TS28C16A	
TS28C17A	

## PLD

GAL16V8  
GAL16V8A  
GAL20V8  
GAL20V8A

**SHARP****E (E) PROM/FRAM/NVRAM**

LH28F002SCHN@PSOP44 [(SA638)]	LH28F002SCHT@TSOP40
[(SA409T)]	
LH28F002SCN@PSOP44 [(SA638)]	LH28F002SCT@TSOP40
[(SA409T)]	
LH28F004BVE(BT)@TSOP40 [(SA409T)]	
LH28F004BVE(TT)@TSOP40 [(SA409T)]	
LH28F004BVHS(BT)@VSOP40 [(SA623)]	
LH28F004BVHS(TT)@VSOP40 [(SA623)]	
LH28F004BVT(BT)@TSOP40 [(SA409T)]	
LH28F004BVT(TT)@TSOP40 [(SA409T)]	
LH28F004SCHN@PSOP44 [(SA638)]	LH28F004SCHS@VSOP40
[(SA623)]	
LH28F004SCHT@TSOP40 [(SA409T)]	LH28F004SCN@PSOP44
[(SA638)]	
LH28F004SCS@VSOP40 [(SA623)]	LH28F004SCT@TSOP40
[(SA409T)]	
LH28F008BJT(BTLZ1)@TSOP40 [(SA409T)]	
LH28F008BJT(TB)@TSOP40 [(SA409T)]	
LH28F008BJT(TT)@TSOP40 [(SA409T)]	
LH28F008BJT(TTLZ2)@TSOP40 [(SA409T)]	
LH28F008BVT(BT)@TSOP40 [(SA409T)]	
LH28F008BVT(TT)@TSOP40 [(SA409T)]	
LH28F008SAN@PSOP44 [(SA638)]	LH28F008SAR@RTSOP40
[(SA409T)]	
LH28F008SAT@TSOP40 [(SA409T)]	
LH28F008SCH(L85)@RTSOP40 [(SA409T)]	
LH28F008SCH-L@TSOP40 [(SA409T)]	LH28F008SCHN@PSOP44
[(SA638)]	
LH28F008SCH-V@TSOP40 [(SA409T)]	
LH28F008SCH-ZU-120@TSOP40 [(SA409T)]	
LH28F008SCN@PSOP44 [(SA638)]	LH28F008SCN-L@PSOP44
[(SA638)]	
LH28F008SCT@TSOP40 [(SA409T)]	LH28F008SCT-L@TSOP40
[(SA409T)]	
LH28F008SCT-V@TSOP40 [(SA409T)]	LH28F008SCV@TSOP40
[(SA409T)]	
LH28F016SA@TSOP56 [(SA628-B011)]	LH28F016SC@PSOP44

[ (SA638) ]  
LH28F016SCR(L95)@RTSOP40 [ (SA409T) ]  
LH28F016SCT-L95@TSOP40 [ (SA409T) ]  
LH28F016SUT@TSOP56 [ (SA628-B011) ]  
LH28F128BFHBD@CSP72 [ (SA642E-B052A-T072F001) ]  
LH28F128BFHE@TSOP48 [ (SA247-B005) ]  
LH28F128BFHT(PBTL70\_75A)@TSOP56 [ (SA628-B045) ]  
LH28F128BFHT(PTTL70\_75A)@TSOP56 [ (SA628-B045) ]  
LH28F128BFHT(PWTL80)@TSOP56 [ (SA628-B045) ]  
LH28F128BFND@PSOP44 [ (SA638) ]  
LH28F128SPHTD@TSOP56 [ (SA628-B018) ]  
LH28F160BGB(B)@CSP48 [ (SA642B-B029A-Y072F001) ]  
LH28F160BGB(T)@CSP48 [ (SA642B-B029A-Y072F001) ]  
LH28F160BGE(B)@TSOP48 [ (SA247-B005) ]  
LH28F160BGE(T)@TSOP48 [ (SA247-B005) ]  
LH28F160BJBB@FBGA48 [ (SA642B-B029A-Y072F001) ]  
LH28F160BJBT@FBGA48 [ (SA642B-B029A-Y072F001) ]  
LH28F160BJD  
LH28F160BJEB@TSOP48 [ (SA247-B005) ]  
LH28F160BJET@TSOP48 [ (SA247-B005) ]  
LH28F160BJHBB@FBGA48 [ (SA642B-B029A-Y072F001) ]  
LH28F160BJHBT@FBGA48 [ (SA642B-B029A-Y072F001) ]  
LH28F160BJHEB@TSOP48 [ (SA247-B005) ]  
LH28F160BJHET@TSOP48 [ (SA247-B005) ]  
LH28F160BVE(BTL)@TSOP48 [ (SA247-B005) ]  
LH28F160BVE(TTL)@TSOP48 [ (SA247-B005) ]  
LH28F160BVEB(B)@CSP48 [ (SA642B-B029A-Y072F001) ]  
LH28F160BVEB(T)@CSP48 [ (SA642B-B029A-Y072F001) ]  
LH28F160BVHE(BTL)@TSOP48 [ (SA247-B005) ]  
LH28F160BVHE(TTL)@TSOP48 [ (SA247-B005) ]  
LH28F160S3HNS@SSOP56 [ (SA629A-B013) ]  
LH28F160S3HT@TSOP56 [ (SA628-B011) ]  
LH28F160S3NS@SSOP56 [ (SA629A-B013) ]  
LH28F160S3T@TSOP56 [ (SA628-B011) ]  
LH28F160S5HNS@SSOP56 [ (SA629A-B013) ]  
LH28F160S5HT@TSOP56 [ (SA628-B011) ]  
LH28F160S5NS@SSOP56 [ (SA629A-B013) ]  
LH28F160S5T@TSOP56 [ (SA628-B011) ]  
LH28F160SKT@TSOP56 [ (SA628-B011) ]  
LH28F320BFE(PB)@TSOP48 [ (SA247-B005) ]  
LH28F320BFE(PT)@TSOP48 [ (SA247-B005) ]  
LH28F320BFHB(PB)@FBGA48 [ (SA642B-B029A-Y072F001) ]  
LH28F320BFHB(PT)@FBGA48 [ (SA642B-B029A-Y072F001) ]

LH28F320BFHE(PB)@TSOP48 [(SA247-B005)]  
LH28F320BFHE(PBTLZ2)@TSOP48 [(SA247-B005)]  
LH28F320BFHE(PT)@TSOP48 [(SA247-B005)]  
LH28F320BFHE(PTTLZ1)@TSOP48 [(SA247-B005)]  
LH28F320BFHG(PBTLZL)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BFHG(PBTLZN)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BFHG(PTTLZ3)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BFHG(PTTLZK)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BFHG(PTTLZM)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BJD  
LH28F320BJE(PB)(OTP)@TSOP48 [(SA247-B005)]  
LH28F320BJE(PB)@TSOP48 [(SA247-B005)]  
LH28F320BJE(PT)(OTP)@TSOP48 [(SA247-B005)]  
LH28F320BJE(PT)@TSOP48 [(SA247-B005)]  
LH28F320BJHE(PB)(OTP)@TSOP48 [(SA247-B005)]  
LH28F320BJHE(PT)(OTP)@TSOP48 [(SA247-B005)]  
LH28F320BJN@PSOP44 [(SA638)]  
LH28F320S3HNS@SSOP56 [(SA629A-B013)]  
LH28F320S3HT@TSOP56 [(SA628-B011)]  
LH28F320S3NS@SSOP56 [(SA629A-B013)]  
LH28F320S3T@TSOP56 [(SA628-B011)]  
LH28F320S3TD@TSOP56 [(SA628-B011)]  
LH28F320S5HNS@SSOP56 [(SA629A-B013)]  
LH28F320S5HT@TSOP56 [(SA628-B011)]  
LH28F320S5NS@SSOP56 [(SA629A-B013)]  
LH28F320S5T@TSOP56 [(SA628-B011)]  
LH28F320SKTD@TSOP56 [(SA628-B011)]  
LH28F400BGB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BGB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BGE(B)@TSOP48 [(SA247-B005)]  
LH28F400BGE(T)@TSOP48 [(SA247-B005)]  
LH28F400BGHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BGHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BGHE(B)@TSOP48 [(SA247-B005)]  
LH28F400BGHE(T)@TSOP48 [(SA247-B005)]  
LH28F400BGN(B)@PSOP44 [(SA638)]            LH28F400BGN(T)@PSOP44  
[(SA638)]  
LH28F400BVB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BVB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BVE(B)@TSOP48 [(SA247-B005)]  
LH28F400BVE(T)@TSOP48 [(SA247-B005)]  
LH28F400BVHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BVHB(T)@CSP48 [(SA642B-B029A-Y072F001)]

LH28F400BVHE(B)@TSOP48 [(SA247-B005)]  
LH28F400BVHE(T)@TSOP48 [(SA247-B005)]  
LH28F400BVN(B)@PSOP44 [(SA638)] LH28F400BVN(T)@PSOP44  
[(SA638)]  
LH28F640BFE(PB)@TSOP48 [(SA247-B005)]  
LH28F640BFE(PT)@TSOP48 [(SA247-B005)]  
LH28F640BFHB(PB)@FBGA60 [(SA642B-B029A-Y072F001)]  
LH28F640BFHB(PT)@FBGA60 [(SA642B-B029A-Y072F001)]  
LH28F640BFHE(PB)@TSOP48 [(SA247-B005)]  
LH28F640BFHE(PT)@TSOP48 [(SA247-B005)]  
LH28F640BFHE(PTTLHIA)@TSOP48 [(SA247-B005)]  
LH28F640BFHG@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F640BNHG@CSP56 [(SA644A-B025A-Y056F001)]  
LH28F640SPHT@TSOP56 [(SA628-B018)]  
LH28F800BGB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BGB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BGE(B)@TSOP48 [(SA247-B005)]  
LH28F800BGE(T)@TSOP48 [(SA247-B005)]  
LH28F800BGHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BGHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BGHE(B)@TSOP48 [(SA247-B005)]  
LH28F800BGHE(T)@TSOP48 [(SA247-B005)]  
LH28F800BGN(B)@PSOP44 [(SA638)] LH28F800BGN(T)@PSOP44  
[(SA638)]  
LH28F800BH-B@TSOP48 [(SA247-B005)]  
LH28F800BJE(PB)(OTP)@TSOP48 [(SA247-B005)]  
LH28F800BJE(PB)@TSOP48 [(SA247-B005)]  
LH28F800BJE(PT)(OTP)@TSOP48 [(SA247-B005)]  
LH28F800BJE(PT)@TSOP48 [(SA247-B005)]  
LH28F800BJHE(PB)(OTP)@TSOP48 [(SA247-B005)]  
LH28F800BJHE(PT)(OTP)@TSOP48 [(SA247-B005)]  
LH28F800BJHG(PB)(OTP)@CSP48 [(SA634A-B005A-Y048F001)]  
LH28F800BVB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BVB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BV-B@TSOP48 [(SA247-B005)]  
LH28F800BVE(B)@TSOP48 [(SA247-B005)]  
LH28F800BVE(T)@TSOP48 [(SA247-B005)]  
LH28F800BVE(TV85)@TSOP48 [(SA247-B005)]  
LH28F800BVHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BVHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BVHB@TSOP48 [(SA247-B005)]  
LH28F800BVHE(B)@TSOP48 [(SA247-B005)]  
LH28F800BVHE(T)@TSOP48 [(SA247-B005)]



LH28F800BVHT@TSOP48 [(SA247-B005)]  
LH28F800BVN(B)@PSOP44 [(SA638)] LH28F800BVN(T)@PSOP44  
[(SA638)]  
LH28F800BVN(TV85)@PSOP44 [(SA638)]  
LH28F800BV-T@TSOP48 [(SA247-B005)]  
LH28F800SG(L100)@TSOP48 [(SA247)]  
LH28F800SG(L120)@TSOP48 [(SA247)]  
LH28F800SG(L70)@TSOP48 [(SA247)] LH28F800SG(L80)@TSOP48  
[(SA247)]  
LH28F800SG(L85)@TSOP48 [(SA247)]  
LH28F800SGH(L100)@TSOP48 [(SA247)]  
LH28F800SGH(L120)@TSOP48 [(SA247)]  
LH28F800SGH(L70)@TSOP48 [(SA247)]  
LH28F800SGH(L80)@TSOP48 [(SA247)]  
LH28F800SGH(L85)@TSOP48 [(SA247)]  
LH28F800SUT@TSOP56 [(SA628-B011)]  
LHF00L03@PLCC32 [(SA015A1T)] LHF00L04@TSOP40  
[(SA409T)]  
LHF00L06@TSOP40 [(SA409T)] LHF00L07@PLCC32  
[(SA015A1T)]  
LHF00L08(LH28F320T)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
LHF00L09(LH28F320B)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
LHF00L10(LH28F320T)@FBGA48 [(SA634A-B005A-Y048F001Y)]  
LHF00L11(LH28F320B)@FBGA48 [(SA634A-B005A-Y048F001Y)]  
LHF00L12(LH28F320T)@TSOP48 [(SA247-B005)]  
LHF00L13(LH28F320B)@TSOP48 [(SA247-B005)]  
LHF00L14(LH28F320T)@TSOP48 [(SA247-B005)]  
LHF00L15(LH28F320B)@TSOP48 [(SA247-B005)]  
LHF00L24(LH28F160T)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
LHF00L25(LH28F160B)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
LHF00L28(LH28F160T)@TSOP48 [(SA247-B005)]  
LHF00L29(LH28F160B)@TSOP48 [(SA247-B005)]  
LHF00L30(LH28F160T)@TSOP48 [(SA247-B005)]  
LHF00L31(LH28F160B)@TSOP48 [(SA247-B005)]  
LRS1311@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1311A@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1315@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1316@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1317@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1320@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1320A@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1329@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1329A@FBGA72 [(SA642E-B069A-T072F001)]

LRs1330A@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1331@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1331B@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1331C@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1336@FBGA72 [ (SA642E-B069A-T072F001) ]  
LRs1339@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1341@FBGA72 [ (SA642E-B069A-T072F001) ]  
LRs1342@FBGA72 [ (SA642E-B069A-T072F001) ]  
LRs1348B@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1350@FBGA72 [ (SA642E-B069A-T072F001) ]  
LRs1356@FBGA72 [ (SA642E-B069A-T072F001) ]  
LRs1360@FBGA72 [ (SA642B-B023A-Y072F001) ]  
LRs1360C@FBGA72 [ (SA642B-B023A-Y072F001) ]  
LRs1370@FBGA72 [ (SA642B-B023A-Y072F001) ]  
LRs1370B@FBGA72 [ (SA642B-B023A-Y072F001) ]  
LRs1380@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1381@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1382@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1383@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1383C@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1383F@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1384@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1385@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1386@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1387@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1391@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1392A@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1393A@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1393C@FBGA72 [ (SA642E-B023A-T072F001N) ]  
LRs1395@FBGA72 [ (SA642E-B052A-T072F001) ]  
LRs1396@TSOP56 [ (SA628-B178) ]  
LRs13A0@FBGA72 [ (SA642E-B052A-T072F001) ]  
LRs13A1@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs13A2@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs13A3@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs13A4@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs13A5@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs13A6@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs13A8@TSOP56 [ (SA628-B216) ]  
LRs1805A@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1806A@FBGA72 [ (SA642E-B023A-T072F001) ]  
LRs1806F@FBGA72 [ (SA642B-B023A-Y072F001) ]  
LRs1807A@FBGA72 [ (SA642E-B023A-T072F001) ]

LRS1808A@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1811@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1812@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1816@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1816A@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1822@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1825@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1826@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1826A@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1827@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1828@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1829@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1832@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1844@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1845@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1850@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1851@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1852@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1853@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1871@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]  
LRS1872@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]  
LRS1875@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]  
LRS1876@FBGA72 [ ( SA642B-B023A-Y072F001Y ) ]  
LRS18B0@FBGA72 [ ( SA642E-B141A-T072F001Y ) ]  
LRS18BK@FBGA88 [ ( SA642A-B091A-Y096F001 ) ]  
LRS18BL@FBGA88 [ ( SA642A-B091A-Y096F001 ) ]  
LRS18BS@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]

## SHARP-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

LH28F640BFHE ( PT ) @ TSOP48 [ ( SA247-B005 ) ]

## SIEMENS

### E ( E ) PROM / FRAM / NVRAM

SDA2526  
[ ( SA602A ) ]

SDA2526@SOIC8

SDA2546	SDA2546@SOIC8
[ ( SA602A ) ]	
SDA25X26	SDA25X26@SOIC8
[ ( SA602A ) ]	
SDA25X46	SDA25X46@SOIC8
[ ( SA602A ) ]	
SDE2526	SDE2526@SOIC8
[ ( SA602A ) ]	
SDE2546	SDE2546@SOIC8
[ ( SA602A ) ]	
SDE25X26	SDE25X26@SOIC8
[ ( SA602A ) ]	
SDE25X46	SDE25X46@SOIC8
[ ( SA602A ) ]	
SLA24C01	SLA24C01@SOIC8
[ ( SA602A ) ]	
SLA24C02	SLA24C02@SOIC8
[ ( SA602A ) ]	
SLA24C04	SLA24C04@SOIC8
[ ( SA602A ) ]	
SLA24C08	SLA24C08@SOIC8
[ ( SA602A ) ]	
SLA24C16	SLA24C16@SOIC8
[ ( SA602A ) ]	
SLA24C164	SLA24C164@SOIC8
[ ( SA602A ) ]	
SLA24C32	SLA24C32@SOIC8
[ ( SA602A ) ]	
SLA24C64	SLA24C64@SOIC8
[ ( SA602A ) ]	
SLA25010	SLA25010@SOIC8
[ ( SA602A ) ]	
SLA25020	SLA25020@SOIC8
[ ( SA602A ) ]	
SLA25040	SLA25040@SOIC8
[ ( SA602A ) ]	
SLA25080	SLA25080@SOIC8
[ ( SA602A ) ]	
SLA25160	SLA25160@SOIC8
[ ( SA602A ) ]	
SLE24C01	SLE24C01@SOIC8
[ ( SA602A ) ]	
SLE24C02	SLE24C02@SOIC8

[ (SA602A) ]	
SLE24C04	SLE24C04@SOIC8
[ (SA602A) ]	
SLE24C08	SLE24C08@SOIC8
[ (SA602A) ]	
SLE24C16	SLE24C16@SOIC8
[ (SA602A) ]	
SLE24C164	SLE24C164@SOIC8
[ (SA602A) ]	
SLE24C32	SLE24C32@SOIC8
[ (SA602A) ]	
SLE24C64	SLE24C64@SOIC8
[ (SA602A) ]	
SLE25010	SLE25010@SOIC8
[ (SA602A) ]	
SLE25020	SLE25020@SOIC8
[ (SA602A) ]	
SLE25040	SLE25040@SOIC8
[ (SA602A) ]	
SLE25080	SLE25080@SOIC8
[ (SA602A) ]	
SLE25160	SLE25160@SOIC8
[ (SA602A) ]	

## MICROCONTROLLER

SAB-C504-2EM@TQFP44 [ (SA245A) ]	SAB-C505A-4EM@TQFP44
[ (SA245A) ]	
SAB-C505CA-4EM@TQFP44 [ (SA245A) ]	
SAB-C505L-4EM@PQFP80 [ (PEP+S611A) ]	
SAB-C508-4EM@TQFP64 [ (PEP+S625A) ]	
SAB-C508-4EP@SDIP64 [ (PEP+S600A) ]	
SAB-C515C-8EM@TQFP80 [ (PEP+S615B) ]	
SAB-C540U-1EN@PLCC44 [ (SA244) ]	
SAB-C540U-1EP@SDIP52 [ (PEP+S600A) ]	
SAB-C541U-1EN@PLCC44 [ (SA244) ]	
SAB-C541U-1EP@SDIP52 [ (PEP+S600A) ]	
SAF-C164CI-8EM@TQFP80 [ (PEP+S615B) ]	
SAF-C504-2EM@TQFP44 [ (SA245A) ]	SAF-C505A-4EM@TQFP44
[ (SA245A) ]	
SAF-C505CA-4EM@TQFP44 [ (SA245A) ]	
SAF-C505L-4EM@PQFP80 [ (PEP+S611A) ]	

SAF-C508-4EM@TQFP64 [(PEP+S616)]  
SAF-C508-4EP@SDIP64 [(PEP+S600A)]  
SAF-C513AO-2EM@TQFP44 [(SA245A)]      SAF-C513AO-2EN@PLCC44  
[(SA244)]  
SAF-C513AO-2EP  
SAF-C515C-8EM@TQFP80 [(PEP+S615B)]  
SAF-XC164CM-4F20F@TQFP64 [(PEP+S616)]  
SAF-XC164CM-4F40F@TQFP64 [(PEP+S616)]  
SAF-XC164CM-8F20F@TQFP64 [(PEP+S616)]  
SAF-XC164CM-8F40F@TQFP64 [(PEP+S616)]  
SAF-XC164CS-16F20F@TQFP100 [(PEP+S604)]  
SAF-XC164CS-16F40F@TQFP100 [(PEP+S604)]  
SAF-XC164CS-8F20F@TQFP100 [(PEP+S604)]  
SAF-XC164CS-8F40F@TQFP100 [(PEP+S604)]  
SAF-XC164D-16F20F@TQFP100 [(PEP+S604)]  
SAF-XC164D-16F40F@TQFP100 [(PEP+S604)]  
SAF-XC164D-8F20F@TQFP100 [(PEP+S604)]  
SAF-XC164D-8F40F@TQFP100 [(PEP+S604)]  
SAF-XC164N-16F20F@TQFP100 [(PEP+S604)]  
SAF-XC164N-16F40F@TQFP100 [(PEP+S604)]  
SAF-XC164N-8F20F@TQFP100 [(PEP+S604)]  
SAF-XC164N-8F40F@TQFP100 [(PEP+S604)]  
SAF-XC164S-16F20F@TQFP100 [(PEP+S604)]  
SAF-XC164S-16F40F@TQFP100 [(PEP+S604)]  
SAF-XC164S-8F20F@TQFP100 [(PEP+S604)]  
SAF-XC164S-8F40F@TQFP100 [(PEP+S604)]  
SAH-C504-2EM@TQFP44 [(SA245A)]      SAH-C505A-4EM@TQFP44  
[(SA245A)]  
SAH-C505CA-4EM@TQFP44 [(SA245A)]  
SAK-C164CI-8EM@TQFP80 [(PEP+S615B)]  
SAK-C504-2EM@TQFP44 [(SA245A)]      SAK-C505A-4EM@TQFP44  
[(SA245A)]  
SAK-C505CA-4EM@TQFP44 [(SA245A)]  
SAK-C505L-4EM@PQFP80 [(PEP+S611A)]  
SAK-C515C-8EM@TQFP80 [(PEP+S615B)]  
SAK-XC164CM-4F20F@TQFP64 [(PEP+S616)]  
SAK-XC164CM-4F40F@TQFP64 [(PEP+S616)]  
SAK-XC164CM-8F20F@TQFP64 [(PEP+S616)]  
SAK-XC164CM-8F40F@TQFP64 [(PEP+S616)]  
SAK-XC164CS-16F20F@TQFP100 [(PEP+S604)]  
SAK-XC164CS-16F40F@TQFP100 [(PEP+S604)]  
SAK-XC164CS-8F20F@TQFP100 [(PEP+S604)]  
SAK-XC164CS-8F40F@TQFP100 [(PEP+S604)]

# SIGNETICS

## E ( E ) PROM / FRAM / NVRAM

27C010 [ ( SA015A1T ) ] 27C010@TSOP32 [ ( SA410T ) ] 27C040 27C040@PLCC32 [ ( SA015A1T ) ] [ ( SA410T ) ] 27C210 [ ( SA244 ) ] 27C240 [ ( SA244 ) ] 27C256 [ ( SA015A1T ) ] 27C512 [ ( SA015A1T ) ] 27C64A [ ( SA015A1T ) ] 27HC641 [ ( SA008A ) ] 27HC642 [ ( SA008A ) ] PCA8582A [ ( SA602A ) ] PCA8582B [ ( SA602A ) ] PCA8582C [ ( SA602A ) ] PCA8582D [ ( SA602A ) ] PCA8582E [ ( SA602A ) ] PCD8582A [ ( SA602A ) ] PCD8582B [ ( SA602A ) ] PCD8582C [ ( SA602A ) ] PCD8582D	27C010@PLCC32   27C040@TSOP32  27C210@PLCC44  27C240@PLCC44  27C256@PLCC32  27C512@PLCC32  27C64A@PLCC32  27HC641@PLCC28  27HC642@PLCC28  PCA8582A@SOIC8  PCA8582B@SOIC8  PCA8582C@SOIC8  PCA8582D@SOIC8  PCA8582E@SOIC8  PCD8582A@SOIC8  PCD8582B@SOIC8  PCD8582C@SOIC8  PCD8582D@SOIC8
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

[ (SA602A) ]	
PCD8582E	PCD8582E@SOIC8
[ (SA602A) ]	
PCF8582A	PCF8582A@SOIC8
[ (SA602A) ]	
PCF8582B	PCF8582B@SOIC8
[ (SA602A) ]	
PCF8582C	PCF8582C@SOIC8
[ (SA602A) ]	
PCF8582D	PCF8582D@SOIC8
[ (SA602A) ]	
PCF8582E	PCF8582E@SOIC8
[ (SA602A) ]	
PCF8594	PCF8594@SOIC8
[ (SA626A) ]	
PCF8594C	PCF8594C@SOIC8
[ (SA626A) ]	
PCF8594D	PCF8594D@SOIC8
[ (SA626A) ]	
PCF8594E	PCF8594E@SOIC8
[ (SA626A) ]	
PCF8598	PCF8598@SOIC8
[ (SA626A) ]	
PCF8598C	PCF8598C@SOIC8
[ (SA626A) ]	
PCF8598D	PCF8598D@SOIC8
[ (SA626A) ]	
PCF8598E	PCF8598E@SOIC8
[ (SA626A) ]	

## BPROM

82LS135	82LS135@PLCC20
[ (SA001A) ]	
82S123	
82S123A	
82S126	
82S126A	
82S129	
82S129A	
82S135	82S135@PLCC20
[ (SA001A) ]	



82S136  
82S137  
82S137A  
82S137B  
82S137C  
82S140  
82S141  
82S146  
82S146@PLCC20 [(SA001A)]  
82S147  
82S147@PLCC20 [(SA001A)]  
82S147A  
82S147A@PLCC20 [(SA001A)]  
82S147B  
82S147B@PLCC20 [(SA001A)]  
82S167  
82S184  
82S184A  
82S185  
82S185A  
82S185B  
82S185C  
82S191  
82S191A  
82S191B  
82S191C  
82S23  
82S23A

**PLD**

82S100	
82S101	
82S105	82S105A@PLCC28
[(SA008A)]	
82S152	82S152@PLCC20
[(SA001A)]	
82S153	82S153@PLCC20
[(SA001A)]	
82S155	82S155@PLCC20
[(SA001A)]	
82S157	82S157@PLCC20

[ (SA001A) ]	
82S159	82S159@PLCC20
[ (SA001A) ]	
82S167	82S167@PLCC28
[ (SA008A) ]	
82S168	82S168@PLCC28
[ (SA008A) ]	
82S173	82S173@PLCC28
[ (SA008A) ]	
82S179	82S179@PLCC28
[ (SA008A) ]	
PLS100	PLS100@PLCC28
[ (SA008A) ]	
PLS101	PLS101@PLCC28
[ (SA008A) ]	
PLS104	PLS104@PLCC28
[ (SA008A) ]	
PLS104A	PLS104A@PLCC28
[ (SA008A) ]	
PLS105	PLS105@PLCC28
[ (SA008A) ]	
PLS105A	PLS105A@PLCC28
[ (SA008A) ]	
PLS152	PLS152@PLCC20
[ (SA001A) ]	
PLS153	PLS153@PLCC20
[ (SA001A) ]	
PLS153A	PLS153A@PLCC20
[ (SA001A) ]	
PLS155	PLS155@PLCC20
[ (SA001A) ]	
PLS157	PLS157@PLCC20
[ (SA001A) ]	
PLS159	PLS159@PLCC20
[ (SA001A) ]	
PLS159A	PLS159A@PLCC20
[ (SA001A) ]	
PLS167	PLS167@PLCC28
[ (SA008A) ]	
PLS167A	PLS167A@PLCC28
[ (SA008A) ]	
PLS168	PLS168@PLCC28
[ (SA008A) ]	

PLS168A  
[ (SA008A) ]  
PLS173  
[ (SA008A) ]  
PLS179  
[ (SA008A) ]  
PLUS105  
[ (SA008A) ]

PLS168A@PLCC28  
  
PLS173@PLCC28  
  
PLS179@PLCC28  
  
PLUS105@PLCC28

## MICROCONTROLLER

PSD301@PLCC44 [ (SA244) ]  
[ (SA244) ]  
PSD302@PLCC44 [ (SA244) ]  
[ (SA244) ]  
PSD303@PLCC44 [ (SA244) ]  
[ (SA244) ]  
PSD311@PLCC44 [ (SA244) ]  
[ (SA244) ]  
PSD312@PLCC44 [ (SA244) ]  
[ (SA244) ]  
PSD313@PLCC44 [ (SA244) ]  
[ (SA245A) ]  
PSD313-B@PLCC44 [ (SA244) ]  
[ (SA245A) ]  
PSD313L@PLCC44 [ (SA244) ]  
[ (SA245A) ]  
S87C054@SDIP42 [ (SA028) ]  
[ (SA028) ]  
S87C451@PLCC68 [ (PEP+S414T) ]  
+S600A) ]  
S87C453@PLCC68 [ (PEP+S414T) ]  
S87C51  
S87C51@PLCC44 [ (SA244) ]  
[ (SA245A) ]  
S87C51FA  
[ (SA244) ]  
S87C51FA@TQFP44 [ (SA245A) ]  
S87C51FB  
S87C51FB@PLCC44 [ (SA244) ]  
[ (SA245A) ]  
S87C51FC

PSD301L@PLCC44  
  
PSD302L@PLCC44  
  
PSD303L@PLCC44  
  
PSD311L@PLCC44  
  
PSD312L@PLCC44  
  
PSD313@TQFP44  
  
PSD313-B@TQFP44  
  
PSD313L@TQFP44  
  
S87C055@SDIP42  
  
S87C451@SDIP64 [ (PEP  
  
S87C51@TQFP44  
  
S87C51FA@PLCC44  
  
S87C51FB@TQFP44  
  
S87C51FC@PLCC44

[ (SA244) ]  
S87C51FC@TQFP44 [ (SA245A) ]  
S87C52  
S87C52@PLCC44 [ (SA244) ] S87C52@TQFP44  
[ (SA245A) ]  
S87C524 S87C524@PLCC44  
[ (SA244) ]  
S87C524@TQFP44 [ (SA245A) ]  
S87C528  
S87C528@PLCC44 [ (SA244) ] S87C528@TQFP44  
[ (SA245A) ]  
S87C54 S87C54@PLCC44  
[ (SA244) ]  
S87C54@TQFP44 [ (SA245A) ]  
S87C550  
S87C550@PLCC44 [ (SA244) ] S87C552@PLCC68 [ (PEP  
+S414T) ]  
S87C552@PLCC68 ( \* ) [ (SA648-B6806) ]  
S87C554@PLCC68 [ (PEP+S414T) ]  
S87C554@PLCC68 ( \* ) [ (SA648-B6806) ]  
S87C575 S87C575@PLCC44  
[ (SA244) ]  
S87C575@TQFP44 [ (SA245A) ]  
S87C576  
S87C576@PLCC44 [ (SA244) ] S87C576@TQFP44  
[ (SA245A) ]  
S87C58 S87C58@PLCC44  
[ (SA244) ]  
S87C58@TQFP44 [ (SA245A) ] S87C591@PLCC44  
[ (SA244) ]  
S87C591@TQFP44 [ (SA245A) ] S87C592@PLCC68 [ (PEP  
+S414T) ]  
S87C652 S87C652@PLCC44  
[ (SA244) ]  
S87C652@TQFP44 [ (SA245A) ]  
S87C654  
S87C654@PLCC44 [ (SA244) ] S87C654@TQFP44  
[ (SA245A) ]  
S87C748 S87C748@PLCC28  
[ (SA008A) ]  
S87C749 S87C749@PLCC28  
[ (SA008A) ]  
S87C750 S87C750@PLCC28

[ (SA008A) ]	
S87C750@SSOP24 [ (SA626A) ]	
S87C751	
S87C751@PLCC28 [ (SA008A) ]	S87C751@SSOP24
[ (SA626A) ]	
S87C752	S87C752@PLCC28
[ (SA008A) ]	
S87C752@SSOP28 [ (SA626A) ]	
S87C754	
S87C754@PLCC28 [ (SA008A) ]	S87C754@SSOP28
[ (SA626A) ]	
S87L51FA	S87L51FA@PLCC44
[ (SA244) ]	
S87L51FA@TQFP44 [ (SA245A) ]	
S87L51FB	
S87L51FB@PLCC44 [ (SA244) ]	S87L51FB@TQFP44
[ (SA245A) ]	

## Silicon Laboratories

### MICROCONTROLLER

C8051F000@TQFP64 [ (PEP+S616) ]	C8051F001@TQFP48
[ (SA248) ]	
C8051F002@TQFP32 [ (SA663) ]	C8051F005@TQFP64 [ (PEP
+S616) ]	
C8051F006@TQFP48 [ (SA248) ]	C8051F007@TQFP32
[ (SA663) ]	
C8051F010@TQFP64 [ (PEP+S616) ]	C8051F011@TQFP48
[ (SA248) ]	
C8051F012@TQFP32 [ (SA663) ]	C8051F015@TQFP64 [ (PEP
+S616) ]	
C8051F016@TQFP48 [ (SA248) ]	C8051F017@TQFP32
[ (SA663) ]	
C8051F018@TQFP64 [ (PEP+S616) ]	C8051F019@TQFP48
[ (SA248) ]	
C8051F020@TQFP100 [ (PEP+S604) ]	
C8051F020@TQFP100 (ISP) [ ISP-HEADER01 ]	
C8051F021@TQFP64 [ (PEP+S616) ]	
C8051F021@TQFP64 (*) [ (TA050-B005) ]	
C8051F021@TQFP64 (ISP) [ ISP-HEADER01 ]	
C8051F022@TQFP100 [ (PEP+S604) ]	

C8051F022@TQFP100 (ISP) [ISP-HEADER01]  
C8051F023@TQFP64 [(PEP+S616)]  
C8051F023@TQFP64(\*) [(TA050-B005)]  
C8051F023@TQFP64 (ISP) [ISP-HEADER01]  
C8051F040@TQFP100 [(PEP+S604)]  
C8051F040@TQFP100 (ISP) [ISP-HEADER01]  
C8051F041@TQFP64 [(PEP+S616)]  
C8051F041@TQFP64(\*) [(TA050-B005)]  
C8051F041@TQFP64 (ISP) [ISP-HEADER01]  
C8051F042@TQFP100 [(PEP+S604)]  
C8051F042@TQFP100 (ISP) [ISP-HEADER01]  
C8051F043@TQFP64 [(PEP+S616)]  
C8051F043@TQFP64(\*) [(TA050-B005)]  
C8051F043@TQFP64 (ISP) [ISP-HEADER01]  
C8051F044@TQFP100 [(PEP+S604)]  
C8051F044@TQFP100 (ISP) [ISP-HEADER01]  
C8051F045@TQFP64 [(PEP+S616)]  
C8051F045@TQFP64(\*) [(TA050-B005)]  
C8051F045@TQFP64 (ISP) [ISP-HEADER01]  
C8051F046@TQFP100 [(PEP+S604)]  
C8051F046@TQFP100 (ISP) [ISP-HEADER01]  
C8051F047@TQFP64 [(PEP+S616)]  
C8051F047@TQFP64(\*) [(TA050-B005)]  
C8051F047@TQFP64 (ISP) [ISP-HEADER01]  
C8051F060@TQFP100 [(PEP+S604)] C8051F061@TQFP64 [(PEP+S616)]  
C8051F062@TQFP100 [(PEP+S604)] C8051F063@TQFP64 [(PEP+S616)]  
C8051F064@TQFP100 [(PEP+S604)] C8051F065@TQFP64 [(PEP+S616)]  
C8051F066@TQFP100 [(PEP+S604)] C8051F067@TQFP64 [(PEP+S616)]  
C8051F120@TQFP100 [(PEP+S604)]  
C8051F120-GQ@TQFP100 [(PEP+S604)]  
C8051F121@TQFP64 [(PEP+S616)] C8051F121-GQ@TQFP64 [(PEP+S616)]  
C8051F122@TQFP100 [(PEP+S604)]  
C8051F122-GQ@TQFP100 [(PEP+S604)]  
C8051F123@TQFP64 [(PEP+S616)] C8051F123-GQ@TQFP64 [(PEP+S616)]  
C8051F124@TQFP100 [(PEP+S604)]  
C8051F124-GQ@TQFP100 [(PEP+S604)]  
C8051F125@TQFP64 [(PEP+S616)] C8051F125-GQ@TQFP64 [(PEP+S616)]

+S616) ]	
C8051F126@TQFP100 [(PEP+S604) ]	
C8051F126-GQ@TQFP100 [(PEP+S604) ]	
C8051F127@TQFP64 [(PEP+S616) ]	C8051F127-GQ@TQFP64 [(PEP
+S616) ]	
C8051F130@TQFP100 [(PEP+S604) ]	
C8051F130-GQ@TQFP100 [(PEP+S604) ]	
C8051F131@TQFP64 [(PEP+S616) ]	C8051F131-GQ@TQFP64 [(PEP
+S616) ]	
C8051F132@TQFP100 [(PEP+S604) ]	
C8051F132-GQ@TQFP100 [(PEP+S604) ]	
C8051F133@TQFP64 [(PEP+S616) ]	C8051F133-GQ@TQFP64 [(PEP
+S616) ]	
C8051F206@TQFP48 [(SA248) ]	C8051F220@TQFP48
[(SA248) ]	
C8051F221@TQFP32 [(SA663) ]	C8051F226@TQFP48
[(SA248) ]	
C8051F230@TQFP48 [(SA248) ]	C8051F231@TQFP32
[(SA663) ]	
C8051F236@TQFP48 [(SA248) ]	C8051F300
[(SA695A) ]	
C8051F301 [(SA695A) ]	C8051F302
[(SA695A) ]	
C8051F303 [(SA695A) ]	C8051F304
[(SA695A) ]	
C8051F305 [(SA695A) ]	C8051F310@TQFP32
[(SA663) ]	
C8051F310-GQ@TQFP32 [(SA663) ]	C8051F311@QFN28 [(SA697-
B006) ]	
C8051F311-GM@QFN28 [(SA697-B006) ]	
C8051F312@TQFP32 [(SA663) ]	C8051F312-GQ@TQFP32
[(SA663) ]	
C8051F313@QFN28 [(SA697-B006) ]	
C8051F313-GM@QFN28 [(SA697-B006) ]	
C8051F314@TQFP32 [(SA663) ]	C8051F314-GQ@TQFP32
[(SA663) ]	
C8051F315@QFN28 [(SA697-B006) ]	
C8051F315-GM@QFN28 [(SA697-B006) ]	
C8051F316-GM@QFN24 [(SA710-B006) ]	
C8051F317-GM@QFN24 [(SA710-B006) ]	
C8051F320@TQFP32 [(SA663) ]	C8051F321@QFN28 [(SA697-
B006) ]	
C8051F326@QFN28 [(SA697-B006) ]	

C8051F326-GQ@QFN28 [(SA697-B006)]  
C8051F327@QFN28 [(SA697-B006)]  
C8051F327-GQ@QFN28 [(SA697-B006)]  
C8051F330@MLP20 [(SA692)]  
C8051F330D  
C8051F331@MLP20 [(SA692)] C8051F332-GM@MLP20  
[(SA692)]  
C8051F333-GM@MLP20 [(SA692)] C8051F334-GM@MLP20  
[(SA692)]  
C8051F335-GM@MLP20 [(SA692)] C8051F336-GM@QFN20  
[(SA692)]  
C8051F337-GM@QFN20 [(SA692)] C8051F338-GM@QFN24  
[(SA710)]  
C8051F339-GM@QFN24 [(SA710)] C8051F340-GQ@TQFP48  
[(SA248)]  
C8051F341-GQ@TQFP48 [(SA248)] C8051F342-GQ@LQFP32  
[(SA663)]  
C8051F343-GQ@LQFP32 [(SA663)] C8051F344-GQ@TQFP48  
[(SA248)]  
C8051F345-GQ@TQFP48 [(SA248)] C8051F346-GQ@LQFP32  
[(SA663)]  
C8051F347-GQ@LQFP32 [(SA663)] C8051F350-GQ@LQFP32  
[(SA663)]  
C8051F351-GM@QFN28 [(SA697-B006)]  
C8051F352-GQ@LQFP32 [(SA663)]  
C8051F353-GM@QFN28 [(SA697-B006)]  
C8051F360@QFP48 [(SA248)] C8051F361@QFP32  
[(SA663)]  
C8051F362@QFN28 [(SA697)] C8051F363@QFP48  
[(SA248)]  
C8051F364@QFP32 [(SA663)] C8051F365@QFN28  
[(SA697)]  
C8051F366@QFP32 [(SA663)] C8051F367@QFN28  
[(SA697)]  
C8051F368@QFP32 [(SA663)] C8051F369@QFN28  
[(SA697)]  
C8051F410-GQ@LQFP32 [ordering number is marked above]  
C8051F411-GM@QFN28 [ordering number is marked above]  
C8051F412-GQ@LQFP32 [ordering number is marked above]  
C8051F413-GM@QFN28 [ordering number is marked above]  
C8051F520-IM@QFN10 [(SA695A)] C8051F521-IM@QFN10  
[(SA695A)]  
C8051F523-IM@QFN10 [(SA695A)] C8051F524-IM@QFN10



[ (SA695A) ]	
C8051F526-IM@QFN10 [ (SA695A) ]	C8051F527-IM@QFN10
[ (SA695A) ]	
C8051F530-IM@QFN20 [ (SA692) ]	C8051F530-IT@TSSOP20
[ (SA026) ]	
C8051F531-IM@QFN20 [ (SA692) ]	C8051F531-IT@TSSOP20
[ (SA026) ]	
C8051F533-IM@QFN20 [ (SA692) ]	C8051F533-IT@TSSOP20
[ (SA026) ]	
C8051F534-IM@QFN20 [ (SA692) ]	C8051F534-IT@TSSOP20
[ (SA026) ]	
C8051F536-IM@QFN20 [ (SA692) ]	C8051F536-IT@TSSOP20
[ (SA026) ]	
C8051F537-IM@QFN20 [ (SA692) ]	C8051F537-IT@TSSOP20
[ (SA026) ]	
C8051T600@QFN11 [ (SA695A) ]	C8051T600@SOIC14
[ (SA602) ]	
C8051T601@QFN11 [ (SA695A) ]	C8051T601@SOIC14
[ (SA602) ]	
C8051T602@SOIC14 [ (SA602) ]	C8051T603@SOIC14
[ (SA602) ]	
C8051T604@QFN11 [ (SA695A) ]	C8051T604@SOIC14
[ (SA602) ]	
C8051T605@QFN11 [ (SA695A) ]	C8051T605@SOIC14
[ (SA602) ]	
SI8250@LQFP32 [ (SA663) ]	SI8250@QFN28
[ (SA697) ]	
SI8251@LQFP32 [ (SA663) ]	SI8251@QFN28
[ (SA697) ]	
SI8252@LQFP32 [ (SA663) ]	SI8252@QFN28
[ (SA697) ]	

## SILICON7

### E (E) PROM/FRAM/NVRAM

SV4E1602UBA@FBGA56 [ (SA642P-B079A-W056F001Y) ]
SV4E1602UTA@FBGA56 [ (SA642P-B079A-W056F001Y) ]
SV4E1604UBA@FBGA56 [ (SA642P-B079A-W056F001Y) ]
SV4E1604UTA@FBGA56 [ (SA642P-B079A-W056F001Y) ]
SV4E1608UBA@FBGA56 [ (SA642P-B079A-W056F001Y) ]
SV4E1608UTA@FBGA56 [ (SA642P-B079A-W056F001Y) ]

SV4E3204UBA@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
SV4E3204UTA@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
SV4E3208UBA@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
SV4E3208UTA@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
SV4E3216UBA@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
SV4E3216UTA@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
SV4F1602UBA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F1602UTA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F1604UBA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F1604UTA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F1608UBA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F1608UTA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3204UBA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3204UTA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3208UBA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3208UTA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3216UBA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3216UTA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV5C2832UCR@FBGA72 [ (SA642E-B052A-T072F001) ]  
SV5C3238UBA(NO EFP)@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV5C3238UBA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV5C3238UTA(NO EFP)@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV5C3238UTA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV5C6416UBB(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UBB@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UBR(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UBR@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UTB(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UTB@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UTR(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UTR@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6432UBR(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6432UTR(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5D2832UCA@FBGA88 [ (SA642A-B081A-Y096F001) ]  
SV6C2832UBA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6C2832UTA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6C6416UBA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6C6416UTA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6C6432UBA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6C6432UTA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6D2832UBA@FBGA88 [ (SA642A-B124A-Y096F001Y) ]  
SV6D2832UTA@FBGA88 [ (SA642A-B124A-Y096F001Y) ]  
SV7C1602UBA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]

SV7C1602UTA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
 SV7C1604UBA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
 SV7C1604UTA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
 SV7C1608UBA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
 SV7C1608UTA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
 SV7C3204UBA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
 SV7C3204UTA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
 SV7C3208UBA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
 SV7C3208UTA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
 SV7C3216UBA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
 SV7C3216UTA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
 SV7E1602UBA@FBGA56 [ (SA642A-B032A-Y096F001Y) ]  
 SV7E1602UTA@FBGA56 [ (SA642A-B032A-Y096F001Y) ]  
 SV7E1604UBA@FBGA56 [ (SA642A-B032A-Y096F001Y) ]  
 SV7E1604UTA@FBGA56 [ (SA642A-B032A-Y096F001Y) ]  
 SV7E1608UBA@FBGA56 [ (SA642A-B032A-Y096F001Y) ]  
 SV7E1608UTA@FBGA56 [ (SA642A-B032A-Y096F001Y) ]  
 SV7E3204UBA@FBGA56 [ (SA642A-B032A-Y096F001Y) ]  
 SV7E3204UTA@FBGA56 [ (SA642A-B032A-Y096F001Y) ]  
 SV7E3208UBA@FBGA56 [ (SA642A-B032A-Y096F001Y) ]  
 SV7E3208UTA@FBGA56 [ (SA642A-B032A-Y096F001Y) ]  
 SV7E3216UBA@FBGA56 [ (SA642A-B032A-Y096F001Y) ]  
 SV7E3216UTA@FBGA56 [ (SA642A-B032A-Y096F001Y) ]

## SIMTEK

### E ( E ) PROM / FRAM / NVRAM

STK10C48  
 STK10C48@SOIC28(300 mil) [ (SA404) ]  
 STK10C48@SOIC28(350 mil) [ (SA630) ]  
 STK10C68 STK10C68@PLCC28  
 [ (SA008A) ]  
 STK10C68@SOIC28(350 mil) [ (SA630) ]  
 STK11C48  
 STK11C48@SOIC28(300 mil) [ (SA404) ]  
 STK11C48@SOIC28(350 mil) [ (SA630) ]  
 STK11C68 STK11C68@PLCC28  
 [ (SA008A) ]  
 STK11C68@SOIC28(350 mil) [ (SA630) ]  
 STK11C88 STK11C88  
 (3V)

STK11C88(3V)@SOIC28(300 mil) [(SA404)]  
STK11C88(3V)@SOIC28(350 mil) [(SA630)]  
STK11C88@SOIC28(300 mil) [(SA404)]  
STK11C88@SOIC28(350 mil) [(SA630)]  
STK12C68 STK12C68@PLCC28  
[(SA008A)]  
STK12C68@SOIC28(350 mil) [(SA630)]  
STK14C88 STK14C88  
(3V)  
STK14C88(3V)@PLCC32 [(SA015A1T)]  
STK14C88(3V)@SOIC32(300 mil) [(SA715)]  
STK14C88(3V)@SOIC32(350 mil) [(SA630)]  
STK14C88@PLCC32 [(SA015A1T)]  
STK14C88@SOIC32(300 mil) [(SA715)]  
STK14C88@SOIC32(350 mil) [(SA630)]  
STK14CA8 STK14CA8@SOIC32  
[(SA715)]  
STK14CA8@SSOP48 [(SA669)] STK14D88@SOIC32  
[(SA715)]  
STK14D88@SSOP48 [(SA669)]  
STK15C68  
STK15C68@SOIC28(350 mil) [(SA630)]  
STK15C88  
STK15C88@SOIC28(300 mil) [(SA404)]  
STK15C88@SOIC28(350 mil) [(SA630)]  
STK16C68  
STK16C88  
STK16C88(3V)  
STK16CA8  
STK20C04  
STK22C48  
STK22C48@SOIC28(300 mil) [(SA404)]  
STK22C48@SOIC28(350 mil) [(SA630)]  
STK25C48

## SIRF

### E(E) PROM/FRAM/NVRAM

GSC3F(LP)-7979@FBGA140 [(SA678G-B190A-M140F001Y)]  
GSC3F-7879@FBGA140 [(SA678G-B190A-M140F001Y)]

## SMOS

### E ( E ) PROM / FRAM / NVRAM

SPM27128  
SPM27128C  
SPM27C256  
SPM27C64  
SPM27C64H

## SONIX

### MICROCONTROLLER

SN8P1504 [ ( SA404 ) ]	SN8P1504@SOP18
SN8P1504@SOP28 [ ( SA404 ) ]	
SN8P1506 SN8P1507@TQFP44 [ ( SA245A ) ]	
SN8P1602 SN8P1602@SOP18 [ ( SA404 ) ]	SN8P1602@SSOP20 [ ( SA674- B005 ) ]
SN8P1603 [ ( SA404 ) ]	SN8P1603@SOP18
SN8P1603@SSOP20 [ ( SA674-B005 ) ]	
SN8P1604 SN8P1604@SOP28 [ ( SA404 ) ]	
SN8P1702 SN8P1702@SOP18 [ ( SA404 ) ]	SN8P1702@SSOP20 [ ( SA674- B005 ) ]
SN8P1704A [ ( SA404 ) ]	SN8P1704A@SOP28
SN8P1704B [ ( SA404 ) ]	SN8P1704B@SOP28
SN8P1706A SN8P1706B	
SN8P1707A [ ( SA245A ) ]	SN8P1707A@TQFP44
SN8P1707B@TQFP44 [ ( SA245A ) ]	
SN8P1708A	

SN8P1708A@SSOP48 [(SA669)]

SN8P1708B

SN8P1708B@SSOP48 [(SA669)]

SN8P1714

SN8P1714@SOP18 [(SA404)]

[(SA404)]

SN8P1716

[(SA245A)]

SN8P2501AP

[(SA602)]

SN8P2501AX@TSSOP16 [(SA026)]

SN8P2501BP

SN8P2501BS@SOP14 [(SA602)]

[(SA026)]

SN8P2602AP

[(SA023A)]

SN8P2602AX@SSOP20 [(SA674)]

SN8P2602BP

SN8P2602BS@SOP18 [(SA023A)]

[(SA674)]

SN8P2603AP

[(SA023A)]

SN8P2603AX@SSOP20 [(SA674)]

SN8P2603BP

SN8P2603BS@SOP18 [(SA023A)]

[(SA674)]

SN8P26042AP

[(SA023A)]

SN8P26042AX@SSOP20 [(SA674)]

SN8P26042BP

SN8P26042BS@SOP20 [(SA023A)]

[(SA674)]

SN8P26042P

[(SA023A)]

SN8P26042X@SSOP20 [(SA674)]

SN8P2604AK

SN8P2604AS@SOP28 [(SA404)]

[(SA626A)]

SN8P2604BK

[(SA404)]

SN8P2604BX@SSOP28 [(SA626A)]

SN8P2604K

SN8P2604S@SOP28 [(SA404)]

SN8P1714@SOP28

SN8P1717@TQFP44

SN8P2501AS@SOP14

SN8P2501BX@TSSOP16

SN8P2602AS@SOP18

SN8P2602BX@SSOP20

SN8P2603AS@SOP18

SN8P2603BX@SSOP20

SN8P26042AS@SOP20

SN8P26042BX@SSOP20

SN8P26042S@SOP20

SN8P2604AX@SSOP28

SN8P2604BS@SOP28

SN8P2604X@SSOP28

[ (SA626A) ]	
SN8P2606P	
SN8P2608P	
SN8P2608X@SSOP48 [ (SA669) ]	
SN8P2622P	
SN8P2622S@SOP18 [ (SA023A) ]	SN8P2622X@SSOP20
[ (SA674) ]	
SN8P2624K	SN8P2624S@SOP28
[ (SA404) ]	
SN8P2624X@SSOP28 [ (SA626A) ]	SN8P2704AK@SDIP28
[ (SA653) ]	
SN8P2704AP	SN8P2704AS@SOP28
[ (SA723) ]	
SN8P2705AP	SN8P2705AS@SOP32
[ (SA687) ]	
SN8P2706AP	SN8P2707AQ@QFP44
[ (SA245A) ]	
SN8P2708AP	SN8P2708AQ@LQFP48
[ (SA248) ]	
SN8P2708AX@TSOP48 [ (SA669) ]	
SN8P2722P	
SN8P2722S@SOP20 [ (SA023A) ]	SN8P2722X@SSOP20
[ (SA674) ]	

## SONY

### E (E) PROM / FRAM / NVRAM

CXK1011M@SOIC8 [ (SA602A) ]  
CXK1011P  
CXK1012P  
CXK1013P  
CXK1023P  
CXK27C4001

### DRAM & SRAM

CXK581000	CXK581000@SOIC32
[ (SA630) ]	

**SPACE ELECTRONICS[SEi]****E ( E ) PROM / FRAM / NVRAM**

28C010 [ ( SA015A1T ) ]	28C010@PLCC32
28C010@TSOP32 [ ( SA410T ) ]	
28C010T 28C010T@PLCC32 [ ( SA015A1T ) ]	28C010T@TSOP32
[ ( SA410T ) ]	
28C011 [ ( SA015A1T ) ]	28C011@PLCC32
28C011@TSOP32 [ ( SA410T ) ]	
28C011T 28C011T@PLCC32 [ ( SA015A1T ) ]	28C011T@TSOP32
[ ( SA410T ) ]	

**SPANSION****E ( E ) PROM / FRAM / NVRAM**

AM29BL162CB@SSOP56 [ ( SA629A-B022 ) ]	
AM29BL802CB@SSOP56 [ ( SA629A-B022 ) ]	
AM29DL161DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]	
AM29DL161DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]	
AM29DL161DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]	
AM29DL161DB@TSOP48 [ ( SA247-B005 ) ]	
AM29DL161DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]	
AM29DL161DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]	
AM29DL161DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]	
AM29DL161DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]	
AM29DL161DT@TSOP48 [ ( SA247-B005 ) ]	
AM29DL161DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]	
AM29DL162CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]	
AM29DL162CB@TSOP48 [ ( SA247-B005 ) ]	
AM29DL162CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]	
AM29DL162CT@TSOP48 [ ( SA247-B005 ) ]	
AM29DL162DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]	
AM29DL162DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]	
AM29DL162DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]	
AM29DL162DB@TSOP48 [ ( SA247-B005 ) ]	



AM29DL162DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL162DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL162DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL162DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL163DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL163DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL163DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL163DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL164DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL164DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL164DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL164DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GB@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL320GB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL320GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL320GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GT@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL320GT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL320GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL321CB@TSOP48 [ ( SA247-B005 ) ]

AM29DL321CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322CB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322CT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL322GB@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL322GB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL322GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL322GT@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL322GT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL322GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323CB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323CT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323GB@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL323GB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL323GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323GT@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL323GT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL323GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL324DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL324DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL324GB@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]

AM29DL324GB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
 AM29DL324GB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL324GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DL324GT@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
 AM29DL324GT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
 AM29DL324GT@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL400BB@PSOP44 [ ( SA638-B006 ) ]  
 AM29DL400BB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL400BT@PLCC44 [ ( SA638-B006 ) ]  
 AM29DL400BT@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL640D@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
 AM29DL640D@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL640G@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
 AM29DL640G@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
 AM29DL640G@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL642G@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
 AM29DL800B@PSOP44 [ ( SA638-B006 ) ]      AM29DL800B@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL800BB@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
 AM29DL800BB@PSOP44 [ ( SA638 ) ]  
 AM29DL800BB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL800BT@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
 AM29DL800BT@PSOP44 [ ( SA638 ) ]  
 AM29DL800BT@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL800T@PSOP44 [ ( SA638-B006 ) ]      AM29DL800T@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS163CB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS163CT@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS163DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DS163DB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS163DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DS163DT@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS323DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DS323DB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS323DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DS323DT@TSOP48 [ ( SA247-B005 ) ]  
 AM29F002B      AM29F002B@PLCC32  
 [ ( SA015A1T ) ]  
 AM29F002B@TSOP32 [ ( SA410T ) ]  
 AM29F002BB  
 AM29F002BB@PLCC32 [ ( SA015A1T ) ]      AM29F002BB@TSOP32  
 [ ( SA410T ) ]  
 AM29F002BT      AM29F002BT@PLCC32

[ (SA015A1T) ]	
AM29F002BT@TSOP32 [ (SA410T) ]	
AM29F002NB	
AM29F002NB@PLCC32 [ (SA015A1T) ]	AM29F002NB@TSOP32
[ (SA410T) ]	
AM29F002NBB	
[ (SA015A1T) ]	
AM29F002NBB@TSOP32 [ (SA410T) ]	AM29F002NBB@PLCC32
AM29F002NBT	
AM29F002NBT@PLCC32 [ (SA015A1T) ]	AM29F002NBT@TSOP32
[ (SA410T) ]	
AM29F002NT	
[ (SA015A1T) ]	
AM29F002NT@TSOP32 [ (SA410T) ]	AM29F002NT@PLCC32
AM29F002T	
AM29F002T@PLCC32 [ (SA015A1T) ]	AM29F002T@TSOP32
[ (SA410T) ]	
AM29F004BB@PLCC32 [ (SA015A1T) ]	AM29F004BB@TSOP32
[ (SA410T) ]	
AM29F004BT@PLCC32 [ (SA015A1T) ]	AM29F004BT@TSOP32
[ (SA410T) ]	
AM29F010	
[ (SA015A1T) ]	AM29F010@PLCC32
AM29F010@TSOP32 [ (SA410T) ]	
AM29F010A	
AM29F010A@PLCC32 [ (SA015A1T) ]	AM29F010A@TSOP32
[ (SA410T) ]	
AM29F010B	
[ (SA015A1T) ]	AM29F010B@PLCC32
AM29F010B@TSOP32 [ (SA410T) ]	AM29F016@PSOP44
[ (SA638) ]	
AM29F016@TSOP40 [ (SA409T) ]	AM29F016@TSOP48 [ (SA247-
B005) ]	
AM29F016B@PSOP44 [ (SA638) ]	AM29F016B@TSOP40
[ (SA409T) ]	
AM29F016B@TSOP48 [ (SA247-B005) ]	
AM29F016D(REVERSE)@TSOP48 [ (SA247-B005) ]	
AM29F016D@PSOP44 [ (SA638) ]	AM29F016D@TSOP40
[ (SA409T) ]	
AM29F016D@TSOP48 [ (SA247-B005) ]	AM29F017B@TSOP48 [ (SA247-
B005) ]	
AM29F017D@TSOP40 [ (SA409T) ]	AM29F017D@TSOP48 [ (SA247-
B005) ]	

AM29F032B@PSOP44 [(SA638)]	AM29F032B@TSOP40
[(SA409T)]	
AM29F040	AM29F040@PLCC32
[(SA015A1T)]	
AM29F040@TSOP32 [(SA410T)]	
AM29F040A	
AM29F040A@PLCC32 [(SA015A1T)]	AM29F040A@TSOP32
[(SA410T)]	
AM29F040B	
AM29F040B(Reverse)@TSOP32 [(SA410T)]	
AM29F040B@PLCC32 [(SA015A1T)]	AM29F040B@TSOP32
[(SA410T)]	
AM29F080@PSOP44 [(SA638)]	AM29F080@TSOP40
[(SA409T)]	
AM29F080B@PSOP44 [(SA638)]	AM29F080B@TSOP40
[(SA409T)]	
AM29F100BE@PSOP44 [(SA638-B006)]	AM29F100BE@TSOP48 [(SA247-
B005)]	
AM29F100BS@PSOP44 [(SA638-B006)]	AM29F100BS@TSOP48 [(SA247-
B005)]	
AM29F100TE@PSOP44 [(SA638-B006)]	AM29F100TE@TSOP48 [(SA247-
B005)]	
AM29F100TS@PSOP44 [(SA638-B006)]	AM29F100TS@TSOP48 [(SA247-
B005)]	
AM29F160DB@TSOP48 [(SA247-B005)]	AM29F160DT@TSOP48 [(SA247-
B005)]	
AM29F200AB@PSOP44 [(SA638-B006)]	AM29F200AB@TSOP48 [(SA247-
B005)]	
AM29F200AT@PSOP44 [(SA638-B006)]	AM29F200AT@TSOP48 [(SA247-
B005)]	
AM29F200BB@PSOP44 [(SA638-B006)]	AM29F200BB@TSOP48 [(SA247-
B005)]	
AM29F200BE@PSOP44 [(SA638-B006)]	AM29F200BE@TSOP48 [(SA247-
B005)]	
AM29F200BS@PSOP44 [(SA638-B006)]	AM29F200BS@TSOP48 [(SA247-
B005)]	
AM29F200BT@PSOP44 [(SA638-B006)]	AM29F200BT@TSOP48 [(SA247-
B005)]	
AM29F200TE@PSOP44 [(SA638-B006)]	AM29F200TE@TSOP48 [(SA247-
B005)]	
AM29F200TS@PSOP44 [(SA638-B006)]	AM29F200TS@TSOP48 [(SA247-
B005)]	
AM29F400AB@PSOP44 [(SA638-B006)]	AM29F400AB@TSOP48 [(SA247-

B005) ]  
AM29F400AT@PSOP44 [ (SA638-B006) ] AM29F400AT@TSOP48 [ (SA247-  
B005) ]  
AM29F400BB@PSOP44 [ (SA638-B006) ] AM29F400BB@TSOP48 [ (SA247-  
B005) ]  
AM29F400BBE@PSOP44 [ (SA638-B006) ]  
AM29F400BBE@TSOP48 [ (SA247-B005) ]  
AM29F400BBF@PSOP44 [ (SA638-B006) ]  
AM29F400BBF@TSOP48 [ (SA247-B005) ]  
AM29F400BBS@PSOP44 [ (SA638-B006) ]  
AM29F400BBS@TSOP48 [ (SA247-B005) ]  
AM29F400BE@PSOP44 [ (SA638-B006) ] AM29F400BE@TSOP48 [ (SA247-  
B005) ]  
AM29F400BF@PSOP44 [ (SA638-B006) ] AM29F400BF@TSOP48 [ (SA247-  
B005) ]  
AM29F400BS@PSOP44 [ (SA638-B006) ] AM29F400BS@TSOP48 [ (SA247-  
B005) ]  
AM29F400BT@PSOP44 [ (SA638-B006) ] AM29F400BT@TSOP48 [ (SA247-  
B005) ]  
AM29F400BTE@PSOP44 [ (SA638-B006) ]  
AM29F400BTE@TSOP48 [ (SA247-B005) ]  
AM29F400BTF@PSOP44 [ (SA638-B006) ]  
AM29F400BTF@TSOP48 [ (SA247-B005) ]  
AM29F400BTS@PSOP44 [ (SA638-B006) ]  
AM29F400BTS@TSOP48 [ (SA247-B005) ]  
AM29F800B@PSOP44 [ (SA638-B006) ] AM29F800B@TSOP48 [ (SA247-  
B005) ]  
AM29F800BB@PSOP44 [ (SA638-B006) ] AM29F800BB@TSOP48 [ (SA247-  
B005) ]  
AM29F800BBF@PSOP44 [ (SA638-B006) ]  
AM29F800BBF@TSOP48 [ (SA247-B005) ]  
AM29F800BF@PSOP44 [ (SA638-B006) ] AM29F800BF@TSOP48 [ (SA247-  
B005) ]  
AM29F800BT@PSOP44 [ (SA638-B006) ] AM29F800BT@TSOP48 [ (SA247-  
B005) ]  
AM29F800BTF@PSOP44 [ (SA638-B006) ]  
AM29F800BTF@TSOP48 [ (SA247-B005) ]  
AM29F800T@PSOP44 [ (SA638-B006) ] AM29F800T@TSOP48 [ (SA247-  
B005) ]  
AM29F800TB@PSOP44 [ (SA638-B006) ] AM29F800TB@TSOP48 [ (SA247-  
B005) ]  
AM29F800TF@PSOP44 [ (SA638-B006) ] AM29F800TF@TSOP48 [ (SA247-  
B005) ]

AM29LL800B@TSOP48 [(SA247-B005)]	
AM29LL800BB@TSOP48 [(SA247-B005)]	
AM29LL800BT@TSOP48 [(SA247-B005)]	
AM29LL800T@TSOP48 [(SA247-B005)]	AM29LV001BB@PLCC32
[(SA015A1T)]	
AM29LV001BB@TSOP32 [(SA410T)]	AM29LV001BT@PLCC32
[(SA015A1T)]	
AM29LV001BT@TSOP32 [(SA410T)]	AM29LV002@TSOP40
[(SA409T)]	
AM29LV002B@TSOP40 [(SA409T)]	AM29LV002BB@TSOP40
[(SA409T)]	
AM29LV002BT@TSOP40 [(SA409T)]	AM29LV004B@PSOP44
[(SA638)]	
AM29LV004B@TSOP40 [(SA409T)]	AM29LV004BB@TSOP40
[(SA409T)]	
AM29LV004BT@TSOP40 [(SA409T)]	AM29LV004T@PSOP44
[(SA638)]	
AM29LV004T@TSOP40 [(SA409T)]	AM29LV008B@PSOP44
[(SA638)]	
AM29LV008B@TSOP40 [(SA409T)]	AM29LV008BB@TSOP40
[(SA409T)]	
AM29LV008BT@TSOP40 [(SA409T)]	AM29LV008T@PSOP44
[(SA638)]	
AM29LV008T@TSOP40 [(SA409T)]	AM29LV010B@PLCC32
[(SA015A1T)]	
AM29LV010B@TSOP32 [(SA410T)]	AM29LV017B@TSOP40
[(SA409T)]	
AM29LV017D@FBGA48 [(SA642B-B026A-Y072F001)]	
AM29LV017D@TSOP40 [(SA409T)]	AM29LV020B@PLCC32
[(SA015A1T)]	
AM29LV020B@TSOP32 [(SA410T)]	
AM29LV033C@FBGA63 [(SA642A-B026A-Y096N001)]	
AM29LV033C@TSOP40 [(SA409T)]	
AM29LV033MU@FBGA48 [(SA642B-B026A-Y072F001)]	
AM29LV033MU@TSOP40 [(SA409T)]	AM29LV040B@PLCC32
[(SA015A1T)]	
AM29LV040B@TSOP32 [(SA410T)]	AM29LV040E@PLCC32
[(SA015A1T)]	
AM29LV040E@TSOP32 [(SA410T)]	AM29LV040J@PLCC32
[(SA015A1T)]	
AM29LV040J@TSOP32 [(SA410T)]	
AM29LV065D@FBGA63 [(SA642C-B026A-Y056F001)]	
AM29LV065D@TSOP48 [(SA247-B005)]	

AM29LV065MU@FBGA63 [ (SA642C-B026A-Y056F001) ]  
AM29LV065MU@TSOP48 [ (SA247-B005) ]  
AM29LV080@TSOP40 [ (SA409T) ] AM29LV081@TSOP40  
[ (SA409T) ]  
AM29LV081B@TSOP40 [ (SA409T) ] AM29LV116BB@TSOP40  
[ (SA409T) ]  
AM29LV116BT@TSOP40 [ (SA409T) ] AM29LV116DB@TSOP40  
[ (SA409T) ]  
AM29LV116DT@TSOP40 [ (SA409T) ]  
AM29LV128MH@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
AM29LV128MH@TSOP56 [ (SA628-B067) ]  
AM29LV128ML@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
AM29LV128ML@TSOP56 [ (SA628-B067) ]  
AM29LV160BB@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
AM29LV160BB@PSOP44 [ (SA638) ]  
AM29LV160BB@TSOP48 [ (SA247-B005) ]  
AM29LV160BT@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
AM29LV160BT@PSOP44 [ (SA638) ]  
AM29LV160BT@TSOP48 [ (SA247-B005) ]  
AM29LV160DB(REVERSE)@TSOP48 [ (SA247-B005) ]  
AM29LV160DB@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
AM29LV160DB@PSOP44 [ (SA638) ]  
AM29LV160DB@TSOP48 [ (SA247-B005) ]  
AM29LV160DT(REVERSE)@TSOP48 [ (SA247-B005) ]  
AM29LV160DT@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
AM29LV160DT@PSOP44 [ (SA638) ]  
AM29LV160DT@TSOP48 [ (SA247-B005) ]  
AM29LV160MB@FBGA48 [ (SA642B-B026A-Y072F001) ]  
AM29LV160MB@FBGA64 [ (SA655A-B044A-T064N001) ]  
AM29LV160MB@PSOP44 [ (SA638) ]  
AM29LV160MB@TSOP48 [ (SA247-B005) ]  
AM29LV160MT@FBGA48 [ (SA642B-B026A-Y072F001) ]  
AM29LV160MT@FBGA64 [ (SA655A-B044A-T064N001) ]  
AM29LV160MT@PSOP44 [ (SA638) ]  
AM29LV160MT@TSOP48 [ (SA247-B005) ]  
AM29LV200B@PSOP44 [ (SA638-B006) ] AM29LV200B@TSOP48 [ (SA247-  
B005) ]  
AM29LV200BB@PSOP44 [ (SA638-B006) ]  
AM29LV200BB@TSOP48 [ (SA247-B005) ]  
AM29LV200BE@PSOP44 [ (SA638-B006) ]  
AM29LV200BE@TSOP48 [ (SA247-B005) ]  
AM29LV200BF@PSOP44 [ (SA638-B006) ]  
AM29LV200BF@TSOP48 [ (SA247-B005) ]



AM29LV200BS@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BS@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BT@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200T@PSOP44 [ ( SA638-B006 ) ]      AM29LV200T@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TE@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200TE@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TF@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200TF@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TS@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200TS@TSOP48 [ ( SA247-B005 ) ]  
AM29LV256MH@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
AM29LV256MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV256ML@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
AM29LV256ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320DB@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29LV320DB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320DT@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29LV320DT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320FB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320FT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320MB@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AM29LV320MB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV320MB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320MH@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV320MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320ML@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV320ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320MT@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AM29LV320MT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV320MT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400B@PSOP44 [ ( SA638-B006 ) ]      AM29LV400B@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400BB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29LV400BB@PSOP44 [ ( SA638-B006 ) ]  
AM29LV400BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400BT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29LV400BT@PSOP44 [ ( SA638-B006 ) ]  
AM29LV400BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400T@PSOP44 [ ( SA638-B006 ) ]      AM29LV400T@TSOP48 [ ( SA247-B005 ) ]  
AM29LV640DH@SSOP56 [ ( SA629A-B020 ) ]

AM29LV640DL@SSOP56 [ ( SA629A-B020 ) ]  
AM29LV640DU@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640DU@FBGA64 [ ( SA655D-B044A-W064F001 ) ]  
AM29LV640GU@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640GU@FBGA64 [ ( SA655D-B044A-W064F001 ) ]  
AM29LV640MB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29LV640MB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV640MB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV640MH@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV640MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV640ML@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV640ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV640MT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29LV640MT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV640MT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV640MU@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29LV640MU@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV641DH@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641DHR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641DL@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641DLR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GH@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GHR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GL@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GLR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641MH@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641ML@TSOP48 [ ( SA247-B005 ) ]  
AM29LV642G@FBGA64 [ ( SA655A-B038A-T064N001 ) ]  
AM29LV652D@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV800B@PSOP44 [ ( SA638-B006 ) ]      AM29LV800B@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800BB@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29LV800BB@PSOP44 [ ( SA638-B006 ) ]  
AM29LV800BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800BT@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29LV800BT@PSOP44 [ ( SA638-B006 ) ]  
AM29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800DB(WB)@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29LV800DB(WC)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
AM29LV800DB@PSOP44 [ ( SA638 ) ]  
AM29LV800DB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800DT(WB)@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29LV800DT(WC)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]

AM29LV800DT@PSOP44 [ (SA638) ]  
AM29LV800DT@TSOP48 [ (SA247-B005) ]  
AM29LV800T@PSOP44 [ (SA638-B006) ]      AM29LV800T@TSOP48 [ (SA247-B005) ]  
AM29N163DT@FBGA47 [ (SA733A-B206A-M056F001N) ]  
AM29N323DT@FBGA47 [ (SA733A-B206A-M056F001N) ]  
AM29N643GT@FBGA44 [ (SA733A-B206A-M056F001Y) ]  
AM29PDS322DB@FBGA48 [ (SA642E-B026A-T072F001) ]  
AM29PDS322DT@FBGA48 [ (SA642E-B026A-T072F001) ]  
AM29PL160CB@PSOP44 [ (SA638-B006) ]  
AM29PL160CB@TSOP48 [ (SA247-B005) ]  
AM29PL160CT@PSOP44 [ (SA638-B006) ]  
AM29PL160CT@TSOP48 [ (SA247-B005) ]  
AM29SL160CB@FBGA48 [ (SA642B-B026A-Y072F001) ]  
AM29SL160CB@TSOP48 [ (SA247-B005) ]  
AM29SL160CT@FBGA48 [ (SA642B-B026A-Y072F001) ]  
AM29SL160CT@TSOP48 [ (SA247-B005) ]  
AM29SL400CB@TSOP48 [ (SA247-B005) ]  
AM29SL400CT@TSOP48 [ (SA247-B005) ]  
AM29SL800BB@TSOP48 [ (SA247-B005) ]  
AM29SL800BT@TSOP48 [ (SA247-B005) ]  
AM29SL800CB@TSOP48 [ (SA247-B005) ]  
AM29SL800CT@TSOP48 [ (SA247-B005) ]  
AM29SL800DB@TSOP48 [ (SA247-B005) ]  
AM29SL800DBUF@FBGA48 [ (SA716A-B119B-M048F001Y) ]  
AM29SL800DBVG@FBGA48 [ (SA716A-B119B-M048F001Y) ]  
AM29SL800DBVU@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
AM29SL800DBWA@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
AM29SL800DBWC@FBGA48 [ (SA642R-B026A-W080F001N) ]  
AM29SL800DT@TSOP48 [ (SA247-B005) ]  
AM29SL800DTUF@FBGA48 [ (SA716A-B119B-M048F001Y) ]  
AM29SL800DTVG@FBGA48 [ (SA716A-B119B-M048F001Y) ]  
AM29SL800DTVU@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
AM29SL800DTWA@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
AM29SL800DTWC@FBGA48 [ (SA642R-B026A-W080F001N) ]  
DS42514 (AM29DL163DB)@FBGA69 [ (SA642B-B032A-Y072F001) ]  
DS42515 (AM29DL164)@FBGA69 [ (SA642B-B032A-Y072F001) ]  
DS42516 (AM29DL324)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
DS42546 (AM29DL163)@FBGA69 [ (SA642B-B032A-Y072F001) ]  
DS42553 (AM29DL323)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
DS42585 (AM29DL323D)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
DS42587 (AM29DL324D)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
DS42629 (AM29DL640G)@VFBGA48 [ (SA634A-B005A-Y048F001) ]

DS42677 (AM29LV128MH/L)@FBGA88 [ (SA642A-B058A-Y096N001) ]  
DS42678 (AM29LV320MT)@FBGA67 [ (SA642E-B041A-T072F001) ]  
DS42689 (AM29LV320MT)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
DS42690 (AM29LV320MB)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
DS42695 (AM29LV320MT)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
DS42696 (AM29LV320MB)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
DS42701 (AM29LV640MU)@FBGA88 [ (SA642W-B116A-W088F001Y) ]  
DS42725 (AM50DL128CH)@FBGA88 [ (SA642A-B062A-Y096F001) ]  
DS42772A (AM29LV640M)@FBGA88 [ (SA642W-B116A-W088F001Y) ]  
M420000070 (AM42BDS6408HE8)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000071 (AM42BDS6408HE9)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000072 (AM42BDS6408HD8)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000073 (AM42BDS6408HD9)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000074 (AM42BDS6408HE3)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000075 (AM42BDS6408HE4)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000076 (AM42BDS6408HD3)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000077 (AM42BDS6408HD4)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M490000030 (AM49PDL129BH)@FBGA73 [ (SA642A-B039A-Y096F001) ]  
M490000031 (AM49PDL129BH)@FBGA73 [ (SA642A-B039A-Y096F001) ]  
M4900000K (AM49PDL129AH)@FBGA73 [ (SA642A-B039A-Y096F001) ]  
M4900000L (AM49PDL129AH)@FBGA73 [ (SA642A-B039A-Y096F001) ]  
MB84VD21081@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21081EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21082@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21082EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21083@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21083EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21084@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21084EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21091@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21091EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21092@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21092EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21093@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21093EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21094@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21094EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21181DA@FBGA69 [ (SA642C-B032A-Y056F001) ]  
MB84VD21181EG@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21181EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21182DA@FBGA69 [ (SA642C-B032A-Y056F001) ]  
MB84VD21182EG@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21182EM@FBGA56 [ (SA642C-B032A-Y056F001) ]

MB84VD21183DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21183EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21183EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21184DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21184EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21184EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21191DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21191EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21191EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21192DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21192EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21192EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD22180FA@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22180FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22181A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22181EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22181EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22181FM@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22182A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22182EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22182EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22183A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22183EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22183EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22184EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184FM@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22190FA@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22190FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22191A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22191EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22191EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22191FM@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22192A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22192EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22192EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]

MB84VD22193A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22193EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22193EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22194A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22194EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22194EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22194FM@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22280FE@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22282EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22283EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22284EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22290FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22292EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22293EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22294EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22386EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22387EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22388EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22396EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22397EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22398EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD23180FM@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD23280EA@FBGA101 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23280EE@FBGA101 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23280FA@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23381EJ@FBGA101 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23381FJ@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23381HJ@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD23481FJ@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VF5F5FF4J2@BGA107 [ ( SA642D-B062A-Y088F001 ) ]  
MB84VP23481FK@FBGA65 [ ( SA642JJ-B032A-W064F001Y ) ]  
MB84VP24481HK@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
MB84VP24491HK@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
MBM29DL161BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL161BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL161BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL161TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL161TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL161TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL162BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162BE@TSOP48 [ ( SA247-B005 ) ]

MBM29DL162TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL162TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL320BF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL320BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL320TF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL320TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL321BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL321TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL321TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL322BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL322TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL323BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]

MBM29DL323BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL323TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL324BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL324BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL324TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL324TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL32BF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL32BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL32TF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL32TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL34BF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL34BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL34TF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL34TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL400BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL400BC@PSOP44 [ ( SA638 ) ]  
MBM29DL400BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL400BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400TC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL400TC@PSOP44 [ ( SA638 ) ]  
MBM29DL400TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL640E@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
MBM29DL640E@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL64DF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
MBM29DL64DF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800B@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL800B@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800BA@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL800BA@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL800BB@TSOP48 [ ( SA247-B005 ) ]



MBM29DL800BT@PSOP44 [(SA638-B006)]  
 MBM29DL800BT@TSOP48 [(SA247-B005)]  
 MBM29DL800T@PSOP44 [(SA638-B006)]  
 MBM29DL800T@TSOP48 [(SA247-B005)]  
 MBM29DL800TA@FBGA48 [(SA642N-B026A-W048F001Y)]  
 MBM29DL800TA@TSOP48 [(SA247-B005)]  
 MBM29DS163BE@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 MBM29DS163BE@TSOP48 [(SA247-B005)]  
 MBM29DS163TE@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 MBM29DS163TE@TSOP48 [(SA247-B005)]  
 MBM29F001B MBM29F001B@PLCC32  
 [(SA015A1T)]  
 MBM29F001B@TSOP32 [(SA410T)]  
 MBM29F001T MBM29F001T@TSOP32  
 MBM29F001T@PLCC32 [(SA015A1T)]  
 [(SA410T)]  
 MBM29F002B MBM29F002B@PLCC32  
 [(SA015A1T)]  
 MBM29F002B@TSOP32 [(SA410T)]  
 MBM29F002NB MBM29F002NB@TSOP32  
 MBM29F002NB@PLCC32 [(SA015A1T)]  
 [(SA410T)]  
 MBM29F002NT MBM29F002NT@PLCC32  
 [(SA015A1T)]  
 MBM29F002NT@TSOP32 [(SA410T)]  
 MBM29F002T MBM29F002T@TSOP32  
 MBM29F002T@PLCC32 [(SA015A1T)]  
 [(SA410T)]  
 MBM29F010 MBM29F010@PLCC32  
 [(SA015A1T)]  
 MBM29F010@TSOP32 [(SA410T)]  
 MBM29F010A MBM29F010A@TSOP32  
 MBM29F010A@PLCC32 [(SA015A1T)]  
 [(SA410T)]  
 MBM29F016@PSOP44 [(SA638)] MBM29F016@TSOP40  
 [(SA409T)]  
 MBM29F016@TSOP48 [(SA247-B005)] MBM29F016A@PSOP44  
 [(SA638)]  
 MBM29F016A@TSOP40 [(SA409T)] MBM29F016A@TSOP48 [(SA247-  
 B005)]  
 MBM29F016B@PSOP44 [(SA638)] MBM29F016B@TSOP40  
 [(SA409T)]  
 MBM29F016B@TSOP48 [(SA247-B005)] MBM29F017B@TSOP48 [(SA247-

B005) ]  
MBM29F017D@TSOP40 [ (SA409T) ]  
B005) ]  
MBM29F032B@PSOP44 [ (SA638) ]  
[ (SA409T) ]  
MBM29F033C@TSOP40 [ (SA409T) ]  
MBM29F040  
MBM29F040@PLCC32 [ (SA015A1T) ]  
[ (SA410T) ]  
MBM29F040B  
[ (SA015A1T) ]  
MBM29F040B@TSOP32 [ (SA410T) ]  
[ (SA015A1T) ]  
MBM29F040C@TSOP32 [ (SA410T) ]  
[ (SA638) ]  
MBM29F080@TSOP40 [ (SA409T) ]  
B005) ]  
MBM29F080B@PSOP44 [ (SA638) ]  
[ (SA409T) ]  
MBM29F100B@PSOP44 [ (SA638-B006) ]  
B005) ]  
MBM29F100T@PSOP44 [ (SA638-B006) ]  
B005) ]  
MBM29F160BE@TSOP48 [ (SA247-B005) ]  
MBM29F160TE@TSOP48 [ (SA247-B005) ]  
MBM29F200AB@PSOP44 [ (SA638-B006) ]  
MBM29F200AB@TSOP48 [ (SA247-B005) ]  
MBM29F200AT@PSOP44 [ (SA638-B006) ]  
MBM29F200AT@TSOP48 [ (SA247-B005) ]  
MBM29F200B@PSOP44 [ (SA638-B006) ]  
B005) ]  
MBM29F200T@PSOP44 [ (SA638-B006) ]  
B005) ]  
MBM29F400AB@PSOP44 [ (SA638-B006) ]  
MBM29F400AB@TSOP48 [ (SA247-B005) ]  
MBM29F400AT@PSOP44 [ (SA638-B006) ]  
MBM29F400AT@TSOP48 [ (SA247-B005) ]  
MBM29F400B@PSOP44 [ (SA638-B006) ]  
B005) ]  
MBM29F400BB@PSOP44 [ (SA638-B006) ]  
MBM29F400BB@TSOP48 [ (SA247-B005) ]  
MBM29F400BT@PSOP44 [ (SA638-B006) ]  
MBM29F400BT@TSOP48 [ (SA247-B005) ]

MBM29F017D@TSOP48 [ (SA247-  
B005) ]  
MBM29F032B@TSOP40  
MBM29F040@TSOP32  
MBM29F040B@PLCC32  
MBM29F040C@PLCC32  
MBM29F080@PSOP44  
MBM29F080A@TSOP48 [ (SA247-  
B005) ]  
MBM29F080B@TSOP40  
MBM29F100B@TSOP48 [ (SA247-  
B005) ]  
MBM29F100T@TSOP48 [ (SA247-  
B005) ]  
MBM29F200B@TSOP48 [ (SA247-  
B005) ]  
MBM29F200T@TSOP48 [ (SA247-  
B005) ]  
MBM29F400B@TSOP48 [ (SA247-  
B005) ]

MBM29F400T@PSOP44 [ (SA638-B006) ]	MBM29F400T@TSOP48 [ (SA247-B005) ]
MBM29F800B@PSOP44 [ (SA638-B006) ]	MBM29F800B@TSOP48 [ (SA247-B005) ]
MBM29F800BB@PSOP44 [ (SA638-B006) ]	
MBM29F800BB@TSOP48 [ (SA247-B005) ]	
MBM29F800BT@PSOP44 [ (SA638-B006) ]	
MBM29F800BT@TSOP48 [ (SA247-B005) ]	
MBM29F800T@PSOP44 [ (SA638-B006) ]	MBM29F800T@TSOP48 [ (SA247-B005) ]
MBM29LL800B@TSOP48 [ (SA247-B005) ]	
MBM29LL800BB@TSOP48 [ (SA247-B005) ]	
MBM29LL800BT@TSOP48 [ (SA247-B005) ]	
MBM29LL800T@TSOP48 [ (SA247-B005) ]	
MBM29LV001B@PLCC32 [ (SA015A1T) ]	MBM29LV001BB@PLCC32 [ (SA015A1T) ]
MBM29LV001BB@TSOP32 [ (SA410T) ]	MBM29LV001BC@PLCC32 [ (SA015A1T) ]
MBM29LV001BC@TSOP32 [ (SA410T) ]	MBM29LV001BT@PLCC32 [ (SA015A1T) ]
MBM29LV001BT@TSOP32 [ (SA410T) ]	MBM29LV001T@TSOP32 [ (SA410T) ]
MBM29LV001TC@PLCC32 [ (SA015A1T) ]	MBM29LV001TC@TSOP32 [ (SA410T) ]
MBM29LV002B@TSOP40 [ (SA409T) ]	MBM29LV002T@TSOP40 [ (SA409T) ]
MBM29LV004B@PSOP44 [ (SA638) ]	MBM29LV004B@TSOP40 [ (SA409T) ]
MBM29LV004BB@TSOP40 [ (SA409T) ]	MBM29LV004BT@TSOP40 [ (SA409T) ]
MBM29LV004T@PSOP44 [ (SA638) ]	MBM29LV004T@TSOP40 [ (SA409T) ]
MBM29LV008B@PSOP44 [ (SA638) ]	MBM29LV008B@TSOP40 [ (SA409T) ]
MBM29LV008BB@TSOP40 [ (SA409T) ]	MBM29LV008BT@TSOP40 [ (SA409T) ]
MBM29LV008T@PSOP44 [ (SA638) ]	MBM29LV008T@TSOP40 [ (SA409T) ]
MBM29LV016/B@TSOP40 [ (SA409T) ]	MBM29LV016/T@TSOP40 [ (SA409T) ]
MBM29LV016B@TSOP40 [ (SA409T) ]	
MBM29LV017@FBGA48 [ (SA642O-B026A-T064F001) ]	
MBM29LV017@TSOP40 [ (SA409T) ]	MBM29LV017B@TSOP40 [ (SA409T) ]

[ ( SA409T ) ]  
 MBM29LV017E@TSOP40 [ ( SA409T ) ] MBM29LV033C@TSOP40  
 [ ( SA409T ) ]  
 MBM29LV080@TSOP40 [ ( SA409T ) ] MBM29LV081@TSOP40  
 [ ( SA409T ) ]  
 MBM29LV081B@TSOP40 [ ( SA409T ) ] MBM29LV116B@TSOP40  
 [ ( SA409T ) ]  
 MBM29LV160B@SON46 [ ( SA631 ) ] MBM29LV160B@SON46  
 ( \* )  
 MBM29LV160BB@PSOP44 [ ( SA638-B006 ) ]  
 MBM29LV160BB@TSOP48 [ ( SA247-B005 ) ]  
 MBM29LV160BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 MBM29LV160BE@TSOP48 [ ( SA247-B005 ) ]  
 MBM29LV160BM@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 MBM29LV160BM@TSOP48 [ ( SA247-B005 ) ]  
 MBM29LV160BT@PSOP44 [ ( SA638-B006 ) ]  
 MBM29LV160BT@TSOP48 [ ( SA247-B005 ) ]  
 MBM29LV160T@SON46 [ ( SA631 ) ] MBM29LV160T@SON46  
 ( \* )  
 MBM29LV160TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 MBM29LV160TE@TSOP48 [ ( SA247-B005 ) ]  
 MBM29LV160TM@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 MBM29LV160TM@TSOP48 [ ( SA247-B005 ) ]  
 MBM29LV200B@PSOP44 [ ( SA638-B006 ) ]  
 MBM29LV200B@TSOP48 [ ( SA247-B005 ) ]  
 MBM29LV200BB@PSOP44 [ ( SA638-B006 ) ]  
 MBM29LV200BB@TSOP48 [ ( SA247-B005 ) ]  
 MBM29LV200BC@PSOP44 [ ( SA638 ) ]  
 MBM29LV200BC@TSOP48 [ ( SA247-B005 ) ]  
 MBM29LV200BT@PSOP44 [ ( SA638-B006 ) ]  
 MBM29LV200BT@TSOP48 [ ( SA247-B005 ) ]  
 MBM29LV200T@PSOP44 [ ( SA638-B006 ) ]  
 MBM29LV200T@TSOP48 [ ( SA247-B005 ) ]  
 MBM29LV200TC@PSOP44 [ ( SA638 ) ]  
 MBM29LV200TC@TSOP48 [ ( SA247-B005 ) ]  
 MBM29LV320BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
 MBM29LV320BE@TSOP48 [ ( SA247-B005 ) ]  
 MBM29LV320TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
 MBM29LV320TE@TSOP48 [ ( SA247-B005 ) ]  
 MBM29LV400B@PSOP44 [ ( SA638-B006 ) ]  
 MBM29LV400B@TSOP48 [ ( SA247-B005 ) ]  
 MBM29LV400BB@PSOP44 [ ( SA638-B006 ) ]  
 MBM29LV400BB@TSOP48 [ ( SA247-B005 ) ]

MBM29LV400BC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29LV400BC@PSOP44 [ ( SA638 ) ]  
MBM29LV400BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400TC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29LV400TC@PSOP44 [ ( SA638 ) ]  
MBM29LV400TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV650UE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV651UE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV652UE@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
MBM29LV800B@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800B@SON46 [ ( SA631 ) ] MBM29LV800B@SON46  
( \* )  
MBM29LV800B@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BA@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800BA@PSOP44 [ ( SA638 ) ]  
MBM29LV800BA@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800BE@PSOP44 [ ( SA638 ) ]  
MBM29LV800BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800T@SON46 [ ( SA631 ) ] MBM29LV800T@SON46  
( \* )  
MBM29LV800T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800TA@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800TA@PSOP44 [ ( SA638 ) ]  
MBM29LV800TA@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800TE@PSOP44 [ ( SA638 ) ]  
MBM29LV800TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29PDS323B@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29PDS323T@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29PL160BD@PSOP44 [ ( SA638 ) ]  
MBM29PL160BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL160TD@PSOP44 [ ( SA638 ) ]  
MBM29PL160TD@TSOP48 [ ( SA247-B005 ) ]

MBM29PL32BM@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
MBM29PL32BM@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL32TM@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
MBM29PL32TM@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL64LM@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL64LM@TSOP56 [ ( SA628-B067 ) ]  
MBM29QM12DH@FBGA88 [ ( SA642J-B101A-W080F001 ) ]  
MBM29QM12DH@TSOP56 [ ( SA628-B097 ) ]  
MBM29SL160BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29SL160BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29SL160TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29SL160TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29SL800BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29SL800BT@TSOP48 [ ( SA247-B005 ) ]  
PDL127H53V(AM29PDL127H53)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL127H63V(AM29PDL127H63)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL127H68V(AM29PDL127H68)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL127H88V(AM29PDL127H88)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL129H53V(AM29PDL129H53)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL129H63V(AM29PDL129H63)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL129H68V(AM29PDL129H68)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL129H88V(AM29PDL129H88)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PL032J55BAI12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J55BAI15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J55BAW12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J55BAW15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J55BFI12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J55BFI15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J55BFW12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J55BFW15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J60BAI12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J60BAI15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J60BAW12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J60BAW15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J60BFI12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J60BFI15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J60BFW12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J60BFW15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J70BAI12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J70BAI15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J70BAW12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J70BAW15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J70BFI12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]

PL032J70BFI15 (S29PL032J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL032J70BFW12 (S29PL032J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL032J70BFW15 (S29PL032J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J55BAI12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J55BAI15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J55BAW12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J55BAW15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J55BFI12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J55BFI15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J55BFW12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J55BFW15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J60BAI12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J60BAI15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J60BAW12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J60BAW15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J60BFI12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J60BFI15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J60BFW12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J60BFW15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J70BAI12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J70BAI15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J70BAW12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J70BAW15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J70BFI12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J70BFI15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J70BFW12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J70BFW15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL127J55BAI00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J55BAI02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J55BAW00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J55BAW02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J55BFI00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J55BFI02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J55BFW00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J55BFW02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J60BAI00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J60BAI02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J60BAW00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J60BAW02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J60BFI00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J60BFI02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J60BFW00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J60BFW02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]

PL127J65BAI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BAI01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BAI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J65BAW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BAW01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BAW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J65BFI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BFI01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BFI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J65BFW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BFW01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J65BFW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J70BAI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BAI01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BAI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J70BAW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BAW01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BAW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J70BFI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BFI01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BFI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
PL127J70BFW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BFW01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
PL127J70BFW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S19MN02GP30TFP00@TSOP48 [(SA247-B005)]  
S19MN256P30TFP00@TSOP48 [(SA247-B005)]  
S19MN512P30TFP00@TSOP48 [(SA247-B005)]  
S25FL001D@SOIC8 [(SA602A)] S25FL001D@USON8  
[(SA683)]  
S25FL002A@SOIC8 [(SA605A)] S25FL002A@USON8  
[(SA683)]  
S25FL002D@SOIC8 [(SA602A)] S25FL002D@USON8  
[(SA683)]  
S25FL004A@SOIC8 [(SA605A)] S25FL004A@USON8  
[(SA683)]  
S25FL004D@SOIC8 [(SA602A)] S25FL004D@USON8  
[(SA683)]  
S25FL008A@SOIC8 [(SA605A)] S25FL008A@USON8  
[(SA683)]  
S25FL008D@SOIC8 [(SA602A)] S25FL008D@USON8  
[(SA683)]  
S25FL016A@SOIC16 [(SA404)]  
S25FL016A@SOIC16(ISP) [ISP-HEADER01]



S25FL016A@SOIC8 [(SA605A)]  
S25FL016A@SOIC8(ISP) [ISP-HEADER01]  
S25FL016A@WSON8 [(SA684)]  
S25FL016A@WSON8(ISP) [ISP-HEADER01]  
S25FL020A@SOIC8(4.0) [(SA602A)] S25FL020A@SOIC8(5.4)  
[(SA605A)]  
S25FL020A@USON8 [(SA683)] S25FL032A@SOIC16  
[(SA404)]  
S25FL032A@SOIC16(ISP) [ISP-HEADER01]  
S25FL032A@WSON8 [(SA684)]  
S25FL032A@WSON8(ISP) [ISP-HEADER01]  
S25FL040A(Bottom Boot)@SOP8(4.0) [(SA602A)]  
S25FL040A(Bottom Boot)@SOP8(5.4) [(SA605A)]  
S25FL040A(Bottom Boot)@USON8 [(SA683)]  
S25FL040A(Top Boot)@SOP8(4.0) [(SA602A)]  
S25FL040A(Top Boot)@SOP8(5.4) [(SA605A)]  
S25FL040A(Top Boot)@USON8 [(SA683)]  
S25FL040A@SOP8(4.0) [(SA602A)] S25FL040A@SOP8(5.4)  
[(SA605A)]  
S25FL040A@USON8 [(SA683)] S25FL064A@SOIC16  
[(SA404)]  
S25FL064A@SOIC16(ISP) [ISP-HEADER01]  
S25FL064A@WSON8 [(SA684)]  
S25FL064A@WSON8(ISP) [ISP-HEADER01]  
S25FL080A@SOIC8(4.0) [(SA602A)] S25FL080A@SOIC8(5.4)  
[(SA605A)]  
S25FL080A@USON8 [(SA683)]  
S25FL128P(256 KB)@SOIC16 [(SA404)]  
S25FL128P(256 KB)@SOIC16(ISP) [ISP-HEADER01]  
S25FL128P(256 KB)@WSON8 [(SA684)]  
S25FL128P(256 KB)@WSON8(ISP) [ISP-HEADER01]  
S25FL128P(64 KB)@SOIC16 [(SA404)]  
S25FL128P(64 KB)@SOIC16(ISP) [ISP-HEADER01]  
S25FL128P(64 KB)@WSON8 [(SA684)]  
S25FL128P(64 KB)@WSON8(ISP) [ISP-HEADER01]  
S25FLK05D@SOIC8 [(SA602A)] S25FLK05D@USON8  
[(SA683)]  
S29AD016DBFA01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AD016DBFA02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AD016DBFB01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AD016DBFB02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AD016DBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29AD016DBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]

S29AD016DBFV01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AD016DBFV02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AD016DMFA01@PSOP44 [ ( SA638 ) ] S29AD016DMFA02@PSOP44  
[ ( SA638 ) ]  
S29AD016DMFB01@PSOP44 [ ( SA638 ) ] S29AD016DMFB02@PSOP44  
[ ( SA638 ) ]  
S29AD016DMFI01@PSOP44 [ ( SA638 ) ] S29AD016DMFI02@PSOP44  
[ ( SA638 ) ]  
S29AD016DMFV01@PSOP44 [ ( SA638 ) ] S29AD016DMFV02@PSOP44  
[ ( SA638 ) ]  
S29AD016DTFA01@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFA02@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFB01@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFB02@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFV01@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFV02@TSOP48 [ ( SA247-B005 ) ]  
S29AL002BBAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL002BBAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL002BBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL002BBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL002BMAI01@PSOP44 [ ( SA638 ) ] S29AL002BMAI02@PSOP44  
[ ( SA638 ) ]  
S29AL002BMFI01@PSOP44 [ ( SA638 ) ] S29AL002BMFI02@PSOP44  
[ ( SA638 ) ]  
S29AL002BTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL002BTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL002BTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL002BTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL004BBAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004BBAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004BBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004BBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004BMAI01@PSOP44 [ ( SA638 ) ] S29AL004BMAI02@PSOP44  
[ ( SA638 ) ]  
S29AL004BMFI01@PSOP44 [ ( SA638 ) ] S29AL004BMFI02@PSOP44  
[ ( SA638 ) ]  
S29AL004BTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL004BTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL004BTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL004BTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DBAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]

S29AL004DBAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBAN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBAN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBANR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBANR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFNR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFNR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DMAI01@PSOP44 [ ( SA638 ) ] S29AL004DMAI02@PSOP44  
[ ( SA638 ) ]  
S29AL004DMAN01@PSOP44 [ ( SA638 ) ] S29AL004DMAN02@PSOP44  
[ ( SA638 ) ]  
S29AL004DMANR1@PSOP44 [ ( SA638 ) ] S29AL004DMANR2@PSOP44  
[ ( SA638 ) ]  
S29AL004DMFI01@PSOP44 [ ( SA638 ) ] S29AL004DMFI02@PSOP44  
[ ( SA638 ) ]  
S29AL004DMFN01@PSOP44 [ ( SA638 ) ] S29AL004DMFN02@PSOP44  
[ ( SA638 ) ]  
S29AL004DMFNR1@PSOP44 [ ( SA638 ) ] S29AL004DMFNR2@PSOP44  
[ ( SA638 ) ]  
S29AL004DTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTAN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTAN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTANR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTANR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTFN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTFN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTFNR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DTFNR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DBAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBAN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBAN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBANR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBANR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]

S29AL008DBFN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBFN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBFN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DBFN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL008DMAI01@PSOP44 [ ( SA638 ) ] S29AL008DMAI02@PSOP44  
[ ( SA638 ) ]  
S29AL008DMAN01@PSOP44 [ ( SA638 ) ] S29AL008DMAN02@PSOP44  
[ ( SA638 ) ]  
S29AL008DMANR1@PSOP44 [ ( SA638 ) ] S29AL008DMANR2@PSOP44  
[ ( SA638 ) ]  
S29AL008DMFI01@PSOP44 [ ( SA638 ) ] S29AL008DMFI02@PSOP44  
[ ( SA638 ) ]  
S29AL008DMFN01@PSOP44 [ ( SA638 ) ] S29AL008DMFN02@PSOP44  
[ ( SA638 ) ]  
S29AL008DMFNR1@PSOP44 [ ( SA638 ) ] S29AL008DMFNR2@PSOP44  
[ ( SA638 ) ]  
S29AL008DTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTAN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTAN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTANR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTANR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFNR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFNR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DBAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBAN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBAN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBFN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBFN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DMAI01@PSOP44 [ ( SA638 ) ] S29AL016DMAI02@PSOP44  
[ ( SA638 ) ]  
S29AL016DMAN01@PSOP44 [ ( SA638 ) ] S29AL016DMAN02@PSOP44  
[ ( SA638 ) ]  
S29AL016DMFI01@PSOP44 [ ( SA638 ) ] S29AL016DMFI02@PSOP44  
[ ( SA638 ) ]  
S29AL016DMFN01@PSOP44 [ ( SA638 ) ] S29AL016DMFN02@PSOP44

[ ( SA638 ) ]

S29AL016DTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTAN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTAN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTFN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTFN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MBAI01@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBAI02@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBAIR1@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBAIR2@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBFI01@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBFI02@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBFIR1@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBFIR2@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MFAI01@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFAI02@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFAIR1@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFAIR2@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFFI01@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFFI02@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFFIR1@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFFIR2@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTAIR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTAIR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTFIR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTFIR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL032DBAI00@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DBAI03@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DBAI04@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DBFI00@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DBFI03@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DBFI04@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DTAI00@TSOP40 [ ( SA409T ) ]  
S29AL032DTAI03@TSOP48 [ ( SA247-B005 ) ]  
S29AL032DTAI04@TSOP48 [ ( SA247-B005 ) ]  
S29AL032DTFI00@TSOP40 [ ( SA409T ) ]

S29AL032DTFI03@TSOP48 [ ( SA247-B005 ) ]  
S29AL032DTFI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ABAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAI03@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAI04@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAIR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAIR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAIR3@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAIR4@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAIW1@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S29GL016ABAIW2@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S29GL016ABFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFI03@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFI04@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFIR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFIR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFIR3@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFIR4@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFIW1@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S29GL016ABFIW2@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S29GL016AFAI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFAI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFAIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFAIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFAIR3@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFAIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFIR3@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016ATAI01@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAI02@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAIR1@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAIR2@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATFI01@TSOP48 [ ( SA247-B005 ) ]

S29GL016ATFI02@TSOP48 [ (SA247-B005) ]  
S29GL016ATFI03@TSOP48 [ (SA247-B005) ]  
S29GL016ATFI04@TSOP48 [ (SA247-B005) ]  
S29GL016ATFIR1@TSOP48 [ (SA247-B005) ]  
S29GL016ATFIR2@TSOP48 [ (SA247-B005) ]  
S29GL016ATFIR3@TSOP48 [ (SA247-B005) ]  
S29GL016ATFIR4@TSOP48 [ (SA247-B005) ]  
S29GL032ABAIR3@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
S29GL032ABAIR4(Normal)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
S29GL032ABAIR4@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
S29GL032ABAIW3@FBGA56 [ (SA642P-B032A-W056F001Y) ]  
S29GL032ABAIW4@FBGA56 [ (SA642P-B032A-W056F001Y) ]  
S29GL032ABFIR3@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
S29GL032ABFIR4@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
S29GL032ABFIW3@FBGA56 [ (SA642P-B032A-W056F001Y) ]  
S29GL032ABFIW4@FBGA56 [ (SA642P-B032A-W056F001Y) ]  
S29GL032AFAIR1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFAIR2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFAIR3@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFAIR4@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFAIS1(29LV320MT)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFAIS2(29LV320MB)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFAIS3(29LV320MT)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
S29GL032AFAIS4(29LV320MB)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
S29GL032AFFIR1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFFIR2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFFIR3@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFFIR4@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFFIS1(29LV320MT)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFFIS2(29LV320MB)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFFIS3(29LV320MT)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
S29GL032AFFIS4(29LV320MB)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
S29GL032ATAIR1@TSOP56 [ (SA628-B102) ]  
S29GL032ATAIR2@TSOP56 [ (SA628-B102) ]  
S29GL032ATAIR3@TSOP48 [ (SA247-B005) ]  
S29GL032ATAIR4@TSOP48 [ (SA247-B005) ]  
S29GL032ATFIR1@TSOP56 [ (SA628-B102) ]  
S29GL032ATFIR2@TSOP56 [ (SA628-B102) ]  
S29GL032ATFIR3@TSOP48 [ (SA247-B005) ]  
S29GL032ATFIR4(Normal)@TSOP48 [ (SA247-B005) ]  
S29GL032ATFIR4@TSOP48 [ (SA247-B005) ]  
S29GL032MBACR0(Mirror)@FBGA48 [ (SA642AA-B026A-W064F001N) ]  
S29GL032MBACR0@FBGA48 [ (SA642AA-B026A-W064F001N) ]

S29GL032MBACR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBACR3@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBACR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBACR4@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBAIR0@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBAIR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR3@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR4@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR5@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBAIR6@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFCR0@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFCR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR3@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR4@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFIR0@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFIR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR3@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR4@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR5@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR6@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MFACR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFACS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFACS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFACS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFAIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]



S29GL032MFAIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFAIS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFAIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFAIS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFCR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFCS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFCS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFCS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFIS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFIS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MTACR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTACR0@TSOP40 [(SA409T)]  
S29GL032MTACR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTACR1@TSOP56 [(SA628-B067)]  
S29GL032MTACR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTACR2@TSOP56 [(SA628-B067)]  
S29GL032MTACR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTACR3@TSOP48 [(SA247-B005)]  
S29GL032MTACR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTACR4@TSOP48 [(SA247-B005)]  
S29GL032MTAIR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTAIR0@TSOP40 [(SA409T)]

S29GL032MTAIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTAIR1@TSOP56 [(SA628-B067)]  
S29GL032MTAIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTAIR2@TSOP56 [(SA628-B067)]  
S29GL032MTAIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTAIR3@TSOP48 [(SA247-B005)]  
S29GL032MTAIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTAIR4@TSOP48 [(SA247-B005)]  
S29GL032MTFCR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTFCR0@TSOP40 [(SA409T)]  
S29GL032MTFCR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFCR1@TSOP56 [(SA628-B067)]  
S29GL032MTFCR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFCR2@TSOP56 [(SA628-B067)]  
S29GL032MTFCR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFCR3@TSOP48 [(SA247-B005)]  
S29GL032MTFCR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFCR4@TSOP48 [(SA247-B005)]  
S29GL032MTFIR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTFIR0@TSOP40 [(SA409T)]  
S29GL032MTFIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFIR1@TSOP56 [(SA628-B067)]  
S29GL032MTFIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFIR2@TSOP56 [(SA628-B067)]  
S29GL032MTFIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFIR3@TSOP48 [(SA247-B005)]  
S29GL032MTFIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFIR4@TSOP48 [(SA247-B005)]  
S29GL032NBAI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBAI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFIO3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFIO4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAI03@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAI04@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]

S29GL032NFAIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFAIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFAIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFAIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL032NFAIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL032NFAIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFAIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFI03@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFI04@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIR3@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL032NFFIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL032NFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTAI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTAI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTAI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTAIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTAIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTAIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTAIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTFI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTFIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTFIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTFIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL064ABAIR3@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
S29GL064ABAIR4@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]

S29GL064ABAIR5@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
S29GL064ABFIR3@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
S29GL064ABFIR4@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
S29GL064ABFIR5@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
S29GL064AFAIR1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFAIR2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFAIR3@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFAIR4@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFAIR5@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFAIS1 (29LV640MT)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFAIS2 (29LV640MB)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFAIS3 (29LV640MT)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
S29GL064AFAIS4 (29LV640MB)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
S29GL064AFFIR1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFFIR2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFFIR3@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFFIR4@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFFIR5@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFFIS1 (29LV640MT)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFFIS2 (29LV640MB)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFFIS3 (29LV640MT)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
S29GL064AFFIS4 (29LV640MB)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
S29GL064ATAIR1@TSOP56 [ (SA628-B102) ]  
S29GL064ATAIR2@TSOP56 [ (SA628-B102) ]  
S29GL064ATAIR3@TSOP48 [ (SA247-B005) ]  
S29GL064ATAIR4@TSOP48 [ (SA247-B005) ]  
S29GL064ATAIR6@TSOP48 [ (SA247-B005) ]  
S29GL064ATAIR7@TSOP48 [ (SA247-B005) ]  
S29GL064ATAIR8@TSOP48 [ (SA247-B005) ]  
S29GL064ATAIR9@TSOP48 [ (SA247-B005) ]  
S29GL064ATFIR1@TSOP56 [ (SA628-B102) ]  
S29GL064ATFIR2@TSOP56 [ (SA628-B102) ]  
S29GL064ATFIR3@TSOP48 [ (SA247-B005) ]  
S29GL064ATFIR4@TSOP48 [ (SA247-B005) ]  
S29GL064ATFIR6@TSOP48 [ (SA247-B005) ]  
S29GL064ATFIR7@TSOP48 [ (SA247-B005) ]  
S29GL064ATFIR8@TSOP48 [ (SA247-B005) ]  
S29GL064ATFIR9@TSOP48 [ (SA247-B005) ]  
S29GL064MBAIR0 (Mirror)@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBAIR0@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBAIR3 (Mirror)@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBAIR3@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBAIR4 (Mirror)@FBGA63 [ (SA642M-B026A-W048F001Y) ]

S29GL064MBAIR4@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBAIR5(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBAIR5@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR0(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR0@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR3(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR3@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR4(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR4@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR5(Mirror)@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MBFIR5@FBGA63 [(SA642M-B026A-W048F001Y)]  
S29GL064MFAIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR5(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR5@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIS1(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFAIS2(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFAIS3(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MFAIS4(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MFFIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR5(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR5@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIS1(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFFIS2(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFFIS2(Normal)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFFIS3(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MFFIS4(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MTAIR0(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR0@TSOP48 [(SA247-B005)]  
S29GL064MTAIR1(Mirror)@TSOP56 [(SA628-B067)]

S29GL064MTAIR1@TSOP56 [(SA628-B067)]  
S29GL064MTAIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL064MTAIR2@TSOP56 [(SA628-B067)]  
S29GL064MTAIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR3@TSOP48 [(SA247-B005)]  
S29GL064MTAIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR4@TSOP48 [(SA247-B005)]  
S29GL064MTAIR6(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR6@TSOP48 [(SA247-B005)]  
S29GL064MTAIR7(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR7@TSOP48 [(SA247-B005)]  
S29GL064MTFIR0(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR0@TSOP48 [(SA247-B005)]  
S29GL064MTFIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL064MTFIR1@TSOP56 [(SA628-B067)]  
S29GL064MTFIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL064MTFIR2@TSOP56 [(SA628-B067)]  
S29GL064MTFIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR3@TSOP48 [(SA247-B005)]  
S29GL064MTFIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR4@TSOP48 [(SA247-B005)]  
S29GL064MTFIR6(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR6@TSOP48 [(SA247-B005)]  
S29GL064MTFIR7(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR7@TSOP48 [(SA247-B005)]  
S29GL064NBAI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBAI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIO3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIO4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAI03@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAI04@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]

S29GL064NFAIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL064NFAIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL064NFAIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFAIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFI03@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFI04@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIR3@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL064NFFIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL064NFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAI06@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAI07@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIR6@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIR7@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAIV6@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIV7@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTFI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTFI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI04 ( Low )@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI06@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI07@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTFIR2@TSOP56 [ ( SA628-B102 ) ]

S29GL064NTFIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFIR6@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFIR7@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTFIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTFIV6@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFIV7@TSOP48 [ ( SA247-B005 ) ]  
S29GL128MFAIR1@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29GL128MFAIR2@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29GL128MFFIR1@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29GL128MFFIR2@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29GL128MTAIR1@TSOP56 [ ( SA628-B067 ) ]  
S29GL128MTAIR2@TSOP56 [ ( SA628-B067 ) ]  
S29GL128MTFIR1@TSOP56 [ ( SA628-B067 ) ]  
S29GL128MTFIR2@TSOP56 [ ( SA628-B067 ) ]  
S29GL128NFAI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIIH@FBGA64 [ ( SA655E-B129A-T056F001Y ) ]  
S29GL128NFAIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128NFAIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128NFAIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAW01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAW02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAWIH@FBGA64 [ ( SA655E-B129A-T056F001Y ) ]  
S29GL128NFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIIH@FBGA64 [ ( SA655E-B129A-T056F001Y ) ]  
S29GL128NFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128NFFIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128NFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFW01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFW02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]



S29GL128NTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAW01@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAW02@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFW01@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFW02@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PFAI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFAI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFAIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFAIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFAIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFAIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFAIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128PFAIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128PFAIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFAIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFFIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFFIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128PFFIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128PFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128PTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTAI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTAIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTAIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL128PTFI01@TSOP56 [ ( SA628-B102 ) ]

S29GL128PTFI02@TSOP56 [ (SA628-B102) ]  
S29GL128PTFIR1@TSOP56 [ (SA628-B102) ]  
S29GL128PTFIR2@TSOP56 [ (SA628-B102) ]  
S29GL128PTFIV1@TSOP56 [ (SA628-B102) ]  
S29GL128PTFIV2@TSOP56 [ (SA628-B102) ]  
S29GL256MR1@FBGA64 [ (SA655C-B099A-W064F001Y) ]  
S29GL256MR1@TSOP56 [ (SA628-B067) ]  
S29GL256MR2@FBGA64 [ (SA655C-B099A-W064F001Y) ]  
S29GL256MR2@TSOP56 [ (SA628-B067) ]  
S29GL256NFAI01@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL256NFAI02@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL256NFAIIH@FBGA64 [ (SA655E-B129A-T056F001Y) ]  
S29GL256NFAIR1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL256NFAIR2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL256NFAIS1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL256NFAIS2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL256NFAIS3@FBGA64 [ (SA655E-B129A-T064F001Y) ]  
S29GL256NFAIS4@FBGA64 [ (SA655E-B129A-T064F001Y) ]  
S29GL256NFAIV1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL256NFAIV2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL256NFFI01@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL256NFFI02@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL256NFFIIH@FBGA64 [ (SA655E-B129A-T056F001Y) ]  
S29GL256NFFIR1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL256NFFIR2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL256NFFIS1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL256NFFIS2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL256NFFIS3@FBGA64 [ (SA655E-B129A-T064F001Y) ]  
S29GL256NFFIS4@FBGA64 [ (SA655E-B129A-T064F001Y) ]  
S29GL256NFFIV1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL256NFFIV2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL256NTAI01@TSOP56 [ (SA628-B102) ]  
S29GL256NTAI02@TSOP56 [ (SA628-B102) ]  
S29GL256NTAIR1@TSOP56 [ (SA628-B102) ]  
S29GL256NTAIR2@TSOP56 [ (SA628-B102) ]  
S29GL256NTAIV1@TSOP56 [ (SA628-B102) ]  
S29GL256NTAIV2@TSOP56 [ (SA628-B102) ]  
S29GL256NTFI01@TSOP56 [ (SA628-B102) ]  
S29GL256NTFI02@TSOP56 [ (SA628-B102) ]  
S29GL256NTFIR1@TSOP56 [ (SA628-B102) ]  
S29GL256NTFIR2@TSOP56 [ (SA628-B102) ]  
S29GL256NTFIV1@TSOP56 [ (SA628-B102) ]  
S29GL256NTFIV2@TSOP56 [ (SA628-B102) ]

S29GL256PFAI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFAI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFAIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFAIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFAIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFAIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFAIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL256PFAIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL256PFAIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFAIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL256PFFIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL256PFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTAI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTAIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTAIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NFA01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFA02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFAIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFAIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFAV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFAV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFF01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFF02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFFIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFFV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]

S29GL512NFFV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NTA01@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTA02@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTAV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTAV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTF01@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTF02@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTFV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTFV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PFAI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFAI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFAIR1@FBGA64 [ ( SA655F-B287A-W064F001Y ) ]  
S29GL512PFAIR2@FBGA64 [ ( SA655F-B287A-W064F001Y ) ]  
S29GL512PFAIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFAIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFFIR1@FBGA64 [ ( SA655F-B287A-W064F001Y ) ]  
S29GL512PFFIR2@FBGA64 [ ( SA655F-B287A-W064F001Y ) ]  
S29GL512PFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFFIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTAI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTAIR1@TSOP56 [ ( SA628-B257 ) ]  
S29GL512PTAIR2@TSOP56 [ ( SA628-B257 ) ]  
S29GL512PTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTFI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTFI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTFIR1@TSOP56 [ ( SA628-B257 ) ]  
S29GL512PTFIR2@TSOP56 [ ( SA628-B257 ) ]  
S29GL512PTFIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTFIV2@TSOP56 [ ( SA628-B102 ) ]  
S29JL032HBAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI21@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI22@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI31@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI32@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI41@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI42@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]

S29JL032HBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI21@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI22@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI31@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI32@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI41@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI42@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI21@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI22@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI31@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI32@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI41@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI42@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI21@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI22@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI31@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI32@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI41@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI42@TSOP48 [ ( SA247-B005 ) ]  
S29JL064HBAI00@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
S29JL064HBFI00@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
S29JL064HTAI00@TSOP48 [ ( SA247-B005 ) ]  
S29JL064HTAN00@TSOP48 [ ( SA247-B005 ) ]  
S29JL064HTFI00@TSOP48 [ ( SA247-B005 ) ]  
S29JL064HTFN00@TSOP48 [ ( SA247-B005 ) ]  
S29NS016J0LBFW00@FBGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29NS016J0LBJW00@FBGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29NS016J0PBFW00@FBGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29NS016J0PBJW00@FBGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29NS032J0LBFW00@FBGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29NS032J0LBJW00@FBGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29NS032J0PBFW00@FBGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29NS032J0PBJW00@FBGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29NS064J0LBAW00@FBGA44 [ ( SA733A-B206A-M056F001Y ) ]  
S29NS064J0LBFW00@FBGA44 [ ( SA733A-B206A-M056F001Y ) ]  
S29NS064J0LBJW00@FBGA44 [ ( SA733A-B206A-M056F001Y ) ]  
S29NS064J0PBAW00@FBGA44 [ ( SA733A-B206A-M056F001Y ) ]  
S29NS064J0PBFW00@FBGA44 [ ( SA733A-B206A-M056F001Y ) ]

S29NS064J0PBJW00@FBGA44 [ ( SA733A-B206A-M056F001Y ) ]  
S29NS128J0LBAW00@FBGA48 [ ( SA733A-B206A-M056F001N ) ]  
S29NS128J0LBFW00@FBGA48 [ ( SA733A-B206A-M056F001N ) ]  
S29NS128J0LBJW00@FBGA48 [ ( SA733A-B206A-M056F001N ) ]  
S29NS128J0PBAW00@FBGA48 [ ( SA733A-B206A-M056F001N ) ]  
S29NS128J0PBFW00@FBGA48 [ ( SA733A-B206A-M056F001N ) ]  
S29NS128J0PBJW00@FBGA48 [ ( SA733A-B206A-M056F001N ) ]  
S29PL127J55TAI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J55TAW13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J55TFI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J55TFW13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J60TAI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J60TAW13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J60TFI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J60TFW13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J70TAI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J70TAW13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J70TFI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J70TFW13@TSOP56 [ ( SA628-B097 ) ]  
S29VS016K0PBJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS016K0PBJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS016KAABJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS016KAABJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS032K0PBJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS032K0PBJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS032KAABJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS032KAABJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS064K0PBJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS064K0PBJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS064KAABJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS064KAABJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29WS064J0PBAI00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAI01@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAI02@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAI03@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAW00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAW01@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAW02@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAW03@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBFI00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBFI01@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBFW00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBFW01@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]

S29WS064J0SBAI00@FBGA80 [ ( SA642T-B093A-W080F001Y) ]  
S29WS064J0SBAI01@FBGA80 [ ( SA642T-B093A-W080F001Y) ]  
S29WS064J0SBAI02@FBGA80 [ ( SA642T-B093A-W080F001Y) ]  
S29WS064J0SBAI03@FBGA80 [ ( SA642T-B093A-W080F001Y) ]  
S29WS064J0SBAW00@FBGA80 [ ( SA642T-B093A-W080F001Y) ]  
S29WS064J0SBAW01@FBGA80 [ ( SA642T-B093A-W080F001Y) ]  
S29WS064J0SBAW02@FBGA80 [ ( SA642T-B093A-W080F001Y) ]  
S29WS064J0SBAW03@FBGA80 [ ( SA642T-B093A-W080F001Y) ]  
S29WS064J0SBFI00@FBGA80 [ ( SA642T-B093A-W080F001Y) ]  
S29WS064J0SBFI01@FBGA80 [ ( SA642T-B093A-W080F001Y) ]  
S29WS064J0SBFW00@FBGA80 [ ( SA642T-B093A-W080F001Y) ]  
S29WS064J0SBFW01@FBGA80 [ ( SA642T-B093A-W080F001Y) ]  
S29WS064J1ABAI00@FBGA80 [ ( SA642T-B093A-W080F001Y) ]  
S29WS064J1ABAI01@FBGA80 [ ( SA642T-B093A-W080F001Y) ]  
S29WS064J1ABAW00@FBGA80 [ ( SA642T-B093A-W080F001Y) ]  
S29WS064J1ABAW01@FBGA80 [ ( SA642T-B093A-W080F001Y) ]  
S29WS128J0PBAI00@FBGA80 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBAI01@FBGA80 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBAI02@FBGA80 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBAI03@FBGA80 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBAI10@FBGA84 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBAI11@FBGA84 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBAW00@FBGA80 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBAW01@FBGA80 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBAW02@FBGA80 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBAW03@FBGA80 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBAW10@FBGA84 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBAW11@FBGA84 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBFI00@FBGA84 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBFI01@FBGA84 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBFI10@FBGA84 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBFI11@FBGA84 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBFW00@FBGA84 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBFW10@FBGA84 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0PBFW11@FBGA84 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0SBAI00@FBGA80 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0SBAI01@FBGA80 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0SBAI02@FBGA80 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0SBAI03@FBGA80 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0SBAW00@FBGA80 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0SBAW01@FBGA80 [ ( SA642A-B093A-Y096F001Y) ]  
S29WS128J0SBAW02@FBGA80 [ ( SA642A-B093A-Y096F001Y) ]

S29WS128J0SBAW03@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBF100@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBF101@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBFW00@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J1ABAI00@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J1ABAI01@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J1ABAW00@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J1ABAW01@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0LBAW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0LBAW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0LBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0LBFW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0PBAW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0PBAW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0PBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0PBFW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0LBAW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0LBAW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0LBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0LBFW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0PBAW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0PBAW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0PBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0PBFW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0SBAW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0SBAW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0SBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0SBFW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S30ML01GP30TFE00@TSOP48 [ ( SA247-B005 ) ]  
S30ML01GP30TFE50@TSOP48 [ ( SA247-B005 ) ]  
S30ML01GP50TFE01@TSOP48 [ ( SA247-B005 ) ]  
S30ML01GP50TFE51@TSOP48 [ ( SA247-B005 ) ]  
S30ML02GP30TFE00@TSOP48 [ ( SA247-B005 ) ]  
S30ML02GP30TFE50@TSOP48 [ ( SA247-B005 ) ]  
S30ML02GP50TFE01@TSOP48 [ ( SA247-B005 ) ]  
S30ML02GP50TFE51@TSOP48 [ ( SA247-B005 ) ]  
S30ML128P30TFE00@TSOP48 [ ( SA247-B005 ) ]  
S30ML128P30TFE50@TSOP48 [ ( SA247-B005 ) ]  
S30ML128P50TFE01@TSOP48 [ ( SA247+B005 ) ]  
S30ML128P50TFE51@TSOP48 [ ( SA247+B005 ) ]  
S30ML256P30TFE00@TSOP48 [ ( SA247-B005 ) ]  
S30ML256P30TFE50@TSOP48 [ ( SA247-B005 ) ]



S30ML256P50TFE01@TSOP48 [ ( SA247+B005 ) ]  
S30ML256P50TFE51@TSOP48 [ ( SA247+B005 ) ]  
S30ML512P50TFE01@TSOP48 [ ( SA247+B005 ) ]  
S30ML512P50TFE51@TSOP48 [ ( SA247+B005 ) ]  
S30MS01GP25TFW00@TSOP48 [ ( SA247-B005 ) ]  
S30MS01GP25TFW010@TSOP48 [ ( SA247-B005 ) ]  
S30MS01GP25TFW50@TSOP48 [ ( SA247-B005 ) ]  
S30MS01GP25TFW510@TSOP48 [ ( SA247-B005 ) ]  
S70PL254J00BAW91@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BAW93@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BAWA1@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BAWA3@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BFW91@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BFW93@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BFWA1@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BFWA3@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL512N00HAW53@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S70PL512N00HFW53@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71AL016D02BAWB@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D02BAWT@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D02BFWB@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D02BFWT@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D04BAWB@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D04BAWT@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D04BFWB@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D04BFWT@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71GL016A40BAW1J@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL016A40BAW3J@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL016A40BFW1J@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL016A40BFW3J@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A08BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A08BAW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A08BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A08BFW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A40BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A40BAW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A40BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A40BFW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A80BAW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A80BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A80BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A80BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032AA0BAW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]

S71GL032AA0BAW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL032AA0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL032AA0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL032M40BAIBQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAIFQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAIKQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAIPQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAWBQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAWFQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAWKQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAWPQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFIBQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFIFQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFIKQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFIPQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFWBQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFWFQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFWKQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFWPQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032N40BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL032N40BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL032N80BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL032N80BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL032NA0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL032NA0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A08BAI0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A08BAI0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A08BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A08BAW0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A08BFI0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A08BFI0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A08BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A08BFW0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A0ABAI0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A0ABAI0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A0ABAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A0ABAW0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A0ABFI0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A0ABFI0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A0ABFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A0ABFW0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A80BAI0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71GL064A80BAI0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]

S71GL064A80BAW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BFI0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BFI0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAI0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAI0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAI0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAI0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFI0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFI0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFI0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFI0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NA0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NA0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NB0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NB0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL128NB0BAEAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAEAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAEAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAEAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAW9J@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9K@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9N@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9T@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9Y@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAWAJ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAK@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAN@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAP@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]

S71GL128NB0BAWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWEJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFEBT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFEAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFEBY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFEBZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFW9J@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9K@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9N@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9T@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9Y@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFWAJ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAK@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAN@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAP@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWEJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFWEK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFWEN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFWEP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFWET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFWEU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFWFY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFWFZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NC0BAEAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAEAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAEAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]

S71GL128NC0BAWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAZAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFEAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFEAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFEAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFEAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAJ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAK@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAN@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAP@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWEJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFWAJ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAK@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAN@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAP@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFW EJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW EK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW EN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW EP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW ET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW EU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW EY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]

S71GL256NB0BFWEZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NC0BAEAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAEAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAEAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAEAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BFEAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BFEAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BFEAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BFEAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BFWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BFWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BFWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BFWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL512NB0BAWEJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFWEJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFWEK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFWEN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFWEP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFWET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFWEU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFW EY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFWEZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71JL064H80BAW01 (DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW02 (DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW03 (DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW04 (DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW10 (DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW11 (DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW12 (DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HA0BAW01 (DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HA0BAW02 (DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HA0BAW10 (DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]

S71JL064HA0BAW11(DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HA0BAW12(DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HB0BAW00(DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HB0BAW01(DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL064HB0BAW02(DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
S71JL128HB0BAW00(DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
S71JL128HB0BAW01(DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
S71JL128HB0BAW02(DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
S71JL128HB0BAW03(DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
S71JL128HC0BAW00(DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]  
S71JL128HC0BAW01(DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]  
S71JL128HC0BAW02(DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]  
S71JL128HC0BAW03(DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]  
S71NS032J80BJWRA@FBGA56 [(SA733A-B212A-M056F001Y)]  
S71NS032JA0BJWRT@FBGA56 [(SA733A-B212A-M056F001Y)]  
S71NS064JA0BAW01@FBGA44 [(SA733A-B206A-M056F001Y)]  
S71NS064JA0BAW11@FBGA44 [(SA733A-B206A-M056F001Y)]  
S71NS064JA0BAW21@FBGA44 [(SA733A-B206A-M056F001Y)]  
S71NS064JA0BFW01@FBGA44 [(SA733A-B206A-M056F001Y)]  
S71NS064JA0BFW11@FBGA44 [(SA733A-B206A-M056F001Y)]  
S71NS064JA0BFW21@FBGA44 [(SA733A-B212A-M056F001Y)]  
S71NS064JA0BJWRN@FBGA56 [(SA733A-B206A-M056F001Y)]  
S71NS128JA0BAW01@FBGA48 [(SA733A-B206A-M056F001N)]  
S71NS128JA0BAW11@FBGA48 [(SA733A-B206A-M056F001N)]  
S71NS128JA0BAW21@FBGA48 [(SA733A-B206A-M056F001N)]  
S71NS128JA0BFW01@FBGA48 [(SA733A-B206A-M056F001N)]  
S71NS128JA0BFW11@FBGA48 [(SA733A-B206A-M056F001N)]  
S71NS128JA0BFW21@FBGA48 [(SA733A-B206A-M056F001N)]  
S71PL032J04BAI0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BAI0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BFI0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BFI0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BAE0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]

S71PL032J08BFW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J08BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J40BAI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J40BAW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J40BAW0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J40BFI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J40BFW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J40BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BAI05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BAI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BAW05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BAW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BAWQ7@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BAWQF@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BFI05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BFI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BFW05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BFW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BFWQ7@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BFWQF@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BAE07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BAE0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BAI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BAI0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BAW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BAW0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BAW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BAWQF@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BFI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BFI0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BFW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BFW0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BFWQF@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BAI0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BAI0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BAI0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BAI0U@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BAW0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]



S71PL064J08BAW0U@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BFI0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BFI0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BFI0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BFI0U@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J0ABAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J0ABAW0S@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J0ABFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J0ABFW0S@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BAI05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BAI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BAI0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BAW05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BAW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BAW0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BFI05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BFI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BFI0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BFW05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BFW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAI05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAI0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAI0Z@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAW05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BFI05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BFI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BFI0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BFI0Z@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BFW05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BFW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]

S71PL064JA0BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JA0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BAI07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BAI0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BAIQB@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BAW07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BAW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BAWQB@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BFI07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BFI0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BFIQB@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BFW07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BFWQB@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JA0BAI9P@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JA0BAI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JA0BAW9P@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JA0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JA0BFI9P@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JA0BFI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JA0BFW9P@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JA0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BAI97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BAI9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BAI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BAIQB@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127JB0BAW97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BAW9B@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BAW9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BAWQB@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127JB0BFI97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BFI9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BFI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BFIQB@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127JB0BFW97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BFW9B@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BFW9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BFWQB@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127JC0BAI97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]

S71PL127JC0BAI9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BAI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BAW97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JC0BAW9B@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JC0BAW9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BFI97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JC0BFI9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BFI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BFW97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JC0BFW9B@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JC0BFW9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127NB0HAW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NB0HAW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NB0HFW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NB0HFW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NC0HAW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NC0HAW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NC0HFW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NC0HFW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JA0BAW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JA0BFW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BAW9B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BAW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BAW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BFW9B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BFW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BFW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BAW9B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BAW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BFW9B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BFW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NB0HAW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NB0HAW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NB0HFW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NB0HFW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NC0HAW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NC0HAW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]

S71PL129NC0HFW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NC0HFW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL191HB0BAI10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HB0BAW10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HB0BFI10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HB0BFW10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HC0BAI10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HC0BAW10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HC0BFI10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HC0BFW10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL193HB0BAI10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HB0BAW10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HB0BFI10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HB0BFW10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HC0BAI10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HC0BAW10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HC0BFI10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HC0BFW10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL254HC0BAW00@FBGA84 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL254JB0BAIT7@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BAITU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BAWT7@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BAWTU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BFIT7@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BFITU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BFWT7@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BFWTU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BAITU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BAITZ@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BAWTU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BAWTZ@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BFITU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BFITZ@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BFWTU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BFWTZ@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JD0BAWTB@FBGA84 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL254JD0BFWTB@FBGA84 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL256NC0HAW5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256NC0HAW5U@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256NC0HFW5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256NC0HFW5U@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256ND0GAW5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256ND0GF5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]

S71PL256ND0HAW5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256ND0HFW5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL258HC0BAW00@FBGA84 [ ( SA642A-B088A-Y096N001 ) ]  
S71PL512ND0JAW5B@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71PL512ND0JFW5B@FBGA84 [ ( SA642A-B158A-Y096F001Y ) ]  
S71VS032K80ZJK01@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032K80ZJK03@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032KA0ZJK09@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032KA0ZJK0B@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032KA0ZJK11@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032KA0ZJK13@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032KA0ZJK19@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032KA0ZJK1B@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK01@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK03@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK09@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK0B@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK11@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK13@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK19@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK1B@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71WS064JA0BAI2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JA0BAI2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JA0BAW2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JA0BAW2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JA0BFI2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JA0BFI2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JA0BFW2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JA0BFW2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JB0BAI2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JB0BAI2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JB0BAW2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JB0BAW2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JB0BFI2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JB0BFI2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JB0BFW2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JB0BFW2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS128JA0BAIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JA0BAIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JA0BAWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JA0BAWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JA0BFIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JA0BFIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]

S71WS128JA0BFWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JA0BFWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JB0BAIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JB0BAIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JB0BAIAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JB0BAWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JB0BAWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JB0BAWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JB0BFIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JB0BFIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JB0BFIAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JB0BFWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JB0BFWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JB0BFWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JC0BAE9A@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BAIA6@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BAIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BAIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JC0BAIAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JC0BAWA6@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BAWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BAWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JC0BAWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JC0BFE9A@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BFIA6@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BFIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BFIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JC0BFIAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JC0BFWA6@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BFWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BFWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JC0BFWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128NB0BAWAH@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BAWAJ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BAWAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BAWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BAWAN@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BAWAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BFWAH@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BFWAJ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BFWAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BFWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BFWAN@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]

S71WS128NB0BFWAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAH@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAJ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAN@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BFWAH@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BFWAJ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BFWAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BFWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BFWAN@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BFWAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256JC0BAIA6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAIAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BAIT6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAITJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAITY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BAWA6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BAWT6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAWTJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAWTY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BFIA6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFIAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BFIT6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFITJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFITY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BFWA6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BFWT6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFWTJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFWTY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256NC0BAIAB@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAIAF@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAIAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAIAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAIAU@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAIAZ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]

S71WS256NC0BAWA2@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWA3@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWA6@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWA7@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAA@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAB@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAE@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAF@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAH@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAJ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAN@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAU@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAZ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFIAB@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFIAF@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFIAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFIAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFIAU@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFIAZ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWA2@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWA3@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWA6@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWA7@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAA@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAB@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAE@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAF@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAH@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAJ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAN@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAU@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAZ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256ND0BAIE3@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAIE7@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAIEK@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAIEP@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAIEU@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]



S71WS256ND0BAIEZ@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWE3@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWE7@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWEK@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWEP@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWEU@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWEZ@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWYH@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWYJ@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWYK@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWYM@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWYN@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWYP@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFIE3@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFIE7@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFIEK@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFIEP@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFIEU@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFIEZ@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWE3@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWE7@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWEK@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWEP@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWEU@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWEZ@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYH@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYJ@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYK@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYM@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYN@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYP@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS512NC0BAIAB@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAIAF@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAIAK@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAIAP@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAIAU@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAIAZ@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAB@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAF@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAK@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAP@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAU@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAZ@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]

S71WS512NC0BAWTA@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAWTE@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAWTH@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAWTJ@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAWTM@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BAWTN@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFIAB@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFIAF@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFIAK@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFIAP@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFIAU@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFIAZ@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWAB@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWAF@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWAK@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWAP@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWAU@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWAZ@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWTA@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWTE@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWTH@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWTJ@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWTM@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512NC0BFWTN@FBGA88 [(SA642A-B139A-Y096F001Y)]  
S71WS512ND0BAIE3@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAIE7@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAIEK@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAIEP@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWE2@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWE3@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWE6@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWE7@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEH@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEJ@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEK@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEM@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEN@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BAWEP@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFIE3@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFIE7@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFIEK@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFIEP@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWWE2@FBGA88 [(SA642CC-B139A-W080F001Y)]

S71WS512ND0BFWE3@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWE6@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWE7@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEH@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEJ@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEK@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEM@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEN@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S71WS512ND0BFWEP@FBGA88 [(SA642CC-B139A-W080F001Y)]  
S75PL127JBDBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBDBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBDBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBDBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCDBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCDBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCDBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCDBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCEBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCEBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCEBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCEBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S98NS032JA0FW001@FBGA88 [(SA642A-B180A-Y096F001Y)]  
S98PL191JD0AQ001@FBGA115 [(SA664A-B160A-W115F001Y)]  
S98PL191JD0FQ001@FBGA115 [(SA664A-B160A-W115F001Y)]  
S98PL191JDFAQ001(Nor)@FBGA115 [(SA664A-B160A-W115F001Y)]  
S98PL191JDFFQ001(Nor)@FBGA115 [(SA664A-B160A-W115F001Y)]  
S98WS128NB0-001@FBGA88 [(SA642A-B124A-Y096F001Y)]  
S98WS256NEFFW001(Nor)@FBGA115 [(SA642A-B139A-Y096N001N)]  
S98WS512N0GFW002(Nor)@FBGA115 [(SA664J-B165A-M116F001Y)]  
S98WS512N0GFW003(Nor)@FBGA115 [(SA664J-B165A-M116F001Y)]  
S99-50001(S29WS256N)@FBGA88 [(SA642A-B094A-Y096F001Y)]  
S99-50003(S29WS256N)@FBGA88 [(SA642A-B094A-Y096F001Y)]  
S99-50005(2\*S29WS128H)@FBGA88 [(SA642A-B123A-Y096F001Y)]  
S99-50011(2\*S29WS256N)@FBGA103 [(SA664H-B157A-W115F001N)]  
S99-50019(S29GL128N)@FBGA88 [(SA642W-B199A-W088F001Y)]  
S99-50031(AM29BDS320)@FBGA56 [(SA644B-B025B-Y056F001Y)]  
S99-50034-9N(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]  
S99-50034-9P(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]  
S99-50034-9Y(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]

S99-50034-9Z(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)] ]  
S99-50048(S29GL064N)@FBGA64 [(SA655E-B129A-T056F001Y)] ]  
S99-50052(S29GL128N)@FBGA64 [(SA655E-B129A-T056F001Y)] ]  
S99-50057(S29GL032A)@FBGA88 [(SA642W-B116A-W088F001Y)] ]  
S99-50059(S29GL064A)@FBGA88 [(SA642A-B116A-Y096N001N)] ]  
S99-50063(High)@FBGA137 [(SA678A-B151A-Y129F001Y)] ]  
S99-50063(Low)@FBGA137 [(SA678A-B150A-Y129F001Y)] ]  
S99-50066(S29GL032M)@FBGA88 [(SA642A-B116A-Y096N001N)] ]  
S99-50073(S29WS256N)@FBGA88 [(SA642A-B124A-Y096F001Y)] ]  
S99-50074(2\*S29WS128J)@FBGA88 [(SA642A-B121A-Y096F001Y)] ]  
S99-50076(S29WS256N)@FBGA103 [(SA664H-B157A-W115F001N)] ]  
S99-50080(S71PL064JB0)@FBGA56 [(SA642P-B079A-W056F001Y)] ]  
S99-50080-LF(S71PL064JB0)@FBGA56 [(SA642P-B079A-W056F001Y)] ]  
S99-50085(S29WS256N)@FBGA88 [(SA642A-B112A-Y096F001Y)] ]  
S99-50087(S29WS128J)@FBGA88 [(SA642A-B154A-Y096F001Y)] ]  
S99-50089(2\*S29WS128J)@FBGA88 [(SA642A-B121A-Y096F001Y)] ]  
S99-50109(2\*S29WS256N)@FBGA88 [(SA642A-B138A-Y096F001Y)] ]  
S99-50111(S29AL016DFFI02)@FBGA64 [(SA655F-B099A-W064F001Y)] ]  
S99-50121-9Y@FBGA64 [(SA642A-B039A-Y096F001Y)] ]  
S99-50121-9Y-LF@FBGA64 [(SA642A-B039A-Y096F001Y)] ]  
S99-50121-9Z@FBGA64 [(SA642A-B039A-Y096F001Y)] ]  
S99-50121-9Z-LF@FBGA64 [(SA642A-B039A-Y096F001Y)] ]  
S99-50134(S29GL128N)@FBGA88 [(SA642R-B199A-T096F001Y)] ]  
S99-50149-0(Nand)@FBGA107 [(SA664A-B128A-W115F001Y)] ]  
S99-50149-0(Nor)@FBGA107 [(SA664A-B127A-W115F001Y)] ]  
S99-50149-2(Nand)@FBGA107 [(SA664A-B128A-W115F001Y)] ]  
S99-50149-2(Nor)@FBGA107 [(SA664A-B127A-W115F001Y)] ]  
S99-50149-3(Nand)@FBGA107 [(SA664A-B128A-W115F001Y)] ]  
S99-50149-3(Nor)@FBGA107 [(SA664A-B127A-W115F001Y)] ]  
S99-50158(S29PL320J)@FBGA67 [(SA642A-B041A-Y096F001Y)] ]  
S99-50158-LF(S29PL320J)@FBGA67 [(SA642A-B041A-Y096F001Y)] ]  
S99-50183(S29GL256N)@FBGA64 [(SA655E-B129A-T056F001Y)] ]  
S99PL128JC0BAWFC0@FBGA84 [(SA642A-B062A-Y096F001Y)] ]  
S99PL128JC0BAWNB0@FBGA84 [(SA642A-B062A-Y096F001Y)] ]  
S99PL128JC0BAWT10@FBGA84 [(SA642A-B062A-Y096F001Y)] ]  
S99PL128JC0BAWUB0@FBGA84 [(SA642A-B062A-Y096F001Y)] ]  
S99PL193JB0BAEFC@FBGA73 [(SA664J-B236A-M116F001Y)] ]  
S99PL193JB0BAEUC@FBGA73 [(SA664J-B236A-M116F001Y)] ]  
S99PL193JB0BAWFC@FBGA73 [(SA664J-B236A-M116F001Y)] ]  
S99PL193JB0BAWUC@FBGA73 [(SA664J-B236A-M116F001Y)] ]  
S99PL193JC0BAEFC@FBGA73 [(SA664J-B236A-M116F001Y)] ]  
S99PL193JC0BAEUC@FBGA73 [(SA664J-B236A-M116F001Y)] ]  
S99PL193JC0BAWFC@FBGA73 [(SA664J-B236A-M116F001Y)] ]

S99PL193JC0BAWUC@FBGA73 [ (SA664J-B236A-M116F001Y) ]  
S99WS256NC0BAWA3@FBGA84 [ (SA642A-B139A-Y096F001Y) ]  
S99WS256NC0BAWA7@FBGA84 [ (SA642A-B139A-Y096F001Y) ]  
S99WS256NC0BFWA3@FBGA84 [ (SA642A-B139A-Y096F001Y) ]  
S99WS256NC0BFWA7@FBGA84 [ (SA642A-B139A-Y096F001Y) ]

## SPANSION-CUSTOMER

### E (E) PROM/FRAM/NVRAM

41F60(S29WS256N)@FBGA88 [ (SA642A-B124A-Y096F001Y) ]  
52H70(S29WS128J)@FBGA88 [ (SA642A-B154A-Y096F001Y) ]  
S71PL129JB0BFW9U(ZX)@FBGA64 [ (SA642A-B079A-Y096F001Y) ]  
S75PL127JBEBAWKB(DX)@FBGA84 [ (SA642CC-B135A-W080F001Y) ]  
S75PL127JBEBAWKU(DX)@FBGA84 [ (SA642CC-B135A-W080F001Y) ]  
S75PL127JBEBFWKB(DX)@FBGA84 [ (SA642CC-B135A-W080F001Y) ]  
S75PL127JBEBFWKU(DX)@FBGA84 [ (SA642CC-B135A-W080F001Y) ]

## SSSC

### MICROCONTROLLER

SSU7301 SSU7301@PLCC44  
[ (SA244) ]  
SSU7301@TQFP44 [ (SA245A) ]

## SST

### E (E) PROM/FRAM/NVRAM

SST25LF010@SOIC8(4.0) [ (SA602A) ] SST25LF010@SOIC8(5.4)  
[ (SA605B) ]  
SST25LF010@WSON8 [ (SA683) ]  
SST25LF010A@SOIC8(4.0) [ (SA602A) ]  
SST25LF010A@SOIC8(5.4) [ (SA605B) ]  
SST25LF010A@WSON8 [ (SA683) ]  
SST25LF016A@SOIC8(4.0) [ (SA602A) ]  
SST25LF016A@SOIC8(5.4) [ (SA605A) ]  
SST25LF016A@WSON8 [ (SA683) ]

SST25LF016B@SOIC8(4.0) [(SA602A)]	
SST25LF016B@SOIC8(5.4) [(SA605A)]	
SST25LF016B@WSON8 [(SA683)]	SST25LF020@SOIC8(4.0)
[(SA602A)]	
SST25LF020@SOIC8(5.4) [(SA605B)]	SST25LF020@WSON8
[(SA683)]	
SST25LF020A@SOIC8(4.0) [(SA602A)]	
SST25LF020A@SOIC8(5.4) [(SA605B)]	
SST25LF020A@WSON8 [(SA683)]	SST25LF040@SOIC8(4.0)
[(SA602A)]	
SST25LF040@SOIC8(5.4) [(SA605B)]	SST25LF040@WSON8
[(SA683)]	
SST25LF040A@SOIC8(4.0) [(SA602A)]	
SST25LF040A@SOIC8(5.4) [(SA605B)]	
SST25LF040A@WSON8 [(SA683)]	SST25LF080@SOIC8(4.0)
[(SA602A)]	
SST25LF080@SOIC8(5.4) [(SA605B)]	SST25LF080@WSON8
[(SA683)]	
SST25LF080A@SOIC8(4.0) [(SA602A)]	
SST25LF080A@SOIC8(5.4) [(SA605B)]	
SST25LF080A@WSON8 [(SA683)]	SST25VF010@SOIC8(4.0)
[(SA602A)]	
SST25VF010@SOIC8(5.4) [(SA605B)]	SST25VF010@WSON8
[(SA683)]	
SST25VF010A@SOIC8(4.0) [(SA602A)]	
SST25VF010A@SOIC8(5.4) [(SA605B)]	
SST25VF010A@WSON8 [(SA683)]	
SST25VF016B@SOIC8(4.0) [(SA602A)]	
SST25VF016B@SOIC8(5.4) [(SA605A)]	
SST25VF016B@WSON8 [(SA683)]	SST25VF020@SOIC8(4.0)
[(SA602A)]	
SST25VF020@SOIC8(5.4) [(SA605B)]	SST25VF020@WSON8
[(SA683)]	
SST25VF032B@SOIC8(4.0) [(SA602A)]	
SST25VF032B@SOIC8(5.4) [(SA605A)]	
SST25VF032B@WSON8 [(SA683)]	SST25VF040@SOIC8(4.0)
[(SA602A)]	
SST25VF040@SOIC8(5.4) [(SA605B)]	SST25VF040@WSON8
[(SA683)]	
SST25VF040B@SOIC8(4.0) [(SA602A)]	
SST25VF040B@SOIC8(5.4) [(SA605A)]	
SST25VF040B@WSON8 [(SA683)]	SST25VF080@SOIC8(4.0)
[(SA602A)]	

SST25VF080@SOIC8(5.4) [(SA605B)]	SST25VF080@WSON8
[(SA683)]	
SST25VF080B@SOIC8(4.0) [(SA602A)]	
SST25VF080B@SOIC8(5.4) [(SA605A)]	
SST25VF080B@WSON8 [(SA683)]	SST25VF512@SOIC8(4.0)
[(SA602A)]	
SST25VF512@SOIC8(5.4) [(SA605B)]	SST25VF512@WSON8
[(SA683)]	
SST25VF512A@SOIC8(4.0) [(SA602A)]	
SST25VF512A@SOIC8(5.4) [(SA605B)]	
SST25VF512A@WSON8 [(SA683)]	SST25WF010@SOIC8
[(SA602A)]	
SST25WF020@SOIC8 [(SA602A)]	SST25WF040@SOIC8
[(SA602A)]	
SST25WF080@SOIC8 [(SA602A)]	SST25WF512@SOIC8
[(SA602A)]	
SST27SF010	SST27SF010@PLCC32
[(SA015A1T)]	
SST27SF010@TSOP32 [(SA410T)]	
SST27SF020	
SST27SF020@PLCC32 [(SA015A1T)]	SST27SF020@TSOP32
[(SA410T)]	
SST27SF256	SST27SF256@PLCC32
[(SA015A1T)]	
SST27SF256@VSOP32 [(SA620)]	
SST27SF512	
SST27SF512@PLCC32 [(SA015A1T)]	SST27SF512@VSOP32
[(SA620)]	
SST27VF010	SST27VF010@PLCC32
[(SA015A1T)]	
SST27VF010@TSOP32 [(SA410T)]	
SST27VF020	
SST27VF020@PLCC32 [(SA015A1T)]	SST27VF020@TSOP32
[(SA410T)]	
SST27VF040	SST27VF040@PLCC32
[(SA015A1T)]	
SST27VF040@TSOP32 [(SA410T)]	
SST27VF256	
SST27VF256@PLCC32 [(SA015A1T)]	SST27VF256@VSOP32
[(SA620)]	
SST27VF512	SST27VF512@PLCC32
[(SA015A1T)]	
SST27VF512@VSOP32 [(SA620)]	

SST28EE011	
SST28EE011@PLCC32 [(SA015A1T)]	SST28EE011@TSOP32
[(SA410T)]	
SST28LE011	SST28LE011@PLCC32
[(SA015A1T)]	
SST28LE011@TSOP32 [(SA410T)]	
SST28LF040	
SST28LF040@PLCC32 [(SA015A1T)]	SST28LF040@TSOP32
[(SA410T)]	
SST28SF040	SST28SF040@PLCC32
[(SA015A1T)]	
SST28SF040@TSOP32 [(SA410T)]	
SST28SF040A	
SST28SF040A@PLCC32 [(SA015A1T)]	SST28SF040A@TSOP32
[(SA410T)]	
SST28VE011	SST28VE011@PLCC32
[(SA015A1T)]	
SST28VE011@TSOP32 [(SA410T)]	
SST28VF040	
SST28VF040@PLCC32 [(SA015A1T)]	SST28VF040@TSOP32
[(SA410T)]	
SST28VF040A	SST28VF040A@PLCC32
[(SA015A1T)]	
SST28VF040A@TSOP32 [(SA410T)]	
SST29EE010	
SST29EE010@PLCC32 [(SA015A1T)]	SST29EE010@TSOP32
[(SA410T)]	
SST29EE020	SST29EE020@PLCC32
[(SA015A1T)]	
SST29EE020@TSOP32 [(SA410T)]	
SST29EE512	
SST29EE512@PLCC32 [(SA015A1T)]	SST29EE512@TSOP32
[(SA410T)]	
SST29LE010	SST29LE010@PLCC32
[(SA015A1T)]	
SST29LE010@TSOP32 [(SA410T)]	
SST29LE020	
SST29LE020@PLCC32 [(SA015A1T)]	SST29LE020@TSOP32
[(SA410T)]	
SST29LE512	SST29LE512@PLCC32
[(SA015A1T)]	
SST29LE512@TSOP32 [(SA410T)]	
SST29SF010	



SST29SF010@PLCC32 [ (SA015A1T) ]	SST29SF010@VSOP32
[ (SA620) ]	
SST29SF020	SST29SF020@PLCC32
[ (SA015A1T) ]	
SST29SF020@VSOP32 [ (SA620) ]	
SST29SF040	
SST29SF040@PLCC32 [ (SA015A1T) ]	SST29SF040@VSOP32
[ (SA620) ]	
SST29SF512	SST29SF512@PLCC32
[ (SA015A1T) ]	
SST29SF512@VSOP32 [ (SA620) ]	
SST29VE010	
SST29VE010@PLCC32 [ (SA015A1T) ]	SST29VE010@TSOP32
[ (SA410T) ]	
SST29VE020	SST29VE020@PLCC32
[ (SA015A1T) ]	
SST29VE020@TSOP32 [ (SA410T) ]	
SST29VE512	
SST29VE512@PLCC32 [ (SA015A1T) ]	SST29VE512@TSOP32
[ (SA410T) ]	
SST29VF010	SST29VF010@PLCC32
[ (SA015A1T) ]	
SST29VF010@VSOP32 [ (SA620) ]	
SST29VF020	
SST29VF020@PLCC32 [ (SA015A1T) ]	SST29VF020@VSOP32
[ (SA620) ]	
SST29VF040	SST29VF040@PLCC32
[ (SA015A1T) ]	
SST29VF040@VSOP32 [ (SA620) ]	
SST29VF512	
SST29VF512@PLCC32 [ (SA015A1T) ]	SST29VF512@VSOP32
[ (SA620) ]	
SST31LF021@VSOP32 [ (SA620) ]	SST31LF041@VSOP40
[ (SA623) ]	
SST31LF041A@VSOP32 [ (SA620) ]	SST31LF043@VSOP40
[ (SA623) ]	
SST31LF043A@VSOP32 [ (SA620) ]	
SST32HF162@LFBGA48 [ (SA655E-B026A-T064F001) ]	
SST32HF162@LFBGA48(SST adapter)	SST32HF162@TSOP48 [ (SA247-B005) ]
SST32HF1621C@LFBGA62 [ (SA642R-B083A-T096F001Y) ]	
SST32HF1621C@LFBGA63 [ (SA642R-B032A-T096F001Y) ]	
SST32HF1622C@LFBGA62 [ (SA642R-B083A-T096F001Y) ]	

SST32HF1622C@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF164@LFBGA48 [ (SA655E-B026A-T064F001) ]  
SST32HF164@LFBGA48(SST adapter)            SST32HF164@TSOP48 [ (SA247-  
B005) ]  
SST32HF1641@LFBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF1641@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF1641C@LFBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF1641C@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF1642@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF1642@FBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF1642C@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF1642C@FBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF1681@LFBGA62 [ (SA642R-B083A-T096F001Y) ]  
SST32HF1681@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF1682@LFBGA62 [ (SA642R-B083A-T096F001Y) ]  
SST32HF1682@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF200@LFBGA48 [ (SA642B-B026A-Y072F001) ]  
SST32HF201@LFBGA48 [ (SA642B-B026A-Y072F001) ]  
SST32HF202@LFBGA48 [ (SA642B-B026A-Y072F001) ]  
SST32HF324@LFBGA62 [ (SA642E-B023A-T072F001) ]  
SST32HF324@LFBGA63 [ (SA642E-B032A-T072F001) ]  
SST32HF324@TFBGA63 [ (SA642E-B032A-T072F001) ]  
SST32HF3241@LFBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF3241@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF3241C@LFBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF3241C@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF3242@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF3242@FBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF3242C@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF3242C@FBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF3244C@FBGA56 [ (SA642R-B032A-T096F001Y) ]  
SST32HF324C@LFBGA62 [ (SA642E-B023A-T072F001) ]  
SST32HF324C@LFBGA63 [ (SA642E-B032A-T072F001) ]  
SST32HF324C@TFBGA63 [ (SA642E-B032A-T072F001) ]  
SST32HF328@LFBGA62 [ (SA642E-B023A-T072F001) ]  
SST32HF328@LFBGA63 [ (SA642E-B032A-T072F001) ]  
SST32HF328@TFBGA63 [ (SA642E-B032A-T072F001) ]  
SST32HF3281@LFBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF3281@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF3281C@LFBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF3281C@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
SST32HF3282@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
SST32HF3282@FBGA63 [ (SA642R-B032A-T096F001Y) ]

SST32HF3282C@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF3282C@FBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF3284@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF328C@LFBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST32HF328C@LFBGA63 [ ( SA642E-B032A-T072F001 ) ]  
SST32HF328C@TFBGA63 [ ( SA642E-B032A-T072F001 ) ]  
SST32HF32A1@LFBGA62 [ ( SA642R-B083A-T096F001Y ) ]  
SST32HF32A1@LFBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF32A4@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF400@LFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST32HF401@LFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST32HF402@LFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST32HF64161@LFBGA64 [ ( SA642R-B083A-T096F001Y ) ]  
SST32HF64161C@LFBGA64 [ ( SA642R-B083A-T096F001Y ) ]  
SST32HF6481@LFBGA64 [ ( SA642R-B083A-T096F001Y ) ]  
SST32HF6481C@LFBGA64 [ ( SA642R-B083A-T096F001Y ) ]  
SST32HF6482@FBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF6482@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF6482C@FBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF6482C@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF64A1@FBGA63 [ ( SA642I-B032A-W080F001Y ) ]  
SST32HF64A1@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF64A2@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF64A2@FBGA63 [ ( SA642I-B032A-W080F001Y ) ]  
SST32HF64A2@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF64B1@FBGA63 [ ( SA642I-B032A-W080F001Y ) ]  
SST32HF64B1@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF64B2@FBGA63 [ ( SA642I-B032A-W080F001Y ) ]  
SST32HF64B2@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF800@LFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST32HF802@LBGA48 [ ( SA655E-B026A-T064F001 ) ]  
SST32HF802@LFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST32HF802@LFBGA48(SST adapter)  
SST34HF1601B@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1601B@TSOP48 [ ( SA247-B005 ) ]  
SST34HF1601C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1601C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1602C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1602C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1621@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1621A@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1621A@LFBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF1621C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]

SST34HF1621C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1621S@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1622@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1622C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1622C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1622S@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF162C@LBGA48 [ ( SA655E-B026A-T064F001 ) ]  
SST34HF162G@LBGA48 [ ( SA655E-B026A-T064F001 ) ]  
SST34HF162G@LFBGA48 [ ( SA642G-B026A-T048F001 ) ]  
SST34HF1641@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1641A@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1641A@LFBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF1641C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1641C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1641D@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1641D@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1641J@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1641J@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF1641S@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1642@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1642C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1642C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1642D@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1642D@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1642S@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF164C@LBGA48 [ ( SA655E-B026A-T064F001 ) ]  
SST34HF164G@LBGA48 [ ( SA655E-B026A-T064F001 ) ]  
SST34HF164G@LFBGA48 [ ( SA642G-B026A-T048F001 ) ]  
SST34HF1681@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1681@LFBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF1681D@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1681D@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1681J@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1681J@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF1682D@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1682D@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF3243C@FBGA56 [ ( SA642I-B032A-W080F001Y ) ]  
SST34HF3243C@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF3244@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF3244@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF3244C@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF3244C@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF3282@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]

SST34HF3282@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
 SST34HF3283@FBGA56 [ (SA642I-B032A-W080F001Y) ]  
 SST34HF3283@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
 SST34HF3284@FBGA56 [ (SA642R-B032A-T096F001Y) ]  
 SST34HF3284@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
 SST34HF32A4@FBGA56 [ (SA642R-B032A-T096F001Y) ]  
 SST34HF32A4@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
 SST36VF1601(B3K)@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
 SST36VF1601(BK)@TFBGA48 [ (SA642R-B026A-T096F001Y) ]  
 SST36VF1601@TSOP48 [ (SA247-B005) ]  
 SST36VF1601C@FBGA48 [ (SA642G-B026A-T048F001) ]  
 SST36VF1601C@TSOP48 [ (SA247-B005) ]  
 SST36VF1601E@FBGA48 [ (SA642G-B026A-T048F001) ]  
 SST36VF1601E@TSOP48 [ (SA247-B005) ]  
 SST36VF1601G@LFBGA56 [ (SA642A-B032A) ]  
 SST36VF1601G@TFBGA48 [ (SA642G-B026A-T048F001) ]  
 SST36VF1601G@TSOP48 [ (SA247-B005) ]  
 SST36VF1602(B3K)@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
 SST36VF1602(BK)@TFBGA48 [ (SA642R-B026A-T096F001Y) ]  
 SST36VF1602@TSOP48 [ (SA247-B005) ]  
 SST36VF1602C@FBGA48 [ (SA642G-B026A-T048F001) ]  
 SST36VF1602C@TSOP48 [ (SA247-B005) ]  
 SST36VF1602E@FBGA48 [ (SA642G-B026A-T048F001) ]  
 SST36VF1602E@TSOP48 [ (SA247-B005) ]  
 SST36VF1602G@LFBGA56 [ (SA642A-B032A) ]  
 SST36VF1602G@TFBGA48 [ (SA642G-B026A-T048F001) ]  
 SST36VF1602G@TSOP48 [ (SA247-B005) ]  
 SST36VF3203@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 SST36VF3203@TSOP48 [ (SA247-B005) ]  
 SST36VF3204@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 SST36VF3204@TSOP48 [ (SA247-B005) ]  
 SST37VF010 [ (SA015A1T) ]  
 SST37VF010@VSOP32 [ (SA620) ]  
 SST37VF020 [ (SA015A1T) ]  
 SST37VF020@PLCC32 [ (SA015A1T) ]  
 SST37VF040 [ (SA015A1T) ]  
 SST37VF040@VSOP32 [ (SA620) ]  
 SST37VF512 [ (SA015A1T) ]  
 SST37VF512@PLCC32 [ (SA015A1T) ]  
 SST37VF512@VSOP32 [ (SA620) ]

SST39LF010@PLCC32 [ (SA015A1T) ]  
SST39LF010@TFBGA48 [ (SA642G-B026A-T048F001) ]  
SST39LF010@VSOP32 [ (SA620) ]  
SST39LF010@WFBGA48 [ (SA716A-B120A-M048F001Y) ]  
SST39LF016@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39LF016@TSOP40 [ (SA409T) ] SST39LF020@PLCC32  
[ (SA015A1T) ]  
SST39LF020@TFBGA48 [ (SA642G-B026A-T048F001) ]  
SST39LF020@VSOP32 [ (SA620) ]  
SST39LF020@WFBGA48 [ (SA716A-B120A-M048F001Y) ]  
SST39LF040@PLCC32 [ (SA015A1T) ] SST39LF040@VSOP32  
[ (SA620) ]  
SST39LF080@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39LF080@TSOP40 [ (SA409T) ] SST39LF080Q@TSOP40  
[ (SA409T) ]  
SST39LF100@FBGA48 [ (SA642B-B026A-Y072F001) ]  
SST39LF100@VSOP40 [ (SA623) ]  
SST39LF160@TFBGA48 [ (SA642B-B026A-Y072F001) ]  
SST39LF160@TSOP48 [ (SA247-B005) ]  
SST39LF200A@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39LF200A@TSOP48 [ (SA247-B005) ]  
SST39LF200A@WFBGA48 [ (SA716B-B119B-T048F001Y) ]  
SST39LF400A@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39LF400A@TSOP48 [ (SA247-B005) ]  
SST39LF400A@WFBGA48 [ (SA716B-B119B-T048F001Y) ]  
SST39LF512@PLCC32 [ (SA015A1T) ] SST39LF512@VSOP32  
[ (SA620) ]  
SST39LF800A@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39LF800A@TSOP48 [ (SA247-B005) ]  
SST39LF800A@WFBGA48 [ (SA716B-B119B-T048F001Y) ]  
SST39LH010 SST39LH010@PLCC32  
[ (SA015A1T) ]  
SST39LH010@TSOP32 [ (SA410T) ]  
SST39LH040  
SST39LH040@PLCC32 [ (SA015A1T) ] SST39LH040@TSOP32  
[ (SA410T) ]  
SST39LH512 SST39LH512@PLCC32  
[ (SA015A1T) ]  
SST39LH512@TSOP32 [ (SA410T) ]  
SST39SF010  
SST39SF010@PLCC32 [ (SA015A1T) ] SST39SF010@VSOP32  
[ (SA620) ]  
SST39SF010A SST39SF010A@PLCC32

[ ( SA015A1T ) ]  
 SST39SF010A@VSOP32 [ ( SA620 ) ]  
 SST39SF020  
 SST39SF020@PLCC32 [ ( SA015A1T ) ]                      SST39SF020@VSOP32  
 [ ( SA620 ) ]  
 SST39SF020A                                                      SST39SF020A@PLCC32  
 [ ( SA015A1T ) ]  
 SST39SF020A@VSOP32 [ ( SA620 ) ]  
 SST39SF020P  
 SST39SF020P@PLCC32 [ ( SA015A1T ) ]                      SST39SF020P@VSOP32  
 [ ( SA620 ) ]  
 SST39SF040                                                      SST39SF040@PLCC32  
 [ ( SA015A1T ) ]  
 SST39SF040@VSOP32 [ ( SA620 ) ]  
 SST39SF040P  
 SST39SF040P@PLCC32 [ ( SA015A1T ) ]                      SST39SF040P@VSOP32  
 [ ( SA620 ) ]  
 SST39SF512                                                      SST39SF512@PLCC32  
 [ ( SA015A1T ) ]  
 SST39SF512@VSOP32 [ ( SA620 ) ]  
 SST39SF512A  
 SST39SF512A@PLCC32 [ ( SA015A1T ) ]                      SST39SF512A@VSOP32  
 [ ( SA620 ) ]  
 SST39VF010                                                      SST39VF010@PLCC32  
 [ ( SA015A1T ) ]  
 SST39VF010@TFBGA48 [ ( SA642G-B026A-T048F001 ) ]  
 SST39VF010@VSOP32 [ ( SA620 ) ]  
 SST39VF016@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 SST39VF016@TSOP40 [ ( SA409T ) ]                              SST39VF016Q@TSOP40  
 [ ( SA409T ) ]  
 SST39VF020                                                      SST39VF020@PLCC32  
 [ ( SA015A1T ) ]  
 SST39VF020@TFBGA48 [ ( SA642G-B026A-T048F001 ) ]  
 SST39VF020@VSOP32 [ ( SA620 ) ]  
 SST39VF020P  
 SST39VF020P@PLCC32 [ ( SA015A1T ) ]                      SST39VF020P@VSOP32  
 [ ( SA620 ) ]  
 SST39VF040                                                      SST39VF040@PLCC32  
 [ ( SA015A1T ) ]  
 SST39VF040@VSOP32 [ ( SA620 ) ]  
 SST39VF040P  
 SST39VF040P@PLCC32 [ ( SA015A1T ) ]                      SST39VF040P@VSOP32  
 [ ( SA620 ) ]

SST39VF080@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39VF080@TSOP40 [ (SA409T) ] SST39VF080Q@TSOP40  
[ (SA409T) ]  
SST39VF088@TSOP48 [ (SA247-B005) ]  
SST39VF100@FBGA48 [ (SA642B-B026A-Y072F001) ]  
SST39VF100@VSOP40 [ (SA623) ]  
SST39VF160@TFBGA48 [ (SA642B-B026A-Y072F001) ]  
SST39VF160@TSOP48 [ (SA247-B005) ]  
SST39VF1601@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39VF1601@TSOP48 [ (SA247-B005) ]  
SST39VF1602@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39VF1602@TSOP48 [ (SA247-B005) ]  
SST39VF160Q@TSOP48 [ (SA247-B005) ]  
SST39VF1681@TFBGA48 [ (SA642B-B026A-Y072F001) ]  
SST39VF1681@TSOP48 [ (SA247-B005) ]  
SST39VF1682@TFBGA48 [ (SA642B-B026A-Y072F001) ]  
SST39VF1682@TSOP48 [ (SA247-B005) ]  
SST39VF200A@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39VF200A@TSOP48 [ (SA247-B005) ]  
SST39VF200A@WFBGA48 [ (SA716B-B119B-T048F001Y) ]  
SST39VF320@TFBGA48 [ (SA642G-B026A-T048F001) ]  
SST39VF320@TSOP48 [ (SA247-B005) ]  
SST39VF3201@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39VF3201@TSOP48 [ (SA247-B005) ]  
SST39VF3202@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39VF3202@TSOP48 [ (SA247-B005) ]  
SST39VF400@TSOP48 [ (SA247-B005) ]  
SST39VF400A(Low)@TSOP48 [ (SA247) ]  
SST39VF400A@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39VF400A@TSOP48 [ (SA247-B005) ]  
SST39VF400A@WFBGA48 [ (SA716B-B119B-T048F001Y) ]  
SST39VF400Q@TSOP48 [ (SA247-B005) ]  
SST39VF512 SST39VF512@PLCC32  
[ (SA015A1T) ]  
SST39VF512@VSOP32 [ (SA620) ]  
SST39VF6401@TFBGA48 [ (SA642R-B026A-T096F001Y) ]  
SST39VF6401@TSOP48 [ (SA247-B005) ]  
SST39VF6401B@FBGA48 [ (SA642R-B026A-T096F001Y) ]  
SST39VF6401B@TSOP48 [ (SA247-B005) ]  
SST39VF6402@TFBGA48 [ (SA642R-B026A-T096F001Y) ]  
SST39VF6402@TSOP48 [ (SA247-B005) ]  
SST39VF6402B@FBGA48 [ (SA642R-B026A-T096F001Y) ]  
SST39VF6402B@TSOP48 [ (SA247-B005) ]



SST39VF800@TSOP48 [(SA247-B005)]  
 SST39VF800A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39VF800A@TSOP48 [(SA247-B005)]  
 SST39VF800A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39VF800Q@TSOP48 [(SA247-B005)]  
 SST39WF1601@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39WF1601@WFBGA48 [(SA716C-B119A-T048F001Y)]  
 SST39WF1602@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39WF1602@WFBGA48 [(SA716C-B119A-T048F001Y)]  
 SST39WF400A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39WF400A@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39WF800A(M2)@WFBGA48 [(SA716A-B119B-M048F001Y)]  
 SST39WF800A(Y1)@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39WF800A@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39WF800B(M2)@WFBGA48 [(SA716A-B119B-M048F001Y)]  
 SST39WF800B(Y1)@WFBGA48 [(SA716B-B119B-T048F001Y)]  
 SST39WF800B@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST45LF010@SOIC8 [(SA602A)] SST45LF010@WSON8  
 [(SA683)]  
 SST45VF010@SOIC8 [(SA602A)] SST45VF020@SOIC8  
 [(SA602A)]  
 SST45VF512@SOIC8 [(SA602A)] SST49LF002@PLCC32  
 [(SA015A1T)]  
 SST49LF002@VSOP32 [(SA620)] SST49LF002A@PLCC32  
 [(SA015A1T)]  
 SST49LF002A@VSOP32 [(SA620)] SST49LF002B@PLCC32  
 [(SA015A1T)]  
 SST49LF003A@PLCC32 [(SA015A1T)] SST49LF003A@VSOP32  
 [(SA620)]  
 SST49LF003B@PLCC32 [(SA015A1T)] SST49LF004@PLCC32  
 [(SA015A1T)]  
 SST49LF004@VSOP32 [(SA620)] SST49LF004A@PLCC32  
 [(SA015A1T)]  
 SST49LF004A@VSOP32 [(SA620)] SST49LF004B@PLCC32  
 [(SA015A1T)]  
 SST49LF004B@VSOP32 [(SA620)] SST49LF004B@VSOP40  
 [(SA409T)]  
 SST49LF004C@PLCC32 [(SA015A1T)] SST49LF004C@VSOP32  
 [(SA620)]  
 SST49LF008@PLCC32 [(SA015A1T)] SST49LF008@VSOP32  
 [(SA620)]  
 SST49LF008A@PLCC32 [(SA015A1T)] SST49LF008A@TSOP40  
 [(SA409T)]

SST49LF008A@VSOP32 [ (SA620) ] [ (SA015A1T) ]	SST49LF008C@PLCC32
SST49LF008C@VSOP32 [ (SA620) ] [ (SA015A1T) ]	SST49LF016C@PLCC32
SST49LF016C@TSOP40 [ (SA409T) ] [ (SA620) ]	SST49LF016C@VSOP32
SST49LF020@PLCC32 [ (SA015A1T) ] [ (SA620) ]	SST49LF020@VSOP32
SST49LF020A@PLCC32 [ (SA015A1T) ] [ (SA620) ]	SST49LF020A@VSOP32
SST49LF030A@PLCC32 [ (SA015A1T) ] [ (SA620) ]	SST49LF030A@VSOP32
SST49LF040@PLCC32 [ (SA015A1T) ] [ (SA620) ]	SST49LF040@VSOP32
SST49LF040A@PLCC32 [ (SA015A1T) ] [ (SA620) ]	SST49LF040A@VSOP32
SST49LF040B@PLCC32 [ (SA015A1T) ] [ (SA409T) ]	SST49LF040B@TSOP40
SST49LF040B@VSOP32 [ (SA620) ] [ (SA015A1T) ]	SST49LF080A@PLCC32
SST49LF080A@VSOP32 [ (SA620) ] [ (SA015A1T) ]	SST49LF160C@PLCC32
SST49LF160C@TSOP32 [ (SA620) ]	

## MICROCONTROLLER

SST65P542R@SOIC28 [ (SA404) ]	
SST89C54	
SST89C54@PLCC44 [ (SA244) ] [ (SA245A) ]	SST89C54@TQFP44
SST89C58 [ (SA244) ]	SST89C58@PLCC44
SST89C58@TQFP44 [ (SA245A) ] [ (SA244) ]	SST89C58RC@PLCC44
SST89C58RC@TQFP44 [ (SA245A) ] [ (SA750) ]	SST89C58RC@WQFN40
SST89E516RD [ (SA244) ]	SST89E516RD@PLCC44
SST89E516RD@TQFP44 [ (SA245A) ]	
SST89E516RD2	
SST89E516RD2@PLCC44 [ (SA244) ] [ (SA245A) ]	SST89E516RD2@TQFP44

SST89E52RC [ ( SA244 ) ]	SST89E52RC@PLCC44
SST89E52RC@TQFP44 [ ( SA245A ) ]	
SST89E52RD SST89E52RD@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	SST89E52RD@TQFP44
SST89E52RD2 [ ( SA244 ) ]	SST89E52RD2@PLCC44
SST89E52RD2@TQFP44 [ ( SA245A ) ]	
SST89E54RC SST89E54RC@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	SST89E54RC@TQFP44
SST89E54RD [ ( SA244 ) ]	SST89E54RD@PLCC44
SST89E54RD@TQFP44 [ ( SA245A ) ]	
SST89E54RD2 SST89E54RD2@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	SST89E54RD2@TQFP44
SST89E554RC [ ( SA244 ) ]	SST89E554RC@PLCC44
SST89E554RC@TQFP44 [ ( SA245A ) ]	
SST89E564RD SST89E564RD@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	SST89E564RD@TQFP44
SST89E58RD [ ( SA244 ) ]	SST89E58RD@PLCC44
SST89E58RD@TQFP44 [ ( SA245A ) ]	
SST89E58RD2 SST89E58RD2@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	SST89E58RD2@TQFP44
SST89V516RD [ ( SA244 ) ]	SST89V516RD@PLCC44
SST89V516RD@TQFP44 [ ( SA245A ) ]	
SST89V516RD2 SST89V516RD2@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	SST89V516RD2@TQFP44
SST89V52RD [ ( SA244 ) ]	SST89V52RD@PLCC44
SST89V52RD@TQFP44 [ ( SA245A ) ]	
SST89V52RD2 SST89V52RD2@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	SST89V52RD2@TQFP44
SST89V54RD2	SST89V54RD2@PLCC44

[ ( SA244 ) ]	
SST89V54RD2@TQFP44 [ ( SA245A ) ]	
SST89V54RC	
SST89V54RC@PLCC44 [ ( SA244 ) ]	SST89V54RC@TQFP44
[ ( SA245A ) ]	
SST89V564RD	SST89V564RD@PLCC44
[ ( SA244 ) ]	
SST89V564RD@TQFP44 [ ( SA245A ) ]	
SST89V58RD2	
SST89V58RD2@PLCC44 [ ( SA244 ) ]	SST89V58RD2@TQFP44
[ ( SA245A ) ]	

## ST

### E ( E ) PROM / FRAM / NVRAM

ET2716	
ETC2716	
ETC2732	
M24128	
M24128@MLP8 [ ( SA724 ) ]	M24128@SOIC8
[ ( SA602A ) ]	
M24128@TSOP8 [ ( SA026 ) ]	
M24164	
M24164@SOIC8 [ ( SA602A ) ]	
M24256	
M24256@MLP8 [ ( SA724 ) ]	M24256@TSOP8
[ ( SA026 ) ]	
M24256[ 3.9 ]@SOIC8 [ ( SA602A ) ]	M24256[ 5.5 ]@SOIC8
[ ( SA605A ) ]	
M24512	M24512@SOIC8
[ ( SA605A ) ]	
M24512@TSOP8 [ ( SA026 ) ]	
M24C01	
M24C01@MLP8 [ ( SA724 ) ]	M24C01@SOIC8
[ ( SA602A ) ]	
M24C01R	M24C01R@MLP8
[ ( SA724 ) ]	
M24C01R@SOIC8 [ ( SA602A ) ]	M24C01R@TSOP8
[ ( SA026 ) ]	
M24C01W	M24C01W@MLP8
[ ( SA724 ) ]	

M24C01W@SOIC8 [(SA602A)]	M24C01W@TSOP8
[(SA026)]	
M24C02	M24C02@MLP8
[(SA724)]	
M24C02@SOIC8 [(SA602A)]	
M24C02R	
M24C02R@MLP8 [(SA724)]	M24C02R@SOIC8
[(SA602A)]	
M24C02R@TSOP8 [(SA026)]	
M24C02W	
M24C02W@MLP8 [(SA724)]	M24C02W@SOIC8
[(SA602A)]	
M24C02W@TSOP8 [(SA026)]	
M24C04	
M24C04@MLP8 [(SA724)]	M24C04@SOIC8
[(SA602A)]	
M24C04R	M24C04R@MLP8
[(SA724)]	
M24C04R@SOIC8 [(SA602A)]	M24C04R@TSOP8
[(SA026)]	
M24C04W	M24C04W@MLP8
[(SA724)]	
M24C04W@SOIC8 [(SA602A)]	M24C04W@TSOP8
[(SA026)]	
M24C08	M24C08@MLP8
[(SA724)]	
M24C08@MSOP8 [(SA695A)]	M24C08@SOIC8
[(SA602A)]	
M24C08@TSOP8 [(SA026)]	
M24C08R	
M24C08R@MLP8 [(SA724)]	M24C08R@MSOP8
[(SA695A)]	
M24C08R@SOIC8 [(SA602A)]	M24C08R@TSOP8
[(SA026)]	
M24C08W	M24C08W@MLP8
[(SA724)]	
M24C08W@MSOP8 [(SA695A)]	M24C08W@SOIC8
[(SA602A)]	
M24C08W@TSOP8 [(SA026)]	M24C128
(BN)	
M24C128(MN)@SOIC8 [(SA605A)]	M24C128(MW)@SOIC8
[(SA602A)]	
M24C128@MLP8 [(SA724)]	M24C128B

(BN)  
M24C128B(MN)@SOIC8 [(SA605A)]  
[(SA602A)]  
M24C128B@MLP8 [(SA724)]  
M24C16  
M24C16@MLP8 [(SA724)]  
[(SA602A)]  
M24C16R  
[(SA724)]  
M24C16R@SOIC8 [(SA602A)]  
[(SA026)]  
M24C16W  
[(SA724)]  
M24C16W@SOIC8 [(SA602A)]  
[(SA026)]  
M24C256(BN)  
[(SA605A)]  
M24C256(MW)@SOIC8 [(SA602A)]  
[(SA724)]  
M24C256A(BN)  
[(SA605A)]  
M24C256A(MW)@SOIC8 [(SA602A)]  
[(SA724)]  
M24C256B(BN)  
[(SA605A)]  
M24C256B(MW)@SOIC8 [(SA602A)]  
[(SA724)]  
M24C256W(BN)  
[(SA605A)]  
M24C256W(MW)@SOIC8 [(SA602A)]  
[(SA724)]  
M24C32(BN)  
[(SA026)]  
M24C32(DW)@TSSOP8 [(SA602A)]  
[(SA605A)]  
M24C32(MW)@SOIC8 [(SA602A)]  
[(SA724)]  
M24C32W(BN)  
[(SA026)]  
M24C32W(DW)@TSSOP8 [(SA602A)]  
[(SA605A)]  
M24C32W(MW)@SOIC8 [(SA602A)]  
[(SA724)]

M24C128B(MW)@SOIC8  
  
M24C16@SOIC8  
M24C16R@MLP8  
M24C16R@TSOP8  
M24C16W@MLP8  
M24C16W@TSOP8  
M24C256(MN)@SOIC8  
M24C256@MLP8  
M24C256A(MN)@SOIC8  
M24C256A@MLP8  
M24C256B(MN)@SOIC8  
M24C256B@MLP8  
M24C256W(MN)@SOIC8  
M24C256W@MLP8  
M24C32(DL)@TSSOP14  
M24C32(MN)@SOIC8  
M24C32@MLP8  
M24C32W(DL)@TSSOP14  
M24C32W(MN)@SOIC8  
M24C32W@MLP8

M24C64 (BN)	M24C64 (DL)@TSSOP14
[ (SA026) ]	
M24C64 (DW)@TSSOP8 [ (SA602A) ]	M24C64 (MN)@SOIC8
[ (SA605A) ]	
M24C64 (MW)@SOIC8 [ (SA602A) ]	M24C64@MLP8
[ (SA724) ]	
M24C64W (BN)	M24C64W (DL)@TSSOP14
[ (SA026) ]	
M24C64W (DW)@TSSOP8 [ (SA602A) ]	M24C64W (MN)@SOIC8
[ (SA605A) ]	
M24C64W (MW)@SOIC8 [ (SA602A) ]	M24C64W@MLP8
[ (SA724) ]	
M24CL04B	M24CL04B@MLP8
[ (SA724) ]	
M24CL04B@SOIC8 [ (SA602A) ]	M24CL04B@TSOP8
[ (SA026) ]	
M24E16	M24E32
(BN)	
M24E32 (DW)@TSSOP8 [ (SA602A) ]	M24E32 (MN)@SOIC8
[ (SA605A) ]	
M24E32 (MW)@SOIC8 [ (SA602A) ]	
M24W01	
M24W01@SOIC8 [ (SA602A) ]	
M24W02	
M24W02@SOIC8 [ (SA602A) ]	
M24W04	
M24W04@SOIC8 [ (SA602A) ]	
M24W08	
M24W08@SOIC8 [ (SA602A) ]	
M24W16	
M24W16@SOIC8 [ (SA602A) ]	
M25C01	
M25C02	
M25C04	
M25C08	
M25C16	
M25E16	M25P05@SOIC8
[ (SA602A) ]	
M25P05@VQFPN8 [ (SA684) ]	M25P05-A@SOIC8
[ (SA602A) ]	
M25P05-A@TSSOP8 [ (SA605A) ]	M25P05-A@VDFPN8
[ (SA684) ]	
M25P10@SOIC8 [ (SA602A) ]	M25P10@VQFPN8

[(SA684)]  
 M25P10-A@SOIC8 [(SA602A)] M25P10-A@VFQFPN8  
 [(SA684)]  
 M25P128@SOIC16 [(SA404)]  
 M25P128@SOIC16(ISP) [ISP-HEADER01]  
 M25P128@VDFPN8 [(SA684)]  
 M25P128@VDFPN8(ISP) [ISP-HEADER01]  
 M25P16@SOIC16 [(SA404)]  
 M25P16@SOIC16(ISP) [ISP-HEADER01]  
 M25P16@SOIC8(150mil) [(SA602A)]  
 M25P16@SOIC8(150mil)(ISP) [ISP-HEADER01]  
 M25P16@SOIC8(200mil) [(SA605A)]  
 M25P16@SOIC8(200mil)(ISP) [ISP-HEADER01]  
 M25P16@VDFPN8 [(SA684)]  
 M25P16@VDFPN8(ISP) [ISP-HEADER01]  
 M25P16@VFQFPN8 [(SA683)]  
 M25P16@VFQFPN8(ISP) [ISP-HEADER01]  
 M25P20@SOIC8 [(SA602A)] M25P20@VFQFPN8  
 [(SA684)]  
 M25P32(Fast Mode)@SOIC16 [(SA404)]  
 M25P32(Fast Mode)@VQFPN8 [(SA684)]  
 M25P32@SOIC16 [(SA404)]  
 M25P32@SOIC16(ISP) [ISP-HEADER01]  
 M25P32@SOIC8 [(SA605A)] M25P32@SOIC8(ISP) [ISP-  
 HEADER01]  
 M25P32@VDFPN8 [(SA684)]  
 M25P32@VDFPN8(ISP) [ISP-HEADER01]  
 M25P32@VFQFPN8 [(SA683)]  
 M25P32@VFQFPN8(ISP) [ISP-HEADER01]  
 M25P40@SOIC8 [(SA602A)] M25P40@VFQFPN8  
 [(SA684)]  
 M25P64(Fast Mode)@SOIC16 [(SA404)]  
 M25P64(Fast Mode)@VDFPN8 [(SA684)]  
 M25P64@SOIC16 [(SA404)]  
 M25P64@SOIC16(ISP) [ISP-HEADER01]  
 M25P64@VDFPN8 [(SA684)]  
 M25P64@VDFPN8(ISP) [ISP-HEADER01]  
 M25P80@SOIC16 [(SA404)] M25P80@SOIC8  
 [(SA605A)]  
 M25P80@VFQFPN8 [(SA684)] M25PE10@SOIC8  
 [(SA602A)]  
 M25PE10@SOIC8(ISP) [ISP-HEADER01]  
 M25PE10@VQFPN8 [(SA683)]



M25PE10@VQFPN8 (ISP) [ISP-HEADER01]	
M25PE16@SOIC8 [(SA023A)]	M25PE16@VQFPN8
[(SA683)]	
M25PE20@SOIC8 [(SA602A)]	
M25PE20@SOIC8(ISP) [ISP-HEADER01]	
M25PE20@VQFPN8 [(SA683)]	
M25PE20@VQFPN8 (ISP) [ISP-HEADER01]	
M25PE40@SOIC8 [(SA023A)]	
M25PE40@SOIC8(ISP) [ISP-HEADER01]	
M25PE40@VQFPN8 [(SA683)]	
M25PE40@VQFPN8 (ISP) [ISP-HEADER01]	
M25PE80@SOIC8 [(SA023A)]	
M25PE80@SOIC8(ISP) [ISP-HEADER01]	
M25PE80@VQFPN8 [(SA683)]	
M25PE80@VQFPN8 (ISP) [ISP-HEADER01]	
M25PX32@SOIC16 [(SA404)]	M25PX32@SOIC8
[(SA023A)]	
M25PX32@VFQFPN8 [(SA683)]	M25PX64@SOIC16
[(SA404)]	
M25PX64@VDFPN8 [(SA684)]	
M25W01	
M25W02	
M25W04	
M25W08	
M25W16	
M25W166	
M27128A	
M2716	
M2716F1	
M27256	
M27256A	
M2732A	
M27512	
M2764	
M2764A	
M27C1000	M27C1000@PLCC32
[(SA015A1T)]	
M27C1000@TSOP32 [(SA410T)]	
M27C1001	
M27C1001@PLCC32 [(SA015A1T)]	M27C1001@TSOP32
[(SA410T)]	
M27C1024	M27C1024@PLCC44
[(SA244)]	

M27C128B	
M27C16	
M27C160	M27C160@PLCC44
[ (SA244) ]	
M27C160@PSOP44 [ (SA638) ]	
M27C160K	
M27C160K@PLCC44 [ (SA244) ]	M27C160K@PSOP44
[ (SA638) ]	
M27C2001	M27C2001@PLCC32
[ (SA015A1T) ]	
M27C2001@TSOP32 [ (SA410T) ]	
M27C202	
M27C202@PLCC44 [ (SA244) ]	M27C202@TSOP40
[ (SA409T) ]	
M27C256B	M27C256B@PLCC32
[ (SA015A1T) ]	
M27C32	
M27C322	
M27C322@SDIP42 [ (SA028) ]	
M27C400	
M27C4001	M27C4001@PLCC32
[ (SA015A1T) ]	
M27C4001@TSOP32 [ (SA410T) ]	
M27C4002	
M27C4002@PLCC44 [ (SA244) ]	
M27C405	
M27C405@PLCC32 [ (SA015A1T) ]	M27C405@TSOP32
[ (SA410T) ]	
M27C512	M27C512@PLCC32
[ (SA015A1T) ]	
M27C513	
M27C516	
M27C516@PLCC44 [ (SA244) ]	
M27C64A	
M27C64A@PLCC32 [ (SA015A1T) ]	
M27C800	
M27C800@PLCC44 [ (SA244) ]	M27C800@PSOP44
[ (SA638) ]	
M27C801	M27C801@PLCC32
[ (SA015A1T) ]	
M27C801@TSOP32 [ (SA410T) ]	
M27HC641	
M27HC641@PLCC28 [ (SA008A) ]	

M27HC642	
M27HC642@PLCC28 [(SA008A)]	
M27V101	
M27V101@PLCC32 [(SA015A1T)]	M27V101@TSOP32
[(SA410T)]	
M27V102	M27V102@PLCC44
[(SA244)]	
M27V160	M27V160@PLCC44
[(SA244)]	
M27V160@PSOP44 [(SA638)]	
M27V160K	
M27V160K@PLCC44 [(SA244)]	M27V160K@PSOP44
[(SA638)]	
M27V201	M27V201@PLCC32
[(SA015A1T)]	
M27V201@TSOP32 [(SA410T)]	
M27V256	
M27V322	M27V322@SDIP42
[(SA028)]	
M27V401	M27V401@PLCC32
[(SA015A1T)]	
M27V401@TSOP32 [(SA410T)]	
M27V402	
M27V402@PLCC44 [(SA244)]	M27V402@TSOP40
[(SA409T)]	
M27V405	M27V405@PLCC32
[(SA015A1T)]	
M27V405@TSOP32 [(SA410T)]	
M27V512	
M27V512@PLCC32 [(SA015A1T)]	M27V512@TSOP28
[(SA430T)]	
M27V800	M27V800@PLCC44
[(SA244)]	
M27V801	M27V801@PLCC32
[(SA015A1T)]	
M27V801@TSOP32 [(SA410T)]	M27W016@PSOP44
[(SA638)]	
M27W016@TSOP48 [(SA247-B005)]	M27W032@PSOP44
[(SA638)]	
M27W032@TSOP48 [(SA247-B005)]	M27W064@PSOP44
[(SA638)]	
M27W064@TSOP48 [(SA247-B005)]	
M27W101	

M27W101@PLCC32 [(SA015A1T)]	M27W101@TSOP32
[(SA410T)]	
M27W102	M27W102@PLCC44
[(SA244)]	
M27W160	M27W160@PLCC44
[(SA244)]	
M27W160@PSOP44 [(SA638)]	
M27W201	
M27W201@PLCC32 [(SA015A1T)]	M27W201@TSOP32
[(SA410T)]	
M27W202	M27W202@PLCC44
[(SA244)]	
M27W202@TSOP40 [(SA409T)]	
M27W400	
M27W400@PLCC44 [(SA244)]	
M27W401	
M27W401@PLCC32 [(SA015A1T)]	M27W401@TSOP32
[(SA410T)]	
M27W402	M27W402@PLCC44
[(SA244)]	
M27W402@TSOP40 [(SA409T)]	
M27W512	
M27W512@PLCC32 [(SA015A1T)]	M27W512@TSOP28
[(SA430T)]	
M27W800	M27W800@PLCC44
[(SA244)]	
M27W801	M27W801@PLCC32
[(SA015A1T)]	
M27W801@TSOP32 [(SA410T)]	
M28010	
M28010@PLCC32 [(SA015A1T)]	M28010@TSOP32
[(SA410T)]	
M28010R	M28010R@PLCC32
[(SA015A1T)]	
M28010R@TSOP32 [(SA410T)]	
M28010W	
M28010W@PLCC32 [(SA015A1T)]	M28010W@TSOP32
[(SA410T)]	
M28256	M28256@PLCC32
[(SA015A1T)]	
M28256@TSOP28 [(SA430T)]	
M28C010	
M28C010@PLCC32 [(SA015A1T)]	M28C010@TSOP32

[ (SA410T) ]	
M28C010R	M28C010R@PLCC32
[ (SA015A1T) ]	
M28C010R@TSOP32 [ (SA410T) ]	
M28C010W	
M28C010W@PLCC32 [ (SA015A1T) ]	M28C010W@TSOP32
[ (SA410T) ]	
M28C16@PLCC32 [ (SA015A1T) ]	M28C17@SOIC28
[ (SA404) ]	
M28C64	M28C64@PLCC32
[ (SA015A1T) ]	
M28C64@TSOP28 [ (SA430T) ]	
M28C64C	
M28C64C@PLCC32 [ (SA015A1T) ]	M28C64C@SOIC28
[ (SA404) ]	
M28C64C@TSOP28 [ (SA430T) ]	
M28C64X	
M28C64X@PLCC32 [ (SA015A1T) ]	M28C64X@TSOP28
[ (SA430T) ]	
M28F101	M28F101@PLCC32
[ (SA015A1T) ]	
M28F101@TSOP32 [ (SA410T) ]	
M28F102	
M28F102@PLCC44 [ (SA244) ]	M28F102@TSOP40
[ (SA409T) ]	
M28F151	M28F151@PLCC32
[ (SA015A1T) ]	
M28F151@TSOP32 [ (SA410T) ]	
M28F201	
M28F201@PLCC32 [ (SA015A1T) ]	M28F201@TSOP32
[ (SA410T) ]	
M28F211@TSOP40 [ (SA409T) ]	M28F220@PSOP44
[ (SA638) ]	
M28F220@TSOP48 [ (SA247-B005) ]	M28F221@TSOP40
[ (SA409T) ]	
M28F256	M28F256@PLCC32
[ (SA015A1T) ]	
M28F256@TSOP32 [ (SA410T) ]	M28F411@TSOP40
[ (SA409T) ]	
M28F421@TSOP40 [ (SA409T) ]	
M28F512	
M28F512@PLCC32 [ (SA015A1T) ]	M28F512@TSOP32
[ (SA410T) ]	

M28LV64 M28LV64@PLCC32  
[ (SA015A1T) ]  
M28LV64@TSOP28 [ (SA430T) ]  
M28R400CB@FBGA48 [ (SA634A-B005A-Y048F001) ]  
M28R400CT@FBGA48 [ (SA634A-B005A-Y048F001) ]  
M28V411@TSOP40 [ (SA409T) ] M28V421@TSOP40  
[ (SA409T) ]  
M28W160B@FBGA48 [ (SA634A-B005A-Y048F001) ]  
M28W160B@TSOP48 [ (SA247-B005) ]  
M28W160BB@FBGA48 [ (SA634A-B005A-Y048F001) ]  
M28W160BB@TSOP48 [ (SA247-B005) ]  
M28W160BT@FBGA48 [ (SA634A-B005A-Y048F001) ]  
M28W160BT@TSOP48 [ (SA247-B005) ]  
M28W160CB@FBGA48 [ (SA634A-B005A-Y048F001) ]  
M28W160CB@TSOP48 [ (SA247-B005) ]  
M28W160CT@FBGA48 [ (SA634A-B005A-Y048F001) ]  
M28W160CT@TSOP48 [ (SA247-B005) ]  
M28W160ECB@FBGA48 [ (SA634A-B005A-Y048F001Y) ]  
M28W160ECB@TSOP48 [ (SA247-B005) ]  
M28W160ECT@FBGA48 [ (SA634A-B005A-Y048F001Y) ]  
M28W160ECT@TSOP48 [ (SA247-B005) ]  
M28W160ESB@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
M28W160EST@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
M28W160T@FBGA48 [ (SA634A-B005A-Y048F001) ]  
M28W160T@TSOP48 [ (SA247-B005) ]  
M28W320CB@FBGA48 [ (SA634A-B005A-Y048F001) ]  
M28W320CB@TSOP48 [ (SA247-B005) ]  
M28W320CT@FBGA48 [ (SA634A-B005A-Y048F001) ]  
M28W320CT@TSOP48 [ (SA247-B005) ]  
M28W320ECB@FBGA48 [ (SA634A-B005A-Y048F001) ]  
M28W320ECB@TSOP48 [ (SA247-B005) ]  
M28W320ECT@FBGA48 [ (SA634A-B005A-Y048F001) ]  
M28W320ECT@TSOP48 [ (SA247-B005) ]  
M28W320FCB@FBGA48 [ (SA634A-B005A-Y048F001Y) ]  
M28W320FCB@TSOP48 [ (SA247-B005) ]  
M28W320FCT@FBGA48 [ (SA634A-B005A-Y048F001Y) ]  
M28W320FCT@TSOP48 [ (SA247-B005) ]  
M28W320FSB@FBGA47 [ (SA714B-B026A-T048F001Y) ]  
M28W320FSB@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
M28W320FST@FBGA47 [ (SA714B-B026A-T048F001Y) ]  
M28W320FST@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
M28W320FSU(Double)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
M28W320FSU@FBGA64 [ (SA655E-B090A-T064F001Y) ]

M28W320HSB@FBGA47 [ ( SA714B-B026A-T048F001Y ) ]  
M28W320HSB@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W320HST@FBGA47 [ ( SA714B-B026A-T048F001Y ) ]  
M28W320HST@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W320HSU(Double)@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W320HSU@FBGA47 [ ( SA714B-B026A-T048F001Y ) ]  
M28W320HSU@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W640ECB@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W640ECB@TSOP48 [ ( SA247-B005 ) ]  
M28W640ECT@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W640ECT@TSOP48 [ ( SA247-B005 ) ]  
M28W640FCB@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
M28W640FCB@TSOP48 [ ( SA247-B005 ) ]  
M28W640FCT@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
M28W640FCT@TSOP48 [ ( SA247-B005 ) ]  
M28W640FSB@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W640FST@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W640FSU@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W640HSB@FBGA48 [ ( SA714B-B026A-T048F001Y ) ]  
M28W640HSB@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W640HST@FBGA48 [ ( SA714B-B026A-T048F001Y ) ]  
M28W640HST@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W640HSU@FBGA48 [ ( SA714B-B026A-T048F001Y ) ]  
M28W640HSU@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W800B@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800B@TSOP48 [ ( SA247-B005 ) ]  
M28W800BB@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800BB@TSOP48 [ ( SA247-B005 ) ]  
M28W800BT@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800BT@TSOP48 [ ( SA247-B005 ) ]  
M28W800CB@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800CB@TSOP48 [ ( SA247-B005 ) ]  
M28W800CT@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800CT@TSOP48 [ ( SA247-B005 ) ]  
M28W800T@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800T@TSOP48 [ ( SA247-B005 ) ]  
M29DW128F@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29DW128F@TSOP56 [ ( SA628-B102 ) ]  
M29DW323DB@TFBGA48 [ ( SA642E-B026A-T072F001 ) ]  
M29DW323DB@TFBGA63 [ ( SA642E-B026A-T072F001 ) ]  
M29DW323DB@TSOP48 [ ( SA247-B005 ) ]  
M29DW323DT@TFBGA48 [ ( SA642E-B026A-T072F001 ) ]  
M29DW323DT@TFBGA63 [ ( SA642E-B026A-T072F001 ) ]

M29DW323DT@TSOP48 [(SA247-B005)]  
M29DW324DB@TFBGA48 [(SA642E-B026A-T072F001)]  
M29DW324DB@TFBGA63 [(SA642E-B026A-T072F001)]  
M29DW324DB@TSOP48 [(SA247-B005)]  
M29DW324DT@TFBGA48 [(SA642E-B026A-T072F001)]  
M29DW324DT@TFBGA63 [(SA642E-B026A-T072F001)]  
M29DW324DT@TSOP48 [(SA247-B005)]  
M29DW640D@FBGA63 [(SA642E-B026A-T072F001N)]  
M29DW640D@TSOP48 [(SA247-B005)]  
M29DW640F@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29DW640F@TSOP48 [(SA247-B005)]  
M29DW641F@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29DW641F@TSOP48 [(SA247-B005)]  
M29F002B  
M29F002B@PLCC32 [(SA015A1T)] M29F002B@TSOP32  
[(SA410T)]  
M29F002BB M29F002BB@PLCC32  
[(SA015A1T)]  
M29F002BB@TSOP32 [(SA410T)]  
M29F002BNT  
M29F002BNT@PLCC32 [(SA015A1T)] M29F002BNT@TSOP32  
[(SA410T)]  
M29F002BT M29F002BT@PLCC32  
[(SA015A1T)]  
M29F002BT@TSOP32 [(SA410T)]  
M29F002T  
M29F002T@PLCC32 [(SA015A1T)] M29F002T@TSOP32  
[(SA410T)]  
M29F010B M29F010B@PLCC32  
[(SA015A1T)]  
M29F010B@TSOP32 [(SA410T)] M29F016B@PSOP44  
[(SA638)]  
M29F016B@TSOP40 [(SA409T)] M29F016D@PSOP44  
[(SA638)]  
M29F016D@TSOP40 [(SA409T)] M29F032D@TSOP40  
[(SA409T)]  
M29F040 M29F040@PLCC32  
[(SA015A1T)]  
M29F040@TSOP32 [(SA410T)]  
M29F040B  
M29F040B@PLCC32 [(SA015A1T)] M29F040B@TSOP32  
[(SA410T)]  
M29F080A@PSOP44 [(SA638)] M29F080A@TSOP40



[ (SA409T) ]	
M29F080D@PSOP44 [ (SA638) ]	M29F080D@TSOP40
[ (SA409T) ]	
M29F100B@PSOP44 [ (SA638-B006) ]	M29F100B@TSOP48 [ (SA247-
B005) ]	
M29F100T@PSOP44 [ (SA638-B006) ]	M29F100T@TSOP48 [ (SA247-
B005) ]	
M29F102B@PLCC44 [ (SA244) ]	M29F102B@TSOP40
[ (SA623) ]	
M29F102BB@PLCC44 [ (SA244) ]	M29F102BB@TSOP40
[ (SA623) ]	
M29F160BB@TSOP48 [ (SA247-B005) ]	M29F160BT@TSOP48 [ (SA247-
B005) ]	
M29F200B@PSOP44 [ (SA638-B006) ]	M29F200B@TSOP48 [ (SA247-
B005) ]	
M29F200BB@PSOP44 [ (SA638-B006) ]	M29F200BB@TSOP48 [ (SA247-
B005) ]	
M29F200BT@PSOP44 [ (SA638-B006) ]	M29F200BT@TSOP48 [ (SA247-
B005) ]	
M29F200T@PSOP44 [ (SA638-B006) ]	M29F200T@TSOP48 [ (SA247-
B005) ]	
M29F400B@PSOP44 [ (SA638-B006) ]	M29F400B@TSOP48 [ (SA247-
B005) ]	
M29F400BB@PSOP44 [ (SA638-B006) ]	M29F400BB@TSOP48 [ (SA247-
B005) ]	
M29F400BT@PSOP44 [ (SA638-B006) ]	M29F400BT@TSOP48 [ (SA247-
B005) ]	
M29F400T@PSOP44 [ (SA638-B006) ]	M29F400T@TSOP48 [ (SA247-
B005) ]	
M29F512B@PLCC32 [ (SA015A1T) ]	M29F512B@TSOP32
[ (SA620) ]	
M29F800AB@PSOP44 [ (SA638-B006) ]	M29F800AB@TSOP48 [ (SA247-
B005) ]	
M29F800AT@PSOP44 [ (SA638-B006) ]	M29F800AT@TSOP48 [ (SA247-
B005) ]	
M29F800DB@PSOP44 [ (SA638) ]	M29F800DB@TSOP48 [ (SA247-
B005) ]	
M29F800DT@PSOP44 [ (SA638) ]	M29F800DT@TSOP48 [ (SA247-
B005) ]	
M29KW016E@PSOP44 [ (SA638) ]	
M29KW016E@TFBGA48 [ (SA642E-B026A-T072F001) ]	
M29KW016E@TSOP48 [ (SA247-B005) ]	
M29KW032E@TFBGA48 [ (SA642E-B026A-T072F001) ]	

M29KW032E@TSOP48 [ ( SA247-B005 ) ]  
M29KW064E@TFBGA48 [ ( SA642E-B026A-T072F001 ) ]  
M29KW064E@TSOP48 [ ( SA247-B005 ) ] M29V040@PLCC32  
[ ( SA015A1T ) ]  
M29V040@TSOP32 [ ( SA410T ) ] M29W004B@TSOP40  
[ ( SA409T ) ]  
M29W004BB@TSOP40 [ ( SA409T ) ] M29W004BT@TSOP40  
[ ( SA409T ) ]  
M29W004T@TSOP40 [ ( SA409T ) ] M29W008AB@TSOP40  
[ ( SA409T ) ]  
M29W008AT@TSOP40 [ ( SA409T ) ] M29W008B@TSOP40  
[ ( SA409T ) ]  
M29W008T@TSOP40 [ ( SA409T ) ] M29W010B@PLCC32  
[ ( SA015A1T ) ]  
M29W010B@TSOP32 [ ( SA410T ) ]  
M29W017D@TFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
M29W017D@TSOP40 [ ( SA409T ) ]  
M29W022BB  
M29W022BB@PLCC32 [ ( SA015A1T ) ] M29W022BB@TSOP32  
[ ( SA410T ) ]  
M29W022BT M29W022BT@PLCC32  
[ ( SA015A1T ) ]  
M29W022BT@TSOP32 [ ( SA410T ) ] M29W040@PLCC32  
[ ( SA015A1T ) ]  
M29W040@TSOP32 [ ( SA410T ) ] M29W040B@PLCC32  
[ ( SA015A1T ) ]  
M29W040B@TSOP32 [ ( SA410T ) ] M29W102BB@TSOP40  
[ ( SA623 ) ]  
M29W102BT@TSOP40 [ ( SA623 ) ] M29W116BB@TSOP40  
[ ( SA409T ) ]  
M29W116BT@TSOP40 [ ( SA409T ) ]  
M29W128FH@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W128FH@TSOP56 [ ( SA628-B102 ) ]  
M29W128FL@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W128FL@TSOP56 [ ( SA628-B102 ) ]  
M29W128GH@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W128GH@TSOP56 [ ( SA628-B102 ) ]  
M29W128GL@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W128GL@TSOP56 [ ( SA628-B102 ) ]  
M29W160BB@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W160BB@PSOP44 [ ( SA638 ) ] M29W160BB@TSOP48 [ ( SA247-  
B005 ) ]  
M29W160BT@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]

M29W160BT@PSOP44 [ ( SA638 ) ] M29W160BT@TSOP48 [ ( SA247-  
B005 ) ]  
M29W160DB@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W160DB@PSOP44 [ ( SA638 ) ] M29W160DB@TSOP48 [ ( SA247-  
B005 ) ]  
M29W160DT@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W160DT@PSOP44 [ ( SA638 ) ] M29W160DT@TSOP48 [ ( SA247-  
B005 ) ]  
M29W160EB@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W160EB@PSOP44 [ ( SA638 ) ] M29W160EB@TSOP48 [ ( SA247-  
B005 ) ]  
M29W160ET@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W160ET@PSOP44 [ ( SA638 ) ] M29W160ET@TSOP48 [ ( SA247-  
B005 ) ]  
M29W160FB@TSOP48 [ ( SA247-B005 ) ] M29W160FT@TSOP48 [ ( SA247-  
B005 ) ]  
M29W200BB@PSOP44 [ ( SA638 ) ] M29W200BB@TSOP48 [ ( SA247-  
B005 ) ]  
M29W200BT@PSOP44 [ ( SA638 ) ] M29W200BT@TSOP48 [ ( SA247-  
B005 ) ]  
M29W320DB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W320DB@FBGA63 [ ( SA642DD-B026A-W063F001Y ) ]  
M29W320DB@TSOP48 [ ( SA247-B005 ) ]  
M29W320DT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W320DT@FBGA63 [ ( SA642DD-B026A-W063F001Y ) ]  
M29W320DT@TSOP48 [ ( SA247-B005 ) ]  
M29W320EB@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
M29W320EB@TSOP48 [ ( SA247-B005 ) ]  
M29W320ET@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
M29W320ET@TSOP48 [ ( SA247-B005 ) ] M29W400B@PSOP44  
[ ( SA638 ) ]  
M29W400B@TSOP48 [ ( SA247-B005 ) ]  
M29W400BB@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W400BB@PSOP44 [ ( SA638 ) ] M29W400BB@TSOP48 [ ( SA247-  
B005 ) ]  
M29W400BT@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W400BT@PSOP44 [ ( SA638 ) ] M29W400BT@TSOP48 [ ( SA247-  
B005 ) ]  
M29W400DB( ZA )@LBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
M29W400DB( ZE )@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W400DB@PSOP44 [ ( SA638 ) ] M29W400DB@TSOP48 [ ( SA247-  
B005 ) ]  
M29W400DT( ZA )@LBGA48 [ ( SA642N-B026A-W048F001Y ) ]

M29W400DT(ZE)@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W400DT@PSOP44 [(SA638)] M29W400DT@TSOP48 [(SA247-B005)]  
M29W400T@PSOP44 [(SA638)] M29W400T@TSOP48 [(SA247-B005)]  
M29W512B@PLCC32 [(SA015A1T)] M29W512B@TSOP32 [(SA620)]  
M29W640DB@FBGA63 [(SA642E-B026A-T072F001)]  
M29W640DB@TSOP48 [(SA247-B005)]  
M29W640DT@FBGA63 [(SA642E-B026A-T072F001)]  
M29W640DT@TSOP48 [(SA247-B005)]  
M29W640FB@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640FB@TSOP48 [(SA247-B005)]  
M29W640FT@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640FT@TSOP48 [(SA247-B005)]  
M29W640GB@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GB@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GB@TSOP48 [(SA247-B005)] M29W640GB@TSOP56 [(SA628-B102)]  
M29W640GH@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GH@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GH@TSOP48 [(SA247-B005)] M29W640GH@TSOP56 [(SA628-B102)]  
M29W640GL@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GL@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GL@TSOP48 [(SA247-B005)] M29W640GL@TSOP56 [(SA628-B102)]  
M29W640GSB@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GSB@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GSB@TSOP48 [(SA247-B005)] M29W640GSB@TSOP56 [(SA628-B102)]  
M29W640GSH@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GSH@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GSH@TSOP48 [(SA247-B005)] M29W640GSH@TSOP56 [(SA628-B102)]  
M29W640GSL@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GSL@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GSL@TSOP48 [(SA247-B005)] M29W640GSL@TSOP56 [(SA628-B102)]  
M29W640GST@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GST@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GST@TSOP48 [(SA247-B005)] M29W640GST@TSOP56 [(SA628-B102)]

M29W640GT@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W640GT@FBGA64 [(SA655E-B099A-T064F001Y)]  
M29W640GT@TSOP48 [(SA247-B005)] M29W640GT@TSOP56 [(SA628-B102)]  
M29W641DH@TSOP48 [(SA247-B005)] M29W641DL@TSOP48 [(SA247-B005)]  
M29W641DU@FBGA63 [(SA642E-B026A-T072F001)]  
M29W800AB@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W800AB@PSOP44 [(SA638)] M29W800AB@TSOP48 [(SA247-B005)]  
M29W800AT@LBGA48 [(SA642G-B026A-T048F001Y)]  
M29W800AT@PSOP44 [(SA638)] M29W800AT@TSOP48 [(SA247-B005)]  
M29W800B@PSOP44 [(SA638)] M29W800B@TSOP48 [(SA247-B005)]  
M29W800DB@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W800DB@PSOP44 [(SA638)] M29W800DB@TSOP48 [(SA247-B005)]  
M29W800DT@FBGA48 [(SA642G-B026A-T048F001Y)]  
M29W800DT@PSOP44 [(SA638)] M29W800DT@TSOP48 [(SA247-B005)]  
M29W800T@PSOP44 [(SA638)] M29W800T@TSOP48 [(SA247-B005)]  
M30L0R7000B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M30L0R7000T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M30L0R8000B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M30L0R8000T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M30L0T8800B0@FBGA88 [(SA642R-B154A-T096F001Y)]  
M30L0T8800T0@FBGA88 [(SA642R-B154A-T096F001Y)]  
M30W0R6600T0@LFBGA88 [(SA642A-B061A-Y096F001)]  
M30WR128B@LFBGA88 [(SA642A-B061A-Y096F001)]  
M34C02 M34C02@MSOP8  
[(SA666)]  
M34C02@SOIC8 [(SA602A)] M34C02@TSOP8  
[(SA026)]  
M34D32 M34D32@SOIC8  
[(SA602A)]  
M34D32@TSSOP8 [(SA026)]  
M34D64 M34D64@TSSOP8  
M34D64@SOIC8 [(SA602A)]  
[(SA026)]  
M34E02 M34E02@MSOP8  
[(SA666)]

M34E02@SOIC8 [(SA602A)] M34E02@TSOP8  
[(SA026)]  
M35080 M35080@SOIC8  
[(SA602A)]  
M36A0W5020B0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5020T0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5030B0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5030T0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5040B0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36A0W5040T0@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36D0R5030B0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5030B0(Q\_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5030T0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5030T0(Q\_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5040B0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5040B0(Q\_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5040T0(EFP)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R5040T0(Q\_Word)@FBGA67 [(SA642E-B023A-T072F001Y)]  
M36D0R6040B0(EFP)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36D0R6040B0(Q\_Word)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36D0R6040T0(EFP)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36D0R6040T0(Q\_Word)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36DR232A@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36DR232B@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36DR432AD@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36DR432BD@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36L0R7040B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7040T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050L1@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R7050L2@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R7050T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050U1@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R7050U2@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R7060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7060L1@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R7060T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7060U1@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R8060B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060L0@FBGA88 [(SA642R-B180A-T096F001Y)]

M36L0R8060T0@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0R8060T1@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0R8060U0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
M36L0T7040B0@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0T7040T0@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0T7050B0@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0T7050B1@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0T7050T0@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0T7050T1@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0T7060B0@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0T7060B1@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0T7060T0@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0T7060T1@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0T8050B1@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0T8050T1@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0T8060B0@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0T8060B1@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0T8060T0@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36L0T8060T1@FBGA88 [ ( SA642R-B124A-T096F001Y ) ]  
M36LLR8760B1@FBGA88 [ ( SA642R-B113A-T096F001Y ) ]  
M36LLR8760D1@FBGA88 [ ( SA642R-B113A-T096F001Y ) ]  
M36LLR8760M1@FBGA88 [ ( SA642R-B113A-T096F001Y ) ]  
M36LLR8760T1@FBGA88 [ ( SA642R-B113A-T096F001Y ) ]  
M36LLR8860B1@FBGA88 [ ( SA642R-B113A-T096F001Y ) ]  
M36LLR8860D1@FBGA88 [ ( SA642R-B113A-T096F001Y ) ]  
M36LLR8860M1@FBGA88 [ ( SA642R-B113A-T096F001Y ) ]  
M36LLR8860T1@FBGA88 [ ( SA642R-B113A-T096F001Y ) ]  
M36LLR8870B0@FBGA88 [ ( SA642R-B113A-T096F001Y ) ]  
M36LLR8870B1@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]  
M36LLR8870D0@FBGA88 [ ( SA642R-B113A-T096F001Y ) ]  
M36LLR8870D1@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]  
M36LLR8870M0@FBGA88 [ ( SA642R-B113A-T096F001Y ) ]  
M36LLR8870M1@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]  
M36LLR8870T0@FBGA88 [ ( SA642R-B113A-T096F001Y ) ]  
M36LLR8870T1@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]  
M36W0R5020B0 ( EFP ) @FBGA88 [ ( SA642R-B107A-T096F001Y ) ]  
M36W0R5020B0 ( Q\_Word ) @FBGA88 [ ( SA642R-B107A-T096F001Y ) ]  
M36W0R5020T0 ( EFP ) @FBGA88 [ ( SA642R-B107A-T096F001Y ) ]  
M36W0R5020T0 ( Q\_Word ) @FBGA88 [ ( SA642R-B107A-T096F001Y ) ]  
M36W0R5030B0 ( EFP ) @FBGA88 [ ( SA642R-B107A-T096F001Y ) ]  
M36W0R5030B0 ( Q\_Word ) @FBGA88 [ ( SA642R-B107A-T096F001Y ) ]  
M36W0R5030T0 ( EFP ) @FBGA88 [ ( SA642R-B107A-T096F001Y ) ]  
M36W0R5030T0 ( Q\_Word ) @FBGA88 [ ( SA642R-B107A-T096F001Y ) ]

M36W0R5040B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5040B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5040L3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R5040T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5040T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5040U3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6030B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6030B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6030T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6030T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040B1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0R6040L3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6040T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040T1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0R6040U3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6050B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050B1@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050L0@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6050T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050T1@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050U0@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0T5040B1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T5040T1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040B0@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040B1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040T0@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040T1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T7050B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36W0T7050T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36W216BI@LFBGA66 [(SA642E-B041A-T072F001)]  
M36W216TI@LFBGA66 [(SA642E-B041A-T072F001)]  
M36W432BG@LFBGA66 [(SA642E-B041A-T072F001)]  
M36W432TG@LFBGA66 [(SA642E-B041A-T072F001)]  
M36W864BE@LFBGA67 [(SA642E-B041A-T072F001)]  
M36W864TE@LFBGA67 [(SA642E-B041A-T072F001)]  
M36WWR6650B0@LFBGA88 [(SA642A-B076A-Y096F001)]  
M36WWR6650D0@LFBGA88 [(SA642A-B076A-Y096F001)]  
M36WWR6650T0@LFBGA88 [(SA642A-B076A-Y096F001)]



M45PE10@SOIC8 [(SA602A)]	M45PE10@VQFPN8
[(SA683)]	
M45PE16@SOIC8 [(SA023A)]	M45PE16@VQFPN8
[(SA683)]	
M45PE20@SOIC8 [(SA602A)]	
M45PE20@SOIC8(ISP) [ISP-HEADER01]	
M45PE20@VQFPN8 [(SA683)]	
M45PE20@VQFPN8(ISP) [ISP-HEADER01]	
M45PE40@SOIC8 [(SA023A)]	
M45PE40@SOIC8(ISP) [ISP-HEADER01]	
M45PE40@VQFPN8 [(SA683)]	
M45PE40@VQFPN8(ISP) [ISP-HEADER01]	
M45PE80@SOIC16 [(SA023A)]	
M45PE80@SOIC16(ISP) [ISP-HEADER01]	
M45PE80@SOIC8 [(SA023A)]	
M45PE80@SOIC8(ISP) [ISP-HEADER01]	
M45PE80@VQFPN8 [(SA683)]	
M45PE80@VQFPN8(ISP) [ISP-HEADER01]	
M48C02	
M48C02B	
M48C12	
M48C12B	
M48T02	
M48T02B	
M48T08	
M48T12	
M48T128V	
M48T128Y	
M48T129V	
M48T129Y	
M48T12B	
M48T18	
M48T30	
M48T30Y	
M48T32	
M48T32Y	
M48T35	M48T35@SOIC28
[(SA404)]	
M48T35AV	M48T35AV@SOIC28
[(SA630)]	
M48T35AY	M48T35AY@SOIC28
[(SA630)]	
M48T35Y	M48T35Y@SOIC28

[ ( SA404 ) ]  
M48T512AV  
M48T512AY  
M48T512V  
M48T512Y  
M48T559 M48T559@SOIC28  
[ ( SA630 ) ]  
M48T559Y M48T559Y@SOIC28  
[ ( SA630 ) ]  
M48T58 M48T58@SOIC28  
[ ( SA404 ) ]  
M48T58Y M48T58Y@SOIC28  
[ ( SA404 ) ]  
M48T59 M48T59@SOIC28  
[ ( SA404 ) ]  
M48T59V M48T59V@SOIC28  
[ ( SA404 ) ]  
M48T59Y M48T59Y@SOIC28  
[ ( SA404 ) ]  
M48Z02  
M48Z02B  
M48Z08  
M48Z12  
M48Z128  
M48Z128V  
M48Z128Y  
M48Z129V  
M48Z129Y  
M48Z12B  
M48Z18  
M48Z30  
M48Z30Y  
M48Z32  
M48Z32Y  
M48Z35  
M48Z35@SOIC28 [ ( SA630 ) ]  
M48Z35Y  
M48Z35Y@SOIC28 [ ( SA630 ) ]  
M48Z512AV  
M48Z512AY  
M48Z512V  
M48Z512Y  
M48Z58

M48Z58@SOIC28 [(SA404)]  
M48Z58Y  
M48Z58Y@SOIC28 [(SA404)]  
M48Z59  
M48Z59@SOIC28 [(SA404)]  
M48Z59W  
M48Z59W@SOIC28 [(SA404)]  
M48Z59Y  
M48Z59Y@SOIC28 [(SA404)] M50FLW040A@PLCC32  
[(SA015A1T)]  
M50FLW040A@TSOP40 [(SA409T)] M50FLW040A@VSOP32  
[(SA620)]  
M50FLW040B@PLCC32 [(SA015A1T)] M50FLW040B@TSOP40  
[(SA409T)]  
M50FLW040B@VSOP32 [(SA620)] M50FLW080A@PLCC32  
[(SA015A1T)]  
M50FLW080A@TSOP40 [(SA409T)] M50FLW080A@VSOP32  
[(SA620)]  
M50FLW080B@PLCC32 [(SA015A1T)] M50FLW080B@TSOP40  
[(SA409T)]  
M50FLW080B@VSOP32 [(SA620)] M50FW002@PLCC32  
[(SA015A1T)]  
M50FW016@TSOP40 [(SA409T)] M50FW020@PLCC32  
[(SA015A1T)]  
M50FW040@PLCC32 [(SA015A1T)] M50FW040@TSOP40  
[(SA409T)]  
M50FW080@PLCC32 [(SA015A1T)] M50FW080@TSOP40  
[(SA409T)]  
M50FW080@VSOP32 [(SA620)] M50LPW002@PLCC32  
[(SA015A1T)]  
M50LPW012@PLCC32 [(SA015A1T)] M50LPW020@PLCC32  
[(SA015A1T)]  
M50LPW040@PLCC32 [(SA015A1T)] M50LPW040@TSOP40  
[(SA409T)]  
M50LPW041@PLCC32 [(SA015A1T)] M50LPW041@TSOP40  
[(SA409T)]  
M50LPW080@PLCC32 [(SA015A1T)] M50LPW080@TSOP40  
[(SA409T)]  
M50LPW116@TSOP40 [(SA409T)]  
M58LR128FB@VFBGA56 [(SA644A-B025B-Y072F001)]  
M58LR128FT@VFBGA56 [(SA644A-B025B-Y072F001)]  
M58LR128GB@VFBGA56 [(SA644A-B025B-Y072F001)]  
M58LR128GL@FBGA44 [(SA733A-B206A-M056F001Y)]

M58LR128GT@VFBGA56 [ (SA644A-B025B-Y072F001) ]  
M58LR128GU@FBGA44 [ (SA733A-B206A-M056F001Y) ]  
M58LR256GL@FBGA44 [ (SA733C-B206A-M056F001N) ]  
M58LR256GU@FBGA44 [ (SA733C-B206A-M056F001N) ]  
M58LT128GB@FBGA56 [ (SA644A-B025B-Y072F001Y) ]  
M58LT128GSB@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
M58LT128GST@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
M58LT128GT@FBGA56 [ (SA644A-B025B-Y072F001Y) ]  
M58LT128HSB@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
M58LT128HST@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
M58LT256GB@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
M58LT256GT@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
M58LW032A@TSOP56 [ (SA628-B031) ]  
M58LW032C@FBGA64 [ (SA655A-B054A-T064F001) ]  
M58LW032C@TSOP56 [ (SA628-B031) ]  
M58LW032D@FBGA64 [ (SA655A-B054A-T064F001) ]  
M58LW032D@TSOP56 [ (SA628-B018) ]  
M58LW064C@FBGA64 [ (SA655A-B054A-T064F001) ]  
M58LW064C@TSOP56 [ (SA628-B063) ]  
M58LW064D@FBGA64 [ (SA655A-B054A-T064F001) ]  
M58LW064D@TSOP56 [ (SA628-B018) ] M58LW128A@TSOP56 [ (SA628-B018) ]  
M58WR016QB(EFP)@FBGA56 [ (SA656C-B104A-T056F001Y) ]  
M58WR016QB(Q\_Word)@FBGA56 [ (SA656C-B104A-T056F001Y) ]  
M58WR016QL@FBGA44 [ (SA733A-B206A-M056F001N) ]  
M58WR016QT(EFP)@FBGA56 [ (SA656C-B104A-T056F001Y) ]  
M58WR016QT(Q\_Word)@FBGA56 [ (SA656C-B104A-T056F001Y) ]  
M58WR016QU@FBGA44 [ (SA733A-B206A-M056F001N) ]  
M58WR032EB(EFP)@FBGA56 [ (SA644A-B025B-Y072F001) ]  
M58WR032EB(Q\_Word)@FBGA56 [ (SA644A-B025B-Y072F001) ]  
M58WR032ET(EFP)@FBGA56 [ (SA644A-B025B-Y072F001) ]  
M58WR032ET(Q\_Word)@FBGA56 [ (SA644A-B025B-Y072F001) ]  
M58WR032FB(EFP)@FBGA56 [ (SA644A-B025B-Y072F001) ]  
M58WR032FB(Q\_Word)@FBGA56 [ (SA644A-B025B-Y072F001) ]  
M58WR032FT(EFP)@FBGA56 [ (SA644A-B025B-Y072F001) ]  
M58WR032FT(Q\_Word)@FBGA56 [ (SA644A-B025B-Y072F001) ]  
M58WR032HB@FBGA56 [ (SA656C-B104A-T056F001Y) ]  
M58WR032HT@FBGA56 [ (SA656C-B104A-T056F001Y) ]  
M58WR032QB(EFP)@FBGA56 [ (SA656C-B104A-T056F001Y) ]  
M58WR032QB(Q\_Word)@FBGA56 [ (SA656C-B104A-T056F001Y) ]  
M58WR032QL@FBGA44 [ (SA733A-B206A-M056F001N) ]  
M58WR032QT(EFP)@FBGA56 [ (SA656C-B104A-T056F001Y) ]  
M58WR032QT(Q\_Word)@FBGA56 [ (SA656C-B104A-T056F001Y) ]

M58WR032QU@FBGA44 [(SA733A-B206A-M056F001N)]  
M58WR064EB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064EB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064ET(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064ET(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FT(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FT(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064HB@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR064HT@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR128FB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR128FB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR128FT(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR128FT(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M59DR008E@FBGA48 [(SA634A-B005-Y048F001Y)]  
M59DR008E@TSOP48 [(SA247-B005)]  
M59DR008F@FBGA48 [(SA634A-B005-Y048F001Y)]  
M59DR008F@TSOP48 [(SA247-B005)]  
M59DR016C@FBGA48 [(SA634A-B005A-Y048N001N)]  
M59DR016D@FBGA48 [(SA634A-B005A-Y048N001N)]  
M59PW016@PSOP44 [(SA638)] M59PW016@SDIP42  
[(SA028)]  
M59PW016@TSOP48 [(SA247-B005)] M59PW032@PSOP44  
[(SA638)]  
M59PW032@PSOP44(Fast) [(SA638+B006)]  
M59PW032@TSOP48 [(SA247-B005)] M59PW064@PSOP44  
[(SA638)]  
M59PW1282@PSOP44 [(SA638)]  
M72DW64000B@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M72DW75000C@FBGA73 [(SA642A-B039A-Y096F001Y)]  
M72DW75001C@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M72DW76001D@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M76DW52003BA@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M76DW52003TA@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M76DW52004BA@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M76DW52004TA@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M76DW62000A@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M76DW63000A@FBGA73 [(SA642A-B032A-Y096F001Y)]  
M87C257 M87C257@PLCC32  
[(SA015A1T)]  
M93C06(08bit) M93C06(08bit)@SOIC8  
[(SA602A)]

M93C06(16bit) [(SA602A)]	M93C06(16bit)@SOIC8
M93C46(08bit) [(SA694)]	M93C46(08bit)@MLP8
M93C46(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C46(08bit)@SOIC8
M93C46(08bit)@TSSOP8 [(SA026)] (16bit)	M93C46
M93C46(16bit)@MLP8 [(SA694)] [(SA666)]	M93C46(16bit)@MSOP8
M93C46(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C46(16bit)@TSSOP8
M93C46R(08bit) [(SA694)]	M93C46R(08bit)@MLP8
M93C46R(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C46R(08bit)@SOIC8
M93C46R(08bit)@TSSOP8 [(SA026)] (16bit)	M93C46R
M93C46R(16bit)@MLP8 [(SA694)] [(SA666)]	M93C46R(16bit)@MSOP8
M93C46R(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C46R(16bit)@TSSOP8
M93C46W(08bit) [(SA694)]	M93C46W(08bit)@MLP8
M93C46W(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C46W(08bit)@SOIC8
M93C46W(08bit)@TSSOP8 [(SA026)] (16bit)	M93C46W
M93C46W(16bit)@MLP8 [(SA694)] [(SA666)]	M93C46W(16bit)@MSOP8
M93C46W(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C46W(16bit)@TSSOP8
M93C56(08bit) [(SA694)]	M93C56(08bit)@MLP8
M93C56(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C56(08bit)@SOIC8
M93C56(08bit)@TSSOP8 [(SA026)] (16bit)	M93C56
M93C56(16bit)@MLP8 [(SA694)] [(SA666)]	M93C56(16bit)@MSOP8
M93C56(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C56(16bit)@TSSOP8
M93C56R(08bit)	M93C56R(08bit)@MLP8

[(SA694)]	
M93C56R(08bit)@MSOP8 [(SA666)]	M93C56R(08bit)@SOIC8
[(SA602A)]	
M93C56R(08bit)@TSSOP8 [(SA026)]	M93C56R
(16bit)	
M93C56R(16bit)@MLP8 [(SA694)]	M93C56R(16bit)@MSOP8
[(SA666)]	
M93C56R(16bit)@SOIC8 [(SA602A)]	M93C56R(16bit)@TSSOP8
[(SA026)]	
M93C56W(08bit)	M93C56W(08bit)@MLP8
[(SA694)]	
M93C56W(08bit)@MSOP8 [(SA666)]	M93C56W(08bit)@SOIC8
[(SA602A)]	
M93C56W(08bit)@TSSOP8 [(SA026)]	M93C56W
(16bit)	
M93C56W(16bit)@MLP8 [(SA694)]	M93C56W(16bit)@MSOP8
[(SA666)]	
M93C56W(16bit)@SOIC8 [(SA602A)]	M93C56W(16bit)@TSSOP8
[(SA026)]	
M93C66(08bit)	M93C66(08bit)@MLP8
[(SA694)]	
M93C66(08bit)@MSOP8 [(SA666)]	M93C66(08bit)@SOIC8
[(SA602A)]	
M93C66(08bit)@TSSOP8 [(SA026)]	M93C66
(16bit)	
M93C66(16bit)@MLP8 [(SA694)]	M93C66(16bit)@MSOP8
[(SA666)]	
M93C66(16bit)@SOIC8 [(SA602A)]	M93C66(16bit)@TSSOP8
[(SA026)]	
M93C66R(08bit)	M93C66R(08bit)@MLP8
[(SA694)]	
M93C66R(08bit)@MSOP8 [(SA666)]	M93C66R(08bit)@SOIC8
[(SA602A)]	
M93C66R(08bit)@TSSOP8 [(SA026)]	M93C66R
(16bit)	
M93C66R(16bit)@MLP8 [(SA694)]	M93C66R(16bit)@MSOP8
[(SA666)]	
M93C66R(16bit)@SOIC8 [(SA602A)]	M93C66R(16bit)@TSSOP8
[(SA026)]	
M93C66W(08bit)	M93C66W(08bit)@MLP8
[(SA694)]	
M93C66W(08bit)@MSOP8 [(SA666)]	M93C66W(08bit)@SOIC8
[(SA602A)]	

M93C66W(08bit)@TSSOP8 [(SA026)] (16bit)	M93C66W
M93C66W(16bit)@MLP8 [(SA694)] [(SA666)]	M93C66W(16bit)@MSOP8
M93C66W(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C66W(16bit)@TSSOP8
M93C76(08bit) [(SA694)]	M93C76(08bit)@MLP8
M93C76(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C76(08bit)@SOIC8
M93C76(08bit)@TSSOP8 [(SA026)] (16bit)	M93C76
M93C76(16bit)@MLP8 [(SA694)] [(SA666)]	M93C76(16bit)@MSOP8
M93C76(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C76(16bit)@TSSOP8
M93C76R(08bit) [(SA694)]	M93C76R(08bit)@MLP8
M93C76R(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C76R(08bit)@SOIC8
M93C76R(08bit)@TSSOP8 [(SA026)] (16bit)	M93C76R
M93C76R(16bit)@MLP8 [(SA694)] [(SA666)]	M93C76R(16bit)@MSOP8
M93C76R(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C76R(16bit)@TSSOP8
M93C76W(08bit) [(SA694)]	M93C76W(08bit)@MLP8
M93C76W(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C76W(08bit)@SOIC8
M93C76W(08bit)@TSSOP8 [(SA026)] (16bit)	M93C76W
M93C76W(16bit)@MLP8 [(SA694)] [(SA666)]	M93C76W(16bit)@MSOP8
M93C76W(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C76W(16bit)@TSSOP8
M93C86(08bit) [(SA694)]	M93C86(08bit)@MLP8
M93C86(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C86(08bit)@SOIC8
M93C86(08bit)@TSSOP8 [(SA026)] (16bit)	M93C86
M93C86(16bit)@MLP8 [(SA694)]	M93C86(16bit)@MSOP8



[ (SA666) ]	
M93C86(16bit)@SOIC8 [ (SA602A) ]	M93C86(16bit)@TSSOP8
[ (SA026) ]	
M93C86R(08bit)	M93C86R(08bit)@MLP8
[ (SA694) ]	
M93C86R(08bit)@MSOP8 [ (SA666) ]	M93C86R(08bit)@SOIC8
[ (SA602A) ]	
M93C86R(08bit)@TSSOP8 [ (SA026) ]	M93C86R
(16bit)	
M93C86R(16bit)@MLP8 [ (SA694) ]	M93C86R(16bit)@MSOP8
[ (SA666) ]	
M93C86R(16bit)@SOIC8 [ (SA602A) ]	M93C86R(16bit)@TSSOP8
[ (SA026) ]	
M93C86W(08bit)	M93C86W(08bit)@MLP8
[ (SA694) ]	
M93C86W(08bit)@MSOP8 [ (SA666) ]	M93C86W(08bit)@SOIC8
[ (SA602A) ]	
M93C86W(08bit)@TSSOP8 [ (SA026) ]	M93C86W
(16bit)	
M93C86W(16bit)@MLP8 [ (SA694) ]	M93C86W(16bit)@MSOP8
[ (SA666) ]	
M93C86W(16bit)@SOIC8 [ (SA602A) ]	M93C86W(16bit)@TSSOP8
[ (SA026) ]	
M93CS566	M93CS566@SOIC8
[ (SA602A) ]	
M93S46	M93S46@SOIC8
[ (SA602A) ]	
M93S46@TSSOP8 [ (SA026) ]	
M93S46R	
M93S46R@SOIC8 [ (SA602A) ]	M93S46R@TSSOP8
[ (SA026) ]	
M93S46W	M93S46W@SOIC8
[ (SA602A) ]	
M93S46W@TSSOP8 [ (SA026) ]	
M93S56	
M93S56@SOIC8 [ (SA602A) ]	M93S56@TSSOP8
[ (SA026) ]	
M93S56R	M93S56R@SOIC8
[ (SA602A) ]	
M93S56R@TSSOP8 [ (SA026) ]	
M93S56W	
M93S56W@SOIC8 [ (SA602A) ]	M93S56W@TSSOP8
[ (SA026) ]	

M93S66	M93S66@SOIC8
[ (SA602A) ]	
M93S66@TSSOP8 [ (SA026) ]	
M93S66R	
M93S66R@SOIC8 [ (SA602A) ]	M93S66R@TSSOP8
[ (SA026) ]	
M93S66W	M93S66W@SOIC8
[ (SA602A) ]	
M93S66W@TSSOP8 [ (SA026) ]	
M95010	
M95010(ISP) [ ISP-HEADER01 ]	M95010@SOIC8
[ (SA602A) ]	
M95010@SOIC8(ISP) [ ISP-HEADER01 ]	M95010@TSSOP8
[ (SA026) ]	
M95010@TSSOP8(ISP) [ ISP-HEADER01 ]	
M95020	M95020(ISP) [ ISP-
HEADER01 ]	
M95020@SOIC8 [ (SA602A) ]	M95020@SOIC8(ISP) [ ISP-
HEADER01 ]	
M95020@TSSOP8 [ (SA026) ]	
M95020@TSSOP8(ISP) [ ISP-HEADER01 ]	
M95040	M95040(ISP) [ ISP-
HEADER01 ]	
M95040@SOIC8 [ (SA602A) ]	M95040@SOIC8(ISP) [ ISP-
HEADER01 ]	
M95040@TSSOP8 [ (SA026) ]	
M95040@TSSOP8(ISP) [ ISP-HEADER01 ]	
M95080	M95080(ISP) [ ISP-
HEADER01 ]	
M95080@SOIC8 [ (SA602A) ]	M95080@SOIC8(ISP) [ ISP-
HEADER01 ]	
M95080@TSSOP14 [ (SA026) ]	
M95080@TSSOP14(ISP) [ ISP-HEADER01 ]	
M95080@TSSOP8 [ (SA026) ]	
M95080@TSSOP8(ISP) [ ISP-HEADER01 ]	
M95128	M95128(ISP) [ ISP-
HEADER01 ]	
M95128@TSSOP14 [ (SA026) ]	
M95128@TSSOP14(ISP) [ ISP-HEADER01 ]	
M95128@TSSOP8 [ (SA026) ]	
M95128@TSSOP8(ISP) [ ISP-HEADER01 ]	
M95128[150mil]@SOIC8 [ (SA602A) ]	
M95128[150mil]@SOIC8(ISP) [ ISP-HEADER01 ]	

M95128[200mil]@SOIC8 [(SA023A)]  
M95128[200mil]@SOIC8(ISP) [ISP-HEADER01]  
M95160 M95160(ISP) [ISP-  
HEADER01]  
M95160@SOIC8 [(SA602A)] M95160@SOIC8(ISP) [ISP-  
HEADER01]  
M95160@TSSOP14 [(SA026)]  
M95160@TSSOP14(ISP) [ISP-HEADER01]  
M95160@TSSOP8 [(SA026)]  
M95160@TSSOP8(ISP) [ISP-HEADER01]  
M95256 M95256(ISP) [ISP-  
HEADER01]  
M95256@TSSOP14 [(SA026)]  
M95256@TSSOP14(ISP) [ISP-HEADER01]  
M95256@TSSOP8 [(SA026)]  
M95256@TSSOP8(ISP) [ISP-HEADER01]  
M95256[150mil]@SOIC8 [(SA602A)]  
M95256[150mil]@SOIC8(ISP) [ISP-HEADER01]  
M95256[200mil]@SOIC8 [(SA023A)]  
M95256[200mil]@SOIC8(ISP) [ISP-HEADER01]  
M95320 M95320(ISP) [ISP-  
HEADER01]  
M95320@SOIC8 [(SA602A)] M95320@SOIC8(ISP) [ISP-  
HEADER01]  
M95320@TSSOP14 [(SA026)]  
M95320@TSSOP14(ISP) [ISP-HEADER01]  
M95320@TSSOP8 [(SA026)]  
M95320@TSSOP8(ISP) [ISP-HEADER01]  
M95512@SOIC8 [(SA602A)] M95512@SOIC8(ISP) [ISP-  
HEADER01]  
M95512@TSSOP8 [(SA026)]  
M95512@TSSOP8(ISP) [ISP-HEADER01]  
M95640 M95640(ISP) [ISP-  
HEADER01]  
M95640@SOIC8 [(SA602A)] M95640@SOIC8(ISP) [ISP-  
HEADER01]  
M95640@TSSOP14 [(SA026)]  
M95640@TSSOP14(ISP) [ISP-HEADER01]  
M95640@TSSOP8 [(SA026)]  
M95640@TSSOP8(ISP) [ISP-HEADER01]  
M95M01[150mil]@SOIC8 [(SA602A)]  
M95P02  
M95P02@SOIC8 [(SA602A)]

M95P04  
M95P04@SOIC8 [(SA602A)]  
M95P08  
M95P08@SOIC8 [(SA602A)]  
MK48C02  
MK48C02B  
MK48C12  
MK48C12B  
MK48T02  
MK48T02B  
MK48T08  
MK48T12  
MK48T12B  
MK48T18  
MK48T32  
MK48T32Y  
MK48T35  
MK48T35@SOIC28 [(SA630)]  
MK48T35Y  
MK48T35Y@SOIC28 [(SA630)]  
MK48T512V  
MK48T512Y  
MK48Z02  
MK48Z02B  
MK48Z08  
MK48Z12  
MK48Z12B  
MK48Z18  
MK48Z32  
MK48Z32Y  
MK48Z35  
MK48Z35@SOIC28 [(SA630)]  
MK48Z35Y  
MK48Z35Y@SOIC28 [(SA630)]  
MK48Z512V  
MK48Z512Y  
MKI48Z02  
MKI48Z02B  
MKI48Z12  
MKI48Z12B  
MKI48Z18  
NAND01GR3B2BZA6@FBGA63 [(SA642KK-B280-W048F001Y)]  
NAND01GW3A0AN6@TSOP48 [(SA247-B005)]

NAND01GW3B2AN6E@TSOP48 [(SA247-B005)]  
 NAND01GW3B2BN6E@TSOP48 [(SA247-B005)]  
 NAND01GW3B2BZA6@FBGA63 [(SA642KK-B026-W048F001Y)]  
 NAND01GW3M2AZC5E@FBGA137 [(SA700E-B153A-M137F001Y)]  
 NAND02GR3B2CZA6E@FBGA63 [(SA642NN-B026A-W063F001Y)]  
 NAND02GW3B2AN6@TSOP48 [(SA247-B005)]  
 NAND02GW3B2CN6@TSOP48 [(SA247-B005)]  
 NAND02GW3B2CZA6E@FBGA63 [(SA642NN-B026A-W063F001Y)]  
 NAND04GW3B2BN6@TSOP48 [(SA247-B005)]  
 NAND04GW3C2AN1@TSOP48 [(SA247-B005)]  
 NAND08GW3B2AN6@TSOP48 [(SA247-B005)]  
 NAND128W3A0AN6@TSOP48 [(SA247-B005)]  
 NAND128W3A2BN6@TSOP48 [(SA247-B005)]  
 NAND256R3A2AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
 NAND256R3A2BZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
 NAND256W3A0AN6@TSOP48 [(SA247-B005)]  
 NAND256W3A0AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
 NAND256W3A2AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
 NAND256W3A2BN6@TSOP48 [(SA247-B005)]  
 NAND256W3A2BZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
 NAND512R3A2AZB6@TFBGA63 [(SA642KK-B026-W048F001Y)]  
 NAND512R3A2AZB6E@TFBGA55 [(SA642R-B026-T096F001Y)]  
 NAND512R3A2CZA6E@TFBGA63 [(SA642KK-B026-W048F001Y)]  
 NAND512R3M0AZB5@FBGA107 [(SA642V-B133-T096F001Y)]  
 NAND512W3A0AN6@TSOP48 [(SA247-B005)]  
 NAND512W3A2BN6@TSOP48 [(SA247-B005)]  
 NAND512W3A2CN6@TSOP48 [(SA247-B005)]  
 NAND512W3A2CZA6E@TFBGA63 [(SA642KK-B026-W048F001Y)]  
 NAND98R3M0AZBB5@FBGA107 [(SA642V-B133-T096F001Y)]  
 NAND99R4M2AZBA5@BGA149 [(SA664G-B279-Y149F001Y)]  
 NANDA9R4N2AZBA5@FBGA149 [(SA664G-B279-Y149F001Y)]  
 NANDC9R4N0AZBA5E@FBGA149 [(SA664G-B279-Y149F001Y)]  
 ST24C01 ST24C01@SOIC8  
 [(SA602A)]  
 ST24C02A ST24C02A@SOIC8  
 [(SA602A)]  
 ST24C16 ST24C16@SOIC8  
 [(SA602A)]  
 ST24FC21 ST24FC21@SOIC8  
 [(SA602A)]  
 ST24FW21 ST24FW21@SOIC8  
 [(SA602A)]  
 ST24LC21B ST24LC21B@SOIC8

[ (SA602A) ]	
ST24LW21	ST24LW21@SOIC8
[ (SA602A) ]	
ST24W01	ST24W01@SOIC8
[ (SA602A) ]	
ST24W02	ST24W02@SOIC8
[ (SA602A) ]	
ST24W04C	ST24W04C@SOIC8
[ (SA602A) ]	
ST26C201	ST26C201@PLCC32
[ (SA015A1T) ]	
ST26C201@TSOP32 [ (SA410T) ]	
ST27128A	
ST27256	
ST2764A	
ST27C256	ST93C06
(08bit)	
ST93C06(08bit)@SOIC8 [ (SA602A) ]	ST93C06
(16bit)	
ST93C06(16bit)@SOIC8 [ (SA602A) ]	ST93C46
(08bit)	
ST93C46(08bit)@SOIC8 [ (SA602A) ]	ST93C46
(16bit)	
ST93C46(16bit)@SOIC8 [ (SA602A) ]	ST93C46A
(08bit)	
ST93C46A(08bit)@SOIC8 [ (SA602A) ]	ST93C46A
(16bit)	
ST93C46A(16bit)@SOIC8 [ (SA602A) ]	ST93C46C
(08bit)	
ST93C46C(08bit)@SOIC8 [ (SA602A) ]	ST93C46C
(16bit)	
ST93C46C(16bit)@SOIC8 [ (SA602A) ]	ST93C46T
(08bit)	
ST93C46T(08bit)@SOIC8 [ (SA602A) ]	ST93C46T
(16bit)	
ST93C46T(16bit)@SOIC8 [ (SA602A) ]	ST93C47C
(08bit)	
ST93C47C(08bit)@SOIC8 [ (SA602A) ]	ST93C47C
(16bit)	
ST93C47C(16bit)@SOIC8 [ (SA602A) ]	ST93C47T
(08bit)	
ST93C47T(08bit)@SOIC8 [ (SA602A) ]	ST93C47T
(16bit)	

ST93C47T(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C56
ST93C56(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C56
ST93C56(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C56B
ST93C56B(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C56B
ST93C56B(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C56C
ST93C56C(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C56C
ST93C56C(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C57C
ST93C57C(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C57C
ST93C57C(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C66
ST93C66(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C66
ST93C66(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C67
ST93C67(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C67
ST93C67(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C76
ST93C76(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C76
ST93C76(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C86
ST93C86(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C86
ST93CS46	
ST93CS46@SOIC8 [(SA602A)]	
ST93CS47	
ST93CS47@SOIC8 [(SA602A)]	
ST93CS56	
ST93CS56@SOIC8 [(SA602A)]	
ST93CS566	
ST93CS566@SOIC8 [(SA602A)]	
ST93CS57	
ST93CS57@SOIC8 [(SA602A)]	

ST93CS66

ST93CS66@SOIC14 [(SA602)]

ST93CS67

ST93CS67@SOIC14 [(SA602)]

TS27C256

TS27C64

[(SA015A1T)]

TS27C64A

[(SA015A1T)]

TS28C16A

TS28C17A

TS27C64@PLCC32

TS27C64A@PLCC32

## MICROCONTROLLER

PSD211R@PLCC44 [(SA244)]

[(SA245A)]

PSD301@PLCC44 [(SA244)]

[(SA245A)]

PSD301B@PLCC44 [(SA244)]

[(SA244)]

PSD301L@TQFP44 [(SA245A)]

[(SA244)]

PSD301R@TQFP44 [(SA245A)]

[(SA244)]

PSD301V@PLCC44 [(SA244)]

[(SA244)]

PSD302@TQFP44 [(SA245A)]

[(SA244)]

PSD302B@PLCC44(USA) [(SA411A)]

[(SA244)]

PSD302L@TQFP44 [(SA245A)]

[(SA244)]

PSD302R@TQFP44 [(SA245A)]

[(SA244)]

PSD302V@PLCC44 [(SA244)]

[(SA244)]

PSD303@TQFP44 [(SA245A)]

[(SA244)]

PSD303L@TQFP44 [(SA245A)]

[(SA244)]

PSD303R@TQFP44 [(SA245A)]

[(SA244)]

PSD211R@TQFP44

PSD301@TQFP44

PSD301L@PLCC44

PSD301R@PLCC44

PSD301RV@PLCC44

PSD302@PLCC44

PSD302B@PLCC44

PSD302L@PLCC44

PSD302R@PLCC44

PSD302RV@PLCC44

PSD303@PLCC44

PSD303L@PLCC44

PSD303R@PLCC44

PSD303RV@PLCC44



PSD303V@PLCC44 [(SA244)]	PSD311@PLCC44
[(SA244)]	
PSD311@TQFP44 [(SA245A)]	PSD311B@PLCC44
[(SA244)]	
PSD311L@PLCC44 [(SA244)]	PSD311L@TQFP44
[(SA245A)]	
PSD311R@PLCC44 [(SA244)]	PSD311R@TQFP44
[(SA245A)]	
PSD311RV@PLCC44 [(SA244)]	PSD311V@PLCC44
[(SA244)]	
PSD312@PLCC44 [(SA244)]	PSD312@TQFP44
[(SA245A)]	
PSD312B@PLCC44 [(SA244)]	PSD312L@PLCC44
[(SA244)]	
PSD312L@TQFP44 [(SA245A)]	PSD312R@PLCC44
[(SA244)]	
PSD312R@TQFP44 [(SA245A)]	PSD312RV@PLCC44
[(SA244)]	
PSD312V@PLCC44 [(SA244)]	PSD313@PLCC44
[(SA244)]	
PSD313@TQFP44 [(SA245A)]	PSD313-B@PLCC44
[(SA244)]	
PSD313-B@TQFP44 [(SA245A)]	PSD313L@PLCC44
[(SA244)]	
PSD313L@TQFP44 [(SA245A)]	PSD313R@PLCC44
[(SA244)]	
PSD313R@TQFP44 [(SA245A)]	PSD313RV@PLCC44
[(SA244)]	
PSD313V@PLCC44 [(SA244)]	PSD813F1@PLCC52 [(PEP
+S415T)]	
PSD813F1@TQFP52 [(PEP+S662)]	
PSD813F1@TQFP52(*) [(TA071+B006)]	
PSD813F1A@PLCC52 [(PEP+S415T)]	PSD813F1V@PLCC52 [(PEP
+S415T)]	
PSD813F1V@TQFP52 [(PEP+S662)]	
PSD813F1V@TQFP52(*) [(TA071+B006)]	
PSD813F1VA@PLCC52 [(PEP+S415T)]	PSD813F2@PLCC52 [(PEP
+S415T)]	
PSD813F2@TQFP52 [(PEP+S662)]	
PSD813F2@TQFP52(*) [(TA071+B006)]	
PSD813F2A@PLCC52 [(PEP+S415T)]	PSD813F2V@PLCC52 [(PEP
+S415T)]	
PSD813F2V@TQFP52 [(PEP+S662)]	

PSD813F2V@TQFP52(\*) [(TA071+B006)]  
PSD813F2VA@PLCC52 [(PEP+S415T)] PSD813F3@PLCC52 [(PEP+S415T)]  
PSD813F3@TQFP52 [(PEP+S662)]  
PSD813F3@TQFP52(\*) [(TA071+B006)]  
PSD813F3V@PLCC52 [(PEP+S415T)] PSD813F3V@TQFP52 [(PEP+S662)]  
PSD813F3V@TQFP52(\*) [(TA071+B006)]  
PSD813F4@PLCC52 [(PEP+S415T)] PSD813F4@TQFP52 [(PEP+S662)]  
PSD813F4@TQFP52(\*) [(TA071+B006)]  
PSD813F4V@PLCC52 [(PEP+S415T)] PSD813F4V@TQFP52 [(PEP+S662)]  
PSD813F4V@TQFP52(\*) [(TA071+B006)]  
PSD813F5@PLCC52 [(PEP+S415T)] PSD813F5@TQFP52 [(PEP+S662)]  
PSD813F5@TQFP52(\*) [(TA071+B006)]  
PSD813F5V@PLCC52 [(PEP+S415T)] PSD813F5V@TQFP52 [(PEP+S662)]  
PSD813F5V@TQFP52(\*) [(TA071+B006)]  
PSD833F2@PLCC52 [(PEP+S415T)] PSD833F2@PQFP52 [(PEP+S662)]  
PSD833F2@TQFP52(\*) [(TA071+B006)]  
PSD833F2V@PLCC52 [(PEP+S415T)] PSD833F2V@TQFP52 [(PEP+S662)]  
PSD833F2V@TQFP52(\*) [(TA071+B006)]  
PSD834F2@PLCC52 [(PEP+S415T)] PSD834F2@TQFP52 [(PEP+S662)]  
PSD834F2V@PLCC52 [(PEP+S415T)] PSD834F2V@TQFP52 [(PEP+S662)]  
PSD853F2@PLCC52 [(PEP+S415T)] PSD853F2@PQFP52 [(PEP+S662)]  
PSD853F2@TQFP52(\*) [(TA071+B006)]  
PSD853F2V@PLCC52 [(PEP+S415T)] PSD853F2V@TQFP52 [(PEP+S662)]  
PSD853F2V@TQFP52(\*) [(TA071+B006)]  
PSD854F2@PLCC52 [(PEP+S415T)] PSD854F2@TQFP52 [(PEP+S662)]  
PSD854F2V@PLCC52 [(PEP+S415T)] PSD854F2V@TQFP52 [(PEP+S662)]  
ST62E01  
[(SA404)]  
ST62E01CF1  
ST62E01@SOIC16

ST62E18CF1	
ST62E20	ST62E20@SOIC20
[(SA404)]	
ST62E20CF1	
ST62E25	
ST62E25@SOIC28 [(SA404)]	
ST62E25CF1	
ST62E28CF1	
ST62E30BF1	
ST62E32BF1@SDIP42 [(SA028)]	ST62E40BG1@PQFP80 [(PEP
+S611A)]	
ST62E42BG1@TQFP64 [(PEP+S621)]	ST62E46BG1@SDIP56 [(PEP
+S627)]	
ST62E60B	ST62E60B@SOIC20
[(SA404)]	
ST62E62CF1	
ST62E65B	
ST62E65B@SOIC28 [(SA404)]	
ST62E65CF1	
ST62E80BG1@PQFP100 [(PEP+S427)]	ST62E85BG1@PQFP80 [(PEP
+S611A)]	
ST62T00	ST62T00@SOIC16
[(SA404)]	
ST62T00C(B6)	ST62T00C(M6)@SOIC16
[(SA404)]	
ST62T00C(N6)@SSOP16 [(SA626A)]	
ST62T01	
ST62T01@SOIC16 [(SA404)]	ST62T01C
(B3)	
ST62T01C(B6)	ST62T01C(M3)@SOIC16
[(SA404)]	
ST62T01C(M6)@SOIC16 [(SA404)]	ST62T01C(N3)@SSOP16
[(SA626A)]	
ST62T01C(N6)@SSOP16 [(SA626A)]	
ST62T03	
ST62T03@SOIC16 [(SA404)]	ST62T03C
(B6)	
ST62T03C(M3)@SOIC16 [(SA404)]	ST62T03C(M6)@SOIC16
[(SA404)]	
ST62T03C(N6)@SSOP16 [(SA626A)]	
ST62T08	
ST62T08@SOIC20 [(SA404)]	ST62T08C
(B6)	

ST62T08C(M6)@SOIC20 [(SA404)]	
ST62T09	
ST62T09@SOIC20 [(SA404)]	ST62T09C
(B3)	
ST62T09C(B6)	ST62T09C(M3)@SOIC20
[(SA404)]	
ST62T09C(M6)@SOIC20 [(SA404)]	
ST62T10	
ST62T10@SOIC20 [(SA404)]	ST62T10C
(B6)	
ST62T10C(M6)@SOIC20 [(SA404)]	
ST62T15	
ST62T15@SOIC28 [(SA404)]	ST62T15C
(B6)	
ST62T15C(M6)@SOIC28 [(SA404)]	ST62T18C
(B6)	
ST62T18C(M3)@SOIC20 [(SA404)]	ST62T18C(M6)@SOIC20
[(SA404)]	
ST62T20	ST62T20@SOIC20
[(SA404)]	
ST62T20C(B3)	ST62T20C
(B6)	
ST62T20C(M3)@SOIC20 [(SA404)]	ST62T20C(M6)@SOIC20
[(SA404)]	
ST62T25	ST62T25@SOIC28
[(SA404)]	
ST62T25C(B3)	ST62T25C
(B6)	
ST62T25C(M3)@SOIC28 [(SA404)]	ST62T25C(M6)@SOIC28
[(SA404)]	
ST62T25C(N6)@SSOP28 [(SA626A)]	ST62T28C
(B6)	
ST62T28C(M3)@SOIC28 [(SA404)]	ST62T28C(M6)@SOIC28
[(SA404)]	
ST62T28C(N6)@SSOP28 [(SA626A)]	ST62T30B
(B3)	
ST62T30B(B6)	ST62T30B(M6)@SOIC28
[(SA404)]	
ST62T32B(B6)@SDIP42 [(SA028)]	
ST62T40B(Q6)@PQFP80 [(PEP+S611A)]	
ST62T42B(Q6)@TQFP64 [(PEP+S621)]	ST62T46B(Q6)@SDIP56 [(PEP
+S627)]	
ST62T52C(B6)	ST62T52C(M3)@SOIC16

[ (SA404) ]	
ST62T52C(M6)@SOIC16 [ (SA404) ]	ST62T52C(N3)@SSOP16
[ (SA626A) ]	
ST62T52C(N6)@SSOP16 [ (SA626A) ]	
ST62T53B	
ST62T53B@SOIC20 [ (SA404) ]	ST62T53C
(B6)	
ST62T53C(M6)@SOIC20 [ (SA404) ]	ST62T55C
(B6)	
ST62T55C(M6)@SOIC28 [ (SA404) ]	ST62T55C(N6)@SSOP28
[ (SA626A) ]	
ST62T60B	ST62T60B@SOIC20
[ (SA404) ]	
ST62T60C6	ST62T62C
(B6)	
ST62T62C(M3)@SOIC16 [ (SA404) ]	ST62T62C(M6)@SOIC16
[ (SA404) ]	
ST62T62C(N3)@SSOP16 [ (SA626A) ]	ST62T62C(N6)@SSOP16
[ (SA626A) ]	
ST62T63B	ST62T63B@SOIC20
[ (SA404) ]	
ST62T63C(B6)	ST62T63C(M6)@SOIC20
[ (SA404) ]	
ST62T65B	ST62T65B@SOIC28
[ (SA404) ]	
ST62T65C(B3)	ST62T65C
(B6)	
ST62T65C(M3)@SOIC28 [ (SA404) ]	ST62T65C(M6)@SOIC28
[ (SA404) ]	
ST62T65C(N6)@SSOP28 [ (SA626A) ]	
ST62T80B(Q6)@PQFP100 [ (PEP+S427) ]	
ST62T85B(Q6)@PQFP80 [ (PEP+S611A) ]	
ST63E73@SDIP42 [ (SA028) ]	ST63T73@SDIP42
[ (SA028) ]	
ST72C104G1B@SDIP32 [ (SA653) ]	ST72C104G1M@SOIC28
[ (SA404) ]	
ST72C104G2B@SDIP32 [ (SA653) ]	ST72C104G2M@SOIC28
[ (SA404) ]	
ST72C124J2B@SDIP42 [ (SA028) ]	ST72C124J2T@TQFP44
[ (SA245A) ]	
ST72C124J4B@SDIP42 [ (SA028) ]	ST72C124J4T@TQFP44
[ (SA245A) ]	
ST72C215G1B@SDIP32 [ (SA653) ]	ST72C215G1M@SOIC28

[ (SA404) ]	
ST72C215G2B@SDIP32 [ (SA653) ]	ST72C215G2M@SOIC28
[ (SA404) ]	
ST72C216G1B@SDIP32 [ (SA653) ]	ST72C216G1M@SOIC28
[ (SA404) ]	
ST72C216G2B@SDIP32 [ (SA653) ]	ST72C216G2M@SOIC28
[ (SA404) ]	
ST72C254G1B@SDIP32 [ (SA653) ]	ST72C254G1M@SOIC28
[ (SA404) ]	
ST72C254G2B@SDIP32 [ (SA653) ]	ST72C254G2M@SOIC28
[ (SA404) ]	
ST72C314J2B@SDIP42 [ (SA028) ]	ST72C314J2T@TQFP44
[ (SA245A) ]	
ST72C314J4B@SDIP42 [ (SA028) ]	ST72C314J4T@TQFP44
[ (SA245A) ]	
ST72C314N2B@SDIP56 [ (PEP+S627) ]	ST72C314N2T@TQFP64 [ (PEP
+S625A) ]	
ST72C314N4B@SDIP56 [ (PEP+S627) ]	ST72C314N4T@TQFP64 [ (PEP
+S625A) ]	
ST72C334J2B@SDIP42 [ (SA028) ]	ST72C334J2T@TQFP44
[ (SA245A) ]	
ST72C334J4B@SDIP42 [ (SA028) ]	ST72C334J4T@TQFP44
[ (SA245A) ]	
ST72C334N2B@SDIP56 [ (PEP+S627) ]	ST72C334N2T@TQFP64 [ (PEP
+S625A) ]	
ST72C334N4B@SDIP56 [ (PEP+S627) ]	ST72C334N4T@TQFP64 [ (PEP
+S625A) ]	
ST72F260G1B6@SDIP32 [ (SA653) ]	ST72F260G1M6@SOIC28
[ (SA404) ]	
ST72F262G1B6@SDIP32 [ (SA653) ]	ST72F262G1M6@SOIC28
[ (SA404) ]	
ST72F262G2B6@SDIP32 [ (SA653) ]	ST72F262G2M6@SOIC28
[ (SA404) ]	
ST72F264G1B6@SDIP32 [ (SA653) ]	ST72F264G1M6@SOIC28
[ (SA404) ]	
ST72F264G2B6@SDIP32 [ (SA653) ]	
ST72F264G2H1@LFBGA36 [ (SA642G-B026A-T048F001N) ]	
ST72F264G2H6@LFBGA36 [ (SA642G-B026A-T048F001N) ]	
ST72F264G2M6@SOIC28 [ (SA404) ]	
ST72F321AR6T6@TQFP64 [ (PEP+S616) ]	
ST72F321AR6TA@TQFP64 [ (PEP+S616) ]	
ST72F321AR7T6@TQFP64 [ (PEP+S616) ]	
ST72F321AR7TA@TQFP64 [ (PEP+S616) ]	

ST72F321AR9T6@TQFP64 [ ( PEP+S616 ) ]  
ST72F321AR9TA@TQFP64 [ ( PEP+S616 ) ]  
ST72F321AR9TC@TQFP64 [ ( PEP+S616 ) ]  
ST72F321BAR6T6@TQFP64 [ ( PEP+S616 ) ]  
ST72F321BAR6TA@TQFP64 [ ( PEP+S616 ) ]  
ST72F321BAR7T6@TQFP64 [ ( PEP+S616 ) ]  
ST72F321BAR7TA@TQFP64 [ ( PEP+S616 ) ]  
ST72F321BAR9T6@TQFP64 [ ( PEP+S616 ) ]  
ST72F321BAR9TA@TQFP64 [ ( PEP+S616 ) ]  
ST72F321BAR9TC@TQFP64 [ ( PEP+S616 ) ]  
ST72F321BJ7T6@TQFP44 [ ( SA245A ) ] ST72F321BJ7TA@TQFP44  
[ ( SA245A ) ]  
ST72F321BJ9T6@TQFP44 [ ( SA245A ) ] ST72F321BJ9TA@TQFP44  
[ ( SA245A ) ]  
ST72F321BJ9TC@TQFP44 [ ( SA245A ) ]  
ST72F321BR6T6@TQFP64 [ ( PEP+S625A ) ]  
ST72F321BR6TA@TQFP64 [ ( PEP+S625A ) ]  
ST72F321BR7T6@TQFP64 [ ( PEP+S625A ) ]  
ST72F321BR7TA@TQFP64 [ ( PEP+S625A ) ]  
ST72F321BR9T6@TQFP64 [ ( PEP+S625A ) ]  
ST72F321BR9TA@TQFP64 [ ( PEP+S625A ) ]  
ST72F321BR9TC@TQFP64 [ ( PEP+S625A ) ]  
ST72F321J7T6@TQFP44 [ ( SA245A ) ] ST72F321J7TA@TQFP44  
[ ( SA245A ) ]  
ST72F321J9T6@TQFP44 [ ( SA245A ) ] ST72F321J9TA@TQFP44  
[ ( SA245A ) ]  
ST72F321J9TC@TQFP44 [ ( SA245A ) ]  
ST72F321R6T6@TQFP64 [ ( PEP+S625A ) ]  
ST72F321R6TA@TQFP64 [ ( PEP+S625A ) ]  
ST72F321R7T6@TQFP64 [ ( PEP+S625A ) ]  
ST72F321R7TA@TQFP64 [ ( PEP+S625A ) ]  
ST72F321R9T6@TQFP64 [ ( PEP+S625A ) ]  
ST72F321R9TA@TQFP64 [ ( PEP+S625A ) ]  
ST72F321R9TC@TQFP64 [ ( PEP+S625A ) ]  
ST72F324BJ2B5@SDIP42 [ ( SA028 ) ] ST72F324BJ2B6@SDIP42  
[ ( SA028 ) ]  
ST72F324BJ2T3@TQFP44 [ ( SA245A ) ] ST72F324BJ2T5@TQFP44  
[ ( SA245A ) ]  
ST72F324BJ2T6@TQFP44 [ ( SA245A ) ] ST72F324BJ4B5@SDIP42  
[ ( SA028 ) ]  
ST72F324BJ4B6@SDIP42 [ ( SA028 ) ] ST72F324BJ4T3@TQFP44  
[ ( SA245A ) ]  
ST72F324BJ4T6@TQFP44 [ ( SA245A ) ] ST72F324BJ6B5@SDIP42

[ (SA028) ]  
ST72F324BJ6B6@SDIP42 [ (SA028) ] ST72F324BJ6T3@TQFP44  
[ (SA245A) ]  
ST72F324BJ6T6@TQFP44 [ (SA245A) ] ST72F324BK2B5@SDIP32  
[ (SA653) ]  
ST72F324BK2B6@SDIP32 [ (SA653) ] ST72F324BK2T3@TQFP32  
[ (SA663) ]  
ST72F324BK2T5@TQFP32 [ (SA663) ] ST72F324BK2T6@TQFP32  
[ (SA663) ]  
ST72F324BK4B5@SDIP32 [ (SA653) ] ST72F324BK4B6@SDIP32  
[ (SA653) ]  
ST72F324BK4T3@TQFP32 [ (SA663) ] ST72F324BK4T6@TQFP32  
[ (SA663) ]  
ST72F324BK6B5@SDIP32 [ (SA653) ] ST72F324BK6B6@SDIP32  
[ (SA653) ]  
ST72F324BK6T3@TQFP32 [ (SA663) ] ST72F324BK6T6@TQFP32  
[ (SA663) ]  
ST72F324J2B5@SDIP42 [ (SA028) ]  
ST72F324J2B5@SDIP42( ISP) [ ISP-HEADER01 ]  
ST72F324J2T6@TQFP44 [ (SA245A) ]  
ST72F324J2T6@TQFP44( ISP) [ ISP-HEADER01 ]  
ST72F324J2TA@TQFP44 [ (SA245A) ]  
ST72F324J2TA@TQFP44( ISP) [ ISP-HEADER01 ]  
ST72F324J4B5@SDIP42 [ (SA028) ]  
ST72F324J4B5@SDIP42( ISP) [ ISP-HEADER01 ]  
ST72F324J4T6@TQFP44 [ (SA245A) ]  
ST72F324J4T6@TQFP44( ISP) [ ISP-HEADER01 ]  
ST72F324J4TA@TQFP44 [ (SA245A) ]  
ST72F324J4TA@TQFP44( ISP) [ ISP-HEADER01 ]  
ST72F324J6B5@SDIP42 [ (SA028) ]  
ST72F324J6B5@SDIP42( ISP) [ ISP-HEADER01 ]  
ST72F324J6T3@TQFP44 [ (SA245A) ]  
ST72F324J6T3@TQFP44( ISP) [ ISP-HEADER01 ]  
ST72F324J6T5@TQFP44 [ (SA245A) ]  
ST72F324J6T5@TQFP44( ISP) [ ISP-HEADER01 ]  
ST72F324J6T6@TQFP44 [ (SA245A) ]  
ST72F324J6T6@TQFP44( ISP) [ ISP-HEADER01 ]  
ST72F324J6TA@TQFP44 [ (SA245A) ]  
ST72F324J6TA@TQFP44( ISP) [ ISP-HEADER01 ]  
ST72F324J6TC@TQFP44 [ (SA245A) ]  
ST72F324J6TC@TQFP44( ISP) [ ISP-HEADER01 ]  
ST72F324K2B5@SDIP32 [ (SA653) ]  
ST72F324K2B5@SDIP32( ISP) [ ISP-HEADER01 ]



ST72F324K2B6@SDIP32 [(SA653)]  
ST72F324K2B6@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K2T6@TQFP32 [(SA663)]  
ST72F324K2T6@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K2TA@TQFP32 [(SA663)]  
ST72F324K2TA@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K4B5@SDIP32 [(SA653)]  
ST72F324K4B5@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K4B6@SDIP32 [(SA653)]  
ST72F324K4B6@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K4T6@TQFP32 [(SA663)]  
ST72F324K4T6@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K4TA@TQFP32 [(SA663)]  
ST72F324K4TA@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K6B5@SDIP32 [(SA653)]  
ST72F324K6B5@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K6B6@SDIP32 [(SA653)]  
ST72F324K6B6@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K6T5@TQFP32 [(SA663)]  
ST72F324K6T5@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K6T6@TQFP32 [(SA663)]  
ST72F324K6T6@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K6TA@TQFP32 [(SA663)]  
ST72F324K6TA@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K6TC@TQFP32 [(SA663)]  
ST72F324K6TC@TQFP32(ISP) [ISP-HEADER01]  
ST72F324LJ2T5@TQFP44 [(SA245A)]  
ST72F324LJ2T5@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LJ2T6@TQFP44 [(SA245A)]  
ST72F324LJ2T6@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LJ4T5@TQFP44 [(SA245A)]  
ST72F324LJ4T5@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LJ4T6@TQFP44 [(SA245A)]  
ST72F324LJ4T6@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LJ6T5@TQFP44 [(SA245A)]  
ST72F324LJ6T5@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LJ6T6@TQFP44 [(SA245A)]  
ST72F324LJ6T6@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LJ6TA@TQFP44 [(SA245A)]  
ST72F324LJ6TA@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LK2T5@TQFP32 [(SA663)]  
ST72F324LK2T5@TQFP32(ISP) [ISP-HEADER01]  
ST72F324LK2T6@TQFP32 [(SA663)]

ST72F324LK2T6@TQFP32 (ISP) [ISP-HEADER01]  
ST72F324LK4T5@TQFP32 [(SA663)]  
ST72F324LK4T5@TQFP32 (ISP) [ISP-HEADER01]  
ST72F324LK4T6@TQFP32 [(SA663)]  
ST72F324LK4T6@TQFP32 (ISP) [ISP-HEADER01]  
ST72F324LK6B5@SDIP32 [(SA653)]  
ST72F324LK6B5@SDIP32 (ISP) [ISP-HEADER01]  
ST72F324LK6T5@TQFP32 [(SA663)]  
ST72F324LK6T5@TQFP32 (ISP) [ISP-HEADER01]  
ST72F324LK6T6@TQFP32 [(SA663)]  
ST72F324LK6T6@TQFP32 (ISP) [ISP-HEADER01]  
ST72F324LK6TA@TQFP32 [(SA663)]  
ST72F324LK6TA@TQFP32 (ISP) [ISP-HEADER01]  
ST72F325AR6T6@TQFP64 [(PEP+S616)]  
ST72F325AR7T6@TQFP64 [(PEP+S616)]  
ST72F325AR9T6@TQFP64 [(PEP+S616)]  
ST72F325C4T6@TQFP48 [(SA248)] ST72F325C6T6@TQFP48  
[(SA248)]  
ST72F325C7T6@TQFP48 [(SA248)] ST72F325C9T6@TQFP48  
[(SA248)]  
ST72F325J4T6@TQFP44 [(SA245A)] ST72F325J6B5@SDIP42  
[(SA028)]  
ST72F325J6B6@SDIP42 [(SA028)]  
ST72F325J6B6@SDIP42 (ISP) [ISP-HEADER01]  
ST72F325J6T6@TQFP44 [(SA245A)] ST72F325J7T6@TQFP44  
[(SA245A)]  
ST72F325J9T6@TQFP44 [(SA245A)] ST72F325K4B5@SDIP32  
[(SA653)]  
ST72F325K4T6@TQFP32 [(SA663)] ST72F325K6B5@SDIP32  
[(SA653)]  
ST72F325K6B6@SDIP32 [(SA653)]  
ST72F325K6B6@SDIP32 (ISP) [ISP-HEADER01]  
ST72F325K6T6@TQFP32 [(SA663)]  
ST72F325R6T6@TQFP64 [(PEP+S625A)]  
ST72F325R7T6@TQFP64 [(PEP+S625A)]  
ST72F325R9T6@TQFP64 [(PEP+S625A)]  
ST72F32AJ1B5@SDIP42 [(SA028)] ST72F32AJ1B6@SDIP42  
[(SA028)]  
ST72F32AJ1T5@TQFP44 [(SA245A)] ST72F32AJ1T6@TQFP44  
[(SA245A)]  
ST72F32AJ2B5@SDIP42 [(SA028)] ST72F32AJ2B6@SDIP42  
[(SA028)]  
ST72F32AJ2T5@TQFP44 [(SA245A)] ST72F32AJ2T6@TQFP44

[ ( SA245A ) ]		
ST72F32AJ2TA@TQFP44 [ ( SA245A ) ]		ST72F32AJ2TB@TQFP44
[ ( SA245A ) ]		
ST72F32AJ2TC@TQFP44 [ ( SA245A ) ]		ST72F32AK1B5@SDIP32
[ ( SA653 ) ]		
ST72F32AK1B6@SDIP32 [ ( SA653 ) ]		ST72F32AK1T5@TQFP32
[ ( SA663 ) ]		
ST72F32AK1T6@TQFP32 [ ( SA663 ) ]		ST72F32AK2B5@SDIP32
[ ( SA653 ) ]		
ST72F32AK2B6@SDIP32 [ ( SA653 ) ]		ST72F32AK2T5@TQFP32
[ ( SA663 ) ]		
ST72F32AK2T6@TQFP32 [ ( SA663 ) ]		ST72F32AK2TA@TQFP32
[ ( SA663 ) ]		
ST72F32AK2TB@TQFP32 [ ( SA663 ) ]		ST72F32AK2TC@TQFP32
[ ( SA663 ) ]		
ST72F340K2T6@LQFP32 [ ( SA663 ) ]		ST72F340K4T6@LQFP32
[ ( SA663 ) ]		
ST72F340S2T6@LQFP44 [ ( SA245A ) ]		ST72F340S4T6@LQFP44
[ ( SA245A ) ]		
ST72F344K2T6@LQFP32 [ ( SA663 ) ]		ST72F344K4T6@LQFP32
[ ( SA663 ) ]		
ST72F344S2T6@LQFP44 [ ( SA245A ) ]		ST72F344S4T6@LQFP44
[ ( SA245A ) ]		
ST72F345C2T6@LQFP48 [ ( SA248 ) ]		ST72F345C4T6@LQFP48
[ ( SA248 ) ]		
ST72F361AR4T3@TQFP64 [ ( PEP+S616 ) ]		
ST72F361AR4T6@TQFP64 [ ( PEP+S616 ) ]		
ST72F361AR4TA@TQFP64 [ ( PEP+S616 ) ]		
ST72F361AR4TC@TQFP64 [ ( PEP+S616 ) ]		
ST72F361AR6T3@TQFP64 [ ( PEP+S616 ) ]		
ST72F361AR6T6@TQFP64 [ ( PEP+S616 ) ]		
ST72F361AR6TA@TQFP64 [ ( PEP+S616 ) ]		
ST72F361AR6TC@TQFP64 [ ( PEP+S616 ) ]		
ST72F361AR7T3@TQFP64 [ ( PEP+S616 ) ]		
ST72F361AR7T6@TQFP64 [ ( PEP+S616 ) ]		
ST72F361AR7TA@TQFP64 [ ( PEP+S616 ) ]		
ST72F361AR7TC@TQFP64 [ ( PEP+S616 ) ]		
ST72F361AR9T3@TQFP64 [ ( PEP+S616 ) ]		
ST72F361AR9T6@TQFP64 [ ( PEP+S616 ) ]		
ST72F361AR9TA@TQFP64 [ ( PEP+S616 ) ]		
ST72F361AR9TC@TQFP64 [ ( PEP+S616 ) ]		
ST72F361J4T3@TQFP44 [ ( SA245A ) ]		ST72F361J4T6@TQFP44
[ ( SA245A ) ]		

ST72F361J4TA@TQFP44 [ ( SA245A ) ] [ ( SA245A ) ]	ST72F361J4TC@TQFP44
ST72F361J6T3@TQFP44 [ ( SA245A ) ] [ ( SA245A ) ]	ST72F361J6T6@TQFP44
ST72F361J6TA@TQFP44 [ ( SA245A ) ] [ ( SA245A ) ]	ST72F361J6TC@TQFP44
ST72F361J7T3@TQFP44 [ ( SA245A ) ] [ ( SA245A ) ]	ST72F361J7T6@TQFP44
ST72F361J7TA@TQFP44 [ ( SA245A ) ] [ ( SA245A ) ]	ST72F361J7TC@TQFP44
ST72F361J9T3@TQFP44 [ ( SA245A ) ] [ ( SA245A ) ]	ST72F361J9T6@TQFP44
ST72F361J9TA@TQFP44 [ ( SA245A ) ] [ ( SA245A ) ]	ST72F361J9TC@TQFP44
ST72F361K4T3@TQFP32 [ ( SA663 ) ] [ ( SA663 ) ]	ST72F361K4T6@TQFP32
ST72F361K4TA@TQFP32 [ ( SA663 ) ] [ ( SA663 ) ]	ST72F361K4TC@TQFP32
ST72F361K6T3@TQFP32 [ ( SA663 ) ] [ ( SA663 ) ]	ST72F361K6T6@TQFP32
ST72F361K6TA@TQFP32 [ ( SA663 ) ] [ ( SA663 ) ]	ST72F361K6TC@TQFP32
ST72F361K7T3@TQFP32 [ ( SA663 ) ] [ ( SA663 ) ]	ST72F361K7T6@TQFP32
ST72F361K7TA@TQFP32 [ ( SA663 ) ] [ ( SA663 ) ]	ST72F361K7TC@TQFP32
ST72F361K9T3@TQFP32 [ ( SA663 ) ] [ ( SA663 ) ]	ST72F361K9T6@TQFP32
ST72F361K9TA@TQFP32 [ ( SA663 ) ] [ ( SA663 ) ]	ST72F361K9TC@TQFP32
ST72F361R4T3@TQFP64 [ ( PEP+S625A ) ]	
ST72F361R4T6@TQFP64 [ ( PEP+S625A ) ]	
ST72F361R4TA@TQFP64 [ ( PEP+S625A ) ]	
ST72F361R4TC@TQFP64 [ ( PEP+S625A ) ]	
ST72F361R6T3@TQFP64 [ ( PEP+S625A ) ]	
ST72F361R6T6@TQFP64 [ ( PEP+S625A ) ]	
ST72F361R6TA@TQFP64 [ ( PEP+S625A ) ]	
ST72F361R6TC@TQFP64 [ ( PEP+S625A ) ]	
ST72F361R7T3@TQFP64 [ ( PEP+S625A ) ]	
ST72F361R7T6@TQFP64 [ ( PEP+S625A ) ]	
ST72F361R7TA@TQFP64 [ ( PEP+S625A ) ]	
ST72F361R7TC@TQFP64 [ ( PEP+S625A ) ]	
ST72F361R9T3@TQFP64 [ ( PEP+S625A ) ]	

ST72F361R9T6@TQFP64 [(PEP+S625A)]  
ST72F361R9TA@TQFP64 [(PEP+S625A)]  
ST72F361R9TC@TQFP64 [(PEP+S625A)]  
ST72F521AR6T6@TQFP64 [(PEP+S616)]  
ST72F521AR6TC@TQFP64 [(PEP+S616)]  
ST72F521AR9T6@TQFP64 [(PEP+S616)]  
ST72F521AR9TC@TQFP64 [(PEP+S616)]  
ST72F521BAR6T6@TQFP64 [(PEP+S616)]  
ST72F521BAR6TC@TQFP64 [(PEP+S616)]  
ST72F521BAR9T6@TQFP64 [(PEP+S616)]  
ST72F521BAR9TC@TQFP64 [(PEP+S616)]  
ST72F521BM9T6@TQFP80 [(PEP+S615B)]  
ST72F521BM9TC@TQFP80 [(PEP+S615B)]  
ST72F521BR6T6@TQFP64 [(PEP+S625A)]  
ST72F521BR6TC@TQFP64 [(PEP+S625A)]  
ST72F521BR9T3@TQFP64 [(PEP+S625A)]  
ST72F521BR9T6@TQFP64 [(PEP+S625A)]  
ST72F521BR9TC@TQFP64 [(PEP+S625A)]  
ST72F521M9T6@TQFP80 [(PEP+S615B)]  
ST72F521M9TC@TQFP80 [(PEP+S615B)]  
ST72F521R6T6@TQFP64 [(PEP+S625A)]  
ST72F521R6TC@TQFP64 [(PEP+S625A)]  
ST72F521R9T3@TQFP64 [(PEP+S625A)]  
ST72F521R9T6@TQFP64 [(PEP+S625A)]  
ST72F521R9TC@TQFP64 [(PEP+S625A)]  
ST72F561AR4T3@TQFP64 [(PEP+S616)]  
ST72F561AR4T6@TQFP64 [(PEP+S616)]  
ST72F561AR4TA@TQFP64 [(PEP+S616)]  
ST72F561AR4TC@TQFP64 [(PEP+S616)]  
ST72F561AR6T3@TQFP64 [(PEP+S616)]  
ST72F561AR6T6@TQFP64 [(PEP+S616)]  
ST72F561AR6TA@TQFP64 [(PEP+S616)]  
ST72F561AR6TC@TQFP64 [(PEP+S616)]  
ST72F561AR7T3@TQFP64 [(PEP+S616)]  
ST72F561AR7T6@TQFP64 [(PEP+S616)]  
ST72F561AR7TA@TQFP64 [(PEP+S616)]  
ST72F561AR7TC@TQFP64 [(PEP+S616)]  
ST72F561AR9T3@TQFP64 [(PEP+S616)]  
ST72F561AR9T6@TQFP64 [(PEP+S616)]  
ST72F561AR9TA@TQFP64 [(PEP+S616)]  
ST72F561AR9TC@TQFP64 [(PEP+S616)]  
ST72F561J4T3@TQFP44 [(SA245A)]  
[(SA245A)]

ST72F561J4T6@TQFP44

ST72F561J4TA@TQFP44 [(SA245A)]	ST72F561J4TC@TQFP44
[(SA245A)]	
ST72F561J6T3@TQFP44 [(SA245A)]	ST72F561J6T6@TQFP44
[(SA245A)]	
ST72F561J6TA@TQFP44 [(SA245A)]	ST72F561J6TC@TQFP44
[(SA245A)]	
ST72F561J7T3@TQFP44 [(SA245A)]	ST72F561J7T6@TQFP44
[(SA245A)]	
ST72F561J7TA@TQFP44 [(SA245A)]	ST72F561J7TC@TQFP44
[(SA245A)]	
ST72F561J9T3@TQFP44 [(SA245A)]	ST72F561J9T6@TQFP44
[(SA245A)]	
ST72F561J9TA@TQFP44 [(SA245A)]	ST72F561J9TC@TQFP44
[(SA245A)]	
ST72F561K4T3@TQFP32 [(SA663)]	ST72F561K4T6@TQFP32
[(SA663)]	
ST72F561K4TA@TQFP32 [(SA663)]	ST72F561K4TC@TQFP32
[(SA663)]	
ST72F561K6T3@TQFP32 [(SA663)]	ST72F561K6T6@TQFP32
[(SA663)]	
ST72F561K6TA@TQFP32 [(SA663)]	ST72F561K6TC@TQFP32
[(SA663)]	
ST72F561K7T3@TQFP32 [(SA663)]	ST72F561K7T6@TQFP32
[(SA663)]	
ST72F561K7TA@TQFP32 [(SA663)]	ST72F561K7TC@TQFP32
[(SA663)]	
ST72F561K9T3@TQFP32 [(SA663)]	ST72F561K9T6@TQFP32
[(SA663)]	
ST72F561K9TA@TQFP32 [(SA663)]	ST72F561K9TC@TQFP32
[(SA663)]	
ST72F561R4T3@TQFP64 [(PEP+S625A)]	
ST72F561R4T6@TQFP64 [(PEP+S625A)]	
ST72F561R4TA@TQFP64 [(PEP+S625A)]	
ST72F561R4TC@TQFP64 [(PEP+S625A)]	
ST72F561R6T3@TQFP64 [(PEP+S625A)]	
ST72F561R6T6@TQFP64 [(PEP+S625A)]	
ST72F561R6TA@TQFP64 [(PEP+S625A)]	
ST72F561R6TC@TQFP64 [(PEP+S625A)]	
ST72F561R7T3@TQFP64 [(PEP+S625A)]	
ST72F561R7T6@TQFP64 [(PEP+S625A)]	
ST72F561R7TA@TQFP64 [(PEP+S625A)]	
ST72F561R7TC@TQFP64 [(PEP+S625A)]	
ST72F561R9T3@TQFP64 [(PEP+S625A)]	

ST72F561R9T6@TQFP64 [(PEP+S625A)]  
ST72F561R9TA@TQFP64 [(PEP+S625A)]  
ST72F561R9TC@TQFP64 [(PEP+S625A)]  
ST72F60D4U1@QFN40 [(SA750)]  
ST72F60D4U1@QFN40(ISP) [ISP-HEADER01]  
ST72F60D6U1@QFN40 [(SA750)]  
ST72F60D6U1@QFN40(ISP) [ISP-HEADER01]  
ST72F60E1M1@SOIC24 [(SA404)]  
ST72F60E1M1@SOIC24(ISP) [ISP-HEADER01]  
ST72F60E2M1@SOIC24 [(SA404)]  
ST72F60E2M1@SOIC24(ISP) [ISP-HEADER01]  
ST72F60E4M1@SOIC24 [(SA404)]  
ST72F60E4M1@SOIC24(ISP) [ISP-HEADER01]  
ST72F60E6M1@SOIC24 [(SA404)]  
ST72F60E6M1@SOIC24(ISP) [ISP-HEADER01]  
ST72F60K1U1@QFN40 [(SA750)]  
ST72F60K1U1@QFN40(ISP) [ISP-HEADER01]  
ST72F60K2U1@QFN40 [(SA750)]  
ST72F60K2U1@QFN40(ISP) [ISP-HEADER01]  
ST72F621J4B1@SDIP42 [(SA028)] ST72F621J4T1@TQFP44  
[(SA245A)]  
ST72F621K4B1@SDIP32 [(SA653)] ST72F621L4M1@SOIC34  
[(SA658)]  
ST72F622L2M1@SOIC34 [(SA658)]  
ST72F623F2B1  
ST72F623F2M1@SOIC20 [(SA404)] ST72F63BD4U1@QFN40  
[(SA750)]  
ST72F63BD4U1@QFN40(ISP) [ISP-HEADER01]  
ST72F63BD6U1@QFN40 [(SA750)]  
ST72F63BD6U1@QFN40(ISP) [ISP-HEADER01]  
ST72F63BE1M1@SOP24 [(SA404)]  
ST72F63BE1M1@SOP24(ISP) [ISP-HEADER01]  
ST72F63BE2M1@SOP24 [(SA404)]  
ST72F63BE2M1@SOP24(ISP) [ISP-HEADER01]  
ST72F63BE4M1@SOP24 [(SA404)]  
ST72F63BE4M1@SOP24(ISP) [ISP-HEADER01]  
ST72F63BE6M1@SOP24 [(SA404)]  
ST72F63BE6M1@SOP24(ISP) [ISP-HEADER01]  
ST72F63BH1T1@QFP48 [(SA248)]  
ST72F63BH1T1@QFP48(ISP) [ISP-HEADER01]  
ST72F63BH2T1@QFP48 [(SA248)]  
ST72F63BH2T1@QFP48(ISP) [ISP-HEADER01]  
ST72F63BH4T1@QFP48 [(SA248)]

ST72F63BH4T1@QFP48(ISP) [ISP-HEADER01]  
 ST72F63BH6T1@QFP48 [(SA248)]  
 ST72F63BH6T1@QFP48(ISP) [ISP-HEADER01]  
 ST72F63BK1B1@SOIC34 [(SA653)]  
 ST72F63BK1B1@SOIC34(ISP) [ISP-HEADER01]  
 ST72F63BK1M1@SOIC34 [(SA658)]  
 ST72F63BK1M1@SOIC34(ISP) [ISP-HEADER01]  
 ST72F63BK1U1@QFN40 [(SA750)]  
 ST72F63BK1U1@QFN40(ISP) [ISP-HEADER01]  
 ST72F63BK2B1@SOIC34 [(SA653)]  
 ST72F63BK2B1@SOIC34(ISP) [ISP-HEADER01]  
 ST72F63BK2M1@SOIC34 [(SA658)]  
 ST72F63BK2M1@SOIC34(ISP) [ISP-HEADER01]  
 ST72F63BK2U1@QFN40 [(SA750)]  
 ST72F63BK2U1@QFN40(ISP) [ISP-HEADER01]  
 ST72F63BK4B1@SOIC34 [(SA653)]  
 ST72F63BK4B1@SOIC34(ISP) [ISP-HEADER01]  
 ST72F63BK4M1@SOIC34 [(SA658)]  
 ST72F63BK4M1@SOIC34(ISP) [ISP-HEADER01]  
 ST72F63BK6B1@SOIC34 [(SA653)]  
 ST72F63BK6B1@SOIC34(ISP) [ISP-HEADER01]  
 ST72F63BK6M1@SOIC34 [(SA658)]  
 ST72F63BK6M1@SOIC34(ISP) [ISP-HEADER01]  
 ST72F651AR6T1@TQFP64 [(PEP+S616)]  
 ST72F651AR6T1E@TQFP64 [(PEP+S616)]  
 ST72T101G1B@SDIP32 [(SA653)] ST72T101G1M@SOIC28  
 [(SA404)]  
 ST72T101G2B@SDIP32 [(SA653)] ST72T101G2M@SOIC28  
 [(SA404)]  
 ST72T121J2B@SDIP42 [(SA028)] ST72T121J2T@TQFP44  
 [(SA245A)]  
 ST72T121J4B@SDIP42 [(SA028)] ST72T121J4T@TQFP44  
 [(SA245A)]  
 ST72T141K2B@SDIP32 [(SA653)] ST72T141K2M@SSOP34  
 [(SA658)]  
 ST72T212G2B@SDIP32 [(SA653)] ST72T212G2M@SOIC28  
 [(SA404)]  
 ST72T213G1B@SDIP32 [(SA653)] ST72T213G1M@SOIC28  
 [(SA404)]  
 ST72T251G1B@SDIP32 [(SA653)] ST72T251G1M@SOIC28  
 [(SA404)]  
 ST72T251G2B@SDIP32 [(SA653)] ST72T251G2M@SOIC28  
 [(SA404)]



ST72T272K4B@SDIP32 [(SA653)]	ST72T272K4M@SSOP34
[(SA658)]	
ST72T311J2B@SDIP42 [(SA028)]	ST72T311J2T@TQFP44
[(SA245A)]	
ST72T311J4B@SDIP42 [(SA028)]	ST72T311J4T@TQFP44
[(SA245A)]	
ST72T311N2B@SDIP56 [(PEP+S627)]	ST72T311N2T@TQFP64 [(PEP
+S625A)]	
ST72T311N4B@SDIP56 [(PEP+S627)]	ST72T311N4T@TQFP64 [(PEP
+S625A)]	
ST72T311R6T@TQFP64 [(PEP+S625A)]	ST72T311R7T@TQFP64 [(PEP
+S625A)]	
ST72T311R9T@TQFP64 [(PEP+S625A)]	ST72T331J2B@SDIP42
[(SA028)]	
ST72T331J2T@TQFP44 [(SA245A)]	ST72T331J4B@SDIP42
[(SA028)]	
ST72T331J4T@TQFP44 [(SA245A)]	ST72T331N2B@SDIP56 [(PEP
+S627)]	
ST72T331N2T@TQFP64 [(PEP+S625A)]	ST72T331N4B@SDIP56 [(PEP
+S627)]	
ST72T331N4T@TQFP64 [(PEP+S625A)]	
ST72T371N4B@SDIP56(*) [(SA627-B5601)]	
ST72T371N4T@TQFP64 [(PEP+S625A)]	ST72T372J4B@SDIP42
[(SA028)]	
ST72T511R6T@TQFP64 [(PEP+S625A)]	ST72T511R7T@TQFP64 [(PEP
+S625A)]	
ST72T511R9T@TQFP64 [(PEP+S625A)]	ST72T512R4T@TQFP64 [(PEP
+S625A)]	
ST72T532R4T@TQFP64 [(PEP+S625A)]	ST72T631K4B1@SDIP32
[(SA653)]	
ST72T631K4M1@SSOP34 [(SA658)]	ST72T632K2B1@SDIP32
[(SA653)]	
ST72T632K2M1@SSOP34 [(SA658)]	ST72T633K1B1@SDIP32
[(SA653)]	
ST72T633K1M1@SSOP34 [(SA658)]	
ST72T671N6B@SDIP56(*) [(SA627-B5601)]	
ST72T671N6T@TQFP64 [(PEP+S625A)]	
ST72T751N9B@SDIP56(*) [(SA627-B5601)]	
ST72T752J6B@SDIP42 [(SA028)]	ST72T753L6M@SSOP34
[(SA658)]	
ST72T771N9B@SDIP56(*) [(SA627-B5601)]	
ST72T771R9T@TQFP64 [(PEP+S625A)]	ST7FAUDIO@LQFP64 [(PEP
+S616)]	

ST7FAUDIO@LQFP64(\*) [(SA732+B329)]  
ST7FAUDIOAR9@LQFP64 [(PEP+S616)]  
ST7FAUDIOAR9@LQFP64(\*) [(SA732+B329)]  
ST7FDALIF2M6@SOIC20 [(SA404)]  
ST7FDALIF2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLI49MK1B6@SDIP32 [(SA653)] ST7FLI49MK1T6@TQFP32  
[(SA663)]  
ST7FLIT10BF0B3  
ST7FLIT10BF0B6  
ST7FLIT10BF0M3@SOIC20 [(SA404)] ST7FLIT10BF0M6@SOIC20  
[(SA404)]  
ST7FLIT10BF1B3  
ST7FLIT10BF1B6  
ST7FLIT10BF1M3@SOIC20 [(SA404)] ST7FLIT10BF1M6@SOIC20  
[(SA404)]  
ST7FLIT10BY0B3  
ST7FLIT10BY0B6  
ST7FLIT10BY0M3@SOIC16 [(SA602)] ST7FLIT10BY0M6@SOIC16  
[(SA602)]  
ST7FLIT10BY1B3  
ST7FLIT10BY1B6  
ST7FLIT10BY1M3@SOIC16 [(SA602)] ST7FLIT10BY1M6@SOIC16  
[(SA602)]  
ST7FLIT15BF0B3  
ST7FLIT15BF0B6  
ST7FLIT15BF0M3@SOIC20 [(SA404)] ST7FLIT15BF0M6@SOIC20  
[(SA404)]  
ST7FLIT15BF1B3  
ST7FLIT15BF1B6  
ST7FLIT15BF1M3@SOIC20 [(SA404)] ST7FLIT15BF1M6@SOIC20  
[(SA404)]  
ST7FLIT15BF1U6TR@QFN20 [(BBBB)]  
ST7FLIT15BY0B3  
ST7FLIT15BY0B6 ST7FLIT15BY0M3@SOIC16  
[(SA602)]  
ST7FLIT15BY0M6@SOIC16 [(SA602)]  
ST7FLIT15BY1B3  
ST7FLIT15BY1B6 ST7FLIT15BY1M3@SOIC16  
[(SA602)]  
ST7FLIT15BY1M6@SOIC16 [(SA602)]  
ST7FLIT19BF0B3  
ST7FLIT19BF0B6 ST7FLIT19BF0M3@SOIC20  
[(SA404)]

ST7FLIT19BF0M6@SOIC20 [(SA404)]  
ST7FLIT19BF1B3  
ST7FLIT19BF1B6 ST7FLIT19BF1M3@SOIC20  
[(SA404)]  
ST7FLIT19BF1M6@SOIC20 [(SA404)] ST7FLIT19BF1U6TR@QFN20  
[(BBBB)]  
ST7FLIT19BY0B3  
ST7FLIT19BY0B6  
ST7FLIT19BY0M3@SOIC16 [(SA602)] ST7FLIT19BY0M6@SOIC16  
[(SA602)]  
ST7FLIT19BY1B3  
ST7FLIT19BY1B6  
ST7FLIT19BY1M3@SOIC16 [(SA602)] ST7FLIT19BY1M6@SOIC16  
[(SA602)]  
ST7FLITE02B6 ST7FLITE02B6(ISP) [ISP-  
HEADER01]  
ST7FLITE02M6@SOIC16 [(SA602)]  
ST7FLITE02M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE02Y0B6  
ST7FLITE02Y0B6(ISP) [ISP-HEADER01]  
ST7FLITE02Y0M6@SOIC16 [(SA602)]  
ST7FLITE02Y0M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE05B6 ST7FLITE05B6(ISP) [ISP-  
HEADER01]  
ST7FLITE05M6@SOIC16 [(SA602)]  
ST7FLITE05M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE05Y0B6  
ST7FLITE05Y0B6(ISP) [ISP-HEADER01]  
ST7FLITE05Y0M6@SOIC16 [(SA602)]  
ST7FLITE05Y0M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE09B6 ST7FLITE09B6(ISP) [ISP-  
HEADER01]  
ST7FLITE09M6@SOIC16 [(SA602)]  
ST7FLITE09M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE09Y0B6  
ST7FLITE09Y0B6(ISP) [ISP-HEADER01]  
ST7FLITE09Y0M6@SOIC16 [(SA602)]  
ST7FLITE09Y0M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE10F1B6  
ST7FLITE10F1B6(ISP) [ISP-HEADER01]  
ST7FLITE10F1M6@SOIC20 [(SA404)]  
ST7FLITE10F1M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE15F1B6

ST7FLITE15F1B6(ISP) [ISP-HEADER01]  
ST7FLITE15F1M6@SOIC20 [(SA404)]  
ST7FLITE15F1M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE19F1B6  
ST7FLITE19F1B6(ISP) [ISP-HEADER01]  
ST7FLITE19F1M6@SOIC20 [(SA404)]  
ST7FLITE19F1M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE20F2B6  
ST7FLITE20F2B6(ISP) [ISP-HEADER01]  
ST7FLITE20F2M6@SOIC20 [(SA404)]  
ST7FLITE20F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE25F2B6  
ST7FLITE25F2B6(ISP) [ISP-HEADER01]  
ST7FLITE25F2M6@SOIC20 [(SA404)]  
ST7FLITE25F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE29F2B6  
ST7FLITE29F2B6(ISP) [ISP-HEADER01]  
ST7FLITE29F2M6@SOIC20 [(SA404)]  
ST7FLITE29F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE30F2B6  
ST7FLITE30F2B6(ISP) [ISP-HEADER01]  
ST7FLITE30F2M6@SOIC20 [(SA404)]  
ST7FLITE30F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE35F2B6  
ST7FLITE35F2B6(ISP) [ISP-HEADER01]  
ST7FLITE35F2M6@SOIC20 [(SA404)]  
ST7FLITE35F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE39F2B6  
ST7FLITE39F2B6(ISP) [ISP-HEADER01]  
ST7FLITE39F2M6@SOIC20 [(SA404)]  
ST7FLITE39F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE49  
ST7FLITE49@QFN40  
[(SA750)]  
ST7FLITE49@TQFP32 [(SA663)]  
ST7FLITEBC  
ST7FLITEBCM6@SOIC16 [(SA602)]  
ST7FLITES0  
ST7FLITES0@SOIC16 [(SA602)]  
ST7FLITES2B6  
ST7FLITES2B6(ISP) [ISP-HEADER01] ST7FLITES2M6@SOIC16  
[(SA602)]  
ST7FLITES2M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITES2Y0B6

ST7FLITES2Y0B6(ISP) [ISP-HEADER01]  
 ST7FLITES2Y0M6@SOIC16 [(SA602)]  
 ST7FLITES2Y0M6@SOIC16(ISP) [ISP-HEADER01]  
 ST7FLITES5B6 ST7FLITES5B6(ISP) [ISP-  
 HEADER01]  
 ST7FLITES5M6@SOIC16 [(SA602)]  
 ST7FLITES5M6@SOIC16(ISP) [ISP-HEADER01]  
 ST7FLITES5Y0B6  
 ST7FLITES5Y0B6(ISP) [ISP-HEADER01]  
 ST7FLITES5Y0M6@SOIC16 [(SA602)]  
 ST7FLITES5Y0M6@SOIC16(ISP) [ISP-HEADER01]  
 ST7FLITEU05B3  
 ST7FLITEU05B6  
 ST7FLITEU05M3@SO8 [(SA602A)] ST7FLITEU05M3TR@SO8  
 [(SA602A)]  
 ST7FLITEU05M6@SO8 [(SA602A)] ST7FLITEU05M6TR@SO8  
 [(SA602A)]  
 ST7FLITEU05U3@DFN8 [(BBBB)] ST7FLITEU05U3TR@DFN8  
 [(BBBB)]  
 ST7FLITEU05U6@DFN8 [(BBBB)] ST7FLITEU05U6TR@DFN8  
 [(BBBB)]  
 ST7FLITEU09B3  
 ST7FLITEU09B6  
 ST7FLITEU09M3@SO8 [(SA602A)] ST7FLITEU09M3TR@SO8  
 [(SA602A)]  
 ST7FLITEU09M6@SO8 [(SA602A)] ST7FLITEU09M6TR@SO8  
 [(SA602A)]  
 ST7FLITEU09U3@DFN8 [(BBBB)] ST7FLITEU09U3TR@DFN8  
 [(BBBB)]  
 ST7FLITEU09U6@DFN8 [(BBBB)] ST7FLITEU09U6TR@DFN8  
 [(BBBB)]  
 ST7FLITEUS2B6 ST7FLITEUS2M6@SOIC8  
 [(SA602A)]  
 ST7FLITEUS2M6TR@SOIC8 [(SA602A)] ST7FLITEUS2U6TR@DFN8  
 [(BBBB)]  
 ST7FLITEUS5B6 ST7FLITEUS5M6@SOIC8  
 [(SA602A)]  
 ST7FLITEUS5M6TR@SOIC8 [(SA602A)] ST7FLITEUS5U6TR@DFN8  
 [(BBBB)]  
 ST7FLU05B6  
 ST7FLU05BAE  
 ST7FLU05BATRE  
 ST7FLU05BCE

ST7FLU05BCTRE [ (SA602A) ]	ST7FLU05M6@SOIC8
ST7FLU05MAE@SOIC8 [ (SA602A) ] [ (SA602A) ]	ST7FLU05MATRE@SOIC8
ST7FLU05MCE@SOIC8 [ (SA602A) ] [ (SA602A) ]	ST7FLU05MCTRE@SOIC8
ST7FLU09B6 ST7FLU09BAE ST7FLU09BATRE ST7FLU09BCE	
ST7FLU09BCTRE [ (SA602A) ]	ST7FLU09M6@SOIC8
ST7FLU09MAE@SOIC8 [ (SA602A) ] [ (SA602A) ]	ST7FLU09MATRE@SOIC8
ST7FLU09MCE@SOIC8 [ (SA602A) ] [ (SA602A) ]	ST7FLU09MCTRE@SOIC8
ST7FLUS5B6 ST7FLUS5BAE ST7FLUS5BATRE ST7FLUS5BCE	
ST7FLUS5BCTRE [ (SA602A) ]	ST7FLUS5M6@SOIC8
ST7FLUS5MAE@SOIC8 [ (SA602A) ] [ (SA602A) ]	ST7FLUS5MATRE@SOIC8
ST7FLUS5MCE@SOIC8 [ (SA602A) ] [ (SA602A) ]	ST7FLUS5MCTRE@SOIC8
ST7FMC1K2B6@SDIP32 [ (SA653) ] ST7FMC1K2B6@SDIP32( ISP ) [ ISP-HEADER01 ] ST7FMC1K2T3@TQFP32 [ (SA663) ] ST7FMC1K2T3@TQFP32( ISP ) [ ISP-HEADER01 ] ST7FMC1K2T6@TQFP32 [ (SA663) ] ST7FMC1K2T6@TQFP32( ISP ) [ ISP-HEADER01 ] ST7FMC1K2TC@TQFP32 [ (SA663) ] ST7FMC1K2TC@TQFP32( ISP ) [ ISP-HEADER01 ] ST7FMC1K4T6@TQFP32 [ (SA663) ] ST7FMC1K4T6@TQFP32( ISP ) [ ISP-HEADER01 ] ST7FMC1K6TC@TQFP32 [ (SA663) ] ST7FMC1K6TC@TQFP32( ISP ) [ ISP-HEADER01 ] ST7FMC2M9T6@LQFP80( ISP ) [ ISP-HEADER01 ] ST7FMC2N6B6@SDIP56 [ (PEP+S627) ] ST7FMC2N6B6@SDIP56( ISP ) [ ISP-HEADER01 ] ST7FMC2R6T6@TQFP64 [ (PEP+S625A) ] ST7FMC2R6T6@TQFP64( ISP ) [ ISP-HEADER01 ]	

ST7FMC2R7T6@TQFP64 [(PEP+S625A)]  
 ST7FMC2R7T6@TQFP64(ISP) [ISP-HEADER01]  
 ST7FMC2S4T3@TQFP44 [(SA245A)]  
 ST7FMC2S4T3@TQFP44(ISP) [ISP-HEADER01]  
 ST7FMC2S4T6@TQFP44 [(SA245A)]  
 ST7FMC2S4T6@TQFP44(ISP) [ISP-HEADER01]  
 ST7FMC2S4TC@TQFP44 [(SA245A)]  
 ST7FMC2S4TC@TQFP44(ISP) [ISP-HEADER01]  
 ST7FMC2S5T6@TQFP44 [(SA245A)]  
 ST7FMC2S5T6@TQFP44(ISP) [ISP-HEADER01]  
 ST7FMC2S5TC@TQFP44 [(SA245A)]  
 ST7FMC2S5TC@TQFP44(ISP) [ISP-HEADER01]  
 ST7FMC2S6T3@TQFP44 [(SA245A)]  
 ST7FMC2S6T3@TQFP44(ISP) [ISP-HEADER01]  
 ST7FMC2S6T6@TQFP44 [(SA245A)]  
 ST7FMC2S6T6@TQFP44(ISP) [ISP-HEADER01]  
 ST7FMC2S6TC@TQFP44 [(SA245A)]  
 ST7FMC2S6TC@TQFP44(ISP) [ISP-HEADER01]  
 ST7FOXF1B6 [(SA404)] ST7FOXF1M6@SOIC20  
 ST7FOXF2B6 [(SA404)] ST7FOXF2M6@SOIC20  
 ST7FOXK1B6@SDIP32 [(SA653)] ST7FOXK1T6@QFP32  
 [(SA663)]  
 ST7FOXK2B6@SDIP32 [(SA653)] ST7FOXK2T6@QFP32  
 [(SA663)]  
 ST7FOXU0B6 [(SA602A)] ST7FOXU0M6@SO8  
 ST7FSCR1E4M1@SOIC24(\*) [(SA404-B140)]  
 ST7FSCR1R4T1@TQFP64(\*) [(TA032-B006)]  
 ST92T165@TQFP64 [(PEP+S625)] STR910FM@QFP80 [(PEP  
 +S640B)]  
 STR911FM@QFP80 [(PEP+S640B)] STR912FM@QFP80 [(PEP  
 +S640B)]  
 uPSD3212C@TQFP52 [(PEP+S673)] uPSD3212C@TQFP80 [(PEP  
 +S640B)]  
 uPSD3212CV@TQFP52 [(PEP+S673)] uPSD3212CV@TQFP80 [(PEP  
 +S640B)]  
 uPSD3233B@TQFP52 [(PEP+S673)] uPSD3233B@TQFP80 [(PEP  
 +S640B)]  
 uPSD3233BV@TQFP52 [(PEP+S673)] uPSD3233BV@TQFP80 [(PEP  
 +S640B)]  
 uPSD3234A@TQFP52 [(PEP+S673)] uPSD3234A@TQFP80 [(PEP

+S640B) ]  
uPSD3234BV@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3253B@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3253BV@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3254A@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3254BV@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3312D@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3312DB@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3312DV@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3312DVB@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3333D@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3333DB@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3333DV@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3333DVB@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3334D@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3334DB@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3334DV@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3334DVB@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3354D@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3354DB@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3354DV@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]  
uPSD3354DVB@TQFP52 [ ( PEP+S673 ) ]  
+S640B) ]

uPSD3234BV@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3253B@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3253BV@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3254A@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3254BV@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3312D@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3312DB@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3312DV@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3312DVB@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3333D@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3333DB@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3333DV@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3333DVB@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3334D@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3334DB@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3334DV@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3334DVB@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3354D@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3354DB@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3354DV@TQFP80 [ ( PEP  
+S640B) ]  
uPSD3354DVB@TQFP80 [ ( PEP  
+S640B) ]



uPSD3422E@TQFP52 [(PEP+S673)]  
+S640B)]  
uPSD3422EB@TQFP52 [(PEP+S673)]  
+S640B)]  
uPSD3422EV@TQFP52 [(PEP+S673)]  
+S640B)]  
uPSD3422EVB@TQFP52 [(PEP+S673)]  
+S640B)]  
uPSD3433E@TQFP52 [(PEP+S673)]  
+S640B)]  
uPSD3433EB@TQFP52 [(PEP+S673)]  
+S640B)]  
uPSD3433EV@TQFP52 [(PEP+S673)]  
+S640B)]  
uPSD3433EVB@TQFP52 [(PEP+S673)]  
+S640B)]  
uPSD3434E@TQFP52 [(PEP+S673)]  
+S640B)]  
uPSD3434EB@TQFP52 [(PEP+S673)]  
+S640B)]  
uPSD3434EV@TQFP52 [(PEP+S673)]  
+S640B)]  
uPSD3434EVB@TQFP52 [(PEP+S673)]  
+S640B)]  
uPSD3454E@TQFP52 [(PEP+S673)]  
+S640B)]  
uPSD3454EB@TQFP52 [(PEP+S673)]  
+S640B)]  
uPSD3454EV@TQFP52 [(PEP+S673)]  
+S640B)]  
uPSD3454EVB@TQFP52 [(PEP+S673)]  
+S640B)]  
ZPSD211R@PLCC44 [(SA244)]  
[(SA245A)]  
ZPSD211RV@PLCC44 [(SA244)]  
[(SA245A)]  
ZPSD301@PLCC44 [(SA244)]  
[(SA245A)]  
ZPSD301L@PLCC44 [(SA244)]  
[(SA245A)]  
ZPSD301R@PLCC44 [(SA244)]  
[(SA245A)]  
ZPSD301RL@PLCC44 [(SA244)]

uPSD3422E@TQFP80 [(PEP  
uPSD3422EB@TQFP80 [(PEP  
uPSD3422EV@TQFP80 [(PEP  
uPSD3422EVB@TQFP80 [(PEP  
uPSD3433E@TQFP80 [(PEP  
uPSD3433EB@TQFP80 [(PEP  
uPSD3433EV@TQFP80 [(PEP  
uPSD3433EVB@TQFP80 [(PEP  
uPSD3434E@TQFP80 [(PEP  
uPSD3434EB@TQFP80 [(PEP  
uPSD3434EV@TQFP80 [(PEP  
uPSD3434EVB@TQFP80 [(PEP  
uPSD3454E@TQFP80 [(PEP  
uPSD3454EB@TQFP80 [(PEP  
uPSD3454EV@TQFP80 [(PEP  
uPSD3454EVB@TQFP80 [(PEP  
ZPSD211R@TQFP44  
ZPSD211RV@TQFP44  
ZPSD301@TQFP44  
ZPSD301L@TQFP44  
ZPSD301R@TQFP44  
ZPSD301RL@TQFP44

[ (SA245A) ]	
ZPSD301RV@PLCC44 [ (SA244) ]	ZPSD301RV@TQFP44
[ (SA245A) ]	
ZPSD301V@PLCC44 [ (SA244) ]	ZPSD301V@TQFP44
[ (SA245A) ]	
ZPSD302@PLCC44 [ (SA244) ]	ZPSD302@TQFP44
[ (SA245A) ]	
ZPSD302B@PLCC44 [ (SA244) ]	ZPSD302B@PLCC44 (USA)
[ (SA411A) ]	
ZPSD302L@PLCC44 [ (SA244) ]	ZPSD302L@TQFP44
[ (SA245A) ]	
ZPSD302R@PLCC44 [ (SA244) ]	ZPSD302R@TQFP44
[ (SA245A) ]	
ZPSD302RL@PLCC44 [ (SA244) ]	ZPSD302RL@TQFP44
[ (SA245A) ]	
ZPSD302RV@PLCC44 [ (SA244) ]	ZPSD302RV@TQFP44
[ (SA245A) ]	
ZPSD302V@PLCC44 [ (SA244) ]	ZPSD302V@TQFP44
[ (SA245A) ]	
ZPSD303@PLCC44 [ (SA244) ]	ZPSD303@TQFP44
[ (SA245A) ]	
ZPSD303L@PLCC44 [ (SA244) ]	ZPSD303L@TQFP44
[ (SA245A) ]	
ZPSD303R@PLCC44 [ (SA244) ]	ZPSD303R@TQFP44
[ (SA245A) ]	
ZPSD303RL@PLCC44 [ (SA244) ]	ZPSD303RL@TQFP44
[ (SA245A) ]	
ZPSD303RV@PLCC44 [ (SA244) ]	ZPSD303RV@TQFP44
[ (SA245A) ]	
ZPSD303V@PLCC44 [ (SA244) ]	ZPSD303V@TQFP44
[ (SA245A) ]	
ZPSD311@PLCC44 [ (SA244) ]	ZPSD311@TQFP44
[ (SA245A) ]	
ZPSD311L@PLCC44 [ (SA244) ]	ZPSD311L@TQFP44
[ (SA245A) ]	
ZPSD311R@PLCC44 [ (SA244) ]	ZPSD311R@TQFP44
[ (SA245A) ]	
ZPSD311RL@PLCC44 [ (SA244) ]	ZPSD311RL@TQFP44
[ (SA245A) ]	
ZPSD311RV@PLCC44 [ (SA244) ]	ZPSD311RV@TQFP44
[ (SA245A) ]	
ZPSD311V@PLCC44 [ (SA244) ]	ZPSD311V@TQFP44
[ (SA245A) ]	

ZPSD312@PLCC44 [(SA244)]	ZPSD312@TQFP44
[(SA245A)]	
ZPSD312B@PLCC44 [(SA244)]	ZPSD312L@PLCC44
[(SA244)]	
ZPSD312L@TQFP44 [(SA245A)]	ZPSD312R@PLCC44
[(SA244)]	
ZPSD312R@TQFP44 [(SA245A)]	ZPSD312RL@PLCC44
[(SA244)]	
ZPSD312RL@TQFP44 [(SA245A)]	ZPSD312RV@PLCC44
[(SA244)]	
ZPSD312RV@TQFP44 [(SA245A)]	ZPSD312V@PLCC44
[(SA244)]	
ZPSD312V@TQFP44 [(SA245A)]	ZPSD313@PLCC44
[(SA244)]	
ZPSD313@TQFP44 [(SA245A)]	ZPSD313L@PLCC44
[(SA244)]	
ZPSD313L@TQFP44 [(SA245A)]	ZPSD313R@PLCC44
[(SA244)]	
ZPSD313R@TQFP44 [(SA245A)]	ZPSD313RL@PLCC44
[(SA244)]	
ZPSD313RL@TQFP44 [(SA245A)]	ZPSD313RV@PLCC44
[(SA244)]	
ZPSD313RV@TQFP44 [(SA245A)]	ZPSD313V@PLCC44
[(SA244)]	
ZPSD313V@TQFP44 [(SA245A)]	ZPSD813F2@PLCC52 [(PEP
+S415T)]	
ZPSD813F4@PLCC52 [(PEP+S415T)]	

## STC

### MICROCONTROLLER

STC89C516RD	STC89C516RD@PLCC44
[(SA244)]	
STC89C516RD@TQFP44 [(SA245A)]	
STC89C58RD	
STC89C58RD@PLCC44 [(SA244)]	STC89C58RD@TQFP44
[(SA245A)]	
STC89LE516AD	STC89LE516AD@PLCC44
[(SA244)]	
STC89LE516AD@TQFP44 [(SA245A)]	
STC89LE516X2	

STC89LE516X2@PLCC44 [(SA244)]	STC89LE516X2@TQFP44
[(SA245A)]	
STC89LE52AD	STC89LE52AD@PLCC44
[(SA244)]	
STC89LE52AD@TQFP44 [(SA675)]	
STC89LE54AD	
STC89LE54AD@PLCC44 [(SA244)]	STC89LE54AD@TQFP44
[(SA675)]	
STC89LE556AD	STC89LE556AD@PLCC44
[(SA244)]	
STC89LE556AD@TQFP44 [(SA245A)]	
STC89LE556X2	
STC89LE556X2@PLCC44 [(SA244)]	STC89LE556X2@TQFP44
[(SA245A)]	
STC89LE58AD	STC89LE58AD@PLCC44
[(SA244)]	
STC89LE58AD@TQFP44 [(SA675)]	
STC89LV516RD	
STC89LV516RD@PLCC44 [(SA244)]	STC89LV516RD@TQFP44
[(SA245A)]	
STC89LV58RD	STC89LV58RD@PLCC44
[(SA244)]	
STC89LV58RD@TQFP44 [(SA245A)]	

## ST-CUSTOMER

### E (E) PROM/FRAM/NVRAM

M28W160ECB(Moto)@FBGA48 [(SA714A-B026A-M046F001Y)]  
M28W160ECT(Moto)@FBGA48 [(SA714A-B026A-M046F001Y)]  
M36L0R7050B0\_B1(HZ)@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050T0\_T1(HZ)@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060B3(HZ)@FBGA88 [(SA642A-B124A-Y096F001Y)]  
M36L0R8060B5ZAQ(HZ)@FBGA88 [(SA642A-B124A-Y096F001Y)]  
M58LR128FB\_GB(HZ)@VFBGA56 [(SA644A-B025B-Y072F001)]  
M58LR128FT\_GT(HZ)@VFBGA56 [(SA644A-B025B-Y072F001)]  
NAND01GW3B2BZA6(ASUS)@FBGA63 [(SA642KK-B026-W048F001Y)]  
NAND04GW3B2BN6(WS)@TSOP48 [(SA247-B005)]  
NAND512R3A2(MLT)@FBGA63 [(SA642KK-B026-W0638F001Y)]  
NANDA9R4N2AZBA5(UT)@FBGA149 [(SA664G-B279-Y149F001Y)]

# SUMMIT

## E ( E ) PROM / FRAM / NVRAM

S24022	S24022@SOIC8
[ ( SA602A ) ]	
S24023	S24023@SOIC8
[ ( SA602A ) ]	
S24042	S24042@SOIC8
[ ( SA602A ) ]	
S24043	S24043@SOIC8
[ ( SA602A ) ]	
S24162	S24162@SOIC8
[ ( SA602A ) ]	
S24VP02	S24VP02@SOIC8
[ ( SA602A ) ]	
S24VP04	S24VP04@SOIC8
[ ( SA602A ) ]	
S24VP08	S24VP08@SOIC8
[ ( SA602A ) ]	
S24VP16	S24VP16@SOIC8
[ ( SA602A ) ]	
S93462(08bit)	S93462(08bit)@SOIC8
[ ( SA602A ) ]	
S93462(16bit)	S93462(16bit)@SOIC8
[ ( SA602A ) ]	
S93463(08bit)	S93463(08bit)@SOIC8
[ ( SA602A ) ]	
S93463(16bit)	S93463(16bit)@SOIC8
[ ( SA602A ) ]	
S93662(08bit)	S93662(08bit)@SOIC8
[ ( SA602A ) ]	
S93662(16bit)	S93662(16bit)@SOIC8
[ ( SA602A ) ]	
S93663(08bit)	S93663(08bit)@SOIC8
[ ( SA602A ) ]	
S93663(16bit)	S93663(16bit)@SOIC8
[ ( SA602A ) ]	
S93WD462(08bit)	S93WD462(08bit)@SOIC8
[ ( SA602A ) ]	
S93WD462(16bit)	S93WD462(16bit)@SOIC8
[ ( SA602A ) ]	
S93WD463(08bit)	S93WD463(08bit)@SOIC8

[ (SA602A) ]	
S93WD463(16bit)	S93WD463(16bit)@SOIC8
[ (SA602A) ]	
S93WD662(08bit)	S93WD662(08bit)@SOIC8
[ (SA602A) ]	
S93WD662(16bit)	S93WD662(16bit)@SOIC8
[ (SA602A) ]	
S93WD663(08bit)	S93WD663(08bit)@SOIC8
[ (SA602A) ]	
S93WD663(16bit)	S93WD663(16bit)@SOIC8
[ (SA602A) ]	

## MICROCONTROLLER

I-SMM465F-249@TQFP48 (ISP) [ ISP-HEADER01 ]	
SMM465F-249@TQFP48 [ (SA248) ]	SMM665BFC-266@TQFP48
[ (SA248) ]	
SMM665BFC-266@TQFP48 (ISP) [ ISP-HEADER01 ]	

## SUNPLUS

### E ( E ) PROM / FRAM / NVRAM

SPHE6400A	SPHE6400A@SOIC8
[ (SA602A) ]	

## MICROCONTROLLER

SPMC65P2102A(dip18)	
SPMC65P2102A(dip18)(ISP) [ ISP-HEADER01 ]	
SPMC65P2102A@SOP18 [ (SA404) ]	
SPMC65P2102A@SOP18(ISP) [ ISP-HEADER01 ]	
SPMC65P2104A(dip18)	
SPMC65P2104A(dip18)(ISP) [ ISP-HEADER01 ]	
SPMC65P2104A@SOP18 [ (SA404) ]	
SPMC65P2104A@SOP18(ISP) [ ISP-HEADER01 ]	
SPMC65P2202A(dip16)	
SPMC65P2202A(dip16)(ISP) [ ISP-HEADER01 ]	
SPMC65P2202A(dip20)	

SPMC65P2202A(dip20)(ISP) [ISP-HEADER01]  
SPMC65P2202A@SOP16 [(SA404)]  
SPMC65P2202A@SOP16(ISP) [ISP-HEADER01]  
SPMC65P2202A@SOP20 [(SA404)]  
SPMC65P2202A@SOP20(ISP) [ISP-HEADER01]  
SPMC65P2204A(dip16)  
SPMC65P2204A(dip16)(ISP) [ISP-HEADER01]  
SPMC65P2204A(dip20)  
SPMC65P2204A(dip20)(ISP) [ISP-HEADER01]  
SPMC65P2204A@SOP16 [(SA404)]  
SPMC65P2204A@SOP16(ISP) [ISP-HEADER01]  
SPMC65P2204A@SOP20 [(SA404)]  
SPMC65P2204A@SOP20(ISP) [ISP-HEADER01]  
SPMC65P2404A(dip20)  
SPMC65P2404A(dip20)(ISP) [ISP-HEADER01]  
SPMC65P2404A(dip28)  
SPMC65P2404A(dip28)(ISP) [ISP-HEADER01]  
SPMC65P2404A@SOP20 [(SA404)]  
SPMC65P2404A@SOP20(ISP) [ISP-HEADER01]  
SPMC65P2404A@SOP28 [(SA404)]  
SPMC65P2404A@SOP28(ISP) [ISP-HEADER01]  
SPMC65P2408A(dip28)  
SPMC65P2408A(dip28)(ISP) [ISP-HEADER01]  
SPMC65P2408A(dip32)  
SPMC65P2408A(dip32)(ISP) [ISP-HEADER01]  
SPMC65P2408A@SOP28 [(SA404)]  
SPMC65P2408A@SOP28(ISP) [ISP-HEADER01]  
SPMC65P2408A@SOP32 [(SA603)]  
SPMC65P2408A@SOP32(ISP) [ISP-HEADER01]

## SYNCMOS

### E(E) PROM/FRAM/NVRAM

F29C31004B [(SA015A1T)]	F29C31004B@PLCC32
F29C31004B@TSOP32 [(SA410T)]	
F29C31004T	
F29C31004T@PLCC32 [(SA015A1T)]	F29C31004T@TSOP32
[(SA410T)]	
F29C51000B	F29C51000B@PLCC32
[(SA015A1T)]	

F29C51000T [ (SA015A1T) ]	F29C51000T@PLCC32
F29C51001B [ (SA015A1T) ]	F29C51001B@PLCC32
F29C51001B@TSOP32 [ (SA410T) ]	
F29C51001T F29C51001T@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	F29C51001T@TSOP32
F29C51002B [ (SA015A1T) ]	F29C51002B@PLCC32
F29C51002B@TSOP32 [ (SA410T) ]	
F29C51002T F29C51002T@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	F29C51002T@TSOP32
F29C51004B [ (SA015A1T) ]	F29C51004B@PLCC32
F29C51004B@TSOP32 [ (SA410T) ]	
F29C51004T F29C51004T@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	F29C51004T@TSOP32
F29LC51000 [ (SA015A1T) ]	F29LC51000@PLCC32
F29LC51001 [ (SA015A1T) ]	F29LC51001@PLCC32
F29LC51002 [ (SA015A1T) ]	F29LC51002@PLCC32
S29C31001B [ (SA015A1T) ]	S29C31001B@PLCC32
S29C31001B@TSOP32 [ (SA410T) ]	
S29C31001T S29C31001T@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	S29C31001T@TSOP32
S29C31002B [ (SA015A1T) ]	S29C31002B@PLCC32
S29C31002B@TSOP32 [ (SA410T) ]	
S29C31002T S29C31002T@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	S29C31002T@TSOP32
S29C31004B [ (SA015A1T) ]	S29C31004B@PLCC32
S29C31004B@TSOP32 [ (SA410T) ]	
S29C31004T S29C31004T@PLCC32 [ (SA015A1T) ]	S29C31004T@TSOP32



[ (SA410T) ]	
S29C51001B	S29C51001B@PLCC32
[ (SA015A1T) ]	
S29C51001B@TSOP32 [ (SA410T) ]	
S29C51001T	
S29C51001T@PLCC32 [ (SA015A1T) ]	S29C51001T@TSOP32
[ (SA410T) ]	
S29C51002B	S29C51002B@PLCC32
[ (SA015A1T) ]	
S29C51002B@TSOP32 [ (SA410T) ]	
S29C51002T	
S29C51002T@PLCC32 [ (SA015A1T) ]	S29C51002T@TSOP32
[ (SA410T) ]	
S29C51004B	S29C51004B@PLCC32
[ (SA015A1T) ]	
S29C51004B@TSOP32 [ (SA410T) ]	
S29C51004T	
S29C51004T@PLCC32 [ (SA015A1T) ]	S29C51004T@TSOP32
[ (SA410T) ]	

## MICROCONTROLLER

MSU1958	MSU1958@PLCC44
[ (SA244) ]	
MSU1958@TQFP44 [ (SA245A) ]	
MSU2952	
MSU2952@PLCC44 [ (SA244) ]	MSU2952@TQFP44
[ (SA245A) ]	
MSU2964	MSU2964@PLCC44
[ (SA244) ]	
MSU2964@TQFP44 [ (SA245A) ]	
SM2958	
SM2958@PLCC44 [ (SA244) ]	SM2958@TQFP44
[ (SA245A) ]	
SM2965	SM2965@PLCC44
[ (SA244) ]	
SM2965@TQFP44 [ (SA245A) ]	
SM59064	
SM59064@PLCC44 [ (SA244) ]	SM59064@TQFP44
[ (SA245A) ]	
SM59128C	SM59128C@PLCC44
[ (SA244) ]	

SM59128C@TQFP44 [(SA245A)]	
SM59128L	
SM59128L@PLCC44 [(SA244)]	SM59128L@TQFP44
[(SA245A)]	
SM59164	
[(SA244)]	SM59164@PLCC44
SM59164@TQFP44 [(SA245A)]	
SM59264	
SM59264@PLCC44 [(SA244)]	SM59264@TQFP44
[(SA245A)]	
SM5964	
[(SA244)]	SM5964@PLCC44
SM5964@TQFP44 [(SA245A)]	
SM5964A	
SM5964A@PLCC44 [(SA244)]	SM5964A@TQFP44
[(SA245A)]	
SM5964AC	
[(SA244)]	SM5964AC@PLCC44
SM5964AC@TQFP44 [(SA245A)]	
SM5964AL	
SM5964AL@PLCC44 [(SA244)]	SM5964AL@TQFP44
[(SA245A)]	
SM5964C	
[(SA244)]	SM5964C@PLCC44
SM5964C@TQFP44 [(SA245A)]	
SM5964D0	
SM5964D0@PLCC44 [(SA244)]	SM5964D0@TQFP44
[(SA245A)]	
SM5964D0A	
[(SA244)]	SM5964D0A@PLCC44
SM5964D0A@TQFP44 [(SA245A)]	
SM5964D1A	
SM5964D1A@PLCC44 [(SA244)]	SM5964D1A@TQFP44
[(SA245A)]	
SM59D02G2C	
HEADER01]	SM59D02G2C(ISP) [ISP-
SM59D02G2C@LQFP44 [(SA675-B005)]	
SM59D02G2C@LQFP44(ISP) [ISP-HEADER01]	
SM59D02G2C@PLCC44 [(SA244-B002)]	
SM59D02G2C@PLCC44(ISP) [ISP-HEADER01]	
SM59D02G2L	
HEADER01]	SM59D02G2L(ISP) [ISP-
SM59D02G2L@LQFP44 [(SA675-B005)]	

SM59D02G2L@LQFP44 (ISP) [ISP-HEADER01]  
 SM59D02G2L@PLCC44 [(SA244-B002)]  
 SM59D02G2L@PLCC44 (ISP) [ISP-HEADER01]  
 SM59D03G2C SM59D03G2C (ISP) [ISP-  
 HEADER01]  
 SM59D03G2C@LQFP44 [(SA675-B005)]  
 SM59D03G2C@LQFP44 (ISP) [ISP-HEADER01]  
 SM59D03G2C@PLCC44 [(SA244-B002)]  
 SM59D03G2C@PLCC44 (ISP) [ISP-HEADER01]  
 SM59D03G2L SM59D03G2L (ISP) [ISP-  
 HEADER01]  
 SM59D03G2L@LQFP44 [(SA675-B005)]  
 SM59D03G2L@LQFP44 (ISP) [ISP-HEADER01]  
 SM59D03G2L@PLCC44 [(SA244-B002)]  
 SM59D03G2L@PLCC44 (ISP) [ISP-HEADER01]  
 SM59D04G2C SM59D04G2C (ISP) [ISP-  
 HEADER01]  
 SM59D04G2C@LQFP44 [(SA675-B005)]  
 SM59D04G2C@LQFP44 (ISP) [ISP-HEADER01]  
 SM59D04G2C@PLCC44 [(SA244-B002)]  
 SM59D04G2C@PLCC44 (ISP) [ISP-HEADER01]  
 SM59D04G2L SM59D04G2L (ISP) [ISP-  
 HEADER01]  
 SM59D04G2L@LQFP44 [(SA675-B005)]  
 SM59D04G2L@LQFP44 (ISP) [ISP-HEADER01]  
 SM59D04G2L@PLCC44 [(SA244-B002)]  
 SM59D04G2L@PLCC44 (ISP) [ISP-HEADER01]  
 SM59R08A2@TQFP64 (\*) [(SA732-B292)]  
 SM59R16A2@TQFP64 (\*) [(SA732-B292)]  
 SM7908 SM7908@PLCC44  
 [(SA244)]  
 SM7908@TQFP44 [(SA245A)]  
 SM79108  
 SM79108@PLCC44 [(SA244)] SM79108@TQFP44  
 [(SA245A)]  
 SM79164 SM79164@PLCC44  
 [(SA244)]  
 SM79164@TQFP44 [(SA245A)]  
 SM79164L  
 SM79164L@PLCC44 [(SA244)] SM79164L@TQFP44  
 [(SA245A)]  
 SM79164V SM79164V@PLCC44  
 [(SA244)]

SM79164V@TQFP44 [(SA245A)]

SM7932

SM7932@PLCC44 [(SA244)]

[(SA245A)]

SM7964

[(SA244)]

SM7964@TQFP44 [(SA245A)]

SM894051

SM894051@SOIC20 [ordering number is marked above]

SM8951

[(SA244)]

SM8951@TQFP44 [(SA245A)]

SM89516

SM89516@PLCC44 [(SA244)]

[(SA245A)]

SM89516A

[(SA244)]

SM89516A@TQFP44 [(SA245A)]

SM89516AL

SM89516AL@PLCC44 [(SA244)]

[(SA245A)]

SM89516B

[(SA244)]

SM89516B@TQFP44 [(SA245A)]

SM89516BL

SM89516BL@PLCC44 [(SA244)]

[(SA245A)]

SM89516L

[(SA244)]

SM89516L@TQFP44 [(SA245A)]

SM8951A

SM8951A@PLCC44 [(SA244)]

[(SA245A)]

SM8951AL

[(SA244)]

SM8951AL@TQFP44 [(SA245A)]

SM8951B

SM8951B@PLCC44 [(SA244)]

[(SA245A)]

SM8951BL

[(SA244)]

SM8951BL@TQFP44 [(SA245A)]

SM8951L

SM7932@TQFP44

SM7964@PLCC44

SM89516@TQFP44

SM89516A@PLCC44

SM89516AL@TQFP44

SM89516B@PLCC44

SM89516BL@TQFP44

SM89516L@PLCC44

SM8951A@TQFP44

SM8951AL@PLCC44

SM8951B@TQFP44

SM8951BL@PLCC44

SM8951L@PLCC44 [(SA244)]  
[(SA245A)]  
SM8952  
[(SA244)]  
SM8952@TQFP44 [(SA245A)]  
SM8952A  
SM8952A@PLCC44 [(SA244)]  
[(SA245A)]  
SM8952AL  
[(SA244)]  
SM8952AL@TQFP44 [(SA245A)]  
SM8952B  
SM8952B@PLCC44 [(SA244)]  
[(SA245A)]  
SM8952BL  
[(SA244)]  
SM8952BL@TQFP44 [(SA245A)]  
SM8952L  
SM8952L@PLCC44 [(SA244)]  
[(SA245A)]  
SM8954  
[(SA244)]  
SM8954@TQFP44 [(SA245A)]  
SM8954A  
SM8954A@PLCC44 [(SA244)]  
[(SA245A)]  
SM8954AL  
[(SA244)]  
SM8954AL@TQFP44 [(SA245A)]  
SM8954B  
SM8954B@PLCC44 [(SA244)]  
[(SA245A)]  
SM8954BL  
[(SA244)]  
SM8954BL@TQFP44 [(SA245A)]  
SM8954L  
SM8954L@PLCC44 [(SA244)]  
[(SA245A)]  
SM8958  
[(SA244)]  
SM8958@TQFP44 [(SA245A)]  
SM8958A  
SM8958A@PLCC44 [(SA244)]

SM8951L@TQFP44  
  
SM8952@PLCC44  
  
SM8952A@TQFP44  
  
SM8952AL@PLCC44  
  
SM8952B@TQFP44  
  
SM8952BL@PLCC44  
  
SM8952L@TQFP44  
  
SM8954@PLCC44  
  
SM8954A@TQFP44  
  
SM8954AL@PLCC44  
  
SM8954B@TQFP44  
  
SM8954BL@PLCC44  
  
SM8954L@TQFP44  
  
SM8958@PLCC44  
  
SM8958A@TQFP44

[ ( SA245A ) ]	
SM8958AL	SM8958AL@PLCC44
[ ( SA244 ) ]	
SM8958AL@TQFP44 [ ( SA245A ) ]	
SM8958B	
SM8958B@PLCC44 [ ( SA244 ) ]	SM8958B@TQFP44
[ ( SA245A ) ]	
SM8958BL	
[ ( SA244 ) ]	
SM8958BL@TQFP44 [ ( SA245A ) ]	
SM8958L	
SM8958L@PLCC44 [ ( SA244 ) ]	SM8958L@TQFP44
[ ( SA245A ) ]	
SM89S16R1C	SM89S16R1C@PLCC44
[ ( SA244 ) ]	
SM89S16R1C@TQFP44 [ ( SA245A ) ]	
SM89T04R1C	
SM89T04R1C@PLCC44 [ ( SA244 ) ]	SM89T04R1C@TQFP44
[ ( SA245A ) ]	
SM89T04R1L	
[ ( SA244 ) ]	
SM89T04R1L@TQFP44 [ ( SA245A ) ]	
SM89T08R1C	
SM89T08R1C@PLCC44 [ ( SA244 ) ]	SM89T08R1C@TQFP44
[ ( SA245A ) ]	
SM89T08R1L	
[ ( SA244 ) ]	
SM89T08R1L@TQFP44 [ ( SA245A ) ]	
SM89T16R1C	
SM89T16R1C@PLCC44 [ ( SA244 ) ]	SM89T16R1C@TQFP44
[ ( SA245A ) ]	
SM89T16R1L	
[ ( SA244 ) ]	
SM89T16R1L@TQFP44 [ ( SA245A ) ]	

## **SYNERTEK**

### **E ( E ) PROM / FRAM / NVRAM**

SY2716

**SYNTEK****MICROCONTROLLER**

STK6011BP1-3V@PLCC44 [(SA244)] [(SA244)]	STK6011BP21-5V@PLCC44
STK6011BP5-3V@TQFP44 [(SA245A)] [(SA248)]	STK6011P10-5V@LQFP48
STK6011P1-3V@PLCC44 [(SA244)] [(SA244)]	STK6011P2-5V@PLCC44
STK6011P3-3V@SDIP42 [(SA028)] [(SA028)]	STK6011P4-5V@SDIP42
STK6011P5-3V@PQFP44 [(SA245A)] [(SA245A)]	STK6011P6-5V@PQFP44
STK6011P7-3V 5V	STK6011P8-
STK6011P9-3V@LQFP48 [(SA248)] [(SA244)]	STK6012BP1-3V@PLCC44
STK6012BP22-5V@PLCC44 [(SA244)] [(SA245A)]	STK6012BP5-3V@TQFP44
STK6012P10-5V@LQFP48 [(SA248)] [(SA244)]	STK6012P1-3V@PLCC44
STK6012P2-5V@PLCC44 [(SA244)] [(SA028)]	STK6012P3-3V@SDIP42
STK6012P4-5V@SDIP42 [(SA028)] [(SA245A)]	STK6012P5-3V@PQFP44
STK6012P6-5V@PQFP44 [(SA245A)] 3V	STK6012P7-
STK6012P8-5V [(SA248)]	STK6012P9-3V@LQFP48

**TECHCODE****MICROCONTROLLER**

T89C516 [(SA244)]	T89C516@PLCC44
T89C516@TQFP44 [(SA245A)]	
T89C52	
T89C52@PLCC44 [(SA244)] [(SA245A)]	T89C52@TQFP44

T89C58  
[ ( SA244 ) ]  
T89C58@TQFP44 [ ( SA245A ) ]

T89C58@PLCC44

## TEKMOS

### E ( E ) PROM / FRAM / NVRAM

TK17LV040@PLCC20 [ ( SA001A ) ]

## TEMIC

### MICROCONTROLLER

T89C51RD2  
[ ( SA244 ) ]  
T89C51RD2@PLCC68 [ ( PEP+S414T ) ]  
[ ( SA245A ) ]  
T89F64  
[ ( SA244 ) ]  
T89F64@TQFP44 [ ( SA245A ) ]  
TS87C51RB2  
TS87C51RB2@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]  
TS87C51RC2  
[ ( SA244 ) ]  
TS87C51RC2@TQFP44 [ ( SA245A ) ]  
TS87C51RD2  
TS87C51RD2@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]  
TS87C51U2  
[ ( SA244 ) ]  
TS87C51U2@TQFP44 [ ( SA245A ) ]  
TS87C52X2  
TS87C52X2@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]  
TS87C54X2  
[ ( SA244 ) ]  
TS87C54X2@TQFP44 [ ( SA245A ) ]  
TS87C58X2

T89C51RD2@PLCC44  
T89C51RD2@TQFP44  
T89F64@PLCC44  
TS87C51RB2@TQFP44  
TS87C51RC2@PLCC44  
TS87C51RD2@TQFP44  
TS87C51U2@PLCC44  
TS87C52X2@TQFP44  
TS87C54X2@PLCC44



TS87C58X2@PLCC44 [(SA244)]	TS87C58X2@TQFP44
[(SA245A)]	
TSC71RBX2	TSC71RBX2@PLCC44
[(SA244)]	
TSC71RBX2@TQFP44 [(SA245A)]	
TSC71RCX2	
TSC71RCX2@PLCC44 [(SA244)]	TSC71RCX2@TQFP44
[(SA245A)]	
TSC71RDX2	TSC71RDX2@PLCC44
[(SA244)]	
TSC71RDX2@PLCC68 [(PEP+S414T)]	TSC71RDX2@TQFP44
[(SA245A)]	
TSC71RDX2@TQFP64 [(PEP+S417T)]	TSC87251A1@PLCC44
[(SA244)]	
TSC87251G1	TSC87251G1@PLCC44
[(SA244)]	
TSC87251G1A	TSC87251G1A@PLCC44
[(SA244)]	
TSC87251G2D	TSC87251G2D@PLCC44
[(SA244)]	
TSC87251G2D@TQFP44 [(SA245A)]	
TSC87C51	
TSC87C51@PLCC44 [(SA244)]	TSC87C51@TQFP44
[(SA245A)]	
TSC87C52	TSC87C52@PLCC44
[(SA244)]	
TSC87C52@TQFP44 [(SA245A)]	
TSC87C54	
TSC87C54@PLCC44 [(SA244)]	TSC87C54@TQFP44
[(SA245A)]	
TSC87C58	TSC87C58@PLCC44
[(SA244)]	
TSC87C58@TQFP44 [(SA245A)]	

## TEST-LOGIC

### MICROCONTROLLER

TL1008	TL1008@PLCC44
[(SA244)]	
TL1008@TQFP44 [(SA245A)]	
TL2008	

TL2008@PLCC44 [(SA244)]	TL2008@TQFP44
[(SA245A)]	
TL20164	TL20164@PLCC44
[(SA244)]	
TL20164@TQFP44 [(SA245A)]	
TL20164A	
TL20164A@PLCC44 [(SA244)]	TL20164A@TQFP44
[(SA245A)]	
TL20164L	TL20164L@PLCC44
[(SA244)]	
TL20164L@TQFP44 [(SA245A)]	
TL2032	
TL2032@PLCC44 [(SA244)]	TL2032@TQFP44
[(SA245A)]	
TL2054A	TL2054A@PLCC44
[(SA244)]	
TL2054A@TQFP44 [(SA245A)]	
TL2064	
TL2064@PLCC44 [(SA244)]	TL2064@TQFP44
[(SA245A)]	
TL40516	TL40516@PLCC44
[(SA244)]	
TL40516@TQFP44 [(SA245A)]	
TL40516A	
TL40516A@PLCC44 [(SA244)]	TL40516A@TQFP44
[(SA245A)]	
TL40516B	TL40516B@PLCC44
[(SA244)]	
TL40516B@TQFP44 [(SA245A)]	
TL4054	
TL4054@PLCC44 [(SA244)]	TL4054@TQFP44
[(SA245A)]	
TL4058	TL4058@PLCC44
[(SA244)]	
TL4058@TQFP44 [(SA245A)]	
TL4058A	
TL4058A@PLCC44 [(SA244)]	TL4058A@TQFP44
[(SA245A)]	

**TI**

**E (E) PROM / FRAM / NVRAM**

BQ4010  
BQ4010Y  
BQ4011  
BQ4011Y  
BQ4013  
BQ4013Y  
BQ4014  
BQ4014Y  
BQ4015  
BQ4015Y  
SMJ2516  
SMJ2532  
SMJ2532A  
SMJ2564  
SMJ2564@PLCC32 [(SA015A1T)]  
SMJ2716  
SMJ27C256 SMJ27C256@PLCC32  
[(SA015A1T)]  
SMJ27C512 SMJ27C512@PLCC32  
[(SA015A1T)]  
TMS2516  
TMS2516JLW  
TMS2532  
TMS2532A  
TMS2564 TMS2564@PLCC32  
[(SA015A1T)]  
TMS25L32  
TMS27128  
TMS27128A  
TMS2716  
TMS2732  
TMS2732A  
TMS2764  
TMS27C010  
TMS27C010@PLCC32 [(SA015A1T)] TMS27C010@TSOP32  
[(SA410T)]  
TMS27C010A TMS27C010A@PLCC32  
[(SA015A1T)]  
TMS27C010A@TSOP32 [(SA410T)]  
TMS27C020  
TMS27C020@PLCC32 [(SA015A1T)] TMS27C020@TSOP32  
[(SA410T)]

TMS27C040	TMS27C040@PLCC32
[ (SA015A1T) ]	
TMS27C040@TSOP32 [ (SA410T) ]	
TMS27C128	
TMS27C128@PLCC32 [ (SA015A1T) ]	
TMS27C2001	
TMS27C2001@PLCC32 [ (SA015A1T) ]	TMS27C2001@TSOP32
[ (SA410T) ]	
TMS27C210	TMS27C210@PLCC44
[ (SA244) ]	
TMS27C210A	TMS27C210A@PLCC44
[ (SA244) ]	
TMS27C240	TMS27C240@PLCC44
[ (SA244) ]	
TMS27C256	TMS27C256@PLCC32
[ (SA015A1T) ]	
TMS27C291	TMS27C291@PLCC28
[ (SA008A) ]	
TMS27C292	TMS27C292@PLCC28
[ (SA008A) ]	
TMS27C32	
TMS27C512	
TMS27C512@PLCC32 [ (SA015A1T) ]	
TMS27C64	
TMS27LV010A	TMS27LV010A@PLCC32
[ (SA015A1T) ]	
TMS27LV010A@TSOP32 [ (SA410T) ]	
TMS27P32A	
TMS27P64	
TMS27PC010	
TMS27PC010@PLCC32 [ (SA015A1T) ]	TMS27PC010@TSOP32
[ (SA410T) ]	
TMS27PC010A	TMS27PC010A@PLCC32
[ (SA015A1T) ]	
TMS27PC010A@TSOP32 [ (SA410T) ]	
TMS27PC020	
TMS27PC020@PLCC32 [ (SA015A1T) ]	TMS27PC020@TSOP32
[ (SA410T) ]	
TMS27PC040	TMS27PC040@PLCC32
[ (SA015A1T) ]	
TMS27PC040@TSOP32 [ (SA410T) ]	
TMS27PC128	
TMS27PC128@PLCC32 [ (SA015A1T) ]	

TMS27PC210  
TMS27PC210@PLCC44 [ (SA244) ]  
TMS27PC210A  
TMS27PC210A@PLCC44 [ (SA244) ]  
TMS27PC240  
TMS27PC240@PLCC44 [ (SA244) ]  
TMS27PC256  
TMS27PC256@PLCC32 [ (SA015A1T) ]  
TMS27PC291  
TMS27PC291@PLCC28 [ (SA008A) ]  
TMS27PC32  
TMS27PC32A  
TMS27PC512  
TMS27PC512@PLCC32 [ (SA015A1T) ]  
TMS27PC64  
TMS28F010 TMS28F010@PLCC32  
[ (SA015A1T) ]  
TMS28F010@TSOP32 [ (SA410T) ]  
TMS28F020  
TMS28F020@PLCC32 [ (SA015A1T) ] TMS28F020@TSOP32  
[ (SA410T) ]  
TMS28F200BZ-B@PSOP44 [ (SA638) ] TMS28F200BZ-T@PSOP44  
[ (SA638) ]  
TMS28F210 TMS28F210@PLCC44  
[ (SA244) ]  
TMS28F210@TSOP40 [ (SA409T) ] TMS28F400AF-B@PSOP44  
[ (SA638) ]  
TMS28F400AF-T@PSOP44 [ (SA638) ] TMS28F400AS-B@PSOP44  
[ (SA638) ]  
TMS28F400AS-T@PSOP44 [ (SA638) ] TMS28F400BZ-B@PSOP44  
[ (SA638) ]  
TMS28F400BZ-T@PSOP44 [ (SA638) ]  
TMS28F512  
TMS28F512@PLCC32 [ (SA015A1T) ] TMS28F512@TSOP32  
[ (SA410T) ]  
TMS29F040 TMS29F040@PLCC32  
[ (SA015A1T) ]  
TMS29F040@TSOP32 [ (SA410T) ]  
TMS29F259  
TMS29F259@PLCC32 [ (SA015A1T) ] TMS29F259@TSOP32  
[ (SA410T) ]  
TMS29F512 TMS29F512@PLCC32  
[ (SA015A1T) ]

TMS29F512@TSOP32 [(SA410T)]  
 TMS87C257  
 TMS87C257@PLCC32 [(SA015A1T)]

## PLD

EP1800@PLCC68 [(PEP+S414T)] +S414T)]	EP1810@PLCC68 [(PEP
EP1830@PLCC68 [(PEP+S414T)]	
EP330	
EP330@PLCC20 [(SA001A)]	
EP910	
EP910-P44 [(SA244)]	
PAL16L8A	
PAL16L8A@PLCC20 [(SA001A)]	PAL16L8A-
2	
PAL16L8A-2@PLCC20 [(SA001A)]	
PAL16R4A	
PAL16R4A@PLCC20 [(SA001A)]	PAL16R4A-
2	
PAL16R4A-2@PLCC20 [(SA001A)]	
PAL16R6A	
PAL16R6A@PLCC20 [(SA001A)]	PAL16R6A-
2	
PAL16R6A-2@PLCC20 [(SA001A)]	
PAL16R8A	
PAL16R8A@PLCC20 [(SA001A)]	PAL16R8A-
2	
PAL16R8A-2@PLCC20 [(SA001A)]	
TIB82S167A	
TIB82S167A@PLCC28 [(SA008A)]	
TIB82S167B	
TIB82S167B@PLCC28 [(SA008A)]	TIBPAL16L8-
10	
TIBPAL16L8-10@PLCC20 [(SA001A)]	TIBPAL16L8-
15	
TIBPAL16L8-15@PLCC20 [(SA001A)]	TIBPAL16L8-
25	
TIBPAL16L8-25@PLCC20 [(SA001A)]	TIBPAL16L8-
5	
TIBPAL16L8-5@PLCC20 [(SA001A)]	TIBPAL16L8-
7	

TIBPAL16L8-7@PLCC20 [(SA001A)] 15	TIBPAL16L8H-
TIBPAL16L8H-15@PLCC20 [(SA001A)] 10	TIBPAL16R4-
TIBPAL16R4-10@PLCC20 [(SA001A)] 5	TIBPAL16R4-
TIBPAL16R4-5@PLCC20 [(SA001A)] 7	TIBPAL16R4-
TIBPAL16R4-7@PLCC20 [(SA001A)] 15	TIBPAL16R4H-
TIBPAL16R4H-15@PLCC20 [(SA001A)] 10	TIBPAL16R6-
TIBPAL16R6-10@PLCC20 [(SA001A)] 5	TIBPAL16R6-
TIBPAL16R6-5@PLCC20 [(SA001A)] 7	TIBPAL16R6-
TIBPAL16R6-7@PLCC20 [(SA001A)] 15	TIBPAL16R6H-
TIBPAL16R6H-15@PLCC20 [(SA001A)] 10	TIBPAL16R8-
TIBPAL16R8-10@PLCC20 [(SA001A)] 5	TIBPAL16R8-
TIBPAL16R8-5@PLCC20 [(SA001A)] 7	TIBPAL16R8-
TIBPAL16R8-7@PLCC20 [(SA001A)] 15	TIBPAL16R8H-
TIBPAL16R8H-15@PLCC20 [(SA001A)] 10	TIBPAL20L8-
TIBPAL20L8-10@PLCC28 [(SA008A)] 15	TIBPAL20L8-
TIBPAL20L8-15@PLCC28 [(SA008A)] 25	TIBPAL20L8-
TIBPAL20L8-25@PLCC28 [(SA008A)] 5	TIBPAL20L8-
TIBPAL20L8-5@PLCC28 [(SA008A)] 7	TIBPAL20L8-
TIBPAL20L8-7@PLCC28 [(SA008A)] 10	TIBPAL20R4-
TIBPAL20R4-10@PLCC28 [(SA008A)] 15	TIBPAL20R4-
TIBPAL20R4-15@PLCC28 [(SA008A)] 25	TIBPAL20R4-
TIBPAL20R4-25@PLCC28 [(SA008A)]	TIBPAL20R4-

5	TIBPAL20R4-5@PLCC28 [(SA008A)]	TIBPAL20R4-
7		
10	TIBPAL20R4-7@PLCC28 [(SA008A)]	TIBPAL20R6-
15		
25	TIBPAL20R6-10@PLCC28 [(SA008A)]	TIBPAL20R6-
5		
7	TIBPAL20R6-15@PLCC28 [(SA008A)]	TIBPAL20R6-
10		
15	TIBPAL20R6-25@PLCC28 [(SA008A)]	TIBPAL20R6-
25		
5	TIBPAL20R6-5@PLCC28 [(SA008A)]	TIBPAL20R6-
7		
10	TIBPAL20R6-7@PLCC28 [(SA008A)]	TIBPAL20R8-
15		
25	TIBPAL20R8-10@PLCC28 [(SA008A)]	TIBPAL20R8-
5		
7	TIBPAL20R8-15@PLCC28 [(SA008A)]	TIBPAL20R8-
10		
15	TIBPAL20R8-25@PLCC28 [(SA008A)]	TIBPAL20R8-
25		
5	TIBPAL20R8-5@PLCC28 [(SA008A)]	TIBPAL20R8-
7		
10	TIBPAL20R8-7@PLCC28 [(SA008A)]	
15	TIBPAL22V10	
20	TIBPAL22V10@PLCC28 [(SA008A)]	TIBPAL22V10-
25		
5	TIBPAL22V10-10@PLCC28 [(SA008A)]	TIBPAL22V10-
7		
10	TIBPAL22V10-15@PLCC28 [(SA008A)]	TIBPAL22V10-
15		
20	TIBPAL22V10-20@PLCC28 [(SA008A)]	TIBPAL22V10-
25		
5	TIBPAL22V10-5@PLCC28 [(SA008A)]	TIBPAL22V10-
7		
10	TIBPAL22V10-7@PLCC28 [(SA008A)]	
15	TIBPAL22V10A	
20	TIBPAL22V10A@PLCC28 [(SA008A)]	TICPAL22V10Z(0
25	PWR)	
5	TICPAL22V10Z(0 PWR)@PLCC28 [(SA008A)]	
7	TICPAL22V10Z(TURBO)	
10	TICPAL22V10Z(TURBO)@PLCC28 [(SA008A)]	



**MICROCONTROLLER**

IMSP430F2330IRHA@QFN40 (ISP) [ISP-HEADER01]  
IMSP430F2330TRHA@QFN40 (ISP) [ISP-HEADER01]  
IMSP430F2350IRHA@QFN40 (ISP) [ISP-HEADER01]  
IMSP430F2350TRHA@QFN40 (ISP) [ISP-HEADER01]  
IMSP430F2370IRHA@QFN40 (ISP) [ISP-HEADER01]  
IMSP430F2370TRHA@QFN40 (ISP) [ISP-HEADER01]  
MSP430F110@SOIC20 [(SA404)]  
MSP430F110@SOIC20 (ISP) [ISP-HEADER01]  
MSP430F110@TSSOP20 [(SA026)]  
MSP430F110@TSSOP20 (ISP) [ISP-HEADER01]  
MSP430F1101@SOIC20 [(SA404)]  
MSP430F1101@SOIC20 (ISP) [ISP-HEADER01]  
MSP430F1101@TSSOP20 [(SA026)]  
MSP430F1101@TSSOP20 (ISP) [ISP-HEADER01]  
MSP430F1101A@QFN24 [(SA710)]  
MSP430F1101A@QFN24 (ISP) [ISP-HEADER01]  
MSP430F1101A@SOIC20 [(SA404)]  
MSP430F1101A@SOIC20 (ISP) [ISP-HEADER01]  
MSP430F1101A@TSSOP20 [(SA026)]  
MSP430F1101A@TSSOP20 (ISP) [ISP-HEADER01]  
MSP430F1111A@QFN24 [(SA710)]  
MSP430F1111A@QFN24 (ISP) [ISP-HEADER01]  
MSP430F1111A@SOIC20 [(SA404)]  
MSP430F1111A@SOIC20 (ISP) [ISP-HEADER01]  
MSP430F1111A@TSSOP20 [(SA026)]  
MSP430F1111A@TSSOP20 (ISP) [ISP-HEADER01]  
MSP430F112@SOIC20 [(SA404)]  
MSP430F112@SOIC20 (ISP) [ISP-HEADER01]  
MSP430F112@TSSOP20 [(SA026)]  
MSP430F112@TSSOP20 (ISP) [ISP-HEADER01]  
MSP430F1121@SOIC20 [(SA404)]  
MSP430F1121@SOIC20 (ISP) [ISP-HEADER01]  
MSP430F1121@TSSOP20 [(SA026)]  
MSP430F1121@TSSOP20 (ISP) [ISP-HEADER01]  
MSP430F1121A@QFN24 [(SA710)]  
MSP430F1121A@QFN24 (ISP) [ISP-HEADER01]  
MSP430F1121A@SOIC20 [(SA404)]  
MSP430F1121A@SOIC20 (ISP) [ISP-HEADER01]  
MSP430F1121A@TSSOP20 [(SA026)]  
MSP430F1121A@TSSOP20 (ISP) [ISP-HEADER01]

MSP430F1122@QFN32 [(SA686)]                      MSP430F1122@SOIC20  
[(SA404)]  
MSP430F1122@SOIC20(ISP) [ISP-HEADER01]  
MSP430F1122@TSSOP20 [(SA026)]  
MSP430F1122@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F1132@QFN32 [(SA686)]                      MSP430F1132@SOIC20  
[(SA404)]  
MSP430F1132@SOIC20(ISP) [ISP-HEADER01]  
MSP430F1132@TSSOP20 [(SA026)]  
MSP430F1132@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F122@QFN32 [(SA686)]                      MSP430F122@SOIC28  
[(SA404)]  
MSP430F122@TSSOP28 [(SA643)]                      MSP430F1222@QFN32  
[(SA686)]  
MSP430F1222@SOIC28 [(SA404)]  
MSP430F1222@SOIC28(ISP) [ISP-HEADER01]  
MSP430F1222@TSSOP28 [(SA643)]  
MSP430F1222@TSSOP28(ISP) [ISP-HEADER01]  
MSP430F123@QFN32 [(SA686)]                      MSP430F123@SOIC28  
[(SA404)]  
MSP430F123@TSSOP28 [(SA643)]                      MSP430F1232@QFN32  
[(SA686)]  
MSP430F1232@SOIC28 [(SA404)]  
MSP430F1232@SOIC28(ISP) [ISP-HEADER01]  
MSP430F1232@TSSOP28 [(SA643)]  
MSP430F1232@TSSOP28(ISP) [ISP-HEADER01]  
MSP430F133@QFN64 [(PEP+S702)]                      MSP430F133@TQFP64 [(PEP  
+S616)]  
MSP430F135@QFN64 [(PEP+S702)]                      MSP430F135@TQFP64 [(PEP  
+S616)]  
MSP430F147@QFN64 [(PEP+S702)]                      MSP430F147@TQFP64 [(PEP  
+S616)]  
MSP430F1471@QFN64 [(PEP+S702)]                      MSP430F1471@TQFP64 [(PEP  
+S616)]  
MSP430F148@QFN64 [(PEP+S702)]                      MSP430F148@TQFP64 [(PEP  
+S616)]  
MSP430F1481@QFN64 [(PEP+S702)]                      MSP430F1481@TQFP64 [(PEP  
+S616)]  
MSP430F149@QFN64 [(PEP+S702)]                      MSP430F149@TQFP64 [(PEP  
+S616)]  
MSP430F1491@QFN64 [(PEP+S702)]                      MSP430F1491@TQFP64 [(PEP  
+S616)]  
MSP430F155@QFN64 [(PEP+S702)]

MSP430F155@QFN64(ISP) [ISP-HEADER01]  
MSP430F155@TQFP64 [(PEP+S616)]  
MSP430F155@TQFP64(ISP) [ISP-HEADER01]  
MSP430F156@QFN64 [(PEP+S702)]  
MSP430F156@QFN64(ISP) [ISP-HEADER01]  
MSP430F156@TQFP64 [(PEP+S616)]  
MSP430F156@TQFP64(ISP) [ISP-HEADER01]  
MSP430F157@QFN64 [(PEP+S702)]  
MSP430F157@QFN64(ISP) [ISP-HEADER01]  
MSP430F157@TQFP64 [(PEP+S616)]  
MSP430F157@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1610@QFN64 [(PEP+S702)]  
MSP430F1610@QFN64(ISP) [ISP-HEADER01]  
MSP430F1610@TQFP64 [(PEP+S616)]  
MSP430F1610@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1611@QFN64 [(PEP+S702)]  
MSP430F1611@QFN64(ISP) [ISP-HEADER01]  
MSP430F1611@TQFP64 [(PEP+S616)]  
MSP430F1611@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1612@QFN64 [(PEP+S702)]  
MSP430F1612@QFN64(ISP) [ISP-HEADER01]  
MSP430F1612@TQFP64 [(PEP+S616)]  
MSP430F1612@TQFP64(ISP) [ISP-HEADER01]  
MSP430F167@QFN64 [(PEP+S702)]  
MSP430F167@QFN64(ISP) [ISP-HEADER01]  
MSP430F167@TQFP64 [(PEP+S616)]  
MSP430F167@TQFP64(ISP) [ISP-HEADER01]  
MSP430F168@QFN64 [(PEP+S702)]  
MSP430F168@QFN64(ISP) [ISP-HEADER01]  
MSP430F168@TQFP64 [(PEP+S616)]  
MSP430F168@TQFP64(ISP) [ISP-HEADER01]  
MSP430F169@QFN64 [(PEP+S702)]  
MSP430F169@QFN64(ISP) [ISP-HEADER01]  
MSP430F169@TQFP64 [(PEP+S616)]  
MSP430F169@TQFP64(ISP) [ISP-HEADER01]  
MSP430F2001IN  
MSP430F2001IN(ISP) [ISP-HEADER01]  
MSP430F2001IN(SPW ISP) [ISP-HEADER01]  
MSP430F2001IN(SPW) MSP430F2001IPW@TSSOP14  
[(SA026)]  
MSP430F2001IPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2001IPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2001IPW@TSSOP14(SPW) [(SA026)]

MSP430F2001IRSA@QFN16 [(SA727)]  
MSP430F2001IRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2001IRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2001IRSA@QFN16(SPW) [(SA727)]  
MSP430F2001TN  
MSP430F2001TN(ISP) [ISP-HEADER01]  
MSP430F2001TN(SPW ISP) [ISP-HEADER01]  
MSP430F2001TN(SPW) MSP430F2001TPW@TSSOP14  
[(SA026)]  
MSP430F2001TPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2001TPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2001TPW@TSSOP14(SPW) [(SA026)]  
MSP430F2001TRSA@QFN16 [(SA727)]  
MSP430F2001TRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2001TRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2001TRSA@QFN16(SPW) [(SA727)]  
MSP430F2002IN  
MSP430F2002IN(ISP) [ISP-HEADER01]  
MSP430F2002IN(SPW ISP) [ISP-HEADER01]  
MSP430F2002IN(SPW) MSP430F2002IPW@TSSOP14  
[(SA026)]  
MSP430F2002IPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2002IPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2002IPW@TSSOP14(SPW) [(SA026)]  
MSP430F2002IRSA@QFN16 [(SA727)]  
MSP430F2002IRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2002IRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2002IRSA@QFN16(SPW) [(SA727)]  
MSP430F2002TN  
MSP430F2002TN(ISP) [ISP-HEADER01]  
MSP430F2002TN(SPW ISP) [ISP-HEADER01]  
MSP430F2002TN(SPW) MSP430F2002TPW@TSSOP14  
[(SA026)]  
MSP430F2002TPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2002TPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2002TPW@TSSOP14(SPW) [(SA026)]  
MSP430F2002TRSA@QFN16 [(SA727)]  
MSP430F2002TRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2002TRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2002TRSA@QFN16(SPW) [(SA727)]  
MSP430F2003IN  
MSP430F2003IN(ISP) [ISP-HEADER01]  
MSP430F2003IN(SPW ISP) [ISP-HEADER01]

MSP430F2003IN(SPW) MSP430F2003IPW@TSSOP14  
[(SA026)]  
MSP430F2003IPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2003IPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2003IPW@TSSOP14(SPW) [(SA026)]  
MSP430F2003IRSA@QFN16 [(SA727)]  
MSP430F2003IRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2003IRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2003IRSA@QFN16(SPW) [(SA727)]  
MSP430F2003TN  
MSP430F2003TN(ISP) [ISP-HEADER01]  
MSP430F2003TN(SPW ISP) [ISP-HEADER01]  
MSP430F2003TN(SPW) MSP430F2003TPW@TSSOP14  
[(SA026)]  
MSP430F2003TPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2003TPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2003TPW@TSSOP14(SPW) [(SA026)]  
MSP430F2003TRSA@QFN16 [(SA727)]  
MSP430F2003TRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2003TRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2003TRSA@QFN16(SPW) [(SA727)]  
MSP430F2011IN  
MSP430F2011IN(ISP) [ISP-HEADER01]  
MSP430F2011IN(SPW ISP) [ISP-HEADER01]  
MSP430F2011IN(SPW) MSP430F2011IPW@TSSOP14  
[(SA026)]  
MSP430F2011IPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2011IPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2011IPW@TSSOP14(SPW) [(SA026)]  
MSP430F2011IRSA@QFN16 [(SA727)]  
MSP430F2011IRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2011IRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2011IRSA@QFN16(SPW) [(SA727)]  
MSP430F2011TN  
MSP430F2011TN(ISP) [ISP-HEADER01]  
MSP430F2011TN(SPW ISP) [ISP-HEADER01]  
MSP430F2011TN(SPW) MSP430F2011TPW@TSSOP14  
[(SA026)]  
MSP430F2011TPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2011TPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2011TPW@TSSOP14(SPW) [(SA026)]  
MSP430F2011TRSA@QFN16 [(SA727)]  
MSP430F2011TRSA@QFN16(ISP) [ISP-HEADER01]

MSP430F2011TRSA@QFN16 (SPW ISP) [ISP-HEADER01]  
MSP430F2011TRSA@QFN16 (SPW) [(SA727)]  
MSP430F2012IN  
MSP430F2012IN (ISP) [ISP-HEADER01]  
MSP430F2012IN (SPW ISP) [ISP-HEADER01]  
MSP430F2012IN (SPW) MSP430F2012IPW@TSSOP14  
[(SA026)]  
MSP430F2012IPW@TSSOP14 (ISP) [ISP-HEADER01]  
MSP430F2012IPW@TSSOP14 (SPW ISP) [ISP-HEADER01]  
MSP430F2012IPW@TSSOP14 (SPW) [(SA026)]  
MSP430F2012IRSA@QFN16 [(SA727)]  
MSP430F2012IRSA@QFN16 (ISP) [ISP-HEADER01]  
MSP430F2012IRSA@QFN16 (SPW ISP) [ISP-HEADER01]  
MSP430F2012IRSA@QFN16 (SPW) [(SA727)]  
MSP430F2012TN  
MSP430F2012TN (ISP) [ISP-HEADER01]  
MSP430F2012TN (SPW ISP) [ISP-HEADER01]  
MSP430F2012TN (SPW) MSP430F2012TPW@TSSOP14  
[(SA026)]  
MSP430F2012TPW@TSSOP14 (ISP) [ISP-HEADER01]  
MSP430F2012TPW@TSSOP14 (SPW ISP) [ISP-HEADER01]  
MSP430F2012TPW@TSSOP14 (SPW) [(SA026)]  
MSP430F2012TRSA@QFN16 [(SA727)]  
MSP430F2012TRSA@QFN16 (ISP) [ISP-HEADER01]  
MSP430F2012TRSA@QFN16 (SPW ISP) [ISP-HEADER01]  
MSP430F2012TRSA@QFN16 (SPW) [(SA727)]  
MSP430F2013IN  
MSP430F2013IN (ISP) [ISP-HEADER01]  
MSP430F2013IN (SPW ISP) [ISP-HEADER01]  
MSP430F2013IN (SPW) MSP430F2013IPW@TSSOP14  
[(SA026)]  
MSP430F2013IPW@TSSOP14 (ISP) [ISP-HEADER01]  
MSP430F2013IPW@TSSOP14 (SPW ISP) [ISP-HEADER01]  
MSP430F2013IPW@TSSOP14 (SPW) [(SA026)]  
MSP430F2013IRSA@QFN16 [(SA727)]  
MSP430F2013IRSA@QFN16 (ISP) [ISP-HEADER01]  
MSP430F2013IRSA@QFN16 (SPW ISP) [ISP-HEADER01]  
MSP430F2013IRSA@QFN16 (SPW) [(SA727)]  
MSP430F2013TN  
MSP430F2013TN (ISP) [ISP-HEADER01]  
MSP430F2013TN (SPW ISP) [ISP-HEADER01]  
MSP430F2013TN (SPW) MSP430F2013TPW@TSSOP14  
[(SA026)]

MSP430F2013TPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2013TPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2013TPW@TSSOP14(SPW) [(SA026)]  
MSP430F2013TRSA@QFN16 [(SA727)]  
MSP430F2013TRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2013TRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2013TRSA@QFN16(SPW) [(SA727)]  
MSP430F2101@QFN24 [(SA710-B006)]  
MSP430F2101@QFN24(ISP) [ISP-HEADER01]  
MSP430F2101@SOIC20 [(SA404)]  
MSP430F2101@SOIC20(ISP) [ISP-HEADER01]  
MSP430F2101@TSSOP20 [(SA643)]  
MSP430F2101@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F2101@TVSOP20 [(SA713-B005)]  
MSP430F2101@TVSOP20(ISP) [ISP-HEADER01]  
MSP430F2111@QFN24 [(SA710-B006)]  
MSP430F2111@QFN24(ISP) [ISP-HEADER01]  
MSP430F2111@SOIC20 [(SA404)]  
MSP430F2111@SOIC20(ISP) [ISP-HEADER01]  
MSP430F2111@TSSOP20 [(SA643)]  
MSP430F2111@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F2111@TVSOP20 [(SA713-B005)]  
MSP430F2111@TVSOP20(ISP) [ISP-HEADER01]  
MSP430F2121@QFN24 [(SA710-B006)]  
MSP430F2121@QFN24(ISP) [ISP-HEADER01]  
MSP430F2121@SOIC20 [(SA404)]  
MSP430F2121@SOIC20(ISP) [ISP-HEADER01]  
MSP430F2121@TSSOP20 [(SA643)]  
MSP430F2121@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F2121@TVSOP20 [(SA713-B005)]  
MSP430F2121@TVSOP20(ISP) [ISP-HEADER01]  
MSP430F2131@QFN24 [(SA710-B006)]  
MSP430F2131@QFN24(ISP) [ISP-HEADER01]  
MSP430F2131@SOIC20 [(SA404)]  
MSP430F2131@SOIC20(ISP) [ISP-HEADER01]  
MSP430F2131@TSSOP20 [(SA643)]  
MSP430F2131@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F2131@TVSOP20 [(SA713-B005)]  
MSP430F2131@TVSOP20(ISP) [ISP-HEADER01]  
MSP430F2232IDA@SSOP38 [(SA689)]  
MSP430F2232IDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2232IRHA@QFN40 [(SA750)]  
MSP430F2232IRHA@QFN40(ISP) [ISP-HEADER01]

MSP430F2232TDA@SSOP38 [(SA689)]  
MSP430F2232TDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2232TRHA@QFN40 [(SA750)]  
MSP430F2232TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2234IDA@SSOP38 [(SA689)]  
MSP430F2234IDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2234IRHA@QFN40 [(SA750)]  
MSP430F2234IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2234TDA@SSOP38 [(SA689)]  
MSP430F2234TDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2234TRHA@QFN40 [(SA750)]  
MSP430F2234TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2252IDA@SSOP38 [(SA689)]  
MSP430F2252IDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2252IRHA@QFN40 [(SA750)]  
MSP430F2252IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2252TDA@SSOP38 [(SA689)]  
MSP430F2252TDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2252TRHA@QFN40 [(SA750)]  
MSP430F2252TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2254IDA@SSOP38 [(SA689)]  
MSP430F2254IDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2254IRHA@QFN40 [(SA750)]  
MSP430F2254IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2254TDA@SSOP38 [(SA689)]  
MSP430F2254TDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2254TRHA@QFN40 [(SA750)]  
MSP430F2254TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2272IDA@SSOP38 [(SA689)]  
MSP430F2272IDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2272IRHA@QFN40 [(SA750)]  
MSP430F2272IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2272TDA@SSOP38 [(SA689)]  
MSP430F2272TDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2272TRHA@QFN40 [(SA750)]  
MSP430F2272TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2274IDA@SSOP38 [(SA689)]  
MSP430F2274IDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2274IRHA@QFN40 [(SA750)]  
MSP430F2274IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2274TDA@SSOP38 [(SA689)]  
MSP430F2274TDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2274TRHA@QFN40 [(SA750)]



MSP430F2274TRHA@QFN40 (ISP) [ISP-HEADER01]  
MSP430F2330IRHA@QFN40 [(SA750)] MSP430F2330TRHA@QFN40  
[(SA750)]  
MSP430F2350IRHA@QFN40 [(SA750)] MSP430F2350TRHA@QFN40  
[(SA750)]  
MSP430F2370IRHA@QFN40 [(SA750)] MSP430F2370TRHA@QFN40  
[(SA750)]  
MSP430F2410@LQFP64 [(PEP+S616)] MSP430F2410@QFN64 [(PEP  
+S702)]  
MSP430F2416@LQFP64 [(PEP+S616)] MSP430F2416@LQFP80 [(PEP  
+S640B)]  
MSP430F2417@LQFP64 [(PEP+S616)] MSP430F2417@LQFP80 [(PEP  
+S640B)]  
MSP430F2418@LQFP64 [(PEP+S616)] MSP430F2418@LQFP80 [(PEP  
+S640B)]  
MSP430F2419@LQFP64 [(PEP+S616)] MSP430F2419@LQFP80 [(PEP  
+S640B)]  
MSP430F247@LQFP64 [(PEP+S616)] MSP430F247@QFN64 [(PEP  
+S702)]  
MSP430F2471@LQFP64 [(PEP+S616)] MSP430F2471@QFN64 [(PEP  
+S702)]  
MSP430F248@LQFP64 [(PEP+S616)] MSP430F248@QFN64 [(PEP  
+S702)]  
MSP430F2481@LQFP64 [(PEP+S616)] MSP430F2481@QFN64 [(PEP  
+S702)]  
MSP430F249@LQFP64 [(PEP+S616)] MSP430F249@QFN64 [(PEP  
+S702)]  
MSP430F2491@LQFP64 [(PEP+S616)] MSP430F2491@QFN64 [(PEP  
+S702)]  
MSP430F2616@LQFP64 [(PEP+S616)] MSP430F2616@LQFP80 [(PEP  
+S640B)]  
MSP430F2617@LQFP64 [(PEP+S616)] MSP430F2617@LQFP80 [(PEP  
+S640B)]  
MSP430F2618@LQFP64 [(PEP+S616)] MSP430F2618@LQFP80 [(PEP  
+S640B)]  
MSP430F2619@LQFP64 [(PEP+S616)] MSP430F2619@LQFP80 [(PEP  
+S640B)]  
MSP430F412@QFN64 [(PEP+S702)] MSP430F412@TQFP64 [(PEP  
+S616)]  
MSP430F413@QFN64 [(PEP+S702)] MSP430F413@TQFP64 [(PEP  
+S616)]  
MSP430F415@TQFP64 [(PEP+S616)]  
MSP430F415@TQFP64(\*) [(SA732+B320)]

MSP430F415@TQFP64(ISP) [ISP-HEADER01]  
MSP430F417@TQFP64 [(PEP+S616)]  
MSP430F417@TQFP64(\*) [(SA732+B320)]  
MSP430F417@TQFP64(ISP) [ISP-HEADER01]  
MSP430F423@TQFP64 [(PEP+S616)]           MSP430F425@TQFP64 [(PEP+S616)]  
MSP430F4250@QFN48 [(SA696)]           MSP430F4250@SSOP48  
[(SA669)]  
MSP430F4260@QFN48 [(SA696)]           MSP430F4260@SSOP48  
[(SA669)]  
MSP430F427@TQFP64 [(PEP+S616)]           MSP430F4270@QFN48  
[(SA696)]  
MSP430F4270@SSOP48 [(SA669)]           MSP430F435@TQFP100 [(PEP+S604)]  
MSP430F435@TQFP80 [(PEP+S640B)]           MSP430F4351@TQFP100 [(PEP+S604)]  
MSP430F4351@TQFP80 [(PEP+S640B)]           MSP430F436@TQFP100 [(PEP+S604)]  
MSP430F436@TQFP80 [(PEP+S640B)]           MSP430F4361@TQFP100 [(PEP+S604)]  
MSP430F4361@TQFP80 [(PEP+S640B)]           MSP430F437@TQFP100 [(PEP+S604)]  
MSP430F437@TQFP80 [(PEP+S640B)]           MSP430F4371@TQFP100 [(PEP+S604)]  
MSP430F4371@TQFP80 [(PEP+S640B)]           MSP430F447@TQFP100 [(PEP+S604)]  
MSP430F448@TQFP100 [(PEP+S604)]           MSP430F449@TQFP100 [(PEP+S604)]  
MSP430FE423@TQFP64 [(PEP+S616)]  
MSP430FE423@TQFP64(\*) [(SA732+B320)]  
MSP430FE423@TQFP64(ISP) [ISP-HEADER01]  
MSP430FE425@TQFP64 [(PEP+S616)]  
MSP430FE425@TQFP64(\*) [(SA732+B320)]  
MSP430FE425@TQFP64(ISP) [ISP-HEADER01]  
MSP430FE427@TQFP64 [(PEP+S616)]  
MSP430FE427@TQFP64(\*) [(SA732+B320)]  
MSP430FE427@TQFP64(ISP) [ISP-HEADER01]  
MSP430FG4250@QFN48 [(SA696)]           MSP430FG4260@QFN48  
[(SA696)]  
MSP430FG4270@QFN48 [(SA696)]           MSP430FG437@TQFP100 [(PEP+S604)]  
MSP430FG437@TQFP100(ISP) [ISP-HEADER01]  
MSP430FG437@TQFP80 [(PEP+S640B)]

MSP430FG437@TQFP80(ISP) [ISP-HEADER01]  
 MSP430FG438@TQFP100 [(PEP+S604)]  
 MSP430FG438@TQFP100(ISP) [ISP-HEADER01]  
 MSP430FG438@TQFP80 [(PEP+S640B)]  
 MSP430FG438@TQFP80(ISP) [ISP-HEADER01]  
 MSP430FG439@TQFP100 [(PEP+S604)]  
 MSP430FG439@TQFP100(ISP) [ISP-HEADER01]  
 MSP430FG439@TQFP80 [(PEP+S640B)]  
 MSP430FG439@TQFP80(ISP) [ISP-HEADER01]  
 MSP430FG4616IPZ@TQFP100 [(PEP+S604)]  
 MSP430FG4616IPZR@TQFP100 [(PEP+S604)]  
 MSP430FG4617IPZ@TQFP100 [(PEP+S604)]  
 MSP430FG4617IPZR@TQFP100 [(PEP+S604)]  
 MSP430FG4618IPZ@TQFP100 [(PEP+S604)]  
 MSP430FG4618IPZR@TQFP100 [(PEP+S604)]  
 MSP430FG4619IPZ@TQFP100 [(PEP+S604)]  
 MSP430FG4619IPZR@TQFP100 [(PEP+S604)]  
 MSP430FW423@TQFP64 [(PEP+S616)]           MSP430FW425@TQFP64 [(PEP  
 +S616)]  
 MSP430FW427@TQFP64 [(PEP+S616)]  
 MSP430P112  
 MSP430P112@SOIC20 [(SA404)]  
 PMS430E112  
 PMS430E112@SOIC20 [(SA404)]

## TMC

### E(E) PROM/FRAM/NVRAM

24A01	24A01@SOIC8
[(SA602A)]	
24A01@TSSOP8 [(SA026)]	
24A02	
24A02@SOIC8 [(SA602A)]	24A02@TSSOP8
[(SA026)]	
24A04	24A04@SOIC8
[(SA602A)]	
24A04@TSSOP8 [(SA026)]	
24A08	
24A08@SOIC8 [(SA602A)]	24A08@TSSOP8
[(SA026)]	
24A16	24A16@SOIC8

[ (SA602A) ]	
24A16@TSSOP8 [ (SA026) ]	93LC46
(08bit)	
93LC46(08bit)@SOIC8 [ (SA602A) ]	93LC46(08bit)@TSSOP8
[ (SA026) ]	
93LC46(16bit)	93LC46(16bit)@SOIC8
[ (SA602A) ]	
93LC46(16bit)@TSSOP8 [ (SA026) ]	93LC56
(08bit)	
93LC56(08bit)@SOIC8 [ (SA602A) ]	93LC56(08bit)@TSSOP8
[ (SA026) ]	
93LC56(16bit)	93LC56(16bit)@SOIC8
[ (SA602A) ]	
93LC56(16bit)@TSSOP8 [ (SA026) ]	
93LC57	
93LC57@SOIC8 [ (SA602A) ]	93LC57@TSSOP8
[ (SA026) ]	
93LC66(08bit)	93LC66(08bit)@SOIC8
[ (SA602A) ]	
93LC66(08bit)@TSSOP8 [ (SA026) ]	93LC66
(16bit)	
93LC66(16bit)@SOIC8 [ (SA602A) ]	93LC66(16bit)@TSSOP8
[ (SA026) ]	
93LC86(08bit)	93LC86(08bit)@SOIC8
[ (SA602A) ]	
93LC86(08bit)@TSSOP8 [ (SA026) ]	93LC86
(16bit)	
93LC86(16bit)@SOIC8 [ (SA602A) ]	93LC86(16bit)@TSSOP8
[ (SA026) ]	

## TOPRO

### MICROCONTROLLER

TP2804H	TP2804H@PLCC44
[ (SA244) ]	
TP2804H@TQFP44 [ (SA245A) ]	
TP2804L	
TP2804L@PLCC44 [ (SA244) ]	TP2804L@TQFP44
[ (SA245A) ]	
TP2808H	TP2808H@PLCC44
[ (SA244) ]	

TP2808H@TQFP44 [ (SA245A) ]  
TP2808L  
TP2808L@PLCC44 [ (SA244) ]  
[ (SA245A) ]

TP2808L@TQFP44

## TOSHIBA

### E (E) PROM / FRAM / NVRAM

TC541000AF@PLCC32 [ (SA015A1T) ]  
TC541000AP  
TC541001AF@PLCC32 [ (SA015A1T) ]  
TC541001AP

TC54256AF@SOIC28

TC54256AF  
[ (SA404) ]

TC54256AP@SOIC28

TC54256AP  
[ (SA404) ]

TC544000P

TC54512AF

TC54512AP

TC571000

TC571000AD

TC571000D

TC571001AD

TC571001D

TC571024D

TC57256

TC57256A

TC57256AD

TC57256ADI

TC57256D

TC574000D

TC574096D

TC574200D

TC57512

TC57512AD

TC578200D

TC57H1000AD

TC57H1001AD

TC57H256D

TC58128AFT@TSOP48 [ (SA247-

B005) ]

TC58512FT@TSOP48 [ (SA247-B005) ]

TC58DVG02A1FT00@TSOP48 [(SA247-B005)]  
TC58DVG02A2FT00@TSOP48 [(SA247-B005)]  
TC58DVM72A1FT00@TSOP48 [(SA247-B005)]  
TC58DVM72A1TG00@TSOP48 [(SA247-B005)]  
TC58DVM82A1FT00@TSOP48 [(SA247-B005)]  
TC58DVM82A1XBJ1@TFBGA56 [(SA642U-B197-T064F001Y)]  
TC58DVM92A1FT00@TSOP48 [(SA247-B005)]  
TC58F400@PSOP44 [(SA638-B006)] TC58F400@TSOP48 [(SA247-B005)]  
TC58F401@PSOP44 [(SA638-B006)] TC58F401@TSOP48 [(SA247-B005)]  
TC58FVB004FT@TSOP40 [(SA409T)] TC58FVB008FT@TSOP40 [(SA409T)]  
TC58FVB016FT@TSOP40 [(SA409T)]  
TC58FVB160AFT@TSOP48 [(SA247-B005)]  
TC58FVB160AXB@TFBGA48 [(SA642B\_B026A-Y072F001)]  
TC58FVB160FT@TSOP48 [(SA247-B005)]  
TC58FVB321FT@TSOP48 [(SA247-B005)]  
TC58FVB321XB@TFBGA56 [(SA642A-B026A-Y096F001)]  
TC58FVB400F@PSOP44 [(SA638)]  
TC58FVB400FT@TSOP48 [(SA247-B005)]  
TC58FVB641FT@TSOP48 [(SA247-B005)]  
TC58FVB641XB@TFBGA63 [(SA642A-B026A-Y096N001)]  
TC58FVB800F@PSOP44 [(SA638)]  
TC58FVB800FT@TSOP48 [(SA247-B005)]  
TC58FVM5B2AFT@TSOP48 [(SA247-B005)]  
TC58FVM5B2ATG@TSOP48 [(SA247-B005)]  
TC58FVM5B2AXB@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5B2AXG@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5B3AFT@TSOP48 [(SA247-B005)]  
TC58FVM5B3ATG@TSOP48 [(SA247-B005)]  
TC58FVM5B3AXB@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5B3AXG@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5T2AFT@TSOP48 [(SA247-B005)]  
TC58FVM5T2ATG@TSOP48 [(SA247-B005)]  
TC58FVM5T2AXB@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5T2AXG@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5T3AFT@TSOP48 [(SA247-B005)]  
TC58FVM5T3ATG@TSOP48 [(SA247-B005)]  
TC58FVM5T3AXB@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM5T3AXG@TFBGA56 [(SA642B-B026A-Y072F001)]  
TC58FVM6B2AFT@TSOP48 [(SA247-B005)]  
TC58FVM6B2AXB@TFBGA63 [(SA642B-B026A-Y072F001)]

TC58FVM6B5BTG@TSOP48 [(SA247-B005)]  
 TC58FVM6B5BXG@TFBGA56 [(SA642U-B026A-T064F001Y)]  
 TC58FVM6T2AFT@TSOP48 [(SA247-B005)]  
 TC58FVM6T2AXB@TFBGA63 [(SA642B-B026A-Y072F001)]  
 TC58FVM6T5BTG@TSOP48 [(SA247-B005)]  
 TC58FVM6T5BXG@TFBGA56 [(SA642U-B026A-T064F001Y)]  
 TC58FVM7B2AFT@TSOP56 [(SA628-B045)]  
 TC58FVM7B5BTG@TSOP56 [(SA628-B102)]  
 TC58FVM7B5BXG@FBGA80 [(SA642R-B099A-T096F001Y)]  
 TC58FVM7T2AFT@TSOP56 [(SA628-B045)]  
 TC58FVM7T5BTG@TSOP56 [(SA628-B102)]  
 TC58FVM7T5BXG@FBGA80 [(SA642R-B099A-T096F001Y)]  
 TC58FVT004FT@TSOP40 [(SA409T)] TC58FVT008FT@TSOP40  
 [(SA409T)]  
 TC58FVT016FT@TSOP40 [(SA409T)]  
 TC58FVT160AFT@TSOP48 [(SA247-B005)]  
 TC58FVT160AXB@TFBGA48 [(SA642B\_B026A-Y072F001)]  
 TC58FVT160FT@TSOP48 [(SA247-B005)]  
 TC58FVT321FT@TSOP48 [(SA247-B005)]  
 TC58FVT321XB@TFBGA56 [(SA642A-B026A-Y096F001)]  
 TC58FVT400F@PSOP44 [(SA638)]  
 TC58FVT400FT@TSOP48 [(SA247-B005)]  
 TC58FVT641FT@TSOP48 [(SA247-B005)]  
 TC58FVT641XB@TFBGA63 [(SA642A-B026A-Y096N001)]  
 TC58FVT800F@PSOP44 [(SA638)]  
 TC58FVT800FT@TSOP48 [(SA247-B005)]  
 TC58FYB160FT@TSOP48 [(SA247-B005)]  
 TC58FYT160FT@TSOP48 [(SA247-B005)]  
 TC58NVG0S3AFT05@TSOP48 [(SA247-B005)]  
 TC58V64BFT@TSOP44 [(SA645-B005)] TC89101  
 (08bit)  
 TC89101(16bit) TC89102  
 (08bit)  
 TC89102(16bit)  
 TC89121  
 TC89121@SOIC8 [(SA602A)]  
 TC89122  
 TC89122@SOIC8 [(SA602A)]  
 TC97101  
 TC9WMA1FK@US8 [(BBBB)] TC9WMA2FK@US8  
 [(BBBB)]  
 TC9WMB1AFK@US8 [(BBBB)] TC9WMB1AFU@SM8  
 [(SA666)]

TC9WMB1FK@US8 [ (BBBB) ] [ (BBBB) ]	TC9WMB2AFK@US8
TC9WMB2AFU@SM8 [ (SA666) ] [ (BBBB) ]	TC9WMB2FK@US8
TC9WMB4FU@SM8 [ (SA666) ] [ (SA666) ]	TC9WMB8FU@SM8
TC9WMC1FK@US8 [ (BBBB) ] [ (SA666) ]	TC9WMC1FU@SM8
TC9WMC2FK@US8 [ (BBBB) ] [ (SA666) ]	TC9WMC2FU@SM8
TC9WMC4FK@US8 [ (BBBB) ] [ (SA602A) ]	TC9WMC4FU@SM8
TH50VPF5582ADSB@FBGA73 [ (SA642E-B032A-T072F001) ]	
TH50VPF5583ADSB@FBGA73 [ (SA642E-B032A-T072F001) ]	
TH50VPF5682CDSB@FBGA73 [ (SA642E-B032A-T072F001) ]	
TH50VPF5683CDSB@FBGA73 [ (SA642E-B032A-T072F001) ]	
TH50VPF5782AASB@FBGA73 [ (SA664A-B096A-W115F001Y) ]	
TH50VPF5783AASB@FBGA73 [ (SA664A-B096A-W115F001Y) ]	
TH50VPF6782AASB@FBGA73 [ (SA664A-B096A-W115F001Y) ]	
TH50VPF6783AASB@FBGA73 [ (SA664A-B096A-W115F001Y) ]	
TH50VSF1480AASB@FBGA65 [ (SA642A-B032A-Y096N001) ]	
TH50VSF1481AASB@FBGA65 [ (SA642A-B032A-Y096N001) ]	
TH50VSF2480AASB@FBGA65 [ (SA642A-B032A-Y096N001) ]	
TH50VSF2481AASB@FBGA65 [ (SA642A-B032A-Y096N001) ]	
TH50VSF2580AASB@FBGA69 [ (SA642A-B032A-Y096F001) ]	
TH50VSF2581AASB@FBGA69 [ (SA642A-B032A-Y096F001) ]	
TH50VSF2582AASB@FBGA69 [ (SA642A-B032A-Y096F001) ]	
TH50VSF2582ADSB@FBGA73 [ (SA642A-B032A-Y096F001) ]	
TH50VSF2582BDSB@FBGA73 [ (SA642A-B032A-Y096F001) ]	
TH50VSF2583AASB@FBGA69 [ (SA642A-B032A-Y096F001) ]	
TH50VSF2583ADSB@FBGA73 [ (SA642A-B032A-Y096F001) ]	
TH50VSF2583BDSB@FBGA73 [ (SA642A-B032A-Y096F001) ]	
TH50VSF2590AASB@FBGA69 [ (SA642A-B032A-Y096F001) ]	
TH50VSF2682BDSB@FBGA73 [ (SA642A-B032A-Y096F001) ]	
TH50VSF2683BDSB@FBGA73 [ (SA642A-B032A-Y096F001) ]	
TH50VSF3580AASB@FBGA69 [ (SA642A-B032A-Y096N001) ]	
TH50VSF3581AASB@FBGA69 [ (SA642A-B032A-Y096N001) ]	
TH50VSF3582AASB@FBGA69 [ (SA642A-B032A-Y096N001) ]	
TH50VSF3582BDSB@FBGA73 [ (SA642A-B032A-Y096F001) ]	
TH50VSF3583AASB@FBGA69 [ (SA642A-B032A-Y096N001) ]	
TH50VSF3583BDSB@FBGA73 [ (SA642A-B032A-Y096F001) ]	
TH50VSF3680AASB@FBGA69 [ (SA642A-B032A-Y096N001) ]	
TH50VSF3681AASB@FBGA69 [ (SA642A-B032A-Y096N001) ]	



TH50VSF3682AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3682BDSB@FBGA73 [ ( SA642E-B032A-T072F001 ) ]  
TH50VSF3683AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3683BDSB@FBGA73 [ ( SA642E-B032A-T072F001 ) ]  
TH50VSF4682AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF4683AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]

TMM24128  
TMM24128A  
TMM24128AP  
TMM24256  
TMM24256A  
TMM24256AP  
TMM24256B  
TMM24512  
TMM24512A  
TMM24512P  
TMM2464AP  
TMM27128  
TMM27128A  
TMM27128ADI  
TMM27128AP  
TMM27256  
TMM27256A  
TMM27256AD  
TMM27256ADI  
TMM27256BD  
TMM27256BDI  
TMM27256D  
TMM27256DI  
TMM2732  
TMM2732A  
TMM2732D  
TMM27512  
TMM27512AD  
TMM27512ADI  
TMM27512D  
TMM27512DI  
TMM2764  
TMM2764AD  
TMM2764ADI  
TMM2764AP  
TMM2764D  
TMM2764DI

TV00560002ADBB@FBGA73 [(SA642U-B095A-W064F001Y)]  
TV00560002DDGB@FBGA81 [(SA642R-B079A-T096F001N)]  
TV00560002EDGB@FBGA81 [(SA642R-B079A-T096F001N)]  
TV00560003ADBB@FBGA73 [(SA642U-B095A-W064F001Y)]  
TV00569002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00569002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00569002BABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00569002BABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00569003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00569003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00569003BABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00569003BABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00570002AABB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV00570002ADGB@FBGA85 [(SA642A-B039A-Y096F001Y)]  
TV00570003AABB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV00570003ADGB@FBGA85 [(SA642A-B039A-Y096F001Y)]  
TV00578002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00578002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00578002CABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00578002CABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00578003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00578003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00578003CABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00578003CABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00579002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00579002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00579002AAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00579002AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00579003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00579003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00579003AAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00579003AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0057A002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0057A002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0057A002CAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0057A002CAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0057A003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0057A003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0057A003CAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0057A003CAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00670002ADGB@FBGA81 [(SA642R-B079A-T096F001N)]  
TV00670002CABB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV00670002CAGB@FBGA73 [(SA664A-B096A-W115F001Y)]

TV00670003ADGB@FBGA81 [(SA642R-B079A-T096F001N)]  
 TV00670003CABB@FBGA73 [(SA664A-B096A-W115F001Y)]  
 TV00670003CAGB@FBGA73 [(SA664A-B096A-W115F001Y)]  
 TV0067A002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 TV0067A002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TV0067A003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
 TV0067A003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TY00679002AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TY00679003AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
 TY80008000AMGF@FBGA149 [(SA664G-B143A-Y144F001Y)]  
 TY80008000DMGF@FBGA149 [(SA664G-B143A-Y144F001Y)]  
 TY80009000AMBF@FBGA149 [(SA664G-B143A-Y144F001Y)]  
 TY8000A010AMGF(HZ)@BGA149 [(SA664G-B143A-Y144F001Y)]  
 TY8000A010AMGF@BGA149 [(SA664G-B143A-Y144F001Y)]  
 TY90009000AMGF@FBGA149 [(SA664G-B143A-Y144F001Y)]  
 TY90009400BMGF(HZ)@FBGA149 [(SA664G-B143A-Y144F001Y)]  
 TY90009400BMGF@FBGA149 [(SA664G-B143A-Y144F001Y)]  
 TY90009400DMGF@FBGA149 [(SA664G-B143A-Y144F001Y)]  
 TY90009800AOGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY90009800COGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY90009C00AOGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY9000A000ALHF@BGA149 [(SA664G-B279-Y149F001Y)]  
 TY9000A000CMHF@BGA149 [(SA664G-B279-Y149F001Y)]  
 TY9000A000EMGF@BGA149 [(SA664G-B279-Y149F001Y)]  
 TY9000A000GMGF@BGA149 [(SA664G-B143A-Y144F001Y)]  
 TY9000A400AMGF(HZ)@BGA149 [(SA664G-B143A-Y144F001Y)]  
 TY9000A400AMGF@BGA149 [(SA664G-B143A-Y144F001Y)]  
 TY9000A800AOGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY9000A800EOGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY9000A800GOGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY9000A800H0GG@TFBGA225 [(SA678L-B244-M225F001Y)]  
 TY9000AC00COGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY9000C010ALHF@BGA149 [(SA664G-B279-Y149F001Y)]  
 TYA000AC00EOGG@TFBGA225 [(SA678L-B294-Y225F001Y)]  
 TYA000B400ALHF@BGA149 [(SA664G-B279-Y149F001Y)]  
 TYA000BC10A0GG@FBGA225 [(SA678L-B244-Y225F001Y)]

## DRAM & SRAM

TC518128 TC518128@SOIC32  
 [(SA630)]  
 TC518129 TC518129@SOIC32

[ (SA630) ]	
TC51832	TC51832@SOIC28
[ (SA630) ]	
TC518512	TC518512@SOIC32
[ (SA630) ]	
TC551001FL	TC551001FL@SOIC32
[ (SA630) ]	
TC551001PL	TC551001PL@SOIC32
[ (SA630) ]	
TC55257	TC55257@SOIC28
[ (SA630) ]	
TC55257L	TC55257L@SOIC28
[ (SA630) ]	
TC55258	TC55258@SOIC28
[ (SA630) ]	
TC55258L	TC55258L@SOIC28
[ (SA630) ]	
TC55328	TC55328@SOIC28
[ (SA630) ]	
TC5561P	TC5561P@SOJ24
[ (SA646) ]	
TC5562P	TC5562P@SOJ24
[ (SA646) ]	
TC5563APL	TC5563APL@SOIC28
[ (SA630) ]	
TC5564APL	TC5564APL@SOIC28
[ (SA630) ]	
TC5565AFL	TC5565AFL@SOIC28
[ (SA630) ]	
TC5565APL	TC5565APL@SOIC28
[ (SA630) ]	
TC5588	TC5588@SOIC28
[ (SA630) ]	
TC55B88	TC55B88@SOIC28
[ (SA630) ]	
TMM2018	TMM2018@PLCC32
[ (SA015A1T) ]	
TMM2063	TMM2063@SOIC28
[ (SA630) ]	

## MICROCONTROLLER

TMP47P443VDM@SSOP30 [(SA438T)]                      TMP47P443VM@SOP28  
 [(SA404)]  
 TMP47P443VN@SDIP28 [(SA022A)]                      TMP68HC11E1@PLCC52 [(PEP  
 +S415T)]  
 TMP68HC11E1@PLCC52(\*) [(SA647-B5202)]  
 TMP68HC11E9@PLCC52 [(PEP+S415T)]  
 TMP68HC11E9@PLCC52(\*) [(SA647-B5202)]  
 TMP68HC711E9@PLCC52(\*) [(SA647-B5202)]  
 TMP86CS44@LQFP44 [(SA245A)]                      TMP86P202M@SOIC20  
 [(SA023A)]  
 TMP86P202P                                              TMP86P203M@SOIC20  
 [(SA023A)]  
 TMP86P203P                                              TMP86P807M@SOP28  
 [(SA438T)]  
 TMP86P807N@SDIP28 [(SA653)]                      TMP86P808DM@SSOP30  
 [(SA626A)]  
 TMP86P808N@SDIP30 [(SA653)]                      TMP86PH06N@SDIP42 [(SA028  
 +B005)]  
 TMP86PH06U@QFP44 [(SA245A+B005)]                      TMP86PM47U@QFP44 [(SA245A  
 +B005)]  
 TMP86PM47UG@QFP44 [(SA245A+B005)]  
 TMP86PS44@LQFP44 [(SA245A)]                      TMP87P408M@SOIC28  
 [(SA404)]  
 TMP87P408N@SDIP28 [(SA022A)]                      TMP87P409M@SOIC28  
 [(SA404)]  
 TMP87P409N@SDIP28 [(SA022A)]                      TMP87P808LM@SOP28  
 [(SA404)]  
 TMP87P808LM@SOP28(Toshiba) [(BM11116)]  
 TMP87P808LN@SDIP28 [(SA022A)]  
 TMP87P808LN@SDIP28(Toshiba) [(BM11122)]  
 TMP87P808M@SOP28 [(SA404)]  
 TMP87P808M@SOP28(Toshiba) [(BM11116)]  
 TMP87P808N@SDIP28 [(SA022A)]  
 TMP87P808N@SDIP28(Toshiba) [(BM11122)]  
 TMP87P809M@SOIC28 [(SA404)]                      TMP87P809N@SDIP28  
 [(SA022A)]  
 TMP87P844N@SDIP42 [(SA028)]  
 TMP87P844N@SDIP42(Toshiba) [(BM11108)]  
 TMP87P844NG@SDIP42 [(SA028)]  
 TMP87P844NG@SDIP42(Toshiba) [(BM11108)]  
 TMP87PH00DF@QFP64 [(PEP+S621)]  
 TMP87PH00DF@QFP64(Toshiba) [(BM1173)]  
 TMP87PH00F@QFP64(\*) [(TA022-B006)]

TMP87PH00F@QFP64(Toshiba) [(BM1137)]  
TMP87PH00LF@QFP64 [(PEP+S621)]  
TMP87PH00LF@QFP64(Toshiba) [(BM1173)]  
TMP87PH00N@SDIP64(\*) [(S600A-B6402)]  
TMP87PH00N@SDIP64(Toshiba) [(BM1136)]  
TMP87PH20F@QFP80(Toshiba) [(BM1138)]  
TMP87PH40AF@PQFP64(\*) [(TA022-B006)]  
TMP87PH40AF@PQFP64(Toshiba) [(BM1137)]  
TMP87PH40AN@SDIP64(\*) [(S600A-B6402)]  
TMP87PH40AN@SDIP64(Toshiba) [(BM1136)]  
TMP87PH46N@SDIP42 [(SA028)]  
TMP87PH46N@SDIP42(Toshiba) [(BM1193)]  
TMP87PH47LU@QFP44 [(SA245A)]  
TMP87PH47LU@QFP44(Toshiba) [(BM1194C)]  
TMP87PH47U@QFP44 [(SA245A)]  
TMP87PH47U@QFP44(Toshiba) [(BM1194C)]  
TMP87PM14F@QFP64(Toshiba) [(BM1199)]  
TMP87PM14N@SDIP64(Toshiba) [(BM1198)]  
TMP87PM20F@QFP80(Toshiba) [(BM1138)]  
TMP87PM29U@LQFP64 [(PEP+S616)]  
TMP87PM29U@LQFP64(Toshiba) [(BM11117)]  
TMP87PM34AN@SDIP42(Toshiba) [(BM1183A)]  
TMP87PM36N@SDIP42(Toshiba) [(BM1183A)]  
TMP87PM40AF@PQFP64(\*) [(TA022-B006)]  
TMP87PM40AF@PQFP64(Toshiba) [(BM1137)]  
TMP87PM40AN@SDIP64(\*) [(S600A-B6402)]  
TMP87PM40AN@SDIP64(Toshiba) [(BM1136)]  
TMP87PM41F@QFP64(\*) [(TA022-B006)]  
TMP87PM41F@QFP64(Toshiba) [(BM1137)]  
TMP87PM41N@SDIP64(\*) [(S600A-B6402)]  
TMP87PM41N@SDIP64(Toshiba) [(BM1136)]  
TMP87PM41U@LQFP64 [(PEP+S621)]  
TMP87PM41U@LQFP64(Toshiba) [(BM1121)]  
TMP87PM43N@SDIP42 [(SA028)]  
TMP87PM43N@SDIP42(Toshiba) [(BM1163)]  
TMP87PM70F@QFP80 [(PEP+S611A)]  
TMP87PM70F@QFP80(Toshiba) [(BM1150B)]  
TMP87PM74F@QFP80 [(PEP+S611A)]  
TMP87PM74F@QFP80(Toshiba) [(BM11120)]  
TMP87PM75F@QFP100(Toshiba) [(BM11124)]  
TMP87PM78F@QFP100(Toshiba) [(BM1188)]  
TMP87PP21DF@LQFP80 [(PEP+S640B)]  
TMP87PP21DF@LQFP80(Toshiba) [(BM11105)]

TMP87PP21F@QFP80 [(PEP+S611A)]  
TMP87PP21F@QFP80(Toshiba) [(BM11104)]  
TMP87PP23F@QFP100 [(PEP+S427)]  
TMP87PP23F@QFP100(Toshiba) [(BM1185A)]  
TMP87PP24F@LQFP100 [(PEP+S604)]  
TMP87PP24F@LQFP100(Toshiba) [(BM11127)]  
TMP87PP71F@QFP80 [(PEP+S611A)]  
TMP87PP71F@QFP80(Toshiba) [(BM11107)]  
TMP87PS38F@QFP44 [(SA679)]  
TMP87PS38F@QFP44(Toshiba) [(BM11136)]  
TMP87PS38N@SDIP42 [(SA028)]  
TMP87PS38N@SDIP42(Toshiba) [(BM11112)]  
TMP87PS39F@QFP64(Toshiba) [(BM11138)]  
TMP87PS39N@SDIP64(Toshiba) [(BM11118)]  
TMP87PS64F@QFP100(Toshiba) [(BM1185A)]  
TMP87PS71F@QFP80 [(PEP+S611A)]  
TMP87PS71F@QFP80(Toshiba) [(BM11107)]  
TMP88PH40M@SOIC28 [(SA438T)]                      TMP88PH40N@SDIP28  
[(SA653)]  
TMP91PW12F@LQFP100 [(PEP+S604)]                      TMP91PW18A@LQFP80 [(PEP  
+S604)]  
TMP93PW44ADF@PQFP80 [(SA730+B263)]

## TOSHIBA-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

TC58DAM72A1F@TSOP48 [(SA247-B005)]  
TC58DVM72A1F@TSOP48 [(SA247-B005)]  
TC58DVM82A1@FBGA63 [(SA642B-B026A-Y072F001)]  
TC58DVM82A1@TSOP48 [(SA247-B005)]  
TY9000A000EMGF(YH)@BGA149 [(SA664G-B279-Y149F001Y)]

### MICROCONTROLLER

TMP87PM40AF@PQFP64(\*) [(TA022-B006)]  
TMP87PM40AN@SDIP64(\*) [(S600A-B6402)]

## TURBO IC

## **E ( E ) PROM / FRAM / NVRAM**

TU24C01 [ ( SA602A ) ]	TU24C01@SOIC8
TU24C02 [ ( SA602A ) ]	TU24C02@SOIC8
TU24C04 [ ( SA602A ) ]	TU24C04@SOIC8
TU24C08 [ ( SA602A ) ]	TU24C08@SOIC8
TU24C128 [ ( SA602A ) ]	TU24C128@SOIC8
TU24C16 [ ( SA602A ) ]	TU24C16@SOIC8
TU24C16@TSSOP8 [ ( SA026 ) ]	
TU24C256 TU24C256@SOIC8 [ ( SA602A ) ]	
TU24C32 TU24C32@SOIC8 [ ( SA602A ) ]	
TU24C64 TU24C64@SOIC8 [ ( SA602A ) ]	

## **UBICOM**

### **MICROCONTROLLER**

SX20AC/SS/G@SSOP20 [ ( SA626A ) ] [ ( SA626A ) ]	SX20AC/SS@SSOP20
SX28AC/DP G	SX28AC/DP/
SX28AC/SS/G@SSOP28 [ ( SA626A ) ] [ ( SA626A ) ]	SX28AC/SS@SSOP28
SX48BD/G@TQFP48 [ ( SA248 ) ] [ ( SA248 ) ]	SX48BD@TQFP48

## **UMC**

### **E ( E ) PROM / FRAM / NVRAM**

2732



2764

**DRAM & SRAM**

UM6116 [ (SA015A1T) ]	UM6116@PLCC32
UM6116A [ (SA015A1T) ]	UM6116A@PLCC32
UM61256 [ (SA630) ]	UM61256@SOIC28
UM61257	
UM61512	
UM61512@SOIC32 [ (SA630) ]	
UM6164	
UM6164@SOIC28 [ (SA630) ]	
UM6167	
UM621024 [ (SA630) ]	UM621024@SOIC32
UM62256 [ (SA630) ]	UM62256@SOIC28
UM62256A [ (SA630) ]	UM62256A@SOIC28
UM6264 [ (SA630) ]	UM6264@SOIC28
UM6264A [ (SA630) ]	UM6264A@SOIC28

**UTRON****E (E) PROM / FRAM / NVRAM**

UT61256C [ (SA630) ]	UT61256C@SOIC28
UT61256C@TSOP28 [ (SA430T) ] [ (SA630) ]	UT6164C@SOIC28
UT6164C@TSOP28 [ (SA430T) ]	
UT61L256C	
UT61L256C@SOIC28 [ (SA630) ] [ (SA430T) ]	UT61L256C@TSOP28
UT62256C [ (SA630) ]	UT62256C@SOIC28

UT62256C@TSOP28 [(SA430T)]  
UT62256CE  
UT62256CE@SOIC28 [(SA630)]  
[(SA430T)]  
UT62257C  
[(SA630)]  
UT62257C@TSOP28 [(SA430T)]  
UT6264C  
UT6264C@SOIC28 [(SA630)]  
UT62L256C  
UT62L256C@SOIC28 [(SA630)]  
[(SA430T)]  
UT62L64C  
[(SA630)]  
UT62W256C  
[(SA630)]  
UT62W256C@TSOP28 [(SA430T)]  
UT62W64C  
UT62W64C@SOIC28 [(SA630)]

UT62256CE@TSOP28  
  
UT62257C@SOIC28  
  
UT62L256C@TSOP28  
  
UT62L64C@SOIC28  
  
UT62W256C@SOIC28

## VANTIS

### PLD

M4-128/64@PQFP100 [(PEP+S427)]  
+S604)]  
M4-128N/64@PLCC84 [(PEP+S416T)]  
+S427)]  
M4A3-128/64@TQFP100 [(PEP+S604)]  
M4A3-128N/64@PLCC84 [(PEP+S416T)]  
M4A3-32/32@PLCC44 [(SA244)]  
[(SA245A)]  
M4A3-32/32@TQFP48 [(SA248)]  
[(SA244)]  
M4A3-64/32@TQFP44 [(SA245A)]  
[(SA248)]  
M4A3-64/64@TQFP100 [(PEP+S604)]  
+S604)]  
M4A5-128/64@PQFP100 [(PEP+S427)]  
+S604)]  
M4A5-128N/64@PLCC84 [(PEP+S416T)]  
M4A5-32/32@PLCC44 [(SA244)]

M4-128/64@TQFP100 [(PEP  
M4A3-128/64@PQFP100 [(PEP  
M4A3-32/32@TQFP44  
M4A3-64/32@PLCC44  
M4A3-64/32@TQFP48  
M4A3-96/48@TQFP100 [(PEP  
M4A5-128/64@TQFP100 [(PEP  
M4A5-32/32@TQFP44

[ (SA245A) ]  
M4A5-32/32@TQFP48 [ (SA248) ]  
[ (SA244) ]  
M4A5-64/32@TQFP44 [ (SA245A) ]  
[ (SA248) ]  
M4A5-96/48@TQFP100 [ (PEP+S604) ]  
+S427) ]  
M4LV-128/64@TQFP100 [ (PEP+S604) ]  
M4LV-128N/64@PLCC84 [ (PEP+S416T) ]  
MACH110@PLCC44 [ (SA244) ]  
[ (SA244) ]  
MACH111@TQFP44 [ (SA245A) ]  
+S414T) ]  
MACH130@PLCC84 [ (PEP+S416T) ]  
+S416T) ]  
MACH131@PLCC84 [ (PEP+S416T) ]  
+S427) ]  
MACH131SP@TQFP100 [ (PEP+S604) ]  
[ (SA244) ]  
MACH210@TQFP44 [ (SA245A) ]  
[ (SA244) ]  
MACH210A@TQFP44 [ (SA245A) ]  
[ (SA244) ]  
MACH210AQ@TQFP44 [ (SA245A) ]  
[ (SA244) ]  
MACH211@TQFP44 [ (SA245A) ]  
[ (SA244) ]  
MACH211SP@TQFP44 [ (SA245A) ]  
+S414T) ]  
MACH221@PLCC68 [ (PEP+S414T) ]  
+S416T) ]  
MACH231@PLCC84 [ (PEP+S416T) ]  
+S416T) ]  
MACH231SP@PQFP100 [ (PEP+S427) ]  
+S604) ]  
MACH435@PLCC84 [ (PEP+S416T) ]  
+S416T) ]  
MACH446@PQFP100 [ (PEP+S427) ]  
+S604) ]  
MACHLV210@PLCC44 [ (SA244) ]  
+S416T) ]  
MACHLV446@PQFP100 [ (PEP+S427) ]  
+S604) ]  
M4A5-64/32@PLCC44  
M4A5-64/32@TQFP48  
M4LV-128/64@PQFP100 [ (PEP  
MACH111@PLCC44  
MACH120@PLCC68 [ (PEP  
MACH131/1@PLCC84 [ (PEP  
MACH131SP@PQFP100 [ (PEP  
MACH210@PLCC44  
MACH210A@PLCC44  
MACH210AQ@PLCC44  
MACH211@PLCC44  
MACH211SP@PLCC44  
MACH220@PLCC68 [ (PEP  
MACH230@PLCC84 [ (PEP  
MACH231SP@PLCC84 [ (PEP  
MACH231SP@TQFP100 [ (PEP  
MACH436@PLCC84 [ (PEP  
MACH446@TQFP100 [ (PEP  
MACHLV436@PLCC84 [ (PEP  
MACHLV446@TQFP100 [ (PEP

PAL29M16H

PALCE20RA10

PALCE20RA10@PLCC28 [(SA008A)]  
[(SA404)]

PALCE20RA10H  
[(SA008A)]

PALCE20RA10H@SOIC24 [(SA404)]

PALCE20RA10Q

PALCE20RA10Q@PLCC28 [(SA008A)]  
[(SA404)]

PALCE26V12H/4  
[(SA008A)]

PALCE26V12H/4@SOIC28 [(SA404)]  
15

PALCE26V12H-15@PLCC28 [(SA008A)]  
[(SA404)]

PALCE26V12H-20  
[(SA008A)]

PALCE26V12H-20@SOIC28 [(SA404)]  
25

PALCE26V12H-25@PLCC28 [(SA008A)]  
[(SA404)]

PALCE29M16H  
[(SA008A)]

PALCE29M16H@SOIC24 [(SA404)]

PALCE29MA16H

PALCE29MA16H@PLCC28 [(SA008A)]  
[(SA404)]

PALCE610  
[(SA008A)]

PALCE610@SOIC24 [(SA404)]

PALCE610H

PALCE610H@PLCC28 [(SA008A)]  
[(SA404)]

PALCE630H  
[(SA008A)]

PALCE630H@SOIC24 [(SA404)]

PALCE20RA10@SOIC24

PALCE20RA10H@PLCC28

PALCE20RA10Q@SOIC24

PALCE26V12H/4@PLCC28

PALCE26V12H-

PALCE26V12H-15@SOIC28

PALCE26V12H-20@PLCC28

PALCE26V12H-

PALCE26V12H-25@SOIC28

PALCE29M16H@PLCC28

PALCE29MA16H@SOIC24

PALCE610@PLCC28

PALCE610H@SOIC24

PALCE630H@PLCC28

## VERSACHIPS

### MICROCONTROLLER

V87C54  
[ ( SA244 ) ]  
V87C54@TQFP44 [ ( SA245A ) ]  
V87C58  
V87C58@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]

V87C54@PLCC44

V87C58@TQFP44

## VLSI

### E ( E ) PROM / FRAM / NVRAM

VT27C128  
VT27C256  
VT27C512  
VT27C64  
VT28H64  
VT28HC64

### PLD

GAL16V8

## WELTREND

### MICROCONTROLLER

WT61P4K420@SDIP42 [ ( SA028 ) ]  
[ ( SA028 ) ]  
WT61P4K422@SDIP42 [ ( SA028 ) ]  
[ ( SA244 ) ]  
WT61P4N400  
WT61P4N401  
WT61P6K420@SDIP42 [ ( SA028 ) ]  
[ ( SA244 ) ]  
WT61P6L441@PLCC44 [ ( SA244 ) ]  
+B258 ) ]  
WT61P7@LQFP44 [ ( SA245 ) ]  
[ ( SA244 ) ]  
WT61P7@TQFP48 [ ( SA248+B250 ) ]

WT61P4K421@SDIP42

WT61P4L440@PLCC44

WT61P6L440@PLCC44

WT61P6S@LQFP44 [ ( SA245A

WT61P7@PLCC44

WT61P8@LQFP44 [ ( SA245A

+B258) ]

WT61P8S@LQFP44 [ (SA245A+B005) ]  
[ (SA028) ]

WT62P1-N28(dip28)  
(dip40)

WT62P1-N42(dip42)  
[ (SA638) ]

WT62P2-K42@SDIP42 [ (SA028) ]  
[ (SA244) ]

WT62P2-N40(dip40)  
(dip42)

WT62P2-S44@PSOP44 [ (SA638) ]  
[ (SA404) ]

WT65F1@TQFP48 [ (SA248) ]

WT62P1-K42@SDIP42

WT62P1-N40

WT62P1-S44@PSOP44

WT62P2-L44@PLCC44

WT62P2-N42

WT65F1@SOIC28

## WHITE ELECTRONIC DESIGNS

### E (E) PROM / FRAM / NVRAM

WE128K8

WE256K8

WE512K8

WF256K8

WF256K8@CLCC32 [ (SA015A1T) ]  
[ (SA661) ]

WF512K8  
[ (SA015A1T) ]

WF512K8@CSOJ32 [ (SA661) ]

WME128K8

WME128K8@CLCC32 [ (SA015A1T) ]  
[ (SA661) ]

WMF128K8  
[ (SA015A1T) ]

WMF128K8@CSOJ32 [ (SA661) ]

WMF256K8

WMF256K8@CLCC32 [ (SA015A1T) ]  
[ (SA661) ]

WMF512K8  
[ (SA015A1T) ]

WMF512K8@CSOJ32 [ (SA661) ]

WMS128K8

WMS128K8@CLCC32 [ (SA015A1T) ]

WF256K8@CSOJ32

WF512K8@CLCC32

WME128K8@CSOJ32

WMF128K8@CLCC32

WMF256K8@CSOJ32

WMF512K8@CLCC32

WMS128K8@CSOJ32

[ ( SA661 ) ]  
WMS256K8 WMS256K8@CLCC32  
[ ( SA015A1T ) ]  
WMS256K8@CSOJ32 [ ( SA661 ) ]  
WMS512K8  
WMS512K8@CLCC32 [ ( SA015A1T ) ] WMS512K8@CSOJ32  
[ ( SA661 ) ]

## WINBOND

### E ( E ) PROM / FRAM / NVRAM

W15B020L W15B020L@SOIC8  
[ ( SA602A ) ]  
W15B020M W15B020M@SOIC8  
[ ( SA602A ) ]  
W15B040L W15B040L@SOIC8  
[ ( SA602A ) ]  
W15B040M W15B040M@SOIC8  
[ ( SA602A ) ]  
W19B160BB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
W19B160BB@TSOP48 [ ( SA247-B005 ) ]  
W19B160BT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
W19B160BT@TSOP48 [ ( SA247-B005 ) ]  
W19B320AB@FBGA48 [ ( SA642A-B026A-Y096F001Y ) ]  
W19B320AB@TSOP48 [ ( SA247-B005 ) ]  
W19B320AT@FBGA48 [ ( SA642A-B026A-Y096F001Y ) ]  
W19B320AT@TSOP48 [ ( SA247-B005 ) ]  
W19B320BB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
W19B320BB@TSOP48 [ ( SA247-B005 ) ]  
W19B320BT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
W19B320BT@TSOP48 [ ( SA247-B005 ) ]  
W19B320SB@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
W19B320SB@TSOP48 [ ( SA247-B005 ) ]  
W19B320ST@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
W19B320ST@TSOP48 [ ( SA247-B005 ) ]  
W19B322MB@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
W19B322MB@TSOP48 [ ( SA247-B005 ) ]  
W19B322MT@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
W19B322MT@TSOP48 [ ( SA247-B005 ) ]  
W19B323MB@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
W19B323MB@TSOP48 [ ( SA247-B005 ) ]

W19B323MT@FBGA48 [(SA642F-B026A-T064F001)]	
W19B323MT@TSOP48 [(SA247-B005)]	
W19B324MB@FBGA48 [(SA642F-B026A-T064F001)]	
W19B324MB@TSOP48 [(SA247-B005)]	
W19B324MT@FBGA48 [(SA642F-B026A-T064F001)]	
W19B324MT@TSOP48 [(SA247-B005)]	
W19L320SB@FBGA48 [(SA642F-B026A-T064F001)]	
W19L320SB@TSOP48 [(SA247-B005)]	
W19L320ST@FBGA48 [(SA642F-B026A-T064F001)]	
W19L320ST@TSOP48 [(SA247-B005)]	
W25B40(Bottom Boot)@SOIC8 [(SA602A)]	
W25B40(Bottom Boot)@WSON8 [(SA683)]	
W25B40(Top Boot)@SOIC8 [(SA602A)]	
W25B40(Top Boot)@WSON8 [(SA683)]	
W25B40A(Bottom Boot)@SOIC8 [(SA602A)]	
W25B40A(Bottom Boot)@WSON8 [(SA683)]	
W25B40A(Top Boot)@SOIC8 [(SA602A)]	
W25B40A(Top Boot)@WSON8 [(SA683)]	
W25D10 [(SA602A)]	W25D10(SN)@SOIC8
W25D10(SS)@SOIC8 [(SA023A)] [(SA683)]	W25D10(ZP)@WSON8
W25D20 [(SA602A)]	W25D20(SN)@SOIC8
W25D20(SS)@SOIC8 [(SA023A)] [(SA683)]	W25D20(ZP)@WSON8
W25D40 [(SA602A)]	W25D40(SN)@SOIC8
W25D40(SS)@SOIC8 [(SA023A)] [(SA683)]	W25D40(ZP)@WSON8
W25D80 [(SA602A)]	W25D80(SN)@SOIC8
W25D80(SS)@SOIC8 [(SA023A)] [(SA683)]	W25D80(ZP)@WSON8
W25P10@SOIC8 [(SA602A)] [(SA683)]	W25P10@WSON8
W25P16@SOIC16 [(SA404)]	
W25P16@SOIC16(ISP) [ISP-HEADER01]	
W25P16@SOIC8 [(SA023A)] [ISP-HEADER01]	W25P16@SOIC8(ISP) [ISP-HEADER01]
W25P16@WSON8 [(SA683)] [ISP-HEADER01]	W25P16@WSON8(ISP) [ISP-HEADER01]
W25P20@SOIC8 [(SA602A)]	W25P20@WSON8



[ (SA683) ]	
W25P32@SOIC16 [ (SA404) ]	
W25P32@SOIC16(ISP) [ISP-HEADER01]	
W25P32@WSON8 [ (SA683) ]	W25P32@WSON8(ISP) [ISP-
HEADER01]	
W25P40@SOIC8 [ (SA602A) ]	W25P40@WSON8
[ (SA683) ]	
W25P64@SOIC16 [ (SA404) ]	
W25P64@SOIC16(ISP) [ISP-HEADER01]	
W25P64@WSON8 [ (SA683) ]	W25P64@WSON8(ISP) [ISP-
HEADER01]	
W25P80@SOIC8 [ (SA602A) ]	W25P80@WSON8
[ (SA683) ]	
W25Q16@SOIC16 [ (SA404) ]	
W25Q16@SOIC16(ISP) [ISP-HEADER01]	
W25Q16@SOIC8 [ (SA023A) ]	W25Q16@SOIC8(ISP) [ISP-
HEADER01]	
W25Q16@WSON8 [ (SA683) ]	W25Q16@WSON8(ISP) [ISP-
HEADER01]	
W25Q32@SOIC16 [ (SA404) ]	
W25Q32@SOIC16(ISP) [ISP-HEADER01]	
W25Q32@WSON8 [ (SA683) ]	W25Q32@WSON8(ISP) [ISP-
HEADER01]	
W25Q80@SOIC8 [ (SA602A) ]	W25Q80@WSON8
[ (SA683) ]	
W25X10	W25X10(SN)@SOIC8
[ (SA602A) ]	
W25X10(SS)@SOIC8 [ (SA023A) ]	W25X10(ZP)@WSON8
[ (SA683) ]	
W25X10L	W25X10L(SN)@SOIC8
[ (SA602A) ]	
W25X10L(ZP)@WSON8 [ (SA683) ]	
W25X10V	
W25X10V(SN)@SOIC8 [ (SA602A) ]	W25X10V(SS)@SOIC8
[ (SA023A) ]	
W25X10V(ZP)@WSON8 [ (SA683) ]	W25X16@SOIC16
[ (SA404) ]	
W25X16@SOIC16(ISP) [ISP-HEADER01]	
W25X16@SOIC8 [ (SA023A) ]	W25X16@SOIC8(ISP) [ISP-
HEADER01]	
W25X20	W25X20(SN)@SOIC8
[ (SA602A) ]	
W25X20(SS)@SOIC8 [ (SA023A) ]	W25X20(ZP)@WSON8

[ (SA683) ]	
W25X20L	W25X20L(SN)@SOIC8
[ (SA602A) ]	
W25X20L(ZP)@WSON8 [ (SA683) ]	
W25X20V	
W25X20V(SN)@SOIC8 [ (SA602A) ]	W25X20V(SS)@SOIC8
[ (SA023A) ]	
W25X20V(ZP)@WSON8 [ (SA683) ]	W25X32@SOIC16
[ (SA404) ]	
W25X32@SOIC16(ISP) [ ISP-HEADER01 ]	
W25X32@SOIC8 [ (SA023A) ]	W25X32@SOIC8(ISP) [ ISP-
HEADER01 ]	
W25X40	W25X40(SN)@SOIC8
[ (SA602A) ]	
W25X40(SS)@SOIC8 [ (SA023A) ]	W25X40(ZP)@WSON8
[ (SA683) ]	
W25X40L	W25X40L(SN)@SOIC8
[ (SA602A) ]	
W25X40L(SS)@SOIC8 [ (SA023A) ]	W25X40L(ZP)@WSON8
[ (SA683) ]	
W25X40V	W25X40V(SN)@SOIC8
[ (SA602A) ]	
W25X40V(SS)@SOIC8 [ (SA023A) ]	W25X40V(ZP)@WSON8
[ (SA683) ]	
W25X64@SOIC16 [ (SA404) ]	
W25X64@SOIC16(ISP) [ ISP-HEADER01 ]	
W25X64@SOIC8 [ (SA023A) ]	W25X64@SOIC8(ISP) [ ISP-
HEADER01 ]	
W25X80	W25X80(SN)@SOIC8
[ (SA602A) ]	
W25X80(SS)@SOIC8 [ (SA023A) ]	W25X80(ZP)@WSON8
[ (SA683) ]	
W25X80L	W25X80L(SS)@SOIC8
[ (SA023A) ]	
W25X80L(ZP)@WSON8 [ (SA683) ]	
W25X80V	
W25X80V(SN)@SOIC8 [ (SA602A) ]	W25X80V(SS)@SOIC8
[ (SA023A) ]	
W25X80V(ZP)@WSON8 [ (SA683) ]	
W27C01	
W27C01@PLCC32 [ (SA015A1T) ]	W27C01@VSOP32
[ (SA620) ]	
W27C010	W27C010@PLCC32

[ (SA015A1T) ]	
W27C010@SOIC32 [ (SA438T) ]	
W27C02	
W27C02@PLCC32 [ (SA015A1T) ]	W27C02@VSOP32
[ (SA620) ]	
W27C020	W27C020@PLCC32
[ (SA015A1T) ]	
W27C020M	W27C020M@PLCC32
[ (SA015A1T) ]	
W27C257	W27C257@PLCC32
[ (SA015A1T) ]	
W27C4096	W27C4096@PLCC44
[ (SA244) ]	
W27C4096@TSOP40 [ (SA409T) ]	
W27C512	
W27C512@PLCC32 [ (SA015A1T) ]	W27C512@TSOP28
[ (SA430T) ]	
W27C520@SOIC20 [ (SA404) ]	W27C520@TSSOP20
[ (SA026) ]	
W27E01	W27E01@PLCC32
[ (SA015A1T) ]	
W27E01@VSOP32 [ (SA620) ]	
W27E010	
W27E010@PLCC32 [ (SA015A1T) ]	W27E010@SOIC32
[ (SA438T) ]	
W27E02	W27E02@PLCC32
[ (SA015A1T) ]	
W27E02@VSOP32 [ (SA620) ]	
W27E020	
W27E020@PLCC32 [ (SA015A1T) ]	
W27E040	
W27E040@PLCC32 [ (SA015A1T) ]	W27E040@SOIC32
[ (SA438T) ]	
W27E257	W27E257@PLCC32
[ (SA015A1T) ]	
W27E4096	W27E4096@PLCC44
[ (SA244) ]	
W27E4096@TSOP40 [ (SA409T) ]	
W27E512	
W27E512@PLCC32 [ (SA015A1T) ]	W27E512@TSOP28
[ (SA430T) ]	
W27E520@SOIC20 [ (SA404) ]	W27E520@TSSOP20
[ (SA026) ]	

W27L01	W27L01@PLCC32
[ (SA015A1T) ]	
W27L01@VSOP32 [ (SA620) ]	
W27L010	
W27L010@PLCC32 [ (SA015A1T) ]	
W27L02	
W27L02@PLCC32 [ (SA015A1T) ]	W27L02@VSOP32
[ (SA620) ]	
W27L520@SOIC20 [ (SA404) ]	W27L520@TSSOP20
[ (SA026) ]	
W28F321BB@FBGA48 [ (SA634A-B005A-Y048F001) ]	
W28F321BT@TSOP48 [ (SA247-B005) ]	
W28F321TB@FBGA48 [ (SA634A-B005A-Y048F001) ]	
W28F321TT@TSOP48 [ (SA247-B005) ]	
W28F641BB@FBGA48 [ (SA634A-B005A-Y048F001) ]	
W28F641BT@TSOP48 [ (SA247-B005) ]	
W28F641TB@FBGA48 [ (SA634A-B005A-Y048F001) ]	
W28F641TT@TSOP48 [ (SA247-B005) ]	W28J160BT@TSOP48 [ (SA247-B005) ]
W28J160TT@TSOP48 [ (SA247-B005) ]	
W28J161BB@TFBGA48 [ (SA634A-B005A-Y048F001) ]	
W28J161TB@TFBGA48 [ (SA634A-B005A-Y048F001) ]	
W28J320BT@TSOP48 [ (SA247-B005) ]	W28J320TT@TSOP48 [ (SA247-B005) ]
W28J321BB@TFBGA48 [ (SA634A-B005A-Y048F001) ]	
W28J321TB@TFBGA48 [ (SA634A-B005A-Y048F001) ]	
W28J800BT@TSOP48 [ (SA247-B005) ]	W28J800TT@TSOP48 [ (SA247-B005) ]
W28V400BT@TSOP48 [ (SA247-B005) ]	W28V400TT@TSOP48 [ (SA247-B005) ]
W29C010	W29C010@PLCC32
[ (SA015A1T) ]	
W29C011A	W29C011A@PLCC32
[ (SA015A1T) ]	
W29C020	W29C020@PLCC32
[ (SA015A1T) ]	
W29C020@SOIC32 [ (SA438T) ]	W29C020@TSOP32
[ (SA410T) ]	
W29C020C	
W29C020C@PLCC32 [ (SA015A1T-B001) ]	
W29C020C@TSOP32 [ (SA410T-B003) ]	W29C020C@VSOP32 [ (SA620-B005) ]
W29C040	W29C040@PLCC32 [ (SA015A1T-

B001) ]	
W29C040@TSOP32 [(SA410T-B003) ]	W29C040@VSOP32 [(SA620-
B005) ]	
W29C101	W29C101@PLCC44
[(SA244) ]	
W29C101@TSOP40 [(SA409T) ]	
W29C102	
W29C102@PLCC44 [(SA244) ]	W29C102@TSOP40
[(SA409T) ]	
W29EE010	W29EE010@PLCC32
[(SA015A1T) ]	
W29EE010@SOIC32 [(SA438T) ]	W29EE010@TSOP32
[(SA410T) ]	
W29EE011	W29EE011@PLCC32
[(SA015A1T) ]	
W29EE011@SOIC32 [(SA438T) ]	
W29EE012	
W29EE012@PLCC32 [(SA015A1T) ]	W29EE012@SOIC32
[(SA438T) ]	
W29EE512	W29EE512@PLCC32
[(SA015A1T) ]	
W29EE512@SOIC32 [(SA438T) ]	W29EE512@TSOP32
[(SA410T) ]	
W29F040	W29F040@PLCC32
[(SA015A1T) ]	
W29F040@TSOP32 [(SA410T) ]	W29F102@PLCC44
[(SA244) ]	
W29F102@TSOP40 [(SA623) ]	W29L102@PLCC44
[(SA244) ]	
W29L102@TSOP40 [(SA623) ]	
W39F010	
W39F010@PLCC32 [(SA015A1T-B001) ]	
W39F010@TSOP32[12.4mm] [(SA620-B005) ]	
W39F010@TSOP32[18.4mm] [(SA410T-B003) ]	
W39L010@PLCC32 [(SA015A1T-B001) ]	W39L010@TSOP32 [(SA620-
B005) ]	
W39L020@PLCC32 [(SA015A1T-B001) ]	
W39L020@TSOP32[12.4mm] [(SA620-B005) ]	
W39L020@TSOP32[18.4mm] [(SA410T-B003) ]	
W39L040@PLCC32 [(SA015A1T-B001) ]	
W39L040@TSOP32[12.4mm] [(SA620-B005) ]	
W39L040@TSOP32[18.4mm] [(SA410T-B003) ]	
W39L040A	W39L040A@PLCC32

[ (SA015A1T) ]  
W39L040A@TSOP32 [ (SA410T) ]  
[ (SA620) ]  
W39L512@PLCC32 [ (SA015A1T-B001) ]  
B005) ]  
W39V040AP@PLCC32 [ (SA015A1T) ]  
[ (SA620) ]  
W39V040B(P)@PLCC32 [ (SA015A1T) ]  
[ (SA620) ]  
W39V040CP@PLCC32 [ (SA015A1T) ]  
[ (SA015A1T) ]  
W39V040CQ@VSOP32 [ (SA620) ]  
[ (SA620) ]  
W39V040FAP@PLCC32 [ (SA015A1T) ]  
[ (SA620) ]  
W39V040FAT@TSOP40 [ (SA409T) ]  
[ (SA015A1T) ]  
W39V040FB(Q)@VSOP32 [ (SA620) ]  
[ (SA015A1T) ]  
W39V040FCPZ@PLCC32 [ (SA015A1T) ]  
[ (SA620) ]  
W39V040FCQZ@VSOP32 [ (SA620) ]  
[ (SA015A1T) ]  
W39V080A(Q)@VSOP32 [ (SA620) ]  
[ (SA409T) ]  
W39V080FA(P)@PLCC32 [ (SA015A1T) ]  
[ (SA620) ]  
W39V080FA(T)@TSOP40 [ (SA409T) ]  
[ (SA015A1T) ]  
W45B012@SON8 [ (SA683) ]  
[ (SA015A1T) ]  
W45B512@SON8 [ (SA683) ]  
W49F002  
W49F002@PLCC32 [ (SA015A1T-B001) ]  
B003) ]  
W49F002B  
W49F002B@PLCC32 [ (SA015A1T-B001) ]  
W49F002B@TSOP32 [ (SA410T-B003) ]  
W49F002N  
W49F002N@PLCC32 [ (SA015A1T-B001) ]  
W49F002N@TSOP32 [ (SA410T-B003) ]  
W49F002U  
W49F002U@PLCC32 [ (SA015A1T-B001) ]

W39L040A@VSOP32  
W39L512@TSOP32 [ (SA620-  
W39V040AQ@VSOP32  
W39V040B(Q)@VSOP32  
W39V040CPZ@PLCC32  
W39V040CQZ@VSOP32  
W39V040FAQ@VSOP32  
W39V040FB(P)@PLCC32  
W39V040FCP@PLCC32  
W39V040FCQ@VSOP32  
W39V080A(P)@PLCC32  
W39V080A(T)@TSOP40  
W39V080FA(Q)@VSOP32  
W45B012@PLCC32  
W45B512@PLCC32  
W49F002@TSOP32 [ (SA410T-

W49F002U@TSOP32 [(SA410T-B003)]	
W49F020	
W49F020@PLCC32 [(SA015A1T)]	W49F020@TSOP32
[(SA410T)]	
W49F102@PLCC44 [(SA244)]	W49F102@TSOP40
[(SA623)]	
W49F201@PSOP44 [(SA638)]	W49F201@TSOP48 [(SA247-
B005)]	
W49L102@PLCC44 [(SA244)]	W49L102@TSOP40
[(SA623)]	
W49L201@PSOP44 [(SA638)]	W49L201@TSOP48 [(SA247-
B005)]	
W49L401@PSOP44 [(SA638)]	W49L401@TSOP48 [(SA247-
B005)]	
W49L401T@PSOP44 [(SA638)]	W49L401T@TSOP48 [(SA247-
B005)]	
W49V002A@PLCC32 [(SA015A1T)]	W49V002A@VSOP32
[(SA620)]	
W49V002FA@PLCC32 [(SA015A1T)]	W49V002FA@VSOP32
[(SA620)]	
W49V002FP@PLCC32 [(SA015A1T)]	W49V002FP@VSOP32
[(SA620)]	
W49V002P@PLCC32 [(SA015A1T)]	W49V002P@VSOP32
[(SA620)]	
W55F05	
W55F10A	
W55F20	

## MICROCONTROLLER

W77E058	W77E058@PLCC44
[(SA244)]	
W77E058@TQFP44 [(SA245A)]	
W77E516	
W77E516@PLCC44 [(SA244)]	W77E516@TQFP44
[(SA245A)]	
W77E532	W77E532@PLCC44
[(SA244)]	
W77E532@TQFP44 [(SA245A)]	
W77E532A	
W77E532A@PLCC44 [(SA244)]	W77E532A@TQFP44
[(SA245A)]	

W77E58 [ (SA244) ] W77E58@TQFP44 [ (SA245A) ] W77IE58 W77IE58@PLCC44 [ (SA244) ] [ (SA245A) ] W77L058 [ (SA244) ] W77L058@TQFP44 [ (SA245A) ] W77L516A W77L516A@PLCC44 [ (SA244) ] [ (SA245A) ] W77L532A [ (SA244) ] W77L532A@TQFP44 [ (SA245A) ] W77LE516 W77LE516@PLCC44 [ (SA244) ] [ (SA245A) ] W77LE532 [ (SA244) ] W77LE532@TQFP44 [ (SA245A) ] W77LE58 W77LE58@PLCC44 [ (SA244) ] [ (SA245A) ] W78E051B [ (SA244) ] W78E051B@TQFP44 [ (SA245A) ] W78E051C W78E051C@PLCC44 [ (SA244) ] [ (SA245A) ] W78E052B [ (SA244) ] W78E052B@TQFP44 [ (SA245A) ] W78E052C W78E052C@PLCC44 [ (SA244) ] [ (SA245A) ] W78E054B [ (SA244) ] W78E054B@TQFP44 [ (SA245A) ] W78E054C W78E054C@PLCC44 [ (SA244) ] [ (SA245A) ] W78E058B	W77E58@PLCC44   W77IE58@TQFP44  W77L058@PLCC44  W77L516A@TQFP44  W77L532A@PLCC44  W77LE516@TQFP44  W77LE532@PLCC44  W77LE58@TQFP44  W78E051B@PLCC44  W78E051C@TQFP44  W78E052B@PLCC44  W78E052C@TQFP44  W78E054B@PLCC44  W78E054C@TQFP44  W78E058B@PLCC44
----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



[ (SA244) ]	
W78E058B@TQFP44 [ (SA245A) ]	
W78E065	
W78E065@PLCC44 [ (SA244) ]	W78E065@TQFP44
[ (SA245A) ]	
W78E354(dip40)	W78E354
(dip48)	
W78E354@PLCC68 [ (PEP+S414T) ]	
W78E365	
W78E365@PLCC44 [ (SA244) ]	W78E365@TQFP44
[ (SA245A) ]	
W78E374B	
W78E378	
W78E378E	W78E378P@PLCC44
[ (SA244) ]	
W78E51	W78E51@PLCC44
[ (SA244) ]	
W78E51@TQFP44 [ (SA245A) ]	
W78E516	
W78E516@PLCC44 [ (SA244) ]	W78E516@TQFP44
[ (SA245A) ]	
W78E516B	W78E516B@PLCC44
[ (SA244) ]	
W78E516B@TQFP44 [ (SA245A) ]	
W78E51B	
W78E51B@PLCC44 [ (SA244) ]	W78E51B@TQFP44
[ (SA245A) ]	
W78E51C	W78E51C@PLCC44
[ (SA244) ]	
W78E51C@TQFP44 [ (SA245A) ]	
W78E52	
W78E52@PLCC44 [ (SA244) ]	W78E52@TQFP44
[ (SA245A) ]	
W78E52B	W78E52B@PLCC44
[ (SA244) ]	
W78E52B@TQFP44 [ (SA245A) ]	
W78E52C	
W78E52C@PLCC44 [ (SA244) ]	W78E52C@TQFP44
[ (SA245A) ]	
W78E54	W78E54@PLCC44
[ (SA244) ]	
W78E54@TQFP44 [ (SA245A) ]	
W78E54B	

W78E54B@PLCC44 [(SA244)]	W78E54B@TQFP44
[(SA245A)]	
W78E54C	W78E54C@PLCC44
[(SA244)]	
W78E54C@TQFP44 [(SA245A)]	
W78E58	
W78E58@PLCC44 [(SA244)]	W78E58@TQFP44
[(SA245A)]	
W78E58B	W78E58B@PLCC44
[(SA244)]	
W78E58B@TQFP44 [(SA245A)]	
W78E62B	
W78E62B@PLCC44 [(SA244)]	W78E62B@TQFP44
[(SA245A)]	
W78E65	W78E65@PLCC44
[(SA244)]	
W78E65@TQFP44 [(SA245A)]	
W78E858	
W78E858@PLCC44 [(SA244)]	W78E858@TQFP44
[(SA245A)]	
W78ERD2	W78ERD2@PLCC44
[(SA244)]	
W78ERD2@TQFP44 [(SA245A)]	
W78I052	
W78I052@PLCC44 [(SA244)]	
W78I054	
W78I054@PLCC44 [(SA244)]	
W78IE52	
W78IE52@PLCC44 [(SA244)]	
W78IE54	
W78IE54@PLCC44 [(SA244)]	
W78IRD2	
W78IRD2@PLCC44 [(SA244)]	W78IRD2@TQFP44
[(SA245A)]	
W78L051	W78L051@PLCC44
[(SA244)]	
W78L051@TQFP44 [(SA245A)]	
W78L051C	
W78L051C@PLCC44 [(SA244)]	W78L051C@TQFP44
[(SA245A)]	
W78L052	W78L052@PLCC44
[(SA244)]	
W78L052@TQFP44 [(SA245A)]	

W78L052C	
W78L052C@PLCC44 [(SA244)]	W78L052C@TQFP44
[(SA245A)]	
W78L054	W78L054@PLCC44
[(SA244)]	
W78L054@TQFP44 [(SA245A)]	
W78L054C	
W78L054C@PLCC44 [(SA244)]	W78L054C@TQFP44
[(SA245A)]	
W78L058	W78L058@PLCC44
[(SA244)]	
W78L058@TQFP44 [(SA245A)]	
W78L365	
W78L365@PLCC44 [(SA244)]	W78L365@TQFP44
[(SA245A)]	
W78L365@TQFP48 [(SA248A-B005)]	
W78L516	
W78L516@PLCC44 [(SA244)]	W78L516@TQFP44
[(SA245A)]	
W78L812	W78L812@PLCC44
[(SA244)]	
W78L812@TQFP44 [(SA245A)]	
W78LE365	
W78LE365@PLCC44 [(SA244)]	W78LE365@TQFP44
[(SA245A)]	
W78LE365@TQFP48 [(SA248A-B005)]	
W78LE51	
W78LE51@PLCC44 [(SA244)]	W78LE51@TQFP44
[(SA245A)]	
W78LE516	W78LE516@PLCC44
[(SA244)]	
W78LE516@TQFP44 [(SA675)]	
W78LE51C	
W78LE51C@PLCC44 [(SA244)]	W78LE51C@TQFP44
[(SA245A)]	
W78LE52	W78LE52@PLCC44
[(SA244)]	
W78LE52@TQFP44 [(SA245A)]	
W78LE52C	
W78LE52C@PLCC44 [(SA244)]	W78LE52C@TQFP44
[(SA245A)]	
W78LE54	W78LE54@PLCC44
[(SA244)]	

W78LE54@TQFP44 [(SA245A)]	
W78LE54C	
W78LE54C@PLCC44 [(SA244)]	W78LE54C@TQFP44
[(SA245A)]	
W78LE58	
[(SA244)]	W78LE58@PLCC44
W78LE58@TQFP44 [(SA245A)]	
W78LE812	
W78LE812@PLCC44 [(SA244)]	W78LE812@TQFP44
[(SA245A)]	
W79E201	
[(SA244)]	W79E201@PLCC44
W79E201@TQFP44 [(SA245A)]	W79E2051
(dip14)	
W79E2051(dip16)	W79E2051
(dip20)	
W79E2051@SOP20 [(SA404A)]	W79E2051@SSOP14
[(SA626A)]	
W79E2051@SSOP16 [(SA626A)]	W79E2051@SSOP20
[(SA626A)]	
W79E216AFG@PQFP100 [(PEP+S427)]	
W79E216AFG@PQFP100(*) [(SA741-B226)]	
W79E217AFG@PQFP100 [(PEP+S427)]	
W79E217AFG@PQFP100(*) [(SA741-B226)]	
W79E227A@LQFP48 [(SA248)]	W79E227A@PLCC44
[(SA244)]	
W79E4051(dip14)	W79E4051
(dip16)	
W79E4051(dip20)	W79E4051@SOP20
[(SA404A)]	
W79E4051@SSOP14 [(SA626A)]	W79E4051@SSOP16
[(SA626A)]	
W79E4051@SSOP20 [(SA626A)]	
W79E532	
W79E532@PLCC44 [(SA244)]	W79E532@TQFP44
[(SA245A)]	
W79E532A	W79E532A@PLCC44
[(SA244)]	
W79E532A@TQFP44 [(SA245A)]	
W79E632	
W79E632@PLCC44 [(SA244)]	W79E632@TQFP44
[(SA245A)]	
W79E633@PLCC44 [(SA244)]	W79E648A@PLCC68 [(PEP

+S414T) ]  
W79E648A@PLCC68(\*) [(SA648-B6809)]  
W79E649A@PLCC68 [(PEP+S414T)]  
W79E649A@PLCC68(\*) [(SA648-B6809)]  
W79E659A@PQFP100(\*) [(SA741-B233)]  
W79E801A W79E801A@SOIC20  
[(SA404)]  
W79E802A W79E802A@SOIC20  
[(SA404)]  
W79E803A W79E803A@SOIC20  
[(SA404)]  
W79E804A W79E804A@SOIC20  
[(SA404)]  
W79E821A W79E821A@SOIC20  
[(SA404)]  
W79E822A W79E822A@SOIC20  
[(SA404)]  
W79E822B W79E822B@SOIC20  
[(SA404)]  
W79E823A W79E823A@SOIC20  
[(SA404)]  
W79E823B W79E823B@SOIC20  
[(SA404)]  
W79E824A W79E824A@SOIC20  
[(SA404)]  
W79E825A W79E825A@SOIC20  
[(SA404)]  
W79E831A W79E831A@SOIC28  
[(SA404)]  
W79E832A W79E832A@SOIC28  
[(SA404)]  
W79E833A W79E833A@SOIC28  
[(SA404)]  
W79E834A W79E834A@SOIC28  
[(SA404)]  
W79L532 W79L532@PLCC44  
[(SA244)]  
W79L532@TQFP44 [(SA245A)]  
W79L632 W79L632@TQFP44  
W79L632@PLCC44 [(SA244)]  
[(SA245A)]  
W79L633@PLCC44 [(SA244)]  
+S414T) ]

W79L648A@PLCC68(\*) [(SA648-B6809)]  
 W79L649A@PLCC68 [(PEP+S414T)]  
 W79L649A@PLCC68(\*) [(SA648-B6809)]  
 W79L659A@PQFP100(\*) [(SA741-B233)]  
 W83L950D@TQFP80 [(PEP+S640)]  
 W83L950D@TQFP80(\*) [(TA060-B006)]  
 W83L950G@TQFP80 [(PEP+S640)]  
 W83L950G@TQFP80(\*) [(TA060-B006)]  
 W83L951D@LQFP128(\*) [(TA056-B006)]  
 W83L951DF@QFP128(\*) [(TA058-B084)]  
 W83L951DG@LQFP128(\*) [(TA056-B006)]  
 W83L951F@QFP128(\*) [(TA058-B084)]  
 W925EP01@PQFP100 [(PEP+S427)]  
 W925EP01@PQFP100(\*) [(TA041-B006)]  
 W99100DG@TQFP48 [(SA248A-B005)]

## WISTRON

### E (E) PROM/FRAM/NVRAM

MX29LV320CBB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV320CBE@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV320CBT@TSOP48 [(SA247-B005)]  
 MX29LV320CTB@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV320CTE@FBGA48 [(SA642G-B026A-T048F001Y)]  
 MX29LV320CTT@TSOP48 [(SA247-B005)]  
 MX29LV640BBT@TSOP48 [(SA247-B005)]  
 MX29LV640BBXB@FBGA63 [(SA642M-B026A-W048F001Y)]  
 MX29LV640BT@TSOP48 [(SA247-B005)]  
 MX29LV640BTT@TSOP48 [(SA247-B005)]  
 MX29LV640BTXB@FBGA63 [(SA642M-B026A-W048F001Y)]  
 MX29LV640BXB@FBGA63 [(SA642C-B026A-Y056F001)]  
 MX29LV640BXC@FBGA64 [(SA655A-B044A-T064F001)]  
 MX29LV640TT@TSOP48 [(SA247-B005)]  
 MX29LV640TXB@FBGA63 [(SA642C-B026A-Y056F001)]  
 MX29LV640TXC@FBGA64 [(SA655A-B044A-T064F001)]  
 SST25LF016A@SOIC8 [(SA602A)]                      SST25LF016A@WSON8  
 [(SA683)]  
 SST25LF016B@SOIC8 [(SA602A)]                      SST25LF016B@WSON8  
 [(SA683)]  
 SST25VF016B@SOIC8 [(SA602A)]                      SST25VF016B@WSON8  
 [(SA683)]

**MICROCONTROLLER**

CY8C21334@SSOP20 [ (SA626A) ]  
 CY8C21334@SSOP20 (ISP) [ ISP-HEADER01 ]

**WSI****E (E) PROM / FRAM / NVRAM**

WS27C010L [ (SA015A1T) ]	WS27C010L@PLCC32
WS27C010L@TSOP32 [ (SA410T) ]	
WS27C010R WS27C010R@PLCC32 [ (SA015A1T) ]	WS27C010R@TSOP32
[ (SA410T) ]	
WS27C040L [ (SA015A1T) ]	WS27C040L@PLCC32
WS27C040L@TSOP32 [ (SA410T) ]	
WS27C128F WS27C128F@PLCC32 [ (SA015A1T) ]	
WS27C128L WS27C128L@PLCC32 [ (SA015A1T) ]	
WS27C210L WS27C210L@PLCC44 [ (SA244) ]	
WS27C256F WS27C256F@PLCC32 [ (SA015A1T) ]	
WS27C256L WS27C256L@PLCC32 [ (SA015A1T) ]	
WS27C512F WS27C512F@PLCC32 [ (SA015A1T) ]	
WS27C512L WS27C512L@PLCC32 [ (SA015A1T) ]	
WS27C64 WS27C64@PLCC32 [ (SA015A1T) ]	
WS27C64F WS27C64F@PLCC32 [ (SA015A1T) ]	
WS27C64L WS27C64L@PLCC32 [ (SA015A1T) ]	
WS57C128 WS57C128@PLCC32 [ (SA015A1T) ]	

WS57C128F  
WS57C128F@PLCC32 [(SA015A1T)]  
WS57C128FB  
WS57C128FB@PLCC32 [(SA015A1T)]  
WS57C191  
WS57C191@PLCC28 [(SA008A)]  
WS57C191B  
WS57C191B@PLCC28 [(SA008A)]  
WS57C191C  
WS57C191C@PLCC28 [(SA008A)]  
WS57C256F  
WS57C256F@PLCC32 [(SA015A1T)]  
WS57C256FB  
WS57C256FB@PLCC32 [(SA015A1T)]  
WS57C257  
WS57C257@PLCC44 [(SA244)]  
WS57C291  
WS57C291@PLCC28 [(SA008A)]  
WS57C291B  
WS57C291B@PLCC28 [(SA008A)]  
WS57C291C  
WS57C291C@PLCC28 [(SA008A)]  
WS57C43  
WS57C43@PLCC28 [(SA008A)]  
WS57C43B  
WS57C43B@PLCC28 [(SA008A)]  
WS57C43C  
WS57C43C@PLCC28 [(SA008A)]  
WS57C45  
WS57C45@PLCC28 [(SA008A)]  
WS57C49  
WS57C49@PLCC28 [(SA008A)]  
WS57C49B  
WS57C49B@PLCC28 [(SA008A)]  
WS57C49C  
WS57C49C@PLCC28 [(SA008A)]  
WS57C51  
WS57C51@PLCC32 [(SA015A1T)]  
WS57C51B  
WS57C51B@PLCC32 [(SA015A1T)]  
WS57C51C  
WS57C51C@PLCC32 [(SA015A1T)]  
WS57C64F



WS57C64F@PLCC32 [(SA015A1T)]  
WS57C71C  
WS57C71C@PLCC32 [(SA015A1T)]  
WS57LV191C  
WS57LV191C@PLCC28 [(SA008A)]  
WS57LV291C  
WS57LV291C@PLCC28 [(SA008A)]

## MICROCONTROLLER

PSD211R@PLCC44 [(SA244)] [(SA245A)]	PSD211R@TQFP44
PSD301@PLCC44 [(SA244)] [(SA245A)]	PSD301@TQFP44
PSD301B@PLCC44 [(SA244)] [(SA244)]	PSD301C1@PLCC44
PSD301L@PLCC44 [(SA244)] [(SA245A)]	PSD301L@TQFP44
PSD301R@PLCC44 [(SA244)] [(SA245A)]	PSD301R@TQFP44
PSD301RV@PLCC44 [(SA244)] [(SA244)]	PSD301V@PLCC44
PSD302@PLCC44 [(SA244)] [(SA245A)]	PSD302@TQFP44
PSD302B@PLCC44 [(SA244)] [(SA411A)]	PSD302B@PLCC44 (USA)
PSD302C1@PLCC44 [(SA244)] [(SA244)]	PSD302L@PLCC44
PSD302L@TQFP44 [(SA245A)] [(SA244)]	PSD302R@PLCC44
PSD302R@TQFP44 [(SA245A)] [(SA244)]	PSD302RV@PLCC44
PSD302V@PLCC44 [(SA244)] [(SA244)]	PSD303@PLCC44
PSD303@TQFP44 [(SA245A)] [(SA244)]	PSD303C1@PLCC44
PSD303L@PLCC44 [(SA244)] [(SA245A)]	PSD303L@TQFP44
PSD303R@PLCC44 [(SA244)] [(SA245A)]	PSD303R@TQFP44
PSD303RV@PLCC44 [(SA244)] [(SA244)]	PSD303V@PLCC44

PSD311@PLCC44 [(SA244)]	PSD311@TQFP44
[(SA245A)]	
PSD311B@PLCC44 [(SA244)]	PSD311C1@PLCC44
[(SA244)]	
PSD311L@PLCC44 [(SA244)]	PSD311L@TQFP44
[(SA245A)]	
PSD311R@PLCC44 [(SA244)]	PSD311R@TQFP44
[(SA245A)]	
PSD311RV@PLCC44 [(SA244)]	PSD311V@PLCC44
[(SA244)]	
PSD312@PLCC44 [(SA244)]	PSD312@TQFP44
[(SA245A)]	
PSD312B@PLCC44 [(SA244)]	PSD312C1@PLCC44
[(SA244)]	
PSD312L@PLCC44 [(SA244)]	PSD312L@TQFP44
[(SA245A)]	
PSD312R@PLCC44 [(SA244)]	PSD312R@TQFP44
[(SA245A)]	
PSD312RV@PLCC44 [(SA244)]	PSD312V@PLCC44
[(SA244)]	
PSD313@PLCC44 [(SA244)]	PSD313@TQFP44
[(SA245A)]	
PSD313-B@PLCC44 [(SA244)]	PSD313-B@TQFP44
[(SA245A)]	
PSD313C1@PLCC44 [(SA244)]	PSD313L@PLCC44
[(SA244)]	
PSD313L@TQFP44 [(SA245A)]	PSD313R@PLCC44
[(SA244)]	
PSD313R@TQFP44 [(SA245A)]	PSD313RV@PLCC44
[(SA244)]	
PSD313V@PLCC44 [(SA244)]	PSD813F1@PLCC52 [(PEP
+S415T)]	
PSD813F1@TQFP52 [(PEP+S662)]	
PSD813F1@TQFP52(*) [(TA071+B006)]	
PSD813F1A@PLCC52 [(PEP+S415T)]	PSD813F1V@PLCC52 [(PEP
+S415T)]	
PSD813F1V@TQFP52 [(PEP+S662)]	
PSD813F1V@TQFP52(*) [(TA071+B006)]	
PSD813F1VA@PLCC52 [(PEP+S415T)]	PSD813F2@PLCC52 [(PEP
+S415T)]	
PSD813F2@TQFP52 [(PEP+S662)]	
PSD813F2@TQFP52(*) [(TA071+B006)]	
PSD813F2A@PLCC52 [(PEP+S415T)]	PSD813F2V@PLCC52 [(PEP

+S415T) ]  
PSD813F2V@TQFP52 [(PEP+S662)]  
PSD813F2V@TQFP52(\*) [(TA071+B006)]  
PSD813F2VA@PLCC52 [(PEP+S415T)] PSD813F3@PLCC52 [(PEP  
+S415T)]  
PSD813F3@TQFP52 [(PEP+S662)]  
PSD813F3@TQFP52(\*) [(TA071+B006)]  
PSD813F3V@PLCC52 [(PEP+S415T)] PSD813F3V@TQFP52 [(PEP  
+S662)]  
PSD813F3V@TQFP52(\*) [(TA071+B006)]  
PSD813F4@PLCC52 [(PEP+S415T)] PSD813F4@TQFP52 [(PEP  
+S662)]  
PSD813F4@TQFP52(\*) [(TA071+B006)]  
PSD813F4V@PLCC52 [(PEP+S415T)] PSD813F4V@TQFP52 [(PEP  
+S662)]  
PSD813F4V@TQFP52(\*) [(TA071+B006)]  
PSD813F5@PLCC52 [(PEP+S415T)] PSD813F5@TQFP52 [(PEP  
+S662)]  
PSD813F5@TQFP52(\*) [(TA071+B006)]  
PSD813F5V@PLCC52 [(PEP+S415T)] PSD813F5V@TQFP52 [(PEP  
+S662)]  
PSD813F5V@TQFP52(\*) [(TA071+B006)]  
PSD833F2@PLCC52 [(PEP+S415T)] PSD833F2@PQFP52 [(PEP  
+S662)]  
PSD833F2@TQFP52(\*) [(TA071+B006)]  
PSD833F2V@PLCC52 [(PEP+S415T)] PSD833F2V@TQFP52 [(PEP  
+S662)]  
PSD833F2V@TQFP52(\*) [(TA071+B006)]  
PSD834F2@PLCC52 [(PEP+S415T)] PSD834F2@TQFP52 [(PEP  
+S662)]  
PSD834F2V@PLCC52 [(PEP+S415T)] PSD834F2V@TQFP52 [(PEP  
+S662)]  
PSD853F2@PLCC52 [(PEP+S415T)] PSD853F2@PQFP52 [(PEP  
+S662)]  
PSD853F2@TQFP52(\*) [(TA071+B006)]  
PSD853F2V@PLCC52 [(PEP+S415T)] PSD853F2V@TQFP52 [(PEP  
+S662)]  
PSD853F2V@TQFP52(\*) [(TA071+B006)]  
PSD854F2@PLCC52 [(PEP+S415T)] PSD854F2@TQFP52 [(PEP  
+S662)]  
PSD854F2V@PLCC52 [(PEP+S415T)] PSD854F2V@TQFP52 [(PEP  
+S662)]  
ZPSD211R@PLCC44 [(SA244)] ZPSD211R@TQFP44

[ (SA245A) ]	
ZPSD211RV@PLCC44 [ (SA244) ]	ZPSD211RV@TQFP44
[ (SA245A) ]	
ZPSD301@PLCC44 [ (SA244) ]	ZPSD301@TQFP44
[ (SA245A) ]	
ZPSD301L@PLCC44 [ (SA244) ]	ZPSD301L@TQFP44
[ (SA245A) ]	
ZPSD301R@PLCC44 [ (SA244) ]	ZPSD301R@TQFP44
[ (SA245A) ]	
ZPSD301RL@PLCC44 [ (SA244) ]	ZPSD301RL@TQFP44
[ (SA245A) ]	
ZPSD301RV@PLCC44 [ (SA244) ]	ZPSD301RV@TQFP44
[ (SA245A) ]	
ZPSD301V@PLCC44 [ (SA244) ]	ZPSD301V@TQFP44
[ (SA245A) ]	
ZPSD302@PLCC44 [ (SA244) ]	ZPSD302@TQFP44
[ (SA245A) ]	
ZPSD302B@PLCC44 [ (SA244) ]	ZPSD302B@PLCC44 (USA)
[ (SA411A) ]	
ZPSD302L@PLCC44 [ (SA244) ]	ZPSD302L@TQFP44
[ (SA245A) ]	
ZPSD302R@PLCC44 [ (SA244) ]	ZPSD302R@TQFP44
[ (SA245A) ]	
ZPSD302RL@PLCC44 [ (SA244) ]	ZPSD302RL@TQFP44
[ (SA245A) ]	
ZPSD302RV@PLCC44 [ (SA244) ]	ZPSD302RV@TQFP44
[ (SA245A) ]	
ZPSD302V@PLCC44 [ (SA244) ]	ZPSD302V@TQFP44
[ (SA245A) ]	
ZPSD303@PLCC44 [ (SA244) ]	ZPSD303@TQFP44
[ (SA245A) ]	
ZPSD303L@PLCC44 [ (SA244) ]	ZPSD303L@TQFP44
[ (SA245A) ]	
ZPSD303R@PLCC44 [ (SA244) ]	ZPSD303R@TQFP44
[ (SA245A) ]	
ZPSD303RL@PLCC44 [ (SA244) ]	ZPSD303RL@TQFP44
[ (SA245A) ]	
ZPSD303RV@PLCC44 [ (SA244) ]	ZPSD303RV@TQFP44
[ (SA245A) ]	
ZPSD303V@PLCC44 [ (SA244) ]	ZPSD303V@TQFP44
[ (SA245A) ]	
ZPSD311@PLCC44 [ (SA244) ]	ZPSD311@TQFP44
[ (SA245A) ]	

ZPSD311L@PLCC44 [(SA244)]	ZPSD311L@TQFP44
[(SA245A)]	
ZPSD311R@PLCC44 [(SA244)]	ZPSD311R@TQFP44
[(SA245A)]	
ZPSD311RL@PLCC44 [(SA244)]	ZPSD311RL@TQFP44
[(SA245A)]	
ZPSD311RV@PLCC44 [(SA244)]	ZPSD311RV@TQFP44
[(SA245A)]	
ZPSD311V@PLCC44 [(SA244)]	ZPSD311V@TQFP44
[(SA245A)]	
ZPSD312@PLCC44 [(SA244)]	ZPSD312@TQFP44
[(SA245A)]	
ZPSD312B@PLCC44 [(SA244)]	ZPSD312L@PLCC44
[(SA244)]	
ZPSD312L@TQFP44 [(SA245A)]	ZPSD312R@PLCC44
[(SA244)]	
ZPSD312R@TQFP44 [(SA245A)]	ZPSD312RL@PLCC44
[(SA244)]	
ZPSD312RL@TQFP44 [(SA245A)]	ZPSD312RV@PLCC44
[(SA244)]	
ZPSD312RV@TQFP44 [(SA245A)]	ZPSD312V@PLCC44
[(SA244)]	
ZPSD312V@TQFP44 [(SA245A)]	ZPSD313@PLCC44
[(SA244)]	
ZPSD313@TQFP44 [(SA245A)]	ZPSD313L@PLCC44
[(SA244)]	
ZPSD313L@TQFP44 [(SA245A)]	ZPSD313R@PLCC44
[(SA244)]	
ZPSD313R@TQFP44 [(SA245A)]	ZPSD313RL@PLCC44
[(SA244)]	
ZPSD313RL@TQFP44 [(SA245A)]	ZPSD313RV@PLCC44
[(SA244)]	
ZPSD313RV@TQFP44 [(SA245A)]	ZPSD313V@PLCC44
[(SA244)]	
ZPSD313V@TQFP44 [(SA245A)]	ZPSD813F2@PLCC52 [(PEP
+S415T)]	
ZPSD813F4@PLCC52 [(PEP+S415T)]	

## **XELTEK**

### **E ( E ) PROM / FRAM / NVRAM**

S29GL128PFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PTAI01@TSOP56 [(SA628-B102)]  
S29GL256PFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PTAI01@TSOP56 [(SA628-B102)]

**MICROCONTROLLER**

#####1111111111111111  
#####2222222222222222  
#####3333333333333333  
#####4444444444444444  
#####9999999999999999 ATMEGA168@TQFP32  
[(SA636)]  
ATMEGA48@TQFP32 [(SA636)] ATMEGA88@TQFP32  
[(SA636)]  
ATMEGA8L(fast)@TQFP32 [(SA636)] ATMEGA8L@TQFP32  
[(SA636)]  
MK68F15P MK68F15S@SOP18  
[(SA023A)]  
MK68F15X@SSOP20 [(SA674)]  
MK68F30K  
MK68F30S@SOP28 [(SA404)] MK68F30X@SSOP28  
[(SA626A)]  
ST7FLI49MK1B6@SDIP32 [(SA653)] ST7FLI49MK1T6@TQFP32  
[(SA663)]  
ST7FLITE49 ST7FLITE49@TQFP32  
[(SA663)]

**XICOR**

**E (E) PROM/FRAM/NVRAM**

X2004 X2004@PLCC32  
[(SA015A1T)]  
X2004D X2004D@PLCC32  
[(SA015A1T)]  
X2004I X2004I@PLCC32  
[(SA015A1T)]  
X2210 X2210@SOIC16  
[(SA404)]  
X2210A X2210A@SOIC16

[ (SA404) ]	
X2210I	X2210I@SOIC16
[ (SA404) ]	
X2212	X2212@SOIC20
[ (SA404) ]	
X2212A	X2212A@SOIC20
[ (SA404) ]	
X2212I	X2212I@SOIC20
[ (SA404) ]	
X22C10	X22C10@SOIC16
[ (SA404) ]	
X22C10I	X22C10I@SOIC16
[ (SA404) ]	
X22C12	X22C12@SOIC20
[ (SA404) ]	
X22C12I	X22C12I@SOIC20
[ (SA404) ]	
X24012	X24012@SOIC8
[ (SA602A) ]	
X24022	X24022@SOIC8
[ (SA602A) ]	
X24026	X24026@SOIC8
[ (SA602A) ]	
X24042	X24042@SOIC8
[ (SA602A) ]	
X24164	X24164@SOIC8
[ (SA602A) ]	
X24165	X24165@SOIC8
[ (SA602A) ]	
X24325	X24325@SOIC8
[ (SA602A) ]	
X24645	X24645@SOIC8
[ (SA602A) ]	
X24C01	X24C01@MSOP8
[ (SA666) ]	
X24C01@SOIC8 [ (SA602A) ]	
X24C01A	
X24C01A@SOIC8 [ (SA602A) ]	
X24C01I	
X24C01I@SOIC8 [ (SA602A) ]	
X24C02	
X24C02@SOIC8 [ (SA602A) ]	
X24C02I	

X24C02I@SOIC8 [(SA602A)]	
X24C04	
X24C04@SOIC14 [(SA602)]	X24C04@SOIC8
[(SA602A)]	
X24C04I	
[(SA602)]	X24C04I@SOIC14
X24C04I@SOIC8 [(SA602A)]	
X24C08	
X24C08@SOIC14 [(SA602)]	X24C08@SOIC8
[(SA602A)]	
X24C08I	
[(SA602)]	X24C08I@SOIC14
X24C08I@SOIC8 [(SA602A)]	
X24C16	
X24C16@SOIC14 [(SA602)]	X24C16@SOIC8
[(SA602A)]	
X24C16I	
[(SA602)]	X24C16I@SOIC14
X24C16I@SOIC8 [(SA602A)]	
X24C44	
X24C44@SOIC8 [(SA602A)]	
X24C44I	
X24C44I@SOIC8 [(SA602A)]	
X24C45	
X24C45@SOIC8 [(SA602A)]	
X24C45I	
X24C45I@SOIC8 [(SA602A)]	X24F008
(3V)	
X24F008(3V)@SOIC8 [(SA602A)]	X24F008(3V)@TSSOP14
[(SA602)]	
X24F008(5V)	
[(SA602A)]	X24F008(5V)@SOIC8
X24F008(5V)@TSSOP14 [(SA602)]	
(3V)	X24F016
X24F016(3V)@SOIC8 [(SA602A)]	X24F016(3V)@TSSOP14
[(SA602)]	
X24F016(5V)	
[(SA602A)]	X24F016(5V)@SOIC8
X24F016(5V)@TSSOP14 [(SA602)]	
(3V)	X24F032
X24F032(3V)@SOIC8 [(SA602A)]	X24F032(3V)@TSSOP14
[(SA602)]	
X24F032(5V)	X24F032(5V)@SOIC8



[ (SA602A) ]	
X24F032(5V)@TSSOP14 [ (SA602) ]	X24F064
(3V)	
X24F064(3V)@SOIC8 [ (SA602A) ]	X24F064(3V)@TSSOP20
[ (SA404) ]	
X24F064(5V)	X24F064(5V)@SOIC8
[ (SA602A) ]	
X24F064(5V)@TSSOP20 [ (SA404) ]	
X25020	
X25020@SOIC8 [ (SA602A) ]	
X25021	
X25021@SOIC8 [ (SA602A) ]	
X25040	
X25040@SOIC8 [ (SA602A) ]	
X25041	
X25041@SOIC8 [ (SA602A) ]	
X25043	
X25043@MSOP8 [ (SA666) ]	X25043@SOIC8
[ (SA602A) ]	
X25043@TSSOP14 [ (SA026) ]	
X25045	
X25045@MSOP8 [ (SA666) ]	X25045@SOIC8
[ (SA602A) ]	
X25045@TSSOP14 [ (SA026) ]	X25057@MSOP8
[ (SA666) ]	
X25057@TSSOP8 [ (SA026) ]	
X25080	
X25080@SOIC8 [ (SA602A) ]	X25080@TSSOP14
[ (SA026) ]	
X25097@MSOP8 [ (SA666) ]	X25097@SOIC8
[ (SA602A) ]	
X25097@TSSOP8 [ (SA026) ]	
X25128	
X25128@SOIC16 [ (SA602) ]	
X25138	
X25138@SOIC14 [ (SA602) ]	X25138@SOIC16
[ (SA602) ]	
X25138@SOIC8 [ (SA602A) ]	X25138@TSSOP8
[ (SA026) ]	
X25160	X25160@SOIC8
[ (SA602A) ]	
X25160@TSSOP14 [ (SA026) ]	
X25163	

X25163@SOIC8 [(SA602A)]	X25163@TSSOP14
[(SA026)]	
X25164	X25164@SOIC8
[(SA602A)]	
X25164@TSSOP14 [(SA026)]	
X25165	
X25165@SOIC8 [(SA602A)]	X25165@TSSOP14
[(SA026)]	
X25166	X25166@SOIC8
[(SA602A)]	
X25166@TSSOP14 [(SA026)]	
X25168	
X25168@SOIC8 [(SA602A)]	X25168@TSSOP14
[(SA026)]	
X25169	X25169@SOIC8
[(SA602A)]	
X25169@TSSOP14 [(SA026)]	
X25256	
X25256@SOIC8 [(SA602A)]	X25256@TSSOP20
[(SA026)]	
X25320	X25320@SOIC8
[(SA602A)]	
X25323@SOIC8 [(SA602A)]	X25323@TSSOP14
[(SA026)]	
X25324@SOIC8 [(SA602A)]	X25324@TSSOP14
[(SA026)]	
X25325@SOIC8 [(SA602A)]	X25325@TSSOP14
[(SA026)]	
X25326@SOIC8 [(SA602A)]	X25328@SOIC8
[(SA602A)]	
X25328@TSSOP14 [(SA026)]	X25329@SOIC8
[(SA602A)]	
X25329@TSSOP14 [(SA026)]	X25330@SOIC8
[(SA602A)]	
X25330@TSSOP14 [(SA026)]	
X25401	
X25401@SOIC8 [(SA602A)]	
X25640	
X25640@SOIC14 [(SA602)]	
X25642	
X25642@SOIC14 [(SA602)]	X25642@SOIC8
[(SA602A)]	
X25642@TSSOP20 [(SA026)]	X25643@SOIC14

[ (SA602) ]	
X25644@SOIC14 [ (SA602) ]	
X25645	
X25645@SOIC14 [ (SA602) ]	X25645@SOIC8
[ (SA602A) ]	
X25645@TSSOP20 [ (SA026) ]	X25648@SOIC14
[ (SA602) ]	
X25649@SOIC14 [ (SA602) ]	
X25650	
X25650@SOIC14 [ (SA602) ]	X25650@SOIC8
[ (SA602A) ]	
X25650@TSSOP20 [ (SA026) ]	
X25C02	
X25C02@SOIC8 [ (SA602A) ]	X25C02@TSSOP8
[ (SA026) ]	
X25F008 (3V)	X25F008 (3V)@SOIC8
[ (SA602A) ]	
X25F008 (3V)@TSSOP14 [ (SA602) ]	X25F008 (3V)@TSSOP20
[ (SA404) ]	
X25F008 (5V)	X25F008 (5V)@SOIC8
[ (SA602A) ]	
X25F008 (5V)@TSSOP14 [ (SA602) ]	X25F008 (5V)@TSSOP20
[ (SA404) ]	
X25F016 (3V)	X25F016 (3V)@SOIC8
[ (SA602A) ]	
X25F016 (3V)@TSSOP14 [ (SA602) ]	X25F016 (3V)@TSSOP20
[ (SA404) ]	
X25F016 (5V)	X25F016 (5V)@SOIC8
[ (SA602A) ]	
X25F016 (5V)@TSSOP14 [ (SA602) ]	X25F016 (5V)@TSSOP20
[ (SA404) ]	
X25F032 (3V)	X25F032 (3V)@SOIC8
[ (SA602A) ]	
X25F032 (3V)@TSSOP14 [ (SA602) ]	X25F032 (3V)@TSSOP20
[ (SA404) ]	
X25F032 (5V)	X25F032 (5V)@SOIC8
[ (SA602A) ]	
X25F032 (5V)@TSSOP14 [ (SA602) ]	X25F032 (5V)@TSSOP20
[ (SA404) ]	
X25F047 (3V)	X25F047 (3V)@MSOP8
[ (SA666) ]	
X25F047 (3V)@SOIC8 [ (SA602A) ]	X25F047 (3V)@TSSOP8
[ (SA026) ]	

X25F047(5V) [(SA666)]	X25F047(5V)@MSOP8
X25F047(5V)@SOIC8 [(SA602A)] [(SA026)]	X25F047(5V)@TSSOP8
X25F064(3V) [(SA602A)]	X25F064(3V)@SOIC8
X25F064(3V)@TSSOP14 [(SA602)] [(SA404)]	X25F064(3V)@TSSOP20
X25F064(5V) [(SA602A)]	X25F064(5V)@SOIC8
X25F064(5V)@TSSOP14 [(SA602)] [(SA404)]	X25F064(5V)@TSSOP20
X25F087(3V) [(SA666)]	X25F087(3V)@MSOP8
X25F087(3V)@SOIC8 [(SA602A)] [(SA026)]	X25F087(3V)@TSSOP8
X25F087(5V) [(SA666)]	X25F087(5V)@MSOP8
X25F087(5V)@SOIC8 [(SA602A)] [(SA026)]	X25F087(5V)@TSSOP8
X25F128(3V) [(SA602)]	X25F128(3V)@SOIC16
X25F128(5V) [(SA602)]	X25F128(5V)@SOIC16
X28010 [(SA015A1T)]	X28010@PLCC32
X28010@TSOP32 [(SA410T)]	
X2804A X2804A(I) (MB)	X2804A
X2816A [(SA015A1T)]	X2816A@PLCC32
X2816B [(SA015A1T)]	X2816B@PLCC32
X2816BI [(SA015A1T)]	X2816BI@PLCC32
X2816BMB X2816C X2816C@PLCC32 [(SA015A1T)]	
X28256 X28256@PLCC32 [(SA015A1T)]	
X28256I X28256I@PLCC32 [(SA015A1T)]	

X2864A	
X2864A(I)	X2864A(I)@PLCC32
[(SA015A1T)]	
X2864A(M)	X2864A(M)@PLCC32
[(SA015A1T)]	
X2864A(MB)	X2864A(MB)@PLCC32
[(SA015A1T)]	
X2864A(T)	X2864A(T)@PLCC32
[(SA015A1T)]	
X2864A@PLCC32 [(SA015A1T)]	
X2864B	
X2864B(I)	X2864B(I)@PLCC32
[(SA015A1T)]	
X2864B(M)	X2864B(M)@PLCC32
[(SA015A1T)]	
X2864B@PLCC32 [(SA015A1T)]	
X2864H	
X2864H(I)	X2864H(I)@PLCC32
[(SA015A1T)]	
X2864H@PLCC32 [(SA015A1T)]	
X28C010	
X28C010@PLCC32 [(SA015A1T)]	
X28C16A	
X28C16A@PLCC32 [(SA015A1T)]	
X28C16B	
X28C16B@PLCC32 [(SA015A1T)]	
X28C16C	
X28C16C@PLCC32 [(SA015A1T)]	
X28C256	
X28C256@PLCC32 [(SA015A1T)]	X28C256@TSOP28
[(SA430T)]	
X28C512	X28C512@PLCC32
[(SA015A1T)]	
X28C513	X28C513@PLCC32
[(SA015A1T)]	
X28C64	X28C64@PLCC32
[(SA015A1T)]	
X28C64@SOIC28 [(SA404)]	X28C64@TSOP28
[(SA430T)]	
X28HC16	X28HC16@PLCC32
[(SA015A1T)]	
X28HC16@SOIC24 [(SA404)]	
X28HC256	

X28HC256@PLCC32 [(SA015A1T)]	X28HC256@TSOP28
[(SA430T)]	
X28HC64	X28HC64@PLCC32
[(SA015A1T)]	
X28HC64@SOIC28 [(SA404)]	X28HC64@TSOP28
[(SA430T)]	
X28LC512	X28LC512@PLCC32
[(SA015A1T)]	
X28LC513	X28LC513@PLCC32
[(SA015A1T)]	
X28VC256	X28VC256@PLCC32
[(SA015A1T)]	
X28VC256@TSOP28 [(SA430T)]	X40231@SOIC16
[(SA404)]	
X40233@SOIC16 [(SA404)]	X40235@SOIC16
[(SA404)]	
X40237@SOIC16 [(SA404)]	X40239@SOIC16
[(SA404)]	
X40430@SOIC14 [(SA404)]	X40430@TSSOP14
[(SA026)]	
X40431@SOIC14 [(SA404)]	X40431@TSSOP14
[(SA026)]	
X40434@SOIC14 [(SA404)]	X40434@TSSOP14
[(SA026)]	
X40435@SOIC14 [(SA404)]	X40435@TSSOP14
[(SA026)]	
X4C105@TSSOP20 [(SA026)]	
X5043	
X5043@MSOP8 [(SA666)]	X5043@SOIC8
[(SA602A)]	
X5043@TSSOP14 [(SA026)]	
X5045	
X5045@MSOP8 [(SA666)]	X5045@SOIC8
[(SA602A)]	
X5045@TSSOP14 [(SA026)]	
X5083	
X5083@SOIC8 [(SA602A)]	X5083@TSSOP8
[(SA026)]	
X5163	X5163@SOIC8
[(SA602A)]	
X5163@TSSOP14 [(SA026)]	
X51638	
X51638@SOIC8 [(SA602A)]	X51638@TSSOP14

[(SA026)]	
X5165	X5165@SOIC8
[(SA602A)]	
X5165@TSSOP14 [(SA026)]	
X5168	
X5168@SOIC8 [(SA602A)]	X5168@TSSOP14
[(SA026)]	
X5169	X5169@SOIC8
[(SA602A)]	
X5169@TSSOP14 [(SA026)]	
X5323	
X5323@SOIC8 [(SA602A)]	X5323@TSSOP14
[(SA026)]	
X5325	X5325@SOIC8
[(SA602A)]	
X5325@TSSOP14 [(SA026)]	
X5328	
X5328@SOIC8 [(SA602A)]	X5328@TSSOP14
[(SA026)]	
X5329	X5329@SOIC8
[(SA602A)]	
X5329@TSSOP14 [(SA026)]	
X5643	
X5643@SOIC14 [(SA602)]	X5643@SOIC8
[(SA602A)]	
X5643@TSSOP20 [(SA026)]	
X5645	
X5645@SOIC14 [(SA602)]	X5645@SOIC8
[(SA602A)]	
X5645@TSSOP20 [(SA026)]	
X5648	
X5648@SOIC14 [(SA602)]	
X5649	
X5649@SOIC14 [(SA602)]	
X76F041	
X76F041(3)	X76F041(3)@SOIC8
[(SA605)]	
X76F041@SOIC8 [(SA605)]	
X76F101	
X76F101@SOIC8 [(SA602A)]	X76F400@SOIC8
[(SA602A)]	
X76F400@TSSOP8 [(SA026)]	
X84041	

X84041@SOIC14 [(SA602)]	X84041@SOIC8
[(SA602A)]	
X84047	X84047@TSSOP8
[(SA026)]	
X84087	X84087@TSSOP8
[(SA026)]	
X84128	X84128@SOIC14
[(SA602)]	
X84128@TSSOP28 [(SA643)]	X84128@XBGA8
[(SA683)]	
X84129	X84129@SOIC16
[(SA602)]	
X84160	X84160@SOIC8
[(SA602A)]	
X84160@TSSOP8 [(SA026)]	
X84161	
X84161@SOIC8 [(SA602A)]	X84161@TSSOP8
[(SA026)]	
X84256	X84256@SOIC8
[(SA602A)]	
X84256@TSSOP14 [(SA026)]	X84256@XBGA8
[(SA683)]	
X84640	X84640@SOIC8
[(SA602A)]	
X84640@TSSOP20 [(SA026)]	X84640@XBGA8
[(SA683)]	
X84641	X84641@SOIC8
[(SA602A)]	
X84641@TSSOP20 [(SA026)]	X84641@XBGA8
[(SA683)]	
XD2210	XD2210@SOIC16
[(SA404)]	
XM28C010	
XM28C020	
XM28C040	

## **XILINX**

### **E(E) PROM/FRAM/NVRAM**

XC1701	XC1701@PLCC20
[(SA001A)]	



XC1701@PLCC44 [(SA244)]	XC1701@SOIC20
[(SA404)]	
XC1701L	XC1701L@PLCC20
[(SA001A)]	
XC1701L@PLCC44 [(SA244)]	XC1701L@SOIC20
[(SA404)]	
XC1702L@PLCC44 [(SA244)]	XC1702L@TQFP44
[(SA245A)]	
XC1704L@PLCC44 [(SA244)]	XC1704L@TQFP44
[(SA245A)]	
XC17128	XC17128@SOIC8
[(SA602A)]	
XC17128D	XC17128D@PLCC20
[(SA001A)]	
XC17128D@SOIC8 [(SA602A)]	XC17128D@VOIC8
[(SA602A)]	
XC17128E	XC17128E@PLCC20
[(SA001A)]	
XC17128E@VOIC8 [(SA602A)]	
XC17128EL	
XC17128EL@PLCC20 [(SA001A)]	XC17128EL@VOIC8
[(SA602A)]	
XC17128L	XC17128L@PLCC20
[(SA001A)]	
XC17128L@SOIC8 [(SA602A)]	XC17128L@VOIC8
[(SA602A)]	
XC17128X	XC17128X@PLCC20
[(SA001A)]	
XC17128X@SOIC8 [(SA602A)]	XC17128X@VOIC8
[(SA602A)]	
XC1718D	XC1718D@PLCC20
[(SA001A)]	
XC1718D@SOIC8 [(SA602A)]	XC1718D@VOIC8
[(SA602A)]	
XC1718L	XC1718L@PLCC20
[(SA001A)]	
XC1718L@SOIC8 [(SA602A)]	XC1718L@VOIC8
[(SA602A)]	
XC17256D	XC17256D@PLCC20
[(SA001A)]	
XC17256D@SOIC8 [(SA602A)]	XC17256D@VOIC8
[(SA602A)]	
XC17256E	XC17256E@PLCC20

[(SA001A)]	
XC17256E@VOIC8 [(SA602A)]	
XC17256EL	
XC17256EL@PLCC20 [(SA001A)]	XC17256EL@VOIC8
[(SA602A)]	
XC17256L	
[(SA001A)]	XC17256L@PLCC20
XC17256L@SOIC8 [(SA602A)]	
[(SA602A)]	XC17256L@VOIC8
XC17256X	
[(SA001A)]	XC17256X@PLCC20
XC17256X@SOIC8 [(SA602A)]	
[(SA602A)]	XC17256X@VOIC8
XC1736	
[(SA602A)]	XC1736@SOIC8
XC1736A	
[(SA602A)]	XC1736A@SOIC8
XC1736D	
[(SA001A)]	XC1736D@PLCC20
XC1736D@SOIC8 [(SA602A)]	
[(SA602A)]	XC1736D@VOIC8
XC1736E	
[(SA001A)]	XC1736E@PLCC20
XC1736E@SOIC8 [(SA602A)]	
[(SA602A)]	XC1736E@VOIC8
XC17512L	
[(SA001A)]	XC17512L@PLCC20
XC17512L@PLCC44 [(SA244)]	
[(SA404)]	XC17512L@SOIC20
XC1765	
[(SA602A)]	XC1765@SOIC8
XC1765D	
[(SA001A)]	XC1765D@PLCC20
XC1765D@SOIC8 [(SA602A)]	
[(SA602A)]	XC1765D@VOIC8
XC1765E	
[(SA001A)]	XC1765E@PLCC20
XC1765E@SOIC8 [(SA602A)]	
[(SA602A)]	XC1765E@VOIC8
XC1765EL	
[(SA001A)]	XC1765EL@PLCC20
XC1765EL@SOIC8 [(SA602A)]	
[(SA602A)]	XC1765EL@VOIC8

XC1765L [ (SA001A) ]	XC1765L@PLCC20
XC1765L@SOIC8 [ (SA602A) ] [ (SA602A) ]	XC1765L@VOIC8
XC1765X [ (SA001A) ]	XC1765X@PLCC20
XC1765X@SOIC8 [ (SA602A) ] [ (SA602A) ]	XC1765X@VOIC8
XC17S05 [ (SA602A) ]	XC17S05@SOIC8
XC17S05XL(L) [ (SA602A) ]	XC17S05XL(L)@SOIC8
XC17S10 [ (SA602A) ]	XC17S10@SOIC8
XC17S100A [ (SA404) ]	XC17S100A@SOIC20
XC17S100A@SOIC8 [ (SA602A) ] (L)	XC17S100XL
XC17S100XL(L)@SOIC20 [ (SA404) ] (L)	XC17S10XL
XC17S10XL(L)@SOIC8 [ (SA602A) ]	
XC17S150A XC17S150A@SOIC20 [ (SA404) ] [ (SA602A) ]	XC17S150A@SOIC8
XC17S150XL(L) [ (SA404) ]	XC17S150XL(L)@SOIC20
XC17S15A [ (SA404) ]	XC17S15A@SOIC20
XC17S15A@SOIC8 [ (SA602A) ]	
XC17S20 XC17S20@SOIC8 [ (SA602A) ]	
XC17S200A XC17S200A@SOIC8 [ (SA602A) ] [ (SA245A) ]	XC17S200A@TQFP44
XC17S20XL(L) [ (SA602A) ]	XC17S20XL(L)@SOIC8
XC17S30 [ (SA602A) ]	XC17S30@SOIC8
XC17S300A@TQFP44 [ (SA245A) ]	
XC17S30A XC17S30A@SOIC20 [ (SA404) ] [ (SA602A) ]	XC17S30A@SOIC8
XC17S30XL(L)	XC17S30XL(L)@SOIC8

[ (SA602A) ]	
XC17S40	XC17S40@SOIC20
[ (SA404) ]	
XC17S40XL(L)	XC17S40XL(L)@SOIC20
[ (SA404) ]	
XC17S50A	XC17S50A@SOIC20
[ (SA404) ]	
XC17S50A@SOIC8 [ (SA602A) ]	XC17S50XL
(L)	
XC17S50XL(L)@SOIC20 [ (SA404) ]	XC17V01@PLCC20
[ (SA001A) ]	
XC17V01@SOIC20 [ (SA404) ]	XC17V01@SOIC8
[ (SA602A) ]	
XC17V02@PLCC20 [ (SA001A) ]	XC17V02@PLCC44
[ (SA244) ]	
XC17V02@TQFP44 [ (SA245A) ]	XC17V04@PLCC20
[ (SA001A) ]	
XC17V04@PLCC44 [ (SA244) ]	XC17V04@TQFP44
[ (SA245A) ]	
XC17V08@PLCC44 [ (SA244) ]	XC17V08@TQFP44
[ (SA245A) ]	
XC17V16@PLCC44 [ (SA244) ]	XC17V16@TQFP44
[ (SA245A) ]	
XC18V01@PLCC20 [ (SA001A) ]	XC18V01@SOIC20
[ (SA404) ]	
XC18V01@TQFP44 [ (SA245A) ]	XC18V02@PLCC44
[ (SA244) ]	
XC18V02@TQFP44 [ (SA245A) ]	XC18V04@PLCC44
[ (SA244) ]	
XC18V04@TQFP44 [ (SA245A) ]	XC18V256@PLCC20
[ (SA001A) ]	
XC18V256@SOIC20 [ (SA404) ]	XC18V256@TQFP44
[ (SA245A) ]	
XC18V512@PLCC20 [ (SA001A) ]	XC18V512@SOIC20
[ (SA404) ]	
XC18V512@TQFP44 [ (SA245A) ]	XCF01S(VO)@TSSOP20
[ (SA026) ]	
XCF01S(VOG)@TSSOP20 [ (SA026) ]	XCF02S(VO)@TSSOP20
[ (SA026) ]	
XCF02S(VOG)@TSSOP20 [ (SA026) ]	XCF04S(VO)@TSSOP20
[ (SA026) ]	
XCF04S(VOG)@TSSOP20 [ (SA026) ]	
XCF08P(FS)@FBGA48 [ (SA642E-B026A-T072F001N) ]	

XCF08P(FS)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]  
 XCF08P(FSG)@FBGA48 [(SA642E-B026A-T072F001N)]  
 XCF08P(FSG)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]  
 XCF08P(VO)@TSOP48 [(SA247-B005)]  
 XCF08P(VO)@TSOP48(ISP) [ISP-HEADER01]  
 XCF08P(VOG)@TSOP48 [(SA247-B005)]  
 XCF08P(VOG)@TSOP48(ISP) [ISP-HEADER01]  
 XCF16P(FS)@FBGA48 [(SA642E-B026A-T072F001N)]  
 XCF16P(FS)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]  
 XCF16P(FSG)@FBGA48 [(SA642E-B026A-T072F001N)]  
 XCF16P(FSG)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]  
 XCF16P(VO)@TSOP48 [(SA247-B005)]  
 XCF16P(VO)@TSOP48(ISP) [ISP-HEADER01]  
 XCF16P(VOG)@TSOP48 [(SA247-B005)]  
 XCF16P(VOG)@TSOP48(ISP) [ISP-HEADER01]  
 XCF32P(FS)@FBGA48 [(SA642E-B026A-T072F001N)]  
 XCF32P(FS)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]  
 XCF32P(FSG)@FBGA48 [(SA642E-B026A-T072F001N)]  
 XCF32P(FSG)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]  
 XCF32P(VO)@TSOP48 [(SA247-B005)]  
 XCF32P(VO)@TSOP48(ISP) [ISP-HEADER01]  
 XCF32P(VOG)@TSOP48 [(SA247-B005)]  
 XCF32P(VOG)@TSOP48(ISP) [ISP-HEADER01]

## PLD

PZ3032C@PLCC44 [(SA244)]	PZ3032C@TQFP44
[(SA245A)]	
PZ3032N@PLCC44 [(SA244)]	PZ3032N@TQFP44
[(SA245A)]	
PZ5032C@PLCC44 [(SA244)]	PZ5032C@TQFP44
[(SA245A)]	
PZ5032N@PLCC44 [(SA244)]	PZ5032N@TQFP44
[(SA245A)]	
XC2C128@CP132(ISP) [ISP-HEADER01]	
XC2C128@FT256(ISP) [ISP-HEADER01]	
XC2C128@TQFP100 [(PEP+S604)]	
XC2C128@TQFP100(ISP) [ISP-HEADER01]	
XC2C128@TQFP144(*) [(SA681+B14418)]	
XC2C128@TQFP144(ISP) [ISP-HEADER01]	
XC2C256@CP132(ISP) [ISP-HEADER01]	
XC2C256@FT256(*) [(SA800+B177)]	

XC2C256@FT256(ISP) [ISP-HEADER01]  
 XC2C256@TQFP100 [(PEP+S604)]  
 XC2C256@TQFP100(ISP) [ISP-HEADER01]  
 XC2C256@TQFP144(\*) [(SA681+B14418)]  
 XC2C256@TQFP144(ISP) [ISP-HEADER01]  
 XC2C256@TQFP208(ISP) [ISP-HEADER01]  
 XC2C32@PLCC44 [(SA244)]  
 XC2C32@PLCC44(ISP) [ISP-HEADER01]  
 XC2C32@QFG32 [(SA686)] XC2C32@QFG32(ISP) [ISP-  
 HEADER01]  
 XC2C32@VQFP44 [(SA245A)]  
 XC2C32@VQFP44(ISP) [ISP-HEADER01]  
 XC2C32A@PLCC44 [(SA244)]  
 XC2C32A@PLCC44(ISP) [ISP-HEADER01]  
 XC2C32A@QFG32 [(SA686)]  
 XC2C32A@QFG32(ISP) [ISP-HEADER01]  
 XC2C32A@VQFP44 [(SA245A)]  
 XC2C32A@VQFP44(ISP) [ISP-HEADER01]  
 XC2C384@CP204(ISP) [ISP-HEADER01]  
 XC2C384@FG324(ISP) [ISP-HEADER01]  
 XC2C384@FT256(\*) [(SA800+B177)]  
 XC2C384@FT256(ISP) [ISP-HEADER01]  
 XC2C384@TQFP144(\*) [(SA681+B14418)]  
 XC2C384@TQFP144(ISP) [ISP-HEADER01]  
 XC2C384@TQFP208(ISP) [ISP-HEADER01]  
 XC2C64@CSP56(\*) [(SA699A-B136B-W056F001Y)]  
 XC2C64@CSP56(ISP) [ISP-HEADER01] XC2C64@PLCC44  
 [(SA244)]  
 XC2C64@VQFP100 [(PEP+S604)] XC2C64@VQFP100(\*) [(TA063  
 +B006)]  
 XC2C64@VQFP44 [(SA245A)] XC2C64A@5QFG48C  
 [(SA696)]  
 XC2C64A@5QFG48I [(SA696)] XC2C64A@7QFG48C  
 [(SA696)]  
 XC2C64A@7QFG48I [(SA696)]  
 XC2C64A@CSP56(\*) [(SA699A-B136B-W056F001Y)]  
 XC2C64A@CSP56(ISP) [ISP-HEADER01]  
 XC2C64A@PLCC44 [(SA244)] XC2C64A@VQFP100 [(PEP  
 +S604)]  
 XC2C64A@VQFP100(\*) [(TA063+B006)]  
 XC2C64A@VQFP44 [(SA245A)] XC7354@PLCC44  
 [(SA244)]  
 XC7354@PLCC68 [(PEP+S414T)] XC7372@PLCC68 [(PEP

+S414T) ]	
XC7372@PLCC84 [(PEP+S416T)]	XC7372@PQFP100 [(PEP
+S427) ]	
XC95108@PLCC84 [(PEP+S416T)]	XC95108@PQFP100 [(PEP
+S427) ]	
XC95108@PQFP100(*) [(TA082+B084)]	
XC95108@TQFP100 [(PEP+S604)]	XC95144@PQFP100 [(PEP
+S427) ]	
XC95144@TQFP100 [(PEP+S604)]	XC95144XL@TQFP100 [(PEP
+S604) ]	
XC95144XL@TQFP100(*) [(SA718+B186)]	
XC95144XL@TQFP144(*) [(PEP+TA028)]	
XC95144XL@TQFP144(**) [(TA028A+B084)]	
XC95144XV@TQFP100 [(PEP+S604)]	
XC95144XV@TQFP144(*) [(PEP+TA028)]	
XC95144XV@TQFP144(**) [(TA028A+B084)]	
XC95216@PQFP160(*) [(TA081+B084)]	
XC95288XL@TQFP144(*) [(PEP+TA028)]	
XC95288XL@TQFP144(**) [(TA028A+B084)]	
XC95288XV@FG256(*) [(SA800+B181)]	
XC95288XV@TQFP144(*) [(PEP+TA028)]	
XC95288XV@TQFP144(**) [(TA028A+B084)]	
XC9536@PLCC44 [(SA244)]	XC9536@TQFP44
[(SA245A)]	
XC9536XL@BCSP48	XC9536XL@PLCC44
[(SA244)]	
XC9536XL@TQFP64 [(PEP+S616)]	
XC9536XL@TQFP64(*) [(TA073+B006)]	
XC9536XL@VQFP44 [(SA245A)]	
XC9536XV@BCSP48	
XC9536XV@PLCC44 [(SA244)]	XC9536XV@TQFP44
[(SA245A)]	
XC9572@PLCC44 [(SA244)]	XC9572@PLCC84 [(PEP
+S416T) ]	
XC9572@PQFP100 [(PEP+S427)]	XC9572@TQFP100 [(PEP
+S604) ]	
XC9572@TQFP44 [(SA245A)]	
XC9572XL@BCSP48	
XC9572XL@PLCC44 [(SA244)]	XC9572XL@TQFP100 [(PEP
+S604) ]	
XC9572XL@TQFP44 [(SA245A)]	XC9572XL@TQFP64 [(PEP
+S616) ]	
XC9572XL@TQFP64(*) [(TA073+B006)]	

XC9572XV@BCSP48 [ (SA244) ]	XC9572XV@PLCC44
XC9572XV@TQFP100 [ (PEP+S604) ] [ (SA245A) ]	XC9572XV@TQFP44
XCR3032A@PLCC44 [ (SA244) ] [ (SA245A) ]	XCR3032A@TQFP44
XCR3032C@PLCC44 [ (SA244) ] [ (SA245A) ]	XCR3032C@TQFP44
XCR3032N@PLCC44 [ (SA244) ] [ (SA245A) ]	XCR3032N@TQFP44
XCR3032XL@PLCC44 [ (SA244) ] [ (SA245A) ]	XCR3032XL@TQFP44
XCR3064XL@FPGA56 [ (SA699+B155) ] [ (SA244) ]	XCR3064XL@PLCC44
XCR3064XL@TQFP100 [ (PEP+S604) ] [ (SA245A) ]	XCR3064XL@TQFP44
XCR3128XL@TQFP100 [ (PEP+S604) ]	
XCR3128XL@TQFP144(ISP) [ ISP-HEADER01 ]	
XCR3256XL@TQFP144(ISP) [ ISP-HEADER01 ]	
XCR3256XL@TQFP208(ISP) [ ISP-HEADER01 ]	
XCR5032C@PLCC44 [ (SA244) ] [ (SA245A) ]	XCR5032C@TQFP44
XCR5032N@PLCC44 [ (SA244) ] [ (SA245A) ]	XCR5032N@TQFP44

## **XILINX-CUSTOMER**

### **E(E) PROM/FRAM/NVRAM**

XC17S100A [ (SA404) ]	XC17S100A@SOIC20
XC17S100A@SOIC8 [ (SA602A) ]	
XC17S150A XC17S150A@SOIC20 [ (SA404) ] [ (SA602A) ]	XC17S150A@SOIC8
XC17S15A [ (SA404) ]	XC17S15A@SOIC20
XC17S15A@SOIC8 [ (SA602A) ]	
XC17S200A XC17S200A@SOIC8 [ (SA602A) ] [ (SA245A) ]	XC17S200A@TQFP44
XC17S300A@TQFP44 [ (SA245A) ]	



XC17S30A	
XC17S30A@SOIC20 [(SA404)]	XC17S30A@SOIC8
[(SA602A)]	
XC17S50A	XC17S50A@SOIC20
[(SA404)]	
XC17S50A@SOIC8 [(SA602A)]	XC17V01@PLCC20
[(SA001A)]	
XC17V01@SOIC20 [(SA404)]	XC17V01@SOIC8
[(SA602A)]	
XC17V02@PLCC20 [(SA001A)]	XC17V02@PLCC44
[(SA244)]	
XC17V02@TQFP44 [(SA245A)]	XC17V04@PLCC20
[(SA001A)]	
XC17V04@PLCC44 [(SA244)]	XC17V04@TQFP44
[(SA245A)]	
XC17V08@PLCC44 [(SA244)]	XC17V08@TQFP44
[(SA245A)]	
XC17V16@PLCC44 [(SA244)]	XC17V16@TQFP44
[(SA245A)]	

## YMC

### E(E) PROM/FRAM/NVRAM

Y24LC01	Y24LC01@SOIC8
[(SA602A)]	
Y24LC01@TSSOP8 [(SA026)]	
Y24LC02	
Y24LC02@SOIC8 [(SA602A)]	Y24LC02@TSSOP8
[(SA026)]	
Y24LC02A	Y24LC02A@SOIC8
[(SA602A)]	
Y24LC02A@TSSOP8 [(SA026)]	
Y24LC04	
Y24LC04@SOIC8 [(SA602A)]	Y24LC04@TSSOP8
[(SA026)]	
Y24LC08	Y24LC08@SOIC8
[(SA602A)]	
Y24LC08@TSSOP8 [(SA026)]	
Y24LC16	
Y24LC16@SOIC8 [(SA602A)]	Y24LC16@TSSOP8
[(SA026)]	

Y24LC32 [ (SA602A) ]	Y24LC32@SOIC8
Y24LC32@TSSOP8 [ (SA026) ]	
Y24LC64	
Y24LC64@SOIC8 [ (SA602A) ] [ (SA026) ]	Y24LC64@TSSOP8
Y93LC46 (08bit) [ (SA602A) ]	Y93LC46 (08bit)@SOIC8
Y93LC46 (08bit)@TSSOP8 [ (SA026) ] (16bit)	Y93LC46
Y93LC46 (16bit)@SOIC8 [ (SA602A) ] [ (SA026) ]	Y93LC46 (16bit)@TSSOP8
Y93LC66 (08bit) [ (SA602A) ]	Y93LC66 (08bit)@SOIC8
Y93LC66 (08bit)@TSSOP8 [ (SA026) ] (16bit)	Y93LC66
Y93LC66 (16bit)@SOIC8 [ (SA602A) ] [ (SA026) ]	Y93LC66 (16bit)@TSSOP8
Y93LC86 (08bit) [ (SA602A) ]	Y93LC86 (08bit)@SOIC8
Y93LC86 (08bit)@TSSOP8 [ (SA026) ] (16bit)	Y93LC86
Y93LC86 (16bit)@SOIC8 [ (SA602A) ] [ (SA026) ]	Y93LC86 (16bit)@TSSOP8

## YSS

### E (E) PROM / FRAM / NVRAM

Y25F05@SOP8 [ (SA602A) ] [ (SA683) ]	Y25F05@VQFN8
Y25F10@SOP8 [ (SA602A) ] [ (SA683) ]	Y25F10@VQFN8

## ZILOG

### MICROCONTROLLER

Z16F2810AG20AG@LQFP64 [ (PEP+S616) ]	
Z16F2810AG20EG@LQFP64 [ (PEP+S616) ]	

Z16F2810AG20SG@LQFP64 [(PEP+S616)]  
 Z16F2810FI20AG@QFP80 [(PEP+S611A)]  
 Z16F2810FI20EG@QFP80 [(PEP+S611A)]  
 Z16F2810FI20SG@QFP80 [(PEP+S611A)]  
 Z16F2810VH20AG@PLCC68 [(PEP+S414T)]  
 Z16F2810VH20EG@PLCC68 [(PEP+S414T)]  
 Z16F2810VH20SG@PLCC68 [(PEP+S414T)]  
 Z16F2811AL20AG@LQFP100 [(PEP+S604)]  
 Z16F2811AL20EG@LQFP100 [(PEP+S604)]  
 Z16F2811AL20SG@LQFP100 [(PEP+S604)]  
 Z16F2811FI20AG@QFP80 [(PEP+S611A)]  
 Z16F2811FI20EG@QFP80 [(PEP+S611A)]  
 Z16F2811FI20SG@QFP80 [(PEP+S611A)]  
 Z16F3211AL20AG@LQFP100 [(PEP+S604)]  
 Z16F3211AL20EG@LQFP100 [(PEP+S604)]  
 Z16F3211AL20SG@LQFP100 [(PEP+S604)]  
 Z16F3211FI20AG@QFP80 [(PEP+S611A)]  
 Z16F3211FI20EG@QFP80 [(PEP+S611A)]  
 Z16F3211FI20SG@QFP80 [(PEP+S611A)]  
 Z16F6411AL20AG@LQFP100 [(PEP+S604)]  
 Z16F6411AL20EG@LQFP100 [(PEP+S604)]  
 Z16F6411AL20SG@LQFP100 [(PEP+S604)]  
 Z16F6411FI20AG@QFP80 [(PEP+S611A)]  
 Z16F6411FI20EG@QFP80 [(PEP+S611A)]  
 Z16F6411FI20SG@QFP80 [(PEP+S611A)]  
 Z86733 Z86733@PLCC28  
 [(SA008A)]  
 Z86733@SOIC28 [(SA404)]  
 Z86743  
 Z86743@PLCC44 [(SA244)]  
 Z86C0208PEC  
 Z86C0208PSC Z86C0208SEC@SOIC18  
 [(SA404)]  
 Z86C0208SSC@SOIC18 [(SA404)] Z86D7308FSC@QFP44  
 [(SA245A)]  
 Z86D7308HSC@SSOP48 [(SA669)]  
 Z86D7308PSC  
 Z86D7308VSC@PLCC44 [(SA244)]  
 Z86D8608PSC  
 Z86D8608SSC@SOIC28 [(SA404)] Z86D8608SSG@SOIC28  
 [(SA404)]  
 Z86D9808PSC Z86D9808SSC@SOIC28  
 [(SA404)]

Z86E02	Z86E02@SOIC18
[(SA404)]	
Z86E03	Z86E03@SOIC18
[(SA404)]	
Z86E04	Z86E04@SOIC18
[(SA404)]	
Z86E0412PEC	
Z86E0412PEC1903	
Z86E0412PSC1866	
Z86E0412PSC1903	
Z86E0412SEC [(SA404)]	Z86E0412SEC1903
[(SA404)]	
Z86E0412SSC1866 [(SA404)]	Z86E0412SSC1903
[(SA404)]	
Z86E06	Z86E06@SOIC18
[(SA404)]	
Z86E07	Z86E07@SOIC18
[(SA404)]	
Z86E08	Z86E08@SOIC18
[(SA404)]	
Z86E0812PEC	
Z86E0812PEC1903	
Z86E0812PSC1866	
Z86E0812PSC1903	
Z86E0812SEC [(SA404)]	Z86E0812SEC1903
[(SA404)]	
Z86E0812SSC1866 [(SA404)]	Z86E0812SSC1903
[(SA404)]	
Z86E122	Z86E122@SOIC20
[(SA404)]	
Z86E123	Z86E123@SOIC20
[(SA404)]	
Z86E124	Z86E124@SOIC20
[(SA404)]	
Z86E125	Z86E125@SOIC20
[(SA404)]	
Z86E126	Z86E126@SOIC20
[(SA404)]	
Z86E132	Z86E132@SOIC28
[(SA404)]	
Z86E133	Z86E133@SOIC28
[(SA404)]	
Z86E134	Z86E134@SOIC28

[(SA404)]	
Z86E135	Z86E135@SOIC28
[(SA404)]	
Z86E136	Z86E136@SOIC28
[(SA404)]	
Z86E142	Z86E142@TQFP44
[(SA245A)]	
Z86E143	Z86E143@TQFP44
[(SA245A)]	
Z86E144	Z86E144@TQFP44
[(SA245A)]	
Z86E145	Z86E145@TQFP44
[(SA245A)]	
Z86E146	Z86E146@TQFP44
[(SA245A)]	
Z86E15	
Z86E21	
Z86E21@PLCC44 [(SA244)]	
Z86E21@TQFP44	
Z86E23	Z86E23@PLCC44
[(SA244)]	
Z86E23@TQFP44 [(SA245A)]	
Z86E3016PEC	
Z86E3016PSC	Z86E3016SEC@SOIC28
[(SA404)]	
Z86E3016SSC@SOIC28 [(SA404)]	Z86E3016VEC@PLCC28
[(SA008A)]	
Z86E3016VSC@PLCC28 [(SA008A)]	Z86E3016VSG@PLCC28
[(SA008A)]	
Z86E3116PEC	
Z86E3116PSC	
Z86E3116SEC@SOIC28 [(SA404)]	Z86E3116SSC@SOIC28
[(SA404)]	
Z86E3116VEC@PLCC28 [(SA008A)]	Z86E3116VSC@PLCC28
[(SA008A)]	
Z86E3116VSG@PLCC28 [(SA008A)]	
Z86E33	
Z86E33@PLCC28 [(SA008A)]	Z86E33@SOIC28
[(SA404)]	
Z86E34	Z86E34@PLCC28
[(SA008A)]	
Z86E34@SOIC28 [(SA404)]	Z86E4016FEC@TQFP44
[(SA245A)]	

Z86E4016FSC@TQFP44 [(SA245A)]	
Z86E4016PEC	
Z86E4016PSC	Z86E4016VEC@PLCC44
[(SA244)]	
Z86E4016VSC@PLCC44 [(SA244)]	Z86E4016VSG@PLCC44
[(SA244)]	
Z86E43	Z86E43@PLCC44
[(SA244)]	
Z86E43@TQFP44 [(SA245A)]	
Z86E44	
Z86E44@PLCC44 [(SA244)]	Z86E44@TQFP44
[(SA245A)]	
Z86E61FSC@TQFP44 [(SA245A)]	
Z86E61PSC	
Z86E61VSC@PLCC44 [(SA244)]	Z86E63FSC@TQFP44
[(SA245A)]	
Z86E63PSC	Z86E63VSC@PLCC44
[(SA244)]	
Z86E72	Z86E72@PLCC44
[(SA244)]	
Z86E72@TQFP44 [(SA245A)]	
Z86E73	
Z86E73@PLCC44 [(SA244)]	Z86E73@TQFP44
[(SA245A)]	
Z86E83	Z86E83@PLCC28
[(SA008A)]	
Z86E83@SOIC28 [(SA404)]	
Z86L0208PEC	
Z86L0208PSC	Z86L0208SEC@SOIC18
[(SA404)]	
Z86L0208SSC@SOIC18 [(SA404)]	
Z89371	
Z89371@PLCC44 [(SA244)]	Z89371@TQFP44
[(SA245A)]	
Z89371B	Z89371B@PLCC44
[(SA244)]	
Z89371B@TQFP44 [(SA245A)]	Z8E00010HEC@SSOP20
[(SA626A)]	
Z8E00010HSC@SSOP20 [(SA626A)]	
Z8E00010PEC	
Z8E00010PSC	Z8E00010SEC@SOIC18
[(SA404)]	
Z8E00010SSC@SOIC18 [(SA404)]	Z8E00010SSG@SOIC18

[ (SA404) ]	
Z8E00110HEC@SSOP20 [ (SA626A) ]	Z8E00110HSC@SSOP20
[ (SA626A) ]	
Z8E00110PEC	
Z8E00110PSC	
Z8E00110SEC@SOIC18 [ (SA404) ]	Z8E00110SSC@SOIC18
[ (SA404) ]	
Z8E00110SSG@SOIC18 [ (SA404) ]	Z8F0113HH005EC@SSOP20
[ (SA626A) ]	
Z8F0113HH005EG@SSOP20 [ (SA626A) ]	Z8F0113HH005SC@SSOP20
[ (SA626A) ]	
Z8F0113HH005SG@SSOP20 [ (SA626A) ]	Z8F0113HJ005EC@SSOP28
[ (SA626A) ]	
Z8F0113HJ005EG@SSOP28 [ (SA626A) ]	Z8F0113HJ005SC@SSOP28
[ (SA626A) ]	
Z8F0113HJ005SG@SSOP28 [ (SA626A) ]	
Z8F0113PB005EC	
Z8F0113PB005EG	
Z8F0113PB005SC	
Z8F0113PB005SG	
Z8F0113PH005EC	
Z8F0113PH005EG	
Z8F0113PH005SC	
Z8F0113PH005SG	
Z8F0113PJ005EC	
Z8F0113PJ005EG	
Z8F0113PJ005SC	
Z8F0113PJ005SG	Z8F0113QB005EC@QFN8
[ (SA683) ]	
Z8F0113QB005EG@QFN8 [ (SA683) ]	Z8F0113QB005SC@QFN8
[ (SA683) ]	
Z8F0113QB005SG@QFN8 [ (SA683) ]	Z8F0113SB005EC@SOIC8
[ (SA602A) ]	
Z8F0113SB005EG@SOIC8 [ (SA602A) ]	Z8F0113SB005SC@SOIC8
[ (SA602A) ]	
Z8F0113SB005SG@SOIC8 [ (SA602A) ]	Z8F0113SH005EC@SOIC20
[ (SA404) ]	
Z8F0113SH005EG@SOIC20 [ (SA404) ]	Z8F0113SH005SC@SOIC20
[ (SA404) ]	
Z8F0113SH005SG@SOIC20 [ (SA404) ]	Z8F0113SJ005EC@SOIC28
[ (SA404) ]	
Z8F0113SJ005EG@SOIC28 [ (SA404) ]	Z8F0113SJ005SC@SOIC28
[ (SA404) ]	

Z8F0113SJ005SG@SOIC28 [(SA404)]	Z8F011AHH020EC@SSOP20
[(SA626A)]	
Z8F011AHH020EG@SSOP20 [(SA626A)]	Z8F011AHH020SC@SSOP20
[(SA626A)]	
Z8F011AHH020SG@SSOP20 [(SA626A)]	Z8F011AHJ020EC@SSOP28
[(SA626A)]	
Z8F011AHJ020EG@SSOP28 [(SA626A)]	Z8F011AHJ020SC@SSOP28
[(SA626A)]	
Z8F011AHJ020SG@SSOP28 [(SA626A)]	
Z8F011APB020EC	
Z8F011APB020EG	
Z8F011APB020SC	
Z8F011APB020SG	
Z8F011APH020EC	
Z8F011APH020EG	
Z8F011APH020SC	
Z8F011APH020SG	
Z8F011APJ020EC	
Z8F011APJ020EG	
Z8F011APJ020SC	
Z8F011APJ020SG	
[(SA683)]	Z8F011AQB020EC@QFN8
Z8F011AQB020EG@QFN8 [(SA683)]	Z8F011AQB020SC@QFN8
[(SA683)]	
Z8F011AQB020SG@QFN8 [(SA683)]	Z8F011ASB020EC@SOIC8
[(SA602A)]	
Z8F011ASB020EG@SOIC8 [(SA602A)]	Z8F011ASB020SC@SOIC8
[(SA602A)]	
Z8F011ASB020SG@SOIC8 [(SA602A)]	Z8F011ASH020EC@SOIC20
[(SA404)]	
Z8F011ASH020EG@SOIC20 [(SA404)]	Z8F011ASH020SC@SOIC20
[(SA404)]	
Z8F011ASH020SG@SOIC20 [(SA404)]	Z8F011ASJ020EC@SOIC28
[(SA404)]	
Z8F011ASJ020EG@SOIC28 [(SA404)]	Z8F011ASJ020SC@SOIC28
[(SA404)]	
Z8F011ASJ020SG@SOIC28 [(SA404)]	Z8F0123HH005EC@SSOP20
[(SA626A)]	
Z8F0123HH005EG@SSOP20 [(SA626A)]	Z8F0123HH005SC@SSOP20
[(SA626A)]	
Z8F0123HH005SG@SSOP20 [(SA626A)]	Z8F0123HJ005EC@SSOP28
[(SA626A)]	
Z8F0123HJ005EG@SSOP28 [(SA626A)]	Z8F0123HJ005SC@SSOP28



[ ( SA626A ) ]

Z8F0123HJ005SG@SSOP28 [ ( SA626A ) ]

Z8F0123PB005EC

Z8F0123PB005EG

Z8F0123PB005SC

Z8F0123PB005SG

Z8F0123PH005EC

Z8F0123PH005EG

Z8F0123PH005SC

Z8F0123PH005SG

Z8F0123PJ005EC

Z8F0123PJ005EG

Z8F0123PJ005SC

Z8F0123PJ005SG

Z8F0123QB005EC@QFN8

[ ( SA683 ) ]

Z8F0123QB005EG@QFN8 [ ( SA683 ) ]

Z8F0123QB005SC@QFN8

[ ( SA683 ) ]

Z8F0123QB005SG@QFN8 [ ( SA683 ) ]

Z8F0123SB005EC@SOIC8

[ ( SA602A ) ]

Z8F0123SB005EG@SOIC8 [ ( SA602A ) ]

Z8F0123SB005SC@SOIC8

[ ( SA602A ) ]

Z8F0123SB005SG@SOIC8 [ ( SA602A ) ]

Z8F0123SH005EC@SOIC20

[ ( SA404 ) ]

Z8F0123SH005EG@SOIC20 [ ( SA404 ) ]

Z8F0123SH005SC@SOIC20

[ ( SA404 ) ]

Z8F0123SH005SG@SOIC20 [ ( SA404 ) ]

Z8F0123SJ005EC@SOIC28

[ ( SA404 ) ]

Z8F0123SJ005EG@SOIC28 [ ( SA404 ) ]

Z8F0123SJ005SC@SOIC28

[ ( SA404 ) ]

Z8F0123SJ005SG@SOIC28 [ ( SA404 ) ]

Z8F012AHH020EC@SSOP20

[ ( SA626A ) ]

Z8F012AHH020EG@SSOP20 [ ( SA626A ) ]

Z8F012AHH020SC@SSOP20

[ ( SA626A ) ]

Z8F012AHH020SG@SSOP20 [ ( SA626A ) ]

Z8F012AHJ020EC@SSOP28

[ ( SA626A ) ]

Z8F012AHJ020EG@SSOP28 [ ( SA626A ) ]

Z8F012AHJ020SC@SSOP28

[ ( SA626A ) ]

Z8F012AHJ020SG@SSOP28 [ ( SA626A ) ]

Z8F012APB020EC

Z8F012APB020EG

Z8F012APB020SC

Z8F012APB020SG

Z8F012APH020EC

Z8F012APH020EG	
Z8F012APH020SC	
Z8F012APH020SG	
Z8F012APJ020EC	
Z8F012APJ020EG	
Z8F012APJ020SC	
Z8F012APJ020SG	Z8F012AQB020EC@QFN8
[(SA683)]	
Z8F012AQB020EG@QFN8 [(SA683)]	Z8F012AQB020SC@QFN8
[(SA683)]	
Z8F012AQB020SG@QFN8 [(SA683)]	Z8F012ASB020EC@SOIC8
[(SA602A)]	
Z8F012ASB020EG@SOIC8 [(SA602A)]	Z8F012ASB020SC@SOIC8
[(SA602A)]	
Z8F012ASB020SG@SOIC8 [(SA602A)]	Z8F012ASH020EC@SOIC20
[(SA404)]	
Z8F012ASH020EG@SOIC20 [(SA404)]	Z8F012ASH020SC@SOIC20
[(SA404)]	
Z8F012ASH020SG@SOIC20 [(SA404)]	Z8F012ASJ020EC@SOIC28
[(SA404)]	
Z8F012ASJ020EG@SOIC28 [(SA404)]	Z8F012ASJ020SC@SOIC28
[(SA404)]	
Z8F012ASJ020SG@SOIC28 [(SA404)]	Z8F0130HH020EG@SSOP20
[(SA626A)]	
Z8F0130HH020SG@SSOP20 [(SA626A)]	Z8F0130HJ020EG@SSOP28
[(SA626A)]	
Z8F0130HJ020SG@SSOP28 [(SA626A)]	
Z8F0130PH020EG	
Z8F0130PH020SG	
Z8F0130PJ020EG	
Z8F0130PJ020SG	Z8F0130QH020EG@QFN20
[(SA759)]	
Z8F0130QH020SG@QFN20 [(SA759)]	Z8F0130QJ020EG@QFN28
[(SA697)]	
Z8F0130QJ020SG@QFN28 [(SA697)]	Z8F0130SH020EG@SOIC20
[(SA404)]	
Z8F0130SH020SG@SOIC20 [(SA404)]	Z8F0130SJ020EG@SOIC28
[(SA404)]	
Z8F0130SJ020SG@SOIC28 [(SA404)]	Z8F0131HH020EG@SSOP20
[(SA626A)]	
Z8F0131HH020SG@SSOP20 [(SA626A)]	Z8F0131HJ020EG@SSOP28
[(SA626A)]	
Z8F0131HJ020SG@SSOP28 [(SA626A)]	

Z8F0131PH020EG  
Z8F0131PH020SG  
Z8F0131PJ020EG  
Z8F0131PJ020SG  
[ (SA759) ]  
Z8F0131QH020SG@QFN20 [ (SA759) ]  
[ (SA697) ]  
Z8F0131QJ020SG@QFN28 [ (SA697) ]  
[ (SA404) ]  
Z8F0131SH020SG@SOIC20 [ (SA404) ]  
[ (SA404) ]  
Z8F0131SJ020SG@SOIC28 [ (SA404) ]  
[ (SA626A) ]  
Z8F0213HH005EG@SSOP20 [ (SA626A) ]  
[ (SA626A) ]  
Z8F0213HH005SG@SSOP20 [ (SA626A) ]  
[ (SA626A) ]  
Z8F0213HJ005EG@SSOP28 [ (SA626A) ]  
[ (SA626A) ]  
Z8F0213HJ005SG@SSOP28 [ (SA626A) ]  
Z8F0213PB005EC  
Z8F0213PB005EG  
Z8F0213PB005SC  
Z8F0213PB005SG  
Z8F0213PH005EC  
Z8F0213PH005EG  
Z8F0213PH005SC  
Z8F0213PH005SG  
Z8F0213PJ005EC  
Z8F0213PJ005EG  
Z8F0213PJ005SC  
Z8F0213PJ005SG  
[ (SA683) ]  
Z8F0213QB005EG@QFN8 [ (SA683) ]  
[ (SA683) ]  
Z8F0213QB005SG@QFN8 [ (SA683) ]  
[ (SA602A) ]  
Z8F0213SB005EG@SOIC8 [ (SA602A) ]  
[ (SA602A) ]  
Z8F0213SB005SG@SOIC8 [ (SA602A) ]  
[ (SA404) ]  
Z8F0213SH005EG@SOIC20 [ (SA404) ]  
[ (SA404) ]

Z8F0131QH020EG@QFN20  
Z8F0131QJ020EG@QFN28  
Z8F0131SH020EG@SOIC20  
Z8F0131SJ020EG@SOIC28  
Z8F0213HH005EC@SSOP20  
Z8F0213HH005SC@SSOP20  
Z8F0213HJ005EC@SSOP28  
Z8F0213HJ005SC@SSOP28  
Z8F0213QB005EC@QFN8  
Z8F0213QB005SC@QFN8  
Z8F0213SB005EC@SOIC8  
Z8F0213SB005SC@SOIC8  
Z8F0213SH005EC@SOIC20  
Z8F0213SH005SC@SOIC20

Z8F0213SH005SG@SOIC20 [(SA404)]	Z8F0213SJ005EC@SOIC28
[(SA404)]	
Z8F0213SJ005EG@SOIC28 [(SA404)]	Z8F0213SJ005SC@SOIC28
[(SA404)]	
Z8F0213SJ005SG@SOIC28 [(SA404)]	Z8F021AHH020EC@SSOP20
[(SA626A)]	
Z8F021AHH020EG@SSOP20 [(SA626A)]	Z8F021AHH020SC@SSOP20
[(SA626A)]	
Z8F021AHH020SG@SSOP20 [(SA626A)]	Z8F021AHJ020EC@SSOP28
[(SA626A)]	
Z8F021AHJ020EG@SSOP28 [(SA626A)]	Z8F021AHJ020SC@SSOP28
[(SA626A)]	
Z8F021AHJ020SG@SSOP28 [(SA626A)]	
Z8F021APB020EC	
Z8F021APB020EG	
Z8F021APB020SC	
Z8F021APB020SG	
Z8F021APH020EC	
Z8F021APH020EG	
Z8F021APH020SC	
Z8F021APH020SG	
Z8F021APJ020EC	
Z8F021APJ020EG	
Z8F021APJ020SC	
Z8F021APJ020SG	
[(SA683)]	Z8F021AQB020EC@QFN8
Z8F021AQB020EG@QFN8 [(SA683)]	Z8F021AQB020SC@QFN8
[(SA683)]	
Z8F021AQB020SG@QFN8 [(SA683)]	Z8F021ASB020EC@SOIC8
[(SA602A)]	
Z8F021ASB020EG@SOIC8 [(SA602A)]	Z8F021ASB020SC@SOIC8
[(SA602A)]	
Z8F021ASB020SG@SOIC8 [(SA602A)]	Z8F021ASH020EC@SOIC20
[(SA404)]	
Z8F021ASH020EG@SOIC20 [(SA404)]	Z8F021ASH020SC@SOIC20
[(SA404)]	
Z8F021ASH020SG@SOIC20 [(SA404)]	Z8F021ASJ020EC@SOIC28
[(SA404)]	
Z8F021ASJ020EG@SOIC28 [(SA404)]	Z8F021ASJ020SC@SOIC28
[(SA404)]	
Z8F021ASJ020SG@SOIC28 [(SA404)]	Z8F0223HH005EC@SSOP20
[(SA626A)]	
Z8F0223HH005EG@SSOP20 [(SA626A)]	Z8F0223HH005SC@SSOP20

[ ( SA626A ) ]		
Z8F0223HH005SG@SSOP20 [ ( SA626A ) ]		Z8F0223HJ005EC@SSOP28
[ ( SA626A ) ]		
Z8F0223HJ005EG@SSOP28 [ ( SA626A ) ]		Z8F0223HJ005SC@SSOP28
[ ( SA626A ) ]		
Z8F0223HJ005SG@SSOP28 [ ( SA626A ) ]		
Z8F0223PB005EC		
Z8F0223PB005EG		
Z8F0223PB005SC		
Z8F0223PB005SG		
Z8F0223PH005EC		
Z8F0223PH005EG		
Z8F0223PH005SC		
Z8F0223PH005SG		
Z8F0223PJ005EC		
Z8F0223PJ005EG		
Z8F0223PJ005SC		
Z8F0223PJ005SG		Z8F0223QB005EC@QFN8
[ ( SA683 ) ]		
Z8F0223QB005EG@QFN8 [ ( SA683 ) ]		Z8F0223QB005SC@QFN8
[ ( SA683 ) ]		
Z8F0223QB005SG@QFN8 [ ( SA683 ) ]		Z8F0223SB005EC@SOIC8
[ ( SA602A ) ]		
Z8F0223SB005EG@SOIC8 [ ( SA602A ) ]		Z8F0223SB005SC@SOIC8
[ ( SA602A ) ]		
Z8F0223SB005SG@SOIC8 [ ( SA602A ) ]		Z8F0223SH005EC@SOIC20
[ ( SA404 ) ]		
Z8F0223SH005EG@SOIC20 [ ( SA404 ) ]		Z8F0223SH005SC@SOIC20
[ ( SA404 ) ]		
Z8F0223SH005SG@SOIC20 [ ( SA404 ) ]		Z8F0223SJ005EC@SOIC28
[ ( SA404 ) ]		
Z8F0223SJ005EG@SOIC28 [ ( SA404 ) ]		Z8F0223SJ005SC@SOIC28
[ ( SA404 ) ]		
Z8F0223SJ005SG@SOIC28 [ ( SA404 ) ]		Z8F022AHH020EC@SSOP20
[ ( SA626A ) ]		
Z8F022AHH020EG@SSOP20 [ ( SA626A ) ]		Z8F022AHH020SC@SSOP20
[ ( SA626A ) ]		
Z8F022AHH020SG@SSOP20 [ ( SA626A ) ]		Z8F022AHJ020EC@SSOP28
[ ( SA626A ) ]		
Z8F022AHJ020EG@SSOP28 [ ( SA626A ) ]		Z8F022AHJ020SC@SSOP28
[ ( SA626A ) ]		
Z8F022AHJ020SG@SSOP28 [ ( SA626A ) ]		
Z8F022APB020EC		

Z8F022APB020EG

Z8F022APB020SC

Z8F022APB020SG

Z8F022APH020EC

Z8F022APH020EG

Z8F022APH020SC

Z8F022APH020SG

Z8F022APJ020EC

Z8F022APJ020EG

Z8F022APJ020SC

Z8F022APJ020SG

Z8F022AQB020EC@QFN8

[ (SA683) ]

Z8F022AQB020EG@QFN8 [ (SA683) ]

Z8F022AQB020SC@QFN8

[ (SA683) ]

Z8F022AQB020SG@QFN8 [ (SA683) ]

Z8F022ASB020EC@SOIC8

[ (SA602A) ]

Z8F022ASB020EG@SOIC8 [ (SA602A) ]

Z8F022ASB020SC@SOIC8

[ (SA602A) ]

Z8F022ASB020SG@SOIC8 [ (SA602A) ]

Z8F022ASH020EC@SOIC20

[ (SA404) ]

Z8F022ASH020EG@SOIC20 [ (SA404) ]

Z8F022ASH020SC@SOIC20

[ (SA404) ]

Z8F022ASH020SG@SOIC20 [ (SA404) ]

Z8F022ASJ020EC@SOIC28

[ (SA404) ]

Z8F022ASJ020EG@SOIC28 [ (SA404) ]

Z8F022ASJ020SC@SOIC28

[ (SA404) ]

Z8F022ASJ020SG@SOIC28 [ (SA404) ]

Z8F0230HH020EG@SSOP20

[ (SA626A) ]

Z8F0230HH020SG@SSOP20 [ (SA626A) ]

Z8F0230HJ020EG@SSOP28

[ (SA626A) ]

Z8F0230HJ020SG@SSOP28 [ (SA626A) ]

Z8F0230PH020EG

Z8F0230PH020SG

Z8F0230PJ020EG

Z8F0230PJ020SG

Z8F0230QH020EG@QFN20

[ (SA759) ]

Z8F0230QH020SG@QFN20 [ (SA759) ]

Z8F0230QJ020EG@QFN28

[ (SA697) ]

Z8F0230QJ020SG@QFN28 [ (SA697) ]

Z8F0230SH020EG@SOIC20

[ (SA404) ]

Z8F0230SH020SG@SOIC20 [ (SA404) ]

Z8F0230SJ020EG@SOIC28

[ (SA404) ]

Z8F0230SJ020SG@SOIC28 [ (SA404) ]

Z8F0231HH020EG@SSOP20

[ (SA626A) ]  
Z8F0231HH020SG@SSOP20 [ (SA626A) ] Z8F0231HJ020EG@SSOP28  
[ (SA626A) ]  
Z8F0231HJ020SG@SSOP28 [ (SA626A) ]  
Z8F0231PH020EG  
Z8F0231PH020SG  
Z8F0231PJ020EG  
Z8F0231PJ020SG Z8F0231QH020EG@QFN20  
[ (SA759) ]  
Z8F0231QH020SG@QFN20 [ (SA759) ] Z8F0231QJ020EG@QFN28  
[ (SA697) ]  
Z8F0231QJ020SG@QFN28 [ (SA697) ] Z8F0231SH020EG@SOIC20  
[ (SA404) ]  
Z8F0231SH020SG@SOIC20 [ (SA404) ] Z8F0231SJ020EG@SOIC28  
[ (SA404) ]  
Z8F0231SJ020SG@SOIC28 [ (SA404) ] Z8F0411HH020EC@SSOP20  
[ (SA626A) ]  
Z8F0411HH020EG@SSOP20 [ (SA626A) ] Z8F0411HH020SC@SSOP20  
[ (SA626A) ]  
Z8F0411HH020SG@SSOP20 [ (SA626A) ]  
Z8F0411PH020EC  
Z8F0411PH020EG  
Z8F0411PH020SC  
Z8F0411PH020SG  
Z8F0412PJ020EC  
Z8F0412PJ020EG  
Z8F0412PJ020SC  
Z8F0412PJ020SG Z8F0412SJ020EC@SOIC28  
[ (SA404) ]  
Z8F0412SJ020EG@SOIC28 [ (SA404) ] Z8F0412SJ020SC@SOIC28  
[ (SA404) ]  
Z8F0412SJ020SG@SOIC28 [ (SA404) ] Z8F0413HH005EC@SSOP20  
[ (SA626A) ]  
Z8F0413HH005EG@SSOP20 [ (SA626A) ] Z8F0413HH005SC@SSOP20  
[ (SA626A) ]  
Z8F0413HH005SG@SSOP20 [ (SA626A) ] Z8F0413HJ005EC@SSOP28  
[ (SA626A) ]  
Z8F0413HJ005EG@SSOP28 [ (SA626A) ] Z8F0413HJ005SC@SSOP28  
[ (SA626A) ]  
Z8F0413HJ005SG@SSOP28 [ (SA626A) ]  
Z8F0413PB005EC  
Z8F0413PB005EG  
Z8F0413PB005SC

Z8F0413PB005SG

Z8F0413PH005EC

Z8F0413PH005EG

Z8F0413PH005SC

Z8F0413PH005SG

Z8F0413PJ005EC

Z8F0413PJ005EG

Z8F0413PJ005SC

Z8F0413PJ005SG

[ (SA683) ]

Z8F0413QB005EG@QFN8 [ (SA683) ]

[ (SA683) ]

Z8F0413QB005SG@QFN8 [ (SA683) ]

[ (SA602A) ]

Z8F0413SB005EG@SOIC8 [ (SA602A) ]

[ (SA602A) ]

Z8F0413SB005SG@SOIC8 [ (SA602A) ]

[ (SA404) ]

Z8F0413SH005EG@SOIC20 [ (SA404) ]

[ (SA404) ]

Z8F0413SH005SG@SOIC20 [ (SA404) ]

[ (SA404) ]

Z8F0413SJ005EG@SOIC28 [ (SA404) ]

[ (SA404) ]

Z8F0413SJ005SG@SOIC28 [ (SA404) ]

[ (SA626A) ]

Z8F041AHH020EG@SSOP20 [ (SA626A) ]

[ (SA626A) ]

Z8F041AHH020SG@SSOP20 [ (SA626A) ]

[ (SA626A) ]

Z8F041AHJ020EG@SSOP28 [ (SA626A) ]

[ (SA626A) ]

Z8F041AHJ020SG@SSOP28 [ (SA626A) ]

Z8F041APB020EC

Z8F041APB020EG

Z8F041APB020SC

Z8F041APB020SG

Z8F041APH020EC

Z8F041APH020EG

Z8F041APH020SC

Z8F041APH020SG

Z8F041APJ020EC

Z8F041APJ020EG

Z8F0413QB005EC@QFN8

Z8F0413QB005SC@QFN8

Z8F0413SB005EC@SOIC8

Z8F0413SB005SC@SOIC8

Z8F0413SH005EC@SOIC20

Z8F0413SH005SC@SOIC20

Z8F0413SJ005EC@SOIC28

Z8F0413SJ005SC@SOIC28

Z8F041AHH020EC@SSOP20

Z8F041AHH020SC@SSOP20

Z8F041AHJ020EC@SSOP28

Z8F041AHJ020SC@SSOP28



Z8F041APJ020SC

Z8F041APJ020SG

[ (SA683) ]

Z8F041AQB020EG@QFN8 [ (SA683) ]

[ (SA683) ]

Z8F041AQB020SG@QFN8 [ (SA683) ]

[ (SA602A) ]

Z8F041ASB020EG@SOIC8 [ (SA602A) ]

[ (SA602A) ]

Z8F041ASB020SG@SOIC8 [ (SA602A) ]

[ (SA404) ]

Z8F041ASH020EG@SOIC20 [ (SA404) ]

[ (SA404) ]

Z8F041ASH020SG@SOIC20 [ (SA404) ]

[ (SA404) ]

Z8F041ASJ020EG@SOIC28 [ (SA404) ]

[ (SA404) ]

Z8F041ASJ020SG@SOIC28 [ (SA404) ]

[ (SA626A) ]

Z8F0421HH020EG@SSOP20 [ (SA626A) ]

[ (SA626A) ]

Z8F0421HH020SG@SSOP20 [ (SA626A) ]

Z8F0421PH020EC

Z8F0421PH020EG

Z8F0421PH020SC

Z8F0421PH020SG

Z8F0422PJ020EC

Z8F0422PJ020EG

Z8F0422PJ020SC

Z8F0422PJ020SG

[ (SA404) ]

Z8F0422SJ020EG@SOIC28 [ (SA404) ]

[ (SA404) ]

Z8F0422SJ020SG@SOIC28 [ (SA404) ]

[ (SA626A) ]

Z8F0423HH005EG@SSOP20 [ (SA626A) ]

[ (SA626A) ]

Z8F0423HH005SG@SSOP20 [ (SA626A) ]

[ (SA626A) ]

Z8F0423HJ005EG@SSOP28 [ (SA626A) ]

[ (SA626A) ]

Z8F0423HJ005SG@SSOP28 [ (SA626A) ]

Z8F0423PB005EC

Z8F041AQB020EC@QFN8

Z8F041AQB020SC@QFN8

Z8F041ASB020EC@SOIC8

Z8F041ASB020SC@SOIC8

Z8F041ASH020EC@SOIC20

Z8F041ASH020SC@SOIC20

Z8F041ASJ020EC@SOIC28

Z8F041ASJ020SC@SOIC28

Z8F0421HH020EC@SSOP20

Z8F0421HH020SC@SSOP20

Z8F0422SJ020EC@SOIC28

Z8F0422SJ020SC@SOIC28

Z8F0423HH005EC@SSOP20

Z8F0423HH005SC@SSOP20

Z8F0423HJ005EC@SSOP28

Z8F0423HJ005SC@SSOP28

Z8F0423PB005EG  
Z8F0423PB005SC  
Z8F0423PB005SG  
Z8F0423PH005EC  
Z8F0423PH005EG  
Z8F0423PH005SC  
Z8F0423PH005SG  
Z8F0423PJ005EC  
Z8F0423PJ005EG  
Z8F0423PJ005SC  
Z8F0423PJ005SG

[ (SA683) ]

Z8F0423QB005EG@QFN8 [ (SA683) ]

[ (SA683) ]

Z8F0423QB005SG@QFN8 [ (SA683) ]

[ (SA602A) ]

Z8F0423SB005EG@SOIC8 [ (SA602A) ]

[ (SA602A) ]

Z8F0423SB005SG@SOIC8 [ (SA602A) ]

[ (SA404) ]

Z8F0423SH005EG@SOIC20 [ (SA404) ]

[ (SA404) ]

Z8F0423SH005SG@SOIC20 [ (SA404) ]

[ (SA404) ]

Z8F0423SJ005EG@SOIC28 [ (SA404) ]

[ (SA404) ]

Z8F0423SJ005SG@SOIC28 [ (SA404) ]

[ (SA626A) ]

Z8F042AHH020EG@SSOP20 [ (SA626A) ]

[ (SA626A) ]

Z8F042AHH020SG@SSOP20 [ (SA626A) ]

[ (SA626A) ]

Z8F042AHJ020EG@SSOP28 [ (SA626A) ]

[ (SA626A) ]

Z8F042AHJ020SG@SSOP28 [ (SA626A) ]

Z8F042APB020EC

Z8F042APB020EG

Z8F042APB020SC

Z8F042APB020SG

Z8F042APH020EC

Z8F042APH020EG

Z8F042APH020SC

Z8F042APH020SG

Z8F0423QB005EC@QFN8

Z8F0423QB005SC@QFN8

Z8F0423SB005EC@SOIC8

Z8F0423SB005SC@SOIC8

Z8F0423SH005EC@SOIC20

Z8F0423SH005SC@SOIC20

Z8F0423SJ005EC@SOIC28

Z8F0423SJ005SC@SOIC28

Z8F042AHH020EC@SSOP20

Z8F042AHH020SC@SSOP20

Z8F042AHJ020EC@SSOP28

Z8F042AHJ020SC@SSOP28

Z8F042APJ020EC

Z8F042APJ020EG

Z8F042APJ020SC

Z8F042APJ020SG

[ (SA683) ]

Z8F042AQB020EG@QFN8 [ (SA683) ]

[ (SA683) ]

Z8F042AQB020SG@QFN8 [ (SA683) ]

[ (SA602A) ]

Z8F042ASB020EG@SOIC8 [ (SA602A) ]

[ (SA602A) ]

Z8F042ASB020SG@SOIC8 [ (SA602A) ]

[ (SA404) ]

Z8F042ASH020EG@SOIC20 [ (SA404) ]

[ (SA404) ]

Z8F042ASH020SG@SOIC20 [ (SA404) ]

[ (SA404) ]

Z8F042ASJ020EG@SOIC28 [ (SA404) ]

[ (SA404) ]

Z8F042ASJ020SG@SOIC28 [ (SA404) ]

[ (SA626A) ]

Z8F0430HH020SG@SSOP20 [ (SA626A) ]

[ (SA626A) ]

Z8F0430HJ020SG@SSOP28 [ (SA626A) ]

Z8F0430PH020EG

Z8F0430PH020SG

Z8F0430PJ020EG

Z8F0430PJ020SG

[ (SA759) ]

Z8F0430QH020SG@QFN20 [ (SA759) ]

[ (SA697) ]

Z8F0430QJ020SG@QFN28 [ (SA697) ]

[ (SA404) ]

Z8F0430SH020SG@SOIC20 [ (SA404) ]

[ (SA404) ]

Z8F0430SJ020SG@SOIC28 [ (SA404) ]

[ (SA626A) ]

Z8F0431HH020SG@SSOP20 [ (SA626A) ]

[ (SA626A) ]

Z8F0431HJ020SG@SSOP28 [ (SA626A) ]

Z8F0431PH020EG

Z8F0431PH020SG

Z8F0431PJ020EG

Z8F042AQB020EC@QFN8

Z8F042AQB020SC@QFN8

Z8F042ASB020EC@SOIC8

Z8F042ASB020SC@SOIC8

Z8F042ASH020EC@SOIC20

Z8F042ASH020SC@SOIC20

Z8F042ASJ020EC@SOIC28

Z8F042ASJ020SC@SOIC28

Z8F0430HH020EG@SSOP20

Z8F0430HJ020EG@SSOP28

Z8F0430QH020EG@QFN20

Z8F0430QJ020EG@QFN28

Z8F0430SH020EG@SOIC20

Z8F0430SJ020EG@SOIC28

Z8F0431HH020EG@SSOP20

Z8F0431HJ020EG@SSOP28

Z8F0431PJ020SG [ (SA759) ]	Z8F0431QH020EG@QFN20
Z8F0431QH020SG@QFN20 [ (SA759) ] [ (SA697) ]	Z8F0431QJ020EG@QFN28
Z8F0431QJ020SG@QFN28 [ (SA697) ] [ (SA404) ]	Z8F0431SH020EG@SOIC20
Z8F0431SH020SG@SOIC20 [ (SA404) ] [ (SA404) ]	Z8F0431SJ020EG@SOIC28
Z8F0431SJ020SG@SOIC28 [ (SA404) ] [ (SA626A) ]	Z8F0811HH020EC@SSOP20
Z8F0811HH020EG@SSOP20 [ (SA626A) ] [ (SA626A) ]	Z8F0811HH020SC@SSOP20
Z8F0811HH020SG@SSOP20 [ (SA626A) ]	
Z8F0811PH020EC	
Z8F0811PH020EG	
Z8F0811PH020SC	
Z8F0811PH020SG	
Z8F0812PJ020EC	
Z8F0812PJ020EG	
Z8F0812PJ020SC	
Z8F0812PJ020SG [ (SA404) ]	Z8F0812SJ020EC@SOIC28
Z8F0812SJ020EG@SOIC28 [ (SA404) ] [ (SA404) ]	Z8F0812SJ020SC@SOIC28
Z8F0812SJ020SG@SOIC28 [ (SA404) ] [ (SA626A) ]	Z8F0813HH005EC@SSOP20
Z8F0813HH005EG@SSOP20 [ (SA626A) ] [ (SA626A) ]	Z8F0813HH005SC@SSOP20
Z8F0813HH005SG@SSOP20 [ (SA626A) ] [ (SA626A) ]	Z8F0813HJ020EC@SSOP28
Z8F0813HJ020EG@SSOP28 [ (SA626A) ] [ (SA626A) ]	Z8F0813HJ020SC@SSOP28
Z8F0813HJ020SG@SSOP28 [ (SA626A) ]	
Z8F0813PB005EC	
Z8F0813PB005EG	
Z8F0813PB005SC	
Z8F0813PB005SG	
Z8F0813PH005EC	
Z8F0813PH005EG	
Z8F0813PH005SC	
Z8F0813PH005SG	
Z8F0813PJ020EC	
Z8F0813PJ020EG	

Z8F0813PJ020SC

Z8F0813PJ020SG

[ (SA683) ]

Z8F0813QB005EG@QFN8 [ (SA683) ]

[ (SA683) ]

Z8F0813QB005SG@QFN8 [ (SA683) ]

[ (SA602A) ]

Z8F0813SB005EG@SOIC8 [ (SA602A) ]

[ (SA602A) ]

Z8F0813SB005SG@SOIC8 [ (SA602A) ]

[ (SA404) ]

Z8F0813SH005EG@SOIC20 [ (SA404) ]

[ (SA404) ]

Z8F0813SH005SG@SOIC20 [ (SA404) ]

[ (SA404) ]

Z8F0813SJ020EG@SOIC28 [ (SA404) ]

[ (SA404) ]

Z8F0813SJ020SG@SOIC28 [ (SA404) ]

[ (SA626A) ]

Z8F081AHH005EG@SSOP20 [ (SA626A) ]

[ (SA626A) ]

Z8F081AHH005SG@SSOP20 [ (SA626A) ]

[ (SA626A) ]

Z8F081AHJ020EG@SSOP28 [ (SA626A) ]

[ (SA626A) ]

Z8F081AHJ020SG@SSOP28 [ (SA626A) ]

Z8F081APB020EC

Z8F081APB020EG

Z8F081APB020SC

Z8F081APB020SG

Z8F081APH005EC

Z8F081APH005EG

Z8F081APH005SC

Z8F081APH005SG

Z8F081APJ020EC

Z8F081APJ020EG

Z8F081APJ020SC

Z8F081APJ020SG

[ (SA683) ]

Z8F081AQB020EG@QFN8 [ (SA683) ]

[ (SA683) ]

Z8F081AQB020SG@QFN8 [ (SA683) ]

[ (SA602A) ]

Z8F0813QB005EC@QFN8

Z8F0813QB005SC@QFN8

Z8F0813SB005EC@SOIC8

Z8F0813SB005SC@SOIC8

Z8F0813SH005EC@SOIC20

Z8F0813SH005SC@SOIC20

Z8F0813SJ020EC@SOIC28

Z8F0813SJ020SC@SOIC28

Z8F081AHH005EC@SSOP20

Z8F081AHH005SC@SSOP20

Z8F081AHJ020EC@SSOP28

Z8F081AHJ020SC@SSOP28

Z8F081AQB020EC@QFN8

Z8F081AQB020SC@QFN8

Z8F081ASB020EC@SOIC8

Z8F081ASB020EG@SOIC8 [(SA602A)]	Z8F081ASB020SC@SOIC8
[(SA602A)]	
Z8F081ASB020SG@SOIC8 [(SA602A)]	Z8F081ASH005EC@SOIC20
[(SA404)]	
Z8F081ASH005EG@SOIC20 [(SA404)]	Z8F081ASH005SC@SOIC20
[(SA404)]	
Z8F081ASH005SG@SOIC20 [(SA404)]	Z8F081ASJ020EC@SOIC28
[(SA404)]	
Z8F081ASJ020EG@SOIC28 [(SA404)]	Z8F081ASJ020SC@SOIC28
[(SA404)]	
Z8F081ASJ020SG@SOIC28 [(SA404)]	Z8F0821HH020EC@SSOP20
[(SA626A)]	
Z8F0821HH020EG@SSOP20 [(SA626A)]	Z8F0821HH020SC@SSOP20
[(SA626A)]	
Z8F0821HH020SG@SSOP20 [(SA626A)]	
Z8F0821PH020EC	
Z8F0821PH020EG	
Z8F0821PH020SC	
Z8F0821PH020SG	
Z8F0822PJ020EC	
Z8F0822PJ020EG	
Z8F0822PJ020SC	
Z8F0822PJ020SG	Z8F0822SJ020EC@SOIC28
[(SA404)]	
Z8F0822SJ020EG@SOIC28 [(SA404)]	Z8F0822SJ020SC@SOIC28
[(SA404)]	
Z8F0822SJ020SG@SOIC28 [(SA404)]	Z8F0823HH005EC@SSOP20
[(SA626A)]	
Z8F0823HH005EG@SSOP20 [(SA626A)]	Z8F0823HH005SC@SSOP20
[(SA626A)]	
Z8F0823HH005SG@SSOP20 [(SA626A)]	Z8F0823HJ020EC@SSOP28
[(SA626A)]	
Z8F0823HJ020EG@SSOP28 [(SA626A)]	Z8F0823HJ020SC@SSOP28
[(SA626A)]	
Z8F0823HJ020SG@SSOP28 [(SA626A)]	
Z8F0823PB005EC	
Z8F0823PB005EG	
Z8F0823PB005SC	
Z8F0823PB005SG	
Z8F0823PH005EC	
Z8F0823PH005EG	
Z8F0823PH005SC	
Z8F0823PH005SG	

Z8F0823PJ020EC	
Z8F0823PJ020EG	
Z8F0823PJ020SC	
Z8F0823PJ020SG	Z8F0823QB005EC@QFN8
[(SA683)]	
Z8F0823QB005EG@QFN8 [(SA683)]	Z8F0823QB005SC@QFN8
[(SA683)]	
Z8F0823QB005SG@QFN8 [(SA683)]	Z8F0823SB005EC@SOIC8
[(SA602A)]	
Z8F0823SB005EG@SOIC8 [(SA602A)]	Z8F0823SB005SC@SOIC8
[(SA602A)]	
Z8F0823SB005SG@SOIC8 [(SA602A)]	Z8F0823SH005EC@SOIC20
[(SA404)]	
Z8F0823SH005EG@SOIC20 [(SA404)]	Z8F0823SH005SC@SOIC20
[(SA404)]	
Z8F0823SH005SG@SOIC20 [(SA404)]	Z8F0823SJ020EC@SOIC28
[(SA404)]	
Z8F0823SJ020EG@SOIC28 [(SA404)]	Z8F0823SJ020SC@SOIC28
[(SA404)]	
Z8F0823SJ020SG@SOIC28 [(SA404)]	Z8F082AHH005EC@SSOP20
[(SA626A)]	
Z8F082AHH005EG@SSOP20 [(SA626A)]	Z8F082AHH005SC@SSOP20
[(SA626A)]	
Z8F082AHH005SG@SSOP20 [(SA626A)]	Z8F082AHJ020EC@SSOP28
[(SA626A)]	
Z8F082AHJ020EG@SSOP28 [(SA626A)]	Z8F082AHJ020SC@SSOP28
[(SA626A)]	
Z8F082AHJ020SG@SSOP28 [(SA626A)]	
Z8F082APB020EC	
Z8F082APB020EG	
Z8F082APB020SC	
Z8F082APB020SG	
Z8F082APH005EC	
Z8F082APH005EG	
Z8F082APH005SC	
Z8F082APH005SG	
Z8F082APJ020EC	
Z8F082APJ020EG	
Z8F082APJ020SC	
Z8F082APJ020SG	Z8F082AQB020EC@QFN8
[(SA683)]	
Z8F082AQB020EG@QFN8 [(SA683)]	Z8F082AQB020SC@QFN8
[(SA683)]	

Z8F082AQB020SG@QFN8 [(SA683)]	Z8F082ASB020EC@SOIC8
[(SA602A)]	
Z8F082ASB020EG@SOIC8 [(SA602A)]	Z8F082ASB020SC@SOIC8
[(SA602A)]	
Z8F082ASB020SG@SOIC8 [(SA602A)]	Z8F082ASH005EC@SOIC20
[(SA404)]	
Z8F082ASH005EG@SOIC20 [(SA404)]	Z8F082ASH005SC@SOIC20
[(SA404)]	
Z8F082ASH005SG@SOIC20 [(SA404)]	Z8F082ASJ020EC@SOIC28
[(SA404)]	
Z8F082ASJ020EG@SOIC28 [(SA404)]	Z8F082ASJ020SC@SOIC28
[(SA404)]	
Z8F082ASJ020SG@SOIC28 [(SA404)]	Z8F0830HH020EG@SSOP20
[(SA626A)]	
Z8F0830HH020SG@SSOP20 [(SA626A)]	Z8F0830HJ020EG@SSOP28
[(SA626A)]	
Z8F0830HJ020SG@SSOP28 [(SA626A)]	
Z8F0830PH020EG	
Z8F0830PH020SG	
Z8F0830PJ020EG	
Z8F0830PJ020SG	Z8F0830QH020EG@QFN20
[(SA759)]	
Z8F0830QH020SG@QFN20 [(SA759)]	Z8F0830QJ020EG@QFN28
[(SA697)]	
Z8F0830QJ020SG@QFN28 [(SA697)]	Z8F0830SH020EG@SOIC20
[(SA404)]	
Z8F0830SH020SG@SOIC20 [(SA404)]	Z8F0830SJ020EG@SOIC28
[(SA404)]	
Z8F0830SJ020SG@SOIC28 [(SA404)]	Z8F0831HH020EG@SSOP20
[(SA626A)]	
Z8F0831HH020SG@SSOP20 [(SA626A)]	Z8F0831HJ020EG@SSOP28
[(SA626A)]	
Z8F0831HJ020SG@SSOP28 [(SA626A)]	
Z8F0831PH020EG	
Z8F0831PH020SG	
Z8F0831PJ020EG	
Z8F0831PJ020SG	Z8F0831QH020EG@QFN20
[(SA759)]	
Z8F0831QH020SG@QFN20 [(SA759)]	Z8F0831QJ020EG@QFN28
[(SA697)]	
Z8F0831QJ020SG@QFN28 [(SA697)]	Z8F0831SH020EG@SOIC20
[(SA404)]	
Z8F0831SH020SG@SOIC20 [(SA404)]	Z8F0831SJ020EG@SOIC28



[ (SA404) ]		
Z8F0831SJ020SG@SOIC28 [ (SA404) ]		Z8F1232HH020EG@SSOP20
[ (SA626A) ]		
Z8F1232HH020SG@SSOP20 [ (SA626A) ]		Z8F1232HJ020EG@SSOP28
[ (SA626A) ]		
Z8F1232HJ020SG@SSOP28 [ (SA626A) ]		
Z8F1232PH020EG		
Z8F1232PH020SG		
Z8F1232PJ020EG		
Z8F1232PJ020SG		Z8F1232QH020EG@QFN20
[ (SA759) ]		
Z8F1232QH020SG@QFN20 [ (SA759) ]		Z8F1232QJ020EG@QFN28
[ (SA697) ]		
Z8F1232QJ020SG@QFN28 [ (SA697) ]		Z8F1232SH020EG@SOIC20
[ (SA404) ]		
Z8F1232SH020SG@SOIC20 [ (SA404) ]		Z8F1232SJ020EG@SOIC28
[ (SA404) ]		
Z8F1232SJ020SG@SOIC28 [ (SA404) ]		Z8F1233HH020EG@SSOP20
[ (SA626A) ]		
Z8F1233HH020SG@SSOP20 [ (SA626A) ]		Z8F1233HJ020EG@SSOP28
[ (SA626A) ]		
Z8F1233HJ020SG@SSOP28 [ (SA626A) ]		
Z8F1233PH020EG		
Z8F1233PH020SG		
Z8F1233PJ020EG		
Z8F1233PJ020SG		Z8F1233QH020EG@QFN20
[ (SA759) ]		
Z8F1233QH020SG@QFN20 [ (SA759) ]		Z8F1233QJ020EG@QFN28
[ (SA697) ]		
Z8F1233QJ020SG@QFN28 [ (SA697) ]		Z8F1233SH020EG@SOIC20
[ (SA404) ]		
Z8F1233SH020SG@SOIC20 [ (SA404) ]		Z8F1233SJ020EG@SOIC28
[ (SA404) ]		
Z8F1233SJ020SG@SOIC28 [ (SA404) ]		Z8F1601AN020SC@LQFP44
[ (SA245A) ]		
Z8F1601PM020SC		Z8F1601VN020EC@PLCC44
[ (SA244) ]		
Z8F1621AN020AC@LQFP44 [ (SA245A) ]		Z8F1621AN020AG@LQFP44
[ (SA245A) ]		
Z8F1621AN020EC@LQFP44 [ (SA245A) ]		Z8F1621AN020EG@LQFP44
[ (SA245A) ]		
Z8F1621AN020SC@LQFP44 [ (SA245A) ]		Z8F1621AN020SG@LQFP44
[ (SA245A) ]		

Z8F1621PM020AC

Z8F1621PM020AG

Z8F1621PM020EC

Z8F1621PM020EG

Z8F1621PM020SC

Z8F1621PM020SG

Z8F1621VN020AC@PLCC44 [ (SA244) ]

Z8F1621VN020AG@PLCC44

[ (SA244) ]

Z8F1621VN020EC@PLCC44 [ (SA244) ]

Z8F1621VN020EG@PLCC44

[ (SA244) ]

Z8F1621VN020SC@PLCC44 [ (SA244) ]

Z8F1621VN020SG@PLCC44

[ (SA244) ]

Z8F1622AR020AC@LQFP64 [ (PEP+S616) ]

Z8F1622AR020AG@LQFP64 [ (PEP+S616) ]

Z8F1622AR020EC@LQFP64 [ (PEP+S616) ]

Z8F1622AR020EG@LQFP64 [ (PEP+S616) ]

Z8F1622AR020SC@LQFP64 [ (PEP+S616) ]

Z8F1622AR020SG@LQFP64 [ (PEP+S616) ]

Z8F1622VS020AC@PLCC68 [ (PEP+S414T) ]

Z8F1622VS020AG@PLCC68 [ (PEP+S414T) ]

Z8F1622VS020EC@PLCC68 [ (PEP+S414T) ]

Z8F1622VS020EG@PLCC68 [ (PEP+S414T) ]

Z8F1622VS020SC@PLCC68 [ (PEP+S414T) ]

Z8F1622VS020SG@PLCC68 [ (PEP+S414T) ]

Z8F2421AN020AC@LQFP44 [ (SA245A) ]

Z8F2421AN020AG@LQFP44

[ (SA245A) ]

Z8F2421AN020EC@LQFP44 [ (SA245A) ]

Z8F2421AN020EG@LQFP44

[ (SA245A) ]

Z8F2421AN020SC@LQFP44 [ (SA245A) ]

Z8F2421AN020SG@LQFP44

[ (SA245A) ]

Z8F2421PM020AC

Z8F2421PM020AG

Z8F2421PM020EC

Z8F2421PM020EG

Z8F2421PM020SC

Z8F2421PM020SG

Z8F2421VN020AC@PLCC44 [ (SA244) ]

Z8F2421VN020AG@PLCC44

[ (SA244) ]

Z8F2421VN020EC@PLCC44 [ (SA244) ]

Z8F2421VN020EG@PLCC44

[ (SA244) ]

Z8F2421VN020SC@PLCC44 [ (SA244) ]

Z8F2421VN020SG@PLCC44

[ (SA244) ]

Z8F2422AR020AC@LQFP64 [ (PEP+S616) ]

Z8F2422AR020AG@LQFP64 [ ( PEP+S616 ) ]  
 Z8F2422AR020EC@LQFP64 [ ( PEP+S616 ) ]  
 Z8F2422AR020EG@LQFP64 [ ( PEP+S616 ) ]  
 Z8F2422AR020SC@LQFP64 [ ( PEP+S616 ) ]  
 Z8F2422AR020SG@LQFP64 [ ( PEP+S616 ) ]  
 Z8F2422VS020AC@PLCC68 [ ( PEP+S414T ) ]  
 Z8F2422VS020AG@PLCC68 [ ( PEP+S414T ) ]  
 Z8F2422VS020EC@PLCC68 [ ( PEP+S414T ) ]  
 Z8F2422VS020EG@PLCC68 [ ( PEP+S414T ) ]  
 Z8F2422VS020SC@PLCC68 [ ( PEP+S414T ) ]  
 Z8F2422VS020SG@PLCC68 [ ( PEP+S414T ) ]  
 Z8F3221AN020AC@LQFP44 [ ( SA245A ) ]      Z8F3221AN020AG@LQFP44  
 [ ( SA245A ) ]  
 Z8F3221AN020EC@LQFP44 [ ( SA245A ) ]      Z8F3221AN020EG@LQFP44  
 [ ( SA245A ) ]  
 Z8F3221AN020SC@LQFP44 [ ( SA245A ) ]      Z8F3221AN020SG@LQFP44  
 [ ( SA245A ) ]  
 Z8F3221PM020AC  
 Z8F3221PM020AG  
 Z8F3221PM020EC  
 Z8F3221PM020EG  
 Z8F3221PM020SC  
 Z8F3221PM020SG  
 Z8F3221VN020AC@PLCC44 [ ( SA244 ) ]      Z8F3221VN020AG@PLCC44  
 [ ( SA244 ) ]  
 Z8F3221VN020EC@PLCC44 [ ( SA244 ) ]      Z8F3221VN020EG@PLCC44  
 [ ( SA244 ) ]  
 Z8F3221VN020SC@PLCC44 [ ( SA244 ) ]      Z8F3221VN020SG@PLCC44  
 [ ( SA244 ) ]  
 Z8F3222AR020AC@LQFP64 [ ( PEP+S616 ) ]  
 Z8F3222AR020AG@LQFP64 [ ( PEP+S616 ) ]  
 Z8F3222AR020EC@LQFP64 [ ( PEP+S616 ) ]  
 Z8F3222AR020EG@LQFP64 [ ( PEP+S616 ) ]  
 Z8F3222AR020SC@LQFP64 [ ( PEP+S616 ) ]  
 Z8F3222AR020SG@LQFP64 [ ( PEP+S616 ) ]  
 Z8F3222VS020AC@PLCC68 [ ( PEP+S414T ) ]  
 Z8F3222VS020AG@PLCC68 [ ( PEP+S414T ) ]  
 Z8F3222VS020EC@PLCC68 [ ( PEP+S414T ) ]  
 Z8F3222VS020EG@PLCC68 [ ( PEP+S414T ) ]  
 Z8F3222VS020SC@PLCC68 [ ( PEP+S414T ) ]  
 Z8F3222VS020SG@PLCC68 [ ( PEP+S414T ) ]  
 Z8F4801AN@TQFP44 [ ( SA245A ) ]  
 Z8F4801PM

Z8F4801VN@PLCC44 [(SA244)]  
Z8F4802AR020SC@LQFP64 [(PEP+S616)]  
Z8F4821AN020AC@LQFP44 [(SA245A)] Z8F4821AN020AG@LQFP44  
[(SA245A)]  
Z8F4821AN020EC@LQFP44 [(SA245A)] Z8F4821AN020EG@LQFP44  
[(SA245A)]  
Z8F4821AN020EG21@LQFP44 [(SA245A)]  
Z8F4821AN020SC@LQFP44 [(SA245A)] Z8F4821AN020SG@LQFP44  
[(SA245A)]  
Z8F4821AN020SG21@LQFP44 [(SA245A)]  
Z8F4821PM020AC  
Z8F4821PM020AG  
Z8F4821PM020EC  
Z8F4821PM020EG  
Z8F4821PM020SC  
Z8F4821PM020SG  
Z8F4821VN020AC@PLCC44 [(SA244)] Z8F4821VN020AG@PLCC44  
[(SA244)]  
Z8F4821VN020EC@PLCC44 [(SA244)] Z8F4821VN020EG@PLCC44  
[(SA244)]  
Z8F4821VN020SC@PLCC44 [(SA244)] Z8F4821VN020SG@PLCC44  
[(SA244)]  
Z8F4822AR020AC@LQFP64 [(PEP+S616)]  
Z8F4822AR020AG@LQFP64 [(PEP+S616)]  
Z8F4822AR020EC@LQFP64 [(PEP+S616)]  
Z8F4822AR020EG@LQFP64 [(PEP+S616)]  
Z8F4822AR020SC@LQFP64 [(PEP+S616)]  
Z8F4822AR020SG@LQFP64 [(PEP+S616)]  
Z8F4822VS020AC@PLCC68 [(PEP+S414T)]  
Z8F4822VS020AG@PLCC68 [(PEP+S414T)]  
Z8F4822VS020EC@PLCC68 [(PEP+S414T)]  
Z8F4822VS020EG@PLCC68 [(PEP+S414T)]  
Z8F4822VS020SC@PLCC68 [(PEP+S414T)]  
Z8F4822VS020SG@PLCC68 [(PEP+S414T)]  
Z8F4823FT020AC@QFP80 [(PEP+S611A)]  
Z8F4823FT020AG@QFP80 [(PEP+S611A)]  
Z8F4823FT020EC@QFP80 [(PEP+S611A)]  
Z8F4823FT020EG@QFP80 [(PEP+S611A)]  
Z8F4823FT020SC@QFP80 [(PEP+S611A)]  
Z8F4823FT020SG@QFP80 [(PEP+S611A)]  
Z8F6401AN@TQFP44 [(SA245A)]  
Z8F6401PM  
Z8F6401VN@PLCC44 [(SA244)]

Z8F6402AR020EC@LQFP64 [(PEP+S616)]  
 Z8F6402AR020SC@LQFP64 [(PEP+S616)]  
 Z8F6402VS020SC@PLCC68 [(PEP+S414T)]  
 Z8F6403FT020EC@QFP80 [(PEP+S611A)]  
 Z8F6403FT020SC@QFP80 [(PEP+S611A)]  
 Z8F6421AN020AC@LQFP44 [(SA245A)] Z8F6421AN020AG@LQFP44  
 [(SA245A)]  
 Z8F6421AN020EC@LQFP44 [(SA245A)] Z8F6421AN020EG@LQFP44  
 [(SA245A)]  
 Z8F6421AN020SC@LQFP44 [(SA245A)] Z8F6421AN020SG@LQFP44  
 [(SA245A)]  
 Z8F6421PM020AC  
 Z8F6421PM020AG  
 Z8F6421PM020EC  
 Z8F6421PM020EG  
 Z8F6421PM020SC  
 Z8F6421PM020SG  
 Z8F6421VN020AC@PLCC44 [(SA244)] Z8F6421VN020AG@PLCC44  
 [(SA244)]  
 Z8F6421VN020EC@PLCC44 [(SA244)] Z8F6421VN020EG@PLCC44  
 [(SA244)]  
 Z8F6421VN020SC@PLCC44 [(SA244)] Z8F6421VN020SG@PLCC44  
 [(SA244)]  
 Z8F6422AR020AC@LQFP64 [(PEP+S616)]  
 Z8F6422AR020AG@LQFP64 [(PEP+S616)]  
 Z8F6422AR020EC@LQFP64 [(PEP+S616)]  
 Z8F6422AR020EG@LQFP64 [(PEP+S616)]  
 Z8F6422AR020SC@LQFP64 [(PEP+S616)]  
 Z8F6422AR020SG@LQFP64 [(PEP+S616)]  
 Z8F6422VS020AC@PLCC68 [(PEP+S414T)]  
 Z8F6422VS020AG@PLCC68 [(PEP+S414T)]  
 Z8F6422VS020EC@PLCC68 [(PEP+S414T)]  
 Z8F6422VS020EG@PLCC68 [(PEP+S414T)]  
 Z8F6422VS020SC@PLCC68 [(PEP+S414T)]  
 Z8F6422VS020SG@PLCC68 [(PEP+S414T)]  
 Z8F6423FT020AC@QFP80 [(PEP+S611A)]  
 Z8F6423FT020AG@QFP80 [(PEP+S611A)]  
 Z8F6423FT020EC@QFP80 [(PEP+S611A)]  
 Z8F6423FT020EG@QFP80 [(PEP+S611A)]  
 Z8F6423FT020SC@QFP80 [(PEP+S611A)]  
 Z8F6423FT020SG@QFP80 [(PEP+S611A)]  
 Z8FMC04100AKEG@QFP32 [(SA663)] Z8FMC04100AKSG@QFP32  
 [(SA663)]

Z8FMC04100QKEG@QFN32 [(SA686)]	Z8FMC04100QKSG@QFN32
[(SA686)]	
Z8FMC08100AKEG@QFP32 [(SA663)]	Z8FMC08100AKSG@QFP32
[(SA663)]	
Z8FMC08100QKEG@QFN32 [(SA686)]	Z8FMC08100QKSG@QFN32
[(SA686)]	
Z8FMC16100AKEG@QFP32 [(SA663)]	Z8FMC16100AKSG@QFP32
[(SA663)]	
Z8FMC16100QKEG@QFN32 [(SA686)]	Z8FMC16100QKSG@QFN32
[(SA686)]	
Z8PE00210HEC@SSOP20 [(SA626A)]	Z8PE00210HSC@SSOP20
[(SA626A)]	
Z8PE00210PEC	
Z8PE00210PSC	
Z8PE00210SEC@SOIC18 [(SA404)]	Z8PE00210SSC@SOIC18
[(SA404)]	
Z8PE00210SSG@SOIC18 [(SA404)]	Z8PE00310HEC@SSOP20
[(SA626A)]	
Z8PE00310HSC@SSOP20 [(SA626A)]	
Z8PE00310PEC	
Z8PE00310PSC	Z8PE00310SEC@SOIC18
[(SA404)]	
Z8PE00310SSC@SOIC18 [(SA404)]	Z8PE00310SSG@SOIC18
[(SA404)]	
ZGP323HAH2004C@SSOP20 [(SA626A)]	ZGP323HAH2004G@SSOP20
[(SA626A)]	
ZGP323HAH2008C@SSOP20 [(SA626A)]	ZGP323HAH2008G@SSOP20
[(SA626A)]	
ZGP323HAH2016C@SSOP20 [(SA626A)]	ZGP323HAH2016G@SSOP20
[(SA626A)]	
ZGP323HAH2032C@SSOP20 [(SA626A)]	ZGP323HAH2032G@SSOP20
[(SA626A)]	
ZGP323HAH2804C@SSOP28 [(SA626A)]	ZGP323HAH2804G@SSOP28
[(SA626A)]	
ZGP323HAH2808C@SSOP28 [(SA626A)]	ZGP323HAH2808G@SSOP28
[(SA626A)]	
ZGP323HAH2816C@SSOP28 [(SA626A)]	ZGP323HAH2816G@SSOP28
[(SA626A)]	
ZGP323HAH2832C@SSOP28 [(SA626A)]	ZGP323HAH2832G@SSOP28
[(SA626A)]	
ZGP323HAH4804C@SSOP48 [(SA669)]	ZGP323HAH4804G@SSOP48
[(SA669)]	
ZGP323HAH4808C@SSOP48 [(SA669)]	ZGP323HAH4808G@SSOP48

[ ( SA669 ) ]

ZGP323HAH4816C@SSOP48 [ ( SA669 ) ]

ZGP323HAH4816G@SSOP48

[ ( SA669 ) ]

ZGP323HAH4832C@SSOP48 [ ( SA669 ) ]

ZGP323HAH4832G@SSOP48

[ ( SA669 ) ]

ZGP323HAP2004C

ZGP323HAP2004G

ZGP323HAP2008C

ZGP323HAP2008G

ZGP323HAP2016C

ZGP323HAP2016G

ZGP323HAP2032C

ZGP323HAP2032G

ZGP323HAP2804C

ZGP323HAP2804G

ZGP323HAP2808C

ZGP323HAP2808G

ZGP323HAP2816C

ZGP323HAP2816G

ZGP323HAP2832C

ZGP323HAP2832G

ZGP323HAP4004C

ZGP323HAP4004G

ZGP323HAP4008C

ZGP323HAP4008G

ZGP323HAP4016C

ZGP323HAP4016G

ZGP323HAP4032C

ZGP323HAP4032G

ZGP323HAS2004C@SOIC20 [ ( SA404 ) ]

ZGP323HAS2004G@SOIC20

[ ( SA404 ) ]

ZGP323HAS2008C@SOIC20 [ ( SA404 ) ]

ZGP323HAS2008G@SOIC20

[ ( SA404 ) ]

ZGP323HAS2016C@SOIC20 [ ( SA404 ) ]

ZGP323HAS2016G@SOIC20

[ ( SA404 ) ]

ZGP323HAS2032C@SOIC20 [ ( SA404 ) ]

ZGP323HAS2032G@SOIC20

[ ( SA404 ) ]

ZGP323HAS2804C@SOIC28 [ ( SA404 ) ]

ZGP323HAS2804G@SOIC28

[ ( SA404 ) ]

ZGP323HAS2808C@SOIC28 [ ( SA404 ) ]

ZGP323HAS2808G@SOIC28

[ ( SA404 ) ]

ZGP323HAS2816C@SOIC28 [ ( SA404 ) ]

ZGP323HAS2816G@SOIC28

[ ( SA404 ) ]

ZGP323HAS2832C@SOIC28 [(SA404)]	ZGP323HAS2832G@SOIC28
[(SA404)]	
ZGP323HEH2004C@SSOP20 [(SA626A)]	ZGP323HEH2004G@SSOP20
[(SA626A)]	
ZGP323HEH2008C@SSOP20 [(SA626A)]	ZGP323HEH2008G@SSOP20
[(SA626A)]	
ZGP323HEH2016C@SSOP20 [(SA626A)]	ZGP323HEH2016G@SSOP20
[(SA626A)]	
ZGP323HEH2032C@SSOP20 [(SA626A)]	ZGP323HEH2032G@SSOP20
[(SA626A)]	
ZGP323HEH2804C@SSOP28 [(SA626A)]	ZGP323HEH2804G@SSOP28
[(SA626A)]	
ZGP323HEH2808C@SSOP28 [(SA626A)]	ZGP323HEH2808G@SSOP28
[(SA626A)]	
ZGP323HEH2816C@SSOP28 [(SA626A)]	ZGP323HEH2816G@SSOP28
[(SA626A)]	
ZGP323HEH2832C@SSOP28 [(SA626A)]	ZGP323HEH2832G@SSOP28
[(SA626A)]	
ZGP323HEH4804C@SSOP48 [(SA669)]	ZGP323HEH4804G@SSOP48
[(SA669)]	
ZGP323HEH4808C@SSOP48 [(SA669)]	ZGP323HEH4808G@SSOP48
[(SA669)]	
ZGP323HEH4816C@SSOP48 [(SA669)]	ZGP323HEH4816G@SSOP48
[(SA669)]	
ZGP323HEH4832C@SSOP48 [(SA669)]	ZGP323HEH4832G@SSOP48
[(SA669)]	
ZGP323HEP2004C	
ZGP323HEP2004G	
ZGP323HEP2008C	
ZGP323HEP2008G	
ZGP323HEP2016C	
ZGP323HEP2016G	
ZGP323HEP2032C	
ZGP323HEP2032G	
ZGP323HEP2804C	
ZGP323HEP2804G	
ZGP323HEP2808C	
ZGP323HEP2808G	
ZGP323HEP2816C	
ZGP323HEP2816G	
ZGP323HEP2832C	
ZGP323HEP2832G	
ZGP323HEP4004C	



ZGP323HEP4004G  
ZGP323HEP4008C  
ZGP323HEP4008G  
ZGP323HEP4016C  
ZGP323HEP4016G  
ZGP323HEP4032C  
ZGP323HEP4032G

ZGP323HES2004C@SOIC20 [ ( SA404 ) ]  
[ ( SA404 ) ]

ZGP323HES2004G@SOIC20

ZGP323HES2008C@SOIC20 [ ( SA404 ) ]  
[ ( SA404 ) ]

ZGP323HES2008G@SOIC20

ZGP323HES2016C@SOIC20 [ ( SA404 ) ]  
[ ( SA404 ) ]

ZGP323HES2016G@SOIC20

ZGP323HES2032C@SOIC20 [ ( SA404 ) ]  
[ ( SA404 ) ]

ZGP323HES2032G@SOIC20

ZGP323HES2804C@SOIC28 [ ( SA404 ) ]  
[ ( SA404 ) ]

ZGP323HES2804G@SOIC28

ZGP323HES2808C@SOIC28 [ ( SA404 ) ]  
[ ( SA404 ) ]

ZGP323HES2808G@SOIC28

ZGP323HES2816C@SOIC28 [ ( SA404 ) ]  
[ ( SA404 ) ]

ZGP323HES2816G@SOIC28

ZGP323HES2832C@SOIC28 [ ( SA404 ) ]  
[ ( SA404 ) ]

ZGP323HES2832G@SOIC28

ZGP323HSH2004C@SSOP20 [ ( SA626A ) ]  
[ ( SA626A ) ]

ZGP323HSH2004G@SSOP20

ZGP323HSH2008C@SSOP20 [ ( SA626A ) ]  
[ ( SA626A ) ]

ZGP323HSH2008G@SSOP20

ZGP323HSH2016C@SSOP20 [ ( SA626A ) ]  
[ ( SA626A ) ]

ZGP323HSH2016G@SSOP20

ZGP323HSH2032C@SSOP20 [ ( SA626A ) ]  
[ ( SA626A ) ]

ZGP323HSH2032G@SSOP20

ZGP323HSH2804C@SSOP28 [ ( SA626A ) ]  
[ ( SA626A ) ]

ZGP323HSH2804G@SSOP28

ZGP323HSH2808C@SSOP28 [ ( SA626A ) ]  
[ ( SA626A ) ]

ZGP323HSH2808G@SSOP28

ZGP323HSH2816C@SSOP28 [ ( SA626A ) ]  
[ ( SA626A ) ]

ZGP323HSH2816G@SSOP28

ZGP323HSH2832C@SSOP28 [ ( SA626A ) ]  
[ ( SA626A ) ]

ZGP323HSH2832G@SSOP28

ZGP323HSH4804C@SSOP48 [ ( SA669 ) ]  
[ ( SA669 ) ]

ZGP323HSH4804G@SSOP48

ZGP323HSH4808C@SSOP48 [ ( SA669 ) ]  
[ ( SA669 ) ]

ZGP323HSH4808G@SSOP48

ZGP323HSH4816C@SSOP48 [(SA669)]	ZGP323HSH4816G@SSOP48
[(SA669)]	
ZGP323HSH4832C@SSOP48 [(SA669)]	ZGP323HSH4832G@SSOP48
[(SA669)]	
ZGP323HSP2004C	
ZGP323HSP2004G	
ZGP323HSP2008C	
ZGP323HSP2008G	
ZGP323HSP2016C	
ZGP323HSP2016G	
ZGP323HSP2032C	
ZGP323HSP2032G	
ZGP323HSP2804C	
ZGP323HSP2804G	
ZGP323HSP2808C	
ZGP323HSP2808G	
ZGP323HSP2816C	
ZGP323HSP2816G	
ZGP323HSP2832C	
ZGP323HSP2832G	
ZGP323HSP4004C	
ZGP323HSP4004G	
ZGP323HSP4008C	
ZGP323HSP4008G	
ZGP323HSP4016C	
ZGP323HSP4016G	
ZGP323HSP4032C	
ZGP323HSP4032G	
ZGP323HSS2004C@SOIC20 [(SA404)]	ZGP323HSS2004G@SOIC20
[(SA404)]	
ZGP323HSS2008C@SOIC20 [(SA404)]	ZGP323HSS2008G@SOIC20
[(SA404)]	
ZGP323HSS2016C@SOIC20 [(SA404)]	ZGP323HSS2016G@SOIC20
[(SA404)]	
ZGP323HSS2032C@SOIC20 [(SA404)]	ZGP323HSS2032G@SOIC20
[(SA404)]	
ZGP323HSS2804C@SOIC28 [(SA404)]	ZGP323HSS2804G@SOIC28
[(SA404)]	
ZGP323HSS2808C@SOIC28 [(SA404)]	ZGP323HSS2808G@SOIC28
[(SA404)]	
ZGP323HSS2816C@SOIC28 [(SA404)]	ZGP323HSS2816G@SOIC28
[(SA404)]	
ZGP323HSS2832C@SOIC28 [(SA404)]	ZGP323HSS2832G@SOIC28

[ ( SA404 ) ]

ZGP323LAH2004C@SSOP20 [ ( SA626A ) ]

ZGP323LAH2004G@SSOP20

[ ( SA626A ) ]

ZGP323LAH2008C@SSOP20 [ ( SA626A ) ]

ZGP323LAH2008G@SSOP20

[ ( SA626A ) ]

ZGP323LAH2016C@SSOP20 [ ( SA626A ) ]

ZGP323LAH2016G@SSOP20

[ ( SA626A ) ]

ZGP323LAH2032C@SSOP20 [ ( SA626A ) ]

ZGP323LAH2032G@SSOP20

[ ( SA626A ) ]

ZGP323LAH2804C@SSOP28 [ ( SA626A ) ]

ZGP323LAH2804G@SSOP28

[ ( SA626A ) ]

ZGP323LAH2808C@SSOP28 [ ( SA626A ) ]

ZGP323LAH2808G@SSOP28

[ ( SA626A ) ]

ZGP323LAH2816C@SSOP28 [ ( SA626A ) ]

ZGP323LAH2816G@SSOP28

[ ( SA626A ) ]

ZGP323LAH2832C@SSOP28 [ ( SA626A ) ]

ZGP323LAH2832G@SSOP28

[ ( SA626A ) ]

ZGP323LAH4804C@SSOP48 [ ( SA669 ) ]

ZGP323LAH4804G@SSOP48

[ ( SA669 ) ]

ZGP323LAH4808C@SSOP48 [ ( SA669 ) ]

ZGP323LAH4808G@SSOP48

[ ( SA669 ) ]

ZGP323LAH4816C@SSOP48 [ ( SA669 ) ]

ZGP323LAH4816G@SSOP48

[ ( SA669 ) ]

ZGP323LAH4832C@SSOP48 [ ( SA669 ) ]

ZGP323LAH4832G@SSOP48

[ ( SA669 ) ]

ZGP323LAP2004C

ZGP323LAP2004G

ZGP323LAP2008C

ZGP323LAP2008G

ZGP323LAP2016C

ZGP323LAP2016G

ZGP323LAP2032C

ZGP323LAP2032G

ZGP323LAP2804C

ZGP323LAP2804G

ZGP323LAP2808C

ZGP323LAP2808G

ZGP323LAP2816C

ZGP323LAP2816G

ZGP323LAP2832C

ZGP323LAP2832G

ZGP323LAP4004C

ZGP323LAP4004G

ZGP323LAP4008C

ZGP323LAP4008G

ZGP323LAP4016C

ZGP323LAP4016G

ZGP323LAP4032C

ZGP323LAP4032G

ZGP323LAS2004C@SOIC20 [(SA404)]  
[(SA404)]

ZGP323LAS2004G@SOIC20

ZGP323LAS2008C@SOIC20 [(SA404)]  
[(SA404)]

ZGP323LAS2008G@SOIC20

ZGP323LAS2016C@SOIC20 [(SA404)]  
[(SA404)]

ZGP323LAS2016G@SOIC20

ZGP323LAS2032C@SOIC20 [(SA404)]  
[(SA404)]

ZGP323LAS2032G@SOIC20

ZGP323LAS2804C@SOIC28 [(SA404)]  
[(SA404)]

ZGP323LAS2804G@SOIC28

ZGP323LAS2808C@SOIC28 [(SA404)]  
[(SA404)]

ZGP323LAS2808G@SOIC28

ZGP323LAS2816C@SOIC28 [(SA404)]  
[(SA404)]

ZGP323LAS2816G@SOIC28

ZGP323LAS2832C@SOIC28 [(SA404)]  
[(SA404)]

ZGP323LAS2832G@SOIC28

ZGP323LEH2004C@SSOP20 [(SA626A)]  
[(SA626A)]

ZGP323LEH2004G@SSOP20

ZGP323LEH2008C@SSOP20 [(SA626A)]  
[(SA626A)]

ZGP323LEH2008G@SSOP20

ZGP323LEH2016C@SSOP20 [(SA626A)]  
[(SA626A)]

ZGP323LEH2016G@SSOP20

ZGP323LEH2032C@SSOP20 [(SA626A)]  
[(SA626A)]

ZGP323LEH2032G@SSOP20

ZGP323LEH2804C@SSOP28 [(SA626A)]  
[(SA626A)]

ZGP323LEH2804G@SSOP28

ZGP323LEH2808C@SSOP28 [(SA626A)]  
[(SA626A)]

ZGP323LEH2808G@SSOP28

ZGP323LEH2816C@SSOP28 [(SA626A)]  
[(SA626A)]

ZGP323LEH2816G@SSOP28

ZGP323LEH2832C@SSOP28 [(SA626A)]  
[(SA626A)]

ZGP323LEH2832G@SSOP28

ZGP323LEH4804C@SSOP48 [(SA669)]  
[(SA669)]

ZGP323LEH4804G@SSOP48

ZGP323LEH4808C@SSOP48 [(SA669)]  
[(SA669)]

ZGP323LEH4808G@SSOP48

ZGP323LEH4816C@SSOP48 [(SA669)]

ZGP323LEH4816G@SSOP48

[ ( SA669 ) ]

ZGP323LEH4832C@SSOP48 [ ( SA669 ) ]

ZGP323LEH4832G@SSOP48

[ ( SA669 ) ]

ZGP323LEP2004C

ZGP323LEP2004G

ZGP323LEP2008C

ZGP323LEP2008G

ZGP323LEP2016C

ZGP323LEP2016G

ZGP323LEP2032C

ZGP323LEP2032G

ZGP323LEP2804C

ZGP323LEP2804G

ZGP323LEP2808C

ZGP323LEP2808G

ZGP323LEP2816C

ZGP323LEP2816G

ZGP323LEP2832C

ZGP323LEP2832G

ZGP323LEP4004C

ZGP323LEP4004G

ZGP323LEP4008C

ZGP323LEP4008G

ZGP323LEP4016C

ZGP323LEP4016G

ZGP323LEP4032C

ZGP323LEP4032G

ZGP323LES2004C@SOIC20 [ ( SA404 ) ]

ZGP323LES2004G@SOIC20

[ ( SA404 ) ]

ZGP323LES2008C@SOIC20 [ ( SA404 ) ]

ZGP323LES2008G@SOIC20

[ ( SA404 ) ]

ZGP323LES2016C@SOIC20 [ ( SA404 ) ]

ZGP323LES2016G@SOIC20

[ ( SA404 ) ]

ZGP323LES2032C@SOIC20 [ ( SA404 ) ]

ZGP323LES2032G@SOIC20

[ ( SA404 ) ]

ZGP323LES2804C@SOIC28 [ ( SA404 ) ]

ZGP323LES2804G@SOIC28

[ ( SA404 ) ]

ZGP323LES2808C@SOIC28 [ ( SA404 ) ]

ZGP323LES2808G@SOIC28

[ ( SA404 ) ]

ZGP323LES2816C@SOIC28 [ ( SA404 ) ]

ZGP323LES2816G@SOIC28

[ ( SA404 ) ]

ZGP323LES2832C@SOIC28 [ ( SA404 ) ]

ZGP323LES2832G@SOIC28

[ ( SA404 ) ]

ZGP323LSH2004C@SSOP20 [(SA626A)]	ZGP323LSH2004G@SSOP20
[(SA626A)]	
ZGP323LSH2008C@SSOP20 [(SA626A)]	ZGP323LSH2008G@SSOP20
[(SA626A)]	
ZGP323LSH2016C@SSOP20 [(SA626A)]	ZGP323LSH2016G@SSOP20
[(SA626A)]	
ZGP323LSH2032C@SSOP20 [(SA626A)]	ZGP323LSH2032G@SSOP20
[(SA626A)]	
ZGP323LSH2804C@SSOP28 [(SA626A)]	ZGP323LSH2804G@SSOP28
[(SA626A)]	
ZGP323LSH2808C@SSOP28 [(SA626A)]	ZGP323LSH2808G@SSOP28
[(SA626A)]	
ZGP323LSH2816C@SSOP28 [(SA626A)]	ZGP323LSH2816G@SSOP28
[(SA626A)]	
ZGP323LSH2832C@SSOP28 [(SA626A)]	ZGP323LSH2832G@SSOP28
[(SA626A)]	
ZGP323LSH4804C@SSOP48 [(SA669)]	ZGP323LSH4804G@SSOP48
[(SA669)]	
ZGP323LSH4808C@SSOP48 [(SA669)]	ZGP323LSH4808G@SSOP48
[(SA669)]	
ZGP323LSH4816C@SSOP48 [(SA669)]	ZGP323LSH4816G@SSOP48
[(SA669)]	
ZGP323LSH4832C@SSOP48 [(SA669)]	ZGP323LSH4832G@SSOP48
[(SA669)]	
ZGP323LSK2032E	
ZGP323LSK2032G	
ZGP323LSK2832E	
ZGP323LSK2832G	
ZGP323LSK4032E	
ZGP323LSK4032G	
ZGP323LSP2004C	
ZGP323LSP2004G	
ZGP323LSP2008C	
ZGP323LSP2008G	
ZGP323LSP2016C	
ZGP323LSP2016G	
ZGP323LSP2032C	
ZGP323LSP2032G	
ZGP323LSP2804C	
ZGP323LSP2804G	
ZGP323LSP2808C	
ZGP323LSP2808G	
ZGP323LSP2816C	

ZGP323LSP2816G

ZGP323LSP2832C

ZGP323LSP2832G

ZGP323LSP4004C

ZGP323LSP4004G

ZGP323LSP4008C

ZGP323LSP4008G

ZGP323LSP4016C

ZGP323LSP4016G

ZGP323LSP4032C

ZGP323LSP4032G

ZGP323LSS2004C@SOIC20 [ (SA404) ]

ZGP323LSS2004G@SOIC20

[ (SA404) ]

ZGP323LSS2008C@SOIC20 [ (SA404) ]

ZGP323LSS2008G@SOIC20

[ (SA404) ]

ZGP323LSS2016C@SOIC20 [ (SA404) ]

ZGP323LSS2016G@SOIC20

[ (SA404) ]

ZGP323LSS2032C@SOIC20 [ (SA404) ]

ZGP323LSS2032G@SOIC20

[ (SA404) ]

ZGP323LSS2804C@SOIC28 [ (SA404) ]

ZGP323LSS2804G@SOIC28

[ (SA404) ]

ZGP323LSS2808C@SOIC28 [ (SA404) ]

ZGP323LSS2808G@SOIC28

[ (SA404) ]

ZGP323LSS2816C@SOIC28 [ (SA404) ]

ZGP323LSS2816G@SOIC28

[ (SA404) ]

ZGP323LSS2832C@SOIC28 [ (SA404) ]

ZGP323LSS2832G@SOIC28

[ (SA404) ]

ZLP12840H2028C@SSOP20 [ (SA626A) ]

ZLP12840H2028G@SSOP20

[ (SA626A) ]

ZLP12840H2032C@SSOP20 [ (SA626A) ]

ZLP12840H2032G@SSOP20

[ (SA626A) ]

ZLP12840H2064C@SSOP20 [ (SA626A) ]

ZLP12840H2064G@SSOP20

[ (SA626A) ]

ZLP12840H2096C@SSOP20 [ (SA626A) ]

ZLP12840H2096G@SSOP20

[ (SA626A) ]

ZLP12840H2828C@SSOP28 [ (SA626A) ]

ZLP12840H2828G@SSOP28

[ (SA626A) ]

ZLP12840H2832C@SSOP28 [ (SA626A) ]

ZLP12840H2832G@SSOP28

[ (SA626A) ]

ZLP12840H2864C@SSOP28 [ (SA626A) ]

ZLP12840H2864G@SSOP28

[ (SA626A) ]

ZLP12840H2896C@SSOP28 [ (SA626A) ]

ZLP12840H2896G@SSOP28

[ (SA626A) ]

ZLP12840P2028C  
ZLP12840P2028G  
ZLP12840P2032C  
ZLP12840P2032G  
ZLP12840P2064C  
ZLP12840P2064G  
ZLP12840P2096C  
ZLP12840P2096G  
ZLP12840P2828C  
ZLP12840P2828G  
ZLP12840P2832C  
ZLP12840P2832G  
ZLP12840P2864C  
ZLP12840P2864G  
ZLP12840P2896C  
ZLP12840P2896G

ZLP12840S2028C@SOIC20 [(SA404)]  
[(SA404)]  
ZLP12840S2032C@SOIC20 [(SA404)]  
[(SA404)]  
ZLP12840S2064C@SOIC20 [(SA404)]  
[(SA404)]  
ZLP12840S2096C@SOIC20 [(SA404)]  
[(SA404)]  
ZLP12840S2828C@SOIC28 [(SA404)]  
[(SA404)]  
ZLP12840S2832C@SOIC28 [(SA404)]  
[(SA404)]  
ZLP12840S2864C@SOIC28 [(SA404)]  
[(SA404)]  
ZLP12840S2896C@SOIC28 [(SA404)]  
[(SA404)]  
ZLP32300H2004C@SSOP20 [(SA626A)]  
[(SA626A)]  
ZLP32300H2008C@SSOP20 [(SA626A)]  
[(SA626A)]  
ZLP32300H2016C@SSOP20 [(SA626A)]  
[(SA626A)]  
ZLP32300H2032C@SSOP20 [(SA626A)]  
[(SA626A)]  
ZLP32300H2804C@SSOP28 [(SA626A)]  
[(SA626A)]  
ZLP32300H2808C@SSOP28 [(SA626A)]

ZLP12840S2028G@SOIC20  
ZLP12840S2032G@SOIC20  
ZLP12840S2064G@SOIC20  
ZLP12840S2096G@SOIC20  
ZLP12840S2828G@SOIC28  
ZLP12840S2832G@SOIC28  
ZLP12840S2864G@SOIC28  
ZLP12840S2896G@SOIC28  
ZLP32300H2004G@SSOP20  
ZLP32300H2008G@SSOP20  
ZLP32300H2016G@SSOP20  
ZLP32300H2032G@SSOP20  
ZLP32300H2804G@SSOP28  
ZLP32300H2808G@SSOP28



[ ( SA626A ) ]		
ZLP32300H2816C@SSOP28 [ ( SA626A ) ]		ZLP32300H2816G@SSOP28
[ ( SA626A ) ]		
ZLP32300H2832C@SSOP28 [ ( SA626A ) ]		ZLP32300H2832G@SSOP28
[ ( SA626A ) ]		
ZLP32300H4804C@SSOP48 [ ( SA669 ) ]		ZLP32300H4804G@SSOP48
[ ( SA669 ) ]		
ZLP32300H4808C@SSOP48 [ ( SA669 ) ]		ZLP32300H4808G@SSOP48
[ ( SA669 ) ]		
ZLP32300H4816C@SSOP48 [ ( SA669 ) ]		ZLP32300H4816G@SSOP48
[ ( SA669 ) ]		
ZLP32300H4832C@SSOP48 [ ( SA669 ) ]		ZLP32300H4832G@SSOP48
[ ( SA669 ) ]		
ZLP32300P2004C		
ZLP32300P2004G		
ZLP32300P2008C		
ZLP32300P2008G		
ZLP32300P2016C		
ZLP32300P2016G		
ZLP32300P2032C		
ZLP32300P2032G		
ZLP32300P2804C		
ZLP32300P2804G		
ZLP32300P2808C		
ZLP32300P2808G		
ZLP32300P2816C		
ZLP32300P2816G		
ZLP32300P2832C		
ZLP32300P2832G		
ZLP32300P4004C		
ZLP32300P4004G		
ZLP32300P4008C		
ZLP32300P4008G		
ZLP32300P4016C		
ZLP32300P4016G		
ZLP32300P4032C		
ZLP32300P4032G		
ZLP32300S2004C@SOIC20 [ ( SA404 ) ]		ZLP32300S2004G@SOIC20
[ ( SA404 ) ]		
ZLP32300S2008C@SOIC20 [ ( SA404 ) ]		ZLP32300S2008G@SOIC20
[ ( SA404 ) ]		
ZLP32300S2016C@SOIC20 [ ( SA404 ) ]		ZLP32300S2016G@SOIC20
[ ( SA404 ) ]		

ZLP32300S2032C@SOIC20 [(SA404)]	ZLP32300S2032G@SOIC20
[(SA404)]	
ZLP32300S2804C@SOIC28 [(SA404)]	ZLP32300S2804G@SOIC28
[(SA404)]	
ZLP32300S2808C@SOIC28 [(SA404)]	ZLP32300S2808G@SOIC28
[(SA404)]	
ZLP32300S2816C@SOIC28 [(SA404)]	ZLP32300S2816G@SOIC28
[(SA404)]	
ZLP32300S2832C@SOIC28 [(SA404)]	ZLP32300S2832G@SOIC28
[(SA404)]	

## ZMD

### E (E) PROM/FRAM/NVRAM

U62256	
U6264	
U6264@SOIC28 [(SA630)]	
U6264A	
U6264A@SOIC28 [(SA630)]	U62H256A@SOIC28
[(SA630)]	
U62H256S@SOIC28 [(SA630)]	U62H64SA@SOIC28
[(SA630)]	
U630H16	U630H16@SOIC28
[(SA630)]	
U630H64	U630H64@SOIC28
[(SA630)]	
U631H16	U631H16@SOIC24
[(SA404)]	
U631H16@SOIC28 [(SA630)]	
U631H256	
U631H256@SOIC28 [(SA630)]	
U631H64	
U631H64@SOIC28 [(SA630)]	
U632H16	
U632H16@SOIC28 [(SA630)]	
U632H64	
U632H64@SOIC28 [(SA630)]	
U634H256	
U634H256@SOIC32 [(SA630)]	
U635H16	
U635H16@SOIC24 [(SA404)]	

U635H256

U635H256@SOIC28 [(SA630)]

U635H64

U635H64@SOIC28 [(SA630)]

U63716

U637256

U63764

U637H256

UL62H256A@SOIC28

[(SA630)]

UL631H256@SOIC28 [(SA630)]

UL631H256@TSOP32

[(SA410T)]

UL634H256@SOIC32 [(SA630)]

UL634H256@TSOP32

[(SA410T)]

UL635H256@SOIC28 [(SA630)]

UL635H256@TSOP32

[(SA410T)]