

## DEVICE LIST 10/22/2009

Total Manufacturers 188

Total Devices 34955

<a href="#">ACT</a> <a href="#">(Acer)</a>	<a href="#">ACTRANS</a>	<a href="#">ADVANCE GROUP</a>	<a href="#">ALI</a>
<a href="#">ALL 24 SERIES(ISP)</a>		<a href="#">ALLIANCE</a>	
<a href="#">ALTERA</a>			
<a href="#">AMD</a>	<a href="#">AMI SEMICONDUCTOR</a>		
<a href="#">AMIC</a>			
<a href="#">ANACHIP</a> <a href="#">(AKM)</a>	<a href="#">APLUS FLASH</a>	<a href="#">ARTSCHIP</a>	<a href="#">ASAHI KASEI</a>
<a href="#">ASD</a>	<a href="#">ASI</a>	<a href="#">ASP</a>	
<a href="#">ATC</a>			
<a href="#">ATMEL</a>	<a href="#">ATMEL W&amp;M</a>	<a href="#">ATMEL-CUSTOMER</a>	
<a href="#">AUSTIN</a>			
<a href="#">BELLING-SYSTRON</a>	<a href="#">BENCHMARQ</a>	<a href="#">BMT</a>	
<a href="#">BOSEN</a>			
<a href="#">BRIGHT</a>	<a href="#">CATALYST</a>	<a href="#">CELESTICA</a>	
<a href="#">CERAMATE</a>			
<a href="#">CFeon</a>	<a href="#">CHINA CORE</a>	<a href="#">CHINGIS</a>	
<a href="#">CHIPCON</a>			
<a href="#">CHIPSWINNER</a>	<a href="#">CORERIVER</a>	<a href="#">CWI</a>	
<a href="#">CYGNAL</a>			
<a href="#">CYPRESS</a>	<a href="#">DALLAS</a>	<a href="#">DENSE-PAC</a>	
<a href="#">DEUTRON</a>			
<a href="#">EFST</a>	<a href="#">ELECTRONIC ARRAYS</a>		
<a href="#">EM</a>			
<a href="#">EMTC</a>	<a href="#">EON</a>	<a href="#">EPSON</a>	
<a href="#">ESMT</a>			
<a href="#">EXCELSEMI</a>	<a href="#">EXEL</a>	<a href="#">FAIRCHILD</a>	
<a href="#">FORCE TECHNOLOGIES</a>		<a href="#">FORWARD</a>	
<a href="#">FREESCALE</a>			

<a href="#">Fremont Micro Devices</a>		<a href="#">FUJITSU</a>	
<a href="#">GENCORE</a>			
<a href="#">GENERAL(GI)</a>	<a href="#">GENERIC</a>	<a href="#">GIGADEVICE</a>	
<a href="#">GOAL</a>			
<a href="#">GREENWICH</a>	<a href="#">HAIER</a>	<a href="#">HARRIS</a>	
<a href="#">HITACHI</a>			
<a href="#">HOLTEK</a>	<a href="#">HONGKONG</a>	<a href="#">HYNIX</a>	<a href="#">HYNIX-</a>
<a href="#">CUSTOMER</a>			
<a href="#">HYUNDAI</a>	<a href="#">ICE</a>	<a href="#">ICMIC</a>	
<a href="#">ICSI</a>			
<a href="#">ICT</a>	<a href="#">IDT</a>	<a href="#">IMT</a>	
<a href="#">INTEL</a>			
<a href="#">INTEL-CUSTOMER</a>	<a href="#">INTELSIL</a>	<a href="#">ISSI</a>	
<a href="#">ITHINKO</a>			
<a href="#">K-LINE</a>	<a href="#">LATTICE</a>	<a href="#">LG Semicon</a>	
<a href="#">LINKSMART</a>			
<a href="#">MACRONIX</a>	<a href="#">MAXIM</a>	<a href="#">MAXWELL</a>	
<a href="#">MEGAWIN</a>			
<a href="#">MEMOCOM</a>	<a href="#">MICON</a>	<a href="#">MICROCHIP</a>	
<a href="#">MICRON</a>			
<a href="#">MICRONAS</a>	<a href="#">MICRON-CUSTOMER</a>	<a href="#">MITSUBISHI</a>	<a href="#">MOSEL-</a>
<a href="#">VITELIC</a>			
<a href="#">MOSTEK</a>	<a href="#">MOTOROLA</a>	<a href="#">MYSON</a>	
<a href="#">NEC</a>			
<a href="#">NEXFLASH</a>	<a href="#">NJRC</a>	<a href="#">NOVATEK</a>	
<a href="#">NSC</a>			
<a href="#">NTE</a>	<a href="#">NUMONYX</a>	<a href="#">NUVOTON</a>	
<a href="#">NXP</a>			
<a href="#">OKI</a>	<a href="#">ON Semiconductor</a>	<a href="#">PARALLAX</a>	<a href="#">PFLASH</a>
<a href="#">(MSTAR)</a>			
<a href="#">PHILIPS</a>	<a href="#">PJ</a>	<a href="#">PMC</a>	
<a href="#">PSS</a>			
<a href="#">PTC</a>	<a href="#">QIXIN</a>	<a href="#">Quick Pulse</a>	
<a href="#">RAMTRON</a>			
<a href="#">RATO</a>	<a href="#">RAYDIUM</a>	<a href="#">RENESAS</a>	
<a href="#">RICOH</a>			
<a href="#">ROCKWELL</a>	<a href="#">ROHM</a>	<a href="#">SAIFUN</a>	
<a href="#">SAMSUNG</a>			

[SAMSUNG-CUSTOMER](#)    [SANYO](#)    [SCENIX](#)  
[SEEQ](#)  
[SEIKO](#)    [SGS-THOMSON](#)    [SHARP](#)    [SHARP-](#)  
[CUSTOMER](#)  
[SIEMENS](#)    [SIGNETICS](#)    [Silicon](#)  
[Laboratories](#)  
[SILICON7](#)    [SIMTEK](#)    [SMOS](#)  
[SONIX](#)  
[SONY](#)    [SPACE ELECTRONICS\[SEI\]](#)  
[SPANSION](#)  
[SPANSION-CUSTOMER](#)    [SSSC](#)  
[SST](#)  
[ST](#)    [STC](#)    [ST-CUSTOMER](#)  
[SUMMIT](#)  
[SUNPLUS](#)    [SYNCMOS](#)    [SYNERTEK](#)  
[SYNTEK](#)  
[TECHCODE](#)    [TEKMOS](#)    [TEMIC](#)  
[Terra Semiconductor](#)    [TI](#)  
[TMC](#)  
[TOPRO](#)    [TOSHIBA](#)    [TOSHIBA-CUSTOMER](#)    [TURBO](#)  
[IC](#)  
[UBICOM](#)    [UMC](#)    [UTRON](#)  
[VANTIS](#)  
[VERSACHIPS](#)    [VLSI](#)    [WELTREND](#)  
[WHITE ELECTRONIC DESIGNS](#)    [WINBOND](#)  
[WSI](#)  
[XELTEK](#)    [XICOR](#)    [XILINX](#)    [XILINX-](#)  
[CUSTOMER](#)  
[YMC](#)    [YSS](#)    [ZHIXIN](#)  
[ZILOG](#)  
[ZMD](#)

## ACT

[E \( E \) PROM / FRAM / NVRAM](#)

93LC46(08bit) [(SA602A)]	93LC46(08bit)@SOIC8
93LC46(16bit) [(SA602A)]	93LC46(16bit)@SOIC8
93LC56(08bit) [(SA602A)]	93LC56(08bit)@SOIC8
93LC56(16bit) [(SA602A)]	93LC56(16bit)@SOIC8
93LC66(08bit) [(SA602A)]	93LC66(08bit)@SOIC8
93LC66(16bit) [(SA602A)]	93LC66(16bit)@SOIC8
93LC86(08bit) [(SA602A)]	93LC86(08bit)@SOIC8
93LC86(16bit) [(SA602A)]	93LC86(16bit)@SOIC8

## ACTRANS

### E(E) PROM/FRAM/NVRAM

AC25010@SOIC8 [(SA602A)] [(SA602A)]	AC25512@SOIC8
AC25LC010@SOIC8 [(SA602A)] [(SA602A)]	AC25LC512@SOIC8
AC39LV010@FBGA48 [(SA642B-B026A-Y072F001)]	
AC39LV010@PLCC32 [(SA015A1T)] [(SA620)]	AC39LV010@VSOP32
AC39LV020@FBGA48 [(SA642B-B026A-Y072F001)]	
AC39LV020@PLCC32 [(SA015A1T)] [(SA620)]	AC39LV020@VSOP32
AC39LV040@PLCC32 [(SA015A1T)] [(SA620)]	AC39LV040@VSOP32
AC39LV080@FBGA48 [(SA642B-B026A-Y072F001)]	
AC39LV080@TSOP48 [(SA409T)] [(SA247-B005)]	AC39LV088@TSOP48 [(SA247- B005)]
AC39LV512@PLCC32 [(SA015A1T)] [(SA620)]	AC39LV512@VSOP32
AC39VF800@FBGA48 [(SA642B-B026A-Y072F001)]	
AC39VF800@TSOP48 [(SA247-B005)]	

## ADVANCE GROUP

### E ( E ) PROM / FRAM / NVRAM

AF24BC01 [ ( SA602A ) ]	AF24BC01@SOIC8
AF24BC01@TSOP8 [ ( SA026 ) ]	
AF24BC02 AF24BC02@SOIC8 [ ( SA602A ) ]	AF24BC02@TSOP8
[ ( SA026 ) ]	
AF24BC04 [ ( SA602A ) ]	AF24BC04@SOIC8
AF24BC04@TSOP8 [ ( SA026 ) ]	
AF24BC08 AF24BC08@SOIC8 [ ( SA602A ) ]	AF24BC08@TSOP8
[ ( SA026 ) ]	
AF24BC16 [ ( SA602A ) ]	AF24BC16@SOIC8
AF24BC16@TSOP8 [ ( SA026 ) ]	
AF24C128 AF24C128@SOIC8 [ ( SA602A ) ]	AF24C128@TSOP8
[ ( SA026 ) ]	
AF24C256 [ ( SA602A ) ]	AF24C256@SOIC8
AF24C256@TSOP8 [ ( SA026 ) ]	
AF24C32 AF24C32@SOIC8 [ ( SA602A ) ]	AF24C32@TSOP8
[ ( SA026 ) ]	
AF24C64 [ ( SA602A ) ]	AF24C64@SOIC8
AF24C64@TSOP8 [ ( SA026 ) ]	AF93C46
( 08bit )	
AF93C46 ( 08bit ) @ SOIC8 [ ( SA602A ) ]	AF93C46 ( 08bit ) @ TSOP8
[ ( SA026 ) ]	
AF93C46 ( 16bit ) [ ( SA602A ) ]	AF93C46 ( 16bit ) @ SOIC8
AF93C46 ( 16bit ) @ TSOP8 [ ( SA026 ) ]	AF93C56
( 08bit )	
AF93C56 ( 08bit ) @ SOIC8 [ ( SA602A ) ]	AF93C56 ( 08bit ) @ TSOP8
[ ( SA026 ) ]	
AF93C56 ( 16bit ) [ ( SA602A ) ]	AF93C56 ( 16bit ) @ SOIC8
AF93C56 ( 16bit ) @ TSOP8 [ ( SA026 ) ]	AF93C66

(08bit)	
AF93C66(08bit)@SOIC8 [(SA602A)]	AF93C66(08bit)@TSOP8
[(SA026)]	
AF93C66(16bit)	AF93C66(16bit)@SOIC8
[(SA602A)]	
AF93C66(16bit)@TSOP8 [(SA026)]	AF93C86
(08bit)	
AF93C86(08bit)@SOIC8 [(SA602A)]	AF93C86(08bit)@TSOP8
[(SA026)]	
AF93C86(16bit)	AF93C86(16bit)@SOIC8
[(SA602A)]	
AF93C86(16bit)@TSOP8 [(SA026)]	

## MICROCONTROLLER

A1000A2	A1000A2@PLCC44
[(SA244)]	
A1000A2@PQFP44 [(SA245A)]	
A1000A3	
A1000A3@PLCC44 [(SA244)]	A1000A3@PQFP44
[(SA245A)]	
AG1001@SDIP42 [(SA028)]	
AG89F516	
AG89F516@PLCC44 [(SA244)]	AG89F516@PQFP44
[(SA245A)]	
AG89F54	AG89F54@PLCC44
[(SA244)]	
AG89F54@PQFP44 [(SA245A)]	
AG89P51	
AG89P51@PLCC44 [(SA244)]	AG89P51@PQFP44
[(SA675)]	
AG89P516	AG89P516@PLCC44
[(SA244)]	
AG89P516@PQFP44 [(SA675)]	
AG89P51A	
AG89P51A@PLCC44 [(SA244)]	AG89P51A@PQFP44
[(SA675)]	
AG89P52	AG89P52@PLCC44
[(SA244)]	
AG89P52@PQFP44 [(SA675)]	

## ALI(Acer)

### E ( E ) PROM / FRAM / NVRAM

M8720  
[ ( SA015A1T ) ]

M8720@PLCC32

### MICROCONTROLLER

M6759  
[ ( SA244 ) ]  
M6759@TQFP44 [ ( SA245A ) ]

M6759@PLCC44

## ALL 24 SERIES(ISP)

### E ( E ) PROM / FRAM / NVRAM

24C01 ( ISP ) [ ISP-HEADER01 ]  
HEADER01 ]

24C02 ( ISP ) [ ISP-

24C04 ( ISP ) [ ISP-HEADER01 ]  
HEADER01 ]

24C08 ( ISP ) [ ISP-

24C128 ( ISP ) [ ISP-HEADER01 ]  
HEADER01 ]

24C16 ( ISP ) [ ISP-

24C256 ( ISP ) [ ISP-HEADER01 ]  
HEADER01 ]

24C32 ( ISP ) [ ISP-

24C64 ( ISP ) [ ISP-HEADER01 ]

## ALLIANCE

### E ( E ) PROM / FRAM / NVRAM

AS29F200@PSOP44 [ ( SA638-B006 ) ]  
B005 ) ]

AS29F200@TSOP48 [ ( SA247-

AS29F200B@PSOP44 [ ( SA638-B006 ) ]  
B005 ) ]

AS29F200B@TSOP48 [ ( SA247-

AS29F200T@PSOP44 [ ( SA638-B006 ) ]  
B005 ) ]

AS29F200T@TSOP48 [ ( SA247-

# ALTERA

## E ( E ) PROM / FRAM / NVRAM

EPC1(LC)@PLCC20 [(SA001A)] [(SA001A)]	EPC1(LI)@PLCC20
EPC1(PC) (PI)	EPC1
EPC1441(LC)@PLCC20 [(SA001A)] [(SA001A)]	EPC1441(LI)@PLCC20
EPC1441(PC) (PI)	EPC1441
EPC1441(TC)@TQFP32 [(SA663)] [(SA663)]	EPC1441(TI)@TQFP32
EPC2(LC)@PLCC20 [(SA001A)] [(SA001A)]	EPC2(LI)@PLCC20
EPC2(TC)@TQFP32 [(SA663)] [(SA663)]	EPC2(TI)@TQFP32
EPCS16SI16@SOIC16 [(SA404)] [(SA602A)]	EPCS16SI8N@SOIC8
EPCS1SI8@SOIC8 [(SA602A)] [(SA602A)]	EPCS4SI8@SOIC8
EPCS64SI16@SOIC16 [(SA404)]	

## PLD

EP310 [(SA001A)]	EP310@PLCC20
EP320 [(SA001A)]	EP320@PLCC20
EP330 [(SA001A)]	EP330@PLCC20
EP600 [(SA008A)]	EP600@PLCC28
EP600@SOIC24 [(SA404)]	
EP600I EP600I@PLCC28 [(SA008A)] [(SA404)]	EP600I@SOIC24
EP610 [(SA008A)]	EP610@PLCC28
EP610@SOIC24 [(SA404)]	
EP610A	



EP610A@PLCC28 [(SA008A)]		EP610A@SOIC24
[(SA404)]		
EP610I		EP610I@PLCC28
[(SA008A)]		
EP610I@SOIC24 [(SA404)]		
EP610T		
EP610T@PLCC28 [(SA008A)]		EP610T@SOIC24
[(SA404)]		
EP630		EP630@PLCC28
[(SA008A)]		
EP630@SOIC24 [(SA404)]		
EP900		
EP900@PLCC44 [(SA244)]		
EP900I		
EP900I@PLC44 [(SA244)]		
EP910		
EP910@PLCC44 [(SA244)]		
EP910A		
EP910A@PLCC44 [(SA244)]		
EP910I		
EP910I@PLCC44 [(SA244)]		
EP910T		
EP910T@PLCC44 [(SA244)]		EPM3032A@PLCC44
[(SA244)]		
EPM3032A@TQFP44 [(SA245A)]		EPM3064A@PLCC44
[(SA244)]		
EPM3064A@TQFP44 [(SA245A)]		EPM7032@PLCC44
[(SA244)]		
EPM7032@TQFP44 [(SA245A)]		
EPM7032AE@JLCC44 (7032 mode) [(SA244)]		
EPM7032AE@PLCC44 (7032 mode) [(SA244)]		
EPM7032AE@PLCC44 (7032AE mode) [(SA244)]		
EPM7032AE@PLCC44 (7032S mode) [(SA244)]		
EPM7032AE@PQFP44 (7032 mode) [(SA245A)]		
EPM7032AE@TQFP44 (7032 mode) [(SA245A)]		
EPM7032AE@TQFP44 (7032AE mode) [(SA245A)]		
EPM7032AE@TQFP44 (7032S mode) [(SA245A)]		
EPM7032B@PLCC44 (7032AE mode) [(SA244)]		
EPM7032B@PLCC44 (7032B mode) [(SA244)]		
EPM7032B@PLCC44 (7032S mode) [(SA244)]		
EPM7032B@TQFP44 (7032AE mode) [(SA245A)]		
EPM7032B@TQFP44 (7032B mode) [(SA245A)]		
EPM7032B@TQFP44 (7032S mode) [(SA245A)]		

EPM7032B@TQFP48	(7032AE mode)	[(SA248)]	
EPM7032B@TQFP48	(7032B mode)	[(SA248)]	
EPM7032B@TQFP48	(7032S mode)	[(SA248)]	
EPM7032S@PLCC44	(7032 mode)	[(SA244)]	
EPM7032S@PLCC44	(7032S mode)	[(SA244)]	
EPM7032S@TQFP44	(7032 mode)	[(SA245A)]	
EPM7032S@TQFP44	(7032S mode)	[(SA245A)]	
EPM7032V@PLCC44	[(SA244)]		EPM7032V@TQFP44
[(SA245A)]			
EPM7064@PLCC44	[(SA244)]		EPM7064@TQFP44
[(SA245A)]			
EPM7064AE@PLCC44	(7064S)(ISP)	[ISP-HEADER01]	
EPM7064AE@PLCC44	(7064AE mode)	[(SA244)]	
EPM7064AE@PLCC44	(7064AE)(ISP)	[ISP-HEADER01]	
EPM7064AE@PLCC44	(7064S mode)	[(SA244)]	
EPM7064AE@TQFP44	(7064S)(ISP)	[ISP-HEADER01]	
EPM7064AE@TQFP44	(7064AE mode)	[(SA245A)]	
EPM7064AE@TQFP44	(7064AE)(ISP)	[ISP-HEADER01]	
EPM7064AE@TQFP44	(7064S mode)	[(SA245A)]	
EPM7064B@PLCC44	(7064AE mode)	[(SA244)]	
EPM7064B@PLCC44	(7064B mode)	[(SA244)]	
EPM7064B@PLCC44	(7064S mode)	[(SA244)]	
EPM7064B@TQFP44	(7064AE mode)	[(SA245A)]	
EPM7064B@TQFP44	(7064B mode)	[(SA245A)]	
EPM7064B@TQFP44	(7064S mode)	[(SA245A)]	
EPM7064B@TQFP48	(7064AE mode)	[(SA248)]	
EPM7064B@TQFP48	(7064B mode)	[(SA248)]	
EPM7064B@TQFP48	(7064S mode)	[(SA248)]	
EPM7064S@PLCC44	(7064 mode)	[(SA244)]	
EPM7064S@PLCC44	(7064S mode)	[(SA244)]	
EPM7064S@TQFP44	(7064 mode)	[(SA245A)]	
EPM7064S@TQFP44	(7064S mode)	[(SA245A)]	

## AMD

### E (E) PROM / FRAM / NVRAM

1736		1736@SOIC8
[(SA602A)]		
1765		1765@SOIC8
[(SA602A)]		
AM25FL005D@SOIC8	[(SA602A)]	AM25FL005D@USON8

[ (SA683) ]  
AM25FL010D@SOIC8 [ (SA602A) ] AM25FL010D@USON8  
[ (SA683) ]  
AM25FL016A@SOIC16 [ (SA404) ]  
AM25FL016A@SOIC16(ISP) [ ISP-HEADER01 ]  
AM25FL016A@WSON8 [ (SA684) ]  
AM25FL016A@WSON8(ISP) [ ISP-HEADER01 ]  
AM25FL020D@SOIC8 [ (SA602A) ] AM25FL020D@USON8  
[ (SA683) ]  
AM25FL032A@SOIC16 [ (SA404) ]  
AM25FL032A@SOIC16(ISP) [ ISP-HEADER01 ]  
AM25FL032A@WSON8 [ (SA684) ]  
AM25FL032A@WSON8(ISP) [ ISP-HEADER01 ]  
AM25FL040D@SOIC8 [ (SA602A) ] AM25FL040D@USON8  
[ (SA683) ]  
AM25FL080D@SOIC8 [ (SA602A) ] AM25FL080D@USON8  
[ (SA683) ]  
AM27128 AM27128  
(DC)  
AM27128(DC)@PLCC32 [ (SA015A1T) ] AM27128@PLCC32  
[ (SA015A1T) ]  
AM27128A AM27128A  
(F)  
AM27128A(F)@PLCC32 [ (SA015A1T) ] AM27128A  
(PC)  
AM27128A(PC)@PLCC32 [ (SA015A1T) ] AM27128A@PLCC32  
[ (SA015A1T) ]  
AM2716  
AM2716B  
AM27256 AM27256@PLCC32  
[ (SA015A1T) ]  
AM27256AP AM27256AP@PLCC32  
[ (SA015A1T) ]  
AM27256F AM27256F@PLCC32  
[ (SA015A1T) ]  
AM27256PC AM27256PC@PLCC32  
[ (SA015A1T) ]  
AM2732  
AM2732A  
AM2732B  
AM27512  
AM27512@PLCC32 [ (SA015A1T) ]  
AM27512DC

AM27512DC@PLCC32 [(SA015A1T)]  
AM27512F  
AM27512F@PLCC32 [(SA015A1T)]  
AM27512PC  
AM27512PC@PLCC32 [(SA015A1T)]  
AM27513  
AM2764 AM2764@PLCC32  
[(SA015A1T)]  
AM2764A AM2764A  
(DC)  
AM2764A(DC)@PLCC32 [(SA015A1T)] AM2764A  
(DCB)  
AM2764A(DI) AM2764A  
(DIB)  
AM2764A(F) AM2764A(F)@PLCC32  
[(SA015A1T)]  
AM2764A(JC) AM2764A  
(LC)  
AM2764A(LCB) AM2764A  
(LE)  
AM2764A(LEB) AM2764A  
(PC)  
AM2764A(PC)@PLCC32 [(SA015A1T)] AM2764A@PLCC32  
[(SA015A1T)]  
AM27C010 AM27C010@PLCC32  
[(SA015A1T)]  
AM27C010@TSOP32 [(SA410T)]  
AM27C020  
AM27C020@PLCC32 [(SA015A1T)] AM27C020@TSOP32  
[(SA410T)]  
AM27C040 AM27C040@PLCC32  
[(SA015A1T)]  
AM27C040@TSOP32 [(SA410T)]  
AM27C080  
AM27C080@PLCC32 [(SA015A1T)] AM27C080@TSOP32  
[(SA410T)]  
AM27C100 AM27C100@PLCC32  
[(SA015A1T)]  
AM27C100@TSOP32 [(SA410T)]  
AM27C1024  
AM27C1024@PLCC44 [(SA244)]  
AM27C128  
AM27C128@PLCC32 [(SA015A1T)]

AM27C2048	
AM27C2048@PLCC44 [(SA244)]	AM27C2048@TSOP40
[(SA409T)]	
AM27C256	AM27C256
(F)	
AM27C256(F)@PLCC32 [(SA015A1T)]	AM27C256
(PC)	
AM27C256(PC)@PLCC32 [(SA015A1T)]	AM27C256@PLCC32
[(SA015A1T)]	
AM27C400	AM27C400@PLCC44
[(SA244)]	
AM27C4096	AM27C4096@PLCC44
[(SA244)]	
AM27C512	AM27C512
(P)	
AM27C512(P)@PLCC32 [(SA015A1T)]	AM27C512@PLCC32
[(SA015A1T)]	
AM27C64	AM27C64@PLCC32
[(SA015A1T)]	
AM27H010	AM27H010@PLCC32
[(SA015A1T)]	
AM27H010@TSOP32 [(SA410T)]	
AM27H256	
AM27H256@PLCC32 [(SA015A1T)]	
AM27HB010	
AM27HB010@PLCC32 [(SA015A1T)]	AM27HB010@TSOP32
[(SA410T)]	
AM27LV010	AM27LV010@PLCC32
[(SA015A1T)]	
AM27LV010@TSOP32 [(SA410T)]	
AM27LV010B	
AM27LV010B@PLCC32 [(SA015A1T)]	AM27LV010B@TSOP32
[(SA410T)]	
AM27LV020	AM27LV020@PLCC32
[(SA015A1T)]	
AM27LV020@TSOP32 [(SA410T)]	
AM27LV020B	
AM27LV020B@PLCC32 [(SA015A1T)]	AM27LV020B@TSOP32
[(SA410T)]	
AM2816A	
AM2817A	
AM2817A@PLCC32 [(SA015A1T)]	AM2817A@SOIC28
[(SA404)]	

AM2864A	AM2864A
(E)	
AM2864A(E)@PLCC32 [(SA015A1T)]	AM2864A@PLCC32
[(SA015A1T)]	
AM2864B	AM2864B
(E)	
AM2864B(E)@PLCC32 [(SA015A1T)]	AM2864B@PLCC32
[(SA015A1T)]	
AM28F001	AM28F001@PLCC32
[(SA015A1T)]	
AM28F001@TSOP32 [(SA410T)]	
AM28F010	
AM28F010@PLCC32 [(SA015A1T)]	AM28F010@TSOP32
[(SA410T)]	
AM28F010A	AM28F010A@PLCC32
[(SA015A1T)]	
AM28F010A@TSOP32 [(SA410T)]	
AM28F020	
AM28F020@PLCC32 [(SA015A1T)]	AM28F020@TSOP32
[(SA410T)]	
AM28F020A	AM28F020A@PLCC32
[(SA015A1T)]	
AM28F020A@TSOP32 [(SA410T)]	
AM28F256	
AM28F256@PLCC32 [(SA015A1T)]	AM28F256@TSOP32
[(SA410T)]	
AM28F256A	AM28F256A@PLCC32
[(SA015A1T)]	
AM28F256A@TSOP32 [(SA410T)]	
AM28F512	
AM28F512(F)	AM28F512(F)@PLCC32
[(SA015A1T)]	
AM28F512(F)@TSOP32 [(SA410T)]	AM28F512@PLCC32
[(SA015A1T)]	
AM28F512@TSOP32 [(SA410T)]	
AM28F512A	
AM28F512A(F)	AM28F512A(F)@PLCC32
[(SA015A1T)]	
AM28F512A(F)@TSOP32 [(SA410T)]	AM28F512A@PLCC32
[(SA015A1T)]	
AM28F512A@TSOP32 [(SA410T)]	
AM29BL162CB@SSOP56 [(SA629A-B022)]	
AM29BL802CB@SSOP56 [(SA629A-B022)]	

AM29DL161DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL161DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL161DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL161DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL161DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL161DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL161DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL161DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL161DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL161DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL162CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL162DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL162DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL162DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL162DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL162DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL162DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL162DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DB@FBGA48 [ ( SA642HH-B026A-T048F001Y ) ]  
AM29DL163DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL163DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL163DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163DT@FBGA48 [ ( SA642HH-B026A-T048F001Y ) ]  
AM29DL163DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL163DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL163DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]

AM29DL164DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL164DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL164DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL164DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL164DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GB@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL320GB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL320GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL320GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GT@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL320GT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL320GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL321CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL321CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322CB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322CT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL322GB@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL322GB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL322GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL322GT@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL322GT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL322GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323CB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323CT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]



AM29DL323DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323GB@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL323GB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL323GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323GT@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL323GT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL323GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL324DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL324DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL324GB@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL324GB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL324GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL324GT@FBGA63 [ ( SA642L-B026A-W080F001Y ) ]  
AM29DL324GT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29DL324GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL400BB@PSOP44 [ ( SA638-B006 ) ]  
AM29DL400BB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL400BT@PLCC44 [ ( SA638-B006 ) ]  
AM29DL400BT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL640D@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL640D@TSOP48 [ ( SA247-B005 ) ]  
AM29DL640G@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL640G@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL640G@TSOP48 [ ( SA247-B005 ) ]  
AM29DL642G@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL800B@PSOP44 [ ( SA638-B006 ) ]      AM29DL800B@TSOP48 [ ( SA247-B005 ) ]  
AM29DL800BB@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29DL800BB@PSOP44 [ ( SA638 ) ]  
AM29DL800BB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL800BT@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29DL800BT@PSOP44 [ ( SA638 ) ]  
AM29DL800BT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL800T@PSOP44 [ ( SA638-B006 ) ]      AM29DL800T@TSOP48 [ ( SA247-

B005 ) ]  
AM29DS163CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DS163CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DS163DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DS163DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DS163DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DS163DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DS323DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DS323DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DS323DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DS323DT@TSOP48 [ ( SA247-B005 ) ]  
AM29F002B AM29F002B@PLCC32  
[ ( SA015A1T ) ]  
AM29F002B@TSOP32 [ ( SA410T ) ]  
AM29F002BB  
AM29F002BB@PLCC32 [ ( SA015A1T ) ] AM29F002BB@TSOP32  
[ ( SA410T ) ]  
AM29F002BT AM29F002BT@PLCC32  
[ ( SA015A1T ) ]  
AM29F002BT@TSOP32 [ ( SA410T ) ]  
AM29F002NB  
AM29F002NB@PLCC32 [ ( SA015A1T ) ] AM29F002NB@TSOP32  
[ ( SA410T ) ]  
AM29F002NBB AM29F002NBB@PLCC32  
[ ( SA015A1T ) ]  
AM29F002NBB@TSOP32 [ ( SA410T ) ]  
AM29F002NBT  
AM29F002NBT@PLCC32 [ ( SA015A1T ) ] AM29F002NBT@TSOP32  
[ ( SA410T ) ]  
AM29F002NT AM29F002NT@PLCC32  
[ ( SA015A1T ) ]  
AM29F002NT@TSOP32 [ ( SA410T ) ]  
AM29F002T  
AM29F002T@PLCC32 [ ( SA015A1T ) ] AM29F002T@TSOP32  
[ ( SA410T ) ]  
AM29F004BB@PLCC32 [ ( SA015A1T ) ] AM29F004BB@TSOP32  
[ ( SA410T ) ]  
AM29F004BT@PLCC32 [ ( SA015A1T ) ] AM29F004BT@TSOP32  
[ ( SA410T ) ]  
AM29F010 AM29F010@PLCC32  
[ ( SA015A1T ) ]  
AM29F010@TSOP32 [ ( SA410T ) ]  
AM29F010A

AM29F010A@PLCC32 [(SA015A1T)]	AM29F010A@TSOP32
[(SA410T)]	
AM29F010B	AM29F010B@PLCC32
[(SA015A1T)]	
AM29F010B@TSOP32 [(SA410T)]	AM29F016@PSOP44
[(SA638)]	
AM29F016@TSOP40 [(SA409T)]	AM29F016@TSOP48 [(SA247-
B005)]	
AM29F016B(REVERSE)@TSOP48 [(SA247-B005)]	
AM29F016B@PSOP44 [(SA638)]	AM29F016B@TSOP40
[(SA409T)]	
AM29F016B@TSOP48 [(SA247-B005)]	
AM29F016D(REVERSE)@TSOP48 [(SA247-B005)]	
AM29F016D@PSOP44 [(SA638)]	AM29F016D@TSOP40
[(SA409T)]	
AM29F016D@TSOP48 [(SA247-B005)]	AM29F017B@TSOP48 [(SA247-
B005)]	
AM29F017D@TSOP40 [(SA409T)]	AM29F017D@TSOP48 [(SA247-
B005)]	
AM29F032B@PSOP44 [(SA638)]	AM29F032B@TSOP40
[(SA409T)]	
AM29F040	AM29F040@PLCC32
[(SA015A1T)]	
AM29F040@TSOP32 [(SA410T)]	
AM29F040A	
AM29F040A@PLCC32 [(SA015A1T)]	AM29F040A@TSOP32
[(SA410T)]	
AM29F040B	
AM29F040B(Reverse)@TSOP32 [(SA410T)]	
AM29F040B@PLCC32 [(SA015A1T)]	AM29F040B@TSOP32
[(SA410T)]	
AM29F080@PSOP44 [(SA638)]	AM29F080@TSOP40
[(SA409T)]	
AM29F080B@PSOP44 [(SA638)]	AM29F080B@TSOP40
[(SA409T)]	
AM29F100BE@PSOP44 [(SA638-B006)]	AM29F100BE@TSOP48 [(SA247-
B005)]	
AM29F100BS@PSOP44 [(SA638-B006)]	AM29F100BS@TSOP48 [(SA247-
B005)]	
AM29F100TE@PSOP44 [(SA638-B006)]	AM29F100TE@TSOP48 [(SA247-
B005)]	
AM29F100TS@PSOP44 [(SA638-B006)]	AM29F100TS@TSOP48 [(SA247-
B005)]	

AM29F160DB@TSOP48 [ ( SA247-B005 ) ]	AM29F160DT@TSOP48 [ ( SA247-B005 ) ]
AM29F200AB@PSOP44 [ ( SA638-B006 ) ]	AM29F200AB@TSOP48 [ ( SA247-B005 ) ]
AM29F200AT@PSOP44 [ ( SA638-B006 ) ]	AM29F200AT@TSOP48 [ ( SA247-B005 ) ]
AM29F200BB@PSOP44 [ ( SA638-B006 ) ]	AM29F200BB@TSOP48 [ ( SA247-B005 ) ]
AM29F200BE@PSOP44 [ ( SA638-B006 ) ]	AM29F200BE@TSOP48 [ ( SA247-B005 ) ]
AM29F200BS@PSOP44 [ ( SA638-B006 ) ]	AM29F200BS@TSOP48 [ ( SA247-B005 ) ]
AM29F200BT@PSOP44 [ ( SA638-B006 ) ]	AM29F200BT@TSOP48 [ ( SA247-B005 ) ]
AM29F200TE@PSOP44 [ ( SA638-B006 ) ]	AM29F200TE@TSOP48 [ ( SA247-B005 ) ]
AM29F200TS@PSOP44 [ ( SA638-B006 ) ]	AM29F200TS@TSOP48 [ ( SA247-B005 ) ]
AM29F400AB@PSOP44 [ ( SA638-B006 ) ]	AM29F400AB@TSOP48 [ ( SA247-B005 ) ]
AM29F400AT@PSOP44 [ ( SA638-B006 ) ]	AM29F400AT@TSOP48 [ ( SA247-B005 ) ]
AM29F400BB@PSOP44 [ ( SA638-B006 ) ]	AM29F400BB@TSOP48 [ ( SA247-B005 ) ]
AM29F400BBE@PSOP44 [ ( SA638-B006 ) ]	
AM29F400BBE@TSOP48 [ ( SA247-B005 ) ]	
AM29F400BBF@PSOP44 [ ( SA638-B006 ) ]	
AM29F400BBF@TSOP48 [ ( SA247-B005 ) ]	
AM29F400BBS@PSOP44 [ ( SA638-B006 ) ]	
AM29F400BBS@TSOP48 [ ( SA247-B005 ) ]	
AM29F400BE@PSOP44 [ ( SA638-B006 ) ]	AM29F400BE@TSOP48 [ ( SA247-B005 ) ]
AM29F400BF@PSOP44 [ ( SA638-B006 ) ]	AM29F400BF@TSOP48 [ ( SA247-B005 ) ]
AM29F400BS@PSOP44 [ ( SA638-B006 ) ]	AM29F400BS@TSOP48 [ ( SA247-B005 ) ]
AM29F400BT@PSOP44 [ ( SA638-B006 ) ]	AM29F400BT@TSOP48 [ ( SA247-B005 ) ]
AM29F400BTE@PSOP44 [ ( SA638-B006 ) ]	
AM29F400BTE@TSOP48 [ ( SA247-B005 ) ]	
AM29F400BTF@PSOP44 [ ( SA638-B006 ) ]	
AM29F400BTF@TSOP48 [ ( SA247-B005 ) ]	
AM29F400BTS@PSOP44 [ ( SA638-B006 ) ]	

AM29F400BTS@TSOP48 [ (SA247-B005) ]  
AM29F800B@PSOP44 [ (SA638-B006) ]      AM29F800B@TSOP48 [ (SA247-B005) ]  
AM29F800BB@FBGA48 [ (SA642N-B026A-W048F001Y) ]  
AM29F800BB@PSOP44 [ (SA638-B006) ]      AM29F800BB@TSOP48 [ (SA247-B005) ]  
AM29F800BBF@PSOP44 [ (SA638-B006) ]  
AM29F800BBF@TSOP48 [ (SA247-B005) ]  
AM29F800BF@PSOP44 [ (SA638-B006) ]      AM29F800BF@TSOP48 [ (SA247-B005) ]  
AM29F800BT@FBGA48 [ (SA642N-B026A-W048F001Y) ]  
AM29F800BT@PSOP44 [ (SA638-B006) ]      AM29F800BT@TSOP48 [ (SA247-B005) ]  
AM29F800BTF@PSOP44 [ (SA638-B006) ]  
AM29F800BTF@TSOP48 [ (SA247-B005) ]  
AM29F800T@PSOP44 [ (SA638-B006) ]      AM29F800T@TSOP48 [ (SA247-B005) ]  
AM29F800TB@PSOP44 [ (SA638-B006) ]      AM29F800TB@TSOP48 [ (SA247-B005) ]  
AM29F800TF@PSOP44 [ (SA638-B006) ]      AM29F800TF@TSOP48 [ (SA247-B005) ]  
AM29LL800B@TSOP48 [ (SA247-B005) ]  
AM29LL800BB@TSOP48 [ (SA247-B005) ]  
AM29LL800BT@TSOP48 [ (SA247-B005) ]  
AM29LL800T@TSOP48 [ (SA247-B005) ]      AM29LV001BB@PLCC32  
[ (SA015A1T) ]  
AM29LV001BB@TSOP32 [ (SA410T) ]      AM29LV001BT@PLCC32  
[ (SA015A1T) ]  
AM29LV001BT@TSOP32 [ (SA410T) ]      AM29LV002@TSOP40  
[ (SA409T) ]  
AM29LV002B@TSOP40 [ (SA409T) ]      AM29LV002BB@TSOP40  
[ (SA409T) ]  
AM29LV002BT@TSOP40 [ (SA409T) ]      AM29LV004B@PSOP44  
[ (SA638) ]  
AM29LV004B@TSOP40 [ (SA409T) ]      AM29LV004BB@TSOP40  
[ (SA409T) ]  
AM29LV004BT@TSOP40 [ (SA409T) ]      AM29LV004T@PSOP44  
[ (SA638) ]  
AM29LV004T@TSOP40 [ (SA409T) ]      AM29LV008B@PSOP44  
[ (SA638) ]  
AM29LV008B@TSOP40 [ (SA409T) ]      AM29LV008BB@TSOP40  
[ (SA409T) ]  
AM29LV008BT@TSOP40 [ (SA409T) ]      AM29LV008T@PSOP44

[ ( SA638 ) ]  
AM29LV008T@TSOP40 [ ( SA409T ) ] AM29LV010B@PLCC32  
[ ( SA015A1T ) ]  
AM29LV010B@TSOP32 [ ( SA410T ) ] AM29LV017B@TSOP40  
[ ( SA409T ) ]  
AM29LV017D@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29LV017D@TSOP40 [ ( SA409T ) ] AM29LV020B@PLCC32  
[ ( SA015A1T ) ]  
AM29LV020B@TSOP32 [ ( SA410T ) ]  
AM29LV033C@FBGA63 [ ( SA642A-B026A-Y096N001 ) ]  
AM29LV033C@TSOP40 [ ( SA409T ) ]  
AM29LV033MU@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29LV033MU@TSOP40 [ ( SA409T ) ] AM29LV040B@PLCC32  
[ ( SA015A1T ) ]  
AM29LV040B@TSOP32 [ ( SA410T ) ] AM29LV040E@PLCC32  
[ ( SA015A1T ) ]  
AM29LV040E@TSOP32 [ ( SA410T ) ] AM29LV040J@PLCC32  
[ ( SA015A1T ) ]  
AM29LV040J@TSOP32 [ ( SA410T ) ]  
AM29LV065D@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29LV065D@TSOP48 [ ( SA247-B005 ) ]  
AM29LV065MU@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29LV065MU@TSOP48 [ ( SA247-B005 ) ]  
AM29LV080@TSOP40 [ ( SA409T ) ] AM29LV081@TSOP40  
[ ( SA409T ) ]  
AM29LV081B@TSOP40 [ ( SA409T ) ] AM29LV116BB@TSOP40  
[ ( SA409T ) ]  
AM29LV116BT@TSOP40 [ ( SA409T ) ] AM29LV116DB@TSOP40  
[ ( SA409T ) ]  
AM29LV116DT@TSOP40 [ ( SA409T ) ]  
AM29LV128MH@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
AM29LV128MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV128ML@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
AM29LV128ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV160BB@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
AM29LV160BB@PSOP44 [ ( SA638 ) ]  
AM29LV160BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160BT@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
AM29LV160BT@PSOP44 [ ( SA638 ) ]  
AM29LV160BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160DB(REVERSE)@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160DB@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
AM29LV160DB@PSOP44 [ ( SA638 ) ]

AM29LV160DB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160DT(REVERSE)@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160DT@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
AM29LV160DT@PSOP44 [ ( SA638 ) ]  
AM29LV160DT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160MB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29LV160MB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV160MB@PSOP44 [ ( SA638 ) ]  
AM29LV160MB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160MT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29LV160MT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV160MT@PSOP44 [ ( SA638 ) ]  
AM29LV160MT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200B@PSOP44 [ ( SA638-B006 ) ]      AM29LV200B@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BB@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BE@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BE@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BF@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BF@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BS@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BS@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BT@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200T@PSOP44 [ ( SA638-B006 ) ]      AM29LV200T@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TE@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200TE@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TF@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200TF@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TS@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200TS@TSOP48 [ ( SA247-B005 ) ]  
AM29LV256MH@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
AM29LV256MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV256ML@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
AM29LV256ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320DB@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29LV320DB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320DT@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29LV320DT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320FB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320FT@TSOP48 [ ( SA247-B005 ) ]

AM29LV320MB@FBGA48 [ ( SA642HH-B026A-T048F001Y ) ]  
AM29LV320MB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV320MB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320MH@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV320MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320ML@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV320ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320MT@FBGA48 [ ( SA642HH-B026A-T048F001Y ) ]  
AM29LV320MT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV320MT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400B@PSOP44 [ ( SA638-B006 ) ]      AM29LV400B@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400BB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29LV400BB@PSOP44 [ ( SA638-B006 ) ]  
AM29LV400BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400BT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29LV400BT@PSOP44 [ ( SA638-B006 ) ]  
AM29LV400BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400T@PSOP44 [ ( SA638-B006 ) ]      AM29LV400T@TSOP48 [ ( SA247-B005 ) ]  
AM29LV640DH@SSOP56 [ ( SA629A-B020 ) ]  
AM29LV640DL@SSOP56 [ ( SA629A-B020 ) ]  
AM29LV640DU@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640DU@FBGA64 [ ( SA655D-B044A-W064F001 ) ]  
AM29LV640GU@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640GU@FBGA64 [ ( SA655D-B044A-W064F001 ) ]  
AM29LV640MB@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640MB@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV640MB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV640MH@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV640MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV640ML@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV640ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV640MT@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640MT@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV640MT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV640MU@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640MU@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
AM29LV641DH@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641DHR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641DL@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641DLR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GH@TSOP48 [ ( SA247-B005 ) ]



AM29LV641GHR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GL@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641GLR@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641MH@TSOP48 [ ( SA247-B005 ) ]  
AM29LV641ML@TSOP48 [ ( SA247-B005 ) ]  
AM29LV642G@FBGA64 [ ( SA655A-B038A-T064N001 ) ]  
AM29LV652D@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV800B@PSOP44 [ ( SA638-B006 ) ]      AM29LV800B@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800BB@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29LV800BB@PSOP44 [ ( SA638-B006 ) ]  
AM29LV800BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800BT@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29LV800BT@PSOP44 [ ( SA638-B006 ) ]  
AM29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800DB(WB)@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29LV800DB(WC)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
AM29LV800DB@PSOP44 [ ( SA638 ) ]  
AM29LV800DB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800DT(WB)@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
AM29LV800DT(WC)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
AM29LV800DT@PSOP44 [ ( SA638 ) ]  
AM29LV800DT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV800T@PSOP44 [ ( SA638-B006 ) ]      AM29LV800T@TSOP48 [ ( SA247-B005 ) ]  
AM29PDS322DB@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29PDS322DT@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29PL160CB@PSOP44 [ ( SA638-B006 ) ]  
AM29PL160CB@TSOP48 [ ( SA247-B005 ) ]  
AM29PL160CT@PSOP44 [ ( SA638-B006 ) ]  
AM29PL160CT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL160CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29SL160CB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL160CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29SL160CT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL400CB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL400CT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800BB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800BT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800CB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800CT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800DB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800DBUF@FBGA48 [ ( SA716A-B119B-M048F001Y ) ]

AM29SL800DBVG@FBGA48 [ (SA716A-B119B-M048F001Y) ]  
AM29SL800DBVU@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
AM29SL800DBWA@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
AM29SL800DBWC@FBGA48 [ (SA642R-B026A-W080F001N) ]  
AM29SL800DT@TSOP48 [ (SA247-B005) ]  
AM29SL800DTUF@FBGA48 [ (SA716A-B119B-M048F001Y) ]  
AM29SL800DTVG@FBGA48 [ (SA716A-B119B-M048F001Y) ]  
AM29SL800DTVU@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
AM29SL800DTWA@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
AM29SL800DTWC@FBGA48 [ (SA642R-B026A-W080F001N) ]  
AM9716  
AM9732  
AM9732A  
AM9764  
AM9764@PLCC32 [ (SA015A1T) ]  
BS128HD8V(AM29BDS128HD)@FBGA80 [ (SA642A-B080A-Y096N001) ]  
BS128HD9V(AM29BDS128HD)@FBGA80 [ (SA642A-B080A-Y096N001) ]  
BS128HE8V(AM29BDS128HE)@FBGA80 [ (SA642A-B080A-Y096N001) ]  
BS128HE9V(AM29BDS128HE)@FBGA80 [ (SA642A-B080A-Y096N001) ]  
BS128HF8V(AM29BDS128HF)@FBGA80 [ (SA642A-B080A-Y096N001) ]  
BS128HF9V(AM29BDS128HF)@FBGA80 [ (SA642A-B080A-Y096N001) ]  
BS640HD8V(AM29BDS640HD)@FBGA64 [ (SA642A-B080A-Y096F001) ]  
BS640HD9V(AM29BDS640HD)@FBGA64 [ (SA642A-B080A-Y096F001) ]  
BS640HE8V(AM29BDS640HE)@FBGA64 [ (SA642A-B080A-Y096F001) ]  
BS640HE9V(AM29BDS640HE)@FBGA64 [ (SA642A-B080A-Y096F001) ]  
BS640HF8V(AM29BDS640HF)@FBGA64 [ (SA642A-B080A-Y096F001) ]  
BS640HF9V(AM29BDS640HF)@FBGA64 [ (SA642A-B080A-Y096F001) ]  
DS42514(AM29DL163DB)@FBGA69 [ (SA642B-B032A-Y072F001) ]  
DS42515(AM29DL164)@FBGA69 [ (SA642B-B032A-Y072F001) ]  
DS42516(AM29DL324)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
DS42546(AM29DL163)@FBGA69 [ (SA642B-B032A-Y072F001) ]  
DS42553(AM29DL323)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
DS42585(AM29DL323D)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
DS42587(AM29DL324D)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
DS42629(AM29DL640G)@VFBGA48 [ (SA634A-B005A-Y048F001) ]  
DS42677(AM29LV128MH/L)@FBGA88 [ (SA642A-B058A-Y096N001) ]  
DS42678(AM29LV320MT)@FBGA67 [ (SA642E-B041A-T072F001) ]  
DS42689(AM29LV320MT)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
DS42690(AM29LV320MB)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
DS42695(AM29LV320MT)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
DS42696(AM29LV320MB)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
DS42701(AM29LV640MU)@FBGA88 [ (SA642W-B116A-W088F001Y) ]  
DS42725(AM50DL128CH)@FBGA88 [ (SA642A-B062A-Y096F001) ]

DS42772A(AM29LV640M)@FBGA88 [(SA642W-B116A-W088F001Y)]  
M410000000(AM41DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000001(AM41DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000002(AM41DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000003(AM41DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000004(AM41DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000005(AM41DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000006(AM41DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000007(AM41DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000008(AM41DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000009(AM41DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000A(AM41DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000B(AM41DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000C(AM41DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000D(AM41DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000E(AM41DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000F(AM41DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000G(AM41DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000000H(AM41DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000001W(AM41DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000001X(AM41DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000001Y(AM41DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000001Z(AM41DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000020(AM41DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000021(AM41DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000022(AM41DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000023(AM41DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000024(AM41DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000025(AM41DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000026(AM41DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000027(AM41DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002L(AM41DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002M(AM41DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002N(AM41DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002O(AM41DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002P(AM41DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002Q(AM41DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002R(AM41DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002S(AM41DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002T(AM41DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002U(AM41DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002V(AM41DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000002W(AM41DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]

M41000003D (AM41DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000003E (AM41DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000003F (AM41DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000003G (AM41DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M410000095 (AM41LV3204MT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000096 (AM41LV3204MB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000009B (AM41DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000009C (AM41DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M41000009D (AM41DL6408H)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000000 (AM42DL640AG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000001 (AM42DL640AG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000004 (AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M420000005 (AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M420000006 (AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M420000007 (AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000I (AM42DL1612DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000J (AM42DL1612DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000K (AM42DL1612DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000L (AM42DL1612DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000M (AM42DL1622DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000N (AM42DL1622DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000O (AM42DL1622DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000P (AM42DL1622DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000Q (AM42DL1632DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000R (AM42DL1632DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000S (AM42DL1632DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000T (AM42DL1632DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000U (AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000V (AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000W (AM42DL1642DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000000X (AM42DL1642DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001A (AM42DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001B (AM42DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001C (AM42DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001D (AM42DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001E (AM42DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001F (AM42DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001G (AM42DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001H (AM42DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001I (AM42DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001J (AM42DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001K (AM42DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001L (AM42DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]

M42000001M(AM42DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001N(AM42DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001O(AM42DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M42000001P(AM42DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M420000022(AM42DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000023(AM42DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000024(AM42DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000025(AM42DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000026(AM42DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000027(AM42DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000028(AM42DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000029(AM42DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002A(AM42DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002B(AM42DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002C(AM42DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002D(AM42DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002U(AM42DL6404G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002V(AM42DL6404G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000002Y(AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M42000002Z(AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000030(AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000031(AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000032(AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000033(AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000034(AM42BDS6408GT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000035(AM42BDS6408GB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M42000004Y(AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M42000004Z(AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000050(AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000051(AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000052(AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000053(AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000054(AM42BDS640AGT)@FBGA93 [(SA642A-B072A-Y096F001)]  
M420000055(AM42BDS640AGB)@FBGA93 [(SA642A-B072A-Y096F001)]  
M42000005M(AM42DL6402G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005N(AM42DL6402G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005W(AM42DL3224GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005X(AM42DL3224GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005Y(AM42DL3234GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M42000005Z(AM42DL3234GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000060(AM42DL3244GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000061(AM42DL3244GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000070(AM42BDS6408HE8)@BGA89 [(SA642A-B072A-Y096F001)]

M420000071 (AM42BDS6408HE9)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000072 (AM42BDS6408HD8)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000073 (AM42BDS6408HD9)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000074 (AM42BDS6408HE3)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000075 (AM42BDS6408HE4)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000076 (AM42BDS6408HD3)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000077 (AM42BDS6408HD4)@BGA89 [(SA642A-B072A-Y096F001)]  
M420000078 (AM42DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M420000079 (AM42DL640AH)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000000 (AM45DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000001 (AM45DL6408G)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000008 (AM45DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M450000009 (AM45DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000A (AM45DL3208GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000B (AM45DL3208GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000S (AM45DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000T (AM45DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000U (AM45DL3228GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000000V (AM45DL3228GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001C (AM45DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001D (AM45DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001E (AM45DL3238GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001F (AM45DL3238GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001W (AM45DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001X (AM45DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001Y (AM45DL3248GT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M45000001Z (AM45DL3248GB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M490000000 (AM49DL640BG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M490000001 (AM49DL640BG)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000G (AM49DL320BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000H (AM49DL320BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000J (AM49DL322BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000K (AM49DL322BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000L (AM49DL322BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000M (AM49DL322BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000N (AM49DL323BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000O (AM49DL323BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000P (AM49DL323BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000Q (AM49DL323BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000R (AM49DL324BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000S (AM49DL324BGT)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000T (AM49DL324BGB)@FBGA73 [(SA642A-B032A-Y096F001)]  
M49000000U (AM49DL324BGB)@FBGA73 [(SA642A-B032A-Y096F001)]

M49000001A (AM49DL320BGB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000001B (AM49DL320BGB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000001Y (AM49PDL640AG)@FBGA73 [ ( SA642A-B032A-Y096N001 ) ]  
M49000001Z (AM49PDL640AG)@FBGA73 [ ( SA642A-B032A-Y096N001 ) ]  
M490000025 (AM49DL640AG)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M490000026 (AM49DL640AG)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M490000028 (AM49PDL127BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M490000029 (AM49PDL127BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M49000002I (AM49PDL127AH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M49000002J (AM49PDL127AH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M49000002T (AM49LV6408MT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000002U (AM49LV6408MB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000002V (AM49LV6408MT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000002X (AM49LV6408MB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M490000030 (AM49PDL129BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M490000031 (AM49PDL129BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M490000032 (AM49DL3208GB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M490000032 (AM49DL3208GT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M490000034 (AM49DL3208GT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M490000035 (AM49DL3208GB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003A (AM49DL640BH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003B (AM49DL640BH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003C (AM49DL640BH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003D (AM49DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003E (AM49DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003F (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003G (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003H (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003I (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003J (AM49DL640AH)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003X (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003Y (AM49DL6408H)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000003Z (AM49LV6408MT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000004A (AM49LV6408MB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000004B (AM49BDS640AH)@FBGA89 [ ( SA642A-B072A-Y096F001 ) ]  
M49000004C (AM49BDS640AH)@FBGA89 [ ( SA642A-B072A-Y096F001 ) ]  
M49000004D (AM49BDS640AH)@FBGA89 [ ( SA642A-B072A-Y096F001 ) ]  
M49000004E (AM49BDS640AH)@FBGA89 [ ( SA642A-B072A-Y096F001 ) ]  
M49000004H (AM49LV128BMH)@FBGA64 [ ( SA642C-B039A-Y056F001 ) ]  
M49000004J (AM49LV128BML)@FBGA64 [ ( SA642C-B039A-Y056F001 ) ]  
M49000004K (AM49LV128BMH)@FBGA64 [ ( SA642C-B039A-Y056F001 ) ]  
M49000004L (AM49LV128BML)@FBGA64 [ ( SA642C-B039A-Y056F001 ) ]  
M49000004S (AM49LV128BMaH)@FBGA64 [ ( SA642C-B039A-Y056F001 ) ]

M49000004T(AM49LV128BMaL)@FBGA64 [(SA642C-B039A-Y056F001)]  
M49000004U(AM49LV128BMaH)@FBGA64 [(SA642C-B039A-Y056F001)]  
M49000004V(AM49LV128BMaL)@FBGA64 [(SA642C-B039A-Y056F001)]  
M4900000K(AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M4900000L(AM49PDL129AH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M500000000(AM50DL128BG)@FBGA73 [(SA642A-B039A-Y096F001)]  
M500000001(AM50DL128BG)@FBGA73 [(SA642A-B039A-Y096F001)]  
M500000008(AM50DL128CG)@FBGA88 [(SA642A-B062A-Y096F001)]  
M500000009(AM50DL128CG)@FBGA88 [(SA642A-B062A-Y096F001)]  
M50000004J(AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M50000004K(AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M50000004L(AM50DL128BH)@FBGA73 [(SA642A-B039A-Y096F001)]  
M50000004M(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
M50000004N(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
M50000004P(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
M550000000(AM55DL128C8G)@FBGA93 [(SA642A-B078A-Y096N001)]  
M550000001(AM55DL128C8G)@FBGA93 [(SA642A-B078A-Y096N001)]  
PDL127H53V(AM29PDL127H53)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL127H63V(AM29PDL127H63)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL127H68V(AM29PDL127H68)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL127H88V(AM29PDL127H88)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL129H53V(AM29PDL129H53)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL129H63V(AM29PDL129H63)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL129H68V(AM29PDL129H68)@FBGA80 [(SA642A-B070A-Y096N001)]  
PDL129H88V(AM29PDL129H88)@FBGA80 [(SA642A-B070A-Y096N001)]

## PLD

M4A3-32/32@PLCC44 [(SA244)] [(SA245A)]	M4A3-32/32@TQFP44
M4A3-32/32@TQFP48 [(SA248)] [(SA244)]	M4A3-64/32@PLCC44
M4A3-64/32@TQFP44 [(SA245A)] [(SA248)]	M4A3-64/32@TQFP48
M4A5-32/32@PLCC44 [(SA244)] [(SA245A)]	M4A5-32/32@TQFP44
M4A5-32/32@TQFP48 [(SA248)] [(SA244)]	M4A5-64/32@PLCC44
M4A5-64/32@TQFP44 [(SA245A)] [(SA248)]	M4A5-64/32@TQFP48
PALC16L8Q [(SA001A)]	PALC16L8Q@PLCC20



PALC16L8Z [ (SA001A) ]	PALC16L8Z@PLCC20
PALC16R4Q [ (SA001A) ]	PALC16R4Q@PLCC20
PALC16R4Z [ (SA001A) ]	PALC16R4Z@PLCC20
PALC16R6Q [ (SA001A) ]	PALC16R6Q@PLCC20
PALC16R6Z [ (SA001A) ]	PALC16R6Z@PLCC20
PALC16R8Q [ (SA001A) ]	PALC16R8Q@PLCC20
PALC16R8Z [ (SA001A) ]	PALC16R8Z@PLCC20
PALCE16V8H [ (SA001A) ]	PALCE16V8H@PLCC20
PALCE16V8H@SOIC20 [ (SA404) ]	
PALCE16V8Q [ (SA404) ]	
PALCE16V8Q@PLCC20 [ (SA001A) ]	PALCE16V8Q@SOIC20
PALCE16V8Z [ (SA001A) ]	
PALCE16V8Z@SOIC20 [ (SA404) ]	PALCE16V8Z@PLCC20
PALCE20RA10 [ (SA404) ]	
PALCE20RA10@PLCC28 [ (SA008A) ]	PALCE20RA10@SOIC24
PALCE20RA10H [ (SA008A) ]	
PALCE20RA10H@SOIC24 [ (SA404) ]	PALCE20RA10H@PLCC28
PALCE20RA10Q [ (SA404) ]	
PALCE20RA10Q@PLCC28 [ (SA008A) ]	PALCE20RA10Q@SOIC24
PALCE20V8H [ (SA008A) ]	
PALCE20V8H@SOIC24 [ (SA404) ]	PALCE20V8H@PLCC28
PALCE20V8Q [ (SA404) ]	
PALCE20V8Q@PLCC28 [ (SA008A) ]	PALCE20V8Q@SOIC24
PALCE22V10H [ (SA008A) ]	
PALCE22V10H@SOIC24 [ (SA404) ]	PALCE22V10H@PLCC28
PALCE22V10Q [ (SA404) ]	
PALCE22V10Q@PLCC28 [ (SA008A) ]	PALCE22V10Q@SOIC24

[ (SA404) ]	
PALCE22V10Z	PALCE22V10Z@PLCC28
[ (SA008A) ]	
PALCE22V10Z@SOIC24 [ (SA404) ]	
PALLV16V8	
PALLV16V8@PLCC20 [ (SA001A) ]	PALLV16V8@SOIC20
[ (SA404) ]	
PALLV16V8Z	PALLV16V8Z@PLCC20
[ (SA001A) ]	
PALLV16V8Z@SOIC20 [ (SA404) ]	

## MICROCONTROLLER

AM87C51	AM87C51@PLCC44
[ (SA244) ]	
AM87C51@TQFP44 [ (SA245A) ]	
AM87C521	
AM87C521@PLCC44 [ (SA244) ]	AM87C521@TQFP44
[ (SA245A) ]	
AM87C541	AM87C541@PLCC44
[ (SA244) ]	
AM87C541@TQFP44 [ (SA245A) ]	

## AMI SEMICONDUCTOR

### E (E) PROM / FRAM / NVRAM

N256S0818HDA	N256S0818HDA@SOIC8
[ (SA602A) ]	
N256S0818HDA@TSSOP8 [ (SA026) ]	
N256S0830HDA	
N256S0830HDA@SOIC8 [ (SA602A) ]	N256S0830HDA@TSSOP8
[ (SA026) ]	
N64S0818HDA	N64S0818HDA@SOIC8
[ (SA602A) ]	
N64S0818HDA@TSSOP8 [ (SA026) ]	
N64S0830HDA	
N64S0830HDA@SOIC8 [ (SA602A) ]	N64S0830HDA@TSSOP8
[ (SA026) ]	

# AMIC

## E ( E ) PROM / FRAM / NVRAM

A25L010 [ ( SA602A ) ]	A25L010 [ 150mil ] @SOP8
A25L010 [ 209mil ] @SOP8 [ ( SA605A ) ]	
A25L016 A25L016 @SOP8 [ ( SA023A ) ]	
A25L020 A25L020 [ 150mil ] @SOP8 [ ( SA602A ) ]	A25L020 [ 209mil ] @SOP8
[ ( SA605A ) ]	
A25L032 [ ( SA023A ) ]	A25L032 @SOP8
A25L040 [ ( SA683 ) ]	A25L040 @QFN8
A25L040 @SOP16 [ ( SA404 ) ]	A25L040 @SOP8
[ ( SA602A ) ]	
A25L05P ( Bottom ) [ ( SA683 ) ]	A25L05P ( Bottom ) @QFN8
A25L05P ( Bottom ) [ 150mil ] @SOP8 [ ( SA602A ) ]	
A25L05P ( Bottom ) [ 209mil ] @SOP8 [ ( SA605A ) ]	
A25L05P ( Top ) [ ( SA683 ) ]	A25L05P ( Top ) @QFN8
A25L05P ( Top ) [ 150mil ] @SOP8 [ ( SA602A ) ]	
A25L05P ( Top ) [ 209mil ] @SOP8 [ ( SA605A ) ]	
A25L080 [ ( SA683 ) ]	A25L080 @QFN8
A25L080 @SOP16 [ ( SA404 ) ]	A25L080 @SOP8
[ ( SA023A ) ]	
A25L10P ( Bottom ) [ ( SA683 ) ]	A25L10P ( Bottom ) @QFN8
A25L10P ( Bottom ) [ 150mil ] @SOP8 [ ( SA602A ) ]	
A25L10P ( Bottom ) [ 209mil ] @SOP8 [ ( SA605A ) ]	
A25L10P ( Top ) [ ( SA683 ) ]	A25L10P ( Top ) @QFN8
A25L10P ( Top ) [ 150mil ] @SOP8 [ ( SA602A ) ]	
A25L10P ( Top ) [ 209mil ] @SOP8 [ ( SA605A ) ]	
A25L16P ( Bottom ) @QFN8 [ ( SA683 ) ]	
A25L16P ( Bottom ) @QFN8 ( ISP ) [ ISP-HEADER01 ]	
A25L16P ( Bottom ) @SOP16 [ ( SA404 ) ]	
A25L16P ( Bottom ) @SOP16 ( ISP ) [ ISP-HEADER01 ]	
A25L16P ( Bottom ) @SOP8 [ ( SA023A ) ]	

A25L16P(Bottom)@SOP8(ISP) [ISP-HEADER01]  
A25L16P(Top)@QFN8 [(SA683)]  
A25L16P(Top)@QFN8(ISP) [ISP-HEADER01]  
A25L16P(Top)@SOP16 [(SA404)]  
A25L16P(Top)@SOP16(ISP) [ISP-HEADER01]  
A25L16P(Top)@SOP8 [(SA023A)]  
A25L16P(Top)@SOP8(ISP) [ISP-HEADER01]  
A25L20P(Bottom) A25L20P(Bottom)@QFN8  
[(SA683)]  
A25L20P(Bottom)[150mil]@SOP8 [(SA602A)]  
A25L20P(Bottom)[209mil]@SOP8 [(SA605A)]  
A25L20P(Top) A25L20P(Top)@QFN8  
[(SA683)]  
A25L20P(Top)[150mil]@SOP8 [(SA602A)]  
A25L20P(Top)[209mil]@SOP8 [(SA605A)]  
A25L40P(Bottom Boot)  
A25L40P(Bottom Boot)@QFN8 [(SA683)]  
A25L40P(Bottom Boot)@SOP16 [(SA404)]  
A25L40P(Bottom Boot)@SOP8 [(SA602A)]  
A25L40P(Top Boot) A25L40P(Top Boot)@QFN8  
[(SA683)]  
A25L40P(Top Boot)@SOP16 [(SA404)]  
A25L40P(Top Boot)@SOP8 [(SA602A)]  
A25L42P(Bottom Boot)  
A25L42P(Bottom Boot)@QFN8 [(SA683)]  
A25L42P(Bottom Boot)@SOP16 [(SA404)]  
A25L42P(Bottom Boot)@SOP8 [(SA602A)]  
A25L42P(Top Boot) A25L42P(Top Boot)@QFN8  
[(SA683)]  
A25L42P(Top Boot)@SOP16 [(SA404)]  
A25L42P(Top Boot)@SOP8 [(SA602A)]  
A25L512 A25L512[150mil]@SOP8  
[(SA602A)]  
A25L512[209mil]@SOP8 [(SA605A)]  
A25L80P  
A25L80P@QFN8 [(SA683)] A25L80P@SOP16  
[(SA404)]  
A25L80P@SOP8 [(SA023A)] A25L82P(Bottom  
Boot)  
A25L82P(Bottom Boot)@QFN8 [(SA683)]  
A25L82P(Bottom Boot)@SOP16 [(SA404)]  
A25L82P(Bottom Boot)@SOP8 [(SA023A)]  
A25L82P(Top Boot) A25L82P(Top Boot)@QFN8

[ (SA683) ]	
A25L82P(Top Boot)@SOP16 [ (SA404) ]	
A25L82P(Top Boot)@SOP8 [ (SA023A) ]	
A25LS080	A25LS080@QFN8
[ (SA683) ]	
A25LS080@SOP16 [ (SA404) ]	A25LS080@SOP8
[ (SA023A) ]	
A27020	A27020@PLCC32
[ (SA015A1T) ]	
A27020@TSOP32 [ (SA410T) ]	
A27020L	
A27020L@PLCC32 [ (SA015A1T) ]	A27020L@TSOP32
[ (SA410T) ]	
A275308	A275308@PLCC32
[ (SA015A1T) ]	
A276308	A276308
(E)	
A276308(E)@PLCC32 [ (SA015A1T) ]	A276308(E)@SOIC28
[ (SA404) ]	
A276308@PLCC32 [ (SA015A1T) ]	A276308@SOIC28
[ (SA404) ]	
A276308A	A276308A
(L)	
A276308A(L)@PLCC32 [ (SA015A1T) ]	A276308A(L)@SOIC28
[ (SA404) ]	
A276308A@PLCC32 [ (SA015A1T) ]	A276308A@SOIC28
[ (SA404) ]	
A277308	A277308@PLCC32
[ (SA015A1T) ]	
A277308A	A277308A@PLCC32
[ (SA015A1T) ]	
A278308	A278308@PLCC32
[ (SA015A1T) ]	
A278308A	A278308A
(L)	
A278308A(L)@PLCC32 [ (SA015A1T) ]	A278308A@PLCC32
[ (SA015A1T) ]	
A279308	A279308@PLCC32
[ (SA015A1T) ]	
A290011T	A290011T@PLCC32
[ (SA015A1T) ]	
A290011T@TSOP32 [ (SA410T) ]	
A290011U	

A290011U@PLCC32 [(SA015A1T)]	A290011U@TSOP32
[(SA410T)]	
A29001T	A29001T@PLCC32
[(SA015A1T)]	
A29001T@TSOP32 [(SA410T)]	
A29001U	
A29001U@PLCC32 [(SA015A1T)]	A29001U@TSOP32
[(SA410T)]	
A290021T	A290021T@PLCC32
[(SA015A1T)]	
A290021T@TSOP32 [(SA410T)]	
A290021U	
A290021U@PLCC32 [(SA015A1T)]	A290021U@TSOP32
[(SA410T)]	
A29002T	A29002T@PLCC32
[(SA015A1T)]	
A29002T@TSOP32 [(SA410T)]	
A29002U	
A29002U@PLCC32 [(SA015A1T)]	A29002U@TSOP32
[(SA410T)]	
A29010	A29010@PLCC32
[(SA015A1T)]	
A29010@TSOP32 [(SA410T)]	
A29040	
A29040@PLCC32 [(SA015A1T)]	A29040@TSOP32
[(SA410T)]	
A29040A	A29040A@PLCC32
[(SA015A1T)]	
A29040A@TSOP32 [(SA410T)]	
A29040B	
A29040B@PLCC32 [(SA015A1T)]	A29040B@TSOP32
[(SA410T)]	
A29400TM@PSOP44 [(SA638)]	A29400TV@TSOP48 [(SA247-
B005)]	
A29400UM@PSOP44 [(SA638)]	A29400UV@TSOP48 [(SA247-
B005)]	
A29512	A29512@PLCC32
[(SA015A1T)]	
A29512@TSOP32 [(SA410T)]	
A29512A	
A29512A@PLCC32 [(SA015A1T)]	A29512A@TSOP32
[(SA410T)]	
A29800TM@PSOP44 [(SA638)]	A29800TV@TSOP48 [(SA247-

B005) ]  
A29800UM@PSOP44 [ (SA638) ]                      A29800UV@TSOP48 [ (SA247-  
B005) ]  
A29DL162TG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29DL162TV@TSOP48 [ (SA247-B005) ]  
A29DL162UG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29DL162UV@TSOP48 [ (SA247-B005) ]  
A29DL163TG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29DL163TV@TSOP48 [ (SA247-B005) ]  
A29DL163UG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29DL163UV@TSOP48 [ (SA247-B005) ]  
A29DL164TG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29DL164TV@TSOP48 [ (SA247-B005) ]  
A29DL164UG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29DL164UV@TSOP48 [ (SA247-B005) ]  
A29DL320FTV@TSOP48 [ (SA247-B005) ]  
A29DL320FUV@TSOP48 [ (SA247-B005) ]  
A29DL322TG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29DL322TV@TSOP48 [ (SA247-B005) ]  
A29DL322UG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29DL322UV@TSOP48 [ (SA247-B005) ]  
A29DL323TG(New)@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29DL323TG@FBGA63 [ (SA642A-B026A-Y096F001) ]  
A29DL323TV(New)@TSOP48 [ (SA247-B005) ]  
A29DL323TV@TSOP48 [ (SA247-B005) ]  
A29DL323UG(New)@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29DL323UG@FBGA63 [ (SA642A-B026A-Y096F001) ]  
A29DL323UV(New)@TSOP48 [ (SA247-B005) ]  
A29DL323UV@TSOP48 [ (SA247-B005) ]  
A29DL324TG(New)@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29DL324TG@FBGA63 [ (SA642A-B026A-Y096F001) ]  
A29DL324TV(New)@TSOP48 [ (SA247-B005) ]  
A29DL324TV@TSOP48 [ (SA247-B005) ]  
A29DL324UG(New)@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29DL324UG@FBGA63 [ (SA642A-B026A-Y096F001) ]  
A29DL324UV(New)@TSOP48 [ (SA247-B005) ]  
A29DL324UV@TSOP48 [ (SA247-B005) ]                      A29L004ATL@PLCC32  
[ (SA015A1T) ]  
A29L004ATV@TSOP32 [ (SA410T) ]                      A29L004ATW@TSOP40  
[ (SA409T) ]  
A29L004ATY@VSOP32 [ (SA620) ]                      A29L004AUL@PLCC32  
[ (SA015A1T) ]  
A29L004AUV@TSOP32 [ (SA410T) ]                      A29L004AUW@TSOP40





A29L320ATV@TSOP48 [ ( SA247-B005 ) ]  
A29L320AUG@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
A29L320AUV@TSOP48 [ ( SA247-B005 ) ]  
A29L400ATG@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
A29L400ATM@PSOP44 [ ( SA638 ) ]                      A29L400ATV@TSOP48 [ ( SA247-B005 ) ]  
A29L400AUG@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
A29L400AUM@PSOP44 [ ( SA638 ) ]                      A29L400AUV@TSOP48 [ ( SA247-B005 ) ]  
A29L400TG@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
A29L400TM@PSOP44 [ ( SA638 ) ]                      A29L400TV@TSOP48 [ ( SA247-B005 ) ]  
A29L400UG@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
A29L400UM@PSOP44 [ ( SA638 ) ]                      A29L400UV@TSOP48 [ ( SA247-B005 ) ]  
A29L800ATG@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
A29L800ATM@PSOP44 [ ( SA638 ) ]                      A29L800ATV@TSOP48 [ ( SA247-B005 ) ]  
A29L800AUG@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
A29L800AUM@PSOP44 [ ( SA638 ) ]                      A29L800AUV@TSOP48 [ ( SA247-B005 ) ]  
A29L800HTG@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
A29L800HTM@PSOP44 [ ( SA638 ) ]                      A29L800HTV@TSOP48 [ ( SA247-B005 ) ]  
A29L800HUG@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
A29L800HUM@PSOP44 [ ( SA638 ) ]                      A29L800HUV@TSOP48 [ ( SA247-B005 ) ]  
A29L800TG@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
A29L800TM@PSOP44 [ ( SA638 ) ]                      A29L800TV@TSOP48 [ ( SA247-B005 ) ]  
A29L800UG@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
A29L800UM@PSOP44 [ ( SA638 ) ]                      A29L800UV@TSOP48 [ ( SA247-B005 ) ]  
A49LF004@PLCC32 [ ( SA015A1T ) ]                      A49LF004@VSOP32  
[ ( SA620 ) ]  
A49LF004M@PLCC32 [ ( SA015A1T ) ]                      A49LF004M@VSOP32  
[ ( SA620 ) ]  
A49LF040ATL@PLCC32 [ ( SA015A1T ) ]                      A49LF040ATX@VSOP32  
[ ( SA620 ) ]  
A49LF040ATY@VSOP32 [ ( SA620 ) ]                      A49LF040TL@PLCC32  
[ ( SA015A1T ) ]  
A49LF040TX@VSOP32 [ ( SA620 ) ]                      A50FW040@PLCC32  
[ ( SA015A1T ) ]

A50FW040@VSOP32 [(SA620)]	A50FW040M@PLCC32
[(SA015A1T)]	
A50FW040M@VSOP32 [(SA620)]	A50LPW040@PLCC32
[(SA015A1T)]	
A50LPW040@TSOP32 [(SA410T)]	
A617308	
A617308@TSOP32 [(SA410T)]	
A61L5308	
A61L5308@TSOP28 [(SA430T)]	A623308
(M)	
A623308(R)@TSOP28 [(SA430T)]	A623308(V)@TSOP28
[(SA430T)]	
A625308(M)	A625308(R)@TSOP28
[(SA430T)]	
A625308(V)@TSOP28 [(SA430T)]	
A62L256	
A62L256(M)	A62L256(R)@TSOP28
[(SA430T)]	
A62L256(V)@TSOP28 [(SA430T)]	A62S6308
(M)	
A62S6308(X)@TSOP32 [(SA410T)]	A62S7308A
(M)	
A62S7308A(X)@TSOP32 [(SA410T)]	A62S8308A
(M)	
A62S8308A(X)@TSOP32 [(SA410T)]	A62W5308
(M)	
A62W5308(R)@TSOP28 [(SA430T)]	A62W5308(V)@TSOP28
[(SA430T)]	
A81L801TG@FBGA69 [(SA642A-B078A-Y096F001Y)]	
A81L801UG@FBGA69 [(SA642A-B078A-Y096F001Y)]	
A82DL1622TG@FBGA69 [(SA642A-B032A-Y096F001Y)]	
A82DL1622UG@FBGA69 [(SA642A-B032A-Y096F001Y)]	
A82DL1624TG@FBGA69 [(SA642A-B032A-Y096F001Y)]	
A82DL1624UG@FBGA69 [(SA642A-B032A-Y096F001Y)]	
A82DL1632TG@FBGA69 [(SA642A-B032A-Y096F001Y)]	
A82DL1632UG@FBGA69 [(SA642A-B032A-Y096F001Y)]	
A82DL1634TG@FBGA69 [(SA642A-B032A-Y096F001Y)]	
A82DL1634UG@FBGA69 [(SA642A-B032A-Y096F001Y)]	
A82DL1642TG@FBGA69 [(SA642A-B032A-Y096F001Y)]	
A82DL1642UG@FBGA69 [(SA642A-B032A-Y096F001Y)]	
A82DL1644TG@FBGA69 [(SA642A-B032A-Y096F001Y)]	
A82DL1644UG@FBGA69 [(SA642A-B032A-Y096F001Y)]	
A82DL32216TG@FBGA69 [(SA642A-B254A-Y096F001Y)]	

A82DL32216UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3224TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3224UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3228TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3228UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL32316TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL32316UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3234TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3234UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3238TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3238UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL32416TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL32416UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3244TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3244UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3248TG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]  
A82DL3248UG@FBGA69 [ ( SA642A-B254A-Y096F001Y ) ]

## ANACHIP

### E ( E ) PROM / FRAM / NVRAM

27CX010	27CX010@PLCC32
[ ( SA015A1T ) ]	
27CX010@TSOP32 [ ( SA410T ) ]	
27CX161	
27CX162	
27CX256	
27CX321	
27CX322	
27CX641	
27CX642	
93C46	93C46@SOIC8
[ ( SA602A ) ]	
93C46A	93C46A@SOIC8
[ ( SA602A ) ]	
93C56A	93C56A@SOIC8
[ ( SA602A ) ]	
93C66A	93C66A@SOIC8
[ ( SA602A ) ]	
93CX46	93CX46@SOIC8
[ ( SA602A ) ]	

93CX56	93CX56@SOIC8
[ (SA602A) ]	
93CX66	93CX66@SOIC8
[ (SA602A) ]	
AM24LC02	AM24LC02@SOIC8
[ (SA602A) ]	
AM24LC02@TSSOP8 [ (SA026) ]	
AM24LC04	
AM24LC04@SOIC8 [ (SA602A) ]	AM24LC04@TSSOP8
[ (SA026) ]	
AM24LC08	AM24LC08@SOIC8
[ (SA602A) ]	
AM24LC08@TSSOP8 [ (SA026) ]	
AM24LC16	
AM24LC16@SOIC8 [ (SA602A) ]	AM24LC16@TSSOP8
[ (SA026) ]	
AM24LC21	AM24LC21@SOIC8
[ (SA602A) ]	
AM24LC21@TSSOP8 [ (SA026) ]	
AM24LC21B	
AM24LC21B@SOIC8 [ (SA602A) ]	AM24LC21B@TSSOP8
[ (SA026) ]	
AM93LC46(08bit)	AM93LC46(08bit)@SOIC8
[ (SA602A) ]	
AM93LC46(08bit)@TSOP8 [ (SA026) ]	AM93LC46
(16bit)	
AM93LC46(16bit)@SOIC8 [ (SA602A) ]	AM93LC46(16bit)@TSOP8
[ (SA026) ]	
AM93LC56(08bit)	AM93LC56(08bit)@SOIC8
[ (SA602A) ]	
AM93LC56(08bit)@TSOP8 [ (SA026) ]	AM93LC56
(16bit)	
AM93LC56(16bit)@SOIC8 [ (SA602A) ]	AM93LC56(16bit)@TSOP8
[ (SA026) ]	
AM93LC66(08bit)	AM93LC66(08bit)@SOIC8
[ (SA602A) ]	
AM93LC66(08bit)@TSOP8 [ (SA026) ]	AM93LC66
(16bit)	
AM93LC66(16bit)@SOIC8 [ (SA602A) ]	AM93LC66(16bit)@TSOP8
[ (SA026) ]	
AM93LC86(08bit)	AM93LC86(08bit)@SOIC8
[ (SA602A) ]	
AM93LC86(08bit)@TSOP8 [ (SA026) ]	AM93LC86

(16bit)

AM93LC86(16bit)@SOIC8 [(SA602A)]  
[(SA026)]

AM93LC86(16bit)@TSOP8

## PLD

PA7024

[(SA008A)]

PA7024(JN)@PLCC28 [(SA008A)]

[(SA404)]

PA7128

[(SA008A)]

PA7128@SOIC28 [(SA404)]

PA7140

PA7140@PLCC44 [(SA244)]

[(SA245A)]

PA7536

[(SA008A)]

PA7536@SOIC28 [(SA404)]

PA7540

PA7540(J)@PLCC28 [(SA008A)]

[(SA008A)]

PA7572

[(SA244)]

PA7572@TQFP44 [(SA245A)]

PEEL18CV8Z

PEEL18CV8Z@PLCC20 [(SA001A)]

[(SA404)]

PEEL18CV8Z@TSOP20 [(SA026)]

PEEL18LV8Z

PEEL18LV8Z@PLCC20 [(SA001A)]

[(SA404)]

PEEL18LV8Z@TSOP20 [(SA026)]

PEEL22CV10A

PEEL22CV10A@PLCC28 [(SA008A)]

[(SA404)]

PEEL22CV10A@TSOP24 [(SA026)]

+

PEEL22CV10A+@PLCC28 [(SA008A)]

[(SA404)]

PEEL22CV10A+@TSOP24 [(SA026)]

+

PA7024(J)@PLCC28

PA7024@SOIC24

PA7128@PLCC28

PA7140@TQFP44

PA7536@PLCC28

PA7540(JN)@PLCC28

PA7572@PLCC44

PEEL18CV8Z@SOIC20

PEEL18LV8Z@SOIC20

PEEL22CV10A@SOIC24

PEEL22CV10A

PEEL22CV10A+@SOIC24

PEEL22CV10A+

PEEL22CV10A++@PLCC28 [(SA008A)]	PEEL22CV10A++@SOIC24
[(SA404)]	
PEEL22CV10A++@TSOP24 [(SA026)]	
PEEL22CV10AZ	
PEEL22CV10AZ@PLCC28 [(SA008A)]	PEEL22CV10AZ@SOIC24
[(SA404)]	
PEEL22CV10AZ@TSOP24 [(SA026)]	PEEL22CV10AZ
+	
PEEL22CV10AZ+@PLCC28 [(SA008A)]	PEEL22CV10AZ+@SOIC24
[(SA404)]	
PEEL22CV10AZ+@TSOP24 [(SA026)]	PEEL22CV10AZ+
+	
PEEL22CV10AZ++@PLCC28 [(SA008A)]	PEEL22CV10AZ++@SOIC24
[(SA404)]	
PEEL22CV10AZ++@TSOP24 [(SA026)]	
PEEL22LV10AZ	
PEEL22LV10AZ@PLCC28 [(SA008A)]	PEEL22LV10AZ@SOIC24
[(SA404)]	
PEEL22LV10AZ@TSOP24 [(SA026)]	PEEL22LV10AZ
+	
PEEL22LV10AZ+@PLCC28 [(SA008A)]	PEEL22LV10AZ+@SOIC24
[(SA404)]	
PEEL22LV10AZ+@TSOP24 [(SA026)]	PEEL22LV10AZ+
+	
PEEL22LV10AZ++@PLCC28 [(SA008A)]	PEEL22LV10AZ++@SOIC24
[(SA404)]	
PEEL22LV10AZ++@TSOP24 [(SA026)]	

## APLUS FLASH

### E (E) PROM / FRAM / NVRAM

AF24BC01	AF24BC01@SOIC8
[(SA602A)]	
AF24BC01@TSSOP8 [(SA026)]	
AF24BC02	
AF24BC02@SOIC8 [(SA602A)]	AF24BC02@TSSOP8
[(SA026)]	
AF24BC04	AF24BC04@SOIC8
[(SA602A)]	
AF24BC04@TSSOP8 [(SA026)]	
AF24BC08	

AF24BC08@SOIC8 [(SA602A)]	AF24BC08@TSSOP8
[(SA026)]	
AF24BC128	AF24BC128@SOIC8
[(SA602A)]	
AF24BC128@TSOP8 [(SA026)]	
AF24BC16	
AF24BC16@SOIC8 [(SA602A)]	AF24BC16@TSSOP8
[(SA026)]	
AF24BC256	AF24BC256@SOIC8
[(SA602A)]	
AF24BC256@TSOP8 [(SA026)]	
AF24BC32	
AF24BC32@SOIC8 [(SA602A)]	AF24BC32@TSOP8
[(SA026)]	
AF24BC64	AF24BC64@SOIC8
[(SA602A)]	
AF24BC64@TSOP8 [(SA026)]	
AF24C128	
AF24C128@SOIC8 [(SA602A)]	AF24C128@TSOP8
[(SA026)]	
AF24C256	AF24C256@SOIC8
[(SA602A)]	
AF24C256@TSOP8 [(SA026)]	
AF24C32	
AF24C32@SOIC8 [(SA602A)]	AF24C32@TSOP8
[(SA026)]	
AF24C64	AF24C64@SOIC8
[(SA602A)]	
AF24C64@TSOP8 [(SA026)]	
AF25BC128	
AF25BC128@SOIC8 [(SA602A)]	AF25BC128@TSOP8
[(SA026)]	
AF25BC256	AF25BC256@SOIC8
[(SA602A)]	
AF25BC256@TSOP8 [(SA026)]	AF93BC46
(08bit)	
AF93BC46(08bit)@SOIC8 [(SA602A)]	AF93BC46(08bit)@TSOP8
[(SA026)]	
AF93BC46(16bit)	AF93BC46(16bit)@SOIC8
[(SA602A)]	
AF93BC46(16bit)@TSOP8 [(SA026)]	AF93BC56
(08bit)	
AF93BC56(08bit)@SOIC8 [(SA602A)]	AF93BC56(08bit)@TSOP8

[(SA026)]	
AF93BC56(16bit)	AF93BC56(16bit)@SOIC8
[(SA602A)]	
AF93BC56(16bit)@TSOP8 [(SA026)]	AF93BC66
(08bit)	
AF93BC66(08bit)@SOIC8 [(SA602A)]	AF93BC66(08bit)@TSOP8
[(SA026)]	
AF93BC66(16bit)	AF93BC66(16bit)@SOIC8
[(SA602A)]	
AF93BC66(16bit)@TSOP8 [(SA026)]	AF93BC86
(08bit)	
AF93BC86(08bit)@SOIC8 [(SA602A)]	AF93BC86(08bit)@TSOP8
[(SA026)]	
AF93BC86(16bit)	AF93BC86(16bit)@SOIC8
[(SA602A)]	
AF93BC86(16bit)@TSOP8 [(SA026)]	AF93C46
(08bit)	
AF93C46(08bit)@SOIC8 [(SA602A)]	AF93C46(08bit)@TSOP8
[(SA026)]	
AF93C46(16bit)	AF93C46(16bit)@SOIC8
[(SA602A)]	
AF93C46(16bit)@TSOP8 [(SA026)]	AF93C56
(08bit)	
AF93C56(08bit)@SOIC8 [(SA602A)]	AF93C56(08bit)@TSOP8
[(SA026)]	
AF93C56(16bit)	AF93C56(16bit)@SOIC8
[(SA602A)]	
AF93C56(16bit)@TSOP8 [(SA026)]	AF93C66
(08bit)	
AF93C66(08bit)@SOIC8 [(SA602A)]	AF93C66(08bit)@TSOP8
[(SA026)]	
AF93C66(16bit)	AF93C66(16bit)@SOIC8
[(SA602A)]	
AF93C66(16bit)@TSOP8 [(SA026)]	AF93C86
(08bit)	
AF93C86(08bit)@SOIC8 [(SA602A)]	AF93C86(08bit)@TSOP8
[(SA026)]	
AF93C86(16bit)	AF93C86(16bit)@SOIC8
[(SA602A)]	
AF93C86(16bit)@TSOP8 [(SA026)]	

## ARTSCHIP



## E ( E ) PROM / FRAM / NVRAM

24AA02	24AA02@MSOP8
[ ( SA666 ) ]	
24AA02@SOIC8 [ ( SA602A ) ]	24AA02@SOT5
[ ( SA698 ) ]	
24AA02@TSSOP8 [ ( SA026 ) ]	
24LC01A	
24LC01A@SOIC8 [ ( SA602A ) ]	24LC01A@SOT5
[ ( SA698 ) ]	
24LC01A@TSSOP8 [ ( SA026 ) ]	
24LC01B	
24LC01B@SOIC8 [ ( SA602A ) ]	24LC01B@SOT5
[ ( SA698 ) ]	
24LC01B@TSSOP8 [ ( SA026 ) ]	
24LC02A	
24LC02A@SOIC8 [ ( SA602A ) ]	24LC02A@SOT5
[ ( SA698 ) ]	
24LC02A@TSSOP8 [ ( SA026 ) ]	
24LC02B	
24LC02B@MSOP8 [ ( SA666 ) ]	24LC02B@SOIC8
[ ( SA602A ) ]	
24LC02B@SOT5 [ ( SA698 ) ]	24LC02B@TSSOP8
[ ( SA026 ) ]	
24LC04A	24LC04A@SOIC8
[ ( SA602A ) ]	
24LC04A@SOT5 [ ( SA698 ) ]	24LC04A@TSSOP8
[ ( SA026 ) ]	
24LC04B	24LC04B@MSOP8
[ ( SA666 ) ]	
24LC04B@SOIC8 [ ( SA602A ) ]	24LC04B@SOT5
[ ( SA698 ) ]	
24LC04B@TSSOP8 [ ( SA026 ) ]	
24LC08A	
24LC08A@SOIC8 [ ( SA602A ) ]	24LC08A@SOT5
[ ( SA698 ) ]	
24LC08A@TSSOP8 [ ( SA026 ) ]	
24LC08B	
24LC08B@MSOP8 [ ( SA666 ) ]	24LC08B@SOIC8
[ ( SA602A ) ]	
24LC08B@SOT5 [ ( SA698 ) ]	24LC08B@TSSOP8
[ ( SA026 ) ]	

24LC16A [ (SA602A) ]	24LC16A@SOIC8
24LC16A@SOT5 [ (SA698) ] [ (SA026) ]	24LC16A@TSSOP8
24LC256B [ (SA666) ]	24LC256B@MSOP8
24LC256B@SOIC8 [ (SA602A) ] [ (SA026) ]	24LC256B@TSSOP8
24LC32 [ (SA026) ]	24LC32@SOIC14
24LC32@SOIC8 [ (SA602A) ] [ (SA026) ]	24LC32@TSSOP8
24LC64 [ (SA026) ]	24LC64@SOIC14
24LC64@SOIC8 [ (SA602A) ] [ (SA026) ]	24LC64@TSSOP8

## ASAHI KASEI(AKM)

### E (E) PROM/FRAM/NVRAM

AK27CX161	
AK27CX162	
AK27CX321	
AK27CX322	
AK27CX641	
AK27CX642	
AK6002A(F)@SOP8 [ (SA602A) ] [ (SA026) ]	AK6002A(V)@TSSOP8
AK6003A(V)@TSSOP8 [ (SA026) ] [ (SA602A) ]	AK6004A(F)@SOP8
AK6004A(M)@SSOP8 [ (SA605A) ] [ (SA602A) ]	AK6008A(F)@SOP8
AK6010A(F)@SOP8 [ (SA602A) ] [ (SA602A) ]	AK6012A(F)@SOP8
AK6416A(M)@SSOP8 [ (SA026) ] [ (SA602A) ]	AK6416C(F)@SOP8
AK6420A(F)@SOP8 [ (SA602A) ] [ (SA605A) ]	AK6420A(M)@SSOP8
AK6420B(H)@MSOP8 [ (SA666) ] [ (SA602A) ]	AK6440A(F)@SOP8
AK6440A(M)@SSOP8 [ (SA605A) ]	AK6440B(H)@MSOP8

[ ( SA666 ) ]	
AK6480A(F)@SOP8 [ ( SA602A ) ]	AK6480A(M)@SSOP8
[ ( SA605A ) ]	
AK6480B(H)@MSOP8 [ ( SA666 ) ]	AK6480C(F)@SOP8
[ ( SA602A ) ]	
AK6480C(H)@MSOP8 [ ( SA666 ) ]	AK6480C(L)
@SON8	
AK6480C(M)@SSOP8 [ ( SA605A ) ]	AK6481C(H)@MSOP8
[ ( SA666 ) ]	
AK6481C(M)@SSOP8 [ ( SA605A ) ]	AK6508C(T)@MSOP8
[ ( SA666 ) ]	
AK6508C(U)@USON8	AK6510C(L)
@SONW8	
AK6510C(M)@SSOP8 [ ( SA026 ) ]	AK6512C(L)
@SONW8	
AK6512C(M)@SSOP8 [ ( SA026 ) ]	AK6514C(F)@SOP8
[ ( SA602A ) ]	
AK6514C(N)@QFN20 [ ( SA692 ) ]	AK6516C(F)@SOP8
[ ( SA602A ) ]	
AK93C10A(F)@SOP8 [ ( SA602A ) ]	AK93C41A(V)@TSSOP8
[ ( SA026 ) ]	
AK93C45	AK93C45(F)@SOP8
[ ( SA602A ) ]	
AK93C45A(F)@SOP8 [ ( SA602A ) ]	AK93C45A(NF)@SOP8
[ ( SA602A ) ]	
AK93C45A(V)@TSSOP8 [ ( SA026 ) ]	AK93C45B(H)@MSOP8
[ ( SA666 ) ]	
AK93C45B(L)@SON8	AK93C45C(T)@MSOP8
[ ( SA666 ) ]	
AK93C45C(U)@USON8	
AK93C45L	
AK93C45L(F)@SOP8 [ ( SA602A ) ]	
AK93C46	
AK93C46(F)@SOP8 [ ( SA602A ) ]	AK93C46A(F)@SOP8
[ ( SA602A ) ]	
AK93C46A(NF)@SOP8 [ ( SA602A ) ]	AK93C46A(V)@TSSOP8
[ ( SA026 ) ]	
AK93C46B(H)@MSOP8 [ ( SA666 ) ]	AK93C46B(L)
@SON8	
AK93C46C(T)@MSOP8 [ ( SA666 ) ]	AK93C46C(U)
@USON8	
AK93C46L	AK93C46L(F)@SOP8
[ ( SA602A ) ]	

AK93C51A(V)@TSSOP8 [(SA026)]  
AK93C55  
AK93C55(F)@SOP8 [(SA602A)]  
[(SA602A)]  
AK93C55A(NF)@SOP8 [(SA602A)]  
[(SA026)]  
AK93C55B(H)@MSOP8 [(SA666)]  
@SON8  
AK93C55C(T)@MSOP8 [(SA666)]  
@USON8  
AK93C55L  
[(SA602A)]  
AK93C56  
[(SA602A)]  
AK93C56A(F)@SOP8 [(SA602A)]  
[(SA602A)]  
AK93C56A(V)@TSSOP8 [(SA026)]  
[(SA666)]  
AK93C56B(L)@SON8  
[(SA666)]  
AK93C56C(U)@USON8  
AK93C56L  
AK93C56L(F)@SOP8 [(SA602A)]  
[(SA026)]  
AK93C65  
[(SA602A)]  
AK93C65A(F)@SOP8 [(SA602A)]  
[(SA602A)]  
AK93C65A(V)@TSSOP8 [(SA026)]  
[(SA666)]  
AK93C65B(L)@SON8  
[(SA666)]  
AK93C65C(U)@USON8  
AK93C65L  
AK93C65L(F)@SOP8 [(SA602A)]  
AK93C66  
AK93C66(F)@SOP8 [(SA602A)]  
[(SA602A)]  
AK93C66A(NF)@SOP8 [(SA602A)]  
[(SA026)]  
AK93C66B(H)@MSOP8 [(SA666)]  
@SON8  
AK93C66C(T)@MSOP8 [(SA666)]

AK93C55A(F)@SOP8  
AK93C55A(V)@TSSOP8  
AK93C55B(L)  
AK93C55C(U)  
AK93C55L(F)@SOP8  
AK93C56(F)@SOP8  
AK93C56A(NF)@SOP8  
AK93C56B(H)@MSOP8  
AK93C56C(T)@MSOP8  
AK93C61A(V)@TSSOP8  
AK93C65(F)@SOP8  
AK93C65A(NF)@SOP8  
AK93C65B(H)@MSOP8  
AK93C65C(T)@MSOP8  
AK93C66A(F)@SOP8  
AK93C66A(V)@TSSOP8  
AK93C66B(L)  
AK93C66C(U)

@USON8	
AK93C66L	AK93C66L(F)@SOP8
[(SA602A)]	
AK93C75	AK93C75(F)@SOP8
[(SA602A)]	
AK93C75A(F)@SOP8	AK93C75A(NF)@SOP8
[(SA602A)]	
AK93C75A(V)@TSSOP8	AK93C75B(H)@MSOP8
[(SA026)]	
[(SA666)]	
AK93C75L	AK93C75L(F)@SOP8
[(SA602A)]	
AK93C85	AK93C85(F)@SOP8
[(SA602A)]	
AK93C85L	AK93C85L(F)@SOP8
[(SA602A)]	
AK93C95A(F)@SOP8	AK9822(M)@SSOP8
[(SA602A)]	
[(SA026)]	
AK9824(M)@SSOP8	AK9844@SOIC14
[(SA026)]	
[(SA602)]	

## ASD

### E(E) PROM/FRAM/NVRAM

AE29F1008  
AE29F2008

## ASI

### E(E) PROM/FRAM/NVRAM

AS58C1001	AS58C1001@PLCC32
[(SA015A1T)]	
AS58C1001@SSOP32	[(SA438T)]

## ASP

### MICROCONTROLLER

AP827C51  
[ (SA244) ]  
AP827C52  
[ (SA244) ]  
AP827C54  
[ (SA244) ]  
AP827C58  
[ (SA244) ]

AP827C51@PLCC44  
  
AP827C52@PLCC44  
  
AP827C54@PLCC44  
  
AP827C58@PLCC44

## ATC

### E ( E ) PROM / FRAM / NVRAM

ATC24C02  
[ (SA602A) ]  
ATC24C02@TSSOP8 [ (SA026) ]  
ATC24C04  
ATC24C04@SOIC8 [ (SA602A) ]  
[ (SA026) ]  
ATC24C08  
[ (SA602A) ]  
ATC24C08@TSSOP8 [ (SA026) ]  
ATC24C16  
ATC24C16@SOIC8 [ (SA602A) ]  
[ (SA026) ]  
ATC24LC02  
[ (SA602A) ]  
ATC24LC02@TSSOP8 [ (SA026) ]  
ATC24LC02A  
ATC24LC02A@SOIC8 [ (SA602A) ]  
[ (SA026) ]  
ATC24LC04  
[ (SA602A) ]  
ATC24LC04@TSSOP8 [ (SA026) ]  
ATC24LC08  
ATC24LC08@SOIC8 [ (SA602A) ]  
[ (SA026) ]  
ATC24LC16  
[ (SA602A) ]  
ATC24LC16@TSSOP8 [ (SA026) ]  
(08bit)  
ATC93C46(08bit)@SOIC8 [ (SA602A) ]

ATC24C02@SOIC8  
  
  
ATC24C04@TSSOP8  
  
ATC24C08@SOIC8  
  
  
ATC24C16@TSSOP8  
  
ATC24LC02@SOIC8  
  
  
ATC24LC02A@TSSOP8  
  
ATC24LC04@SOIC8  
  
  
ATC24LC08@TSSOP8  
  
ATC24LC16@SOIC8  
  
ATC93C46  
  
ATC93C46

(16bit)

ATC93C46(16bit)@SOIC8 [(SA602A)]

ATC93C46R(08bit)@SOIC8 [(SA602A)]

ATC93C46R(16bit)@SOIC8 [(SA602A)]

ATC93C56(08bit)

ATC93C56(08bit)@SOIC8

[(SA602A)]

ATC93C56(16bit)

ATC93C56(16bit)@SOIC8

[(SA602A)]

ATC93C56R(08bit)@SOIC8 [(SA602A)]

ATC93C56R(16bit)@SOIC8 [(SA602A)]

ATC93C66(08bit)

ATC93C66(08bit)@SOIC8

[(SA602A)]

ATC93C66(16bit)

ATC93C66(16bit)@SOIC8

[(SA602A)]

ATC93C66R(08bit)@SOIC8 [(SA602A)]

ATC93C66R(16bit)@SOIC8 [(SA602A)]

ATC93LC46(08bit)

ATC93LC46(08bit)@SOIC8 [(SA602A)]

ATC93LC46(16bit)

ATC93LC46(16bit)@SOIC8 [(SA602A)]

ATC93LC46R(08bit)@SOIC8 [(SA602A)]

ATC93LC46R(16bit)@SOIC8 [(SA602A)]

ATC93LC56(08bit)

ATC93LC56(08bit)@SOIC8 [(SA602A)]

ATC93LC56(16bit)

ATC93LC56(16bit)@SOIC8 [(SA602A)]

ATC93LC56R(08bit)@SOIC8 [(SA602A)]

ATC93LC56R(16bit)@SOIC8 [(SA602A)]

ATC93LC66(08bit)

ATC93LC66(08bit)@SOIC8 [(SA602A)]

ATC93LC66(16bit)

ATC93LC66(16bit)@SOIC8 [(SA602A)]

ATC93LC66R(08bit)@SOIC8 [(SA602A)]

ATC93LC66R(16bit)@SOIC8 [(SA602A)]

## ATMEL

### E (E) PROM/FRAM/NVRAM

AT17C002@PLCC20 [(SA001A)]

AT17C002@PLCC44

[(SA244)]

AT17C002@SOIC20 [(SA404)]

AT17C002@TQFP44

[ (SA245A) ]	
AT17C002A@PLCC20 [ (SA001A) ]	AT17C002A@TQFP32
[ (SA663) ]	
AT17C010	AT17C010@PLCC20
[ (SA001A) ]	
AT17C010A	AT17C010A@PLCC20
[ (SA001A) ]	
AT17C040@PLCC44 [ (SA244) ]	AT17C040@TQFP44
[ (SA245A) ]	
AT17C128	AT17C128@PLCC20
[ (SA001A) ]	
AT17C128@SOIC20 [ (SA404) ]	AT17C128@SOIC8
[ (SA602A) ]	
AT17C128A@PLCC20 [ (SA001A) ]	
AT17C256	
AT17C256@PLCC20 [ (SA001A) ]	AT17C256@SOIC20
[ (SA404) ]	
AT17C256@SOIC8 [ (SA602A) ]	AT17C256A@PLCC20
[ (SA001A) ]	
AT17C512	AT17C512@PLCC20
[ (SA001A) ]	
AT17C512A	AT17C512A@PLCC20
[ (SA001A) ]	
AT17C65	AT17C65@PLCC20
[ (SA001A) ]	
AT17C65@SOIC20 [ (SA404) ]	AT17C65@SOIC8
[ (SA602A) ]	
AT17C65A@PLCC20 [ (SA001A) ]	AT17F040@LAP8
[ (SA760) ]	
AT17F040@PLCC20 [ (SA001A) ]	
AT17F040@PLCC20(Virtex Pinout) [ (SA001A) ]	
AT17F040A@LAP8 [ (SA760) ]	AT17F040A@PLCC20
[ (SA001A) ]	
AT17F040A@TQFP32 [ (SA663) ]	AT17F080@LAP8
[ (SA760) ]	
AT17F080@PLCC20 [ (SA001A) ]	AT17F080@PLCC44
[ (SA244) ]	
AT17F080@TQFP44 [ (SA245A) ]	AT17F080A@LAP8
[ (SA760) ]	
AT17F080A@PLCC20 [ (SA001A) ]	AT17F080A@TQFP32
[ (SA001A) ]	
AT17F16@LAP8 [ (SA760) ]	AT17F16@PLCC20
[ (SA001A) ]	



AT17F16@PLCC44 [(SA244)]	AT17F16@TQFP44
[(SA245A)]	
AT17F16A@LAP8 [(SA760)]	AT17F16A@PLCC20
[(SA001A)]	
AT17F32@PLCC44 [(SA244)]	AT17F32A@PLCC44
[(SA244)]	
AT17LV002@PLCC20 [(SA001A)]	AT17LV002@PLCC44
[(SA244)]	
AT17LV002@SOIC20 [(SA404)]	AT17LV002@TQFP44
[(SA245A)]	
AT17LV002A@PLCC20 [(SA001A)]	AT17LV002A@TQFP32
[(SA663)]	
AT17LV010	AT17LV010@PLCC20
[(SA001A)]	
AT17LV010A	AT17LV010A@PLCC20
[(SA001A)]	
AT17LV040@PLCC44 [(SA244)]	AT17LV040@TQFP44
[(SA245A)]	
AT17LV128	AT17LV128@PLCC20
[(SA001A)]	
AT17LV128@SOIC20 [(SA404)]	AT17LV128@SOIC8
[(SA602A)]	
AT17LV128A@PLCC20 [(SA001A)]	
AT17LV256	
AT17LV256@PLCC20 [(SA001A)]	AT17LV256@SOIC20
[(SA404)]	
AT17LV256@SOIC8 [(SA602A)]	AT17LV256A@PLCC20
[(SA001A)]	
AT17LV512	AT17LV512@PLCC20
[(SA001A)]	
AT17LV512A	AT17LV512A@PLCC20
[(SA001A)]	
AT17LV65	AT17LV65@PLCC20
[(SA001A)]	
AT17LV65@SOIC20 [(SA404)]	AT17LV65@SOIC8
[(SA602A)]	
AT17LV65A@PLCC20 [(SA001A)]	AT17N002@SOIC20
[(SA404)]	
AT17N002@TQFP44 [(SA245A)]	
AT17N010	
AT17N010@SOIC20 [(SA404)]	AT17N040@TQFP44
[(SA245A)]	
AT17N256	AT17N256@SOIC20

[ (SA404) ]	
AT17N256@SOIC8 [ (SA602A) ]	
AT17N512	
AT17N512@SOIC20 [ (SA404) ]	
AT24C01	
AT24C01@MSOP8 [ (SA666) ]	AT24C01@SOIC8
[ (SA602A) ]	
AT24C01@TSSOP8 [ (SA026) ]	
AT24C01A	
AT24C01A@MAP8 [ (SA724) ]	AT24C01A@SOIC8
[ (SA602A) ]	
AT24C01A@SOT23-5 [ (SA717) ]	AT24C01A@TSSOP8
[ (SA026) ]	
AT24C01B	
AT24C01B@dBGA2	
AT24C01B@MAP8 [ (SA724) ]	AT24C01B@SOIC8
[ (SA602A) ]	
AT24C01B@SOT23 [ (SA717) ]	AT24C01B@TSSOP8
[ (SA026) ]	
AT24C02	AT24C02@SOIC8
[ (SA602A) ]	
AT24C02@TSSOP8 [ (SA026) ]	
AT24C02A	
AT24C02A@SOIC8 [ (SA602A) ]	AT24C02A@TSSOP8
[ (SA026) ]	
AT24C02B	
AT24C02B@dBGA2	
AT24C02B@MAP8 [ (SA724) ]	AT24C02B@SOIC8
[ (SA602A) ]	
AT24C02B@SOT23 [ (SA717) ]	AT24C02B@TSSOP8
[ (SA026) ]	
AT24C04	AT24C04@MAP8
[ (SA724) ]	
AT24C04@SOIC8 [ (SA602A) ]	AT24C04@SOT23-5
[ (SA717) ]	
AT24C04@TSSOP8 [ (SA026) ]	
AT24C04A	
AT24C04A@MAP8 [ (SA724) ]	AT24C04A@SOIC8
[ (SA602A) ]	
AT24C04A@TSSOP8 [ (SA026) ]	
AT24C08	
AT24C08@MAP8 [ (SA724) ]	AT24C08@SOIC8
[ (SA602A) ]	

AT24C08@TSSOP8 [(SA026)]	
AT24C08A	
AT24C08A@MAP8 [(SA724)]	AT24C08A@SOIC8
[(SA602A)]	
AT24C08A@TSSOP8 [(SA026)]	
AT24C1024	
AT24C1024@LAP8 [(SA724)]	AT24C1024@SAP8
[(SA684)]	
AT24C1024@SOIC8 [(SA023A)]	AT24C1024B
(1.8V)	
AT24C1024B(1.8V)@LAP8 [(SA724)]	AT24C1024B(1.8V)@SAP8
[(SA684)]	
AT24C1024B(1.8V)@SOIC8 [(SA023A)]	
AT24C1024B(1.8V)@TSSOP8 [(SA026)]	
AT24C1024B(2.5V)	AT24C1024B(2.5V)@LAP8
[(SA724)]	
AT24C1024B(2.5V)@SAP8 [(SA684)]	
AT24C1024B(2.5V)@SOIC8 [(SA023A)]	
AT24C1024B(2.5V)@TSSOP8 [(SA026)]	
AT24C11	AT24C11@SOIC8
[(SA602A)]	
AT24C11@TSSOP8 [(SA026)]	AT24C128
(1.8V)	
AT24C128(1.8V)@MAP8 [(SA724)]	AT24C128(1.8V)@SAP8
[(SA683)]	
AT24C128(1.8V)@SOIC8 [(SA602A)]	AT24C128(1.8V)@TSSOP8
[(SA026)]	
AT24C128(2.7V)	AT24C128(2.7V)@MAP8
[(SA724)]	
AT24C128(2.7V)@SAP8 [(SA683)]	AT24C128(2.7V)@SOIC8
[(SA602A)]	
AT24C128(2.7V)@TSSOP8 [(SA026)]	
AT24C128B	
AT24C128B@MAP8 [(SA724)]	AT24C128B@SAP8
[(SA683)]	
AT24C128B@SOIC8 [(SA602A)]	AT24C128B@TSSOP8
[(SA026)]	
AT24C16	AT24C16@SOIC8
[(SA602A)]	
AT24C16@TSSOP8 [(SA026)]	
AT24C164	
AT24C164@SOIC8 [(SA602A)]	
AT24C16A	

AT24C16A@MAP8 [(SA724)]	AT24C16A@SOIC8
[(SA602A)]	
AT24C16A@TSSOP8 [(SA026)]	
AT24C16B	
AT24C16B@MAP8 [(SA724)]	AT24C16B@SOIC8
[(SA602A)]	
AT24C16B@TSSOP8 [(SA026)]	
AT24C21	
AT24C21@SOIC8 [(SA602A)]	AT24C256
(1.8V)	
AT24C256(1.8V)@MAP8 [(SA724)]	AT24C256(1.8V)@SAP8
[(SA683)]	
AT24C256(1.8V)@SOIC8 [(SA602A)]	AT24C256(1.8V)@TSSOP8
[(SA026)]	
AT24C256(2.7V)	AT24C256(2.7V)@MAP8
[(SA724)]	
AT24C256(2.7V)@SAP8 [(SA683)]	AT24C256(2.7V)@SOIC8
[(SA602A)]	
AT24C256(2.7V)@TSSOP8 [(SA026)]	
AT24C256B	
AT24C256B@MAP8 [(SA724)]	AT24C256B@SAP8
[(SA683)]	
AT24C256B@SOIC8 [(SA602A)]	AT24C256B@TSSOP8
[(SA026)]	
AT24C32	AT24C32@SOIC8
[(SA602A)]	
AT24C32@TSSOP8 [(SA026)]	
AT24C32A	
AT24C32A@MAP8 [(SA724)]	AT24C32A@SOIC8
[(SA602A)]	
AT24C32A@TSSOP8 [(SA026)]	
AT24C32C	
AT24C32C@dBGA8 [(BBBB)]	AT24C32C@MAP8
[(SA724)]	
AT24C32C@SAP8 [(SA683)]	AT24C32C@SOIC8
[(SA602A)]	
AT24C32C@TSSOP8 [(SA026)]	AT24C512
(1.8V)	
AT24C512(1.8V)@LAP8 [(SA684)]	AT24C512(1.8V)@SAP8
[(SA683)]	
AT24C512(1.8V)@SOIC8 [(SA602A)]	AT24C512(1.8V)@TSSOP8
[(SA026)]	
AT24C512(2.7V)	AT24C512(2.7V)@LAP8

[ (SA684) ]	
AT24C512(2.7V)@SAP8 [ (SA683) ]	AT24C512(2.7V)@SOIC8
[ (SA602A) ]	
AT24C512(2.7V)@TSSOP8 [ (SA026) ]	
AT24C512B	
AT24C512B@LAP8 [ (SA684) ]	AT24C512B@SAP8
[ (SA683) ]	
AT24C512B@SOIC8 [ (SA602A) ]	AT24C512B@TSSOP8
[ (SA026) ]	
AT24C64	AT24C64@SOIC8
[ (SA602A) ]	
AT24C64@TSSOP8 [ (SA026) ]	
AT24C64A	
AT24C64A@MAP8 [ (SA724) ]	AT24C64A@SOIC8
[ (SA602A) ]	
AT24C64A@TSSOP8 [ (SA026) ]	
AT24C64B	
AT24C64B@SOIC8 [ (SA602A) ]	AT24C64B@TSSOP8
[ (SA026) ]	
AT24C64C	AT24C64C@dBGA8
[ (BBBB) ]	
AT24C64C@MAP8 [ (SA724) ]	AT24C64C@SAP8
[ (SA683) ]	
AT24C64C@SOIC8 [ (SA602A) ]	AT24C64C@TSSOP8
[ (SA026) ]	
AT24CS128	AT24CS128@SOIC8
[ (SA602A) ]	
AT24HC02B	AT24HC02B@SOIC8
[ (SA602A) ]	
AT24HC02B@TSSOP8 [ (SA026) ]	AT24RF08AN@SOIC8
[ (SA602A) ]	
AT24RF08AT@TSSOP14 [ (SA026) ]	AT24RF08BN@SOIC8
[ (SA602A) ]	
AT24RF08BT@TSSOP14 [ (SA026) ]	AT24RF08CN@SOIC8
[ (SA602A) ]	
AT24RF08CT@TSSOP14 [ (SA026) ]	
AT25010	
AT25010@SOIC8 [ (SA602A) ]	
AT25010A	
AT25010A@SOIC8 [ (SA602A) ]	AT25010A@TSSOP8
[ (SA026) ]	
AT25020	AT25020@SOIC8
[ (SA602A) ]	

AT25020A [(SA602A)] AT25020A@TSSOP8 [(SA026)] AT25040 AT25040(ISP) [ISP-HEADER01] [(SA602A)] AT25040@SOIC8(ISP) [ISP-HEADER01] AT25040A HEADER01] AT25040A@SOIC8 [(SA602A)] AT25040A@SOIC8(ISP) [ISP-HEADER01] AT25080 [(SA602A)] AT25080@TSSOP14 [(SA026)] [(SA026)] AT25080A [(SA602A)] AT25080A@TSSOP14 [(SA026)] AT25080B AT25080B@dBGA8 [(BBBB)] [(SA724)] AT25080B@SOIC8 [(SA602A)] [(SA026)] AT25128 [(SA602)] AT25128@SOIC8 [(SA602A)] [(SA026)] AT25128@TSSOP20 [(SA026)] AT25128A AT25128A@dBGA8 [(BBBB)] [(SA683)] AT25128A@SOIC8(4.0) [(SA602A)] [(SA605A)] AT25128A@TSSOP14 [(SA026)] [(SA026)] AT25160 [(SA602A)] AT25160@TSSOP14 [(SA026)] [(SA026)] AT25160A [(SA602A)] AT25160A@TSSOP14 [(SA026)] AT25160B	AT25020A@SOIC8   AT25040@SOIC8  AT25040A(ISP) [ISP-  AT25080@SOIC8 AT25080@TSSOP20 AT25080A@SOIC8  AT25080B@MAP8 AT25080B@TSSOP8 AT25128@SOIC16 AT25128@TSSOP14  AT25128A@SAP8 AT25128A@SOIC8(5.4) AT25128A@TSSOP8 AT25160@SOIC8 AT25160@TSSOP20 AT25160A@SOIC8
---	--

AT25160B@dBGA8 [(BBBB)] [(SA724)]	AT25160B@MAP8
AT25160B@SOIC8 [(SA602A)] [(SA026)]	AT25160B@TSSOP8
AT25256 [(SA602)]	AT25256@SOIC16
AT25256@SOIC8 [(SA602A)] [(SA026)]	AT25256@TSSOP14
AT25256@TSSOP20 [(SA026)] AT25256A	
AT25256A@dBGA8 [(BBBB)] [(SA683)]	AT25256A@SAP8
AT25256A@SOIC8(4.0) [(SA602A)] [(SA605A)]	AT25256A@SOIC8(5.4)
AT25256A@TSSOP14 [(SA026)] [(SA026)]	AT25256A@TSSOP8
AT25320 [(SA602A)]	AT25320@SOIC8
AT25320@TSSOP14 [(SA026)] [(SA026)]	AT25320@TSSOP20
AT25320A [(SA602A)]	AT25320A@SOIC8
AT25320A@TSSOP14 [(SA026)] AT25320B	
AT25320B@dBGA8 [(BBBB)] [(SA724)]	AT25320B@MAP8
AT25320B@SOIC8 [(SA602A)] [(SA026)]	AT25320B@TSSOP8
AT25640 [(SA602A)]	AT25640@SOIC8
AT25640@TSSOP14 [(SA026)] [(SA026)]	AT25640@TSSOP20
AT25640A [(SA602A)]	AT25640A@SOIC8
AT25640A@TSSOP14 [(SA026)] AT25640B	
AT25640B@dBGA8 [(BBBB)] [(SA724)]	AT25640B@MAP8
AT25640B@SOIC8 [(SA602A)] [(SA026)]	AT25640B@TSSOP8
AT25DF021@SOIC8 [(SA602A)] [(SA683)]	AT25DF021@UDFN8
AT25DF041A@MLF8 [(SA683)]	AT25DF041A@SOIC8(4.0)

[ (SA602A) ]	
AT25DF041A@SOIC8(5.4) [ (SA605A) ]	AT25DF081@SOIC8
[ (SA602A) ]	
AT25DF081@UDFN8 [ (SA683) ]	AT25DF161@MLF8
[ (SA683) ]	
AT25DF161@SOIC8(4.0) [ (SA602A) ]	AT25DF161@SOIC8(5.4)
[ (SA605A) ]	
AT25DF321@SOIC16 [ (SA404) ]	AT25DF321@SOIC8
[ (SA605A) ]	
AT25DF641@SOIC16 [ (SA404) ]	AT25DF641@VDFN8
[ (SA683) ]	
AT25F1024	AT25F1024(W)@SOIC8
[ (SA605A) ]	
AT25F1024(W)@VQFPN8 [ (SA684) ]	AT25F1024@SOIC8
[ (SA602A) ]	
AT25F1024@VQFPN8 [ (SA683) ]	
AT25F1024A	
AT25F1024A(W)@SOIC8 [ (SA605A) ]	AT25F1024A(W)@VQFPN8
[ (SA684) ]	
AT25F1024A@SOIC8 [ (SA602A) ]	AT25F1024A@VQFPN8
[ (SA683) ]	
AT25F2048	AT25F2048(W)@SOIC8
[ (SA605A) ]	
AT25F2048(W)@VQFPN8 [ (SA684) ]	AT25F2048@SOIC8
[ (SA602A) ]	
AT25F2048@VQFPN8 [ (SA683) ]	
AT25F2048A	
AT25F2048A(W)@SOIC8 [ (SA605A) ]	AT25F2048A(W)@VQFPN8
[ (SA684) ]	
AT25F2048A@SOIC8 [ (SA602A) ]	AT25F2048A@VQFPN8
[ (SA683) ]	
AT25F4096	AT25F4096(W)@SOIC8
[ (SA605A) ]	
AT25F4096(W)@VQFPN8 [ (SA684) ]	AT25F4096@SOIC8
[ (SA602A) ]	
AT25F4096@VQFPN8 [ (SA683) ]	
AT25F4096A	
AT25F4096A(W)@SOIC8 [ (SA605A) ]	AT25F4096A(W)@VQFPN8
[ (SA684) ]	
AT25F4096A@SOIC8 [ (SA602A) ]	AT25F4096A@VQFPN8
[ (SA683) ]	
AT25F512	AT25F512(W)@SOIC8
[ (SA605A) ]	



AT25F512(W)VQFPN8 [(SA684)]	AT25F512@SOIC8
[(SA602A)]	
AT25F512@VQFPN8 [(SA683)]	
AT25F512A	
AT25F512A(W)@SOIC8 [(SA605A)]	AT25F512A(W)VQFPN8
[(SA684)]	
AT25F512A@SOIC8 [(SA602A)]	AT25F512A@VQFPN8
[(SA683)]	
AT25FS010@SAP8 [(SA683)]	AT25FS010@SOIC8
[(SA602A)]	
AT25FS040@SAP8 [(SA683)]	AT25FS040@SOIC8
[(SA602A)]	
AT25HP256	AT25HP256(W)VQFPN8
[(SA684)]	
AT25HP256@SOIC16 [(SA404)]	AT25HP256@SOIC8
[(SA602A)]	
AT25HP256@VQFPN8 [(SA683)]	
AT25HP512	
AT25HP512(W)VQFPN8 [(SA684)]	AT25HP512@SOIC16
[(SA404)]	
AT25HP512@SOIC8 [(SA602A)]	AT25HP512@VQFPN8
[(SA683)]	
AT25P1024@SOIC20 [(SA404)]	AT25P1024@VQFPN8
[(SA684)]	
AT26DF041@MLF8 [(SA683)]	AT26DF041@SOIC8(4.0)
[(SA602A)]	
AT26DF041@SOIC8(5.4) [(SA605A)]	AT26DF081@SOIC8(4.0)
[(SA602A)]	
AT26DF081@SOIC8(5.4) [(SA605A)]	AT26DF081A@SOIC8(4.0)
[(SA602A)]	
AT26DF081A@SOIC8(5.4) [(SA605A)]	AT26DF161@MLF8
[(SA683)]	
AT26DF161@SOIC8 [(SA605A)]	AT26DF161A@MLF8
[(SA683)]	
AT26DF161A@SOIC8 [(SA605A)]	AT26DF321@MLF8(5*6mm)
[(SA683)]	
AT26DF321@MLF8(6*8mm) [(SA684)]	AT26DF321@SOIC16
[(SA404)]	
AT26DF321@SOIC8 [(SA605A)]	AT26F004@MLF8
[(SA683)]	
AT26F004@SOIC8(4.0) [(SA602A)]	AT26F004@SOIC8(5.4)
[(SA605A)]	
AT27011	AT27011@PLCC32

[ (SA015A1T) ]  
AT27256  
AT2732A  
AT27BV010 AT27BV010@PLCC32  
[ (SA015A1T) ]  
AT27BV010@TSOP32 [ (SA620) ]  
AT27BV020  
AT27BV020@PLCC32 [ (SA015A1T) ] AT27BV020@TSOP32  
[ (SA620) ]  
AT27BV040 AT27BV040@PLCC32  
[ (SA015A1T) ]  
AT27BV040@TSOP32 [ (SA620) ] AT27BV1024@PLCC44  
[ (SA244) ]  
AT27BV1024@TSOP40 [ (SA623) ]  
AT27BV256  
AT27BV256@PLCC32 [ (SA015A1T) ] AT27BV256@TSOP28  
[ (SA430T) ]  
AT27BV4096 AT27BV4096@PLCC44  
[ (SA244) ]  
AT27BV4096@TSOP40 [ (SA623) ]  
AT27BV512  
AT27BV512@PLCC32 [ (SA015A1T) ] AT27BV512@SOIC28  
[ (SA630) ]  
AT27BV512@TSOP28 [ (SA430T) ] AT27BV520@SOIC20  
[ (SA404) ]  
AT27BV520@TSOP28 [ (SA430T) ] AT27BV520@TSSOP20  
[ (SA026) ]  
AT27C010 AT27C010@PLCC32  
[ (SA015A1T) ]  
AT27C010@TSOP32 [ (SA410T) ]  
AT27C010L  
AT27C010L@PLCC32 [ (SA015A1T) ] AT27C010L@TSOP32  
[ (SA410T) ]  
AT27C020 AT27C020@PLCC32  
[ (SA015A1T) ]  
AT27C020@TSOP32 [ (SA410T) ]  
AT27C040  
AT27C040@PLCC32 [ (SA015A1T) ] AT27C040@TSOP32  
[ (SA410T) ]  
AT27C080 AT27C080@PLCC32  
[ (SA015A1T) ]  
AT27C080@TSOP32 [ (SA410T) ]  
AT27C1024

AT27C1024@PLCC44 [(SA244)]	AT27C1024@TSOP40
[(SA623)]	
AT27C1024L	AT27C1024L@PLCC44
[(SA244)]	
AT27C128	AT27C128@PLCC32
[(SA015A1T)]	
AT27C2048	AT27C2048@PLCC44
[(SA244)]	
AT27C2048@TSOP40 [(SA623)]	
AT27C256	
AT27C256@PLCC32 [(SA015A1T)]	
AT27C256R	
AT27C256R@PLCC32 [(SA015A1T)]	AT27C256R@SOIC28
[(SA630)]	
AT27C256R@TSOP28 [(SA430T)]	
AT27C4096	
AT27C4096@PLCC44 [(SA244)]	AT27C4096@TSOP40
[(SA623)]	
AT27C512	AT27C512@PLCC32
[(SA015A1T)]	
AT27C512R	AT27C512R@PLCC32
[(SA015A1T)]	
AT27C512R@SOIC28 [(SA630)]	AT27C512R@TSOP28
[(SA430T)]	
AT27C513	AT27C513@PLCC32
[(SA015A1T)]	
AT27C513@SOIC28 [(SA630)]	
AT27C513R	
AT27C513R@PLCC32 [(SA015A1T)]	AT27C513R@SOIC28
[(SA630)]	
AT27C515	AT27C515@PLCC32
[(SA015A1T)]	
AT27C516	AT27C516@PLCC44
[(SA244)]	
AT27C516@TSOP40 [(SA623)]	AT27C520@SOIC20
[(SA404)]	
AT27C520@TSOP28 [(SA430T)]	AT27C520@TSSOP20
[(SA026)]	
AT27C64	
AT27C800	
AT27C800@PLCC44 [(SA244)]	AT27C800@PSOP44
[(SA638)]	
AT27HC1024	AT27HC1024@PLCC44

[ (SA244) ]	
AT27HC256	AT27HC256@PLCC32
[ (SA015A1T) ]	
AT27HC256L	AT27HC256L@PLCC32
[ (SA015A1T) ]	
AT27HC256R	AT27HC256R@PLCC32
[ (SA015A1T) ]	
AT27HC256RL	AT27HC256RL@PLCC32
[ (SA015A1T) ]	
AT27HC64	AT27HC64@PLCC32
[ (SA015A1T) ]	
AT27HC641	AT27HC641@PLCC28
[ (SA008A) ]	
AT27HC641R	AT27HC641R@PLCC28
[ (SA008A) ]	
AT27HC642	AT27HC642@PLCC28
[ (SA008A) ]	
AT27HC642R	AT27HC642R@PLCC28
[ (SA008A) ]	
AT27HC64L	AT27HC64L@PLCC32
[ (SA015A1T) ]	
AT27LV010	AT27LV010@PLCC32
[ (SA015A1T) ]	
AT27LV010@TSOP32 [ (SA620) ]	
AT27LV010A	
AT27LV010A@PLCC32 [ (SA015A1T) ]	AT27LV010A@TSOP32
[ (SA620) ]	
AT27LV020A	AT27LV020A@PLCC32
[ (SA015A1T) ]	
AT27LV020A@TSOP32 [ (SA620) ]	
AT27LV040	
AT27LV040@PLCC32 [ (SA015A1T) ]	AT27LV040@TSOP32
[ (SA620) ]	
AT27LV040A	AT27LV040A@PLCC32
[ (SA015A1T) ]	
AT27LV040A@TSOP32 [ (SA620) ]	
AT27LV1024	
AT27LV1024@PLCC44 [ (SA244) ]	
AT27LV256A	
AT27LV256A@PLCC32 [ (SA015A1T) ]	AT27LV256A@SOIC28
[ (SA630) ]	
AT27LV256A@TSOP28 [ (SA430T) ]	
AT27LV256R	

AT27LV256R@PLCC32 [(SA015A1T)] [(SA630)]	AT27LV256R@SOIC28
AT27LV256R@TSOP28 [(SA430T)]	
AT27LV4096	
AT27LV4096@PLCC44 [(SA244)]	
AT27LV512A	
AT27LV512A@PLCC32 [(SA015A1T)] [(SA630)]	AT27LV512A@SOIC28
AT27LV512A@TSOP28 [(SA430T)]	
AT27LV512R	
AT27LV512R@PLCC32 [(SA015A1T)] [(SA430T)]	AT27LV512R@TSOP28
AT27LV520@SOIC20 [(SA404)] [(SA430T)]	AT27LV520@TSOP28
AT27LV520@TSSOP20 [(SA026)]	
AT27LV800	
AT27LV800@PSOP44 [(SA638)]	
AT28BV16	
AT28BV16@PLCC32 [(SA015A1T)] [(SA404)]	AT28BV16@SOIC24
AT28BV16@TSOP28 [(SA430T)]	
AT28BV256	
AT28BV256@PLCC32 [(SA015A1T)] [(SA404)]	AT28BV256@SOIC28
AT28BV256@TSOP28 [(SA430T)]	
AT28BV64	
AT28BV64@PLCC32 [(SA015A1T)] [(SA404)]	AT28BV64@SOIC28
AT28BV64@TSOP28 [(SA430T)]	
AT28BV64B	
AT28BV64B@PLCC32 [(SA015A1T)] [(SA404)]	AT28BV64B@SOIC28
AT28BV64B@TSOP28 [(SA430T)]	
AT28C010	
AT28C010@PLCC32 [(SA015A1T)] [(SA244)]	AT28C010@PLCC44
AT28C010@TSOP32 [(SA410T)]	
AT28C010E	
AT28C010E@PLCC32 [(SA015A1T)] [(SA244)]	AT28C010E@PLCC44
AT28C010E@TSOP32 [(SA410T)]	
AT28C04	
AT28C04@PLCC32 [(SA015A1T)]	

AT28C040  
AT28C040@PLCC32 [ (SA015A1T) ]  
AT28C04E  
AT28C04E@PLCC32 [ (SA015A1T) ]  
AT28C04F  
AT28C04F@PLCC32 [ (SA015A1T) ]  
AT28C16  
AT28C16@PLCC32 [ (SA015A1T) ] AT28C16@SOIC24  
[ (SA404) ]  
AT28C16@TSOP28 [ (SA430T) ]  
AT28C16E  
AT28C16E@PLCC32 [ (SA015A1T) ]  
AT28C16F  
AT28C16F@PLCC32 [ (SA015A1T) ]  
AT28C17  
AT28C17@PLCC32 [ (SA015A1T) ] AT28C17@SOIC28  
[ (SA404) ]  
AT28C17E AT28C17E@PLCC32  
[ (SA015A1T) ]  
AT28C17F AT28C17F@PLCC32  
[ (SA015A1T) ]  
AT28C256 AT28C256@PLCC32  
[ (SA015A1T) ]  
AT28C256@SOIC28 [ (SA404) ] AT28C256@TSOP28  
[ (SA430T) ]  
AT28C256E AT28C256E@PLCC32  
[ (SA015A1T) ]  
AT28C256F AT28C256F@PLCC32  
[ (SA015A1T) ]  
AT28C64 AT28C64@PLCC32  
[ (SA015A1T) ]  
AT28C64@SOIC28 [ (SA404) ] AT28C64@TSOP28  
[ (SA430T) ]  
AT28C64B AT28C64B@PLCC32  
[ (SA015A1T) ]  
AT28C64B@SOIC28 [ (SA404) ] AT28C64B@TSOP28  
[ (SA430T) ]  
AT28C64E AT28C64E@PLCC32  
[ (SA015A1T) ]  
AT28C64E@TSOP28 [ (SA430T) ]  
AT28C64F  
AT28C64F@PLCC32 [ (SA015A1T) ] AT28C64F@TSOP28  
[ (SA430T) ]

AT28C64X [ (SA015A1T) ]	AT28C64X@PLCC32
AT28C64X@SOIC28 [ (SA404) ] [ (SA430T) ]	AT28C64X@TSOP28
AT28HC04	
AT28HC16	
AT28HC16L	
AT28HC191	
AT28HC191L	
AT28HC256	
AT28HC256@PLCC32 [ (SA015A1T) ] [ (SA430T) ]	AT28HC256@TSOP28
AT28HC256E [ (SA015A1T) ]	AT28HC256E@PLCC32
AT28HC256F [ (SA015A1T) ]	AT28HC256F@PLCC32
AT28HC256L [ (SA015A1T) ]	AT28HC256L@PLCC32
AT28HC256LE [ (SA015A1T) ]	AT28HC256LE@PLCC32
AT28HC291 [ (SA008A) ]	AT28HC291@PLCC28
AT28HC291L [ (SA008A) ]	AT28HC291L@PLCC28
AT28HC64 [ (SA015A1T) ]	AT28HC64@PLCC32
AT28HC64@TSOP28 [ (SA430T) ]	
AT28HC64B	
AT28HC64B@PLCC32 [ (SA015A1T) ] [ (SA404) ]	AT28HC64B@SOIC28
AT28HC64B@TSOP28 [ (SA430T) ]	
AT28HC64BF	
AT28HC64BF@PLCC32 [ (SA015A1T) ] [ (SA404) ]	AT28HC64BF@SOIC28
AT28HC64BF@TSOP28 [ (SA430T) ]	
AT28HC64L	
AT28HC64L@PLCC32 [ (SA015A1T) ] [ (SA430T) ]	AT28HC64L@TSOP28
AT28LV010 [ (SA015A1T) ]	AT28LV010@PLCC32
AT28LV010@TSOP32 [ (SA410T) ]	
AT28LV256	
AT28LV256@PLCC32 [ (SA015A1T) ]	AT28LV256@TSOP28

[ (SA430T) ]	
AT28LV64	AT28LV64@PLCC32
[ (SA015A1T) ]	
AT28LV64B	AT28LV64B@PLCC32
[ (SA015A1T) ]	
AT28LV64B@SOIC28 [ (SA404) ]	AT28LV64B@TSOP28
[ (SA430T) ]	
AT28MC010	AT28MC010@PLCC32
[ (SA015A1T) ]	
AT28MC010@PLCC44 [ (SA244) ]	AT28MC010@TSOP32
[ (SA410T) ]	
AT28MC020	AT28MC020@PLCC32
[ (SA015A1T) ]	
AT28MC020@PLCC44 [ (SA244) ]	AT28MC020@TSOP32
[ (SA410T) ]	
AT28MC040	AT28MC040@PLCC32
[ (SA015A1T) ]	
AT28MC040@PLCC44 [ (SA244) ]	AT28MC040@TSOP32
[ (SA410T) ]	
AT28PC64	AT28PC64@PLCC32
[ (SA015A1T) ]	
AT28PC64@TSOP28 [ (SA430T) ]	
AT28PC64E	
AT28PC64E@PLCC32 [ (SA015A1T) ]	AT28PC64E@TSOP28
[ (SA430T) ]	
AT29BV010A@PLCC32 [ (SA015A1T) ]	AT29BV010A@TSOP32
[ (SA410T) ]	
AT29BV020@PLCC32 [ (SA015A1T) ]	AT29BV020@TSOP32
[ (SA410T) ]	
AT29BV040A@TSOP32 [ (SA410T) ]	
AT29C010	
AT29C010@PLCC32 [ (SA015A1T) ]	AT29C010@TSOP32
[ (SA410T) ]	
AT29C010A	AT29C010A@PLCC32
[ (SA015A1T) ]	
AT29C010A@TSOP32 [ (SA410T) ]	
AT29C020	
AT29C020@PLCC32 [ (SA015A1T) ]	AT29C020@TSOP32
[ (SA410T) ]	
AT29C040	AT29C040@PLCC32
[ (SA015A1T) ]	
AT29C040@TSOP32 [ (SA410T) ]	
AT29C040A	



AT29C040A@PLCC32 [(SA015A1T)]	AT29C040A@TSOP32
[(SA410T)]	
AT29C1024@PLCC44 [(SA244)]	AT29C1024@TSOP48 [(SA247-
B005)]	
AT29C256	AT29C256@PLCC32
[(SA015A1T)]	
AT29C256@TSOP28 [(SA430T)]	
AT29C257	
AT29C257@PLCC32 [(SA015A1T)]	
AT29C512	
AT29C512@PLCC32 [(SA015A1T)]	AT29C512@TSOP32
[(SA410T)]	
AT29LV010	AT29LV010@PLCC32
[(SA015A1T)]	
AT29LV010@TSOP32 [(SA410T)]	AT29LV010A@PLCC32
[(SA015A1T)]	
AT29LV010A@TSOP32 [(SA410T)]	
AT29LV020	
AT29LV020@PLCC32 [(SA015A1T)]	AT29LV020@TSOP32
[(SA410T)]	
AT29LV040@TSOP32 [(SA410T)]	
AT29LV040A	
AT29LV040A@PLCC32 [(SA015A1T)]	AT29LV040A@TSOP32
[(SA410T)]	
AT29LV1024@PLCC44 [(SA244)]	AT29LV1024@TSOP48 [(SA247-
B005)]	
AT29LV256	AT29LV256@PLCC32
[(SA015A1T)]	
AT29LV256@TSOP28 [(SA430T)]	
AT29LV512	
AT29LV512@PLCC32 [(SA015A1T)]	AT29LV512@TSOP32
[(SA410T)]	
AT32C16	AT32C16@PLCC44
[(SA244)]	
AT34C02	AT34C02@SOIC8
[(SA602A)]	
AT34C02@TSSOP8 [(SA026)]	
AT34C02B	
AT34C02B@SOIC8 [(SA602A)]	AT34C02B@TSSOP8
[(SA026)]	
AT34C02C	AT34C02C@dBGA8
[(BBBB)]	
AT34C02C@MAP8 [(SA724)]	AT34C02C@SOIC8

[ (SA602A) ]  
AT34C02C@TSSOP8 [ (SA026) ]  
AT45BCM021D(page256)@SOIC8 [ (SA605A) ]  
AT45BCM021D(page256)@SOIC8(ISP) [ ISP-HEADER01 ]  
AT45BCM021D(page264)@SOIC8 [ (SA605A) ]  
AT45BCM021D(page264)@SOIC8(ISP) [ ISP-HEADER01 ]  
AT45D011@PLCC32 [ (SA015A1T) ] AT45D011@SOIC8  
[ (SA605A) ]  
AT45D011@TSSOP14 [ (SA026) ] AT45D021@PLCC32  
[ (SA015A1T) ]  
AT45D021@SOIC28 [ (SA630) ] AT45D021@TSOP28  
[ (SA430T) ]  
AT45D041@PLCC32 [ (SA015A1T) ] AT45D041@SOIC28  
[ (SA630) ]  
AT45D041@TSOP28 [ (SA430T) ] AT45D081@SOIC28  
[ (SA630) ]  
AT45D081@TSOP32 [ (SA410T) ] AT45D161@PLCC32  
[ (SA015A1T) ]  
AT45D161@SOIC28 [ (SA630) ] AT45D161@TSOP28  
[ (SA430T) ]  
AT45DB011@PLCC32 [ (SA015A1T) ] AT45DB011@SOIC8  
[ (SA605A) ]  
AT45DB011@TSSOP14 [ (SA026) ] AT45DB011B@PLCC32  
[ (SA015A1T) ]  
AT45DB011B@PLCC32(ISP) [ ISP-HEADER01 ]  
AT45DB011B@SOIC8 [ (SA605A) ]  
AT45DB011B@SOIC8(ISP) [ ISP-HEADER01 ]  
AT45DB011B@TSSOP14 [ (SA026) ]  
AT45DB011B@TSSOP14(ISP) [ ISP-HEADER01 ]  
AT45DB011D(page264)@QFN8 [ (SA683) ]  
AT45DB011D(page264)@QFN8(ISP) [ ISP-HEADER01 ]  
AT45DB011D(page264)@SOIC8 [ (SA023A) ]  
AT45DB011D(page264)@SOIC8(ISP) [ ISP-HEADER01 ]  
AT45DB021@PLCC32 [ (SA015A1T) ] AT45DB021@SOIC28  
[ (SA630) ]  
AT45DB021@TSOP28 [ (SA430T) ] AT45DB021A@PLCC32  
[ (SA015A1T) ]  
AT45DB021A@PLCC32(ISP) [ ISP-HEADER01 ]  
AT45DB021A@SOIC28 [ (SA630) ]  
AT45DB021A@SOIC28(ISP) [ ISP-HEADER01 ]  
AT45DB021A@TSOP28 [ (SA430T) ]  
AT45DB021A@TSOP28(ISP) [ ISP-HEADER01 ]  
AT45DB021B@CBGA9 [ (SA677A-B089A-K080F001N) ]

AT45DB021B@CBGA9 (ISP) [ISP-HEADER01]  
AT45DB021B@SOIC28 [(SA630)]  
AT45DB021B@SOIC28 (ISP) [ISP-HEADER01]  
AT45DB021B@SOIC8 [(SA023A)]  
AT45DB021B@SOIC8 (ISP) [ISP-HEADER01]  
AT45DB021B@TSOP28 [(SA430T)]  
AT45DB021B@TSOP28 (ISP) [ISP-HEADER01]  
AT45DB021D6 (page264)@CASON8 [(SA683)]  
AT45DB021D6 (page264)@CASON8 (ISP) [ISP-HEADER01]  
AT45DB021D6 (page264)@SOIC8 [(SA023A)]  
AT45DB021D6 (page264)@SOIC8 (ISP) [ISP-HEADER01]  
AT45DB041@PLCC32 [(SA015A1T)] AT45DB041@SOIC28  
[(SA630)]  
AT45DB041@TSOP28 [(SA430T)] AT45DB041A@PLCC32  
[(SA015A1T)]  
AT45DB041A@PLCC32 (ISP) [ISP-HEADER01]  
AT45DB041A@SOIC28 [(SA630)]  
AT45DB041A@SOIC28 (ISP) [ISP-HEADER01]  
AT45DB041A@TSOP28 [(SA430T)]  
AT45DB041A@TSOP28 (ISP) [ISP-HEADER01]  
AT45DB041B@CASON8 [(SA684)] AT45DB041B@CASON8 (ISP)  
[(SA684)]  
AT45DB041B@CBGA14 [(SA677A-B089A-K080F001N)]  
AT45DB041B@CBGA14 (ISP) [ISP-HEADER01]  
AT45DB041B@SOIC28 [(SA630)]  
AT45DB041B@SOIC28 (ISP) [ISP-HEADER01]  
AT45DB041B@SOIC8 [(SA605A)]  
AT45DB041B@SOIC8 (ISP) [ISP-HEADER01]  
AT45DB041B@TSOP28 [(SA430T)]  
AT45DB041B@TSOP28 (ISP) [ISP-HEADER01]  
AT45DB041D (page256)@QFN8 [(SA683)]  
AT45DB041D (page256)@QFN8 (ISP) [ISP-HEADER01]  
AT45DB041D (page256)@SOIC8 [(SA605A)]  
AT45DB041D (page256)@SOIC8 (ISP) [ISP-HEADER01]  
AT45DB041D (page264)@QFN8 [(SA683)]  
AT45DB041D (page264)@QFN8 (ISP) [ISP-HEADER01]  
AT45DB041D (page264)@SOIC8 [(SA605A)]  
AT45DB041D (page264)@SOIC8 (ISP) [ISP-HEADER01]  
AT45DB081@SOIC28 [(SA630)] AT45DB081@TSOP32  
[(SA410T)]  
AT45DB081A@PLCC32 [(SA015A1T)]  
AT45DB081A@PLCC32 (ISP) [ISP-HEADER01]  
AT45DB081A@SOIC28 [(SA630)]

AT45DB081A@SOIC28 (ISP) [ISP-HEADER01]  
AT45DB081A@TSOP28 [(SA430T)]  
AT45DB081A@TSOP28 (ISP) [ISP-HEADER01]  
AT45DB081B@CASON8 [(SA684)] AT45DB081B@CASON8 (ISP)  
[(SA684)]  
AT45DB081B@CBGA14 [(SA677A-B089A-K080F001N)]  
AT45DB081B@CBGA14 (ISP) [ISP-HEADER01]  
AT45DB081B@SOIC28 [(SA630)]  
AT45DB081B@SOIC28 (ISP) [ISP-HEADER01]  
AT45DB081B@SOIC8 [(SA605A)]  
AT45DB081B@SOIC8 (ISP) [ISP-HEADER01]  
AT45DB081B@TSOP28 [(SA430T)]  
AT45DB081B@TSOP28 (ISP) [ISP-HEADER01]  
AT45DB081D(page256)@MLF8 [(SA683)]  
AT45DB081D(page256)@QFN8 (ISP) [ISP-HEADER01]  
AT45DB081D(page256)@SOIC8 [(SA023A)]  
AT45DB081D(page256)@SOIC8 (ISP) [ISP-HEADER01]  
AT45DB081D(page264)@MLF8 [(SA683)]  
AT45DB081D(page264)@QFN8 (ISP) [ISP-HEADER01]  
AT45DB081D(page264)@SOIC8 [(SA023A)]  
AT45DB081D(page264)@SOIC8 (ISP) [ISP-HEADER01]  
AT45DB161@PLCC32 [(SA015A1T)] AT45DB161@SOIC28  
[(SA630)]  
AT45DB161@TSOP28 [(SA430T)]  
AT45DB161B@CASON8 (ISP) [ISP-HEADER01]  
AT45DB161B@CASON8 [(SA684)] AT45DB161B@SOIC28  
[(SA630)]  
AT45DB161B@SOIC28 (ISP) [ISP-HEADER01]  
AT45DB161B@TSOP28 [(SA430T)]  
AT45DB161B@TSOP28 (ISP) [ISP-HEADER01]  
AT45DB161D(page512)@QFN8 [(SA683)]  
AT45DB161D(page512)@QFN8 (ISP) [ISP-HEADER01]  
AT45DB161D(page512)@SOIC8 [(SA605A)]  
AT45DB161D(page512)@SOIC8 (ISP) [ISP-HEADER01]  
AT45DB161D(page512)@TSOP28 [(SA430T)]  
AT45DB161D(page512)@TSOP28 (ISP) [ISP-HEADER01]  
AT45DB161D(page528)@QFN8 [(SA683)]  
AT45DB161D(page528)@QFN8 (ISP) [ISP-HEADER01]  
AT45DB161D(page528)@SOIC8 [(SA605A)]  
AT45DB161D(page528)@SOIC8 (ISP) [ISP-HEADER01]  
AT45DB161D(page528)@TSOP28 [(SA430T)]  
AT45DB161D(page528)@TSOP28 (ISP) [ISP-HEADER01]  
AT45DB321@TSOP32 [(SA410T)] AT45DB321B@SOIC28

[ (SA630) ]  
AT45DB321B@SOIC28 (ISP) [ ISP-HEADER01 ]  
AT45DB321B@TSOP32 [ (SA410T) ]  
AT45DB321B@TSOP32 (ISP) [ ISP-HEADER01 ]  
AT45DB321C@CAS0N8 [ (SA684) ]  
AT45DB321C@CAS0N8 (ISP) [ ISP-HEADER01 ]  
AT45DB321C@SOIC28 [ (SA630) ]  
AT45DB321C@SOIC28 (ISP) [ ISP-HEADER01 ]  
AT45DB321C@TSOP28 [ (SA430T) ]  
AT45DB321C@TSOP28 (ISP) [ ISP-HEADER01 ]  
AT45DB321D(page512)@QFN8 [ (SA683) ]  
AT45DB321D(page512)@QFN8 (ISP) [ ISP-HEADER01 ]  
AT45DB321D(page512)@SOIC8 [ (SA023A) ]  
AT45DB321D(page512)@SOIC8 (ISP) [ ISP-HEADER01 ]  
AT45DB321D(page512)@TSOP28 [ (SA430T) ]  
AT45DB321D(page512)@TSOP28 (ISP) [ ISP-HEADER01 ]  
AT45DB321D(page528)@QFN8 [ (SA683) ]  
AT45DB321D(page528)@QFN8 (ISP) [ ISP-HEADER01 ]  
AT45DB321D(page528)@SOIC8 [ (SA023A) ]  
AT45DB321D(page528)@SOIC8 (ISP) [ ISP-HEADER01 ]  
AT45DB321D(page528)@TSOP28 [ (SA430T) ]  
AT45DB321D(page528)@TSOP28 (ISP) [ ISP-HEADER01 ]  
AT45DB642@TSOP40 [ (SA409T) ]  
AT45DB642@TSOP40 (ISP) [ ISP-HEADER01 ]  
AT45DB642D(page1024)@CAS0N8 [ (SA684) ]  
AT45DB642D(page1024)@CAS0N8 (ISP) [ (ISP-HEADER01) ]  
AT45DB642D(page1024)@TSOP28 [ (SA430) ]  
AT45DB642D(page1024)@TSOP28 (ISP) [ (ISP-HEADER01) ]  
AT45DB642D(page1056)@CAS0N8 [ (SA684) ]  
AT45DB642D(page1056)@CAS0N8 (ISP) [ (ISP-HEADER01) ]  
AT45DB642D(page1056)@TSOP28 [ (SA430) ]  
AT45DB642D(page1056)@TSOP28 (ISP) [ (ISP-HEADER01) ]  
AT45DCB002 [ (CARD005-B005) ] AT45DCB002 (ISP) [ ISP-  
HEADER01 ]  
AT45DCB004 [ (CARD005-B005) ] AT45DCB004 (ISP) [ ISP-  
HEADER01 ]  
AT45DCB004C [ (CARD005-B005) ] AT45DCB004C (ISP) [ ISP-  
HEADER01 ]  
AT45DCB008 [ (CARD005-B005) ] AT45DCB008 (ISP) [ ISP-  
HEADER01 ]  
AT45DCB008D4(page1024) [ (CARD005-B005) ]  
AT45DCB008D4(page1024) (ISP) [ (ISP-HEADER01) ]  
AT45DCB008D6(page1056) [ (CARD005-B005) ]

AT45DCB008D6 (page1056) (ISP) [ (ISP-HEADER01) ]  
AT49BV001 AT49BV001@PLCC32  
[ (SA015A1T) ]  
AT49BV001@TSOP32 [ (SA410T) ] AT49BV001@VSOP32  
[ (SA620) ]  
AT49BV001A AT49BV001A@PLCC32  
[ (SA015A1T) ]  
AT49BV001A@TSOP32 [ (SA410T) ] AT49BV001A@VSOP32  
[ (SA620) ]  
AT49BV001AN AT49BV001AN@PLCC32  
[ (SA015A1T) ]  
AT49BV001AN@TSOP32 [ (SA410T) ] AT49BV001AN@VSOP32  
[ (SA620) ]  
AT49BV001ANT AT49BV001ANT@PLCC32  
[ (SA015A1T) ]  
AT49BV001ANT@TSOP32 [ (SA410T) ] AT49BV001ANT@VSOP32  
[ (SA620) ]  
AT49BV001AT AT49BV001AT@PLCC32  
[ (SA015A1T) ]  
AT49BV001AT@TSOP32 [ (SA410T) ] AT49BV001AT@VSOP32  
[ (SA620) ]  
AT49BV001N AT49BV001N@PLCC32  
[ (SA015A1T) ]  
AT49BV001N@TSOP32 [ (SA410T) ] AT49BV001N@VSOP32  
[ (SA620) ]  
AT49BV001NT AT49BV001NT@PLCC32  
[ (SA015A1T) ]  
AT49BV001NT@TSOP32 [ (SA410T) ] AT49BV001NT@VSOP32  
[ (SA620) ]  
AT49BV001T AT49BV001T@PLCC32  
[ (SA015A1T) ]  
AT49BV001T@TSOP32 [ (SA410T) ] AT49BV001T@VSOP32  
[ (SA620) ]  
AT49BV002 AT49BV002@PLCC32  
[ (SA015A1T) ]  
AT49BV002@TSOP32 [ (SA410T) ] AT49BV002@VSOP32  
[ (SA620) ]  
AT49BV002A AT49BV002A@PLCC32  
[ (SA015A1T) ]  
AT49BV002A@TSOP32 [ (SA410T) ] AT49BV002A@VSOP32  
[ (SA620) ]  
AT49BV002AN AT49BV002AN@PLCC32  
[ (SA015A1T) ]

AT49BV002AN@TSOP32 [(SA410T)]	AT49BV002AN@VSOP32
[(SA620)]	
AT49BV002ANT	AT49BV002ANT@PLCC32
[(SA015A1T)]	
AT49BV002ANT@TSOP32 [(SA410T)]	AT49BV002ANT@VSOP32
[(SA620)]	
AT49BV002AT	AT49BV002AT@PLCC32
[(SA015A1T)]	
AT49BV002AT@TSOP32 [(SA410T)]	AT49BV002AT@VSOP32
[(SA620)]	
AT49BV002N	AT49BV002N@PLCC32
[(SA015A1T)]	
AT49BV002N@TSOP32 [(SA410T)]	AT49BV002N@VSOP32
[(SA620)]	
AT49BV002NT	AT49BV002NT@PLCC32
[(SA015A1T)]	
AT49BV002NT@TSOP32 [(SA410T)]	AT49BV002NT@VSOP32
[(SA620)]	
AT49BV002T	AT49BV002T@PLCC32
[(SA015A1T)]	
AT49BV002T@TSOP32 [(SA410T)]	AT49BV002T@VSOP32
[(SA620)]	
AT49BV008@TSOP40 [(SA409T)]	AT49BV008A@TSOP40
[(SA409T)]	
AT49BV008A@uBGA48 [(SA634)]	AT49BV008AT@TSOP40
[(SA409T)]	
AT49BV008AT@uBGA48 [(SA634)]	
AT49BV010	
AT49BV010@PLCC32 [(SA015A1T)]	AT49BV010@TSOP32
[(SA410T)]	
AT49BV020	AT49BV020@PLCC32
[(SA015A1T)]	
AT49BV020@TSOP32 [(SA410T)]	
AT49BV040	
AT49BV040@PLCC32 [(SA015A1T)]	AT49BV040@TSOP32
[(SA410T)]	
AT49BV040A@PLCC32 [(SA015A1T)]	AT49BV040A@TSOP32
[(SA410T)]	
AT49BV040A@VSOP32 [(SA620)]	
AT49BV040B@PLCC32 [(SA015A1T-B001)]	
AT49BV040B@TSOP32 [(SA410T-B003)]	
AT49BV040B@VSOP32 [(SA620-B005)]	
AT49BV040T	

AT49BV040T@PLCC32 [ (SA015A1T) ] AT49BV040T@TSOP32  
[ (SA410T) ]  
AT49BV080@PSOP44 [ (SA638) ] AT49BV080@TSOP40  
[ (SA409T) ]  
AT49BV080T@PSOP44 [ (SA638) ] AT49BV080T@TSOP40  
[ (SA409T) ]  
AT49BV1024A@TSOP40 [ (SA623) ] AT49BV160@TSOP48 [ (SA247-  
B005) ]  
AT49BV160@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV1604@TSOP48 [ (SA247-B005) ]  
AT49BV1604@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV1604A@TSOP48 [ (SA247-B005) ]  
AT49BV1604A@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV1604AT@TSOP48 [ (SA247-B005) ]  
AT49BV1604AT@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV1604T@TSOP48 [ (SA247-B005) ]  
AT49BV1604T@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV160C@TSOP48 [ (SA247-B005) ]  
AT49BV160C@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV160CT@TSOP48 [ (SA247-B005) ]  
AT49BV160CT@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV160D@TSOP48 [ (SA247-B005) ]  
AT49BV160DT@TSOP48 [ (SA247-B005) ]  
AT49BV160S@FBGA64 [ (SA705A-B147A-W064F001Y) ]  
AT49BV160ST@FBGA64 [ (SA705A-B147A-W064F001Y) ]  
AT49BV160T@TSOP48 [ (SA247-B005) ]  
AT49BV160T@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV161@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV161@TSOP48 [ (SA247-B005) ]  
AT49BV1614@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1614@TSOP48 [ (SA247-B005) ]  
AT49BV1614A@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1614A@TSOP48 [ (SA247-B005) ]  
AT49BV1614AT@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1614AT@TSOP48 [ (SA247-B005) ]  
AT49BV1614T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1614T@TSOP48 [ (SA247-B005) ]  
AT49BV1618@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1618@TSOP48 [ (SA247-B005) ]  
AT49BV1618T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1618T@TSOP48 [ (SA247-B005) ]  
AT49BV161T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV161T@TSOP48 [ (SA247-B005) ]



AT49BV162A@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV162A@TSOP48 [ ( SA247-B005 ) ]  
AT49BV162AT@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV162AT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV163A@CBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49BV163A@TSOP48 [ ( SA247-B005 ) ]  
AT49BV163AT@CBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49BV163AT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV163D@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49BV163D@TSOP48 [ ( SA247-B005 ) ]  
AT49BV163DT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49BV163DT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV2048@PSOP44 [ ( SA638 ) ]                      AT49BV2048@TSOP48 [ ( SA247-  
B005 ) ]  
AT49BV2048A@PSOP44 [ ( SA638 ) ]  
AT49BV2048A@TSOP48 [ ( SA247-B005 ) ]  
AT49BV2048B@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49BV320C@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320C@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49BV320CT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320CT@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49BV320D@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
AT49BV320D@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320DT@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
AT49BV320DT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320S@FBGA64 [ ( SA705A-B147A-W064F001Y ) ]  
AT49BV320ST@FBGA64 [ ( SA705A-B147A-W064F001Y ) ]  
AT49BV320T@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320T@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49BV321@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV321@TSOP48 [ ( SA247-B005 ) ]  
AT49BV3218@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV3218@TSOP48 [ ( SA247-B005 ) ]  
AT49BV3218T@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV3218T@TSOP48 [ ( SA247-B005 ) ]  
AT49BV321T@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV321T@TSOP48 [ ( SA247-B005 ) ]  
AT49BV322A@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV322A@TSOP48 [ ( SA247-B005 ) ]  
AT49BV322AT@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV322AT@TSOP48 [ ( SA247-B005 ) ]

AT49BV322D@FBGA48 [ ( SA642U-B026A-T064F001Y ) ]  
AT49BV322D@TSOP48 [ ( SA247-B005 ) ]  
AT49BV322DT@FBGA48 [ ( SA642U-B026A-T064F001Y ) ]  
AT49BV322DT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV4096@PSOP44 [ ( SA638 ) ] AT49BV4096@TSOP48 [ ( SA247-B005 ) ]  
AT49BV4096A@PSOP44 [ ( SA638 ) ]  
AT49BV4096A@TSOP48 [ ( SA247-B005 ) ]  
AT49BV4096A@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49BV512 AT49BV512@PLCC32  
[ ( SA015A1T ) ]  
AT49BV512@TSOP32 [ ( SA410T ) ] AT49BV512@VSOP32  
[ ( SA620 ) ]  
AT49BV640D@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
AT49BV640D@TSOP56 [ ( SA628-B131 ) ]  
AT49BV640DT@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
AT49BV640DT@TSOP56 [ ( SA628-B131 ) ]  
AT49BV640S@FBGA64 [ ( SA705A-B147A-W064F001Y ) ]  
AT49BV640ST@FBGA64 [ ( SA705A-B147A-W064F001Y ) ]  
AT49BV6416@TSOP48 [ ( SA247-B005 ) ]  
AT49BV6416T@TSOP48 [ ( SA247-B005 ) ]  
AT49BV642D@TSOP48 [ ( SA247-B005 ) ]  
AT49BV642DT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV8004@CBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AT49BV8004@TSOP48 [ ( SA247-B005 ) ]  
AT49BV8004T@CBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AT49BV8004T@TSOP48 [ ( SA247-B005 ) ]  
AT49BV8011@CBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AT49BV8011@TSOP48 [ ( SA247-B005 ) ]  
AT49BV8011T@CBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AT49BV8011T@TSOP48 [ ( SA247-B005 ) ]  
AT49BV802A@CBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AT49BV802A@TSOP48 [ ( SA247-B005 ) ]  
AT49BV802AT@CBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AT49BV802AT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV802D@CBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49BV802D@TSOP48 [ ( SA247 ) ]  
AT49BV802DT@CBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49BV802DT@TSOP48 [ ( SA247 ) ] AT49BV8192@PSOP44  
[ ( SA638 ) ]  
AT49BV8192@TSOP48 [ ( SA247-B005 ) ]  
AT49BV8192A@TSOP48 [ ( SA247-B005 ) ]  
AT49BV8192A@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]

AT49BV8192AT@TSOP48 [(SA247-B005)]	
AT49BV8192AT@uBGA48 [(SA634A-B005A-Y048F001)]	
AT49BV8192T@PSOP44 [(SA638)]	
AT49BV8192T@TSOP48 [(SA247-B005)]	
AT49F001	AT49F001@PLCC32
[(SA015A1T)]	
AT49F001@TSOP32 [(SA410T)]	AT49F001@VSOP32
[(SA620)]	
AT49F001A	AT49F001A@PLCC32
[(SA015A1T)]	
AT49F001A@TSOP32 [(SA410T)]	AT49F001A@VSOP32
[(SA620)]	
AT49F001AN	AT49F001AN@PLCC32
[(SA015A1T)]	
AT49F001AN@TSOP32 [(SA410T)]	AT49F001AN@VSOP32
[(SA620)]	
AT49F001ANT	AT49F001ANT@PLCC32
[(SA015A1T)]	
AT49F001ANT@TSOP32 [(SA410T)]	AT49F001ANT@VSOP32
[(SA620)]	
AT49F001AT	AT49F001AT@PLCC32
[(SA015A1T)]	
AT49F001AT@TSOP32 [(SA410T)]	AT49F001AT@VSOP32
[(SA620)]	
AT49F001N	AT49F001N@PLCC32
[(SA015A1T)]	
AT49F001N@TSOP32 [(SA410T)]	AT49F001N@VSOP32
[(SA620)]	
AT49F001NT	AT49F001NT@PLCC32
[(SA015A1T)]	
AT49F001NT@TSOP32 [(SA410T)]	AT49F001NT@VSOP32
[(SA620)]	
AT49F001T	AT49F001T@PLCC32
[(SA015A1T)]	
AT49F001T@TSOP32 [(SA410T)]	AT49F001T@VSOP32
[(SA620)]	
AT49F002	AT49F002@PLCC32
[(SA015A1T)]	
AT49F002@TSOP32 [(SA410T)]	AT49F002@VSOP32
[(SA620)]	
AT49F002A	AT49F002A@PLCC32
[(SA015A1T)]	
AT49F002A@TSOP32 [(SA410T)]	AT49F002A@VSOP32

[ (SA620) ]	
AT49F002AN	AT49F002AN@PLCC32
[ (SA015A1T) ]	
AT49F002AN@TSOP32 [ (SA410T) ]	AT49F002AN@VSOP32
[ (SA620) ]	
AT49F002ANT	AT49F002ANT@PLCC32
[ (SA015A1T) ]	
AT49F002ANT@TSOP32 [ (SA410T) ]	AT49F002ANT@VSOP32
[ (SA620) ]	
AT49F002AT	AT49F002AT@PLCC32
[ (SA015A1T) ]	
AT49F002AT@TSOP32 [ (SA410T) ]	AT49F002AT@VSOP32
[ (SA620) ]	
AT49F002N	AT49F002N@PLCC32
[ (SA015A1T) ]	
AT49F002N@TSOP32 [ (SA410T) ]	AT49F002N@VSOP32
[ (SA620) ]	
AT49F002NT	AT49F002NT@PLCC32
[ (SA015A1T) ]	
AT49F002NT@TSOP32 [ (SA410T) ]	AT49F002NT@VSOP32
[ (SA620) ]	
AT49F002T	AT49F002T@PLCC32
[ (SA015A1T) ]	
AT49F002T@TSOP32 [ (SA410T) ]	AT49F002T@VSOP32
[ (SA620) ]	
AT49F008@TSOP40 [ (SA409T) ]	AT49F008A@TSOP40
[ (SA409T) ]	
AT49F008AT@TSOP40 [ (SA409T) ]	
AT49F010	
AT49F010@PLCC32 [ (SA015A1T) ]	AT49F010@TSOP32
[ (SA410T) ]	
AT49F020	AT49F020@PLCC32
[ (SA015A1T) ]	
AT49F020@TSOP32 [ (SA410T) ]	
AT49F040	
AT49F040@PLCC32 [ (SA015A1T) ]	AT49F040@TSOP32
[ (SA410T) ]	
AT49F040A	AT49F040A@PLCC32
[ (SA015A1T) ]	
AT49F040A@TSOP32 [ (SA410T) ]	AT49F080@PSOP44
[ (SA638) ]	
AT49F080@TSOP40 [ (SA409T) ]	AT49F080T@PSOP44
[ (SA638) ]	

AT49F080T@TSOP40 [ (SA409T) ] AT49F1024@TSOP40  
[ (SA623) ]  
AT49F1024A@TSOP40 [ (SA623) ] AT49F1025@PLCC44  
[ (SA244) ]  
AT49F1604@TSOP48 [ (SA247-B005) ]  
AT49F1604@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49F1604T@TSOP48 [ (SA247-B005) ]  
AT49F1604T@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49F1614@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49F1614@TSOP48 [ (SA247-B005) ]  
AT49F1614T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49F1614T@TSOP48 [ (SA247-B005) ] AT49F2048@PSOP44  
[ (SA638) ]  
AT49F2048@TSOP48 [ (SA247-B005) ] AT49F2048A@PSOP44  
[ (SA638) ]  
AT49F2048A@TSOP48 [ (SA247-B005) ] AT49F4096@PSOP44  
[ (SA638) ]  
AT49F4096@TSOP48 [ (SA247-B005) ]  
AT49F4096A@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49F4096A@PSOP44 [ (SA638) ] AT49F4096A@TSOP48 [ (SA247-  
B005) ]  
AT49F4096A@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49F512 AT49F512@PLCC32  
[ (SA015A1T) ]  
AT49F512@TSOP32 [ (SA410T) ] AT49F512@VSOP32  
[ (SA620) ]  
AT49F516@PLCC44 [ (SA244) ] AT49F516@TSOP40  
[ (SA623) ]  
AT49F8004@CBGA48 [ (SA642B-B026A-Y072F001) ]  
AT49F8004@TSOP48 [ (SA247-B005) ]  
AT49F8004T@CBGA48 [ (SA642B-B026A-Y072F001) ]  
AT49F8004T@TSOP48 [ (SA247-B005) ]  
AT49F8011@CBGA48 [ (SA642B-B026A-Y072F001) ]  
AT49F8011@TSOP48 [ (SA247-B005) ]  
AT49F8011T@CBGA48 [ (SA642B-B026A-Y072F001) ]  
AT49F8011T@TSOP48 [ (SA247-B005) ] AT49F8192@PSOP44  
[ (SA638) ]  
AT49F8192@TSOP48 [ (SA247-B005) ] AT49F8192A@PSOP44  
[ (SA638) ]  
AT49F8192A@TSOP48 [ (SA247-B005) ] AT49F8192AT@PSOP44  
[ (SA638) ]  
AT49F8192AT@TSOP48 [ (SA247-B005) ]  
AT49F8192T@PSOP44 [ (SA638) ] AT49F8192T@TSOP48 [ (SA247-

B005 ) ]  
AT49HBV010 AT49HBV010@PLCC32  
[ (SA015A1T) ]  
AT49HBV010@TSOP32 [ (SA410T) ]  
AT49HF010  
AT49HF010@PLCC32 [ (SA015A1T) ] AT49HF010@TSOP32  
[ (SA410T) ]  
AT49HLV010 AT49HLV010@PLCC32  
[ (SA015A1T) ]  
AT49HLV010@TSOP32 [ (SA410T) ] AT49LH002@PLCC32  
[ (SA015A1T) ]  
AT49LH002@TSOP40 [ (SA409T) ] AT49LH004@PLCC32  
[ (SA015A1T) ]  
AT49LH004@TSOP40 [ (SA409T) ] AT49LH00B4@PLCC32  
[ (SA015A1T) ]  
AT49LH00B4@TSOP40 [ (SA409T) ] AT49LL020@PLCC32  
[ (SA015A1T) ]  
AT49LL020@TSOP40 [ (SA409T) ] AT49LL040@PLCC32  
[ (SA015A1T) ]  
AT49LL040@TSOP40 [ (SA409T) ] AT49LL080@PLCC32  
[ (SA015A1T) ]  
AT49LL080@TSOP40 [ (SA409T) ]  
AT49LV001  
AT49LV001@PLCC32 [ (SA015A1T) ] AT49LV001@TSOP32  
[ (SA410T) ]  
AT49LV001@VSOP32 [ (SA620) ]  
AT49LV001N  
AT49LV001N@PLCC32 [ (SA015A1T) ] AT49LV001N@TSOP32  
[ (SA410T) ]  
AT49LV001N@VSOP32 [ (SA620) ]  
AT49LV001NT  
AT49LV001NT@PLCC32 [ (SA015A1T) ] AT49LV001NT@TSOP32  
[ (SA410T) ]  
AT49LV001NT@VSOP32 [ (SA620) ]  
AT49LV001T  
AT49LV001T@PLCC32 [ (SA015A1T) ] AT49LV001T@TSOP32  
[ (SA410T) ]  
AT49LV001T@VSOP32 [ (SA620) ]  
AT49LV002  
AT49LV002@PLCC32 [ (SA015A1T) ] AT49LV002@TSOP32  
[ (SA410T) ]  
AT49LV002@VSOP32 [ (SA620) ]  
AT49LV002N

AT49LV002N@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AT49LV002N@TSOP32
AT49LV002N@VSOP32 [ (SA620) ]	
AT49LV002NT	
AT49LV002NT@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AT49LV002NT@TSOP32
AT49LV002NT@VSOP32 [ (SA620) ]	
AT49LV002T	
AT49LV002T@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AT49LV002T@TSOP32
AT49LV002T@VSOP32 [ (SA620) ] [ (SA409T) ]	AT49LV008@TSOP40
AT49LV008A@TSOP40 [ (SA409T) ] [ (SA634) ]	AT49LV008A@uBGA48
AT49LV008AT@TSOP40 [ (SA409T) ] [ (SA634) ]	AT49LV008AT@uBGA48
AT49LV010 [ (SA015A1T) ]	AT49LV010@PLCC32
AT49LV010@TSOP32 [ (SA410T) ]	
AT49LV020	
AT49LV020@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AT49LV020@TSOP32
AT49LV040 [ (SA015A1T) ]	AT49LV040@PLCC32
AT49LV040@TSOP32 [ (SA410T) ]	
AT49LV040T	
AT49LV040T@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AT49LV040T@TSOP32
AT49LV080@PSOP44 [ (SA638) ] [ (SA409T) ]	AT49LV080@TSOP40
AT49LV080T@PSOP44 [ (SA638) ] [ (SA409T) ]	AT49LV080T@TSOP40
AT49LV1024@TSOP40 [ (SA623) ] [ (SA623) ]	AT49LV1024A@TSOP40
AT49LV1025@PLCC44 [ (SA244) ] B005) ]	AT49LV160@TSOP48 [ (SA247-
AT49LV160@uBGA48 [ (SA634A-B005A-Y048F001) ]	
AT49LV1604@TSOP48 [ (SA247-B005) ]	
AT49LV1604@uBGA48 [ (SA634A-B005A-Y048F001) ]	
AT49LV1604T@TSOP48 [ (SA247-B005) ]	
AT49LV1604T@uBGA48 [ (SA634A-B005A-Y048F001) ]	
AT49LV161@CBGA48 [ (SA642F-B026A-T064F001) ]	
AT49LV161@TSOP48 [ (SA247-B005) ]	

AT49LV1614@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV1614@TSOP48 [ (SA247-B005) ]  
AT49LV1614A@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV1614A@TSOP48 [ (SA247-B005) ]  
AT49LV1614AT@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV1614AT@TSOP48 [ (SA247-B005) ]  
AT49LV1614T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV1614T@TSOP48 [ (SA247-B005) ]  
AT49LV161T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV161T@TSOP48 [ (SA247-B005) ] AT49LV2048@PSOP44  
[ (SA638) ]  
AT49LV2048@TSOP48 [ (SA247-B005) ] AT49LV2048A@PSOP44  
[ (SA638) ]  
AT49LV2048A@TSOP48 [ (SA247-B005) ]  
AT49LV2048B@TSOP48 [ (SA247-B005) ]  
AT49LV320@TSOP48 [ (SA247-B005) ]  
AT49LV320@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LV320T@TSOP48 [ (SA247-B005) ]  
AT49LV320T@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LV321@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV321@TSOP48 [ (SA247-B005) ]  
AT49LV3218@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV3218@TSOP48 [ (SA247-B005) ]  
AT49LV3218T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV3218T@TSOP48 [ (SA247-B005) ]  
AT49LV321T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV321T@TSOP48 [ (SA247-B005) ]  
AT49LV4096A@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV4096A@PSOP44 [ (SA638) ]  
AT49LV4096A@TSOP48 [ (SA247-B005) ]  
AT49LV4096A@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LV8011@CBGA48 [ (SA642B-B026A-Y072F001) ]  
AT49LV8011@TSOP48 [ (SA247-B005) ]  
AT49LV8011T@CBGA48 [ (SA642B-B026A-Y072F001) ]  
AT49LV8011T@TSOP48 [ (SA247-B005) ]  
AT49LV8192@PSOP44 [ (SA638) ] AT49LV8192@TSOP48 [ (SA247-  
B005) ]  
AT49LV8192A@TSOP48 [ (SA247-B005) ]  
AT49LV8192A@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LV8192AT@TSOP48 [ (SA247-B005) ]  
AT49LV8192AT@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LW040@PLCC32 [ (SA015A1T) ] AT49LW040@TSOP40  
[ (SA409T) ]



AT49LW080@PLCC32 [ (SA015A1T) ] AT49LW080@TSOP40  
[ (SA409T) ]  
AT49SV163D@FBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV163D@TSOP48 [ (SA247-B005) ]  
AT49SV163DT@FBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV163DT@TSOP48 [ (SA247-B005) ]  
AT49SV322A@CBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV322A@TSOP48 [ (SA247-B005) ]  
AT49SV322AT@CBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV322AT@TSOP48 [ (SA247-B005) ]  
AT49SV322D@FBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV322D@TSOP48 [ (SA247-B005) ]  
AT49SV322DT@FBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV322DT@TSOP48 [ (SA247-B005) ]  
AT49SV802A@CBGA48 [ (SA642G-B026A-T048F001Y) ]  
AT49SV802A@TSOP48 [ (SA247-B005) ]  
AT49SV802AT@CBGA48 [ (SA642G-B026A-T048F001Y) ]  
AT49SV802AT@TSOP48 [ (SA247-B005) ]  
AT52BC1660A@FBGA66 [ (SA642R-B023A-T096F001Y) ]  
AT52BC1660AT@FBGA66 [ (SA642R-B023A-T096F001Y) ]  
AT52BC1661A@FBGA66 [ (SA642R-B023A-T096F001Y) ]  
AT52BC1661AT@FBGA66 [ (SA642R-B023A-T096F001Y) ]  
AT52BC3221A@FBGA66 [ (SA642R-B023A-T080F001Y) ]  
AT52BC3221AT@FBGA66 [ (SA642R-B023A-T080F001Y) ]  
AT52BC3221D@FBGA66 [ (SA642R-B023A-T080F001Y) ]  
AT52BC3221DT@FBGA66 [ (SA642R-B023A-T080F001Y) ]  
AT52BC6402A@FBGA66 [ (SA642B-B023A-Y072F001Y) ]  
AT52BC6402AT@FBGA66 [ (SA642B-B023A-Y072F001Y) ]  
AT52BR1662@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1662A@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1662AT@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1662T@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1664@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1664A@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1664AT@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1664T@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1672@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1672T@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1674@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1674T@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR3224@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR3224A@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR3224AT@CBGA66 [ (SA642E-B023A-T072F001Y) ]

AT52BR3224T@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3228@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3228A@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3228AT@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3228T@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3244@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3244T@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3248@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR3248T@CBGA66 [(SA642E-B023A-T072F001Y)]  
AT52BR6408A@CSP66 [(SA642E-B023A-T072F001Y)]  
AT52BR6408AT@CSP66 [(SA642E-B023A-T072F001Y)]  
AT59C11 AT59C11@SOIC8  
[(SA602A)]  
AT59C12 AT59C12@SOIC8  
[(SA602A)]  
AT59C13 AT59C13@SOIC8  
[(SA602A)]  
AT59C22 AT59C22@SOIC8  
[(SA602A)]  
AT93C46(08bit) AT93C46(08bit)@SOIC8  
[(SA602A)]  
AT93C46(08bit)@TSSOP8 [(SA026)] AT93C46  
(16bit)  
AT93C46(16bit)@SOIC8 [(SA602A)] AT93C46(16bit)@TSSOP8  
[(SA026)]  
AT93C46A AT93C46A@SOIC8  
[(SA602A)]  
AT93C46A@TSSOP8 [(SA026)]  
AT93C46C AT93C46C@TSSOP8  
[(SA026)]  
AT93C46D(08bit) AT93C46D(08bit)@dBGA8  
[(BBBB)]  
AT93C46D(08bit)@MAP8 [(SA724)] AT93C46D(08bit)@SOIC8  
[(SA602A)]  
AT93C46D(08bit)@TSSOP8 [(SA026)] AT93C46D  
(16bit)  
AT93C46D(16bit)@dBGA8 [(BBBB)] AT93C46D(16bit)@MAP8  
[(SA724)]  
AT93C46D(16bit)@SOIC8 [(SA602A)] AT93C46D(16bit)@TSSOP8  
[(SA026)]  
AT93C46E AT93C46E@SOIC8  
[(SA602A)]

AT93C46E@TSSOP8 [(SA026)] (08bit)	AT93C56
AT93C56(08bit)@SOIC8 [(SA602A)] (16bit)	AT93C56
AT93C56(16bit)@SOIC8 [(SA602A)] (08bit)	AT93C56A
AT93C56A(08bit)@SOIC8 [(SA602A)] [(SA026)]	AT93C56A(08bit)@TSSOP8
AT93C56A(16bit) [(SA602A)]	AT93C56A(16bit)@SOIC8
AT93C56A(16bit)@TSSOP8 [(SA026)]	
AT93C57	
AT93C57@SOIC8 [(SA602A)] (08bit)	AT93C66
AT93C66(08bit)@SOIC8 [(SA602A)] (16bit)	AT93C66
AT93C66(16bit)@SOIC8 [(SA602A)] (08bit)	AT93C66A
AT93C66A(08bit)@SOIC8 [(SA602A)] [(SA026)]	AT93C66A(08bit)@TSSOP8
AT93C66A(16bit) [(SA602A)]	AT93C66A(16bit)@SOIC8
AT93C66A(16bit)@TSSOP8 [(SA026)] (08bit)	AT93C86
AT93C86(08bit)@SOIC8 [(SA602A)] [(SA026)]	AT93C86(08bit)@TSSOP8
AT93C86(16bit) [(SA602A)]	AT93C86(16bit)@SOIC8
AT93C86(16bit)@TSSOP8 [(SA026)] (08bit)	AT93C86A
AT93C86A(08bit)@SOIC8 [(SA602A)] [(SA026)]	AT93C86A(08bit)@TSSOP8
AT93C86A(16bit) [(SA602A)]	AT93C86A(16bit)@SOIC8
AT93C86A(16bit)@TSSOP8 [(SA026)]	

## DRAM & SRAM

AT3864L [(SA643)]	AT3864L@TSOP28
AT38H256 [(SA643)]	AT38H256@TSOP28

## PLD

ATF16LV8C [ (SA001A) ]	ATF16LV8C@PLCC20
ATF16LV8C@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16LV8C@TSOP20
ATF16LV8CEXT [ (SA001A) ]	ATF16LV8CEXT@PLCC20
ATF16LV8CEXT@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16LV8CEXT@TSOP20
ATF16V8B [ (SA001A) ]	ATF16V8B@PLCC20
ATF16V8B@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16V8B@TSOP20
ATF16V8BL [ (SA001A) ]	ATF16V8BL@PLCC20
ATF16V8BL@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16V8BL@TSOP20
ATF16V8BQ [ (SA001A) ]	ATF16V8BQ@PLCC20
ATF16V8BQ@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16V8BQ@TSOP20
ATF16V8BQL [ (SA001A) ]	ATF16V8BQL@PLCC20
ATF16V8BQL@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16V8BQL@TSOP20
ATF16V8C [ (SA001A) ]	ATF16V8C@PLCC20
ATF16V8C@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16V8C@TSOP20
ATF16V8CEXT [ (SA001A) ]	ATF16V8CEXT@PLCC20
ATF16V8CEXT@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16V8CEXT@TSOP20
ATF16V8CZ [ (SA001A) ]	ATF16V8CZ@PLCC20
ATF16V8CZ@SOIC20 [ (SA404) ] [ (SA026) ]	ATF16V8CZ@TSOP20
ATF20V8B [ (SA008A) ]	ATF20V8B@PLCC28
ATF20V8B@SOIC24 [ (SA404) ]	

ATF20V8BL  
ATF20V8BL@PLCC28 [(SA008A)]  
[(SA404)]  
ATF20V8BQ  
[(SA008A)]  
ATF20V8BQ@SOIC24 [(SA404)]  
ATF20V8BQL  
ATF20V8BQL@PLCC28 [(SA008A)]  
[(SA404)]  
ATF22LV10C  
(UES)  
ATF22LV10C(UES)@PLCC28 [(SA008A)]  
ATF22LV10C(UES)@SOIC24 [(SA404)]  
ATF22LV10C(UES)@TSSOP24 [(SA643)]  
ATF22LV10C@PLCC28 [(SA008A)]  
[(SA404)]  
ATF22LV10C@TSSOP24 [(SA643)]  
ATF22LV10CEXT  
ATF22LV10CEXT@PLCC28 [(SA008A)]  
[(SA404)]  
ATF22LV10CEXT@TSSOP24 [(SA643)]  
ATF22LV10CQ  
ATF22LV10CQ(UES)  
ATF22LV10CQ(UES)@PLCC28 [(SA008A)]  
ATF22LV10CQ(UES)@SOIC24 [(SA404)]  
ATF22LV10CQ(UES)@TSSOP24 [(SA643)]  
ATF22LV10CQ@PLCC28 [(SA008A)]  
[(SA404)]  
ATF22LV10CQ@TSSOP24 [(SA643)]  
ATF22LV10CQZ  
ATF22LV10CQZ(UES)  
ATF22LV10CQZ(UES)@PLCC28 [(SA008A)]  
ATF22LV10CQZ(UES)@SOIC24 [(SA404)]  
ATF22LV10CQZ(UES)@TSSOP24 [(SA643)]  
ATF22LV10CQZ@PLCC28 [(SA008A)]  
[(SA404)]  
ATF22LV10CQZ@TSSOP24 [(SA643)]  
ATF22LV10CZ  
ATF22LV10CZ(UES)  
ATF22LV10CZ(UES)@PLCC28 [(SA008A)]  
ATF22LV10CZ(UES)@SOIC24 [(SA404)]  
ATF22LV10CZ(UES)@TSSOP24 [(SA643)]  
ATF22LV10CZ@PLCC28 [(SA008A)]

ATF20V8BL@SOIC24  
ATF20V8BQ@PLCC28  
ATF20V8BQL@SOIC24  
ATF22LV10C  
ATF22LV10C@SOIC24  
ATF22LV10CEXT@SOIC24  
ATF22LV10CQ@SOIC24  
ATF22LV10CQZ@SOIC24  
ATF22LV10CZ@SOIC24

[ (SA404) ]  
ATF22LV10CZ@TSSOP24 [ (SA643) ]  
ATF22V10B  
ATF22V10B(UES) ATF22V10B(UES)@PLCC28  
[ (SA008A) ]  
ATF22V10B(UES)@SOIC24 [ (SA404) ] ATF22V10B@PLCC28  
[ (SA008A) ]  
ATF22V10B@SOIC24 [ (SA404) ]  
ATF22V10BL  
ATF22V10BL(UES)  
ATF22V10BL(UES)@PLCC28 [ (SA008A) ]  
ATF22V10BL(UES)@SOIC24 [ (SA404) ] ATF22V10BL@PLCC28  
[ (SA008A) ]  
ATF22V10BL@SOIC24 [ (SA404) ]  
ATF22V10BQ  
ATF22V10BQ(UES)  
ATF22V10BQ(UES)@PLCC28 [ (SA008A) ]  
ATF22V10BQ(UES)@SOIC24 [ (SA404) ] ATF22V10BQ@PLCC28  
[ (SA008A) ]  
ATF22V10BQ@SOIC24 [ (SA404) ]  
ATF22V10BQL  
ATF22V10BQL(UES)  
ATF22V10BQL(UES)@PLCC28 [ (SA008A) ]  
ATF22V10BQL(UES)@SOIC24 [ (SA404) ]  
ATF22V10BQL@PLCC28 [ (SA008A) ] ATF22V10BQL@SOIC24  
[ (SA404) ]  
ATF22V10C ATF22V10C  
(UES)  
ATF22V10C(UES)@PLCC28 [ (SA008A) ] ATF22V10C(UES)@SOIC24  
[ (SA404) ]  
ATF22V10C(UES)@TSSOP24 [ (SA643) ] ATF22V10C@PLCC28  
[ (SA008A) ]  
ATF22V10C@SOIC24 [ (SA404) ] ATF22V10C@TSSOP24  
[ (SA643) ]  
ATF22V10CEXT ATF22V10CEXT@PLCC28  
[ (SA008A) ]  
ATF22V10CEXT@SOIC24 [ (SA404) ] ATF22V10CEXT@TSSOP24  
[ (SA643) ]  
ATF22V10CQ ATF22V10CQ  
(UES)  
ATF22V10CQ(UES)@PLCC28 [ (SA008A) ]  
ATF22V10CQ(UES)@SOIC24 [ (SA404) ]  
ATF22V10CQ(UES)@TSSOP24 [ (SA643) ]

ATF22V10CQ@PLCC28 [(SA008A)]		ATF22V10CQ@SOIC24	
[(SA404)]			
ATF22V10CQ@TSSOP24 [(SA643)]			
ATF22V10CQZ			
ATF22V10CQZ(UES)			
ATF22V10CQZ(UES)@PLCC28 [(SA008A)]			
ATF22V10CQZ(UES)@SOIC24 [(SA404)]			
ATF22V10CQZ(UES)@TSSOP24 [(SA643)]			
ATF22V10CQZ@PLCC28 [(SA008A)]		ATF22V10CQZ@SOIC24	
[(SA404)]			
ATF22V10CQZ@TSSOP24 [(SA643)]			
ATF22V10CZ			
ATF22V10CZ(UES)			
ATF22V10CZ(UES)@PLCC28 [(SA008A)]			
ATF22V10CZ(UES)@SOIC24 [(SA404)]			
ATF22V10CZ(UES)@TSSOP24 [(SA643)]			
ATF22V10CZ@PLCC28 [(SA008A)]		ATF22V10CZ@SOIC24	
[(SA404)]			
ATF22V10CZ@TSSOP24 [(SA643)]		ATF750C	(ATF750C
mode)			
ATF750C	(ATV750 mode)	ATF750C	(ATV750B
mode)			
ATF750C@PLCC28	(ATF750C mode) [(SA008A)]		
ATF750C@PLCC28	(ATV750 mode) [(SA008A)]		
ATF750C@PLCC28	(ATV750B mode) [(SA008A)]		
ATF750C@SOIC24	(ATF750C mode) [(SA404)]		
ATF750C@SOIC24	(ATV750 mode) [(SA404)]		
ATF750C@SOIC24	(ATV750B mode) [(SA404)]		
ATF750CEXT	(ATF750C mode)		
ATF750CEXT@PLCC28	(ATF750C mode) [(SA008A)]		
ATF750CEXT@SOIC24	(ATF750C mode) [(SA404)]		
ATF750CL	(ATV750 mode)	ATF750CL	(ATV750B
mode)			
ATF750CL@PLCC28	(ATV750 mode) [(SA008A)]		
ATF750CL@PLCC28	(ATV750B mode) [(SA008A)]		
ATF750CL@SOIC24	(ATV750 mode) [(SA404)]		
ATF750CL@SOIC24	(ATV750B mode) [(SA404)]		
ATF750LVC	(ATF750C mode)	ATF750LVC	(ATV750
mode)			
ATF750LVC	(ATV750B mode)		
ATF750LVC@PLCC28	(ATF750C mode) [(SA008A)]		
ATF750LVC@PLCC28	(ATV750 mode) [(SA008A)]		
ATF750LVC@PLCC28	(ATV750B mode) [(SA008A)]		

ATF750LVC@SOIC24 (ATF750C mode) [(SA404)]  
ATF750LVC@SOIC24 (ATV750 mode) [(SA404)]  
ATF750LVC@SOIC24 (ATV750B mode) [(SA404)]  
ATF750LVCEXT (ATF750C mode)  
ATF750LVCEXT@PLCC28 (ATF750Cmode) [(SA008A)]  
ATF750LVCEXT@SOIC24 (ATF750Cmode) [(SA404)]  
ATF750LVCL (ATF750C mode) ATF750LVCL (ATV750  
mode)  
ATF750LVCL (ATV750B mode)  
ATF750LVCL@PLCC28 (ATF750C mode) [(SA008A)]  
ATF750LVCL@PLCC28 (ATV750 mode) [(SA008A)]  
ATF750LVCL@PLCC28 (ATV750B mode) [(SA008A)]  
ATF750LVCL@SOIC24 (ATF750C mode) [(SA404)]  
ATF750LVCL@SOIC24 (ATV750 mode) [(SA404)]  
ATF750LVCL@SOIC24 (ATV750B mode) [(SA404)]  
ATV750 ATF750@PLCC28  
[(SA008A)]  
ATV750@SOIC24 [(SA404)]  
ATV750B  
ATV750B@PLCC28 [(SA008A)] ATV750B@SOIC24  
[(SA404)]  
ATV750BL ATV750BL@PLCC28  
[(SA008A)]  
ATV750BL@SOIC24 [(SA404)]  
ATV750L  
ATV750L@PLCC28 [(SA008A)] ATV750L@SOIC24  
[(SA404)]

## MICROCONTROLLER

AT80F51 ATF80F51@PLCC44  
[(SA244)]  
AT80F51@TQFP44 [(SA245A)]  
AT80F52  
AT80F52@PLCC44 [(SA244)] ATF80F52@TQFP44  
[(SA245A)]  
AT87F51 ATF87F51@PLCC44  
[(SA244)]  
AT87F51@TQFP44 [(SA245A)]  
AT87F51RC  
AT87F51RC@PLCC44 [(SA244)] ATF87F51RC@TQFP44  
[(SA245A)]



AT87F52	AT87F52@PLCC44
[(SA244)]	
AT87F52@TQFP44 [(SA245A)]	
AT87F55	
AT87F55@PLCC44 [(SA244)]	AT87F55@TQFP44
[(SA245A)]	
AT87F55WD	AT87F55WD@PLCC44
[(SA244)]	
AT87F55WD@TQFP44 [(SA245A)]	
AT87LV51	
AT87LV51@PLCC44 [(SA244)]	AT87LV51@TQFP44
[(SA245A)]	
AT87LV52	AT87LV52@PLCC44
[(SA244)]	
AT87LV52@TQFP44 [(SA245A)]	
AT89C1051	
AT89C1051@SOIC20 [(SA404)]	
AT89C1051U	
AT89C1051U@SOIC20 [(SA404)]	
AT89C2051	
AT89C2051@SOIC20 [(SA404)]	
AT89C2051X2	
AT89C2051X2@SOIC20 [(SA404)]	
AT89C4051	
AT89C4051@SOIC20 [(SA404)]	
AT89C51	
AT89C51@PLCC44 [(SA244)]	AT89C51@TQFP44
[(SA245A)]	
AT89C5130A@QFN32 [(SA686)]	AT89C5130A@SOIC28
[(SA404)]	
AT89C5130AM@QFN32 [(SA686)]	AT89C5130AM@SOIC28
[(SA404)]	
AT89C5131@MLF48 [(SA696)]	AT89C5131@SOIC28
[(SA404)]	
AT89C5131A@QFN32 [(SA701)]	AT89C5131A@SOIC28
[(SA404)]	
AT89C5131AL@QFN32 [(SA701)]	AT89C5131AL@SOIC28
[(SA404)]	
AT89C5131AM@QFN32 [(SA701)]	AT89C5131AM@SOIC28
[(SA404)]	
AT89C51AC2@PLCC44 [(SA244)]	AT89C51AC2@TQFP44
[(SA245A)]	
AT89C51AC3@PLCC44 [(SA244)]	AT89C51AC3@TQFP44

[ (SA245A) ]	
AT89C51CC01@PLCC44 [ (SA244) ]	AT89C51CC01@TQFP44
[ (SA245A) ]	
AT89C51CC03C@PLCC44 [ (SA244) ]	AT89C51CC03C@TQFP44
[ (SA245A) ]	
AT89C51CC03U@PLCC44 [ (SA244) ]	AT89C51CC03U@TQFP44
[ (SA245A) ]	
AT89C51ED2	AT89C51ED2@PLCC44
[ (SA244) ]	
AT89C51ED2@TQFP44 [ (SA245A) ]	AT89C51IC2@PLCC44
[ (SA244) ]	
AT89C51IC2@TQFP44 [ (SA245A) ]	
AT89C51ID2	
AT89C51ID2@PLCC44 [ (SA244) ]	AT89C51ID2@TQFP44
[ (SA245A) ]	
AT89C51RB2	AT89C51RB2@PLCC44
[ (SA244) ]	
AT89C51RB2@TQFP44 [ (SA245A) ]	
AT89C51RC	
AT89C51RC@PLCC44 [ (SA244) ]	AT89C51RC@TQFP44
[ (SA245A) ]	
AT89C51RC2	AT89C51RC2@PLCC44
[ (SA244) ]	
AT89C51RC2@TQFP44 [ (SA245A) ]	
AT89C51RD2	
AT89C51RD2@PLCC44 [ (SA244) ]	AT89C51RD2@TQFP44
[ (SA245A) ]	
AT89C51RE2@PLCC44 [ (SA244) ]	AT89C51RE2@TQFP44
[ (SA675) ]	
AT89C52	AT89C52@PLCC44
[ (SA244) ]	
AT89C52@TQFP44 [ (SA245A) ]	
AT89C55	
AT89C55@PLCC44 [ (SA244) ]	AT89C55@TQFP44
[ (SA245A) ]	
AT89C55WD	AT89C55WD@PLCC44
[ (SA244) ]	
AT89C55WD@TQFP44 [ (SA245A) ]	
AT89LP2051	
AT89LP2051@SOIC20 [ (SA404) ]	AT89LP2051@TSSOP20
[ (SA026) ]	
AT89LP2052	AT89LP2052(ISP) [ISP-
HEADER01]	

AT89LP2052@SOIC20 [(SA404)]  
AT89LP2052@SOIC20(ISP) [ISP-HEADER01]  
AT89LP2052@TSSOP20 [(SA026)]  
AT89LP2052@TSSOP20(ISP) [ISP-HEADER01]  
AT89LP213 AT89LP213(ISP) [ISP-  
HEADER01]  
AT89LP213@TSSOP14 [(SA026)]  
AT89LP213@TSSOP14(ISP) [ISP-HEADER01]  
AT89LP214 AT89LP214(ISP) [ISP-  
HEADER01]  
AT89LP214@TSSOP14 [(SA026)]  
AT89LP214@TSSOP14(ISP) [ISP-HEADER01]  
AT89LP216 AT89LP216(ISP) [ISP-  
HEADER01]  
AT89LP216@TSSOP16 [(SA026)]  
AT89LP216@TSSOP16(ISP) [ISP-HEADER01]  
AT89LP4051 AT89LP4051@SOIC20  
[(SA404)]  
AT89LP4051@TSSOP20 [(SA026)]  
AT89LP4052 AT89LP4052@SOIC20  
AT89LP4052(ISP) [ISP-HEADER01]  
[(SA404)]  
AT89LP4052@SOIC20(ISP) [ISP-HEADER01]  
AT89LP4052@TSSOP20 [(SA026)]  
AT89LP4052@TSSOP20(ISP) [ISP-HEADER01]  
AT89LP428 AT89LP428(ISP) [ISP-  
HEADER01]  
AT89LP428@PLCC32 [(SA015A1T)]  
AT89LP428@PLCC32(ISP) [ISP-HEADER01]  
AT89LP428@TQFP32 [(SA636)]  
AT89LP428@TQFP32(ISP) [ISP-HEADER01]  
AT89LP828 AT89LP828(ISP) [ISP-  
HEADER01]  
AT89LP828@PLCC32 [(SA015A1T)]  
AT89LP828@PLCC32(ISP) [ISP-HEADER01]  
AT89LP828@TQFP32 [(SA636)]  
AT89LP828@TQFP32(ISP) [ISP-HEADER01]  
AT89LS51 AT89LS51(ISP) [ISP-  
HEADER01]  
AT89LS51@PLCC44 [(SA244)]  
AT89LS51@PLCC44(ISP) [ISP-HEADER01]  
AT89LS51@TQFP44 [(SA245A)]  
AT89LS51@TQFP44(ISP) [ISP-HEADER01]

AT89LS52  
HEADER01 ] AT89LS52 ( ISP ) [ ISP-  
AT89LS52@PLCC44 [ ( SA244 ) ]  
AT89LS52@PLCC44 ( ISP ) [ ISP-HEADER01 ]  
AT89LS52@TQFP44 [ ( SA245A ) ]  
AT89LS52@TQFP44 ( ISP ) [ ISP-HEADER01 ]  
AT89LS53 AT89LS53 ( ISP ) [ ISP-  
HEADER01 ]  
AT89LS53@PLCC44 [ ( SA244 ) ]  
AT89LS53@PLCC44 ( ISP ) [ ISP-HEADER01 ]  
AT89LS53@TQFP44 [ ( SA245A ) ]  
AT89LS53@TQFP44 ( ISP ) [ ISP-HEADER01 ]  
AT89LS8252 AT89LS8252 ( ISP ) [ ISP-  
HEADER01 ]  
AT89LS8252@PLCC44 [ ( SA244 ) ]  
AT89LS8252@PLCC44 ( ISP ) [ ISP-HEADER01 ]  
AT89LS8252@TQFP44 [ ( SA245A ) ]  
AT89LS8252@TQFP44 ( ISP ) [ ISP-HEADER01 ]  
AT89LV51 AT89LV51@PLCC44  
[ ( SA244 ) ]  
AT89LV51@TQFP44 [ ( SA245A ) ]  
AT89LV52  
AT89LV52@PLCC44 [ ( SA244 ) ] AT89LV52@TQFP44  
[ ( SA245A ) ]  
AT89LV55 AT89LV55@PLCC44  
[ ( SA244 ) ]  
AT89LV55@TQFP44 [ ( SA245A ) ]  
AT89S2051  
AT89S2051@SOIC20 [ ( SA404 ) ]  
AT89S4051  
AT89S4051@SOIC20 [ ( SA404 ) ]  
AT89S51  
AT89S51 ( ISP ) [ ISP-HEADER01 ] AT89S51@PLCC44  
[ ( SA244 ) ]  
AT89S51@PLCC44 ( ISP ) [ ISP-HEADER01 ]  
AT89S51@TQFP44 [ ( SA245A ) ]  
AT89S51@TQFP44 ( ISP ) [ ISP-HEADER01 ]  
AT89S52 AT89S52 ( ISP ) [ ISP-  
HEADER01 ]  
AT89S52@PLCC44 [ ( SA244 ) ]  
AT89S52@PLCC44 ( ISP ) [ ISP-HEADER01 ]  
AT89S52@TQFP44 [ ( SA245A ) ]  
AT89S52@TQFP44 ( ISP ) [ ISP-HEADER01 ]

AT89S53  
HEADER01 ] AT89S53( ISP ) [ ISP-  
AT89S53@PLCC44 [ ( SA244 ) ]  
AT89S53@PLCC44( ISP ) [ ISP-HEADER01 ]  
AT89S53@TQFP44 [ ( SA245A ) ]  
AT89S53@TQFP44( ISP ) [ ISP-HEADER01 ]  
AT89S54 AT89S54@PLCC44  
[ ( SA244 ) ]  
AT89S54@TQFP44 [ ( SA245A ) ]  
AT89S58  
AT89S58@PLCC44 [ ( SA244 ) ] AT89S58@TQFP44  
[ ( SA245A ) ]  
AT89S64 AT89S64@PLCC44  
[ ( SA244 ) ]  
AT89S64@TQFP44 [ ( SA245A ) ]  
AT89S8252  
AT89S8252( ISP ) [ ISP-HEADER01 ] AT89S8252@PLCC44  
[ ( SA244 ) ]  
AT89S8252@PLCC44( ISP ) [ ISP-HEADER01 ]  
AT89S8252@TQFP44 [ ( SA245A ) ]  
AT89S8252@TQFP44( ISP ) [ ISP-HEADER01 ]  
AT89S8253 AT89S8253( ISP ) [ ISP-  
HEADER01 ]  
AT89S8253@PLCC44 [ ( SA244 ) ]  
AT89S8253@PLCC44( ISP ) [ ISP-HEADER01 ]  
AT89S8253@TQFP44 [ ( SA245A ) ]  
AT89S8253@TQFP44( ISP ) [ ISP-HEADER01 ]  
AT90CAN128@QFN64( ISP ) [ ISP-HEADER01 ]  
AT90CAN128@TQFP64( ISP ) [ ISP-HEADER01 ]  
AT90CAN32@QFN64( ISP ) [ ISP-HEADER01 ]  
AT90CAN32@TQFP64( ISP ) [ ISP-HEADER01 ]  
AT90CAN64@QFN64( ISP ) [ ISP-HEADER01 ]  
AT90CAN64@TQFP64( ISP ) [ ISP-HEADER01 ]  
AT90LS2323 AT90LS2323( ISP ) [ ISP-  
HEADER01 ]  
AT90LS2323@SOIC8 [ ( SA605A ) ]  
AT90LS2323@SOIC8( ISP ) [ ISP-HEADER01 ]  
AT90LS2333 AT90LS2333( ISP ) [ ISP-  
HEADER01 ]  
AT90LS2333@TQFP32 [ ( SA663 ) ]  
AT90LS2333@TQFP32( ISP ) [ ISP-HEADER01 ]  
AT90LS2343 AT90LS2343( ISP ) [ ISP-  
HEADER01 ]

AT90LS2343@SOIC8 [(SA605A)]  
AT90LS2343@SOIC8(ISP) [ISP-HEADER01]  
AT90LS4433 AT90LS4433(ISP) [ISP-  
HEADER01]  
AT90LS4433@TQFP32 [(SA663)]  
AT90LS4433@TQFP32(ISP) [ISP-HEADER01]  
AT90LS4434 AT90LS4434(ISP) [ISP-  
HEADER01]  
AT90LS4434@PLCC44 [(SA244)]  
AT90LS4434@PLCC44(ISP) [ISP-HEADER01]  
AT90LS4434@TQFP44 [(SA245A)]  
AT90LS4434@TQFP44(ISP) [ISP-HEADER01]  
AT90LS8535 AT90LS8535(ISP) [ISP-  
HEADER01]  
AT90LS8535@PLCC44 [(SA244)]  
AT90LS8535@PLCC44(ISP) [ISP-HEADER01]  
AT90LS8535@TQFP44 [(SA245A)]  
AT90LS8535@TQFP44(ISP) [ISP-HEADER01]  
AT90PWM1@SOIC24 [(SA404)] AT90PWM2@SOIC24  
[(SA404)]  
AT90PWM2@SOIC24(ISP) [ISP-HEADER01]  
AT90PWM216@SOIC24 [(SA404)] AT90PWM2B@SOIC24  
[(SA404)]  
AT90PWM2B@SOIC24(ISP) [ISP-HEADER01]  
AT90PWM3@QFN32 [(SA701)]  
AT90PWM3@QFN32(ISP) [ISP-HEADER01]  
AT90PWM3@SOIC32 [(SA715)]  
AT90PWM3@SOIC32(ISP) [ISP-HEADER01]  
AT90PWM316@QFN32 [(SA701)] AT90PWM316@SOIC32  
[(SA715)]  
AT90PWM3B@QFN32 [(SA701)]  
AT90PWM3B@QFN32(ISP) [ISP-HEADER01]  
AT90PWM3B@SOIC32 [(SA715)]  
AT90PWM3B@SOIC32(ISP) [ISP-HEADER01]  
AT90S1200 AT90S1200(ISP) [ISP-  
HEADER01]  
AT90S1200@SOIC20 [(SA404)]  
AT90S1200@SOIC20(ISP) [ISP-HEADER01]  
AT90S1200@SSOP20 [(SA626A)]  
AT90S1200@SSOP20(ISP) [ISP-HEADER01]  
AT90S1200A AT90S1200A(ISP) [ISP-  
HEADER01]  
AT90S1200A@SOIC20 [(SA404)]

AT90S1200A@SOIC20(ISP) [ISP-HEADER01]  
AT90S1200A@SSOP20 [(SA626A)]  
AT90S1200A@SSOP20(ISP) [ISP-HEADER01]  
AT90S2313 AT90S2313(ISP) [ISP-  
HEADER01]  
AT90S2313@SOIC20 [(SA404)]  
AT90S2313@SOIC20(ISP) [ISP-HEADER01]  
AT90S2323 AT90S2323(ISP) [ISP-  
HEADER01]  
AT90S2323@SOIC8 [(SA605A)]  
AT90S2323@SOIC8(ISP) [ISP-HEADER01]  
AT90S2333 AT90S2333(ISP) [ISP-  
HEADER01]  
AT90S2333@TQFP32 [(SA663)]  
AT90S2333@TQFP32(ISP) [ISP-HEADER01]  
AT90S2343 AT90S2343(ISP) [ISP-  
HEADER01]  
AT90S2343@SOIC8 [(SA605A)]  
AT90S2343@SOIC8(ISP) [ISP-HEADER01]  
AT90S4414 AT90S4414(ISP) [ISP-  
HEADER01]  
AT90S4414@PLCC44 [(SA244)]  
AT90S4414@PLCC44(ISP) [ISP-HEADER01]  
AT90S4414@TQFP44 [(SA245A)]  
AT90S4414@TQFP44(ISP) [ISP-HEADER01]  
AT90S4433 AT90S4433(ISP) [ISP-  
HEADER01]  
AT90S4433@TQFP32 [(SA663)]  
AT90S4433@TQFP32(ISP) [ISP-HEADER01]  
AT90S4434 AT90S4434(ISP) [ISP-  
HEADER01]  
AT90S4434@PLCC44 [(SA244)]  
AT90S4434@PLCC44(ISP) [ISP-HEADER01]  
AT90S4434@TQFP44 [(SA245A)]  
AT90S4434@TQFP44(ISP) [ISP-HEADER01]  
AT90S8515 AT90S8515(ISP) [ISP-  
HEADER01]  
AT90S8515@PLCC44 [(SA244)]  
AT90S8515@PLCC44(ISP) [ISP-HEADER01]  
AT90S8515@TQFP44 [(SA245A)]  
AT90S8515@TQFP44(ISP) [ISP-HEADER01]  
AT90S8535 AT90S8535(ISP) [ISP-  
HEADER01]

AT90S8535@PLCC44 [(SA244)]  
AT90S8535@PLCC44(ISP) [ISP-HEADER01]  
AT90S8535@TQFP44 [(SA245A)]  
AT90S8535@TQFP44(ISP) [ISP-HEADER01]  
AT90USB1286@QFN64(ISP) [ISP-HEADER01]  
AT90USB1286@TQFP64(ISP) [ISP-HEADER01]  
AT90USB1287@QFN64(ISP) [ISP-HEADER01]  
AT90USB1287@TQFP64(ISP) [ISP-HEADER01]  
AT90USB646@QFN64(ISP) [ISP-HEADER01]  
AT90USB646@TQFP64(ISP) [ISP-HEADER01]  
AT90USB647@QFN64(ISP) [ISP-HEADER01]  
AT90USB647@TQFP64(ISP) [ISP-HEADER01]  
ATAM862@SSO24 [(SA026)] ATAM893@SSO20  
[(SA026)]  
ATAM894@SSO24 [(SA026)]  
ATMEGA128@QFN64(ISP) [ISP-HEADER01]  
ATMEGA128@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA1280@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA1280V@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA128L@QFN64(ISP) [ISP-HEADER01]  
ATMEGA128L@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA16 ATMEGA16  
(fast)  
ATMEGA16(fast)@MLF44 [(SA712)] ATMEGA16(fast)@TQFP44  
[(SA245A)]  
ATMEGA16(ISP) [ISP-HEADER01] ATMEGA16@MLF44  
[(SA712)]  
ATMEGA16@MLF44(ISP) [ISP-HEADER01]  
ATMEGA16@TQFP44 [(SA245A)]  
ATMEGA16@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA161 ATMEGA161@TQFP44  
[(SA245A)]  
ATMEGA161L ATMEGA161L@TQFP44  
[(SA245A)]  
ATMEGA162 ATMEGA162(ISP) [ISP-  
HEADER01]  
ATMEGA162@MLF44 [(SA712)]  
ATMEGA162@PLCC44(ISP) [ISP-HEADER01]  
ATMEGA162@TQFP44 [(SA245A)]  
ATMEGA162@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA162V ATMEGA162V@MLF44  
[(SA712)]  
ATMEGA162V@TQFP44 [(SA245A)]



ATMEGA163  
ATMEGA163@TQFP44 [(SA245A)]  
ATMEGA163L  
ATMEGA163L@TQFP44 [(SA245A)]  
ATMEGA164P  
ATMEGA164P@MLP44 [(SA712)] ATMEGA164P@TQFP44  
[(SA245A)]  
ATMEGA164PL ATMEGA164PL@MLP44  
[(SA712)]  
ATMEGA164PL@TQFP44 [(SA245A)]  
ATMEGA165@QFN64(ISP) [ISP-HEADER01]  
ATMEGA165@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA168 ATMEGA168(ISP) [ISP-  
HEADER01]  
ATMEGA168@MLP32 [(SA686)]  
ATMEGA168@MLP32(ISP) [ISP-HEADER01]  
ATMEGA168@TQFP32 [(SA663)]  
ATMEGA168@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA168P ATMEGA168P(ISP) [ISP-  
HEADER01]  
ATMEGA168P@MLP32 [(SA686)]  
ATMEGA168P@MLP32(ISP) [ISP-HEADER01]  
ATMEGA168P@TQFP32 [(SA663)]  
ATMEGA168P@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA168PV ATMEGA168PV(ISP) [ISP-  
HEADER01]  
ATMEGA168PV@MLP32 [(SA686)]  
ATMEGA168PV@MLP32(ISP) [ISP-HEADER01]  
ATMEGA168PV@TQFP32 [(SA663)]  
ATMEGA168PV@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA168V ATMEGA168V(ISP) [ISP-  
HEADER01]  
ATMEGA168V@MLP32 [(SA686)]  
ATMEGA168V@MLP32(ISP) [ISP-HEADER01]  
ATMEGA168V@TQFP32 [(SA663)]  
ATMEGA168V@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA169@MLF64(ISP) [ISP-HEADER01]  
ATMEGA169@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA169PV@MLF64(ISP) [ISP-HEADER01]  
ATMEGA169PV@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA16L ATMEGA16L  
(fast)  
ATMEGA16L(fast)@MLF44 [(SA712)]

ATMEGA16L(fast)@TQFP44 [(SA245A)]  
ATMEGA16L(ISP) [ISP-HEADER01] ATMEGA16L@MLF44  
[(SA712)]  
ATMEGA16L@MLF44(ISP) [ISP-HEADER01]  
ATMEGA16L@TQFP44 [(SA245A)]  
ATMEGA16L@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA2560@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA2560V@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA2561@QFN64(ISP) [ISP-HEADER01]  
ATMEGA2561@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA2561V@QFN64(ISP) [ISP-HEADER01]  
ATMEGA2561V@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA32 ATMEGA32(ISP) [ISP-  
HEADER01]  
ATMEGA32(new) ATMEGA32(new)  
(fast)  
ATMEGA32(new)(fast)@MLF44 [(SA712)]  
ATMEGA32(new)(fast)@PLCC44 [(SA244)]  
ATMEGA32(new)(fast)@TQFP44 [(SA245A)]  
ATMEGA32(new)@MLF44 [(SA712)] ATMEGA32(new)@PLCC44  
[(SA244)]  
ATMEGA32(new)@TQFP44 [(SA245A)] ATMEGA32@MLF44  
[(SA712)]  
ATMEGA32@MLF44(ISP) [ISP-HEADER01]  
ATMEGA32@PLCC44 [(SA244)] ATMEGA32@TQFP44  
[(SA245A)]  
ATMEGA32@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA323 ATMEGA323@TQFP44  
[(SA245A)]  
ATMEGA323L ATMEGA323L@TQFP44  
[(SA245A)]  
ATMEGA324P ATMEGA324P@MLP44  
[(SA712)]  
ATMEGA324P@TQFP44 [(SA245A)]  
ATMEGA324PL ATMEGA324PL@TQFP44  
ATMEGA324PL@MLP44 [(SA712)]  
[(SA245A)]  
ATMEGA3250@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA325P@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA325V@QFN64(ISP) [ISP-HEADER01]  
ATMEGA328P ATMEGA328P(ISP) [ISP-  
HEADER01]  
ATMEGA328P@MLP32 [(SA686)]

ATMEGA328P@MLP32(ISP) [ISP-HEADER01]  
ATMEGA328P@TQFP32 [(SA663)]  
ATMEGA328P@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA328PV ATMEGA328PV(ISP) [ISP-  
HEADER01]  
ATMEGA328PV@MLP32 [(SA686)]  
ATMEGA328PV@MLP32(ISP) [ISP-HEADER01]  
ATMEGA328PV@TQFP32 [(SA663)]  
ATMEGA328PV@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA329@QFN64(ISP) [ISP-HEADER01]  
ATMEGA3290@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA329P@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA32L ATMEGA32L(ISP) [ISP-  
HEADER01]  
ATMEGA32L(new) ATMEGA32L(new)  
(fast)  
ATMEGA32L(new)(fast)@MLF44 [(SA712)]  
ATMEGA32L(new)(fast)@PLCC44 [(SA244)]  
ATMEGA32L(new)(fast)@TQFP44 [(SA245A)]  
ATMEGA32L(new)@MLF44 [(SA712)] ATMEGA32L(new)@PLCC44  
[(SA244)]  
ATMEGA32L(new)@TQFP44 [(SA245A)] ATMEGA32L@MLF44  
[(SA712)]  
ATMEGA32L@MLF44(ISP) [ISP-HEADER01]  
ATMEGA32L@PLCC44 [(SA244)] ATMEGA32L@TQFP44  
[(SA245A)]  
ATMEGA32L@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA406@LQFP48 [(SA248)]  
ATMEGA48  
ATMEGA48(ISP) [ISP-HEADER01] ATMEGA48@MLP32  
[(SA686)]  
ATMEGA48@MLP32(ISP) [ISP-HEADER01]  
ATMEGA48@TQFP32 [(SA663)]  
ATMEGA48@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA48P ATMEGA48P@MLP32  
[(SA686)]  
ATMEGA48P@TQFP32 [(SA663)]  
ATMEGA48PV  
ATMEGA48PV@MLP32 [(SA686)] ATMEGA48PV@TQFP32  
[(SA663)]  
ATMEGA48V ATMEGA48V(ISP) [ISP-  
HEADER01]  
ATMEGA48V@MLP32 [(SA686)]

ATMEGA48V@MLP32( ISP) [ ISP-HEADER01 ]  
ATMEGA48V@TQFP32 [ (SA663) ]  
ATMEGA48V@TQFP32( ISP) [ ISP-HEADER01 ]  
ATMEGA64@QFN64( ISP) [ ISP-HEADER01 ]  
ATMEGA64@TQFP64( ISP) [ ISP-HEADER01 ]  
ATMEGA644 ATMEGA644( ISP) [ ISP-  
HEADER01 ]  
ATMEGA644@MLF44 [ (SA712) ]  
ATMEGA644@MLF44( ISP) [ ISP-HEADER01 ]  
ATMEGA644@TQFP44 [ (SA245A) ]  
ATMEGA644@TQFP44( ISP) [ ISP-HEADER01 ]  
ATMEGA644P ATMEGA644P( ISP) [ ISP-  
HEADER01 ]  
ATMEGA644P@MLF44 [ (SA712) ]  
ATMEGA644P@MLF44( ISP) [ ISP-HEADER01 ]  
ATMEGA644P@TQFP44 [ (SA245A) ]  
ATMEGA644P@TQFP44( ISP) [ ISP-HEADER01 ]  
ATMEGA644PV ATMEGA644PV( ISP) [ ISP-  
HEADER01 ]  
ATMEGA644PV@MLF44 [ (SA712) ]  
ATMEGA644PV@MLF44( ISP) [ ISP-HEADER01 ]  
ATMEGA644PV@TQFP44 [ (SA245A) ]  
ATMEGA644PV@TQFP44( ISP) [ ISP-HEADER01 ]  
ATMEGA644V ATMEGA644V( ISP) [ ISP-  
HEADER01 ]  
ATMEGA644V@MLF44 [ (SA712) ]  
ATMEGA644V@MLF44( ISP) [ ISP-HEADER01 ]  
ATMEGA644V@TQFP44 [ (SA245A) ]  
ATMEGA644V@TQFP44( ISP) [ ISP-HEADER01 ]  
ATMEGA645@QFN64( ISP) [ ISP-HEADER01 ]  
ATMEGA645@TQFP64( ISP) [ ISP-HEADER01 ]  
ATMEGA6450@TQFP100( ISP) [ ISP-HEADER01 ]  
ATMEGA649@TQFP64( ISP) [ ISP-HEADER01 ]  
ATMEGA6490@TQFP100( ISP) [ ISP-HEADER01 ]  
ATMEGA649V@QFN64( ISP) [ ISP-HEADER01 ]  
ATMEGA64L@QFN64( ISP) [ ISP-HEADER01 ]  
ATMEGA64L@TQFP64( ISP) [ ISP-HEADER01 ]  
ATMEGA8 ATMEGA8  
( fast )  
ATMEGA8( fast )@TQFP32 [ (SA663) ] ATMEGA8( ISP) [ ISP-  
HEADER01 ]  
ATMEGA8@MLF32 [ (SA686) ]  
ATMEGA8@MLF32( ISP) [ ISP-HEADER01 ]

ATMEGA8@TQFP32 [(SA663)]  
ATMEGA8@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA8515 ATMEGA8515  
(fast)  
ATMEGA8515(fast)@PLCC44 [(SA244)]  
ATMEGA8515(fast)@TQFP44 [(SA245A)]  
ATMEGA8515(ISP) [ISP-HEADER01] ATMEGA8515@PLCC44  
[(SA244)]  
ATMEGA8515@PLCC44(ISP) [ISP-HEADER01]  
ATMEGA8515@TQFP44 [(SA245A)]  
ATMEGA8515@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA8515L ATMEGA8515L  
(fast)  
ATMEGA8515L(fast)@PLCC44 [(SA244)]  
ATMEGA8515L(fast)@TQFP44 [(SA245A)]  
ATMEGA8515L(ISP) [ISP-HEADER01] ATMEGA8515L@PLCC44  
[(SA244)]  
ATMEGA8515L@PLCC44(ISP) [ISP-HEADER01]  
ATMEGA8515L@TQFP44 [(SA245A)]  
ATMEGA8515L@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA8535 ATMEGA8535  
(fast)  
ATMEGA8535(fast)@MLF44 [(SA712)]  
ATMEGA8535(fast)@PLCC44 [(SA244)]  
ATMEGA8535(fast)@TQFP44 [(SA245A)]  
ATMEGA8535(ISP) [ISP-HEADER01] ATMEGA8535@PLCC44  
[(SA244)]  
ATMEGA8535@PLCC44(ISP) [ISP-HEADER01]  
ATMEGA8535@TQFP44 [(SA245A)]  
ATMEGA8535@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA8535L ATMEGA8535L  
(fast)  
ATMEGA8535L(fast)@MLF44 [(SA712)]  
ATMEGA8535L(fast)@PLCC44 [(SA244)]  
ATMEGA8535L(fast)@TQFP44 [(SA245A)]  
ATMEGA8535L(ISP) [ISP-HEADER01] ATMEGA8535L@PLCC44  
[(SA244)]  
ATMEGA8535L@PLCC44(ISP) [ISP-HEADER01]  
ATMEGA8535L@TQFP44 [(SA245A)]  
ATMEGA8535L@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA88 ATMEGA88(ISP) [ISP-  
HEADER01]  
ATMEGA88@MLP32 [(SA686)]

ATMEGA88@MLP32(ISP) [ISP-HEADER01]  
ATMEGA88@TQFP32 [(SA663)]  
ATMEGA88@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA88P ATMEGA88P@MLP32  
[(SA686)]  
ATMEGA88P@TQFP32 [(SA663)]  
ATMEGA88PV ATMEGA88PV@TQFP32  
ATMEGA88PV@MLP32 [(SA686)]  
[(SA663)]  
ATMEGA88V ATMEGA88V(ISP) [ISP-  
HEADER01]  
ATMEGA88V@MLP32 [(SA686)]  
ATMEGA88V@MLP32(ISP) [ISP-HEADER01]  
ATMEGA88V@TQFP32 [(SA663)]  
ATMEGA88V@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA8L ATMEGA8L  
(fast)  
ATMEGA8L(fast)@TQFP32 [(SA663)] ATMEGA8L(ISP) [ISP-  
HEADER01]  
ATMEGA8L@MLF32 [(SA686)]  
ATMEGA8L@MLF32(ISP) [ISP-HEADER01]  
ATMEGA8L@TQFP32 [(SA663)]  
ATMEGA8L@TQFP32(ISP) [ISP-HEADER01]  
ATtiny10 ATtiny10(ISP) [ISP-  
HEADER01]  
ATtiny10@SOIC8 [(SA605A)]  
ATtiny10@SOIC8(ISP) [ISP-HEADER01]  
ATtiny11 ATtiny11(ISP) [ISP-  
HEADER01]  
ATtiny11@SOIC8 [(SA605A)]  
ATtiny11@SOIC8(ISP) [ISP-HEADER01]  
ATtiny11L ATtiny11L(ISP) [ISP-  
HEADER01]  
ATtiny11L@SOIC8 [(SA605A)]  
ATtiny11L@SOIC8(ISP) [ISP-HEADER01]  
ATtiny12 ATtiny12(ISP) [ISP-  
HEADER01]  
ATtiny12@SOIC8 [(SA605A)]  
ATtiny12@SOIC8(ISP) [ISP-HEADER01]  
ATtiny12L ATtiny12L(ISP) [ISP-  
HEADER01]  
ATtiny12L@SOIC8 [(SA605A)]  
ATtiny12L@SOIC8(ISP) [ISP-HEADER01]

```
ATtiny12V                                ATtiny12V(ISP) [ISP-
HEADER01]
ATtiny12V@SOIC8 [(SA605A)]
ATtiny12V@SOIC8(ISP) [ISP-HEADER01]
ATtiny13                                ATtiny13
(Fuse)
ATtiny13(Fuse)@QFN10 [(SA695A)]        ATtiny13(Fuse)@QFN20
[(SA692)]
ATtiny13(Fuse)@SOIC8(3.9*6.2) [(SA602A)]
ATtiny13(Fuse)@SOIC8(5.5*8.0) [(SA605A)]
ATtiny13(ISP) [ISP-HEADER01]          ATtiny13@QFN10
[(SA695A)]
ATtiny13@QFN10(ISP) [ISP-HEADER01]
ATtiny13@QFN20 [(SA692)]
ATtiny13@QFN20(ISP) [ISP-HEADER01]
ATtiny13@SOIC8(3.9*6.2) [(SA602A)]
ATtiny13@SOIC8(3.9*6.2)(ISP) [ISP-HEADER01]
ATtiny13@SOIC8(5.5*8.0) [(SA605A)]
ATtiny13@SOIC8(5.5*8.0)(ISP) [ISP-HEADER01]
ATtiny13V                                ATtiny13V
(Fuse)
ATtiny13V(Fuse)@QFN10 [(SA695A)]        ATtiny13V(Fuse)@QFN20
[(SA692)]
ATtiny13V(Fuse)@SOIC8(3.9*6.2) [(SA602A)]
ATtiny13V(Fuse)@SOIC8(5.5*8.0) [(SA605A)]
ATtiny13V(ISP) [ISP-HEADER01]          ATtiny13V@QFN10
[(SA695A)]
ATtiny13V@QFN10(ISP) [ISP-HEADER01]
ATtiny13V@QFN20 [(SA692)]
ATtiny13V@QFN20(ISP) [ISP-HEADER01]
ATtiny13V@SOIC8(3.9*6.2) [(SA602A)]
ATtiny13V@SOIC8(3.9*6.2)(ISP) [ISP-HEADER01]
ATtiny13V@SOIC8(5.5*8.0) [(SA605A)]
ATtiny13V@SOIC8(5.5*8.0)(ISP) [ISP-HEADER01]
ATtiny15                                ATtiny15(ISP) [ISP-
HEADER01]
ATtiny15@SOIC8 [(SA605A)]
ATtiny15@SOIC8(ISP) [ISP-HEADER01]
ATtiny15L                                ATtiny15L(ISP) [ISP-
HEADER01]
ATtiny15L@SOIC8 [(SA605A)]
ATtiny15L@SOIC8(ISP) [ISP-HEADER01]
ATtiny2313                                ATtiny2313(ISP) [ISP-
```





ATtiny26(new)@TSSOP20(ISP) [ISP-HEADER01]  
ATtiny26@QFN32 [(SA686)] ATtiny26@SOIC20  
[(SA404)]  
ATtiny26@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26@TSSOP20 [(SA026)]  
ATtiny26@TSSOP20(ISP) [ISP-HEADER01]  
ATtiny261 ATtiny261(ISP) [ISP-  
HEADER01]  
ATtiny261@MLP32 [(SA686)]  
ATtiny261@MLP32(ISP) [ISP-HEADER01]  
ATtiny261@SOIC20 [(SA404)]  
ATtiny261@SOIC20(ISP) [ISP-HEADER01]  
ATtiny261V ATtiny261V(ISP) [ISP-  
HEADER01]  
ATtiny261V@MLP32 [(SA686)]  
ATtiny261V@MLP32(ISP) [ISP-HEADER01]  
ATtiny261V@SOIC20 [(SA404)]  
ATtiny261V@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26L ATtiny26L(ISP) [ISP-  
HEADER01]  
ATtiny26L(new)  
ATtiny26L(new)(ISP) [ISP-HEADER01]  
ATtiny26L(new)@QFN32 [(SA686)] ATtiny26L(new)@SOIC20  
[(SA404)]  
ATtiny26L(new)@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26L(new)@TSSOP20 [(SA026)]  
ATtiny26L(new)@TSSOP20(ISP) [ISP-HEADER01]  
ATtiny26L@QFN32 [(SA686)] ATtiny26L@SOIC20  
[(SA404)]  
ATtiny26L@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26L@TSSOP20 [(SA026)]  
ATtiny26L@TSSOP20(ISP) [ISP-HEADER01]  
ATtiny28L ATtiny28L@TQFP32  
[(SA663)]  
ATtiny28V ATtiny28V@TQFP32  
[(SA663)]  
ATtiny44 ATtiny44(ISP) [ISP-  
HEADER01]  
ATtiny44@QFN20 [(SA692)]  
ATtiny44@QFN20(ISP) [ISP-HEADER01]  
ATtiny44@SOIC14 [(SA602)]  
ATtiny44@SOIC14(ISP) [ISP-HEADER01]  
ATtiny45

ATtiny45(ISP)(12V) [ISP-HEADER01]  
ATtiny45(ISP)(5V) [ISP-HEADER01]      ATtiny45@QFN20  
[(SA692)]  
ATtiny45@QFN20(ISP)(12V) [ISP-HEADER01]  
ATtiny45@QFN20(ISP)(5V) [ISP-HEADER01]  
ATtiny45@SOIC8 [(S605)]  
ATtiny45@SOIC8(ISP)(12V) [ISP-HEADER01]  
ATtiny45@SOIC8(ISP)(5V) [ISP-HEADER01]  
ATtiny461      ATtiny461(ISP) [ISP-  
HEADER01]  
ATtiny461@MLP32 [(SA686)]  
ATtiny461@MLP32(ISP) [ISP-HEADER01]  
ATtiny461@SOIC20 [(SA404)]  
ATtiny461@SOIC20(ISP) [ISP-HEADER01]  
ATtiny461V      ATtiny461V(ISP) [ISP-  
HEADER01]  
ATtiny461V@MLP32 [(SA686)]  
ATtiny461V@MLP32(ISP) [ISP-HEADER01]  
ATtiny461V@SOIC20 [(SA404)]  
ATtiny461V@SOIC20(ISP) [ISP-HEADER01]  
ATtiny48      ATtiny48@MLF32  
[(SA686)]  
ATtiny48@TQFP32 [(SA663)]  
ATtiny48V      ATtiny48V@TQFP32  
ATtiny48V@MLF32 [(SA686)]  
[(SA663)]  
ATtiny84      ATtiny84(ISP) [ISP-  
HEADER01]  
ATtiny84@QFN20 [(SA692)]  
ATtiny84@QFN20(ISP) [ISP-HEADER01]  
ATtiny84@SOIC14 [(SA602)]  
ATtiny84@SOIC14(ISP) [ISP-HEADER01]  
ATtiny85  
ATtiny85(ISP)(12V) [ISP-HEADER01]  
ATtiny85(ISP)(5V) [ISP-HEADER01]      ATtiny85@QFN20  
[(SA692)]  
ATtiny85@QFN20(ISP)(12V) [ISP-HEADER01]  
ATtiny85@QFN20(ISP)(5V) [ISP-HEADER01]  
ATtiny85@SOIC8 [(S605)]  
ATtiny85@SOIC8(ISP)(12V) [ISP-HEADER01]  
ATtiny85@SOIC8(ISP)(5V) [ISP-HEADER01]  
ATtiny861      ATtiny861(ISP) [ISP-  
HEADER01]

ATtiny861@MLP32 [(SA686)]  
ATtiny861@MLP32(ISP) [ISP-HEADER01]  
ATtiny861@SOIC20 [(SA404)]  
ATtiny861@SOIC20(ISP) [ISP-HEADER01]  
ATtiny861V ATtiny861V(ISP) [ISP-  
HEADER01]  
ATtiny861V@MLP32 [(SA686)]  
ATtiny861V@MLP32(ISP) [ISP-HEADER01]  
ATtiny861V@SOIC20 [(SA404)]  
ATtiny861V@SOIC20(ISP) [ISP-HEADER01]  
ATtiny88 ATtiny88@MLF32  
[(SA686)]  
ATtiny88@TQFP32 [(SA663)]  
ATtiny88V ATtiny88V@TQFP32  
ATtiny88V@MLF32 [(SA686)]  
[(SA663)]  
T89F64 T89F64@PLCC44  
[(SA244)]  
T89F64@TQFP44 [(SA245A)]

## ATMEL W&M

### MICROCONTROLLER

AT89C5115@PLCC28 [(SA008A)] AT89C5115@SOIC28  
[(SA404)]  
AT89C5115@TQFP32 [(SA663)] AT89C51CC02@PLCC28  
[(SA008A)]  
AT89C51CC02@SOIC28 [(SA404)] AT89C51CC02@TQFP32  
[(SA663)]  
T89C5115@PLCC28 [(SA008A)] T89C5115@SOIC28  
[(SA404)]  
T89C5115@TQFP32 [(SA663)] T89C51AC2@PLCC44  
[(SA244)]  
T89C51AC2@TQFP44 [(SA245A)] T89C51CC01@PLCC44  
[(SA244)]  
T89C51CC01@TQFP44 [(SA245A)] T89C51CC02@PLCC28  
[(SA008A)]  
T89C51CC02@SOIC24 [(SA404)] T89C51CC02@SOIC28  
[(SA404)]  
T89C51CC02@TQFP32 [(SA663)] T89C51IB2@PLCC44  
[(SA244)]

T89C51IB2@TQFP44 [(SA245A)]	T89C51IC2@PLCC44
[(SA244)]	
T89C51IC2@TQFP44 [(SA245A)]	
T89C51RB2	
T89C51RB2@PLCC44 [(SA244)]	T89C51RB2@TQFP44
[(SA245A)]	
T89C51RC2	T89C51RC2@PLCC44
[(SA244)]	
T89C51RC2@TQFP44 [(SA245A)]	
T89C51RD2	
T89C51RD2@PLCC44 [(SA244)]	T89C51RD2@TQFP44
[(SA245A)]	
T89F64	T89F64@PLCC44
[(SA244)]	
T89F64@TQFP44 [(SA245A)]	
TS87C51RB2	
TS87C51RB2@PLCC44 [(SA244)]	TS87C51RB2@TQFP44
[(SA245A)]	
TS87C51RC2	TS87C51RC2@PLCC44
[(SA244)]	
TS87C51RC2@TQFP44 [(SA245A)]	
TS87C51RD2	
TS87C51RD2@PLCC44 [(SA244)]	TS87C51RD2@TQFP44
[(SA245A)]	
TS87C51U2	TS87C51U2@PLCC44
[(SA244)]	
TS87C51U2@TQFP44 [(SA245A)]	
TS87C52X2	
TS87C52X2@PLCC44 [(SA244)]	TS87C52X2@TQFP44
[(SA245A)]	
TS87C54X2	TS87C54X2@PLCC44
[(SA244)]	
TS87C54X2@TQFP44 [(SA245A)]	
TS87C58X2	
TS87C58X2@PLCC44 [(SA244)]	TS87C58X2@TQFP44
[(SA245A)]	
TSC87251A1@PLCC44 [(SA244)]	
TSC87251G1	
TSC87251G1@PLCC44 [(SA244)]	
TSC87251G1A	
TSC87251G1A@PLCC44 [(SA244)]	
TSC87251G2D	
TSC87251G2D@PLCC44 [(SA244)]	TSC87251G2D@TQFP44

[ ( SA245A ) ]

TSC87C51

TSC87C51@PLCC44

[ ( SA244 ) ]

TSC87C51@TQFP44 [ ( SA245A ) ]

## ATMEL-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

AT24C01

AT24C02

AT24C04

AT24C08

AT24C16

## AUSTIN

### E ( E ) PROM / FRAM / NVRAM

AS8E512K8

AS8E512K8@SOJ32

[ ( SA661 ) ]

## BELLING-SYSTRON

### MICROCONTROLLER

CM5001

## BENCHMARQ

### E ( E ) PROM / FRAM / NVRAM

BQ4010

BQ4010Y

BQ4011

BQ4011Y

BQ4013

BQ4013Y

BQ4014  
BQ4014Y  
BQ4015  
BQ4015Y  
BQ4832Y  
BQ4842Y

## BMT

### E ( E ) PROM / FRAM / NVRAM

BM29LV160B@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
BM29LV160B@TSOP48 [ ( SA247-B005 ) ]  
BM29LV160T@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
BM29LV160T@TSOP48 [ ( SA247-B005 ) ]

## BOSEN

### E ( E ) PROM / FRAM / NVRAM

M28W320FST@FBGA47 [ ( SA714B-B026A-T048F001Y ) ]  
M28W640FSB@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
PC28F640P30B@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
PC28F640P30T@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
S71WS256NC0BAWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
SST39VF800@TSOP48 [ ( SA247 ) ]  
SST39VF800A@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
SST39VF800A@TSOP48 [ ( SA247 ) ] SST39VF800Q@TSOP48  
[ ( SA247 ) ]

## BRIGHT

### E ( E ) PROM / FRAM / NVRAM

BM29F040 [ ( SA015A1T ) ] BM29F040@PLCC32  
BM29F040@TSOP32 [ ( SA410T ) ] BM29F400B@PSOP44 [ ( SA638-  
B006 ) ]

BM29F400B@TSOP48 [ ( SA247-B005 ) ]  
B006 ) ]  
BM29F400T@TSOP48 [ ( SA247-B005 ) ]

BM29F400T@PSOP44 [ ( SA638-

## CATALYST

### E ( E ) PROM / FRAM / NVRAM

CAT1021 ( L )	CAT1021
( P )	
CAT1021 ( R ) @ MSOP8 [ ( SA026 ) ]	CAT1021 ( S ) @ SOIC8
[ ( SA602A ) ]	
CAT1021 ( U ) @ TSSOP8 [ ( SA026 ) ]	CAT1021 ( V ) @ SOIC8
[ ( SA602A ) ]	
CAT1021 ( Y ) @ TSSOP8 [ ( SA026 ) ]	CAT1021 ( Z ) @ MSOP8
[ ( SA026 ) ]	
CAT1022 ( L )	CAT1022
( P )	
CAT1022 ( R ) @ MSOP8 [ ( SA026 ) ]	CAT1022 ( S ) @ SOIC8
[ ( SA602A ) ]	
CAT1022 ( U ) @ TSSOP8 [ ( SA026 ) ]	CAT1022 ( V ) @ SOIC8
[ ( SA602A ) ]	
CAT1022 ( Y ) @ TSSOP8 [ ( SA026 ) ]	CAT1022 ( Z ) @ MSOP8
[ ( SA026 ) ]	
CAT1023 ( L )	CAT1023
( P )	
CAT1023 ( R ) @ MSOP8 [ ( SA026 ) ]	CAT1023 ( S ) @ SOIC8
[ ( SA602A ) ]	
CAT1023 ( U ) @ TSSOP8 [ ( SA026 ) ]	CAT1023 ( V ) @ SOIC8
[ ( SA602A ) ]	
CAT1023 ( Y ) @ TSSOP8 [ ( SA026 ) ]	CAT1023 ( Z ) @ MSOP8
[ ( SA026 ) ]	
CAT1024 ( L )	CAT1024
( P )	
CAT1024 ( R ) @ MSOP8 [ ( SA026 ) ]	CAT1024 ( S ) @ SOIC8
[ ( SA602A ) ]	
CAT1024 ( U ) @ TSSOP8 [ ( SA026 ) ]	CAT1024 ( V ) @ SOIC8
[ ( SA602A ) ]	
CAT1024 ( Y ) @ TSSOP8 [ ( SA026 ) ]	CAT1024 ( Z ) @ MSOP8
[ ( SA026 ) ]	
CAT1025 ( L )	CAT1025
( P )	

CAT1025(R)@MSOP8 [(SA026)] [(SA602A)]	CAT1025(S)@SOIC8
CAT1025(U)@TSSOP8 [(SA026)] [(SA602A)]	CAT1025(V)@SOIC8
CAT1025(Y)@TSSOP8 [(SA026)] [(SA026)]	CAT1025(Z)@MSOP8
CAT1026(L) (P)	CAT1026
CAT1026(R)@MSOP8 [(SA026)] [(SA602A)]	CAT1026(S)@SOIC8
CAT1026(U)@TSSOP8 [(SA026)] [(SA602A)]	CAT1026(V)@SOIC8
CAT1026(Y)@TSSOP8 [(SA026)] [(SA026)]	CAT1026(Z)@MSOP8
CAT1027(L) (P)	CAT1027
CAT1027(R)@MSOP8 [(SA026)] [(SA602A)]	CAT1027(S)@SOIC8
CAT1027(U)@TSSOP8 [(SA026)] [(SA602A)]	CAT1027(V)@SOIC8
CAT1027(Y)@TSSOP8 [(SA026)] [(SA026)]	CAT1027(Z)@MSOP8
CAT1161(J)@SOIC8 [(SA602A)] (P)	CAT1161
CAT1162(J)@SOIC8 [(SA602A)] (P)	CAT1162
CAT1163(J)@SOIC8 [(SA602A)] (P)	CAT1163
CAT1320 [(SA602A)]	CAT1320@SOIC8
CAT1320@TDFN8 [(SA026)]	CAT1320@TSSOP8
CAT1321 [(SA602A)]	CAT1321@SOIC8
CAT1321@TDFN8 [(SA026)]	CAT1321@TSSOP8
CAT14002@SOIC8 [(SA602A)] [(SA602A)]	CAT14004@SOIC8
CAT14008@SOIC8 [(SA602A)] [(SA602A)]	CAT14016@SOIC8
CAT15002@SOIC8 [(SA602A)] [(SA602A)]	CAT15004@SOIC8
CAT15008@SOIC8 [(SA602A)]	CAT15016@SOIC8



[ (SA602A) ]	
CAT1640	CAT1640@SOIC8
[ (SA602A) ]	
CAT1640@TDFN8	CAT1640@TSSOP8
[ (SA026) ]	
CAT1641	CAT1641@SOIC8
[ (SA602A) ]	
CAT1641@TDFN8	CAT1641@TSSOP8
[ (SA026) ]	
CAT2210	CAT2210@SOIC16
[ (SA404) ]	
CAT2210I	CAT2210I@SOIC16
[ (SA404) ]	
CAT2212	CAT2212@SOIC20
[ (SA404) ]	
CAT2212I	CAT2212I@SOIC20
[ (SA404) ]	
CAT22C10	CAT22C10@SOIC16
[ (SA404) ]	
CAT22C10I	CAT22C10I@SOIC16
[ (SA404) ]	
CAT22C12	CAT22C12@SOIC20
[ (SA404) ]	
CAT22C12I	CAT22C12I@SOIC20
[ (SA404) ]	
CAT24AC128	CAT24AC128@SOIC8
[ (SA602A) ]	
CAT24AC128@TSSOP14 [ (SA026) ]	CAT24AC128@UDFN8
[ (SA724) ]	
CAT24C00	CAT24C00@SOIC8
[ (SA602A) ]	
CAT24C00@TSSOP8 [ (SA026) ]	
CAT24C01	
CAT24C01@SOIC14 [ (SA602) ]	CAT24C01@SOIC8
[ (SA602A) ]	
CAT24C01@TSSOP8 [ (SA026) ]	CAT24C01B(J)@SOIC8
[ (SA602A) ]	
CAT24C01B(L)	CAT24C01B
(P)	
CAT24C01B(R)@MSOP8 [ (SA026) ]	CAT24C01B(U)@TSSOP8
[ (SA026) ]	
CAT24C01B(W)@SOIC8 [ (SA602A) ]	CAT24C01B(Y)@TSSOP8
[ (SA026) ]	

CAT24C01B(Z)@MSOP8 [(SA026)]  
CAT24C02  
CAT24C02@SOIC14 [(SA602)] CAT24C02@SOIC8  
[(SA602A)]  
CAT24C02@TSSOP8 [(SA026)]  
CAT24C021  
CAT24C022  
CAT24C023  
CAT24C03 CAT24C03@SOIC8  
[(SA602A)]  
CAT24C03@TSSOP8 [(SA026)]  
CAT24C04  
CAT24C04@SOIC14 [(SA602)] CAT24C04@SOIC8  
[(SA602A)]  
CAT24C04@TSSOP8 [(SA026)]  
CAT24C041  
CAT24C042  
CAT24C043  
CAT24C05 CAT24C05@SOIC8  
[(SA602A)]  
CAT24C05@TSSOP8 [(SA026)]  
CAT24C08  
CAT24C08@SOIC14 [(SA602)] CAT24C08@SOIC8  
[(SA602A)]  
CAT24C08@TSSOP8 [(SA026)]  
CAT24C081  
CAT24C082  
CAT24C083  
CAT24C08I CAT24C08I@SOIC8  
[(SA602A)]  
CAT24C09 CAT24C09@SOIC8  
[(SA602A)]  
CAT24C09@TSSOP8 [(SA026)]  
CAT24C128  
CAT24C128@SOIC8 [(SA602A)] CAT24C128@UDFN8  
[(SA724)]  
CAT24C16 CAT24C16@SOIC14  
[(SA602)]  
CAT24C16@SOIC8 [(SA602A)] CAT24C16@TSSOP8  
[(SA026)]  
CAT24C161  
CAT24C162  
CAT24C163

CAT24C164	
CAT24C164@SOIC8 [(SA602A)]	CAT24C164@TSSOP8
[(SA026)]	
CAT24C16I	CAT24C16I@SOIC8
[(SA602A)]	
CAT24C208(J)@SOIC8 [(SA602A)]	CAT24C208
(L)	
CAT24C208(P)	CAT24C208(R)@MSOP8
[(SA666)]	
CAT24C208(U)@TSSOP8 [(SA026)]	CAT24C208(W)@SOIC8
[(SA602A)]	
CAT24C208(Y)@TSSOP8 [(SA026)]	CAT24C208(Z)@MSOP8
[(SA666)]	
CAT24C21	CAT24C21@SOIC8
[(SA602A)]	
CAT24C21@TSSOP8 [(SA026)]	
CAT24C256	
CAT24C256@SOIC8 [(SA602A)]	CAT24C256@TDFN8
[(SA683)]	
CAT24C256@TSSOP8 [(SA026)]	
CAT24C32	
CAT24C32@SOIC8 [(SA602A)]	
CAT24C44	
CAT24C44@SOIC8 [(SA602A)]	
CAT24C64	
CAT24C64@SOIC8 [(SA602A)]	
CAT24F32	
CAT24F32@SOIC8 [(SA602A)]	CAT24F32@TSSOP8
[(SA026)]	
CAT24F32A	CAT24F32A@SOIC8
[(SA602A)]	
CAT24F32A@TSSOP8 [(SA026)]	
CAT24FC01	
CAT24FC01@SOIC14 [(SA602)]	CAT24FC01@SOIC8
[(SA602A)]	
CAT24FC01@TSSOP8 [(SA026)]	
CAT24FC02	
CAT24FC02@SOIC14 [(SA602)]	CAT24FC02@SOIC8
[(SA602A)]	
CAT24FC02@TSSOP8 [(SA026)]	
CAT24FC16	
CAT24FC16@SOIC14 [(SA602)]	CAT24FC16@SOIC8
[(SA602A)]	

CAT24FC16@TSSOP8 [(SA026)]	
CAT24FC17	
CAT24FC17@SOIC8 [(SA602A)]	CAT24FC17@TSSOP8
[(SA026)]	
CAT24FC256	
[(SA602A)]	CAT24FC256@SOIC8
CAT24FC256@TDFN8 [(SA683)]	
[(SA026)]	CAT24FC256@TSSOP8
CAT24FC32	
[(SA602A)]	CAT24FC32@SOIC8
CAT24FC32@TDFN8 [(SA683)]	
[(SA026)]	CAT24FC32@TSSOP8
CAT24FC64	
[(SA602A)]	CAT24FC64@SOIC8
CAT24FC64@TDFN8 [(SA683)]	
[(SA026)]	CAT24FC64@TSSOP8
CAT24FC65	
[(SA602A)]	CAT24FC65@SOIC8
CAT24FC65@TDFN8 [(SA683)]	
[(SA026)]	CAT24FC65@TSSOP8
CAT24FC66	
[(SA602A)]	CAT24FC66@SOIC8
CAT24FC66@TDFN8 [(SA683)]	
[(SA026)]	CAT24FC66@TSSOP8
CAT24LC02	
[(SA602A)]	CAT24LC02@SOIC8
CAT24LC02@TSSOP8 [(SA026)]	
CAT24WC01	
CAT24WC01@SOIC8 [(SA602A)]	CAT24WC01@TSSOP8
[(SA026)]	
CAT24WC02	
[(SA602A)]	CAT24WC02@SOIC8
CAT24WC02@TSSOP8 [(SA026)]	
CAT24WC03	
CAT24WC03@SOIC8 [(SA602A)]	CAT24WC03@TSSOP8
[(SA026)]	
CAT24WC04	
[(SA602A)]	CAT24WC04@SOIC8
CAT24WC04@TSSOP8 [(SA026)]	
CAT24WC05	
CAT24WC05@SOIC8 [(SA602A)]	CAT24WC05@TSSOP8
[(SA026)]	
CAT24WC08	
	CAT24WC08@SOIC8

[ (SA602A) ]	
CAT24WC08@TSSOP8 [ (SA026) ]	
CAT24WC09	
CAT24WC09@SOIC8 [ (SA602A) ]	CAT24WC09@TSSOP8
[ (SA026) ]	
CAT24WC128	
[ (SA602A) ]	CAT24WC128@SOIC8
CAT24WC129	
[ (SA602A) ]	CAT24WC129@SOIC8
CAT24WC16	
[ (SA602A) ]	CAT24WC16@SOIC8
CAT24WC16@TSSOP8 [ (SA026) ]	
CAT24WC164	
CAT24WC164@SOIC8 [ (SA602A) ]	CAT24WC164@TSSOP8
[ (SA026) ]	
CAT24WC17	
[ (SA602A) ]	CAT24WC17@SOIC8
CAT24WC17@TSSOP8 [ (SA026) ]	
CAT24WC256	
CAT24WC256@SOIC8 [ (SA602A) ]	CAT24WC256@TDFN8
[ (SA683) ]	
CAT24WC256@TSSOP8 [ (SA026) ]	
CAT24WC257	
CAT24WC257@SOIC8 [ (SA605A) ]	
CAT24WC32	
CAT24WC32@SOIC8 [ (SA602A) ]	
CAT24WC33	
CAT24WC33@SOIC8 [ (SA602A) ]	
CAT24WC64	
CAT24WC64@SOIC8 [ (SA602A) ]	
CAT24WC65	
CAT24WC65@SOIC8 [ (SA602A) ]	
CAT24WC66	
CAT24WC66@SOIC8 [ (SA602A) ]	
CAT25010	
CAT25010(S)@SOIC8 [ (SA605A) ]	CAT25010(U)@TSSOP8
[ (SA602A) ]	
CAT25020	
[ (SA605A) ]	CAT25020(S)@SOIC8
CAT25020(U)@TSSOP8 [ (SA602A) ]	
CAT25040	
CAT25040(S)@SOIC8 [ (SA605A) ]	CAT25040(U)@TSSOP8
[ (SA602A) ]	

CAT25080	CAT25080@SOIC8
[(SA602A)]	
CAT25080@TDFN8 [(SA724)]	CAT25080@TSSOP8
[(SA026)]	
CAT25080@UDFN8 [(BBBB)]	
CAT25128	
CAT25128@SOIC8[150 mil] [(SA602A)]	
CAT25128@SOIC8[208 mil] [(SA605A)]	
CAT25128@TDFN8 [(SA724)]	CAT25128@TSSOP8
[(SA026)]	
CAT25160	CAT25160@SOIC8
[(SA602A)]	
CAT25160@TDFN8 [(SA724)]	CAT25160@TSSOP8
[(SA026)]	
CAT25160@UDFN8 [(BBBB)]	
CAT25256	
CAT25256@SOIC8[150 mil] [(SA602A)]	
CAT25256@SOIC8[208 mil] [(SA605A)]	
CAT25256@TDFN8 [(SA602A)]	CAT25256@TSSOP8
[(SA026)]	
CAT25320	CAT25320@SOIC8
[(SA602A)]	
CAT25320@TDFN8 [(SA724)]	CAT25320@TSSOP8
[(SA026)]	
CAT25640	CAT25640@SOIC8
[(SA602A)]	
CAT25640@TDFN8 [(SA724)]	CAT25640@TSSOP8
[(SA026)]	
CAT25C01	CAT25C01@SOIC16
[(SA602)]	
CAT25C01@SOIC8 [(SA602A)]	CAT25C01@TSSOP14
[(SA026)]	
CAT25C01@TSSOP8 [(SA026)]	
CAT25C02	
CAT25C02@SOIC16 [(SA602)]	CAT25C02@SOIC8
[(SA602A)]	
CAT25C02@TSSOP14 [(SA026)]	CAT25C02@TSSOP8
[(SA026)]	
CAT25C03	CAT25C03@SOIC8
[(SA602A)]	
CAT25C03@TSSOP14 [(SA026)]	CAT25C03@TSSOP8
[(SA026)]	
CAT25C04	CAT25C04@SOIC16

[(SA602)]	
CAT25C04@SOIC8 [(SA602A)]	CAT25C04@TSSOP14
[(SA026)]	
CAT25C04@TSSOP8 [(SA026)]	
CAT25C05	
CAT25C05@SOIC8 [(SA602A)]	CAT25C05@TSSOP14
[(SA026)]	
CAT25C05@TSSOP8 [(SA026)]	
CAT25C08	
CAT25C08@SOIC16 [(SA602)]	CAT25C08@SOIC8
[(SA602A)]	
CAT25C08@TSSOP14 [(SA026)]	CAT25C08@TSSOP8
[(SA026)]	
CAT25C09	CAT25C09@SOIC8
[(SA602A)]	
CAT25C09@TSSOP14 [(SA026)]	CAT25C09@TSSOP8
[(SA026)]	
CAT25C11	CAT25C11@SOIC8
[(SA602A)]	
CAT25C11@TSSOP14 [(SA026)]	CAT25C11@TSSOP8
[(SA026)]	
CAT25C128	CAT25C128@SOIC16
[(SA602)]	
CAT25C128@SOIC8[150 mil] [(SA602A)]	
CAT25C128@SOIC8[208 mil] [(SA605A)]	
CAT25C128@TSSOP14 [(SA026)]	CAT25C128@TSSOP20
[(SA026)]	
CAT25C16	CAT25C16@SOIC16
[(SA602)]	
CAT25C16@SOIC8 [(SA602A)]	CAT25C16@TSSOP14
[(SA026)]	
CAT25C16@TSSOP8 [(SA026)]	
CAT25C17	
CAT25C17@SOIC8 [(SA602A)]	CAT25C17@TSSOP14
[(SA026)]	
CAT25C17@TSSOP8 [(SA026)]	
CAT25C256	
CAT25C256@SOIC16 [(SA602)]	
CAT25C256@SOIC8[150 mil] [(SA602A)]	
CAT25C256@SOIC8[208 mil] [(SA605A)]	
CAT25C256@TSSOP14 [(SA026)]	CAT25C256@TSSOP20
[(SA026)]	
CAT25C32	CAT25C32@SOIC8

[ (SA602A) ]  
CAT25C32@TSSOP14 [ (SA026) ] CAT25C32@TSSOP20  
[ (SA026) ]  
CAT25C33 CAT25C33@SOIC8  
[ (SA602A) ]  
CAT25C33@TSSOP14 [ (SA026) ]  
CAT25C64  
CAT25C64@SOIC8 [ (SA602A) ] CAT25C64@TSSOP14  
[ (SA026) ]  
CAT25C64@TSSOP20 [ (SA026) ]  
CAT25C65  
CAT25C65@SOIC8 [ (SA602A) ] CAT25C65@TSSOP14  
[ (SA026) ]  
CAT27010 CAT27010@PLCC32  
[ (SA015A1T) ]  
CAT27010@TSOP32 [ (SA410T) ]  
CAT27128A  
CAT27256  
CAT27512  
CAT27512@PLCC32 [ (SA015A1T) ]  
CAT2764A  
CAT27C16A  
CAT27C210  
CAT27C210@PLCC44 [ (SA244) ]  
CAT27HC256  
CAT27HC256@PLCC32 [ (SA015A1T) ]  
CAT27HC256I  
CAT27HC256I@PLCC32 [ (SA015A1T) ]  
CAT28C16A  
CAT28C16A@PLCC32 [ (SA015A1T) ] CAT28C16A@SOIC24  
[ (SA404) ]  
CAT28C16AI CAT28C16AI@PLCC32  
[ (SA015A1T) ]  
CAT28C16AI@SOIC24 [ (SA404) ]  
CAT28C17A  
CAT28C17A@PLCC32 [ (SA015A1T) ]  
CAT28C17AI  
CAT28C17AI@PLCC32 [ (SA015A1T) ]  
CAT28C256  
CAT28C256@PLCC32 [ (SA015A1T) ] CAT28C256@TSOP28  
[ (SA430T) ]  
CAT28C256I CAT28C256I@PLCC32  
[ (SA015A1T) ]



CAT28C256I@TSOP28 [(SA430T)]	
CAT28C257	
CAT28C257@PLCC32 [(SA015A1T)]	CAT28C257@TSOP28
[(SA430T)]	
CAT28C512	CAT28C512@PLCC32
[(SA015A1T)]	
CAT28C512@TSOP32 [(SA410T)]	CAT28C512@TSOP40
[(SA409T)]	
CAT28C513@PLCC32 [(SA015A1T)]	
CAT28C64A	
CAT28C64A@PLCC32 [(SA015A1T)]	CAT28C64A@SOIC28
[(SA404)]	
CAT28C64AI	CAT28C64AI@PLCC32
[(SA015A1T)]	
CAT28C64AI@SOIC28 [(SA404)]	
CAT28C64B	
CAT28C64B@PLCC32 [(SA015A1T)]	CAT28C64B@TSOP28
[(SA430T)]	
CAT28C64BI	CAT28C64BI@PLCC32
[(SA015A1T)]	
CAT28C64BI@TSOP28 [(SA430T)]	
CAT28C65B	
CAT28C65B@PLCC32 [(SA015A1T)]	CAT28C65B@TSOP28
[(SA430T)]	
CAT28C65BI	CAT28C65BI@PLCC32
[(SA015A1T)]	
CAT28C65BI@TSOP28 [(SA430T)]	CAT28F001N-B@PLCC32
[(SA015A1T)]	
CAT28F001N-T@PLCC32 [(SA015A1T)]	CAT28F001P-
B	
CAT28F001P-T	CAT28F001T-B@TSOP32
[(SA410T)]	
CAT28F001T-T@TSOP32 [(SA410T)]	
CAT28F002	
CAT28F002@TSOP40 [(SA409T)]	
CAT28F010	
CAT28F010@PLCC32 [(SA015A1T)]	CAT28F010@TSOP32
[(SA410T)]	
CAT28F010I	CAT28F010I@PLCC32
[(SA015A1T)]	
CAT28F010I@TSOP32 [(SA410T)]	
CAT28F020	
CAT28F020(REVERSE)@TSOP32 [(SA410T)]	

CAT28F020@PLCC32 [(SA015A1T)]	CAT28F020@TSOP32
[(SA410T)]	
CAT28F020I	CAT28F020I@PLCC32
[(SA015A1T)]	
CAT28F020I@TSOP32 [(SA410T)]	
CAT28F102	
CAT28F102@PLCC44 [(SA244)]	CAT28F102@TSOP40
[(SA409T)]	
CAT28F512	CAT28F512@PLCC32
[(SA015A1T)]	
CAT28F512@TSOP32 [(SA410T)]	
CAT28F512I	
CAT28F512I@PLCC32 [(SA015A1T)]	CAT28F512I@TSOP32
[(SA410T)]	
CAT28LV256	CAT28LV256@PLCC32
[(SA015A1T)]	
CAT28LV256@TSOP28 [(SA430T)]	
CAT28LV64	
CAT28LV64@PLCC32 [(SA015A1T)]	CAT28LV64@TSOP28
[(SA430T)]	
CAT28LV65	CAT28LV65@PLCC32
[(SA015A1T)]	
CAT28LV65@TSOP28 [(SA430T)]	CAT33C101
(08bit)	
CAT33C101(08bit)@SOIC8 [(SA602A)]	
CAT33C101(16bit)	
CAT33C101(16bit)@SOIC8 [(SA602A)]	
CAT33C101H(08bit)	
CAT33C101H(08bit)@SOIC8 [(SA602A)]	
CAT33C101H(16bit)	
CAT33C101H(16bit)@SOIC8 [(SA602A)]	
CAT33C101I(08bit)	
CAT33C101I(08bit)@SOIC8 [(SA602A)]	
CAT33C101I(16bit)	
CAT33C101I(16bit)@SOIC8 [(SA602A)]	
CAT33C104(08bit)	
CAT33C104(08bit)@SOIC8 [(SA602A)]	
CAT33C104(16bit)	
CAT33C104(16bit)@SOIC8 [(SA602A)]	
CAT33C104I(08bit)	
CAT33C104I(08bit)@SOIC8 [(SA602A)]	
CAT33C104I(16bit)	
CAT33C104I(16bit)@SOIC8 [(SA602A)]	

CAT34AC02	CAT34AC02@SOIC8
[ (SA602A) ]	
CAT34AC02@TSSOP8 [ (SA026) ]	
CAT34C02	
CAT34C02@SOIC8 [ (SA602A) ]	CAT34C02@TDFN8
[ (SA694) ]	
CAT34C02@TSSOP8 [ (SA026) ]	
CAT34FC02	
CAT34FC02@SOIC8 [ (SA602A) ]	CAT34FC02@TDFN8
[ (SA694) ]	
CAT34FC02@TSSOP8 [ (SA026) ]	
CAT34RC02	
CAT34RC02@SOIC8 [ (SA602A) ]	CAT34RC02@TDFN8
[ (SA694) ]	
CAT34RC02@TSSOP8 [ (SA026) ]	
CAT34WC02	
CAT34WC02@SOIC8 [ (SA602A) ]	CAT34WC02@TDFN8
[ (SA694) ]	
CAT34WC02@TSSOP8 [ (SA026) ]	
CAT35C102	
CAT35C102H	
CAT35C102I	
CAT35C104(08bit)	
CAT35C104(08bit)@SOIC8 [ (SA602A) ]	
CAT35C104(16bit)	
CAT35C104(16bit)@SOIC8 [ (SA602A) ]	
CAT35C104H(08bit)	
CAT35C104H(08bit)@SOIC8 [ (SA602A) ]	
CAT35C104I(08bit)	
CAT35C104I(08bit)@SOIC8 [ (SA602A) ]	
CAT35C104I(16bit)	
CAT35C104I(16bit)@SOIC8 [ (SA602A) ]	
CAT59C11	CAT59C11@SOIC8
[ (SA602A) ]	
CAT59C11A	CAT59C11A@SOIC8
[ (SA602A) ]	
CAT59C11H	CAT59C11H@SOIC8
[ (SA602A) ]	
CAT59C11I	CAT59C11I@SOIC8
[ (SA602A) ]	
CAT64LC10(J)@SOIC8 [ (SA602A) ]	CAT64LC10
(P)	
CAT64LC10(S)@SOIC8 [ (SA602A) ]	CAT64LC10(U)@TSSOP8

[ (SA026) ]	
CAT64LC10(UR)@TSSOP8 [ (SA026) ]	CAT64LC20(J)@SOIC8
[ (SA602A) ]	
CAT64LC20(P)	CAT64LC20(S)@SOIC8
[ (SA602A) ]	
CAT64LC20(U)@TSSOP8 [ (SA026) ]	CAT64LC20(UR)@TSSOP8
[ (SA026) ]	
CAT64LC40(J)@SOIC8 [ (SA602A) ]	CAT64LC40
(P)	
CAT64LC40(S)@SOIC8 [ (SA602A) ]	CAT64LC40(U)@TSSOP8
[ (SA026) ]	
CAT64LC40(UR)@TSSOP8 [ (SA026) ]	CAT93C46
(08bit)	
CAT93C46(08bit)(J)@SOIC8 [ (SA602A) ]	
CAT93C46(08bit)(K)@SOIC8 [ (SA605A) ]	
CAT93C46(08bit)(S)@SOIC8 [ (SA602A) ]	
CAT93C46(08bit)(U)@TSSOP8 [ (SA026) ]	
CAT93C46(16bit)	
CAT93C46(16bit)(J)@SOIC8 [ (SA602A) ]	
CAT93C46(16bit)(K)@SOIC8 [ (SA605A) ]	
CAT93C46(16bit)(S)@SOIC8 [ (SA602A) ]	
CAT93C46(16bit)(U)@TSSOP8 [ (SA026) ]	
CAT93C46A	CAT93C56
(08bit)	
CAT93C56(08bit)@SOIC8 [ (SA602A) ]	CAT93C56
(16bit)	
CAT93C56(16bit)@SOIC8 [ (SA602A) ]	
CAT93C56A	
CAT93C57	CAT93C66
(08bit)	
CAT93C66(08bit)@SOIC8 [ (SA602A) ]	CAT93C66(08bit)@TSSOP8
[ (SA026) ]	
CAT93C66(16bit)	CAT93C66(16bit)@SOIC8
[ (SA602A) ]	
CAT93C66(16bit)@TSSOP8 [ (SA026) ]	
CAT93C66A	
CAT93C76(08bit)	
CAT93C76(08bit)(J)@SOIC8 [ (SA602A) ]	
CAT93C76(08bit)(K)@SOIC8 [ (SA605A) ]	
CAT93C76(08bit)(S)@SOIC8 [ (SA602A) ]	
CAT93C76(08bit)(U)@TSSOP8 [ (SA026) ]	
CAT93C76(16bit)	
CAT93C76(16bit)(J)@SOIC8 [ (SA602A) ]	

CAT93C76(16bit)(K)@SOIC8 [(SA605A)]  
CAT93C76(16bit)(S)@SOIC8 [(SA602A)]  
CAT93C76(16bit)(U)@TSSOP8 [(SA026)]  
CAT93C86(08bit)  
CAT93C86(08bit)(J)@SOIC8 [(SA602A)]  
CAT93C86(08bit)(K)@SOIC8 [(SA605A)]  
CAT93C86(08bit)(S)@SOIC8 [(SA602A)]  
CAT93C86(08bit)(U)@TSSOP8 [(SA026)]  
CAT93C86(16bit)  
CAT93C86(16bit)(J)@SOIC8 [(SA602A)]  
CAT93C86(16bit)(K)@SOIC8 [(SA605A)]  
CAT93C86(16bit)(S)@SOIC8 [(SA602A)]  
CAT93C86(16bit)(U)@TSSOP8 [(SA026)]  
CAT93H46(08bit)  
CAT93H46(08bit)(J)@SOIC8 [(SA602A)]  
CAT93H46(08bit)(K)@SOIC8 [(SA605A)]  
CAT93H46(08bit)(S)@SOIC8 [(SA602A)]  
CAT93H46(08bit)(U)@TSSOP8 [(SA026)]  
CAT93H46(16bit)  
CAT93H46(16bit)(J)@SOIC8 [(SA602A)]  
CAT93H46(16bit)(K)@SOIC8 [(SA605A)]  
CAT93H46(16bit)(S)@SOIC8 [(SA602A)]  
CAT93H46(16bit)(U)@TSSOP8 [(SA026)]  
CAT93HC46(08bit)  
CAT93HC46(08bit)(J)@SOIC8 [(SA602A)]  
CAT93HC46(08bit)(K)@SOIC8 [(SA605A)]  
CAT93HC46(08bit)(S)@SOIC8 [(SA602A)]  
CAT93HC46(08bit)(U)@TSSOP8 [(SA026)]  
CAT93HC46(16bit)  
CAT93HC46(16bit)(J)@SOIC8 [(SA602A)]  
CAT93HC46(16bit)(K)@SOIC8 [(SA605A)]  
CAT93HC46(16bit)(S)@SOIC8 [(SA602A)]  
CAT93HC46(16bit)(U)@TSSOP8 [(SA026)]

## DRAM & SRAM

CAT71C256 [(SA643)]	CAT71C256@TSOP28
CAT71C256L [(SA643)]	CAT71C256L@TSOP28

## CELESTICA

### E ( E ) PROM / FRAM / NVRAM

SST49LF160C@TSOP40 [ ( SA409T ) ]

## CERAMATE

### E ( E ) PROM / FRAM / NVRAM

24LC02 [ ( SA602A ) ]	24LC02@SOIC8
24LC02@TSSOP8 [ ( SA026 ) ]	
24LC08 24LC08@SOIC8 [ ( SA602A ) ]	24LC08@TSSOP8
[ ( SA026 ) ]	
24LC16 [ ( SA602A ) ]	24LC16@SOIC8
24LC16@TSSOP8 [ ( SA026 ) ]	
24LLC02 24LLC02@SOIC8 [ ( SA602A ) ]	24LLC02@TSSOP8
[ ( SA026 ) ]	
24LLC08 [ ( SA602A ) ]	24LLC08@SOIC8
24LLC08@TSSOP8 [ ( SA026 ) ]	
93LC46 93LC46@SOIC8 [ ( SA602A ) ]	
93LC46R 93LC46R@SOIC8 [ ( SA602A ) ]	
93LC56 93LC56@SOIC8 [ ( SA602A ) ]	
93LC66 93LC66@SOIC8 [ ( SA602A ) ]	

## CFeon

### E ( E ) PROM / FRAM / NVRAM

EN29LV800BB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800BB@TSOP48 [ ( SA247-B005 ) ]

EN29LV800BT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800CB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800CB@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800CT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800CT@TSOP48 [ ( SA247-B005 ) ]

## CHINA CORE

### MICROCONTROLLER

CCM89C51 [ ( SA244 ) ]	CCM89C51@PLCC44
CCM89C51@TQFP44 [ ( SA245A ) ]	
CCM89C52 CCM89C52@PLCC44 [ ( SA244 ) ]	CCM89C52@TQFP44
[ ( SA245A ) ]	

## CHINGIS

### E ( E ) PROM / FRAM / NVRAM

PM24C64 [ ( SA602A ) ]	PM24C64@SOIC8
PM24C64@TSOP8 [ ( SA026 ) ] [ ( SA023A ) ]	PM25LD040 ( B ) @SOIC8
PM25LD040 ( Q ) @WSON8 [ ( SA683 ) ] [ ( SA602A ) ]	PM25LD040 ( S ) @SOIC8
PM25LV010 ( B ) @SOIC8 [ ( SA023A ) ] [ ( SA683 ) ]	PM25LV010 ( Q ) @WSON8
PM25LV010 ( S ) @SOIC8 [ ( SA602A ) ] [ ( SA602A ) ]	PM25LV010A@SOIC8
PM25LV010A@WSON8 [ ( SA683 ) ] [ ( SA605A ) ]	PM25LV016@SOIC8
PM25LV016@WSON8 [ ( SA683 ) ] [ ( SA605A ) ]	PM25LV016A@SOIC8
PM25LV016A@WSON8 [ ( SA683 ) ] [ ( SA023A ) ]	PM25LV020 ( B ) @SOIC8
PM25LV020 ( Q ) @WSON8 [ ( SA683 ) ] [ ( SA602A ) ]	PM25LV020 ( S ) @SOIC8

PM25LV040(B)@SOIC8 [(SA023A)]	PM25LV040(Q)@WSON8
[(SA683)]	
PM25LV040(S)@SOIC8 [(SA602A)]	PM25LV080@SOIC8
[(SA605A)]	
PM25LV080@WSON8 [(SA683)]	PM25LV080A@SOIC8
[(SA605A)]	
PM25LV080A@WSON8 [(SA683)]	PM25LV512(B)@SOIC8
[(SA023A)]	
PM25LV512(Q)@WSON8 [(SA683)]	PM25LV512(S)@SOIC8
[(SA602A)]	
PM25W020(B)@SOIC8 [(SA023A)]	PM25W020(Q)@WSON8
[(SA683)]	
PM25W020(S)@SOIC8 [(SA602A)]	
PM29F002B	
PM29F002B@PLCC32 [(SA015A1T)]	
PM29F002T	
PM29F002T@PLCC32 [(SA015A1T)]	
PM29F004B	
PM29F004B@PLCC32 [(SA015A1T)]	
PM29F004T	
PM29F004T@PLCC32 [(SA015A1T)]	
PM29LV002B	
PM29LV002B@PLCC32 [(SA015A1T)]	PM29LV002B@VSOP32
[(SA620)]	
PM29LV002T	PM29LV002T@PLCC32
[(SA015A1T)]	
PM29LV002T@VSOP32 [(SA620)]	PM29LV004B@PLCC32
[(SA015A1T)]	
PM29LV004B@VSOP32 [(SA620)]	PM29LV004T@PLCC32
[(SA015A1T)]	
PM29LV004T@VSOP32 [(SA620)]	PM29LV104RB@PLCC32
[(SA015A1T)]	
PM29LV104RB@VSOP32 [(SA620)]	PM29LV104RT@PLCC32
[(SA015A1T)]	
PM29LV104RT@VSOP32 [(SA620)]	
PM37LV512	
PM37LV512@PLCC32 [(SA015A1T)]	PM37LV512@VSOP32
[(SA620)]	
PM39F010	PM39F010@PLCC32
[(SA015A1T)]	
PM39F010@VSOP32 [(SA620)]	
PM39F020	
PM39F020@PLCC32 [(SA015A1T)]	PM39F020@VSOP32



[ (SA620) ]	
PM39F040	PM39F040@PLCC32
[ (SA015A1T) ]	
PM39F040@VSOP32 [ (SA620) ]	PM39LV010@PLCC32
[ (SA015A1T) ]	
PM39LV010@VSOP32 [ (SA620) ]	PM39LV010R@PLCC32
[ (SA015A1T) ]	
PM39LV010R@VSOP32 [ (SA620) ]	PM39LV020@PLCC32
[ (SA015A1T) ]	
PM39LV020@VSOP32 [ (SA620) ]	PM39LV040@PLCC32
[ (SA015A1T) ]	
PM39LV040@VSOP32 [ (SA620) ]	PM39LV512@PLCC32
[ (SA015A1T) ]	
PM39LV512@VSOP32 [ (SA620) ]	PM39LV512R@PLCC32
[ (SA015A1T) ]	
PM39LV512R@VSOP32 [ (SA620) ]	PM49FL002T@PLCC32
[ (SA015A1T) ]	
PM49FL002T@VSOP32 [ (SA620) ]	
PM49FL004T(Low)@PLCC32 [ (SA015A1T-B001) ]	
PM49FL004T(Low)@VSOP32 [ (SA620-B005) ]	
PM49FL004T@PLCC32 [ (SA015A1T) ]	PM49FL004T@VSOP32
[ (SA620) ]	
PM49FL008T@PLCC32 [ (SA015A1T) ]	PM49FL008T@VSOP32
[ (SA620) ]	
PM49LP002T@PLCC32 [ (SA015A1T) ]	PM49LP002T@VSOP32
[ (SA620) ]	

## CHIPCON

### MICROCONTROLLER

CC1010@TQFP64(ISP) [ ISP-HEADER01 ]

## CHIPSWINNER

### E ( E ) PROM / FRAM / NVRAM

CW24C02	CW24C02@SOIC8
[ (SA602A) ]	
CW24C04	CW24C04@SOIC8

[ ( SA602A ) ]	
CW24C08	CW24C08@SOIC8
[ ( SA602A ) ]	
CW24C16	CW24C16@SOIC8
[ ( SA602A ) ]	
CW24C32	CW24C32@SOIC8
[ ( SA602A ) ]	
CW24C64	CW24C64@SOIC8
[ ( SA602A ) ]	

## MICROCONTROLLER

CW88CS028@SDIP28 [ ( SA653 ) ]	CW88CS032@SDIP32
[ ( SA653 ) ]	
CW88CS128@SDIP28 [ ( SA653 ) ]	CW88CS132@SDIP32
[ ( SA653 ) ]	
CW89F1050	
CW89F2050	
CW89F4050@SDIP28 [ ( SA653 ) ]	CW89F4050@SOP28
[ ( SA404 ) ]	
CW89F52	CW89F52@LQFP44
[ ( SA675 ) ]	
CW89F54	CW89F54@LQFP44
[ ( SA675 ) ]	

## CORERIVER

### E ( E ) PROM / FRAM / NVRAM

CR24C02LI	CR24C02WI@SOIC8
[ ( SA602 ) ]	
CR24C08LI	CR24C08WI@SOIC8
[ ( SA602 ) ]	
CR24C16LI	CR24C16WI@SOIC8
[ ( SA602 ) ]	
CR24C256LI	CR24C256WI@SOIC8
[ ( SA602 ) ]	
CR24C32LI	CR24C32WI@SOIC8
[ ( SA602 ) ]	
CR24C64LI	CR24C64WI@SOIC8
[ ( SA602 ) ]	

## CWI

### E ( E ) PROM / FRAM / NVRAM

39LV040@VSOP32 [ ( SA620 ) ]

## CYGNAL

### MICROCONTROLLER

C8051F000@TQFP64 ( ISP ) [ ( PEP+S616 ) ]  
C8051F001@TQFP48 ( ISP ) [ ( SA248 ) ]                    C8051F002@TQFP32 ( ISP )  
[ ( SA663 ) ]  
C8051F005@TQFP64 ( ISP ) [ ( PEP+S616 ) ]  
C8051F006@TQFP48 ( ISP ) [ ( SA248 ) ]                    C8051F007@TQFP32 ( ISP )  
[ ( SA663 ) ]  
C8051F010@TQFP64 ( ISP ) [ ( PEP+S616 ) ]  
C8051F011@TQFP48 ( ISP ) [ ( SA248 ) ]                    C8051F012@TQFP32 ( ISP )  
[ ( SA663 ) ]  
C8051F015@TQFP64 ( ISP ) [ ( PEP+S616 ) ]  
C8051F016@TQFP48 ( ISP ) [ ( SA248 ) ]                    C8051F017@TQFP32 ( ISP )  
[ ( SA663 ) ]  
C8051F018@TQFP64 ( ISP ) [ ( PEP+S616 ) ]  
C8051F019@TQFP48 ( ISP ) [ ( SA248 ) ]  
C8051F020@TQFP100 ( ISP ) [ ISP-HEADER01 ]  
C8051F021@TQFP64 ( ISP ) [ ISP-HEADER01 ]  
C8051F022@TQFP100 ( ISP ) [ ISP-HEADER01 ]  
C8051F023@TQFP64 ( ISP ) [ ISP-HEADER01 ]  
C8051F040@TQFP100 ( ISP ) [ ISP-HEADER01 ]  
C8051F041@TQFP64 ( ISP ) [ ISP-HEADER01 ]  
C8051F042@TQFP100 ( ISP ) [ ISP-HEADER01 ]  
C8051F043@TQFP64 ( ISP ) [ ISP-HEADER01 ]  
C8051F044@TQFP100 ( ISP ) [ ISP-HEADER01 ]  
C8051F045@TQFP64 ( ISP ) [ ISP-HEADER01 ]  
C8051F046@TQFP100 ( ISP ) [ ISP-HEADER01 ]  
C8051F047@TQFP64 ( ISP ) [ ISP-HEADER01 ]  
C8051F206@TQFP48 [ ( SA248 ) ]                    C8051F220@TQFP48  
[ ( SA248 ) ]  
C8051F221@TQFP32 [ ( SA663 ) ]                    C8051F226@TQFP48

[(SA248)]	
C8051F230@TQFP48 [(SA248)]	C8051F231@TQFP32
[(SA663)]	
C8051F236@TQFP48 [(SA248)]	C8051F300
[(SA695A)]	
C8051F301 [(SA695A)]	C8051F302
[(SA695A)]	
C8051F303 [(SA695A)]	C8051F304
[(SA695A)]	
C8051F305 [(SA695A)]	C8051F310@TQFP32
[(SA663)]	
C8051F310-GQ@TQFP32 [(SA663)]	C8051F311@QFN28 [(SA697-
B006)]	
C8051F311-GM@QFN28 [(SA697-B006)]	
C8051F312@TQFP32 [(SA663)]	C8051F312-GQ@TQFP32
[(SA663)]	
C8051F313@QFN28 [(SA697-B006)]	
C8051F313-GM@QFN28 [(SA697-B006)]	
C8051F314@TQFP32 [(SA663)]	C8051F314-GQ@TQFP32
[(SA663)]	
C8051F315@QFN28 [(SA697-B006)]	
C8051F315-GM@QFN28 [(SA697-B006)]	
C8051F316-GM@QFN24 [(SA710-B006)]	
C8051F317-GM@QFN24 [(SA710-B006)]	
C8051F320@TQFP32 [(SA663)]	C8051F321@QFN28 [(SA697-
B006)]	
C8051F326@QFN28 [(SA697-B006)]	
C8051F326-GQ@QFN28 [(SA697-B006)]	
C8051F327@QFN28 [(SA697-B006)]	
C8051F327-GQ@QFN28 [(SA697-B006)]	
C8051F330@MLP20 [(SA692)]	
C8051F330D	
C8051F331@MLP20 [(SA692)]	C8051F332-GM@MLP20
[(SA692)]	
C8051F333-GM@MLP20 [(SA692)]	C8051F334-GM@MLP20
[(SA692)]	
C8051F335-GM@MLP20 [(SA692)]	C8051F336-GM@QFN20
[(SA692)]	
C8051F337-GM@QFN20 [(SA692)]	C8051F338-GM@QFN24
[(SA710)]	
C8051F339-GM@QFN24 [(SA710)]	C8051F340-GQ@TQFP48
[(SA248)]	
C8051F341-GQ@TQFP48 [(SA248)]	C8051F342-GQ@LQFP32

[ (SA663) ]	
C8051F343-GQ@LQFP32 [ (SA663) ]	C8051F344-GQ@TQFP48
[ (SA248) ]	
C8051F345-GQ@TQFP48 [ (SA248) ]	C8051F346-GQ@LQFP32
[ (SA663) ]	
C8051F347-GQ@LQFP32 [ (SA663) ]	C8051F350-GQ@LQFP32
[ (SA663) ]	
C8051F351-GM@QFN28 [ (SA697-B006) ]	
C8051F352-GQ@LQFP32 [ (SA663) ]	
C8051F353-GM@QFN28 [ (SA697-B006) ]	
C8051F360@QFP48 [ (SA248) ]	C8051F361@QFP32
[ (SA663) ]	
C8051F362@QFN28 [ (SA697) ]	C8051F363@QFP48
[ (SA248) ]	
C8051F364@QFP32 [ (SA663) ]	C8051F365@QFN28
[ (SA697) ]	
C8051F366@QFP32 [ (SA663) ]	C8051F367@QFN28
[ (SA697) ]	
C8051F368@QFP32 [ (SA663) ]	C8051F369@QFN28
[ (SA697) ]	
C8051F410-GQ@LQFP32 [ (SA663) ]	C8051F411-GM@QFN28
[ (SA697) ]	
C8051F412-GQ@LQFP32 [ (SA663) ]	C8051F413-GM@QFN28
[ (SA697) ]	
C8051F520-IM@QFN10 [ (SA695A) ]	C8051F521-IM@QFN10
[ (SA695A) ]	
C8051F523-IM@QFN10 [ (SA695A) ]	C8051F524-IM@QFN10
[ (SA695A) ]	
C8051F526-IM@QFN10 [ (SA695A) ]	C8051F527-IM@QFN10
[ (SA695A) ]	
C8051F530-IM@QFN20 [ (SA692) ]	C8051F530-IT@TSSOP20
[ (SA026) ]	
C8051F531-IM@QFN20 [ (SA692) ]	C8051F531-IT@TSSOP20
[ (SA026) ]	
C8051F533-IM@QFN20 [ (SA692) ]	C8051F533-IT@TSSOP20
[ (SA026) ]	
C8051F534-IM@QFN20 [ (SA692) ]	C8051F534-IT@TSSOP20
[ (SA026) ]	
C8051F536-IM@QFN20 [ (SA692) ]	C8051F536-IT@TSSOP20
[ (SA026) ]	
C8051F537-IM@QFN20 [ (SA692) ]	C8051F537-IT@TSSOP20
[ (SA026) ]	
C8051F610-GQ@QFP32 [ (SA663) ]	

C8051F611-GM@QFN28 [(SA697-B006)]	
C8051F612-GQ@QFP32 [(SA663)]	
C8051F613-GM@QFN28 [(SA697-B006)]	
C8051F614-GQ@QFP32 [(SA663)]	
C8051F615-GM@QFN28 [(SA697-B006)]	
C8051F616-GM@QFN24 [(SA710-B006)]	
C8051F617-GM@QFN24 [(SA710-B006)]	
SI8250@LQFP32 [(SA663)]	SI8250@QFN28
[(SA697)]	
SI8251@LQFP32 [(SA663)]	SI8251@QFN28
[(SA697)]	
SI8252@LQFP32 [(SA663)]	SI8252@QFN28
[(SA697)]	

## CYPRESS

### E ( E ) PROM / FRAM / NVRAM

CY14B256L@SOIC32 [(SA715)]	
CY27C010	
CY27C010@PLCC32 [(SA015A1T)]	CY27C010@TSOP32
[(SA410T)]	
CY27C020	CY27C020@PLCC32
[(SA015A1T)]	
CY27C020@TSOP32 [(SA410T)]	
CY27C040	
CY27C040@PLCC32 [(SA015A1T)]	CY27C040@TSOP32
[(SA410T)]	
CY27C128	CY27C128@PLCC32
[(SA015A1T)]	
CY27C256	CY27C256@PLCC32
[(SA015A1T)]	
CY27C256@TSOP28 [(SA430T)]	
CY27C512	
CY27C512@PLCC32 [(SA015A1T)]	CY27C512@TSOP28
[(SA430T)]	
CY27H010	CY27H010@PLCC32
[(SA015A1T)]	
CY27H010@TSOP32 [(SA410T)]	
CY27H256	
CY27H256@PLCC32 [(SA015A1T)]	CY27H256@TSOP28
[(SA430T)]	

CY27H512  
[ (SA015A1T) ]  
CY27H512@TSOP28 [ (SA430T) ]  
CY7C225A  
CY7C225A@PLCC28 [ (SA008A) ]  
CY7C243  
CY7C243@PLCC28 [ (SA008A) ]  
CY7C244  
CY7C244@PLCC28 [ (SA008A) ]  
CY7C245  
CY7C245@PLCC28 [ (SA008A) ]  
CY7C245A  
CY7C245A@PLCC28 [ (SA008A) ]  
CY7C251  
CY7C251@PLCC32 [ (SA015A1T) ]  
CY7C254  
CY7C254@PLCC32 [ (SA015A1T) ]  
CY7C256  
CY7C256@PLCC32 [ (SA015A1T) ]  
CY7C261  
CY7C261@PLCC28 [ (SA008A) ]  
CY7C263  
CY7C263@PLCC28 [ (SA008A) ]  
CY7C264  
CY7C264@PLCC28 [ (SA008A) ]  
CY7C265  
CY7C265@PLCC28 [ (SA008A) ]  
CY7C266  
CY7C266@PLCC32 [ (SA015A1T) ]  
CY7C268  
CY7C268@PLCC32 [ (SA015A1T) ]  
CY7C271  
CY7C271@PLCC32 [ (SA015A1T) ]  
CY7C271A  
CY7C271A@PLCC32 [ (SA015A1T) ]  
CY7C274  
CY7C274@PLCC32 [ (SA015A1T) ]  
[ (SA244) ]  
CY7C276 (25JC)@PLCC44 [ (SA244) ]  
[ (SA244) ]  
CY7C281  
[ (SA008A) ]  
CY7C281A

CY27H512@PLCC32

CY7C276 (25HC)@PLCC44

CY7C276 (30JC)@PLCC44

CY7C281@PLCC28

CY7C281A@PLCC28

[ (SA008A) ] CY7C282	CY7C282@PLCC28
[ (SA008A) ] CY7C282A	CY7C282A@PLCC28
[ (SA008A) ] CY7C285	CY7C285@PLCC32
[ (SA015A1T) ] CY7C286	CY7C286@PLCC32
[ (SA015A1T) ] CY7C287	CY7C287@PLCC32
[ (SA015A1T) ] CY7C291	CY7C291@PLCC28
[ (SA008A) ] CY7C291A	CY7C291A@PLCC28
[ (SA008A) ] CY7C292	CY7C292@PLCC28
[ (SA008A) ] CY7C292A	CY7C292A@PLCC28
[ (SA008A) ] CY7C293A	CY7C293A@PLCC28
[ (SA008A) ] CY8C9520@SSOP28 [ (SA626A) ] [ (SA669) ]	CY8C9540@SSOP48

## DRAM & SRAM

CY62128@SOIC32 [ (SA687) ] [ (SA661) ]	CY62128@SOJ32
CY62128@VSOP32 [ (SA620) ] [ (SA687) ]	CY62128L@SOIC32
CY62128L@SOJ32 [ (SA661) ] [ (SA620) ]	CY62128L@VSOP32
CY62128LL@SOIC32 [ (SA687) ] [ (SA661) ]	CY62128LL@SOJ32
CY62128LL@VSOP32 [ (SA620) ] [ (SA645) ]	CY7C1011@TSOP44
CY7C1020@TSOP44 [ (SA645) ] [ (SA645) ]	CY7C1021@TSOP44
CY7C1049@SOJ36 [ (SA027) ] [ (SA645) ]	CY7C1049@TSOP44
CY7C107 [ (SA661) ]	CY7C107@SOJ28



CY7C147  
CY7C167  
CY7C167@PLCC20 [(SA001A)]  
CY7C167A  
CY7C167A@PLCC20 [(SA001A)]  
CY7C185  
CY7C185@SOIC28 [(SA404)] CY7C185@SOJ28  
[(SA646)]  
CY7C186  
CY7C187  
CY7C187@SOJ24 [(SA646)]  
CY7C187A  
CY7C187A@SOJ24 [(SA646)]  
CY7C193  
CY7C193@SOJ28 [(SA646)]  
CY7C199  
CY7C199@PLCC28 [(SA008A)] CY7C199@SOJ28  
[(SA646)]  
CY7C199@TSOP28 [(SA430T)]

**PLD**

CY2291@SOIC20 [(SA404)] CY2292@SOIC16  
[(SA602)]  
CY2295@SSOP28 [(SA626A)] CY37032@PLCC44  
[(SA244)]  
CY37032@TQFP44 [(SA245A)] CY37032V@PLCC44  
[(SA244)]  
CY37032V@TQFP44 [(SA245A)] CY37064@PLCC44  
[(SA244)]  
CY37064@PLCC44(ISP) [ISP-HEADER01]  
CY37064@TQFP44 [(SA245A)]  
CY37064@TQFP44(ISP) [ISP-HEADER01]  
CY37064V@PLCC44 [(SA244)]  
CY37064V@PLCC44(ISP) [ISP-HEADER01]  
CY37064V@TQFP44 [(SA245A)]  
CY37064V@TQFP44(ISP) [ISP-HEADER01]  
CY7C371@PLCC44 [(SA244)] CY7C371@TQFP44  
[(SA245A)]  
CY7C371I@PLCC44 [(SA244)] CY7C371I@TQFP44  
[(SA245A)]  
CY7C372@PLCC44 [(SA244)] CY7C372@TQFP44

[ (SA245A) ] CY7C372I@PLCC44 [ (SA244) ]	CY7C372I@TQFP44
[ (SA245A) ] PALC16L8	PALC16L8@PLCC20
[ (SA001A) ] PALC16L8L	PALC16L8L@PLCC20
[ (SA001A) ] PALC16R4	PALC16R4@PLCC20
[ (SA001A) ] PALC16R4L	PALC16R4L@PLCC20
[ (SA001A) ] PALC16R6	PALC16R6@PLCC20
[ (SA001A) ] PALC16R6L	PALC16R6L@PLCC20
[ (SA001A) ] PALC16R8	PALC16R8@PLCC20
[ (SA001A) ] PALC16R8L	PALC16R8L@PLCC20
[ (SA001A) ] PALC22V10	PALC22V10@PLCC28
[ (SA008A) ] PALC22V10A	PALC22V10A@PLCC28
[ (SA008A) ] PALC22V10B	PALC22V10B@PLCC28
[ (SA008A) ] PALC22V10D	PALC22V10D@PLCC28
[ (SA008A) ] PALC22V10L	PALC22V10L@PLCC28
[ (SA008A) ] PALCE16V8	PALCE16V8@PLCC20
[ (SA001A) ] PALCE20V8	PALCE20V8@PLCC28
[ (SA008A) ] PALCE20V8L	PALCE20V8L@PLCC28
[ (SA008A) ] PALCE22V10	PALCE22V10@PLCC28
[ (SA008A) ]	

## MICROCONTROLLER

CY7C63722 [ (SA404) ]	CY7C63722@SOIC18
--------------------------	------------------

CY7C63722C	CY7C63722C@SOIC18
[ (SA404) ]	
CY7C63723	CY7C63723@SOIC18
[ (SA404) ]	
CY7C63723C	CY7C63723C@SOIC18
[ (SA404) ]	
CY7C63742	CY7C63742@QSOP24
[ (SA674) ]	
CY7C63742@SOIC24 [ (SA404) ]	
CY7C63742C	
CY7C63742C@QSOP24 [ (SA674) ]	CY7C63742C@SOIC24
[ (SA404) ]	
CY7C63743	CY7C63743@QSOP24
[ (SA674) ]	
CY7C63743@SOIC24 [ (SA404) ]	
CY7C63743C	
CY7C63743C@QSOP24 [ (SA674) ]	CY7C63743C@SOIC24
[ (SA404) ]	
CY7C63813	CY7C63813@SOIC18
[ (SA404) ]	

## DALLAS

### E (E) PROM/FRAM/NVRAM

DS1073M-100	DS1073M-
60	
DS1073M-66	DS1073M-
80	
DS1073Z-100@SOIC8 [ (SA602A) ]	DS1073Z-60@SOIC8
[ (SA602A) ]	
DS1073Z-66@SOIC8 [ (SA602A) ]	DS1073Z-80@SOIC8
[ (SA602A) ]	
DS1077LZ-40@SOIC8 [ (SA602A) ]	DS1077LZ-50@SOIC8
[ (SA602A) ]	
DS1077LZ-60@SOIC8 [ (SA602A) ]	DS1077LZ-66@SOIC8
[ (SA602A) ]	
DS1077Z-40@SOIC8 [ (SA602A) ]	DS1077Z-50@SOIC8
[ (SA602A) ]	
DS1077Z-60@SOIC8 [ (SA602A) ]	DS1077Z-66@SOIC8
[ (SA602A) ]	
DS1220AB	

DS1220AD  
DS1220Y  
DS1225AB  
DS1225AD  
DS1225D  
DS1225E  
DS1225Y  
DS1230AB  
DS1230W  
DS1230Y  
DS1235AB  
DS1235Y  
DS1243Y  
DS1244  
DS1244Y  
DS1245AB  
DS1245EE  
DS1245P  
DS1245W  
DS1245Y  
DS1248P  
DS1248W  
DS1248Y  
DS1249AB  
DS1249W  
DS1249Y  
DS1250AB  
DS1250W  
DS1250Y  
DS1251AB  
DS1251W  
DS1251Y  
DS1256P  
DS1256W  
DS1256Y  
DS1258AB  
DS1258W  
DS1258Y  
DS1265AB  
DS1265W  
DS1265Y  
DS1270AB  
DS1270W

DS1270Y  
DS1284  
DS1284N DS1284Q@PLCC28  
[ (SA008A) ]  
DS1284QN@PLCC28 [ (SA008A) ]  
DS1286  
DS1286I  
DS1287  
DS1287A  
DS12887  
DS12887A  
DS12C887  
DS12C887A  
DS1330AB  
DS1330WP  
DS1330Y  
DS1345AB  
DS1345P  
DS1345W  
DS1345Y  
DS1350AB  
DS1350P  
DS1350W  
DS1350Y  
DS1386 (32K) DS1386  
(8K)  
DS14285  
DS14287  
DS1485 DS1485@SOIC28  
[ (SA630) ]  
DS1486  
DS1488  
DS1501  
DS1511  
DS1553  
DS1553W  
DS1554  
DS1554W  
DS1556  
DS1630AB  
DS1630Y  
DS1642  
DS1643

DS1644  
DS1644P  
DS1645AB  
DS1645EE  
DS1645Y  
DS1646  
DS1647  
DS1647LPM  
DS1650AB  
DS1650Y  
3  
DS1687-5  
3  
DS17287-5  
DS1742  
DS1742W  
DS1743  
DS1743P  
DS1743W  
DS1743WP  
DS1744  
DS1744P  
DS1744W  
DS1744WP  
DS1746  
DS1747  
DS1747P  
DS1747W  
DS1747WP  
DS17487-3  
5  
DS17887-3  
5  
DS2406@TO-92  
DS2406P@TSOC6  
DS2430A@TO-92  
[ (SA602A) ]  
DS2431@TO-92  
[ (SA602A) ]  
DS2432P@TSOC6 [ (SA602A) ]  
35  
DS2433S(3.9)@SOIC8 [ (SA602A) ]  
[ (SA605A) ]  
DS1687-  
DS17287-  
DS17487-  
DS17887-  
DS2430AP@TSOC6  
DS2431P@TSOC6  
DS2433@PR-  
DS2433S(5.5)@SOIC8

DS2502 [ (SA602A) ] DS2502S@SOIC8 [ (SA602A) ] DS2502UNW DS2502UNW@SOIC8 [ (SA602A) ] [ (SA602A) ] DS2506 [ (SA023A) ] DS4510@uSOP10 [ (SA026) ] DS4550@TSSOP20 [ (SA026) ]	DS2502P@TSOC6   DS2502UNW@TSOC6  DS2506S@SOIC8  DS4520@TSSOP16
---	---

## **MICROCONTROLLER**

DS87C520 [ (SA244) ] DS87C520@TQFP44 [ (SA245A) ] DS89C420 DS89C420 (rev.A) [ (SA244) ] DS89C420 (rev.A)@TQFP44 [ (SA245A) ] DS89C420@PLCC44 [ (SA244) ] [ (SA245A) ] DS89C430 [ (SA244) ] DS89C430@TQFP44 [ (SA245A) ] DS89C440 DS89C440@PLCC44 [ (SA244) ] [ (SA245A) ] DS89C450 [ (SA244) ] DS89C450@TQFP44 [ (SA245A) ]	DS87C520@PLCC44   DS89C420 (rev.A)@PLCC44  DS89C420@TQFP44  DS89C430@PLCC44  DS89C440@TQFP44  DS89C450@PLCC44
--	--

## **DENSE-PAC**

### **E (E) PROM / FRAM / NVRAM**

DPV27C101 [ (SA015A1T) ] DPV27C256 [ (SA015A1T) ]	DPV27C101@PLCC32  DPV27C256@PLCC32
--	--

DPV27C512  
[ (SA015A1T) ]

DPV27C512@PLCC32

## DEUTRON

### E ( E ) PROM / FRAM / NVRAM

AC25LV010  
[ (SA602A) ]

AC25LV010@SOIC8

AC25LV512  
[ (SA602A) ]

AC25LV512@SOIC8

P439LV010@PLCC32 [ (SA015A1T) ]  
[ (SA620) ]

P439LV010@VSOP32

P439LV040@PLCC32 [ (SA015A1T) ]  
[ (SA620) ]

P439LV040@VSOP32

P439LV088@TSOP48 [ (SA247-B005) ]  
B005) ]

P439VF800@TSOP48 [ (SA247-

## EFST

### E ( E ) PROM / FRAM / NVRAM

EM25LV010@SOIC8 [ (SA602A) ]  
[ (SA684) ]

EM25LV010@VFQFPN8

EM25LV512@SOIC8 [ (SA602A) ]  
[ (SA684) ]

EM25LV512@VFQFPN8

F25L004A@SOIC8 [ (SA602A) ]

F49B002UA

F49B002UA@PLCC32 [ (SA015A1T) ]  
[ (SA015A1T) ]

F49L004BA@PLCC32

F49L004BA@TSOP40 [ (SA409T) ]  
[ (SA015A1T) ]

F49L004UA@PLCC32

F49L004UA@TSOP40 [ (SA409T) ]  
[ (SA015A1T) ]

F49L040A@PLCC32

F49L040A@VSOP32 [ (SA620) ]  
B005) ]

F49L400BA@TSOP48 [ (SA247-

F49L400UA@TSOP48 [ (SA247-B005) ]  
[ (SA247) ]

F49L800BA@TSOP48

F49L800UA@TSOP48 [ (SA247) ]



# ELECTRONIC ARRAYS

## E ( E ) PROM / FRAM / NVRAM

EA2716

## EM

### MICROCONTROLLER

EM6503@SOIC24 [ ( SA404 ) ]  
EM6503@SOIC24 ( ISP ) [ ISP-HEADER01 ]  
EM6504@SOIC24 [ ( SA404 ) ]  
EM6504@SOIC24 ( ISP ) [ ISP-HEADER01 ]  
EM6505@SOIC24 [ ( SA404 ) ]  
EM6505@SOIC24 ( ISP ) [ ISP-HEADER01 ]  
EM6517@SOIC28 [ ( SA404 ) ]  
EM6517@SOIC28 ( ISP ) [ ISP-HEADER01 ]  
EM6520@TQFP44 [ ( SA245A ) ]  
EM6520@TQFP44 ( ISP ) [ ISP-HEADER01 ]  
EM6521@TQFP52 ( ISP ) [ ISP-HEADER01 ]  
EM6522@TQFP64 ( ISP ) [ ISP-HEADER01 ]  
EM6540@SOIC18 [ ( SA404 ) ]  
EM6540@SOIC18 ( ISP ) [ ISP-HEADER01 ]  
EM6580 [ ( SA602 ) ] EM6580 ( ISP ) [ ISP-  
HEADER01 ]  
EM6580@SOIC14 [ ( SA602 ) ]  
EM6580@SOIC14 ( ISP ) [ ISP-HEADER01 ]  
EM6580@SOIC8 [ ( SA602A ) ] EM6580@SOIC8 ( ISP ) [ ISP-  
HEADER01 ]  
EM6580@TSSOP14 [ ( SA026 ) ]  
EM6580@TSSOP14 ( ISP ) [ ISP-HEADER01 ]  
EM6812\_2K [ ( SA404 ) ] EM6812\_2K ( ISP ) [ ISP-  
HEADER01 ]  
EM6812\_2K@SOIC24 [ ( SA404 ) ]  
EM6812\_2K@SOIC24 ( ISP ) [ ISP-HEADER01 ]  
EM6812\_2K@TSSOP24 [ ( SA026 ) ]  
EM6812\_2K@TSSOP24 ( ISP ) [ ISP-HEADER01 ]  
EM6812\_4K [ ( SA404 ) ] EM6812\_4K ( ISP ) [ ISP-  
HEADER01 ]  
EM6812\_4K@SOIC24 [ ( SA404 ) ]

EM6812\_4K@SOIC24(ISP) [ISP-HEADER01]  
EM6812\_4K@TSSOP24 [(SA026)]  
EM6812\_4K@TSSOP24(ISP) [ISP-HEADER01]  
EM6812\_8K EM6812\_8K(ISP) [ISP-  
HEADER01]  
EM6812\_8K@SOIC24 [(SA404)]  
EM6812\_8K@SOIC24(ISP) [ISP-HEADER01]  
EM6812\_8K@TSSOP24 [(SA026)]  
EM6812\_8K@TSSOP24(ISP) [ISP-HEADER01]

## EMTC

### E ( E ) PROM / FRAM / NVRAM

EM24C02 [(SA602A)]	EM24C02@SOIC8
EM24C02@TSSOP8 [(SA026)]	
EM24C04 EM24C04@SOIC8 [(SA602A)] [(SA026)]	EM24C04@TSSOP8
EM24C08 [(SA602A)]	EM24C08@SOIC8
EM24C08@TSSOP8 [(SA026)]	
EM24C16 EM24C16@SOIC8 [(SA602A)] [(SA026)]	EM24C16@TSSOP8
EM25SL512@SOIC8 [(SA602A)]	
EM29SF002AB EM29SF002AB@PLCC32 [(SA015A1T)] [(SA410T)]	EM29SF002AB@TSOP32
EM29SF002AT [(SA015A1T)]	EM29SF002AT@PLCC32
EM29SF002AT@TSOP32 [(SA410T)]	
EM29SF002NAB EM29SF002NAB@PLCC32 [(SA015A1T)] [(SA410T)]	EM29SF002NAB@TSOP32
EM29SF002NAT [(SA015A1T)]	EM29SF002NAT@PLCC32
EM29SF002NAT@TSOP32 [(SA410T)]	

## EON

## E ( E ) PROM / FRAM / NVRAM

EN25B05 (Bottom Boot)@SOP8(4.0) [(SA602A)]  
EN25B05 (Bottom Boot)@SOP8(5.4) [(SA605A)]  
EN25B05 (Bottom Boot)@VDFN8 [(SA683)]  
EN25B05 (Top Boot)@SOP8(4.0) [(SA602A)]  
EN25B05 (Top Boot)@SOP8(5.4) [(SA605A)]  
EN25B05 (Top Boot)@VDFN8 [(SA683)]  
EN25B10 (Bottom Boot)@SOP8(4.0) [(SA602A)]  
EN25B10 (Bottom Boot)@SOP8(5.4) [(SA605A)]  
EN25B10 (Bottom Boot)@VDFN8 [(SA683)]  
EN25B10 (Top Boot)@SOP8(4.0) [(SA602A)]  
EN25B10 (Top Boot)@SOP8(5.4) [(SA605A)]  
EN25B10 (Top Boot)@VDFN8 [(SA683)]  
EN25B16 (Bottom Boot)@SOP8 [(SA605A)]  
EN25B16 (Bottom Boot)@SOP8 (ISP) [ISP-HEADER01]  
EN25B16 (Bottom Boot)@VFQFN8 (ISP) [ISP-HEADER01]  
EN25B16 (Bottom Boot)@VFQFPN8 [(SA684)]  
EN25B16 (Top Boot)@SOP8 [(SA605A)]  
EN25B16 (Top Boot)@SOP8 (ISP) [ISP-HEADER01]  
EN25B16 (Top Boot)@VFQFN8 (ISP) [ISP-HEADER01]  
EN25B16 (Top Boot)@VFQFPN8 [(SA684)]  
EN25B20 (Bottom Boot)@SOP8(4.0) [(SA602A)]  
EN25B20 (Bottom Boot)@SOP8(5.4) [(SA605A)]  
EN25B20 (Bottom Boot)@VDFN8 [(SA683)]  
EN25B20 (Top Boot)@SOP8(4.0) [(SA602A)]  
EN25B20 (Top Boot)@SOP8(5.4) [(SA605A)]  
EN25B20 (Top Boot)@VDFN8 [(SA683)]  
EN25B32 (Bottom Boot)@SOIC16 [(SA404)]  
EN25B32 (Bottom Boot)@SOIC16 (ISP) [(SA404)]  
EN25B32 (Bottom Boot)@SOP8 [(SA605A)]  
EN25B32 (Bottom Boot)@SOP8 (ISP) [(SA605A)]  
EN25B32 (Bottom Boot)@VDFN8 [(SA684)]  
EN25B32 (Bottom Boot)@VDFN8 (ISP) [(SA684)]  
EN25B32 (Top Boot)@SOIC16 [(SA404)]  
EN25B32 (Top Boot)@SOIC16 (ISP) [(SA404)]  
EN25B32 (Top Boot)@SOP8 [(SA605A)]  
EN25B32 (Top Boot)@SOP8 (ISP) [(SA605A)]  
EN25B32 (Top Boot)@VDFN8 [(SA684)]  
EN25B32 (Top Boot)@VDFN8 (ISP) [(SA684)]  
EN25B40 (Bottom Boot)@SOP8(4.0) [(SA602A)]  
EN25B40 (Bottom Boot)@SOP8(5.4) [(SA605A)]

EN25B40(Bottom Boot)@VDFN8 [(SA683)]  
EN25B40(Top Boot)@SOP8(4.0) [(SA602A)]  
EN25B40(Top Boot)@SOP8(5.4) [(SA605A)]  
EN25B40(Top Boot)@VDFN8 [(SA683)]  
EN25B64(Bottom Boot)@SOIC16 [(SA404)]  
EN25B64(Bottom Boot)@SOIC16(ISP) [ISP-HEADER01]  
EN25B64(Bottom Boot)@VDFN8 [(SA683)]  
EN25B64(Bottom Boot)@VDFN8(ISP) [ISP-HEADER01]  
EN25B64(Top Boot)@SOIC16 [(SA404)]  
EN25B64(Top Boot)@SOIC16(ISP) [ISP-HEADER01]  
EN25B64(Top Boot)@VDFN8 [(SA683)]  
EN25B64(Top Boot)@VDFN8(ISP) [ISP-HEADER01]  
EN25B80(Bottom Boot)@SOP8(4.0) [(SA602A)]  
EN25B80(Bottom Boot)@SOP8(5.4) [(SA605A)]  
EN25B80(Bottom Boot)@VDFN8 [(SA683)]  
EN25B80(Top Boot)@SOP8(4.0) [(SA602A)]  
EN25B80(Top Boot)@SOP8(5.4) [(SA605A)]  
EN25B80(Top Boot)@VDFN8 [(SA683)]  
EN25D16  
[(SA404)]  
EN25D16@SOP8 [(SA605A)]  
[(SA684)]  
EN25D80  
[(SA605A)]  
EN25D80@VDFN8 [(SA683)]  
[(SA602A)]  
EN25F05@SOP8(5.4) [(SA605A)]  
[(SA683)]  
EN25F10@SOP8(4.0) [(SA602A)]  
[(SA605A)]  
EN25F10@VDFN8 [(SA683)]  
EN25F16  
EN25F16@SOP16 [(SA404)]  
[(SA605A)]  
EN25F16@VDFN8 [(SA684)]  
[(SA605A)]  
EN25F20@VDFN8 [(SA683)]  
EN25F32  
EN25F32@SOIC16 [(SA404)]  
[(SA605A)]  
EN25F32@VDFN8 [(SA684)]  
[(SA602A)]  
EN25F40@SOP8(209mil) [(SA605A)]

EN25D16@SOP16  
EN25D16@VDFN8  
EN25D80@SOP8  
EN25F05@SOP8(4.0)  
EN25F05@VDFN8  
EN25F10@SOP8(5.4)  
EN25F16@SOP8  
EN25F20@SOP8  
EN25F32@SOP8  
EN25F40@SOP8(150mil)  
EN25F40@VDFN8

[ (SA683) ]	
EN25F80	EN25F80@SOP8
[ (SA605A) ]	
EN25F80@VDFN8 [ (SA683) ]	EN25LF05@SOP8 ( 4.0 )
[ (SA602A) ]	
EN25LF05@SOP8 ( 5.4 ) [ (SA605A) ]	EN25LF05@VDFN8
[ (SA683) ]	
EN25LF10@SOP8 ( 4.0 ) [ (SA602A) ]	EN25LF10@SOP8 ( 5.4 )
[ (SA605A) ]	
EN25LF10@VDFN8 [ (SA683) ]	EN25LV010@SOIC8
[ (SA602A) ]	
EN25LV010@VFQFPN8 [ (SA684) ]	EN25LV020@SOIC8
[ (SA602A) ]	
EN25LV020@VFQFPN8 [ (SA684) ]	EN25LV040@SOIC8
[ (SA602A) ]	
EN25LV040@VFQFPN8 [ (SA684) ]	EN25LV080@SOIC8
[ (SA602A) ]	
EN25LV080@VFQFPN8 [ (SA684) ]	EN25LV160@SOIC8
[ (SA602A) ]	
EN25LV160@SOIC8 ( ISP ) [ ISP-HEADER01 ]	
EN25LV160@VFQFPN8 [ (SA683) ]	
EN25LV160@VFQFPN8 ( ISP ) [ ISP-HEADER01 ]	
EN25LV512@SOIC8 [ (SA602A) ]	EN25LV512@VFQFPN8
[ (SA684) ]	
EN25P05@SOP8 ( 4.0 ) [ (SA602A) ]	EN25P05@SOP8 ( 5.4 )
[ (SA605A) ]	
EN25P05@VDFN8 [ (SA683) ]	EN25P10@SOP8 ( 4.0 )
[ (SA602A) ]	
EN25P10@SOP8 ( 5.4 ) [ (SA605A) ]	EN25P10@VDFN8
[ (SA683) ]	
EN25P16@SOP8 [ (SA605A) ]	EN25P16@SOP8 ( ISP ) [ ISP-
HEADER01 ]	
EN25P16@VFQFPN8 [ (SA684) ]	
EN25P16@VFQFPN8 ( ISP ) [ ISP-HEADER01 ]	
EN25P20@SOP8 ( 4.0 ) [ (SA602A) ]	EN25P20@SOP8 ( 5.4 )
[ (SA605A) ]	
EN25P20@VDFN8 [ (SA683) ]	EN25P32@SOIC16
[ (SA404) ]	
EN25P32@SOIC16 ( ISP ) [ (SA404) ]	EN25P32@SOP8
[ (SA605A) ]	
EN25P32@SOP8 ( ISP ) [ (SA605A) ]	EN25P32@VDFN8
[ (SA684) ]	
EN25P32@VDFN8 ( ISP ) [ (SA684) ]	EN25P40@SOP8 ( 4.0 )

[ (SA602A) ]  
EN25P40@SOP8(5.4) [ (SA605A) ] EN25P40@VDFN8  
[ (SA683) ]  
EN25P64@SOIC16 [ (SA404) ]  
EN25P64@SOIC16(ISP) [ ISP-HEADER01 ]  
EN25P64@VDFN8 [ (SA683) ]  
EN25P64@VDFN8(ISP) [ ISP-HEADER01 ]  
EN25P80@SOP8(4.0) [ (SA602A) ] EN25P80@SOP8(5.4)  
[ (SA605A) ]  
EN25P80@VDFN8 [ (SA683) ] EN25S16@SOP8  
[ (SA605A) ]  
EN25S16@VFQFPN8 [ (SA684) ]  
EN25S32(Bottom Boot)@SOIC16 [ (SA404) ]  
EN25S32(Bottom Boot)@SOIC16(ISP) [ (SA404) ]  
EN25S32(Bottom Boot)@SOP8 [ (SA605A) ]  
EN25S32(Bottom Boot)@SOP8(ISP) [ (SA605A) ]  
EN25S32(Bottom Boot)@VDFN8 [ (SA684) ]  
EN25S32(Bottom Boot)@VDFN8(ISP) [ (SA684) ]  
EN25S32(Top Boot)@SOIC16 [ (SA404) ]  
EN25S32(Top Boot)@SOIC16(ISP) [ (SA404) ]  
EN25S32(Top Boot)@SOP8 [ (SA605A) ]  
EN25S32(Top Boot)@SOP8(ISP) [ (SA605A) ]  
EN25S32(Top Boot)@VDFN8 [ (SA684) ]  
EN25S32(Top Boot)@VDFN8(ISP) [ (SA684) ]  
EN25T16@SOP8 [ (SA605A) ] EN25T16@VFQFPN8  
[ (SA684) ]  
EN25T80 EN25T80@SOP8  
[ (SA605A) ]  
EN25T80@VDFN8 [ (SA683) ]  
EN27C010  
EN27C010@PLCC32 [ (SA015A1T) ]  
EN27C512  
EN27C512@PLCC32 [ (SA015A1T) ]  
EN29F002AB  
EN29F002AB@PLCC32 [ (SA015A1T) ] EN29F002AB@TSOP32  
[ (SA410T) ]  
EN29F002ANB EN29F002ANB@PLCC32  
[ (SA015A1T) ]  
EN29F002ANB@TSOP32 [ (SA410T) ]  
EN29F002ANT  
EN29F002ANT@PLCC32 [ (SA015A1T) ] EN29F002ANT@TSOP32  
[ (SA410T) ]  
EN29F002AT EN29F002AT@PLCC32

[ (SA015A1T) ]  
EN29F002AT@TSOP32 [ (SA410T) ]  
EN29F002B  
EN29F002B@PLCC32 [ (SA015A1T) ] EN29F002B@TSOP32  
[ (SA410T) ]  
EN29F002NB EN29F002NB@PLCC32  
[ (SA015A1T) ]  
EN29F002NB@TSOP32 [ (SA410T) ]  
EN29F002NT  
EN29F002NT@PLCC32 [ (SA015A1T) ] EN29F002NT@TSOP32  
[ (SA410T) ]  
EN29F002T EN29F002T@PLCC32  
[ (SA015A1T) ]  
EN29F002T@TSOP32 [ (SA410T) ]  
EN29F010  
EN29F010@PLCC32 [ (SA015A1T) ] EN29F010@TSOP32  
[ (SA410T) ]  
EN29F010@VSOP32 [ (SA620) ]  
EN29F040  
EN29F040@PLCC32 [ (SA015A1T) ] EN29F040@TSOP32  
[ (SA410T) ]  
EN29F040A EN29F040A@PLCC32  
[ (SA015A1T) ]  
EN29F040A@TSOP32 [ (SA410T) ] EN29F080@TSOP40  
[ (SA409T) ]  
EN29F512 EN29F512@PLCC32  
[ (SA015A1T) ]  
EN29F512@TSOP32 [ (SA410T) ] EN29F512@VSOP32  
[ (SA620) ]  
EN29F800B@TSOP48 [ (SA247-B005) ] EN29F800T@TSOP48 [ (SA247-  
B005) ]  
EN29LV010@PLCC32 [ (SA015A1T) ] EN29LV010@TSOP32  
[ (SA410T) ]  
EN29LV010@VSOP32 [ (SA620) ] EN29LV040@PLCC32  
[ (SA015A1T) ]  
EN29LV040@TSOP32 [ (SA410T) ] EN29LV040@VSOP32  
[ (SA620) ]  
EN29LV040A@PLCC32 [ (SA015A1T) ] EN29LV040A@TSOP32  
[ (SA410T) ]  
EN29LV040A@VSOP32 [ (SA620) ]  
EN29LV160AB@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
EN29LV160AB@TSOP48 [ (SA247-B005) ]  
EN29LV160AT@FBGA48 [ (SA642G-B026A-T048F001Y) ]

EN29LV160AT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV160B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV160B@TSOP48 [ ( SA247-B005 ) ]  
EN29LV160T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV160T@TSOP48 [ ( SA247-B005 ) ]  
EN29LV320AB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV320AB@TSOP48 [ ( SA247-B005 ) ]  
EN29LV320AT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV320AT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV320B@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
EN29LV320B@TSOP48 [ ( SA247-B005 ) ]  
EN29LV320T@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
EN29LV320T@TSOP48 [ ( SA247-B005 ) ]  
EN29LV400AB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV400AB@TSOP48 [ ( SA247-B005 ) ]  
EN29LV400AT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV400AT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV400B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV400B@TSOP48 [ ( SA247-B005 ) ]  
EN29LV400T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV400T@TSOP48 [ ( SA247-B005 ) ] EN29LV512@PLCC32  
[ ( SA015A1T ) ]  
EN29LV512@TSOP32 [ ( SA410T ) ] EN29LV512@VSOP32  
[ ( SA620 ) ]  
EN29LV640B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV640B@TSOP48 [ ( SA247-B005 ) ]  
EN29LV640H@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV640H@TSOP48 [ ( SA247-B005 ) ]  
EN29LV640L@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV640L@TSOP48 [ ( SA247-B005 ) ]  
EN29LV640T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV640T@TSOP48 [ ( SA247-B005 ) ]  
EN29LV641H@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
EN29LV641H@TSOP48 [ ( SA247-B005 ) ]  
EN29LV641L@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
EN29LV641L@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800AB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800AB@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800AT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800AT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800B@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800BB(Low)@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800BB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]



EN29LV800BB@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800BT(Low)@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800BT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800CB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800CB@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800CT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800CT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800T@TSOP48 [ ( SA247-B005 ) ]  
EN29PL032@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29PL032@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
EN29PL032@TSOP48 [ ( SA247-B005 ) ]  
EN29PL064@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29PL064@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
EN29PL064@TSOP48 [ ( SA247-B005 ) ]  
EN29SL160B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL160B@TSOP48 [ ( SA247-B005 ) ]  
EN29SL160T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL160T@TSOP48 [ ( SA247-B005 ) ]  
EN29SL400B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL400B@TSOP48 [ ( SA247-B005 ) ]  
EN29SL400T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL400T@TSOP48 [ ( SA247-B005 ) ]  
EN29SL800B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL800B@TSOP48 [ ( SA247-B005 ) ]  
EN29SL800T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL800T@TSOP48 [ ( SA247-B005 ) ]  
EN71PL03280@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
EN71PL032A0@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
EN71PL064A0@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
EN71PL064B0@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]

## EPSON

### E ( E ) PROM / FRAM / NVRAM

S1H0H324B2B1@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0H324B2T1@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0H326B2B1@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0H326B2T1@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0H328B2B2@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0H328B2T2@FBGA66 [ ( SA642E-B023A-T072F001 ) ]

S1H0J642B2B3@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
S1H0J642B2T3@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
S1H0J646B2B3@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
S1H0J646B2T3@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
S1H0J648B2B2@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
S1H0J648B2T2@FBGA68 [ ( SA642E-B023A-T072F001 ) ]

## ESMT

### E ( E ) PROM / FRAM / NVRAM

EM25LV010@SOIC8 [ ( SA602A ) ]                      EM25LV010@VFQFPN8  
[ ( SA684 ) ]  
EM25LV512@SOIC8 [ ( SA602A ) ]                      EM25LV512@VFQFPN8  
[ ( SA684 ) ]  
F25L004AB  
F25L004AB@SOIC8 ( 150mil ) [ ( SA602A ) ]  
F25L004AB@SOIC8 ( 200mil ) [ ( SA605A ) ]  
F25L004AT  
F25L004AT@SOIC8 ( 150mil ) [ ( SA602A ) ]  
F25L004AT@SOIC8 ( 200mil ) [ ( SA605A ) ]  
F25L008AB@SOIC8 [ ( SA605A ) ]                      F25L008AT@SOIC8  
[ ( SA605A ) ]  
F25L016AB@SOIC8 [ ( SA605A ) ]                      F25L016AT@SOIC8  
[ ( SA605A ) ]  
F25L04UA@SOIC8 [ ( SA602A ) ]  
F25L08PA ( AAI - PROGRAM ) @SOIC8 [ ( SA605A ) ]  
F25L08PA ( PAGE - PROGRAM ) @SOIC8 [ ( SA605A ) ]  
F25L16PA ( AAI - PROGRAM ) @SOIC8 [ ( SA605A ) ]  
F25L16PA ( PAGE - PROGRAM ) @SOIC8 [ ( SA605A ) ]  
F25L320PA@SOIC16 [ ( SA404 ) ]                      F25L320PA@SOIC8  
[ ( SA605A ) ]  
F25L32PA ( new ) @SOIC16 [ ( SA404 ) ]                      F25L32PA ( new ) @SOIC8  
[ ( SA605A ) ]  
F25L32PA@SOIC16 [ ( SA404 ) ]                      F25L32PA@SOIC8  
[ ( SA605A ) ]  
F25L32QA@SOIC16 [ ( SA404 ) ]                      F25L32QA@SOIC8  
[ ( SA605A ) ]  
F49B002UA    F49B002UA@PLCC32  
[ ( SA015A1T ) ]  
F49L004BA@PLCC32 [ ( SA015A1T ) ]                      F49L004BA@TSOP40  
[ ( SA409T ) ]

F49L004UA@PLCC32 [(SA015A1T)]	F49L004UA@TSOP40
[(SA409T)]	
F49L040A@PLCC32 [(SA015A1T)]	F49L040A@VSOP32
[(SA620)]	
F49L160BA@TSOP48 [(SA247)]	F49L160UA@TSOP48
[(SA247)]	
F49L320BA@TSOP48 [(SA247)]	F49L320UA@TSOP48
[(SA247)]	
F49L400BA@TSOP48 [(SA247-B005)]	F49L400UA@TSOP48 [(SA247-
B005)]	
F49L800BA@TSOP48 [(SA247)]	F49L800UA@TSOP48
[(SA247)]	
FM91L01604BA@FBGA56 [(SA642P-B207A-W056F001Y)]	
FM91L01604UA@FBGA56 [(SA642P-B207A-W056F001Y)]	
FM91L03208BA@FBGA56 [(SA642P-B207A-W056F001Y)]	
FM91L03208BIA@FBGA56 [(SA642P-B207A-W056F001Y)]	
FM91L03208UA@FBGA56 [(SA642P-B207A-W056F001Y)]	
FM91L03208UIA@FBGA56 [(SA642P-B207A-W056F001Y)]	

## EXCELSEMI

### E ( E ) PROM / FRAM / NVRAM

ES25M16	ES25M16@SOP16
[(SA404)]	
ES25M16@SOP8[150 mil] [(SA602A)]	ES25M16@SOP8[208 mil]
[(SA605A)]	
ES25M40	ES25M40@SOP16
[(SA404)]	
ES25M40@SOP8[150 mil] [(SA602A)]	ES25M40@SOP8[208 mil]
[(SA605A)]	
ES25M80	ES25M80@SOP16
[(SA404)]	
ES25M80@SOP8[150 mil] [(SA602A)]	ES25M80@SOP8[208 mil]
[(SA605A)]	
ES25P16@SOP8 [(SA605A)]	ES25P40@SOP8
[(SA605A)]	
ES25P80@SOP8 [(SA605A)]	
ES29LV160DB@FBGA48 [(SA642G-B026A-T048F001Y)]	
ES29LV160DB@PSOP44 [(SA638)]	
ES29LV160DB@TSOP48 [(SA247-B005)]	
ES29LV160DT@FBGA48 [(SA642G-B026A-T048F001Y)]	

ES29LV160DT@PSOP44 [ ( SA638 ) ]  
ES29LV160DT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV160EB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV160EB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV160ET@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV160ET@TSOP48 [ ( SA247-B005 ) ]  
ES29LV160FB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV160FB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV160FT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV160FT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320DB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320DB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320DT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320DT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320EB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320EB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320ET@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320ET@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320FB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320FB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320FT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320FT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV400DB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV400DB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV400DT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV400DT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV400EB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV400EB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV400ET@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV400ET@TSOP48 [ ( SA247-B005 ) ]  
ES29LV800DB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV800DB@PSOP44 [ ( SA638 ) ]  
ES29LV800DB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV800DT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV800DT@PSOP44 [ ( SA638 ) ]  
ES29LV800DT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV800EB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV800EB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV800ET@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV800ET@TSOP48 [ ( SA247-B005 ) ]

## EXEL

**E ( E ) PROM / FRAM / NVRAM**

XL24C01A  
XL24C02  
XL24C04  
XL24C16  
XL24C16@SOIC8 [ ( SA602A ) ]  
XL24C32  
XL28C256 XL28C256@PLCC32  
[ ( SA015A1T ) ]  
XL28C256@TSOP28 [ ( SA430T ) ]  
XL9010  
XL9010(F) [ ( SA602A ) ]  
XL9020  
XL9020(F) [ ( SA602A ) ]  
XL9040  
XL9040(F) [ ( SA602A ) ]  
XL9346  
XL9346@SOIC8 [ ( SA602A ) ]  
XL93CS56  
XL93CS56@SOIC8 [ ( SA602A ) ] XL93CS56@TSSOP8  
[ ( SA026 ) ]  
XL93CS66 XL93CS66@SOIC8  
[ ( SA602A ) ]  
XL93CS66@TSSOP8 [ ( SA026 ) ]  
XL93LC46  
XL93LC46@SOIC8 [ ( SA602A ) ]  
XL93LC46A  
XL93LC46A@SOIC8 [ ( SA602A ) ]  
XL93LC56  
XL93LC56@SOIC8 [ ( SA602A ) ]  
XL93LC56A  
XL93LC56A@SOIC8 [ ( SA602A ) ]  
XL93LC66A  
XL93LC66A@SOIC8 [ ( SA602A ) ]  
XL9764  
XLE28C16A XLE28C16A@PLCC32  
[ ( SA015A1T ) ]  
XLE28C16B XLE28C16B@PLCC32  
[ ( SA015A1T ) ]  
XLE28C16B@SOIC24 [ ( SA404 ) ]  
XLM28C16A

XLM28C16A@PLCC32 [(SA015A1T)]	
XLM46C15	
XLM46P15	
XLS2804A	
XLS2816A	XLS2816A@PLCC32
[(SA015A1T)]	
XLS2817A	
XLS28C16A	
XLS28C16A@PLCC32 [(SA015A1T)]	
XLS28C16B	
XLS28C16B@PLCC32 [(SA015A1T)]	XLS28C16B@SOIC24
[(SA404)]	
XLS28C64B	XLS28C64B@PLCC32
[(SA015A1T)]	
XLS28C64B@SOIC28 [(SA404)]	
XLS46C15	
XLS46P15	
XLS93C46	
XLS93C46@SOIC8 [(SA602A)]	
XLS93C56	
XLS93C56@SOIC8 [(SA602A)]	
XLS93C66	
XLS93C66@SOIC8 [(SA602A)]	
XLS93CS46	
XLS93CS46@SOIC8 [(SA602A)]	XLS93CS46@TSSOP8
[(SA026)]	
XLS93LC06	XLS93LC06@SOIC8
[(SA602A)]	
XLS93LC66	XLS93LC66@SOIC8
[(SA602A)]	

## PLD

XLE78C800P-25	XLE78C800P-
35	
XLE78C800P-45	XLE78C800S-
25	
XLE78C800S-35	XLE78C800S-
45	
XLM78C800S-35	XLM78C800S-
45	
XLS78C800P-25	XLS78C800P-

35

XLS78C800P-45

25

XLS78C800S-35

45

XLS78C800S-

XLS78C800S-

## FAIRCHILD

### E ( E ) PROM / FRAM / NVRAM

FM24C02 ( M8 ) @SOIC8 [ ( SA602A ) ]  
[ ( SA026 ) ]

FM24C02 ( N )

[ ( SA602A ) ]

FM24C03 ( MT8 ) @TSSOP8 [ ( SA026 ) ]  
( N )

FM24C04 ( M8 ) @SOIC8 [ ( SA602A ) ]  
[ ( SA026 ) ]

FM24C04 ( N )

[ ( SA602A ) ]

FM24C05 ( MT8 ) @TSSOP8 [ ( SA026 ) ]  
( N )

FM24C08 ( M8 ) @SOIC8 [ ( SA602A ) ]  
[ ( SA026 ) ]

FM24C08 ( N )

[ ( SA602A ) ]

FM24C09 ( MT8 ) @TSSOP8 [ ( SA026 ) ]  
( N )

FM24C128 ( MT8 ) @TSSOP8 [ ( SA026 ) ]  
[ ( SA602A ) ]

FM24C128 ( N )

[ ( SA602A ) ]

FM24C16 ( MT8 ) @TSSOP8 [ ( SA026 ) ]  
( N )

FM24C17 ( M8 ) @SOIC8 [ ( SA602A ) ]  
[ ( SA026 ) ]

FM24C17 ( N )

[ ( SA602A ) ]

FM24C256 ( N )

[ ( SA602A ) ]

FM24C32 ( N )

FM27C010

FM24C02 ( MT8 ) @TSSOP8

FM24C03 ( M8 ) @SOIC8

FM24C03

FM24C04 ( MT8 ) @TSSOP8

FM24C05 ( M8 ) @SOIC8

FM24C05

FM24C08 ( MT8 ) @TSSOP8

FM24C09 ( M8 ) @SOIC8

FM24C09

FM24C128 ( MW8 ) @SOIC8

FM24C16 ( M8 ) @SOIC8

FM24C16

FM24C17 ( MT8 ) @TSSOP8

FM24C256 ( M8 ) @SOIC8

FM24C32 ( M8 ) @SOIC8

FM27C010@PLCC32 [(SA015A1T)]	FM27C010@TSOP32
[(SA410T)]	
FM27C040	FM27C040@PLCC32
[(SA015A1T)]	
FM27C040@TSOP32 [(SA410T)]	
FM27C256	
FM27C256@PLCC32 [(SA015A1T)]	
FM27C256Q	
FM27C256Q@PLCC32 [(SA015A1T)]	
FM27C512	
FM27C512@PLCC32 [(SA015A1T)]	
FM93C06(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C06(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C06(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C06(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C06(N)(08bit)	FM93C06(N)
(16bit)	
FM93C14(16bit)	FM93C46(M8)@SOIC8
[(SA602A)]	
FM93C46(MT8)@TSSOP8 [(SA026)]	FM93C46
(N)	
FM93C46A(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C46A(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C46A(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C46A(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C46A(N)(08bit)	FM93C46A(N)
(16bit)	
FM93C56(M8)@SOIC8 [(SA602A)]	FM93C56(MT8)@TSSOP8
[(SA026)]	
FM93C56(N)	
FM93C56A(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C56A(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C56A(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C56A(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C56A(N)(08bit)	FM93C56A(N)
(16bit)	
FM93C66(M8)@SOIC8 [(SA602A)]	FM93C66(MT8)@TSSOP8
[(SA026)]	
FM93C66(N)	
FM93C66A(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C66A(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C66A(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C66A(MT8)(16bit)@TSSOP8 [(SA026)]	



FM93C66A(N)(08bit) (16bit)	FM93C66A(N)
FM93C76(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C76(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C76(N)(16bit)	
FM93C76A(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C76A(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C76A(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C76A(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C76A(N)(08bit) (16bit)	FM93C76A(N)
FM93C86(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C86(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C86(N)(16bit)	
FM93C86A(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C86A(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C86A(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C86A(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C86A(N)(08bit) (16bit)	FM93C86A(N)
FM93CS06(M8)@SOIC8 [(SA602A)] [(SA026)]	FM93CS06(MT8)@TSSOP8
FM93CS06(N) [(SA602A)]	FM93CS46(M8)@SOIC8
FM93CS46(MT8)@TSSOP8 [(SA026)] (N)	FM93CS46
FM93CS56(M8)@SOIC8 [(SA602A)] [(SA026)]	FM93CS56(MT8)@TSSOP8
FM93CS56(N) [(SA602A)]	FM93CS66(M8)@SOIC8
FM93CS66(MT8)@TSSOP8 [(SA026)] (N)	FM93CS66
FM93S46(M8)@SOIC8 [(SA602A)] [(SA026)]	FM93S46(MT8)@TSSOP8
FM93S46(N) [(SA602A)]	FM93S56(M8)@SOIC8
FM93S56(MT8)@TSSOP8 [(SA026)] (N)	FM93S56
FM93S66(M8)@SOIC8 [(SA602A)] [(SA026)]	FM93S66(MT8)@TSSOP8
FM93S66(N)	
MM2716	
MM2716E	NM24C02(M8)@SOIC8

[ ( SA602A ) ]	
NM24C02 ( MT8 ) @ TSSOP8 [ ( SA026 ) ]	NM24C02
( N )	
NM24C02L ( M8 ) @ SOIC8 [ ( SA602A ) ]	NM24C02L ( MT8 ) @ TSSOP8
[ ( SA026 ) ]	
NM24C02L ( N )	NM24C03 ( M8 ) @ SOIC8
[ ( SA602A ) ]	
NM24C03 ( MT8 ) @ TSSOP8 [ ( SA026 ) ]	NM24C03
( N )	
NM24C04 ( M8 ) @ SOIC8 [ ( SA602A ) ]	NM24C04 ( MT8 ) @ TSSOP8
[ ( SA026 ) ]	
NM24C04 ( N )	NM24C05 ( M8 ) @ SOIC8
[ ( SA602A ) ]	
NM24C05 ( MT8 ) @ TSSOP8 [ ( SA026 ) ]	NM24C05
( N )	
NM24C08 ( M8 ) @ SOIC8 [ ( SA602A ) ]	NM24C08 ( MT8 ) @ TSSOP8
[ ( SA026 ) ]	
NM24C08 ( N )	NM24C09 ( M8 ) @ SOIC8
[ ( SA602A ) ]	
NM24C09 ( MT8 ) @ TSSOP8 [ ( SA026 ) ]	NM24C09
( N )	
NM24C16 ( M8 ) @ SOIC8 [ ( SA602A ) ]	NM24C16 ( MT8 ) @ TSSOP8
[ ( SA026 ) ]	
NM24C16 ( N )	NM24C17 ( M8 ) @ SOIC8
[ ( SA602A ) ]	
NM24C17 ( MT8 ) @ TSSOP8 [ ( SA026 ) ]	NM24C17
( N )	
NM24C65 ( M8 ) SOIC8 [ ( SA602A ) ]	NM24C65
( N )	
NM27C010	NM27C010 @ PLCC32
[ ( SA015A1T ) ]	
NM27C010 @ TSOP32 [ ( SA410T ) ]	
NM27C020	
NM27C020 @ PLCC32 [ ( SA015A1T ) ]	NM27C020 @ TSOP32
[ ( SA410T ) ]	
NM27C020Q	NM27C020Q @ PLCC32
[ ( SA015A1T ) ]	
NM27C020Q @ TSOP32 [ ( SA410T ) ]	
NM27C040	
NM27C040 @ PLCC32 [ ( SA015A1T ) ]	NM27C040 @ TSOP32
[ ( SA410T ) ]	
NM27C128	NM27C128 @ PLCC32
[ ( SA015A1T ) ]	

NM27C210 [ (SA244) ]	NM27C210@PLCC44
NM27C240 [ (SA244) ]	NM27C240@PLCC44
NM27C256 [ (SA015A1T) ]	NM27C256@PLCC32
NM27C512 [ (SA015A1T) ]	NM27C512@PLCC32
NM27C64Q [ (SA015A1T) ]	NM27C64Q@PLCC32
NM27LC256 [ (SA015A1T) ]	NM27LC256@PLCC32
NM27LC512 [ (SA015A1T) ]	NM27LC512@PLCC32
NM27LV010 [ (SA015A1T) ]	NM27LV010@PLCC32
NM27LV010@TSOP32 [ (SA410T) ]	
NM27LV210 NM27LV210@PLCC44 [ (SA244) ]	
NM27LV512 NM27LV512@PLCC32 [ (SA015A1T) ]	
NM27P040 NM27P040@PLCC32 [ (SA015A1T) ]	NM27P040@TSOP32
[ (SA410T) ]	
NM27P210 [ (SA244) ]	NM27P210@PLCC44
NM27P512 [ (SA015A1T) ]	NM27P512@PLCC32
NM93C66(M8)(16bit)@SOIC8 [ (SA602A) ]	
NM93C66(MT8)(16bit)@TSSOP8 [ (SA026) ]	
NM93C66(N)(16bit) [ (SA602A) ]	NM93CS06(M8)@SOIC8
NM93CS06(MT8)@TSSOP8 [ (SA026) ] (N)	NM93CS06
NM93CS46(M8)@SOIC8 [ (SA602A) ] [ (SA026) ]	NM93CS46(MT8)@TSSOP8
NM93CS46(N) [ (SA602A) ]	NM93CS56(M8)@SOIC8
NM93CS56(MT8)@TSSOP8 [ (SA026) ] (N)	NM93CS56
NM93CS66(M8)@SOIC8 [ (SA602A) ] [ (SA026) ]	NM93CS66(MT8)@TSSOP8
NM93CS66(N)	

NMC2732	
NMC27C010	NMC27C010@PLCC32
[ (SA015A1T) ]	
NMC27C010@TSOP32 [ (SA410T) ]	
NMC27C1024	
NMC27C1024@PLCC44 [ (SA244) ]	
NMC27C128B	
NMC27C128B@PLCC32 [ (SA015A1T) ]	
NMC27C128BN	
NMC27C128BN@PLCC32 [ (SA015A1T) ]	
NMC27C128BQ	
NMC27C128BQ@PLCC32 [ (SA015A1T) ]	
NMC27C128CQ	
NMC27C16	
NMC27C16BQ	
NMC27C16BQE	
NMC27C16H	
NMC27C16HQ	
NMC27C16Q	
NMC27C256	NMC27C256@PLCC32
[ (SA015A1T) ]	
NMC27C256B	NMC27C256B@PLCC32
[ (SA015A1T) ]	
NMC27C256Q	NMC27C256Q@PLCC32
[ (SA015A1T) ]	
NMC27C32	
NMC27C32B	
NMC27C32BQ	
NMC27C32E	
NMC27C32EH	
NMC27C32H	
NMC27C512	NMC27C512@PLCC32
[ (SA015A1T) ]	
NMC27C512A	NMC27C512A@PLCC32
[ (SA015A1T) ]	
NMC27C512AN	NMC27C512AN@PLCC32
[ (SA015A1T) ]	
NMC27C64	NMC27C64
(BN)	
NMC27C64(N)	
NMC27CP128	
NMC87C257Q	NMC87C257Q@PLCC32
[ (SA015A1T) ]	

NMC87C257V	NMC87C257V@PLCC32
[ (SA015A1T) ]	
NMC9346(M8)(16bit)@SOIC8 [ (SA602A) ]	
NMC9346(MT8)(16bit)@TSSOP8 [ (SA026) ]	
NMC9346(N)(16bit)	
NMC93C46(M8)(16bit)@SOIC8 [ (SA602A) ]	
NMC93C46(MT8)(16bit)@TSSOP8 [ (SA026) ]	
NMC93C46(N)(16bit)	
NMC93C46A(M8)(16bit)@SOIC8 [ (SA602A) ]	
NMC93C46A(MT8)(16bit)@TSSOP8 [ (SA026) ]	
NMC93C46A(N)(16bit)	
NMC93C56(M8)(16bit)@SOIC8 [ (SA602A) ]	
NMC93C56(MT8)(16bit)@TSSOP8 [ (SA026) ]	
NMC93C56(N)(16bit)	
NMC93C66(M8)(16bit)@SOIC8 [ (SA602A) ]	
NMC93C66(MT8)(16bit)@TSSOP8 [ (SA026) ]	
NMC93C66(N)(16bit)	NMC93CS06(M8)@SOIC8
[ (SA602A) ]	
NMC93CS06(MT8)@TSSOP8 [ (SA026) ]	NMC93CS06
(N)	
NMC93CS46(M8)@SOIC8 [ (SA602A) ]	NMC93CS46(MT8)@TSSOP8
[ (SA026) ]	
NMC93CS46(N)	NMC93CS56(M8)@SOIC8
[ (SA602A) ]	
NMC93CS56(MT8)@TSSOP8 [ (SA026) ]	NMC93CS56
(N)	
NMC93CS66(M8)@SOIC8 [ (SA602A) ]	NMC93CS66(MT8)@TSSOP8
[ (SA026) ]	
NMC93CS66(N)	
NMC9817	

## DRAM & SRAM

F1600	F1600@SOJ24
[ (SA646) ]	
F1601	F1601@SOJ24
[ (SA646) ]	
F1620	
F1621	

## MICROCONTROLLER

ACE1001(M8)@SOIC8 [(SA602A)] [(SA602A)]	ACE1001(M8X)@SOIC8
ACE1001(MT8)@TSSOP8 [(SA026)] [(SA026)]	ACE1001(MT8X)@TSSOP8
ACE1001E(M8)@SOIC8 [(SA602A)] [(SA602A)]	ACE1001E(M8X)@SOIC8
ACE1001E(MT8)@TSSOP8 [(SA026)] [(SA026)]	ACE1001E(MT8X)@TSSOP8
ACE1001L(M8)@SOIC8 [(SA602A)] [(SA602A)]	ACE1001L(M8X)@SOIC8
ACE1001L(MT8)@TSSOP8 [(SA026)] [(SA026)]	ACE1001L(MT8X)@TSSOP8
ACE1101(EMT8)@TSSOP8 [(SA026)] [(SA026)]	ACE1101(EMT8X)@TSSOP8
ACE1101(EN) (EN14)	ACE1101
ACE1101(LMT8)@TSSOP8 [(SA026)] [(SA026)]	ACE1101(LMT8X)@TSSOP8
ACE1101(LN) (LN14)	ACE1101
ACE1101(MT8)@TSSOP8 [(SA026)] [(SA026)]	ACE1101(MT8X)@TSSOP8
ACE1101(N) (N14)	ACE1101
ACE1101(VMT8)@TSSOP8 [(SA026)] [(SA026)]	ACE1101(VMT8X)@TSSOP8
ACE1101(VN) (VN14)	ACE1101
ACE1101B(EMT8)@TSSOP8 [(SA026)] [(SA026)]	ACE1101B(EMT8X)@TSSOP8
ACE1101B(EN) (EN14)	ACE1101B
ACE1101B(MT8)@TSSOP8 [(SA026)] [(SA026)]	ACE1101B(MT8X)@TSSOP8
ACE1101B(N) (N14)	ACE1101B
ACE1101B(VMT8)@TSSOP8 [(SA026)] [(SA026)]	ACE1101B(VMT8X)@TSSOP8
ACE1101B(VN) (VN14)	ACE1101B
ACE1202(dip14) (dip8)	ACE1202

ACE1202(M14)@SOIC14 [(SA602)]	ACE1202(M8)@SOIC8
[(SA602A)]	
ACE12022(dip14)	ACE12022
(dip8)	
ACE12022(M14)@SOIC14 [(SA602)]	ACE12022(M8)@SOIC8
[(SA602A)]	
ACE12022B(dip14)	ACE12022B
(dip8)	
ACE12022B(M14)@SOIC14 [(SA602)]	ACE12022B(M8)@SOIC8
[(SA602A)]	
ACE12022BE(dip14)	ACE12022BE
(dip8)	
ACE12022BE(M14)@SOIC14 [(SA602)]	ACE12022BE(M8)@SOIC8
[(SA602A)]	
ACE12022BV(dip14)	ACE12022BV
(dip8)	
ACE12022BV(M14)@SOIC14 [(SA602)]	ACE12022BV(M8)@SOIC8
[(SA602A)]	
ACE12022E(dip14)	ACE12022E
(dip8)	
ACE12022E(M14)@SOIC14 [(SA602)]	ACE12022E(M8)@SOIC8
[(SA602A)]	
ACE1202B(dip14)	ACE1202B
(dip8)	
ACE1202B(M14)@SOIC14 [(SA602)]	ACE1202B(M8)@SOIC8
[(SA602A)]	
ACE1202BE(dip14)	ACE1202BE
(dip8)	
ACE1202BE(M14)@SOIC14 [(SA602)]	ACE1202BE(M8)@SOIC8
[(SA602A)]	
ACE1202BV(dip14)	ACE1202BV
(dip8)	
ACE1202BV(M14)@SOIC14 [(SA602)]	ACE1202BV(M8)@SOIC8
[(SA602A)]	
ACE1202E(dip14)	ACE1202E
(dip8)	
ACE1202E(M14)@SOIC14 [(SA602)]	ACE1202E(M8)@SOIC8
[(SA602A)]	
ACE1202L(dip14)	ACE1202L
(dip8)	
ACE1202L(M14)@SOIC14 [(SA602)]	ACE1202L(M8)@SOIC8
[(SA602A)]	
ACE1202V(dip8)	ACE1202V(M14)@SOIC14

[ (SA602) ]	
ACE1202V(M8)@SOIC8 [ (SA602A) ]	ACE1501(EM)@SOIC14
[ (SA602) ]	
ACE1501(EM8)@SOIC8 [ (SA602A) ]	ACE1501(EM8X)@SOIC8
[ (SA602A) ]	
ACE1501(EMT)@TSOP14 [ (SA026) ]	ACE1501(EMT8)@TSSOP8
[ (SA026) ]	
ACE1501(EMT8X)@TSSOP8 [ (SA026) ]	ACE1501(EMTX)@TSOP14
[ (SA026) ]	
ACE1501(EMX)@SOIC14 [ (SA602) ]	ACE1501
(EN)	
ACE1501(EN14)	ACE1501(VM)@SOIC14
[ (SA602) ]	
ACE1501(VM8)@SOIC8 [ (SA602A) ]	ACE1501(VM8X)@SOIC8
[ (SA602A) ]	
ACE1501(VMT)@TSOP14 [ (SA026) ]	ACE1501(VMT8)@TSSOP8
[ (SA026) ]	
ACE1501(VMT8X)@TSSOP8 [ (SA026) ]	ACE1501(VMTX)@TSOP14
[ (SA026) ]	
ACE1501(VMX)@SOIC14 [ (SA602) ]	ACE1501
(VN)	
ACE1501(VN14)	ACE1502(EM)@SOIC14
[ (SA602) ]	
ACE1502(EM8)@SOIC8 [ (SA602A) ]	ACE1502(EMT)@TSOP14
[ (SA026) ]	
ACE1502(EMT8)@TSSOP8 [ (SA026) ]	ACE1502
(EN)	
ACE1502(EN14)	ACE1502(VM)@SOIC14
[ (SA602) ]	
ACE1502(VM8)@SOIC8 [ (SA602A) ]	ACE1502(VMT)@TSOP14
[ (SA026) ]	
ACE1502(VMT8)@TSSOP8 [ (SA026) ]	ACE1502
(VN)	
ACE1502(VN14)	ACE8000(M8)@SOIC8
[ (SA602A) ]	
ACE8000(M8X)@SOIC8 [ (SA602A) ]	ACE8000E(M8)@SOIC8
[ (SA602A) ]	
ACE8000E(M8X)@SOIC8 [ (SA602A) ]	ACE8001(M8)@SOIC8
[ (SA602A) ]	
ACE8001(M8X)@SOIC8 [ (SA602A) ]	ACE8001(MT8)@TSSOP8
[ (SA026) ]	
ACE8001(MT8X)@TSSOP8 [ (SA026) ]	ACE8001E(M8)@SOIC8
[ (SA602A) ]	



ACE8001E(M8X)@SOIC8 [(SA602A)] [(SA026)]	ACE8001E(MT8)@TSSOP8
ACE8001E(MT8X)@TSSOP8 [(SA026)] [(SA602A)]	FMS7401L(EM8X)@SOIC8
FMS7401L(EMT8X)@TSSOP8 [(SA026)] [(SA026)]	FMS7401L(EMTX)@TSSOP14
FMS7401L(EMX)@SOIC14 [(SA602)] (EN)	FMS7401L
FMS7401L(EN14) (VN)	FMS7401L
FMS7401L(VN14)	

## FORCE TECHNOLOGIES

### E(E) PROM/FRAM/NVRAM

FT24C01 [(SA602A)]	FT24C01@SOIC8
FT24C01@TSOP8 [(SA026)]	
FT24C01A	
FT24C01A@SOIC8 [(SA602A)] [(SA026)]	FT24C01A@TSOP8
FT24C02 [(SA602A)]	FT24C02@SOP8
FT24C02@TSSOP8 [(SA026)]	
FT24C02A	
FT24C02A@SOP8 [(SA602A)] [(SA026)]	FT24C02A@TSSOP8
FT24C04 [(SA602A)]	FT24C04@SOP8
FT24C04@TSSOP8 [(SA026)]	
FT24C04A	
FT24C04A@SOP8 [(SA602A)] [(SA026)]	FT24C04A@TSSOP8
FT24C08 [(SA602A)]	FT24C08@SOIC8
FT24C08@TSOP8 [(SA026)]	
FT24C08A	
FT24C08A@SOIC8 [(SA602A)] [(SA026)]	FT24C08A@TSOP8
FT24C128 [(SA602A)]	FT24C128@SOIC8

FT24C128@TSOP8 [(SA026)]	
FT24C128A	
FT24C128A@SOIC8 [(SA602A)]	FT24C128A@TSOP8
[(SA026)]	
FT24C16	FT24C16@SOIC8
[(SA602A)]	
FT24C16@TSOP8 [(SA026)]	
FT24C16A	
FT24C16A@SOIC8 [(SA602A)]	FT24C16A@TSOP8
[(SA026)]	
FT24C256	FT24C256@SOIC8
[(SA602A)]	
FT24C256@TSOP8 [(SA026)]	
FT24C256A	
FT24C256A@SOIC8 [(SA602A)]	FT24C256A@TSOP8
[(SA026)]	
FT24C32	FT24C32@SOIC8
[(SA602A)]	
FT24C32@TSOP8 [(SA026)]	
FT24C32A	
FT24C32A@SOIC8 [(SA602A)]	FT24C32A@TSOP8
[(SA026)]	
FT24C64	FT24C64@SOIC8
[(SA602A)]	
FT24C64@TSOP8 [(SA026)]	
FT24C64A	
FT24C64A@SOIC8 [(SA602A)]	FT24C64A@TSOP8
[(SA026)]	
FT27C010	FT27C010@PLCC32
[(SA015A1T)]	
FT27C010@TSOP32 [(SA410T)]	
FT27C020	
FT27C020@PLCC32 [(SA015A1T)]	FT27C020@TSOP32
[(SA410T)]	
FT27C040	FT27C040@PLCC32
[(SA015A1T)]	
FT27C040@TSOP32 [(SA410T)]	
FT27C16	
FT27C256	FT27C256@PLCC32
[(SA015A1T)]	
FT27C64	FT27C64@PLCC32
[(SA015A1T)]	
FT27HC256	FT27HC256@PLCC32

[ (SA015A1T) ]	
FT27HC64	FT27HC64@PLCC32
[ (SA015A1T) ]	
FT28C010	FT28C010@JLCC32
[ (SA412A) ]	
FT28C010@PLCC32 [ (SA015A1T) ]	FT28C010@PLCC44
[ (SA244) ]	
FT28C010@TSOP32 [ (SA410T) ]	
FT28C010E	
FT28C010E@JLCC32 [ (SA412A) ]	FT28C010E@PLCC32
[ (SA015A1T) ]	
FT28C010E@PLCC44 [ (SA244) ]	FT28C010E@TSOP32
[ (SA410T) ]	
FT28C020	FT28C020@JLCC32
[ (SA412A) ]	
FT28C020@PLCC32 [ (SA015A1T) ]	FT28C020@PLCC44
[ (SA244) ]	
FT28C020@TSOP32 [ (SA410T) ]	
FT28C040	
FT28C040@JLCC32 [ (SA412A) ]	FT28C040@PLCC32
[ (SA015A1T) ]	
FT28C040@PLCC44 [ (SA244) ]	FT28C040@TSOP32
[ (SA410T) ]	
FT28C16	FT28C16@PLCC32
[ (SA015A1T) ]	
FT28C256	FT28C256@JLCC32
[ (SA412A) ]	
FT28C256@PLCC32 [ (SA015A1T) ]	FT28C256@SOIC28
[ (SA404) ]	
FT28C256@TSOP28 [ (SA430T) ]	
FT28C256B	
FT28C256B@JLCC32 [ (SA412A) ]	FT28C256B@PLCC32
[ (SA015A1T) ]	
FT28C256B@SOIC28 [ (SA404) ]	FT28C256B@TSOP28
[ (SA430T) ]	
FT28C64	FT28C64@PLCC32
[ (SA015A1T) ]	
FT28C64@SOIC28 [ (SA404) ]	FT28C64@TSOP28
[ (SA430T) ]	
FT28C64B	FT28C64B@JLCC32
[ (SA412A) ]	
FT28C64B@PLCC32 [ (SA015A1T) ]	FT28C64B@SOIC28
[ (SA404) ]	

FT28C64B@TSOP28 [ (SA430T) ]	
FT28C64X	
FT28C64X@PLCC32 [ (SA015A1T) ]	FT28C64X@SOIC28
[ (SA404) ]	
FT28C64X@TSOP28 [ (SA430T) ]	
FT28HC64	
FT28HC64@PLCC32 [ (SA015A1T) ]	FT28HC64@TSOP28
[ (SA430T) ]	
FT58C1001	
[ (SA438T) ]	FT58C1001@SSOP32
FT58C1001@VSOP32 [ (SA620) ]	

## FORWARD

### **E (E) PROM / FRAM / NVRAM**

24LC01	24LC01@SOIC8
[ (SA602A) ]	
24LC02	24LC02@SOIC8
[ (SA602A) ]	
24LC04	24LC04@SOIC8
[ (SA602A) ]	
24LC08	24LC08@SOIC8
[ (SA602A) ]	
24LC16	24LC16@SOIC8
[ (SA602A) ]	
24LC32	24LC32@SOIC8
[ (SA602A) ]	
24LC64	24LC64@SOIC8
[ (SA602A) ]	

## FREESCALE

### **MICROCONTROLLER**

MC56F8011VF AE@QFP32 [ (SA663+B005) ]
MC56F8013VF AE@QFP32 [ (SA663+B005) ]
MC56F8014VF AE@QFP32 [ (SA663+B005) ]
MC56F8023MF AE@QFP32 [ (SA663+B005) ]
MC56F8023VF AE@QFP32 [ (SA663+B005) ]

MC56F8025VLD@QFP44 [(SA245A+B005)]  
MC56F8036MFAE@QFP48 [(SA248+B005)]  
MC56F8036VFAE@QFP48 [(SA248+B005)]  
MC56F8037VLH@QFP64 [(PEP+S616)]  
MC68HC908AP16CB(S)@SDIP42 [(SA028)]  
MC68HC908AP16CB@SDIP42 [(SA028)]  
MC68HC908AP16CFA(S)@LQFP48 [(SA248)]  
MC68HC908AP16CFA@LQFP48 [(SA248)]  
MC68HC908AP16CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP16CFB@TQFP44 [(SA675)]  
MC68HC908AP32CB(S)@SDIP42 [(SA028)]  
MC68HC908AP32CB@SDIP42 [(SA028)]  
MC68HC908AP32CFA(S)@LQFP48 [(SA248)]  
MC68HC908AP32CFA@LQFP48 [(SA248)]  
MC68HC908AP32CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP32CFB@TQFP44 [(SA675)]  
MC68HC908AP64CB@SDIP42 [(SA028)]  
MC68HC908AP64CFA@LQFP48 [(SA248)]  
MC68HC908AP64CFB@TQFP44 [(SA675)]  
MC68HC908AP8CB(S)@SDIP42 [(SA028)]  
MC68HC908AP8CB@SDIP42 [(SA028)]  
MC68HC908AP8CFA(S)@LQFP48 [(SA248)]  
MC68HC908AP8CFA@LQFP48 [(SA248)]  
MC68HC908AP8CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP8CFB@TQFP44 [(SA675)]  
MC68HC908EY16CFA@TQFP32 [(SA663)]  
MC68HC908EY16MFA@TQFP32 [(SA663)]  
MC68HC908EY16VFA@TQFP32 [(SA663)]  
MC68HC908EY8CFA@TQFP32 [(SA663)] MC68HC908EY8MFA@TQFP32  
[(SA663)]  
MC68HC908EY8VFA@TQFP32 [(SA663)]  
MC68HC908GP32  
MC68HC908GP32@SDIP42 [(SA028)] MC68HC908GP32@TQFP44  
[(SA675)]  
MC68HC908GR16CFA@TQFP48 [(SA248)]  
MC68HC908GR16CFJ@TQFP32 [(SA663)]  
MC68HC908GR16MFA@TQFP48 [(SA248)]  
MC68HC908GR16MFJ@TQFP32 [(SA663)]  
MC68HC908GR16VFA@TQFP48 [(SA248)]  
MC68HC908GR16VFJ@TQFP32 [(SA663)]  
MC68HC908GR4CDW@SOIC28 [(SA404)] MC68HC908GR4CFA@TQFP32  
[(SA663)]  
MC68HC908GR4CP MC68HC908GR4MDW@SOIC28

[ ( SA404 ) ]  
MC68HC908GR4MFA@TQFP32 [ ( SA663 ) ]  
MC68HC908GR4MP  
MC68HC908GR4VDW@SOIC28 [ ( SA404 ) ] MC68HC908GR4VFA@TQFP32  
[ ( SA663 ) ]  
MC68HC908GR4VP MC68HC908GR8CDW@SOIC28  
[ ( SA404 ) ]  
MC68HC908GR8CFA@TQFP32 [ ( SA663 ) ]  
MC68HC908GR8CP  
MC68HC908GR8MDW@SOIC28 [ ( SA404 ) ] MC68HC908GR8MFA@TQFP32  
[ ( SA663 ) ]  
MC68HC908GR8MP MC68HC908GR8VDW@SOIC28  
[ ( SA404 ) ]  
MC68HC908GR8VFA@TQFP32 [ ( SA663 ) ]  
MC68HC908GR8VP  
MC68HC908JK1CDW@SOIC20 [ ( SA404 ) ]  
MC68HC908JK1CP  
MC68HC908JK1ECDW@SOIC20 [ ( SA404 ) ]  
MC68HC908JK1ECP  
MC68HC908JK1EMDW@SOIC20 [ ( SA404 ) ]  
MC68HC908JK1EMP MC68HC908JK1MDW@SOIC20  
[ ( SA404 ) ]  
MC68HC908JK1MP MC68HC908JK3CDW@SOIC20  
[ ( SA404 ) ]  
MC68HC908JK3CP  
MC68HC908JK3ECDW@SOIC20 [ ( SA404 ) ]  
MC68HC908JK3ECP  
MC68HC908JK3EMDW@SOIC20 [ ( SA404 ) ]  
MC68HC908JK3EMP MC68HC908JK3MDW@SOIC20  
[ ( SA404 ) ]  
MC68HC908JK3MP MC68HC908JL3CDW@SOIC28  
[ ( SA404 ) ]  
MC68HC908JL3CFA@TQFP48 [ ( SA248 ) ]  
MC68HC908JL3CP  
MC68HC908JL3ECDW@SOIC28 [ ( SA404 ) ]  
MC68HC908JL3ECFA@TQFP48 [ ( SA248 ) ]  
MC68HC908JL3ECP  
MC68HC908JL3EMDW@SOIC28 [ ( SA404 ) ]  
MC68HC908JL3EMFA@TQFP48 [ ( SA248 ) ]  
MC68HC908JL3EMP MC68HC908JL3MDW@SOIC28  
[ ( SA404 ) ]  
MC68HC908JL3MFA@TQFP48 [ ( SA248 ) ]  
MC68HC908JL3MP

MC68HC908LB8CDWE ( S )@SOIC20 ( S )	MC68HC908LB8CPE
MC68HC908LB8MDWE ( S )@SOIC20 ( S )	MC68HC908LB8MPE
MC68HC908LB8VDWE ( S )@SOIC20 ( S )	MC68HC908LB8VPE
MC68HC908QT1ACFQE@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT1AMFQE@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT1AVFQE@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT1CDW@SOIC8 [ ( SA605A ) ]	
MC68HC908QT1CFQ@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT1CP [ ( SA605A ) ]	MC68HC908QT1MDW@SOIC8
MC68HC908QT1MFQ@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT1MP [ ( SA605A ) ]	MC68HC908QT1VDW@SOIC8
MC68HC908QT1VFQ@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT1VP	
MC68HC908QT2ACFQE@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT2AMFQE@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT2AVFQE@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT2CDW@SOIC8 [ ( SA605A ) ]	
MC68HC908QT2CFQ@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT2CP [ ( SA605A ) ]	MC68HC908QT2MDW@SOIC8
MC68HC908QT2MFQ@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT2MP [ ( SA605A ) ]	MC68HC908QT2VDW@SOIC8
MC68HC908QT2VFQ@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT2VP	
MC68HC908QT4ACFQE@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT4AMFQE@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT4AVFQE@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT4CDW@SOIC8 [ ( SA605A ) ]	
MC68HC908QT4CFQ@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT4CP [ ( SA605A ) ]	MC68HC908QT4MDW@SOIC8
MC68HC908QT4MFQ@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT4MP [ ( SA605A ) ]	MC68HC908QT4VDW@SOIC8
MC68HC908QT4VFQ@DFN8 [ ( SA744-B006 ) ]	
MC68HC908QT4VP	
MC68HC908QY1CDT@TSSOP16 [ ( SA026 ) ]	

MC68HC908QY1CDW@SOIC16 [ (SA404) ]  
MC68HC908QY1CP  
MC68HC908QY1MDT@TSSOP16 [ (SA026) ]  
MC68HC908QY1MDW@SOIC16 [ (SA404) ]  
MC68HC908QY1MP  
MC68HC908QY1VDT@TSSOP16 [ (SA026) ]  
MC68HC908QY1VDW@SOIC16 [ (SA404) ]  
MC68HC908QY1VP  
MC68HC908QY2CDT@TSSOP16 [ (SA026) ]  
MC68HC908QY2CDW@SOIC16 [ (SA404) ]  
MC68HC908QY2CP  
MC68HC908QY2MDT@TSSOP16 [ (SA026) ]  
MC68HC908QY2MDW@SOIC16 [ (SA404) ]  
MC68HC908QY2MP  
MC68HC908QY2VDT@TSSOP16 [ (SA026) ]  
MC68HC908QY2VDW@SOIC16 [ (SA404) ]  
MC68HC908QY2VP  
MC68HC908QY4CDT@TSSOP16 [ (SA026) ]  
MC68HC908QY4CDW@SOIC16 [ (SA404) ]  
MC68HC908QY4CP  
MC68HC908QY4MDT@TSSOP16 [ (SA026) ]  
MC68HC908QY4MDW@SOIC16 [ (SA404) ]  
MC68HC908QY4MP  
MC68HC908QY4VDT@TSSOP16 [ (SA026) ]  
MC68HC908QY4VDW@SOIC16 [ (SA404) ]  
MC68HC908QY4VP  
MC68HRC908JK1CDW@SOIC20 [ (SA404) ]  
MC68HRC908JK1CP  
MC68HRC908JK1ECDW@SOIC20 [ (SA404) ]  
MC68HRC908JK1ECP  
MC68HRC908JK1EMDW@SOIC20 [ (SA404) ]  
MC68HRC908JK1EMP  
MC68HRC908JK1MDW@SOIC20 [ (SA404) ]  
MC68HRC908JK1MP  
MC68HRC908JK3CDW@SOIC20 [ (SA404) ]  
MC68HRC908JK3CP  
MC68HRC908JK3ECDW@SOIC20 [ (SA404) ]  
MC68HRC908JK3ECP  
MC68HRC908JK3EMDW@SOIC20 [ (SA404) ]  
MC68HRC908JK3EMP  
MC68HRC908JK3MDW@SOIC20 [ (SA404) ]  
MC68HRC908JK3MP  
MC68HRC908JL3CDW@SOIC28 [ (SA404) ]



MC68HRC908JL3CFA@TQFP48 [(SA248)]	
MC68HRC908JL3CP	
MC68HRC908JL3ECDW@SOIC28 [(SA404)]	
MC68HRC908JL3ECFA@TQFP48 [(SA248)]	
MC68HRC908JL3ECP	
MC68HRC908JL3EMDW@SOIC28 [(SA404)]	
MC68HRC908JL3EMFA@TQFP48 [(SA248)]	
MC68HRC908JL3EMP	
MC68HRC908JL3MDW@SOIC28 [(SA404)]	
MC68HRC908JL3MFA@TQFP48 [(SA248)]	
MC68HRC908JL3MP	MC908AP16CBE@SDIP42
[(SA028)]	
MC908AP16CFAE@LQFP48 [(SA248)]	MC908AP16CFBE@TQFP44
[(SA675)]	
MC908AP32CBE@SDIP42 [(SA028)]	MC908AP32CFAE@LQFP48
[(SA248)]	
MC908AP32CFBE@TQFP44 [(SA675)]	MC908AP64CBE@SDIP42
[(SA028)]	
MC908AP64CFAE@LQFP48 [(SA248)]	MC908AP64CFBE@TQFP44
[(SA675)]	
MC908AP8CBE@SDIP42 [(SA028)]	MC908AP8CFAE@@LQFP48
[(SA248)]	
MC908AP8CFBE@TQFP44 [(SA675)]	MC908EY16ACFJE@TQFP32
[(SA663)]	
MC908EY16AKFJE@TQFP32 [(SA663)]	MC908EY16AMFJE@TQFP32
[(SA663)]	
MC908EY16AVFJE@TQFP32 [(SA663)]	MC908EY8ACFJE@TQFP32
[(SA663)]	
MC908EY8AKFJE@TQFP32 [(SA663)]	MC908EY8AMFJE@TQFP32
[(SA663)]	
MC908EY8AVFJE@TQFP32 [(SA663)]	MC908JL16CDWE@SOIC28
[(SA404)]	
MC908JL16CFJE@LQFP32 [(SA663)]	
MC908JL16CPE	
MC908JL16CSPE@SDIP32 [(SA653)]	MC908QT1ACDWE@SOIC8
[(SA605A)]	
MC908QT1ACPE	MC908QT1AMDWE@SOIC8
[(SA605A)]	
MC908QT1AMPE	MC908QT1AVDWE@SOIC8
[(SA605A)]	
MC908QT1AVPE	MC908QT2ACDWE@SOIC8
[(SA605A)]	
MC908QT2ACPE	MC908QT2AMDWE@SOIC8

[ ( SA605A ) ]	
MC908QT2AMPE	MC908QT2AVDWE@SOIC8
[ ( SA605A ) ]	
MC908QT2AVPE	MC908QT4ACDWE@SOIC8
[ ( SA605A ) ]	
MC908QT4ACPE	MC908QT4AMDWE@SOIC8
[ ( SA605A ) ]	
MC908QT4AMPE	MC908QT4AVDWE@SOIC8
[ ( SA605A ) ]	
MC908QT4AVPE	MC908QY1ACDTE@TSSOP16
[ ( SA026 ) ]	
MC908QY1ACDWE@SOIC16 [ ( SA404 ) ]	
MC908QY1ACPE	
MC908QY1AMDTE@TSSOP16 [ ( SA026 ) ]	MC908QY1AMDWE@SOIC16
[ ( SA404 ) ]	
MC908QY1AMPE	MC908QY1AVDTE@TSSOP16
[ ( SA026 ) ]	
MC908QY1AVDWE@SOIC16 [ ( SA404 ) ]	
MC908QY1AVPE	
MC908QY2ACDTE@TSSOP16 [ ( SA026 ) ]	MC908QY2ACDWE@SOIC16
[ ( SA404 ) ]	
MC908QY2ACPE	MC908QY2AMDTE@TSSOP16
[ ( SA026 ) ]	
MC908QY2AMDWE@SOIC16 [ ( SA404 ) ]	
MC908QY2AMPE	
MC908QY2AVDTE@TSSOP16 [ ( SA026 ) ]	MC908QY2AVDWE@SOIC16
[ ( SA404 ) ]	
MC908QY2AVPE	MC908QY4ACDTE@TSSOP16
[ ( SA026 ) ]	
MC908QY4ACDWE@SOIC16 [ ( SA404 ) ]	
MC908QY4ACPE	
MC908QY4AMDTE@TSSOP16 [ ( SA026 ) ]	MC908QY4AMDWE@SOIC16
[ ( SA404 ) ]	
MC908QY4AMPE	MC908QY4AVDTE@TSSOP16
[ ( SA026 ) ]	
MC908QY4AVDWE@SOIC16 [ ( SA404 ) ]	
MC908QY4AVPE	
MC9S08GT16ACB@SDIP42 [ ( SA028-B167 ) ]	
MC9S08GT16ACFB@LQFP44 [ ( SA675-B168 ) ]	
MC9S08GT16ACFD@QFN48 [ ( SA696-B166 ) ]	
MC9S08GT16AMB@SDIP42 [ ( SA028-B167 ) ]	
MC9S08GT16AMFB@LQFP44 [ ( SA675-B168 ) ]	
MC9S08GT16AMFD@QFN48 [ ( SA696-B166 ) ]	

MC9S08GT16CB@SDIP42 [ (SA028-B167) ]  
MC9S08GT16CBE@SDIP42 [ (SA028-B167) ]  
MC9S08GT16CFB@LQFP44 [ (SA675-B168) ]  
MC9S08GT16CFBE@LQFP44 [ (SA675-B168) ]  
MC9S08GT16CFD@QFN48 [ (SA696-B166) ]  
MC9S08GT16CFDE@QFN48 [ (SA696-B166) ]  
MC9S08GT32ACFB@LQFP44 [ (SA675-B168) ]  
MC9S08GT32ACFBE@LQFP44 [ (SA675-B168) ]  
MC9S08GT32ACFD@QFN48 [ (SA696-B166) ]  
MC9S08GT32ACFDE@QFN48 [ (SA696-B166) ]  
MC9S08GT32CB@SDIP42 [ (SA028-B167) ]  
MC9S08GT32CBE@SDIP42 [ (SA028-B167) ]  
MC9S08GT32CFB@LQFP44 [ (SA675-B168) ]  
MC9S08GT32CFBE@LQFP44 [ (SA675-B168) ]  
MC9S08GT32CFD@QFN48 [ (SA696-B166) ]  
MC9S08GT32CFDE@QFN48 [ (SA696-B166) ]  
MC9S08GT8ACB@SDIP42 [ (SA028-B167) ]  
MC9S08GT8ACFB@LQFP44 [ (SA675-B168) ]  
MC9S08GT8ACFD@QFN48 [ (SA696-B166) ]  
MC9S08GT8AMB@SDIP42 [ (SA028-B167) ]  
MC9S08GT8AMFB@LQFP44 [ (SA675-B168) ]  
MC9S08GT8AMFD@QFN48 [ (SA696-B166) ]  
PC56F8011VF AE@QFP32 [ (SA663+B005) ]  
PC56F8013VF AE@QFP32 [ (SA663+B005) ]  
PC56F8014VF AE@QFP32 [ (SA663+B005) ]

## Fremont Micro Devices

### E ( E ) PROM / FRAM / NVRAM

FT24C02 [ (SA602A) ]	FT24C02@SOP8
FT24C02@TSSOP8 [ (SA026) ]	
FT24C02A FT24C02A@SOP8 [ (SA602A) ] [ (SA026) ]	FT24C02A@TSSOP8
FT24C04 [ (SA602A) ]	FT24C04@SOP8
FT24C04@TSSOP8 [ (SA026) ]	
FT24C04A FT24C04A@SOP8 [ (SA602A) ] [ (SA026) ]	FT24C04A@TSSOP8

FT24C08	FT24C08@SOP8
[ (SA602A) ]	
FT24C08@TSSOP8 [ (SA026) ]	
FT24C08A	
FT24C08A@SOP8 [ (SA602A) ]	FT24C08A@TSSOP8
[ (SA026) ]	
FT24C1024	FT24C1024@SOP8
[ (SA023A) ]	
FT24C1024@TSSOP8 [ (SA026) ]	
FT24C1024A	
FT24C1024A@SOP8 [ (SA023A) ]	FT24C1024A@TSSOP8
[ (SA026) ]	
FT24C128	FT24C128@SOP8
[ (SA602A) ]	
FT24C128@TSSOP8 [ (SA026) ]	
FT24C128A	
FT24C128A@SOP8 [ (SA602A) ]	FT24C128A@TSSOP8
[ (SA026) ]	
FT24C16	FT24C16@SOP8
[ (SA602A) ]	
FT24C16@TSSOP8 [ (SA026) ]	
FT24C16A	
FT24C16A@SOP8 [ (SA602A) ]	FT24C16A@TSSOP8
[ (SA026) ]	
FT24C256	FT24C256@SOP8
[ (SA602A) ]	
FT24C256@TSSOP8 [ (SA026) ]	
FT24C256A	
FT24C256A@SOP8 [ (SA602A) ]	FT24C256A@TSSOP8
[ (SA026) ]	
FT24C32	FT24C32@SOP8
[ (SA602A) ]	
FT24C32@TSSOP8 [ (SA026) ]	
FT24C32A	
FT24C32A@SOP8 [ (SA602A) ]	FT24C32A@TSSOP8
[ (SA026) ]	
FT24C512	FT24C512@SOP8
[ (SA602A) ]	
FT24C512@TSSOP8 [ (SA026) ]	
FT24C512A	
FT24C512A@SOP8 [ (SA602A) ]	FT24C512A@TSSOP8
[ (SA026) ]	
FT24C64	FT24C64@SOP8

[ (SA602A) ]	
FT24C64@TSSOP8 [ (SA026) ]	
FT24C64A	
FT24C64A@SOP8 [ (SA602A) ]	FT24C64A@TSSOP8
[ (SA026) ]	
FT34C02	
[ (SA602A) ]	
FT34C02@TSSOP8 [ (SA026) ]	FT34C02@SOP8
FT34C02A	
FT34C02A@SOP8 [ (SA602A) ]	FT34C02A@TSSOP8
[ (SA026) ]	
FT93C46(08bit)	
[ (SA602A) ]	
FT93C46(08bit)@TSSOP8 [ (SA026) ]	FT93C46(08bit)@SOP8
(16bit)	
FT93C46(16bit)@SOP8 [ (SA602A) ]	FT93C46
[ (SA026) ]	
FT93C46A(08bit)	
[ (SA602A) ]	
FT93C46A(08bit)@TSSOP8 [ (SA026) ]	FT93C46A(08bit)@SOP8
(16bit)	
FT93C46A(16bit)@SOP8 [ (SA602A) ]	FT93C46A
[ (SA026) ]	
FT93C46A(16bit)@TSSOP8	
[ (SA026) ]	
FT93C56(08bit)	
[ (SA602A) ]	
FT93C56(08bit)@TSSOP8 [ (SA026) ]	FT93C56(08bit)@SOP8
(16bit)	
FT93C56(16bit)@SOP8 [ (SA602A) ]	FT93C56
[ (SA026) ]	
FT93C56(16bit)@TSSOP8	
[ (SA026) ]	
FT93C56A(08bit)	
[ (SA602A) ]	
FT93C56A(08bit)@TSSOP8 [ (SA026) ]	FT93C56A(08bit)@SOP8
(16bit)	
FT93C56A(16bit)@SOP8 [ (SA602A) ]	FT93C56A
[ (SA026) ]	
FT93C56A(16bit)@TSSOP8	
[ (SA026) ]	
FT93C66(08bit)	
[ (SA602A) ]	
FT93C66(08bit)@TSSOP8 [ (SA026) ]	FT93C66(08bit)@SOP8
(16bit)	
FT93C66(16bit)@SOP8 [ (SA602A) ]	FT93C66
[ (SA026) ]	
FT93C66(16bit)@TSSOP8	
[ (SA026) ]	
FT93C66A(08bit)	
[ (SA602A) ]	
FT93C66A(08bit)@SOP8	

FT93C66A(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C66A
FT93C66A(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C66A(16bit)@TSSOP8
FT93C86(08bit) [(SA602A)]	FT93C86(08bit)@SOP8
FT93C86(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C86
FT93C86(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C86(16bit)@TSSOP8
FT93C86A(08bit) [(SA602A)]	FT93C86A(08bit)@SOP8
FT93C86A(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C86A
FT93C86A(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C86A(16bit)@TSSOP8

## FUJITSU

### E(E) PROM/FRAM/NVRAM

MB84VD21081@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21081EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21082@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21082EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21083@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21083EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21084@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21084EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21091@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21091EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21092@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21092EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21093@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21093EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21094@FBGA61 [(SA642C-B032A-Y056F001)]  
MB84VD21094EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21181DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21181EG@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21181EM@FBGA56 [(SA642C-B032A-Y056F001)]  
MB84VD21182DA@FBGA69 [(SA642C-B032A-Y056F001)]  
MB84VD21182EG@FBGA56 [(SA642C-B032A-Y056F001)]

MB84VD21182EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21183DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21183EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21183EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21184DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21184EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21184EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21191DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21191EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21191EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21192DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21192EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21192EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD22180FA@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22180FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22181A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22181EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22181EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22181FM@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22182A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22182EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22182EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22183A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22183EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22183EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22184EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184FM@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22190FA@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22190FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22191A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22191EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22191EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22191FM@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22192A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22192EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]

MB84VD22192EE@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22193A@FBGA77 [ (SA642A-B032A-Y096N001) ]  
MB84VD22193EC@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22193EE@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22194A@FBGA77 [ (SA642A-B032A-Y096N001) ]  
MB84VD22194EC@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22194EE@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD22194FM@FBGA56 [ (SA642E-B032A-T072F001) ]  
MB84VD22280FE@FBGA59 [ (SA642F-B032A-T064F001) ]  
MB84VD22282EE@FBGA71 [ (SA642E-B032A-T072F001) ]  
MB84VD22283EE@FBGA71 [ (SA642E-B032A-T072F001) ]  
MB84VD22284EE@FBGA71 [ (SA642E-B032A-T072F001) ]  
MB84VD22290FM@FBGA59 [ (SA642F-B032A-T064F001) ]  
MB84VD22292EE@FBGA71 [ (SA642E-B032A-T072F001) ]  
MB84VD22293EE@FBGA71 [ (SA642E-B032A-T072F001) ]  
MB84VD22294EE@FBGA71 [ (SA642E-B032A-T072F001) ]  
MB84VD22386EJ@FBGA71 [ (SA642F-B032A-T064F001) ]  
MB84VD22387EJ@FBGA71 [ (SA642F-B032A-T064F001) ]  
MB84VD22388EJ@FBGA71 [ (SA642F-B032A-T064F001) ]  
MB84VD22396EJ@FBGA71 [ (SA642F-B032A-T064F001) ]  
MB84VD22397EJ@FBGA71 [ (SA642F-B032A-T064F001) ]  
MB84VD22398EJ@FBGA71 [ (SA642F-B032A-T064F001) ]  
MB84VD23180FM@FBGA73 [ (SA642A-B032A-Y096F001) ]  
MB84VD23280EA@FBGA101 [ (SA642A-B032A-Y096N001) ]  
MB84VD23280EE@FBGA101 [ (SA642A-B032A-Y096N001) ]  
MB84VD23280FA@FBGA65 [ (SA642A-B032A-Y096N001) ]  
MB84VD23381EJ@FBGA101 [ (SA642A-B032A-Y096N001) ]  
MB84VD23381FJ@FBGA65 [ (SA642A-B032A-Y096N001) ]  
MB84VD23381HJ@FBGA56 [ (SA642F-B032A-T064F001) ]  
MB84VD23481FJ@FBGA65 [ (SA642A-B032A-Y096N001) ]  
MB84VF5F5FF4J2@BGA107 [ (SA642D-B062A-Y088F001) ]  
MB84VP23481FK@FBGA65 [ (SA642JJ-B032A-W064F001Y) ]  
MB84VP24481HK@FBGA73 [ (SA642A-B039A-Y096F001) ]  
MB84VP24491HK@FBGA73 [ (SA642A-B039A-Y096F001) ]  
MB85R256@SOP28 [ (SA630) ] MB85R256@TSOP28  
[ (SA430T) ]  
MB85R256A@SOP28 [ (SA630) ] MB85R256A@TSOP28  
[ (SA430T) ]  
MBM271001 MBM271001@PLCC32  
[ (SA015A1T) ]  
MBM271001@TSOP32 [ (SA410T) ]  
MBM27128  
MBM27128@PLCC32 [ (SA015A1T) ]



MBM2716  
MBM2716H  
MBM27256  
MBM27256@PLCC32 [(SA015A1T)]  
MBM2732  
MBM2732A  
MBM2764  
MBM2764@PLCC32 [(SA015A1T)]  
MBM27C1000  
MBM27C1000@PLCC32 [(SA015A1T)] MBM27C1000@TSOP32  
[(SA410T)]  
MBM27C1001 MBM27C1001@PLCC32  
[(SA015A1T)]  
MBM27C1001@TSOP32 [(SA410T)]  
MBM27C1024  
MBM27C1024@PLCC44 [(SA244)]  
MBM27C1028  
MBM27C1028@PLCC32 [(SA015A1T)]  
MBM27C128  
MBM27C128@PLCC32 [(SA015A1T)]  
MBM27C128P  
MBM27C128P@PLCC32 [(SA015A1T)]  
MBM27C2000  
MBM27C2000@PLCC32 [(SA015A1T)] MBM27C2000@TSOP32  
[(SA410T)]  
MBM27C2001 MBM27C2001@PLCC32  
[(SA015A1T)]  
MBM27C2001@TSOP32 [(SA410T)]  
MBM27C2048  
MBM27C256 MBM27C256@PLCC32  
[(SA015A1T)]  
MBM27C256A MBM27C256A@PLCC32  
[(SA015A1T)]  
MBM27C256AP MBM27C256AP@PLCC32  
[(SA015A1T)]  
MBM27C256H MBM27C256H@PLCC32  
[(SA015A1T)]  
MBM27C32A  
MBM27C4001  
MBM27C4001@PLCC32 [(SA015A1T)] MBM27C4001@TSOP32  
[(SA410T)]  
MBM27C4096  
MBM27C512

MBM27C512@PLCC32 [(SA015A1T)]  
MBM27C512P  
MBM27C512P@PLCC32 [(SA015A1T)]  
MBM27C64  
MBM27C64@PLCC32 [(SA015A1T)]  
MBM28C64  
MBM28C65  
MBM28F010  
MBM28F010@PLCC32 [(SA015A1T)] MBM28F010@TSOP32  
[(SA410T)]  
MBM29DL161BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL161BD@TSOP48 [(SA247-B005)]  
MBM29DL161BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL161TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL161TD@TSOP48 [(SA247-B005)]  
MBM29DL161TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162BD@TSOP48 [(SA247-B005)]  
MBM29DL162BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162BE@TSOP48 [(SA247-B005)]  
MBM29DL162TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162TD@TSOP48 [(SA247-B005)]  
MBM29DL162TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL162TE@TSOP48 [(SA247-B005)]  
MBM29DL163BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL163BD@TSOP48 [(SA247-B005)]  
MBM29DL163BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL163BE@TSOP48 [(SA247-B005)]  
MBM29DL163TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL163TD@TSOP48 [(SA247-B005)]  
MBM29DL163TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL163TE@TSOP48 [(SA247-B005)]  
MBM29DL164BD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL164BD@TSOP48 [(SA247-B005)]  
MBM29DL164BE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL164BE@TSOP48 [(SA247-B005)]  
MBM29DL164TD@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL164TD@TSOP48 [(SA247-B005)]  
MBM29DL164TE@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL164TE@TSOP48 [(SA247-B005)]  
MBM29DL320BF@FBGA48 [(SA642B-B026A-Y072F001)]  
MBM29DL320BF@TSOP48 [(SA247-B005)]  
MBM29DL320TF@FBGA48 [(SA642B-B026A-Y072F001)]

MBM29DL320TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL321BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL321TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL321TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL322BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL322TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL323BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL323TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL324BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL324BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL324TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL324TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL32BF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL32BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL32TF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL32TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL34BF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL34BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL34TF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL34TF@TSOP48 [ ( SA247-B005 ) ]

MBM29DL400BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL400BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL400BC@PSOP44 [ ( SA638 ) ]  
MBM29DL400BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL400BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400TC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL400TC@PSOP44 [ ( SA638 ) ]  
MBM29DL400TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL640E@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
MBM29DL640E@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL64DF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
MBM29DL64DF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800B@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL800B@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800BA@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL800BA@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL800BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL800BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800T@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL800T@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800TA@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL800TA@TSOP48 [ ( SA247-B005 ) ]  
MBM29DS163BE@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
MBM29DS163BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DS163TE@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
MBM29DS163TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29F001B MBM29F001B@PLCC32  
[ ( SA015A1T ) ]  
MBM29F001B@TSOP32 [ ( SA410T ) ]  
MBM29F001T MBM29F001T@TSOP32  
MBM29F001T@PLCC32 [ ( SA015A1T ) ]  
[ ( SA410T ) ]  
MBM29F002B MBM29F002B@PLCC32  
[ ( SA015A1T ) ]  
MBM29F002B@TSOP32 [ ( SA410T ) ]  
MBM29F002NB MBM29F002NB@TSOP32  
MBM29F002NB@PLCC32 [ ( SA015A1T ) ]  
[ ( SA410T ) ]  
MBM29F002NT MBM29F002NT@PLCC32

[ (SA015A1T) ]	
MBM29F002NT@TSOP32 [ (SA410T) ]	
MBM29F002T	
MBM29F002T@PLCC32 [ (SA015A1T) ]	MBM29F002T@TSOP32
[ (SA410T) ]	
MBM29F010	MBM29F010@PLCC32
[ (SA015A1T) ]	
MBM29F010@TSOP32 [ (SA410T) ]	
MBM29F010A	
MBM29F010A@PLCC32 [ (SA015A1T) ]	MBM29F010A@TSOP32
[ (SA410T) ]	
MBM29F016@PSOP44 [ (SA638) ]	MBM29F016@TSOP40
[ (SA409T) ]	
MBM29F016@TSOP48 [ (SA247-B005) ]	MBM29F016A@PSOP44
[ (SA638) ]	
MBM29F016A@TSOP40 [ (SA409T) ]	MBM29F016A@TSOP48 [ (SA247-B005) ]
B005) ]	
MBM29F016B@PSOP44 [ (SA638) ]	MBM29F016B@TSOP40
[ (SA409T) ]	
MBM29F016B@TSOP48 [ (SA247-B005) ]	MBM29F017B@TSOP48 [ (SA247-B005) ]
B005) ]	
MBM29F017D@TSOP40 [ (SA409T) ]	MBM29F017D@TSOP48 [ (SA247-B005) ]
B005) ]	
MBM29F032B@PSOP44 [ (SA638) ]	MBM29F032B@TSOP40
[ (SA409T) ]	
MBM29F033C@TSOP40 [ (SA409T) ]	
MBM29F040	
MBM29F040@PLCC32 [ (SA015A1T) ]	MBM29F040@TSOP32
[ (SA410T) ]	
MBM29F040B	MBM29F040B@PLCC32
[ (SA015A1T) ]	
MBM29F040B@TSOP32 [ (SA410T) ]	MBM29F040C@PLCC32
[ (SA015A1T) ]	
MBM29F040C@TSOP32 [ (SA410T) ]	MBM29F080@PSOP44
[ (SA638) ]	
MBM29F080@TSOP40 [ (SA409T) ]	MBM29F080A@TSOP48 [ (SA247-B005) ]
B005) ]	
MBM29F080B@PSOP44 [ (SA638) ]	MBM29F080B@TSOP40
[ (SA409T) ]	
MBM29F100B@PSOP44 [ (SA638-B006) ]	MBM29F100B@TSOP48 [ (SA247-B005) ]
B005) ]	
MBM29F100T@PSOP44 [ (SA638-B006) ]	MBM29F100T@TSOP48 [ (SA247-B005) ]
B005) ]	

MBM29F160BE@TSOP48 [ ( SA247-B005 ) ]	
MBM29F160TE@TSOP48 [ ( SA247-B005 ) ]	
MBM29F200AB@PSOP44 [ ( SA638-B006 ) ]	
MBM29F200AB@TSOP48 [ ( SA247-B005 ) ]	
MBM29F200AT@PSOP44 [ ( SA638-B006 ) ]	
MBM29F200AT@TSOP48 [ ( SA247-B005 ) ]	
MBM29F200B@PSOP44 [ ( SA638-B006 ) ]	MBM29F200B@TSOP48 [ ( SA247-B005 ) ]
MBM29F200T@PSOP44 [ ( SA638-B006 ) ]	MBM29F200T@TSOP48 [ ( SA247-B005 ) ]
MBM29F400AB@PSOP44 [ ( SA638-B006 ) ]	
MBM29F400AB@TSOP48 [ ( SA247-B005 ) ]	
MBM29F400AT@PSOP44 [ ( SA638-B006 ) ]	
MBM29F400AT@TSOP48 [ ( SA247-B005 ) ]	
MBM29F400B@PSOP44 [ ( SA638-B006 ) ]	MBM29F400B@TSOP48 [ ( SA247-B005 ) ]
MBM29F400BB@PSOP44 [ ( SA638-B006 ) ]	
MBM29F400BB@TSOP48 [ ( SA247-B005 ) ]	
MBM29F400BT@PSOP44 [ ( SA638-B006 ) ]	
MBM29F400BT@TSOP48 [ ( SA247-B005 ) ]	
MBM29F400T@PSOP44 [ ( SA638-B006 ) ]	MBM29F400T@TSOP48 [ ( SA247-B005 ) ]
MBM29F800B@PSOP44 [ ( SA638-B006 ) ]	MBM29F800B@TSOP48 [ ( SA247-B005 ) ]
MBM29F800BA@PSOP44 [ ( SA638-B006 ) ]	
MBM29F800BA@TSOP48 [ ( SA247-B005 ) ]	
MBM29F800BB@PSOP44 [ ( SA638-B006 ) ]	
MBM29F800BB@TSOP48 [ ( SA247-B005 ) ]	
MBM29F800BT@PSOP44 [ ( SA638-B006 ) ]	
MBM29F800BT@TSOP48 [ ( SA247-B005 ) ]	
MBM29F800T@PSOP44 [ ( SA638-B006 ) ]	MBM29F800T@TSOP48 [ ( SA247-B005 ) ]
MBM29F800TA@PSOP44 [ ( SA638-B006 ) ]	
MBM29F800TA@TSOP48 [ ( SA247-B005 ) ]	
MBM29LL800B@TSOP48 [ ( SA247-B005 ) ]	
MBM29LL800BB@TSOP48 [ ( SA247-B005 ) ]	
MBM29LL800BT@TSOP48 [ ( SA247-B005 ) ]	
MBM29LL800T@TSOP48 [ ( SA247-B005 ) ]	
MBM29LV001B@PLCC32 [ ( SA015A1T ) ]	MBM29LV001BB@PLCC32 [ ( SA015A1T ) ]
MBM29LV001BB@TSOP32 [ ( SA410T ) ]	MBM29LV001BC@PLCC32 [ ( SA015A1T ) ]
MBM29LV001BC@TSOP32 [ ( SA410T ) ]	MBM29LV001BT@PLCC32 [ ( SA410T ) ]

[ ( SA015A1T ) ]  
MBM29LV001BT@TSOP32 [ ( SA410T ) ] MBM29LV001T@TSOP32  
[ ( SA410T ) ]  
MBM29LV001TC@PLCC32 [ ( SA015A1T ) ] MBM29LV001TC@TSOP32  
[ ( SA410T ) ]  
MBM29LV002B@TSOP40 [ ( SA409T ) ] MBM29LV002T@TSOP40  
[ ( SA409T ) ]  
MBM29LV004B@PSOP44 [ ( SA638 ) ] MBM29LV004B@TSOP40  
[ ( SA409T ) ]  
MBM29LV004BB@TSOP40 [ ( SA409T ) ] MBM29LV004BT@TSOP40  
[ ( SA409T ) ]  
MBM29LV004T@PSOP44 [ ( SA638 ) ] MBM29LV004T@TSOP40  
[ ( SA409T ) ]  
MBM29LV008B@PSOP44 [ ( SA638 ) ] MBM29LV008B@TSOP40  
[ ( SA409T ) ]  
MBM29LV008BB@TSOP40 [ ( SA409T ) ] MBM29LV008BT@TSOP40  
[ ( SA409T ) ]  
MBM29LV008T@PSOP44 [ ( SA638 ) ] MBM29LV008T@TSOP40  
[ ( SA409T ) ]  
MBM29LV016/B@TSOP40 [ ( SA409T ) ] MBM29LV016/T@TSOP40  
[ ( SA409T ) ]  
MBM29LV016B@TSOP40 [ ( SA409T ) ]  
MBM29LV017@FBGA48 [ ( SA6420-B026A-T064F001 ) ]  
MBM29LV017@TSOP40 [ ( SA409T ) ] MBM29LV017B@TSOP40  
[ ( SA409T ) ]  
MBM29LV017E@TSOP40 [ ( SA409T ) ] MBM29LV033C@TSOP40  
[ ( SA409T ) ]  
MBM29LV080@TSOP40 [ ( SA409T ) ] MBM29LV081@TSOP40  
[ ( SA409T ) ]  
MBM29LV081B@TSOP40 [ ( SA409T ) ] MBM29LV116B@TSOP40  
[ ( SA409T ) ]  
MBM29LV160B@SON46 [ ( SA631 ) ] MBM29LV160B@SON46  
( \* )  
MBM29LV160BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV160BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV160BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV160BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV160BM@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV160BM@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV160BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV160BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV160T@SON46 [ ( SA631 ) ] MBM29LV160T@SON46  
( \* )

MBM29LV160TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV160TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV160TM@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV160TM@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200B@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV200B@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV200BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200BC@PSOP44 [ ( SA638 ) ]  
MBM29LV200BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV200BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV200T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200TC@PSOP44 [ ( SA638 ) ]  
MBM29LV200TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV320BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV320BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV320TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV320TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400B@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400B@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29LV400BC@PSOP44 [ ( SA638 ) ]  
MBM29LV400BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400TC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29LV400TC@PSOP44 [ ( SA638 ) ]  
MBM29LV400TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV650UE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV651UE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV652UE@FGBA63 [ ( SA642C-B026A-Y056F001 ) ]  
MBM29LV800B@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800B@SON46 [ ( SA631 ) ] MBM29LV800B@SON46  
( \* )  
MBM29LV800B@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BA@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800BA@PSOP44 [ ( SA638 ) ]



MBM29LV800BA@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800BE@PSOP44 [ ( SA638 ) ]  
MBM29LV800BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800T@SON46 [ ( SA631 ) ] MBM29LV800T@SON46  
( \* )  
MBM29LV800T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800TA@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800TA@PSOP44 [ ( SA638 ) ]  
MBM29LV800TA@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800TE@PSOP44 [ ( SA638 ) ]  
MBM29LV800TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29PDS323B@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29PDS323T@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29PL12LM@TSOP56 [ ( SA628-B102 ) ]  
MBM29PL160BD@PSOP44 [ ( SA638 ) ]  
MBM29PL160BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL160TD@PSOP44 [ ( SA638 ) ]  
MBM29PL160TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL32BM@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
MBM29PL32BM@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL32TM@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
MBM29PL32TM@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL64LM@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL64LM@TSOP56 [ ( SA628-B067 ) ]  
MBM29QM12DH@FBGA88 [ ( SA642J-B101A-W080F001 ) ]  
MBM29QM12DH@TSOP56 [ ( SA628-B097 ) ]  
MBM29SL160BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29SL160BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29SL160TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29SL160TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29SL800BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29SL800BT@TSOP48 [ ( SA247-B005 ) ]

## DRAM & SRAM

MB81C78A  
[ (SA630) ]

MB81C78A@SOIC28

## MICROCONTROLLER

MB89F202@SDIP32 [ (SA653) ]  
[ (SA689) ]  
MB89F202RA@QFP32 [ (SA663) ]  
[ (SA653) ]  
MB89F202RA@SSOP34 [ (SA689) ]  
[ (SA245A) ]  
MB89F482AS@SDIP42 [ (SA028) ]  
[ (SA245A) ]  
MB89F482AW@SDIP42 [ (SA028) ]  
[ (SA245A) ]  
MB89F482HS@SDIP42 [ (SA028) ]  
[ (SA245A) ]  
MB89F482HW@SDIP42 [ (SA028) ]  
MB89P195  
MB89P195(F)@SOIC28 [ (SA630) ]  
MB89P195AP  
MB89P195AP(F)@SOIC28 [ (SA630) ]  
MB89P195P  
MB89P195P(F)@SOIC28 [ (SA630) ]

MB89F202@SSOP34  
MB89F202RA@SDIP32  
MB89F482AS@LQFP44  
MB89F482AW@LQFP44  
MB89F482HS@LQFP44  
MB89F482HW@LQFP44

## GENCORE

### MICROCONTROLLER

GC87C520A0  
[ (SA244) ]  
GC87C520A0@TQFP44 [ (SA245A) ]  
GC87C520G0  
GC87C520G0@PLCC44 [ (SA244) ]  
[ (SA245A) ]

GC87C520A0@PLCC44  
GC87C520G0@TQFP44

## GENERAL(GI)

### E(E) PROM/FRAM/NVRAM

27256  
27C128  
27C128@PLCC32 [ (SA015A1T) ]  
27C256  
27C256@PLCC32 [ (SA015A1T) ]  
27C512  
27C513  
27C64  
27C64@PLCC32 [ (SA015A1T) ]  
27HC191  
27HC291  
27HC64  
27HC641  
27HC641L  
27HC64L  
28C04  
28C04A  
28C04F  
28C16  
28C16A  
28C16F  
28C17  
28C17F  
ER5911  
ER5911@SOIC8 [ (SA602A) ]  
GI5911  
GI5911@SOIC8 [ (SA602A) ]  
GI59C11  
GI59C11@SOIC8 [ (SA602A) ]  
GI59C12  
GI59C12@SOIC8 [ (SA602A) ]  
GR27C513

## GENERIC

### E (E) PROM / FRAM / NVRAM

27128 (21V) (12.5V)	27128A
2716 (25V) (12.5V)	27256

2732 ( 25V ) ( 21V )	2732A
2732B ( 12.5V ) ( 12.5V )	27512
27512 ( 21V ) ( 21V )	2764
2764A ( 12.5V ) ( 12.5V )	27C128
27C128 ( 21V ) ( 25V )	27C16
27C256 ( 12.5V ) ( 25V )	27C32
27C512 ( 12.5V ) ( 12.5V )	27C64
27C64 ( 21V )	

## GIGADEVICE

### E ( E ) PROM / FRAM / NVRAM

GD25D40 HEADER01 ]	GD25D40 ( ISP ) [ ISP-
GD25D40@SOP8 [ ( SA605A ) ] HEADER01 ]	GD25D40@SOP8 ( ISP ) [ ISP-
GD25D80 HEADER01 ]	GD25D80 ( ISP ) [ ISP-
GD25D80@SOP8 [ ( SA605A ) ] HEADER01 ]	GD25D80@SOP8 ( ISP ) [ ISP-
GD25F40 HEADER01 ]	GD25F40 ( ISP ) [ ISP-
GD25F40@SOP8 [ ( SA605A ) ] HEADER01 ]	GD25F40@SOP8 ( ISP ) [ ISP-
GD25F80 HEADER01 ]	GD25F80 ( ISP ) [ ISP-
GD25F80@SOP8 [ ( SA605A ) ] HEADER01 ]	GD25F80@SOP8 ( ISP ) [ ISP-
GD25T80 HEADER01 ]	GD25T80 ( ISP ) [ ISP-
GD25T80@SOP8 [ ( SA605A ) ] HEADER01 ]	GD25T80@SOP8 ( ISP ) [ ISP-

## GOAL

### MICROCONTROLLER

VRS1000 [ ( SA244 ) ]	VRS1000@PLCC44
VRS1000@TQFP44 [ ( SA245A ) ]	
VRS1050 VRS1050@PLCC44 [ ( SA244 ) ]	VRS1050@TQFP44
[ ( SA675 ) ]	
VRS1100 [ ( SA244 ) ]	VRS1100@PLCC44
VRS1100@TQFP44 [ ( SA245A ) ]	
VRS540 VRS540@PLCC44 [ ( SA244 ) ]	VRS540@TQFP44
[ ( SA245A ) ]	
VRS550 [ ( SA244 ) ]	VRS550@PLCC44
VRS550@TQFP44 [ ( SA245A ) ]	
VRS560 VRS560@PLCC44 [ ( SA244 ) ]	VRS560@TQFP44
[ ( SA245A ) ]	
VRS570 [ ( SA244 ) ]	VRS570@PLCC44
VRS570@TQFP44 [ ( SA245A ) ]	
VRS580 VRS580@PLCC44 [ ( SA244 ) ]	VRS580@TQFP44
[ ( SA245A ) ]	
VRS700 [ ( SA244 ) ]	VRS700@PLCC44
VRS700@TQFP44 [ ( SA245A ) ]	
VRS900 VRS900@PLCC44 [ ( SA244 ) ]	VRS900@TQFP44
[ ( SA245A ) ]	

## GREENWICH

### E ( E ) PROM / FRAM / NVRAM

GR27128  
GR27256

GR27512

GR2764

## HAIER

### MICROCONTROLLER

HCM87CP311SP@SDIP42 [(SA028)]  
HR6P59P2DL  
HR6P59P2SL@SOP14 [(SA602)]  
HR6P60P2DL  
HR6P60P2DL-A  
HR6P60P2EL  
HR6P60P2EL-A  
HR6P60P2SL@SOP20  
[(SA404)]  
HR6P60P2SL@SSOP20 [(SA626A)]  
[(SA404)]  
HR6P60P2SL-A@SSOP20 [(SA626A)]  
[(SA404)]  
HR6P60P2XL-A@SOP18 [(SA404)]  
[(SA404)]  
HR6P60P2YL@SOP14  
HR6P60P2P4D  
HR6P62P4DH  
HR6P62P4DHL  
HR6P62P4DHL(INTOSC)  
D  
HR6P62P4DHL-D(INTOSC)  
HR6P62P4NHL(INTOSC)@SSOP20 [(SA626A)]  
HR6P62P4NHL@SSOP20 [(SA626A)]  
HR6P62P4NHL-D(INTOSC)@SSOP20 [(SA626A)]  
HR6P62P4NHL-D@SSOP20 [(SA626A)]  
HR6P62P4RHL(INTOSC)@SSOP20 [(SA626A)]  
HR6P62P4RHL@SSOP20 [(SA626A)]  
HR6P62P4RHL-D(INTOSC)@SSOP20 [(SA626A)]  
HR6P62P4RHL-D@SSOP20 [(SA626A)]  
HR6P62P4SH@SOP20 [(SA404  
+B003)]  
HR6P62P4SHL(INTOSC)@SOP20 [(SA404)]  
HR6P62P4SHL@SOP20 [(SA404)]  
HR6P62P4SHL-D(INTOSC)@SOP20 [(SA404)]  
HR6P62P4SHL-D@SOP20 [(SA404)]  
HR6P62P4XHL(INTOSC)@SOP18 [(SA404)]

HR6P62P4XHL@SOP18 [(SA404)]	
HR6P62P4XHL-D(INTOSC)@SOP18 [(SA404)]	
HR6P62P4XHL-D@SOP18 [(SA404)]	HR6P62P4YHL@SOIC14
[(SA602)]	
HR6P62P4YHL-D@SOP14 [(SA602)]	
HR6P67P4D	
HR6P67P4DL	HR6P67P4DL-
B	
HR6P67P4SL@SOP14 [(SA404+B003)]	
HR6P67P4SL-B@SOP14 [(SA404+B003)]	
HR6P71F8D	HR6P71F8D
(REVERSE)	
HR6P71F8S(REVERSE)@SOP20 [(SA404)]	
HR6P71F8S@SOP20 [(SA404)]	
HR6P72P4D	
HR6P72P4DL	HR6P72P4S@SOP28
[(SA404)]	
HR6P72P4SL@SOP28 [(SA404+B003)]	
HR6P73P8DB	
HR6P73P8DBL	HR6P73P8SB@SOP28
[(SA404)]	
HR6P73P8SBL@SOP28 [(SA404-B003)]	
HR6P73PGD	
HR6P73PGDH	
HR6P73PGDHL	
HR6P73PGS@SOP28 [(SA404+B003)]	HR6P73PGSH@SOP28
[(SA404)]	
HR6P73PGSHL@SOP28 [(SA404-B003)]	
HR6P76PGD	
HR6P76PGDL	HR6P76PGS@SOP28
[(SA404)]	
HR6P76PGSL@SOP28 [(SA404-B003)]	
HR6P77PGD	
HR6P77PGDL	HR6P77PGL@LQFP44 [(SA245-
B005)]	
HR6P77PGLL@LQFP44 [(SA245-B005)]	HR6P78P4SL@SOP32 [(SA715
+B006)]	
HR6P90FGD	HR6P90FGS@SOP28
[(SA404)]	
HR6P90FHD	HR6P90FHS@SOP28
[(SA404)]	
HR6P91FGS@SOP32 [(SA715)]	HR6P91FHS@SOP32
[(SA715)]	

HR6P92FGD [ (SA245A) ]	HR6P92FGL@LQFP44
HR6P92FHD [ (SA245A) ]	HR6P92FHL@LQFP44
HR6P95F8D [ (SA404) ]	HR6P95F8S@SOP28
HR6P97FGD (EEPROM)	HR6P97FGD
HR6P97FGD(EEPROM)(ISP) [ISP-HEADER01]	
HR6P97FGD(ISP) [ISP-HEADER01]	
HR6P97FGS(EEPROM)@SOP28 [ (SA404) ]	
HR6P97FGS(EEPROM)@SOP28(ISP) [ISP-HEADER01]	
HR6P97FGS@SOP28 [ (SA404) ]	
HR6P97FGS@SOP28(ISP) [ISP-HEADER01]	
HR6P98FGD (EEPROM)	HR6P98FGD
HR6P98FGD(EEPROM)(ISP) [ISP-HEADER01]	
HR6P98FGD(ISP) [ISP-HEADER01]	
HR6P98FGL(EEPROM)@LQFP44 [ (SA245A) ]	
HR6P98FGL(EEPROM)@LQFP44(ISP) [ISP-HEADER01]	
HR6P98FGL@LQFP44 [ (SA245A) ]	
HR6P98FGL@LQFP44(ISP) [ISP-HEADER01]	
HR7T46P8V@SDIP42 [ (SA028) ] +B005) ]	HR7T46PGV@SDIP42 [ (SA028
HR7T47P8L@LQFP44 [ (SA245A) ] +B005) ]	HR7T47PGL@LQFP44 [ (SA245A

## HARRIS

### DRAM & SRAM

HM6516 [ (SA015A1T) ]	HM6516@PLCC32
HM65162 [ (SA015A1T) ]	HM65162@PLCC32
HM65642 [ (SA643) ]	HM65642@TSOP28

## HITACHI



## E ( E ) PROM / FRAM / NVRAM

HN27128AG  
HN27128AP  
HN27256G  
HN27256P  
HN27512G  
HN27512P  
HN27C101AG  
HN27C101AP  
HN27C101G  
HN27C101P  
HN27C1024HG  
HN27C1024HG@PLCC44  
[ ( SA244 ) ]  
HN27C256AG  
HN27C256FP  
HN27C256G  
HN27C256HG  
HN27C301AG  
HN27C301AP  
HN27C301G  
HN27C301P  
HN27C4000FP  
HN27C4000G  
HN27C4001  
HN27C4001@TSOP32  
[ ( SA410T ) ]  
HN27C4001G  
HN27C4096A  
HN27C4096A@PLCC44 [ ( SA244 ) ]  
HN27C4096FP  
HN27C4096FP@PLCC44 [ ( SA244 ) ]  
HN27C4096G  
HN27C4096G@PLCC44 [ ( SA244 ) ]  
HN27C512G  
HN27C512G@PLCC32 [ ( SA015A1T ) ]  
HN27C64G  
HN28F101  
HN28F101@PLCC32  
[ ( SA015A1T ) ]  
HN28F101@SOP32 [ ( SA438T ) ]  
HN28F101@TSOP32  
[ ( SA410T ) ]  
HN29A128A0A@CSP95 [ ( SA642A-B066A-Y096N001 ) ]  
HN29A128A0A@TSOP48 [ ( SA247-B005 ) ]  
HN29V128A0A@CSP95 [ ( SA642A-B066A-Y096N001 ) ]

HN29V128A0A@TSOP48 [ (SA247-B005) ]  
HN29V128A0E@CSP95 [ (SA642A-B066A-Y096N001) ]  
HN29V51211@TSOP48 [ (SA247-B005) ]  
HN462716G  
HN462732G  
HN48016  
HN48016P  
HN4827128G  
HN4827128P  
HN482732AG  
HN482764G  
HN482764P  
HN58064(FP)@SOIC28 [ (SA404) ]                      HN58064  
(P)  
HN58C1001(FP)@SSOP32 [ (SA438T) ]                      HN58C1001  
(P)  
HN58C1001(T)@VSOP32 [ (SA620) ]                      HN58C256A(FP)@SOP28  
[ (SA630) ]  
HN58C256A(P)    HN58C256A(T)@TSOP28  
[ (SA643) ]  
HN58C257A(T)@TSOP32 [ (SA620) ]                      HN58C65(FP)@SOIC28  
[ (SA404) ]  
HN58C65(P)  
HN58C66  
HN58C66@SOP28 [ (SA630) ]                              HN58C66@TSOP28  
[ (SA430T) ]  
HN58V24256    HN58V24256@SOIC8  
[ (SA602A) ]  
HN58V24256@TSSOP14 [ (SA026) ]  
HN58V24512  
HN58V24512@SOIC8 [ (SA602A) ]  
HN58V256A  
HN58V256A@TSOP28 [ (SA430T) ]  
HN58V65A  
HN58V65A@SOIC28 [ (SA630) ]                              HN58V65A@TSOP28  
[ (SA430T) ]  
HN58V66A    HN58V66A@SOIC28  
[ (SA630) ]  
HN58V66A@TSOP28 [ (SA430T) ]  
HN58W241000  
HN58W241000@SOIC8 [ (SA602A) ]  
HN58X2402  
HN58X2402@SOIC8 [ (SA602A) ]                              HN58X2402@TSSOP8

[ (SA026) ]	
HN58X2404	HN58X2404@SOIC8
[ (SA602A) ]	
HN58X2404@TSSOP8 [ (SA026) ]	
HN58X2408	
HN58X2408@SOIC8 [ (SA602A) ]	HN58X2408@TSSOP8
[ (SA026) ]	
HN58X24128	HN58X24128@SOIC8
[ (SA602A) ]	
HN58X2416	HN58X2416@SOIC8
[ (SA602A) ]	
HN58X2416@TSSOP8 [ (SA026) ]	
HN58X24256	
HN58X24256@SOIC8 [ (SA602A) ]	
HN58X2432	
HN58X2432@SOIC8 [ (SA602A) ]	HN58X2432@TSSOP8
[ (SA026) ]	
HN58X24512	HN58X24512@SOIC8
[ (SA602A) ]	
HN58X2464	HN58X2464@SOIC8
[ (SA602A) ]	
HN58X2464@TSSOP8 [ (SA026) ]	HN58X2502@SOIC8
[ (SA602A) ]	
HN58X2502@TSSOP8 [ (SA026) ]	HN58X2504@SOIC8
[ (SA602A) ]	
HN58X2504@TSSOP8 [ (SA026) ]	HN58X25128@SOIC8
[ (SA602A) ]	
HN58X25128@TSSOP14 [ (SA026) ]	HN58X25256@SOIC8
[ (SA602A) ]	
HN58X25256@TSSOP14 [ (SA026) ]	HN58X2532@SOIC8
[ (SA602A) ]	
HN58X2532@TSSOP8 [ (SA026) ]	HN58X2564@SOIC8
[ (SA602A) ]	
HN58X2564@TSSOP8 [ (SA026) ]	HT29VB800@TSOP48 [ (SA247-
B005) ]	
HT29VT800@TSOP48 [ (SA247-B005) ]	HT29WB800@TSOP48 [ (SA247-
B005) ]	
HT29WT800@TSOP48 [ (SA247-B005) ]	
V128128A0E@CSP95 [ (SA642A-B105A-Y096N001) ]	

## DRAM & SRAM

HM6116	HM6116@PLCC32
[ (SA015A1T) ]	
HM6116A	HM6116A@PLCC32
[ (SA015A1T) ]	
HM6208	HM6208@SOJ24
[ (SA646) ]	
HM6208H	HM6208H@SOJ24
[ (SA646) ]	
HM62256	HM62256@TSOP28
[ (SA643) ]	
HM62256B	HM62256B@TSOP28
[ (SA643) ]	
HM624256	HM624256@SOJ28
[ (SA646) ]	
HM6264A	HM6264A@TSOP28
[ (SA643) ]	
HM6267	
HM6268	
HM628128	HM628128@TSOP32
[ (SA410T) ]	
HM628128A	HM628128A@TSOP32
[ (SA410T) ]	
HM62832	HM62832@TSOP28
[ (SA643) ]	
HM62832H	HM62832H@TSOP28
[ (SA643) ]	
HM628512	HM628512@TSOP32
[ (SA729) ]	
HM6287	
HM6287HP	
HM6288	HM6288@SOJ22
[ (SA646) ]	
HM65256B	HM65256B@TSOP28
[ (SA643) ]	
HM658128	HM658128@TSOP32
[ (SA410T) ]	
HM66204	HM66204@TSOP32
[ (SA410T) ]	
HM6707	HM6707@SOJ24
[ (SA646) ]	
HM6707A	HM6707A@SOJ24
[ (SA646) ]	
HM6708	HM6708@SOJ24

[ ( SA646 ) ]	
HM6708A	HM6708A@SOJ24
[ ( SA646 ) ]	
HM6716	HM6716@PLCC32
[ ( SA015A1T ) ]	
HM6787	
HM6787HP	
HM6788	HM6788@SOJ22
[ ( SA646 ) ]	
HM6788H	HM6788H@SOJ22
[ ( SA646 ) ]	
HM6788HA	HM6788HA@SOJ22
[ ( SA646 ) ]	

## MICROCONTROLLER

HD4074344@SDIP28 [ ( SA022A ) ]	HD4074344@SOIC28
[ ( SA404 ) ]	
HD4074394@SDIP28 [ ( SA022A ) ]	HD4074394@SOIC28
[ ( SA404 ) ]	
HD64F3694FX@TQFP48 [ ( SA671 ) ]	HD64F3694FY@TQFP48
[ ( SA248 ) ]	
HD64F3694GFX@TQFP48 [ ( SA671 ) ]	HD64F3694GFY@TQFP48
[ ( SA248 ) ]	

## HOLTEK

### E ( E ) PROM / FRAM / NVRAM

HT24C01	HT24C01@SOIC8
[ ( SA602A ) ]	
HT24C02	HT24C02@SOIC8
[ ( SA602A ) ]	
HT24C04	HT24C04@SOIC8
[ ( SA602A ) ]	
HT24C08	
HT24C16	
HT24LC01	HT24LC01@SOIC8
[ ( SA602A ) ]	
HT24LC01@TSSOP8 [ ( SA026 ) ]	
HT24LC02	

HT24LC02@SOIC8 [(SA602A)]	HT24LC02@TSSOP8
[(SA026)]	
HT24LC04	HT24LC04@SOIC8
[(SA602A)]	
HT24LC08	HT24LC08@SOIC8
[(SA602A)]	
HT24LC16	HT24LC16@SOIC8
[(SA602A)]	
HT24LC32	HT24LC32@SOIC8
[(SA602A)]	
HT24LC64	HT24LC64@SOIC8
[(SA602A)]	
HT25LC512@SOIC8 [(SA602A)]	
HT27C010	
HT27C010@PLCC32 [(SA015A1T)]	HT27C010@TSOP32
[(SA410T)]	
HT27C020	HT27C020@PLCC32
[(SA015A1T)]	
HT27C020@TSOP32 [(SA410T)]	
HT27C040	
HT27C040@PLCC32 [(SA015A1T)]	HT27C040@TSOP32
[(SA410T)]	
HT27C4096	HT27C4096@PLCC44
[(SA244)]	
HT27C512	HT27C512@PLCC32
[(SA015A1T)]	
HT27C512@TSOP28 [(SA430T)]	
HT27LC010	
HT27LC010@PLCC32 [(SA015A1T)]	HT27LC010@TSOP32
[(SA410T)]	
HT27LC020	HT27LC020@PLCC32
[(SA015A1T)]	
HT27LC020@TSOP32 [(SA410T)]	
HT27LC040	
HT27LC040@PLCC32 [(SA015A1T)]	HT27LC040@TSOP32
[(SA410T)]	
HT27LC4096	HT27LC4096@PLCC44
[(SA244)]	
HT27LC512	HT27LC512@PLCC32
[(SA015A1T)]	
HT27LC512@TSOP28 [(SA430T)]	HT93C46
(16bit)	
HT93C46(16bit)@SOP8-A [(SA602A)]	HT93C46(16bit)@SOP8-B

[ (SA602A) ]  
HT93C46(16bit)@TSSOP8 [ (SA026) ] HT93C56  
(16bit)  
HT93C56(16bit)@SOP8-A [ (SA602A) ] HT93C56(16bit)@SOP8-B  
[ (SA602A) ]  
HT93C56(16bit)@TSSOP8 [ (SA026) ] HT93C66  
(16bit)  
HT93C66(16bit)@SOP8-A [ (SA602A) ] HT93C66(16bit)@SOP8-B  
[ (SA602A) ]  
HT93C66(16bit)@TSSOP8 [ (SA026) ] HT93LC46A  
(08bit)  
HT93LC46A(08bit)@SOP8-A [ (SA602A) ]  
HT93LC46A(08bit)@SOP8-B [ (SA602A) ]  
HT93LC46A(08bit)@TSSOP8 [ (SA026) ]  
HT93LC46A(16bit)  
HT93LC46A(16bit)@SOP8-A [ (SA602A) ]  
HT93LC46A(16bit)@SOP8-B [ (SA602A) ]  
HT93LC46A(16bit)@TSSOP8 [ (SA026) ]  
HT93LC46B(08bit)  
HT93LC46B(08bit)@SOP8-A [ (SA602A) ]  
HT93LC46B(08bit)@SOP8-B [ (SA602A) ]  
HT93LC46B(08bit)@TSSOP8 [ (SA026) ]  
HT93LC46B(16bit)  
HT93LC46B(16bit)@SOP8-A [ (SA602A) ]  
HT93LC46B(16bit)@SOP8-B [ (SA602A) ]  
HT93LC46B(16bit)@TSSOP8 [ (SA026) ]  
HT93LC56A(08bit)  
HT93LC56A(08bit)@SOP8-A [ (SA602A) ]  
HT93LC56A(08bit)@SOP8-B [ (SA602A) ]  
HT93LC56A(08bit)@TSSOP8 [ (SA026) ]  
HT93LC56A(16bit)  
HT93LC56A(16bit)@SOP8-A [ (SA602A) ]  
HT93LC56A(16bit)@SOP8-B [ (SA602A) ]  
HT93LC56A(16bit)@TSSOP8 [ (SA026) ]  
HT93LC56B(08bit)  
HT93LC56B(08bit)@SOP8-A [ (SA602A) ]  
HT93LC56B(08bit)@SOP8-B [ (SA026) ]  
HT93LC56B(08bit)@TSSOP8 [ (SA026) ]  
HT93LC56B(16bit)  
HT93LC56B(16bit)@SOP8-A [ (SA602A) ]  
HT93LC56B(16bit)@SOP8-B [ (SA602A) ]  
HT93LC56B(16bit)@TSSOP8 [ (SA026) ]  
HT93LC66A(08bit)

HT93LC66A(08bit)@SOP8-A [(SA602A)]  
HT93LC66A(08bit)@SOP8-B [(SA602A)]  
HT93LC66A(08bit)@TSSOP8 [(SA026)]  
HT93LC66A(16bit)  
HT93LC66A(16bit)@SOP8-A [(SA602A)]  
HT93LC66A(16bit)@SOP8-B [(SA602A)]  
HT93LC66A(16bit)@TSSOP8 [(SA026)]  
HT93LC66B(08bit)  
HT93LC66B(08bit)@SOP8-A [(SA602A)]  
HT93LC66B(08bit)@SOP8-B [(SA026)]  
HT93LC66B(08bit)@TSSOP8 [(SA026)]  
HT93LC66B(16bit)  
HT93LC66B(16bit)@SOP8-A [(SA602A)]  
HT93LC66B(16bit)@SOP8-B [(SA602A)]  
HT93LC66B(16bit)@TSSOP8 [(SA026)]  
HT93LC76(08bit)  
HT93LC76(08bit)@SOP8-A [(SA602A)]  
HT93LC76(08bit)@SOP8-B [(SA602A)]  
HT93LC76(08bit)@TSSOP8 [(SA026)] HT93LC76  
(16bit)  
HT93LC76(16bit)@SOP8-A [(SA602A)]  
HT93LC76(16bit)@SOP8-B [(SA602A)]  
HT93LC76(16bit)@TSSOP8 [(SA026)] HT93LC86  
(08bit)  
HT93LC86(08bit)@SOP8-A [(SA602A)]  
HT93LC86(08bit)@SOP8-B [(SA602A)]  
HT93LC86(08bit)@TSSOP8 [(SA026)] HT93LC86  
(16bit)  
HT93LC86(16bit)@SOP8-A [(SA602A)]  
HT93LC86(16bit)@SOP8-B [(SA602A)]  
HT93LC86(16bit)@TSSOP8 [(SA026)]

## MICROCONTROLLER

HT46R22 HT46R22@SOP24  
[(SA404)]  
HT46R23(dip24) HT46R23  
(dip28)  
HT46R23@SOP24 [(SA404)] HT46R23@SOP28  
[(SA404)]  
HT46R24 HT46R24@SOP28  
[(SA404)]



HT46R24@SSOP48 [(SA669)] (dip18)	HT46R46
HT46R46(dip20) [(SA404)]	HT46R46@SOP18
HT46R46@SOP20 [(SA404)] (dip18)	HT46R46E
HT46R46E@SOP18 [(SA404)] H	HT46R46-
HT46R46-H@SOP18 [(SA404)] (dip18)	HT46R47
HT46R47(dip20) [(SA404)]	HT46R47@SOP18
HT46R47@SOP20 [(SA404)] [(SA674)]	HT46R47@SSOP20
HT46R47E(dip18) [(SA404)]	HT46R47E@SOP18
HT46R47-H [(SA404)]	HT46R47-H@SOP18
HT46R48(dip20) (dip24)	HT46R48
HT46R48@SOP20 [(SA404)] [(SA404)]	HT46R48@SOP24
HT46R48@SSOP24 [(SA674)] (dip24)	HT46R48E
HT46R48E@SOP24 [(SA404)] [(SA674)]	HT46R48E@SSOP24
HT46R51A(dip18) [(SA404)]	HT46R51A@SOP20
HT46R51A@SSOP20 [(SA674)] (dip18)	HT46R52A
HT46R52A@SOP20 [(SA404)] [(SA674)]	HT46R52A@SSOP20
HT46R53A(dip28) [(SA404)]	HT46R53A@SOP28
HT46R54A(dip28) [(SA404)]	HT46R54A@SOP28
HT46R65@PQFP100 [(PEP+S427)] [(SA669)]	HT46R65@SSOP56
HT46R71D@SSOP48 [(SA669)] HT46RB70	
HT46RB70@SOP28 [(SA404)] [(SA669)]	HT46RB70@SSOP48
HT46RU22(dip24)	HT46RU22@SOP24

[ (SA404) ]	
HT46RU22@SSOP24 [ (SA674) ]	HT47R10A@QFP44
[ (SA245) ]	
HT48R05A	HT48R05A@SOP16
[ (SA026) ]	
HT48R05A@SOP18 [ (SA404) ]	
HT48R06A	
HT48R06A@SOP16 [ (SA026) ]	HT48R06A@SOP18
[ (SA404) ]	
HT48R07A	HT48R07A@SOP24
[ (SA404) ]	
HT48R07A@SSOP24 [ (SA674) ]	
HT48R08A	
HT48R08A@SOP16 [ (SA026) ]	HT48R08A@SOP18
[ (SA404) ]	
HT48R09A	HT48R09A@SOP24
[ (SA404) ]	
HT48R09A@SSOP24 [ (SA674) ]	
HT48R10A	
HT48R10A@SOP24 [ (SA404) ]	HT48R30A
(dip24)	
HT48R30A(dip28)	HT48R30A@SOP24
[ (SA404) ]	
HT48R30A@SOP28 [ (SA404) ]	
HT48R50A	
HT48R50A@SOP28 [ (SA404) ]	HT48R50A@SSOP48
[ (SA669) ]	
HT48R52A@QFP44 [ (SA245A) ]	HT48R70A@SSOP48
[ (SA669) ]	
HT48RA0-1	HT48RA0-1@SOP24
[ (SA404) ]	
HT48RA0-2	HT48RA0-2@SOP20
[ (SA404) ]	
HT48RA0-2@SSOP20 [ (SA674) ]	HT48RA0-
3	
HT48RA0-3@SOP20 [ (SA404) ]	HT48RA1@SOP28
[ (SA404) ]	
HT48RA1@SSOP28 [ (SA626A) ]	HT48RA3
(dip28)	
HT48RA3@SOP28 [ (SA404) ]	HT48RA3@SSOP28
[ (SA626A) ]	
HT48RA5(dip28)	HT48RA5@SOP28
[ (SA404) ]	

HT48RA5@SSOP28 [(SA626A)]	
HT48RB50	
HT48RB50@SOP28 [(SA404)]	HT48RB50@SSOP48
[(SA669)]	
HT48RB8@SOP28 [(SA404)]	HT48RB8@SSOP48
[(SA669)]	
HT49R30A@SSOP48 [(SA669)]	HT49R50A@SSOP48
[(SA669)]	
HT49RV5@SSOP56 [(SA669)]	HT82A821R@SOP24
[(SA404)]	
HT82A821R@SSOP24 [(SA674)]	HT82A822R@SSOP48
[(SA669)]	
HT82A832R@QFP48 [(SA248)]	HT82A832R@SSOP48
[(SA669)]	
HT82K68E	HT82K68E@SOP20
[(SA404)]	
HT82K68E@SOP28 [(SA404)]	HT82K68E@SSOP48
[(SA669)]	
HT82K94E@SSOP48 [(SA669)]	HT82K95E@SOP20
[(SA404)]	
HT82K95E@SOP28 [(SA404)]	HT82K95E@SSOP48
[(SA669)]	
HT82K96E(dip20)	HT82K96E
(dip40)	
HT82K96E@SOP20 [(SA404)]	HT82K96E@SOP28
[(SA404)]	
HT82K96E@SSOP48 [(SA669)]	HT82M99E
(dip18)	
HT82M99E(dip20)	HT82M99E@SOP18
[(SA404)]	
HT82M99E@SOP20 [(SA404)]	HT82M9AE@SOP20
[(SA404)]	
HT82M9AE@SOP24 [(SA404)]	HT82M9AE@SSOP20
[(SA674)]	
HT82M9AE@SSOP24 [(SA674)]	HT82M9BE@SOP24
[(SA404)]	
HT82M9BE@SOP28 [(SA404)]	HT82M9BE@SSOP24
[(SA674)]	
HT82M9BE@SSOP28 [(SA626A)]	HT95A100@SOP28
[(SA404)]	
HT95A10P@SOP28 [(SA404)]	HT95A200@SSOP48
[(SA669)]	
HT95A20P@SSOP48 [(SA669)]	HT95A300@SSOP48

[ ( SA669 ) ]  
HT95A30P@SSOP48 [ ( SA669 ) ]

## HONGKONG

### E ( E ) PROM / FRAM / NVRAM

HK1215  
HK1225  
HK1235  
HK1245  
HK1255  
HK1265  
HK1275  
HK1285  
HK1295  
HK12A5  
HK12B5  
OKS1225  
OKS1235  
OKS1245  
OKS1255  
OKS1265  
OKS1275  
OKS1285  
OKS1295  
OKS12A5  
OKS12B5

## HYNIX

### E ( E ) PROM / FRAM / NVRAM

H8ACS0EJ0MCP@FBGA137 [ ( SA700E-B153A-M137F001Y ) ]  
HY2764  
HY27C64A  
HY27SF081G2A@FBGA63 [ ( SA642KK-B026A-W048F001Y ) ]  
HY27UA081G1M@TSOP48 [ ( SA247-B005 ) ]  
HY27UF081G2A@FBGA63 [ ( SA642KK-B026-W048F001Y ) ]  
HY27UF081G2A@TSOP48 [ ( SA247-B005 ) ]

HY27UF081G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UF082G2A@TSOP48 [ ( SA247-B005 ) ]  
HY27UF082G2B@TSOP48 [ ( SA247-B005 ) ]  
HY27UF082G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UF084G2B@TSOP48 [ ( SA247-B005 ) ]  
HY27UF084G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UG082G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UG088G5M@TSOP48 [ ( SA247+B005 ) ]  
HY27US08121M@TSOP48 [ ( SA247-B005 ) ]  
HY27US081G1M@USOP48 [ ( SA765-B005 ) ]  
HY27US08281A@TSOP48 [ ( SA247-B005 ) ]  
HY27US08561A@FBGA63 [ ( SA642KK-B026A-W048F001Y ) ]  
HY27US08561A@TSOP48 [ ( SA247-B005 ) ]  
HY27US08561M@TSOP48 [ ( SA247-B005 ) ]  
HY27UT084G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UT088G2A@TSOP48 [ ( SA247-B005 ) ]  
HY27UT088G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UV08BG5M@TSOP48 [ ( SA247-B005 ) ]  
HY29DL162BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
HY29DL162BT@TSOP48 [ ( SA247-B005 ) ]  
HY29DL162TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
HY29DL162TT@TSOP48 [ ( SA247-B005 ) ]  
HY29DL163BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
HY29DL163BT@TSOP48 [ ( SA247-B005 ) ]  
HY29DL163TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
HY29DL163TT@TSOP48 [ ( SA247-B005 ) ]  
HY29DS162BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
HY29DS162BT@TSOP48 [ ( SA247-B005 ) ]  
HY29DS162TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
HY29DS162TT@TSOP48 [ ( SA247-B005 ) ]  
HY29DS163BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
HY29DS163BT@TSOP48 [ ( SA247-B005 ) ]  
HY29DS163TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
HY29DS163TT@TSOP48 [ ( SA247-B005 ) ]  
HY29F002T HY29F002T@PLCC32  
[ ( SA015A1T ) ]  
HY29F002T@TSOP32 [ ( SA410T ) ]  
HY29F040  
HY29F040@PLCC32 [ ( SA015A1T ) ] HY29F040@TSOP32  
[ ( SA410T ) ]  
HY29F040A HY29F040A@PLCC32  
[ ( SA015A1T ) ]  
HY29F040A@TSOP32 [ ( SA410T ) ] HY29F080@TSOP40

[ (SA409T) ]  
HY29F200B@PSOP44 [ (SA638-B006) ]                      HY29F200B@TSOP48 [ (SA247-B005) ]  
HY29F200T@PSOP44 [ (SA638-B006) ]                      HY29F200T@TSOP48 [ (SA247-B005) ]  
HY29F400ABG@PSOP44 [ (SA638) ]  
HY29F400ABT@TSOP48 [ (SA247-B005) ]  
HY29F400ATG@PSOP44 [ (SA638) ]  
HY29F400ATT@TSOP48 [ (SA247-B005) ]  
HY29F400BG@PSOP44 [ (SA638) ]                      HY29F400BT@TSOP48 [ (SA247-B005) ]  
HY29F400TG@PSOP44 [ (SA638) ]                      HY29F400TT@TSOP48 [ (SA247-B005) ]  
HY29F800ABG@PSOP44 [ (SA638) ]  
HY29F800ABT@TSOP48 [ (SA247-B005) ]  
HY29F800ATG@PSOP44 [ (SA638) ]  
HY29F800ATT@TSOP48 [ (SA247-B005) ]  
HY29F800BG@PSOP44 [ (SA638) ]                      HY29F800BT@TSOP48 [ (SA247-B005) ]  
HY29F800TG@PSOP44 [ (SA638) ]                      HY29F800TT@TSOP48 [ (SA247-B005) ]  
HY29LV160BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
HY29LV160BT@TSOP48 [ (SA247-B005) ]  
HY29LV160TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
HY29LV160TT@TSOP48 [ (SA247-B005) ]  
HY29LV320BF@FBGA48 [ (SA642E-B026A-T072F001) ]  
HY29LV320BF@FBGA63 [ (SA642E-B026A-T072F001) ]  
HY29LV320BT@TSOP48 [ (SA247-B005) ]  
HY29LV320TF@FBGA48 [ (SA642E-B026A-T072F001) ]  
HY29LV320TF@FBGA63 [ (SA642E-B026A-T072F001) ]  
HY29LV320TT@TSOP48 [ (SA247-B005) ]  
HY29LV400BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
HY29LV400BT@TSOP48 [ (SA247-B005) ]  
HY29LV400TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
HY29LV400TT@TSOP48 [ (SA247-B005) ]  
HY29LV800BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
HY29LV800BG@PSOP44 [ (SA638) ]  
HY29LV800BT@TSOP48 [ (SA247-B005) ]  
HY29LV800TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
HY29LV800TG@PSOP44 [ (SA638) ]  
HY29LV800TT@TSOP48 [ (SA247-B005) ]  
HY93C46    HY93C46@SOIC8  
[ (SA602A) ]

HY93C56	HY93C56@SOIC8
[ (SA602A) ]	
HY93C66	HY93C66@SOIC8
[ (SA602A) ]	
HY93C76	HY93C76@SOIC8
[ (SA602A) ]	
HY93C86	HY93C86@SOIC8
[ (SA602A) ]	
HYC0SEF0MF3P@FBGA137 [ (SA700E-B153A-M137F001Y) ]	
HYC0SEH0AF3P@FBGA137 [ (SA700E-B153A-M137F001Y) ]	
HYD0SEE0MF2P@FBGA107 [ (SA642V-B133-T096F001Y) ]	
HYD0SFE0BF1P@BGA149 [ (SA700I-B308-T149F001Y) ]	
HYD0SFG0MF1P@BGA149 [ (SA700I-B308-T149F001Y) ]	
HYG0SEG0MF2P@FBGA107 [ (SA642V-B133-T096F001Y) ]	
HYG0UEG0MF2P@FBGA107 [ (SA642V-B133-T096F001Y) ]	

## DRAM & SRAM

HY62256A	HY62256A@TSOP28
[ (SA643) ]	
HY6264A	HY6264A@TSOP28
[ (SA643) ]	
HY628100A	HY628100A@SOP32
[ (SA438T) ]	
HY628100A@TSOP32 [ (SA410T) ]	
HY628100B	
HY628100B@SOP32 [ (SA438T) ]	HY628100B@TSOP32
[ (SA410T) ]	
HY628400	HY628400@SOP32
[ (SA438T) ]	
HY628400@TSOP32 [ (SA410T) ]	
HY628400A	
HY628400A@SOP32 [ (SA438T) ]	HY628400A@TSOP32
[ (SA410T) ]	
HY62CT08081E	HY62CT08081E@SOP28
[ (SA438T) ]	
HY62CT08081E@TSOP28 [ (SA643) ]	
HY62KT08081E	
HY62KT08081E@SOP28 [ (SA438T) ]	HY62KT08081E@TSOP28
[ (SA643) ]	
HY62U8100B	HY62U8100B@SOP32
[ (SA438T) ]	

HY62U8100B@TSOP32 [(SA410T)]	
HY62U8200B	
HY62U8200B@SOP32 [(SA438T)]	HY62U8200B@TSOP32
[(SA410T)]	
HY62U8400A	
[(SA438T)]	HY62U8400A@SOP32
HY62U8400A@TSOP32 [(SA410T)]	
HY62UT08081E	
HY62UT08081E@SOP28 [(SA438T)]	HY62UT08081E@TSOP28
[(SA643)]	
HY62V8100B	
[(SA438T)]	HY62V8100B@SOP32
HY62V8100B@TSOP32 [(SA410T)]	
HY62V8200B	
HY62V8200B@SOP32 [(SA438T)]	HY62V8200B@TSOP32
[(SA410T)]	
HY62V8400A	
[(SA438T)]	HY62V8400A@SOP32
HY62V8400A@TSOP32 [(SA410T)]	
HY62VT08081E	
HY62VT08081E@SOP28 [(SA438T)]	HY62VT08081E@TSOP28
[(SA643)]	
HY62WT08081E	
[(SA438T)]	HY62WT08081E@SOP28
HY62WT08081E@TSOP28 [(SA643)]	

## MICROCONTROLLER

GMS97C1051	GMS97C1051@SOIC20
[(SA404)]	
GMS97C2051	GMS97C2051@SOIC20
[(SA404)]	
GMS97C51	GMS97C51@PLCC44
[(SA244)]	
GMS97C51@TQFP44 [(SA245A)]	
GMS97C52	
GMS97C52@PLCC44 [(SA244)]	GMS97C52@TQFP44
[(SA245A)]	
GMS97C54	GMS97C54@PLCC44
[(SA244)]	
GMS97C54@TQFP44 [(SA245A)]	
GMS97C56	



GMS97C56@PLCC44 [ (SA244) ]	GMS97C56@TQFP44
[ (SA245A) ]	
GMS97C58	GMS97C58@PLCC44
[ (SA244) ]	
GMS97C58@TQFP44 [ (SA245A) ]	
GMS97L1051	
GMS97L1051@SOIC20 [ (SA404) ]	
GMS97L2051	
GMS97L2051@SOIC20 [ (SA404) ]	
GMS97L51	
GMS97L51@PLCC44 [ (SA244) ]	GMS97L51@TQFP44
[ (SA245A) ]	
GMS97L52	GMS97L52@PLCC44
[ (SA244) ]	
GMS97L52@TQFP44 [ (SA245A) ]	
GMS97L54	
GMS97L54@PLCC44 [ (SA244) ]	GMS97L54@TQFP44
[ (SA245A) ]	
GMS97L56	GMS97L56@PLCC44
[ (SA244) ]	
GMS97L56@TQFP44 [ (SA245A) ]	
GMS97L58	
GMS97L58@PLCC44 [ (SA244) ]	GMS97L58@TQFP44
[ (SA245A) ]	
GMS99C52	GMS99C52@PLCC44
[ (SA244) ]	
GMS99C52@TQFP44 [ (SA245A) ]	
GMS99C58	
GMS99C58@PLCC44 [ (SA244) ]	GMS99C58@TQFP44
[ (SA245A) ]	
HMS99C52	HMS99C52@PLCC44
[ (SA244) ]	
HMS99C52@TQFP44 [ (SA245A) ]	
HMS99C58	
HMS99C58@PLCC44 [ (SA244) ]	HMS99C58@TQFP44
[ (SA245A) ]	

## **HYNIX-CUSTOMER**

### **E (E) PROM / FRAM / NVRAM**

HY27UF081G2A (DD)@TSOP48 [ (SA247-B005) ]

HY27UF081G2A(DD5)@TSOP48 [(SA247+B005)]  
HY27UF081G2A(MLT)@TSOP48 [(SA247-B005)]  
HY27UF082G2A(AMLOGIC)@TSOP48 [(SA247-B005)]  
HY27UF082G2A(MLT)@TSOP48 [(SA247-B005)]  
HY27UF084G2M(YH)@TSOP48 [(SA247-B005)]  
HY27US08281A(WS)@TSOP48 [(SA247-B005)]  
HY27UT088G2A(64M)@TSOP48 [(SA247-B005)]  
HY27UT088G2M(OMB)@TSOP48 [(SA247-B005)]

## HYUNDAI

### E ( E ) PROM / FRAM / NVRAM

HY2764  
HY27C64A  
HY29DL162BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DL162BT@TSOP48 [(SA247-B005)]  
HY29DL162TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DL162TT@TSOP48 [(SA247-B005)]  
HY29DL163BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DL163BT@TSOP48 [(SA247-B005)]  
HY29DL163TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DL163TT@TSOP48 [(SA247-B005)]  
HY29DS162BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DS162BT@TSOP48 [(SA247-B005)]  
HY29DS162TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DS162TT@TSOP48 [(SA247-B005)]  
HY29DS163BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DS163BT@TSOP48 [(SA247-B005)]  
HY29DS163TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DS163TT@TSOP48 [(SA247-B005)]  
HY29F002T [(SA015A1T)] HY29F002T@PLCC32  
HY29F002T@TSOP32 [(SA410T)]  
HY29F040  
HY29F040@PLCC32 [(SA015A1T)] HY29F040@TSOP32  
[(SA410T)]  
HY29F040A [(SA015A1T)] HY29F040A@PLCC32  
HY29F040A@TSOP32 [(SA410T)] HY29F080@TSOP40  
[(SA409T)]  
HY29F200B@PSOP44 [(SA638-B006)] HY29F200B@TSOP48 [(SA247-

B005) ]  
HY29F200T@PSOP44 [ (SA638-B006) ]                   HY29F200T@TSOP48 [ (SA247-  
B005) ]  
HY29F400ABG@PSOP44 [ (SA638) ]  
HY29F400ABT@TSOP48 [ (SA247-B005) ]  
HY29F400ATG@PSOP44 [ (SA638) ]  
HY29F400ATT@TSOP48 [ (SA247-B005) ]  
HY29F400BG@PSOP44 [ (SA638) ]                   HY29F400BT@TSOP48 [ (SA247-  
B005) ]  
HY29F400TG@PSOP44 [ (SA638) ]                   HY29F400TT@TSOP48 [ (SA247-  
B005) ]  
HY29F800ABG@PSOP44 [ (SA638) ]  
HY29F800ABT@TSOP48 [ (SA247-B005) ]  
HY29F800ATG@PSOP44 [ (SA638) ]  
HY29F800ATT@TSOP48 [ (SA247-B005) ]  
HY29F800BG@PSOP44 [ (SA638) ]                   HY29F800BT@TSOP48 [ (SA247-  
B005) ]  
HY29F800TG@PSOP44 [ (SA638) ]                   HY29F800TT@TSOP48 [ (SA247-  
B005) ]  
HY29LV160BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
HY29LV160BT@TSOP48 [ (SA247-B005) ]  
HY29LV160TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
HY29LV160TT@TSOP48 [ (SA247-B005) ]  
HY29LV320BF@FBGA48 [ (SA642E-B026A-T072F001) ]  
HY29LV320BF@FBGA63 [ (SA642E-B026A-T072F001) ]  
HY29LV320BT@TSOP48 [ (SA247-B005) ]  
HY29LV320TF@FBGA48 [ (SA642E-B026A-T072F001) ]  
HY29LV320TF@FBGA63 [ (SA642E-B026A-T072F001) ]  
HY29LV320TT@TSOP48 [ (SA247-B005) ]  
HY29LV400BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
HY29LV400BT@TSOP48 [ (SA247-B005) ]  
HY29LV400TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
HY29LV400TT@TSOP48 [ (SA247-B005) ]  
HY29LV800BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
HY29LV800BG@PSOP44 [ (SA638) ]  
HY29LV800BT@TSOP48 [ (SA247-B005) ]  
HY29LV800TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
HY29LV800TG@PSOP44 [ (SA638) ]  
HY29LV800TT@TSOP48 [ (SA247-B005) ]  
HY93C46   HY93C46@SOIC8  
[ (SA602A) ]  
HY93C56   HY93C56@SOIC8  
[ (SA602A) ]

HY93C66 [ (SA602A) ]	HY93C66@SOIC8
HY93C76 [ (SA602A) ]	HY93C76@SOIC8
HY93C86 [ (SA602A) ]	HY93C86@SOIC8

## DRAM & SRAM

HY62256A [ (SA643) ]	HY62256A@TSOP28
HY6264A [ (SA643) ]	HY6264A@TSOP28
HY628100A [ (SA438T) ]	HY628100A@SOP32
HY628100A@TSOP32 [ (SA410T) ]	
HY628100B HY628100B@SOP32 [ (SA438T) ]	HY628100B@TSOP32
[ (SA410T) ]	
HY628400 [ (SA438T) ]	HY628400@SOP32
HY628400@TSOP32 [ (SA410T) ]	
HY628400A HY628400A@SOP32 [ (SA438T) ]	HY628400A@TSOP32
[ (SA410T) ]	
HY62CT08081E [ (SA438T) ]	HY62CT08081E@SOP28
HY62CT08081E@TSOP28 [ (SA643) ]	
HY62KT08081E HY62KT08081E@SOP28 [ (SA438T) ]	HY62KT08081E@TSOP28
[ (SA643) ]	
HY62U8100B [ (SA438T) ]	HY62U8100B@SOP32
HY62U8100B@TSOP32 [ (SA410T) ]	
HY62U8200B HY62U8200B@SOP32 [ (SA438T) ]	HY62U8200B@TSOP32
[ (SA410T) ]	
HY62U8400A [ (SA438T) ]	HY62U8400A@SOP32
HY62U8400A@TSOP32 [ (SA410T) ]	
HY62UT08081E HY62UT08081E@SOP28 [ (SA438T) ]	HY62UT08081E@TSOP28

[ (SA643) ]	
HY62V8100B	HY62V8100B@SOP32
[ (SA438T) ]	
HY62V8100B@TSOP32 [ (SA410T) ]	
HY62V8200B	
HY62V8200B@SOP32 [ (SA438T) ]	HY62V8200B@TSOP32
[ (SA410T) ]	
HY62V8400A	HY62V8400A@SOP32
[ (SA438T) ]	
HY62V8400A@TSOP32 [ (SA410T) ]	
HY62VT08081E	
HY62VT08081E@SOP28 [ (SA438T) ]	HY62VT08081E@TSOP28
[ (SA643) ]	
HY62WT08081E	HY62WT08081E@SOP28
[ (SA438T) ]	
HY62WT08081E@TSOP28 [ (SA643) ]	

## MICROCONTROLLER

GMS97C1051	GMS97C1051@SOIC20
[ (SA404) ]	
GMS97C2051	GMS97C2051@SOIC20
[ (SA404) ]	
GMS97C51	GMS97C51@PLCC44
[ (SA244) ]	
GMS97C51@TQFP44 [ (SA245A) ]	
GMS97C52	
GMS97C52@PLCC44 [ (SA244) ]	GMS97C52@TQFP44
[ (SA245A) ]	
GMS97C54	GMS97C54@PLCC44
[ (SA244) ]	
GMS97C54@TQFP44 [ (SA245A) ]	
GMS97C56	
GMS97C56@PLCC44 [ (SA244) ]	GMS97C56@TQFP44
[ (SA245A) ]	
GMS97C58	GMS97C58@PLCC44
[ (SA244) ]	
GMS97C58@TQFP44 [ (SA245A) ]	
GMS97L1051	
GMS97L1051@SOIC20 [ (SA404) ]	
GMS97L2051	
GMS97L2051@SOIC20 [ (SA404) ]	

GMS97L51	
GMS97L51@PLCC44 [ (SA244) ]	GMS97L51@TQFP44
[ (SA245A) ]	
GMS97L52	GMS97L52@PLCC44
[ (SA244) ]	
GMS97L52@TQFP44 [ (SA245A) ]	
GMS97L54	
GMS97L54@PLCC44 [ (SA244) ]	GMS97L54@TQFP44
[ (SA245A) ]	
GMS97L56	GMS97L56@PLCC44
[ (SA244) ]	
GMS97L56@TQFP44 [ (SA245A) ]	
GMS97L58	
GMS97L58@PLCC44 [ (SA244) ]	GMS97L58@TQFP44
[ (SA245A) ]	
GMS99C52	GMS99C52@PLCC44
[ (SA244) ]	
GMS99C52@TQFP44 [ (SA245A) ]	
GMS99C58	
GMS99C58@PLCC44 [ (SA244) ]	GMS99C58@TQFP44
[ (SA245A) ]	
HMS99C52	HMS99C52@PLCC44
[ (SA244) ]	
HMS99C52@TQFP44 [ (SA245A) ]	
HMS99C58	
HMS99C58@PLCC44 [ (SA244) ]	HMS99C58@TQFP44
[ (SA245A) ]	

## ICE

### E (E) PROM / FRAM / NVRAM

ICE25P05	ICE25P05@SOIC8
[ (SA602A) ]	
ICE27C010	ICE27C010@PLCC32
[ (SA015A1T) ]	
ICE27C010@TSOP32 [ (SA410T) ]	
ICE27C020	
ICE27C020@PLCC32 [ (SA015A1T) ]	ICE27C020@TSOP32
[ (SA410T) ]	
ICE27C512	ICE27C512@PLCC32
[ (SA015A1T) ]	

ICE27C512@TSOP28 [ (SA430T) ]  
ICE27LC010  
ICE27LC010@PLCC32 [ (SA015A1T) ] ICE27LC010@TSOP32  
[ (SA410T) ]  
ICE27LC020 ICE27LC020@PLCC32  
[ (SA015A1T) ]  
ICE27LC020@TSOP32 [ (SA410T) ]  
ICE27LC512  
ICE27LC512@PLCC32 [ (SA015A1T) ] ICE27LC512@TSOP28  
[ (SA430T) ]  
ICE28LF010 ICE28LF010@PLCC32  
[ (SA015A1T) ]  
ICE37C512 ICE37C512@PLCC32  
[ (SA015A1T) ]  
ICE37C512@TSOP32 [ (SA410T) ]  
ICE37LC512  
ICE37LC512@PLCC32 [ (SA015A1T) ] ICE37LC512@TSOP32  
[ (SA410T) ]

## ICMIC

### E ( E ) PROM / FRAM / NVRAM

X76F101 X76F101@SOIC8  
[ (SA602A) ]  
X76F400@SOIC8 [ (SA602A) ] X76F400@TSSOP8  
[ (SA026) ]

## ICSI

### E ( E ) PROM / FRAM / NVRAM

IC71V08F32AS04@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32AS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32AS08@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32AS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32BS04@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32BS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32BS08@FBGA64 [ (SA642A-B032A-Y096F001) ]  
IC71V08F32BS08@FBGA73 [ (SA642A-B032A-Y096F001) ]

IC71V08F32CS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32CS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32CS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32CS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32DS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32DS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32DS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32DS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32ES04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32ES04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32ES08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32ES08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32FS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32FS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32FS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32FS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32AS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32AS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32AS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32AS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32BS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32BS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32BS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32BS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32CS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32CS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32CS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32CS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32DS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32DS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32DS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32DS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32ES04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32ES04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32ES08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32ES08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32FS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32FS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32FS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32FS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32GS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32GS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32HS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]



IC71V16F32HS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F64IP16@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F64IS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]

## MICROCONTROLLER

IC89LV51A [ ( SA244 ) ]	IC89LV51A@PLCC44
IC89LV51A@TQFP44 [ ( SA245A ) ]	
IC89LV52A IC89LV52A@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	IC89LV52A@TQFP44
IS89C51A [ ( SA244 ) ]	IS89C51A@PLCC44
IS89C51A@TQFP44 [ ( SA245A ) ]	
IS89C52A IS89C52A@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	IS89C52A@TQFP44
IS89C54 [ ( SA244 ) ]	IS89C54@PLCC44
IS89C54@TQFP44 [ ( SA245A ) ]	
IS89C58 IS89C58@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	IS89C58@TQFP44
IS89C64 [ ( SA244 ) ]	IS89C64@PLCC44
IS89C64@TQFP44 [ ( SA245A ) ]	
IS89E54 IS89E54@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	IS89E54@TQFP44
IS89E58 [ ( SA244 ) ]	IS89E58@PLCC44
IS89E58@TQFP44 [ ( SA245A ) ]	
IS89E64 IS89E64@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	IS89E64@TQFP44

## ICT

## E ( E ) PROM / FRAM / NVRAM

27CX010	27CX010@PLCC32
[ (SA015A1T) ]	
27CX010@TSOP32 [ (SA410T) ]	
27CX161	
27CX162	
27CX256	
27CX321	
27CX322	
27CX641	
27CX642	
93C46	93C46@SOIC8
[ (SA602A) ]	
93C46A	93C46A@SOIC8
[ (SA602A) ]	
93C56A	93C56A@SOIC8
[ (SA602A) ]	
93C66A	93C66A@SOIC8
[ (SA602A) ]	
93CX46	93CX46@SOIC8
[ (SA602A) ]	
93CX56	93CX56@SOIC8
[ (SA602A) ]	
93CX66	93CX66@SOIC8
[ (SA602A) ]	

## PLD

PA7024	PA7024(J)@PLCC28
[ (SA008A) ]	
PA7024(JN)@PLCC28 [ (SA008A) ]	PA7024@SOIC24
[ (SA404) ]	
PA7128	PA7128@PLCC28
[ (SA008A) ]	
PA7128@SOIC28 [ (SA404) ]	
PA7140	
PA7140@PLCC44 [ (SA244) ]	PA7140@TQFP44
[ (SA245A) ]	
PA7536	PA7536@PLCC28
[ (SA008A) ]	
PA7536@SOIC28 [ (SA404) ]	
PA7540	
PA7540(J)@PLCC28 [ (SA008A) ]	PA7540(JN)@PLCC28

[ (SA008A) ]	
PA7572	PA7572@PLCC44
[ (SA244) ]	
PA7572@TQFP44 [ (SA245A) ]	
PEEL18CV8Z	
PEEL18CV8Z@PLCC20 [ (SA001A) ]	PEEL18CV8Z@SOIC20
[ (SA404) ]	
PEEL18CV8Z@TSOP20 [ (SA026) ]	
PEEL18LV8Z	
PEEL18LV8Z@PLCC20 [ (SA001A) ]	PEEL18LV8Z@SOIC20
[ (SA404) ]	
PEEL18LV8Z@TSOP20 [ (SA026) ]	
PEEL22CV10	
PEEL22CV10@PLCC28 [ (SA008A) ]	
PEEL22CV10A	
PEEL22CV10A@PLCC28 [ (SA008A) ]	PEEL22CV10A@SOIC24
[ (SA404) ]	
PEEL22CV10A@TSOP24 [ (SA026) ]	PEEL22CV10A
+	
PEEL22CV10A+@PLCC28 [ (SA008A) ]	PEEL22CV10A+@SOIC24
[ (SA404) ]	
PEEL22CV10A+@TSOP24 [ (SA026) ]	PEEL22CV10A+
+	
PEEL22CV10A++@PLCC28 [ (SA008A) ]	PEEL22CV10A++@SOIC24
[ (SA404) ]	
PEEL22CV10A++@TSOP24 [ (SA026) ]	
PEEL22CV10AZ	
PEEL22CV10AZ@PLCC28 [ (SA008A) ]	PEEL22CV10AZ@SOIC24
[ (SA404) ]	
PEEL22CV10AZ@TSOP24 [ (SA026) ]	PEEL22CV10AZ
+	
PEEL22CV10AZ+@PLCC28 [ (SA008A) ]	PEEL22CV10AZ+@SOIC24
[ (SA404) ]	
PEEL22CV10AZ+@TSOP24 [ (SA026) ]	PEEL22CV10AZ+
+	
PEEL22CV10AZ++@PLCC28 [ (SA008A) ]	PEEL22CV10AZ++@SOIC24
[ (SA404) ]	
PEEL22CV10AZ++@TSOP24 [ (SA026) ]	
PEEL22LV10AZ	
PEEL22LV10AZ@PLCC28 [ (SA008A) ]	PEEL22LV10AZ@SOIC24
[ (SA404) ]	
PEEL22LV10AZ@TSOP24 [ (SA026) ]	PEEL22LV10AZ
+	

PEEL22LV10AZ+@PLCC28 [(SA008A)]  
[(SA404)]  
PEEL22LV10AZ+@TSOP24 [(SA026)]  
+  
PEEL22LV10AZ++@PLCC28 [(SA008A)]  
[(SA404)]  
PEEL22LV10AZ++@TSOP24 [(SA026)]

PEEL22LV10AZ+@SOIC24  
  
PEEL22LV10AZ+  
  
PEEL22LV10AZ++@SOIC24

## IDT

### E (E) PROM/FRAM/NVRAM

ICS280@TSSOP16 [(SA026)]  
[(SA026)]

ICS281@TSSOP16

## IMT

### E (E) PROM/FRAM/NVRAM

IM29F001B  
[(SA015A1T)]  
IM29F001B@TSOP32 [(SA410T)]  
[(SA620)]  
IM29F001T  
[(SA015A1T)]  
IM29F001T@TSOP32 [(SA410T)]  
[(SA620)]  
IM29F002B  
[(SA015A1T)]  
IM29F002B@TSOP32 [(SA410T)]  
[(SA620)]  
IM29F002T  
[(SA015A1T)]  
IM29F002T@TSOP32 [(SA410T)]  
[(SA620)]  
IM29F004B  
[(SA015A1T)]  
IM29F004B@TSOP32 [(SA410T)]  
[(SA620)]  
IM29F004T

IM29F001B@PLCC32  
  
IM29F001B@VSOP32  
  
IM29F001T@PLCC32  
  
IM29F001T@VSOP32  
  
IM29F002B@PLCC32  
  
IM29F002B@VSOP32  
  
IM29F002T@PLCC32  
  
IM29F002T@VSOP32  
  
IM29F004B@PLCC32  
  
IM29F004B@VSOP32  
  
IM29F004T@PLCC32

[ (SA015A1T) ]	
IM29F004T@TSOP32 [ (SA410T) ]	IM29F004T@VSOP32
[ (SA620) ]	
IM29LV004B	IM29LV004B@PLCC32
[ (SA015A1T) ]	
IM29LV004B@TSOP32 [ (SA410T) ]	IM29LV004B@VSOP32
[ (SA620) ]	
IM29LV004T	IM29LV004T@PLCC32
[ (SA015A1T) ]	
IM29LV004T@TSOP32 [ (SA410T) ]	IM29LV004T@VSOP32
[ (SA620) ]	
IM29LV400B@PSOP44 [ (SA638) ]	IM29LV400B@TSOP48 [ (SA247-
B005) ]	
IM29LV400T@PSOP44 [ (SA638) ]	IM29LV400T@TSOP48 [ (SA247-
B005) ]	

## INTEL

### E (E) PROM / FRAM / NVRAM

27010	27010@PLCC32
[ (SA015A1T) ]	
27010@TSOP32 [ (SA410T) ]	
27128	
27128A	
27128B	
2716	
27210	
27256	
2732	
2732A	
27512	
2764	
2764A	
27C010	27C010@PLCC32
[ (SA015A1T) ]	
27C010@TSOP32 [ (SA410T) ]	
27C010A	
27C010A@PLCC32 [ (SA015A1T) ]	27C010A@TSOP32
[ (SA410T) ]	
27C020	27C020@PLCC32
[ (SA015A1T) ]	

27C020@TSOP32 [ (SA410T) ]  
27C040  
27C040@PLCC32 [ (SA015A1T) ] 27C040@TSOP32  
[ (SA410T) ]  
27C100 27C100@PLCC32  
[ (SA015A1T) ]  
27C100@TSOP32 [ (SA410T) ]  
27C128  
27C128@PLCC32 [ (SA015A1T) ]  
27C210  
27C210@PLCC44 [ (SA244) ]  
27C220  
27C220@PLCC44 [ (SA244) ]  
27C240  
27C240@PLCC44 [ (SA244) ]  
27C256  
27C256@PLCC32 [ (SA015A1T) ]  
27C400  
27C400@PLCC44 [ (SA244) ]  
27C512  
27C512@PLCC32 [ (SA015A1T) ]  
27C64  
27C64@PLCC32 [ (SA015A1T) ]  
27C800  
27S512  
2816A  
2817A  
2864A  
68C257 68C257@PLCC32  
[ (SA015A1T) ]  
87C256  
87C257  
87C257@PLCC32 [ (SA015A1T) ]  
87C64  
D27011  
D27513  
D27C011  
D27C513  
D28F256  
D28F256A  
D28F512  
DA28F016SA@SSOP56 [ (SA629A-B013) ]  
DA28F016SV@SSOP56 [ (SA629A-B013) ]

DA28F320J5(low)@SSOP56 [(SA629-B013)]  
DA28F320J5@SSOP56 [(SA629A-B013)]  
DA28F320J5A(low)@SSOP56 [(SA629-B013)]  
DA28F320J5A@SSOP56 [(SA629A-B013)]  
DA28F640J5@SSOP56 [(SA629A-B013)]  
DA28F640J5A@SSOP56 [(SA629A-B013)]  
DD28F032SA@TSOP56 [(SA628-B011)]  
DT28F016SA@SSOP56 [(SA629A-B013)]  
DT28F016SA@TSOP56 [(SA628-B011)]  
DT28F016SV@SSOP56 [(SA629A-B013)]  
DT28F016SV@TSOP56 [(SA628-B011)]  
DT28F160F3B@SSOP56 [(SA629A-B015)]  
DT28F160F3T@SSOP56 [(SA629A-B015)]  
DT28F160S3@SSOP56 [(SA629A-B013)]  
DT28F160S5@SSOP56 [(SA629A-B013)]  
DT28F320J5@SSOP56 [(SA629A-B013)]  
DT28F320J5A@SSOP56 [(SA629A-B013)]  
DT28F320S3@SSOP56 [(SA629A-B013)]  
DT28F320S5@SSOP56 [(SA629A-B013)]  
DT28F640J5@SSOP56 [(SA629A-B013)]  
DT28F640J5A@SSOP56 [(SA629A-B013)]  
DT28F800F3B@SSOP56 [(SA629A-B015)]  
DT28F800F3T@SSOP56 [(SA629A-B015)]  
E28F001BX-B@TSOP32 [(SA410T)] E28F001BX-T@TSOP32  
[(SA410T)]  
E28F002BCT@TSOP40 [(SA409T)] E28F002BEB@TSOP40  
[(SA409T)]  
E28F002BET@TSOP40 [(SA409T)] E28F002BLB@TSOP40  
[(SA409T)]  
E28F002BLT@TSOP40 [(SA409T)] E28F002BVB@TSOP40  
[(SA409T)]  
E28F002BVT@TSOP40 [(SA409T)] E28F002BXB@TSOP40  
[(SA409T)]  
E28F002BXT@TSOP40 [(SA409T)] E28F004B5B@TSOP40  
[(SA409T)]  
E28F004B5T@TSOP40 [(SA409T)] E28F004BEB@TSOP40  
[(SA409T)]  
E28F004BET@TSOP40 [(SA409T)] E28F004BLB@TSOP40  
[(SA409T)]  
E28F004BLT@TSOP40 [(SA409T)] E28F004BVB@TSOP40  
[(SA409T)]  
E28F004BVT@TSOP40 [(SA409T)] E28F004BXB@TSOP40  
[(SA409T)]

E28F004BXT@TSOP40 [(SA409T)]	E28F004S3@TSOP40
[(SA409T)]	
E28F004S5@TSOP40 [(SA409T)]	E28F004SC@TSOP40
[(SA409T)]	
E28F008BEB@TSOP40 [(SA409T)]	E28F008BET@TSOP40
[(SA409T)]	
E28F008BLB@TSOP40 [(SA409T)]	E28F008BLT@TSOP40
[(SA409T)]	
E28F008BVB@TSOP40 [(SA409T)]	E28F008BVT@TSOP40
[(SA409T)]	
E28F008BXB@TSOP40 [(SA409T)]	E28F008BXT@TSOP40
[(SA409T)]	
E28F008S3@TSOP40 [(SA409T)]	E28F008S5@TSOP40
[(SA409T)]	
E28F008SA@TSOP40 [(SA409T)]	E28F008SA-L@TSOP40
[(SA409T)]	
E28F008SC@TSOP40 [(SA409T)]	E28F010@TSOP32
[(SA410T)]	
E28F016S3@TSOP40 [(SA409T)]	E28F016S5@TSOP40
[(SA409T)]	
E28F016SA@TSOP56 [(SA628-B011)]	E28F016SC@TSOP40
[(SA409T)]	
E28F016SV@TSOP56 [(SA628-B011)]	E28F020@TSOP32
[(SA410T)]	
E28F128J3A@TSOP56 [(SA628-B018)]	E28F200B5B@TSOP48 [(SA247-
B005)]	
E28F200B5T@TSOP48 [(SA247-B005)]	E28F200BVB@TSOP56 [(SA628-
B012)]	
E28F200BVT@TSOP56 [(SA628-B012)]	E28F200BXB@TSOP56 [(SA628-
B012)]	
E28F200BXT@TSOP56 [(SA628-B012)]	E28F200CVB@TSOP48 [(SA247-
B005)]	
E28F200CVT@TSOP48 [(SA247-B005)]	E28F256@TSOP32
[(SA410T)]	
E28F256A@TSOP32 [(SA410T)]	E28F320J3A@TSOP56 [(SA628-
B018)]	
E28F320J5(low)@TSOP56 [(SA628-B011)]	
E28F320J5@TSOP56 [(SA628-B011)]	
E28F320J5A(low)@TSOP56 [(SA628-B011)]	
E28F320J5A@TSOP56 [(SA628-B011)]	E28F400B5B@TSOP48 [(SA247-
B005)]	
E28F400B5T@TSOP48 [(SA247-B005)]	E28F400BVB@TSOP56 [(SA628-
B012)]	



E28F400BVT@TSOP56 [(SA628-B012)] E28F400BXB@TSOP56 [(SA628-B012)]  
E28F400BXT@TSOP56 [(SA628-B012)] E28F400CVB@TSOP48 [(SA247-B005)]  
E28F400CVT@TSOP48 [(SA247-B005)] E28F512@TSOP32  
[(SA410T)]  
E28F640J3A@TSOP56 [(SA628-B018)] E28F800B5B@TSOP48 [(SA247-B005)]  
E28F800B5T@TSOP48 [(SA247-B005)] E28F800CEB@TSOP48 [(SA247-B005)]  
E28F800CET@TSOP48 [(SA247-B005)] E28F800CVB@TSOP48 [(SA247-B005)]  
E28F800CVT@TSOP48 [(SA247-B005)] E82802AA@TSOP40  
[(SA409T)] E82802AC@TSOP40  
E82802AB@TSOP40 [(SA409T)] [(SA409T)]  
F28F010@TSOP32 [(SA410T)]  
F28F020(REVERSE)@TSOP32 [(SA410T)]  
F28F020@TSOP32 [(SA410T)] F28F256@TSOP32  
[(SA410T)]  
F28F256A@TSOP32 [(SA410T)] F28F512@TSOP32  
[(SA410T)]  
G28F640J5@uBGA56 [(SA644A-B028A-Y072F001Y)]  
G28F640J5A@uBGA56 [(SA644A-B028A-Y072F001Y)]  
GE28F008B3BA@uBGA48 [(SA634)] GE28F008B3TA@uBGA48  
[(SA634)]  
GE28F128K18C@FBGA56 [(SA656D-B085A-T056F001Y)]  
GE28F128K3C@FBGA56 [(SA656D-B085A-T056F001Y)]  
GE28F128L18B@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F128L18T@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F128L30B@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F128L30T@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F128W18BC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W18BC@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W18BD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W18BD@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W18TC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W18TC@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W18TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W18TD@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W30BC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W30BC@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W30BD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]

GE28F128W30BD@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W30TC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W30TC@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W30TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W30TD@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F160B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3TC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3TD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160C3BC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F160C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F160C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F160C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F160C3TC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F160C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F160C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F160C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F256K18C@FBGA79 [(SA656B-B103A-T063F001Y)]  
GE28F256K3C@FBGA79 [(SA656B-B103A-T063F001Y)]  
GE28F256L18B@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F256L18T@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F256L30B@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F256L30T@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F320B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F320B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F320B3TC@uBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320B3TD@uBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3BC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3TC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320J3A@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320J3C@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320W18BC(NO EFP)@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18BC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18BE(SLOW)@VFBGA56 [(SA656C-B104A-T056F001Y)]

GE28F320W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18TC(NO EFP)@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W18TC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W30BC(NO EFP)@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W30BC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W30TC(NO EFP)@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W30TC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F640B3TC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F640C3BC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F640C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F640C3TC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F640C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F640J3C@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F640K18C@FBGA56 [(SA644A-B025B-Y072F001Y)]  
GE28F640K3C@FBGA56 [(SA644A-B025B-Y072F001Y)]  
GE28F640L18B@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640L18T@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640L30B@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640L30T@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640W18BC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18BC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18TC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18TC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W30BC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30BC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30TC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30TC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F800B3BA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F800B3TA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F800C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F800C3BA@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F800C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F800C3TA@VFBGA48 [(SA634A-B005A-Y048F001)]  
GT28F016C3BA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F016C3TA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F032C3BA@FBGA48 [(SA634A-B005A-Y048F001Y)]

GT28F032C3TA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F128W30BC(NO EFP)@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30BC@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30BD(NO EFP)@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30BD@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30TC(NO EFP)@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30TC@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30TD(NO EFP)@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30TD@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F160B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3BA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3TA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F160C3BA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F160C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F160C3TA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F320B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F320B3T@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F320C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F320C3BA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F320C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F320C3TA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F800B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F800B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]  
JS28F128J3C@TSOP56 [(SA628-B018)]  
JS28F128J3D@TSOP56 [(SA628-B018)]  
JS28F128P30B@TSOP56 [(SA628-B131)]  
JS28F128P30T@TSOP56 [(SA628-B131)]  
JS28F128P33B@TSOP56 [(SA628-B131)]  
JS28F128P33T@TSOP56 [(SA628-B131)]  
JS28F160B3BD@TSOP48 [(SA247-B005)]  
JS28F160B3TD@TSOP48 [(SA247-B005)]  
JS28F160C3BD@TSOP48 [(SA247-B005)]  
JS28F160C3TD@TSOP48 [(SA247-B005)]  
JS28F256P30B@TSOP56 [(SA628-B131)]  
JS28F256P30T@TSOP56 [(SA628-B131)]  
JS28F256P33B@TSOP56 [(SA628-B131)]  
JS28F256P33T@TSOP56 [(SA628-B131)]  
JS28F320B3BD@TSOP48 [(SA247-B005)]  
JS28F320B3TD@TSOP48 [(SA247-B005)]  
JS28F320C3BD@TSOP48 [(SA247-B005)]  
JS28F320C3TD@TSOP48 [(SA247-B005)]

JS28F320J3C@TSOP56 [(SA628-B018)]  
JS28F320J3D@TSOP56 [(SA628-B018)]  
JS28F640J3C@TSOP56 [(SA628-B018)]  
JS28F640J3D@TSOP56 [(SA628-B018)]  
JS28F640P30B(Low)@TSOP56 [(SA628-B131)]  
JS28F640P30B@TSOP56 [(SA628-B131)]  
JS28F640P30T@TSOP56 [(SA628-B131)]  
JS28F640P33B@TSOP56 [(SA628-B131)]  
JS28F640P33T@TSOP56 [(SA628-B131)]  
JS28F800C3BD@TSOP48 [(SA247-B005)]  
JS28F800C3TD@TSOP48 [(SA247-B005)]  
JZ48F4000L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
JZ48F4000L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
JZ48F4000L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
JZ48F4000L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
LZ38F4060L0YBB0@FBGA103 [(SA664F-B157A-W108F001Y)]  
LZ38F4060L0YTB0@FBGA103 [(SA664F-B157A-W108F001Y)]  
M28F010 M28F010@PLCC32  
[(SA015A1T)]  
M28F010@TSOP32 [(SA410T)] N28F001BN-B@PLCC32  
[(SA015A1T)]  
N28F001BN-T@PLCC32 [(SA015A1T)] N28F001BX-B@PLCC32  
[(SA015A1T)]  
N28F001BX-T@PLCC32 [(SA015A1T)] N28F010@PLCC32  
[(SA015A1T)]  
N28F020@PLCC32 [(SA015A1T)] N28F256@PLCC32  
[(SA015A1T)]  
N28F256A@PLCC32 [(SA015A1T)] N28F512@PLCC32  
[(SA015A1T)]  
N82802AA@PLCC32 [(SA015A1T)] N82802AB@PLCC32  
[(SA015A1T)]  
N82802AC@PLCC32 [(SA015A1T)]  
NZ48F4000L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
NZ48F4000L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
NZ48F4000L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
NZ48F4000L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
P27011  
P27128A  
P27128A@PLCC32 [(SA015A1T)]  
P27128B  
P27128B@PLCC32 [(SA015A1T)]  
P27256  
P27256@PLCC32 [(SA015A1T)]

P27512  
P27513  
P2764A  
P2764A@PLCC32 [ (SA015A1T) ]  
P27C011  
P27C128 P27C128@PLCC32  
[ (SA015A1T) ]  
P27C256 P27C256@PLCC32  
[ (SA015A1T) ]  
P27C513  
P27C64  
P27C64@PLCC32 [ (SA015A1T) ] P28F001BX-  
B  
P28F001BX-T P28F002BCT@TSOP40  
[ (SA409T) ]  
P28F010  
P28F020  
P28F256  
P28F256A  
P28F512  
P87C64  
P87C64@PLCC32 [ (SA015A1T) ] PA28F004S3@PSOP44  
[ (SA638) ]  
PA28F004S5@PSOP44 [ (SA638) ] PA28F004SC@PSOP44  
[ (SA638) ]  
PA28F008S3@PSOP44 [ (SA638) ] PA28F008S5@PSOP44  
[ (SA638) ]  
PA28F008SA@PSOP44 [ (SA638) ] PA28F008SA-L@PSOP44  
[ (SA638) ]  
PA28F008SC@PSOP44 [ (SA638) ] PA28F016S3@PSOP44  
[ (SA638) ]  
PA28F016S5@PSOP44 [ (SA638) ] PA28F016SC@PSOP44  
[ (SA638) ]  
PA28F200B5B@PSOP44 [ (SA638) ] PA28F200B5T@PSOP44  
[ (SA638) ]  
PA28F200BVB@PSOP44 [ (SA638) ] PA28F200BVT@PSOP44  
[ (SA638) ]  
PA28F200BXB@PSOP44 [ (SA638) ] PA28F200BXT@PSOP44  
[ (SA638) ]  
PA28F400B5B@PSOP44 [ (SA638) ] PA28F400B5T@PSOP44  
[ (SA638) ]  
PA28F400BVB@PSOP44 [ (SA638) ] PA28F400BVT@PSOP44  
[ (SA638) ]

PA28F400BXB@PSOP44 [ (SA638) ] PA28F400BXT@PSOP44  
[ (SA638) ]  
PA28F800B5B@PSOP44 [ (SA638) ] PA28F800B5T@PSOP44  
[ (SA638) ]  
PA28F800BVB@PSOP44 [ (SA638) ] PA28F800BVT@PSOP44  
[ (SA638) ]  
PC28F128J3C@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
PC28F128J3D@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
PC28F128P30B@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F128P30T@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F128P33B@EBGA64 [ (SA655K-B122A-T064F001Y) ]  
PC28F128P33T@EBGA64 [ (SA655K-B122A-T064F001Y) ]  
PC28F160C3BD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
PC28F160C3TD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
PC28F256P30B@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F256P30T@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F256P33B@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F256P33T@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F320C3BD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
PC28F320C3TD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
PC28F320J3C@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
PC28F320J3D@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
PC28F640J3C@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
PC28F640J3D@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
PC28F640P30B@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F640P30T@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F640P33B@EBGA64 [ (SA655K-B122A-T064F001Y) ]  
PC28F640P33T@EBGA64 [ (SA655K-B122A-T064F001Y) ]  
PC28F800C3BD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
PC28F800C3TD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
PF38F1020W0YBQ1@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1020W0YTQ1@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030C0ZBL0@FBGA72 [ (SA642R-B041A-T096F001Y) ]  
PF38F1030C0ZTL0@FBGA72 [ (SA642R-B041A-T096F001Y) ]  
PF38F1030W0YBQ2@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YBQE@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YBQF@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YCQ3@FBGA88 [ (SA642R-B180A-T096F001Y) ]  
PF38F1030W0YCQE@FBGA88 [ (SA642R-B180A-T096F001Y) ]  
PF38F1030W0YTQ2@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YTQE@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YTQF@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YUQ3@FBGA88 [ (SA642R-B180A-T096F001Y) ]

PF38F1030W0YUQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F1030W0ZBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F1030W0ZTQ0 ( SLOW ) @FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F1030W0ZTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2020W0ZBQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2020W0ZTQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YBQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YBQE@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YBQF@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YCQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2030W0YCQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2030W0YTQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YTQE@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YTQF@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YUQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2030W0YUQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2030W0ZBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0ZTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2040W0YBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2040W0YCQ1@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YCQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YCQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2040W0YUQ1@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YUQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YUQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F2040W0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3040L0YBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F3040L0YBQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0YBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F3040L0YTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0YTQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0YTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F3040L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3040L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3040M0Y1QE@FBGA88 [ ( SA642R-B303A-T096F001Y ) ]  
PF38F3040M0Y3QE@FBGA88 [ ( SA642R-B303A-T096F001Y ) ]  
PF38F3050L0YBQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]



PF38F3050L0YBQ2@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0YTQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0YTQ2@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3050L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3350LLZDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
PF38F3350W0ZDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
PF38F3350WWZDQ1@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
PF38F4050L0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YBQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YTQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4055L0YBQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4055L0YTQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4060L0YBB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4060L0YBB1@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4060L0YTB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4060L0YTB1@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4450LLYBQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LLYTQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LVYBQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LVYBQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LVYTQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LVYTQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4466LVYBQ0@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4466LVYTQ0@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF48F2000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
PF48F2000P0XTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
PF48F2000P0ZBQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
PF48F2000P0ZTQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
PF48F3000L0YBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF48F3000L0YTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF48F3000L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF48F3000L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF48F3000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]

PF48F3000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F3000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F3000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F3000W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF48F3000W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF48F3000W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF48F3000W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF48F3300W0YBQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
PF48F3300W0YDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
PF48F3300W0YTQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
PF48F4000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F4000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F4000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F4000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F4040LVYBQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F4040LVYBQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F4040LVYTQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F4040LVYTQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F5000M0Y1B0@FBGA105 [(SA664F-B301A-W108F001N)]  
PH28F128W18BC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18BC@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18BD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F128W18BD@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F128W18TC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18TC@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F128W18TD@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F160B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
PH28F160B3TD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
PH28F160C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F160C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F160C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F160C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
PH28F320B3TD@uBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F320C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F320C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F320W18BE(SLOW)@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F320W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F320W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]

PH28F320W18TE@VFBGA56 [ (SA656C-B104A-T056F001Y) ]  
PH28F640W18BD@VFBGA56 [ (SA656C-B104A-T056F001Y) ]  
PH28F640W18BE@VFBGA56 [ (SA656C-B104A-T056F001Y) ]  
PH28F640W18TD@VFBGA56 [ (SA656C-B104A-T056F001Y) ]  
PH28F640W18TE@VFBGA56 [ (SA656C-B104A-T056F001Y) ]  
QB25F016S33B60@SOIC8 [ (SA605A) ] QB25F016S33T60@SOIC8  
[ (SA605A) ]  
QB25F160S33B60@SOIC16 [ (SA404) ] QB25F160S33T60@SOIC16  
[ (SA404) ]  
QB25F320S33B60@SOIC16 [ (SA404) ] QB25F320S33T60@SOIC16  
[ (SA404) ]  
QB25F640S33B60@SOIC16 [ (SA404) ] QB25F640S33T60@SOIC16  
[ (SA404) ]  
QH25F016S33B60@SOIC8 [ (SA605A) ] QH25F016S33T60@SOIC8  
[ (SA605A) ]  
QH25F160S33B60@SOIC16 [ (SA404) ] QH25F160S33T60@SOIC16  
[ (SA404) ]  
QH25F320S33B60@SOIC16 [ (SA404) ] QH25F320S33T60@SOIC16  
[ (SA404) ]  
QH25F640S33B60@SOIC16 [ (SA404) ] QH25F640S33T60@SOIC16  
[ (SA404) ]  
RC28F128J3A@FBGA64 [ (SA655A-B054A-T064F001) ]  
RC28F128J3C@FBGA64 [ (SA655A-B054A-T064F001) ]  
RC28F128J3D@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
RC28F128K18C@FBGA64 [ (SA655G-B122A-T064F001Y) ]  
RC28F128K3C@FBGA64 [ (SA655G-B122A-T064F001Y) ]  
RC28F128P30B@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
RC28F128P30T@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
RC28F128P33B@EBGA64 [ (SA655K-B122A-T064F001Y) ]  
RC28F128P33T@EBGA64 [ (SA655K-B122A-T064F001Y) ]  
RC28F160C3BA@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
RC28F160C3BC@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
RC28F160C3BD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
RC28F160C3TA@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
RC28F160C3TC@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
RC28F160C3TD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
RC28F256J3A@FBGA96 [ (SA642A-B273-Y096N001N) ]  
RC28F256J3C@FBGA64 [ (SA655M-B054A-T064F001Y) ]  
RC28F256K18C@FBGA64 [ (SA655L-B286A-T064F001Y) ]  
RC28F256K3C@FBGA64 [ (SA655L-B286A-T064F001Y) ]  
RC28F256P30B@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
RC28F256P30T@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
RC28F256P33B@EBGA64 [ (SA655G-B122A-T064F001Y) ]

RC28F256P33T@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F320C3BA@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320C3BC@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320C3BD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320C3TA@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320C3TC@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320C3TD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320J3A@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
RC28F320J3C@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
RC28F320J3D@FBGA64 [ ( SA655A-B054A-T064F001Y ) ]  
RC28F640C3BC@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F640C3TC@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F640J3A@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
RC28F640J3C@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
RC28F640J3D@FBGA64 [ ( SA655A-B054A-T064F001Y ) ]  
RC28F640K18C@FBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F640K3C@FBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F640P30B@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F640P30T@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F640P33B@EBGA64 [ ( SA655K-B122A-T064F001Y ) ]  
RC28F640P33T@EBGA64 [ ( SA655K-B122A-T064F001Y ) ]  
RC28F800C3BA@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F800C3BD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F800C3TA@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F800C3TD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RD28F1602C3B@FBGA72 [ ( SA642E-B041A-T072F001 ) ]  
RD28F1602C3T@FBGA72 [ ( SA642E-B041A-T072F001 ) ]  
RD28F1604C3B@FBGA72 [ ( SA642E-B041A-T072F001 ) ]  
RD28F1604C3T@FBGA72 [ ( SA642E-B041A-T072F001 ) ]  
RD28F3204C3B@FBGA72 [ ( SA642E-B041A-T072F001 ) ]  
RD28F3204C3T@FBGA72 [ ( SA642E-B041A-T072F001 ) ]  
RD28F3204W18B(NO EFP)@FBGA96 [ ( SA642L-B082A-W080F001Y ) ]  
RD28F3204W18B@FBGA96 [ ( SA642L-B082A-W080F001Y ) ]  
RD28F3204W18T(NO EFP)@FBGA96 [ ( SA642L-B082A-W080F001Y ) ]  
RD28F3204W18T@FBGA96 [ ( SA642L-B082A-W080F001Y ) ]  
RD28F3204W30B(NO EFP)@FBGA96 [ ( SA642L-B082A-W080F001Y ) ]  
RD28F3204W30B@FBGA96 [ ( SA642L-B082A-W080F001Y ) ]  
RD28F3204W30T(NO EFP)@FBGA96 [ ( SA642L-B082A-W080F001Y ) ]  
RD28F3204W30T@FBGA96 [ ( SA642L-B082A-W080F001Y ) ]  
RD28F3208C3B@FBGA72 [ ( SA642E-B041A-T072F001 ) ]  
RD28F3208C3T@FBGA72 [ ( SA642E-B041A-T072F001 ) ]  
RD28F6408W18B(NO EFP)@FBGA96 [ ( SA642L-B082A-W080F001Y ) ]  
RD28F6408W18B@FBGA96 [ ( SA642L-B082A-W080F001Y ) ]

RD28F6408W18T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W18T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD38F1010C0ZB@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1010C0ZT@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1010W0YTL0@FBGA67 [(SA642E-B041A-T072F001N)]  
RD38F1020C0ZB@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1020C0ZT@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1020W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2010W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2010W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2010W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2010W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2020W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2020W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2020W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2020W0ZBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2020W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2020W0ZTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YBQE@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YBQF@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YTQE@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0YTQF@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0ZBQ0(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZBQ1(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]

RD38F2030W0ZBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2030W0ZTQ0(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZTQ1(NO EFP)@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2030W0ZTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2040W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2040W0YBQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2040W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2040W0YTQ1@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2040W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2040W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2220WWYBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2220WWYDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2220WWYTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2220WWZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2220WWZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2220WWZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2230WWYBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2230WWYDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2230WWYTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2230WWZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2230WWZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2230WWZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWYBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWYDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWYTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWZBQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWZDQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F2240WWZDQ1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
RD38F2240WWZTQ0@FBGA88 [(SA642A-B081A-Y096F001)]  
RD38F3040L0YBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3040L0YBQ1@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3040L0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F3040L0YTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3040L0YTQ1@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3040L0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F3040L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3040L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3050L0YBQ1@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3050L0YBQ2@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3050L0YTQ1@FBGA88 [(SA642I-B112A-W080F001)]  
RD38F3050L0YTQ2@FBGA88 [(SA642I-B112A-W080F001)]

RD38F3050L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F3050L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F3340LLYDQ1@FBGA88 [ ( SA642A-B091A-Y096F001 ) ]  
RD38F3350LLZDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD38F3350W0ZDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD38F3350WWZDQ1@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD38F4050L0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YBQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YTQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4055L0YBQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4055L0YTQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4055L0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4055L0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4450LVYBQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4450LVYBQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4450LVYTQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4450LVYTQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD48F2000L0YBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F2000L0YTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F2000L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F2000L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F2000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F2000P0XTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F2000P0ZBQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F2000P0ZTQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F2000W0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F2000W0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F2000W0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F2000W0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F2100W0YBQ0@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]  
RD48F2100W0YDQE@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]  
RD48F2100W0YTQ0@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]  
RD48F2200W0YBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0YDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]

RD48F2200W0YTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0ZBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0ZDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0ZTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F3000L0YBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F3000L0YTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F3000L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F3000L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F3000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F3000P0XTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F3000P0ZBQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F3000P0ZTQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F3000W0YBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD48F3000W0YTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD48F3000W0ZBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD48F3000W0ZTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD48F3300W0YBQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD48F3300W0YDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD48F3300W0YTQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD48F4000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F4000P0XTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F4000P0ZBQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F4000P0ZTQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F4040LVYBQ0 (BEEP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVYBQ0 (BP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVYTQ0 (BEEP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVYTQ0 (BP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVZBQ0 (BEEP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVZBQ0 (BP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVZTQ0 (BEEP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVZTQ0 (BP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
TB28F004S3@PSOP44 [ ( SA638 ) ] TB28F004S5@PSOP44  
[ ( SA638 ) ]  
TB28F004SC@PSOP44 [ ( SA638 ) ] TB28F008S3@PSOP44  
[ ( SA638 ) ]  
TB28F008S5@PSOP44 [ ( SA638 ) ] TB28F008SA@PSOP44  
[ ( SA638 ) ]  
TB28F008SA-L@PSOP44 [ ( SA638 ) ] TB28F008SC@PSOP44  
[ ( SA638 ) ]  
TB28F016S3@PSOP44 [ ( SA638 ) ] TB28F016S5@PSOP44  
[ ( SA638 ) ]  
TB28F016SC@PSOP44 [ ( SA638 ) ] TB28F200B5B@PSOP44  
[ ( SA638 ) ]



TB28F200B5T@PSOP44 [(SA638)] [(SA638)]	TB28F200BVB@PSOP44
TB28F200BVT@PSOP44 [(SA638)] [(SA638)]	TB28F200BXB@PSOP44
TB28F200BXT@PSOP44 [(SA638)] [(SA638)]	TB28F400B5B@PSOP44
TB28F400B5T@PSOP44 [(SA638)] [(SA638)]	TB28F400BVB@PSOP44
TB28F400BVT@PSOP44 [(SA638)] [(SA638)]	TB28F400BXB@PSOP44
TB28F400BXT@PSOP44 [(SA638)] [(SA638)]	TB28F800B5B@PSOP44
TB28F800B5T@PSOP44 [(SA638)] [(SA638)]	TB28F800BVB@PSOP44
TB28F800BVT@PSOP44 [(SA638)] [(SA409T)]	TE28F002BEB@TSOP40
TE28F002BET@TSOP40 [(SA409T)] [(SA409T)]	TE28F002BVB@TSOP40
TE28F002BVT@TSOP40 [(SA409T)] [(SA409T)]	TE28F002BXB@TSOP40
TE28F002BXT@TSOP40 [(SA409T)] [(SA409T)]	TE28F004BEB@TSOP40
TE28F004BET@TSOP40 [(SA409T)] [(SA409T)]	TE28F004BVB@TSOP40
TE28F004BVT@TSOP40 [(SA409T)] [(SA409T)]	TE28F004BXB@TSOP40
TE28F004BXT@TSOP40 [(SA409T)] [(SA409T)]	TE28F004S3@TSOP40
TE28F004S5@TSOP40 [(SA409T)] [(SA409T)]	TE28F004SC@TSOP40
TE28F008B3B@TSOP40 [(SA409T)] [(SA409T)]	TE28F008B3BA@TSOP40
TE28F008B3T@TSOP40 [(SA409T)] [(SA409T)]	TE28F008B3TA@TSOP40
TE28F008BEB@TSOP40 [(SA409T)] [(SA409T)]	TE28F008BET@TSOP40
TE28F008BVB@TSOP40 [(SA409T)] [(SA409T)]	TE28F008BVT@TSOP40
TE28F008C3BA@TSOP40 [(SA409T)] [(SA409T)]	TE28F008C3TA@TSOP40
TE28F008S3@TSOP40 [(SA409T)] [(SA409T)]	TE28F008S5@TSOP40
TE28F008SA@TSOP40 [(SA409T)]	TE28F008SA-L@TSOP40

[ (SA409T) ]  
TE28F008SC@TSOP40 [ (SA409T) ] TE28F016B3B@TSOP40  
[ (SA409T) ]  
TE28F016B3T@TSOP40 [ (SA409T) ] TE28F016C3BA@TSOP40  
[ (SA409T) ]  
TE28F016C3TA@TSOP40 [ (SA409T) ] TE28F016S3@TSOP40  
[ (SA409T) ]  
TE28F016S5@TSOP40 [ (SA409T) ] TE28F016SC@TSOP40  
[ (SA409T) ]  
TE28F128J3C@TSOP56 [ (SA628-B018) ]  
TE28F128J3D@TSOP56 [ (SA628-B018) ]  
TE28F128P30B@TSOP56 [ (SA628-B131) ]  
TE28F128P30T@TSOP56 [ (SA628-B131) ]  
TE28F128P33B@TSOP56 [ (SA628-B131) ]  
TE28F128P33T@TSOP56 [ (SA628-B131) ]  
TE28F160B3B@TSOP48 [ (SA247-B005) ]  
TE28F160B3BA@TSOP48 [ (SA247-B005) ]  
TE28F160B3BC@TSOP48 [ (SA247-B005) ]  
TE28F160B3BD@TSOP48 [ (SA247-B005) ]  
TE28F160B3T@TSOP48 [ (SA247-B005) ]  
TE28F160B3TA@TSOP48 [ (SA247-B005) ]  
TE28F160B3TC@TSOP48 [ (SA247-B005) ]  
TE28F160B3TD@TSOP48 [ (SA247-B005) ]  
TE28F160C3BA@TSOP48 [ (SA247-B005) ]  
TE28F160C3BC@TSOP48 [ (SA247-B005) ]  
TE28F160C3BD@TSOP48 [ (SA247-B005) ]  
TE28F160C3TA@TSOP48 [ (SA247-B005) ]  
TE28F160C3TC@TSOP48 [ (SA247-B005) ]  
TE28F160C3TD@TSOP48 [ (SA247-B005) ]  
TE28F160F3B@TSOP56 [ (SA628-B014) ]  
TE28F160F3T@TSOP56 [ (SA628-B014) ]  
TE28F160S3@TSOP56 [ (SA628-B011) ] TE28F160S5@TSOP56 [ (SA628-B011) ]  
TE28F200B5B@TSOP48 [ (SA247-B005) ]  
TE28F200B5T@TSOP48 [ (SA247-B005) ]  
TE28F200BVB@TSOP56 [ (SA628-B012) ]  
TE28F200BVT@TSOP56 [ (SA628-B012) ]  
TE28F200BXB@TSOP56 [ (SA628-B012) ]  
TE28F200BXT@TSOP56 [ (SA628-B012) ]  
TE28F200CEB@TSOP56 [ (SA628-B012) ]  
TE28F200CET@TSOP56 [ (SA628-B012) ]  
TE28F200CVB@TSOP48 [ (SA247-B005) ]  
TE28F200CVT@TSOP48 [ (SA247-B005) ]

TE28F256J3C@TSOP56 [ ( SA628-B018 ) ]  
TE28F256P30B@TSOP56 [ ( SA628-B131 ) ]  
TE28F256P30T@TSOP56 [ ( SA628-B131 ) ]  
TE28F256P33B@TSOP56 [ ( SA628-B131 ) ]  
TE28F256P33T@TSOP56 [ ( SA628-B131 ) ]  
TE28F320B3B@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3BA@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3BC@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3BD@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3T@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3TA@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3TC@TSOP48 [ ( SA247-B005 ) ]  
TE28F320B3TD@TSOP48 [ ( SA247-B005 ) ]  
TE28F320C3BA@TSOP48 [ ( SA247-B005 ) ]  
TE28F320C3BC@TSOP48 [ ( SA247-B005 ) ]  
TE28F320C3BD@TSOP48 [ ( SA247-B005 ) ]  
TE28F320C3TA@TSOP48 [ ( SA247-B005 ) ]  
TE28F320C3TC@TSOP48 [ ( SA247-B005 ) ]  
TE28F320C3TD@TSOP48 [ ( SA247-B005 ) ]  
TE28F320J3C@TSOP56 [ ( SA628-B018 ) ]  
TE28F320J3D@TSOP56 [ ( SA628-B018 ) ]  
TE28F400B3B@TSOP48 [ ( SA247-B005 ) ]  
TE28F400B3T@TSOP48 [ ( SA247-B005 ) ]  
TE28F400B5B@TSOP48 [ ( SA247-B005 ) ]  
TE28F400B5T@TSOP48 [ ( SA247-B005 ) ]  
TE28F400BVB@TSOP56 [ ( SA628-B012 ) ]  
TE28F400BVT@TSOP56 [ ( SA628-B012 ) ]  
TE28F400BXB@TSOP56 [ ( SA628-B012 ) ]  
TE28F400BXT@TSOP56 [ ( SA628-B012 ) ]  
TE28F400CEB@TSOP48 [ ( SA247-B005 ) ]  
TE28F400CET@TSOP48 [ ( SA247-B005 ) ]  
TE28F400CVB@TSOP48 [ ( SA247-B005 ) ]  
TE28F400CVT@TSOP48 [ ( SA247-B005 ) ]  
TE28F640B3BC@TSOP48 [ ( SA247-B005 ) ]  
TE28F640B3TC@TSOP48 [ ( SA247-B005 ) ]  
TE28F640C3BC@TSOP48 [ ( SA247-B005 ) ]  
TE28F640C3TC@TSOP48 [ ( SA247-B005 ) ]  
TE28F640J3C@TSOP56 [ ( SA628-B018 ) ]  
TE28F640J3D@TSOP56 [ ( SA628-B018 ) ]  
TE28F640P30B@TSOP56 [ ( SA628-B131 ) ]  
TE28F640P30T@TSOP56 [ ( SA628-B131 ) ]  
TE28F640P33B@TSOP56 [ ( SA628-B131 ) ]  
TE28F640P33T@TSOP56 [ ( SA628-B131 ) ]

TE28F800B3B@TSOP48 [ (SA247-B005) ]  
TE28F800B3BA@TSOP48 [ (SA247-B005) ]  
TE28F800B3T@TSOP48 [ (SA247-B005) ]  
TE28F800B3TA@TSOP48 [ (SA247-B005) ]  
TE28F800B5B@TSOP48 [ (SA247-B005) ]  
TE28F800B5T@TSOP48 [ (SA247-B005) ]  
TE28F800C3BA@TSOP48 [ (SA247-B005) ]  
TE28F800C3BD@TSOP48 [ (SA247-B005) ]  
TE28F800C3TA@TSOP48 [ (SA247-B005) ]  
TE28F800C3TD@TSOP48 [ (SA247-B005) ]  
TE28F800CEB@TSOP48 [ (SA247-B005) ]  
TE28F800CET@TSOP48 [ (SA247-B005) ]  
TE28F800CVB@TSOP48 [ (SA247-B005) ]  
TE28F800CVT@TSOP48 [ (SA247-B005) ]  
TE28F800F3B@TSOP56 [ (SA628-B014) ]  
TE28F800F3T@TSOP56 [ (SA628-B014) ]

## PLD

5C031 [ (SA001A) ]	5C031@PLCC20
5C032 [ (SA001A) ]	5C032@PLCC20
5C090 [ (SA244) ]	5C090@PLCC44
85C090 [ (SA244) ]	85C090-P44
85C220 [ (SA001A) ]	85C220@PLCC20
IPLD910 [ (SA244) ]	IPLD910-P44

## MICROCONTROLLER

8751BH [ (SA244) ]	8751BH@PLCC44
8752BH [ (SA244) ]	8752BH@PLCC44
8796BH@PLCC68(*) [ (SA648-B6803) ]	8796JF@PLCC68(*) [ (SA648-B6803) ]
8797BH@PGA68(*) [ (SA650-B6804) ]	8797BH@PLCC68(*) [ (SA648-

B6803) ]  
8797JF@PGA68 (\*) [ (SA650-B6804) ] 8797JF@PLCC68 (\*) [ (SA648-  
B6803) ]  
87C151SA 87C151SA@PLCC44  
[ (SA244) ]  
87C151SB 87C151SB@PLCC44  
[ (SA244) ]  
87C196CA@PLCC68 (\*) [ (SA648-B6805) ]  
87C196JQ@PLCC52 (\*) [ (SA647-B5201) ]  
87C196JR@PLCC52 (\*) [ (SA647-B5201) ]  
87C196JT@PLCC52 (\*) [ (SA647-B5201) ]  
87C196JV@PLCC52 (\*) [ (SA647-B5201) ]  
87C196KB@PLCC68 (\*) [ (SA648-B6801) ]  
87C196KC@PLCC68 (\*) [ (SA648-B6801) ]  
87C196KD@PLCC68 (\*) [ (SA648-B6801) ]  
87C196KQ@PLCC68 (\*) [ (SA648-B6802) ]  
87C196KR@PLCC68 (\*) [ (SA648-B6802) ]  
87C196KS@PLCC68 (\*) [ (SA648-B6802) ]  
87C196KT@PLCC68 (\*) [ (SA648-B6802) ]  
87C196LA@PLCC52 (\*) [ (SA647-B5201) ]  
87C196MC@PLCC84 (\*) [ (SA649-B8401) ]  
87C196MC@PQFP80 (\*) [ (TA026-B006) ]  
87C196MC@SDIP64 (\*) [ (SA651) ]  
87C196MH@PLCC84 (\*) [ (SA649-B8401) ]  
87C196MH@PQFP80 (\*) [ (TA026-B006) ]  
87C196MH@SDIP64 (\*) [ (SA651) ]  
87C251SA  
87C251SA@PLCC44 [ (SA244) ]  
87C251SB  
87C251SB@PLCC44 [ (SA244) ]  
87C251SP  
87C251SP@PLCC44 [ (SA244) ]  
87C251SQ  
87C251SQ@PLCC44 [ (SA244) ]  
87C51  
87C51@PLCC44 [ (SA244) ] 87C51@TQFP44  
[ (SA245A) ]  
87C51FA 87C51FA@PLCC44  
[ (SA244) ]  
87C51FA@TQFP44 [ (SA245A) ]  
87C51FB  
87C51FB@PLCC44 [ (SA244) ] 87C51FB@TQFP44  
[ (SA245A) ]

87C51FC [ (SA244) ]	87C51FC@PLCC44
87C51FC@TQFP44 [ (SA245A) ]	
87C51RA 87C51RA@PLCC44 [ (SA244) ] [ (SA245A) ]	87C51RA@TQFP44
87C51RB [ (SA244) ]	87C51RB@PLCC44
87C51RB@TQFP44 [ (SA245A) ]	
87C51RC 87C51RC@PLCC44 [ (SA244) ] [ (SA245A) ]	87C51RC@TQFP44
87C52 [ (SA244) ]	87C52@PLCC44
87C52@TQFP44 [ (SA245A) ]	
87C54 87C54@PLCC44 [ (SA244) ] [ (SA245A) ]	87C54@TQFP44
87C58 [ (SA244) ]	87C58@PLCC44
87C58@TQFP44 [ (SA245A) ] [ (SA244) ]	87L51FA@PLCC44
87L51FA@TQFP44 [ (SA245A) ] [ (SA244) ]	87L51FB@PLCC44
87L51FB@TQFP44 [ (SA245A) ] [ (SA244) ]	87L51FC@PLCC44
87L51FC@TQFP44 [ (SA245A) ] [ (SA244) ]	87L52@PLCC44
87L52@TQFP44 [ (SA245A) ] [ (SA244) ]	87L54@PLCC44
87L54@TQFP44 [ (SA245A) ] [ (SA244) ]	87L58@PLCC44
87L58@TQFP44 [ (SA245A) ]	

## INTEL-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

TE28F800C3TD@TSOP48 [ (SA247-B005) ]

## INTELSIL

## **E ( E ) PROM / FRAM / NVRAM**

HS-6617RH [ ( SA404 ) ]	HS-6617RH@SOIC24
HS-6617RH-T [ ( SA404 ) ]	HS-6617RH-T@SOIC24
HS-6883RH [ ( SA404 ) ]	HS-6883RH@SOIC24
HS-6883RH-T [ ( SA404 ) ]	HS-6883RH-T@SOIC24

## **ISSI**

### **E ( E ) PROM / FRAM / NVRAM**

IS24C01 [ ( SA666 ) ]	IS24C01@MSOP8
IS24C01@SOIC8 [ ( SA602A ) ] [ ( SA026 ) ]	IS24C01@TSSOP8
IS24C01B [ ( SA666 ) ]	IS24C01B@MSOP8
IS24C01B@SOIC8 [ ( SA602A ) ] [ ( SA026 ) ]	IS24C01B@TSSOP8
IS24C02 [ ( SA666 ) ]	IS24C02@MSOP8
IS24C02@SOIC8 [ ( SA602A ) ] [ ( SA026 ) ]	IS24C02@TSSOP8
IS24C02A IS24C02A@DFN8	
IS24C02A@MSOP8 [ ( SA666 ) ] [ ( SA602A ) ]	IS24C02A@SOIC8
IS24C02A@TSSOP8 [ ( SA026 ) ]	
IS24C02B IS24C02B@DFN8	
IS24C02B@MSOP8 [ ( SA666 ) ]	IS24C02B@MSOP8
IS24C02B@SOIC8 [ ( SA602A ) ] [ ( SA026 ) ]	IS24C02B@TSSOP8
IS24C02C IS24C02C@DFN8	
IS24C02C@MSOP8 [ ( SA666 ) ]	IS24C02C@SOIC8

[ (SA602A) ]	
IS24C02C@TSSOP8 [ (SA026) ]	
IS24C04	
IS24C04@MSOP8 [ (SA666) ]	IS24C04@SOIC8
[ (SA602A) ]	
IS24C04@TSSOP8 [ (SA026) ]	
IS24C04A	
IS24C04A@DFN8	IS24C04A@MSOP8
[ (SA666) ]	
IS24C04A@SOIC8 [ (SA602A) ]	IS24C04A@TSSOP8
[ (SA026) ]	
IS24C08	IS24C08@MSOP8
[ (SA666) ]	
IS24C08@SOIC8 [ (SA602A) ]	IS24C08@TSSOP8
[ (SA026) ]	
IS24C08A	
IS24C08A@DFN8	
IS24C08A@MSOP8 [ (SA666) ]	IS24C08A@SOIC8
[ (SA602A) ]	
IS24C08A@TSSOP8 [ (SA026) ]	
IS24C128	
IS24C128@SOIC8 [ (SA602A) ]	IS24C128@TSSOP14
[ (SA026) ]	
IS24C16	IS24C16@MSOP8
[ (SA666) ]	
IS24C16@SOIC8 [ (SA602A) ]	IS24C16@TSSOP8
[ (SA026) ]	
IS24C16A	IS24C16A@MSOP8
[ (SA666) ]	
IS24C16A@SOIC8 [ (SA602A) ]	IS24C16A@TSSOP8
[ (SA026) ]	
IS24C256	IS24C256@SOIC8
[ (SA602A) ]	
IS24C256@TSSOP14 [ (SA026) ]	
IS24C256A	
IS24C256A@SOIC8 [ (SA602A) ]	IS24C256A@TSSOP14
[ (SA026) ]	
IS24C32	IS24C32@SOIC8
[ (SA602A) ]	
IS24C32@TSSOP8 [ (SA026) ]	
IS24C32A	
IS24C32A@MSOP8 [ (SA666) ]	IS24C32A@SOIC8
[ (SA602A) ]	



IS24C32A@TSSOP8 [(SA026)]	
IS24C32B	
IS24C32B@SOIC8 [(SA602A)]	IS24C32B@TSSOP8
[(SA026)]	
IS24C64	IS24C64@SOIC8
[(SA602A)]	
IS24C64@TSSOP8 [(SA026)]	
IS24C64A	
IS24C64A@MSOP8 [(SA666)]	IS24C64A@SOIC8
[(SA602A)]	
IS24C64A@TSSOP8 [(SA026)]	
IS24C64B	
IS24C64B@SOIC8 [(SA602A)]	IS24C64B@TSSOP8
[(SA026)]	
IS24L128	
IS24L128@SOIC8(150mil) [(SA602A)]	
IS24L128@SOIC8(200mil) [(SA605A)]	
IS24L256	
IS24L256@SOIC8(150mil) [(SA602A)]	
IS24L256@SOIC8(200mil) [(SA605A)]	
IS25C01	IS25C01@SOIC8
[(SA602A)]	
IS25C01@TSSOP8 [(SA026)]	
IS25C02	
IS25C02@SOIC8 [(SA602A)]	IS25C02@TSSOP8
[(SA026)]	
IS25C04	IS25C04@SOIC8
[(SA602A)]	
IS25C04@TSSOP8 [(SA026)]	
IS25C08	
IS25C08@SOIC8 [(SA602A)]	IS25C08@TSSOP8
[(SA026)]	
IS25C128@SOIC8 [(SA602A)]	IS25C128@TSSOP8
[(SA026)]	
IS25C16	IS25C16@SOIC8
[(SA602A)]	
IS25C16@TSSOP8 [(SA026)]	IS25C256@SOIC8
[(SA602A)]	
IS25C256@TSSOP8 [(SA026)]	
IS25C32A	
IS25C32A@SOIC8 [(SA602A)]	IS25C32A@TSSOP8
[(SA026)]	
IS25C64A	IS25C64A@SOIC8

[ (SA602A) ]  
IS25C64A@TSSOP8 [ (SA026) ]  
IS27C010  
IS27C010@PLCC32 [ (SA015A1T) ] IS27C010@TSOP32  
[ (SA410T) ]  
IS27C020 IS27C020@PLCC32  
[ (SA015A1T) ]  
IS27C020@TSOP32 [ (SA410T) ]  
IS27C256  
IS27C256@PLCC32 [ (SA015A1T) ]  
IS27C512  
IS27C512@PLCC32 [ (SA015A1T) ] IS27C512@TSOP28  
[ (SA430T) ]  
IS27HC010 IS27HC010@PLCC32  
[ (SA015A1T) ]  
IS27HC010@TSOP32 [ (SA410T) ]  
IS27HC020  
IS27HC020@PLCC32 [ (SA015A1T) ] IS27HC020@TSOP32  
[ (SA410T) ]  
IS27HC256 IS27HC256@PLCC32  
[ (SA015A1T) ]  
IS27HC512 IS27HC512@PLCC32  
[ (SA015A1T) ]  
IS27HC512@TSOP28 [ (SA430T) ]  
IS27LV010  
IS27LV010@PLCC32 [ (SA015A1T) ] IS27LV010@TSOP32  
[ (SA410T) ]  
IS27LV512 IS27LV512@PLCC32  
[ (SA015A1T) ]  
IS27LV512@TSOP28 [ (SA430T) ]  
IS28F010  
IS28F010@PLCC32 [ (SA015A1T) ] IS28F010@TSOP32  
[ (SA410T) ]  
IS28F010A IS28F010A@PLCC32  
[ (SA015A1T) ]  
IS28F010A@TSOP32 [ (SA410T) ]  
IS28F020  
IS28F020@PLCC32 [ (SA015A1T) ] IS28F020@TSOP32  
[ (SA410T) ]  
IS29F010 IS29F010@PLCC32  
[ (SA015A1T) ]  
IS29F010@TSOP32 [ (SA410T) ]  
IS34C02

IS34C02@MSOP8 [ (SA666) ] IS34C02@SOIC8  
[ (SA602A) ]  
IS34C02@TSSOP8 [ (SA026) ]  
IS34C02B@DFN8  
IS34C02B@TSSOP8 [ (SA026) ]  
IS71V08F32AS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32BS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32CS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32DS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32ES08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32ESB08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32EST08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32FS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32GSB08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F32GST08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V08F64GS08@FBGA101 [ (SA642C-B032A-Y056F001) ]  
IS71V08F64GS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32AS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32B04@FBGA56 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32B04@FBGA59 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32BS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32CS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32DS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32ES08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32ESB08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32EST08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32FS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32GSB08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32GST08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32T04@FBGA56 [ (SA642A-B032A-Y096F001) ]  
IS71V16F32T04@FBGA59 [ (SA642A-B032A-Y096F001) ]  
IS71V16F64GS08@FBGA101 [ (SA642C-B032A-Y056F001) ]  
IS71V16F64GS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71VPCF32AS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71VPCF32BS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71VPCF32CS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71VPCF32DS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71VPCF32ES04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71VPCF32FS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
IS71VPCF64GS08@FBGA73 [ (SA642C-B032A-Y056F001) ]  
IS75V16F64GS16@FBGA65 [ (SA642C-B032A-Y056F001) ]  
IS75V16F64GS32@FBGA65 [ (SA642C-B032A-Y056F001) ]  
IS93C46 IS93C46@SOIC8

[(SA602A)]	
IS93C46A(08bit)	IS93C46A(08bit)@SOIC8
[(SA602A)]	
IS93C46A(08bit)@TSSOP8 [(SA026)]	IS93C46A
(16bit)	
IS93C46A(16bit)@SOIC8 [(SA602A)]	IS93C46A(16bit)@TSSOP8
[(SA026)]	
IS93C46B	IS93C46B@SOIC8
[(SA602A)]	
IS93C46B@TSSOP8 [(SA026)]	IS93C46D
(08bit)	
IS93C46D(08bit)@SOIC8 [(SA602A)]	IS93C46D(08bit)@TSSOP8
[(SA026)]	
IS93C46D(16bit)	IS93C46D(16bit)@SOIC8
[(SA602A)]	
IS93C46D(16bit)@TSSOP8 [(SA026)]	
IS93C56	
IS93C56@SOIC8 [(SA602A)]	IS93C56A
(08bit)	
IS93C56A(08bit)@SOIC8 [(SA602A)]	IS93C56A(08bit)@TSSOP8
[(SA026)]	
IS93C56A(16bit)	IS93C56A(16bit)@SOIC8
[(SA602A)]	
IS93C56A(16bit)@TSSOP8 [(SA026)]	
IS93C66	
IS93C66@SOIC8 [(SA602A)]	IS93C66A
(08bit)	
IS93C66A(08bit)@SOIC8 [(SA602A)]	IS93C66A(08bit)@TSSOP8
[(SA026)]	
IS93C66A(16bit)	IS93C66A(16bit)@SOIC8
[(SA602A)]	
IS93C66A(16bit)@TSSOP8 [(SA026)]	IS93C76A
(08bit)	
IS93C76A(08bit)@SOIC8 [(SA602A)]	IS93C76A(08bit)@TSSOP8
[(SA026)]	
IS93C76A(16bit)	IS93C76A(16bit)@SOIC8
[(SA602A)]	
IS93C76A(16bit)@TSSOP8 [(SA026)]	IS93C86A
(08bit)	
IS93C86A(08bit)@SOIC8 [(SA602A)]	IS93C86A(08bit)@TSSOP8
[(SA026)]	
IS93C86A(16bit)	IS93C86A(16bit)@SOIC8
[(SA602A)]	

IS93C86A(16bit)@TSSOP8 [(SA026)]

## DRAM & SRAM

IS61C1024 [(SA646)]	IS61C1024(300m)@SOJ32
IS61C1024(400m)@SOJ32 [(SA661)] [(SA410T)]	IS61C1024@TSOP32
IS61C1024L [(SA646)]	IS61C1024L(300m)@SOJ32
IS61C1024L(400m)@SOJ32 [(SA661)] [(SA410T)]	IS61C1024L@TSOP32
IS61C256AH [(SA646)]	IS61C256AH@SOJ28
IS61C256AH@TSOP28 [(SA430T)]	
IS61C512	
IS61C512(300m)@SOJ32 [(SA646)] [(SA661)]	IS61C512(400m)@SOJ32
IS61C512@TSOP32 [(SA410T)]	
IS61C64AH	
IS61C64AH@SOJ28 [(SA646)] [(SA430T)]	IS61C64AH@TSOP28
IS61LV256 [(SA646)]	IS61LV256@SOJ28
IS61LV256@TSOP28 [(SA430T)]	
IS61M256	
IS61M256@SOJ28 [(SA646)] [(SA430T)]	IS61M256@TSOP28
IS62C1024 [(SA646)]	IS62C1024(300m)@SOJ32
IS62C1024(400m)@SOJ32 [(SA661)] [(SA410T)]	IS62C1024@TSOP32
IS62C256 [(SA646)]	IS62C256@SOJ28
IS62C256@TSOP28 [(SA430T)]	
IS62C512	
IS62C512(300m)@SOJ32 [(SA646)] [(SA661)]	IS62C512(400m)@SOJ32
IS62C512@TSOP32 [(SA410T)]	
IS62C64	
IS62C64@SOJ28 [(SA646)] [(SA430T)]	IS62C64@TSOP28

IS62LV256  
[ (SA646) ]  
IS62LV256@TSOP28 [ (SA430T) ]

IS62LV256@SOJ28

## MICROCONTROLLER

IS89C51A  
[ (SA244) ]  
IS89C51A@TQFP44 [ (SA245A) ]  
IS89C52A  
IS89C52A@PLCC44 [ (SA244) ]  
[ (SA245A) ]

IS89C51A@PLCC44

IS89C52A@TQFP44

## ITHINKO

### MICROCONTROLLER

AX5012  
[ (SA404) ]  
AX5012(5.5V)@SOP24 [ (SA404) ]  
[ (SA404) ]  
AX5012@SOP24 [ (SA404) ]  
AX5012@SOP32

AX5012(5.0V)@SOP24

AX5012(6.0V)@SOP24

## K-LINE

### E ( E ) PROM / FRAM / NVRAM

K24C32  
[ (SA602A) ]  
K24C32@TSSOP8 [ (SA026) ]  
K24C64  
K24C64@SOIC8 [ (SA602A) ]  
[ (SA026) ]

K24C32@SOIC8

K24C64@TSSOP8

## LATTICE

### PLD

GAL16LV8 [ (SA001A) ]	GAL16LV8@PLCC20
GAL16LV8C [ (SA001A) ]	GAL16LV8C@PLCC20
GAL16LV8D [ (SA001A) ]	GAL16LV8D@PLCC20
GAL16LV8Z [ (SA001A) ]	GAL16LV8Z@PLCC20
GAL16LV8ZD [ (SA001A) ]	GAL16LV8ZD@PLCC20
GAL16V8 [ (SA001A) ]	GAL16V8@PLCC20
GAL16V8@SOIC20 [ (SA404) ]	
GAL16V8A GAL16V8A@PLCC20 [ (SA001A) ] [ (SA404) ]	GAL16V8A@SOIC20
GAL16V8B [ (SA001A) ]	GAL16V8B@PLCC20
GAL16V8B@SOIC20 [ (SA404) ]	
GAL16V8C GAL16V8C@PLCC20 [ (SA001A) ] [ (SA404) ]	GAL16V8C@SOIC20
GAL16V8D [ (SA001A) ]	GAL16V8D@PLCC20
GAL16V8D@SOIC20 [ (SA404) ]	
GAL16V8Z GAL16V8Z@PLCC20 [ (SA001A) ] [ (SA404) ]	GAL16V8Z@SOIC20
GAL18V10 [ (SA001A) ]	GAL18V10@PLCC20
GAL18V10B [ (SA001A) ]	GAL18V10B@PLCC20
GAL20LV8 [ (SA008A) ]	GAL20LV8@PLCC28
GAL20LV8Z [ (SA008A) ]	GAL20LV8Z@PLCC28
GAL20LV8ZD [ (SA008A) ]	GAL20LV8ZD@PLCC28
GAL20RA10 [ (SA008A) ]	GAL20RA10@PLCC28
GAL20RA10B [ (SA008A) ]	GAL20RA10B@PLCC28

GAL20V8	GAL20V8@PLCC28
[ (SA008A) ]	
GAL20V8A	GAL20V8A@PLCC28
[ (SA008A) ]	
GAL20V8B	GAL20V8B@PLCC28
[ (SA008A) ]	
GAL20V8C	GAL20V8C@PLCC28
[ (SA008A) ]	
GAL20V8Z	GAL20V8Z@PLCC28
[ (SA008A) ]	
GAL20XV10	GAL20XV10@PLCC28
[ (SA008A) ]	
GAL20XV10B	GAL20XV10B@PLCC28
[ (SA008A) ]	
GAL22LV10C	GAL22LV10C@PLCC28
[ (SA008A) ]	
GAL22LV10C@SOIC24 [ (SA404) ]	GAL22LV10C@TSOP24
[ (SA643) ]	
GAL22LV10D	GAL22LV10D@PLCC28
[ (SA008A) ]	
GAL22LV10D@SOIC24 [ (SA404) ]	GAL22LV10D@TSOP24
[ (SA643) ]	
GAL22LV10Z	GAL22LV10Z@PLCC28
[ (SA008A) ]	
GAL22LV10Z@SOIC24 [ (SA404) ]	GAL22LV10Z@TSOP24
[ (SA643) ]	
GAL22LV10ZD	GAL22LV10ZD@PLCC28
[ (SA008A) ]	
GAL22LV10ZD@SOIC24 [ (SA404) ]	GAL22LV10ZD@TSOP24
[ (SA643) ]	
GAL22V10	GAL22V10@PLCC28
[ (SA008A) ]	
GAL22V10@SOIC24 [ (SA404) ]	
GAL22V10A	
GAL22V10A@PLCC28 [ (SA008A) ]	GAL22V10A@SOIC24
[ (SA404) ]	
GAL22V10B	GAL22V10B@PLCC28
[ (SA008A) ]	
GAL22V10B@SOIC24 [ (SA404) ]	
GAL22V10BQ	
GAL22V10BQ@PLCC28 [ (SA008A) ]	GAL22V10BQ@SOIC24
[ (SA404) ]	
GAL22V10C	GAL22V10C@PLCC28



[ (SA008A) ]  
GAL22V10C@SOIC24 [ (SA404) ]  
GAL22V10D  
GAL22V10D@PLCC28 [ (SA008A) ] GAL22V10D@SOIC24  
[ (SA404) ]  
GAL26CLV12 GAL26CLV12@PLCC28  
[ (SA008A) ]  
GAL26CLV12@SOIC28 [ (SA404) ] GAL26CLV12@TSOP28  
[ (SA643) ]  
GAL26CLV12B GAL26CLV12B@PLCC28  
[ (SA008A) ]  
GAL26CLV12B@SOIC28 [ (SA404) ] GAL26CLV12B@TSOP28  
[ (SA643) ]  
GAL26CLV12C GAL26CLV12C@PLCC28  
[ (SA008A) ]  
GAL26CLV12C@SOIC28 [ (SA404) ] GAL26CLV12C@TSOP28  
[ (SA643) ]  
GAL26CLV12D GAL26CLV12D@PLCC28  
[ (SA008A) ]  
GAL26CLV12D@SOIC28 [ (SA404) ] GAL26CLV12D@TSOP28  
[ (SA643) ]  
GAL26CLV12Z GAL26CLV12Z@PLCC28  
[ (SA008A) ]  
GAL26CLV12Z@SOIC28 [ (SA404) ] GAL26CLV12Z@TSOP28  
[ (SA643) ]  
GAL26CLV12ZD GAL26CLV12ZD@PLCC28  
[ (SA008A) ]  
GAL26CLV12ZD@SOIC28 [ (SA404) ] GAL26CLV12ZD@TSOP28  
[ (SA643) ]  
GAL26CV12 GAL26CV12@PLCC28  
[ (SA008A) ]  
GAL26CV12B GAL26CV12B@PLCC28  
[ (SA008A) ]  
GAL26CV12C GAL26CV12C@PLCC28  
[ (SA008A) ]  
GAL26V12C GAL26V12C@PLCC28  
[ (SA008A) ]  
ispGAL22LV10 ispGAL22LV10(ISP) [ ISP-  
HEADER01 ]  
ispGAL22LV10@PLCC28 [ (SA008A) ]  
ispGAL22LV10@PLCC28(ISP) [ ISP-HEADER01 ]  
ispGAL22LV10@SSOP28 [ (SA626A) ]  
ispGAL22LV10@SSOP28(ISP) [ ISP-HEADER01 ]

ispGAL22LV10A  
ispGAL22LV10A(ISP) [ISP-HEADER01]  
ispGAL22LV10A@PLCC28 [(SA008A)]  
ispGAL22LV10A@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10A@SSOP28 [(SA626A)]  
ispGAL22LV10A@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22LV10B  
ispGAL22LV10B(ISP) [ISP-HEADER01]  
ispGAL22LV10B@PLCC28 [(SA008A)]  
ispGAL22LV10B@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10B@SSOP28 [(SA626A)]  
ispGAL22LV10B@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22LV10C  
ispGAL22LV10C(ISP) [ISP-HEADER01]  
ispGAL22LV10C@PLCC28 [(SA008A)]  
ispGAL22LV10C@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10C@SSOP28 [(SA626A)]  
ispGAL22LV10C@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22LV10D  
ispGAL22LV10D(ISP) [ISP-HEADER01]  
ispGAL22LV10D@PLCC28 [(SA008A)]  
ispGAL22LV10D@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10D@SSOP28 [(SA626A)]  
ispGAL22LV10D@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22V10AB@PLCC28 [(SA008A)]      ispGAL22V10AB@QFN32  
[(SA686)]  
ispGAL22V10AC@PLCC28 [(SA008A)]      ispGAL22V10AC@QFN32  
[(SA686)]  
ispGAL22V10AV@PLCC28 [(SA008A)]      ispGAL22V10AV@QFN32  
[(SA686)]  
ispGAL22V10C(UES)@PLCC28 [(SA008A)]  
ispGAL22V10C@PLCC28 [(SA008A)]      ispLSI1016@PLCC44  
[(SA244)]  
ispLSI1016@TQFP44 [(SA245A)]      ispLSI1016E@PLCC44  
[(SA244)]  
ispLSI1016E@TQFP44 [(SA245A)]      ispLSI1016EA@PLCC44  
[(SA244)]  
ispLSI1016EA@TQFP44 [(SA245A)]      ispLSI2032@PLCC44  
[(SA244)]  
ispLSI2032@TQFP44 [(SA245A)]      ispLSI2032A@PLCC44  
[(SA244)]  
ispLSI2032A@TQFP44 [(SA245A)]      ispLSI2032A@TQFP48  
[(SA248)]

ispLSI2032E@PLCC44 [(SA244)] [(SA245A)]	ispLSI2032E@TQFP44
ispLSI2032E@TQFP48 [(SA248)] [(SA244)]	ispLSI2032V@PLCC44
ispLSI2032V@TQFP44 [(SA245A)] [(SA248)]	ispLSI2032V@TQFP48
ispLSI2032VE@PLCC44 [(SA244)] [(SA245A)]	ispLSI2032VE@TQFP44
ispLSI2064A@PLCC44 [(SA244)] [(SA245A)]	ispLSI2064A@TQFP44
ispLSI2064V@PLCC44 [(SA244)] [(SA245A)]	ispLSI2064V@TQFP44
ispLSI2064VE@PLCC44 [(SA244)] [(SA245A)]	ispLSI2064VE@TQFP44
LC4032B@TQFP44 [(SA245A)]	
LC4032B@TQFP44(ISP) [ISP-HEADER01]	
LC4032B@TQFP48 [(SA248)]	
LC4032B@TQFP48(ISP) [ISP-HEADER01]	
LC4032C@TQFP44 [(SA245A)]	
LC4032C@TQFP44(ISP) [ISP-HEADER01]	
LC4032C@TQFP48 [(SA248)]	
LC4032C@TQFP48(ISP) [ISP-HEADER01]	
LC4032V@TQFP44 [(SA245A)]	
LC4032V@TQFP44(ISP) [ISP-HEADER01]	
LC4032V@TQFP48 [(SA248)]	
LC4032V@TQFP48(ISP) [ISP-HEADER01]	
LC4032ZC@csBGA56 [(SA699+B161)]	
LC4032ZC@csBGA56(ISP) [ISP-HEADER01]	
LC4032ZC@TQFP48 [(SA248)]	
LC4032ZC@TQFP48(ISP) [ISP-HEADER01]	
LC4032ZE@TQFP48 [(SA248)]	
LC4032ZE@TQFP48(ISP) [ISP-HEADER01]	
LC4064B@TQFP44 [(SA245A)]	
LC4064B@TQFP44(ISP) [ISP-HEADER01]	
LC4064B@TQFP48 [(SA248)]	
LC4064B@TQFP48(ISP) [ISP-HEADER01]	
LC4064C@TQFP44 [(SA245A)]	
LC4064C@TQFP44(ISP) [ISP-HEADER01]	
LC4064C@TQFP48 [(SA248)]	
LC4064C@TQFP48(ISP) [ISP-HEADER01]	
LC4064V@TQFP44 [(SA245A)]	
LC4064V@TQFP44(ISP) [ISP-HEADER01]	
LC4064V@TQFP48 [(SA248)]	

LC4064V@TQFP48 (ISP) [ISP-HEADER01]  
LC4064ZC@TQFP48 [(SA248)] LC4064ZE@TQFP48  
[(SA248)]  
LCMXO1200C-FT256 (ISP) [ISP-HEADER01]  
LCMXO1200C-FT324 (ISP) [ISP-HEADER01]  
LCMXO1200C-FTN256 (ISP) [ISP-HEADER01]  
LCMXO1200C-FTN324 (ISP) [ISP-HEADER01]  
LCMXO1200C-M100 (ISP) [ISP-HEADER01]  
LCMXO1200C-M132 (ISP) [ISP-HEADER01]  
LCMXO1200C-MN100 (ISP) [ISP-HEADER01]  
LCMXO1200C-MN132 (ISP) [ISP-HEADER01]  
LCMXO1200C-T100 (ISP) [ISP-HEADER01]  
LCMXO1200C-T144 (ISP) [ISP-HEADER01]  
LCMXO1200C-TN100 (ISP) [ISP-HEADER01]  
LCMXO1200C-TN144 (ISP) [ISP-HEADER01]  
LCMXO1200E-FT256 (ISP) [ISP-HEADER01]  
LCMXO1200E-FT324 (ISP) [ISP-HEADER01]  
LCMXO1200E-FTN256 (ISP) [ISP-HEADER01]  
LCMXO1200E-FTN324 (ISP) [ISP-HEADER01]  
LCMXO1200E-M100 (ISP) [ISP-HEADER01]  
LCMXO1200E-M132 (ISP) [ISP-HEADER01]  
LCMXO1200E-MN100 (ISP) [ISP-HEADER01]  
LCMXO1200E-MN132 (ISP) [ISP-HEADER01]  
LCMXO1200E-T100 (ISP) [ISP-HEADER01]  
LCMXO1200E-T144 (ISP) [ISP-HEADER01]  
LCMXO1200E-TN100 (ISP) [ISP-HEADER01]  
LCMXO1200E-TN144 (ISP) [ISP-HEADER01]  
LCMXO2280C-FT256 (ISP) [ISP-HEADER01]  
LCMXO2280C-FT324 (ISP) [ISP-HEADER01]  
LCMXO2280C-FTN256 (ISP) [ISP-HEADER01]  
LCMXO2280C-FTN324 (ISP) [ISP-HEADER01]  
LCMXO2280C-M100 (ISP) [ISP-HEADER01]  
LCMXO2280C-M132 (ISP) [ISP-HEADER01]  
LCMXO2280C-MN100 (ISP) [ISP-HEADER01]  
LCMXO2280C-MN132 (ISP) [ISP-HEADER01]  
LCMXO2280C-T100 (ISP) [ISP-HEADER01]  
LCMXO2280C-T144 (ISP) [ISP-HEADER01]  
LCMXO2280C-TN100 (ISP) [ISP-HEADER01]  
LCMXO2280C-TN144 (ISP) [ISP-HEADER01]  
LCMXO2280E-FT256 (ISP) [ISP-HEADER01]  
LCMXO2280E-FT324 (ISP) [ISP-HEADER01]  
LCMXO2280E-FTN256 (ISP) [ISP-HEADER01]  
LCMXO2280E-FTN324 (ISP) [ISP-HEADER01]

LCMXO2280E-M100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO2280E-M132 ( ISP ) [ ISP-HEADER01 ]  
LCMXO2280E-MN100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO2280E-MN132 ( ISP ) [ ISP-HEADER01 ]  
LCMXO2280E-T100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO2280E-T144 ( ISP ) [ ISP-HEADER01 ]  
LCMXO2280E-TN100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO2280E-TN144 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256C-FT256 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256C-FT324 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256C-FTN256 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256C-FTN324 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256C-M100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256C-M132 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256C-MN100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256C-MN132 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256C-T100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256C-T144 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256C-TN100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256C-TN144 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256E-FT256 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256E-FT324 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256E-FTN256 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256E-FTN324 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256E-M100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256E-M132 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256E-MN100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256E-MN132 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256E-T100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256E-T144 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256E-TN100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO256E-TN144 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640C-FT256 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640C-FT324 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640C-FTN256 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640C-FTN324 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640C-M100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640C-M132 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640C-MN100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640C-MN132 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640C-T100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640C-T144 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640C-TN100 ( ISP ) [ ISP-HEADER01 ]

LCMXO640C-TN144 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640E-FT256 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640E-FT324 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640E-FTN256 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640E-FTN324 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640E-M100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640E-M132 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640E-MN100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640E-MN132 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640E-T100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640E-T144 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640E-TN100 ( ISP ) [ ISP-HEADER01 ]  
LCMXO640E-TN144 ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-3F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-3F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-3F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-3F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-3FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-3FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-3FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-3FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-4F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-4F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-4F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-4F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-4FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-4FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-4FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-4FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-5F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-5F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-5F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-5F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-5FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-5FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-5FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP10C-5FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-3F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-3F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-3F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-3F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-3FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP10E-3FN256I ( ISP ) [ ISP-HEADER01 ]

LFXP10E-3FN388C (ISP) [ISP-HEADER01]  
LFXP10E-3FN388I (ISP) [ISP-HEADER01]  
LFXP10E-4F256C (ISP) [ISP-HEADER01]  
LFXP10E-4F256I (ISP) [ISP-HEADER01]  
LFXP10E-4F388C (ISP) [ISP-HEADER01]  
LFXP10E-4F388I (ISP) [ISP-HEADER01]  
LFXP10E-4FN256C (ISP) [ISP-HEADER01]  
LFXP10E-4FN256I (ISP) [ISP-HEADER01]  
LFXP10E-4FN388C (ISP) [ISP-HEADER01]  
LFXP10E-4FN388I (ISP) [ISP-HEADER01]  
LFXP10E-5F256C (ISP) [ISP-HEADER01]  
LFXP10E-5F256I (ISP) [ISP-HEADER01]  
LFXP10E-5F388C (ISP) [ISP-HEADER01]  
LFXP10E-5F388I (ISP) [ISP-HEADER01]  
LFXP10E-5FN256C (ISP) [ISP-HEADER01]  
LFXP10E-5FN256I (ISP) [ISP-HEADER01]  
LFXP10E-5FN388C (ISP) [ISP-HEADER01]  
LFXP10E-5FN388I (ISP) [ISP-HEADER01]  
LFXP15C-3F256C (ISP) [ISP-HEADER01]  
LFXP15C-3F256I (ISP) [ISP-HEADER01]  
LFXP15C-3F388C (ISP) [ISP-HEADER01]  
LFXP15C-3F388I (ISP) [ISP-HEADER01]  
LFXP15C-3F484C (ISP) [ISP-HEADER01]  
LFXP15C-3F484I (ISP) [ISP-HEADER01]  
LFXP15C-3FN256C (ISP) [ISP-HEADER01]  
LFXP15C-3FN256I (ISP) [ISP-HEADER01]  
LFXP15C-3FN388C (ISP) [ISP-HEADER01]  
LFXP15C-3FN388I (ISP) [ISP-HEADER01]  
LFXP15C-3FN484C (ISP) [ISP-HEADER01]  
LFXP15C-3FN484I (ISP) [ISP-HEADER01]  
LFXP15C-4F256C (ISP) [ISP-HEADER01]  
LFXP15C-4F256I (ISP) [ISP-HEADER01]  
LFXP15C-4F388C (ISP) [ISP-HEADER01]  
LFXP15C-4F388I (ISP) [ISP-HEADER01]  
LFXP15C-4F484C (ISP) [ISP-HEADER01]  
LFXP15C-4F484I (ISP) [ISP-HEADER01]  
LFXP15C-4FN256C (ISP) [ISP-HEADER01]  
LFXP15C-4FN256I (ISP) [ISP-HEADER01]  
LFXP15C-4FN388C (ISP) [ISP-HEADER01]  
LFXP15C-4FN388I (ISP) [ISP-HEADER01]  
LFXP15C-4FN484C (ISP) [ISP-HEADER01]  
LFXP15C-4FN484I (ISP) [ISP-HEADER01]  
LFXP15C-5F256C (ISP) [ISP-HEADER01]

LFXP15C-5F256I (ISP) [ISP-HEADER01]  
LFXP15C-5F388C (ISP) [ISP-HEADER01]  
LFXP15C-5F388I (ISP) [ISP-HEADER01]  
LFXP15C-5F484C (ISP) [ISP-HEADER01]  
LFXP15C-5F484I (ISP) [ISP-HEADER01]  
LFXP15C-5FN256C (ISP) [ISP-HEADER01]  
LFXP15C-5FN256I (ISP) [ISP-HEADER01]  
LFXP15C-5FN388C (ISP) [ISP-HEADER01]  
LFXP15C-5FN388I (ISP) [ISP-HEADER01]  
LFXP15C-5FN484C (ISP) [ISP-HEADER01]  
LFXP15C-5FN484I (ISP) [ISP-HEADER01]  
LFXP15E-3F256C (ISP) [ISP-HEADER01]  
LFXP15E-3F256I (ISP) [ISP-HEADER01]  
LFXP15E-3F388C (ISP) [ISP-HEADER01]  
LFXP15E-3F388I (ISP) [ISP-HEADER01]  
LFXP15E-3F484C (ISP) [ISP-HEADER01]  
LFXP15E-3F484I (ISP) [ISP-HEADER01]  
LFXP15E-3FN256C (ISP) [ISP-HEADER01]  
LFXP15E-3FN256I (ISP) [ISP-HEADER01]  
LFXP15E-3FN388C (ISP) [ISP-HEADER01]  
LFXP15E-3FN388I (ISP) [ISP-HEADER01]  
LFXP15E-3FN484C (ISP) [ISP-HEADER01]  
LFXP15E-3FN484I (ISP) [ISP-HEADER01]  
LFXP15E-4F256C (ISP) [ISP-HEADER01]  
LFXP15E-4F256I (ISP) [ISP-HEADER01]  
LFXP15E-4F388C (ISP) [ISP-HEADER01]  
LFXP15E-4F388I (ISP) [ISP-HEADER01]  
LFXP15E-4F484C (ISP) [ISP-HEADER01]  
LFXP15E-4F484I (ISP) [ISP-HEADER01]  
LFXP15E-4FN256C (ISP) [ISP-HEADER01]  
LFXP15E-4FN256I (ISP) [ISP-HEADER01]  
LFXP15E-4FN388C (ISP) [ISP-HEADER01]  
LFXP15E-4FN388I (ISP) [ISP-HEADER01]  
LFXP15E-4FN484C (ISP) [ISP-HEADER01]  
LFXP15E-4FN484I (ISP) [ISP-HEADER01]  
LFXP15E-5F256C (ISP) [ISP-HEADER01]  
LFXP15E-5F256I (ISP) [ISP-HEADER01]  
LFXP15E-5F388C (ISP) [ISP-HEADER01]  
LFXP15E-5F388I (ISP) [ISP-HEADER01]  
LFXP15E-5F484C (ISP) [ISP-HEADER01]  
LFXP15E-5F484I (ISP) [ISP-HEADER01]  
LFXP15E-5FN256C (ISP) [ISP-HEADER01]  
LFXP15E-5FN256I (ISP) [ISP-HEADER01]



LFXP15E-5FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-5FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-5FN484C ( ISP ) [ ISP-HEADER01 ]  
LFXP15E-5FN484I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-3F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-3F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-3F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-3F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-3F484C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-3F484I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-3FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-3FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-3FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-3FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-3FN484C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-3FN484I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-4F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-4F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-4F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-4F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-4F484C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-4F484I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-4FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-4FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-4FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-4FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-4FN484C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-4FN484I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5F388C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5F388I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5F484C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5F484I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5FN388C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5FN388I ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5FN484C ( ISP ) [ ISP-HEADER01 ]  
LFXP20C-5FN484I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-3F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-3F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP20E-3F388C ( ISP ) [ ISP-HEADER01 ]

LFXP20E-3F388I (ISP) [ISP-HEADER01]  
LFXP20E-3F484C (ISP) [ISP-HEADER01]  
LFXP20E-3F484I (ISP) [ISP-HEADER01]  
LFXP20E-3FN256C (ISP) [ISP-HEADER01]  
LFXP20E-3FN256I (ISP) [ISP-HEADER01]  
LFXP20E-3FN388C (ISP) [ISP-HEADER01]  
LFXP20E-3FN388I (ISP) [ISP-HEADER01]  
LFXP20E-3FN484C (ISP) [ISP-HEADER01]  
LFXP20E-3FN484I (ISP) [ISP-HEADER01]  
LFXP20E-4F256C (ISP) [ISP-HEADER01]  
LFXP20E-4F256I (ISP) [ISP-HEADER01]  
LFXP20E-4F388C (ISP) [ISP-HEADER01]  
LFXP20E-4F388I (ISP) [ISP-HEADER01]  
LFXP20E-4F484C (ISP) [ISP-HEADER01]  
LFXP20E-4F484I (ISP) [ISP-HEADER01]  
LFXP20E-4FN256C (ISP) [ISP-HEADER01]  
LFXP20E-4FN256I (ISP) [ISP-HEADER01]  
LFXP20E-4FN388C (ISP) [ISP-HEADER01]  
LFXP20E-4FN388I (ISP) [ISP-HEADER01]  
LFXP20E-4FN484C (ISP) [ISP-HEADER01]  
LFXP20E-4FN484I (ISP) [ISP-HEADER01]  
LFXP20E-5F256C (ISP) [ISP-HEADER01]  
LFXP20E-5F256I (ISP) [ISP-HEADER01]  
LFXP20E-5F388C (ISP) [ISP-HEADER01]  
LFXP20E-5F388I (ISP) [ISP-HEADER01]  
LFXP20E-5F484C (ISP) [ISP-HEADER01]  
LFXP20E-5F484I (ISP) [ISP-HEADER01]  
LFXP20E-5FN256C (ISP) [ISP-HEADER01]  
LFXP20E-5FN256I (ISP) [ISP-HEADER01]  
LFXP20E-5FN388C (ISP) [ISP-HEADER01]  
LFXP20E-5FN388I (ISP) [ISP-HEADER01]  
LFXP20E-5FN484C (ISP) [ISP-HEADER01]  
LFXP20E-5FN484I (ISP) [ISP-HEADER01]  
LFXP3C-3Q208C (ISP) [ISP-HEADER01]  
LFXP3C-3Q208I (ISP) [ISP-HEADER01]  
LFXP3C-3QN208C (ISP) [ISP-HEADER01]  
LFXP3C-3QN208I (ISP) [ISP-HEADER01]  
LFXP3C-3T100C (ISP) [ISP-HEADER01]  
LFXP3C-3T100I (ISP) [ISP-HEADER01]  
LFXP3C-3T144C (ISP) [ISP-HEADER01]  
LFXP3C-3T144I (ISP) [ISP-HEADER01]  
LFXP3C-3TN100C (ISP) [ISP-HEADER01]  
LFXP3C-3TN100I (ISP) [ISP-HEADER01]

LFXP3C-3TN144C( ISP) [ ISP-HEADER01 ]  
LFXP3C-3TN144I( ISP) [ ISP-HEADER01 ]  
LFXP3C-4Q208C( ISP) [ ISP-HEADER01 ]  
LFXP3C-4Q208I( ISP) [ ISP-HEADER01 ]  
LFXP3C-4QN208C( ISP) [ ISP-HEADER01 ]  
LFXP3C-4QN208I( ISP) [ ISP-HEADER01 ]  
LFXP3C-4T100C( ISP) [ ISP-HEADER01 ]  
LFXP3C-4T100I( ISP) [ ISP-HEADER01 ]  
LFXP3C-4T144C( ISP) [ ISP-HEADER01 ]  
LFXP3C-4T144I( ISP) [ ISP-HEADER01 ]  
LFXP3C-4TN100C( ISP) [ ISP-HEADER01 ]  
LFXP3C-4TN100I( ISP) [ ISP-HEADER01 ]  
LFXP3C-4TN144C( ISP) [ ISP-HEADER01 ]  
LFXP3C-4TN144I( ISP) [ ISP-HEADER01 ]  
LFXP3C-5Q208C( ISP) [ ISP-HEADER01 ]  
LFXP3C-5Q208I( ISP) [ ISP-HEADER01 ]  
LFXP3C-5QN208C( ISP) [ ISP-HEADER01 ]  
LFXP3C-5QN208I( ISP) [ ISP-HEADER01 ]  
LFXP3C-5T100C( ISP) [ ISP-HEADER01 ]  
LFXP3C-5T100I( ISP) [ ISP-HEADER01 ]  
LFXP3C-5T144C( ISP) [ ISP-HEADER01 ]  
LFXP3C-5T144I( ISP) [ ISP-HEADER01 ]  
LFXP3C-5TN100C( ISP) [ ISP-HEADER01 ]  
LFXP3C-5TN100I( ISP) [ ISP-HEADER01 ]  
LFXP3C-5TN144C( ISP) [ ISP-HEADER01 ]  
LFXP3C-5TN144I( ISP) [ ISP-HEADER01 ]  
LFXP3E-3Q208C( ISP) [ ISP-HEADER01 ]  
LFXP3E-3Q208I( ISP) [ ISP-HEADER01 ]  
LFXP3E-3QN208C( ISP) [ ISP-HEADER01 ]  
LFXP3E-3QN208I( ISP) [ ISP-HEADER01 ]  
LFXP3E-3T100C( ISP) [ ISP-HEADER01 ]  
LFXP3E-3T100I( ISP) [ ISP-HEADER01 ]  
LFXP3E-3T144C( ISP) [ ISP-HEADER01 ]  
LFXP3E-3T144I( ISP) [ ISP-HEADER01 ]  
LFXP3E-3TN100C( ISP) [ ISP-HEADER01 ]  
LFXP3E-3TN100I( ISP) [ ISP-HEADER01 ]  
LFXP3E-3TN144C( ISP) [ ISP-HEADER01 ]  
LFXP3E-3TN144I( ISP) [ ISP-HEADER01 ]  
LFXP3E-4Q208C( ISP) [ ISP-HEADER01 ]  
LFXP3E-4Q208I( ISP) [ ISP-HEADER01 ]  
LFXP3E-4QN208C( ISP) [ ISP-HEADER01 ]  
LFXP3E-4QN208I( ISP) [ ISP-HEADER01 ]  
LFXP3E-4T100C( ISP) [ ISP-HEADER01 ]

LFXP3E-4T100I ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-4T144C ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-4T144I ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-4TN100C ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-4TN100I ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-4TN144C ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-4TN144I ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-5Q208C ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-5Q208I ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-5QN208C ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-5QN208I ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-5T100C ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-5T100I ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-5T144C ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-5T144I ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-5TN100C ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-5TN100I ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-5TN144C ( ISP ) [ ISP-HEADER01 ]  
LFXP3E-5TN144I ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-3F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-3F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-3FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-3FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-3Q208C ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-3Q208I ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-3QN208C ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-3QN208I ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-3T144C ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-3T144I ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-3TN144C ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-3TN144I ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4F256C ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4F256I ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4FN256C ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4FN256I ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4Q208C ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4Q208I ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4QN208C ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4QN208I ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4T144C ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4T144I ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4TN144C ( ISP ) [ ISP-HEADER01 ]  
LFXP6C-4TN144I ( ISP ) [ ISP-HEADER01 ]

LFXP6C-5F256C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5F256I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5FN256C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5FN256I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5Q208C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5Q208I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5QN208C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5QN208I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5T144C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5T144I( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5TN144C( ISP ) [ ISP-HEADER01 ]  
LFXP6C-5TN144I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3F256C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3F256I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3FN256C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3FN256I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3Q208C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3Q208I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3QN208C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3QN208I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3T144C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3T144I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3TN144C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-3TN144I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-4F256C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-4F256I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-4FN256C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-4FN256I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-4Q208C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-4Q208I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-4QN208C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-4QN208I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-4T144C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-4T144I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-4TN144C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-4TN144I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-5F256C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-5F256I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-5FN256C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-5FN256I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-5Q208C( ISP ) [ ISP-HEADER01 ]  
LFXP6E-5Q208I( ISP ) [ ISP-HEADER01 ]  
LFXP6E-5QN208C( ISP ) [ ISP-HEADER01 ]

LFXP6E-5QN208I (ISP) [ISP-HEADER01]	
LFXP6E-5T144C (ISP) [ISP-HEADER01]	
LFXP6E-5T144I (ISP) [ISP-HEADER01]	
LFXP6E-5TN144C (ISP) [ISP-HEADER01]	
LFXP6E-5TN144I (ISP) [ISP-HEADER01]	
M4A3-32/32@PLCC44 [(SA244)]	M4A3-32/32@TQFP44
[(SA245A)]	
M4A3-32/32@TQFP48 [(SA248)]	M4A3-64/32@PLCC44
[(SA244)]	
M4A3-64/32@TQFP44 [(SA245A)]	M4A3-64/32@TQFP48
[(SA248)]	
M4A5-32/32@PLCC44 [(SA244)]	M4A5-32/32@TQFP44
[(SA245A)]	
M4A5-32/32@TQFP48 [(SA248)]	M4A5-64/32@PLCC44
[(SA244)]	
M4A5-64/32@TQFP44 [(SA245A)]	M4A5-64/32@TQFP48
[(SA248)]	
MACH110@PLCC44 [(SA244)]	
PALCE20RA10	
PALCE20RA10@PLCC28 [(SA008A)]	PALCE20RA10@SOIC24
[(SA404)]	
PALCE20RA10H	PALCE20RA10H@PLCC28
[(SA008A)]	
PALCE20RA10H@SOIC24 [(SA404)]	
PALCE20RA10Q	
PALCE20RA10Q@PLCC28 [(SA008A)]	PALCE20RA10Q@SOIC24
[(SA404)]	
PALCE22V10H	PALCE22V10H@PLCC28
[(SA008A)]	
PALCE22V10H@SOIC24 [(SA404)]	
PALCE22V10Q	
PALCE22V10Q@PLCC28 [(SA008A)]	PALCE22V10Q@SOIC24
[(SA404)]	
PALCE22V10Z	PALCE22V10Z@PLCC28
[(SA008A)]	
PALCE22V10Z@SOIC24 [(SA404)]	

## LG Semicon

### DRAM & SRAM

GM76C256CL	GM76C256CL@SSOP28
------------	-------------------

[ ( SA430T ) ]	
GM76C256CL@TSOP28 [ ( SA630 ) ]	
GM76C256CLL	
GM76C256CLL@SSOP28 [ ( SA430T ) ]	GM76C256CLL@TSOP28
[ ( SA630 ) ]	
GM76C8128CL	
[ ( SA438T ) ]	
GM76C8128CL@TSOP32 [ ( SA410T ) ]	GM76C8128CL@SSOP32
[ ( SA620 ) ]	
GM76C8128CLL	
[ ( SA438T ) ]	
GM76C8128CLL@TSOP32 [ ( SA410T ) ]	GM76C8128CLL@VSOP32
[ ( SA620 ) ]	
GM76C88AL	
[ ( SA430T ) ]	
GM76C88AL@TSOP28 [ ( SA643 ) ]	GM76C88AL@SSOP28
GM76U256CL	
GM76U256CL@SSOP28 [ ( SA430T ) ]	GM76U256CL@TSOP28
[ ( SA643 ) ]	
GM76U256CLL	
[ ( SA430T ) ]	
GM76U256CLL@TSOP28 [ ( SA643 ) ]	GM76U256CLL@SSOP28
GM76U8128CL	
GM76U8128CL@SSOP32 [ ( SA438T ) ]	GM76U8128CL@TSOP32
[ ( SA410T ) ]	
GM76U8128CL@VSOP32 [ ( SA620 ) ]	
GM76U8128CLL	
GM76U8128CLL@SSOP32 [ ( SA438T ) ]	GM76U8128CLL@TSOP32
[ ( SA410T ) ]	
GM76U8128CLL@VSOP32 [ ( SA620 ) ]	
GM76U8128DL	
GM76U8128DL@SSOP32 [ ( SA438T ) ]	GM76U8128DL@TSOP32
[ ( SA410T ) ]	
GM76U8128DL@VSOP32 [ ( SA620 ) ]	
GM76U8128DLL	
GM76U8128DLL@SSOP32 [ ( SA438T ) ]	GM76U8128DLL@TSOP32
[ ( SA410T ) ]	
GM76U8128DLL@VSOP32 [ ( SA620 ) ]	
GM76U8512L	
GM76U8512L@SSOP32 [ ( SA438T ) ]	GM76U8512L@TSOP32
[ ( SA410T ) ]	
GM76U8512L@VSOP32 [ ( SA620 ) ]	
GM76U8512LL	

GM76U8512LL@SSOP32 [(SA438T)]	GM76U8512LL@TSOP32
[(SA410T)]	
GM76U8512LL@VSOP32 [(SA620)]	
GM76V256CL	
GM76V256CL@SSOP28 [(SA430T)]	GM76V256CL@TSOP28
[(SA630)]	
GM76V256CLL	
[(SA430T)]	GM76V256CLL@SSOP28
GM76V256CLL@TSOP28 [(SA630)]	
GM76V8128CL	
GM76V8128CL@SSOP32 [(SA438T)]	GM76V8128CL@TSOP32
[(SA410T)]	
GM76V8128CL@VSOP32 [(SA620)]	
GM76V8128CLL	
GM76V8128CLL@SSOP32 [(SA438T)]	GM76V8128CLL@TSOP32
[(SA410T)]	
GM76V8128CLL@VSOP32 [(SA620)]	
GM76V8128DL	
GM76V8128DL@SSOP32 [(SA438T)]	GM76V8128DL@TSOP32
[(SA410T)]	
GM76V8128DL@VSOP32 [(SA620)]	
GM76V8128DLL	
GM76V8128DLL@SSOP32 [(SA438T)]	GM76V8128DLL@TSOP32
[(SA410T)]	
GM76V8128DLL@VSOP32 [(SA620)]	
GM76V8512L	
GM76V8512L@SSOP32 [(SA438T)]	GM76V8512L@TSOP32
[(SA410T)]	
GM76V8512L@VSOP32 [(SA620)]	
GM76V8512LL	
GM76V8512LL@SSOP32 [(SA438T)]	GM76V8512LL@TSOP32
[(SA410T)]	
GM76V8512LL@VSOP32 [(SA620)]	
GM77C8128A	
GM77C8128A@SSOP32 [(SA438T)]	GM77C8128A@TSOP32
[(SA410T)]	
GM77C8128A@VSOP32 [(SA620)]	

## MICROCONTROLLER

GMS97C1051	GMS97C1051@SOIC20
[(SA404)]	



GMS97C2051 [ ( SA404 ) ]	GMS97C2051@SOIC20
GMS97C51 [ ( SA244 ) ]	GMS97C51@PLCC44
GMS97C51@TQFP44 [ ( SA245A ) ]	
GMS97C52 GMS97C52@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	GMS97C52@TQFP44
GMS97C54 [ ( SA244 ) ]	GMS97C54@PLCC44
GMS97C54@TQFP44 [ ( SA245A ) ]	
GMS97C56 GMS97C56@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	GMS97C56@TQFP44
GMS97C58 [ ( SA244 ) ]	GMS97C58@PLCC44
GMS97C58@TQFP44 [ ( SA245A ) ]	
GMS97L1051 GMS97L1051@SOIC20 [ ( SA404 ) ]	
GMS97L2051 GMS97L2051@SOIC20 [ ( SA404 ) ]	
GMS97L51 GMS97L51@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	GMS97L51@TQFP44
GMS97L52 [ ( SA244 ) ]	GMS97L52@PLCC44
GMS97L52@TQFP44 [ ( SA245A ) ]	
GMS97L54 GMS97L54@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	GMS97L54@TQFP44
GMS97L56 [ ( SA244 ) ]	GMS97L56@PLCC44
GMS97L56@TQFP44 [ ( SA245A ) ]	
GMS97L58 GMS97L58@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	GMS97L58@TQFP44
GMS99C52 [ ( SA244 ) ]	GMS99C52@PLCC44
GMS99C52@TQFP44 [ ( SA245A ) ]	
GMS99C58 GMS99C58@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	GMS99C58@TQFP44

## LINKSMART

### E ( E ) PROM / FRAM / NVRAM

L24C02 [ ( SA602A ) ] L24C02@TSOP8 [ ( SA026 ) ] L24C04 L24C04@SSOP8 [ ( SA602A ) ] [ ( SA026 ) ] L29004C [ ( SA015A1T ) ] L29004C@TSOP32 [ ( SA620 ) ] B005 ) ] L29S160F-B@TSOP48 [ ( SA247-B005 ) ] [ ( SA638 ) ] L29S400F@TSOP48 [ ( SA247-B005 ) ] [ ( SA638 ) ] L29S400F-B@TSOP48 [ ( SA247-B005 ) ] B005 ) ] L29S800F-B@TSOP48 [ ( SA247-B005 ) ] B005 ) ] L29W800E-B@TSOP48 [ ( SA247-B005 ) ] LST28001 LST28001@PLCC32 [ ( SA015A1T ) ] [ ( SA620 ) ] LST28002 [ ( SA015A1T ) ] LST28002@TSOP32 [ ( SA620 ) ] LST28004 LST28004@PLCC32 [ ( SA015A1T ) ] [ ( SA620 ) ]	L24C02@SSOP8   L24C04@TSOP8  L29004C@PLCC32  L29S160F@TSOP48 [ ( SA247-  L29S400F@PSOP44  L29S400F-B@PSOP44  L29S800F@TSOP48 [ ( SA247-  L29W800E@TSOP48 [ ( SA247-  LST28001@TSOP32  LST28002@PLCC32    LST28004@TSOP32
--	---

## MACRONIX

### E ( E ) PROM / FRAM / NVRAM

KH25L1005 HEADER01 ] KH25L1005@SON8 [ ( SA683 ) ] KH25L1005@SON8 ( ISP ) [ ISP-HEADER01 ]	KH25L1005 ( ISP ) [ ISP-
--	--------------------------

KH25L1005@SOP8 [(SA602A)]  
KH25L1005@SOP8(ISP) [ISP-HEADER01]  
KH25L1005A KH25L1005A@SON8  
[(SA683)]  
KH25L1005A@SOP8 [(SA602A)]  
KH25L12805D@SON8(Fast Mode) [(SA684)]  
KH25L12805D@SOP16(Fast Mode) [(SA404)]  
KH25L12805N@SOP16 [(SA404)]  
KH25L12805N@SOP16(Fast Mode) [(SA404)]  
KH25L1602@SOP28 [(SA630)] KH25L1605@SON8  
[(SA684)]  
KH25L1605@SON8(Fast Mode) [(SA684)]  
KH25L1605@SOP16 [(SA404)]  
KH25L1605@SOP16(Fast Mode) [(SA404)]  
KH25L1605A@SON8 [(SA684)]  
KH25L1605A@SON8(Fast Mode) [(SA684)]  
KH25L1605A@SOP16 [(SA404)]  
KH25L1605A@SOP16(Fast Mode) [(SA404)]  
KH25L1605A@SOP8 [(SA023A)]  
KH25L1605A@SOP8(Fast Mode) [(SA023A)]  
KH25L1605D@SON8 [(SA684)]  
KH25L1605D@SON8(Fast Mode) [(SA683)]  
KH25L1605D@SOP16 [(SA404)]  
KH25L1605D@SOP16(Fast Mode) [(SA404)]  
KH25L1605D@SOP8(150)(Fast Mode) [(SA602A)]  
KH25L1605D@SOP8(200)(Fast Mode) [(SA605B)]  
KH25L1636DM1I@SOP8 [(SA602A)] KH25L1636DM2I@SOP8  
[(SA605B)]  
KH25L1636DMI@SOP16 [(SA404)] KH25L1636DZNI@WSON8  
[(SA683)]  
KH25L2005 KH25L2005(ISP) [ISP-  
HEADER01]  
KH25L2005@SON8 [(SA683)]  
KH25L2005@SON8(ISP) [ISP-HEADER01]  
KH25L2005@SOP8 [(SA602A)]  
KH25L2005@SOP8(ISP) [ISP-HEADER01]  
KH25L2025 KH25L2025@SON8  
[(SA683)]  
KH25L2025@SOP8 [(SA602A)] KH25L3202@SOP32  
[(SA438T)]  
KH25L3205@SOP16 [(SA404)]  
KH25L3205@SOP16(Fast Mode) [(SA404)]  
KH25L3205@SOP8 [(SA023A)]

KH25L3205@SOP8(Fast Mode) [(SA023A)]  
KH25L3205A@SON8 [(SA684)]  
KH25L3205A@SON8(Fast Mode) [(SA684)]  
KH25L3205A@SOP16 [(SA404)]  
KH25L3205A@SOP16(Fast Mode) [(SA404)]  
KH25L3205A@SOP8 [(SA023A)]  
KH25L3205A@SOP8(Fast Mode) [(SA023A)]  
KH25L3205D@SON8(Fast Mode) [(SA683)]  
KH25L3205D@SOP16 [(SA404)]  
KH25L3205D@SOP16(Fast Mode) [(SA404)]  
KH25L3205D@SOP8 [(SA023A)]  
KH25L3205D@SOP8(Fast Mode) [(SA605B)]  
KH25L3236DM2I@SOP8 [(SA605B)]                    KH25L3236DMI@SOP16  
[(SA404)]  
KH25L3236DZNI@WSON8 [(SA683)]  
KH25L4005  
KH25L4005(150mil)@SOP8 [(SA602A)]  
KH25L4005(150mil)@SOP8(ISP) [ISP-HEADER01]  
KH25L4005(209mil)@SOP8 [(SA023A)]  
KH25L4005(209mil)@SOP8(ISP) [ISP-HEADER01]  
KH25L4005(ISP) [ISP-HEADER01]                    KH25L4005@SON8  
[(SA683)]  
KH25L4005@SON8(ISP) [ISP-HEADER01]  
KH25L4005A  
KH25L4005A(150mil)@SOP8 [(SA602A)]  
KH25L4005A(150mil)@SOP8(ISP) [ISP-HEADER01]  
KH25L4005A(209mil)@SOP8 [(SA023A)]  
KH25L4005A(209mil)@SOP8(ISP) [ISP-HEADER01]  
KH25L4005A(ISP) [ISP-HEADER01]                    KH25L4005A@SON8  
[(SA683)]  
KH25L4005A@SON8(ISP) [ISP-HEADER01]  
KH25L4025A  
KH25L4025A(150mil)@SOP8 [(SA602A)]  
KH25L4025A(209mil)@SOP8 [(SA023A)]  
KH25L4025A@SON8 [(SA683)]                    KH25L512@SON8  
[(SA683)]  
KH25L512@SOP8 [(SA602A)]  
KH25L512A  
KH25L512A@SON8 [(SA683)]                    KH25L512A@SOP8  
[(SA602A)]  
KH25L6402@SOP32 [(SA438T)]                    KH25L6402A@SOP28  
[(SA630)]  
KH25L6405@SOP16 [(SA404)]

KH25L6405@SOP16(Fast Mode) [(SA404)]  
KH25L6405@SOP8 [(SA023A)]  
KH25L6405@SOP8(Fast Mode) [(SA023A)]  
KH25L6405D@SON8(Fast Mode) [(SA684)]  
KH25L6405D@SOP16 [(SA404)]  
KH25L6405D@SOP16(Fast Mode) [(SA404)]  
KH25L6405D@SOP8 [(SA023A)]  
KH25L8005  
KH25L8005(150mil)@SOP8 [(SA602A)]  
KH25L8005(150mil)@SOP8(ISP) [ISP-HEADER01]  
KH25L8005(209mil)@SOP8 [(SA023A)]  
KH25L8005(209mil)@SOP8(ISP) [ISP-HEADER01]  
KH25L8005(ISP) [ISP-HEADER01] KH25L8005@SON8  
[(SA683)]  
KH25L8005@SON8(ISP) [ISP-HEADER01]  
KH25L802@SOP28 [(SA630)]  
KH25L8025  
KH25L8025(150mil)@SOP8 [(SA602A)]  
KH25L8025(209mil)@SOP8 [(SA023A)]  
KH25L8025@SON8 [(SA683)]  
KH25L8036D  
KH25L8036D@SOP16 [(SA404)]  
KH25L8036D@SOP8[150 mil] [(SA602A)]  
KH25L8036D@SOP8[200 mil] [(SA023A)]  
KH25L8036D@WSON8 [(SA683)] KH29LV004CB@PLCC32  
[(SA015A1T)]  
KH29LV004CB@TSOP40 [(SA409T)] KH29LV004CT@PLCC32  
[(SA015A1T)]  
KH29LV004CT@TSOP40 [(SA409T)] KH29LV008CB@TSOP40  
[(SA409T)]  
KH29LV008CT@TSOP40 [(SA409T)]  
KH29LV040C  
KH29LV040C@PLCC32 [(SA015A1T)]  
KH29LV160CBT@TSOP48 [(SA247-B005)]  
KH29LV160CTT@TSOP48 [(SA247-B005)]  
KH29LV320CBT@TSOP48 [(SA247-B005)]  
KH29LV320CTT@TSOP48 [(SA247-B005)]  
KH29LV320DBT@TSOP48 [(SA247-B005)]  
KH29LV320DTT@TSOP48 [(SA247-B005)]  
KH29LV400CBT@TSOP48 [(SA247-B005)]  
KH29LV400CTT@TSOP48 [(SA247-B005)]  
KH29LV640DBT@TSOP48 [(SA247-B005)]  
KH29LV640DTT@TSOP48 [(SA247-B005)]

KH29LV800CBT@TSOP48 [(SA247-B005)]  
KH29LV800CTT@TSOP48 [(SA247-B005)]  
MX25L1005  
HEADER01] MX25L1005(ISP) [ISP-  
MX25L1005@SON8 [(SA683)]  
MX25L1005@SON8(ISP) [ISP-HEADER01]  
MX25L1005@SOP8 [(SA602A)]  
MX25L1005@SOP8(ISP) [ISP-HEADER01]  
MX25L1005A  
[(SA683)] MX25L1005A@SON8  
MX25L1005A@SOP8 [(SA602A)]  
MX25L12805D@SON8(Fast Mode) [(SA684)]  
MX25L12805D@SOP16(Fast Mode) [(SA404)]  
MX25L12805N@SOP16 [(SA404)]  
MX25L12805N@SOP16(Fast Mode) [(SA404)]  
MX25L12845E@SOP16 [(SA404)] MX25L12855E@SOP16  
[(SA404)]  
MX25L12855E@TFBGA24 [(TA088)] MX25L1602@SOP28  
[(SA630)]  
MX25L1605@SON8 [(SA684)]  
MX25L1605@SON8(Fast Mode) [(SA684)]  
MX25L1605@SOP16 [(SA404)]  
MX25L1605@SOP16(Fast Mode) [(SA404)]  
MX25L1605A@SON8 [(SA684)]  
MX25L1605A@SON8(Fast Mode) [(SA684)]  
MX25L1605A@SOP16 [(SA404)]  
MX25L1605A@SOP16(Fast Mode) [(SA404)]  
MX25L1605A@SOP8 [(SA023A)]  
MX25L1605A@SOP8(Fast Mode) [(SA023A)]  
MX25L1605D@SON8 [(SA684)]  
MX25L1605D@SON8(Fast Mode) [(SA683)]  
MX25L1605D@SOP16 [(SA404)]  
MX25L1605D@SOP16(Fast Mode) [(SA404)]  
MX25L1605D@SOP8(150)(Fast Mode) [(SA602A)]  
MX25L1605D@SOP8(200)(Fast Mode) [(SA605B)]  
MX25L1605D@USON8 [(SA744)]  
MX25L1605D@USON8(Fast Mode) [(SA744)]  
MX25L1615D@SOP16 [(SA404)] MX25L1615D@SOP8  
[(SA023A)]  
MX25L1635DM1I@SOP8 [(SA602A)] MX25L1635DM2I@SOP8  
[(SA605B)]  
MX25L1635DMI@SOP16 [(SA404)] MX25L1635DZNI@WSON8  
[(SA683)]

MX25L1636DM1I@SOP8 [(SA602A)] [(SA605B)]	MX25L1636DM2I@SOP8
MX25L1636DMI@SOP16 [(SA404)] [(SA683)]	MX25L1636DZNI@WSON8
MX25L2005 HEADER01]	MX25L2005(ISP) [ISP-
MX25L2005@SON8 [(SA683)]	
MX25L2005@SON8(ISP) [ISP-HEADER01]	
MX25L2005@SOP8 [(SA602A)]	
MX25L2005@SOP8(ISP) [ISP-HEADER01]	
MX25L2025 [(SA683)]	MX25L2025@SON8
MX25L2025@SOP8 [(SA602A)] [(SA602A)]	MX25L2026C@SOP8
MX25L3202@SOP32 [(SA438T)] [(SA404)]	MX25L3205@SOP16
MX25L3205@SOP16(Fast Mode) [(SA404)]	
MX25L3205@SOP8 [(SA023A)]	
MX25L3205@SOP8(Fast Mode) [(SA023A)]	
MX25L3205A@SON8 [(SA684)]	
MX25L3205A@SON8(Fast Mode) [(SA684)]	
MX25L3205A@SOP16 [(SA404)]	
MX25L3205A@SOP16(Fast Mode) [(SA404)]	
MX25L3205A@SOP16(Parallel Mode) [(SA404)]	
MX25L3205A@SOP8 [(SA023A)]	
MX25L3205A@SOP8(Fast Mode) [(SA023A)]	
MX25L3205D@SON8(Fast Mode) [(SA683)]	
MX25L3205D@SOP16 [(SA404)]	
MX25L3205D@SOP16(Fast Mode) [(SA404)]	
MX25L3205D@SOP8 [(SA023A)]	
MX25L3205D@SOP8(Fast Mode) [(SA605B)]	
MX25L3205D@USON8 [(SA744)]	
MX25L3205D@USON8(Fast Mode) [(SA744)]	
MX25L3215D@SOP16 [(SA404)] [(SA023A)]	MX25L3215D@SOP8
MX25L3235DM2I@SOP8 [(SA605B)] [(SA404)]	MX25L3235DMI@SOP16
MX25L3235DZNI@WSON8 [(SA683)] [(SA605B)]	MX25L3236DM2I@SOP8
MX25L3236DMI@SOP16 [(SA404)] [(SA683)]	MX25L3236DZNI@WSON8
MX25L3237D@SOP16 [(SA404)] [(SA683)]	MX25L3237D@WSON8

MX25L4005  
MX25L4005(150mil)@SOP8 [(SA602A)]  
MX25L4005(150mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L4005(209mil)@SOP8 [(SA023A)]  
MX25L4005(209mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L4005(ISP) [ISP-HEADER01] MX25L4005@SON8  
[(SA683)]  
MX25L4005@SON8(ISP) [ISP-HEADER01]  
MX25L4005A  
MX25L4005A(150mil)@SOP8 [(SA602A)]  
MX25L4005A(150mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L4005A(209mil)@SOP8 [(SA023A)]  
MX25L4005A(209mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L4005A(ISP) [ISP-HEADER01] MX25L4005A@SON8  
[(SA683)]  
MX25L4005A@SON8(ISP) [ISP-HEADER01]  
MX25L4025@SOP8 [(SA602A)]  
MX25L4025A  
MX25L4025A(150mil)@SOP8 [(SA602A)]  
MX25L4025A(209mil)@SOP8 [(SA023A)]  
MX25L4025A@SON8 [(SA683)] MX25L512@SON8  
[(SA683)]  
MX25L512@SOP8 [(SA602A)]  
MX25L512A  
MX25L512A@SON8 [(SA683)] MX25L512A@SOP8  
[(SA602A)]  
MX25L6402@SOP32 [(SA438T)] MX25L6402A@SOP28  
[(SA630)]  
MX25L6405@SOP16 [(SA404)]  
MX25L6405@SOP16(Fast Mode) [(SA404)]  
MX25L6405@SOP8 [(SA023A)]  
MX25L6405@SOP8(Fast Mode) [(SA023A)]  
MX25L6405D@SON8(Fast Mode) [(SA684)]  
MX25L6405D@SOP16 [(SA404)]  
MX25L6405D@SOP16(Fast Mode) [(SA404)]  
MX25L6405D@SOP8 [(SA023A)] MX25L6415D@SOP16  
[(SA404)]  
MX25L6415D@SOP8 [(SA023A)] MX25L6445E@SOP16  
[(SA404)]  
MX25L6445E@SOP8 [(SA023A)] MX25L6445E@WSON8  
[(SA684)]  
MX25L6446E@SOP16 [(SA404)] MX25L6446E@SOP8  
[(SA023A)]





MX26F128J3TC@TSOP56 [(SA628-B018)]  
MX26F128J3XC@CSP64 [(SA655A-B054A-T064F001)]  
MX26F640J3TC@TSOP56 [(SA628-B018)]  
MX26F640J3XC@CSP64 [(SA655A-B054A-T064F001)]  
MX26L12711MC@PSOP44 [(SA638)] MX26L12811MC@PSOP44  
[(SA638)]  
MX26L6419T@TSOP48 [(SA247-B005)] MX26L6420@PSOP44  
[(SA638)]  
MX26L6420@TSOP48 [(SA247-B005)] MX26LV004B@PLCC32  
[(SA015A1T)]  
MX26LV004B@TSOP40 [(SA409T)] MX26LV004T@PLCC32  
[(SA015A1T)]  
MX26LV004T@TSOP40 [(SA409T)] MX26LV008B@TSOP40  
[(SA409T)]  
MX26LV008T@TSOP40 [(SA409T)]  
MX26LV040(QC)@PLCC32 [(SA015A1T)]  
MX26LV040(TC)@TSOP32 [(SA410T)]  
MX26LV160BT@TSOP48 [(SA247-B005)]  
MX26LV160BX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV160BX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV160TT@TSOP48 [(SA247-B005)]  
MX26LV160TX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV160TX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV400BT@TSOP48 [(SA247-B005)]  
MX26LV400BX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV400BX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV400TT@TSOP48 [(SA247-B005)]  
MX26LV400TX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV400TX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
MX26LV800BM@PSOP44 [(SA638)]  
MX26LV800BT@TSOP48 [(SA247-B005)]  
MX26LV800BX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX26LV800BX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX26LV800TM@PSOP44 [(SA638)]  
MX26LV800TT@TSOP48 [(SA247-B005)]  
MX26LV800TX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX26LV800TX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX27C1000 MX27C1000@PLCC32  
[(SA015A1T)]  
MX27C1000@SOIC32 [(SA603)] MX27C1000@TSOP32  
[(SA410T)]  
MX27C1000A MX27C1000A@PLCC32  
[(SA015A1T)]

MX27C1000A@SOIC32 [(SA603)]	MX27C1000A@TSOP32
[(SA410T)]	
MX27C1001	MX27C1001@PLCC32
[(SA015A1T)]	
MX27C1001@SOIC32 [(SA603)]	MX27C1001@TSOP32
[(SA410T)]	
MX27C1024	MX27C1024@PLCC44
[(SA244)]	
MX27C1024@TSOP40 [(SA409T)]	
MX27C1024A	
MX27C1024A@PLCC44 [(SA244)]	MX27C1024A@TSOP40
[(SA409T)]	
MX27C1024B	MX27C1024B@PLCC44
[(SA244)]	
MX27C1024B@TSOP40 [(SA409T)]	
MX27C1100	
MX27C2000	MX27C2000@PLCC32
[(SA015A1T)]	
MX27C2000@SOIC32 [(SA603)]	MX27C2000@TSOP32
[(SA410T)]	
MX27C2000A	MX27C2000A@PLCC32
[(SA015A1T)]	
MX27C2000A@SOIC32 [(SA603)]	MX27C2000A@TSOP32
[(SA410T)]	
MX27C2048	MX27C2048@PLCC44
[(SA244)]	
MX27C2048@TSOP40 [(SA409T)]	
MX27C2100	
MX27C256	MX27C256@PLCC32
[(SA015A1T)]	
MX27C4000	MX27C4000@PLCC32
[(SA015A1T)]	
MX27C4000@SOIC32 [(SA603)]	MX27C4000@TSOP32
[(SA410T)]	
MX27C4000A	MX27C4000A@PLCC32
[(SA015A1T)]	
MX27C4000A@SOIC32 [(SA603)]	MX27C4000A@TSOP32
[(SA410T)]	
MX27C4096	MX27C4096@PLCC44
[(SA244)]	
MX27C4100	
MX27C4111	
MX27C512	MX27C512@PLCC32

[ (SA015A1T) ]	
MX27C516	MX27C516@PLCC44
[ (SA244) ]	
MX27C516@TSOP40 [ (SA409T) ]	
MX27C8000	
MX27C8000@PLCC32 [ (SA015A1T) ]	MX27C8000@SOIC32
[ (SA603) ]	
MX27C8000@TSOP32 [ (SA410T) ]	
MX27C8000A	
MX27C8000A@PLCC32 [ (SA015A1T) ]	MX27C8000A@SOIC32
[ (SA603) ]	
MX27C8000A@TSOP32 [ (SA410T) ]	
MX27C8100	
MX27C8100@PSOP44 [ (SA638) ]	
MX27C8111	
MX27C8111@PSOP44 [ (SA638) ]	
MX27L1000	
MX27L1000@PLCC32 [ (SA015A1T) ]	MX27L1000@TSOP32
[ (SA410T) ]	
MX27L2000	MX27L2000@PLCC32
[ (SA015A1T) ]	
MX27L2000@TSOP32 [ (SA410T) ]	
MX27L256	
MX27L256@PLCC32 [ (SA015A1T) ]	MX27L256@TSOP32
[ (SA430T) ]	
MX27L4000	MX27L4000@PLCC32
[ (SA015A1T) ]	
MX27L4000@TSOP32 [ (SA410T) ]	
MX27L4096	
MX27L4096@PLCC44 [ (SA244) ]	
MX27L512	
MX27L512@PLCC32 [ (SA015A1T) ]	MX27L512@TSOP28
[ (SA430T) ]	
MX28F002B@TSOP40 [ (SA409T) ]	MX28F002T@TSOP40
[ (SA409T) ]	
MX28F1000	MX28F1000@PLCC32
[ (SA015A1T) ]	
MX28F1000@SOP32 [ (SA603) ]	MX28F1000@TSOP32
[ (SA410T) ]	
MX28F1000P	MX28F1000P@PLCC32
[ (SA015A1T) ]	
MX28F1000P@TSOP32 [ (SA410T) ]	
MX28F160C3BT@TSOP48 [ (SA247-B005) ]	

MX28F160C3BX@uBGA48 [ (SA634A-B005A-Y048F001) ]  
MX28F160C3TT@TSOP48 [ (SA247-B005) ]  
MX28F160C3TX@uBGA48 [ (SA634A-B005A-Y048F001) ]  
MX28F2000 MX28F2000@PLCC32  
[ (SA015A1T) ]  
MX28F2000@TSOP32 [ (SA410T) ]  
MX28F2000P  
MX28F2000P@PLCC32 [ (SA015A1T) ] MX28F2000P@TSOP32  
[ (SA410T) ]  
MX28F2100B@PSOP44 [ (SA638) ] MX28F2100B@TSOP48 [ (SA247-  
B005) ]  
MX28F2100T@PSOP44 [ (SA638) ] MX28F2100T@TSOP48 [ (SA247-  
B005) ]  
MX28F4000 MX28F4000@PLCC32  
[ (SA015A1T) ]  
MX28F4000@TSOP32 [ (SA410T) ]  
MX28F640C3BT@TSOP48 [ (SA247-B005) ]  
MX28F640C3BX@uBGA48 [ (SA634A-B005A-Y048F001) ]  
MX28F640C3TT@TSOP48 [ (SA247-B005) ]  
MX28F640C3TX@uBGA48 [ (SA634A-B005A-Y048F001) ]  
MX29F001B MX29F001B@PLCC32  
[ (SA015A1T) ]  
MX29F001B@TSOP32 [ (SA410T) ]  
MX29F001T  
MX29F001T@PLCC32 [ (SA015A1T) ] MX29F001T@TSOP32  
[ (SA410T) ]  
MX29F002B MX29F002B@PLCC32  
[ (SA015A1T) ]  
MX29F002B@TSOP32 [ (SA410T) ]  
MX29F002NB  
MX29F002NB@PLCC32 [ (SA015A1T) ] MX29F002NB@TSOP32  
[ (SA410T) ]  
MX29F002NT MX29F002NT@PLCC32  
[ (SA015A1T) ]  
MX29F002NT@TSOP32 [ (SA410T) ]  
MX29F002T  
MX29F002T@PLCC32 [ (SA015A1T) ] MX29F002T@TSOP32  
[ (SA410T) ]  
MX29F004B MX29F004B@PLCC32  
[ (SA015A1T) ]  
MX29F004B@TSOP32 [ (SA410T) ]  
MX29F004T  
MX29F004T@PLCC32 [ (SA015A1T) ] MX29F004T@TSOP32

[ (SA410T) ]	
MX29F016@PSOP44 [ (SA638) ]	MX29F016@TSOP40
[ (SA409T) ]	
MX29F016@TSOP48 [ (SA247-B005) ]	
MX29F022B	
MX29F022B@PLCC32 [ (SA015A1T) ]	MX29F022B@TSOP32
[ (SA410T) ]	
MX29F022NB	MX29F022NB@PLCC32
[ (SA015A1T) ]	
MX29F022NB@TSOP32 [ (SA410T) ]	
MX29F022NT	
MX29F022NT@PLCC32 [ (SA015A1T) ]	MX29F022NT@TSOP32
[ (SA410T) ]	
MX29F022T	MX29F022T@PLCC32
[ (SA015A1T) ]	
MX29F022T@TSOP32 [ (SA410T) ]	
MX29F040	
MX29F040@PLCC32 [ (SA015A1T) ]	MX29F040@TSOP32
[ (SA410T) ]	
MX29F040C	MX29F040C@PLCC32
[ (SA015A1T) ]	
MX29F040C@TSOP32 [ (SA410T) ]	MX29F080@PSOP44
[ (SA638) ]	
MX29F080@TSOP40 [ (SA409T) ]	MX29F100B@PSOP44 [ (SA638-
B006) ]	
MX29F100B@TSOP48 [ (SA247-B005) ]	MX29F100T@PSOP44 [ (SA638-
B006) ]	
MX29F100T@TSOP48 [ (SA247-B005) ]	MX29F1610@PSOP44
[ (SA638) ]	
MX29F1610@TSOP48 [ (SA247-B005) ]	MX29F1610A@PSOP44
[ (SA638) ]	
MX29F1610A@TSOP48 [ (SA247-B005) ]	MX29F1610B@TSOP48 [ (SA247-
B005) ]	
MX29F1611@PSOP44 [ (SA638) ]	
MX29F1615	
MX29F200B@PSOP44 [ (SA638-B006) ]	MX29F200B@TSOP48 [ (SA247-
B005) ]	
MX29F200CB@PSOP44 [ (SA638) ]	MX29F200CB@TSOP48 [ (SA247-
B005) ]	
MX29F200CT@PSOP44 [ (SA638) ]	MX29F200CT@TSOP48 [ (SA247-
B005) ]	
MX29F200T@PSOP44 [ (SA638-B006) ]	MX29F200T@TSOP48 [ (SA247-
B005) ]	

MX29F4000 B006 ]	MX29F400B@PSOP44 [ (SA638-
MX29F400B@TSOP48 [ (SA247-B005 ) [ (SA638 ) ]	MX29F400CB@PSOP44
MX29F400CB@TSOP48 [ (SA247-B005 ) [ (SA638 ) ]	MX29F400CT@PSOP44
MX29F400CT@TSOP48 [ (SA247-B005 ) B006 ) ]	MX29F400T@PSOP44 [ (SA638-
MX29F400T@TSOP48 [ (SA247-B005 ) B006 ) ]	MX29F800B@PSOP44 [ (SA638-
MX29F800B@TSOP48 [ (SA247-B005 ) B006 ) ]	MX29F800T@PSOP44 [ (SA638-
MX29F800T@TSOP48 [ (SA247-B005 ) [ (SA638 ) ]	MX29L1611@PSOP44
MX29L1611@TSOP48 [ (SA247-B005 ) MX29L1611G	
MX29L3211@PSOP44 [ (SA638 ) ]	MX29L3211@TSOP48 [ (SA247-
MX29LA128MB@TSOP56 [ (SA628-B102 ) ]	
MX29LA128MT@TSOP56 [ (SA628-B102 ) ]	
MX29LA129MH@TSOP56 [ (SA628-B018 ) ]	
MX29LA129ML@TSOP56 [ (SA628-B018 ) ]	
MX29LA320MB@CFBGA48 [ (SA642G-B026A-T048F001Y ) ]	
MX29LA320MB@TSOP48 [ (SA247-B005 ) ]	
MX29LA320MT@CFBGA48 [ (SA642G-B026A-T048F001Y ) ]	
MX29LA320MT@TSOP48 [ (SA247-B005 ) ]	
MX29LA321MB@FBGA64 [ (SA655A-B054A-T064F001Y ) ]	
MX29LA321MB@TSOP56 [ (SA628-B018 ) ]	
MX29LA321MH@FBGA64 [ (SA655A-B054A-T064F001Y ) ]	
MX29LA321MH@TSOP56 [ (SA628-B018 ) ]	
MX29LA321ML@FBGA64 [ (SA655A-B054A-T064F001Y ) ]	
MX29LA321ML@TSOP56 [ (SA628-B018 ) ]	
MX29LA321MT@FBGA64 [ (SA655A-B054A-T064F001Y ) ]	
MX29LA321MT@TSOP56 [ (SA628-B018 ) ]	
MX29LV002CB@PLCC32 [ (SA015A1T ) ]	MX29LV002CB@TSOP32 [ (SA410T ) ]
MX29LV002CT@PLCC32 [ (SA015A1T ) ]	MX29LV002CT@TSOP32 [ (SA410T ) ]
MX29LV002NCB@PLCC32 [ (SA015A1T ) ]	MX29LV002NCB@TSOP32 [ (SA410T ) ]
MX29LV002NCT@PLCC32 [ (SA015A1T ) ]	MX29LV002NCT@TSOP32 [ (SA410T ) ]
MX29LV004B@PLCC32 [ (SA015A1T ) ]	MX29LV004B@TSOP40

[ (SA409T) ]  
MX29LV004CB@PLCC32 [ (SA015A1T) ] MX29LV004CB@TSOP40  
[ (SA409T) ]  
MX29LV004CT@PLCC32 [ (SA015A1T) ] MX29LV004CT@TSOP40  
[ (SA409T) ]  
MX29LV004T@PLCC32 [ (SA015A1T) ] MX29LV004T@TSOP40  
[ (SA409T) ]  
MX29LV008B@TSOP40 [ (SA409T) ] MX29LV008BB@TSOP40  
[ (SA409T) ]  
MX29LV008BT@TSOP40 [ (SA409T) ] MX29LV008CB@TSOP40  
[ (SA409T) ]  
MX29LV008CT@TSOP40 [ (SA409T) ] MX29LV008T@TSOP40  
[ (SA409T) ]  
MX29LV017AT@TSOP40 [ (SA409T) ]  
MX29LV017AX@CSP48 [ (SA642G-B026A-T048F001) ]  
MX29LV017BT@TSOP40 [ (SA409T) ]  
MX29LV017BX@CSP48 [ (SA642G-B026A-T048F001) ]  
MX29LV033T@TSOP40 [ (SA409T) ] MX29LV040@PLCC32  
[ (SA015A1T) ]  
MX29LV040@TSOP32 [ (SA410T) ] MX29LV040C@PLCC32  
[ (SA015A1T) ]  
MX29LV040C@TSOP32 [ (SA410T) ]  
MX29LV065BT@TSOP48 [ (SA247-B005) ]  
MX29LV065BXB@FBGA63 [ (SA642M-B026A-W048F001) ]  
MX29LV065M@TSOP48 [ (SA247-B005) ] MX29LV081@TSOP40  
[ (SA409T) ]  
MX29LV128DB@TSOP48 [ (SA247-B005) ]  
MX29LV128DB@TSOP56 [ (SA628-B102) ]  
MX29LV128DT@TSOP48 [ (SA247-B005) ]  
MX29LV128DT@TSOP56 [ (SA628-B102) ]  
MX29LV128MB@TSOP56 [ (SA628-B102) ]  
MX29LV128MH@TSOP56 [ (SA628-B102) ]  
MX29LV128ML@TSOP56 [ (SA628-B102) ]  
MX29LV128MT@TSOP56 [ (SA628-B102) ]  
MX29LV160AB(0.3)@CSP48 [ (SA642B-B026A-Y072F001) ]  
MX29LV160AB(0.4)@CSP48 [ (SA642B-B026A-Y072F001) ]  
MX29LV160AB@PSOP44 [ (SA638) ]  
MX29LV160AB@TSOP48 [ (SA247-B005) ]  
MX29LV160AT(0.3)@CSP48 [ (SA642B-B026A-Y072F001) ]  
MX29LV160AT(0.4)@CSP48 [ (SA642B-B026A-Y072F001) ]  
MX29LV160AT@PSOP44 [ (SA638) ]  
MX29LV160AT@TSOP48 [ (SA247-B005) ]  
MX29LV160B(0.3)@CSP48 [ (SA642B-B026A-Y072F001) ]



MX29LV160B(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160B@PSOP44 [(SA638)] MX29LV160B@TSOP48 [(SA247-B005)]  
MX29LV160BB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BB@PSOP44 [(SA638)]  
MX29LV160BB@TSOP48 [(SA247-B005)]  
MX29LV160BT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BT@PSOP44 [(SA638)]  
MX29LV160BT@TSOP48 [(SA247-B005)]  
MX29LV160CBM@PSOP44 [(SA638)]  
MX29LV160CBT@TSOP48 [(SA247-B005)]  
MX29LV160CBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160CBXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160CTM@PSOP44 [(SA638)]  
MX29LV160CTT@TSOP48 [(SA247-B005)]  
MX29LV160CTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160DBT@TSOP48 [(SA247-B005)]  
MX29LV160DBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160DTT@TSOP48 [(SA247-B005)]  
MX29LV160DTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160T(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160T(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160T@PSOP44 [(SA638)] MX29LV160T@TSOP48 [(SA247-B005)]  
MX29LV320ABT@TSOP48 [(SA247-B005)]  
MX29LV320ABXB@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320ABXE@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320ATT@TSOP48 [(SA247-B005)]  
MX29LV320ATXB@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320ATXE@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320BT@TSOP48 [(SA247-B005)]  
MX29LV320BXB@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320BXE@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320CBB@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV320CBE@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV320CBT@TSOP48 [(SA247-B005)]  
MX29LV320CTB@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV320CTE@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV320CTT@TSOP48 [(SA247-B005)]  
MX29LV320DBB@FBGA48 [(SA642G-B026A-T048F001Y)]

MX29LV320DBE@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320DBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320DTB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320DTE@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320DTT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320MB@CFBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320MB@PSOP44 [ ( SA638 ) ]  
MX29LV320MB@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320MH@TSOP56 [ ( SA628-B067 ) ]  
MX29LV320ML@TSOP56 [ ( SA628-B067 ) ]  
MX29LV320MT@CFBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320MT@PSOP44 [ ( SA638 ) ]  
MX29LV320MT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320TT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320TXB@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV320TXE@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV321DBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV321DBXB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV321DTT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV321DTXB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV400B@PSOP44 [ ( SA638 ) ]                      MX29LV400B@TSOP48 [ ( SA247-B005 ) ]  
MX29LV400BX(0.3)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV400BX(0.4)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV400CBM@PSOP44 [ ( SA638 ) ]  
MX29LV400CBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV400CBXB(0.3)@CSP48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV400CBXE(0.4)@CSP48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV400CTM@PSOP44 [ ( SA638 ) ]  
MX29LV400CTT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV400CTXB(0.3)@CSP48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV400CTXE(0.4)@CSP48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV400T@PSOP44 [ ( SA638 ) ]                      MX29LV400T@TSOP48 [ ( SA247-B005 ) ]  
MX29LV400TX(0.3)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV400TX(0.4)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV640BBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV640BBXB@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
MX29LV640BT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV640BTT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV640BTXB@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
MX29LV640BUT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV640BUXB@FBGA63 [ ( SA642M-B026A-W048F001 ) ]

MX29LV640BXB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
MX29LV640BXC@FBGA64 [ ( SA655A-B044A-T064F001 ) ]  
MX29LV640DBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV640DBX@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV640DTT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV640DTX@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV640EBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV640EBX@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV640ETT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV640ETX@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV640MB@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
MX29LV640MB@TSOP48 [ ( SA247-B005 ) ]  
MX29LV640MH@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
MX29LV640MH@TSOP56 [ ( SA628-B067 ) ]  
MX29LV640ML@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
MX29LV640ML@TSOP56 [ ( SA628-B067 ) ]  
MX29LV640MT@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
MX29LV640MT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV640TT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV640TXB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
MX29LV640TXC@FBGA64 [ ( SA655A-B044A-T064F001 ) ]  
MX29LV641MH@TSOP48 [ ( SA247-B005 ) ]  
MX29LV641ML@TSOP48 [ ( SA247-B005 ) ]  
MX29LV800AB(0.3)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV800AB(0.4)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV800AB@PSOP44 [ ( SA638 ) ]  
MX29LV800AB@TSOP48 [ ( SA247-B005 ) ]  
MX29LV800AT(0.3)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV800AT(0.4)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV800AT@PSOP44 [ ( SA638 ) ]  
MX29LV800AT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV800B(0.3)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV800B(0.4)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV800B@PSOP44 [ ( SA638 ) ]                      MX29LV800B@TSOP48 [ ( SA247-B005 ) ]  
MX29LV800CBM@PSOP44 [ ( SA638 ) ]  
MX29LV800CBT(Low)@TSOP48 [ ( SA247-B005 ) ]  
MX29LV800CBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV800CBXB(0.3)@CSP48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV800CBXE(0.4)@CSP48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV800CTM@PSOP44 [ ( SA638 ) ]  
MX29LV800CTT(Low)@TSOP48 [ ( SA247-B005 ) ]  
MX29LV800CTT@TSOP48 [ ( SA247-B005 ) ]

MX29LV800CTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800T(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800T(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800T@PSOP44 [(SA638)] MX29LV800T@TSOP48 [(SA247-  
B005)]  
MX29LW160BT@TSOP48 [(SA247-B005)]  
MX29LW160BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW160BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW160TT@TSOP48 [(SA247-B005)]  
MX29LW160TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW160TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW161BT@TSOP48 [(SA247-B005)]  
MX29LW161BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW161BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW161TT@TSOP48 [(SA247-B005)]  
MX29LW161TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW161TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW320BT@TSOP48 [(SA247-B005)]  
MX29LW320BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW320BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW320TT@TSOP48 [(SA247-B005)]  
MX29LW320TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW320TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW321BT@TSOP48 [(SA247-B005)]  
MX29LW321BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW321BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW321TT@TSOP48 [(SA247-B005)]  
MX29LW321TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW321TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29SL800CB@TSOP48 [(SA247-B005)]  
MX29SL800CBXB(0.30)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29SL800CBXE(0.40)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29SL800CBXH(0.30)@CSP48 [(SA716A-B119B-M048F001Y)]  
MX29SL800CT@TSOP48 [(SA247-B005)]  
MX29SL800CTXB(0.30)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29SL800CTXE(0.40)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29SL800CTXH(0.30)@CSP48 [(SA716A-B119B-M048F001Y)]  
MX69F1602C3BX@FBGA72 [(SA642E-B041A-T072F001)]  
MX69F1602C3TX@FBGA72 [(SA642E-B041A-T072F001)]  
MX69F1604C3BX@FBGA72 [(SA642E-B041A-T072F001)]  
MX69F1604C3TX@FBGA72 [(SA642E-B041A-T072F001)]  
MX69LW162BXB@CSP69 [(SA642A-B032A-Y096F001)]

MX69LW162TXB@CSP69 [ (SA642A-B032A-Y096F001) ]  
MX69LW164BXB@CSP69 [ (SA642A-B032A-Y096F001) ]  
MX69LW164TXB@CSP69 [ (SA642A-B032A-Y096F001) ]  
MX69LW322BXB@CSP69 [ (SA642A-B032A-Y096F001) ]  
MX69LW322TXB@CSP69 [ (SA642A-B032A-Y096F001) ]  
MX69LW324BXB@CSP69 [ (SA642A-B032A-Y096F001) ]  
MX69LW324TXB@CSP69 [ (SA642A-B032A-Y096F001) ]

## MICROCONTROLLER

MX10E8050I  
[ (SA244) ]  
MX10E8050I@TQFP44 [ (SA245A) ]  
[ (SA244) ]  
MX10EXA@TQFP44 [ (SA245A) ]  
MX10F201FC@TQFP100(\*) [ (TA010-B006) ]  
MX10F202FC@TQFP100(\*) [ (TA010-B006) ]  
MX10FLCD  
MX10FMAXD  
MX10FMAXD@PLCC44 [ (SA244) ]  
[ (SA245A) ]  
MX10E8050I@PLCC44  
MX10EXA@PLCC44  
MX10FMAXD@TQFP44

## MAXIM

### E (E) PROM/FRAM/NVRAM

DS1220AB  
DS1220AD  
DS1220Y  
DS1225AB  
DS1225AD  
DS1225D  
DS1225E  
DS1225Y  
DS1230AB  
DS1230W  
DS1230Y  
DS1235AB  
DS1235Y  
DS1243Y  
DS1244

DS1244Y  
DS1245AB  
DS1245EE  
DS1245P  
DS1245W  
DS1245Y  
DS1248P  
DS1248W  
DS1248Y  
DS1249AB  
DS1249W  
DS1249Y  
DS1250AB  
DS1250W  
DS1250Y  
DS1251AB  
DS1251W  
DS1251Y  
DS1256P  
DS1256W  
DS1256Y  
DS1258AB  
DS1258W  
DS1258Y  
DS1265AB  
DS1265W  
DS1265Y  
DS1270AB  
DS1270W  
DS1270Y  
DS1284  
DS1284N  
[ (SA008A) ]  
DS1284QN@PLCC28 [ (SA008A) ]  
DS1286  
DS1286I  
DS1287  
DS1287A  
DS12887  
DS12887A  
DS12C887  
DS12C887A  
( 32K )

DS1284Q@PLCC28

DS1386

DS1386 ( 8K )  
DS1485  
DS1485@SOIC28 [ ( SA630 ) ]  
DS1488  
DS1501  
DS1511  
DS1553  
DS1553W  
DS1554  
DS1554W  
DS1556  
DS1642  
DS1643  
DS1644  
DS1644P  
DS1645AB  
DS1645EE  
DS1645Y  
DS1646  
DS1647  
DS1647LPM  
DS1650AB  
DS1650Y  
3  
DS1687-5  
3  
DS17287-5  
DS1742  
DS1742W  
DS1743  
DS1743P  
DS1743W  
DS1743WP  
DS1744  
DS1744P  
DS1744W  
DS1744WP  
DS1746  
DS1747  
DS1747P  
DS1747W  
DS1747WP  
DS17487-3  
DS1687-  
DS17287-

5

DS17887-3

DS17887-

5

DS2430A@TO-92

DS2430AP@TSOC6

[ (SA602A) ]

DS2431@TO-92

DS2431P@TSOC6

[ (SA602A) ]

DS2432P@TSOC6 [ (SA602A) ]

DS2433@PR-

35

DS2433S(3.9)@SOIC8 [ (SA602A) ]

DS2433S(5.5)@SOIC8

[ (SA605A) ]

DS2502

DS2502P@TSOC6

[ (SA602A) ]

DS2502S@SOIC8 [ (SA602A) ]

DS2502UNW

DS2502UNW@SOIC8 [ (SA602A) ]

DS2502UNW@TSOC6

[ (SA602A) ]

DS2506

DS2506S@SOIC8

[ (SA023A) ]

DS4510@uSOP10

DS4520@TSSOP16

[ (SA026) ]

DS4550@TSSOP20 [ (SA026) ]

## MICROCONTROLLER

DS87C520

DS87C520@PLCC44

[ (SA244) ]

DS87C520@TQFP44 [ (SA245A) ]

DS89C420(rev.

A)

DS89C420(rev.A)@PLCC44 [ (SA244) ]

DS89C420(rev.A)@TQFP44 [ (SA245A) ]

## MAXWELL

### E(E) PROM/FRAM/NVRAM

27C010T@LDFP32 [ (SA438T) ]

28C010

28C010@PLCC32 [ (SA015A1T) ]

28C010@TSOP32

[ (SA438T) ]

28C010T

28C010T@PLCC32



[ (SA015A1T) ]	
28C010T@TSOP32 [ (SA438T) ]	
28C011	
28C011@PLCC32 [ (SA015A1T) ]	28C011@TSOP32
[ (SA438T) ]	
28C011T	28C011T@PLCC32
[ (SA015A1T) ]	
28C011T@TSOP32 [ (SA438T) ]	

## MEGAWIN

### E ( E ) PROM / FRAM / NVRAM

MM25SB512@SOIC8 [ (SA602A) ]	
MM29F040	
MM29F040@PLCC32 [ (SA015A1T) ]	MM29F040@TSOP32
[ (SA410T) ]	
MM29LF040	MM29LF040@PLCC32
[ (SA015A1T) ]	
MM29LF040@TSOP32 [ (SA410T) ]	

### MICROCONTROLLER

MPC82G516AD@LQFP48 [ (SA248) ]	
MPC82G516AE	
MPC82G516AF@PLCC44 [ (SA244) ]	MPC82G516AF@PQFP44
[ (SA675) ]	
MPC89E515AE	MPC89E515AF@PQFP44
[ (SA675) ]	
MPC89E515AP@PLCC44 [ (SA244) ]	
MPC89E51AE	
MPC89E51AF@PQFP44 [ (SA675) ]	MPC89E51AP@PLCC44
[ (SA244) ]	
MPC89E52AE	MPC89E52AF@PQFP44
[ (SA675) ]	
MPC89E52AP@PLCC44 [ (SA244) ]	
MPC89E53AE	
MPC89E53AF@PQFP44 [ (SA675) ]	MPC89E53AP@PLCC44
[ (SA244) ]	
MPC89E54AE	MPC89E54AF@PQFP44
[ (SA675) ]	

MPC89E54AP@PLCC44 [(SA244)]	
MPC89E58AE	
MPC89E58AF@PQFP44 [(SA675)]	MPC89E58AP@PLCC44
[(SA244)]	
MPC89L515AE	MPC89L515AF@PQFP44
[(SA675)]	
MPC89L515AP@PLCC44 [(SA244)]	
MPC89L516X2	
MPC89L516X2@PLCC44 [(SA244)]	MPC89L516X2@TQFP44
[(SA245A)]	
MPC89L51AE	MPC89L51AF@PQFP44
[(SA675)]	
MPC89L51AP@PLCC44 [(SA244)]	
MPC89L52AE	
MPC89L52AF@PQFP44 [(SA675)]	MPC89L52AP@PLCC44
[(SA244)]	
MPC89L53AE	MPC89L53AF@PQFP44
[(SA675)]	
MPC89L53AP@PLCC44 [(SA244)]	
MPC89L54AE	
MPC89L54AF@PQFP44 [(SA675)]	MPC89L54AP@PLCC44
[(SA244)]	
MPC89L556X2	MPC89L556X2@PLCC44
[(SA244)]	
MPC89L556X2@TQFP44 [(SA245A)]	
MPC89L58AE	
MPC89L58AF@PQFP44 [(SA675)]	MPC89L58AP@PLCC44
[(SA244)]	

## MEMOCOM

### E (E) PROM/FRAM/NVRAM

KI01602AB(Ga1)@FBGA66 [(SA642R-B023A-T096F001Y)]
KI01602AB(Gb1)@FBGA66 [(SA642E-B023A-T072001Y)]
KI01602AT(Ga1)@FBGA66 [(SA642R-B023A-T096F001Y)]
KI01602AT(Gb1)@FBGA66 [(SA642E-B023A-T072001Y)]
KI01604AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]
KI01604AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
KI01604AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]
KI01604AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]
KI01608AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]

KI01608AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
KI01608AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
KI01608AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
KI03204AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
KI03204AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
KI03204AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
KI03204AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
KI03204BB@FBGA58 [(SA642R-B023A-T096F001Y)]  
KI03204BT@FBGA58 [(SA642R-B023A-T096F001Y)]  
KI03208AB(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
KI03208AB(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
KI03208AT(Ga1)@FBGA58 [(SA642R-B023A-T096F001Y)]  
KI03208AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
KI03208BB@FBGA58 [(SA642R-B023A-T096F001Y)]  
KI03208BT@FBGA58 [(SA642R-B023A-T096F001Y)]  
KS01602AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS01602AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS01604AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS01604AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS03204AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS03204AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS03204CB@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS03204CT@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS03208AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS03208AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS03208BB@FBGA56 [(SA642P-B207A-W056F001Y)]  
KS03208BT@FBGA56 [(SA642P-B207A-W056F001Y)]  
KSP3216BB@FBGA56 [(SA642P-B207A-W056F001Y)]  
KSP3216BT@FBGA56 [(SA642P-B207A-W056F001Y)]

## MICON

### MICROCONTROLLER

MDT10P21(dip18) (dip20)	MDT10P21
MDT10P21(dip22) [(SA404A)]	MDT10P21@SOP18
MDT10P21@SOP20 [(SA404A)] [(SA404A)]	MDT10P21@SOP24
MDT10P22(dip18) (dip20)	MDT10P22

MDT10P22(dip22) [(SA404A)]	MDT10P22@SOP18
MDT10P22@SOP20 [(SA404A)] [(SA404A)]	MDT10P22@SOP24
MDT10P23(dip18) (dip20)	MDT10P23
MDT10P23(dip22) [(SA404A)]	MDT10P23@SOP18
MDT10P23@SOP20 [(SA404A)] [(SA404A)]	MDT10P23@SOP24
MDT10P61 [(SA404A)]	MDT10P61@SOP18
MDT10P61@SSOP20 [(SA626A)]	
MDT2005 MDT2005@SOP18 [(SA404A)] [(SA626A)]	MDT2005@SSOP20
MDT2010 [(SA404A)]	MDT2010@SOP18
MDT2010@SSOP20 [(SA626A)]	
MDT2020 MDT2020@SOP28 [(SA404A)] [(SA626A)]	MDT2020@SSOP28
MDT2030 [(SA404A)]	MDT2030@SOP18
MDT2030@SSOP20 [(SA626A)]	
MDT2050 MDT2050@SOP18 [(SA404A)] [(SA626A)]	MDT2050@SSOP20
MDT2051 [(SA404A)]	MDT2051@SOP18
MDT2051@SSOP20 [(SA626A)]	
MDT2060 MDT2060@SOP18 [(SA404A)] [(SA626A)]	MDT2060@SSOP20

## MICROCHIP

### E ( E ) PROM / FRAM / NVRAM

24AA00 [(SA602A)]	24AA00@SOIC8
24AA00@SOT-23 [(SA717)]	24AA00@TSSOP8

[ (SA026) ]	
24AA01	24AA01@SOIC8
[ (SA602A) ]	
24AA01@TSSOP8 [ (SA026) ]	
24AA014	
24AA014@SOIC8 [ (SA602A) ]	24AA014@TSSOP8
[ (SA026) ]	
24AA02	24AA02@DFN8
[ (SA694) ]	
24AA02@MSOP8 [ (SA666) ]	24AA02@SOIC8
[ (SA602A) ]	
24AA02@SOT-23-5 [ (SA717) ]	24AA02@TSSOP8
[ (SA026) ]	
24AA024	24AA024@DFN8
[ (SA694) ]	
24AA024@MSOP8 [ (SA666) ]	24AA024@SOIC8
[ (SA602A) ]	
24AA024@TSSOP8 [ (SA026) ]	
24AA025	
24AA025@DFN8 [ (SA694) ]	24AA025@MSOP8
[ (SA666) ]	
24AA025@SOIC8 [ (SA602A) ]	24AA025@TSSOP8
[ (SA026) ]	
24AA04	24AA04@SOIC8
[ (SA602A) ]	
24AA04@TSSOP8 [ (SA026) ]	
24AA08	
24AA08@SOIC8 [ (SA602A) ]	24AA08@TSSOP8
[ (SA026) ]	
24AA1025	24AA1025@SOIC8
[ (SA602A) ]	
24AA1025@TSSOP8 [ (SA026) ]	
24AA128	
24AA128@MSOP8 [ (SA666) ]	24AA128@SOIC8
[ (SA602A) ]	
24AA128@TSSOP14 [ (SA026) ]	24AA128@TSSOP8
[ (SA026) ]	
24AA16	24AA16@SOIC8
[ (SA602A) ]	
24AA16@TSSOP8 [ (SA026) ]	
24AA164	
24AA164@SOIC8 [ (SA602A) ]	24AA164@TSSOP8
[ (SA026) ]	

24AA174 [ (SA602A) ] 24AA174@TSSOP8 [ (SA026) ] 24AA256 24AA256@MSOP8 [ (SA666) ] [ (SA605A) ] 24AA256@TSSOP14 [ (SA026) ] [ (SA026) ] 24AA32 [ (SA026) ] 24AA32@MSOP8 [ (SA666) ] [ (SA602A) ] 24AA32@TSSOP8 [ (SA026) ] 24AA32A 24AA32A(Rotated)@TSSOP8 [ (SA026) ] 24AA32A@MSOP8 [ (SA666) ] [ (SA602A) ] 24AA32A@TSSOP8 [ (SA026) ] 24AA512 24AA512@DFN8 [ (SA683) ] [ (SA605A) ] 24AA512@TSSOP14 [ (SA602) ] 24AA515 24AA515@SOIC8 [ (SA605A) ] 24AA52 24AA52@DFN8 [ (SA694) ] [ (SA666) ] 24AA52@SOIC8 [ (SA602A) ] [ (SA026) ] 24AA64 [ (SA026) ] 24AA64@MSOP8 [ (SA666) ] [ (SA602A) ] 24AA64@TSSOP8 [ (SA026) ] 24AA65 24AA65@SOIC8 [ (SA602A) ] [ (SA026) ] 24C00 [ (SA602A) ] 24C00@SOT-23 [ (SA717) ] [ (SA026) ] 24C01 24C01A	24AA174@SOIC8   24AA256@SOIC8  24AA256@TSSOP8  24AA32(Rotated)@TSSOP8  24AA32@SOIC8    24AA32A@SOIC8    24AA512@SOIC8    24AA52@MSOP8  24AA52@TSSOP8  24AA64(Rotated)@TSSOP8  24AA64@SOIC8   24AA65@TSSOP8  24C00@SOIC8  24C00@TSSOP8
--	---

24C01A@SOIC8 [(SA602A)]	
24C01C	
24C01C@SOIC8 [(SA602A)]	24C01C@TSSOP8
[(SA026)]	
24C02	
24C02A	
24C02A@SOIC8 [(SA602A)]	
24C02C	
24C02C@SOIC8 [(SA602A)]	24C02C@TSSOP8
[(SA026)]	
24C04	
24C04A	
24C04A@SOIC8 [(SA602A)]	24C04A@TSSOP8
[(SA026)]	
24C08	24C08@SOIC8
[(SA602A)]	
24C08B	24C08B@SOIC8
[(SA602A)]	
24C16	24C16@SOIC8
[(SA602A)]	
24C16B	24C16B@SOIC8
[(SA602A)]	
24C32	24C32@SOIC8
[(SA602A)]	
24C64	24C64@SOIC8
[(SA602A)]	
24C64@TSSOP8 [(SA026)]	
24C65	
24C65@SOIC8 [(SA602A)]	
24FC1025	
24FC1025@SOIC8 [(SA602A)]	24FC1025@TSSOP8
[(SA026)]	
24FC128	24FC128@MSOP8
[(SA666)]	
24FC128@SOIC8 [(SA602A)]	24FC128@TSSOP14
[(SA026)]	
24FC128@TSSOP8 [(SA026)]	
24FC256	
24FC256@MSOP8 [(SA666)]	24FC256@SOIC8
[(SA605A)]	
24FC256@TSSOP14 [(SA026)]	24FC256@TSSOP8
[(SA026)]	
24FC32	24FC32@SOIC8

[ (SA602A) ]	
24FC512	24FC512@DFN8
[ (SA683) ]	
24FC512@SOIC8 [ (SA605A) ]	24FC512@TSSOP14
[ (SA602) ]	
24FC515	24FC515@SOIC8
[ (SA605A) ]	
24FC65	24FC65@SOIC8
[ (SA605A) ]	
24LC00	24LC00@SOIC8
[ (SA602A) ]	
24LC00@SOT-23 [ (SA717) ]	24LC00@TSSOP8
[ (SA026) ]	
24LC01	
24LC014	
24LC014@SOIC8 [ (SA602A) ]	24LC014@TSSOP8
[ (SA026) ]	
24LC01B	24LC01B@SOIC8
[ (SA602A) ]	
24LC01B@TSSOP8 [ (SA026) ]	
24LC02	
24LC024	24LC024@SOIC8
[ (SA602A) ]	
24LC024@TSSOP8 [ (SA026) ]	
24LC025	
24LC025@SOIC8 [ (SA602A) ]	24LC025@TSSOP8
[ (SA026) ]	
24LC02B	24LC02B@DFN8
[ (SA694) ]	
24LC02B@MSOP8 [ (SA666) ]	24LC02B@SOIC8
[ (SA602A) ]	
24LC02B@SOT-23-5 [ (SA717) ]	24LC02B@TSSOP8
[ (SA026) ]	
24LC04	
24LC04B	
24LC04B@SOIC8 [ (SA602A) ]	24LC04B@TSSOP8
[ (SA026) ]	
24LC08	
24LC08B	
24LC08B@SOIC8 [ (SA602A) ]	24LC08B@TSSOP8
[ (SA026) ]	
24LC1025	24LC1025@SOIC8
[ (SA602A) ]	



24LC1025@TSSOP8 [(SA026)]	
24LC128	
24LC128@MSOP8 [(SA666)]	24LC128@SOIC8
[(SA605A)]	
24LC128@TSSOP14 [(SA026)]	24LC128@TSSOP8
[(SA026)]	
24LC16	24LC16@MSOP8
[(SA605A)]	
24LC16@SOIC8 [(SA602A)]	
24LC164	
24LC164@SOIC8 [(SA602A)]	
24LC16B	
24LC16B@SOIC8 [(SA602A)]	24LC16B@TSSOP8
[(SA026)]	
24LC174	24LC174@SOIC8
[(SA602A)]	
24LC21	24LC21@SOIC8
[(SA602A)]	
24LC21A	24LC21A@SOIC8
[(SA602A)]	
24LC22A	24LC22A@SOIC8
[(SA602A)]	
24LC256	24LC256@MSOP8
[(SA666)]	
24LC256@SOIC8 [(SA605A)]	24LC256@TSSOP14
[(SA026)]	
24LC256@TSSOP8 [(SA026)]	
24LC32	
24LC32@SOIC8 [(SA602A)]	
24LC32A	
24LC32A@SOIC8 [(SA602A)]	24LC32A@TSSOP8
[(SA026)]	
24LC512	24LC512@DFN8
[(SA683)]	
24LC512@SOIC8 [(SA605A)]	24LC512@TSSOP14
[(SA602)]	
24LC515	24LC515@SOIC8
[(SA605A)]	
24LC64	24LC64(Rotated)@TSSOP8
[(SA026)]	
24LC64@MSOP8 [(SA605A)]	24LC64@SOIC8
[(SA602A)]	
24LC64@TSSOP8 [(SA026)]	

24LC65	
24LC65@SOIC8 [(SA602A)]	
24LCS21	
24LCS21@SOIC8 [(SA602A)]	
24LCS21A	
24LCS21A@SOIC8 [(SA602A)]	
24LCS22	
24LCS22@SOIC8 [(SA602A)]	
24LCS22A	
24LCS22A@SOIC8 [(SA602A)]	
24LCS52	
24LCS52@DFN8 [(SA694)]	24LCS52@MSOP8
[(SA666)]	
24LCS52@SOIC8 [(SA602A)]	24LCS52@TSSOP8
[(SA026)]	
25AA010A	25AA010A@DFN8
[(SA683)]	
25AA010A@MSOP8 [(SA605A)]	25AA010A@SOIC8
[(SA602A)]	
25AA010A@SOT-23 [(SA698)]	25AA010A@TSSOP8
[(SA026)]	
25AA010A[X-Rotated]@TSSOP8 [(SA026)]	
25AA020A	25AA020A@DFN8
[(SA683)]	
25AA020A@MSOP8 [(SA605A)]	25AA020A@SOIC8
[(SA602A)]	
25AA020A@SOT-23 [(SA698)]	25AA020A@TSSOP8
[(SA026)]	
25AA020A[X-Rotated]@TSSOP8 [(SA026)]	
25AA040	25AA040@SOIC8
[(SA602A)]	
25AA040@TSSOP8 [(SA026)]	
25AA040A	
25AA040A@DFN8 [(SA683)]	25AA040A@MSOP8
[(SA605A)]	
25AA040A@SOIC8 [(SA602A)]	25AA040A@SOT-23
[(SA698)]	
25AA040A@TSSOP8 [(SA026)]	
25AA040A[X-Rotated]@TSSOP8 [(SA026)]	
25AA080	25AA080@SOIC8
[(SA602A)]	
25AA080A	25AA080A@MSOP8
[(SA605A)]	

25AA080A@SOIC8 [(SA602A)]	25AA080A@TSSOP8
[(SA026)]	
25AA080B	25AA080B@MSOP8
[(SA605A)]	
25AA080B@SOIC8 [(SA602A)]	25AA080B@TSSOP8
[(SA026)]	
25AA1024	25AA1024@DFN8
[(SA683)]	
25AA1024@SOIC8 [(SA602A)]	25AA1024@SOIJ8
[(SA605)]	
25AA128	25AA128@DFN8
[(SA683)]	
25AA128@SOIC8(4.0) [(SA602A)]	25AA128@SOIC8(5.4)
[(SA605A)]	
25AA128@TSSOP8 [(SA026)]	
25AA128[X-Rotated]@TSSOP8 [(SA026)]	
25AA160	25AA160@SOIC8
[(SA602A)]	
25AA160A	25AA160A@MSOP8
[(SA605A)]	
25AA160A@SOIC8 [(SA602A)]	25AA160A@TSSOP8
[(SA026)]	
25AA160B	25AA160B@MSOP8
[(SA605A)]	
25AA160B@SOIC8 [(SA602A)]	25AA160B@TSSOP8
[(SA026)]	
25AA256	25AA256@DFN8
[(SA683)]	
25AA256@SOIC8(4.0) [(SA602A)]	25AA256@SOIC8(5.4)
[(SA605A)]	
25AA256@TSSOP8 [(SA026)]	
25AA256[X-Rotated]@TSSOP8 [(SA026)]	
25AA320	25AA320@SOIC8
[(SA602A)]	
25AA320@TSSOP14 [(SA026)]	25AA320@TSSOP8
[(SA026)]	
25AA512	25AA512@DFN8
[(SA683)]	
25AA512@SOIC8 [(SA602A)]	25AA512@SOIJ8
[(SA605)]	
25AA640	25AA640@SOIC8
[(SA602A)]	
25AA640@TSSOP8 [(SA026)]	

25C040	
25C040@SOIC8 [(SA602A)]	25C040@TSSOP8
[(SA026)]	
25C080	25C080@SOIC8
[(SA602A)]	
25C160	25C160@SOIC8
[(SA602A)]	
25C320	25C320@SOIC8
[(SA602A)]	
25C320@TSSOP14 [(SA026)]	25C320@TSSOP8
[(SA026)]	
25C640	25C640@SOIC8
[(SA602A)]	
25C640@TSSOP8 [(SA026)]	
25LC010A	
25LC010A@DFN8 [(SA683)]	25LC010A@MSOP8
[(SA605A)]	
25LC010A@SOIC8 [(SA602A)]	25LC010A@SOT-23
[(SA698)]	
25LC010A@TSSOP8 [(SA026)]	
25LC010A[X-Rotated]@TSSOP8 [(SA026)]	
25LC020A	25LC020A@DFN8
[(SA683)]	
25LC020A@MSOP8 [(SA605A)]	25LC020A@SOIC8
[(SA602A)]	
25LC020A@SOT-23 [(SA698)]	25LC020A@TSSOP8
[(SA026)]	
25LC020A[X-Rotated]@TSSOP8 [(SA026)]	
25LC040	25LC040@SOIC8
[(SA602A)]	
25LC040@TSSOP8 [(SA026)]	
25LC040A	
25LC040A@DFN8 [(SA683)]	25LC040A@MSOP8
[(SA605A)]	
25LC040A@SOIC8 [(SA602A)]	25LC040A@SOT-23
[(SA698)]	
25LC040A@TSSOP8 [(SA026)]	
25LC040A[X-Rotated]@TSSOP8 [(SA026)]	
25LC080	25LC080@SOIC8
[(SA602A)]	
25LC080A	25LC080A@MSOP8
[(SA605A)]	
25LC080A@SOIC8 [(SA602A)]	25LC080A@TSSOP8

[ (SA026) ] 25LC080B	25LC080B@MSOP8
[ (SA605A) ] 25LC080B@SOIC8 [ (SA602A) ]	25LC080B@TSSOP8
[ (SA026) ] 25LC1024	25LC1024@DFN8
[ (SA683) ] 25LC1024@SOIC8 [ (SA602A) ]	25LC1024@SOIJ8
[ (SA605) ] 25LC128	25LC128@DFN8
[ (SA683) ] 25LC128@SOIC8(4.0) [ (SA602A) ]	25LC128@SOIC8(5.4)
[ (SA605A) ] 25LC128@TSSOP8 [ (SA026) ]	
25LC128[X-Rotated]@TSSOP8 [ (SA026) ]	
25LC160	25LC160@SOIC8
[ (SA602A) ] 25LC160A	25LC160A@MSOP8
[ (SA605A) ] 25LC160A@SOIC8 [ (SA602A) ]	25LC160A@TSSOP8
[ (SA026) ] 25LC160B	25LC160B@MSOP8
[ (SA605A) ] 25LC160B@SOIC8 [ (SA602A) ]	25LC160B@TSSOP8
[ (SA026) ] 25LC256	25LC256@DFN8
[ (SA683) ] 25LC256@SOIC8(4.0) [ (SA602A) ]	25LC256@SOIC8(5.4)
[ (SA605A) ] 25LC256@TSSOP8 [ (SA026) ]	
25LC256[X-Rotated]@TSSOP8 [ (SA026) ]	
25LC320	25LC320(SN)@SOIC8
[ (SA602A) ] 25LC320@TSSOP14 [ (SA026) ]	25LC320@TSSOP8
[ (SA026) ] 25LC512	25LC512@DFN8
[ (SA683) ] 25LC512@SOIC8 [ (SA602A) ]	25LC512@SOIJ8
[ (SA605) ] 25LC640	25LC640@SOIC8
[ (SA602A) ] 25LC640@TSSOP8 [ (SA026) ]	
27256	

27256@PLCC32 [(SA015A1T)]	
27C128	
27C128@PLCC32 [(SA015A1T)]	
27C128A	
27C128A@PLCC32 [(SA015A1T)]	
27C256	
27C256@PLCC32 [(SA015A1T)]	
27C32A	
27C512	27C512@PLCC32
[(SA015A1T)]	
27C512A	27C512A@PLCC32
[(SA015A1T)]	
27C513	
27C64	
27C64@PLCC32 [(SA015A1T)]	27C64@SOIC28
[(SA404)]	
27HC1616	27HC1616@PLCC44
[(SA244)]	
27HC1616L	27HC1616L@PLCC44
[(SA244)]	
27HC191	27HC191@PLCC28
[(SA008A)]	
27HC191@SOIC24 [(SA404)]	
27HC256	
27HC256@PLCC32 [(SA015A1T)]	
27HC256L	
27HC256L@PLCC32 [(SA015A1T)]	
27HC291	
27HC291@PLCC28 [(SA008A)]	27HC291@SOIC24
[(SA404)]	
27HC416	
27HC64	
27HC64@PLCC32 [(SA015A1T)]	27HC64@SOIC28
[(SA404)]	
27HC641	27HC641@PLCC28
[(SA008A)]	
27HC641@SOIC24 [(SA404)]	
27HC641L	
27HC641L@PLCC28 [(SA008A)]	27HC641L@SOIC24
[(SA404)]	
27HC64L	27HC64L@PLCC32
[(SA015A1T)]	
27HC64L@SOIC28 [(SA404)]	

27LV256  
27LV256@PLCC32 [(SA015A1T)]  
27LV64  
2817  
2864  
2864@PLCC32 [(SA015A1T)]  
28C04  
28C04@PLCC32 [(SA015A1T)] 28C04@SOIC24  
[(SA404)]  
28C04A 28C04A@PLCC32  
[(SA015A1T)]  
28C04A@SOIC24 [(SA404)]  
28C04AF 28C04AF@SOIC24  
28C04AF@PLCC32 [(SA015A1T)] 28C04AF@SOIC24  
[(SA404)]  
28C04F 28C04F@PLCC32  
[(SA015A1T)]  
28C04F@SOIC24 [(SA404)]  
28C16 28C16@SOIC24  
28C16@PLCC32 [(SA015A1T)] 28C16@SOIC24  
[(SA404)]  
28C16A 28C16A@PLCC32  
[(SA015A1T)]  
28C16A@SOIC24 [(SA404)]  
28C16AF 28C16AF@SOIC24  
28C16AF@PLCC32 [(SA015A1T)] 28C16AF@SOIC24  
[(SA404)]  
28C16F 28C16F@PLCC32  
[(SA015A1T)]  
28C16F@SOIC24 [(SA404)]  
28C17 28C17@SOIC28  
28C17@PLCC32 [(SA015A1T)] 28C17@SOIC28  
[(SA404)]  
28C17A 28C17A@PLCC32  
[(SA015A1T)]  
28C17A@SOIC28 [(SA404)]  
28C17AF 28C17AF@SOIC28  
28C17AF@PLCC32 [(SA015A1T)] 28C17AF@SOIC28  
[(SA404)]  
28C17F 28C17F@PLCC32  
[(SA015A1T)]  
28C17F@SOIC28 [(SA404)]  
28C256

28C256@PLCC32 [(SA015A1T)]	
28C256F	
28C256F@PLCC32 [(SA015A1T)]	
28C64A	
28C64A@PLCC32 [(SA015A1T)]	28C64A@SOIC28
[(SA404)]	
28C64A@TSOP32 [(SA410T)]	
28C64AF	
28C64AF@PLCC32 [(SA015A1T)]	28C64AF@SOIC28
[(SA404)]	
28LV64A	28LV64A@PLCC32
[(SA015A1T)]	
28LV64A@SOIC28 [(SA404)]	
28PC64	
28PC64@PLCC32 [(SA015A1T)]	
59C11	
59C11@SOIC8 [(SA602A)]	
85C72	
85C72@SOIC8 [(SA602A)]	
85C82	
85C82@SOIC8 [(SA602A)]	
85C92	
85C92@SOIC8 [(SA602A)]	93AA46
(08bit)	
93AA46(08bit)@SOIC8 [(SA602A)]	93AA46
(16bit)	
93AA46(16bit)@SOIC8 [(SA602A)]	93AA46A
(08bit)	
93AA46A(08bit)@DFN8 [(BBBB)]	93AA46A(08bit)@MSOP8
[(SA666)]	
93AA46A(08bit)@SOIC8 [(SA602A)]	93AA46A(08bit)@SOT-23
[(SA717)]	
93AA46A(08bit)@TSSOP8 [(SA026)]	93AA46B
(16bit)	
93AA46B(16bit)@DFN8 [(BBBB)]	93AA46B(16bit)@MSOP8
[(SA666)]	
93AA46B(16bit)@SOIC8 [(SA602A)]	93AA46B(16bit)@SOT-23
[(SA717)]	
93AA46B(16bit)@TSSOP8 [(SA026)]	93AA46C
(08bit)	
93AA46C(08bit)@DFN8 [(BBBB)]	93AA46C(08bit)@MSOP8
[(SA666)]	
93AA46C(08bit)@SOIC8 [(SA602A)]	93AA46C(08bit)@TSSOP8



[(SA026)]	
93AA46C(16bit)	93AA46C(16bit)@DFN8
[(BBBB)]	
93AA46C(16bit)@MSOP8 [(SA666)]	93AA46C(16bit)@SOIC8
[(SA602A)]	
93AA46C(16bit)@TSSOP8 [(SA026)]	93AA56
(08bit)	
93AA56(08bit)@SOIC8 [(SA602A)]	93AA56
(16bit)	
93AA56(16bit)@SOIC8 [(SA602A)]	93AA56A
(08bit)	
93AA56A(08bit)@DFN8 [(BBBB)]	93AA56A(08bit)@MSOP8
[(SA666)]	
93AA56A(08bit)@SOIC8 [(SA602A)]	93AA56A(08bit)@SOT-23
[(SA717)]	
93AA56A(08bit)@TSSOP8 [(SA026)]	93AA56B
(16bit)	
93AA56B(16bit)@DFN8 [(BBBB)]	93AA56B(16bit)@MSOP8
[(SA666)]	
93AA56B(16bit)@SOIC8 [(SA602A)]	93AA56B(16bit)@SOT-23
[(SA717)]	
93AA56B(16bit)@TSSOP8 [(SA026)]	93AA56C
(08bit)	
93AA56C(08bit)@DFN8 [(BBBB)]	93AA56C(08bit)@MSOP8
[(SA666)]	
93AA56C(08bit)@SOIC8 [(SA602A)]	93AA56C(08bit)@TSSOP8
[(SA026)]	
93AA56C(16bit)	93AA56C(16bit)@DFN8
[(BBBB)]	
93AA56C(16bit)@MSOP8 [(SA666)]	93AA56C(16bit)@SOIC8
[(SA602A)]	
93AA56C(16bit)@TSSOP8 [(SA026)]	93AA66
(08bit)	
93AA66(08bit)@SOIC8 [(SA602A)]	93AA66
(16bit)	
93AA66(16bit)@SOIC8 [(SA602A)]	93AA66A
(08bit)	
93AA66A(08bit)@DFN8 [(BBBB)]	93AA66A(08bit)@MSOP8
[(SA666)]	
93AA66A(08bit)@SOIC8 [(SA602A)]	93AA66A(08bit)@SOT-23
[(SA717)]	
93AA66A(08bit)@TSSOP8 [(SA026)]	93AA66B
(16bit)	

93AA66B(16bit)@DFN8 [(BBBB)] [(SA666)]	93AA66B(16bit)@MSOP8
93AA66B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93AA66B(16bit)@SOT-23
93AA66B(16bit)@TSSOP8 [(SA026)] (08bit)	93AA66C
93AA66C(08bit)@DFN8 [(BBBB)] [(SA666)]	93AA66C(08bit)@MSOP8
93AA66C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93AA66C(08bit)@TSSOP8
93AA66C(16bit) [(BBBB)]	93AA66C(16bit)@DFN8
93AA66C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93AA66C(16bit)@SOIC8
93AA66C(16bit)@TSSOP8 [(SA026)] (08bit)	93AA76
93AA76(08bit)@SOIC8 [(SA602A)] (16bit)	93AA76
93AA76(16bit)@SOIC8 [(SA602A)] (08bit)	93AA76A
93AA76A(08bit)@DFN8 [(BBBB)] [(SA666)]	93AA76A(08bit)@MSOP8
93AA76A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93AA76A(08bit)@SOT-23
93AA76A(08bit)@TSSOP8 [(SA026)] (16bit)	93AA76B
93AA76B(16bit)@DFN8 [(BBBB)] [(SA666)]	93AA76B(16bit)@MSOP8
93AA76B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93AA76B(16bit)@SOT-23
93AA76B(16bit)@TSSOP8 [(SA026)] (08bit)	93AA76C
93AA76C(08bit)@DFN8 [(BBBB)] [(SA666)]	93AA76C(08bit)@MSOP8
93AA76C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93AA76C(08bit)@TSSOP8
93AA76C(16bit) [(BBBB)]	93AA76C(16bit)@DFN8
93AA76C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93AA76C(16bit)@SOIC8
93AA76C(16bit)@TSSOP8 [(SA026)] (08bit)	93AA86
93AA86(08bit)@SOIC8 [(SA602A)]	93AA86

(16bit)	
93AA86(16bit)@SOIC8 [(SA602A)]	93AA86A
(08bit)	
93AA86A(08bit)@DFN8 [(BBBB)]	93AA86A(08bit)@MSOP8
[(SSA666)]	
93AA86A(08bit)@SOIC8 [(SA602A)]	93AA86A(08bit)@SOT-23
[(SA717)]	
93AA86A(08bit)@TSSOP8 [(SA026)]	93AA86B
(16bit)	
93AA86B(16bit)@DFN8 [(BBBB)]	93AA86B(16bit)@MSOP8
[(SA666)]	
93AA86B(16bit)@SOIC8 [(SA602A)]	93AA86B(16bit)@SOT-23
[(SA717)]	
93AA86B(16bit)@TSSOP8 [(SA026)]	93AA86C
(08bit)	
93AA86C(08bit)@DFN8 [(BBBB)]	93AA86C(08bit)@MSOP8
[(SA666)]	
93AA86C(08bit)@SOIC8 [(SA602A)]	93AA86C(08bit)@TSSOP8
[(SA026)]	
93AA86C(16bit)	93AA86C(16bit)@DFN8
[(BBBB)]	
93AA86C(16bit)@MSOP8 [(SA666)]	93AA86C(16bit)@SOIC8
[(SA602A)]	
93AA86C(16bit)@TSSOP8 [(SA026)]	93C06
(08bit)	
93C06(08bit)@SOIC8 [(SA602A)]	93C06
(16bit)	
93C06(16bit)@SOIC8 [(SA602A)]	93C46
(08bit)	
93C46(08bit)@SOIC8 [(SA602A)]	93C46
(16bit)	
93C46(16bit)@SOIC8 [(SA602A)]	93C46A
(08bit)	
93C46A(08bit)@DFN8 [(BBBB)]	93C46A(08bit)@MSOP8
[(SA666)]	
93C46A(08bit)@SOIC8 [(SA602A)]	93C46A(08bit)@SOT-23
[(SA717)]	
93C46A(08bit)@TSSOP8 [(SA026)]	93C46B
(16bit)	
93C46B(16bit)@DFN8 [(BBBB)]	93C46B(16bit)@MSOP8
[(SA666)]	
93C46B(16bit)@SOIC8 [(SA602A)]	93C46B(16bit)@SOT-23
[(SA717)]	

93C46B(16bit)@TSSOP8 [(SA026)] (08bit)	93C46C
93C46C(08bit)@DFN8 [(BBBB)] [(SA666)]	93C46C(08bit)@MSOP8
93C46C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93C46C(08bit)@TSSOP8
93C46C(16bit) [(BBBB)]	93C46C(16bit)@DFN8
93C46C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93C46C(16bit)@SOIC8
93C46C(16bit)@TSSOP8 [(SA026)] (08bit)	93C56
93C56(08bit)@SOIC8 [(SA602A)] (16bit)	93C56
93C56(16bit)@SOIC8 [(SA602A)] (08bit)	93C56A
93C56A(08bit)@DFN8 [(BBBB)] [(SA666)]	93C56A(08bit)@MSOP8
93C56A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93C56A(08bit)@SOT-23
93C56A(08bit)@TSSOP8 [(SA026)] (16bit)	93C56B
93C56B(16bit)@DFN8 [(BBBB)] [(SA666)]	93C56B(16bit)@MSOP8
93C56B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93C56B(16bit)@SOT-23
93C56B(16bit)@TSSOP8 [(SA026)] (08bit)	93C56C
93C56C(08bit)@DFN8 [(BBBB)] [(SA666)]	93C56C(08bit)@MSOP8
93C56C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93C56C(08bit)@TSSOP8
93C56C(16bit) [(BBBB)]	93C56C(16bit)@DFN8
93C56C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93C56C(16bit)@SOIC8
93C56C(16bit)@TSSOP8 [(SA026)] (08bit)	93C66
93C66(08bit)@SOIC8 [(SA602A)] (16bit)	93C66
93C66(16bit)@SOIC8 [(SA602A)] (08bit)	93C66A
93C66A(08bit)@DFN8 [(BBBB)]	93C66A(08bit)@MSOP8

[(SA666)]	
93C66A(08bit)@SOIC8 [(SA602A)]	93C66A(08bit)@SOT-23
[(SA717)]	
93C66A(08bit)@TSSOP8 [(SA026)]	93C66B
(16bit)	
93C66B(16bit)@DFN8 [(BBBB)]	93C66B(16bit)@MSOP8
[(SA666)]	
93C66B(16bit)@SOIC8 [(SA602A)]	93C66B(16bit)@SOT-23
[(SA717)]	
93C66B(16bit)@TSSOP8 [(SA026)]	93C66C
(08bit)	
93C66C(08bit)@DFN8 [(BBBB)]	93C66C(08bit)@MSOP8
[(SA666)]	
93C66C(08bit)@SOIC8 [(SA602A)]	93C66C(08bit)@TSSOP8
[(SA026)]	
93C66C(16bit)	93C66C(16bit)@DFN8
[(BBBB)]	
93C66C(16bit)@MSOP8 [(SA666)]	93C66C(16bit)@SOIC8
[(SA602A)]	
93C66C(16bit)@TSSOP8 [(SA026)]	93C76
(08bit)	
93C76(08bit)@SOIC8 [(SA602A)]	93C76
(16bit)	
93C76(16bit)@SOIC8 [(SA602A)]	93C76A
(08bit)	
93C76A(08bit)@DFN8 [(BBBB)]	93C76A(08bit)@MSOP8
[(SA666)]	
93C76A(08bit)@SOIC8 [(SA602A)]	93C76A(08bit)@SOT-23
[(SA717)]	
93C76A(08bit)@TSSOP8 [(SA026)]	93C76B
(16bit)	
93C76B(16bit)@DFN8 [(BBBB)]	93C76B(16bit)@MSOP8
[(SA666)]	
93C76B(16bit)@SOIC8 [(SA602A)]	93C76B(16bit)@SOT-23
[(SA717)]	
93C76B(16bit)@TSSOP8 [(SA026)]	93C76C
(08bit)	
93C76C(08bit)@DFN8 [(BBBB)]	93C76C(08bit)@MSOP8
[(SA666)]	
93C76C(08bit)@SOIC8 [(SA602A)]	93C76C(08bit)@TSSOP8
[(SA026)]	
93C76C(16bit)	93C76C(16bit)@DFN8
[(BBBB)]	

93C76C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93C76C(16bit)@SOIC8
93C76C(16bit)@TSSOP8 [(SA026)] (08bit)	93C86
93C86(08bit)@SOIC8 [(SA602A)] (16bit)	93C86
93C86(16bit)@SOIC8 [(SA602A)] (08bit)	93C86A
93C86A(08bit)@DFN8 [(BBBB)] [(SSA666)]	93C86A(08bit)@MSOP8
93C86A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93C86A(08bit)@SOT-23
93C86A(08bit)@TSSOP8 [(SA026)] (16bit)	93C86B
93C86B(16bit)@DFN8 [(BBBB)] [(SA666)]	93C86B(16bit)@MSOP8
93C86B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93C86B(16bit)@SOT-23
93C86B(16bit)@TSSOP8 [(SA026)] (08bit)	93C86C
93C86C(08bit)@DFN8 [(BBBB)] [(SA666)]	93C86C(08bit)@MSOP8
93C86C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93C86C(08bit)@TSSOP8
93C86C(16bit) [(BBBB)]	93C86C(16bit)@DFN8
93C86C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93C86C(16bit)@SOIC8
93C86C(16bit)@TSSOP8 [(SA026)] (08bit)	93LC46
93LC46(08bit)@SOIC8 [(SA602A)] (16bit)	93LC46
93LC46(16bit)@SOIC8 [(SA602A)] (08bit)	93LC46A
93LC46A(08bit)@DFN8 [(BBBB)] [(SA666)]	93LC46A(08bit)@MSOP8
93LC46A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93LC46A(08bit)@SOT-23
93LC46A(08bit)@TSSOP8 [(SA026)] (16bit)	93LC46B
93LC46B(16bit)@DFN8 [(BBBB)] [(SA666)]	93LC46B(16bit)@MSOP8
93LC46B(16bit)@SOIC8 [(SA602A)]	93LC46B(16bit)@SOT-23

[(SA717)]	
93LC46B(16bit)@TSSOP8 [(SA026)]	
93LC46BX	
93LC46BX@SOIC8 [(SA602A)]	93LC46C
(08bit)	
93LC46C(08bit)@DFN8 [(BBBB)]	93LC46C(08bit)@MSOP8
[(SA666)]	
93LC46C(08bit)@SOIC8 [(SA602A)]	93LC46C(08bit)@TSSOP8
[(SA026)]	
93LC46C(16bit)	93LC46C(16bit)@DFN8
[(BBBB)]	
93LC46C(16bit)@MSOP8 [(SA666)]	93LC46C(16bit)@SOIC8
[(SA602A)]	
93LC46C(16bit)@TSSOP8 [(SA026)]	93LC56
(08bit)	
93LC56(08bit)@SOIC8 [(SA602A)]	93LC56
(16bit)	
93LC56(16bit)@SOIC8 [(SA602A)]	93LC56A
(08bit)	
93LC56A(08bit)@DFN8 [(BBBB)]	93LC56A(08bit)@MSOP8
[(SA666)]	
93LC56A(08bit)@SOIC8 [(SA602A)]	93LC56A(08bit)@SOT-23
[(SA717)]	
93LC56A(08bit)@TSSOP8 [(SA026)]	93LC56B
(16bit)	
93LC56B(16bit)@DFN8 [(BBBB)]	93LC56B(16bit)@MSOP8
[(SA666)]	
93LC56B(16bit)@SOIC8 [(SA602A)]	93LC56B(16bit)@SOT-23
[(SA717)]	
93LC56B(16bit)@TSSOP8 [(SA026)]	
93LC56BX	
93LC56BX@SOIC8 [(SA602A)]	93LC56C
(08bit)	
93LC56C(08bit)@DFN8 [(BBBB)]	93LC56C(08bit)@MSOP8
[(SA666)]	
93LC56C(08bit)@SOIC8 [(SA602A)]	93LC56C(08bit)@TSSOP8
[(SA026)]	
93LC56C(16bit)	93LC56C(16bit)@DFN8
[(BBBB)]	
93LC56C(16bit)@MSOP8 [(SA666)]	93LC56C(16bit)@SOIC8
[(SA602A)]	
93LC56C(16bit)@TSSOP8 [(SA026)]	93LC66
(08bit)	

93LC66(08bit)@SOIC8 [(SA602A)] (16bit)	93LC66
93LC66(16bit)@SOIC8 [(SA602A)] (08bit)	93LC66A
93LC66A(08bit)@DFN8 [(BBBB)] [(SA666)]	93LC66A(08bit)@MSOP8
93LC66A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93LC66A(08bit)@SOT-23
93LC66A(08bit)@TSSOP8 [(SA026)] (16bit)	93LC66B
93LC66B(16bit)@DFN8 [(BBBB)] [(SA666)]	93LC66B(16bit)@MSOP8
93LC66B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93LC66B(16bit)@SOT-23
93LC66B(16bit)@TSSOP8 [(SA026)]	
93LC66BX	
93LC66BX@SOIC8 [(SA602A)] (08bit)	93LC66C
93LC66C(08bit)@DFN8 [(BBBB)] [(SA666)]	93LC66C(08bit)@MSOP8
93LC66C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93LC66C(08bit)@TSSOP8
93LC66C(16bit) [(BBBB)]	93LC66C(16bit)@DFN8
93LC66C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93LC66C(16bit)@SOIC8
93LC66C(16bit)@TSSOP8 [(SA026)] (08bit)	93LC76
93LC76(08bit)@SOIC8 [(SA602A)] (16bit)	93LC76
93LC76(16bit)@SOIC8 [(SA602A)] (08bit)	93LC76A
93LC76A(08bit)@DFN8 [(BBBB)] [(SA666)]	93LC76A(08bit)@MSOP8
93LC76A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93LC76A(08bit)@SOT-23
93LC76A(08bit)@TSSOP8 [(SA026)] (16bit)	93LC76B
93LC76B(16bit)@DFN8 [(BBBB)] [(SA666)]	93LC76B(16bit)@MSOP8
93LC76B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93LC76B(16bit)@SOT-23
93LC76B(16bit)@TSSOP8 [(SA026)]	93LC76C



(08bit)	
93LC76C(08bit)@DFN8 [(BBBB)]	93LC76C(08bit)@MSOP8
[(SA666)]	
93LC76C(08bit)@SOIC8 [(SA602A)]	93LC76C(08bit)@TSSOP8
[(SA026)]	
93LC76C(16bit)	93LC76C(16bit)@DFN8
[(BBBB)]	
93LC76C(16bit)@MSOP8 [(SA666)]	93LC76C(16bit)@SOIC8
[(SA602A)]	
93LC76C(16bit)@TSSOP8 [(SA026)]	93LC86
(08bit)	
93LC86(08bit)@SOIC8 [(SA602A)]	93LC86
(16bit)	
93LC86(16bit)@SOIC8 [(SA602A)]	93LC86A
(08bit)	
93LC86A(08bit)@DFN8 [(BBBB)]	93LC86A(08bit)@MSOP8
[(SSA666)]	
93LC86A(08bit)@SOIC8 [(SA602A)]	93LC86A(08bit)@SOT-23
[(SA717)]	
93LC86A(08bit)@TSSOP8 [(SA026)]	93LC86B
(16bit)	
93LC86B(16bit)@DFN8 [(BBBB)]	93LC86B(16bit)@MSOP8
[(SA666)]	
93LC86B(16bit)@SOIC8 [(SA602A)]	93LC86B(16bit)@SOT-23
[(SA717)]	
93LC86B(16bit)@TSSOP8 [(SA026)]	93LC86C
(08bit)	
93LC86C(08bit)@DFN8 [(BBBB)]	93LC86C(08bit)@MSOP8
[(SA666)]	
93LC86C(08bit)@SOIC8 [(SA602A)]	93LC86C(08bit)@TSSOP8
[(SA026)]	
93LC86C(16bit)	93LC86C(16bit)@DFN8
[(BBBB)]	
93LC86C(16bit)@MSOP8 [(SA666)]	93LC86C(16bit)@SOIC8
[(SA602A)]	
93LC86C(16bit)@TSSOP8 [(SA026)]	
93LCS46	
93LCS46@SOIC14 [(SA026)]	93LCS46@SOIC8
[(SA602A)]	
93LCS56	93LCS56@SOIC14
[(SA026)]	
93LCS56@SOIC8 [(SA602A)]	
93LCS66	

93LCS66@SOIC14 [(SA026)]	93LCS66@SOIC8
[(SA602A)]	
ER5911	ER5911@SOIC8
[(SA602A)]	
HCS101	HCS101SN@SOIC8
[(SA602A)]	
HCS200	HCS200SN@SOIC8
[(SA602A)]	
HCS300	HCS300SN@SOIC8
[(SA602A)]	
HCS301	HCS301SN@SOIC8
[(SA602A)]	
HCS320	HCS320SN@SOIC8
[(SA602A)]	
HCS360	HCS360SN@SOIC8
[(SA602A)]	
HCS361	HCS361SN@SOIC8
[(SA602A)]	

## MICROCONTROLLER

MCP25020  
MCP25020(150mil)@SOIC14 [(SA602)]  
MCP25020(150mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25020(208mil)@SOIC14 [(SA404)]  
MCP25020(208mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25020(ISP) [ISP-HEADER01]  
MCP25025  
MCP25025(150mil)@SOIC14 [(SA602)]  
MCP25025(150mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25025(208mil)@SOIC14 [(SA404)]  
MCP25025(208mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25025(ISP) [ISP-HEADER01]  
MCP25050  
MCP25050(150mil)@SOIC14 [(SA602)]  
MCP25050(150mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25050(208mil)@SOIC14 [(SA404)]  
MCP25050(208mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25050(ISP) [ISP-HEADER01]  
MCP25055  
MCP25055(150mil)@SOIC14 [(SA602)]  
MCP25055(150mil)@SOIC14(ISP) [ISP-HEADER01]

MCP25055(208mil)@SOIC14 [(SA404)]  
MCP25055(208mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25055(ISP) [ISP-HEADER01]  
PIC10F200  
PIC10F200(ISP) [ISP-HEADER01] PIC10F200@SOT6  
[(SA717)]  
PIC10F200@SOT6(ISP) [ISP-HEADER01]  
PIC10F202 PIC10F202(ISP) [ISP-  
HEADER01]  
PIC10F202@SOT6 [(SA717)]  
PIC10F202@SOT6(ISP) [ISP-HEADER01]  
PIC10F204 PIC10F204(ISP) [ISP-  
HEADER01]  
PIC10F204@SOT6 [(SA717)]  
PIC10F204@SOT6(ISP) [ISP-HEADER01]  
PIC10F206 PIC10F206(ISP) [ISP-  
HEADER01]  
PIC10F206@SOT6 [(SA717)]  
PIC10F206@SOT6(ISP) [ISP-HEADER01]  
PIC10F220 PIC10F220(ISP) [ISP-  
HEADER01]  
PIC10F220@SOT6 [(SA717)]  
PIC10F220@SOT6(ISP) [ISP-HEADER01]  
PIC10F222 PIC10F222(ISP) [ISP-  
HEADER01]  
PIC10F222@SOT6 [(SA717)]  
PIC10F222@SOT6(ISP) [ISP-HEADER01]  
PIC12C508 PIC12C508(ISP) [ISP-  
HEADER01]  
PIC12C508@SOIC8 [(SA605A)]  
PIC12C508@SOIC8(ISP) [ISP-HEADER01]  
PIC12C508A PIC12C508A(ISP) [ISP-  
HEADER01]  
PIC12C508A(SM)@SOIC8 [(SA605A)]  
PIC12C508A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C508A(SN)@SOIC8 [(SA602A)]  
PIC12C508A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509 PIC12C509(ISP) [ISP-  
HEADER01]  
PIC12C509(SM)@SOIC8 [(SA605A)]  
PIC12C509(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509(SN)@SOIC8 [(SA602A)]  
PIC12C509(SN)@SOIC8(ISP) [ISP-HEADER01]

PIC12C509A PIC12C509A(ISP) [ISP-  
HEADER01]  
PIC12C509A(SM)@SOIC8 [(SA605A)]  
PIC12C509A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509A(SN)@SOIC8 [(SA602A)]  
PIC12C509A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509A@DFN8 [(SA683)]  
PIC12C509A@DFN8(ISP) [ISP-HEADER01]  
PIC12C671 PIC12C671(ISP) [ISP-  
HEADER01]  
PIC12C671@DFN8 [(SA683)]  
PIC12C671@DFN8(ISP) [ISP-HEADER01]  
PIC12C671@SOIC8 [(SA605A)]  
PIC12C671@SOIC8(ISP) [ISP-HEADER01]  
PIC12C672 PIC12C672(ISP) [ISP-  
HEADER01]  
PIC12C672@DFN8 [(SA683)]  
PIC12C672@DFN8(ISP) [ISP-HEADER01]  
PIC12C672@SOIC8 [(SA605A)]  
PIC12C672@SOIC8(ISP) [ISP-HEADER01]  
PIC12CE518 PIC12CE518(ISP) [ISP-  
HEADER01]  
PIC12CE518@SOIC8 [(SA605A)]  
PIC12CE518@SOIC8(ISP) [ISP-HEADER01]  
PIC12CE519 PIC12CE519(ISP) [ISP-  
HEADER01]  
PIC12CE519(SM)@SOIC8 [(SA605A)]  
PIC12CE519(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12CE519(SN)@SOIC8 [(SA602A)]  
PIC12CE519(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12CE673 PIC12CE673(ISP) [ISP-  
HEADER01]  
PIC12CE673@SOIC8 [(SA605A)]  
PIC12CE673@SOIC8(ISP) [ISP-HEADER01]  
PIC12CE674 PIC12CE674(ISP) [ISP-  
HEADER01]  
PIC12CE674@SOIC8 [(SA605A)]  
PIC12CE674@SOIC8(ISP) [ISP-HEADER01]  
PIC12F508 PIC12F508(ISP) [ISP-  
HEADER01]  
PIC12F508@MSOP8 [(SA666)]  
PIC12F508@MSOP8(ISP) [ISP-HEADER01]  
PIC12F508@SOIC8 [(SA602)]

PIC12F508@SOIC8(ISP) [ISP-HEADER01]  
PIC12F509 PIC12F509(ISP) [ISP-  
HEADER01]  
PIC12F509@MSOP8 [(SA666)]  
PIC12F509@MSOP8(ISP) [ISP-HEADER01]  
PIC12F509@SOIC8 [(SA602)]  
PIC12F509@SOIC8(ISP) [ISP-HEADER01]  
PIC12F510 PIC12F510(ISP) [ISP-  
HEADER01]  
PIC12F510@MSOP8 [(SA666)]  
PIC12F510@MSOP8(ISP) [ISP-HEADER01]  
PIC12F510@SOIC8 [(SA605A)]  
PIC12F510@SOIC8(ISP) [ISP-HEADER01]  
PIC12F609 PIC12F609(ISP) [ISP-  
HEADER01]  
PIC12F609@DFN8 [(BBBB)]  
PIC12F609@DFN8(ISP) [ISP-HEADER01]  
PIC12F609@SOIC8 [(SA602A)]  
PIC12F609@SOIC8(ISP) [ISP-HEADER01]  
PIC12F615 PIC12F615(ISP) [ISP-  
HEADER01]  
PIC12F615@DFN8 [(BBBB)]  
PIC12F615@DFN8(ISP) [ISP-HEADER01]  
PIC12F615@SOIC8 [(SA602A)]  
PIC12F615@SOIC8(ISP) [ISP-HEADER01]  
PIC12F629 PIC12F629(ISP) [ISP-  
HEADER01]  
PIC12F629(SM)@SOIC8 [(SA605A)]  
PIC12F629(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F629(SN)@SOIC8 [(SA602A)]  
PIC12F629(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F629@DFN8 [(SA683)]  
PIC12F629@DFN8(ISP) [ISP-HEADER01]  
PIC12F635 PIC12F635(ISP) [ISP-  
HEADER01]  
PIC12F635(MD)@DFN8 [(SA744)]  
PIC12F635(MD)@DFN8(ISP) [ISP-HEADER01]  
PIC12F635(MF)@DFN8 [(SA683)]  
PIC12F635(MF)@DFN8(ISP) [ISP-HEADER01]  
PIC12F635(SM)@SOIC8 [(SA605A)]  
PIC12F635(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F635(SN)@SOIC8 [(SA602A)]  
PIC12F635(SN)@SOIC8(ISP) [ISP-HEADER01]

PIC12F675 PIC12F675(ISP) [ISP-  
HEADER01]  
PIC12F675(SM)@SOIC8 [(SA605A)]  
PIC12F675(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F675(SN)@SOIC8 [(SA602A)]  
PIC12F675(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F675@DFN8 [(SA683)]  
PIC12F675@DFN8(ISP) [ISP-HEADER01]  
PIC12F675@SSOP20 [(SA626A)]  
PIC12F675@SSOP20(ISP) [ISP-HEADER01]  
PIC12F683 PIC12F683(ISP) [ISP-  
HEADER01]  
PIC12F683(MD)@DFN8 [(SA744)]  
PIC12F683(MD)@DFN8(ISP) [ISP-HEADER01]  
PIC12F683(MF)@DFN8 [(SA683)]  
PIC12F683(MF)@DFN8(ISP) [ISP-HEADER01]  
PIC12F683(SM)@SOIC8 [(SA605A)]  
PIC12F683(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F683(SN)@SOIC8 [(SA602A)]  
PIC12F683(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12HV609 PIC12HV609(ISP) [ISP-  
HEADER01]  
PIC12HV609@DFN8 [(BBBB)]  
PIC12HV609@DFN8(ISP) [ISP-HEADER01]  
PIC12HV609@SOIC8 [(SA602A)]  
PIC12HV609@SOIC8(ISP) [ISP-HEADER01]  
PIC12HV615 PIC12HV615(ISP) [ISP-  
HEADER01]  
PIC12HV615@DFN8 [(BBBB)]  
PIC12HV615@DFN8(ISP) [ISP-HEADER01]  
PIC12HV615@SOIC8 [(SA602A)]  
PIC12HV615@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC508 PIC12LC508(ISP) [ISP-  
HEADER01]  
PIC12LC508@SOIC8 [(SA605A)]  
PIC12LC508@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC508A PIC12LC508A(ISP) [ISP-  
HEADER01]  
PIC12LC508A(SM)@SOIC8 [(SA605A)]  
PIC12LC508A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC508A(SN)@SOIC8 [(SA602A)]  
PIC12LC508A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509 PIC12LC509(ISP) [ISP-

HEADER01 ]  
PIC12LC509(SM)@SOIC8 [(SA605A)]  
PIC12LC509(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509(SN)@SOIC8 [(SA602A)]  
PIC12LC509(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509A PIC12LC509A(ISP) [ISP-  
HEADER01]  
PIC12LC509A(SM)@SOIC8 [(SA605A)]  
PIC12LC509A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509A(SN)@SOIC8 [(SA602A)]  
PIC12LC509A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC671 PIC12LC671(ISP) [ISP-  
HEADER01]  
PIC12LC671@DFN8 [(SA683)]  
PIC12LC671@DFN8(ISP) [ISP-HEADER01]  
PIC12LC671@SOIC8 [(SA605A)]  
PIC12LC671@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC672 PIC12LC672(ISP) [ISP-  
HEADER01]  
PIC12LC672@DFN8 [(SA683)]  
PIC12LC672@DFN8(ISP) [ISP-HEADER01]  
PIC12LC672@SOIC8 [(SA605A)]  
PIC12LC672@SOIC8(ISP) [ISP-HEADER01]  
PIC12LF508 PIC12LF508(ISP) [ISP-  
HEADER01]  
PIC12LF508@MSOP8 [(SA666)]  
PIC12LF508@MSOP8(ISP) [ISP-HEADER01]  
PIC12LF508@SOIC8 [(SA602)]  
PIC12LF508@SOIC8(ISP) [ISP-HEADER01]  
PIC12LF509 PIC12LF509(ISP) [ISP-  
HEADER01]  
PIC12LF509@MSOP8 [(SA666)]  
PIC12LF509@MSOP8(ISP) [ISP-HEADER01]  
PIC12LF509@SOIC8 [(SA602)]  
PIC12LF509@SOIC8(ISP) [ISP-HEADER01]  
PIC14000 PIC14000(ISP) [ISP-  
HEADER01]  
PIC14000@SOIC28 [(SA404)]  
PIC14000@SOIC28(ISP) [ISP-HEADER01]  
PIC14000@SSOP28 [(SA626A)]  
PIC14000@SSOP28(ISP) [ISP-HEADER01]  
PIC16C432 PIC16C432(ISP) [ISP-  
HEADER01]

PIC16C432@SSOP20 [(SA626A)]  
PIC16C432@SSOP20(ISP) [ISP-HEADER01]  
PIC16C433 PIC16C433(ISP) [ISP-  
HEADER01]  
PIC16C433@SOIC18 [(SA404)]  
PIC16C433@SOIC18(ISP) [ISP-HEADER01]  
PIC16C505 PIC16C505@SOIC14  
[(SA602)]  
PIC16C52 PIC16C52@SOIC18  
[(SA404)]  
PIC16C54 PIC16C54@SOIC18  
[(SA404)]  
PIC16C54A PIC16C54A@SOIC18  
[(SA404)]  
PIC16C54A@SSOP20 [(SA626A)]  
PIC16C54B  
PIC16C54B@SOIC18 [(SA404)] PIC16C54B@SSOP20  
[(SA626A)]  
PIC16C54C PIC16C54C@SOIC18  
[(SA404)]  
PIC16C54C@SSOP20 [(SA626A)]  
PIC16C55  
PIC16C55@SOIC28 [(SA404)]  
PIC16C554  
PIC16C554(ISP) [ISP-HEADER01] PIC16C554@SOIC18  
[(SA404)]  
PIC16C554@SOIC18(ISP) [ISP-HEADER01]  
PIC16C554@SSOP20 [(SA626A)]  
PIC16C554@SSOP20(ISP) [ISP-HEADER01]  
PIC16C556 PIC16C556(ISP) [ISP-  
HEADER01]  
PIC16C556@SOIC18 [(SA404)]  
PIC16C556@SOIC18(ISP) [ISP-HEADER01]  
PIC16C558 PIC16C558(ISP) [ISP-  
HEADER01]  
PIC16C558@SOIC18 [(SA404)]  
PIC16C558@SOIC18(ISP) [ISP-HEADER01]  
PIC16C558@SSOP20 [(SA626A)]  
PIC16C558@SSOP20(ISP) [ISP-HEADER01]  
PIC16C55A PIC16C55A@SOIC28  
[(SA404)]  
PIC16C55A@SSOP28 [(SA626A)]  
PIC16C56



PIC16C56@SOIC18 [(SA404)]  
PIC16C56A  
PIC16C56A@SOIC18 [(SA404)] PIC16C56A@SSOP20  
[(SA626A)]  
PIC16C57 PIC16C57@SOIC28  
[(SA404)]  
PIC16C57@SSOP28 [(SA626A)]  
PIC16C57C  
PIC16C57C@SOIC28 [(SA404)] PIC16C57C@SSOP28  
[(SA626A)]  
PIC16C58 PIC16C58@SOIC18  
[(SA404)]  
PIC16C58A PIC16C58A@SOIC18  
[(SA404)]  
PIC16C58A@SSOP20 [(SA626A)]  
PIC16C58B  
PIC16C58B@SOIC18 [(SA404)] PIC16C58B@SSOP20  
[(SA626A)]  
PIC16C61 PIC16C61(ISP) [ISP-  
HEADER01]  
PIC16C61@SOIC18 [(SA404)]  
PIC16C61@SOIC18(ISP) [ISP-HEADER01]  
PIC16C62 PIC16C62(ISP) [ISP-  
HEADER01]  
PIC16C62@SOIC28 [(SA404)]  
PIC16C62@SOIC28(ISP) [ISP-HEADER01]  
PIC16C62@SSOP28 [(SA626A)]  
PIC16C62@SSOP28(ISP) [ISP-HEADER01]  
PIC16C620 PIC16C620(ISP) [ISP-  
HEADER01]  
PIC16C620@SOIC18 [(SA404)]  
PIC16C620@SOIC18(ISP) [ISP-HEADER01]  
PIC16C620A PIC16C620A(ISP) [ISP-  
HEADER01]  
PIC16C620A@SOIC18 [(SA404)]  
PIC16C620A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C620A@SSOP20 [(SA626A)]  
PIC16C620A@SSOP20(ISP) [ISP-HEADER01]  
PIC16C621 PIC16C621(ISP) [ISP-  
HEADER01]  
PIC16C621@SOIC18 [(SA404)]  
PIC16C621@SOIC18(ISP) [ISP-HEADER01]  
PIC16C621A PIC16C621A(ISP) [ISP-

HEADER01 ]  
PIC16C621A@SOIC18 [(SA404)]  
PIC16C621A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C621A@SSOP20 [(SA626A)]  
PIC16C621A@SSOP20(ISP) [ISP-HEADER01]  
PIC16C622 PIC16C622(ISP) [ISP-  
HEADER01]  
PIC16C622@SOIC18 [(SA404)]  
PIC16C622@SOIC18(ISP) [ISP-HEADER01]  
PIC16C622A PIC16C622A(ISP) [ISP-  
HEADER01]  
PIC16C622A@SOIC18 [(SA404)]  
PIC16C622A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C622A@SSOP20 [(SA626A)]  
PIC16C622A@SSOP20(ISP) [ISP-HEADER01]  
PIC16C625 PIC16C625(ISP) [ISP-  
HEADER01]  
PIC16C625@SOIC18 [(SA404)]  
PIC16C625@SOIC18(ISP) [ISP-HEADER01]  
PIC16C62A PIC16C62A(ISP) [ISP-  
HEADER01]  
PIC16C62A@SOIC28 [(SA404)]  
PIC16C62A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C62A@SSOP28 [(SA626A)]  
PIC16C62A@SSOP28(ISP) [ISP-HEADER01]  
PIC16C62B PIC16C62B(ISP) [ISP-  
HEADER01]  
PIC16C62B@SOIC28 [(SA404)]  
PIC16C62B@SOIC28(ISP) [ISP-HEADER01]  
PIC16C62B@SSOP28 [(SA626A)]  
PIC16C62B@SSOP28(ISP) [ISP-HEADER01]  
PIC16C63 PIC16C63(ISP) [ISP-  
HEADER01]  
PIC16C63@SOIC28 [(SA404)]  
PIC16C63@SOIC28(ISP) [ISP-HEADER01]  
PIC16C63A PIC16C63A(ISP) [ISP-  
HEADER01]  
PIC16C63A@SOIC28 [(SA404)]  
PIC16C63A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C63A@SSOP28 [(SA626A)]  
PIC16C63A@SSOP28(ISP) [ISP-HEADER01]  
PIC16C64 PIC16C64(ISP) [ISP-  
HEADER01]

PIC16C64@PLCC44 [(SA244)]  
PIC16C64@PLCC44(ISP) [ISP-HEADER01]  
PIC16C64@TQFP44 [(SA245A)]  
PIC16C64@TQFP44(ISP) [ISP-HEADER01]  
PIC16C641 PIC16C641@SOIC28  
[(SA404)]  
PIC16C641@SSOP28 [(SA626A)]  
PIC16C642  
PIC16C642@SOIC28 [(SA404)] PIC16C642@SSOP28  
[(SA626A)]  
PIC16C64A PIC16C64A(ISP) [ISP-  
HEADER01]  
PIC16C64A@PLCC44 [(SA244)]  
PIC16C64A@PLCC44(ISP) [ISP-HEADER01]  
PIC16C64A@TQFP44 [(SA245A)]  
PIC16C64A@TQFP44(ISP) [ISP-HEADER01]  
PIC16C65 PIC16C65(ISP) [ISP-  
HEADER01]  
PIC16C65@PLCC44 [(SA244)]  
PIC16C65@PLCC44(ISP) [ISP-HEADER01]  
PIC16C65@TQFP44 [(SA245A)]  
PIC16C65@TQFP44(ISP) [ISP-HEADER01]  
PIC16C65A PIC16C65A(ISP) [ISP-  
HEADER01]  
PIC16C65A@PLCC44 [(SA244)]  
PIC16C65A@PLCC44(ISP) [ISP-HEADER01]  
PIC16C65A@TQFP44 [(SA245A)]  
PIC16C65A@TQFP44(ISP) [ISP-HEADER01]  
PIC16C65B PIC16C65B(ISP) [ISP-  
HEADER01]  
PIC16C65B@PLCC44 [(SA244)]  
PIC16C65B@PLCC44(ISP) [ISP-HEADER01]  
PIC16C65B@TQFP44 [(SA245A)]  
PIC16C65B@TQFP44(ISP) [ISP-HEADER01]  
PIC16C66 PIC16C66(ISP) [ISP-  
HEADER01]  
PIC16C66@SOIC28 [(SA404)]  
PIC16C66@SOIC28(ISP) [ISP-HEADER01]  
PIC16C661 PIC16C661@PLCC44  
[(SA244)]  
PIC16C661@TQFP44 [(SA245A)]  
PIC16C662  
PIC16C662@PLCC44 [(SA244)] PIC16C662@TQFP44

[ (SA245A) ]  
PIC16C67 PIC16C67(ISP) [ISP-  
HEADER01]  
PIC16C67@PLCC44 [ (SA244) ]  
PIC16C67@PLCC44(ISP) [ISP-HEADER01]  
PIC16C67@TQFP44 [ (SA245A) ]  
PIC16C67@TQFP44(ISP) [ISP-HEADER01]  
PIC16C70 PIC16C70(ISP) [ISP-  
HEADER01]  
PIC16C70@SOIC18 [ (SA404) ]  
PIC16C70@SOIC18(ISP) [ISP-HEADER01]  
PIC16C71 PIC16C71(ISP) [ISP-  
HEADER01]  
PIC16C71@SOIC18 [ (SA404) ]  
PIC16C71@SOIC18(ISP) [ISP-HEADER01]  
PIC16C710 PIC16C710(ISP) [ISP-  
HEADER01]  
PIC16C710@SOIC18 [ (SA404) ]  
PIC16C710@SOIC18(ISP) [ISP-HEADER01]  
PIC16C710@SSOP20 [ (SA626A) ]  
PIC16C710@SSOP20(ISP) [ISP-HEADER01]  
PIC16C711 PIC16C711(ISP) [ISP-  
HEADER01]  
PIC16C711@SOIC18 [ (SA404) ]  
PIC16C711@SOIC18(ISP) [ISP-HEADER01]  
PIC16C711@SSOP20 [ (SA626A) ]  
PIC16C711@SSOP20(ISP) [ISP-HEADER01]  
PIC16C712 PIC16C712(ISP) [ISP-  
HEADER01]  
PIC16C712@SOIC18 [ (SA404) ]  
PIC16C712@SOIC18(ISP) [ISP-HEADER01]  
PIC16C712@SSOP20 [ (SA626A) ]  
PIC16C712@SSOP20(ISP) [ISP-HEADER01]  
PIC16C715 PIC16C715@SOIC18  
[ (SA404) ]  
PIC16C715@SSOP20 [ (SA626A) ]  
PIC16C716 PIC16C716@SOIC18  
PIC16C716(ISP) [ISP-HEADER01]  
[ (SA404) ]  
PIC16C716@SOIC18(ISP) [ISP-HEADER01]  
PIC16C716@SSOP20 [ (SA626A) ]  
PIC16C716@SSOP20(ISP) [ISP-HEADER01]  
PIC16C717 PIC16C717(ISP) [ISP-

HEADER01 ]  
PIC16C717@SOIC18 [(SA404)]  
PIC16C717@SOIC18(ISP) [ISP-HEADER01]  
PIC16C717@SSOP20 [(SA626A)]  
PIC16C717@SSOP20(ISP) [ISP-HEADER01]  
PIC16C71A PIC16C71A(ISP) [ISP-  
HEADER01]  
PIC16C71A@SOIC18 [(SA404)]  
PIC16C71A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C72 PIC16C72(ISP) [ISP-  
HEADER01]  
PIC16C72@SOIC28 [(SA404)]  
PIC16C72@SOIC28(ISP) [ISP-HEADER01]  
PIC16C72@SSOP28 [(SA626A)]  
PIC16C72@SSOP28(ISP) [ISP-HEADER01]  
PIC16C72A PIC16C72A(ISP) [ISP-  
HEADER01]  
PIC16C72A@SOIC28 [(SA404)]  
PIC16C72A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C72A@SSOP28 [(SA626A)]  
PIC16C72A@SSOP28(ISP) [ISP-HEADER01]  
PIC16C73 PIC16C73(ISP) [ISP-  
HEADER01]  
PIC16C73@SOIC28 [(SA404)]  
PIC16C73@SOIC28(ISP) [ISP-HEADER01]  
PIC16C73A PIC16C73A(ISP) [ISP-  
HEADER01]  
PIC16C73A@SOIC28 [(SA404)]  
PIC16C73A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C73B PIC16C73B(ISP) [ISP-  
HEADER01]  
PIC16C73B@SOIC28 [(SA404)]  
PIC16C73B@SOIC28(ISP) [ISP-HEADER01]  
PIC16C73B@SSOP28 [(SA626A)]  
PIC16C73B@SSOP28(ISP) [ISP-HEADER01]  
PIC16C74 PIC16C74(ISP) [ISP-  
HEADER01]  
PIC16C74@PLCC44 [(SA244)]  
PIC16C74@PLCC44(ISP) [ISP-HEADER01]  
PIC16C74@TQFP44 [(SA245A)]  
PIC16C74@TQFP44(ISP) [ISP-HEADER01]  
PIC16C745 PIC16C745(ISP) [ISP-  
HEADER01]

PIC16C745@SOIC28 [(SA404)]  
PIC16C745@SOIC28(ISP) [ISP-HEADER01]  
PIC16C74A PIC16C74A(ISP) [ISP-  
HEADER01]  
PIC16C74A@PLCC44 [(SA244)]  
PIC16C74A@PLCC44(ISP) [ISP-HEADER01]  
PIC16C74A@TQFP44 [(SA245A)]  
PIC16C74A@TQFP44(ISP) [ISP-HEADER01]  
PIC16C74B PIC16C74B(ISP) [ISP-  
HEADER01]  
PIC16C74B@MQFP44 [(SA675)]  
PIC16C74B@MQFP44(ISP) [ISP-HEADER01]  
PIC16C74B@PLCC44 [(SA244)]  
PIC16C74B@PLCC44(ISP) [ISP-HEADER01]  
PIC16C74B@TQFP44 [(SA245A)]  
PIC16C74B@TQFP44(ISP) [ISP-HEADER01]  
PIC16C76 PIC16C76(ISP) [ISP-  
HEADER01]  
PIC16C76@SOIC28 [(SA404)]  
PIC16C76@SOIC28(ISP) [ISP-HEADER01]  
PIC16C765 PIC16C765(ISP) [ISP-  
HEADER01]  
PIC16C765@PLCC44 [(SA244)]  
PIC16C765@PLCC44(ISP) [ISP-HEADER01]  
PIC16C765@TQFP44 [(SA245A)]  
PIC16C765@TQFP44(ISP) [ISP-HEADER01]  
PIC16C77 PIC16C77(ISP) [ISP-  
HEADER01]  
PIC16C77@PLCC44 [(SA244)]  
PIC16C77@PLCC44(ISP) [ISP-HEADER01]  
PIC16C77@TQFP44 [(SA245A)]  
PIC16C77@TQFP44(ISP) [ISP-HEADER01]  
PIC16C770 PIC16C770(ISP) [ISP-  
HEADER01]  
PIC16C770@SOIC20 [(SA404)]  
PIC16C770@SOIC20(ISP) [ISP-HEADER01]  
PIC16C770@SSOP20 [(SA626A)]  
PIC16C770@SSOP20(ISP) [ISP-HEADER01]  
PIC16C771 PIC16C771(ISP) [ISP-  
HEADER01]  
PIC16C771@SOIC20 [(SA404)]  
PIC16C771@SOIC20(ISP) [ISP-HEADER01]  
PIC16C771@SSOP20 [(SA626A)]

PIC16C771@SSOP20(ISP) [ISP-HEADER01]  
PIC16C773 PIC16C773(ISP) [ISP-  
HEADER01]  
PIC16C773@SOIC28 [(SA404)]  
PIC16C773@SOIC28(ISP) [ISP-HEADER01]  
PIC16C773@SSOP28 [(SA626A)]  
PIC16C773@SSOP28(ISP) [ISP-HEADER01]  
PIC16C774 PIC16C774(ISP) [ISP-  
HEADER01]  
PIC16C774@PLCC44 [(SA244)]  
PIC16C774@PLCC44(ISP) [ISP-HEADER01]  
PIC16C774@TQFP44 [(SA675)]  
PIC16C774@TQFP44(ISP) [ISP-HEADER01]  
PIC16C781 PIC16C781(ISP) [ISP-  
HEADER01]  
PIC16C781@SOIC20 [(SA404)]  
PIC16C781@SOIC20(ISP) [ISP-HEADER01]  
PIC16C781@SSOP20 [(SA626A)]  
PIC16C781@SSOP20(ISP) [ISP-HEADER01]  
PIC16C782 PIC16C782(ISP) [ISP-  
HEADER01]  
PIC16C782@SOIC20 [(SA404)]  
PIC16C782@SOIC20(ISP) [ISP-HEADER01]  
PIC16C782@SSOP20 [(SA626A)]  
PIC16C782@SSOP20(ISP) [ISP-HEADER01]  
PIC16C84 PIC16C84(ISP) [ISP-  
HEADER01]  
PIC16C84@SOIC18 [(SA404)]  
PIC16C84@SOIC18(ISP) [ISP-HEADER01]  
PIC16C923@PLCC68(\*) [(SA648-B6807)]  
PIC16C923@PLCC68(ISP) [ISP-HEADER01]  
PIC16C923@SDIP64(ISP) [ISP-HEADER01]  
PIC16C923@TQFP64(ISP) [ISP-HEADER01]  
PIC16C924@PLCC68(\*) [(SA648-B6807)]  
PIC16C924@PLCC68(ISP) [ISP-HEADER01]  
PIC16C924@SDIP64(ISP) [ISP-HEADER01]  
PIC16C924@TQFP64(ISP) [ISP-HEADER01]  
PIC16C925@PLCC68(\*) [(SA648-B6807)]  
PIC16C925@PLCC68(ISP) [ISP-HEADER01]  
PIC16C925@TQFP64(ISP) [ISP-HEADER01]  
PIC16C926@PLCC68(\*) [(SA648-B6807)]  
PIC16C926@PLCC68(ISP) [ISP-HEADER01]  
PIC16C926@TQFP64(ISP) [ISP-HEADER01]

PIC16CE623 PIC16CE623(ISP) [ISP-  
HEADER01]  
PIC16CE623@SOIC18 [(SA404)]  
PIC16CE623@SOIC18(ISP) [ISP-HEADER01]  
PIC16CE624 PIC16CE624(ISP) [ISP-  
HEADER01]  
PIC16CE624@SOIC18 [(SA404)]  
PIC16CE624@SOIC18(ISP) [ISP-HEADER01]  
PIC16CE625 PIC16CE625(ISP) [ISP-  
HEADER01]  
PIC16CE625@SOIC18 [(SA404)]  
PIC16CE625@SOIC18(ISP) [ISP-HEADER01]  
PIC16CE625@SSOP20 [(SA626A)]  
PIC16CE625@SSOP20(ISP) [ISP-HEADER01]  
PIC16CR83 PIC16CR83(ISP) [ISP-  
HEADER01]  
PIC16CR83@SOIC18 [(SA404)]  
PIC16CR83@SOIC18(ISP) [ISP-HEADER01]  
PIC16CR84 PIC16CR84(ISP) [ISP-  
HEADER01]  
PIC16CR84@SOIC18 [(SA404)]  
PIC16CR84@SOIC18(ISP) [ISP-HEADER01]  
PIC16F505 PIC16F505(ISP) [ISP-  
HEADER01]  
PIC16F505@SOIC14 [(SA602)]  
PIC16F505@SOIC14(ISP) [ISP-HEADER01]  
PIC16F505@TSSOP14 [(SA026)]  
PIC16F505@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F506 PIC16F506(ISP) [ISP-  
HEADER01]  
PIC16F506@SOIC14 [(SA602)]  
PIC16F506@SOIC14(ISP) [ISP-HEADER01]  
PIC16F506@TSSOP14 [(SA026)]  
PIC16F506@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F526 PIC16F526@SOIC14  
[(SA602)]  
PIC16F526@TSSOP14 [(SA026)]  
PIC16F54 PIC16F54@SOIC18  
PIC16F54(ISP) [ISP-HEADER01]  
[(SA404)]  
PIC16F54@SOIC18(ISP) [ISP-HEADER01]  
PIC16F54@SSOP20 [(SA626A)]  
PIC16F54@SSOP20(ISP) [ISP-HEADER01]



PIC16F57 PIC16F57(ISP) [ISP-  
HEADER01]  
PIC16F57@SOIC28 [(SA404)]  
PIC16F57@SOIC28(ISP) [ISP-HEADER01]  
PIC16F57@SSOP28 [(SA626A)]  
PIC16F57@SSOP28(ISP) [ISP-HEADER01]  
PIC16F59 PIC16F59(ISP) [ISP-  
HEADER01]  
PIC16F59@PLCC44 [(SA244)]  
PIC16F59@PLCC44(ISP) [ISP-HEADER01]  
PIC16F59@TQFP44 [(SA245A)]  
PIC16F59@TQFP44(ISP) [ISP-HEADER01]  
PIC16F610 PIC16F610(ISP) [ISP-  
HEADER01]  
PIC16F610@QFN16 [(SA727)]  
PIC16F610@QFN16(ISP) [ISP-HEADER01]  
PIC16F610@SOIC14 [(SA602)]  
PIC16F610@SOIC14(ISP) [ISP-HEADER01]  
PIC16F610@TSSOP14 [(SA026)]  
PIC16F610@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F616 PIC16F616(ISP) [ISP-  
HEADER01]  
PIC16F616@QFN16 [(SA727)]  
PIC16F616@QFN16(ISP) [ISP-HEADER01]  
PIC16F616@SOIC14 [(SA602)]  
PIC16F616@SOIC14(ISP) [ISP-HEADER01]  
PIC16F616@TSSOP14 [(SA026)]  
PIC16F616@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F627 PIC16F627(ISP) [ISP-  
HEADER01]  
PIC16F627@SOIC18 [(SA404)]  
PIC16F627@SOIC18(ISP) [ISP-HEADER01]  
PIC16F627@SSOP20 [(SA626A)]  
PIC16F627@SSOP20(ISP) [ISP-HEADER01]  
PIC16F627A PIC16F627A(ISP) [ISP-  
HEADER01]  
PIC16F627A@SOIC18 [(SA404)]  
PIC16F627A@SOIC18(ISP) [ISP-HEADER01]  
PIC16F627A@SSOP20 [(SA626A)]  
PIC16F627A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F628 PIC16F628(ISP) [ISP-  
HEADER01]  
PIC16F628@SOIC18 [(SA404)]

PIC16F628@SOIC18(ISP) [ISP-HEADER01]  
PIC16F628@SSOP20 [(SA626A)]  
PIC16F628@SSOP20(ISP) [ISP-HEADER01]  
PIC16F628A PIC16F628A(ISP) [ISP-  
HEADER01]  
PIC16F628A@SOIC18 [(SA404)]  
PIC16F628A@SOIC18(ISP) [ISP-HEADER01]  
PIC16F628A@SSOP20 [(SA626A)]  
PIC16F628A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F630 PIC16F630(ISP) [ISP-  
HEADER01]  
PIC16F630@SOIC14 [(SA602)]  
PIC16F630@SOIC14(ISP) [ISP-HEADER01]  
PIC16F630@TSSOP14 [(SA026)]  
PIC16F630@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F631 PIC16F631(ISP) [ISP-  
HEADER01]  
PIC16F631@QFN20 [(SA692)]  
PIC16F631@QFN20(ISP) [ISP-HEADER01]  
PIC16F631@SOIC20 [(SA404)]  
PIC16F631@SOIC20(ISP) [ISP-HEADER01]  
PIC16F631@SSOP20 [(SA626A)]  
PIC16F631@SSOP20(ISP) [ISP-HEADER01]  
PIC16F636 PIC16F636(ISP) [ISP-  
HEADER01]  
PIC16F636@QFN16 [(SA727)]  
PIC16F636@QFN16(ISP) [ISP-HEADER01]  
PIC16F636@SOIC14 [(SA602)]  
PIC16F636@SOIC14(ISP) [ISP-HEADER01]  
PIC16F636@TSSOP14 [(SA026)]  
PIC16F636@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F639 PIC16F639(ISP) [ISP-  
HEADER01]  
PIC16F639@QFN20 [(SA692)]  
PIC16F639@QFN20(ISP) [ISP-HEADER01]  
PIC16F639@SOIC20 [(SA404)]  
PIC16F639@SOIC20(ISP) [ISP-HEADER01]  
PIC16F639@SSOP20 [(SA626A)]  
PIC16F639@SSOP20(ISP) [ISP-HEADER01]  
PIC16F648A PIC16F648A(ISP) [ISP-  
HEADER01]  
PIC16F648A@SOIC18 [(SA404)]  
PIC16F648A@SOIC18(ISP) [ISP-HEADER01]

PIC16F648A@SSOP20 [(SA626A)]  
PIC16F648A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F676 PIC16F676(ISP) [ISP-  
HEADER01]  
PIC16F676@SOIC14 [(SA602)]  
PIC16F676@SOIC14(ISP) [ISP-HEADER01]  
PIC16F676@TSSOP14 [(SA026)]  
PIC16F676@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F677 PIC16F677(ISP) [ISP-  
HEADER01]  
PIC16F677@QFN20 [(SA692)]  
PIC16F677@QFN20(ISP) [ISP-HEADER01]  
PIC16F677@SOIC20 [(SA404)]  
PIC16F677@SOIC20(ISP) [ISP-HEADER01]  
PIC16F677@SSOP20 [(SA626A)]  
PIC16F677@SSOP20(ISP) [ISP-HEADER01]  
PIC16F684 PIC16F684(ISP) [ISP-  
HEADER01]  
PIC16F684@QFN16 [(SA727)]  
PIC16F684@QFN16(ISP) [ISP-HEADER01]  
PIC16F684@SOIC14 [(SA602)]  
PIC16F684@SOIC14(ISP) [ISP-HEADER01]  
PIC16F684@TSSOP14 [(SA026)]  
PIC16F684@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F685 PIC16F685(ISP) [ISP-  
HEADER01]  
PIC16F685@QFN20 [(SA692)]  
PIC16F685@QFN20(ISP) [ISP-HEADER01]  
PIC16F685@SOIC20 [(SA404)]  
PIC16F685@SOIC20(ISP) [ISP-HEADER01]  
PIC16F685@SSOP20 [(SA626A)]  
PIC16F685@SSOP20(ISP) [ISP-HEADER01]  
PIC16F687 PIC16F687(ISP) [ISP-  
HEADER01]  
PIC16F687@QFN20 [(SA692)]  
PIC16F687@QFN20(ISP) [ISP-HEADER01]  
PIC16F687@SOIC20 [(SA404)]  
PIC16F687@SOIC20(ISP) [ISP-HEADER01]  
PIC16F687@SSOP20 [(SA626A)]  
PIC16F687@SSOP20(ISP) [ISP-HEADER01]  
PIC16F688 PIC16F688(ISP) [ISP-  
HEADER01]  
PIC16F688@QFN16 [(SA727)]

PIC16F688@QFN16(ISP) [ISP-HEADER01]  
PIC16F688@SOIC14 [(SA602)]  
PIC16F688@SOIC14(ISP) [ISP-HEADER01]  
PIC16F688@TSSOP14 [(SA026)]  
PIC16F688@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F689 PIC16F689(ISP) [ISP-  
HEADER01]  
PIC16F689@QFN20 [(SA692)]  
PIC16F689@QFN20(ISP) [ISP-HEADER01]  
PIC16F689@SOIC20 [(SA404)]  
PIC16F689@SOIC20(ISP) [ISP-HEADER01]  
PIC16F689@SSOP20 [(SA626A)]  
PIC16F689@SSOP20(ISP) [ISP-HEADER01]  
PIC16F690 PIC16F690(ISP) [ISP-  
HEADER01]  
PIC16F690@QFN20 [(SA692)]  
PIC16F690@QFN20(ISP) [ISP-HEADER01]  
PIC16F690@SOIC20 [(SA404)]  
PIC16F690@SOIC20(ISP) [ISP-HEADER01]  
PIC16F690@SSOP20 [(SA626A)]  
PIC16F690@SSOP20(ISP) [ISP-HEADER01]  
PIC16F716 PIC16F716(ISP) [ISP-  
HEADER01]  
PIC16F716@SOIC18 [(SA404)]  
PIC16F716@SOIC18(ISP) [ISP-HEADER01]  
PIC16F716@SSOP20 [(SA626A)]  
PIC16F716@SSOP20(ISP) [ISP-HEADER01]  
PIC16F72 PIC16F72(ISP) [ISP-  
HEADER01]  
PIC16F72@QFN28 [(SA685-B006)]  
PIC16F72@QFN28(ISP) [ISP-HEADER01]  
PIC16F72@SOIC28 [(SA404)]  
PIC16F72@SOIC28(ISP) [ISP-HEADER01]  
PIC16F72@SSOP28 [(SA626A)]  
PIC16F72@SSOP28(ISP) [ISP-HEADER01]  
PIC16F722 PIC16F722@QFN28 [(SA685-  
B006)]  
PIC16F722@SOIC28 [(SA404)] PIC16F722@SSOP28  
[(SA626A)]  
PIC16F723 PIC16F723@QFN28 [(SA685-  
B006)]  
PIC16F723@SOIC28 [(SA404)] PIC16F723@SSOP28  
[(SA626A)]

PIC16F724 [(SA737)]	PIC16F724@QFN44
PIC16F724@TQFP44 [(SA245A)]	
PIC16F726	
PIC16F726@QFN28 [(SA685-B006)] [(SA404)]	PIC16F726@SOIC28
PIC16F726@SSOP28 [(SA626A)]	
PIC16F727	
PIC16F727@QFN44 [(SA737)] [(SA245A)]	PIC16F727@TQFP44
PIC16F73 HEADER01]	PIC16F73(ISP) [ISP-
PIC16F73@SOIC28 [(SA404)]	
PIC16F73@SOIC28(ISP) [ISP-HEADER01]	
PIC16F73@SSOP28 [(SA626A)]	
PIC16F73@SSOP28(ISP) [ISP-HEADER01]	
PIC16F737 HEADER01]	PIC16F737(ISP) [ISP-
PIC16F737@SOIC28 [(SA404)]	
PIC16F737@SOIC28(ISP) [ISP-HEADER01]	
PIC16F737@SSOP28 [(SA626A)]	
PIC16F737@SSOP28(ISP) [ISP-HEADER01]	
PIC16F74 HEADER01]	PIC16F74(ISP) [ISP-
PIC16F74@PLCC44 [(SA244)]	
PIC16F74@PLCC44(ISP) [ISP-HEADER01]	
PIC16F74@TQFP44 [(SA245A)]	
PIC16F74@TQFP44(ISP) [ISP-HEADER01]	
PIC16F747 HEADER01]	PIC16F747(ISP) [ISP-
PIC16F747@TQFP44 [(SA245A)]	
PIC16F747@TQFP44(ISP) [ISP-HEADER01]	
PIC16F76 HEADER01]	PIC16F76(ISP) [ISP-
PIC16F76@SOIC28 [(SA404)]	
PIC16F76@SOIC28(ISP) [ISP-HEADER01]	
PIC16F76@SSOP28 [(SA626A)]	
PIC16F76@SSOP28(ISP) [ISP-HEADER01]	
PIC16F767 HEADER01]	PIC16F767(ISP) [ISP-
PIC16F767@SOIC28 [(SA404)]	
PIC16F767@SOIC28(ISP) [ISP-HEADER01]	
PIC16F767@SSOP28 [(SA626A)]	

PIC16F767@SSOP28(ISP) [ISP-HEADER01]  
PIC16F77 PIC16F77(ISP) [ISP-  
HEADER01]  
PIC16F77@PLCC44 [(SA244)]  
PIC16F77@PLCC44(ISP) [ISP-HEADER01]  
PIC16F77@TQFP44 [(SA245A)]  
PIC16F77@TQFP44(ISP) [ISP-HEADER01]  
PIC16F777 PIC16F777(ISP) [ISP-  
HEADER01]  
PIC16F777@TQFP44 [(SA245A)]  
PIC16F777@TQFP44(ISP) [ISP-HEADER01]  
PIC16F785 PIC16F785(ISP) [ISP-  
HEADER01]  
PIC16F785@QFN20 [(SA692)]  
PIC16F785@QFN20(ISP) [ISP-HEADER01]  
PIC16F785@SOIC20 [(SA404)]  
PIC16F785@SOIC20(ISP) [ISP-HEADER01]  
PIC16F785@SSOP20 [(SA626A)]  
PIC16F785@SSOP20(ISP) [ISP-HEADER01]  
PIC16F818 PIC16F818(ISP) [ISP-  
HEADER01]  
PIC16F818(LV)  
PIC16F818(LV)@QFN28 [(SA685-B006)]  
PIC16F818(LV)@SOIC18 [(SA404)] PIC16F818(LV)@SSOP20  
[(SA626A)]  
PIC16F818@QFN28 [(SA685-B006)]  
PIC16F818@QFN28(ISP) [ISP-HEADER01]  
PIC16F818@SOIC18 [(SA404)]  
PIC16F818@SOIC18(ISP) [ISP-HEADER01]  
PIC16F818@SSOP20 [(SA626A)]  
PIC16F818@SSOP20(ISP) [ISP-HEADER01]  
PIC16F819 PIC16F819(ISP) [ISP-  
HEADER01]  
PIC16F819(LV)  
PIC16F819(LV)@QFN28 [(SA685-B006)]  
PIC16F819(LV)@SOIC18 [(SA404)] PIC16F819(LV)@SSOP20  
[(SA626A)]  
PIC16F819@QFN28 [(SA685-B006)]  
PIC16F819@QFN28(ISP) [ISP-HEADER01]  
PIC16F819@SOIC18 [(SA404)]  
PIC16F819@SOIC18(ISP) [ISP-HEADER01]  
PIC16F819@SSOP20 [(SA626A)]  
PIC16F819@SSOP20(ISP) [ISP-HEADER01]

PIC16F83 PIC16F83(ISP) [ISP-  
HEADER01]  
PIC16F83@SOIC18 [(SA404)]  
PIC16F83@SOIC18(ISP) [ISP-HEADER01]  
PIC16F84 PIC16F84(ISP) [ISP-  
HEADER01]  
PIC16F84@SOIC18 [(SA404)]  
PIC16F84@SOIC18(ISP) [ISP-HEADER01]  
PIC16F84A PIC16F84A(ISP) [ISP-  
HEADER01]  
PIC16F84A@SOIC18 [(SA404)]  
PIC16F84A@SOIC18(ISP) [ISP-HEADER01]  
PIC16F84A@SSOP20 [(SA626A)]  
PIC16F84A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F87 PIC16F87(ISP) [ISP-  
HEADER01]  
PIC16F87@QFN28 [(SA685-B006)]  
PIC16F87@QFN28(ISP) [ISP-HEADER01]  
PIC16F87@SOIC18 [(SA404)]  
PIC16F87@SOIC18(ISP) [ISP-HEADER01]  
PIC16F87@SSOP20 [(SA626A)]  
PIC16F87@SSOP20(ISP) [ISP-HEADER01]  
PIC16F870 PIC16F870(ISP) [ISP-  
HEADER01]  
PIC16F870@SOIC28 [(SA404)]  
PIC16F870@SOIC28(ISP) [ISP-HEADER01]  
PIC16F870@SSOP28 [(SA626A)]  
PIC16F870@SSOP28(ISP) [ISP-HEADER01]  
PIC16F871 PIC16F871(ISP) [ISP-  
HEADER01]  
PIC16F871@MQFP44 [(SA675)]  
PIC16F871@MQFP44(ISP) [ISP-HEADER01]  
PIC16F871@PLCC44 [(SA244)]  
PIC16F871@PLCC44(ISP) [ISP-HEADER01]  
PIC16F871@TQFP44 [(SA245A)]  
PIC16F871@TQFP44(ISP) [ISP-HEADER01]  
PIC16F872 PIC16F872(ISP) [ISP-  
HEADER01]  
PIC16F872@SOIC28 [(SA404)]  
PIC16F872@SOIC28(ISP) [ISP-HEADER01]  
PIC16F872@SSOP28 [(SA626A)]  
PIC16F872@SSOP28(ISP) [ISP-HEADER01]  
PIC16F873 PIC16F873(ISP) [ISP-

HEADER01 ]  
PIC16F873@SOIC28 [(SA404)]  
PIC16F873@SOIC28(ISP) [ISP-HEADER01]  
PIC16F873A  
PIC16F873A(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F873A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F873A@QFN28 [(SA697-B006)]  
PIC16F873A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F873A@SOIC28 [(SA404)]  
PIC16F873A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F873A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F873A@SSOP28 [(SA626A)]  
PIC16F873A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F873A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F874 PIC16F874(ISP) [ISP-  
HEADER01 ]  
PIC16F874@MQFP44 [(SA675)]  
PIC16F874@MQFP44(ISP) [ISP-HEADER01]  
PIC16F874@PLCC44 [(SA244)]  
PIC16F874@PLCC44(ISP) [ISP-HEADER01]  
PIC16F874@TQFP44 [(SA245A)]  
PIC16F874@TQFP44(ISP) [ISP-HEADER01]  
PIC16F874A  
PIC16F874A(ISP)(High-V) [ISP-HEADER01]  
PIC16F874A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F874A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F874A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F874A@PLCC44 [(SA244)]  
PIC16F874A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16F874A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F874A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F874A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F874A@TQFP44 [(SA245A)]  
PIC16F874A@TQFP44(ISP)(High-V) [ISP-HEADER01]



PIC16F874A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F874A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F874A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876 PIC16F876(ISP) [ISP-  
HEADER01]  
PIC16F876@SOIC28 [(SA404)]  
PIC16F876@SOIC28(ISP) [ISP-HEADER01]  
PIC16F876A  
PIC16F876A(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876A@QFN28 [(SA697-B006)]  
PIC16F876A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876A@SOIC28 [(SA404)]  
PIC16F876A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876A@SSOP28 [(SA626A)]  
PIC16F876A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877 PIC16F877(ISP) [ISP-  
HEADER01]  
PIC16F877@MQFP44 [(SA675)]  
PIC16F877@MQFP44(ISP) [ISP-HEADER01]  
PIC16F877@PLCC44 [(SA244)]  
PIC16F877@PLCC44(ISP) [ISP-HEADER01]  
PIC16F877@TQFP44 [(SA245A)]  
PIC16F877@TQFP44(ISP) [ISP-HEADER01]  
PIC16F877A  
PIC16F877A(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F877A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F877A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877A@PLCC44 [(SA244)]  
PIC16F877A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]

PIC16F877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877A@TQFP44 [(SA245A)]  
PIC16F877A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F88 PIC16F88(ISP) [ISP-  
HEADER01]  
PIC16F88@QFN28 [(SA685-B006)]  
PIC16F88@QFN28(ISP) [ISP-HEADER01]  
PIC16F88@SOIC18 [(SA404)]  
PIC16F88@SOIC18(ISP) [ISP-HEADER01]  
PIC16F88@SSOP20 [(SA626A)]  
PIC16F88@SSOP20(ISP) [ISP-HEADER01]  
PIC16F882  
PIC16F882(ISP)(High-V) [ISP-HEADER01]  
PIC16F882(ISP)(Low-V) [ISP-HEADER01]  
PIC16F882@QFN28 [(SA685-B005)]  
PIC16F882@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F882@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F882@SOIC28 [(SA404)]  
PIC16F882@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F882@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F882@SSOP28 [(SA626A)]  
PIC16F882@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F882@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883  
PIC16F883(ISP)(High-V) [ISP-HEADER01]  
PIC16F883(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883@QFN28 [(SA685-B005)]  
PIC16F883@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F883@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883@SOIC28 [(SA404)]  
PIC16F883@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F883@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883@SSOP28 [(SA626A)]  
PIC16F883@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F883@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884  
PIC16F884(ISP)(High-V) [ISP-HEADER01]  
PIC16F884(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884@QFN44 [(SA712)]

PIC16F884@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC16F884@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884@QFN44(ML) [(SA737)]  
PIC16F884@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]  
PIC16F884@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884@TQFP44 [(SA245A)]  
PIC16F884@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F884@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886  
PIC16F886(ISP)(High-V) [ISP-HEADER01]  
PIC16F886(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886@QFN28 [(SA685-B005)]  
PIC16F886@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F886@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886@SOIC28 [(SA404)]  
PIC16F886@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F886@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886@SSOP28 [(SA626A)]  
PIC16F886@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F886@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887  
PIC16F887(ISP)(High-V) [ISP-HEADER01]  
PIC16F887(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887@QFN44 [(SA712)]  
PIC16F887@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC16F887@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887@QFN44(ML) [(SA737)]  
PIC16F887@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]  
PIC16F887@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887@TQFP44 [(SA245A)]  
PIC16F887@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F887@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F913 PIC16F913(ISP) [ISP-  
HEADER01]  
PIC16F913@QFN28 [(SA697-B006)]  
PIC16F913@QFN28(ISP) [ISP-HEADER01]  
PIC16F913@SOIC28 [(SA404)]  
PIC16F913@SOIC28(ISP) [ISP-HEADER01]  
PIC16F913@SSOP28 [(SA626A)]  
PIC16F913@SSOP28(ISP) [ISP-HEADER01]  
PIC16F914 PIC16F914(ISP) [ISP-  
HEADER01]  
PIC16F914@QFN44 [(SA712)]

PIC16F914@QFN44(ISP) [ISP-HEADER01]  
PIC16F914@QFN44(ML) [(SA737)]  
PIC16F914@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16F914@TQFP44 [(SA245A)]  
PIC16F914@TQFP44(ISP) [ISP-HEADER01]  
PIC16F916 PIC16F916(ISP) [ISP-  
HEADER01]  
PIC16F916@QFN28 [(SA697-B006)]  
PIC16F916@QFN28(ISP) [ISP-HEADER01]  
PIC16F916@SOIC28 [(SA404)]  
PIC16F916@SOIC28(ISP) [ISP-HEADER01]  
PIC16F916@SSOP28 [(SA626A)]  
PIC16F916@SSOP28(ISP) [ISP-HEADER01]  
PIC16F917 PIC16F917(ISP) [ISP-  
HEADER01]  
PIC16F917@QFN44 [(SA712)]  
PIC16F917@QFN44(ISP) [ISP-HEADER01]  
PIC16F917@QFN44(ML) [(SA737)]  
PIC16F917@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16F917@TQFP44 [(SA245A)]  
PIC16F917@TQFP44(ISP) [ISP-HEADER01]  
PIC16F946@TQFP64(ISP) [ISP-HEADER01]  
PIC16HV540 PIC16HV540@SOIC18  
[(SA404)]  
PIC16HV540@SSOP20 [(SA626A)]  
PIC16HV610  
PIC16HV610(ISP) [ISP-HEADER01] PIC16HV610@QFN16  
[(SA727)]  
PIC16HV610@QFN16(ISP) [ISP-HEADER01]  
PIC16HV610@SOIC14 [(SA602)]  
PIC16HV610@SOIC14(ISP) [ISP-HEADER01]  
PIC16HV610@TSSOP14 [(SA026)]  
PIC16HV610@TSSOP14(ISP) [ISP-HEADER01]  
PIC16HV616 PIC16HV616(ISP) [ISP-  
HEADER01]  
PIC16HV616@QFN16 [(SA727)]  
PIC16HV616@QFN16(ISP) [ISP-HEADER01]  
PIC16HV616@SOIC14 [(SA602)]  
PIC16HV616@SOIC14(ISP) [ISP-HEADER01]  
PIC16HV616@TSSOP14 [(SA026)]  
PIC16HV616@TSSOP14(ISP) [ISP-HEADER01]  
PIC16HV785 PIC16HV785(ISP) [ISP-  
HEADER01]

PIC16HV785@QFN20 [(SA692)]  
PIC16HV785@QFN20(ISP) [ISP-HEADER01]  
PIC16HV785@SOIC20 [(SA404)]  
PIC16HV785@SOIC20(ISP) [ISP-HEADER01]  
PIC16HV785@SSOP20 [(SA626A)]  
PIC16HV785@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC505 PIC16LC505@SOIC14  
[(SA602)]  
PIC16LC54A PIC16LC54A@SOIC18  
[(SA404)]  
PIC16LC54A@SSOP20 [(SA626A)]  
PIC16LC54C  
PIC16LC54C@SOIC18 [(SA404)] PIC16LC54C@SSOP20  
[(SA626A)]  
PIC16LC554 PIC16LC554(ISP) [ISP-  
HEADER01]  
PIC16LC554@SOIC18 [(SA404)]  
PIC16LC554@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC558 PIC16LC558(ISP) [ISP-  
HEADER01]  
PIC16LC558@SOIC18 [(SA404)]  
PIC16LC558@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC56A PIC16LC56A@SOIC18  
[(SA404)]  
PIC16LC56A@SSOP20 [(SA626A)]  
PIC16LC58A  
PIC16LC58A@SOIC18 [(SA404)] PIC16LC58A@SSOP20  
[(SA626A)]  
PIC16LC58B PIC16LC58B@SOIC18  
[(SA404)]  
PIC16LC58B@SSOP20 [(SA626A)]  
PIC16LC620  
PIC16LC620(ISP) [ISP-HEADER01] PIC16LC620@SOIC18  
[(SA404)]  
PIC16LC620@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC620A PIC16LC620A(ISP) [ISP-  
HEADER01]  
PIC16LC620A@SOIC18 [(SA404)]  
PIC16LC620A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC620A@SSOP20 [(SA626A)]  
PIC16LC620A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC621A PIC16LC621A(ISP) [ISP-  
HEADER01]

PIC16LC621A@SOIC18 [(SA404)]  
PIC16LC621A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC621A@SSOP20 [(SA626A)]  
PIC16LC621A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC622 PIC16LC622(ISP) [ISP-  
HEADER01]  
PIC16LC622@SOIC18 [(SA404)]  
PIC16LC622@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC62A PIC16LC62A(ISP) [ISP-  
HEADER01]  
PIC16LC62A@SOIC28 [(SA404)]  
PIC16LC62A@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC62A@SSOP28 [(SA626A)]  
PIC16LC62A@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC62B PIC16LC62B(ISP) [ISP-  
HEADER01]  
PIC16LC62B@SOIC28 [(SA404)]  
PIC16LC62B@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC62B@SSOP28 [(SA626A)]  
PIC16LC62B@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC63 PIC16LC63(ISP) [ISP-  
HEADER01]  
PIC16LC63@SOIC28 [(SA404)]  
PIC16LC63@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC63A PIC16LC63A(ISP) [ISP-  
HEADER01]  
PIC16LC63A@SOIC28 [(SA404)]  
PIC16LC63A@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC63A@SSOP28 [(SA626A)]  
PIC16LC63A@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC64A PIC16LC64A(ISP) [ISP-  
HEADER01]  
PIC16LC64A@PLCC44 [(SA244)]  
PIC16LC64A@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC64A@TQFP44 [(SA245A)]  
PIC16LC64A@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC65A PIC16LC65A(ISP) [ISP-  
HEADER01]  
PIC16LC65A@PLCC44 [(SA244)]  
PIC16LC65A@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC65A@TQFP44 [(SA245A)]  
PIC16LC65A@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC65B PIC16LC65B(ISP) [ISP-

HEADER01 ]  
PIC16LC65B@PLCC44 [ (SA244) ]  
PIC16LC65B@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16LC65B@TQFP44 [ (SA245A) ]  
PIC16LC65B@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16LC66 PIC16LC66(ISP) [ ISP-  
HEADER01 ]  
PIC16LC66@SOIC28 [ (SA404) ]  
PIC16LC66@SOIC28(ISP) [ ISP-HEADER01 ]  
PIC16LC67 PIC16LC67(ISP) [ ISP-  
HEADER01 ]  
PIC16LC67@PLCC44 [ (SA244) ]  
PIC16LC67@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16LC67@TQFP44 [ (SA245A) ]  
PIC16LC67@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16LC71 PIC16LC71(ISP) [ ISP-  
HEADER01 ]  
PIC16LC71@SOIC18 [ (SA404) ]  
PIC16LC71@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LC710 PIC16LC710(ISP) [ ISP-  
HEADER01 ]  
PIC16LC710@SOIC18 [ (SA404) ]  
PIC16LC710@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LC710@SSOP20 [ (SA626A) ]  
PIC16LC710@SSOP20(ISP) [ ISP-HEADER01 ]  
PIC16LC711 PIC16LC711(ISP) [ ISP-  
HEADER01 ]  
PIC16LC711@SOIC18 [ (SA404) ]  
PIC16LC711@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LC711@SSOP20 [ (SA626A) ]  
PIC16LC711@SSOP20(ISP) [ ISP-HEADER01 ]  
PIC16LC712 PIC16LC712(ISP) [ ISP-  
HEADER01 ]  
PIC16LC712@SOIC18 [ (SA404) ]  
PIC16LC712@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LC712@SSOP20 [ (SA626A) ]  
PIC16LC712@SSOP20(ISP) [ ISP-HEADER01 ]  
PIC16LC715 PIC16LC715@SOIC18  
[ (SA404) ]  
PIC16LC716 PIC16LC716(ISP) [ ISP-  
HEADER01 ]  
PIC16LC716@SOIC18 [ (SA404) ]  
PIC16LC716@SOIC18(ISP) [ ISP-HEADER01 ]

PIC16LC716@SSOP20 [(SA626A)]  
PIC16LC716@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC717 PIC16LC717(ISP) [ISP-  
HEADER01]  
PIC16LC717@SOIC18 [(SA404)]  
PIC16LC717@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC717@SSOP20 [(SA626A)]  
PIC16LC717@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC72 PIC16LC72(ISP) [ISP-  
HEADER01]  
PIC16LC72@SOIC28 [(SA404)]  
PIC16LC72@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC72@SSOP28 [(SA626A)]  
PIC16LC72@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC72A PIC16LC72A(ISP) [ISP-  
HEADER01]  
PIC16LC72A@SOIC28 [(SA404)]  
PIC16LC72A@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC72A@SSOP28 [(SA626A)]  
PIC16LC72A@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC73A PIC16LC73A(ISP) [ISP-  
HEADER01]  
PIC16LC73A@SOIC28 [(SA404)]  
PIC16LC73A@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC73B PIC16LC73B(ISP) [ISP-  
HEADER01]  
PIC16LC73B@SOIC28 [(SA404)]  
PIC16LC73B@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC73B@SSOP28 [(SA626A)]  
PIC16LC73B@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC74 PIC16LC74(ISP) [ISP-  
HEADER01]  
PIC16LC74@PLCC44 [(SA244)]  
PIC16LC74@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC74@TQFP44 [(SA245A)]  
PIC16LC74@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC74A PIC16LC74A(ISP) [ISP-  
HEADER01]  
PIC16LC74A@PLCC44 [(SA244)]  
PIC16LC74A@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC74A@TQFP44 [(SA245A)]  
PIC16LC74A@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC74B PIC16LC74B(ISP) [ISP-



HEADER01 ]  
PIC16LC74B@MQFP44 [ (SA675) ]  
PIC16LC74B@MQFP44(ISP) [ ISP-HEADER01 ]  
PIC16LC74B@PLCC44 [ (SA244) ]  
PIC16LC74B@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16LC74B@TQFP44 [ (SA245A) ]  
PIC16LC74B@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16LC76 PIC16LC76(ISP) [ ISP-  
HEADER01 ]  
PIC16LC76@SOIC28 [ (SA404) ]  
PIC16LC76@SOIC28(ISP) [ ISP-HEADER01 ]  
PIC16LC77 PIC16LC77(ISP) [ ISP-  
HEADER01 ]  
PIC16LC77@PLCC44 [ (SA244) ]  
PIC16LC77@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16LC773 PIC16LC773(ISP) [ ISP-  
HEADER01 ]  
PIC16LC773@SOIC28 [ (SA404) ]  
PIC16LC773@SOIC28(ISP) [ ISP-HEADER01 ]  
PIC16LC773@SSOP28 [ (SA626A) ]  
PIC16LC773@SSOP28(ISP) [ ISP-HEADER01 ]  
PIC16LC774 PIC16LC774(ISP) [ ISP-  
HEADER01 ]  
PIC16LC774@PLCC44 [ (SA244) ]  
PIC16LC774@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16LC774@TQFP44 [ (SA675) ]  
PIC16LC774@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16LC84 PIC16LC84(ISP) [ ISP-  
HEADER01 ]  
PIC16LC84@SOIC18 [ (SA404) ]  
PIC16LC84@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LC923@PLCC68(\*) [ (SA648-B6807) ]  
PIC16LC923@PLCC68(ISP) [ ISP-HEADER01 ]  
PIC16LC923@SDIP64(ISP) [ ISP-HEADER01 ]  
PIC16LC923@TQFP64(ISP) [ ISP-HEADER01 ]  
PIC16LC924@PLCC68(\*) [ (SA648-B6807) ]  
PIC16LC924@PLCC68(ISP) [ ISP-HEADER01 ]  
PIC16LC924@SDIP64(ISP) [ ISP-HEADER01 ]  
PIC16LC924@TQFP64(ISP) [ ISP-HEADER01 ]  
PIC16LC925@PLCC68(\*) [ (SA648-B6807) ]  
PIC16LC925@PLCC68(ISP) [ ISP-HEADER01 ]  
PIC16LC925@TQFP64(ISP) [ ISP-HEADER01 ]  
PIC16LC926@PLCC68(\*) [ (SA648-B6807) ]

PIC16LC926@PLCC68(ISP) [ISP-HEADER01]  
PIC16LC926@TQFP64(ISP) [ISP-HEADER01]  
PIC16LCE623@SOIC18 [(SA404)]  
PIC16LCE623@SOIC18(ISP) [ISP-HEADER01]  
PIC16LCE623@SSOP20 [(SA626A)]  
PIC16LCE623@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF505 PIC16LF505(ISP) [ISP-  
HEADER01]  
PIC16LF505@SOIC14 [(SA602)]  
PIC16LF505@SOIC14(ISP) [ISP-HEADER01]  
PIC16LF505@TSSOP14 [(SA026)]  
PIC16LF505@TSSOP14(ISP) [ISP-HEADER01]  
PIC16LF506 PIC16LF506(ISP) [ISP-  
HEADER01]  
PIC16LF506@SOIC14 [(SA602)]  
PIC16LF506@SOIC14(ISP) [ISP-HEADER01]  
PIC16LF506@TSSOP14 [(SA026)]  
PIC16LF506@TSSOP14(ISP) [ISP-HEADER01]  
PIC16LF526 PIC16LF526@SOIC14  
[(SA602)]  
PIC16LF526@TSSOP14 [(SA026)]  
PIC16LF54  
PIC16LF54(ISP) [ISP-HEADER01] PIC16LF54@SOIC18  
[(SA404)]  
PIC16LF54@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF54@SSOP20 [(SA626A)]  
PIC16LF54@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF57 PIC16LF57(ISP) [ISP-  
HEADER01]  
PIC16LF57@SOIC28 [(SA404)]  
PIC16LF57@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF57@SSOP28 [(SA626A)]  
PIC16LF57@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF59 PIC16LF59(ISP) [ISP-  
HEADER01]  
PIC16LF59@PLCC44 [(SA244)]  
PIC16LF59@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF59@TQFP44 [(SA245A)]  
PIC16LF59@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF627 PIC16LF627(ISP) [ISP-  
HEADER01]  
PIC16LF627@SOIC18 [(SA404)]  
PIC16LF627@SOIC18(ISP) [ISP-HEADER01]

PIC16LF627@SSOP20 [(SA626A)]  
PIC16LF627@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF627A PIC16LF627A(ISP) [ISP-  
HEADER01]  
PIC16LF627A@SOIC18 [(SA404)]  
PIC16LF627A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF627A@SSOP20 [(SA626A)]  
PIC16LF627A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF628 PIC16LF628(ISP) [ISP-  
HEADER01]  
PIC16LF628@SOIC18 [(SA404)]  
PIC16LF628@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF628@SSOP20 [(SA626A)]  
PIC16LF628@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF628A PIC16LF628A(ISP) [ISP-  
HEADER01]  
PIC16LF628A@SOIC18 [(SA404)]  
PIC16LF628A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF628A@SSOP20 [(SA626A)]  
PIC16LF628A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF631 PIC16LF631(ISP) [ISP-  
HEADER01]  
PIC16LF631@QFN20 [(SA692)]  
PIC16LF631@QFN20(ISP) [ISP-HEADER01]  
PIC16LF631@SOIC20 [(SA404)]  
PIC16LF631@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF631@SSOP20 [(SA626A)]  
PIC16LF631@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF639 PIC16LF639(ISP) [ISP-  
HEADER01]  
PIC16LF639@QFN20 [(SA692)]  
PIC16LF639@QFN20(ISP) [ISP-HEADER01]  
PIC16LF639@SOIC20 [(SA404)]  
PIC16LF639@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF639@SSOP20 [(SA626A)]  
PIC16LF639@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF648A PIC16LF648A(ISP) [ISP-  
HEADER01]  
PIC16LF648A@SOIC18 [(SA404)]  
PIC16LF648A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF648A@SSOP20 [(SA626A)]  
PIC16LF648A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF677 PIC16LF677(ISP) [ISP-

HEADER01 ]  
PIC16LF677@QFN20 [(SA692)]  
PIC16LF677@QFN20(ISP) [ISP-HEADER01]  
PIC16LF677@SOIC20 [(SA404)]  
PIC16LF677@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF677@SSOP20 [(SA626A)]  
PIC16LF677@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF685 PIC16LF685(ISP) [ISP-  
HEADER01]  
PIC16LF685@QFN20 [(SA692)]  
PIC16LF685@QFN20(ISP) [ISP-HEADER01]  
PIC16LF685@SOIC20 [(SA404)]  
PIC16LF685@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF685@SSOP20 [(SA626A)]  
PIC16LF685@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF687 PIC16LF687(ISP) [ISP-  
HEADER01]  
PIC16LF687@QFN20 [(SA692)]  
PIC16LF687@QFN20(ISP) [ISP-HEADER01]  
PIC16LF687@SOIC20 [(SA404)]  
PIC16LF687@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF687@SSOP20 [(SA626A)]  
PIC16LF687@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF689 PIC16LF689(ISP) [ISP-  
HEADER01]  
PIC16LF689@QFN20 [(SA692)]  
PIC16LF689@QFN20(ISP) [ISP-HEADER01]  
PIC16LF689@SOIC20 [(SA404)]  
PIC16LF689@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF689@SSOP20 [(SA626A)]  
PIC16LF689@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF690 PIC16LF690(ISP) [ISP-  
HEADER01]  
PIC16LF690@QFN20 [(SA692)]  
PIC16LF690@QFN20(ISP) [ISP-HEADER01]  
PIC16LF690@SOIC20 [(SA404)]  
PIC16LF690@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF690@SSOP20 [(SA626A)]  
PIC16LF690@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF716 PIC16LF716(ISP) [ISP-  
HEADER01]  
PIC16LF716@SOIC18 [(SA404)]  
PIC16LF716@SOIC18(ISP) [ISP-HEADER01]

PIC16LF716@SSOP20 [(SA626A)]  
PIC16LF716@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF72 PIC16LF72(ISP) [ISP-  
HEADER01]  
PIC16LF72@QFN28 [(SA685-B006)]  
PIC16LF72@QFN28(ISP) [ISP-HEADER01]  
PIC16LF72@SOIC28 [(SA404)]  
PIC16LF72@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF72@SSOP28 [(SA626A)]  
PIC16LF72@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF722 PIC16LF722@QFN28 [(SA685-  
B006)]  
PIC16LF722@SOIC28 [(SA404)] PIC16LF722@SSOP28  
[(SA626A)]  
PIC16LF723 PIC16LF723@QFN28 [(SA685-  
B006)]  
PIC16LF723@SOIC28 [(SA404)] PIC16LF723@SSOP28  
[(SA626A)]  
PIC16LF724 PIC16LF724@QFN44  
[(SA737)]  
PIC16LF724@TQFP44 [(SA245A)]  
PIC16LF726 PIC16LF726@SOIC28  
PIC16LF726@QFN28 [(SA685-B006)] [(SA404)]  
PIC16LF726@SSOP28 [(SA626A)]  
PIC16LF727 PIC16LF727@TQFP44  
PIC16LF727@QFN44 [(SA737)] [(SA245A)]  
PIC16LF73 PIC16LF73(ISP) [ISP-  
HEADER01]  
PIC16LF73@SOIC28 [(SA404)]  
PIC16LF73@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF73@SSOP28 [(SA626A)]  
PIC16LF73@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF737 PIC16LF737(ISP) [ISP-  
HEADER01]  
PIC16LF737@SOIC28 [(SA404)]  
PIC16LF737@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF737@SSOP28 [(SA626A)]  
PIC16LF737@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF74 PIC16LF74(ISP) [ISP-  
HEADER01]  
PIC16LF74@PLCC44 [(SA244)]

PIC16LF74@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF74@TQFP44 [(SA245A)]  
PIC16LF74@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF747 PIC16LF747(ISP) [ISP-  
HEADER01]  
PIC16LF747@TQFP44 [(SA245A)]  
PIC16LF747@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF76 PIC16LF76(ISP) [ISP-  
HEADER01]  
PIC16LF76@SOIC28 [(SA404)]  
PIC16LF76@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF76@SSOP28 [(SA626A)]  
PIC16LF76@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF767 PIC16LF767(ISP) [ISP-  
HEADER01]  
PIC16LF767@SOIC28 [(SA404)]  
PIC16LF767@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF767@SSOP28 [(SA626A)]  
PIC16LF767@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF77 PIC16LF77(ISP) [ISP-  
HEADER01]  
PIC16LF77@PLCC44 [(SA244)]  
PIC16LF77@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF77@TQFP44 [(SA245A)]  
PIC16LF77@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF777 PIC16LF777(ISP) [ISP-  
HEADER01]  
PIC16LF777@TQFP44 [(SA245A)]  
PIC16LF777@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF818 PIC16LF818(ISP) [ISP-  
HEADER01]  
PIC16LF818(LV)  
PIC16LF818(LV)@QFN28 [(SA685-B006)]  
PIC16LF818(LV)@SOIC18 [(SA404)] PIC16LF818(LV)@SSOP20  
[(SA626A)]  
PIC16LF818@QFN28 [(SA685-B006)]  
PIC16LF818@QFN28(ISP) [ISP-HEADER01]  
PIC16LF818@SOIC18 [(SA404)]  
PIC16LF818@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF818@SSOP20 [(SA626A)]  
PIC16LF818@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF819 PIC16LF819(ISP) [ISP-  
HEADER01]

PIC16LF819(LV)  
PIC16LF819(LV)@QFN28 [(SA685-B006)]  
PIC16LF819(LV)@SOIC18 [(SA404)] PIC16LF819(LV)@SSOP20  
[(SA626A)]  
PIC16LF819@QFN28 [(SA685-B006)]  
PIC16LF819@QFN28(ISP) [ISP-HEADER01]  
PIC16LF819@SOIC18 [(SA404)]  
PIC16LF819@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF819@SSOP20 [(SA626A)]  
PIC16LF819@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF83 PIC16LF83(ISP) [ISP-  
HEADER01]  
PIC16LF83@SOIC18 [(SA404)]  
PIC16LF83@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF84 PIC16LF84(ISP) [ISP-  
HEADER01]  
PIC16LF84@SOIC18 [(SA404)]  
PIC16LF84@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF84A PIC16LF84A(ISP) [ISP-  
HEADER01]  
PIC16LF84A@SOIC18 [(SA404)]  
PIC16LF84A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF84A@SSOP20 [(SA626A)]  
PIC16LF84A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF87 PIC16LF87(ISP) [ISP-  
HEADER01]  
PIC16LF87@QFN28 [(SA685-B006)]  
PIC16LF87@QFN28(ISP) [ISP-HEADER01]  
PIC16LF87@SOIC18 [(SA404)]  
PIC16LF87@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF87@SSOP20 [(SA626A)]  
PIC16LF87@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF870 PIC16LF870(ISP) [ISP-  
HEADER01]  
PIC16LF870@SOIC28 [(SA404)]  
PIC16LF870@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF870@SSOP28 [(SA626A)]  
PIC16LF870@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF871 PIC16LF871(ISP) [ISP-  
HEADER01]  
PIC16LF871@MQFP44 [(SA245A)]  
PIC16LF871@MQFP44(ISP) [ISP-HEADER01]  
PIC16LF871@PLCC44 [(SA244)]

PIC16LF871@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF871@TQFP44 [(SA245A)]  
PIC16LF871@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF872 PIC16LF872(ISP) [ISP-  
HEADER01]  
PIC16LF872@SOIC28 [(SA404)]  
PIC16LF872@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF872@SSOP28 [(SA626A)]  
PIC16LF872@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF873 PIC16LF873(ISP) [ISP-  
HEADER01]  
PIC16LF873@SOIC28 [(SA404)]  
PIC16LF873@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF873A  
PIC16LF873A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF873A@QFN28 [(SA697-B006)]  
PIC16LF873A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF873A@SOIC28 [(SA404)]  
PIC16LF873A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF873A@SSOP28 [(SA626A)]  
PIC16LF873A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF874 PIC16LF874(ISP) [ISP-  
HEADER01]  
PIC16LF874@MQFP44 [(SA675)]  
PIC16LF874@MQFP44(ISP) [ISP-HEADER01]  
PIC16LF874@PLCC44 [(SA244)]  
PIC16LF874@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF874@TQFP44 [(SA245A)]  
PIC16LF874@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF874A  
PIC16LF874A(ISP)(High-V) [ISP-HEADER01]



PIC16LF874A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF874A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF874A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF874A@PLCC44 [(SA244)]  
PIC16LF874A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF874A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF874A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF874A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF874A@TQFP44 [(SA245A)]  
PIC16LF874A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF874A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF874A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF874A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876 PIC16LF876(ISP) [ISP-  
HEADER01]  
PIC16LF876@SOIC28 [(SA404)]  
PIC16LF876@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF876A  
PIC16LF876A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876A@QFN28 [(SA697-B006)]  
PIC16LF876A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876A@SOIC28 [(SA404)]  
PIC16LF876A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876A@SSOP28 [(SA626A)]  
PIC16LF876A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF877 PIC16LF877(ISP) [ISP-  
HEADER01]  
PIC16LF877@MQFP44 [(SA675)]  
PIC16LF877@MQFP44(ISP) [ISP-HEADER01]  
PIC16LF877@PLCC44 [(SA244)]  
PIC16LF877@PLCC44(ISP) [ISP-HEADER01]

PIC16LF877@TQFP44 [(SA245A)]  
PIC16LF877@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF877A  
PIC16LF877A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF877A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF877A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF877A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF877A@PLCC44 [(SA244)]  
PIC16LF877A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF877A@TQFP44 [(SA245A)]  
PIC16LF877A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF88 PIC16LF88(ISP) [ISP-  
HEADER01]  
PIC16LF88@QFN28 [(SA685-B006)]  
PIC16LF88@QFN28(ISP) [ISP-HEADER01]  
PIC16LF88@SOIC18 [(SA404)]  
PIC16LF88@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF88@SSOP20 [(SA626A)]  
PIC16LF88@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF913 PIC16LF913(ISP) [ISP-  
HEADER01]  
PIC16LF913@QFN28 [(SA697-B006)]  
PIC16LF913@QFN28(ISP) [ISP-HEADER01]  
PIC16LF913@SOIC28 [(SA404)]  
PIC16LF913@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF913@SSOP28 [(SA626A)]  
PIC16LF913@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF914 PIC16LF914(ISP) [ISP-  
HEADER01]  
PIC16LF914@QFN44 [(SA712)]  
PIC16LF914@QFN44(ISP) [ISP-HEADER01]  
PIC16LF914@QFN44(ML) [(SA737)]  
PIC16LF914@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16LF914@TQFP44 [(SA245A)]  
PIC16LF914@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF916 PIC16LF916(ISP) [ISP-  
HEADER01]

PIC16LF916@QFN28 [(SA697-B006)]  
PIC16LF916@QFN28(ISP) [ISP-HEADER01]  
PIC16LF916@SOIC28 [(SA404)]  
PIC16LF916@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF916@SSOP28 [(SA626A)]  
PIC16LF916@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF917 PIC16LF917(ISP) [ISP-  
HEADER01]  
PIC16LF917@QFN44 [(SA712)]  
PIC16LF917@QFN44(ISP) [ISP-HEADER01]  
PIC16LF917@QFN44(ML) [(SA737)]  
PIC16LF917@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16LF917@TQFP44 [(SA245A)]  
PIC16LF917@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF946@TQFP64(ISP) [ISP-HEADER01]  
PIC16LV54A PIC16LV54A@SOIC18  
[(SA404)]  
PIC16LV54A@SSOP20 [(SA626A)]  
PIC16LV58A  
PIC16LV58A@SOIC18 [(SA404)] PIC16LV58A@SSOP20  
[(SA626A)]  
PIC17C42 PIC17C42@PLCC44  
[(SA244)]  
PIC17C42@TQFP44 [(SA245A)]  
PIC17C42A  
PIC17C42A@PLCC44 [(SA244)] PIC17C42A@TQFP44  
[(SA245A)]  
PIC17C43 PIC17C43@PLCC44  
[(SA244)]  
PIC17C43@TQFP44 [(SA245A)]  
PIC17C44  
PIC17C44@PLCC44 [(SA244)] PIC17C44@TQFP44  
[(SA245A)]  
PIC17LC42 PIC17LC42@PLCC44  
[(SA244)]  
PIC17LC42@TQFP44 [(SA245A)]  
PIC17LC42A  
PIC17LC42A@PLCC44 [(SA244)] PIC17LC42A@TQFP44  
[(SA245A)]  
PIC17LC43 PIC17LC43@PLCC44  
[(SA244)]  
PIC17LC43@TQFP44 [(SA245A)]  
PIC17LC44

PIC17LC44@PLCC44 [(SA244)] PIC17LC44@TQFP44  
[(SA245A)]  
PIC18C242 PIC18C242@SOIC28  
[(SA404)]  
PIC18C252 PIC18C252@SOIC28  
[(SA404)]  
PIC18C442 PIC18C442@PLCC44  
[(SA244)]  
PIC18C442@TQFP44 [(SA245A)]  
PIC18C452  
PIC18C452@PLCC44 [(SA244)] PIC18C452@TQFP44  
[(SA245A)]  
PIC18F1220 PIC18F1220(ISP) [ISP-  
HEADER01]  
PIC18F1220@SOIC18 [(SA404)]  
PIC18F1220@SOIC18(ISP) [ISP-HEADER01]  
PIC18F1220@SSOP20 [(SA626A)]  
PIC18F1220@SSOP20(ISP) [ISP-HEADER01]  
PIC18F1230 PIC18F1230(ISP) [ISP-  
HEADER01]  
PIC18F1230@QFN28 [(SA685-B006)]  
PIC18F1230@QFN28(ISP) [ISP-HEADER01]  
PIC18F1230@SOIC18 [(SA404)]  
PIC18F1230@SOIC18(ISP) [ISP-HEADER01]  
PIC18F1230@SSOP20 [(SA626A)]  
PIC18F1230@SSOP20(ISP) [ISP-HEADER01]  
PIC18F1320 PIC18F1320(ISP) [ISP-  
HEADER01]  
PIC18F1320@SOIC18 [(SA404)]  
PIC18F1320@SOIC18(ISP) [ISP-HEADER01]  
PIC18F1320@SSOP20 [(SA626A)]  
PIC18F1320@SSOP20(ISP) [ISP-HEADER01]  
PIC18F1330 PIC18F1330(ISP) [ISP-  
HEADER01]  
PIC18F1330@QFN28 [(SA685-B006)]  
PIC18F1330@QFN28(ISP) [ISP-HEADER01]  
PIC18F1330@SOIC18 [(SA404)]  
PIC18F1330@SOIC18(ISP) [ISP-HEADER01]  
PIC18F1330@SSOP20 [(SA626A)]  
PIC18F1330@SSOP20(ISP) [ISP-HEADER01]  
PIC18F1330-ICD@QFN28 [(SA685-B006)]  
PIC18F1330-ICD@QFN28(ISP) [ISP-HEADER01]  
PIC18F2220 PIC18F2220(ISP) [ISP-

HEADER01 ]  
PIC18F2220@SOIC28 [(SA404)]  
PIC18F2220@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2221  
PIC18F2221(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2221@QFN28 [(SA685-B006)]  
PIC18F2221@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2221@SOIC28 [(SA404)]  
PIC18F2221@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2320 PIC18F2320(ISP) [ISP-  
HEADER01]  
PIC18F2320@SOIC28 [(SA404)]  
PIC18F2320@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2321  
PIC18F2321(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2321@QFN28 [(SA685-B006)]  
PIC18F2321@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2321@SOIC28 [(SA404)]  
PIC18F2321@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2331 PIC18F2331(ISP) [ISP-  
HEADER01]  
PIC18F2331@SOIC28 [(SA404)]  
PIC18F2331@SOIC28(ISP) [ISP-HEADER01]  
PIC18F23K20  
PIC18F23K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F23K20@QFN28 [(SA685-B006)]  
PIC18F23K20@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F23K20@SOIC28 [(SA404)]  
PIC18F23K20@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F23K20@SSOP28 [(SA626A)]  
PIC18F23K20@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2410  
PIC18F2410(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2410@QFN28 [(SA685-B006)]  
PIC18F2410@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2410@SOIC28 [(SA404)]  
PIC18F2410@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F242 PIC18F242(ISP) [ISP-  
HEADER01]

PIC18F242@SOIC28 [(SA404)]  
PIC18F242@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2420  
PIC18F2420(ISP)(High-V) [ISP-HEADER01]  
PIC18F2420(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2420@SOIC28 [(SA404)]  
PIC18F2420@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2420@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2423  
PIC18F2423(ISP)(High-V) [ISP-HEADER01]  
PIC18F2423(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2423@QFN28 [(SA685-B006)]  
PIC18F2423@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2423@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2423@SOIC28 [(SA404)]  
PIC18F2423@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2423@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2431 PIC18F2431(ISP) [ISP-  
HEADER01]  
PIC18F2431@SOIC28 [(SA404)]  
PIC18F2431@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2439 PIC18F2439(ISP) [ISP-  
HEADER01]  
PIC18F2439@SOIC28 [(SA404)]  
PIC18F2439@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2450  
PIC18F2450(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2450@QFN28 [(SA685-B006)]  
PIC18F2450@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2450@SOIC28 [(SA404)]  
PIC18F2450@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2455  
PIC18F2455(ISP)(High-V) [ISP-HEADER01]  
PIC18F2455(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2455@SOIC28 [(SA404)]  
PIC18F2455@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2455@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2458  
PIC18F2458(ISP)(High-V) [ISP-HEADER01]  
PIC18F2458(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2458@SOIC28 [(SA404)]  
PIC18F2458@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2458@SOIC28(ISP)(Low-V) [ISP-HEADER01]

PIC18F2458@SSOP28 [(SA626A)]  
PIC18F2458@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2458@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F248 PIC18F248(ISP) [ISP-  
HEADER01]  
PIC18F248@SOIC28 [(SA404)]  
PIC18F248@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2480  
PIC18F2480(ISP)(High-V) [ISP-HEADER01]  
PIC18F2480(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2480@QFN28 [(SA685-B006)]  
PIC18F2480@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2480@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2480@SOIC28 [(SA404)]  
PIC18F2480@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2480@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24J10 PIC18F24J10(ISP) [ISP-  
HEADER01]  
PIC18F24J10@QFN28 [(SA685-B006)]  
PIC18F24J10@QFN28(ISP) [ISP-HEADER01]  
PIC18F24J10@SOIC28 [(SA404)]  
PIC18F24J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18F24J10@SSOP28 [(SA626A)]  
PIC18F24J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18F24K20  
PIC18F24K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24K20@QFN28 [(SA685-B006)]  
PIC18F24K20@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24K20@SOIC28 [(SA404)]  
PIC18F24K20@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24K20@SSOP28 [(SA626A)]  
PIC18F24K20@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2510 PIC18F2510(ISP) [ISP-  
HEADER01]  
PIC18F2510@QFN28 [(SA685-B006)]  
PIC18F2510@QFN28(ISP) [ISP-HEADER01]  
PIC18F2510@SOIC28 [(SA404)]  
PIC18F2510@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2515

PIC18F2515(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2515@SOIC28 [(SA404)]  
PIC18F2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F252 PIC18F252(ISP) [ISP-  
HEADER01]  
PIC18F252@SOIC28 [(SA404)]  
PIC18F252@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2520  
PIC18F2520(ISP)(High-V) [ISP-HEADER01]  
PIC18F2520(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2520@SOIC28 [(SA404)]  
PIC18F2520@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2523  
PIC18F2523(ISP)(High-V) [ISP-HEADER01]  
PIC18F2523(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2523@QFN28 [(SA685-B006)]  
PIC18F2523@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2523@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2523@SOIC28 [(SA404)]  
PIC18F2523@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2523@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2525  
PIC18F2525(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2525@SOIC28 [(SA404)]  
PIC18F2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2539 PIC18F2539(ISP) [ISP-  
HEADER01]  
PIC18F2539@SOIC28 [(SA404)]  
PIC18F2539@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2550  
PIC18F2550(ISP)(High-V) [ISP-HEADER01]  
PIC18F2550(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2550@SOIC28 [(SA404)]  
PIC18F2550@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2553  
PIC18F2553(ISP)(High-V) [ISP-HEADER01]  
PIC18F2553(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2553@SOIC28 [(SA404)]  
PIC18F2553@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2553@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2553@SSOP28 [(SA626A)]



PIC18F2553@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2553@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F258 PIC18F258(ISP) [ISP-  
HEADER01]  
PIC18F258@SOIC28 [(SA404)]  
PIC18F258@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2580  
PIC18F2580(ISP)(High-V) [ISP-HEADER01]  
PIC18F2580(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2580@QFN28 [(SA685-B006)]  
PIC18F2580@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2580@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2580@SOIC28 [(SA404)]  
PIC18F2580@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2585  
PIC18F2585(ISP)(High-V) [ISP-HEADER01]  
PIC18F2585(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2585@SDIP28 [(SA022A)]  
PIC18F2585@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2585@SOIC28 [(SA404)]  
PIC18F2585@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25J10 PIC18F25J10(ISP) [ISP-  
HEADER01]  
PIC18F25J10@QFN28 [(SA685-B006)]  
PIC18F25J10@QFN28(ISP) [ISP-HEADER01]  
PIC18F25J10@SOIC28 [(SA404)]  
PIC18F25J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18F25J10@SSOP28 [(SA626A)]  
PIC18F25J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18F25K20  
PIC18F25K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25K20@QFN28 [(SA685-B006)]  
PIC18F25K20@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25K20@SOIC28 [(SA404)]  
PIC18F25K20@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25K20@SSOP28 [(SA626A)]  
PIC18F25K20@SSOP28(ISP)(High-V) [ISP-HEADER01]

PIC18F25K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2610  
PIC18F2610(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2610@SOIC28 [(SA404)]  
PIC18F2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2620  
PIC18F2620(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2620@SOIC28 [(SA404)]  
PIC18F2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2680  
PIC18F2680(ISP)(High-V) [ISP-HEADER01]  
PIC18F2680(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2680@SDIP28 [(SA022A)]  
PIC18F2680@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2680@SOIC28 [(SA404)]  
PIC18F2680@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2682  
PIC18F2682(ISP)(High-V) [ISP-HEADER01]  
PIC18F2682(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2682@QFN28 [(SA685)]  
PIC18F2682@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2682@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2682@SOIC28 [(SA404)]  
PIC18F2682@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2685  
PIC18F2685(ISP)(High-V) [ISP-HEADER01]  
PIC18F2685(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2685@QFN28 [(SA685)]  
PIC18F2685@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2685@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2685@SOIC28 [(SA404)]  
PIC18F2685@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F26K20  
PIC18F26K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F26K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F26K20@QFN28 [(SA685-B006)]  
PIC18F26K20@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F26K20@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F26K20@SOIC28 [(SA404)]

PIC18F26K20@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F26K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F26K20@SSOP28 [(SA626A)]  
PIC18F26K20@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F26K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4220 PIC18F4220(ISP) [ISP-  
HEADER01]  
PIC18F4220@QFN44 [(SA712)]  
PIC18F4220@QFN44(ISP) [ISP-HEADER01]  
PIC18F4220@QFN44(ML) [(SA737)]  
PIC18F4220@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4220@TQFP44 [(SA245A)]  
PIC18F4220@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4221  
PIC18F4221(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4221@QFN44 [(SA712)]  
PIC18F4221@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4221@QFN44(ML) [(SA737)]  
PIC18F4221@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4221@TQFP44 [(SA245A)]  
PIC18F4221@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4320 PIC18F4320(ISP) [ISP-  
HEADER01]  
PIC18F4320@QFN44 [(SA712)]  
PIC18F4320@QFN44(ISP) [ISP-HEADER01]  
PIC18F4320@QFN44(ML) [(SA737)]  
PIC18F4320@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4320@TQFP44 [(SA245A)]  
PIC18F4320@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4321  
PIC18F4321(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4321@QFN44 [(SA712)]  
PIC18F4321@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4321@QFN44(ML) [(SA737)]  
PIC18F4321@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4321@TQFP44 [(SA245A)]  
PIC18F4321@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4331 PIC18F4331(ISP) [ISP-  
HEADER01]  
PIC18F4331@TQFP44 [(SA245A)]  
PIC18F4331@TQFP44(ISP) [ISP-HEADER01]  
PIC18F43K20  
PIC18F43K20(ISP)(High-V) [ISP-HEADER01]

PIC18F43K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F43K20@QFN44 [(SA712)]  
PIC18F43K20@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F43K20@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F43K20@QFN44(ML) [(SA737)]  
PIC18F43K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F43K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18F43K20@TQFP44 [(SA245A)]  
PIC18F43K20@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F43K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410  
PIC18F4410(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410@QFN44 [(SA712)]  
PIC18F4410@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410@QFN44(ML) [(SA737)]  
PIC18F4410@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410@TQFP44 [(SA245A)]  
PIC18F4410@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F442 PIC18F442(ISP) [ISP-  
HEADER01]  
PIC18F442@PLCC44 [(SA244)]  
PIC18F442@PLCC44(ISP) [ISP-HEADER01]  
PIC18F442@TQFP44 [(SA245A)]  
PIC18F442@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4420  
PIC18F4420(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4420@QFN44 [(SA712)]  
PIC18F4420@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4420@QFN44(ML) [(SA737)]  
PIC18F4420@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4420@TQFP44 [(SA245A)]  
PIC18F4420@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423  
PIC18F4423(ISP)(High-V) [ISP-HEADER01]  
PIC18F4423(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423@QFN44 [(SA712)]  
PIC18F4423@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4423@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423@QFN44(ML) [(SA737)]  
PIC18F4423@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4423@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423@TQFP44 [(SA245A)]  
PIC18F4423@TQFP44(ISP)(High-V) [ISP-HEADER01]

PIC18F4423@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4431 PIC18F4431(ISP) [ISP-  
HEADER01]  
PIC18F4431@TQFP44 [(SA245A)]  
PIC18F4431@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4439 PIC18F4439(ISP) [ISP-  
HEADER01]  
PIC18F4439@TQFP44 [(SA245A)]  
PIC18F4439@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4450  
PIC18F4450(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4450@QFN44 [(SA712)]  
PIC18F4450@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4450@QFN44(ML) [(SA737)]  
PIC18F4450@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4450@TQFP44 [(SA245A)]  
PIC18F4450@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455  
PIC18F4455(ISP)(High-V) [ISP-HEADER01]  
PIC18F4455(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455@QFN44 [(SA712)]  
PIC18F4455@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4455@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455@QFN44(ML) [(SA737)]  
PIC18F4455@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4455@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455@TQFP44 [(SA245A)]  
PIC18F4455@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4455@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4458  
PIC18F4458(ISP)(High-V) [ISP-HEADER01]  
PIC18F4458(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4458@QFN44 [(SA737)]  
PIC18F4458@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4458@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4458@TQFP44 [(SA245A)]  
PIC18F4458@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4458@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F448 PIC18F448(ISP) [ISP-  
HEADER01]  
PIC18F448@PLCC44 [(SA244)]  
PIC18F448@PLCC44(ISP) [ISP-HEADER01]  
PIC18F448@TQFP44 [(SA245A)]

PIC18F448@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4480  
PIC18F4480(ISP)(High-V) [ISP-HEADER01]  
PIC18F4480(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4480@QFN44 [(SA712)]  
PIC18F4480@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4480@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4480@QFN44(ML) [(SA737)]  
PIC18F4480@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4480@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4480@TQFP44 [(SA245A)]  
PIC18F4480@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4480@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F44J10 PIC18F44J10(ISP) [ISP-  
HEADER01]  
PIC18F44J10@QFN44 [(SA712)]  
PIC18F44J10@QFN44(ISP) [ISP-HEADER01]  
PIC18F44J10@QFN44(ML) [(SA709)]  
PIC18F44J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F44J10@TQFP44 [(SA245A)]  
PIC18F44J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18F44K20  
PIC18F44K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F44K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F44K20@QFN44 [(SA712)]  
PIC18F44K20@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F44K20@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F44K20@QFN44(ML) [(SA737)]  
PIC18F44K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F44K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18F44K20@TQFP44 [(SA245A)]  
PIC18F44K20@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F44K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4510 PIC18F4510(ISP) [ISP-  
HEADER01]  
PIC18F4510@QFN44 [(SA712)]  
PIC18F4510@QFN44(ISP) [ISP-HEADER01]  
PIC18F4510@QFN44(ML) [(SA737)]  
PIC18F4510@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4510@TQFP44 [(SA245A)]  
PIC18F4510@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4515  
PIC18F4515(ISP)(Low-V) [ISP-HEADER01]

PIC18F4515@QFN44 [(SA712)]  
PIC18F4515@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4515@QFN44(ML) [(SA737)]  
PIC18F4515@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4515@TQFP44 [(SA245A)]  
PIC18F4515@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F452 PIC18F452(ISP) [ISP-  
HEADER01]  
PIC18F452@PLCC44 [(SA244)]  
PIC18F452@PLCC44(ISP) [ISP-HEADER01]  
PIC18F452@TQFP44 [(SA245A)]  
PIC18F452@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4520 PIC18F4520(ISP) [ISP-  
HEADER01]  
PIC18F4520@QFN44 [(SA712)]  
PIC18F4520@QFN44(ISP) [ISP-HEADER01]  
PIC18F4520@QFN44(ML) [(SA737)]  
PIC18F4520@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4520@TQFP44 [(SA245A)]  
PIC18F4520@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4523  
PIC18F4523(ISP)(High-V) [ISP-HEADER01]  
PIC18F4523(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4523@QFN44 [(SA712)]  
PIC18F4523@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4523@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4523@QFN44(ML) [(SA737)]  
PIC18F4523@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4523@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4523@TQFP44 [(SA245A)]  
PIC18F4523@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4523@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525  
PIC18F4525(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525@QFN44 [(SA712)]  
PIC18F4525@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525@QFN44(ML) [(SA737)]  
PIC18F4525@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525@TQFP44 [(SA245A)]  
PIC18F4525@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4539 PIC18F4539(ISP) [ISP-  
HEADER01]  
PIC18F4539@TQFP44 [(SA245A)]

PIC18F4539@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4550  
PIC18F4550(ISP)(High-V) [ISP-HEADER01]  
PIC18F4550(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4550@QFN44 [(SA712)]  
PIC18F4550@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4550@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4550@QFN44(ML) [(SA737)]  
PIC18F4550@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4550@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4550@TQFP44 [(SA245A)]  
PIC18F4550@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4550@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4553  
PIC18F4553(ISP)(High-V) [ISP-HEADER01]  
PIC18F4553(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4553@QFN44 [(SA737)]  
PIC18F4553@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4553@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4553@TQFP44 [(SA245A)]  
PIC18F4553@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4553@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F458 PIC18F458(ISP) [ISP-  
HEADER01]  
PIC18F458@PLCC44 [(SA244)]  
PIC18F458@PLCC44(ISP) [ISP-HEADER01]  
PIC18F458@TQFP44 [(SA245A)]  
PIC18F458@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4580  
PIC18F4580(ISP)(High-V) [ISP-HEADER01]  
PIC18F4580(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4580@QFN44 [(SA712)]  
PIC18F4580@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4580@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4580@QFN44(ML) [(SA737)]  
PIC18F4580@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4580@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4580@TQFP44 [(SA245A)]  
PIC18F4580@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4580@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585  
PIC18F4585(ISP)(High-V) [ISP-HEADER01]  
PIC18F4585(ISP)(Low-V) [ISP-HEADER01]



PIC18F4585@QFN44 [(SA712)]  
PIC18F4585@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4585@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585@QFN44(ML) [(SA737)]  
PIC18F4585@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4585@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585@TQFP44 [(SA245A)]  
PIC18F4585@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F45J10 PIC18F45J10(ISP) [ISP-  
HEADER01]  
PIC18F45J10@QFN44 [(SA712)]  
PIC18F45J10@QFN44(ISP) [ISP-HEADER01]  
PIC18F45J10@QFN44(ML) [(SA709)]  
PIC18F45J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F45J10@TQFP44 [(SA245A)]  
PIC18F45J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18F45K20  
PIC18F45K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F45K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F45K20@QFN44 [(SA712)]  
PIC18F45K20@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F45K20@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F45K20@QFN44(ML) [(SA737)]  
PIC18F45K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F45K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18F45K20@TQFP44 [(SA245A)]  
PIC18F45K20@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F45K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610  
PIC18F4610(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610@QFN44 [(SA712)]  
PIC18F4610@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610@QFN44(ML) [(SA737)]  
PIC18F4610@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610@TQFP44 [(SA245A)]  
PIC18F4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620  
PIC18F4620(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620@QFN44 [(SA712)]  
PIC18F4620@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620@QFN44(ML) [(SA737)]  
PIC18F4620@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]

PIC18F4620@TQFP44 [(SA245A)]  
PIC18F4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680  
PIC18F4680(ISP)(High-V) [ISP-HEADER01]  
PIC18F4680(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680@QFN44 [(SA712)]  
PIC18F4680@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4680@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680@QFN44(ML) [(SA737)]  
PIC18F4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4680@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680@TQFP44 [(SA245A)]  
PIC18F4680@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682  
PIC18F4682(ISP)(High-V) [ISP-HEADER01]  
PIC18F4682(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682@QFN44 [(SA712)]  
PIC18F4682@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4682@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682@QFN44(ML) [(SA737)]  
PIC18F4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4682@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682@TQFP44 [(SA245A)]  
PIC18F4682@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685  
PIC18F4685(ISP)(High-V) [ISP-HEADER01]  
PIC18F4685(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685@QFN44 [(SA712)]  
PIC18F4685@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4685@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685@QFN44(ML) [(SA737)]  
PIC18F4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4685@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685@TQFP44 [(SA245A)]  
PIC18F4685@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F46K20  
PIC18F46K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F46K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F46K20@QFN44 [(SA712)]  
PIC18F46K20@QFN44(ISP)(High-V) [ISP-HEADER01]

PIC18F46K20@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F46K20@QFN44(ML) [(SA737)]  
PIC18F46K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F46K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18F46K20@TQFP44 [(SA245A)]  
PIC18F46K20@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F46K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6310@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6390@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6393@TQFP64(ISP) [ISP-HEADER01]  
PIC18F63J11@TQFP64(\*) [(SA732+B340)]  
PIC18F63J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F63J90@TQFP64(\*) [(SA732+B340)]  
PIC18F63J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6410@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6490@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6493@TQFP64(ISP) [ISP-HEADER01]  
PIC18F64J11@TQFP64(\*) [(SA732+B340)]  
PIC18F64J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F64J90@TQFP64(\*) [(SA732+B340)]  
PIC18F64J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6520@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6525@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6527@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6527@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6585@PLCC68(ISP) [ISP-HEADER01]  
PIC18F6585@TQFP64(ISP) [ISP-HEADER01]  
PIC18F65J10@TQFP64(\*) [(SA732+B340)]  
PIC18F65J10@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F65J10@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F65J11@TQFP64(\*) [(SA732+B340)]  
PIC18F65J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F65J15@TQFP64(\*) [(SA732+B340)]  
PIC18F65J15@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F65J15@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F65J50@TQFP64(\*) [(SA732+B340)]  
PIC18F65J50@TQFP64(ISP) [ISP-HEADER01]  
PIC18F65J90@TQFP64(\*) [(SA732+B340)]  
PIC18F65J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6620@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6621@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6622@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6622@TQFP64(ISP)(Low-V) [ISP-HEADER01]

PIC18F6627@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6627@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6680@PLCC68(ISP) [ISP-HEADER01]  
PIC18F6680@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J10@TQFP64(\*) [(SA732+B340)]  
PIC18F66J10@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F66J10@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F66J11@TQFP64(\*) [(SA732+B340)]  
PIC18F66J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J15@TQFP64(\*) [(SA732+B340)]  
PIC18F66J15@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F66J15@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F66J16@TQFP64(\*) [(SA732+B340)]  
PIC18F66J16@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J50@TQFP64(\*) [(SA732+B340)]  
PIC18F66J50@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J55@TQFP64(\*) [(SA732+B340)]  
PIC18F66J55@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J60@TQFP64(\*) [(SA732+B340)]  
PIC18F66J60@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J65@TQFP64(\*) [(SA732+B340)]  
PIC18F66J65@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6720@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6722@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6722@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F67J10@TQFP64(\*) [(SA732+B340)]  
PIC18F67J10@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F67J10@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F67J11@TQFP64(\*) [(SA732+B340)]  
PIC18F67J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F67J50@TQFP64(\*) [(SA732+B340)]  
PIC18F67J50@TQFP64(ISP) [ISP-HEADER01]  
PIC18F67J60@TQFP64(\*) [(SA732+B340)]  
PIC18F67J60@TQFP64(ISP) [ISP-HEADER01]  
PIC18F8310@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8390@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8393@TQFP80(ISP) [ISP-HEADER01]  
PIC18F83J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F83J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8410@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8490@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8493@TQFP80(ISP) [ISP-HEADER01]  
PIC18F84J11@TQFP80(ISP) [ISP-HEADER01]

PIC18F84J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8520@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8525@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8527@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8527@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F8585@TQFP80(ISP) [ISP-HEADER01]  
PIC18F85J10@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F85J10@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F85J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F85J15@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F85J15@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F85J50@TQFP80(ISP) [ISP-HEADER01]  
PIC18F85J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8620@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8621@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8622@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F8627@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F8680@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J10@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F86J10@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F86J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J15@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F86J15@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F86J16@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J50@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J55@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J60@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J65@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8720@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8722@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8722@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F87J10@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F87J10@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F87J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F87J50@TQFP80(ISP) [ISP-HEADER01]  
PIC18F87J60@TQFP80(ISP) [ISP-HEADER01]  
PIC18F96J60@TQFP100(ISP) [ISP-HEADER01]  
PIC18F96J65@TQFP100(ISP) [ISP-HEADER01]  
PIC18F97J60@TQFP100(ISP) [ISP-HEADER01]  
PIC18LC452 PIC18LC452@PLCC44  
[(SA244)]

PIC18LC452@TQFP44 [(SA245A)]  
PIC18LF1220  
PIC18LF1220(ISP) [ISP-HEADER01] PIC18LF1220@SOIC18  
[(SA404)]  
PIC18LF1220@SOIC18(ISP) [ISP-HEADER01]  
PIC18LF1220@SSOP20 [(SA626A)]  
PIC18LF1220@SSOP20(ISP) [ISP-HEADER01]  
PIC18LF1320 PIC18LF1320(ISP) [ISP-  
HEADER01]  
PIC18LF1320@SOIC18 [(SA404)]  
PIC18LF1320@SOIC18(ISP) [ISP-HEADER01]  
PIC18LF1320@SSOP20 [(SA626A)]  
PIC18LF1320@SSOP20(ISP) [ISP-HEADER01]  
PIC18LF2220 PIC18LF2220(ISP) [ISP-  
HEADER01]  
PIC18LF2220@SOIC28 [(SA404)]  
PIC18LF2220@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2221  
PIC18LF2221(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2221@QFN28 [(SA685-B006)]  
PIC18LF2221@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2221@SOIC28 [(SA404)]  
PIC18LF2221@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2320 PIC18LF2320(ISP) [ISP-  
HEADER01]  
PIC18LF2320@SOIC28 [(SA404)]  
PIC18LF2320@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2321  
PIC18LF2321(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2321@QFN28 [(SA685-B006)]  
PIC18LF2321@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2321@SOIC28 [(SA404)]  
PIC18LF2321@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2331 PIC18LF2331(ISP) [ISP-  
HEADER01]  
PIC18LF2331@SOIC28 [(SA404)]  
PIC18LF2331@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2410  
PIC18LF2410(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2410@QFN28 [(SA685-B006)]  
PIC18LF2410@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2410@SOIC28 [(SA404)]  
PIC18LF2410@SOIC28(ISP)(Low-V) [ISP-HEADER01]

PIC18LF242 PIC18LF242(ISP) [ISP-  
HEADER01]  
PIC18LF242@SOIC28 [(SA404)]  
PIC18LF242@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2420  
PIC18LF2420(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2420(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2420@SOIC28 [(SA404)]  
PIC18LF2420@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2420@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2431 PIC18LF2431(ISP) [ISP-  
HEADER01]  
PIC18LF2431@SOIC28 [(SA404)]  
PIC18LF2431@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2439 PIC18LF2439(ISP) [ISP-  
HEADER01]  
PIC18LF2439@SOIC28 [(SA404)]  
PIC18LF2439@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2450  
PIC18LF2450(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2450@QFN28 [(SA685-B006)]  
PIC18LF2450@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2450@SOIC28 [(SA404)]  
PIC18LF2450@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2455  
PIC18LF2455(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2455(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2455@SOIC28 [(SA404)]  
PIC18LF2455@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2455@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF248 PIC18LF248(ISP) [ISP-  
HEADER01]  
PIC18LF248@SOIC28 [(SA404)]  
PIC18LF248@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2480  
PIC18LF2480(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2480(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2480@QFN28 [(SA685-B006)]  
PIC18LF2480@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2480@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2480@SOIC28 [(SA404)]  
PIC18LF2480@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2480@SOIC28(ISP)(Low-V) [ISP-HEADER01]

PIC18LF24J10 PIC18LF24J10(ISP) [ISP-  
HEADER01]  
PIC18LF24J10@QFN28 [(SA685-B006)]  
PIC18LF24J10@QFN28(ISP) [ISP-HEADER01]  
PIC18LF24J10@SOIC28 [(SA404)]  
PIC18LF24J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF24J10@SSOP28 [(SA626A)]  
PIC18LF24J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18LF2510 PIC18LF2510(ISP) [ISP-  
HEADER01]  
PIC18LF2510@QFN28 [(SA685-B006)]  
PIC18LF2510@QFN28(ISP) [ISP-HEADER01]  
PIC18LF2510@SOIC28 [(SA404)]  
PIC18LF2510@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2515  
PIC18LF2515(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2515@SOIC28 [(SA404)]  
PIC18LF2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF252 PIC18LF252(ISP) [ISP-  
HEADER01]  
PIC18LF252@SOIC28 [(SA404)]  
PIC18LF252@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2520  
PIC18LF2520(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2520(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2520@SOIC28 [(SA404)]  
PIC18LF2520@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2525  
PIC18LF2525(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2525@SOIC28 [(SA404)]  
PIC18LF2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2539 PIC18LF2539(ISP) [ISP-  
HEADER01]  
PIC18LF2539@SOIC28 [(SA404)]  
PIC18LF2539@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2550  
PIC18LF2550(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2550(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2550@SOIC28 [(SA404)]  
PIC18LF2550@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF258 PIC18LF258(ISP) [ISP-



HEADER01 ]  
PIC18LF258@SOIC28 [(SA404)]  
PIC18LF258@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2580  
PIC18LF2580(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2580(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2580@QFN28 [(SA685-B006)]  
PIC18LF2580@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2580@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2580@SOIC28 [(SA404)]  
PIC18LF2580@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2585  
PIC18LF2585(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2585@SDIP28 [(SA022A)]  
PIC18LF2585@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2585@SOIC28 [(SA404)]  
PIC18LF2585@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF25J10 PIC18LF25J10(ISP) [ISP-  
HEADER01]  
PIC18LF25J10@QFN28 [(SA685-B006)]  
PIC18LF25J10@QFN28(ISP) [ISP-HEADER01]  
PIC18LF25J10@SOIC28 [(SA404)]  
PIC18LF25J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF25J10@SSOP28 [(SA626A)]  
PIC18LF25J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18LF2610  
PIC18LF2610(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2610@SOIC28 [(SA404)]  
PIC18LF2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2620  
PIC18LF2620(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2620@SOIC28 [(SA404)]  
PIC18LF2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2680  
PIC18LF2680(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2680(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2680@SDIP28 [(SA022A)]  
PIC18LF2680@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]

PIC18LF2680@SOIC28 [(SA404)]  
PIC18LF2680@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2682  
PIC18LF2682(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2682(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2682@QFN28 [(SA685)]  
PIC18LF2682@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2682@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2682@SOIC28 [(SA404)]  
PIC18LF2682@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2685  
PIC18LF2685(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2685(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2685@QFN28 [(SA685)]  
PIC18LF2685@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2685@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2685@SOIC28 [(SA404)]  
PIC18LF2685@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4220 PIC18LF4220(ISP) [ISP-  
HEADER01]  
PIC18LF4220@QFN44 [(SA712)]  
PIC18LF4220@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4220@QFN44(ML) [(SA737)]  
PIC18LF4220@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4220@TQFP44 [(SA245A)]  
PIC18LF4220@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4221  
PIC18LF4221(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4221@QFN44 [(SA712)]  
PIC18LF4221@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4221@QFN44(ML) [(SA737)]  
PIC18LF4221@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4221@TQFP44 [(SA245A)]  
PIC18LF4221@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4320 PIC18LF4320(ISP) [ISP-  
HEADER01]  
PIC18LF4320@QFN44 [(SA712)]  
PIC18LF4320@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4320@QFN44(ML) [(SA737)]  
PIC18LF4320@QFN44(ML)(ISP) [ISP-HEADER01]

PIC18LF4320@TQFP44 [(SA245A)]  
PIC18LF4320@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4321  
PIC18LF4321(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4321@QFN44 [(SA712)]  
PIC18LF4321@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4321@QFN44(ML) [(SA737)]  
PIC18LF4321@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4321@TQFP44 [(SA245A)]  
PIC18LF4321@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4331 PIC18LF4331(ISP) [ISP-  
HEADER01]  
PIC18LF4331@TQFP44 [(SA245A)]  
PIC18LF4331@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4410  
PIC18LF4410(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4410@QFN44 [(SA712)]  
PIC18LF4410@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4410@QFN44(ML) [(SA737)]  
PIC18LF4410@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4410@TQFP44 [(SA245A)]  
PIC18LF4410@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF442 PIC18LF442(ISP) [ISP-  
HEADER01]  
PIC18LF442@PLCC44 [(SA244)]  
PIC18LF442@PLCC44(ISP) [ISP-HEADER01]  
PIC18LF442@TQFP44 [(SA245A)]  
PIC18LF442@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4420  
PIC18LF4420(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4420@QFN44 [(SA712)]  
PIC18LF4420@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4420@QFN44(ML) [(SA737)]  
PIC18LF4420@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4420@TQFP44 [(SA245A)]  
PIC18LF4420@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4431 PIC18LF4431(ISP) [ISP-  
HEADER01]  
PIC18LF4431@TQFP44 [(SA245A)]  
PIC18LF4431@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4439 PIC18LF4439(ISP) [ISP-  
HEADER01]  
PIC18LF4439@TQFP44 [(SA245A)]

PIC18LF4439@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4450  
PIC18LF4450(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4450@QFN44 [(SA712)]  
PIC18LF4450@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4450@QFN44(ML) [(SA737)]  
PIC18LF4450@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4450@TQFP44 [(SA245A)]  
PIC18LF4450@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4455  
PIC18LF4455(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4455(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4455@QFN44 [(SA712)]  
PIC18LF4455@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4455@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4455@QFN44(ML) [(SA737)]  
PIC18LF4455@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4455@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4455@TQFP44 [(SA245A)]  
PIC18LF4455@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4455@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF448 PIC18LF448(ISP) [ISP-  
HEADER01]  
PIC18LF448@PLCC44 [(SA244)]  
PIC18LF448@PLCC44(ISP) [ISP-HEADER01]  
PIC18LF448@TQFP44 [(SA245A)]  
PIC18LF448@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4480  
PIC18LF4480(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4480(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4480@QFN44 [(SA712)]  
PIC18LF4480@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4480@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4480@QFN44(ML) [(SA737)]  
PIC18LF4480@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4480@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4480@TQFP44 [(SA245A)]  
PIC18LF4480@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4480@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF44J10 PIC18LF44J10(ISP) [ISP-  
HEADER01]  
PIC18LF44J10@QFN44 [(SA712)]  
PIC18LF44J10@QFN44(ISP) [ISP-HEADER01]

PIC18LF44J10@QFN44(ML) [(SA709)]  
PIC18LF44J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF44J10@TQFP44 [(SA245A)]  
PIC18LF44J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4510 PIC18LF4510(ISP) [ISP-  
HEADER01]  
PIC18LF4510@QFN44 [(SA712)]  
PIC18LF4510@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4510@QFN44(ML) [(SA737)]  
PIC18LF4510@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4510@TQFP44 [(SA245A)]  
PIC18LF4510@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4515  
PIC18LF4515(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4515@QFN44 [(SA712)]  
PIC18LF4515@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4515@QFN44(ML) [(SA737)]  
PIC18LF4515@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4515@TQFP44 [(SA245A)]  
PIC18LF4515@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF452 PIC18LF452(ISP) [ISP-  
HEADER01]  
PIC18LF452@PLCC44 [(SA244)]  
PIC18LF452@PLCC44(ISP) [ISP-HEADER01]  
PIC18LF452@TQFP44 [(SA245A)]  
PIC18LF452@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4520 PIC18LF4520(ISP) [ISP-  
HEADER01]  
PIC18LF4520@QFN44 [(SA712)]  
PIC18LF4520@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4520@QFN44(ML) [(SA737)]  
PIC18LF4520@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4520@TQFP44 [(SA245A)]  
PIC18LF4520@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4525  
PIC18LF4525(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4525@QFN44 [(SA712)]  
PIC18LF4525@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4525@QFN44(ML) [(SA737)]  
PIC18LF4525@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4525@TQFP44 [(SA245A)]  
PIC18LF4525@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4539 PIC18LF4539(ISP) [ISP-

HEADER01 ]

PIC18LF4539@TQFP44 [ (SA245A) ]

PIC18LF4539@TQFP44(ISP) [ ISP-HEADER01 ]

PIC18LF4550

PIC18LF4550(ISP)(High-V) [ ISP-HEADER01 ]

PIC18LF4550(ISP)(Low-V) [ ISP-HEADER01 ]

PIC18LF4550@QFN44 [ (SA712) ]

PIC18LF4550@QFN44(ISP)(High-V) [ ISP-HEADER01 ]

PIC18LF4550@QFN44(ISP)(Low-V) [ ISP-HEADER01 ]

PIC18LF4550@QFN44(ML) [ (SA737) ]

PIC18LF4550@QFN44(ML)(ISP)(H-V) [ ISP-HEADER01 ]

PIC18LF4550@QFN44(ML)(ISP)(L-V) [ ISP-HEADER01 ]

PIC18LF4550@TQFP44 [ (SA245A) ]

PIC18LF4550@TQFP44(ISP)(High-V) [ ISP-HEADER01 ]

PIC18LF4550@TQFP44(ISP)(Low-V) [ ISP-HEADER01 ]

PIC18LF458 PIC18LF458(ISP) [ ISP-  
HEADER01 ]

PIC18LF458@PLCC44 [ (SA244) ]

PIC18LF458@PLCC44(ISP) [ ISP-HEADER01 ]

PIC18LF458@TQFP44 [ (SA245A) ]

PIC18LF458@TQFP44(ISP) [ ISP-HEADER01 ]

PIC18LF4580

PIC18LF4580(ISP)(High-V) [ ISP-HEADER01 ]

PIC18LF4580(ISP)(Low-V) [ ISP-HEADER01 ]

PIC18LF4580@QFN44 [ (SA712) ]

PIC18LF4580@QFN44(ISP)(High-V) [ ISP-HEADER01 ]

PIC18LF4580@QFN44(ISP)(Low-V) [ ISP-HEADER01 ]

PIC18LF4580@QFN44(ML) [ (SA737) ]

PIC18LF4580@QFN44(ML)(ISP)(H-V) [ ISP-HEADER01 ]

PIC18LF4580@QFN44(ML)(ISP)(L-V) [ ISP-HEADER01 ]

PIC18LF4580@TQFP44 [ (SA245A) ]

PIC18LF4580@TQFP44(ISP)(High-V) [ ISP-HEADER01 ]

PIC18LF4580@TQFP44(ISP)(Low-V) [ ISP-HEADER01 ]

PIC18LF4585

PIC18LF4585(ISP)(High-V) [ ISP-HEADER01 ]

PIC18LF4585(ISP)(Low-V) [ ISP-HEADER01 ]

PIC18LF4585@QFN44 [ (SA712) ]

PIC18LF4585@QFN44(ISP)(High-V) [ ISP-HEADER01 ]

PIC18LF4585@QFN44(ISP)(Low-V) [ ISP-HEADER01 ]

PIC18LF4585@QFN44(ML) [ (SA737) ]

PIC18LF4585@QFN44(ML)(ISP)(H-V) [ ISP-HEADER01 ]

PIC18LF4585@QFN44(ML)(ISP)(L-V) [ ISP-HEADER01 ]

PIC18LF4585@TQFP44 [ (SA245A) ]

PIC18LF4585@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF45J10 PIC18LF45J10(ISP) [ISP-  
HEADER01]  
PIC18LF45J10@QFN44 [(SA712)]  
PIC18LF45J10@QFN44(ISP) [ISP-HEADER01]  
PIC18LF45J10@QFN44(ML) [(SA709)]  
PIC18LF45J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF45J10@TQFP44 [(SA245A)]  
PIC18LF45J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4610  
PIC18LF4610(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4610@QFN44 [(SA712)]  
PIC18LF4610@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4610@QFN44(ML) [(SA737)]  
PIC18LF4610@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4610@TQFP44 [(SA245A)]  
PIC18LF4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4620  
PIC18LF4620(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4620@QFN44 [(SA712)]  
PIC18LF4620@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4620@QFN44(ML) [(SA737)]  
PIC18LF4620@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4620@TQFP44 [(SA245A)]  
PIC18LF4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4680  
PIC18LF4680(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4680(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4680@QFN44 [(SA712)]  
PIC18LF4680@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4680@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4680@QFN44(ML) [(SA737)]  
PIC18LF4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4680@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4680@TQFP44 [(SA245A)]  
PIC18LF4680@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4682  
PIC18LF4682(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4682(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4682@QFN44 [(SA712)]  
PIC18LF4682@QFN44(ISP)(High-V) [ISP-HEADER01]

PIC18LF4682@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4682@QFN44(ML) [(SA737)]  
PIC18LF4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4682@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4682@TQFP44 [(SA245A)]  
PIC18LF4682@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4685  
PIC18LF4685(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4685(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4685@QFN44 [(SA712)]  
PIC18LF4685@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4685@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4685@QFN44(ML) [(SA737)]  
PIC18LF4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4685@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4685@TQFP44 [(SA245A)]  
PIC18LF4685@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6310@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6390@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6393@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF63J11@TQFP64(\*) [(SA732+B340)]  
PIC18LF63J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF63J90@TQFP64(\*) [(SA732+B340)]  
PIC18LF63J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6410@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6490@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6493@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF64J11@TQFP64(\*) [(SA732+B340)]  
PIC18LF64J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF64J90@TQFP64(\*) [(SA732+B340)]  
PIC18LF64J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6520@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6525@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6527@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18LF6527@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6585@PLCC68(ISP) [ISP-HEADER01]  
PIC18LF6585@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF65J11@TQFP64(\*) [(SA732+B340)]  
PIC18LF65J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF65J90@TQFP64(\*) [(SA732+B340)]  
PIC18LF65J90@TQFP64(ISP) [ISP-HEADER01]



PIC18LF6620@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6621@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6622@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18LF6622@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6627@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18LF6627@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6680@PLCC68(ISP) [ISP-HEADER01]  
PIC18LF6680@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6720@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6722@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18LF6722@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF8310@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8390@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8393@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF83J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF83J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8410@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8490@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8493@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF84J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF84J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8520@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8525@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8527@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8527@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF8585@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF85J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF85J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8620@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8621@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8622@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF8627@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF8680@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8720@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8722@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8722@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC30F2010 PIC30F2010(ISP) [ISP-  
HEADER01]  
PIC30F2010@SDIP28 [(SA022A)]  
PIC30F2010@SDIP28(ISP) [ISP-HEADER01]  
PIC30F2010@SOIC28 [(SA404)]

PIC30F2010@SOIC28(ISP) [ISP-HEADER01]  
PIC30F2011(ISP) [ISP-HEADER01]  
PIC30F2011@QFN28(ISP) [ISP-HEADER01]  
PIC30F2011@SDIP18(ISP) [ISP-HEADER01]  
PIC30F2011@SOIC18(ISP) [ISP-HEADER01]  
PIC30F2012(ISP) [ISP-HEADER01]  
PIC30F2012@QFN28(ISP) [ISP-HEADER01]  
PIC30F2012@SDIP28(ISP) [ISP-HEADER01]  
PIC30F2012@SOIC28(ISP) [ISP-HEADER01]  
PIC30F3010(ISP) [ISP-HEADER01]  
PIC30F3010@QFN44(ISP) [ISP-HEADER01]  
PIC30F3010@SDIP28(ISP) [ISP-HEADER01]  
PIC30F3010@SOIC28(ISP) [ISP-HEADER01]  
PIC30F3011(ISP) [ISP-HEADER01]  
PIC30F3011@QFN44(ISP) [ISP-HEADER01]  
PIC30F3011@QFP44(ISP) [ISP-HEADER01]  
PIC30F3012(ISP) [ISP-HEADER01]  
PIC30F3012@QFN44(ISP) [ISP-HEADER01]  
PIC30F3012@QFP44(ISP) [ISP-HEADER01]  
PIC30F3012@SDIP18(ISP) [ISP-HEADER01]  
PIC30F3012@SOIC18(ISP) [ISP-HEADER01]  
PIC30F3013(ISP) [ISP-HEADER01]  
PIC30F3013@QFN44(ISP) [ISP-HEADER01]  
PIC30F3013@QFP44(ISP) [ISP-HEADER01]  
PIC30F3013@SDIP28(ISP) [ISP-HEADER01]  
PIC30F3013@SOIC28(ISP) [ISP-HEADER01]  
PIC30F3014(ISP) [ISP-HEADER01]  
PIC30F3014@QFN44(ISP) [ISP-HEADER01]  
PIC30F3014@QFP44(ISP) [ISP-HEADER01]  
PIC30F4011(ISP) [ISP-HEADER01]  
PIC30F4011@QFN44(ISP) [ISP-HEADER01]  
PIC30F4011@QFP44(ISP) [ISP-HEADER01]  
PIC30F4012(ISP) [ISP-HEADER01]  
PIC30F4012@QFN44(ISP) [ISP-HEADER01]  
PIC30F4012@SDIP28(ISP) [ISP-HEADER01]  
PIC30F4012@SOIC28(ISP) [ISP-HEADER01]  
PIC30F4013(ISP) [ISP-HEADER01]  
PIC30F4013@QFN44(ISP) [ISP-HEADER01]  
PIC30F4013@QFP44(ISP) [ISP-HEADER01]  
PIC30F5011@QFP64(ISP) [ISP-HEADER01]  
PIC30F5013@QFP80(ISP) [ISP-HEADER01]  
PIC30F5015@QFP64(ISP) [ISP-HEADER01]  
PIC30F5016@QFP80(ISP) [ISP-HEADER01]

PIC30F6010@QFP80 (ISP) [ISP-HEADER01]  
PIC30F6010@TQFP80 (ISP) [ISP-HEADER01]  
PIC30F6010A@QFP80 (ISP) [ISP-HEADER01]  
PIC30F6010A@TQFP80 (ISP) [ISP-HEADER01]  
PIC30F6011@QFP64 (ISP) [ISP-HEADER01]  
PIC30F6011A@QFP64 (ISP) [ISP-HEADER01]  
PIC30F6012@QFP64 (ISP) [ISP-HEADER01]  
PIC30F6012A@QFP64 (ISP) [ISP-HEADER01]  
PIC30F6013@QFP80 (ISP) [ISP-HEADER01]  
PIC30F6013A@QFP80 (ISP) [ISP-HEADER01]  
PIC30F6014@QFP80 (ISP) [ISP-HEADER01]  
PIC30F6014@TQFP80 (ISP) [ISP-HEADER01]  
PIC30F6014A@QFP80 (ISP) [ISP-HEADER01]  
PIC30F6014A@TQFP80 (ISP) [ISP-HEADER01]  
PIC30F6015@QFP64 (ISP) [ISP-HEADER01]  
PS200 PS200 (ISP) [ISP-  
HEADER01]  
PS200@SOIC20 [(SA404)] PS200@SOIC20 (ISP) [ISP-  
HEADER01]  
PS200@SSOP20 [(SA626A)] PS200@SSOP20 (ISP) [ISP-  
HEADER01]  
rfPIC12C509AF@SSOP20 [(SA626A)]  
rfPIC12C509AF@SSOP20 (ISP) [ISP-HEADER01]  
rfPIC12C509AG@SOIC18 [(SA404)]  
rfPIC12C509AG@SOIC18 (ISP) [ISP-HEADER01]  
rfPIC12LC509AF@SSOP20 [(SA626A)]  
rfPIC12LC509AF@SSOP20 (ISP) [ISP-HEADER01]  
rfPIC12LC509AG@SOIC18 [(SA404)]  
rfPIC12LC509AG@SOIC18 (ISP) [ISP-HEADER01]

## MICRON

### E (E) PROM / FRAM / NVRAM

MT28F002B1VG-B@TSOP40 [(SA409T)] MT28F002B1VG-T@TSOP40  
[(SA409T)]  
MT28F002B3VG-B@TSOP40 [(SA409T)] MT28F002B3VG-T@TSOP40  
[(SA409T)]  
MT28F002B5VG-B@TSOP40 [(SA409T)] MT28F002B5VG-T@TSOP40  
[(SA409T)]  
MT28F002C1VG-T@TSOP40 [(SA409T)] MT28F002C5VG-T@TSOP40  
[(SA409T)]

MT28F002VG-B@TSOP40 [(SA409T)] MT28F002VG-T@TSOP40  
[(SA409T)]  
MT28F004B1VG-B@TSOP40 [(SA409T)] MT28F004B1VG-T@TSOP40  
[(SA409T)]  
MT28F004B3VG-B@TSOP40 [(SA409T)] MT28F004B3VG-T@TSOP40  
[(SA409T)]  
MT28F004B5VG-B@TSOP40 [(SA409T)] MT28F004B5VG-T@TSOP40  
[(SA409T)]  
MT28F004VG-B@TSOP40 [(SA409T)] MT28F004VG-T@TSOP40  
[(SA409T)]  
MT28F008B1VG-B@TSOP40 [(SA409T)] MT28F008B1VG-T@TSOP40  
[(SA409T)]  
MT28F008B3VG-B@TSOP40 [(SA409T)] MT28F008B3VG-T@TSOP40  
[(SA409T)]  
MT28F008B5VG-B@TSOP40 [(SA409T)] MT28F008B5VG-T@TSOP40  
[(SA409T)]  
MT28F016S3VG@TSOP40 [(SA409T)] MT28F016S5VG@TSOP40  
[(SA409T)]  
MT28F1284W18BQ@VFBGA56 [(SA656D-B085A-Y056F001Y)]  
MT28F1284W18TQ@VFBGA56 [(SA656D-B085A-Y056F001Y)]  
MT28F128J3A(FW203)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F128J3A(FW501)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F128J3A(FW502)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F128J3A(FW503)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F128J3A(INTEL)@TSOP56 [(SA628-B018)]  
MT28F128J3A(MICRON)@TSOP56 [(SA628-B018)]  
MT28F200B1SGB@PSOP44 [(SA638)] MT28F200B1SGT@PSOP44  
[(SA638)]  
MT28F200B1WGB@TSOP48 [(SA247-B005)]  
MT28F200B1WGT@TSOP48 [(SA247-B005)]  
MT28F200B3SGB@PSOP44 [(SA638)] MT28F200B3SGT@PSOP44  
[(SA638)]  
MT28F200B3WGB@TSOP48 [(SA247-B005)]  
MT28F200B3WGT@TSOP48 [(SA247-B005)]  
MT28F200B5SGB@PSOP44 [(SA638)] MT28F200B5SGT@PSOP44  
[(SA638)]  
MT28F200B5WGB@TSOP48 [(SA247-B005)]  
MT28F200B5WGT@TSOP48 [(SA247-B005)]  
MT28F320J3A(FW201)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F320J3A(FW204)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F320J3A(FW207)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F320J3A(FW208)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F320J3A(INTEL)@TSOP56 [(SA628-B018)]

MT28F320J3A(MICRON)@TSOP56 [(SA628-B018)]  
MT28F400B1SGB@PSOP44 [(SA638)] MT28F400B1SGT@PSOP44  
[(SA638)]  
MT28F400B1WGB@TSOP48 [(SA247-B005)]  
MT28F400B1WGT@TSOP48 [(SA247-B005)]  
MT28F400B3SGB@PSOP44 [(SA638)] MT28F400B3SGT@PSOP44  
[(SA638)]  
MT28F400B3WGB@TSOP48 [(SA247-B005)]  
MT28F400B3WGT@TSOP48 [(SA247-B005)]  
MT28F400B5SGB@PSOP44 [(SA638)] MT28F400B5SGT@PSOP44  
[(SA638)]  
MT28F400B5WGB@TSOP48 [(SA247-B005)]  
MT28F400B5WGT@TSOP48 [(SA247-B005)]  
MT28F640J3A(FW202)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW205)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW206)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW209)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW505)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW506)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(INTEL)@TSOP56 [(SA628-B018)]  
MT28F640J3A(MICRON)@TSOP56 [(SA628-B018)]  
MT28F800B1SGB@PSOP44 [(SA638)] MT28F800B1SGT@PSOP44  
[(SA638)]  
MT28F800B1WGB@TSOP48 [(SA247-B005)]  
MT28F800B1WGT@TSOP48 [(SA247-B005)]  
MT28F800B3SGB@PSOP44 [(SA638)] MT28F800B3SGT@PSOP44  
[(SA638)]  
MT28F800B3WGB@TSOP48 [(SA247-B005)]  
MT28F800B3WGT@TSOP48 [(SA247-B005)]  
MT28F800B5SGB@PSOP44 [(SA638)] MT28F800B5SGT@PSOP44  
[(SA638)]  
MT28F800B5WGB@TSOP48 [(SA247-B005)]  
MT28F800B5WGT@TSOP48 [(SA247-B005)]  
MT29F1G08ABAWP@TSOP48 [(SA247-B005)]  
MT29F2G08AAAWG@TSOP48 [(SA247-B005)]  
MT29F2G08AABWP@TSOP48 [(SA247-B005)]  
MT29F2G08AACWP@TSOP48 [(SA247-B005)]  
MT29F4G08AAAWP@TSOP48 [(SA247-B005)]  
MT29F4G08BAB@TSOP48 [(SA247-B005)]  
MT29F8G08DAA@TSOP48 [(SA247-B005)]

## DRAM & SRAM

MTSRAM@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]

## MICRONAS

### MICROCONTROLLER

SDA555XFL@SDIP52( \* ) [ ( SA627-B5603 ) ]

## MICRON-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

MT29F4G08AAWP ( sony ) @TSOP48 [ ( SA247+B005 ) ]

## MITSUBISHI

### E ( E ) PROM / FRAM / NVRAM

M5L27128K

M5L2716

M5L27256K

M5L2732

M5L2732A

M5L27512

M5L27512K

M5L2764K

M5L27C512A

M5M27128P

M5M27256P

M5M27512P

M5M2764P

M5M27C100K

M5M27C100K@PLCC32 [ ( SA015A1T ) ]

M5M27C100K@TSOP32

[ ( SA410T ) ]

M5M27C100P

M5M27C100P@PLCC32

[ ( SA015A1T ) ]

M5M27C100P@TSOP32 [ ( SA410T ) ]

M5M27C101JK

M5M27C101JK@PLCC32 [(SA015A1T)]	M5M27C101JK@TSOP32
[(SA410T)]	
M5M27C101K	M5M27C101K@PLCC32
[(SA015A1T)]	
M5M27C101K@TSOP32 [(SA410T)]	
M5M27C101P	
M5M27C101P@PLCC32 [(SA015A1T)]	M5M27C101P@TSOP32
[(SA410T)]	
M5M27C102K	M5M27C102K@PLCC44
[(SA244)]	
M5M27C102P	M5M27C102P@PLCC44
[(SA244)]	
M5M27C128K	
M5M27C201K	
M5M27C201K@PLCC32 [(SA015A1T)]	M5M27C201K@TSOP32
[(SA410T)]	
M5M27C202K	M5M27C202K@PLCC44
[(SA244)]	
M5M27C256(K)	M5M27C256
(P)	
M5M27C256A(FP)	M5M27C256A
(K)	
M5M27C256A(P)	
M5M27C401K	
M5M27C401K@PLCC32 [(SA015A1T)]	M5M27C401K@TSOP32
[(SA410T)]	
M5M27C402K	M5M27C512
(FP)	
M5M27C512A(FP)	M5M27C512A
(K)	
M5M27C512A(P)	
M5M28F101	
M5M28F101@PLCC32 [(SA015A1T)]	M5M28F101@SOP32
[(SA438T)]	
M5M28F101@TSOP32 [(SA410T)]	
M5M28F101A	
M5M28F101A@PLCC32 [(SA015A1T)]	M5M28F101A@SOIC32
[(SA438T)]	
M5M28F101A@TSOP32 [(SA410T)]	
M5M29FB160A@TSOP48 [(SA247-B005)]	
M5M29FB800(FP)@PSOP44 [(SA638)]	
M5M29FB800(VP)@TSOP48 [(SA247-B005)]	
M5M29FT160A@TSOP48 [(SA247-B005)]	

M5M29FT800 (FP)@PSOP44 [ (SA638) ]  
M5M29FT800 (VP)@TSOP48 [ (SA247-B005) ]  
M5M29GB160B (VP)@TSOP48 [ (SA247-B005) ]  
M5M29GB320 (VP)@TSOP48 [ (SA247-B005) ]  
M5M29GB320 (WG)@CBGA48 [ (SA642B-B026A-Y072F001) ]  
M5M29GT160B (VP)@TSOP48 [ (SA247-B005) ]  
M5M29GT320 (VP)@TSOP48 [ (SA247-B005) ]  
M5M29GT320 (WG)@CBGA48 [ (SA642B-B026A-Y072F001) ]  
M5M29JB160A@TSOP48 [ (SA247-B005) ]  
M5M29JT160A@TSOP48 [ (SA247-B005) ]  
M6M80011A [ (SA023A) ] M6M80011A@SOIC10  
M6M80011A@SOIC16 [ (SA023A) ]  
M6M80021 [ (SA023A) ] M6M80021@SOIC16  
M6M80021@SOIC10 [ (SA023A) ]  
M6M80041 [ (SA023A) ] M6M80041@SOIC10  
M6MG3B641S16TP@TSOP52 [ (SA657-B036) ]  
M6MG3T641S16TP@TSOP52 [ (SA657-B036) ]  
M6MGB321S4TP@TSOP52 [ (SA657-B036) ]  
M6MGB321S8TP@TSOP52 [ (SA657-B036) ]  
M6MGB32BS4WG@CSP66 [ (SA642F-B023A-T064F001) ]  
M6MGB32BS8WG@CSP66 [ (SA642F-B023A-T064F001) ]  
M6MGB331S8KT@TSOP52 [ (SA657-B036) ]  
M6MGB33BS8AWG@CSP66 [ (SA642F-B023A-T064F001) ]  
M6MGB641S16TP@TSOP52 [ (SA657-B036) ]  
M6MGB641S4TP@TSOP52 [ (SA657-B036) ]  
M6MGB641S8TP@TSOP52 [ (SA657-B036) ]  
M6MGB64BS4WG@CSP67 [ (SA642F-B023A-T064F001) ]  
M6MGB64BS8WG@CSP67 [ (SA642F-B023A-T064F001) ]  
M6MGD137W33 (WG)@CSP72 [ (SA642F-B056A-T064F001) ]  
M6MGE157S4KT@TSOP52 [ (SA657-B055) ]  
M6MGT321S4TP@TSOP52 [ (SA657-B036) ]  
M6MGT321S8TP@TSOP52 [ (SA657-B036) ]  
M6MGT32BS4WG@CSP66 [ (SA642F-B023A-T064F001) ]  
M6MGT32BS8WG@CSP66 [ (SA642F-B023A-T064F001) ]  
M6MGT331S8KT@TSOP52 [ (SA657-B036) ]  
M6MGT33BS8AWG@CSP66 [ (SA642F-B023A-T064F001) ]  
M6MGT641S16TP@TSOP52 [ (SA657-B036) ]  
M6MGT641S4TP@TSOP52 [ (SA657-B036) ]  
M6MGT641S8TP@TSOP52 [ (SA657-B036) ]  
M6MGT64BS4WG@CSP67 [ (SA642F-B023A-T064F001) ]



M6MGT64BS8WG@CSP67 [ (SA642F-B023A-T064F001) ]

## MICROCONTROLLER

M30240ECFP@QFP80 (Renesas) [ (PCA7302E1F-80) ]  
M30620ECFP@QFP100 (Renesas) [ (PCA7412F-100) ]  
M30620ECFS@QFN100 (Renesas) [ (PCA7412L-100) ]  
M30620ECGP@LQFP100 (Renesas) [ (PCA7412G-100) ]  
M30621ECGP@QFP80 (Renesas) [ (PCA7413F-80) ]  
M30622ECTFP@QFP100 (Renesas) [ (PCA7412F-100) ]  
M30623ECTGP@QFP80 (Renesas) [ (PCA7413F-80) ]  
M306V0EEFP@QFP100 (Renesas) [ (PCA7412F-100) ]  
M306V0EEFS@QFN100 (Renesas) [ (PCA7412L-100) ]  
M306V2EEFP@QFP100 (Renesas) [ (PCA7412F-100) ]  
M306V2EEFS@QFN100 (Renesas) [ (PCA7412L-100) ]  
M34282E2GP [ (SA026) ] M34283G2GP  
[ (SA026) ]  
M34283G2GP (ISP) [ ISP-HEADER01 ]  
M34513E4FP@LQFP32 (Renesas) [ (PCA7442FPG02) ]  
M34513E4SP@SDIP32 (Renesas) [ (PCA7442SP) ]  
M34513E8FP@LQFP32 (Renesas) [ (PCA7442FPG02) ]  
M34514E8FP@SSOP42 (Renesas) [ (PCA7441) ]  
M34518E8FP@LQFP32 (Renesas) [ (PCA7442FPG02) ]  
M34518E8SP@SDIP32 (Renesas) [ (PCA7442SP) ]  
M34519E8FP@SSOP42 (Renesas) [ (PCA7441) ]  
M34524EDFP@QFP64 (Renesas) [ (PCA7448) ]  
M34551E8FP@QFP48 (Renesas) [ (PCA7414) ]  
M34554EDFP@QFP64 (Renesas) [ (PCA7448) ]  
M34570E8FP@SSOP36 (Renesas) [ (PCA7425) ]  
M34570EDFP@SSOP36 (Renesas) [ (PCA7425) ]  
M34583EDFP@LQFP32 (Renesas) [ (PCA7442FPG02) ]  
M34584EDFP@SSOP42 (Renesas) [ (PCA7441) ]  
M37150EFFP@SSOP42 (Renesas) [ (PCA7450FP) ]  
M37151EFFP@SSOP42 (Renesas) [ (PCA7450FP) ]  
M37160EFFP@SSOP42 (Renesas) [ (PCA7450FP) ]  
M37161EFFP@SSOP42 (Renesas) [ (PCA7450FP) ]  
M37516E6HKP@QFN44 (Renesas) [ (PCA7446) ]  
M37516E6HP@LQFP48 (Renesas) [ (PCA7419) ]  
M37540E2FP@SSOP36 (Renesas) [ (PCA7435FPG02) ]  
M37540E2GP@LQFP32 (Renesas) [ (PCA7435GPG03) ]  
M37540E2SP@SDIP32 (Renesas) [ (PCA7435SPG02) ]  
M37540E8FP@SSOP36 (Renesas) [ (PCA7435FPG02) ]

M37540E8GP@LQFP32 (Renesas) [(PCA7435GPG03)]  
M37540E8SP@SDIP32 (Renesas) [(PCA7435SPG02)]  
M37544G2A(GP)@LQFP32 [(SA663)]  
M37544G2A(GP)@LQFP32 (ISP) [ISP-HEADER01]  
M37544G2A(SP)@SDIP32 [(SA653)]  
M37544G2A(SP)@SDIP32 (ISP) [ISP-HEADER01]  
M37545G4(GP)@LQFP32 [(SA663)] M37545G6(GP)@LQFP32  
[(SA663)]  
M37545G8(GP)@LQFP32 [(SA663)] M37546G2(FP)@SSOP36  
[(SA645)]  
M37546G2(FP)@SSOP36 (ISP) [ISP-HEADER01]  
M37546G2(GP)@LQFP32 [(SA663)]  
M37546G2(GP)@LQFP32 (ISP) [ISP-HEADER01]  
M37546G2(SP)@SDIP32 [(SA653)]  
M37546G2(SP)@SDIP32 (ISP) [ISP-HEADER01]  
M37546G4(FP)@SSOP36 [(SA645)]  
M37546G4(FP)@SSOP36 (ISP) [ISP-HEADER01]  
M37546G4(GP)@LQFP32 [(SA663)]  
M37546G4(GP)@LQFP32 (ISP) [ISP-HEADER01]  
M37546G4(SP)@SDIP32 [(SA653)]  
M37546G4(SP)@SDIP32 (ISP) [ISP-HEADER01]  
M37547G2(FP)@SSOP36 [(SA645)]  
M37547G2(FP)@SSOP36 (ISP) [ISP-HEADER01]  
M37547G4(FP)@SSOP36 [(SA645)]  
M37547G4(FP)@SSOP36 (ISP) [ISP-HEADER01]  
M37548G1(FP)@TSSOP20 [(SA026)] M37548G2(FP)@TSSOP20  
[(SA026)]  
M37548G3(FP)@TSSOP20 [(SA026)] M37549G1FP@SSOP24  
[(SA711)]  
M37549G2FP@SSOP24 [(SA711)] M37549G3FP@SSOP24  
[(SA711)]  
M37560EFDFP@QFP100 (Renesas) [(PCA4738F-100A)]  
M37560EFFP@QFN100 (Renesas) [(PCA4738L-100A)]  
M37560EFFP@QFP100 (Renesas) [(PCA4738F-100A)]  
M37560EFGP@LQFP100 (Renesas) [(PCA4738G-100A)]  
M37630E4FP@QFP44 (Renesas) [(PCA7430)]  
M37630E4FS@QFN80 (Renesas) [(PCA7431)]  
M37640E8FP@QFP80 (Renesas) [(PCA7440FP)]  
M37640E8FS@QFN80 (Renesas) [(PCA7440FS)]  
M37733EHBFP@QFP80 (Renesas) [(PCA4774G05)]  
M37733EHBFS@QFN80 (Renesas) [(PCA4708G05)]  
M37735EHBFP@QFP80 (Renesas) [(PCA4774G05)]  
M37735EHBFS@QFN80 (Renesas) [(PCA4708G05)]

M37736EHBGP@QFP100(Renesas) [(PCA7422GPG02)]  
M37736EHBGS@QFN100(Renesas) [(PCA7422GSG02)]  
M37751E6CFP@QFP80(Renesas) [(PCA4774G05)]  
M37751E6CFS@QFN80(Renesas) [(PCA4708G05)]  
M37751F6CFP@QFP80(Renesas) [(PCA4774G05)]  
M38027E8DFP@QFP64(Mitsubishi) [(PCA4738F-64A)]  
M38027E8DSP@DIP64(Mitsubishi) [(BBBB)]  
M38027E8DXXXFP@QFP64(Mitsubishi) [(PCA4738F-64A)]  
M38027E8DXXXSP@DIP64(Mitsubishi) [(BBBB)]  
M38027E8FS@LCC64(Mitsubishi) [(BBBB)]  
M38027E8SP@DIP64(Mitsubishi) [(BBBB)]  
M38027E8SS@DIP64(Mitsubishi) [(BBBB)]  
M38027E8-XXXFP@QFP64(Mitsubishi) [(PCA4738F-64A)]  
M38027E8-XXXSP@DIP64(Mitsubishi) [(BBBB)]  
M38027M8-XXXFP@QFP64(Mitsubishi) [(PCA4738F-64A)]  
M38039FFFP@QFP64(Renesas) [(PCA4738FF-64)]  
M38039FFHP@LQFP64(Renesas) [(PCA4738HF-64)]  
M38039FFSP@SDIP64(Renesas) [(PCA4738SF-64)]  
M38049FFFP@QFP64(Renesas) [(PCA4738FF-64)]  
M38049FFHP@LQFP64(Renesas) [(PCA4738HF-64)]  
M38049FFSP@SDIP64(Renesas) [(PCA4738SF-64)]  
M38223E4FP@QFP80(Renesas) [(PCA4738F-80A)]  
M38223E4FS@QFN80(Renesas) [(PCA4738L-80A)]  
M38223E4GP@QFP80(Renesas) [(PCA4738G-80A)]  
M38223E4HP@LQFP80(Renesas) [(PCA4738H-80A)]  
M38227ECFP@QFP80(Renesas) [(PCA4738F-80A)]  
M38227ECFS@QFN80(Renesas) [(PCA4738L-80A)]  
M38227ECHP@LQFP80(Renesas) [(PCA4738H-80A)]  
M38267E8FP@QFP100(Renesas) [(PCA4738F-100A)]  
M38267E8GP@LQFP100(Renesas) [(PCA4738G-100A)]  
M3826AEFFP@QFP100(Renesas) [(PCA4738F-100A)]  
M3826AEFFS@QFN100(Renesas) [(PCA4738L-100A)]  
M3826AEFGP@LQFP100(Renesas) [(PCA4738G-100A)]  
M38504E6FP@SSOP42(Renesas) [(PCA4738F-42A)]  
M38504E6SP@SDIP42(Renesas) [(PCA4738S-42A)]  
M38504E6SS@SDIP42(Renesas) [(PCA4738S-42A)]  
M38514E6FP@SSOP42(Renesas) [(PCA4738F-42A)]  
M38514E6SP@SDIP42(Renesas) [(PCA4738S-42A)]  
M38514E6SS@SDIP42(Renesas) [(PCA4738S-42A)]  
M38867E8AFS@QFN80(Renesas) [(PCA4738L-80A)]  
M38867E8AHP@LQFP80(Renesas) [(PCA4738H-80A)]  
M38869FFAGP@QFP80(Renesas) [(PCA4738GF-80)]  
M38869FFAHP@LQFP80(Renesas) [(PCA4738HF-80)]

M38B79FFFP@QFP100(Renesas) [(PCA7438FF-100)]  
M38C13E6FP@LQFP64(Renesas) [(PCA7438F-64A)]  
M38C13E6HP@QFP64(Renesas) [(PCA7438H-64A)]  
M38C89EFFP@LQFP144(Renesas) [(PCA7447FP)]  
R5F21102DFP@TQFP32 [(SA663+B005)]  
R5F21102DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21102FP@TQFP32 [(SA663+B005)]  
R5F21102FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21103DFP@TQFP32 [(SA663+B005)]  
R5F21103DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21103FP@TQFP32 [(SA663+B005)]  
R5F21103FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21104DFP@TQFP32 [(SA663+B005)]  
R5F21104DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21104FP@TQFP32 [(SA663+B005)]  
R5F21104FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21112DFP@TQFP32 [(SA663+B005)]  
R5F21112DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21112FP@TQFP32 [(SA663+B005)]  
R5F21112FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21113DFP@TQFP32 [(SA663+B005)]  
R5F21113DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21113FP@TQFP32 [(SA663+B005)]  
R5F21113FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21114DFP@TQFP32 [(SA663+B005)]  
R5F21114DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21114FP@TQFP32 [(SA663+B005)]  
R5F21114FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21122DFP@TQFP32 [(SA663+B005)]  
R5F21122DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21122FP@TQFP32 [(SA663+B005)]  
R5F21122FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21123DFP@TQFP32 [(SA663+B005)]  
R5F21123DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21123FP@TQFP32 [(SA663+B005)]  
R5F21123FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21124DFP@TQFP32 [(SA663+B005)]  
R5F21124DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21124FP@TQFP32 [(SA663+B005)]  
R5F21124FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21132DFP@TQFP32 [(SA663+B005)]  
R5F21132DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21132FP@TQFP32 [(SA663+B005)]

R5F21132FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133DFP@TQFP32 [(SA663+B005)]  
R5F21133DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133FP@TQFP32 [(SA663+B005)]  
R5F21133FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21134DFP@TQFP32 [(SA663+B005)]  
R5F21134DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21134FP@TQFP32 [(SA663+B005)]  
R5F21134FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20 [(SA725-B005)]  
R5F21181DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20(single wire) [(SA725-B005)]  
R5F21181DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21181DSP@TSSOP20 [(SA026-B001)]  
R5F21181DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21181DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21181DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21181SP@TSSOP20 [(SA026-B001)]  
R5F21181SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21181SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182DD@SDIP20 [(SA725-B005)]  
R5F21182DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(single wire) [(SA725-B005)]  
R5F21182DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21182DSP@TSSOP20 [(SA026-B001)]  
R5F21182DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21182DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182NP@QFN28 [(SA697-B006)]  
R5F21182NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(single wire) [(SA697-B006)]  
R5F21182NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(UART mode) [(SA697+B006)]  
R5F21182SP@TSSOP20 [(SA026-B001)]  
R5F21182SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21182SP@TSSOP20(UART ISP) [ISP-HEADER01]

R5F21182SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183DD@SDIP20 [(SA725-B005)]  
R5F21183DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(single wire) [(SA725-B005)]  
R5F21183DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21183DSP@TSSOP20 [(SA026-B001)]  
R5F21183DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21183DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183NP@QFN28 [(SA697-B006)]  
R5F21183NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(single wire) [(SA697-B006)]  
R5F21183NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(UART mode) [(SA697+B006)]  
R5F21183SP@TSSOP20 [(SA026-B001)]  
R5F21183SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21183SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184DD@SDIP20 [(SA725-B005)]  
R5F21184DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(single wire) [(SA725-B005)]  
R5F21184DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21184DSP@TSSOP20 [(SA026-B001)]  
R5F21184DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F21184DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184NP@QFN28 [(SA697-B006)]  
R5F21184NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(single wire) [(SA697-B006)]  
R5F21184NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(UART mode) [(SA697+B006)]  
R5F21184SP@TSSOP20 [(SA026-B001)]  
R5F21184SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(single wire) [(SA026-B001)]  
R5F21184SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191DD@SDIP20 [(SA725-B005)]  
R5F21191DD@SDIP20(single ISP) [ISP-HEADER01]

R5F21191DD@SDIP20(single wire) [(SA725+B005)]  
R5F21191DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21191DSP@TSSOP20 [(SA026-B001)]  
R5F21191DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191SP@TSSOP20 [(SA026-B001)]  
R5F21191SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192DD@SDIP20 [(SA725-B005)]  
R5F21192DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(single wire) [(SA725+B005)]  
R5F21192DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21192DSP@TSSOP20 [(SA026-B001)]  
R5F21192DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192NP@QFN28 [(SA697-B006)]  
R5F21192NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(single wire) [(SA697+B006)]  
R5F21192NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(UART mode) [(SA697+B006)]  
R5F21192SP@TSSOP20 [(SA026-B001)]  
R5F21192SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193DD@SDIP20 [(SA725-B005)]  
R5F21193DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(single wire) [(SA725+B005)]  
R5F21193DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21193DSP@TSSOP20 [(SA026-B001)]  
R5F21193DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(UART mode) [(SA026+B001)]

R5F21193NP@QFN28 [(SA697-B006)]  
R5F21193NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(single wire) [(SA697+B006)]  
R5F21193NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(UART mode) [(SA697+B006)]  
R5F21193SP@TSSOP20 [(SA026-B001)]  
R5F21193SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194DD@SDIP20 [(SA725-B005)]  
R5F21194DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(single wire) [(SA725+B005)]  
R5F21194DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21194DSP@TSSOP20 [(SA026-B001)]  
R5F21194DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194NP@QFN28 [(SA697-B006)]  
R5F21194NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(single wire) [(SA697+B006)]  
R5F21194NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(UART mode) [(SA697+B006)]  
R5F21194SP@TSSOP20 [(SA026-B001)]  
R5F21194SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1DD@SDIP20 [(SA725-B005)]  
R5F211A1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A1DSP@TSSOP20 [(SA026-B001)]  
R5F211A1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1SP@TSSOP20 [(SA026-B001)]  
R5F211A1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(single wire) [(SA026-B001)]



R5F211A1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2DD@SDIP20 [(SA725-B005)]  
R5F211A2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A2DSP@TSSOP20 [(SA026-B001)]  
R5F211A2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2NP@QFN28 [(SA697-B006)]  
R5F211A2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(single wire) [(SA697-B006)]  
R5F211A2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A2SP@TSSOP20 [(SA026-B001)]  
R5F211A2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3DD@SDIP20 [(SA725-B005)]  
R5F211A3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A3DSP@TSSOP20 [(SA026-B001)]  
R5F211A3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3NP@QFN28 [(SA697-B006)]  
R5F211A3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(single wire) [(SA697-B006)]  
R5F211A3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A3SP@TSSOP20 [(SA026-B001)]  
R5F211A3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4DD@SDIP20 [(SA725-B005)]

R5F211A4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(single wire) [(SA725-B005)]  
R5F211A4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A4DSP@TSSOP20 [(SA026-B001)]  
R5F211A4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4NP@QFN28 [(SA697-B006)]  
R5F211A4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(single wire) [(SA697-B006)]  
R5F211A4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A4SP@TSSOP20 [(SA026-B001)]  
R5F211A4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(single wire) [(SA026-B001)]  
R5F211A4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1DD@SDIP20 [(SA725-B005)]  
R5F211B1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B1DSP@TSSOP20 [(SA026-B001)]  
R5F211B1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1SP@TSSOP20 [(SA026-B001)]  
R5F211B1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2DD@SDIP20 [(SA725-B005)]  
R5F211B2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B2DSP@TSSOP20 [(SA026-B001)]  
R5F211B2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2DSP@TSSOP20(UART ISP) [ISP-HEADER01]

R5F211B2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2NP@QFN28 [(SA697-B006)]  
R5F211B2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(single wire) [(SA697+B006)]  
R5F211B2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B2SP@TSSOP20 [(SA026-B001)]  
R5F211B2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3DD@SDIP20 [(SA725-B005)]  
R5F211B3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B3DSP@TSSOP20 [(SA026-B001)]  
R5F211B3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3NP@QFN28 [(SA697-B006)]  
R5F211B3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(single wire) [(SA697+B006)]  
R5F211B3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B3SP@TSSOP20 [(SA026-B001)]  
R5F211B3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4DD@SDIP20 [(SA725-B005)]  
R5F211B4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B4DSP@TSSOP20 [(SA026-B001)]  
R5F211B4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4NP@QFN28 [(SA697-B006)]  
R5F211B4NP@QFN28(single ISP) [ISP-HEADER01]

R5F211B4NP@QFN28(single wire) [(SA697+B006)]  
R5F211B4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B4SP@TSSOP20 [(SA026-B001)]  
R5F211B4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21206JFP@TQFP48 [(SA248-B005)]  
R5F21206JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21206JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21206KFP@TQFP48 [(SA248-B005)]  
R5F21206KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21206KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21207JFP@TQFP48 [(SA248-B005)]  
R5F21207JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21207JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21207KFP@TQFP48 [(SA248-B005)]  
R5F21207KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21207KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21208JFP@TQFP48 [(SA248-B005)]  
R5F21208JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21208JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21208KFP@TQFP48 [(SA248-B005)]  
R5F21208KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21208KFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120AJFP@TQFP48 [(SA248-B005)]  
R5F2120AJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120AJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120AKFP@TQFP48 [(SA248-B005)]  
R5F2120AKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120AKFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120CJFP@TQFP48 [(SA248-B005)]  
R5F2120CJFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120CJFP@TQFP48(single wire) [(SA248-B005)]  
R5F2120CKFP@TQFP48 [(SA248-B005)]  
R5F2120CKFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F2120CKFP@TQFP48(single wire) [(SA248-B005)]  
R5F21216JFP@TQFP48 [(SA248-B005)]  
R5F21216JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21216JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21216KFP@TQFP48 [(SA248-B005)]  
R5F21216KFP@TQFP48(single ISP) [ISP-HEADER01]

R5F21216KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21217JFP@TQFP48 [(SA248-B005)]  
R5F21217JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21217JFP@TQFP48(single wire) [(SA248-B005)]  
R5F21217KFP@TQFP48 [(SA248-B005)]  
R5F21217KFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21217KFP@TQFP48(single wire) [(SA248-B005)]  
R5F21218JFP@TQFP48 [(SA248-B005)]  
R5F21218JFP@TQFP48(single ISP) [ISP-HEADER01]  
R5F21218JFP