

## DEVICE LIST 7/16/2008

Total Manufacturers 189

Total Devices 39005

<a href="#">ABOV</a>	<a href="#">ACT</a>	<a href="#">ACTRANS</a>	
<a href="#">ADI</a>			
<a href="#">ADVANCE GROUP (ISP)</a>	<a href="#">ALI(Acer)</a>	<a href="#">ALL 24 SERIES</a>	
<a href="#">ALLIANCE</a>	<a href="#">ALTERA</a>	<a href="#">AMD</a>	
<a href="#">AMI SEMICONDUCTOR</a>		<a href="#">AMIC</a>	
<a href="#">ANACHIP</a>			
<a href="#">APLUS FLASH</a>	<a href="#">ARTSCHIP</a>	<a href="#">ASAHI KASEI(AKM)</a>	
<a href="#">ASD</a>			
<a href="#">ASI</a>	<a href="#">ASP</a>	<a href="#">ATC</a>	
<a href="#">ATMEL</a>			
<a href="#">ATMEL W&amp;M</a>	<a href="#">ATMEL-CUSTOMER</a>	<a href="#">AUSTIN</a>	<a href="#">BELLING-</a>
<a href="#">SYSTRON</a>			
<a href="#">BENCHMARQ</a>	<a href="#">BMT</a>	<a href="#">BOSEN</a>	
<a href="#">BRIGHT</a>			
<a href="#">CATALYST</a>	<a href="#">CERAMATE</a>	<a href="#">CHINA CORE</a>	
<a href="#">CHINGIS</a>			
<a href="#">CHIPCON</a>	<a href="#">CHIPSWINNER</a>	<a href="#">CORERIVER</a>	
<a href="#">CWI</a>			
<a href="#">CYGNAL</a>	<a href="#">CYPRESS</a>	<a href="#">DALLAS</a>	<a href="#">DENSE-</a>
<a href="#">PAC</a>			
<a href="#">DEUTRON</a>	<a href="#">EFST</a>	<a href="#">ELECTRONIC</a>	
<a href="#">ARRAYS</a>			
<a href="#">ELPIDA</a>	<a href="#">EM</a>	<a href="#">EMTC</a>	
<a href="#">EON</a>			
<a href="#">EPSON</a>	<a href="#">ESMT</a>	<a href="#">EXCELSEMI</a>	
<a href="#">EXEL</a>			
<a href="#">FAIRCHILD</a>	<a href="#">FORCE TECHNOLOGIES</a>		
<a href="#">FORWARD</a>			

<a href="#">FREESCALE</a>	<a href="#">Fremont Micro Devices</a>		
<a href="#">FUJITSU</a>			
<a href="#">GENCORE</a>	<a href="#">GENERAL (GI)</a>	<a href="#">GENERIC</a>	
<a href="#">GOAL</a>			
<a href="#">GREENWICH</a>	<a href="#">HAIER</a>	<a href="#">HARRIS</a>	
<a href="#">HITACHI</a>			
<a href="#">HOLTEK</a>	<a href="#">HONGKONG</a>	<a href="#">HYNIX</a>	<a href="#">HYNIX-</a>
<a href="#">CUSTOMER</a>			
<a href="#">HYUNDAI</a>	<a href="#">ICE</a>	<a href="#">ICMIC</a>	
<a href="#">ICSI</a>			
<a href="#">ICT</a>	<a href="#">IMT</a>	<a href="#">INFINEON</a>	
<a href="#">INTEL</a>			
<a href="#">INTEL-CUSTOMER</a>	<a href="#">INTELSIL</a>	<a href="#">ISSI</a>	
<a href="#">ITHINKO</a>			
<a href="#">LATTICE</a>	<a href="#">LG Semicon</a>	<a href="#">LINKSMART</a>	
<a href="#">MACRONIX</a>			
<a href="#">MAGNACHIP</a>	<a href="#">MAXIM</a>	<a href="#">MAXWELL</a>	
<a href="#">MEGAWIN</a>			
<a href="#">MEMOCOM</a>	<a href="#">MICON</a>	<a href="#">MICROCHIP</a>	
<a href="#">MICRON</a>			
<a href="#">MICRONAS</a>	<a href="#">MICRON-CUSTOMER</a>	<a href="#">MITSUBISHI</a>	<a href="#">MOSEL-</a>
<a href="#">VITELIC</a>			
<a href="#">MOSTEK</a>	<a href="#">MOTOROLA</a>	<a href="#">MYSON</a>	<a href="#">MYSON-</a>
<a href="#">CUSTOMER</a>			
<a href="#">NEC</a>	<a href="#">NEXFLASH</a>	<a href="#">NJRC</a>	
<a href="#">NOVATEK</a>			
<a href="#">NSC</a>	<a href="#">NTE</a>	<a href="#">NUMONYX</a>	
<a href="#">NXP</a>			
<a href="#">OKI</a>	<a href="#">PARALLAX</a>	<a href="#">PFLASH (MSTAR)</a>	
<a href="#">PHILIPS</a>			
<a href="#">PJ</a>	<a href="#">PMC</a>	<a href="#">POLYSTAK</a>	
<a href="#">PSS</a>			
<a href="#">PTC</a>	<a href="#">QIXIN</a>	<a href="#">Quick Pulse</a>	
<a href="#">RAMTRON</a>			
<a href="#">RATO</a>	<a href="#">RAYDIUM</a>	<a href="#">RENESAS</a>	
<a href="#">RICOH</a>			
<a href="#">ROCKWELL</a>	<a href="#">ROHM</a>	<a href="#">SAIFUN</a>	
<a href="#">SAMSUNG</a>			

<a href="#"><u>SAMSUNG-CUSTOMER</u></a>	<a href="#"><u>SANYO</u></a>	<a href="#"><u>SCENIX</u></a>	
<a href="#"><u>SEEQ</u></a>			
<a href="#"><u>SEIKO</u></a>	<a href="#"><u>SGS-THOMSON</u></a>	<a href="#"><u>SHARP</u></a>	<a href="#"><u>SHARP-</u></a>
<a href="#"><u>CUSTOMER</u></a>			
<a href="#"><u>SIEMENS</u></a>	<a href="#"><u>SIGNETICS</u></a>	<a href="#"><u>Silicon</u></a>	
<a href="#"><u>Laboratories</u></a>			
<a href="#"><u>SILICON7</u></a>	<a href="#"><u>SIMTEK</u></a>	<a href="#"><u>SIRF</u></a>	
<a href="#"><u>SMOS</u></a>			
<a href="#"><u>SONIX</u></a>	<a href="#"><u>SONY</u></a>	<a href="#"><u>SPACE ELECTRONICS</u></a>	
<a href="#"><u>[SEi]</u></a>			
<a href="#"><u>SPANSION</u></a>	<a href="#"><u>SPANSION-CUSTOMER</u></a>		
<a href="#"><u>SSSC</u></a>			
<a href="#"><u>SST</u></a>	<a href="#"><u>ST</u></a>	<a href="#"><u>STC</u></a>	<a href="#"><u>ST-</u></a>
<a href="#"><u>CUSTOMER</u></a>			
<a href="#"><u>SUMMIT</u></a>	<a href="#"><u>SUNPLUS</u></a>	<a href="#"><u>SYNCMOS</u></a>	
<a href="#"><u>SYNERTEK</u></a>			
<a href="#"><u>SYNTEK</u></a>	<a href="#"><u>TECHCODE</u></a>	<a href="#"><u>TEKMOS</u></a>	
<a href="#"><u>TEMIC</u></a>			
<a href="#"><u>TEST-LOGIC</u></a>	<a href="#"><u>TI</u></a>	<a href="#"><u>TMC</u></a>	
<a href="#"><u>TOPRO</u></a>			
<a href="#"><u>TOSHIBA</u></a>	<a href="#"><u>TOSHIBA-CUSTOMER</u></a>	<a href="#"><u>TURBO IC</u></a>	
<a href="#"><u>UBICOM</u></a>			
<a href="#"><u>UMC</u></a>	<a href="#"><u>UTRON</u></a>	<a href="#"><u>VANTIS</u></a>	
<a href="#"><u>VERSACHIPS</u></a>			
<a href="#"><u>VLSI</u></a>	<a href="#"><u>WELTREND</u></a>	<a href="#"><u>WHITE ELECTRONIC</u></a>	
<a href="#"><u>DESIGNS</u></a>			
<a href="#"><u>WINBOND</u></a>	<a href="#"><u>WISTRON</u></a>	<a href="#"><u>WSI</u></a>	
<a href="#"><u>XELTEK</u></a>			
<a href="#"><u>XICOR</u></a>	<a href="#"><u>XILINX</u></a>	<a href="#"><u>XILINX-CUSTOMER</u></a>	
<a href="#"><u>YMC</u></a>			
<a href="#"><u>YSS</u></a>	<a href="#"><u>ZILOG</u></a>	<a href="#"><u>ZMD</u></a>	

**ABOV**

**MICROCONTROLLER**

MC80F0104 +B003 ]	MC80F0104@SOP16 [ (SA404
MC80F0104@TSSOP16 [ (SA026) ]	
MC80F0204	
MC80F0204@SOP20 [ (SA404+B003) ]	MC80F0208@MQFP44 [ (SA675-
B005) ]	
MC80F0208@SDIP42 [ (SA028) ]	MC80F0216@MQFP44 [ (SA675-
B005) ]	
MC80F0216@SDIP42 [ (SA028) ]	MC80F0224@MQFP44 [ (SA675-
B005) ]	
MC80F0224@SDIP42 [ (SA028) ]	
MC80F0304	
MC80F0304@SOP28 [ (SA404+B003) ]	
MC80F0308	
MC80F0308@SOP28 [ (SA404+B003) ]	
MC80F0316	
MC80F0316@SOP28 [ (SA404+B003) ]	
MC80F0424K@SDIP64(*) [ (SA752+B290) ]	
MC80F0424L@LQFP64(*) [ (SA732+B291) ]	
MC80F0424Q@MQFP64(*) [ (SA758+B289) ]	
MC80F0432K@SDIP64(*) [ (SA752+B290) ]	
MC80F0432L@LQFP64(*) [ (SA732+B291) ]	
MC80F0432Q@MQFP64(*) [ (SA758+B289) ]	
MC80F0448K@SDIP64(*) [ (SA752+B292) ]	
MC80F0448L@LQFP64(*) [ (SA732+B291) ]	
MC80F0448Q@MQFP64(*) [ (SA758+B289) ]	
MC80F0504 [ (SA715) ]	MC80F0504@SOP16
MC80F0504@SSOP16 [ (SA626A) ]	
MC80F0504[153mil]@SOP16 [ (SA602) ]	
MC80F0604 [ (SA715) ]	MC80F0604@SOP20
MC80F0604@SSOP20 [ (SA626A) ]	
MC80F0704	
MC80F0704@QFN28 [ (SA697) ]	MC80F0704@SOP28
[ (SA715) ]	
MC80F0708 [ (SA697) ]	MC80F0708@QFN28
MC80F0708@SOP28 [ (SA715) ]	
[ (SA653) ]	MC80F0804@SDIP32
MC80F0804@SOP32 [ (SA715) ]	
[ (SA653) ]	MC80F0808@SDIP32
MC80F0808@SOP32 [ (SA715) ]	
	MC80F7108@TQFP44 [ (SA675-

B005) ]  
 MC80F7308@SDIP42 [ (SA028) ]  
 B005) ]

MC80F7408@TQFP44 [ (SA675-

## ACT

### E (E) PROM/FRAM/NVRAM

93LC46(08bit) [ (SA602A) ]	93LC46(08bit)@SOIC8
93LC46(16bit) [ (SA602A) ]	93LC46(16bit)@SOIC8
93LC56(08bit) [ (SA602A) ]	93LC56(08bit)@SOIC8
93LC56(16bit) [ (SA602A) ]	93LC56(16bit)@SOIC8
93LC66(08bit) [ (SA602A) ]	93LC66(08bit)@SOIC8
93LC66(16bit) [ (SA602A) ]	93LC66(16bit)@SOIC8
93LC86(08bit) [ (SA602A) ]	93LC86(08bit)@SOIC8
93LC86(16bit) [ (SA602A) ]	93LC86(16bit)@SOIC8

## ACTTRANS

### E (E) PROM/FRAM/NVRAM

AC25010@SOIC8 [ (SA602A) ] [ (SA602A) ]	AC25512@SOIC8
AC25LC010@SOIC8 [ (SA602A) ] [ (SA602A) ]	AC25LC512@SOIC8
AC39LV010@FBGA48 [ (SA642B-B026A-Y072F001) ]	
AC39LV010@PLCC32 [ (SA015A1T) ] [ (SA620) ]	AC39LV010@VSOP32
AC39LV020@FBGA48 [ (SA642B-B026A-Y072F001) ]	
AC39LV020@PLCC32 [ (SA015A1T) ] [ (SA620) ]	AC39LV020@VSOP32
AC39LV040@PLCC32 [ (SA015A1T) ]	AC39LV040@VSOP32

[ (SA620) ]  
 AC39LV080@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AC39LV080@TSOP40 [ (SA409T) ] AC39LV088@TSOP48 [ (SA247-B005) ]  
 AC39LV512@PLCC32 [ (SA015A1T) ] AC39LV512@VSOP32  
 [ (SA620) ]  
 AC39VF800@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AC39VF800@TSOP48 [ (SA247-B005) ]

## ADI

### MICROCONTROLLER

ADE7166F16@LQFP64(\*) [ (SA732+B237) ]  
 ADE7169F16@LQFP64(\*) [ (SA732+B237) ]  
 ADE7566F16@LQFP64(\*) [ (SA732+B237) ]  
 ADE7569F16@LQFP64(\*) [ (SA732+B237) ]  
 ADM1026@LQFP48 [ (SA248+B005) ] ADM1062@LFCSP40 [ (SA750+B006) ]  
 ADM1062@LQFP48 [ (SA248+B005) ] ADM1066@LFCSP40 [ (SA750+B006) ]  
 ADM1066@LQFP48 [ (SA248+B005) ] ADUC814@SSOP28 [ (SA643+B005) ]  
 ADuC831BCP@LFCSP56 [ (SA706+B296) ]  
 ADuC831BS@MQFP52 [ (SA662+B042) ]  
 ADuC832BCP@LFCSP56 [ (SA706+B296) ]  
 ADuC832BS@MQFP52 [ (SA662+B042) ]  
 ADuC834BCP@LFCSP56 [ (SA706+B296) ]  
 ADuC834BS@MQFP52 [ (SA662+B042) ]  
 ADuC836BCP@LFCSP56 [ (SA706+B296) ]  
 ADuC836BS@MQFP52 [ (SA662+B042) ]  
 ADuC841BCP62@LFCSP56 [ (SA706+B296) ]  
 ADuC841BS62@MQFP52 [ (SA662+B042) ]  
 ADuC842BCP62@LFCSP56 [ (SA706+B296) ]  
 ADuC842BS62@MQFP52 [ (SA662+B042) ]  
 ADuC843BCP62@LFCSP56 [ (SA706+B296) ]  
 ADuC843BS62@MQFP52 [ (SA662+B042) ]  
 ADuC845BCP62@LFCSP56 [ (SA706+B297) ]  
 ADuC845BS62@MQFP52 [ (SA662+B042) ]  
 ADuC847BCP62@LFCSP56 [ (SA706+B297) ]  
 ADuC847BS62@MQFP52 [ (SA662+B042) ]  
 ADuC848BCP62@LFCSP56 [ (SA706+B297) ]

ADuC848BS62@MQFP52 [ (SA662+B042) ]

**ADVANCE GROUP****E (E) PROM/FRAM/NVRAM**

AF24BC01 [ (SA602A) ]	AF24BC01@SOIC8
AF24BC01@TSOP8 [ (SA026) ]	
AF24BC02 AF24BC02@SOIC8 [ (SA602A) ] [ (SA026) ]	AF24BC02@TSOP8
AF24BC04 [ (SA602A) ]	AF24BC04@SOIC8
AF24BC04@TSOP8 [ (SA026) ]	
AF24BC08 AF24BC08@SOIC8 [ (SA602A) ] [ (SA026) ]	AF24BC08@TSOP8
AF24BC16 [ (SA602A) ]	AF24BC16@SOIC8
AF24BC16@TSOP8 [ (SA026) ]	
AF24C128 AF24C128@SOIC8 [ (SA602A) ] [ (SA026) ]	AF24C128@TSOP8
AF24C256 [ (SA602A) ]	AF24C256@SOIC8
AF24C256@TSOP8 [ (SA026) ]	
AF24C32 AF24C32@SOIC8 [ (SA602A) ] [ (SA026) ]	AF24C32@TSOP8
AF24C64 [ (SA602A) ]	AF24C64@SOIC8
AF24C64@TSOP8 [ (SA026) ] (08bit)	AF93C46
AF93C46(08bit)@SOIC8 [ (SA602A) ] [ (SA026) ]	AF93C46(08bit)@TSOP8
AF93C46(16bit) [ (SA602A) ]	AF93C46(16bit)@SOIC8
AF93C46(16bit)@TSOP8 [ (SA026) ] (08bit)	AF93C56
AF93C56(08bit)@SOIC8 [ (SA602A) ] [ (SA026) ]	AF93C56(08bit)@TSOP8

AF93C56(16bit) [(SA602A)]	AF93C56(16bit)@SOIC8
AF93C56(16bit)@TSOP8 [(SA026)] (08bit)	AF93C66
AF93C66(08bit)@SOIC8 [(SA602A)] [(SA026)]	AF93C66(08bit)@TSOP8
AF93C66(16bit) [(SA602A)]	AF93C66(16bit)@SOIC8
AF93C66(16bit)@TSOP8 [(SA026)] (08bit)	AF93C86
AF93C86(08bit)@SOIC8 [(SA602A)] [(SA026)]	AF93C86(08bit)@TSOP8
AF93C86(16bit) [(SA602A)]	AF93C86(16bit)@SOIC8
AF93C86(16bit)@TSOP8 [(SA026)]	

## MICROCONTROLLER

A1000A2 [(SA244)]	A1000A2@PLCC44
A1000A2@PQFP44 [(SA245A)]	
A1000A3	
A1000A3@PLCC44 [(SA244)] [(SA245A)]	A1000A3@PQFP44
AG1001@SDIP42 [(SA028)]	
AG89F516	
AG89F516@PLCC44 [(SA244)] [(SA245A)]	AG89F516@PQFP44
AG89F54 [(SA244)]	AG89F54@PLCC44
AG89F54@PQFP44 [(SA245A)]	
AG89P51	
AG89P51@PLCC44 [(SA244)] [(SA675)]	AG89P51@PQFP44
AG89P516 [(SA244)]	AG89P516@PLCC44
AG89P516@PQFP44 [(SA675)]	
AG89P51A	
AG89P51A@PLCC44 [(SA244)] [(SA675)]	AG89P51A@PQFP44
AG89P52 [(SA244)]	AG89P52@PLCC44



AG89P52@PQFP44 [ ( SA675 ) ]

## **ALI(Acer)**

### **E ( E ) PROM / FRAM / NVRAM**

M8720  
[ ( SA015A1T ) ]

M8720@PLCC32

### **MICROCONTROLLER**

M6759  
M6759@PLCC44 [ordering number is marked above]  
M6759@TQFP44 [ordering number is marked above]

## **ALL 24 SERIES(ISP)**

### **E ( E ) PROM / FRAM / NVRAM**

24C01 ( ISP ) [ ISP-HEADER01 ] HEADER01 ]	24C02 ( ISP ) [ ISP-
24C04 ( ISP ) [ ISP-HEADER01 ] HEADER01 ]	24C08 ( ISP ) [ ISP-
24C128 ( ISP ) [ ISP-HEADER01 ] HEADER01 ]	24C16 ( ISP ) [ ISP-
24C256 ( ISP ) [ ISP-HEADER01 ] HEADER01 ]	24C32 ( ISP ) [ ISP-
24C64 ( ISP ) [ ISP-HEADER01 ]	

## **ALLIANCE**

### **E ( E ) PROM / FRAM / NVRAM**

AS29F200@PSOP44 [ ( SA638-B006 ) ] B005 ) ]	AS29F200@TSOP48 [ ( SA247-
AS29F200B@PSOP44 [ ( SA638-B006 ) ] B005 ) ]	AS29F200B@TSOP48 [ ( SA247-
AS29F200T@PSOP44 [ ( SA638-B006 ) ]	AS29F200T@TSOP48 [ ( SA247-

B005) ]

**ALTERA****E ( E ) PROM / FRAM / NVRAM**

EPC1(LC)@PLCC20 [(SA001A)]	EPC1(LI)@PLCC20
[(SA001A)]	
EPC1(PC)	EPC1
(PI)	
EPC1441(LC)@PLCC20 [(SA001A)]	EPC1441(LI)@PLCC20
[(SA001A)]	
EPC1441(PC)	EPC1441
(PI)	
EPC1441(TC)@TQFP32 [(SA663)]	EPC1441(TI)@TQFP32
[(SA663)]	
EPC16UC88@BGA88 [(SA642A-B146A-Y096F001Y)]	
EPC16UC88AA@BGA88 [(SA642A-B146A-Y096F001Y)]	
EPC16UC88AB@BGA88 [(SA642A-B146A-Y096F001Y)]	
EPC16UC88N@BGA88 [(SA642A-B146A-Y096F001Y)]	
EPC16UI88AA@BGA88 [(SA642A-B146A-Y096F001Y)]	
EPC2(LC)@PLCC20 [(SA001A)]	EPC2(LI)@PLCC20
[(SA001A)]	
EPC2(TC)@TQFP32 [(SA663)]	EPC2(TI)@TQFP32
[(SA663)]	
EPCS16SI16@SOIC16 [(SA404)]	EPCS16SI8N@SOIC8
[(SA602A)]	
EPCS1SI8@SOIC8 [(SA602A)]	EPCS4SI8@SOIC8
[(SA602A)]	
EPCS64SI16@SOIC16 [(SA404)]	

**PLD**

EP310	EP310@PLCC20
[(SA001A)]	
EP320	EP320@PLCC20
[(SA001A)]	
EP330	EP330@PLCC20
[(SA001A)]	
EP600	EP600@PLCC28
[(SA008A)]	

EP600@SOIC24 [(SA404)]	
EP600I	
EP600I@PLCC28 [(SA008A)]	EP600I@SOIC24
[(SA404)]	
EP610	EP610@PLCC28
[(SA008A)]	
EP610@SOIC24 [(SA404)]	
EP610A	
EP610A@PLCC28 [(SA008A)]	EP610A@SOIC24
[(SA404)]	
EP610I	EP610I@PLCC28
[(SA008A)]	
EP610I@SOIC24 [(SA404)]	
EP610T	
EP610T@PLCC28 [(SA008A)]	EP610T@SOIC24
[(SA404)]	
EP630	EP630@PLCC28
[(SA008A)]	
EP630@SOIC24 [(SA404)]	
EP900	
EP900@PLCC44 [(SA244)]	
EP900I	
EP900I@PLC44 [(SA244)]	
EP910	
EP910@PLCC44 [(SA244)]	
EP910A	
EP910A@PLCC44 [(SA244)]	
EP910I	
EP910I@PLCC44 [(SA244)]	
EP910T	
EP910T@PLCC44 [(SA244)]	
EPM1270@FBGA256(*) [(SA800-B209)]	
EPM1270@TQFP144(*) [(SA681-B14405)]	
EPM1270G@FBGA256(*) [(SA800-B209)]	
EPM1270G@TQFP144(*) [(SA681-B14405)]	
EPM2210@FBGA256(*) [(SA800-B209)]	
EPM2210G@FBGA256(*) [(SA800-B209)]	
EPM240@FBGA100(*) [(SA800B-B293-W100F001Y)]	
EPM240@TQFP100(*) [(TA053-B006)]	
EPM240G@FBGA100(*) [(SA800B-B293-W100F001Y)]	
EPM240G@TQFP100(*) [(TA053-B006)]	
EPM3032A@PLCC44 [(SA244)]	EPM3032A@TQFP44
[(SA245A)]	

EPM3064A@PLCC44 [(SA244)] EPM3064A@TQFP44  
 [(SA245A)]  
 EPM3128A@TQFP144(\*) [(SA681-B14409)]  
 EPM3256A@PQFP208(\*) [(TA078-B084)]  
 EPM570@FBGA256(\*) [(SA800-B209)] EPM570@TQFP100(\*) [(TA053-  
 B006)]  
 EPM570@TQFP144(\*) [(SA681-B14405)]  
 EPM570G@FBGA256(\*) [(SA800-B209)]  
 EPM570G@TQFP100(\*) [(TA053-B006)]  
 EPM570G@TQFP144(\*) [(SA681-B14405)]  
 EPM7032@PLCC44 [(SA244)] EPM7032@TQFP44  
 [(SA245A)]  
 EPM7032AE@JLCC44 (7032 mode) [(SA244)]  
 EPM7032AE@PLCC44 (7032 mode) [(SA244)]  
 EPM7032AE@PLCC44 (7032AE mode) [(SA244)]  
 EPM7032AE@PLCC44 (7032S mode) [(SA244)]  
 EPM7032AE@PQFP44 (7032 mode) [(SA245A)]  
 EPM7032AE@TQFP44 (7032 mode) [(SA245A)]  
 EPM7032AE@TQFP44 (7032AE mode) [(SA245A)]  
 EPM7032AE@TQFP44 (7032S mode) [(SA245A)]  
 EPM7032B@PLCC44 (7032AE mode) [(SA244)]  
 EPM7032B@PLCC44 (7032B mode) [(SA244)]  
 EPM7032B@PLCC44 (7032S mode) [(SA244)]  
 EPM7032B@TQFP44 (7032AE mode) [(SA245A)]  
 EPM7032B@TQFP44 (7032B mode) [(SA245A)]  
 EPM7032B@TQFP44 (7032S mode) [(SA245A)]  
 EPM7032B@TQFP48 (7032AE mode) [(SA248)]  
 EPM7032B@TQFP48 (7032B mode) [(SA248)]  
 EPM7032B@TQFP48 (7032S mode) [(SA248)]  
 EPM7032S@PLCC44 (7032 mode) [(SA244)]  
 EPM7032S@PLCC44 (7032S mode) [(SA244)]  
 EPM7032S@TQFP44 (7032 mode) [(SA245A)]  
 EPM7032S@TQFP44 (7032S mode) [(SA245A)]  
 EPM7032V@PLCC44 [(SA244)] EPM7032V@TQFP44  
 [(SA245A)]  
 EPM7064@PLCC44 [(SA244)] EPM7064@TQFP44  
 [(SA245A)]  
 EPM7064AE@PLCC44 (7064S) (ISP) [ISP-HEADER01]  
 EPM7064AE@PLCC44 (7064AE mode) [(SA244)]  
 EPM7064AE@PLCC44 (7064AE) (ISP) [ISP-HEADER01]  
 EPM7064AE@PLCC44 (7064S mode) [(SA244)]  
 EPM7064AE@TQFP44 (7064S) (ISP) [ISP-HEADER01]  
 EPM7064AE@TQFP44 (7064AE mode) [(SA245A)]

EPM7064AE@TQFP44	(7064AE) (ISP)	[ISP-HEADER01]
EPM7064AE@TQFP44	(7064S mode)	[(SA245A)]
EPM7064B@PLCC44	(7064AE mode)	[(SA244)]
EPM7064B@PLCC44	(7064B mode)	[(SA244)]
EPM7064B@PLCC44	(7064S mode)	[(SA244)]
EPM7064B@TQFP44	(7064AE mode)	[(SA245A)]
EPM7064B@TQFP44	(7064B mode)	[(SA245A)]
EPM7064B@TQFP44	(7064S mode)	[(SA245A)]
EPM7064B@TQFP48	(7064AE mode)	[(SA248)]
EPM7064B@TQFP48	(7064B mode)	[(SA248)]
EPM7064B@TQFP48	(7064S mode)	[(SA248)]
EPM7064S@PLCC44	(7064 mode)	[(SA244)]
EPM7064S@PLCC44	(7064S mode)	[(SA244)]
EPM7064S@TQFP44	(7064 mode)	[(SA245A)]
EPM7064S@TQFP44	(7064S mode)	[(SA245A)]

## AMD

### E (E) PROM/FRAM/NVRAM

1736		1736@SOIC8
[(SA602A)]		
1765		1765@SOIC8
[(SA602A)]		
AM25FL005D@SOIC8	[(SA602A)]	AM25FL005D@USON8
[(SA683)]		
AM25FL010D@SOIC8	[(SA602A)]	AM25FL010D@USON8
[(SA683)]		
AM25FL016A@SOIC16	[(SA404)]	
AM25FL016A@SOIC16	(ISP)	[ISP-HEADER01]
AM25FL016A@WSON8	[(SA684)]	
AM25FL016A@WSON8	(ISP)	[ISP-HEADER01]
AM25FL020D@SOIC8	[(SA602A)]	AM25FL020D@USON8
[(SA683)]		
AM25FL032A@SOIC16	[(SA404)]	
AM25FL032A@SOIC16	(ISP)	[ISP-HEADER01]
AM25FL032A@WSON8	[(SA684)]	
AM25FL032A@WSON8	(ISP)	[ISP-HEADER01]
AM25FL040D@SOIC8	[(SA602A)]	AM25FL040D@USON8
[(SA683)]		
AM25FL080D@SOIC8	[(SA602A)]	AM25FL080D@USON8
[(SA683)]		

AM27128	AM27128
(DC)	
AM27128(DC)@PLCC32 [(SA015A1T)]	AM27128@PLCC32
[(SA015A1T)]	
AM27128A	AM27128A
(F)	
AM27128A(F)@PLCC32 [(SA015A1T)]	AM27128A
(PC)	
AM27128A(PC)@PLCC32 [(SA015A1T)]	AM27128A@PLCC32
[(SA015A1T)]	
AM2716	
AM2716B	
AM27256	AM27256@PLCC32
[(SA015A1T)]	
AM27256AP	AM27256AP@PLCC32
[(SA015A1T)]	
AM27256F	AM27256F@PLCC32
[(SA015A1T)]	
AM27256PC	AM27256PC@PLCC32
[(SA015A1T)]	
AM2732	
AM2732A	
AM2732B	
AM27512	
AM27512@PLCC32 [(SA015A1T)]	
AM27512DC	
AM27512DC@PLCC32 [(SA015A1T)]	
AM27512F	
AM27512F@PLCC32 [(SA015A1T)]	
AM27512PC	
AM27512PC@PLCC32 [(SA015A1T)]	
AM27513	
AM2764	AM2764@PLCC32
[(SA015A1T)]	
AM2764A	AM2764A
(DC)	
AM2764A(DC)@PLCC32 [(SA015A1T)]	AM2764A
(DCB)	
AM2764A(DI)	AM2764A
(DIB)	
AM2764A(F)	AM2764A(F)@PLCC32
[(SA015A1T)]	
AM2764A(JC)	AM2764A

(LC)	
AM2764A(LCB)	AM2764A
(LE)	
AM2764A(LEB)	AM2764A
(PC)	
AM2764A(PC)@PLCC32 [(SA015A1T)]	AM2764A@PLCC32
[(SA015A1T)]	
AM27C010	AM27C010@PLCC32
[(SA015A1T)]	
AM27C010@TSOP32 [(SA410T)]	
AM27C020	
AM27C020@PLCC32 [(SA015A1T)]	AM27C020@TSOP32
[(SA410T)]	
AM27C040	AM27C040@PLCC32
[(SA015A1T)]	
AM27C040@TSOP32 [(SA410T)]	
AM27C080	
AM27C080@PLCC32 [(SA015A1T)]	AM27C080@TSOP32
[(SA410T)]	
AM27C100	AM27C100@PLCC32
[(SA015A1T)]	
AM27C100@TSOP32 [(SA410T)]	
AM27C1024	
AM27C1024@PLCC44 [(SA244)]	
AM27C128	
AM27C128@PLCC32 [(SA015A1T)]	
AM27C2048	
AM27C2048@PLCC44 [(SA244)]	AM27C2048@TSOP40
[(SA409T)]	
AM27C256	AM27C256
(F)	
AM27C256(F)@PLCC32 [(SA015A1T)]	AM27C256
(PC)	
AM27C256(PC)@PLCC32 [(SA015A1T)]	AM27C256@PLCC32
[(SA015A1T)]	
AM27C400	AM27C400@PLCC44
[(SA244)]	
AM27C4096	AM27C4096@PLCC44
[(SA244)]	
AM27C512	AM27C512
(P)	
AM27C512(P)@PLCC32 [(SA015A1T)]	AM27C512@PLCC32
[(SA015A1T)]	

AM27C64	AM27C64@PLCC32
[ (SA015A1T) ]	
AM27H010	AM27H010@PLCC32
[ (SA015A1T) ]	
AM27H010@TSOP32 [ (SA410T) ]	
AM27H256	
AM27H256@PLCC32 [ (SA015A1T) ]	
AM27HB010	
AM27HB010@PLCC32 [ (SA015A1T) ]	AM27HB010@TSOP32
[ (SA410T) ]	
AM27LV010	AM27LV010@PLCC32
[ (SA015A1T) ]	
AM27LV010@TSOP32 [ (SA410T) ]	
AM27LV010B	
AM27LV010B@PLCC32 [ (SA015A1T) ]	AM27LV010B@TSOP32
[ (SA410T) ]	
AM27LV020	AM27LV020@PLCC32
[ (SA015A1T) ]	
AM27LV020@TSOP32 [ (SA410T) ]	
AM27LV020B	
AM27LV020B@PLCC32 [ (SA015A1T) ]	AM27LV020B@TSOP32
[ (SA410T) ]	
AM2816A	
AM2817A	
AM2817A@PLCC32 [ (SA015A1T) ]	AM2817A@SOIC28
[ (SA404) ]	
AM2864A	AM2864A
(E)	
AM2864A(E)@PLCC32 [ (SA015A1T) ]	AM2864A@PLCC32
[ (SA015A1T) ]	
AM2864B	AM2864B
(E)	
AM2864B(E)@PLCC32 [ (SA015A1T) ]	AM2864B@PLCC32
[ (SA015A1T) ]	
AM28F001	AM28F001@PLCC32
[ (SA015A1T) ]	
AM28F001@TSOP32 [ (SA410T) ]	
AM28F010	
AM28F010@PLCC32 [ (SA015A1T) ]	AM28F010@TSOP32
[ (SA410T) ]	
AM28F010A	AM28F010A@PLCC32
[ (SA015A1T) ]	
AM28F010A@TSOP32 [ (SA410T) ]	



AM28F020	
AM28F020@PLCC32 [(SA015A1T)]	AM28F020@TSOP32
[(SA410T)]	
AM28F020A	AM28F020A@PLCC32
[(SA015A1T)]	
AM28F020A@TSOP32 [(SA410T)]	
AM28F256	
AM28F256@PLCC32 [(SA015A1T)]	AM28F256@TSOP32
[(SA410T)]	
AM28F256A	AM28F256A@PLCC32
[(SA015A1T)]	
AM28F256A@TSOP32 [(SA410T)]	
AM28F512	
AM28F512(F)	AM28F512(F)@PLCC32
[(SA015A1T)]	
AM28F512(F)@TSOP32 [(SA410T)]	AM28F512@PLCC32
[(SA015A1T)]	
AM28F512@TSOP32 [(SA410T)]	
AM28F512A	
AM28F512A(F)	AM28F512A(F)@PLCC32
[(SA015A1T)]	
AM28F512A(F)@TSOP32 [(SA410T)]	AM28F512A@PLCC32
[(SA015A1T)]	
AM28F512A@TSOP32 [(SA410T)]	
AM29BL162CB@SSOP56 [(SA629A-B022)]	
AM29BL802CB@SSOP56 [(SA629A-B022)]	
AM29DL161DB@FBGA48 [(SA642B-B026A-Y072F001)]	
AM29DL161DB@FBGA63 [(SA642C-B026A-Y056F001)]	
AM29DL161DB@FBGA64 [(SA655A-B044A-T064N001)]	
AM29DL161DB@TSOP48 [(SA247-B005)]	
AM29DL161DB@VFBGA48 [(SA642B-B026A-Y072F001)]	
AM29DL161DT@FBGA48 [(SA642B-B026A-Y072F001)]	
AM29DL161DT@FBGA63 [(SA642C-B026A-Y056F001)]	
AM29DL161DT@FBGA64 [(SA655A-B044A-T064N001)]	
AM29DL161DT@TSOP48 [(SA247-B005)]	
AM29DL161DT@VFBGA48 [(SA642B-B026A-Y072F001)]	
AM29DL162CB@FBGA48 [(SA642B-B026A-Y072F001)]	
AM29DL162CB@TSOP48 [(SA247-B005)]	
AM29DL162CT@FBGA48 [(SA642B-B026A-Y072F001)]	
AM29DL162CT@TSOP48 [(SA247-B005)]	
AM29DL162DB@FBGA48 [(SA642B-B026A-Y072F001)]	
AM29DL162DB@FBGA63 [(SA642C-B026A-Y056F001)]	
AM29DL162DB@FBGA64 [(SA655A-B044A-T064N001)]	

AM29DL162DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL162DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL162DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL162DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL162DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL162DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DB@FBGA48 [ ( SA642HH-B026A-T048F001Y ) ]  
AM29DL163DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL163DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL163DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163DT@FBGA48 [ ( SA642HH-B026A-T048F001Y ) ]  
AM29DL163DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL163DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL163DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL164DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL164DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL164DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL164DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GB@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL320GB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL320GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL320GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GT@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL320GT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL320GT@TSOP48 [ ( SA247-B005 ) ]

AM29DL321CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL321CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322CB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322CT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL322GB@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL322GB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL322GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL322GT@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL322GT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL322GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323CB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323CT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323GB@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL323GB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL323GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323GT@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL323GT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL323GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL324DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL324DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]

AM29DL324GB@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
 AM29DL324GB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
 AM29DL324GB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL324GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DL324GT@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
 AM29DL324GT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
 AM29DL324GT@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL400BB@PSOP44 [ ( SA638-B006 ) ]  
 AM29DL400BB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL400BT@PLCC44 [ ( SA638-B006 ) ]  
 AM29DL400BT@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL640D@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
 AM29DL640D@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL640G@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
 AM29DL640G@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
 AM29DL640G@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL642G@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
 AM29DL800B@PSOP44 [ ( SA638-B006 ) ]      AM29DL800B@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL800BB@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
 AM29DL800BB@PSOP44 [ ( SA638 ) ]  
 AM29DL800BB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL800BT@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
 AM29DL800BT@PSOP44 [ ( SA638 ) ]  
 AM29DL800BT@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL800T@PSOP44 [ ( SA638-B006 ) ]      AM29DL800T@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS163CB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS163CT@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS163DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DS163DB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS163DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DS163DT@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS323DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DS323DB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS323DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DS323DT@TSOP48 [ ( SA247-B005 ) ]  
 AM29F002B      AM29F002B@PLCC32  
 [ ( SA015A1T ) ]  
 AM29F002B@TSOP32 [ ( SA410T ) ]  
 AM29F002BB  
 AM29F002BB@PLCC32 [ ( SA015A1T ) ]      AM29F002BB@TSOP32  
 [ ( SA410T ) ]

AM29F002BT [ (SA015A1T) ]	AM29F002BT@PLCC32
AM29F002BT@TSOP32 [ (SA410T) ]	
AM29F002NB AM29F002NB@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AM29F002NB@TSOP32
AM29F002NBB [ (SA015A1T) ]	AM29F002NBB@PLCC32
AM29F002NBB@TSOP32 [ (SA410T) ]	
AM29F002NBT AM29F002NBT@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AM29F002NBT@TSOP32
AM29F002NT [ (SA015A1T) ]	AM29F002NT@PLCC32
AM29F002NT@TSOP32 [ (SA410T) ]	
AM29F002T AM29F002T@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AM29F002T@TSOP32
AM29F004BB@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AM29F004BB@TSOP32
AM29F004BT@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AM29F004BT@TSOP32
AM29F010 [ (SA015A1T) ]	AM29F010@PLCC32
AM29F010@TSOP32 [ (SA410T) ]	
AM29F010A AM29F010A@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AM29F010A@TSOP32
AM29F010B [ (SA015A1T) ]	AM29F010B@PLCC32
AM29F010B@TSOP32 [ (SA410T) ] [ (SA638) ]	AM29F016@PSOP44
AM29F016@TSOP40 [ (SA409T) ] B005) ]	AM29F016@TSOP48 [ (SA247-
AM29F016B(REVERSE)@TSOP48 [ (SA247-B005) ]	
AM29F016B@PSOP44 [ (SA638) ] [ (SA409T) ]	AM29F016B@TSOP40
AM29F016B@TSOP48 [ (SA247-B005) ]	
AM29F016D(REVERSE)@TSOP48 [ (SA247-B005) ]	
AM29F016D@PSOP44 [ (SA638) ] [ (SA409T) ]	AM29F016D@TSOP40
AM29F016D@TSOP48 [ (SA247-B005) ] B005) ]	AM29F017B@TSOP48 [ (SA247-

AM29F017D@TSOP40 [(SA409T)] B005]	AM29F017D@TSOP48 [(SA247-
AM29F032B@PSOP44 [(SA638)] [(SA409T)]	AM29F032B@TSOP40
AM29F040 [(SA015A1T)]	AM29F040@PLCC32
AM29F040@TSOP32 [(SA410T)]	
AM29F040A AM29F040A@PLCC32 [(SA015A1T)] [(SA410T)]	AM29F040A@TSOP32
AM29F040B AM29F040B(Reverse)@TSOP32 [(SA410T)]	
AM29F040B@PLCC32 [(SA015A1T)] [(SA410T)]	AM29F040B@TSOP32
AM29F080@PSOP44 [(SA638)] [(SA409T)]	AM29F080@TSOP40
AM29F080B@PSOP44 [(SA638)] [(SA409T)]	AM29F080B@TSOP40
AM29F100BE@PSOP44 [(SA638-B006)] B005]	AM29F100BE@TSOP48 [(SA247-
AM29F100BS@PSOP44 [(SA638-B006)] B005]	AM29F100BS@TSOP48 [(SA247-
AM29F100TE@PSOP44 [(SA638-B006)] B005]	AM29F100TE@TSOP48 [(SA247-
AM29F100TS@PSOP44 [(SA638-B006)] B005]	AM29F100TS@TSOP48 [(SA247-
AM29F160DB@TSOP48 [(SA247-B005)]	AM29F160DT@TSOP48 [(SA247-
AM29F200AB@PSOP44 [(SA638-B006)] B005]	AM29F200AB@TSOP48 [(SA247-
AM29F200AT@PSOP44 [(SA638-B006)] B005]	AM29F200AT@TSOP48 [(SA247-
AM29F200BB@PSOP44 [(SA638-B006)] B005]	AM29F200BB@TSOP48 [(SA247-
AM29F200BE@PSOP44 [(SA638-B006)] B005]	AM29F200BE@TSOP48 [(SA247-
AM29F200BS@PSOP44 [(SA638-B006)] B005]	AM29F200BS@TSOP48 [(SA247-
AM29F200BT@PSOP44 [(SA638-B006)] B005]	AM29F200BT@TSOP48 [(SA247-
AM29F200TE@PSOP44 [(SA638-B006)] B005]	AM29F200TE@TSOP48 [(SA247-
AM29F200TS@PSOP44 [(SA638-B006)]	AM29F200TS@TSOP48 [(SA247-

B005) ]  
AM29F400AB@PSOP44 [ (SA638-B006) ] AM29F400AB@TSOP48 [ (SA247-  
B005) ]  
AM29F400AT@PSOP44 [ (SA638-B006) ] AM29F400AT@TSOP48 [ (SA247-  
B005) ]  
AM29F400BB@PSOP44 [ (SA638-B006) ] AM29F400BB@TSOP48 [ (SA247-  
B005) ]  
AM29F400BBE@PSOP44 [ (SA638-B006) ]  
AM29F400BBE@TSOP48 [ (SA247-B005) ]  
AM29F400BBF@PSOP44 [ (SA638-B006) ]  
AM29F400BBF@TSOP48 [ (SA247-B005) ]  
AM29F400BBS@PSOP44 [ (SA638-B006) ]  
AM29F400BBS@TSOP48 [ (SA247-B005) ]  
AM29F400BE@PSOP44 [ (SA638-B006) ] AM29F400BE@TSOP48 [ (SA247-  
B005) ]  
AM29F400BF@PSOP44 [ (SA638-B006) ] AM29F400BF@TSOP48 [ (SA247-  
B005) ]  
AM29F400BS@PSOP44 [ (SA638-B006) ] AM29F400BS@TSOP48 [ (SA247-  
B005) ]  
AM29F400BT@PSOP44 [ (SA638-B006) ] AM29F400BT@TSOP48 [ (SA247-  
B005) ]  
AM29F400BTE@PSOP44 [ (SA638-B006) ]  
AM29F400BTE@TSOP48 [ (SA247-B005) ]  
AM29F400BTF@PSOP44 [ (SA638-B006) ]  
AM29F400BTF@TSOP48 [ (SA247-B005) ]  
AM29F400BTS@PSOP44 [ (SA638-B006) ]  
AM29F400BTS@TSOP48 [ (SA247-B005) ]  
AM29F800B@PSOP44 [ (SA638-B006) ] AM29F800B@TSOP48 [ (SA247-  
B005) ]  
AM29F800BB@PSOP44 [ (SA638-B006) ] AM29F800BB@TSOP48 [ (SA247-  
B005) ]  
AM29F800BBF@PSOP44 [ (SA638-B006) ]  
AM29F800BBF@TSOP48 [ (SA247-B005) ]  
AM29F800BF@PSOP44 [ (SA638-B006) ] AM29F800BF@TSOP48 [ (SA247-  
B005) ]  
AM29F800BT@PSOP44 [ (SA638-B006) ] AM29F800BT@TSOP48 [ (SA247-  
B005) ]  
AM29F800BTF@PSOP44 [ (SA638-B006) ]  
AM29F800BTF@TSOP48 [ (SA247-B005) ]  
AM29F800T@PSOP44 [ (SA638-B006) ] AM29F800T@TSOP48 [ (SA247-  
B005) ]  
AM29F800TB@PSOP44 [ (SA638-B006) ] AM29F800TB@TSOP48 [ (SA247-  
B005) ]

AM29F800TF@PSOP44 [ (SA638-B006) ]	AM29F800TF@TSOP48 [ (SA247-B005) ]
AM29LL800B@TSOP48 [ (SA247-B005) ]	
AM29LL800BB@TSOP48 [ (SA247-B005) ]	
AM29LL800BT@TSOP48 [ (SA247-B005) ]	
AM29LL800T@TSOP48 [ (SA247-B005) ]	AM29LV001BB@PLCC32
[ (SA015A1T) ]	
AM29LV001BB@TSOP32 [ (SA410T) ]	AM29LV001BT@PLCC32
[ (SA015A1T) ]	
AM29LV001BT@TSOP32 [ (SA410T) ]	AM29LV002@TSOP40
[ (SA409T) ]	
AM29LV002B@TSOP40 [ (SA409T) ]	AM29LV002BB@TSOP40
[ (SA409T) ]	
AM29LV002BT@TSOP40 [ (SA409T) ]	AM29LV004B@PSOP44
[ (SA638) ]	
AM29LV004B@TSOP40 [ (SA409T) ]	AM29LV004BB@TSOP40
[ (SA409T) ]	
AM29LV004BT@TSOP40 [ (SA409T) ]	AM29LV004T@PSOP44
[ (SA638) ]	
AM29LV004T@TSOP40 [ (SA409T) ]	AM29LV008B@PSOP44
[ (SA638) ]	
AM29LV008B@TSOP40 [ (SA409T) ]	AM29LV008BB@TSOP40
[ (SA409T) ]	
AM29LV008BT@TSOP40 [ (SA409T) ]	AM29LV008T@PSOP44
[ (SA638) ]	
AM29LV008T@TSOP40 [ (SA409T) ]	AM29LV010B@PLCC32
[ (SA015A1T) ]	
AM29LV010B@TSOP32 [ (SA410T) ]	AM29LV017B@TSOP40
[ (SA409T) ]	
AM29LV017D@FBGA48 [ (SA642B-B026A-Y072F001) ]	
AM29LV017D@TSOP40 [ (SA409T) ]	AM29LV020B@PLCC32
[ (SA015A1T) ]	
AM29LV020B@TSOP32 [ (SA410T) ]	
AM29LV033C@FBGA63 [ (SA642A-B026A-Y096N001) ]	
AM29LV033C@TSOP40 [ (SA409T) ]	
AM29LV033MU@FBGA48 [ (SA642B-B026A-Y072F001) ]	
AM29LV033MU@TSOP40 [ (SA409T) ]	AM29LV040B@PLCC32
[ (SA015A1T) ]	
AM29LV040B@TSOP32 [ (SA410T) ]	AM29LV040E@PLCC32
[ (SA015A1T) ]	
AM29LV040E@TSOP32 [ (SA410T) ]	AM29LV040J@PLCC32
[ (SA015A1T) ]	
AM29LV040J@TSOP32 [ (SA410T) ]	



AM29LV065D@FBGA63 [ (SA642C-B026A-Y056F001) ]  
AM29LV065D@TSOP48 [ (SA247-B005) ]  
AM29LV065MU@FBGA63 [ (SA642C-B026A-Y056F001) ]  
AM29LV065MU@TSOP48 [ (SA247-B005) ]  
AM29LV080@TSOP40 [ (SA409T) ] AM29LV081@TSOP40  
[ (SA409T) ]  
AM29LV081B@TSOP40 [ (SA409T) ] AM29LV116BB@TSOP40  
[ (SA409T) ]  
AM29LV116BT@TSOP40 [ (SA409T) ] AM29LV116DB@TSOP40  
[ (SA409T) ]  
AM29LV116DT@TSOP40 [ (SA409T) ]  
AM29LV128MH@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
AM29LV128MH@TSOP56 [ (SA628-B067) ]  
AM29LV128ML@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
AM29LV128ML@TSOP56 [ (SA628-B067) ]  
AM29LV160BB@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
AM29LV160BB@PSOP44 [ (SA638) ]  
AM29LV160BB@TSOP48 [ (SA247-B005) ]  
AM29LV160BT@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
AM29LV160BT@PSOP44 [ (SA638) ]  
AM29LV160BT@TSOP48 [ (SA247-B005) ]  
AM29LV160DB(REVERSE)@TSOP48 [ (SA247-B005) ]  
AM29LV160DB@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
AM29LV160DB@PSOP44 [ (SA638) ]  
AM29LV160DB@TSOP48 [ (SA247-B005) ]  
AM29LV160DT(REVERSE)@TSOP48 [ (SA247-B005) ]  
AM29LV160DT@FBGA48 [ (SA642B-B026A-Y072F001N) ]  
AM29LV160DT@PSOP44 [ (SA638) ]  
AM29LV160DT@TSOP48 [ (SA247-B005) ]  
AM29LV160MB@FBGA48 [ (SA642B-B026A-Y072F001) ]  
AM29LV160MB@FBGA64 [ (SA655A-B044A-T064N001) ]  
AM29LV160MB@PSOP44 [ (SA638) ]  
AM29LV160MB@TSOP48 [ (SA247-B005) ]  
AM29LV160MT@FBGA48 [ (SA642B-B026A-Y072F001) ]  
AM29LV160MT@FBGA64 [ (SA655A-B044A-T064N001) ]  
AM29LV160MT@PSOP44 [ (SA638) ]  
AM29LV160MT@TSOP48 [ (SA247-B005) ]  
AM29LV200B@PSOP44 [ (SA638-B006) ] AM29LV200B@TSOP48 [ (SA247-  
B005) ]  
AM29LV200BB@PSOP44 [ (SA638-B006) ]  
AM29LV200BB@TSOP48 [ (SA247-B005) ]  
AM29LV200BE@PSOP44 [ (SA638-B006) ]  
AM29LV200BE@TSOP48 [ (SA247-B005) ]

AM29LV200BF@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BF@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BS@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BS@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BT@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200T@PSOP44 [ ( SA638-B006 ) ]      AM29LV200T@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TE@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200TE@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TF@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200TF@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TS@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200TS@TSOP48 [ ( SA247-B005 ) ]  
AM29LV256MH@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
AM29LV256MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV256ML@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
AM29LV256ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320DB@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29LV320DB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320DT@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29LV320DT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320FB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320FT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320MB@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AM29LV320MB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV320MB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320MH@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV320MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320ML@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV320ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320MT@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AM29LV320MT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV320MT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400B@PSOP44 [ ( SA638-B006 ) ]      AM29LV400B@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400BB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29LV400BB@PSOP44 [ ( SA638-B006 ) ]  
AM29LV400BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400BT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29LV400BT@PSOP44 [ ( SA638-B006 ) ]  
AM29LV400BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400T@PSOP44 [ ( SA638-B006 ) ]      AM29LV400T@TSOP48 [ ( SA247-

B005) ]  
 AM29LV640DH@SSOP56 [ (SA629A-B020) ]  
 AM29LV640DL@SSOP56 [ (SA629A-B020) ]  
 AM29LV640DU@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
 AM29LV640DU@FBGA64 [ (SA655D-B044A-W064F001) ]  
 AM29LV640GU@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
 AM29LV640GU@FBGA64 [ (SA655D-B044A-W064F001) ]  
 AM29LV640MB@FBGA63 [ (SA642C-B026A-Y056F001) ]  
 AM29LV640MB@FBGA64 [ (SA655A-B044A-T064N001) ]  
 AM29LV640MB@TSOP48 [ (SA247-B005) ]  
 AM29LV640MH@FBGA64 [ (SA655A-B044A-T064N001) ]  
 AM29LV640MH@TSOP56 [ (SA628-B067) ]  
 AM29LV640ML@FBGA64 [ (SA655A-B044A-T064N001) ]  
 AM29LV640ML@TSOP56 [ (SA628-B067) ]  
 AM29LV640MT@FBGA63 [ (SA642C-B026A-Y056F001) ]  
 AM29LV640MT@FBGA64 [ (SA655A-B044A-T064N001) ]  
 AM29LV640MT@TSOP48 [ (SA247-B005) ]  
 AM29LV640MU@FBGA63 [ (SA642C-B026A-Y056F001) ]  
 AM29LV640MU@FBGA64 [ (SA655A-B044A-T064N001) ]  
 AM29LV641DH@TSOP48 [ (SA247-B005) ]  
 AM29LV641DHR@TSOP48 [ (SA247-B005) ]  
 AM29LV641DL@TSOP48 [ (SA247-B005) ]  
 AM29LV641DLR@TSOP48 [ (SA247-B005) ]  
 AM29LV641GH@TSOP48 [ (SA247-B005) ]  
 AM29LV641GHR@TSOP48 [ (SA247-B005) ]  
 AM29LV641GL@TSOP48 [ (SA247-B005) ]  
 AM29LV641GLR@TSOP48 [ (SA247-B005) ]  
 AM29LV641MH@TSOP48 [ (SA247-B005) ]  
 AM29LV641ML@TSOP48 [ (SA247-B005) ]  
 AM29LV642G@FBGA64 [ (SA655A-B038A-T064N001) ]  
 AM29LV652D@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
 AM29LV800B@PSOP44 [ (SA638-B006) ]      AM29LV800B@TSOP48 [ (SA247-B005) ]  
 AM29LV800BB@FBGA48 [ (SA642N-B026A-W048F001Y) ]  
 AM29LV800BB@PSOP44 [ (SA638-B006) ]  
 AM29LV800BB@TSOP48 [ (SA247-B005) ]  
 AM29LV800BT@FBGA48 [ (SA642N-B026A-W048F001Y) ]  
 AM29LV800BT@PSOP44 [ (SA638-B006) ]  
 AM29LV800BT@TSOP48 [ (SA247-B005) ]  
 AM29LV800DB(WB)@FBGA48 [ (SA642N-B026A-W048F001Y) ]  
 AM29LV800DB(WC)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
 AM29LV800DB@PSOP44 [ (SA638) ]  
 AM29LV800DB@TSOP48 [ (SA247-B005) ]

AM29LV800DT(WB)@FBGA48 [(SA642N-B026A-W048F001Y)]  
AM29LV800DT(WC)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
AM29LV800DT@PSOP44 [(SA638)]  
AM29LV800DT@TSOP48 [(SA247-B005)]  
AM29LV800T@PSOP44 [(SA638-B006)] AM29LV800T@TSOP48 [(SA247-B005)]  
AM29N163DT@FBGA47 [(SA733A-B206A-M056F001N)]  
AM29N323DT@FBGA47 [(SA733A-B206A-M056F001N)]  
AM29N643GT@FBGA44 [(SA733A-B206A-M056F001Y)]  
AM29PDS322DB@FBGA48 [(SA642E-B026A-T072F001)]  
AM29PDS322DT@FBGA48 [(SA642E-B026A-T072F001)]  
AM29PL160CB@PSOP44 [(SA638-B006)]  
AM29PL160CB@TSOP48 [(SA247-B005)]  
AM29PL160CT@PSOP44 [(SA638-B006)]  
AM29PL160CT@TSOP48 [(SA247-B005)]  
AM29SL160CB@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29SL160CB@TSOP48 [(SA247-B005)]  
AM29SL160CT@FBGA48 [(SA642B-B026A-Y072F001)]  
AM29SL160CT@TSOP48 [(SA247-B005)]  
AM29SL400CB@TSOP48 [(SA247-B005)]  
AM29SL400CT@TSOP48 [(SA247-B005)]  
AM29SL800BB@TSOP48 [(SA247-B005)]  
AM29SL800BT@TSOP48 [(SA247-B005)]  
AM29SL800CB@TSOP48 [(SA247-B005)]  
AM29SL800CT@TSOP48 [(SA247-B005)]  
AM29SL800DB@TSOP48 [(SA247-B005)]  
AM29SL800DBUF@FBGA48 [(SA716A-B119B-M048F001Y)]  
AM29SL800DBVG@FBGA48 [(SA716A-B119B-M048F001Y)]  
AM29SL800DBVU@FBGA48 [(SA642Z-B026A-W048F001Y)]  
AM29SL800DBWA@FBGA48 [(SA642G-B026A-T048F001Y)]  
AM29SL800DBWC@FBGA48 [(SA642R-B026A-W080F001N)]  
AM29SL800DT@TSOP48 [(SA247-B005)]  
AM29SL800DTUF@FBGA48 [(SA716A-B119B-M048F001Y)]  
AM29SL800DTV@FBGA48 [(SA716A-B119B-M048F001Y)]  
AM29SL800DTVU@FBGA48 [(SA642Z-B026A-W048F001Y)]  
AM29SL800DTWA@FBGA48 [(SA642G-B026A-T048F001Y)]  
AM29SL800DTWC@FBGA48 [(SA642R-B026A-W080F001N)]  
AM9716  
AM9732  
AM9732A  
AM9764  
AM9764@PLCC32 [(SA015A1T)]  
BS128HD8V(AM29BDS128HD)@FBGA80 [(SA642A-B080A-Y096N001)]

BS128HD9V(AM29BDS128HD)@FBGA80 [(SA642A-B080A-Y096N001)]  
BS128HE8V(AM29BDS128HE)@FBGA80 [(SA642A-B080A-Y096N001)]  
BS128HE9V(AM29BDS128HE)@FBGA80 [(SA642A-B080A-Y096N001)]  
BS128HF8V(AM29BDS128HF)@FBGA80 [(SA642A-B080A-Y096N001)]  
BS128HF9V(AM29BDS128HF)@FBGA80 [(SA642A-B080A-Y096N001)]  
BS640HD8V(AM29BDS640HD)@FBGA64 [(SA642A-B080A-Y096F001)]  
BS640HD9V(AM29BDS640HD)@FBGA64 [(SA642A-B080A-Y096F001)]  
BS640HE8V(AM29BDS640HE)@FBGA64 [(SA642A-B080A-Y096F001)]  
BS640HE9V(AM29BDS640HE)@FBGA64 [(SA642A-B080A-Y096F001)]  
BS640HF8V(AM29BDS640HF)@FBGA64 [(SA642A-B080A-Y096F001)]  
BS640HF9V(AM29BDS640HF)@FBGA64 [(SA642A-B080A-Y096F001)]  
DS42514(AM29DL163DB)@FBGA69 [(SA642B-B032A-Y072F001)]  
DS42515(AM29DL164)@FBGA69 [(SA642B-B032A-Y072F001)]  
DS42516(AM29DL324)@FBGA73 [(SA642A-B032A-Y096F001)]  
DS42546(AM29DL163)@FBGA69 [(SA642B-B032A-Y072F001)]  
DS42553(AM29DL323)@FBGA73 [(SA642A-B032A-Y096F001)]  
DS42585(AM29DL323D)@FBGA73 [(SA642A-B032A-Y096F001)]  
DS42587(AM29DL324D)@FBGA73 [(SA642A-B032A-Y096F001)]  
DS42629(AM29DL640G)@VFBGA48 [(SA634A-B005A-Y048F001)]  
DS42677(AM29LV128MH/L)@FBGA88 [(SA642A-B058A-Y096N001)]  
DS42678(AM29LV320MT)@FBGA67 [(SA642E-B041A-T072F001)]  
DS42689(AM29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
DS42690(AM29LV320MB)@FBGA64 [(SA655E-B090A-T064F001Y)]  
DS42695(AM29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
DS42696(AM29LV320MB)@FBGA64 [(SA655F-B099A-W064F001Y)]  
DS42701(AM29LV640MU)@FBGA88 [(SA642W-B116A-W088F001Y)]  
DS42725(AM50DL128CH)@FBGA88 [(SA642A-B062A-Y096F001)]  
DS42772A(AM29LV640M)@FBGA88 [(SA642W-B116A-W088F001Y)]  
M410000000(AM41DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000001(AM41DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000002(AM41DL1614DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000003(AM41DL1614DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000004(AM41DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000005(AM41DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000006(AM41DL1624DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000007(AM41DL1624DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000008(AM41DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M410000009(AM41DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000A(AM41DL1634DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000B(AM41DL1634DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000C(AM41DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000D(AM41DL1644DB)@FBGA69 [(SA642A-B032A-Y096F001)]  
M41000000E(AM41DL1644DT)@FBGA69 [(SA642A-B032A-Y096F001)]

M41000000F (AM41DL1644DB)@FBGA69 [ (SA642A-B032A-Y096F001) ]  
M41000000G (AM41DL6408G)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000000H (AM41DL6408G)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000001W (AM41DL3224GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000001X (AM41DL3224GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000001Y (AM41DL3224GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000001Z (AM41DL3224GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M410000020 (AM41DL3234GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M410000021 (AM41DL3234GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M410000022 (AM41DL3234GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M410000023 (AM41DL3234GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M410000024 (AM41DL3244GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M410000025 (AM41DL3244GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M410000026 (AM41DL3244GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M410000027 (AM41DL3244GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000002L (AM41DL3228GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000002M (AM41DL3228GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000002N (AM41DL3228GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000002O (AM41DL3228GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000002P (AM41DL3238GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000002Q (AM41DL3238GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000002R (AM41DL3238GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000002S (AM41DL3238GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000002T (AM41DL3248GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000002U (AM41DL3248GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000002V (AM41DL3248GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000002W (AM41DL3248GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000003D (AM41DL3208GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000003E (AM41DL3208GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000003F (AM41DL3208GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000003G (AM41DL3208GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M410000095 (AM41LV3204MT)@FBGA69 [ (SA642A-B032A-Y096F001) ]  
M410000096 (AM41LV3204MB)@FBGA69 [ (SA642A-B032A-Y096F001) ]  
M41000009B (AM41DL6408H)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000009C (AM41DL6408H)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M41000009D (AM41DL6408H)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M420000000 (AM42DL640AG)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M420000001 (AM42DL640AG)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M420000004 (AM42DL1642DT)@FBGA69 [ (SA642A-B032A-Y096F001) ]  
M420000005 (AM42DL1642DB)@FBGA69 [ (SA642A-B032A-Y096F001) ]  
M420000006 (AM42DL1642DT)@FBGA69 [ (SA642A-B032A-Y096F001) ]  
M420000007 (AM42DL1642DB)@FBGA69 [ (SA642A-B032A-Y096F001) ]  
M42000000I (AM42DL1612DT)@FBGA69 [ (SA642A-B032A-Y096F001) ]

M42000000J (AM42DL1612DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000K (AM42DL1612DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000L (AM42DL1612DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000M (AM42DL1622DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000N (AM42DL1622DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000O (AM42DL1622DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000P (AM42DL1622DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000Q (AM42DL1632DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000R (AM42DL1632DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000S (AM42DL1632DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000T (AM42DL1632DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000U (AM42DL1642DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000V (AM42DL1642DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000W (AM42DL1642DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000000X (AM42DL1642DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001A (AM42DL1614DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001B (AM42DL1614DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001C (AM42DL1614DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001D (AM42DL1614DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001E (AM42DL1624DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001F (AM42DL1624DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001G (AM42DL1624DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001H (AM42DL1624DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001I (AM42DL1634DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001J (AM42DL1634DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001K (AM42DL1634DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001L (AM42DL1634DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001M (AM42DL1644DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001N (AM42DL1644DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001O (AM42DL1644DT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M42000001P (AM42DL1644DB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M420000022 (AM42DL3224GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000023 (AM42DL3224GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000024 (AM42DL3224GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000025 (AM42DL3224GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000026 (AM42DL3234GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000027 (AM42DL3234GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000028 (AM42DL3234GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M420000029 (AM42DL3234GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M42000002A (AM42DL3244GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M42000002B (AM42DL3244GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M42000002C (AM42DL3244GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M42000002D (AM42DL3244GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]

M42000002U (AM42DL6404G)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M42000002V (AM42DL6404G)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M42000002Y (AM42BDS6408GT)@FBGA93 [ (SA642A-B072A-Y096F001) ]  
M42000002Z (AM42BDS6408GB)@FBGA93 [ (SA642A-B072A-Y096F001) ]  
M420000030 (AM42BDS6408GT)@FBGA93 [ (SA642A-B072A-Y096F001) ]  
M420000031 (AM42BDS6408GB)@FBGA93 [ (SA642A-B072A-Y096F001) ]  
M420000032 (AM42BDS6408GT)@FBGA93 [ (SA642A-B072A-Y096F001) ]  
M420000033 (AM42BDS6408GB)@FBGA93 [ (SA642A-B072A-Y096F001) ]  
M420000034 (AM42BDS6408GT)@FBGA93 [ (SA642A-B072A-Y096F001) ]  
M420000035 (AM42BDS6408GB)@FBGA93 [ (SA642A-B072A-Y096F001) ]  
M42000004Y (AM42BDS640AGT)@FBGA93 [ (SA642A-B072A-Y096F001) ]  
M42000004Z (AM42BDS640AGB)@FBGA93 [ (SA642A-B072A-Y096F001) ]  
M420000050 (AM42BDS640AGT)@FBGA93 [ (SA642A-B072A-Y096F001) ]  
M420000051 (AM42BDS640AGB)@FBGA93 [ (SA642A-B072A-Y096F001) ]  
M420000052 (AM42BDS640AGT)@FBGA93 [ (SA642A-B072A-Y096F001) ]  
M420000053 (AM42BDS640AGB)@FBGA93 [ (SA642A-B072A-Y096F001) ]  
M420000054 (AM42BDS640AGT)@FBGA93 [ (SA642A-B072A-Y096F001) ]  
M420000055 (AM42BDS640AGB)@FBGA93 [ (SA642A-B072A-Y096F001) ]  
M42000005M (AM42DL6402G)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M42000005N (AM42DL6402G)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M42000005W (AM42DL3224GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M42000005X (AM42DL3224GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M42000005Y (AM42DL3234GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M42000005Z (AM42DL3234GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M420000060 (AM42DL3244GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M420000061 (AM42DL3244GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M420000070 (AM42BDS6408HE8)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000071 (AM42BDS6408HE9)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000072 (AM42BDS6408HD8)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000073 (AM42BDS6408HD9)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000074 (AM42BDS6408HE3)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000075 (AM42BDS6408HE4)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000076 (AM42BDS6408HD3)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000077 (AM42BDS6408HD4)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000078 (AM42DL640AH)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M420000079 (AM42DL640AH)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M450000000 (AM45DL6408G)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M450000001 (AM45DL6408G)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M450000008 (AM45DL3208GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M450000009 (AM45DL3208GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M45000000A (AM45DL3208GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M45000000B (AM45DL3208GB)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M45000000S (AM45DL3228GT)@FBGA73 [ (SA642A-B032A-Y096F001) ]



M45000000T (AM45DL3228GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M45000000U (AM45DL3228GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M45000000V (AM45DL3228GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M45000001C (AM45DL3238GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M45000001D (AM45DL3238GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M45000001E (AM45DL3238GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M45000001F (AM45DL3238GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M45000001W (AM45DL3248GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M45000001X (AM45DL3248GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M45000001Y (AM45DL3248GT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M45000001Z (AM45DL3248GB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M490000000 (AM49DL640BG)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M490000001 (AM49DL640BG)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000000G (AM49DL320BGT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000000H (AM49DL320BGT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000000J (AM49DL322BGT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000000K (AM49DL322BGT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000000L (AM49DL322BGB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000000M (AM49DL322BGB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000000N (AM49DL323BGT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000000O (AM49DL323BGT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000000P (AM49DL323BGB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000000Q (AM49DL323BGB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000000R (AM49DL324BGT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000000S (AM49DL324BGT)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000000T (AM49DL324BGB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000000U (AM49DL324BGB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000001A (AM49DL320BGB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000001B (AM49DL320BGB)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M49000001Y (AM49PDL640AG)@FBGA73 [ ( SA642A-B032A-Y096N001 ) ]  
M49000001Z (AM49PDL640AG)@FBGA73 [ ( SA642A-B032A-Y096N001 ) ]  
M490000025 (AM49DL640AG)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M490000026 (AM49DL640AG)@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
M490000028 (AM49PDL127BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M490000029 (AM49PDL127BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M49000002I (AM49PDL127AH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M49000002J (AM49PDL127AH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M49000002T (AM49LV6408MT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000002U (AM49LV6408MB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000002V (AM49LV6408MT)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M49000002X (AM49LV6408MB)@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
M490000030 (AM49PDL129BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
M490000031 (AM49PDL129BH)@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]

M490000032 (AM49DL3208GB)@FBGA69 [ (SA642A-B032A-Y096F001) ]  
M490000032 (AM49DL3208GT)@FBGA69 [ (SA642A-B032A-Y096F001) ]  
M490000034 (AM49DL3208GT)@FBGA69 [ (SA642A-B032A-Y096F001) ]  
M490000035 (AM49DL3208GB)@FBGA69 [ (SA642A-B032A-Y096F001) ]  
M49000003A (AM49DL640BH)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M49000003B (AM49DL640BH)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M49000003C (AM49DL640BH)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M49000003D (AM49DL640AH)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M49000003E (AM49DL640AH)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M49000003F (AM49DL6408H)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M49000003G (AM49DL6408H)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M49000003H (AM49DL6408H)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M49000003I (AM49DL6408H)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M49000003J (AM49DL640AH)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M49000003X (AM49DL6408H)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M49000003Y (AM49DL6408H)@FBGA73 [ (SA642A-B032A-Y096F001) ]  
M49000003Z (AM49LV6408MT)@FBGA69 [ (SA642A-B032A-Y096F001) ]  
M49000004A (AM49LV6408MB)@FBGA69 [ (SA642A-B032A-Y096F001) ]  
M49000004B (AM49BDS640AH)@FBGA89 [ (SA642A-B072A-Y096F001) ]  
M49000004C (AM49BDS640AH)@FBGA89 [ (SA642A-B072A-Y096F001) ]  
M49000004D (AM49BDS640AH)@FBGA89 [ (SA642A-B072A-Y096F001) ]  
M49000004E (AM49BDS640AH)@FBGA89 [ (SA642A-B072A-Y096F001) ]  
M49000004H (AM49LV128BMH)@FBGA64 [ (SA642C-B039A-Y056F001) ]  
M49000004J (AM49LV128BML)@FBGA64 [ (SA642C-B039A-Y056F001) ]  
M49000004K (AM49LV128BMH)@FBGA64 [ (SA642C-B039A-Y056F001) ]  
M49000004L (AM49LV128BML)@FBGA64 [ (SA642C-B039A-Y056F001) ]  
M49000004S (AM49LV128BMaH)@FBGA64 [ (SA642C-B039A-Y056F001) ]  
M49000004T (AM49LV128BMaL)@FBGA64 [ (SA642C-B039A-Y056F001) ]  
M49000004U (AM49LV128BMaH)@FBGA64 [ (SA642C-B039A-Y056F001) ]  
M49000004V (AM49LV128BMaL)@FBGA64 [ (SA642C-B039A-Y056F001) ]  
M4900000K (AM49PDL129AH)@FBGA73 [ (SA642A-B039A-Y096F001) ]  
M4900000L (AM49PDL129AH)@FBGA73 [ (SA642A-B039A-Y096F001) ]  
M500000000 (AM50DL128BG)@FBGA73 [ (SA642A-B039A-Y096F001) ]  
M500000001 (AM50DL128BG)@FBGA73 [ (SA642A-B039A-Y096F001) ]  
M500000008 (AM50DL128CG)@FBGA88 [ (SA642A-B062A-Y096F001) ]  
M500000009 (AM50DL128CG)@FBGA88 [ (SA642A-B062A-Y096F001) ]  
M50000004J (AM50DL128BH)@FBGA73 [ (SA642A-B039A-Y096F001) ]  
M50000004K (AM50DL128BH)@FBGA73 [ (SA642A-B039A-Y096F001) ]  
M50000004L (AM50DL128BH)@FBGA73 [ (SA642A-B039A-Y096F001) ]  
M50000004M (AM50DL128CH)@FBGA88 [ (SA642A-B062A-Y096F001) ]  
M50000004N (AM50DL128CH)@FBGA88 [ (SA642A-B062A-Y096F001) ]  
M50000004P (AM50DL128CH)@FBGA88 [ (SA642A-B062A-Y096F001) ]  
M550000000 (AM55DL128C8G)@FBGA93 [ (SA642A-B078A-Y096N001) ]

M550000001 (AM55DL128C8G)@FBGA93 [ (SA642A-B078A-Y096N001) ]  
 PDL127H53V (AM29PDL127H53)@FBGA80 [ (SA642A-B070A-Y096N001) ]  
 PDL127H63V (AM29PDL127H63)@FBGA80 [ (SA642A-B070A-Y096N001) ]  
 PDL127H68V (AM29PDL127H68)@FBGA80 [ (SA642A-B070A-Y096N001) ]  
 PDL127H88V (AM29PDL127H88)@FBGA80 [ (SA642A-B070A-Y096N001) ]  
 PDL129H53V (AM29PDL129H53)@FBGA80 [ (SA642A-B070A-Y096N001) ]  
 PDL129H63V (AM29PDL129H63)@FBGA80 [ (SA642A-B070A-Y096N001) ]  
 PDL129H68V (AM29PDL129H68)@FBGA80 [ (SA642A-B070A-Y096N001) ]  
 PDL129H88V (AM29PDL129H88)@FBGA80 [ (SA642A-B070A-Y096N001) ]

## PLD

M4A3-32/32@PLCC44 [ (SA244) ] [ (SA245A) ]	M4A3-32/32@TQFP44
M4A3-32/32@TQFP48 [ (SA248) ] [ (SA244) ]	M4A3-64/32@PLCC44
M4A3-64/32@TQFP44 [ (SA245A) ] [ (SA248) ]	M4A3-64/32@TQFP48
M4A5-32/32@PLCC44 [ (SA244) ] [ (SA245A) ]	M4A5-32/32@TQFP44
M4A5-32/32@TQFP48 [ (SA248) ] [ (SA244) ]	M4A5-64/32@PLCC44
M4A5-64/32@TQFP44 [ (SA245A) ] [ (SA248) ]	M4A5-64/32@TQFP48
PALC16L8Q [ (SA001A) ]	PALC16L8Q@PLCC20
PALC16L8Z [ (SA001A) ]	PALC16L8Z@PLCC20
PALC16R4Q [ (SA001A) ]	PALC16R4Q@PLCC20
PALC16R4Z [ (SA001A) ]	PALC16R4Z@PLCC20
PALC16R6Q [ (SA001A) ]	PALC16R6Q@PLCC20
PALC16R6Z [ (SA001A) ]	PALC16R6Z@PLCC20
PALC16R8Q [ (SA001A) ]	PALC16R8Q@PLCC20
PALC16R8Z [ (SA001A) ]	PALC16R8Z@PLCC20
PALCE16V8H [ (SA001A) ]	PALCE16V8H@PLCC20

PALCE16V8H@SOIC20 [(SA404)]	
PALCE16V8Q	
PALCE16V8Q@PLCC20 [(SA001A)]	PALCE16V8Q@SOIC20
[(SA404)]	
PALCE16V8Z	
[(SA001A)]	PALCE16V8Z@PLCC20
PALCE16V8Z@SOIC20 [(SA404)]	
PALCE20RA10	
PALCE20RA10@PLCC28 [(SA008A)]	PALCE20RA10@SOIC24
[(SA404)]	
PALCE20RA10H	
[(SA008A)]	PALCE20RA10H@PLCC28
PALCE20RA10H@SOIC24 [(SA404)]	
PALCE20RA10Q	
PALCE20RA10Q@PLCC28 [(SA008A)]	PALCE20RA10Q@SOIC24
[(SA404)]	
PALCE20V8H	
[(SA008A)]	PALCE20V8H@PLCC28
PALCE20V8H@SOIC24 [(SA404)]	
PALCE20V8Q	
PALCE20V8Q@PLCC28 [(SA008A)]	PALCE20V8Q@SOIC24
[(SA404)]	
PALCE22V10H	
[(SA008A)]	PALCE22V10H@PLCC28
PALCE22V10H@SOIC24 [(SA404)]	
PALCE22V10Q	
PALCE22V10Q@PLCC28 [(SA008A)]	PALCE22V10Q@SOIC24
[(SA404)]	
PALCE22V10Z	
[(SA008A)]	PALCE22V10Z@PLCC28
PALCE22V10Z@SOIC24 [(SA404)]	
PALLV16V8	
PALLV16V8@PLCC20 [(SA001A)]	PALLV16V8@SOIC20
[(SA404)]	
PALLV16V8Z	
[(SA001A)]	PALLV16V8Z@PLCC20
PALLV16V8Z@SOIC20 [(SA404)]	

## MICROCONTROLLER

AM87C51	AM87C51@PLCC44
[(SA244)]	

AM87C51@TQFP44 [(SA245A)]  
AM87C521  
AM87C521@PLCC44 [(SA244)]  
[(SA245A)]  
AM87C541  
[(SA244)]  
AM87C541@TQFP44 [(SA245A)]

AM87C521@TQFP44  
  
AM87C541@PLCC44

## AMI SEMICONDUCTOR

### E (E) PROM/FRAM/NVRAM

N256S0818HDA  
[(SA602A)]  
N256S0818HDA@TSSOP8 [(SA026)]  
N256S0830HDA  
N256S0830HDA@SOIC8 [(SA602A)]  
[(SA026)]  
N64S0818HDA  
[(SA602A)]  
N64S0818HDA@TSSOP8 [(SA026)]  
N64S0830HDA  
N64S0830HDA@SOIC8 [(SA602A)]  
[(SA026)]

N256S0818HDA@SOIC8  
  
N256S0830HDA@TSSOP8  
  
N64S0818HDA@SOIC8  
  
N64S0830HDA@TSSOP8

## AMIC

### E (E) PROM/FRAM/NVRAM

A25L010  
[(SA602A)]  
A25L010[209mil]@SOP8 [(SA605A)]  
A25L016  
A25L016@SOP8 [(SA023A)]  
A25L020  
A25L020[150mil]@SOP8 [(SA602A)]  
[(SA605A)]  
A25L032  
[(SA023A)]  
A25L040P

A25L010[150mil]@SOP8  
  
A25L020[209mil]@SOP8  
  
A25L032@SOP8  
  
A25L040P@QFN8

[(SA683)]  
 A25L040P@SOP16 [(SA404)] A25L040P@SOP8  
 [(SA602A)]  
 A25L05P(Bottom) A25L05P(Bottom)@QFN8  
 [(SA683)]  
 A25L05P(Bottom)[150mil]@SOP8 [(SA602A)]  
 A25L05P(Bottom)[209mil]@SOP8 [(SA605A)]  
 A25L05P(Top) A25L05P(Top)@QFN8  
 [(SA683)]  
 A25L05P(Top)[150mil]@SOP8 [(SA602A)]  
 A25L05P(Top)[209mil]@SOP8 [(SA605A)]  
 A25L080P A25L080P@QFN8  
 [(SA683)]  
 A25L080P@SOP16 [(SA404)] A25L080P@SOP8  
 [(SA023A)]  
 A25L10P(Bottom) A25L10P(Bottom)@QFN8  
 [(SA683)]  
 A25L10P(Bottom)[150mil]@SOP8 [(SA602A)]  
 A25L10P(Bottom)[209mil]@SOP8 [(SA605A)]  
 A25L10P(Top) A25L10P(Top)@QFN8  
 [(SA683)]  
 A25L10P(Top)[150mil]@SOP8 [(SA602A)]  
 A25L10P(Top)[209mil]@SOP8 [(SA605A)]  
 A25L16P(Bottom)@QFN8 [(SA683)]  
 A25L16P(Bottom)@QFN8(ISP) [ISP-HEADER01]  
 A25L16P(Bottom)@SOP16 [(SA404)]  
 A25L16P(Bottom)@SOP16(ISP) [ISP-HEADER01]  
 A25L16P(Bottom)@SOP8 [(SA023A)]  
 A25L16P(Bottom)@SOP8(ISP) [ISP-HEADER01]  
 A25L16P(Top)@QFN8 [(SA683)]  
 A25L16P(Top)@QFN8(ISP) [ISP-HEADER01]  
 A25L16P(Top)@SOP16 [(SA404)]  
 A25L16P(Top)@SOP16(ISP) [ISP-HEADER01]  
 A25L16P(Top)@SOP8 [(SA023A)]  
 A25L16P(Top)@SOP8(ISP) [ISP-HEADER01]  
 A25L20P(Bottom) A25L20P(Bottom)@QFN8  
 [(SA683)]  
 A25L20P(Bottom)[150mil]@SOP8 [(SA602A)]  
 A25L20P(Bottom)[209mil]@SOP8 [(SA605A)]  
 A25L20P(Top) A25L20P(Top)@QFN8  
 [(SA683)]  
 A25L20P(Top)[150mil]@SOP8 [(SA602A)]  
 A25L20P(Top)[209mil]@SOP8 [(SA605A)]

A25L40P(Bottom Boot)	
A25L40P(Bottom Boot)@QFN8 [(SA683)]	
A25L40P(Bottom Boot)@SOP16 [(SA404)]	
A25L40P(Bottom Boot)@SOP8 [(SA602A)]	
A25L40P(Top Boot)	A25L40P(Top Boot)@QFN8
[(SA683)]	
A25L40P(Top Boot)@SOP16 [(SA404)]	
A25L40P(Top Boot)@SOP8 [(SA602A)]	
A25L42P(Bottom Boot)	
A25L42P(Bottom Boot)@QFN8 [(SA683)]	
A25L42P(Bottom Boot)@SOP16 [(SA404)]	
A25L42P(Bottom Boot)@SOP8 [(SA602A)]	
A25L42P(Top Boot)	A25L42P(Top Boot)@QFN8
[(SA683)]	
A25L42P(Top Boot)@SOP16 [(SA404)]	
A25L42P(Top Boot)@SOP8 [(SA602A)]	
A25L512	A25L512[150mil]@SOP8
[(SA602A)]	
A25L512[209mil]@SOP8 [(SA605A)]	
A25L80P	
A25L80P@QFN8 [(SA683)]	A25L80P@SOP16
[(SA404)]	
A25L80P@SOP8 [(SA023A)]	A25L82P(Bottom
Boot)	
A25L82P(Bottom Boot)@QFN8 [(SA683)]	
A25L82P(Bottom Boot)@SOP16 [(SA404)]	
A25L82P(Bottom Boot)@SOP8 [(SA023A)]	
A25L82P(Top Boot)	A25L82P(Top Boot)@QFN8
[(SA683)]	
A25L82P(Top Boot)@SOP16 [(SA404)]	
A25L82P(Top Boot)@SOP8 [(SA023A)]	
A25LS080P	A25LS080P@QFN8
[(SA683)]	
A25LS080P@SOP16 [(SA404)]	A25LS080P@SOP8
[(SA023A)]	
A27020	A27020@PLCC32
[(SA015A1T)]	
A27020@TSOP32 [(SA410T)]	
A27020L	
A27020L@PLCC32 [(SA015A1T)]	A27020L@TSOP32
[(SA410T)]	
A275308	A275308@PLCC32
[(SA015A1T)]	

A276308	A276308
(E)	
A276308(E)@PLCC32 [(SA015A1T)]	A276308(E)@SOIC28
[(SA404)]	
A276308@PLCC32 [(SA015A1T)]	A276308@SOIC28
[(SA404)]	
A276308A	A276308A
(L)	
A276308A(L)@PLCC32 [(SA015A1T)]	A276308A(L)@SOIC28
[(SA404)]	
A276308A@PLCC32 [(SA015A1T)]	A276308A@SOIC28
[(SA404)]	
A277308	A277308@PLCC32
[(SA015A1T)]	
A277308A	A277308A@PLCC32
[(SA015A1T)]	
A278308	A278308@PLCC32
[(SA015A1T)]	
A278308A	A278308A
(L)	
A278308A(L)@PLCC32 [(SA015A1T)]	A278308A@PLCC32
[(SA015A1T)]	
A279308	A279308@PLCC32
[(SA015A1T)]	
A290011T	A290011T@PLCC32
[(SA015A1T)]	
A290011T@TSOP32 [(SA410T)]	
A290011U	
A290011U@PLCC32 [(SA015A1T)]	A290011U@TSOP32
[(SA410T)]	
A29001T	A29001T@PLCC32
[(SA015A1T)]	
A29001T@TSOP32 [(SA410T)]	
A29001U	
A29001U@PLCC32 [(SA015A1T)]	A29001U@TSOP32
[(SA410T)]	
A290021T	A290021T@PLCC32
[(SA015A1T)]	
A290021T@TSOP32 [(SA410T)]	
A290021U	
A290021U@PLCC32 [(SA015A1T)]	A290021U@TSOP32
[(SA410T)]	
A29002T	A29002T@PLCC32



[ (SA015A1T) ]	
A29002T@TSOP32 [ (SA410T) ]	
A29002U	
A29002U@PLCC32 [ (SA015A1T) ]	A29002U@TSOP32
[ (SA410T) ]	
A29010	A29010@PLCC32
[ (SA015A1T) ]	
A29010@TSOP32 [ (SA410T) ]	
A29040	
A29040@PLCC32 [ (SA015A1T) ]	A29040@TSOP32
[ (SA410T) ]	
A29040A	A29040A@PLCC32
[ (SA015A1T) ]	
A29040A@TSOP32 [ (SA410T) ]	
A29040B	
A29040B@PLCC32 [ (SA015A1T) ]	A29040B@TSOP32
[ (SA410T) ]	
A29400TM@PSOP44 [ (SA638) ]	A29400TV@TSOP48 [ (SA247-
B005) ]	
A29400UM@PSOP44 [ (SA638) ]	A29400UV@TSOP48 [ (SA247-
B005) ]	
A29512	A29512@PLCC32
[ (SA015A1T) ]	
A29512@TSOP32 [ (SA410T) ]	
A29512A	
A29512A@PLCC32 [ (SA015A1T) ]	A29512A@TSOP32
[ (SA410T) ]	
A29800TM@PSOP44 [ (SA638) ]	A29800TV@TSOP48 [ (SA247-
B005) ]	
A29800UM@PSOP44 [ (SA638) ]	A29800UV@TSOP48 [ (SA247-
B005) ]	
A29DL162TG@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
A29DL162TV@TSOP48 [ (SA247-B005) ]	
A29DL162UG@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
A29DL162UV@TSOP48 [ (SA247-B005) ]	
A29DL163TG@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
A29DL163TV@TSOP48 [ (SA247-B005) ]	
A29DL163UG@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
A29DL163UV@TSOP48 [ (SA247-B005) ]	
A29DL164TG@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
A29DL164TV@TSOP48 [ (SA247-B005) ]	
A29DL164UG@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
A29DL164UV@TSOP48 [ (SA247-B005) ]	

A29DL320FTV@TSOP48 [(SA247-B005)]  
A29DL320FUV@TSOP48 [(SA247-B005)]  
A29DL322TG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL322TV@TSOP48 [(SA247-B005)]  
A29DL322UG@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL322UV@TSOP48 [(SA247-B005)]  
A29DL323TG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL323TG@FBGA63 [(SA642A-B026A-Y096F001)]  
A29DL323TV(New)@TSOP48 [(SA247-B005)]  
A29DL323TV@TSOP48 [(SA247-B005)]  
A29DL323UG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL323UG@FBGA63 [(SA642A-B026A-Y096F001)]  
A29DL323UV(New)@TSOP48 [(SA247-B005)]  
A29DL323UV@TSOP48 [(SA247-B005)]  
A29DL324TG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL324TG@FBGA63 [(SA642A-B026A-Y096F001)]  
A29DL324TV(New)@TSOP48 [(SA247-B005)]  
A29DL324TV@TSOP48 [(SA247-B005)]  
A29DL324UG(New)@FBGA48 [(SA642G-B026A-T048F001Y)]  
A29DL324UG@FBGA63 [(SA642A-B026A-Y096F001)]  
A29DL324UV(New)@TSOP48 [(SA247-B005)]  
A29DL324UV@TSOP48 [(SA247-B005)]      A29L004ATL@PLCC32  
[(SA015A1T)]  
A29L004ATV@TSOP32 [(SA410T)]      A29L004ATW@TSOP40  
[(SA409T)]  
A29L004ATY@VSOP32 [(SA620)]      A29L004AUL@PLCC32  
[(SA015A1T)]  
A29L004AUV@TSOP32 [(SA410T)]      A29L004AUW@TSOP40  
[(SA409T)]  
A29L004AUY@VSOP32 [(SA620)]      A29L004T@PLCC32  
[(SA015A1T)]  
A29L004T@TSOP32 [(SA410T)]      A29L004T@TSOP40  
[(SA409T)]  
A29L004T@VSOP32 [(SA620)]      A29L004U@PLCC32  
[(SA015A1T)]  
A29L004U@TSOP32 [(SA410T)]      A29L004U@TSOP40  
[(SA409T)]  
A29L004U@VSOP32 [(SA620)]      A29L008ATV@TSOP40  
[(SA409T)]  
A29L008AUV@TSOP40 [(SA409T)]      A29L008T@TSOP40  
[(SA409T)]  
A29L008U@TSOP40 [(SA409T)]  
A29L040

A29L040@PLCC32 [ (SA015A1T) ]                      A29L040@TSOP32  
[ (SA410T) ]  
A29L040@VSOP32 [ (SA620) ]  
A29L160ATG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29L160ATM@PSOP44 [ (SA638) ]                      A29L160ATV@TSOP48 [ (SA247-  
B005) ]  
A29L160AUG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29L160AUM@PSOP44 [ (SA638) ]                      A29L160AUV@TSOP48 [ (SA247-  
B005) ]  
A29L160BTG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29L160BTGB@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29L160BTM@PSOP44 [ (SA638) ]                      A29L160BTV@TSOP48 [ (SA247-  
B005) ]  
A29L160BUG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29L160BUGB@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29L160BUM@PSOP44 [ (SA638) ]                      A29L160BUV@TSOP48 [ (SA247-  
B005) ]  
A29L160HTG@FBGA48 [ (SA642B-B026A-Y072F001) ]  
A29L160HTV@TSOP48 [ (SA247-B005) ]  
A29L160HUG@FBGA48 [ (SA642B-B026A-Y072F001) ]  
A29L160HUV@TSOP48 [ (SA247-B005) ]  
A29L160TG@FBGA48 [ (SA642B-B026A-Y072F001) ]  
A29L160TM@PSOP44 [ (SA638) ]                      A29L160TV@TSOP48 [ (SA247-  
B005) ]  
A29L160UG@FBGA48 [ (SA642B-B026A-Y072F001) ]  
A29L160UM@PSOP44 [ (SA638) ]                      A29L160UV@TSOP48 [ (SA247-  
B005) ]  
A29L320ATG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29L320ATV@TSOP48 [ (SA247-B005) ]  
A29L320AUG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29L320AUV@TSOP48 [ (SA247-B005) ]  
A29L400ATG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29L400ATM@PSOP44 [ (SA638) ]                      A29L400ATV@TSOP48 [ (SA247-  
B005) ]  
A29L400AUG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29L400AUM@PSOP44 [ (SA638) ]                      A29L400AUV@TSOP48 [ (SA247-  
B005) ]  
A29L400TG@FBGA48 [ (SA642B-B026A-Y072F001) ]  
A29L400TM@PSOP44 [ (SA638) ]                      A29L400TV@TSOP48 [ (SA247-  
B005) ]  
A29L400UG@FBGA48 [ (SA642B-B026A-Y072F001) ]  
A29L400UM@PSOP44 [ (SA638) ]                      A29L400UV@TSOP48 [ (SA247-  
B005) ]

A29L800ATG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29L800ATM@PSOP44 [ (SA638) ] A29L800ATV@TSOP48 [ (SA247-B005) ]  
A29L800AUG@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
A29L800AUM@PSOP44 [ (SA638) ] A29L800AUV@TSOP48 [ (SA247-B005) ]  
A29L800HTG@FBGA48 [ (SA642B-B026A-Y072F001) ]  
A29L800HTM@PSOP44 [ (SA638) ] A29L800HTV@TSOP48 [ (SA247-B005) ]  
A29L800HUG@FBGA48 [ (SA642B-B026A-Y072F001) ]  
A29L800HUM@PSOP44 [ (SA638) ] A29L800HUV@TSOP48 [ (SA247-B005) ]  
A29L800TG@FBGA48 [ (SA642B-B026A-Y072F001) ]  
A29L800TM@PSOP44 [ (SA638) ] A29L800TV@TSOP48 [ (SA247-B005) ]  
A29L800UG@FBGA48 [ (SA642B-B026A-Y072F001) ]  
A29L800UM@PSOP44 [ (SA638) ] A29L800UV@TSOP48 [ (SA247-B005) ]  
A49LF004@PLCC32 [ (SA015A1T) ] A49LF004@VSOP32 [ (SA620) ]  
A49LF004M@PLCC32 [ (SA015A1T) ] A49LF004M@VSOP32 [ (SA620) ]  
A49LF040ATL@PLCC32 [ (SA015A1T) ] A49LF040ATX@VSOP32 [ (SA620) ]  
A49LF040ATY@VSOP32 [ (SA620) ] A49LF040TL@PLCC32 [ (SA015A1T) ]  
A49LF040TX@VSOP32 [ (SA620) ] A50FW040@PLCC32 [ (SA015A1T) ]  
A50FW040@VSOP32 [ (SA620) ] A50FW040M@PLCC32 [ (SA015A1T) ]  
A50FW040M@VSOP32 [ (SA620) ] A50LPW040@PLCC32 [ (SA015A1T) ]  
A50LPW040@TSOP32 [ (SA410T) ]  
A617308  
A617308@TSOP32 [ (SA410T) ]  
A61L5308  
A61L5308@TSOP28 [ (SA430T) ] A623308 (M)  
A623308 (R)@TSOP28 [ (SA430T) ] A623308 (V)@TSOP28 [ (SA430T) ]  
A625308 (M) A625308 (R)@TSOP28 [ (SA430T) ]  
A625308 (V)@TSOP28 [ (SA430T) ]

A62L256  
 A62L256 (M) A62L256 (R)@TSOP28  
 [ (SA430T) ]  
 A62L256 (V)@TSOP28 [ (SA430T) ] A62S6308  
 (M)  
 A62S6308 (X)@TSOP32 [ (SA410T) ] A62S7308A  
 (M)  
 A62S7308A (X)@TSOP32 [ (SA410T) ] A62S8308A  
 (M)  
 A62S8308A (X)@TSOP32 [ (SA410T) ] A62W5308  
 (M)  
 A62W5308 (R)@TSOP28 [ (SA430T) ] A62W5308 (V)@TSOP28  
 [ (SA430T) ]  
 A81L801TG@FBGA69 [ (SA642A-B078A-Y096F001Y) ]  
 A81L801UG@FBGA69 [ (SA642A-B078A-Y096F001Y) ]  
 A82DL1622TG@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
 A82DL1622UG@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
 A82DL1624TG@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
 A82DL1624UG@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
 A82DL1632TG@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
 A82DL1632UG@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
 A82DL1634TG@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
 A82DL1634UG@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
 A82DL1642TG@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
 A82DL1642UG@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
 A82DL1644TG@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
 A82DL1644UG@FBGA69 [ (SA642A-B032A-Y096F001Y) ]  
 A82DL32216TG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL32216UG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL3224TG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL3224UG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL3228TG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL3228UG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL32316TG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL32316UG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL3234TG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL3234UG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL3238TG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL3238UG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL32416TG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL32416UG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL3244TG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]  
 A82DL3244UG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]

A82DL3248TG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]

A82DL3248UG@FBGA69 [ (SA642A-B254A-Y096F001Y) ]

**ANACHIP****E ( E ) PROM / FRAM / NVRAM**

27CX010	27CX010@PLCC32
[ (SA015A1T) ]	
27CX010@TSOP32 [ (SA410T) ]	
27CX161	
27CX162	
27CX256	
27CX321	
27CX322	
27CX641	
27CX642	
93C46	93C46@SOIC8
[ (SA602A) ]	
93C46A	93C46A@SOIC8
[ (SA602A) ]	
93C56A	93C56A@SOIC8
[ (SA602A) ]	
93C66A	93C66A@SOIC8
[ (SA602A) ]	
93CX46	93CX46@SOIC8
[ (SA602A) ]	
93CX56	93CX56@SOIC8
[ (SA602A) ]	
93CX66	93CX66@SOIC8
[ (SA602A) ]	
AM24LC02	AM24LC02@SOIC8
[ (SA602A) ]	
AM24LC02@TSSOP8 [ (SA026) ]	
AM24LC04	
AM24LC04@SOIC8 [ (SA602A) ]	AM24LC04@TSSOP8
[ (SA026) ]	
AM24LC08	AM24LC08@SOIC8
[ (SA602A) ]	
AM24LC08@TSSOP8 [ (SA026) ]	
AM24LC16	
AM24LC16@SOIC8 [ (SA602A) ]	AM24LC16@TSSOP8

[(SA026)]	
AM24LC21	AM24LC21@SOIC8
[(SA602A)]	
AM24LC21@TSSOP8 [(SA026)]	
AM24LC21B	
AM24LC21B@SOIC8 [(SA602A)]	AM24LC21B@TSSOP8
[(SA026)]	
AM93LC46(08bit)	AM93LC46(08bit)@SOIC8
[(SA602A)]	
AM93LC46(08bit)@TSOP8 [(SA026)]	AM93LC46
(16bit)	
AM93LC46(16bit)@SOIC8 [(SA602A)]	AM93LC46(16bit)@TSOP8
[(SA026)]	
AM93LC56(08bit)	AM93LC56(08bit)@SOIC8
[(SA602A)]	
AM93LC56(08bit)@TSOP8 [(SA026)]	AM93LC56
(16bit)	
AM93LC56(16bit)@SOIC8 [(SA602A)]	AM93LC56(16bit)@TSOP8
[(SA026)]	
AM93LC66(08bit)	AM93LC66(08bit)@SOIC8
[(SA602A)]	
AM93LC66(08bit)@TSOP8 [(SA026)]	AM93LC66
(16bit)	
AM93LC66(16bit)@SOIC8 [(SA602A)]	AM93LC66(16bit)@TSOP8
[(SA026)]	
AM93LC86(08bit)	AM93LC86(08bit)@SOIC8
[(SA602A)]	
AM93LC86(08bit)@TSOP8 [(SA026)]	AM93LC86
(16bit)	
AM93LC86(16bit)@SOIC8 [(SA602A)]	AM93LC86(16bit)@TSOP8
[(SA026)]	

## PLD

PA7024	PA7024(J)@PLCC28
[(SA008A)]	
PA7024(JN)@PLCC28 [(SA008A)]	PA7024@SOIC24
[(SA404)]	
PA7128	PA7128@PLCC28
[(SA008A)]	
PA7128@SOIC28 [(SA404)]	
PA7140	

PA7140@PLCC44 [(SA244)]	PA7140@TQFP44
[(SA245A)]	
PA7536	PA7536@PLCC28
[(SA008A)]	
PA7536@SOIC28 [(SA404)]	
PA7540	
PA7540(J)@PLCC28 [(SA008A)]	PA7540(JN)@PLCC28
[(SA008A)]	
PA7572	PA7572@PLCC44
[(SA244)]	
PA7572@TQFP44 [(SA245A)]	
PEEL18CV8Z	
PEEL18CV8Z@PLCC20 [(SA001A)]	PEEL18CV8Z@SOIC20
[(SA404)]	
PEEL18CV8Z@TSOP20 [(SA026)]	
PEEL18LV8Z	
PEEL18LV8Z@PLCC20 [(SA001A)]	PEEL18LV8Z@SOIC20
[(SA404)]	
PEEL18LV8Z@TSOP20 [(SA026)]	
PEEL22CV10A	
PEEL22CV10A@PLCC28 [(SA008A)]	PEEL22CV10A@SOIC24
[(SA404)]	
PEEL22CV10A@TSOP24 [(SA026)]	PEEL22CV10A
+	
PEEL22CV10A+@PLCC28 [(SA008A)]	PEEL22CV10A+@SOIC24
[(SA404)]	
PEEL22CV10A+@TSOP24 [(SA026)]	PEEL22CV10A+
+	
PEEL22CV10A++@PLCC28 [(SA008A)]	PEEL22CV10A++@SOIC24
[(SA404)]	
PEEL22CV10A++@TSOP24 [(SA026)]	
PEEL22CV10AZ	
PEEL22CV10AZ@PLCC28 [(SA008A)]	PEEL22CV10AZ@SOIC24
[(SA404)]	
PEEL22CV10AZ@TSOP24 [(SA026)]	PEEL22CV10AZ
+	
PEEL22CV10AZ+@PLCC28 [(SA008A)]	PEEL22CV10AZ+@SOIC24
[(SA404)]	
PEEL22CV10AZ+@TSOP24 [(SA026)]	PEEL22CV10AZ+
+	
PEEL22CV10AZ++@PLCC28 [(SA008A)]	PEEL22CV10AZ++@SOIC24
[(SA404)]	
PEEL22CV10AZ++@TSOP24 [(SA026)]	



PEEL22LV10AZ

PEEL22LV10AZ@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22LV10AZ@TSOP24 [(SA026)]

+

PEEL22LV10AZ+@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22LV10AZ+@TSOP24 [(SA026)]

+

PEEL22LV10AZ++@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22LV10AZ++@TSOP24 [(SA026)]

PEEL22LV10AZ@SOIC24

PEEL22LV10AZ

PEEL22LV10AZ+@SOIC24

PEEL22LV10AZ+

PEEL22LV10AZ++@SOIC24

## APLUS FLASH

### E ( E ) PROM / FRAM / NVRAM

AF24BC01

[(SA602A)]

AF24BC01@TSSOP8 [(SA026)]

AF24BC02

AF24BC02@SOIC8 [(SA602A)]

[(SA026)]

AF24BC04

[(SA602A)]

AF24BC04@TSSOP8 [(SA026)]

AF24BC08

AF24BC08@SOIC8 [(SA602A)]

[(SA026)]

AF24BC128

[(SA602A)]

AF24BC128@TSOP8 [(SA026)]

AF24BC16

AF24BC16@SOIC8 [(SA602A)]

[(SA026)]

AF24BC256

[(SA602A)]

AF24BC256@TSOP8 [(SA026)]

AF24BC32

AF24BC32@SOIC8 [(SA602A)]

[(SA026)]

AF24BC64

AF24BC01@SOIC8

AF24BC02@TSSOP8

AF24BC04@SOIC8

AF24BC08@TSSOP8

AF24BC128@SOIC8

AF24BC16@TSSOP8

AF24BC256@SOIC8

AF24BC32@TSOP8

AF24BC64@SOIC8

[ (SA602A) ]	
AF24BC64@TSOP8 [ (SA026) ]	
AF24C128	
AF24C128@SOIC8 [ (SA602A) ]	AF24C128@TSOP8
[ (SA026) ]	
AF24C256	
[ (SA602A) ]	
AF24C256@TSOP8 [ (SA026) ]	AF24C256@SOIC8
AF24C32	
AF24C32@SOIC8 [ (SA602A) ]	AF24C32@TSOP8
[ (SA026) ]	
AF24C64	
[ (SA602A) ]	
AF24C64@TSOP8 [ (SA026) ]	AF24C64@SOIC8
AF25BC128	
AF25BC128@SOIC8 [ (SA602A) ]	AF25BC128@TSOP8
[ (SA026) ]	
AF25BC256	
[ (SA602A) ]	
AF25BC256@TSOP8 [ (SA026) ]	AF93BC46
(08bit)	
AF93BC46(08bit)@SOIC8 [ (SA602A) ]	AF93BC46(08bit)@TSOP8
[ (SA026) ]	
AF93BC46(16bit)	
[ (SA602A) ]	
AF93BC46(16bit)@TSOP8 [ (SA026) ]	AF93BC56
(08bit)	
AF93BC56(08bit)@SOIC8 [ (SA602A) ]	AF93BC56(08bit)@TSOP8
[ (SA026) ]	
AF93BC56(16bit)	
[ (SA602A) ]	
AF93BC56(16bit)@TSOP8 [ (SA026) ]	AF93BC66
(08bit)	
AF93BC66(08bit)@SOIC8 [ (SA602A) ]	AF93BC66(08bit)@TSOP8
[ (SA026) ]	
AF93BC66(16bit)	
[ (SA602A) ]	
AF93BC66(16bit)@TSOP8 [ (SA026) ]	AF93BC86
(08bit)	
AF93BC86(08bit)@SOIC8 [ (SA602A) ]	AF93BC86(08bit)@TSOP8
[ (SA026) ]	
AF93BC86(16bit)	
[ (SA602A) ]	
AF93BC86(16bit)@SOIC8	

AF93BC86(16bit)@TSOP8 [(SA026)] (08bit)	AF93C46
AF93C46(08bit)@SOIC8 [(SA602A)] [(SA026)]	AF93C46(08bit)@TSOP8
AF93C46(16bit) [(SA602A)]	AF93C46(16bit)@SOIC8
AF93C46(16bit)@TSOP8 [(SA026)] (08bit)	AF93C56
AF93C56(08bit)@SOIC8 [(SA602A)] [(SA026)]	AF93C56(08bit)@TSOP8
AF93C56(16bit) [(SA602A)]	AF93C56(16bit)@SOIC8
AF93C56(16bit)@TSOP8 [(SA026)] (08bit)	AF93C66
AF93C66(08bit)@SOIC8 [(SA602A)] [(SA026)]	AF93C66(08bit)@TSOP8
AF93C66(16bit) [(SA602A)]	AF93C66(16bit)@SOIC8
AF93C66(16bit)@TSOP8 [(SA026)] (08bit)	AF93C86
AF93C86(08bit)@SOIC8 [(SA602A)] [(SA026)]	AF93C86(08bit)@TSOP8
AF93C86(16bit) [(SA602A)]	AF93C86(16bit)@SOIC8
AF93C86(16bit)@TSOP8 [(SA026)]	

## ARTSCHIP

### E (E) PROM/FRAM/NVRAM

24AA02 [(SA666)]	24AA02@MSOP8
24AA02@SOIC8 [(SA602A)] [(SA698)]	24AA02@SOT5
24AA02@TSSOP8 [(SA026)]	
24LC01A	
24LC01A@SOIC8 [(SA602A)] [(SA698)]	24LC01A@SOT5
24LC01A@TSSOP8 [(SA026)]	
24LC01B	
24LC01B@SOIC8 [(SA602A)] [(SA698)]	24LC01B@SOT5

24LC01B@TSSOP8 [(SA026)]	
24LC02A	
24LC02A@SOIC8 [(SA602A)]	24LC02A@SOT5
[(SA698)]	
24LC02A@TSSOP8 [(SA026)]	
24LC02B	
24LC02B@MSOP8 [(SA666)]	24LC02B@SOIC8
[(SA602A)]	
24LC02B@SOT5 [(SA698)]	24LC02B@TSSOP8
[(SA026)]	
24LC04A	
[(SA602A)]	24LC04A@SOIC8
24LC04A@SOT5 [(SA698)]	24LC04A@TSSOP8
[(SA026)]	
24LC04B	
[(SA666)]	24LC04B@MSOP8
24LC04B@SOIC8 [(SA602A)]	24LC04B@SOT5
[(SA698)]	
24LC04B@TSSOP8 [(SA026)]	
24LC08A	
24LC08A@SOIC8 [(SA602A)]	24LC08A@SOT5
[(SA698)]	
24LC08A@TSSOP8 [(SA026)]	
24LC08B	
24LC08B@MSOP8 [(SA666)]	24LC08B@SOIC8
[(SA602A)]	
24LC08B@SOT5 [(SA698)]	24LC08B@TSSOP8
[(SA026)]	
24LC16A	
[(SA602A)]	24LC16A@SOIC8
24LC16A@SOT5 [(SA698)]	24LC16A@TSSOP8
[(SA026)]	
24LC32	
[(SA026)]	24LC32@SOIC14
24LC32@SOIC8 [(SA602A)]	24LC32@TSSOP8
[(SA026)]	
24LC64	
[(SA026)]	24LC64@SOIC14
24LC64@SOIC8 [(SA602A)]	24LC64@TSSOP8
[(SA026)]	

**ASAHI KASEI(AKM)**

**E ( E ) PROM / FRAM / NVRAM**

AK27CX161	
AK27CX162	
AK27CX321	
AK27CX322	
AK27CX641	
AK27CX642	
AK6002A(F)@SOP8 [(SA602A)]	AK6002A(V)@TSSOP8
[(SA026)]	
AK6003A(V)@TSSOP8 [(SA026)]	AK6004A(F)@SOP8
[(SA602A)]	
AK6004A(M)@SSOP8 [(SA605A)]	AK6008A(F)@SOP8
[(SA602A)]	
AK6010A(F)@SOP8 [(SA602A)]	AK6012A(F)@SOP8
[(SA602A)]	
AK6416A(M)@SSOP8 [(SA026)]	AK6416C(F)@SOP8
[(SA602A)]	
AK6420A(F)@SOP8 [(SA602A)]	AK6420A(M)@SSOP8
[(SA605A)]	
AK6420B(H)@MSOP8 [(SA666)]	AK6440A(F)@SOP8
[(SA602A)]	
AK6440A(M)@SSOP8 [(SA605A)]	AK6440B(H)@MSOP8
[(SA666)]	
AK6480A(F)@SOP8 [(SA602A)]	AK6480A(M)@SSOP8
[(SA605A)]	
AK6480B(H)@MSOP8 [(SA666)]	AK6480C(F)@SOP8
[(SA602A)]	
AK6480C(H)@MSOP8 [(SA666)]	AK6480C(L)
@SON8	
AK6480C(M)@SSOP8 [(SA605A)]	AK6481C(H)@MSOP8
[(SA666)]	
AK6481C(M)@SSOP8 [(SA605A)]	AK6508C(T)@MSOP8
[(SA666)]	
AK6508C(U)@USON8	AK6510C(L)
@SONW8	
AK6510C(M)@SSOP8 [(SA026)]	AK6512C(L)
@SONW8	
AK6512C(M)@SSOP8 [(SA026)]	AK6514C(F)@SOP8
[(SA602A)]	
AK6514C(N)@QFN20 [(SA692)]	AK6516C(F)@SOP8
[(SA602A)]	

AK93C10A(F)@SOP8 [(SA602A)]  
[(SA026)]  
AK93C45  
[(SA602A)]  
AK93C45A(F)@SOP8 [(SA602A)]  
[(SA602A)]  
AK93C45A(V)@TSSOP8 [(SA026)]  
[(SA666)]  
AK93C45B(L)@SON8  
[(SA666)]  
AK93C45C(U)@USON8  
AK93C45L  
AK93C45L(F)@SOP8 [(SA602A)]  
AK93C46  
AK93C46(F)@SOP8 [(SA602A)]  
[(SA602A)]  
AK93C46A(NF)@SOP8 [(SA602A)]  
[(SA026)]  
AK93C46B(H)@MSOP8 [(SA666)]  
@SON8  
AK93C46C(T)@MSOP8 [(SA666)]  
@USON8  
AK93C46L  
[(SA602A)]  
AK93C51A(V)@TSSOP8 [(SA026)]  
AK93C55  
AK93C55(F)@SOP8 [(SA602A)]  
[(SA602A)]  
AK93C55A(NF)@SOP8 [(SA602A)]  
[(SA026)]  
AK93C55B(H)@MSOP8 [(SA666)]  
@SON8  
AK93C55C(T)@MSOP8 [(SA666)]  
@USON8  
AK93C55L  
[(SA602A)]  
AK93C56  
[(SA602A)]  
AK93C56A(F)@SOP8 [(SA602A)]  
[(SA602A)]  
AK93C56A(V)@TSSOP8 [(SA026)]  
[(SA666)]  
AK93C56B(L)@SON8

AK93C41A(V)@TSSOP8  
AK93C45(F)@SOP8  
AK93C45A(NF)@SOP8  
AK93C45B(H)@MSOP8  
AK93C45C(T)@MSOP8  
AK93C46A(F)@SOP8  
AK93C46A(V)@TSSOP8  
AK93C46B(L)  
AK93C46C(U)  
AK93C46L(F)@SOP8  
AK93C55A(F)@SOP8  
AK93C55A(V)@TSSOP8  
AK93C55B(L)  
AK93C55C(U)  
AK93C55L(F)@SOP8  
AK93C56(F)@SOP8  
AK93C56A(NF)@SOP8  
AK93C56B(H)@MSOP8  
AK93C56C(T)@MSOP8

[ ( SA666 ) ]	
AK93C56C(U)@USON8	
AK93C56L	
AK93C56L(F)@SOP8 [ ( SA602A ) ]	AK93C61A(V)@TSSOP8
[ ( SA026 ) ]	
AK93C65	AK93C65(F)@SOP8
[ ( SA602A ) ]	
AK93C65A(F)@SOP8 [ ( SA602A ) ]	AK93C65A(NF)@SOP8
[ ( SA602A ) ]	
AK93C65A(V)@TSSOP8 [ ( SA026 ) ]	AK93C65B(H)@MSOP8
[ ( SA666 ) ]	
AK93C65B(L)@SON8	AK93C65C(T)@MSOP8
[ ( SA666 ) ]	
AK93C65C(U)@USON8	
AK93C65L	
AK93C65L(F)@SOP8 [ ( SA602A ) ]	
AK93C66	
AK93C66(F)@SOP8 [ ( SA602A ) ]	AK93C66A(F)@SOP8
[ ( SA602A ) ]	
AK93C66A(NF)@SOP8 [ ( SA602A ) ]	AK93C66A(V)@TSSOP8
[ ( SA026 ) ]	
AK93C66B(H)@MSOP8 [ ( SA666 ) ]	AK93C66B(L)
@SON8	
AK93C66C(T)@MSOP8 [ ( SA666 ) ]	AK93C66C(U)
@USON8	
AK93C66L	AK93C66L(F)@SOP8
[ ( SA602A ) ]	
AK93C75	AK93C75(F)@SOP8
[ ( SA602A ) ]	
AK93C75A(F)@SOP8 [ ( SA602A ) ]	AK93C75A(NF)@SOP8
[ ( SA602A ) ]	
AK93C75A(V)@TSSOP8 [ ( SA026 ) ]	AK93C75B(H)@MSOP8
[ ( SA666 ) ]	
AK93C75L	AK93C75L(F)@SOP8
[ ( SA602A ) ]	
AK93C85	AK93C85(F)@SOP8
[ ( SA602A ) ]	
AK93C85L	AK93C85L(F)@SOP8
[ ( SA602A ) ]	
AK93C95A(F)@SOP8 [ ( SA602A ) ]	AK9822(M)@SSOP8
[ ( SA026 ) ]	
AK9824(M)@SSOP8 [ ( SA026 ) ]	AK9844@SOIC14
[ ( SA602 ) ]	

## ASD

### E ( E ) PROM / FRAM / NVRAM

AE29F1008

AE29F2008

## ASI

### E ( E ) PROM / FRAM / NVRAM

AS58C1001

[ ( SA015A1T ) ]

AS58C1001@SSOP32 [ ( SA438T ) ]

AS58C1001@PLCC32

## ASP

### MICROCONTROLLER

AP827C51

[ ( SA244 ) ]

AP827C52

[ ( SA244 ) ]

AP827C54

[ ( SA244 ) ]

AP827C58

[ ( SA244 ) ]

AP827C51@PLCC44

AP827C52@PLCC44

AP827C54@PLCC44

AP827C58@PLCC44

## ATC

### E ( E ) PROM / FRAM / NVRAM

ATC24C02

[ ( SA602A ) ]

ATC24C02@TSSOP8 [ ( SA026 ) ]

ATC24C04

ATC24C02@SOIC8



ATC24C04@SOIC8 [(SA602A)]	ATC24C04@TSSOP8
[(SA026)]	
ATC24C08	ATC24C08@SOIC8
[(SA602A)]	
ATC24C08@TSSOP8 [(SA026)]	
ATC24C16	
ATC24C16@SOIC8 [(SA602A)]	ATC24C16@TSSOP8
[(SA026)]	
ATC24LC02	ATC24LC02@SOIC8
[(SA602A)]	
ATC24LC02@TSSOP8 [(SA026)]	
ATC24LC02A	
ATC24LC02A@SOIC8 [(SA602A)]	ATC24LC02A@TSSOP8
[(SA026)]	
ATC24LC04	ATC24LC04@SOIC8
[(SA602A)]	
ATC24LC04@TSSOP8 [(SA026)]	
ATC24LC08	
ATC24LC08@SOIC8 [(SA602A)]	ATC24LC08@TSSOP8
[(SA026)]	
ATC24LC16	ATC24LC16@SOIC8
[(SA602A)]	
ATC24LC16@TSSOP8 [(SA026)]	ATC93C46
(08bit)	
ATC93C46(08bit)@SOIC8 [(SA602A)]	ATC93C46
(16bit)	
ATC93C46(16bit)@SOIC8 [(SA602A)]	
ATC93C46R(08bit)@SOIC8 [(SA602A)]	
ATC93C46R(16bit)@SOIC8 [(SA602A)]	
ATC93C56(08bit)	ATC93C56(08bit)@SOIC8
[(SA602A)]	
ATC93C56(16bit)	ATC93C56(16bit)@SOIC8
[(SA602A)]	
ATC93C56R(08bit)@SOIC8 [(SA602A)]	
ATC93C56R(16bit)@SOIC8 [(SA602A)]	
ATC93C66(08bit)	ATC93C66(08bit)@SOIC8
[(SA602A)]	
ATC93C66(16bit)	ATC93C66(16bit)@SOIC8
[(SA602A)]	
ATC93C66R(08bit)@SOIC8 [(SA602A)]	
ATC93C66R(16bit)@SOIC8 [(SA602A)]	
ATC93LC46(08bit)	
ATC93LC46(08bit)@SOIC8 [(SA602A)]	

ATC93LC46(16bit)  
 ATC93LC46(16bit)@SOIC8 [(SA602A)]  
 ATC93LC46R(08bit)@SOIC8 [(SA602A)]  
 ATC93LC46R(16bit)@SOIC8 [(SA602A)]  
 ATC93LC56(08bit)  
 ATC93LC56(08bit)@SOIC8 [(SA602A)]  
 ATC93LC56(16bit)  
 ATC93LC56(16bit)@SOIC8 [(SA602A)]  
 ATC93LC56R(08bit)@SOIC8 [(SA602A)]  
 ATC93LC56R(16bit)@SOIC8 [(SA602A)]  
 ATC93LC66(08bit)  
 ATC93LC66(08bit)@SOIC8 [(SA602A)]  
 ATC93LC66(16bit)  
 ATC93LC66(16bit)@SOIC8 [(SA602A)]  
 ATC93LC66R(08bit)@SOIC8 [(SA602A)]  
 ATC93LC66R(16bit)@SOIC8 [(SA602A)]

## ATMEL

### E (E) PROM/FRAM/NVRAM

AT17C002@PLCC20 [(SA001A)] [(SA244)]	AT17C002@PLCC44
AT17C002@SOIC20 [(SA404)] [(SA245A)]	AT17C002@TQFP44
AT17C002A@PLCC20 [(SA001A)] [(SA663)]	AT17C002A@TQFP32
AT17C010 [(SA001A)]	AT17C010@PLCC20
AT17C010A [(SA001A)]	AT17C010A@PLCC20
AT17C040@PLCC44 [(SA244)] [(SA245A)]	AT17C040@TQFP44
AT17C128 [(SA001A)]	AT17C128@PLCC20
AT17C128@SOIC20 [(SA404)] [(SA602A)]	AT17C128@SOIC8
AT17C128A@PLCC20 [(SA001A)]	
AT17C256	
AT17C256@PLCC20 [(SA001A)] [(SA404)]	AT17C256@SOIC20
AT17C256@SOIC8 [(SA602A)]	AT17C256A@PLCC20

[(SA001A)]	
AT17C512	AT17C512@PLCC20
[(SA001A)]	
AT17C512A	AT17C512A@PLCC20
[(SA001A)]	
AT17C65	AT17C65@PLCC20
[(SA001A)]	
AT17C65@SOIC20 [(SA404)]	AT17C65@SOIC8
[(SA602A)]	
AT17C65A@PLCC20 [(SA001A)]	AT17F040@LAP8
[(SA760)]	
AT17F040@PLCC20 [(SA001A)]	
AT17F040@PLCC20(Virtex Pinout) [(SA001A)]	
AT17F040A@LAP8 [(SA760)]	AT17F040A@PLCC20
[(SA001A)]	
AT17F040A@TQFP32 [(SA663)]	AT17F080@LAP8
[(SA760)]	
AT17F080@PLCC20 [(SA001A)]	AT17F080@PLCC44
[(SA244)]	
AT17F080@TQFP44 [(SA245A)]	AT17F080A@LAP8
[(SA760)]	
AT17F080A@PLCC20 [(SA001A)]	AT17F080A@TQFP32
[(SA001A)]	
AT17F16@LAP8 [(SA760)]	AT17F16@PLCC20
[(SA001A)]	
AT17F16@PLCC44 [(SA244)]	AT17F16@TQFP44
[(SA245A)]	
AT17F16A@LAP8 [(SA760)]	AT17F16A@PLCC20
[(SA001A)]	
AT17F32@PLCC44 [(SA244)]	AT17F32A@PLCC44
[(SA244)]	
AT17LV002@PLCC20 [(SA001A)]	AT17LV002@PLCC44
[(SA244)]	
AT17LV002@SOIC20 [(SA404)]	AT17LV002@TQFP44
[(SA245A)]	
AT17LV002A@PLCC20 [(SA001A)]	AT17LV002A@TQFP32
[(SA663)]	
AT17LV010	AT17LV010@PLCC20
[(SA001A)]	
AT17LV010A	AT17LV010A@PLCC20
[(SA001A)]	
AT17LV040@PLCC44 [(SA244)]	AT17LV040@TQFP44
[(SA245A)]	

AT17LV128	AT17LV128@PLCC20
[(SA001A)]	
AT17LV128@SOIC20 [(SA404)]	AT17LV128@SOIC8
[(SA602A)]	
AT17LV128A@PLCC20 [(SA001A)]	
AT17LV256	
AT17LV256@PLCC20 [(SA001A)]	AT17LV256@SOIC20
[(SA404)]	
AT17LV256@SOIC8 [(SA602A)]	AT17LV256A@PLCC20
[(SA001A)]	
AT17LV512	AT17LV512@PLCC20
[(SA001A)]	
AT17LV512A	AT17LV512A@PLCC20
[(SA001A)]	
AT17LV65	AT17LV65@PLCC20
[(SA001A)]	
AT17LV65@SOIC20 [(SA404)]	AT17LV65@SOIC8
[(SA602A)]	
AT17LV65A@PLCC20 [(SA001A)]	AT17N002@SOIC20
[(SA404)]	
AT17N002@TQFP44 [(SA245A)]	
AT17N010	
AT17N010@SOIC20 [(SA404)]	AT17N040@TQFP44
[(SA245A)]	
AT17N256	AT17N256@SOIC20
[(SA404)]	
AT17N256@SOIC8 [(SA602A)]	
AT17N512	
AT17N512@SOIC20 [(SA404)]	
AT24C01	
AT24C01@MSOP8 [(SA666)]	AT24C01@SOIC8
[(SA602A)]	
AT24C01@TSSOP8 [(SA026)]	
AT24C01A	
AT24C01A@MAP8 [(SA724)]	AT24C01A@SOIC8
[(SA602A)]	
AT24C01A@SOT23-5 [(SA717)]	AT24C01A@TSSOP8
[(SA026)]	
AT24C01B	
AT24C01B@dBGA2	
AT24C01B@MAP8 [(SA724)]	AT24C01B@SOIC8
[(SA602A)]	
AT24C01B@SOT23 [(SA717)]	AT24C01B@TSSOP8

[(SA026)]	
AT24C02	AT24C02@SOIC8
[(SA602A)]	
AT24C02@TSSOP8 [(SA026)]	
AT24C02A	
AT24C02A@SOIC8 [(SA602A)]	AT24C02A@TSSOP8
[(SA026)]	
AT24C02B	
AT24C02B@dBGA2	
AT24C02B@MAP8 [(SA724)]	AT24C02B@SOIC8
[(SA602A)]	
AT24C02B@SOT23 [(SA717)]	AT24C02B@TSSOP8
[(SA026)]	
AT24C04	AT24C04@MAP8
[(SA724)]	
AT24C04@SOIC8 [(SA602A)]	AT24C04@SOT23-5
[(SA717)]	
AT24C04@TSSOP8 [(SA026)]	
AT24C04A	
AT24C04A@MAP8 [(SA724)]	AT24C04A@SOIC8
[(SA602A)]	
AT24C04A@TSSOP8 [(SA026)]	
AT24C08	
AT24C08@MAP8 [(SA724)]	AT24C08@SOIC8
[(SA602A)]	
AT24C08@TSSOP8 [(SA026)]	
AT24C08A	
AT24C08A@MAP8 [(SA724)]	AT24C08A@SOIC8
[(SA602A)]	
AT24C08A@TSSOP8 [(SA026)]	
AT24C1024	
AT24C1024@LAP8 [(SA724)]	AT24C1024@SAP8
[(SA684)]	
AT24C1024@SOIC8 [(SA023A)]	AT24C1024B
(1.8V)	
AT24C1024B(1.8V)@LAP8 [(SA724)]	AT24C1024B(1.8V)@SAP8
[(SA684)]	
AT24C1024B(1.8V)@SOIC8 [(SA023A)]	
AT24C1024B(1.8V)@TSSOP8 [(SA026)]	
AT24C1024B(2.5V)	AT24C1024B(2.5V)@LAP8
[(SA724)]	
AT24C1024B(2.5V)@SAP8 [(SA684)]	
AT24C1024B(2.5V)@SOIC8 [(SA023A)]	

AT24C1024B(2.5V)@TSSOP8 [(SA026)]	
AT24C11	AT24C11@SOIC8
[(SA602A)]	
AT24C11@TSSOP8 [(SA026)]	AT24C128
(1.8V)	
AT24C128(1.8V)@MAP8 [(SA724)]	AT24C128(1.8V)@SAP8
[(SA683)]	
AT24C128(1.8V)@SOIC8 [(SA602A)]	AT24C128(1.8V)@TSSOP8
[(SA026)]	
AT24C128(2.7V)	AT24C128(2.7V)@MAP8
[(SA724)]	
AT24C128(2.7V)@SAP8 [(SA683)]	AT24C128(2.7V)@SOIC8
[(SA602A)]	
AT24C128(2.7V)@TSSOP8 [(SA026)]	
AT24C128B	
AT24C128B@MAP8 [(SA724)]	AT24C128B@SAP8
[(SA683)]	
AT24C128B@SOIC8 [(SA602A)]	AT24C128B@TSSOP8
[(SA026)]	
AT24C16	AT24C16@SOIC8
[(SA602A)]	
AT24C16@TSSOP8 [(SA026)]	
AT24C164	
AT24C164@SOIC8 [(SA602A)]	
AT24C16A	
AT24C16A@MAP8 [(SA724)]	AT24C16A@SOIC8
[(SA602A)]	
AT24C16A@TSSOP8 [(SA026)]	
AT24C16B	
AT24C16B@MAP8 [(SA724)]	AT24C16B@SOIC8
[(SA602A)]	
AT24C16B@TSSOP8 [(SA026)]	
AT24C21	
AT24C21@SOIC8 [(SA602A)]	AT24C256
(1.8V)	
AT24C256(1.8V)@MAP8 [(SA724)]	AT24C256(1.8V)@SAP8
[(SA683)]	
AT24C256(1.8V)@SOIC8 [(SA602A)]	AT24C256(1.8V)@TSSOP8
[(SA026)]	
AT24C256(2.7V)	AT24C256(2.7V)@MAP8
[(SA724)]	
AT24C256(2.7V)@SAP8 [(SA683)]	AT24C256(2.7V)@SOIC8
[(SA602A)]	

AT24C256(2.7V)@TSSOP8 [(SA026)]	
AT24C256B	
AT24C256B@MAP8 [(SA724)]	AT24C256B@SAP8
[(SA683)]	
AT24C256B@SOIC8 [(SA602A)]	AT24C256B@TSSOP8
[(SA026)]	
AT24C32	AT24C32@SOIC8
[(SA602A)]	
AT24C32@TSSOP8 [(SA026)]	
AT24C32A	
AT24C32A@MAP8 [(SA724)]	AT24C32A@SOIC8
[(SA602A)]	
AT24C32A@TSSOP8 [(SA026)]	
AT24C32C	
AT24C32C@dBGA8 [(BBBB)]	AT24C32C@MAP8
[(SA724)]	
AT24C32C@SAP8 [(SA683)]	AT24C32C@SOIC8
[(SA602A)]	
AT24C32C@TSSOP8 [(SA026)]	AT24C512
(1.8V)	
AT24C512(1.8V)@LAP8 [(SA684)]	AT24C512(1.8V)@SAP8
[(SA683)]	
AT24C512(1.8V)@SOIC8 [(SA602A)]	AT24C512(1.8V)@TSSOP8
[(SA026)]	
AT24C512(2.7V)	AT24C512(2.7V)@LAP8
[(SA684)]	
AT24C512(2.7V)@SAP8 [(SA683)]	AT24C512(2.7V)@SOIC8
[(SA602A)]	
AT24C512(2.7V)@TSSOP8 [(SA026)]	
AT24C512B	
AT24C512B@LAP8 [(SA684)]	AT24C512B@SAP8
[(SA683)]	
AT24C512B@SOIC8 [(SA602A)]	AT24C512B@TSSOP8
[(SA026)]	
AT24C64	AT24C64@SOIC8
[(SA602A)]	
AT24C64@TSSOP8 [(SA026)]	
AT24C64A	
AT24C64A@MAP8 [(SA724)]	AT24C64A@SOIC8
[(SA602A)]	
AT24C64A@TSSOP8 [(SA026)]	
AT24C64B	
AT24C64B@SOIC8 [(SA602A)]	AT24C64B@TSSOP8

[(SA026)]	
AT24C64C	AT24C64C@dBGA8
[(BBBB)]	
AT24C64C@MAP8 [(SA724)]	AT24C64C@SAP8
[(SA683)]	
AT24C64C@SOIC8 [(SA602A)]	AT24C64C@TSSOP8
[(SA026)]	
AT24CS128	AT24CS128@SOIC8
[(SA602A)]	
AT24HC02B	AT24HC02B@SOIC8
[(SA602A)]	
AT24HC02B@TSSOP8 [(SA026)]	AT24RF08AN@SOIC8
[(SA602A)]	
AT24RF08AT@TSSOP14 [(SA026)]	AT24RF08BN@SOIC8
[(SA602A)]	
AT24RF08BT@TSSOP14 [(SA026)]	AT24RF08CN@SOIC8
[(SA602A)]	
AT24RF08CT@TSSOP14 [(SA026)]	
AT25010	
AT25010@SOIC8 [(SA602A)]	
AT25010A	
AT25010A@SOIC8 [(SA602A)]	AT25010A@TSSOP8
[(SA026)]	
AT25020	AT25020@SOIC8
[(SA602A)]	
AT25020A	AT25020A@SOIC8
[(SA602A)]	
AT25020A@TSSOP8 [(SA026)]	
AT25040	
AT25040(ISP) [ISP-HEADER01]	AT25040@SOIC8
[(SA602A)]	
AT25040@SOIC8(ISP) [ISP-HEADER01]	
AT25040A	AT25040A(ISP) [ISP-
HEADER01]	
AT25040A@SOIC8 [(SA602A)]	
AT25040A@SOIC8(ISP) [ISP-HEADER01]	
AT25080	AT25080@SOIC8
[(SA602A)]	
AT25080@TSSOP14 [(SA026)]	AT25080@TSSOP20
[(SA026)]	
AT25080A	AT25080A@SOIC8
[(SA602A)]	
AT25080A@TSSOP14 [(SA026)]	



AT25128	
AT25128@SOIC16 [(SA602)]	AT25128@SOIC8
[(SA602A)]	
AT25128@TSSOP14 [(SA026)]	AT25128@TSSOP20
[(SA026)]	
AT25128A	AT25128A@dBGA8
[(BBBB)]	
AT25128A@SAP8 [(SA683)]	AT25128A@SOIC8(4.0)
[(SA602A)]	
AT25128A@SOIC8(5.4) [(SA605A)]	AT25128A@TSSOP14
[(SA026)]	
AT25128A@TSSOP8 [(SA026)]	
AT25160	
AT25160@SOIC8 [(SA602A)]	AT25160@TSSOP14
[(SA026)]	
AT25160@TSSOP20 [(SA026)]	
AT25160A	
AT25160A@SOIC8 [(SA602A)]	AT25160A@TSSOP14
[(SA026)]	
AT25256	AT25256@SOIC16
[(SA602)]	
AT25256@SOIC8 [(SA602A)]	AT25256@TSSOP14
[(SA026)]	
AT25256@TSSOP20 [(SA026)]	
AT25256A	
AT25256A@dBGA8 [(BBBB)]	AT25256A@SAP8
[(SA683)]	
AT25256A@SOIC8(4.0) [(SA602A)]	AT25256A@SOIC8(5.4)
[(SA605A)]	
AT25256A@TSSOP14 [(SA026)]	AT25256A@TSSOP8
[(SA026)]	
AT25320	AT25320@SOIC8
[(SA602A)]	
AT25320@TSSOP14 [(SA026)]	AT25320@TSSOP20
[(SA026)]	
AT25320A	AT25320A@SOIC8
[(SA602A)]	
AT25320A@TSSOP14 [(SA026)]	
AT25640	
AT25640@SOIC8 [(SA602A)]	AT25640@TSSOP14
[(SA026)]	
AT25640@TSSOP20 [(SA026)]	
AT25640A	

AT25640A@SOIC8 [(SA602A)]	AT25640A@TSSOP14
[(SA026)]	
AT25DF041A@MLF8 [(SA683)]	AT25DF041A@SOIC8(4.0)
[(SA602A)]	
AT25DF041A@SOIC8(5.4) [(SA605A)]	AT25DF641@SOIC16
[(SA404)]	
AT25DF641@VDFN8 [(SA683)]	
AT25F1024	
AT25F1024(W)@SOIC8 [(SA605A)]	AT25F1024(W)@VQFPN8
[(SA684)]	
AT25F1024@SOIC8 [(SA602A)]	AT25F1024@VQFPN8
[(SA683)]	
AT25F1024A	AT25F1024A(W)@SOIC8
[(SA605A)]	
AT25F1024A(W)@VQFPN8 [(SA684)]	AT25F1024A@SOIC8
[(SA602A)]	
AT25F1024A@VQFPN8 [(SA683)]	
AT25F2048	
AT25F2048(W)@SOIC8 [(SA605A)]	AT25F2048(W)@VQFPN8
[(SA684)]	
AT25F2048@SOIC8 [(SA602A)]	AT25F2048@VQFPN8
[(SA683)]	
AT25F2048A	AT25F2048A(W)@SOIC8
[(SA605A)]	
AT25F2048A(W)@VQFPN8 [(SA684)]	AT25F2048A@SOIC8
[(SA602A)]	
AT25F2048A@VQFPN8 [(SA683)]	
AT25F4096	
AT25F4096(W)@SOIC8 [(SA605A)]	AT25F4096(W)@VQFPN8
[(SA684)]	
AT25F4096@SOIC8 [(SA602A)]	AT25F4096@VQFPN8
[(SA683)]	
AT25F4096A	AT25F4096A(W)@SOIC8
[(SA605A)]	
AT25F4096A(W)@VQFPN8 [(SA684)]	AT25F4096A@SOIC8
[(SA602A)]	
AT25F4096A@VQFPN8 [(SA683)]	
AT25F512	
AT25F512(W)@SOIC8 [(SA605A)]	AT25F512(W)@VQFPN8
[(SA684)]	
AT25F512@SOIC8 [(SA602A)]	AT25F512@VQFPN8
[(SA683)]	
AT25F512A	AT25F512A(W)@SOIC8

[ (SA605A) ]	
AT25F512A(W)VQFPN8 [ (SA684) ]	AT25F512A@SOIC8
[ (SA602A) ]	
AT25F512A@VQFPN8 [ (SA683) ]	AT25FS010@SAP8
[ (SA683) ]	
AT25FS010@SOIC8 [ (SA602A) ]	AT25FS040@SAP8
[ (SA683) ]	
AT25FS040@SOIC8 [ (SA602A) ]	
AT25HP256	
AT25HP256(W)VQFPN8 [ (SA684) ]	AT25HP256@SOIC16
[ (SA404) ]	
AT25HP256@SOIC8 [ (SA602A) ]	AT25HP256@VQFPN8
[ (SA683) ]	
AT25HP512	AT25HP512(W)VQFPN8
[ (SA684) ]	
AT25HP512@SOIC16 [ (SA404) ]	AT25HP512@SOIC8
[ (SA602A) ]	
AT25HP512@VQFPN8 [ (SA683) ]	AT25P1024@SOIC20
[ (SA404) ]	
AT25P1024@VQFPN8 [ (SA684) ]	AT26DF041@MLF8
[ (SA683) ]	
AT26DF041@SOIC8(4.0) [ (SA602A) ]	AT26DF041@SOIC8(5.4)
[ (SA605A) ]	
AT26DF081@SOIC8(4.0) [ (SA602A) ]	AT26DF081@SOIC8(5.4)
[ (SA605A) ]	
AT26DF081A@SOIC8(4.0) [ (SA602A) ]	AT26DF081A@SOIC8(5.4)
[ (SA605A) ]	
AT26DF161@MLF8 [ (SA683) ]	AT26DF161@SOIC8
[ (SA605A) ]	
AT26DF161A@MLF8 [ (SA683) ]	AT26DF161A@SOIC8
[ (SA605A) ]	
AT26DF321@MLF8(5*6mm) [ (SA683) ]	AT26DF321@MLF8(6*8mm)
[ (SA684) ]	
AT26DF321@SOIC16 [ (SA404) ]	AT26DF321@SOIC8
[ (SA605A) ]	
AT26F004@MLF8 [ (SA683) ]	AT26F004@SOIC8(4.0)
[ (SA602A) ]	
AT26F004@SOIC8(5.4) [ (SA605A) ]	
AT27011	
AT27011@PLCC32 [ (SA015A1T) ]	
AT27256	
AT2732A	
AT27BV010	

AT27BV010@PLCC32 [(SA015A1T)]	AT27BV010@TSOP32
[(SA620)]	
AT27BV020	AT27BV020@PLCC32
[(SA015A1T)]	
AT27BV020@TSOP32 [(SA620)]	
AT27BV040	
AT27BV040@PLCC32 [(SA015A1T)]	AT27BV040@TSOP32
[(SA620)]	
AT27BV1024@PLCC44 [(SA244)]	AT27BV1024@TSOP40
[(SA623)]	
AT27BV256	AT27BV256@PLCC32
[(SA015A1T)]	
AT27BV256@TSOP28 [(SA430T)]	
AT27BV4096	
AT27BV4096@PLCC44 [(SA244)]	AT27BV4096@TSOP40
[(SA623)]	
AT27BV512	AT27BV512@PLCC32
[(SA015A1T)]	
AT27BV512@SOIC28 [(SA630)]	AT27BV512@TSOP28
[(SA430T)]	
AT27BV520@SOIC20 [(SA404)]	AT27BV520@TSOP28
[(SA430T)]	
AT27BV520@TSSOP20 [(SA026)]	
AT27C010	
AT27C010@PLCC32 [(SA015A1T)]	AT27C010@TSOP32
[(SA410T)]	
AT27C010L	AT27C010L@PLCC32
[(SA015A1T)]	
AT27C010L@TSOP32 [(SA410T)]	
AT27C020	
AT27C020@PLCC32 [(SA015A1T)]	AT27C020@TSOP32
[(SA410T)]	
AT27C040	AT27C040@PLCC32
[(SA015A1T)]	
AT27C040@TSOP32 [(SA410T)]	
AT27C080	
AT27C080@PLCC32 [(SA015A1T)]	AT27C080@TSOP32
[(SA410T)]	
AT27C1024	AT27C1024@PLCC44
[(SA244)]	
AT27C1024@TSOP40 [(SA623)]	
AT27C1024L	
AT27C1024L@PLCC44 [(SA244)]	

AT27C128  
AT27C128@PLCC32 [(SA015A1T)]  
AT27C2048  
AT27C2048@PLCC44 [(SA244)] AT27C2048@TSOP40  
[(SA623)]  
AT27C256 AT27C256@PLCC32  
[(SA015A1T)]  
AT27C256R AT27C256R@PLCC32  
[(SA015A1T)]  
AT27C256R@SOIC28 [(SA630)] AT27C256R@TSOP28  
[(SA430T)]  
AT27C4096 AT27C4096@PLCC44  
[(SA244)]  
AT27C4096@TSOP40 [(SA623)]  
AT27C512  
AT27C512@PLCC32 [(SA015A1T)]  
AT27C512R  
AT27C512R@PLCC32 [(SA015A1T)] AT27C512R@SOIC28  
[(SA630)]  
AT27C512R@TSOP28 [(SA430T)]  
AT27C513  
AT27C513@PLCC32 [(SA015A1T)] AT27C513@SOIC28  
[(SA630)]  
AT27C513R AT27C513R@PLCC32  
[(SA015A1T)]  
AT27C513R@SOIC28 [(SA630)]  
AT27C515  
AT27C515@PLCC32 [(SA015A1T)]  
AT27C516  
AT27C516@PLCC44 [(SA244)] AT27C516@TSOP40  
[(SA623)]  
AT27C520@SOIC20 [(SA404)] AT27C520@TSOP28  
[(SA430T)]  
AT27C520@TSSOP20 [(SA026)]  
AT27C64  
AT27C800 AT27C800@PLCC44  
[(SA244)]  
AT27C800@PSOP44 [(SA638)]  
AT27HC1024  
AT27HC1024@PLCC44 [(SA244)]  
AT27HC256  
AT27HC256@PLCC32 [(SA015A1T)]  
AT27HC256L

AT27HC256L@PLCC32 [(SA015A1T)]	
AT27HC256R	
AT27HC256R@PLCC32 [(SA015A1T)]	
AT27HC256RL	
AT27HC256RL@PLCC32 [(SA015A1T)]	
AT27HC64	
AT27HC64@PLCC32 [(SA015A1T)]	
AT27HC641	
AT27HC641@PLCC28 [(SA008A)]	
AT27HC641R	
AT27HC641R@PLCC28 [(SA008A)]	
AT27HC642	
AT27HC642@PLCC28 [(SA008A)]	
AT27HC642R	
AT27HC642R@PLCC28 [(SA008A)]	
AT27HC64L	
AT27HC64L@PLCC32 [(SA015A1T)]	
AT27LV010	
AT27LV010@PLCC32 [(SA015A1T)]	AT27LV010@TSOP32
[(SA620)]	
AT27LV010A	AT27LV010A@PLCC32
[(SA015A1T)]	
AT27LV010A@TSOP32 [(SA620)]	
AT27LV020A	
AT27LV020A@PLCC32 [(SA015A1T)]	AT27LV020A@TSOP32
[(SA620)]	
AT27LV040	AT27LV040@PLCC32
[(SA015A1T)]	
AT27LV040@TSOP32 [(SA620)]	
AT27LV040A	
AT27LV040A@PLCC32 [(SA015A1T)]	AT27LV040A@TSOP32
[(SA620)]	
AT27LV1024	AT27LV1024@PLCC44
[(SA244)]	
AT27LV256A	AT27LV256A@PLCC32
[(SA015A1T)]	
AT27LV256A@SOIC28 [(SA630)]	AT27LV256A@TSOP28
[(SA430T)]	
AT27LV256R	AT27LV256R@PLCC32
[(SA015A1T)]	
AT27LV256R@SOIC28 [(SA630)]	AT27LV256R@TSOP28
[(SA430T)]	
AT27LV4096	AT27LV4096@PLCC44

[ (SA244) ]	
AT27LV512A	AT27LV512A@PLCC32
[ (SA015A1T) ]	
AT27LV512A@SOIC28 [ (SA630) ]	AT27LV512A@TSOP28
[ (SA430T) ]	
AT27LV512R	AT27LV512R@PLCC32
[ (SA015A1T) ]	
AT27LV512R@TSOP28 [ (SA430T) ]	AT27LV520@SOIC20
[ (SA404) ]	
AT27LV520@TSOP28 [ (SA430T) ]	AT27LV520@TSSOP20
[ (SA026) ]	
AT27LV800	AT27LV800@PSOP44
[ (SA638) ]	
AT28BV16	AT28BV16@PLCC32
[ (SA015A1T) ]	
AT28BV16@SOIC24 [ (SA404) ]	AT28BV16@TSOP28
[ (SA430T) ]	
AT28BV256	AT28BV256@PLCC32
[ (SA015A1T) ]	
AT28BV256@SOIC28 [ (SA404) ]	AT28BV256@TSOP28
[ (SA430T) ]	
AT28BV64	AT28BV64@PLCC32
[ (SA015A1T) ]	
AT28BV64@SOIC28 [ (SA404) ]	AT28BV64@TSOP28
[ (SA430T) ]	
AT28BV64B	AT28BV64B@PLCC32
[ (SA015A1T) ]	
AT28BV64B@SOIC28 [ (SA404) ]	AT28BV64B@TSOP28
[ (SA430T) ]	
AT28C010	AT28C010@PLCC32
[ (SA015A1T) ]	
AT28C010@PLCC44 [ (SA244) ]	AT28C010@TSOP32
[ (SA410T) ]	
AT28C010E	AT28C010E@PLCC32
[ (SA015A1T) ]	
AT28C010E@PLCC44 [ (SA244) ]	AT28C010E@TSOP32
[ (SA410T) ]	
AT28C04	AT28C04@PLCC32
[ (SA015A1T) ]	
AT28C040	AT28C040@PLCC32
[ (SA015A1T) ]	
AT28C04E	AT28C04E@PLCC32
[ (SA015A1T) ]	

AT28C04F [ (SA015A1T) ]	AT28C04F@PLCC32
AT28C16 [ (SA015A1T) ]	AT28C16@PLCC32
AT28C16@SOIC24 [ (SA404) ] [ (SA430T) ]	AT28C16@TSOP28
AT28C16E [ (SA015A1T) ]	AT28C16E@PLCC32
AT28C16F [ (SA015A1T) ]	AT28C16F@PLCC32
AT28C17 [ (SA015A1T) ]	AT28C17@PLCC32
AT28C17@SOIC28 [ (SA404) ]	
AT28C17E AT28C17E@PLCC32 [ (SA015A1T) ]	
AT28C17F AT28C17F@PLCC32 [ (SA015A1T) ]	
AT28C256 AT28C256@PLCC32 [ (SA015A1T) ]	AT28C256@SOIC28
[ (SA404) ] AT28C256@TSOP28 [ (SA430T) ]	
AT28C256E AT28C256E@PLCC32 [ (SA015A1T) ]	
AT28C256F AT28C256F@PLCC32 [ (SA015A1T) ]	
AT28C64 AT28C64@PLCC32 [ (SA015A1T) ]	AT28C64@SOIC28
[ (SA404) ] AT28C64@TSOP28 [ (SA430T) ]	
AT28C64B AT28C64B@PLCC32 [ (SA015A1T) ]	AT28C64B@SOIC28
[ (SA404) ] AT28C64B@TSOP28 [ (SA430T) ]	
AT28C64E AT28C64E@PLCC32 [ (SA015A1T) ]	AT28C64E@TSOP28
[ (SA430T) ]	
AT28C64F [ (SA015A1T) ]	AT28C64F@PLCC32
AT28C64F@TSOP28 [ (SA430T) ]	
AT28C64X AT28C64X@PLCC32 [ (SA015A1T) ]	AT28C64X@SOIC28
[ (SA404) ] AT28C64X@TSOP28 [ (SA430T) ]	



AT28HC04  
AT28HC16  
AT28HC16L  
AT28HC191  
AT28HC191L  
AT28HC256 AT28HC256@PLCC32  
[ (SA015A1T) ]  
AT28HC256@TSOP28 [ (SA430T) ]  
AT28HC256E  
AT28HC256E@PLCC32 [ (SA015A1T) ]  
AT28HC256F  
AT28HC256F@PLCC32 [ (SA015A1T) ]  
AT28HC256L  
AT28HC256L@PLCC32 [ (SA015A1T) ]  
AT28HC256LE  
AT28HC256LE@PLCC32 [ (SA015A1T) ]  
AT28HC291  
AT28HC291@PLCC28 [ (SA008A) ]  
AT28HC291L  
AT28HC291L@PLCC28 [ (SA008A) ]  
AT28HC64  
AT28HC64@PLCC32 [ (SA015A1T) ] AT28HC64@TSOP28  
[ (SA430T) ]  
AT28HC64B AT28HC64B@PLCC32  
[ (SA015A1T) ]  
AT28HC64B@SOIC28 [ (SA404) ] AT28HC64B@TSOP28  
[ (SA430T) ]  
AT28HC64BF AT28HC64BF@PLCC32  
[ (SA015A1T) ]  
AT28HC64BF@SOIC28 [ (SA404) ] AT28HC64BF@TSOP28  
[ (SA430T) ]  
AT28HC64L AT28HC64L@PLCC32  
[ (SA015A1T) ]  
AT28HC64L@TSOP28 [ (SA430T) ]  
AT28LV010  
AT28LV010@PLCC32 [ (SA015A1T) ] AT28LV010@TSOP32  
[ (SA410T) ]  
AT28LV256 AT28LV256@PLCC32  
[ (SA015A1T) ]  
AT28LV256@TSOP28 [ (SA430T) ]  
AT28LV64  
AT28LV64@PLCC32 [ (SA015A1T) ]  
AT28LV64B

AT28LV64B@PLCC32 [(SA015A1T)]	AT28LV64B@SOIC28
[(SA404)]	
AT28LV64B@TSOP28 [(SA430T)]	
AT28MC010	
AT28MC010@PLCC32 [(SA015A1T)]	AT28MC010@PLCC44
[(SA244)]	
AT28MC010@TSOP32 [(SA410T)]	
AT28MC020	
AT28MC020@PLCC32 [(SA015A1T)]	AT28MC020@PLCC44
[(SA244)]	
AT28MC020@TSOP32 [(SA410T)]	
AT28MC040	
AT28MC040@PLCC32 [(SA015A1T)]	AT28MC040@PLCC44
[(SA244)]	
AT28MC040@TSOP32 [(SA410T)]	
AT28PC64	
AT28PC64@PLCC32 [(SA015A1T)]	AT28PC64@TSOP28
[(SA430T)]	
AT28PC64E	
[(SA015A1T)]	AT28PC64E@PLCC32
AT28PC64E@TSOP28 [(SA430T)]	AT29BV010A@PLCC32
[(SA015A1T)]	
AT29BV010A@TSOP32 [(SA410T)]	AT29BV020@PLCC32
[(SA015A1T)]	
AT29BV020@TSOP32 [(SA410T)]	AT29BV040A@TSOP32
[(SA410T)]	
AT29C010	
[(SA015A1T)]	AT29C010@PLCC32
AT29C010@TSOP32 [(SA410T)]	
AT29C010A	
AT29C010A@PLCC32 [(SA015A1T)]	AT29C010A@TSOP32
[(SA410T)]	
AT29C020	
[(SA015A1T)]	AT29C020@PLCC32
AT29C020@TSOP32 [(SA410T)]	
AT29C040	
AT29C040@PLCC32 [(SA015A1T)]	AT29C040@TSOP32
[(SA410T)]	
AT29C040A	
[(SA015A1T)]	AT29C040A@PLCC32
AT29C040A@TSOP32 [(SA410T)]	AT29C1024@PLCC44
[(SA244)]	
AT29C1024@TSOP48 [(SA247-B005)]	

AT29C256	
AT29C256@PLCC32 [(SA015A1T)]	AT29C256@TSOP28
[(SA430T)]	
AT29C257	AT29C257@PLCC32
[(SA015A1T)]	
AT29C512	AT29C512@PLCC32
[(SA015A1T)]	
AT29C512@TSOP32 [(SA410T)]	
AT29LV010	
AT29LV010@PLCC32 [(SA015A1T)]	AT29LV010@TSOP32
[(SA410T)]	
AT29LV010A@PLCC32 [(SA015A1T)]	AT29LV010A@TSOP32
[(SA410T)]	
AT29LV020	AT29LV020@PLCC32
[(SA015A1T)]	
AT29LV020@TSOP32 [(SA410T)]	AT29LV040@TSOP32
[(SA410T)]	
AT29LV040A	AT29LV040A@PLCC32
[(SA015A1T)]	
AT29LV040A@TSOP32 [(SA410T)]	AT29LV1024@PLCC44
[(SA244)]	
AT29LV1024@TSOP48 [(SA247-B005)]	
AT29LV256	
AT29LV256@PLCC32 [(SA015A1T)]	AT29LV256@TSOP28
[(SA430T)]	
AT29LV512	AT29LV512@PLCC32
[(SA015A1T)]	
AT29LV512@TSOP32 [(SA410T)]	
AT32C16	
AT32C16@PLCC44 [(SA244)]	
AT34C02	
AT34C02@SOIC8 [(SA602A)]	AT34C02@TSSOP8
[(SA026)]	
AT34C02B	AT34C02B@SOIC8
[(SA602A)]	
AT34C02B@TSSOP8 [(SA026)]	
AT34C02C	
AT34C02C@dBGA8 [(BBBB)]	AT34C02C@MAP8
[(SA724)]	
AT34C02C@SOIC8 [(SA602A)]	AT34C02C@TSSOP8
[(SA026)]	
AT45BCM021D(page256)@SOIC8 [(SA605A)]	
AT45BCM021D(page256)@SOIC8(ISP) [ISP-HEADER01]	

AT45BCM021D(page264)@SOIC8 [(SA605A)]  
AT45BCM021D(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45D011@PLCC32 [(SA015A1T)] AT45D011@SOIC8  
[(SA605A)]  
AT45D011@TSSOP14 [(SA026)] AT45D021@PLCC32  
[(SA015A1T)]  
AT45D021@SOIC28 [(SA630)] AT45D021@TSOP28  
[(SA430T)]  
AT45D041@PLCC32 [(SA015A1T)] AT45D041@SOIC28  
[(SA630)]  
AT45D041@TSOP28 [(SA430T)] AT45D081@SOIC28  
[(SA630)]  
AT45D081@TSOP32 [(SA410T)] AT45D161@PLCC32  
[(SA015A1T)]  
AT45D161@SOIC28 [(SA630)] AT45D161@TSOP28  
[(SA430T)]  
AT45DB011@PLCC32 [(SA015A1T)] AT45DB011@SOIC8  
[(SA605A)]  
AT45DB011@TSSOP14 [(SA026)] AT45DB011B@PLCC32  
[(SA015A1T)]  
AT45DB011B@PLCC32(ISP) [ISP-HEADER01]  
AT45DB011B@SOIC8 [(SA605A)]  
AT45DB011B@SOIC8(ISP) [ISP-HEADER01]  
AT45DB011B@TSSOP14 [(SA026)]  
AT45DB011B@TSSOP14(ISP) [ISP-HEADER01]  
AT45DB011D(page264)@QFN8 [ordering number is marked above]  
AT45DB011D(page264)@QFN8(ISP) [ISP-HEADER01]  
AT45DB011D(page264)@SOIC8 [ordering number is marked above]  
AT45DB011D(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB021@PLCC32 [(SA015A1T)] AT45DB021@SOIC28  
[(SA630)]  
AT45DB021@TSOP28 [(SA430T)] AT45DB021A@PLCC32  
[(SA015A1T)]  
AT45DB021A@PLCC32(ISP) [ISP-HEADER01]  
AT45DB021A@SOIC28 [(SA630)]  
AT45DB021A@SOIC28(ISP) [ISP-HEADER01]  
AT45DB021A@TSOP28 [(SA430T)]  
AT45DB021A@TSOP28(ISP) [ISP-HEADER01]  
AT45DB021B@CBGA9 [(SA677A-B089A-K080F001N)]  
AT45DB021B@CBGA9(ISP) [ISP-HEADER01]  
AT45DB021B@SOIC28 [(SA630)]  
AT45DB021B@SOIC28(ISP) [ISP-HEADER01]  
AT45DB021B@SOIC8 [(SA023A)]

AT45DB021B@SOIC8(ISP) [ISP-HEADER01]  
AT45DB021B@TSOP28 [(SA430T)]  
AT45DB021B@TSOP28(ISP) [ISP-HEADER01]  
AT45DB021D6(page264)@CASON8 [ordering number is marked above]  
AT45DB021D6(page264)@CASON8(ISP) [ISP-HEADER01]  
AT45DB021D6(page264)@SOIC8 [ordering number is marked above]  
AT45DB021D6(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB041@PLCC32 [(SA015A1T)] AT45DB041@SOIC28  
[(SA630)]  
AT45DB041@TSOP28 [(SA430T)] AT45DB041A@PLCC32  
[(SA015A1T)]  
AT45DB041A@PLCC32(ISP) [ISP-HEADER01]  
AT45DB041A@SOIC28 [(SA630)]  
AT45DB041A@SOIC28(ISP) [ISP-HEADER01]  
AT45DB041A@TSOP28 [(SA430T)]  
AT45DB041A@TSOP28(ISP) [ISP-HEADER01]  
AT45DB041B@CASON8 [(SA684)] AT45DB041B@CASON8(ISP)  
[(SA684)]  
AT45DB041B@CBGA14 [(SA677A-B089A-K080F001N)]  
AT45DB041B@CBGA14(ISP) [ISP-HEADER01]  
AT45DB041B@SOIC28 [(SA630)]  
AT45DB041B@SOIC28(ISP) [ISP-HEADER01]  
AT45DB041B@SOIC8 [(SA605A)]  
AT45DB041B@SOIC8(ISP) [ISP-HEADER01]  
AT45DB041B@TSOP28 [(SA430T)]  
AT45DB041B@TSOP28(ISP) [ISP-HEADER01]  
AT45DB041D(page256)@QFN8 [(SA683)]  
AT45DB041D(page256)@QFN8(ISP) [ISP-HEADER01]  
AT45DB041D(page256)@SOIC8 [(SA605A)]  
AT45DB041D(page256)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB041D(page264)@QFN8 [(SA683)]  
AT45DB041D(page264)@QFN8(ISP) [ISP-HEADER01]  
AT45DB041D(page264)@SOIC8 [(SA605A)]  
AT45DB041D(page264)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB081@SOIC28 [(SA630)] AT45DB081@TSOP32  
[(SA410T)]  
AT45DB081A@PLCC32 [(SA015A1T)]  
AT45DB081A@PLCC32(ISP) [ISP-HEADER01]  
AT45DB081A@SOIC28 [(SA630)]  
AT45DB081A@SOIC28(ISP) [ISP-HEADER01]  
AT45DB081A@TSOP28 [(SA430T)]  
AT45DB081A@TSOP28(ISP) [ISP-HEADER01]  
AT45DB081B@CASON8 [(SA684)] AT45DB081B@CASON8(ISP)

[ (SA684) ]  
AT45DB081B@CBGA14 [ (SA677A-B089A-K080F001N) ]  
AT45DB081B@CBGA14(ISP) [ ISP-HEADER01 ]  
AT45DB081B@SOIC28 [ (SA630) ]  
AT45DB081B@SOIC28(ISP) [ ISP-HEADER01 ]  
AT45DB081B@SOIC8 [ (SA605A) ]  
AT45DB081B@SOIC8(ISP) [ ISP-HEADER01 ]  
AT45DB081B@TSOP28 [ (SA430T) ]  
AT45DB081B@TSOP28(ISP) [ ISP-HEADER01 ]  
AT45DB081D(page256)@MLF8 [ (SA683) ]  
AT45DB081D(page256)@QFN8(ISP) [ ISP-HEADER01 ]  
AT45DB081D(page256)@SOIC8 [ (SA023A) ]  
AT45DB081D(page256)@SOIC8(ISP) [ ISP-HEADER01 ]  
AT45DB081D(page264)@MLF8 [ (SA683) ]  
AT45DB081D(page264)@QFN8(ISP) [ ISP-HEADER01 ]  
AT45DB081D(page264)@SOIC8 [ (SA023A) ]  
AT45DB081D(page264)@SOIC8(ISP) [ ISP-HEADER01 ]  
AT45DB161@PLCC32 [ (SA015A1T) ] AT45DB161@SOIC28  
[ (SA630) ]  
AT45DB161@TSOP28 [ (SA430T) ]  
AT45DB161B@CAS0N8(ISP) [ ISP-HEADER01 ]  
AT45DB161B@CASON8 [ (SA684) ] AT45DB161B@SOIC28  
[ (SA630) ]  
AT45DB161B@SOIC28(ISP) [ ISP-HEADER01 ]  
AT45DB161B@TSOP28 [ (SA430T) ]  
AT45DB161B@TSOP28(ISP) [ ISP-HEADER01 ]  
AT45DB161D(page512)@QFN8 [ (SA683) ]  
AT45DB161D(page512)@QFN8(ISP) [ ISP-HEADER01 ]  
AT45DB161D(page512)@SOIC8 [ (SA605A) ]  
AT45DB161D(page512)@SOIC8(ISP) [ ISP-HEADER01 ]  
AT45DB161D(page512)@TSOP28 [ (SA430T) ]  
AT45DB161D(page512)@TSOP28(ISP) [ ISP-HEADER01 ]  
AT45DB161D(page528)@QFN8 [ (SA683) ]  
AT45DB161D(page528)@QFN8(ISP) [ ISP-HEADER01 ]  
AT45DB161D(page528)@SOIC8 [ (SA605A) ]  
AT45DB161D(page528)@SOIC8(ISP) [ ISP-HEADER01 ]  
AT45DB161D(page528)@TSOP28 [ (SA430T) ]  
AT45DB161D(page528)@TSOP28(ISP) [ ISP-HEADER01 ]  
AT45DB321@TSOP32 [ (SA410T) ] AT45DB321B@SOIC28  
[ (SA630) ]  
AT45DB321B@SOIC28(ISP) [ ISP-HEADER01 ]  
AT45DB321B@TSOP32 [ (SA410T) ]  
AT45DB321B@TSOP32(ISP) [ ISP-HEADER01 ]

AT45DB321C@CAS0N8 [(SA684)]  
AT45DB321C@CAS0N8(ISP) [ISP-HEADER01]  
AT45DB321C@SOIC28 [(SA630)]  
AT45DB321C@SOIC28(ISP) [ISP-HEADER01]  
AT45DB321C@TSOP28 [(SA430T)]  
AT45DB321C@TSOP28(ISP) [ISP-HEADER01]  
AT45DB321D(page512)@QFN8 [(SA683)]  
AT45DB321D(page512)@QFN8(ISP) [ISP-HEADER01]  
AT45DB321D(page512)@SOIC8 [(SA023A)]  
AT45DB321D(page512)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB321D(page512)@TSOP28 [(SA430T)]  
AT45DB321D(page512)@TSOP28(ISP) [ISP-HEADER01]  
AT45DB321D(page528)@QFN8 [(SA683)]  
AT45DB321D(page528)@QFN8(ISP) [ISP-HEADER01]  
AT45DB321D(page528)@SOIC8 [(SA023A)]  
AT45DB321D(page528)@SOIC8(ISP) [ISP-HEADER01]  
AT45DB321D(page528)@TSOP28 [(SA430T)]  
AT45DB321D(page528)@TSOP28(ISP) [ISP-HEADER01]  
AT45DB642@TSOP40 [(SA409T)]  
AT45DB642@TSOP40(ISP) [ISP-HEADER01]  
AT45DB642D(page1024)@CAS0N8 [(SA684)]  
AT45DB642D(page1024)@CAS0N8(ISP) [(ISP-HEADER01)]  
AT45DB642D(page1024)@TSOP28 [(SA430)]  
AT45DB642D(page1024)@TSOP28(ISP) [(ISP-HEADER01)]  
AT45DB642D(page1056)@CAS0N8 [(SA684)]  
AT45DB642D(page1056)@CAS0N8(ISP) [(ISP-HEADER01)]  
AT45DB642D(page1056)@TSOP28 [(SA430)]  
AT45DB642D(page1056)@TSOP28(ISP) [(ISP-HEADER01)]  
AT45DCB002 [(CARD005-B005)] AT45DCB002(ISP) [ISP-  
HEADER01]  
AT45DCB004 [(CARD005-B005)] AT45DCB004(ISP) [ISP-  
HEADER01]  
AT45DCB004C [(CARD005-B005)] AT45DCB004C(ISP) [ISP-  
HEADER01]  
AT45DCB008 [(CARD005-B005)] AT45DCB008(ISP) [ISP-  
HEADER01]  
AT45DCB008D4(page1024) [(CARD005-B005)]  
AT45DCB008D4(page1024)(ISP) [(ISP-HEADER01)]  
AT45DCB008D6(page1056) [(CARD005-B005)]  
AT45DCB008D6(page1056)(ISP) [(ISP-HEADER01)]  
AT49BV001 AT49BV001@PLCC32  
[(SA015A1T)]  
AT49BV001@TSOP32 [(SA410T)] AT49BV001@VSOP32

[ (SA620) ]	
AT49BV001A	AT49BV001A@PLCC32
[ (SA015A1T) ]	
AT49BV001A@TSOP32 [ (SA410T) ]	AT49BV001A@VSOP32
[ (SA620) ]	
AT49BV001AN	AT49BV001AN@PLCC32
[ (SA015A1T) ]	
AT49BV001AN@TSOP32 [ (SA410T) ]	AT49BV001AN@VSOP32
[ (SA620) ]	
AT49BV001ANT	AT49BV001ANT@PLCC32
[ (SA015A1T) ]	
AT49BV001ANT@TSOP32 [ (SA410T) ]	AT49BV001ANT@VSOP32
[ (SA620) ]	
AT49BV001AT	AT49BV001AT@PLCC32
[ (SA015A1T) ]	
AT49BV001AT@TSOP32 [ (SA410T) ]	AT49BV001AT@VSOP32
[ (SA620) ]	
AT49BV001N	AT49BV001N@PLCC32
[ (SA015A1T) ]	
AT49BV001N@TSOP32 [ (SA410T) ]	AT49BV001N@VSOP32
[ (SA620) ]	
AT49BV001NT	AT49BV001NT@PLCC32
[ (SA015A1T) ]	
AT49BV001NT@TSOP32 [ (SA410T) ]	AT49BV001NT@VSOP32
[ (SA620) ]	
AT49BV001T	AT49BV001T@PLCC32
[ (SA015A1T) ]	
AT49BV001T@TSOP32 [ (SA410T) ]	AT49BV001T@VSOP32
[ (SA620) ]	
AT49BV002	AT49BV002@PLCC32
[ (SA015A1T) ]	
AT49BV002@TSOP32 [ (SA410T) ]	AT49BV002@VSOP32
[ (SA620) ]	
AT49BV002A	AT49BV002A@PLCC32
[ (SA015A1T) ]	
AT49BV002A@TSOP32 [ (SA410T) ]	AT49BV002A@VSOP32
[ (SA620) ]	
AT49BV002AN	AT49BV002AN@PLCC32
[ (SA015A1T) ]	
AT49BV002AN@TSOP32 [ (SA410T) ]	AT49BV002AN@VSOP32
[ (SA620) ]	
AT49BV002ANT	AT49BV002ANT@PLCC32
[ (SA015A1T) ]	



AT49BV002ANT@TSOP32 [(SA410T)]	AT49BV002ANT@VSOP32
[(SA620)]	
AT49BV002AT	AT49BV002AT@PLCC32
[(SA015A1T)]	
AT49BV002AT@TSOP32 [(SA410T)]	AT49BV002AT@VSOP32
[(SA620)]	
AT49BV002N	AT49BV002N@PLCC32
[(SA015A1T)]	
AT49BV002N@TSOP32 [(SA410T)]	AT49BV002N@VSOP32
[(SA620)]	
AT49BV002NT	AT49BV002NT@PLCC32
[(SA015A1T)]	
AT49BV002NT@TSOP32 [(SA410T)]	AT49BV002NT@VSOP32
[(SA620)]	
AT49BV002T	AT49BV002T@PLCC32
[(SA015A1T)]	
AT49BV002T@TSOP32 [(SA410T)]	AT49BV002T@VSOP32
[(SA620)]	
AT49BV008@TSOP40 [(SA409T)]	AT49BV008A@TSOP40
[(SA409T)]	
AT49BV008A@uBGA48 [(SA634)]	AT49BV008AT@TSOP40
[(SA409T)]	
AT49BV008AT@uBGA48 [(SA634)]	
AT49BV010	
AT49BV010@PLCC32 [(SA015A1T)]	AT49BV010@TSOP32
[(SA410T)]	
AT49BV020	AT49BV020@PLCC32
[(SA015A1T)]	
AT49BV020@TSOP32 [(SA410T)]	
AT49BV040	
AT49BV040@PLCC32 [(SA015A1T)]	AT49BV040@TSOP32
[(SA410T)]	
AT49BV040A@PLCC32 [(SA015A1T)]	AT49BV040A@TSOP32
[(SA410T)]	
AT49BV040A@VSOP32 [(SA620)]	
AT49BV040B@PLCC32 [(SA015A1T-B001)]	
AT49BV040B@TSOP32 [(SA410T-B003)]	
AT49BV040B@VSOP32 [(SA620-B005)]	
AT49BV040T	
AT49BV040T@PLCC32 [(SA015A1T)]	AT49BV040T@TSOP32
[(SA410T)]	
AT49BV080@PSOP44 [(SA638)]	AT49BV080@TSOP40
[(SA409T)]	

AT49BV080T@PSOP44 [ (SA638) ] AT49BV080T@TSOP40  
[ (SA409T) ]  
AT49BV1024A@TSOP40 [ (SA623) ] AT49BV160@TSOP48 [ (SA247-  
B005) ]  
AT49BV160@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV1604@TSOP48 [ (SA247-B005) ]  
AT49BV1604@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV1604A@TSOP48 [ (SA247-B005) ]  
AT49BV1604A@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV1604AT@TSOP48 [ (SA247-B005) ]  
AT49BV1604AT@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV1604T@TSOP48 [ (SA247-B005) ]  
AT49BV1604T@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV160C@TSOP48 [ (SA247-B005) ]  
AT49BV160C@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV160CT@TSOP48 [ (SA247-B005) ]  
AT49BV160CT@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV160D@TSOP48 [ (SA247-B005) ]  
AT49BV160DT@TSOP48 [ (SA247-B005) ]  
AT49BV160S@FBGA64 [ (SA705A-B147A-W064F001Y) ]  
AT49BV160ST@FBGA64 [ (SA705A-B147A-W064F001Y) ]  
AT49BV160T@TSOP48 [ (SA247-B005) ]  
AT49BV160T@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV161@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV161@TSOP48 [ (SA247-B005) ]  
AT49BV1614@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1614@TSOP48 [ (SA247-B005) ]  
AT49BV1614A@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1614A@TSOP48 [ (SA247-B005) ]  
AT49BV1614AT@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1614AT@TSOP48 [ (SA247-B005) ]  
AT49BV1614T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1614T@TSOP48 [ (SA247-B005) ]  
AT49BV1618@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1618@TSOP48 [ (SA247-B005) ]  
AT49BV1618T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV1618T@TSOP48 [ (SA247-B005) ]  
AT49BV161T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV161T@TSOP48 [ (SA247-B005) ]  
AT49BV162A@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV162A@TSOP48 [ (SA247-B005) ]  
AT49BV162AT@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49BV162AT@TSOP48 [ (SA247-B005) ]

AT49BV163A@CBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49BV163A@TSOP48 [ ( SA247-B005 ) ]  
AT49BV163AT@CBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49BV163AT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV163D@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49BV163D@TSOP48 [ ( SA247-B005 ) ]  
AT49BV163DT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AT49BV163DT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV2048@PSOP44 [ ( SA638 ) ] AT49BV2048@TSOP48 [ ( SA247-B005 ) ]  
AT49BV2048A@PSOP44 [ ( SA638 ) ]  
AT49BV2048A@TSOP48 [ ( SA247-B005 ) ]  
AT49BV2048B@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49BV320C@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320C@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49BV320CT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320CT@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49BV320D@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
AT49BV320D@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320DT@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
AT49BV320DT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320S@FBGA64 [ ( SA705A-B147A-W064F001Y ) ]  
AT49BV320ST@FBGA64 [ ( SA705A-B147A-W064F001Y ) ]  
AT49BV320T@TSOP48 [ ( SA247-B005 ) ]  
AT49BV320T@uBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
AT49BV321@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV321@TSOP48 [ ( SA247-B005 ) ]  
AT49BV3218@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV3218@TSOP48 [ ( SA247-B005 ) ]  
AT49BV3218T@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV3218T@TSOP48 [ ( SA247-B005 ) ]  
AT49BV321T@CBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV321T@TSOP48 [ ( SA247-B005 ) ]  
AT49BV322A@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV322A@TSOP48 [ ( SA247-B005 ) ]  
AT49BV322AT@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AT49BV322AT@TSOP48 [ ( SA247-B005 ) ]  
AT49BV322D@FBGA48 [ ( SA642U-B026A-T064F001Y ) ]  
AT49BV322D@TSOP48 [ ( SA247-B005 ) ]  
AT49BV322DT@FBGA48 [ ( SA642U-B026A-T064F001Y ) ]  
AT49BV322DT@TSOP48 [ ( SA247-B005 ) ]

AT49BV4096@PSOP44 [ (SA638) ] AT49BV4096@TSOP48 [ (SA247-B005) ]  
AT49BV4096A@PSOP44 [ (SA638) ]  
AT49BV4096A@TSOP48 [ (SA247-B005) ]  
AT49BV4096A@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV512 AT49BV512@PLCC32  
[ (SA015A1T) ]  
AT49BV512@TSOP32 [ (SA410T) ] AT49BV512@VSOP32  
[ (SA620) ]  
AT49BV640D@FBGA48 [ (SA634A-B005A-Y048F001Y) ]  
AT49BV640D@TSOP56 [ (SA628-B131) ]  
AT49BV640DT@FBGA48 [ (SA634A-B005A-Y048F001Y) ]  
AT49BV640DT@TSOP56 [ (SA628-B131) ]  
AT49BV640S@FBGA64 [ (SA705A-B147A-W064F001Y) ]  
AT49BV640ST@FBGA64 [ (SA705A-B147A-W064F001Y) ]  
AT49BV6416@TSOP48 [ (SA247-B005) ]  
AT49BV6416T@TSOP48 [ (SA247-B005) ]  
AT49BV642D@TSOP48 [ (SA247-B005) ]  
AT49BV642DT@TSOP48 [ (SA247-B005) ]  
AT49BV8004@CBGA48 [ (SA642B-B026A-Y072F001) ]  
AT49BV8004@TSOP48 [ (SA247-B005) ]  
AT49BV8004T@CBGA48 [ (SA642B-B026A-Y072F001) ]  
AT49BV8004T@TSOP48 [ (SA247-B005) ]  
AT49BV8011@CBGA48 [ (SA642B-B026A-Y072F001) ]  
AT49BV8011@TSOP48 [ (SA247-B005) ]  
AT49BV8011T@CBGA48 [ (SA642B-B026A-Y072F001) ]  
AT49BV8011T@TSOP48 [ (SA247-B005) ]  
AT49BV802A@CBGA48 [ (SA642B-B026A-Y072F001) ]  
AT49BV802A@TSOP48 [ (SA247-B005) ]  
AT49BV802AT@CBGA48 [ (SA642B-B026A-Y072F001) ]  
AT49BV802AT@TSOP48 [ (SA247-B005) ]  
AT49BV802D@CBGA48 [ (SA642G-B026A-T048F001Y) ]  
AT49BV802D@TSOP48 [ (SA247) ]  
AT49BV802DT@CBGA48 [ (SA642G-B026A-T048F001Y) ]  
AT49BV802DT@TSOP48 [ (SA247) ] AT49BV8192@PSOP44  
[ (SA638) ]  
AT49BV8192@TSOP48 [ (SA247-B005) ]  
AT49BV8192A@TSOP48 [ (SA247-B005) ]  
AT49BV8192A@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV8192AT@TSOP48 [ (SA247-B005) ]  
AT49BV8192AT@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49BV8192T@PSOP44 [ (SA638) ]  
AT49BV8192T@TSOP48 [ (SA247-B005) ]

AT49F001  
[ (SA015A1T) ]  
AT49F001@TSOP32 [ (SA410T) ]  
[ (SA620) ]  
AT49F001A  
[ (SA015A1T) ]  
AT49F001A@TSOP32 [ (SA410T) ]  
[ (SA620) ]  
AT49F001AN  
[ (SA015A1T) ]  
AT49F001AN@TSOP32 [ (SA410T) ]  
[ (SA620) ]  
AT49F001ANT  
[ (SA015A1T) ]  
AT49F001ANT@TSOP32 [ (SA410T) ]  
[ (SA620) ]  
AT49F001AT  
[ (SA015A1T) ]  
AT49F001AT@TSOP32 [ (SA410T) ]  
[ (SA620) ]  
AT49F001N  
[ (SA015A1T) ]  
AT49F001N@TSOP32 [ (SA410T) ]  
[ (SA620) ]  
AT49F001NT  
[ (SA015A1T) ]  
AT49F001NT@TSOP32 [ (SA410T) ]  
[ (SA620) ]  
AT49F001T  
[ (SA015A1T) ]  
AT49F001T@TSOP32 [ (SA410T) ]  
[ (SA620) ]  
AT49F002  
[ (SA015A1T) ]  
AT49F002@TSOP32 [ (SA410T) ]  
[ (SA620) ]  
AT49F002A  
[ (SA015A1T) ]  
AT49F002A@TSOP32 [ (SA410T) ]  
[ (SA620) ]  
AT49F002AN  
[ (SA015A1T) ]  
AT49F002AN@TSOP32 [ (SA410T) ]

AT49F001@PLCC32  
AT49F001@VSOP32  
AT49F001A@PLCC32  
AT49F001A@VSOP32  
AT49F001AN@PLCC32  
AT49F001AN@VSOP32  
AT49F001ANT@PLCC32  
AT49F001ANT@VSOP32  
AT49F001AT@PLCC32  
AT49F001AT@VSOP32  
AT49F001N@PLCC32  
AT49F001N@VSOP32  
AT49F001NT@PLCC32  
AT49F001NT@VSOP32  
AT49F001T@PLCC32  
AT49F001T@VSOP32  
AT49F002@PLCC32  
AT49F002@VSOP32  
AT49F002A@PLCC32  
AT49F002A@VSOP32  
AT49F002AN@PLCC32  
AT49F002AN@VSOP32

[ (SA620) ]	
AT49F002ANT	AT49F002ANT@PLCC32
[ (SA015A1T) ]	
AT49F002ANT@TSOP32 [ (SA410T) ]	AT49F002ANT@VSOP32
[ (SA620) ]	
AT49F002AT	AT49F002AT@PLCC32
[ (SA015A1T) ]	
AT49F002AT@TSOP32 [ (SA410T) ]	AT49F002AT@VSOP32
[ (SA620) ]	
AT49F002N	AT49F002N@PLCC32
[ (SA015A1T) ]	
AT49F002N@TSOP32 [ (SA410T) ]	AT49F002N@VSOP32
[ (SA620) ]	
AT49F002NT	AT49F002NT@PLCC32
[ (SA015A1T) ]	
AT49F002NT@TSOP32 [ (SA410T) ]	AT49F002NT@VSOP32
[ (SA620) ]	
AT49F002T	AT49F002T@PLCC32
[ (SA015A1T) ]	
AT49F002T@TSOP32 [ (SA410T) ]	AT49F002T@VSOP32
[ (SA620) ]	
AT49F008@TSOP40 [ (SA409T) ]	AT49F008A@TSOP40
[ (SA409T) ]	
AT49F008AT@TSOP40 [ (SA409T) ]	
AT49F010	
AT49F010@PLCC32 [ (SA015A1T) ]	AT49F010@TSOP32
[ (SA410T) ]	
AT49F020	AT49F020@PLCC32
[ (SA015A1T) ]	
AT49F020@TSOP32 [ (SA410T) ]	
AT49F040	
AT49F040@PLCC32 [ (SA015A1T) ]	AT49F040@TSOP32
[ (SA410T) ]	
AT49F040A	AT49F040A@PLCC32
[ (SA015A1T) ]	
AT49F040A@TSOP32 [ (SA410T) ]	AT49F080@PSOP44
[ (SA638) ]	
AT49F080@TSOP40 [ (SA409T) ]	AT49F080T@PSOP44
[ (SA638) ]	
AT49F080T@TSOP40 [ (SA409T) ]	AT49F1024@TSOP40
[ (SA623) ]	
AT49F1024A@TSOP40 [ (SA623) ]	AT49F1025@PLCC44
[ (SA244) ]	

AT49F1604@TSOP48 [ (SA247-B005) ]  
 AT49F1604@uBGA48 [ (SA634A-B005A-Y048F001) ]  
 AT49F1604T@TSOP48 [ (SA247-B005) ]  
 AT49F1604T@uBGA48 [ (SA634A-B005A-Y048F001) ]  
 AT49F1614@CBGA48 [ (SA642F-B026A-T064F001) ]  
 AT49F1614@TSOP48 [ (SA247-B005) ]  
 AT49F1614T@CBGA48 [ (SA642F-B026A-T064F001) ]  
 AT49F1614T@TSOP48 [ (SA247-B005) ]      AT49F2048@PSOP44  
 [ (SA638) ]  
 AT49F2048@TSOP48 [ (SA247-B005) ]      AT49F2048A@PSOP44  
 [ (SA638) ]  
 AT49F2048A@TSOP48 [ (SA247-B005) ]      AT49F4096@PSOP44  
 [ (SA638) ]  
 AT49F4096@TSOP48 [ (SA247-B005) ]  
 AT49F4096A@CBGA48 [ (SA642F-B026A-T064F001) ]  
 AT49F4096A@PSOP44 [ (SA638) ]      AT49F4096A@TSOP48 [ (SA247-  
 B005) ]  
 AT49F4096A@uBGA48 [ (SA634A-B005A-Y048F001) ]  
 AT49F512      AT49F512@PLCC32  
 [ (SA015A1T) ]  
 AT49F512@TSOP32 [ (SA410T) ]      AT49F512@VSOP32  
 [ (SA620) ]  
 AT49F516@PLCC44 [ (SA244) ]      AT49F516@TSOP40  
 [ (SA623) ]  
 AT49F8004@CBGA48 [ (SA642B-B026A-Y072F001) ]  
 AT49F8004@TSOP48 [ (SA247-B005) ]  
 AT49F8004T@CBGA48 [ (SA642B-B026A-Y072F001) ]  
 AT49F8004T@TSOP48 [ (SA247-B005) ]  
 AT49F8011@CBGA48 [ (SA642B-B026A-Y072F001) ]  
 AT49F8011@TSOP48 [ (SA247-B005) ]  
 AT49F8011T@CBGA48 [ (SA642B-B026A-Y072F001) ]  
 AT49F8011T@TSOP48 [ (SA247-B005) ]      AT49F8192@PSOP44  
 [ (SA638) ]  
 AT49F8192@TSOP48 [ (SA247-B005) ]      AT49F8192A@PSOP44  
 [ (SA638) ]  
 AT49F8192A@TSOP48 [ (SA247-B005) ]      AT49F8192AT@PSOP44  
 [ (SA638) ]  
 AT49F8192AT@TSOP48 [ (SA247-B005) ]  
 AT49F8192T@PSOP44 [ (SA638) ]      AT49F8192T@TSOP48 [ (SA247-  
 B005) ]  
 AT49HBV010      AT49HBV010@PLCC32  
 [ (SA015A1T) ]  
 AT49HBV010@TSOP32 [ (SA410T) ]

AT49HF010	
AT49HF010@PLCC32 [(SA015A1T)]	AT49HF010@TSOP32
[(SA410T)]	
AT49HLV010	AT49HLV010@PLCC32
[(SA015A1T)]	
AT49HLV010@TSOP32 [(SA410T)]	AT49LH002@PLCC32
[(SA015A1T)]	
AT49LH002@TSOP40 [(SA409T)]	AT49LH004@PLCC32
[(SA015A1T)]	
AT49LH004@TSOP40 [(SA409T)]	AT49LH00B4@PLCC32
[(SA015A1T)]	
AT49LH00B4@TSOP40 [(SA409T)]	AT49LL020@PLCC32
[(SA015A1T)]	
AT49LL020@TSOP40 [(SA409T)]	AT49LL040@PLCC32
[(SA015A1T)]	
AT49LL040@TSOP40 [(SA409T)]	AT49LL080@PLCC32
[(SA015A1T)]	
AT49LL080@TSOP40 [(SA409T)]	
AT49LV001	
AT49LV001@PLCC32 [(SA015A1T)]	AT49LV001@TSOP32
[(SA410T)]	
AT49LV001@VSOP32 [(SA620)]	
AT49LV001N	
AT49LV001N@PLCC32 [(SA015A1T)]	AT49LV001N@TSOP32
[(SA410T)]	
AT49LV001N@VSOP32 [(SA620)]	
AT49LV001NT	
AT49LV001NT@PLCC32 [(SA015A1T)]	AT49LV001NT@TSOP32
[(SA410T)]	
AT49LV001NT@VSOP32 [(SA620)]	
AT49LV001T	
AT49LV001T@PLCC32 [(SA015A1T)]	AT49LV001T@TSOP32
[(SA410T)]	
AT49LV001T@VSOP32 [(SA620)]	
AT49LV002	
AT49LV002@PLCC32 [(SA015A1T)]	AT49LV002@TSOP32
[(SA410T)]	
AT49LV002@VSOP32 [(SA620)]	
AT49LV002N	
AT49LV002N@PLCC32 [(SA015A1T)]	AT49LV002N@TSOP32
[(SA410T)]	
AT49LV002N@VSOP32 [(SA620)]	
AT49LV002NT	



AT49LV002NT@PLCC32 [ (SA015A1T) ]	AT49LV002NT@TSOP32
[ (SA410T) ]	
AT49LV002NT@VSOP32 [ (SA620) ]	
AT49LV002T	
AT49LV002T@PLCC32 [ (SA015A1T) ]	AT49LV002T@TSOP32
[ (SA410T) ]	
AT49LV002T@VSOP32 [ (SA620) ]	AT49LV008@TSOP40
[ (SA409T) ]	
AT49LV008A@TSOP40 [ (SA409T) ]	AT49LV008A@uBGA48
[ (SA634) ]	
AT49LV008AT@TSOP40 [ (SA409T) ]	AT49LV008AT@uBGA48
[ (SA634) ]	
AT49LV010	AT49LV010@PLCC32
[ (SA015A1T) ]	
AT49LV010@TSOP32 [ (SA410T) ]	
AT49LV020	
AT49LV020@PLCC32 [ (SA015A1T) ]	AT49LV020@TSOP32
[ (SA410T) ]	
AT49LV040	AT49LV040@PLCC32
[ (SA015A1T) ]	
AT49LV040@TSOP32 [ (SA410T) ]	
AT49LV040T	
AT49LV040T@PLCC32 [ (SA015A1T) ]	AT49LV040T@TSOP32
[ (SA410T) ]	
AT49LV080@PSOP44 [ (SA638) ]	AT49LV080@TSOP40
[ (SA409T) ]	
AT49LV080T@PSOP44 [ (SA638) ]	AT49LV080T@TSOP40
[ (SA409T) ]	
AT49LV1024@TSOP40 [ (SA623) ]	AT49LV1024A@TSOP40
[ (SA623) ]	
AT49LV1025@PLCC44 [ (SA244) ]	AT49LV160@TSOP48 [ (SA247-
B005) ]	
AT49LV160@uBGA48 [ (SA634A-B005A-Y048F001) ]	
AT49LV1604@TSOP48 [ (SA247-B005) ]	
AT49LV1604@uBGA48 [ (SA634A-B005A-Y048F001) ]	
AT49LV1604T@TSOP48 [ (SA247-B005) ]	
AT49LV1604T@uBGA48 [ (SA634A-B005A-Y048F001) ]	
AT49LV161@CBGA48 [ (SA642F-B026A-T064F001) ]	
AT49LV161@TSOP48 [ (SA247-B005) ]	
AT49LV1614@CBGA48 [ (SA642F-B026A-T064F001) ]	
AT49LV1614@TSOP48 [ (SA247-B005) ]	
AT49LV1614A@CBGA48 [ (SA642F-B026A-T064F001) ]	
AT49LV1614A@TSOP48 [ (SA247-B005) ]	

AT49LV1614AT@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV1614AT@TSOP48 [ (SA247-B005) ]  
AT49LV1614T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV1614T@TSOP48 [ (SA247-B005) ]  
AT49LV161T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV161T@TSOP48 [ (SA247-B005) ] AT49LV2048@PSOP44  
[ (SA638) ]  
AT49LV2048@TSOP48 [ (SA247-B005) ] AT49LV2048A@PSOP44  
[ (SA638) ]  
AT49LV2048A@TSOP48 [ (SA247-B005) ]  
AT49LV2048B@TSOP48 [ (SA247-B005) ]  
AT49LV320@TSOP48 [ (SA247-B005) ]  
AT49LV320@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LV320T@TSOP48 [ (SA247-B005) ]  
AT49LV320T@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LV321@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV321@TSOP48 [ (SA247-B005) ]  
AT49LV3218@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV3218@TSOP48 [ (SA247-B005) ]  
AT49LV3218T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV3218T@TSOP48 [ (SA247-B005) ]  
AT49LV321T@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV321T@TSOP48 [ (SA247-B005) ]  
AT49LV4096A@CBGA48 [ (SA642F-B026A-T064F001) ]  
AT49LV4096A@PSOP44 [ (SA638) ]  
AT49LV4096A@TSOP48 [ (SA247-B005) ]  
AT49LV4096A@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LV8011@CBGA48 [ (SA642B-B026A-Y072F001) ]  
AT49LV8011@TSOP48 [ (SA247-B005) ]  
AT49LV8011T@CBGA48 [ (SA642B-B026A-Y072F001) ]  
AT49LV8011T@TSOP48 [ (SA247-B005) ]  
AT49LV8192@PSOP44 [ (SA638) ] AT49LV8192@TSOP48 [ (SA247-  
B005) ]  
AT49LV8192A@TSOP48 [ (SA247-B005) ]  
AT49LV8192A@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LV8192AT@TSOP48 [ (SA247-B005) ]  
AT49LV8192AT@uBGA48 [ (SA634A-B005A-Y048F001) ]  
AT49LW040@PLCC32 [ (SA015A1T) ] AT49LW040@TSOP40  
[ (SA409T) ]  
AT49LW080@PLCC32 [ (SA015A1T) ] AT49LW080@TSOP40  
[ (SA409T) ]  
AT49SV163D@FBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV163D@TSOP48 [ (SA247-B005) ]

AT49SV163DT@FBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV163DT@TSOP48 [ (SA247-B005) ]  
AT49SV322A@CBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV322A@TSOP48 [ (SA247-B005) ]  
AT49SV322AT@CBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV322AT@TSOP48 [ (SA247-B005) ]  
AT49SV322D@FBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV322D@TSOP48 [ (SA247-B005) ]  
AT49SV322DT@FBGA48 [ (SA642U-B026A-T064F001Y) ]  
AT49SV322DT@TSOP48 [ (SA247-B005) ]  
AT49SV802A@CBGA48 [ (SA642G-B026A-T048F001Y) ]  
AT49SV802A@TSOP48 [ (SA247-B005) ]  
AT49SV802AT@CBGA48 [ (SA642G-B026A-T048F001Y) ]  
AT49SV802AT@TSOP48 [ (SA247-B005) ]  
AT52BC1660A@FBGA66 [ (SA642R-B023A-T096F001Y) ]  
AT52BC1660AT@FBGA66 [ (SA642R-B023A-T096F001Y) ]  
AT52BC1661A@FBGA66 [ (SA642R-B023A-T096F001Y) ]  
AT52BC1661AT@FBGA66 [ (SA642R-B023A-T096F001Y) ]  
AT52BC3221A@FBGA66 [ (SA642R-B023A-T080F001Y) ]  
AT52BC3221AT@FBGA66 [ (SA642R-B023A-T080F001Y) ]  
AT52BC3221D@FBGA66 [ (SA642R-B023A-T080F001Y) ]  
AT52BC3221DT@FBGA66 [ (SA642R-B023A-T080F001Y) ]  
AT52BC6402A@FBGA66 [ (SA642B-B023A-Y072F001Y) ]  
AT52BC6402AT@FBGA66 [ (SA642B-B023A-Y072F001Y) ]  
AT52BR1662@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1662A@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1662AT@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1662T@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1664@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1664A@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1664AT@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1664T@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1672@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1672T@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1674@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR1674T@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR3224@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR3224A@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR3224AT@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR3224T@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR3228@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR3228A@CBGA66 [ (SA642E-B023A-T072F001Y) ]  
AT52BR3228AT@CBGA66 [ (SA642E-B023A-T072F001Y) ]

AT52BR3228T@CBGA66 [(SA642E-B023A-T072F001Y)]	
AT52BR3244@CBGA66 [(SA642E-B023A-T072F001Y)]	
AT52BR3244T@CBGA66 [(SA642E-B023A-T072F001Y)]	
AT52BR3248@CBGA66 [(SA642E-B023A-T072F001Y)]	
AT52BR3248T@CBGA66 [(SA642E-B023A-T072F001Y)]	
AT52BR6408A@CSP66 [(SA642E-B023A-T072F001Y)]	
AT52BR6408AT@CSP66 [(SA642E-B023A-T072F001Y)]	
AT59C11	AT59C11@SOIC8
[(SA602A)]	
AT59C12	AT59C12@SOIC8
[(SA602A)]	
AT59C13	AT59C13@SOIC8
[(SA602A)]	
AT59C22	AT59C22@SOIC8
[(SA602A)]	
AT93C46(08bit)	AT93C46(08bit)@SOIC8
[(SA602A)]	
AT93C46(08bit)@TSSOP8 [(SA026)]	AT93C46
(16bit)	
AT93C46(16bit)@SOIC8 [(SA602A)]	AT93C46(16bit)@TSSOP8
[(SA026)]	
AT93C46A	AT93C46A@SOIC8
[(SA602A)]	
AT93C46A@TSSOP8 [(SA026)]	
AT93C46C	
AT93C46C@SOIC8 [(SA602A)]	AT93C46C@TSSOP8
[(SA026)]	
AT93C46D(08bit)	AT93C46D(08bit)@dBGA8
[(BBBB)]	
AT93C46D(08bit)@MAP8 [(SA724)]	AT93C46D(08bit)@SOIC8
[(SA602A)]	
AT93C46D(08bit)@TSSOP8 [(SA026)]	AT93C46D
(16bit)	
AT93C46D(16bit)@dBGA8 [(BBBB)]	AT93C46D(16bit)@MAP8
[(SA724)]	
AT93C46D(16bit)@SOIC8 [(SA602A)]	AT93C46D(16bit)@TSSOP8
[(SA026)]	
AT93C46E	AT93C46E@SOIC8
[(SA602A)]	
AT93C46E@TSSOP8 [(SA026)]	AT93C56
(08bit)	
AT93C56(08bit)@SOIC8 [(SA602A)]	AT93C56
(16bit)	

AT93C56(16bit)@SOIC8 [(SA602A)] (08bit)	AT93C56A
AT93C56A(08bit)@SOIC8 [(SA602A)] [(SA026)]	AT93C56A(08bit)@TSSOP8
AT93C56A(16bit) [(SA602A)]	AT93C56A(16bit)@SOIC8
AT93C56A(16bit)@TSSOP8 [(SA026)]	
AT93C57	
AT93C57@SOIC8 [(SA602A)] (08bit)	AT93C66
AT93C66(08bit)@SOIC8 [(SA602A)] (16bit)	AT93C66
AT93C66(16bit)@SOIC8 [(SA602A)] (08bit)	AT93C66A
AT93C66A(08bit)@SOIC8 [(SA602A)] [(SA026)]	AT93C66A(08bit)@TSSOP8
AT93C66A(16bit) [(SA602A)]	AT93C66A(16bit)@SOIC8
AT93C66A(16bit)@TSSOP8 [(SA026)] (08bit)	AT93C86
AT93C86(08bit)@SOIC8 [(SA602A)] [(SA026)]	AT93C86(08bit)@TSSOP8
AT93C86(16bit) [(SA602A)]	AT93C86(16bit)@SOIC8
AT93C86(16bit)@TSSOP8 [(SA026)] (08bit)	AT93C86A
AT93C86A(08bit)@SOIC8 [(SA602A)] [(SA026)]	AT93C86A(08bit)@TSSOP8
AT93C86A(16bit) [(SA602A)]	AT93C86A(16bit)@SOIC8
AT93C86A(16bit)@TSSOP8 [(SA026)]	

## DRAM & SRAM

AT3864L [(SA643)]	AT3864L@TSOP28
AT38H256 [(SA643)]	AT38H256@TSOP28

## PLD

ATF1502AS@PLCC44 [(SA244)]	ATF1502AS@PQFP44
[(SA675)]	
ATF1502AS@TQFP44 [(SA245A)]	ATF1502ASL@PLCC44
[(SA244)]	
ATF1502ASL@PQFP44 [(SA675)]	ATF1502ASL@TQFP44
[(SA245A)]	
ATF1502ASV@PLCC44 [(SA244)]	ATF1502ASV@PQFP44
[(SA675)]	
ATF1502ASV@TQFP44 [(SA245A)]	ATF1502ASVL@PLCC44
[(SA244)]	
ATF1502ASVL@PQFP44 [(SA675)]	ATF1502ASVL@TQFP44
[(SA245A)]	
ATF1504AS@PLCC44 [(SA244)]	
ATF1504AS@PLCC44(ISP) [ISP-HEADER01]	
ATF1504AS@TQFP44 [(SA245A)]	
ATF1504AS@TQFP44(ISP) [ISP-HEADER01]	
ATF1504ASV(L)@PLCC44 [(SA244)]	
ATF1504ASV(L)@PLCC44(ISP) [ISP-HEADER01]	
ATF1504ASV(L)@TQFP44 [(SA245A)]	
ATF1504ASV(L)@TQFP44(ISP) [ISP-HEADER01]	
ATF16LV8C	ATF16LV8C@PLCC20
[(SA001A)]	
ATF16LV8C@SOIC20 [(SA404)]	ATF16LV8C@TSOP20
[(SA026)]	
ATF16LV8CEXT	ATF16LV8CEXT@PLCC20
[(SA001A)]	
ATF16LV8CEXT@SOIC20 [(SA404)]	ATF16LV8CEXT@TSOP20
[(SA026)]	
ATF16V8B	ATF16V8B@PLCC20
[(SA001A)]	
ATF16V8B@SOIC20 [(SA404)]	ATF16V8B@TSOP20
[(SA026)]	
ATF16V8BL	ATF16V8BL@PLCC20
[(SA001A)]	
ATF16V8BL@SOIC20 [(SA404)]	ATF16V8BL@TSOP20
[(SA026)]	
ATF16V8BQ	ATF16V8BQ@PLCC20
[(SA001A)]	
ATF16V8BQ@SOIC20 [(SA404)]	ATF16V8BQ@TSOP20
[(SA026)]	
ATF16V8BQL	ATF16V8BQL@PLCC20
[(SA001A)]	
ATF16V8BQL@SOIC20 [(SA404)]	ATF16V8BQL@TSOP20

[(SA026)]	
ATF16V8C	ATF16V8C@PLCC20
[(SA001A)]	
ATF16V8C@SOIC20 [(SA404)]	ATF16V8C@TSOP20
[(SA026)]	
ATF16V8CEXT	ATF16V8CEXT@PLCC20
[(SA001A)]	
ATF16V8CEXT@SOIC20 [(SA404)]	ATF16V8CEXT@TSOP20
[(SA026)]	
ATF16V8CZ	ATF16V8CZ@PLCC20
[(SA001A)]	
ATF16V8CZ@SOIC20 [(SA404)]	ATF16V8CZ@TSOP20
[(SA026)]	
ATF20V8B	ATF20V8B@PLCC28
[(SA008A)]	
ATF20V8B@SOIC24 [(SA404)]	
ATF20V8BL	
ATF20V8BL@PLCC28 [(SA008A)]	ATF20V8BL@SOIC24
[(SA404)]	
ATF20V8BQ	ATF20V8BQ@PLCC28
[(SA008A)]	
ATF20V8BQ@SOIC24 [(SA404)]	
ATF20V8BQL	
ATF20V8BQL@PLCC28 [(SA008A)]	ATF20V8BQL@SOIC24
[(SA404)]	
ATF22LV10C	ATF22LV10C
(UES)	
ATF22LV10C(UES)@PLCC28 [(SA008A)]	
ATF22LV10C(UES)@SOIC24 [(SA404)]	
ATF22LV10C(UES)@TSSOP24 [(SA643)]	
ATF22LV10C@PLCC28 [(SA008A)]	ATF22LV10C@SOIC24
[(SA404)]	
ATF22LV10C@TSSOP24 [(SA643)]	
ATF22LV10CEXT	
ATF22LV10CEXT@PLCC28 [(SA008A)]	ATF22LV10CEXT@SOIC24
[(SA404)]	
ATF22LV10CEXT@TSSOP24 [(SA643)]	
ATF22LV10CQ	
ATF22LV10CQ(UES)	
ATF22LV10CQ(UES)@PLCC28 [(SA008A)]	
ATF22LV10CQ(UES)@SOIC24 [(SA404)]	
ATF22LV10CQ(UES)@TSSOP24 [(SA643)]	
ATF22LV10CQ@PLCC28 [(SA008A)]	ATF22LV10CQ@SOIC24

[ (SA404) ]  
ATF22LV10CQ@TSSOP24 [ (SA643) ]  
ATF22LV10CQZ  
ATF22LV10CQZ(UES)  
ATF22LV10CQZ(UES)@PLCC28 [ (SA008A) ]  
ATF22LV10CQZ(UES)@SOIC24 [ (SA404) ]  
ATF22LV10CQZ(UES)@TSSOP24 [ (SA643) ]  
ATF22LV10CQZ@PLCC28 [ (SA008A) ] ATF22LV10CQZ@SOIC24  
[ (SA404) ]  
ATF22LV10CQZ@TSSOP24 [ (SA643) ]  
ATF22LV10CZ  
ATF22LV10CZ(UES)  
ATF22LV10CZ(UES)@PLCC28 [ (SA008A) ]  
ATF22LV10CZ(UES)@SOIC24 [ (SA404) ]  
ATF22LV10CZ(UES)@TSSOP24 [ (SA643) ]  
ATF22LV10CZ@PLCC28 [ (SA008A) ] ATF22LV10CZ@SOIC24  
[ (SA404) ]  
ATF22LV10CZ@TSSOP24 [ (SA643) ]  
ATF22V10B  
ATF22V10B(UES) ATF22V10B(UES)@PLCC28  
[ (SA008A) ]  
ATF22V10B(UES)@SOIC24 [ (SA404) ] ATF22V10B@PLCC28  
[ (SA008A) ]  
ATF22V10B@SOIC24 [ (SA404) ]  
ATF22V10BL  
ATF22V10BL(UES)  
ATF22V10BL(UES)@PLCC28 [ (SA008A) ]  
ATF22V10BL(UES)@SOIC24 [ (SA404) ] ATF22V10BL@PLCC28  
[ (SA008A) ]  
ATF22V10BL@SOIC24 [ (SA404) ]  
ATF22V10BQ  
ATF22V10BQ(UES)  
ATF22V10BQ(UES)@PLCC28 [ (SA008A) ]  
ATF22V10BQ(UES)@SOIC24 [ (SA404) ] ATF22V10BQ@PLCC28  
[ (SA008A) ]  
ATF22V10BQ@SOIC24 [ (SA404) ]  
ATF22V10BQL  
ATF22V10BQL(UES)  
ATF22V10BQL(UES)@PLCC28 [ (SA008A) ]  
ATF22V10BQL(UES)@SOIC24 [ (SA404) ]  
ATF22V10BQL@PLCC28 [ (SA008A) ] ATF22V10BQL@SOIC24  
[ (SA404) ]  
ATF22V10C ATF22V10C



(UES)			
ATF22V10C(UES)@PLCC28 [(SA008A)]		ATF22V10C(UES)@SOIC24	
[(SA404)]			
ATF22V10C(UES)@TSSOP24 [(SA643)]		ATF22V10C@PLCC28	
[(SA008A)]			
ATF22V10C@SOIC24 [(SA404)]		ATF22V10C@TSSOP24	
[(SA643)]			
ATF22V10CEXT		ATF22V10CEXT@PLCC28	
[(SA008A)]			
ATF22V10CEXT@SOIC24 [(SA404)]		ATF22V10CEXT@TSSOP24	
[(SA643)]			
ATF22V10CQ		ATF22V10CQ	
(UES)			
ATF22V10CQ(UES)@PLCC28 [(SA008A)]			
ATF22V10CQ(UES)@SOIC24 [(SA404)]			
ATF22V10CQ(UES)@TSSOP24 [(SA643)]			
ATF22V10CQ@PLCC28 [(SA008A)]		ATF22V10CQ@SOIC24	
[(SA404)]			
ATF22V10CQ@TSSOP24 [(SA643)]			
ATF22V10CQZ			
ATF22V10CQZ(UES)			
ATF22V10CQZ(UES)@PLCC28 [(SA008A)]			
ATF22V10CQZ(UES)@SOIC24 [(SA404)]			
ATF22V10CQZ(UES)@TSSOP24 [(SA643)]			
ATF22V10CQZ@PLCC28 [(SA008A)]		ATF22V10CQZ@SOIC24	
[(SA404)]			
ATF22V10CQZ@TSSOP24 [(SA643)]			
ATF22V10CZ			
ATF22V10CZ(UES)			
ATF22V10CZ(UES)@PLCC28 [(SA008A)]			
ATF22V10CZ(UES)@SOIC24 [(SA404)]			
ATF22V10CZ(UES)@TSSOP24 [(SA643)]			
ATF22V10CZ@PLCC28 [(SA008A)]		ATF22V10CZ@SOIC24	
[(SA404)]			
ATF22V10CZ@TSSOP24 [(SA643)]			
ATF750C		ATF750C	(ATF750C
mode)			
ATF750C	(ATV750 mode)	ATF750C	(ATV750B
mode)			
ATF750C@PLCC28	(ATF750C mode) [(SA008A)]		
ATF750C@PLCC28	(ATV750 mode) [(SA008A)]		
ATF750C@PLCC28	(ATV750B mode) [(SA008A)]		
ATF750C@SOIC24	(ATF750C mode) [(SA404)]		
ATF750C@SOIC24	(ATV750 mode) [(SA404)]		

ATF750C@SOIC24 (ATV750B mode) [ (SA404) ]  
 ATF750CEXT (ATF750C mode)  
 ATF750CEXT@PLCC28 (ATF750C mode) [ (SA008A) ]  
 ATF750CEXT@SOIC24 (ATF750C mode) [ (SA404) ]  
 ATF750CL (ATV750 mode) ATF750CL (ATV750B mode)  
 ATF750CL@PLCC28 (ATV750 mode) [ (SA008A) ]  
 ATF750CL@PLCC28 (ATV750B mode) [ (SA008A) ]  
 ATF750CL@SOIC24 (ATV750 mode) [ (SA404) ]  
 ATF750CL@SOIC24 (ATV750B mode) [ (SA404) ]  
 ATF750LVC (ATF750C mode) ATF750LVC (ATV750 mode)  
 ATF750LVC (ATV750B mode)  
 ATF750LVC@PLCC28 (ATF750C mode) [ (SA008A) ]  
 ATF750LVC@PLCC28 (ATV750 mode) [ (SA008A) ]  
 ATF750LVC@PLCC28 (ATV750B mode) [ (SA008A) ]  
 ATF750LVC@SOIC24 (ATF750C mode) [ (SA404) ]  
 ATF750LVC@SOIC24 (ATV750 mode) [ (SA404) ]  
 ATF750LVC@SOIC24 (ATV750B mode) [ (SA404) ]  
 ATF750LVCEXT (ATF750C mode)  
 ATF750LVCEXT@PLCC28 (ATF750C mode) [ (SA008A) ]  
 ATF750LVCEXT@SOIC24 (ATF750C mode) [ (SA404) ]  
 ATF750LVCL (ATF750C mode) ATF750LVCL (ATV750 mode)  
 ATF750LVCL (ATV750B mode)  
 ATF750LVCL@PLCC28 (ATF750C mode) [ (SA008A) ]  
 ATF750LVCL@PLCC28 (ATV750 mode) [ (SA008A) ]  
 ATF750LVCL@PLCC28 (ATV750B mode) [ (SA008A) ]  
 ATF750LVCL@SOIC24 (ATF750C mode) [ (SA404) ]  
 ATF750LVCL@SOIC24 (ATV750 mode) [ (SA404) ]  
 ATF750LVCL@SOIC24 (ATV750B mode) [ (SA404) ]  
 ATV750 ATF750@PLCC28  
 [ (SA008A) ]  
 ATV750@SOIC24 [ (SA404) ]  
 ATV750B  
 ATV750B@PLCC28 [ (SA008A) ] ATF750B@SOIC24  
 [ (SA404) ]  
 ATV750BL ATF750BL@PLCC28  
 [ (SA008A) ]  
 ATV750BL@SOIC24 [ (SA404) ]  
 ATV750L  
 ATV750L@PLCC28 [ (SA008A) ] ATF750L@SOIC24  
 [ (SA404) ]

**MICROCONTROLLER**

AT80F51 [ (SA244) ]	AT80F51@PLCC44
AT80F51@TQFP44 [ (SA245A) ]	
AT80F52 AT80F52@PLCC44 [ (SA244) ] [ (SA245A) ]	AT80F52@TQFP44
AT87F51 [ (SA244) ]	AT87F51@PLCC44
AT87F51@TQFP44 [ (SA245A) ]	
AT87F51RC AT87F51RC@PLCC44 [ (SA244) ] [ (SA245A) ]	AT87F51RC@TQFP44
AT87F52 [ (SA244) ]	AT87F52@PLCC44
AT87F52@TQFP44 [ (SA245A) ]	
AT87F55 AT87F55@PLCC44 [ (SA244) ] [ (SA245A) ]	AT87F55@TQFP44
AT87F55WD [ (SA244) ]	AT87F55WD@PLCC44
AT87F55WD@TQFP44 [ (SA245A) ]	
AT87LV51 AT87LV51@PLCC44 [ (SA244) ] [ (SA245A) ]	AT87LV51@TQFP44
AT87LV52 [ (SA244) ]	AT87LV52@PLCC44
AT87LV52@TQFP44 [ (SA245A) ]	
AT89C1051 AT89C1051@SOIC20 [ (SA404) ]	
AT89C1051U AT89C1051U@SOIC20 [ (SA404) ]	
AT89C2051 AT89C2051@SOIC20 [ (SA404) ]	
AT89C2051X2 AT89C2051X2@SOIC20 [ (SA404) ]	
AT89C4051 AT89C4051@SOIC20 [ (SA404) ]	
AT89C51 AT89C51@PLCC44 [ (SA244) ]	AT89C51@TQFP44

[ (SA245A) ]	
AT89C5130A@QFN32 [ (SA686) ]	AT89C5130A@SOIC28
[ (SA404) ]	
AT89C5130AM@QFN32 [ (SA686) ]	AT89C5130AM@SOIC28
[ (SA404) ]	
AT89C5131@MLF48 [ (SA696) ]	AT89C5131@SOIC28
[ (SA404) ]	
AT89C5131A@QFN32 [ (SA701) ]	AT89C5131A@SOIC28
[ (SA404) ]	
AT89C5131AL@QFN32 [ (SA701) ]	AT89C5131AL@SOIC28
[ (SA404) ]	
AT89C5131AM@QFN32 [ (SA701) ]	AT89C5131AM@SOIC28
[ (SA404) ]	
AT89C51AC2@PLCC44 [ (SA244) ]	AT89C51AC2@TQFP44
[ (SA245A) ]	
AT89C51AC3@PLCC44 [ (SA244) ]	AT89C51AC3@TQFP44
[ (SA245A) ]	
AT89C51CC01@PLCC44 [ (SA244) ]	AT89C51CC01@TQFP44
[ (SA245A) ]	
AT89C51CC03C@PLCC44 [ (SA244) ]	AT89C51CC03C@TQFP44
[ (SA245A) ]	
AT89C51CC03U@PLCC44 [ (SA244) ]	AT89C51CC03U@TQFP44
[ (SA245A) ]	
AT89C51ED2	AT89C51ED2@PLCC44
[ (SA244) ]	
AT89C51ED2@PLCC68 ( * ) [ (SA648-B6808) ]	
AT89C51ED2@TQFP44 [ (SA245A) ]	
AT89C51ED2@TQFP64 ( * ) [ (TA054-B006) ]	
AT89C51IC2@PLCC44 [ (SA244) ]	AT89C51IC2@TQFP44
[ (SA245A) ]	
AT89C51ID2	AT89C51ID2@PLCC44
[ (SA244) ]	
AT89C51ID2@PLCC68 ( * ) [ (SA648-B6808) ]	
AT89C51ID2@TQFP44 [ (SA245A) ]	
AT89C51ID2@TQFP64 ( * ) [ (TA054-B006) ]	
AT89C51RB2	AT89C51RB2@PLCC44
[ (SA244) ]	
AT89C51RB2@TQFP44 [ (SA245A) ]	
AT89C51RC	
AT89C51RC@PLCC44 [ (SA244) ]	AT89C51RC@TQFP44
[ (SA245A) ]	
AT89C51RC2	AT89C51RC2@PLCC44
[ (SA244) ]	

AT89C51RC2@TQFP44 [(SA245A)]  
AT89C51RD2  
AT89C51RD2@PLCC44 [(SA244)]  
AT89C51RD2@PLCC68(\*) [(SA648-B6808)]  
AT89C51RD2@TQFP44 [(SA245A)]  
AT89C51RD2@TQFP64(\*) [(TA054-B006)]  
AT89C51RE2@PLCC44 [(SA244)] AT89C51RE2@TQFP44  
[(SA675)]  
AT89C51SND1C@BGA81(\*) [(SA664E-B156A-P081F001Y)]  
AT89C51SND2C@BGA100 [(SA664K-B242A-W100F001Y)]  
AT89C52 AT89C52@PLCC44  
[(SA244)]  
AT89C52@TQFP44 [(SA245A)]  
AT89C55  
AT89C55@PLCC44 [(SA244)] AT89C55@TQFP44  
[(SA245A)]  
AT89C55WD AT89C55WD@PLCC44  
[(SA244)]  
AT89C55WD@TQFP44 [(SA245A)]  
AT89LP2051  
AT89LP2051@SOIC20 [(SA404)] AT89LP2051@TSSOP20  
[(SA026)]  
AT89LP2052 AT89LP2052(ISP) [ISP-  
HEADER01]  
AT89LP2052@SOIC20 [(SA404)]  
AT89LP2052@SOIC20(ISP) [ISP-HEADER01]  
AT89LP2052@TSSOP20 [(SA026)]  
AT89LP2052@TSSOP20(ISP) [ISP-HEADER01]  
AT89LP213 AT89LP213(ISP) [ISP-  
HEADER01]  
AT89LP213@TSSOP14 [(SA026)]  
AT89LP213@TSSOP14(ISP) [ISP-HEADER01]  
AT89LP214 AT89LP214(ISP) [ISP-  
HEADER01]  
AT89LP214@TSSOP14 [(SA026)]  
AT89LP214@TSSOP14(ISP) [ISP-HEADER01]  
AT89LP216 AT89LP216(ISP) [ISP-  
HEADER01]  
AT89LP216@TSSOP16 [(SA026)]  
AT89LP216@TSSOP16(ISP) [ISP-HEADER01]  
AT89LP4051 AT89LP4051@SOIC20  
[(SA404)]  
AT89LP4051@TSSOP20 [(SA026)]

AT89LP4052  
AT89LP4052(ISP) [ISP-HEADER01] AT89LP4052@SOIC20  
[(SA404)]  
AT89LP4052@SOIC20(ISP) [ISP-HEADER01]  
AT89LP4052@TSSOP20 [(SA026)]  
AT89LP4052@TSSOP20(ISP) [ISP-HEADER01]  
AT89LS51 AT89LS51(ISP) [ISP-  
HEADER01]  
AT89LS51@PLCC44 [(SA244)]  
AT89LS51@PLCC44(ISP) [ISP-HEADER01]  
AT89LS51@TQFP44 [(SA245A)]  
AT89LS51@TQFP44(ISP) [ISP-HEADER01]  
AT89LS52 AT89LS52(ISP) [ISP-  
HEADER01]  
AT89LS52@PLCC44 [(SA244)]  
AT89LS52@PLCC44(ISP) [ISP-HEADER01]  
AT89LS52@TQFP44 [(SA245A)]  
AT89LS52@TQFP44(ISP) [ISP-HEADER01]  
AT89LS53 AT89LS53(ISP) [ISP-  
HEADER01]  
AT89LS53@PLCC44 [(SA244)]  
AT89LS53@PLCC44(ISP) [ISP-HEADER01]  
AT89LS53@TQFP44 [(SA245A)]  
AT89LS53@TQFP44(ISP) [ISP-HEADER01]  
AT89LS8252 AT89LS8252(ISP) [ISP-  
HEADER01]  
AT89LS8252@PLCC44 [(SA244)]  
AT89LS8252@PLCC44(ISP) [ISP-HEADER01]  
AT89LS8252@TQFP44 [(SA245A)]  
AT89LS8252@TQFP44(ISP) [ISP-HEADER01]  
AT89LV51 AT89LV51@PLCC44  
[(SA244)]  
AT89LV51@TQFP44 [(SA245A)]  
AT89LV52 AT89LV52@TQFP44  
[(SA245A)]  
AT89LV55 AT89LV55@PLCC44  
[(SA244)]  
AT89LV55@TQFP44 [(SA245A)]  
AT89S2051  
AT89S2051@SOIC20 [(SA404)]  
AT89S4051  
AT89S4051@SOIC20 [(SA404)]

AT89S51  
AT89S51(ISP) [ISP-HEADER01] AT89S51@PLCC44  
[(SA244)]  
AT89S51@PLCC44(ISP) [ISP-HEADER01]  
AT89S51@TQFP44 [(SA245A)]  
AT89S51@TQFP44(ISP) [ISP-HEADER01]  
AT89S52 AT89S52(ISP) [ISP-  
HEADER01]  
AT89S52@PLCC44 [(SA244)]  
AT89S52@PLCC44(ISP) [ISP-HEADER01]  
AT89S52@TQFP44 [(SA245A)]  
AT89S52@TQFP44(ISP) [ISP-HEADER01]  
AT89S53 AT89S53(ISP) [ISP-  
HEADER01]  
AT89S53@PLCC44 [(SA244)]  
AT89S53@PLCC44(ISP) [ISP-HEADER01]  
AT89S53@TQFP44 [(SA245A)]  
AT89S53@TQFP44(ISP) [ISP-HEADER01]  
AT89S54 AT89S54@PLCC44  
[(SA244)]  
AT89S54@TQFP44 [(SA245A)]  
AT89S58 AT89S58@TQFP44  
AT89S58@PLCC44 [(SA244)]  
[(SA245A)]  
AT89S64 AT89S64@PLCC44  
[(SA244)]  
AT89S64@TQFP44 [(SA245A)]  
AT89S8252 AT89S8252@PLCC44  
AT89S8252(ISP) [ISP-HEADER01] AT89S8252@PLCC44  
[(SA244)]  
AT89S8252@PLCC44(ISP) [ISP-HEADER01]  
AT89S8252@TQFP44 [(SA245A)]  
AT89S8252@TQFP44(ISP) [ISP-HEADER01]  
AT89S8253 AT89S8253(ISP) [ISP-  
HEADER01]  
AT89S8253@PLCC44 [(SA244)]  
AT89S8253@PLCC44(ISP) [ISP-HEADER01]  
AT89S8253@TQFP44 [(SA245A)]  
AT89S8253@TQFP44(ISP) [ISP-HEADER01]  
AT90CAN128@QFN64(ISP) [ISP-HEADER01]  
AT90CAN128@TQFP64(ISP) [ISP-HEADER01]  
AT90CAN32@QFN64(ISP) [ISP-HEADER01]  
AT90CAN32@TQFP64(ISP) [ISP-HEADER01]

AT90CAN64@QFN64 (ISP) [ISP-HEADER01]  
AT90CAN64@TQFP64 (ISP) [ISP-HEADER01]  
AT90LS2323 AT90LS2323 (ISP) [ISP-  
HEADER01]  
AT90LS2323@SOIC8 [(SA605A)]  
AT90LS2323@SOIC8 (ISP) [ISP-HEADER01]  
AT90LS2333 AT90LS2333 (ISP) [ISP-  
HEADER01]  
AT90LS2333@TQFP32 [(SA663)]  
AT90LS2333@TQFP32 (ISP) [ISP-HEADER01]  
AT90LS2343 AT90LS2343 (ISP) [ISP-  
HEADER01]  
AT90LS2343@SOIC8 [(SA605A)]  
AT90LS2343@SOIC8 (ISP) [ISP-HEADER01]  
AT90LS4433 AT90LS4433 (ISP) [ISP-  
HEADER01]  
AT90LS4433@TQFP32 [(SA663)]  
AT90LS4433@TQFP32 (ISP) [ISP-HEADER01]  
AT90LS4434 AT90LS4434 (ISP) [ISP-  
HEADER01]  
AT90LS4434@PLCC44 [(SA244)]  
AT90LS4434@PLCC44 (ISP) [ISP-HEADER01]  
AT90LS4434@TQFP44 [(SA245A)]  
AT90LS4434@TQFP44 (ISP) [ISP-HEADER01]  
AT90LS8535 AT90LS8535 (ISP) [ISP-  
HEADER01]  
AT90LS8535@PLCC44 [(SA244)]  
AT90LS8535@PLCC44 (ISP) [ISP-HEADER01]  
AT90LS8535@TQFP44 [(SA245A)]  
AT90LS8535@TQFP44 (ISP) [ISP-HEADER01]  
AT90PWM1@SOIC24 [(SA404)] AT90PWM2@SOIC24  
[(SA404)]  
AT90PWM2@SOIC24 (ISP) [ISP-HEADER01]  
AT90PWM216@SOIC24 [(SA404)] AT90PWM2B@SOIC24  
[(SA404)]  
AT90PWM2B@SOIC24 (ISP) [ISP-HEADER01]  
AT90PWM3@QFN32 [(SA701)]  
AT90PWM3@QFN32 (ISP) [ISP-HEADER01]  
AT90PWM3@SOIC32 [(SA715)]  
AT90PWM3@SOIC32 (ISP) [ISP-HEADER01]  
AT90PWM316@QFN32 [(SA701)] AT90PWM316@SOIC32  
[(SA715)]  
AT90PWM3B@QFN32 [(SA701)]



AT90PWM3B@QFN32(ISP) [ISP-HEADER01]  
AT90PWM3B@SOIC32 [(SA715)]  
AT90PWM3B@SOIC32(ISP) [ISP-HEADER01]  
AT90S1200 AT90S1200(ISP) [ISP-  
HEADER01]  
AT90S1200@SOIC20 [(SA404)]  
AT90S1200@SOIC20(ISP) [ISP-HEADER01]  
AT90S1200@SSOP20 [(SA626A)]  
AT90S1200@SSOP20(ISP) [ISP-HEADER01]  
AT90S1200A AT90S1200A(ISP) [ISP-  
HEADER01]  
AT90S1200A@SOIC20 [(SA404)]  
AT90S1200A@SOIC20(ISP) [ISP-HEADER01]  
AT90S1200A@SSOP20 [(SA626A)]  
AT90S1200A@SSOP20(ISP) [ISP-HEADER01]  
AT90S2313 AT90S2313(ISP) [ISP-  
HEADER01]  
AT90S2313@SOIC20 [(SA404)]  
AT90S2313@SOIC20(ISP) [ISP-HEADER01]  
AT90S2323 AT90S2323(ISP) [ISP-  
HEADER01]  
AT90S2323@SOIC8 [(SA605A)]  
AT90S2323@SOIC8(ISP) [ISP-HEADER01]  
AT90S2333 AT90S2333(ISP) [ISP-  
HEADER01]  
AT90S2333@TQFP32 [(SA663)]  
AT90S2333@TQFP32(ISP) [ISP-HEADER01]  
AT90S2343 AT90S2343(ISP) [ISP-  
HEADER01]  
AT90S2343@SOIC8 [(SA605A)]  
AT90S2343@SOIC8(ISP) [ISP-HEADER01]  
AT90S4414 AT90S4414(ISP) [ISP-  
HEADER01]  
AT90S4414@PLCC44 [(SA244)]  
AT90S4414@PLCC44(ISP) [ISP-HEADER01]  
AT90S4414@TQFP44 [(SA245A)]  
AT90S4414@TQFP44(ISP) [ISP-HEADER01]  
AT90S4433 AT90S4433(ISP) [ISP-  
HEADER01]  
AT90S4433@TQFP32 [(SA663)]  
AT90S4433@TQFP32(ISP) [ISP-HEADER01]  
AT90S4434 AT90S4434(ISP) [ISP-  
HEADER01]

AT90S4434@PLCC44 [(SA244)]  
AT90S4434@PLCC44(ISP) [ISP-HEADER01]  
AT90S4434@TQFP44 [(SA245A)]  
AT90S4434@TQFP44(ISP) [ISP-HEADER01]  
AT90S8515 AT90S8515(ISP) [ISP-  
HEADER01]  
AT90S8515@PLCC44 [(SA244)]  
AT90S8515@PLCC44(ISP) [ISP-HEADER01]  
AT90S8515@TQFP44 [(SA245A)]  
AT90S8515@TQFP44(ISP) [ISP-HEADER01]  
AT90S8535 AT90S8535(ISP) [ISP-  
HEADER01]  
AT90S8535@PLCC44 [(SA244)]  
AT90S8535@PLCC44(ISP) [ISP-HEADER01]  
AT90S8535@TQFP44 [(SA245A)]  
AT90S8535@TQFP44(ISP) [ISP-HEADER01]  
AT90USB1286@QFN64(ISP) [ISP-HEADER01]  
AT90USB1286@TQFP64(ISP) [ISP-HEADER01]  
AT90USB1287@QFN64(ISP) [ISP-HEADER01]  
AT90USB1287@TQFP64(ISP) [ISP-HEADER01]  
AT90USB162@QFN32 [(SA686)] AT90USB162@VQFP32  
[(SA663)]  
AT90USB646@QFN64(ISP) [ISP-HEADER01]  
AT90USB646@TQFP64(ISP) [ISP-HEADER01]  
AT90USB647@QFN64(ISP) [ISP-HEADER01]  
AT90USB647@TQFP64(ISP) [ISP-HEADER01]  
AT90USB82@QFN32 [(SA686)]  
AT91FR40162@FBGA121 [(SA664B-B100A-W121F001)]  
AT91FR40162S@FBGA121 [(SA664B-B100A-W121F001Y)]  
AT91FR4042@FBGA121 [(SA664B-B100A-W121F001)]  
AT91SAM7S128@LQFP64(\*) [(TA059-B006)]  
AT91SAM7S128@QFN64(\*) [(SA734-B318)]  
AT91SAM7S256@LQFP64(\*) [(TA059-B006)]  
AT91SAM7S256@QFN64(\*) [(SA734-B318)]  
AT91SAM7S32@LQFP48 [(SA248)]  
AT91SAM7S321@LQFP64(\*) [(TA059-B006)]  
AT91SAM7S321@QFN64(\*) [(SA734-B318)]  
AT91SAM7S64@LQFP64(\*) [(TA059-B006)]  
AT91SAM7S64@QFN64(\*) [(SA734-B318)]  
AT91SAM7SE512AU@LQFP128(\*) [(SA720-B203)]  
AT91SAM7X128AU@LQFP100(\*) [(SA718+B185)]  
AT91SAM7X256AU@LQFP100(\*) [(SA718+B185)]  
AT91SAM7XC128AU@LQFP100(\*) [(SA718+B185)]

AT91SAM7XC256AU@LQFP100(\*) [(SA718+B185)]  
ATAM862@SSO24 [(SA026)] ATAM893@SSO20  
[(SA026)]  
ATAM894@SSO24 [(SA026)]  
ATMEGA128@QFN64(\*) [(SA734+B211)]  
ATMEGA128@QFN64(ISP) [ISP-HEADER01]  
ATMEGA128@TQFP64(\*) [(SA668+B211)]  
ATMEGA128@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA1280@TQFP100(\*) [(TA065+B006)]  
ATMEGA1280@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA1280V@TQFP100(\*) [(TA065+B006)]  
ATMEGA1280V@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA1281@TQFP64(\*) [(TA057-B006)]  
ATMEGA128L@QFN64(ISP) [ISP-HEADER01]  
ATMEGA128L@TQFP64(\*) [(SA668+B211)]  
ATMEGA128L@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA16 ATMEGA16  
(fast)  
ATMEGA16(fast)@MLF44 [(SA712)] ATMEGA16(fast)@TQFP44  
[(SA245A)]  
ATMEGA16(ISP) [ISP-HEADER01] ATMEGA16@MLF44  
[(SA712)]  
ATMEGA16@MLF44(ISP) [ISP-HEADER01]  
ATMEGA16@TQFP44 [(SA245A)]  
ATMEGA16@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA161 ATMEGA161@TQFP44  
[(SA245A)]  
ATMEGA161L ATMEGA161L@TQFP44  
[(SA245A)]  
ATMEGA162 ATMEGA162(ISP) [ISP-  
HEADER01]  
ATMEGA162@PLCC44(ISP) [ISP-HEADER01]  
ATMEGA162@TQFP44 [(SA245A)]  
ATMEGA162@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA162V ATMEGA162V@TQFP44  
[(SA245A)]  
ATMEGA163 ATMEGA163@TQFP44  
[(SA245A)]  
ATMEGA163L ATMEGA163L@TQFP44  
[(SA245A)]  
ATMEGA164P ATMEGA164P@MLP44  
[(SA712)]  
ATMEGA164P@TQFP44 [(SA245A)]

ATMEGA164PL  
ATMEGA164PL@MLP44 [(SA712)] ATMEGA164PL@TQFP44  
[(SA245A)]  
ATMEGA165@QFN64(ISP) [ISP-HEADER01]  
ATMEGA165@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA168 ATMEGA168(ISP) [ISP-  
HEADER01]  
ATMEGA168@MLP32 [(SA686)]  
ATMEGA168@MLP32(ISP) [ISP-HEADER01]  
ATMEGA168@TQFP32 [(SA663)]  
ATMEGA168@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA168P ATMEGA168P(ISP) [ISP-  
HEADER01]  
ATMEGA168P@MLP32 [(SA686)]  
ATMEGA168P@MLP32(ISP) [ISP-HEADER01]  
ATMEGA168P@TQFP32 [(SA663)]  
ATMEGA168P@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA168PV ATMEGA168PV(ISP) [ISP-  
HEADER01]  
ATMEGA168PV@MLP32 [(SA686)]  
ATMEGA168PV@MLP32(ISP) [ISP-HEADER01]  
ATMEGA168PV@TQFP32 [(SA663)]  
ATMEGA168PV@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA168V ATMEGA168V(ISP) [ISP-  
HEADER01]  
ATMEGA168V@MLP32 [(SA686)]  
ATMEGA168V@MLP32(ISP) [ISP-HEADER01]  
ATMEGA168V@TQFP32 [(SA663)]  
ATMEGA168V@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA169@MLF64(ISP) [ISP-HEADER01]  
ATMEGA169@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA169PV@MLF64(ISP) [ISP-HEADER01]  
ATMEGA169PV@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA16L ATMEGA16L  
(fast)  
ATMEGA16L(fast)@MLF44 [(SA712)]  
ATMEGA16L(fast)@TQFP44 [(SA245A)]  
ATMEGA16L(ISP) [ISP-HEADER01] ATMEGA16L@MLF44  
[(SA712)]  
ATMEGA16L@MLF44(ISP) [ISP-HEADER01]  
ATMEGA16L@TQFP44 [(SA245A)]  
ATMEGA16L@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA2560@TQFP100(\*) [(TA065+B006)]

ATMEGA2560@TQFP100(ISP) [ISP-HEADER01]  
 ATMEGA2560V@TQFP100(\*) [(TA065+B006)]  
 ATMEGA2560V@TQFP100(ISP) [ISP-HEADER01]  
 ATMEGA2561@QFN64(ISP) [ISP-HEADER01]  
 ATMEGA2561@TQFP64(\*) [(TA057-B006)]  
 ATMEGA2561@TQFP64(ISP) [ISP-HEADER01]  
 ATMEGA2561V@QFN64(ISP) [ISP-HEADER01]  
 ATMEGA2561V@TQFP64(\*) [(TA057-B006)]  
 ATMEGA2561V@TQFP64(ISP) [ISP-HEADER01]  
 ATMEGA32 ATMEGA32(ISP) [ISP-  
 HEADER01]  
 ATMEGA32(new) ATMEGA32(new)  
 (fast)  
 ATMEGA32(new)(fast)@MLF44 [(SA712)]  
 ATMEGA32(new)(fast)@PLCC44 [(SA244)]  
 ATMEGA32(new)(fast)@TQFP44 [(SA245A)]  
 ATMEGA32(new)@MLF44 [(SA712)] ATMEGA32(new)@PLCC44  
 [(SA244)]  
 ATMEGA32(new)@TQFP44 [(SA245A)] ATMEGA32@MLF44  
 [(SA712)]  
 ATMEGA32@MLF44(ISP) [ISP-HEADER01]  
 ATMEGA32@PLCC44 [(SA244)] ATMEGA32@TQFP44  
 [(SA245A)]  
 ATMEGA32@TQFP44(ISP) [ISP-HEADER01]  
 ATMEGA323 ATMEGA323@TQFP44  
 [(SA245A)]  
 ATMEGA323L ATMEGA323L@TQFP44  
 [(SA245A)]  
 ATMEGA324P ATMEGA324P@MLP44  
 [(SA712)]  
 ATMEGA324P@TQFP44 [(SA245A)]  
 ATMEGA324PL ATMEGA324PL@TQFP44  
 ATMEGA324PL@MLP44 [(SA712)]  
 [(SA245A)]  
 ATMEGA3250@TQFP100(\*) [(TA065-B006)]  
 ATMEGA3250@TQFP100(ISP) [ISP-HEADER01]  
 ATMEGA325P@TQFP64(ISP) [ISP-HEADER01]  
 ATMEGA325V@QFN64(ISP) [ISP-HEADER01]  
 ATMEGA328P ATMEGA328P(ISP) [ISP-  
 HEADER01]  
 ATMEGA328P@MLP32 [(SA686)]  
 ATMEGA328P@MLP32(ISP) [ISP-HEADER01]  
 ATMEGA328P@TQFP32 [(SA663)]

ATMEGA328P@TQFP32 (ISP) [ISP-HEADER01]  
 ATMEGA328PV ATMEGA328PV (ISP) [ISP-  
 HEADER01]  
 ATMEGA328PV@MLP32 [(SA686)]  
 ATMEGA328PV@MLP32 (ISP) [ISP-HEADER01]  
 ATMEGA328PV@TQFP32 [(SA663)]  
 ATMEGA328PV@TQFP32 (ISP) [ISP-HEADER01]  
 ATMEGA329@QFN64 (ISP) [ISP-HEADER01]  
 ATMEGA3290@TQFP100 (\*) [(TA065-B006)]  
 ATMEGA3290@TQFP100 (ISP) [ISP-HEADER01]  
 ATMEGA3290P@TQFP100 (\*) [(TA065-B006)]  
 ATMEGA329P@TQFP64 (ISP) [ISP-HEADER01]  
 ATMEGA32L ATMEGA32L (ISP) [ISP-  
 HEADER01]  
 ATMEGA32L (new) ATMEGA32L (new)  
 (fast)  
 ATMEGA32L (new) (fast)@MLF44 [(SA712)]  
 ATMEGA32L (new) (fast)@PLCC44 [(SA244)]  
 ATMEGA32L (new) (fast)@TQFP44 [(SA245A)]  
 ATMEGA32L (new)@MLF44 [(SA712)] ATMEGA32L (new)@PLCC44  
 [(SA244)]  
 ATMEGA32L (new)@TQFP44 [(SA245A)] ATMEGA32L@MLF44  
 [(SA712)]  
 ATMEGA32L@MLF44 (ISP) [ISP-HEADER01]  
 ATMEGA32L@PLCC44 [(SA244)] ATMEGA32L@TQFP44  
 [(SA245A)]  
 ATMEGA32L@TQFP44 (ISP) [ISP-HEADER01]  
 ATMEGA406@LQFP48 [(SA248)]  
 ATMEGA48  
 ATMEGA48 (ISP) [ISP-HEADER01] ATMEGA48@MLP32  
 [(SA686)]  
 ATMEGA48@MLP32 (ISP) [ISP-HEADER01]  
 ATMEGA48@TQFP32 [(SA663)]  
 ATMEGA48@TQFP32 (ISP) [ISP-HEADER01]  
 ATMEGA48P ATMEGA48P@MLP32  
 [(SA686)]  
 ATMEGA48P@TQFP32 [(SA663)]  
 ATMEGA48PV  
 ATMEGA48PV@MLP32 [(SA686)] ATMEGA48PV@TQFP32  
 [(SA663)]  
 ATMEGA48V ATMEGA48V (ISP) [ISP-  
 HEADER01]  
 ATMEGA48V@MLP32 [(SA686)]

ATMEGA48V@MLP32(ISP) [ISP-HEADER01]  
ATMEGA48V@TQFP32 [(SA663)]  
ATMEGA48V@TQFP32(ISP) [ISP-HEADER01]  
ATMEGA64@QFN64(ISP) [ISP-HEADER01]  
ATMEGA64@TQFP64(\*) [(SA668+B211)]  
ATMEGA64@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA640@TQFP100(\*) [(TA065+B006)]  
ATMEGA644 ATMEGA644(ISP) [ISP-  
HEADER01]  
ATMEGA644@MLF44 [(SA712)]  
ATMEGA644@MLF44(ISP) [ISP-HEADER01]  
ATMEGA644@TQFP44 [(SA245A)]  
ATMEGA644@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA644P ATMEGA644P(ISP) [ISP-  
HEADER01]  
ATMEGA644P@MLF44 [(SA712)]  
ATMEGA644P@MLF44(ISP) [ISP-HEADER01]  
ATMEGA644P@TQFP44 [(SA245A)]  
ATMEGA644P@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA644PV ATMEGA644PV(ISP) [ISP-  
HEADER01]  
ATMEGA644PV@MLF44 [(SA712)]  
ATMEGA644PV@MLF44(ISP) [ISP-HEADER01]  
ATMEGA644PV@TQFP44 [(SA245A)]  
ATMEGA644PV@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA644V ATMEGA644V(ISP) [ISP-  
HEADER01]  
ATMEGA644V@MLF44 [(SA712)]  
ATMEGA644V@MLF44(ISP) [ISP-HEADER01]  
ATMEGA644V@TQFP44 [(SA245A)]  
ATMEGA644V@TQFP44(ISP) [ISP-HEADER01]  
ATMEGA645@QFN64(ISP) [ISP-HEADER01]  
ATMEGA645@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA6450@TQFP100(\*) [(TA065-B006)]  
ATMEGA6450@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA649@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA6490@TQFP100(\*) [(TA065-B006)]  
ATMEGA6490@TQFP100(ISP) [ISP-HEADER01]  
ATMEGA649V@QFN64(ISP) [ISP-HEADER01]  
ATMEGA64L@QFN64(ISP) [ISP-HEADER01]  
ATMEGA64L@TQFP64(\*) [(SA668+B211)]  
ATMEGA64L@TQFP64(ISP) [ISP-HEADER01]  
ATMEGA8 ATMEGA8

```

(fast)
ATMEGA8(fast)@TQFP32 [(SA663)]           ATMEGA8(ISP) [ISP-
HEADER01]
ATMEGA8@MLF32 [(SA686)]
ATMEGA8@MLF32(ISP) [ISP-HEADER01]
ATMEGA8@TQFP32 [(SA663)]
ATMEGA8@TQFP32(ISP) [ISP-HEADER01]
ATMEGA8515                               ATMEGA8515
(fast)
ATMEGA8515(fast)@PLCC44 [(SA244)]
ATMEGA8515(fast)@TQFP44 [(SA245A)]
ATMEGA8515(ISP) [ISP-HEADER01]         ATMEGA8515@PLCC44
[(SA244)]
ATMEGA8515@PLCC44(ISP) [ISP-HEADER01]
ATMEGA8515@TQFP44 [(SA245A)]
ATMEGA8515@TQFP44(ISP) [ISP-HEADER01]
ATMEGA8515L                               ATMEGA8515L
(fast)
ATMEGA8515L(fast)@PLCC44 [(SA244)]
ATMEGA8515L(fast)@TQFP44 [(SA245A)]
ATMEGA8515L(ISP) [ISP-HEADER01]       ATMEGA8515L@PLCC44
[(SA244)]
ATMEGA8515L@PLCC44(ISP) [ISP-HEADER01]
ATMEGA8515L@TQFP44 [(SA245A)]
ATMEGA8515L@TQFP44(ISP) [ISP-HEADER01]
ATMEGA8535                               ATMEGA8535
(fast)
ATMEGA8535(fast)@MLF44 [(SA712)]
ATMEGA8535(fast)@PLCC44 [(SA244)]
ATMEGA8535(fast)@TQFP44 [(SA245A)]
ATMEGA8535(ISP) [ISP-HEADER01]       ATMEGA8535@PLCC44
[(SA244)]
ATMEGA8535@PLCC44(ISP) [ISP-HEADER01]
ATMEGA8535@TQFP44 [(SA245A)]
ATMEGA8535@TQFP44(ISP) [ISP-HEADER01]
ATMEGA8535L                               ATMEGA8535L
(fast)
ATMEGA8535L(fast)@MLF44 [(SA712)]
ATMEGA8535L(fast)@PLCC44 [(SA244)]
ATMEGA8535L(fast)@TQFP44 [(SA245A)]
ATMEGA8535L(ISP) [ISP-HEADER01]     ATMEGA8535L@PLCC44
[(SA244)]
ATMEGA8535L@PLCC44(ISP) [ISP-HEADER01]

```



ATMEGA8535L@TQFP44 [(SA245A)]  
 ATMEGA8535L@TQFP44(ISP) [ISP-HEADER01]  
 ATMEGA88 ATMEGA88(ISP) [ISP-  
 HEADER01]  
 ATMEGA88@MLP32 [(SA686)]  
 ATMEGA88@MLP32(ISP) [ISP-HEADER01]  
 ATMEGA88@TQFP32 [(SA663)]  
 ATMEGA88@TQFP32(ISP) [ISP-HEADER01]  
 ATMEGA88P ATMEGA88P@MLP32  
 [(SA686)]  
 ATMEGA88P@TQFP32 [(SA663)]  
 ATMEGA88PV ATMEGA88PV@TQFP32  
 [(SA663)]  
 ATMEGA88V ATMEGA88V(ISP) [ISP-  
 HEADER01]  
 ATMEGA88V@MLP32 [(SA686)]  
 ATMEGA88V@MLP32(ISP) [ISP-HEADER01]  
 ATMEGA88V@TQFP32 [(SA663)]  
 ATMEGA88V@TQFP32(ISP) [ISP-HEADER01]  
 ATMEGA8L ATMEGA8L  
 (fast)  
 ATMEGA8L(fast)@TQFP32 [(SA663)] ATMEGA8L(ISP) [ISP-  
 HEADER01]  
 ATMEGA8L@MLF32 [(SA686)]  
 ATMEGA8L@MLF32(ISP) [ISP-HEADER01]  
 ATMEGA8L@TQFP32 [(SA663)]  
 ATMEGA8L@TQFP32(ISP) [ISP-HEADER01]  
 ATtiny10 ATtiny10(ISP) [ISP-  
 HEADER01]  
 ATtiny10@SOIC8 [(SA605A)]  
 ATtiny10@SOIC8(ISP) [ISP-HEADER01]  
 ATtiny11 ATtiny11(ISP) [ISP-  
 HEADER01]  
 ATtiny11@SOIC8 [(SA605A)]  
 ATtiny11@SOIC8(ISP) [ISP-HEADER01]  
 ATtiny11L ATtiny11L(ISP) [ISP-  
 HEADER01]  
 ATtiny11L@SOIC8 [(SA605A)]  
 ATtiny11L@SOIC8(ISP) [ISP-HEADER01]  
 ATtiny12 ATtiny12(ISP) [ISP-  
 HEADER01]  
 ATtiny12@SOIC8 [(SA605A)]

ATtiny12@SOIC8(ISP) [ISP-HEADER01]  
 ATtiny12L ATtiny12L(ISP) [ISP-  
 HEADER01]  
 ATtiny12L@SOIC8 [(SA605A)]  
 ATtiny12L@SOIC8(ISP) [ISP-HEADER01]  
 ATtiny12V ATtiny12V(ISP) [ISP-  
 HEADER01]  
 ATtiny12V@SOIC8 [(SA605A)]  
 ATtiny12V@SOIC8(ISP) [ISP-HEADER01]  
 ATtiny13 ATtiny13  
 (Fuse)  
 ATtiny13(Fuse)@QFN20 [(SA692)]  
 ATtiny13(Fuse)@SOIC8(3.9\*6.2) [(SA602A)]  
 ATtiny13(Fuse)@SOIC8(5.5\*8.0) [(SA605A)]  
 ATtiny13(ISP) [ISP-HEADER01] ATtiny13@QFN20  
 [(SA692)]  
 ATtiny13@QFN20(ISP) [ISP-HEADER01]  
 ATtiny13@SOIC8(3.9\*6.2) [(SA602A)]  
 ATtiny13@SOIC8(3.9\*6.2)(ISP) [ISP-HEADER01]  
 ATtiny13@SOIC8(5.5\*8.0) [(SA605A)]  
 ATtiny13@SOIC8(5.5\*8.0)(ISP) [ISP-HEADER01]  
 ATtiny13V ATtiny13V  
 (Fuse)  
 ATtiny13V(Fuse)@QFN20 [(SA692)]  
 ATtiny13V(Fuse)@SOIC8(3.9\*6.2) [(SA602A)]  
 ATtiny13V(Fuse)@SOIC8(5.5\*8.0) [(SA605A)]  
 ATtiny13V(ISP) [ISP-HEADER01] ATtiny13V@QFN20  
 [(SA692)]  
 ATtiny13V@QFN20(ISP) [ISP-HEADER01]  
 ATtiny13V@SOIC8(3.9\*6.2) [(SA602A)]  
 ATtiny13V@SOIC8(3.9\*6.2)(ISP) [ISP-HEADER01]  
 ATtiny13V@SOIC8(5.5\*8.0) [(SA605A)]  
 ATtiny13V@SOIC8(5.5\*8.0)(ISP) [ISP-HEADER01]  
 ATtiny15 ATtiny15(ISP) [ISP-  
 HEADER01]  
 ATtiny15@SOIC8 [(SA605A)]  
 ATtiny15@SOIC8(ISP) [ISP-HEADER01]  
 ATtiny15L ATtiny15L(ISP) [ISP-  
 HEADER01]  
 ATtiny15L@SOIC8 [(SA605A)]  
 ATtiny15L@SOIC8(ISP) [ISP-HEADER01]  
 ATtiny2313 ATtiny2313(ISP) [ISP-  
 HEADER01]

ATtiny2313@SOIC20 [(SA404)]  
ATtiny2313@SOIC20(ISP) [ISP-HEADER01]  
ATtiny2313V  
ATtiny2313V(ISP) [ISP-  
HEADER01]  
ATtiny2313V@SOIC20 [(SA404)]  
ATtiny2313V@SOIC20(ISP) [ISP-HEADER01]  
ATtiny24  
ATtiny24(ISP) [ISP-  
HEADER01]  
ATtiny24@QFN20 [(SA692)]  
ATtiny24@QFN20(ISP) [ISP-HEADER01]  
ATtiny24@SOIC14 [(SA602)]  
ATtiny24@SOIC14(ISP) [ISP-HEADER01]  
ATtiny24V  
ATtiny24V(ISP) [ISP-  
HEADER01]  
ATtiny24V@QFN20 [(SA692)]  
ATtiny24V@QFN20(ISP) [ISP-HEADER01]  
ATtiny24V@SOIC14 [(SA602)]  
ATtiny24V@SOIC14(ISP) [ISP-HEADER01]  
ATtiny25  
ATtiny25(ISP) [ISP-  
HEADER01]  
ATtiny25@QFN20 [(SA692)]  
ATtiny25@QFN20(ISP) [ISP-HEADER01]  
ATtiny25@SOIC8 [(SA023A)]  
ATtiny25@SOIC8(ISP) [ISP-HEADER01]  
ATtiny26  
ATtiny26(ISP) [ISP-  
HEADER01]  
ATtiny26(new)  
ATtiny26(new)(ISP) [ISP-HEADER01]  
ATtiny26(new)@QFN32 [(SA686)]  
ATtiny26(new)@SOIC20  
[(SA404)]  
ATtiny26(new)@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26(new)@TSSOP20 [(SA026)]  
ATtiny26(new)@TSSOP20(ISP) [ISP-HEADER01]  
ATtiny26@QFN32 [(SA686)]  
ATtiny26@SOIC20  
[(SA404)]  
ATtiny26@SOIC20(ISP) [ISP-HEADER01]  
ATtiny26@TSSOP20 [(SA026)]  
ATtiny26@TSSOP20(ISP) [ISP-HEADER01]  
ATtiny261  
ATtiny261@MLP32  
[(SA686)]  
ATtiny261@SOIC20 [(SA404)]  
ATtiny261V  
ATtiny261V@MLP32 [(SA686)]  
ATtiny261V@SOIC20

[(SA404)]  
 ATtiny26L ATtiny26L(ISP) [ISP-  
 HEADER01]  
 ATtiny26L(new)  
 ATtiny26L(new)(ISP) [ISP-HEADER01]  
 ATtiny26L(new)@QFN32 [(SA686)] ATtiny26L(new)@SOIC20  
 [(SA404)]  
 ATtiny26L(new)@SOIC20(ISP) [ISP-HEADER01]  
 ATtiny26L(new)@TSSOP20 [(SA026)]  
 ATtiny26L(new)@TSSOP20(ISP) [ISP-HEADER01]  
 ATtiny26L@QFN32 [(SA686)] ATtiny26L@SOIC20  
 [(SA404)]  
 ATtiny26L@SOIC20(ISP) [ISP-HEADER01]  
 ATtiny26L@TSSOP20 [(SA026)]  
 ATtiny26L@TSSOP20(ISP) [ISP-HEADER01]  
 ATtiny28L ATtiny28L@TQFP32  
 [(SA663)]  
 ATtiny28V ATtiny28V@TQFP32  
 [(SA663)]  
 ATtiny44 ATtiny44(ISP) [ISP-  
 HEADER01]  
 ATtiny44@QFN20 [(SA692)]  
 ATtiny44@QFN20(ISP) [ISP-HEADER01]  
 ATtiny44@SOIC14 [(SA602)]  
 ATtiny44@SOIC14(ISP) [ISP-HEADER01]  
 ATtiny45  
 ATtiny45(ISP)(12V) [ISP-HEADER01]  
 ATtiny45(ISP)(5V) [ISP-HEADER01] ATtiny45@QFN20  
 [(SA692)]  
 ATtiny45@QFN20(ISP)(12V) [ISP-HEADER01]  
 ATtiny45@QFN20(ISP)(5V) [ISP-HEADER01]  
 ATtiny45@SOIC8 [(S605)]  
 ATtiny45@SOIC8(ISP)(12V) [ISP-HEADER01]  
 ATtiny45@SOIC8(ISP)(5V) [ISP-HEADER01]  
 ATtiny461 ATtiny461@MLP32  
 [(SA686)]  
 ATtiny461@SOIC20 [(SA404)]  
 ATtiny461V  
 ATtiny461V@MLP32 [(SA686)] ATtiny461V@SOIC20  
 [(SA404)]  
 ATtiny84 ATtiny84(ISP) [ISP-  
 HEADER01]  
 ATtiny84@QFN20 [(SA692)]

ATtiny84@QFN20(ISP) [ISP-HEADER01]  
 ATtiny84@SOIC14 [(SA602)]  
 ATtiny84@SOIC14(ISP) [ISP-HEADER01]  
 ATtiny85  
 ATtiny85(ISP)(12V) [ISP-HEADER01]  
 ATtiny85(ISP)(5V) [ISP-HEADER01]      ATtiny85@QFN20  
 [(SA692)]  
 ATtiny85@QFN20(ISP)(12V) [ISP-HEADER01]  
 ATtiny85@QFN20(ISP)(5V) [ISP-HEADER01]  
 ATtiny85@SOIC8 [(S605)]  
 ATtiny85@SOIC8(ISP)(12V) [ISP-HEADER01]  
 ATtiny85@SOIC8(ISP)(5V) [ISP-HEADER01]  
 ATtiny861                                      ATtiny861@MLP32  
 [(SA686)]  
 ATtiny861@SOIC20 [(SA404)]  
 ATtiny861V  
 ATtiny861V@MLP32 [(SA686)]                      ATtiny861V@SOIC20  
 [(SA404)]  
 T89F64    T89F64@PLCC44  
 [(SA244)]  
 T89F64@TQFP44 [(SA245A)]

## ATMEL W&M

### MICROCONTROLLER

AT89C5115@PLCC28 [(SA008A)]                      AT89C5115@SOIC28  
 [(SA404)]  
 AT89C5115@TQFP32 [(SA663)]                      AT89C51CC02@PLCC28  
 [(SA008A)]  
 AT89C51CC02@SOIC28 [(SA404)]                      AT89C51CC02@TQFP32  
 [(SA663)]  
 T89C5115@PLCC28 [(SA008A)]                      T89C5115@SOIC28  
 [(SA404)]  
 T89C5115@TQFP32 [(SA663)]                      T89C51AC2@PLCC44  
 [(SA244)]  
 T89C51AC2@TQFP44 [(SA245A)]                      T89C51CC01@PLCC44  
 [(SA244)]  
 T89C51CC01@TQFP44 [(SA245A)]                      T89C51CC02@PLCC28  
 [(SA008A)]  
 T89C51CC02@SOIC24 [(SA404)]                      T89C51CC02@SOIC28  
 [(SA404)]

T89C51CC02@TQFP32 [(SA663)]	T89C51IB2@PLCC44
[(SA244)]	
T89C51IB2@TQFP44 [(SA245A)]	T89C51IC2@PLCC44
[(SA244)]	
T89C51IC2@TQFP44 [(SA245A)]	
T89C51RB2	
T89C51RB2@PLCC44 [(SA244)]	T89C51RB2@TQFP44
[(SA245A)]	
T89C51RC2	
[(SA244)]	T89C51RC2@PLCC44
T89C51RC2@TQFP44 [(SA245A)]	
T89C51RD2	
T89C51RD2@PLCC44 [(SA244)]	T89C51RD2@TQFP44
[(SA245A)]	
T89F64	
[(SA244)]	T89F64@PLCC44
T89F64@TQFP44 [(SA245A)]	
TS87C51RB2	
TS87C51RB2@PLCC44 [(SA244)]	TS87C51RB2@TQFP44
[(SA245A)]	
TS87C51RC2	TS87C51RC2@PLCC44
[(SA244)]	
TS87C51RC2@TQFP44 [(SA245A)]	
TS87C51RD2	
TS87C51RD2@PLCC44 [(SA244)]	TS87C51RD2@TQFP44
[(SA245A)]	
TS87C51U2	TS87C51U2@PLCC44
[(SA244)]	
TS87C51U2@TQFP44 [(SA245A)]	
TS87C52X2	
TS87C52X2@PLCC44 [(SA244)]	TS87C52X2@TQFP44
[(SA245A)]	
TS87C54X2	TS87C54X2@PLCC44
[(SA244)]	
TS87C54X2@TQFP44 [(SA245A)]	
TS87C58X2	
TS87C58X2@PLCC44 [(SA244)]	TS87C58X2@TQFP44
[(SA245A)]	
TSC87251A1@PLCC44 [(SA244)]	
TSC87251G1	
TSC87251G1@PLCC44 [(SA244)]	
TSC87251G1A	
TSC87251G1A@PLCC44 [(SA244)]	

TSC87251G2D

TSC87251G2D@PLCC44 [ (SA244) ]

[ (SA245A) ]

TSC87C51

[ (SA244) ]

TSC87C51@TQFP44 [ (SA245A) ]

TSC87251G2D@TQFP44

TSC87C51@PLCC44

## **ATMEL-CUSTOMER**

### **E ( E ) PROM / FRAM / NVRAM**

AT24C01

AT24C02

AT24C04

AT24C08

AT24C16

## **AUSTIN**

### **E ( E ) PROM / FRAM / NVRAM**

AS8E512K8

[ (SA661) ]

AS8E512K8@SOJ32

## **BELLING-SYSTRON**

### **MICROCONTROLLER**

CM5001

## **BENCHMARQ**

### **E ( E ) PROM / FRAM / NVRAM**

BQ4010

BQ4010Y

BQ4011

BQ4011Y  
BQ4013  
BQ4013Y  
BQ4014  
BQ4014Y  
BQ4015  
BQ4015Y  
BQ4832Y  
BQ4842Y

## **BMT**

### **E ( E ) PROM / FRAM / NVRAM**

BM29LV160B@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
BM29LV160B@TSOP48 [ ( SA247-B005 ) ]  
BM29LV160T@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
BM29LV160T@TSOP48 [ ( SA247-B005 ) ]

## **BOSEN**

### **E ( E ) PROM / FRAM / NVRAM**

M28W320FST@FBGA47 [ ( SA714B-B026A-T048F001Y ) ]  
M28W640FSB@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
PC28F640P30B@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
PC28F640P30T@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
S29GL128PFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFFI02@FBGA64 [ ( SA655F-B287A-W064F001Y ) ]  
S29GL512PTFI02@TSOP56 [ ( SA628-B257 ) ]  
S71WS256NC0BAWA7@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWA7@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
SST39VF800@TSOP48 [ ( SA247 ) ]  
SST39VF800A@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
SST39VF800A@TSOP48 [ ( SA247 ) ]                   SST39VF800Q@TSOP48  
[ ( SA247 ) ]



**BRIGHT****E ( E ) PROM / FRAM / NVRAM**

BM29F040 [ ( SA015A1T ) ]	BM29F040@PLCC32
BM29F040@TSOP32 [ ( SA410T ) ] B006 ) ]	BM29F400B@PSOP44 [ ( SA638-
BM29F400B@TSOP48 [ ( SA247-B005 ) ] B006 ) ]	BM29F400T@PSOP44 [ ( SA638-
BM29F400T@TSOP48 [ ( SA247-B005 ) ]	

**CATALYST****E ( E ) PROM / FRAM / NVRAM**

CAT1021 ( L ) ( P )	CAT1021
CAT1021 ( R ) @ MSOP8 [ ( SA026 ) ] [ ( SA602A ) ]	CAT1021 ( S ) @ SOIC8
CAT1021 ( U ) @ TSSOP8 [ ( SA026 ) ] [ ( SA602A ) ]	CAT1021 ( V ) @ SOIC8
CAT1021 ( Y ) @ TSSOP8 [ ( SA026 ) ] [ ( SA026 ) ]	CAT1021 ( Z ) @ MSOP8
CAT1022 ( L ) ( P )	CAT1022
CAT1022 ( R ) @ MSOP8 [ ( SA026 ) ] [ ( SA602A ) ]	CAT1022 ( S ) @ SOIC8
CAT1022 ( U ) @ TSSOP8 [ ( SA026 ) ] [ ( SA602A ) ]	CAT1022 ( V ) @ SOIC8
CAT1022 ( Y ) @ TSSOP8 [ ( SA026 ) ] [ ( SA026 ) ]	CAT1022 ( Z ) @ MSOP8
CAT1023 ( L ) ( P )	CAT1023
CAT1023 ( R ) @ MSOP8 [ ( SA026 ) ] [ ( SA602A ) ]	CAT1023 ( S ) @ SOIC8
CAT1023 ( U ) @ TSSOP8 [ ( SA026 ) ] [ ( SA602A ) ]	CAT1023 ( V ) @ SOIC8
CAT1023 ( Y ) @ TSSOP8 [ ( SA026 ) ] [ ( SA026 ) ]	CAT1023 ( Z ) @ MSOP8
CAT1024 ( L )	CAT1024

(P)  
CAT1024(R)@MSOP8 [(SA026)]  
[(SA602A)]  
CAT1024(U)@TSSOP8 [(SA026)]  
[(SA602A)]  
CAT1024(Y)@TSSOP8 [(SA026)]  
[(SA026)]  
CAT1025(L)  
(P)  
CAT1025(R)@MSOP8 [(SA026)]  
[(SA602A)]  
CAT1025(U)@TSSOP8 [(SA026)]  
[(SA602A)]  
CAT1025(Y)@TSSOP8 [(SA026)]  
[(SA026)]  
CAT1026(L)  
(P)  
CAT1026(R)@MSOP8 [(SA026)]  
[(SA602A)]  
CAT1026(U)@TSSOP8 [(SA026)]  
[(SA602A)]  
CAT1026(Y)@TSSOP8 [(SA026)]  
[(SA026)]  
CAT1027(L)  
(P)  
CAT1027(R)@MSOP8 [(SA026)]  
[(SA602A)]  
CAT1027(U)@TSSOP8 [(SA026)]  
[(SA602A)]  
CAT1027(Y)@TSSOP8 [(SA026)]  
[(SA026)]  
CAT1161(J)@SOIC8 [(SA602A)]  
(P)  
CAT1162(J)@SOIC8 [(SA602A)]  
(P)  
CAT1163(J)@SOIC8 [(SA602A)]  
(P)  
CAT2210  
[(SA404)]  
CAT2210I  
[(SA404)]  
CAT2212  
[(SA404)]

CAT1024(S)@SOIC8  
CAT1024(V)@SOIC8  
CAT1024(Z)@MSOP8  
CAT1025  
CAT1025(S)@SOIC8  
CAT1025(V)@SOIC8  
CAT1025(Z)@MSOP8  
CAT1026  
CAT1026(S)@SOIC8  
CAT1026(V)@SOIC8  
CAT1026(Z)@MSOP8  
CAT1027  
CAT1027(S)@SOIC8  
CAT1027(V)@SOIC8  
CAT1027(Z)@MSOP8  
CAT1161  
CAT1162  
CAT1163  
CAT2210@SOIC16  
CAT2210I@SOIC16  
CAT2212@SOIC20

CAT2212I	CAT2212I@SOIC20
[(SA404)]	
CAT22C10	CAT22C10@SOIC16
[(SA404)]	
CAT22C10I	CAT22C10I@SOIC16
[(SA404)]	
CAT22C12	CAT22C12@SOIC20
[(SA404)]	
CAT22C12I	CAT22C12I@SOIC20
[(SA404)]	
CAT24AC128	CAT24AC128@SOIC8
[(SA602A)]	
CAT24AC128@TSSOP14 [(SA026)]	
CAT24C00	
CAT24C00@SOIC8 [(SA602A)]	CAT24C00@TSSOP8
[(SA026)]	
CAT24C01	CAT24C01@SOIC14
[(SA602)]	
CAT24C01@SOIC8 [(SA602A)]	CAT24C01@TSSOP8
[(SA026)]	
CAT24C01B(J)@SOIC8 [(SA602A)]	CAT24C01B
(L)	
CAT24C01B(P)	CAT24C01B(R)@MSOP8
[(SA026)]	
CAT24C01B(U)@TSSOP8 [(SA026)]	CAT24C01B(W)@SOIC8
[(SA602A)]	
CAT24C01B(Y)@TSSOP8 [(SA026)]	CAT24C01B(Z)@MSOP8
[(SA026)]	
CAT24C02	CAT24C02@SOIC14
[(SA602)]	
CAT24C02@SOIC8 [(SA602A)]	CAT24C02@TSSOP8
[(SA026)]	
CAT24C021	
CAT24C022	
CAT24C023	
CAT24C03	
CAT24C03@SOIC8 [(SA602A)]	CAT24C03@TSSOP8
[(SA026)]	
CAT24C04	CAT24C04@SOIC14
[(SA602)]	
CAT24C04@SOIC8 [(SA602A)]	CAT24C04@TSSOP8
[(SA026)]	
CAT24C041	

CAT24C042	
CAT24C043	
CAT24C05	
CAT24C05@SOIC8 [(SA602A)]	CAT24C05@TSSOP8
[(SA026)]	
CAT24C08	CAT24C08@SOIC14
[(SA602)]	
CAT24C08@SOIC8 [(SA602A)]	CAT24C08@TSSOP8
[(SA026)]	
CAT24C081	
CAT24C082	
CAT24C083	
CAT24C08I	
CAT24C08I@SOIC8 [(SA602A)]	
CAT24C09	
CAT24C09@SOIC8 [(SA602A)]	CAT24C09@TSSOP8
[(SA026)]	
CAT24C128	CAT24C128@SOIC8
[(SA602A)]	
CAT24C16	CAT24C16@SOIC14
[(SA602)]	
CAT24C16@SOIC8 [(SA602A)]	CAT24C16@TSSOP8
[(SA026)]	
CAT24C161	
CAT24C162	
CAT24C163	
CAT24C164	
CAT24C164@SOIC8 [(SA602A)]	CAT24C164@TSSOP8
[(SA026)]	
CAT24C16I	CAT24C16I@SOIC8
[(SA602A)]	
CAT24C208(J)@SOIC8 [(SA602A)]	CAT24C208
(L)	
CAT24C208(P)	CAT24C208(R)@MSOP8
[(SA666)]	
CAT24C208(U)@TSSOP8 [(SA026)]	CAT24C208(W)@SOIC8
[(SA602A)]	
CAT24C208(Y)@TSSOP8 [(SA026)]	CAT24C208(Z)@MSOP8
[(SA666)]	
CAT24C21	CAT24C21@SOIC8
[(SA602A)]	
CAT24C21@TSSOP8 [(SA026)]	
CAT24C256	

CAT24C256@SOIC8 [(SA602A)]	CAT24C256@TDFN8
[(SA683)]	
CAT24C256@TSSOP8 [(SA026)]	
CAT24C32	
CAT24C32@SOIC8 [(SA602A)]	
CAT24C44	
CAT24C44@SOIC8 [(SA602A)]	
CAT24C64	
CAT24C64@SOIC8 [(SA602A)]	
CAT24F32	
CAT24F32@SOIC8 [(SA602A)]	CAT24F32@TSSOP8
[(SA026)]	
CAT24F32A	CAT24F32A@SOIC8
[(SA602A)]	
CAT24F32A@TSSOP8 [(SA026)]	
CAT24FC01	
CAT24FC01@SOIC14 [(SA602)]	CAT24FC01@SOIC8
[(SA602A)]	
CAT24FC01@TSSOP8 [(SA026)]	
CAT24FC02	
CAT24FC02@SOIC14 [(SA602)]	CAT24FC02@SOIC8
[(SA602A)]	
CAT24FC02@TSSOP8 [(SA026)]	
CAT24FC16	
CAT24FC16@SOIC14 [(SA602)]	CAT24FC16@SOIC8
[(SA602A)]	
CAT24FC16@TSSOP8 [(SA026)]	
CAT24FC17	
CAT24FC17@SOIC8 [(SA602A)]	CAT24FC17@TSSOP8
[(SA026)]	
CAT24FC256	CAT24FC256@SOIC8
[(SA602A)]	
CAT24FC256@TDFN8 [(SA683)]	CAT24FC256@TSSOP8
[(SA026)]	
CAT24FC32	CAT24FC32@SOIC8
[(SA602A)]	
CAT24FC32@TDFN8 [(SA683)]	CAT24FC32@TSSOP8
[(SA026)]	
CAT24FC64	CAT24FC64@SOIC8
[(SA602A)]	
CAT24FC64@TDFN8 [(SA683)]	CAT24FC64@TSSOP8
[(SA026)]	
CAT24FC65	CAT24FC65@SOIC8

[ ( SA602A ) ]	
CAT24FC65@TDFN8 [ ( SA683 ) ]	CAT24FC65@TSSOP8
[ ( SA026 ) ]	
CAT24FC66	CAT24FC66@SOIC8
[ ( SA602A ) ]	
CAT24FC66@TDFN8 [ ( SA683 ) ]	CAT24FC66@TSSOP8
[ ( SA026 ) ]	
CAT24LC02	CAT24LC02@SOIC8
[ ( SA602A ) ]	
CAT24LC02@TSSOP8 [ ( SA026 ) ]	
CAT24WC01	
CAT24WC01@SOIC8 [ ( SA602A ) ]	CAT24WC01@TSSOP8
[ ( SA026 ) ]	
CAT24WC02	CAT24WC02@SOIC8
[ ( SA602A ) ]	
CAT24WC02@TSSOP8 [ ( SA026 ) ]	
CAT24WC03	
CAT24WC03@SOIC8 [ ( SA602A ) ]	CAT24WC03@TSSOP8
[ ( SA026 ) ]	
CAT24WC04	CAT24WC04@SOIC8
[ ( SA602A ) ]	
CAT24WC04@TSSOP8 [ ( SA026 ) ]	
CAT24WC05	
CAT24WC05@SOIC8 [ ( SA602A ) ]	CAT24WC05@TSSOP8
[ ( SA026 ) ]	
CAT24WC08	CAT24WC08@SOIC8
[ ( SA602A ) ]	
CAT24WC08@TSSOP8 [ ( SA026 ) ]	
CAT24WC09	
CAT24WC09@SOIC8 [ ( SA602A ) ]	CAT24WC09@TSSOP8
[ ( SA026 ) ]	
CAT24WC128	CAT24WC128@SOIC8
[ ( SA602A ) ]	
CAT24WC129	CAT24WC129@SOIC8
[ ( SA602A ) ]	
CAT24WC16	CAT24WC16@SOIC8
[ ( SA602A ) ]	
CAT24WC16@TSSOP8 [ ( SA026 ) ]	
CAT24WC164	
CAT24WC164@SOIC8 [ ( SA602A ) ]	CAT24WC164@TSSOP8
[ ( SA026 ) ]	
CAT24WC17	CAT24WC17@SOIC8
[ ( SA602A ) ]	

CAT24WC17@TSSOP8 [(SA026)]	
CAT24WC256	
CAT24WC256@SOIC8 [(SA602A)]	CAT24WC256@TDFN8
[(SA683)]	
CAT24WC256@TSSOP8 [(SA026)]	
CAT24WC257	
CAT24WC257@SOIC8 [(SA605A)]	
CAT24WC32	
CAT24WC32@SOIC8 [(SA602A)]	
CAT24WC33	
CAT24WC33@SOIC8 [(SA602A)]	
CAT24WC64	
CAT24WC64@SOIC8 [(SA602A)]	
CAT24WC65	
CAT24WC65@SOIC8 [(SA602A)]	
CAT24WC66	
CAT24WC66@SOIC8 [(SA602A)]	
CAT25010	
CAT25010(S)@SOIC8 [(SA605A)]	CAT25010(U)@TSSOP8
[(SA602A)]	
CAT25020	
[(SA605A)]	CAT25020(S)@SOIC8
CAT25020(U)@TSSOP8 [(SA602A)]	
CAT25040	
CAT25040(S)@SOIC8 [(SA605A)]	CAT25040(U)@TSSOP8
[(SA602A)]	
CAT25080	
[(SA602A)]	CAT25080@SOIC8
CAT25080@TDFN8 [(SA724)]	CAT25080@TSSOP8
[(SA026)]	
CAT25080@UDFN8 [(BBBB)]	
CAT25128	
CAT25128@SOIC8 [(SA602A)]	CAT25128@TDFN8
[(SA724)]	
CAT25128@TSSOP8 [(SA026)]	
CAT25160	
CAT25160@SOIC8 [(SA602A)]	CAT25160@TDFN8
[(SA724)]	
CAT25160@TSSOP8 [(SA026)]	CAT25160@UDFN8
[(BBBB)]	
CAT25256	
[(SA602A)]	CAT25256@SOIC8
CAT25256@TDFN8 [(SA602A)]	CAT25256@TSSOP8

[ (SA026) ]	
CAT25320	CAT25320@SOIC8
[ (SA602A) ]	
CAT25320@TDFN8 [ (SA724) ]	CAT25320@TSSOP8
[ (SA026) ]	
CAT25640	CAT25640@SOIC8
[ (SA602A) ]	
CAT25640@TDFN8 [ (SA724) ]	CAT25640@TSSOP8
[ (SA026) ]	
CAT25C01	CAT25C01@SOIC16
[ (SA602) ]	
CAT25C01@SOIC8 [ (SA602A) ]	CAT25C01@TSSOP14
[ (SA026) ]	
CAT25C01@TSSOP8 [ (SA026) ]	
CAT25C02	
CAT25C02@SOIC16 [ (SA602) ]	CAT25C02@SOIC8
[ (SA602A) ]	
CAT25C02@TSSOP14 [ (SA026) ]	CAT25C02@TSSOP8
[ (SA026) ]	
CAT25C03	CAT25C03@SOIC8
[ (SA602A) ]	
CAT25C03@TSSOP14 [ (SA026) ]	CAT25C03@TSSOP8
[ (SA026) ]	
CAT25C04	CAT25C04@SOIC16
[ (SA602) ]	
CAT25C04@SOIC8 [ (SA602A) ]	CAT25C04@TSSOP14
[ (SA026) ]	
CAT25C04@TSSOP8 [ (SA026) ]	
CAT25C05	
CAT25C05@SOIC8 [ (SA602A) ]	CAT25C05@TSSOP14
[ (SA026) ]	
CAT25C05@TSSOP8 [ (SA026) ]	
CAT25C08	
CAT25C08@SOIC16 [ (SA602) ]	CAT25C08@SOIC8
[ (SA602A) ]	
CAT25C08@TSSOP14 [ (SA026) ]	CAT25C08@TSSOP8
[ (SA026) ]	
CAT25C09	CAT25C09@SOIC8
[ (SA602A) ]	
CAT25C09@TSSOP14 [ (SA026) ]	CAT25C09@TSSOP8
[ (SA026) ]	
CAT25C11	CAT25C11@SOIC8
[ (SA602A) ]	



CAT25C11@TSSOP14 [(SA026)]	CAT25C11@TSSOP8
[(SA026)]	
CAT25C128	CAT25C128@SOIC16
[(SA602)]	
CAT25C128@SOIC8 [(SA602A)]	CAT25C128@TSSOP14
[(SA026)]	
CAT25C128@TSSOP20 [(SA026)]	
CAT25C16	
CAT25C16@SOIC16 [(SA602)]	CAT25C16@SOIC8
[(SA602A)]	
CAT25C16@TSSOP14 [(SA026)]	CAT25C16@TSSOP8
[(SA026)]	
CAT25C17	CAT25C17@SOIC8
[(SA602A)]	
CAT25C17@TSSOP14 [(SA026)]	CAT25C17@TSSOP8
[(SA026)]	
CAT25C256	CAT25C256@SOIC16
[(SA602)]	
CAT25C256@SOIC8 [(SA602A)]	CAT25C256@TSSOP14
[(SA026)]	
CAT25C256@TSSOP20 [(SA026)]	
CAT25C32	
CAT25C32@SOIC8 [(SA602A)]	CAT25C32@TSSOP14
[(SA026)]	
CAT25C32@TSSOP20 [(SA026)]	
CAT25C33	
CAT25C33@SOIC8 [(SA602A)]	CAT25C33@TSSOP14
[(SA026)]	
CAT25C64	CAT25C64@SOIC8
[(SA602A)]	
CAT25C64@TSSOP14 [(SA026)]	CAT25C64@TSSOP20
[(SA026)]	
CAT25C65	CAT25C65@SOIC8
[(SA602A)]	
CAT25C65@TSSOP14 [(SA026)]	
CAT27010	
CAT27010@PLCC32 [(SA015A1T)]	CAT27010@TSOP32
[(SA410T)]	
CAT27128A	
CAT27256	
CAT27512	CAT27512@PLCC32
[(SA015A1T)]	
CAT2764A	

CAT27C16A	
CAT27C210	CAT27C210@PLCC44
[ (SA244) ]	
CAT27HC256	CAT27HC256@PLCC32
[ (SA015A1T) ]	
CAT27HC256I	CAT27HC256I@PLCC32
[ (SA015A1T) ]	
CAT28C16A	CAT28C16A@PLCC32
[ (SA015A1T) ]	
CAT28C16AI	CAT28C16AI@PLCC32
[ (SA015A1T) ]	
CAT28C17A	CAT28C17A@PLCC32
[ (SA015A1T) ]	
CAT28C17AI	CAT28C17AI@PLCC32
[ (SA015A1T) ]	
CAT28C256	CAT28C256@PLCC32
[ (SA015A1T) ]	
CAT28C256@TSOP28 [ (SA430T) ]	
CAT28C256I	
CAT28C256I@PLCC32 [ (SA015A1T) ]	CAT28C256I@TSOP28
[ (SA430T) ]	
CAT28C257	CAT28C257@PLCC32
[ (SA015A1T) ]	
CAT28C257@TSOP28 [ (SA430T) ]	
CAT28C512	
CAT28C512@PLCC32 [ (SA015A1T) ]	CAT28C512@TSOP32
[ (SA410T) ]	
CAT28C512@TSOP40 [ (SA409T) ]	CAT28C513@PLCC32
[ (SA015A1T) ]	
CAT28C64A	CAT28C64A@PLCC32
[ (SA015A1T) ]	
CAT28C64A@SOIC28 [ (SA404) ]	
CAT28C64AI	
CAT28C64AI@PLCC32 [ (SA015A1T) ]	CAT28C64AI@SOIC28
[ (SA404) ]	
CAT28C64B	CAT28C64B@PLCC32
[ (SA015A1T) ]	
CAT28C64B@TSOP28 [ (SA430T) ]	
CAT28C64BI	
CAT28C64BI@PLCC32 [ (SA015A1T) ]	CAT28C64BI@TSOP28
[ (SA430T) ]	
CAT28C65B	CAT28C65B@PLCC32
[ (SA015A1T) ]	

CAT28C65B@TSOP28 [(SA430T)]	
CAT28C65BI	
CAT28C65BI@PLCC32 [(SA015A1T)]	CAT28C65BI@TSOP28
[(SA430T)]	
CAT28F001N-B@PLCC32 [(SA015A1T)]	CAT28F001N-T@PLCC32
[(SA015A1T)]	
CAT28F001P-B	CAT28F001P-
T	
CAT28F001T-B@TSOP32 [(SA410T)]	CAT28F001T-T@TSOP32
[(SA410T)]	
CAT28F002	CAT28F002@TSOP40
[(SA409T)]	
CAT28F010	CAT28F010@PLCC32
[(SA015A1T)]	
CAT28F010@TSOP32 [(SA410T)]	
CAT28F010I	
CAT28F010I@PLCC32 [(SA015A1T)]	CAT28F010I@TSOP32
[(SA410T)]	
CAT28F020	CAT28F020@PLCC32
[(SA015A1T)]	
CAT28F020@TSOP32 [(SA410T)]	
CAT28F020I	
CAT28F020I@PLCC32 [(SA015A1T)]	CAT28F020I@TSOP32
[(SA410T)]	
CAT28F102	CAT28F102@PLCC44
[(SA244)]	
CAT28F102@TSOP40 [(SA409T)]	
CAT28F512	
CAT28F512@PLCC32 [(SA015A1T)]	CAT28F512@TSOP32
[(SA410T)]	
CAT28F512I	CAT28F512I@PLCC32
[(SA015A1T)]	
CAT28F512I@TSOP32 [(SA410T)]	
CAT28LV256	
CAT28LV256@PLCC32 [(SA015A1T)]	CAT28LV256@TSOP28
[(SA430T)]	
CAT28LV64	CAT28LV64@PLCC32
[(SA015A1T)]	
CAT28LV64@TSOP28 [(SA430T)]	
CAT28LV65	
CAT28LV65@PLCC32 [(SA015A1T)]	CAT28LV65@TSOP28
[(SA430T)]	
CAT33C101(08bit)	

CAT33C101(08bit)@SOIC8 [(SA602A)]	
CAT33C101(16bit)	
CAT33C101(16bit)@SOIC8 [(SA602A)]	
CAT33C101H(08bit)	
CAT33C101H(08bit)@SOIC8 [(SA602A)]	
CAT33C101H(16bit)	
CAT33C101H(16bit)@SOIC8 [(SA602A)]	
CAT33C101I(08bit)	
CAT33C101I(08bit)@SOIC8 [(SA602A)]	
CAT33C101I(16bit)	
CAT33C101I(16bit)@SOIC8 [(SA602A)]	
CAT33C104(08bit)	
CAT33C104(08bit)@SOIC8 [(SA602A)]	
CAT33C104(16bit)	
CAT33C104(16bit)@SOIC8 [(SA602A)]	
CAT33C104I(08bit)	
CAT33C104I(08bit)@SOIC8 [(SA602A)]	
CAT33C104I(16bit)	
CAT33C104I(16bit)@SOIC8 [(SA602A)]	
CAT34AC02	CAT34AC02@SOIC8
[(SA602A)]	
CAT34AC02@TSSOP8 [(SA026)]	
CAT34C02	
CAT34C02@SOIC8 [(SA602A)]	CAT34C02@TDFN8
[(SA694)]	
CAT34C02@TSSOP8 [(SA026)]	
CAT34FC02	
CAT34FC02@SOIC8 [(SA602A)]	CAT34FC02@TDFN8
[(SA694)]	
CAT34FC02@TSSOP8 [(SA026)]	
CAT34RC02	
CAT34RC02@SOIC8 [(SA602A)]	CAT34RC02@TDFN8
[(SA694)]	
CAT34RC02@TSSOP8 [(SA026)]	
CAT34WC02	
CAT34WC02@SOIC8 [(SA602A)]	CAT34WC02@TDFN8
[(SA694)]	
CAT34WC02@TSSOP8 [(SA026)]	
CAT35C102	
CAT35C102H	
CAT35C102I	
CAT35C104(08bit)	
CAT35C104(08bit)@SOIC8 [(SA602A)]	

CAT35C104(16bit)	
CAT35C104(16bit)@SOIC8 [(SA602A)]	
CAT35C104H(08bit)	
CAT35C104H(08bit)@SOIC8 [(SA602A)]	
CAT35C104I(08bit)	
CAT35C104I(08bit)@SOIC8 [(SA602A)]	
CAT35C104I(16bit)	
CAT35C104I(16bit)@SOIC8 [(SA602A)]	
CAT59C11	CAT59C11@SOIC8
[(SA602A)]	
CAT59C11A	CAT59C11A@SOIC8
[(SA602A)]	
CAT59C11H	CAT59C11H@SOIC8
[(SA602A)]	
CAT59C11I	CAT59C11I@SOIC8
[(SA602A)]	
CAT64LC10(J)@SOIC8 [(SA602A)]	CAT64LC10
(P)	
CAT64LC10(S)@SOIC8 [(SA602A)]	CAT64LC10(U)@TSSOP8
[(SA026)]	
CAT64LC10(UR)@TSSOP8 [(SA026)]	CAT64LC20(J)@SOIC8
[(SA602A)]	
CAT64LC20(P)	CAT64LC20(S)@SOIC8
[(SA602A)]	
CAT64LC20(U)@TSSOP8 [(SA026)]	CAT64LC20(UR)@TSSOP8
[(SA026)]	
CAT64LC40(J)@SOIC8 [(SA602A)]	CAT64LC40
(P)	
CAT64LC40(S)@SOIC8 [(SA602A)]	CAT64LC40(U)@TSSOP8
[(SA026)]	
CAT64LC40(UR)@TSSOP8 [(SA026)]	CAT93C46
(08bit)	
CAT93C46(08bit)(J)@SOIC8 [(SA602A)]	
CAT93C46(08bit)(K)@SOIC8 [(SA605A)]	
CAT93C46(08bit)(S)@SOIC8 [(SA602A)]	
CAT93C46(08bit)(U)@TSSOP8 [(SA026)]	
CAT93C46(16bit)	
CAT93C46(16bit)(J)@SOIC8 [(SA602A)]	
CAT93C46(16bit)(K)@SOIC8 [(SA605A)]	
CAT93C46(16bit)(S)@SOIC8 [(SA602A)]	
CAT93C46(16bit)(U)@TSSOP8 [(SA026)]	
CAT93C46A	CAT93C56
(08bit)	

CAT93C56(08bit)@SOIC8 [(SA602A)] CAT93C56  
(16bit)  
CAT93C56(16bit)@SOIC8 [(SA602A)]  
CAT93C56A  
CAT93C57 CAT93C66  
(08bit)  
CAT93C66(08bit)@SOIC8 [(SA602A)] CAT93C66(08bit)@TSSOP8  
[(SA026)]  
CAT93C66(16bit) CAT93C66(16bit)@SOIC8  
[(SA602A)]  
CAT93C66(16bit)@TSSOP8 [(SA026)]  
CAT93C66A  
CAT93C76(08bit)  
CAT93C76(08bit)(J)@SOIC8 [(SA602A)]  
CAT93C76(08bit)(K)@SOIC8 [(SA605A)]  
CAT93C76(08bit)(S)@SOIC8 [(SA602A)]  
CAT93C76(08bit)(U)@TSSOP8 [(SA026)]  
CAT93C76(16bit)  
CAT93C76(16bit)(J)@SOIC8 [(SA602A)]  
CAT93C76(16bit)(K)@SOIC8 [(SA605A)]  
CAT93C76(16bit)(S)@SOIC8 [(SA602A)]  
CAT93C76(16bit)(U)@TSSOP8 [(SA026)]  
CAT93C86(08bit)  
CAT93C86(08bit)(J)@SOIC8 [(SA602A)]  
CAT93C86(08bit)(K)@SOIC8 [(SA605A)]  
CAT93C86(08bit)(S)@SOIC8 [(SA602A)]  
CAT93C86(08bit)(U)@TSSOP8 [(SA026)]  
CAT93C86(16bit)  
CAT93C86(16bit)(J)@SOIC8 [(SA602A)]  
CAT93C86(16bit)(K)@SOIC8 [(SA605A)]  
CAT93C86(16bit)(S)@SOIC8 [(SA602A)]  
CAT93C86(16bit)(U)@TSSOP8 [(SA026)]  
CAT93H46(08bit)  
CAT93H46(08bit)(J)@SOIC8 [(SA602A)]  
CAT93H46(08bit)(K)@SOIC8 [(SA605A)]  
CAT93H46(08bit)(S)@SOIC8 [(SA602A)]  
CAT93H46(08bit)(U)@TSSOP8 [(SA026)]  
CAT93H46(16bit)  
CAT93H46(16bit)(J)@SOIC8 [(SA602A)]  
CAT93H46(16bit)(K)@SOIC8 [(SA605A)]  
CAT93H46(16bit)(S)@SOIC8 [(SA602A)]  
CAT93H46(16bit)(U)@TSSOP8 [(SA026)]  
CAT93HC46(08bit)

CAT93HC46(08bit)(J)@SOIC8 [(SA602A)]  
 CAT93HC46(08bit)(K)@SOIC8 [(SA605A)]  
 CAT93HC46(08bit)(S)@SOIC8 [(SA602A)]  
 CAT93HC46(08bit)(U)@TSSOP8 [(SA026)]  
 CAT93HC46(16bit)  
 CAT93HC46(16bit)(J)@SOIC8 [(SA602A)]  
 CAT93HC46(16bit)(K)@SOIC8 [(SA605A)]  
 CAT93HC46(16bit)(S)@SOIC8 [(SA602A)]  
 CAT93HC46(16bit)(U)@TSSOP8 [(SA026)]

## DRAM & SRAM

CAT71C256 [(SA643)]	CAT71C256@TSOP28
CAT71C256L [(SA643)]	CAT71C256L@TSOP28

## CERAMATE

### E(E) PROM/FRAM/NVRAM

24LC02 [(SA602A)]	24LC02@SOIC8
24LC02@TSSOP8 [(SA026)]	
24LC08 24LC08@SOIC8 [(SA602A)] [(SA026)]	24LC08@TSSOP8
24LC16 [(SA602A)]	24LC16@SOIC8
24LC16@TSSOP8 [(SA026)]	
24LLC02 24LLC02@SOIC8 [(SA602A)] [(SA026)]	24LLC02@TSSOP8
24LLC08 [(SA602A)]	24LLC08@SOIC8
24LLC08@TSSOP8 [(SA026)]	
93LC46 93LC46@SOIC8 [(SA602A)]	
93LC46R 93LC46R@SOIC8 [(SA602A)]	
93LC56	

93LC56@SOIC8 [ (SA602A) ]  
93LC66  
93LC66@SOIC8 [ (SA602A) ]

## CHINA CORE

### MICROCONTROLLER

CCM89C51  
[ (SA244) ]  
CCM89C51@TQFP44 [ (SA245A) ]  
CCM89C52  
CCM89C52@PLCC44 [ (SA244) ]  
[ (SA245A) ]

CCM89C51@PLCC44  
  
  
CCM89C52@TQFP44

## CHINGIS

### E ( E ) PROM / FRAM / NVRAM

PM24C64  
[ (SA602A) ]  
PM24C64@TSOP8 [ (SA026) ]  
[ (SA023A) ]  
PM25LV010(Q)@WSON8 [ (SA683) ]  
[ (SA602A) ]  
PM25LV010A@SOIC8 [ (SA602A) ]  
[ (SA683) ]  
PM25LV016@SOIC8 [ (SA605A) ]  
[ (SA683) ]  
PM25LV016A@SOIC8 [ (SA605A) ]  
[ (SA683) ]  
PM25LV020(B)@SOIC8 [ (SA023A) ]  
[ (SA683) ]  
PM25LV020(S)@SOIC8 [ (SA602A) ]  
[ (SA023A) ]  
PM25LV040(Q)@WSON8 [ (SA683) ]  
[ (SA602A) ]  
PM25LV080@SOIC8 [ (SA605A) ]  
[ (SA683) ]  
PM25LV080A@SOIC8 [ (SA605A) ]

PM24C64@SOIC8  
  
PM25LV010(B)@SOIC8  
  
PM25LV010(S)@SOIC8  
  
PM25LV010A@WSON8  
  
PM25LV016@WSON8  
  
PM25LV016A@WSON8  
  
PM25LV020(Q)@WSON8  
  
PM25LV040(B)@SOIC8  
  
PM25LV040(S)@SOIC8  
  
PM25LV080@WSON8  
  
PM25LV080A@WSON8



[ (SA683) ]	
PM25LV512(B)@SOIC8 [ (SA023A) ]	PM25LV512(Q)@WSON8
[ (SA683) ]	
PM25LV512(S)@SOIC8 [ (SA602A) ]	
PM29F002B	
PM29F002B@PLCC32 [ (SA015A1T) ]	
PM29F002T	
PM29F002T@PLCC32 [ (SA015A1T) ]	
PM29F004B	
PM29F004B@PLCC32 [ (SA015A1T) ]	
PM29F004T	
PM29F004T@PLCC32 [ (SA015A1T) ]	
PM29LV002B	
PM29LV002B@PLCC32 [ (SA015A1T) ]	PM29LV002B@VSOP32
[ (SA620) ]	
PM29LV002T	PM29LV002T@PLCC32
[ (SA015A1T) ]	
PM29LV002T@VSOP32 [ (SA620) ]	PM29LV004B@PLCC32
[ (SA015A1T) ]	
PM29LV004B@VSOP32 [ (SA620) ]	PM29LV004T@PLCC32
[ (SA015A1T) ]	
PM29LV004T@VSOP32 [ (SA620) ]	PM29LV104RB@PLCC32
[ (SA015A1T) ]	
PM29LV104RB@VSOP32 [ (SA620) ]	PM29LV104RT@PLCC32
[ (SA015A1T) ]	
PM29LV104RT@VSOP32 [ (SA620) ]	
PM37LV512	
PM37LV512@PLCC32 [ (SA015A1T) ]	PM37LV512@VSOP32
[ (SA620) ]	
PM39F010	PM39F010@PLCC32
[ (SA015A1T) ]	
PM39F010@VSOP32 [ (SA620) ]	
PM39F020	
PM39F020@PLCC32 [ (SA015A1T) ]	PM39F020@VSOP32
[ (SA620) ]	
PM39F040	PM39F040@PLCC32
[ (SA015A1T) ]	
PM39F040@VSOP32 [ (SA620) ]	PM39LV010@PLCC32
[ (SA015A1T) ]	
PM39LV010@VSOP32 [ (SA620) ]	PM39LV010R@PLCC32
[ (SA015A1T) ]	
PM39LV010R@VSOP32 [ (SA620) ]	PM39LV020@PLCC32
[ (SA015A1T) ]	

PM39LV020@VSOP32 [(SA620)]	PM39LV040@PLCC32
[(SA015A1T)]	
PM39LV040@VSOP32 [(SA620)]	PM39LV512@PLCC32
[(SA015A1T)]	
PM39LV512@VSOP32 [(SA620)]	PM39LV512R@PLCC32
[(SA015A1T)]	
PM39LV512R@VSOP32 [(SA620)]	PM49FL002T@PLCC32
[(SA015A1T)]	
PM49FL002T@VSOP32 [(SA620)]	
PM49FL004T(Low)@PLCC32 [(SA015A1T-B001)]	
PM49FL004T(Low)@VSOP32 [(SA620-B005)]	
PM49FL004T@PLCC32 [(SA015A1T)]	PM49FL004T@VSOP32
[(SA620)]	
PM49FL008T@PLCC32 [(SA015A1T)]	PM49FL008T@VSOP32
[(SA620)]	
PM49LP002T@PLCC32 [(SA015A1T)]	PM49LP002T@VSOP32
[(SA620)]	

## CHIPCON

### MICROCONTROLLER

CC1010@TQFP64(ISP) [ISP-HEADER01]

## CHIPSWINNER

### E(E) PROM/FRAM/NVRAM

CW24C02	CW24C02@SOIC8
[(SA602A)]	
CW24C04	CW24C04@SOIC8
[(SA602A)]	
CW24C08	CW24C08@SOIC8
[(SA602A)]	
CW24C16	CW24C16@SOIC8
[(SA602A)]	
CW24C32	CW24C32@SOIC8
[(SA602A)]	
CW24C64	CW24C64@SOIC8
[(SA602A)]	

## MICROCONTROLLER

CW88CS028@SDIP28 [(SA653)]	CW88CS032@SDIP32
[(SA653)]	
CW88CS128@SDIP28 [(SA653)]	CW88CS132@SDIP32
[(SA653)]	
CW89F1050	
CW89F2050	
CW89F4050@SDIP28 [(SA653)]	CW89F4050@SOP28
[(SA404)]	
CW89F52	CW89F52@LQFP44
[(SA675)]	
CW89F54	CW89F54@LQFP44
[(SA675)]	

## CORERIVER

### E(E) PROM/FRAM/NVRAM

CR24C02LI	CR24C02WI@SOIC8
[(SA602)]	
CR24C08LI	CR24C08WI@SOIC8
[(SA602)]	
CR24C16LI	CR24C16WI@SOIC8
[(SA602)]	
CR24C256LI	CR24C256WI@SOIC8
[(SA602)]	
CR24C32LI	CR24C32WI@SOIC8
[(SA602)]	
CR24C64LI	CR24C64WI@SOIC8
[(SA602)]	

## MICROCONTROLLER

GC87C520A0	GC87C520A0@MQFP44
[(SA675)]	
GC87C520A0@PLCC44 [(SA244)]	

**CWI****E (E) PROM/FRAM/NVRAM**

39LV040@VSOP32 [(SA620)]

**CYGNAL****MICROCONTROLLER**

C8051F002@TQFP32 [(SA663)]	C8051F007@TQFP32
[(SA663)]	
C8051F012@TQFP32 [(SA663)]	C8051F017@TQFP32
[(SA663)]	
C8051F020@TQFP100 (ISP) [ISP-HEADER01]	
C8051F021@TQFP64(*) [(TA050-B005)]	
C8051F021@TQFP64 (ISP) [ISP-HEADER01]	
C8051F022@TQFP100 (ISP) [ISP-HEADER01]	
C8051F023@TQFP64(*) [(TA050-B005)]	
C8051F023@TQFP64 (ISP) [ISP-HEADER01]	
C8051F040@TQFP100 (ISP) [ISP-HEADER01]	
C8051F041@TQFP64(*) [(TA050-B005)]	
C8051F041@TQFP64 (ISP) [ISP-HEADER01]	
C8051F042@TQFP100 (ISP) [ISP-HEADER01]	
C8051F043@TQFP64(*) [(TA050-B005)]	
C8051F043@TQFP64 (ISP) [ISP-HEADER01]	
C8051F044@TQFP100 (ISP) [ISP-HEADER01]	
C8051F045@TQFP64(*) [(TA050-B005)]	
C8051F045@TQFP64 (ISP) [ISP-HEADER01]	
C8051F046@TQFP100 (ISP) [ISP-HEADER01]	
C8051F047@TQFP64(*) [(TA050-B005)]	
C8051F047@TQFP64 (ISP) [ISP-HEADER01]	
C8051F206@TQFP48 [(SA248)]	C8051F220@TQFP48
[(SA248)]	
C8051F221@TQFP32 [(SA663)]	C8051F226@TQFP48
[(SA248)]	
C8051F230@TQFP48 [(SA248)]	C8051F231@TQFP32
[(SA663)]	
C8051F236@TQFP48 [(SA248)]	C8051F300
[(SA695A)]	
C8051F301 [(SA695A)]	C8051F302

[ (SA695A) ]	
C8051F303 [ (SA695A) ]	C8051F304
[ (SA695A) ]	
C8051F305 [ (SA695A) ]	C8051F310@TQFP32
[ (SA663) ]	
C8051F310-GQ@TQFP32 [ (SA663) ]	C8051F311@QFN28 [ (SA697-
B006) ]	
C8051F311-GM@QFN28 [ (SA697-B006) ]	
C8051F312@TQFP32 [ (SA663) ]	C8051F312-GQ@TQFP32
[ (SA663) ]	
C8051F313@QFN28 [ (SA697-B006) ]	
C8051F313-GM@QFN28 [ (SA697-B006) ]	
C8051F314@TQFP32 [ (SA663) ]	C8051F314-GQ@TQFP32
[ (SA663) ]	
C8051F315@QFN28 [ (SA697-B006) ]	
C8051F315-GM@QFN28 [ (SA697-B006) ]	
C8051F316-GM@QFN24 [ (SA710-B006) ]	
C8051F317-GM@QFN24 [ (SA710-B006) ]	
C8051F320@TQFP32 [ (SA663) ]	C8051F321@QFN28 [ (SA697-
B006) ]	
C8051F326@QFN28 [ (SA697-B006) ]	
C8051F326-GQ@QFN28 [ (SA697-B006) ]	
C8051F327@QFN28 [ (SA697-B006) ]	
C8051F327-GQ@QFN28 [ (SA697-B006) ]	
C8051F330@MLP20 [ (SA692) ]	
C8051F330D	
C8051F331@MLP20 [ (SA692) ]	C8051F332-GM@MLP20
[ (SA692) ]	
C8051F333-GM@MLP20 [ (SA692) ]	C8051F334-GM@MLP20
[ (SA692) ]	
C8051F335-GM@MLP20 [ (SA692) ]	C8051F336-GM@QFN20
[ (SA692) ]	
C8051F337-GM@QFN20 [ (SA692) ]	C8051F338-GM@QFN24
[ (SA710) ]	
C8051F339-GM@QFN24 [ (SA710) ]	C8051F340-GQ@TQFP48
[ (SA248) ]	
C8051F341-GQ@TQFP48 [ (SA248) ]	C8051F342-GQ@LQFP32
[ (SA663) ]	
C8051F343-GQ@LQFP32 [ (SA663) ]	C8051F344-GQ@TQFP48
[ (SA248) ]	
C8051F345-GQ@TQFP48 [ (SA248) ]	C8051F346-GQ@LQFP32
[ (SA663) ]	
C8051F347-GQ@LQFP32 [ (SA663) ]	C8051F350-GQ@LQFP32

[(SA663)]	
C8051F351-GM@QFN28 [(SA697-B006)]	
C8051F352-GQ@LQFP32 [(SA663)]	
C8051F353-GM@QFN28 [(SA697-B006)]	
C8051F360@QFP48 [(SA248)]	C8051F361@QFP32
[(SA663)]	
C8051F362@QFN28 [(SA697)]	C8051F363@QFP48
[(SA248)]	
C8051F364@QFP32 [(SA663)]	C8051F365@QFN28
[(SA697)]	
C8051F366@QFP32 [(SA663)]	C8051F367@QFN28
[(SA697)]	
C8051F368@QFP32 [(SA663)]	C8051F369@QFN28
[(SA697)]	
C8051F410-GQ@LQFP32 [ordering number is marked above]	
C8051F411-GM@QFN28 [ordering number is marked above]	
C8051F412-GQ@LQFP32 [ordering number is marked above]	
C8051F413-GM@QFN28 [ordering number is marked above]	
C8051F520-IM@QFN10 [(SA695A)]	C8051F521-IM@QFN10
[(SA695A)]	
C8051F523-IM@QFN10 [(SA695A)]	C8051F524-IM@QFN10
[(SA695A)]	
C8051F526-IM@QFN10 [(SA695A)]	C8051F527-IM@QFN10
[(SA695A)]	
C8051F530-IM@QFN20 [(SA692)]	C8051F530-IT@TSSOP20
[(SA026)]	
C8051F531-IM@QFN20 [(SA692)]	C8051F531-IT@TSSOP20
[(SA026)]	
C8051F533-IM@QFN20 [(SA692)]	C8051F533-IT@TSSOP20
[(SA026)]	
C8051F534-IM@QFN20 [(SA692)]	C8051F534-IT@TSSOP20
[(SA026)]	
C8051F536-IM@QFN20 [(SA692)]	C8051F536-IT@TSSOP20
[(SA026)]	
C8051F537-IM@QFN20 [(SA692)]	C8051F537-IT@TSSOP20
[(SA026)]	
SI8250@LQFP32 [(SA663)]	SI8250@QFN28
[(SA697)]	
SI8251@LQFP32 [(SA663)]	SI8251@QFN28
[(SA697)]	
SI8252@LQFP32 [(SA663)]	SI8252@QFN28
[(SA697)]	

**CYPRESS****E (E) PROM/FRAM/NVRAM**

CY14B256L@SOIC32 [(SA715)]	
CY27C010	
CY27C010@PLCC32 [(SA015A1T)]	CY27C010@TSOP32
[(SA410T)]	
CY27C020	
CY27C020@PLCC32	CY27C020@PLCC32
[(SA015A1T)]	
CY27C020@TSOP32 [(SA410T)]	
CY27C040	
CY27C040@PLCC32 [(SA015A1T)]	CY27C040@TSOP32
[(SA410T)]	
CY27C128	
CY27C128@PLCC32	CY27C128@PLCC32
[(SA015A1T)]	
CY27C256	
CY27C256@PLCC32	CY27C256@PLCC32
[(SA015A1T)]	
CY27C256@TSOP28 [(SA430T)]	
CY27C512	
CY27C512@PLCC32 [(SA015A1T)]	CY27C512@TSOP28
[(SA430T)]	
CY27H010	
CY27H010@PLCC32	CY27H010@PLCC32
[(SA015A1T)]	
CY27H010@TSOP32 [(SA410T)]	
CY27H256	
CY27H256@PLCC32 [(SA015A1T)]	CY27H256@TSOP28
[(SA430T)]	
CY27H512	
CY27H512@PLCC32	CY27H512@PLCC32
[(SA015A1T)]	
CY27H512@TSOP28 [(SA430T)]	
CY7C225A	
CY7C225A@PLCC28 [(SA008A)]	
CY7C243	
CY7C243@PLCC28 [(SA008A)]	
CY7C244	
CY7C244@PLCC28 [(SA008A)]	
CY7C245	
CY7C245@PLCC28 [(SA008A)]	
CY7C245A	
CY7C245A@PLCC28 [(SA008A)]	
CY7C251	

CY7C251@PLCC32 [(SA015A1T)]	
CY7C254	
CY7C254@PLCC32 [(SA015A1T)]	
CY7C256	
CY7C256@PLCC32 [(SA015A1T)]	
CY7C261	
CY7C261@PLCC28 [(SA008A)]	
CY7C263	
CY7C263@PLCC28 [(SA008A)]	
CY7C264	
CY7C264@PLCC28 [(SA008A)]	
CY7C265	
CY7C265@PLCC28 [(SA008A)]	
CY7C266	
CY7C266@PLCC32 [(SA015A1T)]	
CY7C268	
CY7C268@PLCC32 [(SA015A1T)]	
CY7C271	
CY7C271@PLCC32 [(SA015A1T)]	
CY7C271A	
CY7C271A@PLCC32 [(SA015A1T)]	
CY7C274	
CY7C274@PLCC32 [(SA015A1T)]	CY7C276(25HC)@PLCC44
[(SA244)]	
CY7C276(25JC)@PLCC44 [(SA244)]	CY7C276(30JC)@PLCC44
[(SA244)]	
CY7C281	CY7C281@PLCC28
[(SA008A)]	
CY7C281A	CY7C281A@PLCC28
[(SA008A)]	
CY7C282	CY7C282@PLCC28
[(SA008A)]	
CY7C282A	CY7C282A@PLCC28
[(SA008A)]	
CY7C285	CY7C285@PLCC32
[(SA015A1T)]	
CY7C286	CY7C286@PLCC32
[(SA015A1T)]	
CY7C287	CY7C287@PLCC32
[(SA015A1T)]	
CY7C291	CY7C291@PLCC28
[(SA008A)]	
CY7C291A	CY7C291A@PLCC28



[ (SA008A) ]	
CY7C292	CY7C292@PLCC28
[ (SA008A) ]	
CY7C292A	CY7C292A@PLCC28
[ (SA008A) ]	
CY7C293A	CY7C293A@PLCC28
[ (SA008A) ]	
CY8C9520@SSOP28 [ (SA626A) ]	CY8C9540@SSOP48
[ (SA669) ]	

**DRAM & SRAM**

CY62128@SOIC32 [ (SA687) ]	CY62128@SOJ32
[ (SA661) ]	
CY62128@VSOP32 [ (SA620) ]	CY62128L@SOIC32
[ (SA687) ]	
CY62128L@SOJ32 [ (SA661) ]	CY62128L@VSOP32
[ (SA620) ]	
CY62128LL@SOIC32 [ (SA687) ]	CY62128LL@SOJ32
[ (SA661) ]	
CY62128LL@VSOP32 [ (SA620) ]	CY7C1020@TSOP44
[ (SA645) ]	
CY7C1021@TSOP44 [ (SA645) ]	CY7C1049@SOJ36
[ (SA027) ]	
CY7C1049@TSOP44 [ (SA645) ]	
CY7C107	
CY7C107@SOJ28 [ (SA661) ]	
CY7C147	
CY7C167	CY7C167@PLCC20
[ (SA001A) ]	
CY7C167A	CY7C167A@PLCC20
[ (SA001A) ]	
CY7C185	CY7C185@SOIC28
[ (SA404) ]	
CY7C185@SOJ28 [ (SA646) ]	
CY7C186	
CY7C187	CY7C187@SOJ24
[ (SA646) ]	
CY7C187A	CY7C187A@SOJ24
[ (SA646) ]	
CY7C193	CY7C193@SOJ28
[ (SA646) ]	

CY7C199	CY7C199@PLCC28
[ (SA008A) ]	
CY7C199@SOJ28 [ (SA646) ]	CY7C199@TSOP28
[ (SA430T) ]	

**PLD**

CY22381@SOIC8 [ (SA602A) ]	CY22392@TSSOP16
[ (SA026) ]	
CY22393@TSSOP16 [ (SA026) ]	CY22394@TSSOP16
[ (SA026) ]	
CY22395@TSSOP16 [ (SA026) ]	CY2291@SOIC20
[ (SA404) ]	
CY2292@SOIC16 [ (SA602) ]	CY2295@SSOP28
[ (SA626A) ]	
CY37032@PLCC44 [ (SA244) ]	CY37032@TQFP44
[ (SA245A) ]	
CY37032V@PLCC44 [ (SA244) ]	CY37032V@TQFP44
[ (SA245A) ]	
CY37064@PLCC44 [ (SA244) ]	
CY37064@PLCC44( ISP) [ ISP-HEADER01 ]	
CY37064@TQFP44 [ (SA245A) ]	
CY37064@TQFP44( ISP) [ ISP-HEADER01 ]	
CY37064V@PLCC44 [ (SA244) ]	
CY37064V@PLCC44( ISP) [ ISP-HEADER01 ]	
CY37064V@TQFP44 [ (SA245A) ]	
CY37064V@TQFP44( ISP) [ ISP-HEADER01 ]	
CY7C371@PLCC44 [ (SA244) ]	CY7C371@TQFP44
[ (SA245A) ]	
CY7C371I@PLCC44 [ (SA244) ]	CY7C371I@TQFP44
[ (SA245A) ]	
CY7C372@PLCC44 [ (SA244) ]	CY7C372@TQFP44
[ (SA245A) ]	
CY7C372I@PLCC44 [ (SA244) ]	CY7C372I@TQFP44
[ (SA245A) ]	
PALC16L8	PALC16L8@PLCC20
[ (SA001A) ]	
PALC16L8L	PALC16L8L@PLCC20
[ (SA001A) ]	
PALC16R4	PALC16R4@PLCC20
[ (SA001A) ]	
PALC16R4L	PALC16R4L@PLCC20

[ (SA001A) ]	
PALC16R6	PALC16R6@PLCC20
[ (SA001A) ]	
PALC16R6L	PALC16R6L@PLCC20
[ (SA001A) ]	
PALC16R8	PALC16R8@PLCC20
[ (SA001A) ]	
PALC16R8L	PALC16R8L@PLCC20
[ (SA001A) ]	
PALC22V10	
PALC22V10@PLCC28 [ordering number is marked above]	
PALC22V10A	
PALC22V10A@PLCC28 [ordering number is marked above]	
PALC22V10B	
PALC22V10B@PLCC28 [ordering number is marked above]	
PALC22V10D	PALC22V10D@PLCC28
[ (SA008A) ]	
PALC22V10L	
PALC22V10L@PLCC28 [ordering number is marked above]	
PALCE16V8	PALCE16V8@PLCC20
[ (SA001A) ]	
PALCE20V8	PALCE20V8@PLCC28
[ (SA008A) ]	
PALCE20V8L	PALCE20V8L@PLCC28
[ (SA008A) ]	
PALCE22V10	PALCE22V10@PLCC28
[ (SA008A) ]	

## MICROCONTROLLER

CG6457AM@SSOP20 [ (SA626A) ]	CG6462AM@SOIC8
[ (SA602A) ]	
CY7C53120E2@SOIC32 [ (SA687) ]	CY7C53120E2@TQFP44
[ (SA245A) ]	
CY7C53120E4@SOIC32 [ (SA687) ]	CY7C53120E4@TQFP44
[ (SA245A) ]	
CY7C60113@SSOP28 [ (SA626A) ]	
CY7C60123	
CY7C60123@SSOP48 [ (SA669) ]	
CY7C60223	
CY7C60223@QSOP24 [ (SA643) ]	CY7C60223@SOIC24
[ (SA404) ]	

CY7C60323@MLF32 [(SA686)]	CY7C60323@SSOP28
[(SA626A)]	
CY7C60333@MLF32 [(SA686)]	
CY7C63000	
CY7C63000@SOIC20 [(SA404)]	
CY7C63000A	
CY7C63000A@SOIC20 [(SA404)]	
CY7C63001	
CY7C63001@SOIC20 [(SA404)]	
CY7C63001A	
CY7C63001A@SOIC20 [(SA404)]	
CY7C63100	
CY7C63100@SOIC24 [(SA404)]	
CY7C63100A	
CY7C63100A@SOIC24 [(SA404)]	
CY7C63101	
CY7C63101@SOIC24 [(SA404)]	
CY7C63101A	
CY7C63101A@SOIC24 [(SA404)]	
CY7C63200	
CY7C63200@SOIC18 [(SA404)]	
CY7C63200A	
CY7C63200A@SOIC18 [(SA404)]	
CY7C63201	
CY7C63201@SOIC18 [(SA404)]	
CY7C63201A	
CY7C63201A@SOIC18 [(SA404)]	
CY7C63221	
CY7C63221A	
CY7C63231	
CY7C63231@SOIC18 [(SA404)]	
CY7C63231A	
CY7C63231A@SOIC18 [(SA404)]	
CY7C63310	
CY7C63310@SOIC16 [(SA602)]	CY7C63411
(dip40)	
CY7C63411(dip48)	CY7C63411@SSOP48
[(SA669)]	
CY7C63412(dip40)	CY7C63412
(dip48)	
CY7C63412@SSOP48 [(SA669)]	CY7C63413
(dip40)	
CY7C63413(dip48)	CY7C63413@SSOP48

[(SA669)]	
CY7C63511(dip48)	CY7C63511@SSOP48
[(SA669)]	
CY7C63512(dip48)	CY7C63512@SSOP48
[(SA669)]	
CY7C63513(dip48)	CY7C63513@SSOP48
[(SA669)]	
CY7C63722	CY7C63722@SOIC18
[(SA404)]	
CY7C63722C	CY7C63722C@SOIC18
[(SA404)]	
CY7C63723	CY7C63723@SOIC18
[(SA404)]	
CY7C63723C	CY7C63723C@SOIC18
[(SA404)]	
CY7C63742	CY7C63742@QSOP24
[(SA674)]	
CY7C63742@SOIC24 [(SA404)]	
CY7C63742C	
CY7C63742C@QSOP24 [(SA674)]	CY7C63742C@SOIC24
[(SA404)]	
CY7C63743	CY7C63743@QSOP24
[(SA674)]	
CY7C63743@SOIC24 [(SA404)]	
CY7C63743C	
CY7C63743C@QSOP24 [(SA674)]	CY7C63743C@SOIC24
[(SA404)]	
CY7C63801	CY7C63801@SOIC16
[(SA602)]	
CY7C63803@SOIC16 [(SA602)]	
CY7C63813	
CY7C63813@SOIC18 [(SA404)]	
CY7C63823	
CY7C63823@QSOP24 [(SA643)]	CY7C63823@SOIC24
[(SA404)]	
CY7C63833@QFN32 [(SA686)]	CY7C63903@SSOP28
[(SA626A)]	
CY7C63913	CY7C63923@SSOP48
[(SA669)]	
CY7C64011	CY7C64011@SOIC28
[(SA404)]	
CY7C64011C	CY7C64011C@SOIC28
[(SA404)]	

CY7C64012	CY7C64012@SOIC28
[(SA404)]	
CY7C64012C	CY7C64012C@SOIC28
[(SA404)]	
CY7C64013	CY7C64013@SOIC28
[(SA404)]	
CY7C64013C	CY7C64013C@SOIC28
[(SA404)]	
CY7C64111	CY7C64111@SSOP48
[(SA669)]	
CY7C64111C	CY7C64111C@SSOP48
[(SA669)]	
CY7C64112	CY7C64112@SSOP48
[(SA669)]	
CY7C64112C	CY7C64112C@SSOP48
[(SA669)]	
CY7C64113	CY7C64113@SSOP48
[(SA669)]	
CY7C64113C	CY7C64113C@SSOP48
[(SA669)]	
CY7C64215@MLF56(*) [(SA706+B268)]	
CY7C64215@SSOP28 [(SA626A)]	
CY7C65013	
CY7C65013@SSOP48 [(SA669)]	
CY7C65013C	
CY7C65013C@SSOP48 [(SA669)]	
CY7C65113	
CY7C65113@SOIC28 [(SA404)]	
CY7C65113C	
CY7C65113C@SOIC28 [(SA404)]	
CY7C66011	
CY7C66011@SSOP48 [(SA669)]	
CY7C66011C	
CY7C66011C@SSOP48 [(SA669)]	
CY7C66012	
CY7C66012@SSOP48 [(SA669)]	
CY7C66012C	
CY7C66012C@SSOP48 [(SA669)]	
CY7C66013	
CY7C66013@SSOP48 [(SA669)]	
CY7C66013C	
CY7C66013C@SSOP48 [(SA669)]	
CY7C66111@SSOP56(*) [(SA772-B183)]	

CY7C66111@TSOP56(\*) [(SA628+B183)]  
 CY7C66111C@SSOP56(\*) [(SA772-B183)]  
 CY7C66111C@TSOP56(\*) [(SA628+B183)]  
 CY7C66112@SSOP56(\*) [(SA772-B183)]  
 CY7C66112@TSOP56(\*) [(SA628+B183)]  
 CY7C66112C@SSOP56(\*) [(SA772-B183)]  
 CY7C66112C@TSOP56(\*) [(SA628+B183)]  
 CY7C66113@SSOP56(\*) [(SA772-B183)]  
 CY7C66113@TSOP56(\*) [(SA628+B183)]  
 CY7C66113C@SSOP56(\*) [(SA772-B183)]  
 CY7C66113C@TSOP56(\*) [(SA628+B183)]  
 CY8C20000@MLF48 [(SA696)]  
 CY8C20000@MLF48(ISP) [ISP-HEADER01]  
 CY8C20234@MLF16 [(SA743)]  
 CY8C20234@MLF16(ISP) [ISP-HEADER01]  
 CY8C20334@MLF24 [(SA710)]  
 CY8C20334@MLF24(ISP) [ISP-HEADER01]  
 CY8C20434@MLF32 [(SA686)]  
 CY8C20434@MLF32(ISP) [ISP-HEADER01]  
 CY8C21123@SOIC8 [(SA602A)] CY8C21223@SOIC16  
 [(SA602)]  
 CY8C21234@SOIC16 [(SA602)] CY8C21323@MLF24  
 [(BBBB)]  
 CY8C21323@SSOP20 [(SA626A)] CY8C21334@SSOP20  
 [(SA626A)]  
 CY8C21434@MLF32 [(SA686)] CY8C21534@SSOP28  
 [(SA626A)]  
 CY8C21634@MLF32 [(SA686)]  
 CY8C22113  
 CY8C22113@SOIC8 [(SA602A)]  
 CY8C22213  
 CY8C22213@MLF32 [(SA686)] CY8C22213@SOIC20  
 [(SA404)]  
 CY8C22213@SSOP20 [(SA626A)]  
 CY8C24123  
 CY8C24123(ISP) [ISP-HEADER01] CY8C24123@SOIC8  
 [(SA602A)]  
 CY8C24123@SOIC8(ISP) [ISP-HEADER01]  
 CY8C24123A CY8C24123A(ISP) [ISP-  
 HEADER01]  
 CY8C24123A@SOIC8 [(SA602A)]  
 CY8C24123A@SOIC8(ISP) [ISP-HEADER01]  
 CY8C24223 CY8C24223(ISP) [ISP-

HEADER01 ]

CY8C24223@SOIC20 [ (SA404) ]

CY8C24223@SOIC20(ISP) [ ISP-HEADER01 ]

CY8C24223@SSOP20 [ (SA626A) ]

CY8C24223@SSOP20(ISP) [ ISP-HEADER01 ]

CY8C24223A  
CY8C24223A(ISP) [ ISP-  
HEADER01 ]

CY8C24223A@SOIC20 [ (SA404) ]

CY8C24223A@SOIC20(ISP) [ ISP-HEADER01 ]

CY8C24223A@SSOP20 [ (SA626A) ]

CY8C24223A@SSOP20(ISP) [ ISP-HEADER01 ]

CY8C24423  
CY8C24423(ISP) [ ISP-  
HEADER01 ]

CY8C24423@MLF32 [ (SA686) ]

CY8C24423@MLF32(ISP) [ ISP-HEADER01 ]

CY8C24423@SOIC28 [ (SA404) ]

CY8C24423@SOIC28(ISP) [ ISP-HEADER01 ]

CY8C24423@SSOP28 [ (SA626A) ]

CY8C24423@SSOP28(ISP) [ ISP-HEADER01 ]

CY8C24423A  
CY8C24423A(ISP) [ ISP-  
HEADER01 ]

CY8C24423A@MLF32 [ (SA686) ]

CY8C24423A@MLF32(ISP) [ ISP-HEADER01 ]

CY8C24423A@SOIC28 [ (SA404) ]

CY8C24423A@SOIC28(ISP) [ ISP-HEADER01 ]

CY8C24423A@SSOP28 [ (SA626A) ]

CY8C24423A@SSOP28(ISP) [ ISP-HEADER01 ]

CY8C24533  
CY8C24533(ISP) [ ISP-  
HEADER01 ]

CY8C24533@SOIC28 [ (SA404) ]

CY8C24533@SOIC28(ISP) [ ISP-HEADER01 ]

CY8C24533@SSOP28 [ (SA626A) ]

CY8C24533@SSOP28(ISP) [ ISP-HEADER01 ]

CY8C24533A  
CY8C24533A(ISP) [ ISP-  
HEADER01 ]

CY8C24533A@SOIC28 [ (SA404) ]

CY8C24533A@SOIC28(ISP) [ ISP-HEADER01 ]

CY8C24533A@SSOP28 [ (SA626A) ]

CY8C24533A@SSOP28(ISP) [ ISP-HEADER01 ]

CY8C24633  
CY8C24633(ISP) [ ISP-  
HEADER01 ]

CY8C24633@SOIC28 [ (SA404) ]

CY8C24633@SOIC28(ISP) [ ISP-HEADER01 ]



CY8C24633@SSOP28 [(SA626A)]  
 CY8C24633@SSOP28(ISP) [ISP-HEADER01]  
 CY8C24633A CY8C24633A(ISP) [ISP-  
 HEADER01]  
 CY8C24633A@SOIC28 [(SA404)]  
 CY8C24633A@SOIC28(ISP) [ISP-HEADER01]  
 CY8C24633A@SSOP28 [(SA626A)]  
 CY8C24633A@SSOP28(ISP) [ISP-HEADER01]  
 CY8C24794@MLF56(\*) [(SA706+B268)]  
 CY8C24894@MLF56(\*) [(SA706+B268)]  
 CY8C25122  
 CY8C26233  
 CY8C26233@SOIC20 [(SA404)] CY8C26233@SSOP20  
 [(SA626A)]  
 CY8C26443 CY8C26443@SOIC28  
 [(SA404)]  
 CY8C26443@SSOP28 [(SA626A)]  
 CY8C26643  
 CY8C26643@SSOP48 [(SA669)] CY8C26643@TQFP44  
 [(SA245A)]  
 CY8C27143  
 CY8C27243  
 CY8C27243@SOIC20 [(SA404)] CY8C27243@SSOP20  
 [(SA626A)]  
 CY8C27443 CY8C27443@SOIC28  
 [(SA404)]  
 CY8C27443@SSOP28 [(SA626A)]  
 CY8C27466  
 CY8C27466@SSOP28 [(SA626A)] CY8C27543@TQFP44  
 [(SA245A)]  
 CY8C27566@TQFP44 [(SA245A)] CY8C27643@MLF48  
 [(SA696)]  
 CY8C27643@SSOP48 [(SA669)] CY8C27666@MLF48  
 [(SA696)]  
 CY8C27666@SSOP48 [(SA669)]  
 CY8C27866@TQFP100(\*) [(TA052-B006)]  
 CY8C29466 CY8C29466@SSOP28  
 [(SA626A)]  
 CY8C29566@TQFP44 [(SA245A)] CY8C29666@MLF48  
 [(SA696)]  
 CY8C29666@SSOP48 [(SA669)]  
 CY8C29866@TQFP100(\*) [(TA052-B006)]

# DALLAS

## E (E) PROM/FRAM/NVRAM

DS1073M-100

60

DS1073M-66

80

DS1073Z-100@SOIC8 [(SA602A)]

[(SA602A)]

DS1073Z-66@SOIC8 [(SA602A)]

[(SA602A)]

DS1077LZ-40@SOIC8 [(SA602A)]

[(SA602A)]

DS1077LZ-60@SOIC8 [(SA602A)]

[(SA602A)]

DS1077Z-40@SOIC8 [(SA602A)]

[(SA602A)]

DS1077Z-60@SOIC8 [(SA602A)]

[(SA602A)]

DS1220AB

DS1220AD

DS1220Y

DS1225AB

DS1225AD

DS1225D

DS1225E

DS1225Y

DS1230AB

DS1230W

DS1230Y

DS1235AB

DS1235Y

DS1243Y

DS1244

DS1244Y

DS1245AB

DS1245EE

DS1245P

DS1245W

DS1245Y

DS1248P

DS1073M-

DS1073M-

DS1073Z-60@SOIC8

DS1073Z-80@SOIC8

DS1077LZ-50@SOIC8

DS1077LZ-66@SOIC8

DS1077Z-50@SOIC8

DS1077Z-66@SOIC8

DS1248W  
DS1248Y  
DS1249AB  
DS1249W  
DS1249Y  
DS1250AB  
DS1250W  
DS1250Y  
DS1251AB  
DS1251W  
DS1251Y  
DS1256P  
DS1256W  
DS1256Y  
DS1265AB  
DS1265W  
DS1265Y  
DS1270AB  
DS1270W  
DS1270Y  
DS1284  
DS1284N  
DS1284Q@PLCC28 [(SA008A)]  
[(SA008A)]  
DS1286  
DS1286I  
DS1287  
DS1287A  
DS12887  
DS12887A  
DS12C887  
DS12C887A  
DS1330AB  
DS1330WP  
DS1330Y  
DS1345AB  
DS1345P  
DS1345W  
DS1345Y  
DS1350AB  
DS1350P  
DS1350W  
DS1350Y

DS1284QN@PLCC28

DS1386

( 32K )

DS1386 ( 8K )

DS14285

DS14287

DS1485

DS1485@SOIC28 [ ( SA630 ) ]

DS1486

DS1488

DS1553

DS1553W

DS1554

DS1554W

DS1556

DS1630AB

DS1630Y

DS1642

DS1643

DS1644

DS1644P [ordering number is marked above]

DS1644PS [ ( PEP+S414T ) ]

DS1645AB

DS1645EE

DS1645Y

DS1646

DS1647

DS1647LPM

DS1650AB

DS1650Y

DS1687-

3

DS1687-5

DS17287-

3

DS17287-5

DS1742

DS1742W

DS1743

DS1743P

DS1743W

DS1743WP

DS1744

DS1744P

DS1744W

DS1744WP

DS1746

DS1747	
DS1747P [ordering number is marked above]	
DS1747PS [(PEP+S414T)]	
DS1747W	
DS1747WP [ordering number is marked above]	
DS1747WPS [(PEP+S414T)]	DS17487-
3	
DS17487-5	DS17887-
3	
DS17887-5	DS2406@TO-
92	
DS2406P@TSOC6	DS2430A@TO-
92	
DS2430AP@TSOC6 [(SA602A)]	DS2431@TO-
92	
DS2431P@TSOC6 [(SA602A)]	DS2432P@TSOC6
[(SA602A)]	
DS2433@PR-35	DS2433S(3.9)@SOIC8
[(SA602A)]	
DS2433S(5.5)@SOIC8 [(SA605A)]	
DS2502	
DS2502P@TSOC6 [(SA602A)]	DS2502S@SOIC8
[(SA602A)]	
DS2502UNW	DS2502UNW@SOIC8
[(SA602A)]	
DS2502UNW@TSOC6 [(SA602A)]	
DS2506	
DS2506S@SOIC8 [(SA023A)]	
DS4510@uSOP10	
DS4520@TSSOP16 [(SA026)]	DS4550@TSSOP20
[(SA026)]	

## MICROCONTROLLER

DS87C520	DS87C520@PLCC44
[(SA244)]	
DS87C520@TQFP44 [(SA245A)]	
DS89C420	
DS89C420(rev.A)	DS89C420(rev.A)@PLCC44
[(SA244)]	
DS89C420(rev.A)@TQFP44 [(SA245A)]	
DS89C420@PLCC44 [(SA244)]	DS89C420@TQFP44

[ ( SA245A ) ]	
DS89C430	DS89C430@PLCC44
[ ( SA244 ) ]	
DS89C430@TQFP44 [ ( SA245A ) ]	
DS89C440	
DS89C440@PLCC44 [ ( SA244 ) ]	DS89C440@TQFP44
[ ( SA245A ) ]	
DS89C450	DS89C450@PLCC44
[ ( SA244 ) ]	
DS89C450@TQFP44 [ ( SA245A ) ]	

## DENSE-PAC

### E ( E ) PROM / FRAM / NVRAM

DPV27C101	DPV27C101@PLCC32
[ ( SA015A1T ) ]	
DPV27C256	DPV27C256@PLCC32
[ ( SA015A1T ) ]	
DPV27C512	DPV27C512@PLCC32
[ ( SA015A1T ) ]	

## DEUTRON

### E ( E ) PROM / FRAM / NVRAM

AC25LV010	AC25LV010@SOIC8
[ ( SA602A ) ]	
AC25LV512	AC25LV512@SOIC8
[ ( SA602A ) ]	
P439LV010@PLCC32 [ ( SA015A1T ) ]	P439LV010@VSOP32
[ ( SA620 ) ]	
P439LV040@PLCC32 [ ( SA015A1T ) ]	P439LV040@VSOP32
[ ( SA620 ) ]	
P439LV088@TSOP48 [ ( SA247-B005 ) ]	P439VF800@TSOP48 [ ( SA247-B005 ) ]

## EFST

## **E ( E ) PROM / FRAM / NVRAM**

EM25LV010@SOIC8 [ ( SA602A ) ] [ ( SA684 ) ]	EM25LV010@VFQFPN8
EM25LV512@SOIC8 [ ( SA602A ) ] [ ( SA684 ) ]	EM25LV512@VFQFPN8
F25L004A@SOIC8 [ ( SA602A ) ] F49B002UA	
F49B002UA@PLCC32 [ ( SA015A1T ) ] [ ( SA015A1T ) ]	F49L004BA@PLCC32
F49L004BA@TSOP40 [ ( SA409T ) ] [ ( SA015A1T ) ]	F49L004UA@PLCC32
F49L004UA@TSOP40 [ ( SA409T ) ] [ ( SA015A1T ) ]	F49L040A@PLCC32
F49L040A@VSOP32 [ ( SA620 ) ] B005 ]	F49L400BA@TSOP48 [ ( SA247-
F49L400UA@TSOP48 [ ( SA247-B005 ) ] [ ( SA247 ) ]	F49L800BA@TSOP48
F49L800UA@TSOP48 [ ( SA247 ) ]	

## **ELECTRONIC ARRAYS**

### **E ( E ) PROM / FRAM / NVRAM**

EA2716

## **ELPIDA**

### **E ( E ) PROM / FRAM / NVRAM**

EHD0010A1MA@FBGA137 [ ( SA700C-B327A-Y137F001Y ) ]  
EHD013011MA@FBGA137 [ ( SA700C-B327A-Y137F001Y ) ]

## **EM**

### **MICROCONTROLLER**

EM6503@SOIC24 [ ( SA404 ) ]  
EM6503@SOIC24 ( ISP ) [ ISP-HEADER01 ]

EM6504@SOIC24 [(SA404)]  
 EM6504@SOIC24(ISP) [ISP-HEADER01]  
 EM6505@SOIC24 [(SA404)]  
 EM6505@SOIC24(ISP) [ISP-HEADER01]  
 EM6517@SOIC28 [(SA404)]  
 EM6517@SOIC28(ISP) [ISP-HEADER01]  
 EM6520@TQFP44 [(SA245A)]  
 EM6520@TQFP44(ISP) [ISP-HEADER01]  
 EM6521@TQFP52(ISP) [ISP-HEADER01]  
 EM6522@TQFP64(ISP) [ISP-HEADER01]  
 EM6540@SOIC18 [(SA404)]  
 EM6540@SOIC18(ISP) [ISP-HEADER01]  
 EM6580  
 EM6580(ISP) [ISP-  
 HEADER01]  
 EM6580@SOIC14 [(SA602)]  
 EM6580@SOIC14(ISP) [ISP-HEADER01]  
 EM6580@SOIC8 [(SA602A)]  
 EM6580@SOIC8(ISP) [ISP-  
 HEADER01]  
 EM6580@TSSOP14 [(SA026)]  
 EM6580@TSSOP14(ISP) [ISP-HEADER01]  
 EM6812\_2K  
 EM6812\_2K(ISP) [ISP-  
 HEADER01]  
 EM6812\_2K@SOIC24 [(SA404)]  
 EM6812\_2K@SOIC24(ISP) [ISP-HEADER01]  
 EM6812\_2K@TSSOP24 [(SA026)]  
 EM6812\_2K@TSSOP24(ISP) [ISP-HEADER01]  
 EM6812\_4K  
 EM6812\_4K(ISP) [ISP-  
 HEADER01]  
 EM6812\_4K@SOIC24 [(SA404)]  
 EM6812\_4K@SOIC24(ISP) [ISP-HEADER01]  
 EM6812\_4K@TSSOP24 [(SA026)]  
 EM6812\_4K@TSSOP24(ISP) [ISP-HEADER01]  
 EM6812\_8K  
 EM6812\_8K(ISP) [ISP-  
 HEADER01]  
 EM6812\_8K@SOIC24 [(SA404)]  
 EM6812\_8K@SOIC24(ISP) [ISP-HEADER01]  
 EM6812\_8K@TSSOP24 [(SA026)]  
 EM6812\_8K@TSSOP24(ISP) [ISP-HEADER01]

## EMTC

### E (E) PROM/FRAM/NVRAM



EM24C02 [ (SA602A) ]	EM24C02@SOIC8
EM24C02@TSSOP8 [ (SA026) ]	
EM24C04 EM24C04@SOIC8 [ (SA602A) ]	EM24C04@TSSOP8
[ (SA026) ]	
EM24C08 [ (SA602A) ]	EM24C08@SOIC8
EM24C08@TSSOP8 [ (SA026) ]	
EM24C16 EM24C16@SOIC8 [ (SA602A) ]	EM24C16@TSSOP8
[ (SA026) ]	
EM25SL512@SOIC8 [ (SA602A) ]	
EM29SF002AB EM29SF002AB@PLCC32 [ (SA015A1T) ]	EM29SF002AB@TSOP32
[ (SA410T) ]	
EM29SF002AT [ (SA015A1T) ]	EM29SF002AT@PLCC32
EM29SF002AT@TSOP32 [ (SA410T) ]	
EM29SF002NAB EM29SF002NAB@PLCC32 [ (SA015A1T) ]	EM29SF002NAB@TSOP32
[ (SA410T) ]	
EM29SF002NAT [ (SA015A1T) ]	EM29SF002NAT@PLCC32
EM29SF002NAT@TSOP32 [ (SA410T) ]	

## EON

### E ( E ) PROM / FRAM / NVRAM

EN25B05 (Bottom Boot)@SOP8 (4.0) [ (SA602A) ]	
EN25B05 (Bottom Boot)@SOP8 (5.4) [ (SA605A) ]	
EN25B05 (Bottom Boot)@VDFN8 [ (SA683) ]	
EN25B05 (Top Boot)@SOP8 (4.0) [ (SA602A) ]	
EN25B05 (Top Boot)@SOP8 (5.4) [ (SA605A) ]	
EN25B05 (Top Boot)@VDFN8 [ (SA683) ]	
EN25B10 (Bottom Boot)@SOP8 (4.0) [ (SA602A) ]	
EN25B10 (Bottom Boot)@SOP8 (5.4) [ (SA605A) ]	
EN25B10 (Bottom Boot)@VDFN8 [ (SA683) ]	
EN25B10 (Top Boot)@SOP8 (4.0) [ (SA602A) ]	
EN25B10 (Top Boot)@SOP8 (5.4) [ (SA605A) ]	

EN25B10(Top Boot)@VDFN8 [(SA683)]  
EN25B16(Bottom Boot)@SOP8 [(SA605A)]  
EN25B16(Bottom Boot)@SOP8(ISP) [ISP-HEADER01]  
EN25B16(Bottom Boot)@VFQFN8(ISP) [ISP-HEADER01]  
EN25B16(Bottom Boot)@VFQFPN8 [(SA684)]  
EN25B16(Top Boot)@SOP8 [(SA605A)]  
EN25B16(Top Boot)@SOP8(ISP) [ISP-HEADER01]  
EN25B16(Top Boot)@VFQFN8(ISP) [ISP-HEADER01]  
EN25B16(Top Boot)@VFQFPN8 [(SA684)]  
EN25B20(Bottom Boot)@SOP8(4.0) [(SA602A)]  
EN25B20(Bottom Boot)@SOP8(5.4) [(SA605A)]  
EN25B20(Bottom Boot)@VDFN8 [(SA683)]  
EN25B20(Top Boot)@SOP8(4.0) [(SA602A)]  
EN25B20(Top Boot)@SOP8(5.4) [(SA605A)]  
EN25B20(Top Boot)@VDFN8 [(SA683)]  
EN25B32(Bottom Boot)@SOIC16 [(SA404)]  
EN25B32(Bottom Boot)@SOIC16(ISP) [(SA404)]  
EN25B32(Bottom Boot)@SOP8 [(SA605A)]  
EN25B32(Bottom Boot)@SOP8(ISP) [(SA605A)]  
EN25B32(Bottom Boot)@VDFN8 [(SA684)]  
EN25B32(Bottom Boot)@VDFN8(ISP) [(SA684)]  
EN25B32(Top Boot)@SOIC16 [(SA404)]  
EN25B32(Top Boot)@SOIC16(ISP) [(SA404)]  
EN25B32(Top Boot)@SOP8 [(SA605A)]  
EN25B32(Top Boot)@SOP8(ISP) [(SA605A)]  
EN25B32(Top Boot)@VDFN8 [(SA684)]  
EN25B32(Top Boot)@VDFN8(ISP) [(SA684)]  
EN25B40(Bottom Boot)@SOP8(4.0) [(SA602A)]  
EN25B40(Bottom Boot)@SOP8(5.4) [(SA605A)]  
EN25B40(Bottom Boot)@VDFN8 [(SA683)]  
EN25B40(Top Boot)@SOP8(4.0) [(SA602A)]  
EN25B40(Top Boot)@SOP8(5.4) [(SA605A)]  
EN25B40(Top Boot)@VDFN8 [(SA683)]  
EN25B64(Bottom Boot)@SOIC16 [(SA404)]  
EN25B64(Bottom Boot)@SOIC16(ISP) [ISP-HEADER01]  
EN25B64(Bottom Boot)@VDFN8 [(SA683)]  
EN25B64(Bottom Boot)@VDFN8(ISP) [ISP-HEADER01]  
EN25B64(Top Boot)@SOIC16 [(SA404)]  
EN25B64(Top Boot)@SOIC16(ISP) [ISP-HEADER01]  
EN25B64(Top Boot)@VDFN8 [(SA683)]  
EN25B64(Top Boot)@VDFN8(ISP) [ISP-HEADER01]  
EN25B80(Bottom Boot)@SOP8(4.0) [(SA602A)]  
EN25B80(Bottom Boot)@SOP8(5.4) [(SA605A)]

EN25B80(Bottom Boot)@VDFN8 [(SA683)]	
EN25B80(Top Boot)@SOP8(4.0) [(SA602A)]	
EN25B80(Top Boot)@SOP8(5.4) [(SA605A)]	
EN25B80(Top Boot)@VDFN8 [(SA683)]	
EN25F10@SOP8 [(SA605A)]	EN25F10@VDFN8
[(SA683)]	
EN25F20@SOP8 [(SA605A)]	EN25F20@VDFN8
[(SA683)]	
EN25F40@SOP8(150mil) [(SA602A)]	EN25F40@SOP8(209mil)
[(SA605A)]	
EN25F40@VDFN8 [(SA683)]	EN25F80@SOP8
[(SA605A)]	
EN25F80@VDFN8 [(SA683)]	EN25LV010@SOIC8
[(SA602A)]	
EN25LV010@VFQFPN8 [(SA684)]	EN25LV020@SOIC8
[(SA602A)]	
EN25LV020@VFQFPN8 [(SA684)]	EN25LV040@SOIC8
[(SA602A)]	
EN25LV040@VFQFPN8 [(SA684)]	EN25LV080@SOIC8
[(SA602A)]	
EN25LV080@VFQFPN8 [(SA684)]	EN25LV160@SOIC8
[(SA602A)]	
EN25LV160@SOIC8(ISP) [ISP-HEADER01]	
EN25LV160@VFQFPN8 [(SA683)]	
EN25LV160@VFQFPN8(ISP) [ISP-HEADER01]	
EN25LV512@SOIC8 [(SA602A)]	EN25LV512@VFQFPN8
[(SA684)]	
EN25P05@SOP8(4.0) [(SA602A)]	EN25P05@SOP8(5.4)
[(SA605A)]	
EN25P05@VDFN8 [(SA683)]	EN25P10@SOP8(4.0)
[(SA602A)]	
EN25P10@SOP8(5.4) [(SA605A)]	EN25P10@VDFN8
[(SA683)]	
EN25P16@SOP8 [(SA605A)]	EN25P16@SOP8(ISP) [ISP-
HEADER01]	
EN25P16@VFQFPN8 [(SA684)]	
EN25P16@VFQFPN8(ISP) [ISP-HEADER01]	
EN25P20@SOP8(4.0) [(SA602A)]	EN25P20@SOP8(5.4)
[(SA605A)]	
EN25P20@VDFN8 [(SA683)]	EN25P32@SOIC16
[(SA404)]	
EN25P32@SOIC16(ISP) [(SA404)]	EN25P32@SOP8
[(SA605A)]	

EN25P32@SOP8 (ISP) [(SA605A)]	EN25P32@VDFN8
[(SA684)]	
EN25P32@VDFN8 (ISP) [(SA684)]	EN25P40@SOP8 (4.0)
[(SA602A)]	
EN25P40@SOP8 (5.4) [(SA605A)]	EN25P40@VDFN8
[(SA683)]	
EN25P64@SOIC16 [(SA404)]	
EN25P64@SOIC16 (ISP) [ISP-HEADER01]	
EN25P64@VDFN8 [(SA683)]	
EN25P64@VDFN8 (ISP) [ISP-HEADER01]	
EN25P80@SOP8 (4.0) [(SA602A)]	EN25P80@SOP8 (5.4)
[(SA605A)]	
EN25P80@VDFN8 [(SA683)]	EN25S16@SOP8
[(SA605A)]	
EN25S16@VFQFPN8 [(SA684)]	EN25T16@SOP8
[(SA605A)]	
EN25T16@VFQFPN8 [(SA684)]	
EN25T80	
EN25T80@SOP8 [(SA605A)]	EN25T80@VDFN8
[(SA683)]	
EN27C010	EN27C010@PLCC32
[(SA015A1T)]	
EN27C512	EN27C512@PLCC32
[(SA015A1T)]	
EN29F002AB	EN29F002AB@PLCC32
[(SA015A1T)]	
EN29F002AB@TSOP32 [(SA410T)]	
EN29F002ANB	EN29F002ANB@TSOP32
EN29F002ANB@PLCC32 [(SA015A1T)]	
[(SA410T)]	
EN29F002ANT	EN29F002ANT@PLCC32
[(SA015A1T)]	
EN29F002ANT@TSOP32 [(SA410T)]	
EN29F002AT	EN29F002AT@TSOP32
EN29F002AT@PLCC32 [(SA015A1T)]	
[(SA410T)]	
EN29F002B	EN29F002B@PLCC32
[(SA015A1T)]	
EN29F002B@TSOP32 [(SA410T)]	
EN29F002NB	EN29F002NB@TSOP32
EN29F002NB@PLCC32 [(SA015A1T)]	
[(SA410T)]	
EN29F002NT	EN29F002NT@PLCC32

[ (SA015A1T) ]	
EN29F002NT@TSOP32 [ (SA410T) ]	
EN29F002T	
EN29F002T@PLCC32 [ (SA015A1T) ]	EN29F002T@TSOP32
[ (SA410T) ]	
EN29F010	EN29F010@PLCC32
[ (SA015A1T) ]	
EN29F010@TSOP32 [ (SA410T) ]	EN29F010@VSOP32
[ (SA620) ]	
EN29F040	EN29F040@PLCC32
[ (SA015A1T) ]	
EN29F040@TSOP32 [ (SA410T) ]	
EN29F040A	
EN29F040A@PLCC32 [ (SA015A1T) ]	EN29F040A@TSOP32
[ (SA410T) ]	
EN29F080@TSOP40 [ (SA409T) ]	
EN29F512	
EN29F512@PLCC32 [ (SA015A1T) ]	EN29F512@TSOP32
[ (SA410T) ]	
EN29F512@VSOP32 [ (SA620) ]	EN29F800B@TSOP48 [ (SA247-
B005) ]	
EN29F800T@TSOP48 [ (SA247-B005) ]	EN29LV010@PLCC32
[ (SA015A1T) ]	
EN29LV010@TSOP32 [ (SA410T) ]	EN29LV010@VSOP32
[ (SA620) ]	
EN29LV040@PLCC32 [ (SA015A1T) ]	EN29LV040@TSOP32
[ (SA410T) ]	
EN29LV040@VSOP32 [ (SA620) ]	EN29LV040A@PLCC32
[ (SA015A1T) ]	
EN29LV040A@TSOP32 [ (SA410T) ]	EN29LV040A@VSOP32
[ (SA620) ]	
EN29LV160AB@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
EN29LV160AB@TSOP48 [ (SA247-B005) ]	
EN29LV160AT@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
EN29LV160AT@TSOP48 [ (SA247-B005) ]	
EN29LV160B@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
EN29LV160B@TSOP48 [ (SA247-B005) ]	
EN29LV160T@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
EN29LV160T@TSOP48 [ (SA247-B005) ]	
EN29LV320AB@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
EN29LV320AB@TSOP48 [ (SA247-B005) ]	
EN29LV320AT@FBGA48 [ (SA642G-B026A-T048F001Y) ]	
EN29LV320AT@TSOP48 [ (SA247-B005) ]	

EN29LV320B@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
EN29LV320B@TSOP48 [ ( SA247-B005 ) ]  
EN29LV320T@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
EN29LV320T@TSOP48 [ ( SA247-B005 ) ]  
EN29LV400AB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV400AB@TSOP48 [ ( SA247-B005 ) ]  
EN29LV400AT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV400AT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV400B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV400B@TSOP48 [ ( SA247-B005 ) ]  
EN29LV400T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV400T@TSOP48 [ ( SA247-B005 ) ] EN29LV512@PLCC32  
[ ( SA015A1T ) ]  
EN29LV512@TSOP32 [ ( SA410T ) ] EN29LV512@VSOP32  
[ ( SA620 ) ]  
EN29LV640B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV640B@TSOP48 [ ( SA247-B005 ) ]  
EN29LV640H@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV640H@TSOP48 [ ( SA247-B005 ) ]  
EN29LV640L@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV640L@TSOP48 [ ( SA247-B005 ) ]  
EN29LV640T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV640T@TSOP48 [ ( SA247-B005 ) ]  
EN29LV641H@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
EN29LV641H@TSOP48 [ ( SA247-B005 ) ]  
EN29LV641L@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
EN29LV641L@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800AB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800AB@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800AT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29LV800AT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800B@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800BB@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
EN29LV800BB@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800BT@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
EN29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
EN29LV800T@TSOP48 [ ( SA247-B005 ) ]  
EN29SL160B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL160B@TSOP48 [ ( SA247-B005 ) ]  
EN29SL160T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL160T@TSOP48 [ ( SA247-B005 ) ]  
EN29SL400B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL400B@TSOP48 [ ( SA247-B005 ) ]

EN29SL400T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL400T@TSOP48 [ ( SA247-B005 ) ]  
EN29SL800B@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL800B@TSOP48 [ ( SA247-B005 ) ]  
EN29SL800T@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
EN29SL800T@TSOP48 [ ( SA247-B005 ) ]

## EPSON

### E ( E ) PROM / FRAM / NVRAM

S1H0H324B2B1@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0H324B2T1@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0H326B2B1@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0H326B2T1@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0H328B2B2@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0H328B2T2@FBGA66 [ ( SA642E-B023A-T072F001 ) ]  
S1H0J642B2B3@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
S1H0J642B2T3@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
S1H0J646B2B3@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
S1H0J646B2T3@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
S1H0J648B2B2@FBGA68 [ ( SA642E-B023A-T072F001 ) ]  
S1H0J648B2T2@FBGA68 [ ( SA642E-B023A-T072F001 ) ]

## ESMT

### E ( E ) PROM / FRAM / NVRAM

EM25LV010@SOIC8 [ ( SA602A ) ] [ ( SA684 ) ]	EM25LV010@VFQFPN8
EM25LV512@SOIC8 [ ( SA602A ) ] [ ( SA684 ) ]	EM25LV512@VFQFPN8
F25L004AB F25L004AB@SOIC8 ( 150mil ) [ ( SA602A ) ] F25L004AB@SOIC8 ( 200mil ) [ ( SA605A ) ] F25L004AT F25L004AT@SOIC8 ( 150mil ) [ ( SA602A ) ] F25L004AT@SOIC8 ( 200mil ) [ ( SA605A ) ]	
F25L008AB@SOIC8 [ ( SA605A ) ] [ ( SA605A ) ]	F25L008AT@SOIC8

F25L016AB@SOIC8 [(SA605A)]	F25L016AT@SOIC8
[(SA605A)]	
F25L04UA@SOIC8 [(SA602A)]	
F25L16PA(AAI-PROGRAM)@SOIC8 [(SA605A)]	
F25L16PA(PAGE-PROGRAM)@SOIC8 [(SA605A)]	
F49B002UA	F49B002UA@PLCC32
[(SA015A1T)]	
F49L004BA@PLCC32 [(SA015A1T)]	F49L004BA@TSOP40
[(SA409T)]	
F49L004UA@PLCC32 [(SA015A1T)]	F49L004UA@TSOP40
[(SA409T)]	
F49L040A@PLCC32 [(SA015A1T)]	F49L040A@VSOP32
[(SA620)]	
F49L160BA@TSOP48 [(SA247)]	F49L160UA@TSOP48
[(SA247)]	
F49L320BA@TSOP48 [(SA247)]	F49L320UA@TSOP48
[(SA247)]	
F49L400BA@TSOP48 [(SA247-B005)]	F49L400UA@TSOP48 [(SA247-
B005)]	
F49L800BA@TSOP48 [(SA247)]	F49L800UA@TSOP48
[(SA247)]	

## EXCELSMI

### E (E) PROM/FRAM/NVRAM

ES25M16	ES25M16@SOP16
[(SA404)]	
ES25M16@SOP8[150 mil] [(SA602A)]	ES25M16@SOP8[208 mil]
[(SA605A)]	
ES25M40	ES25M40@SOP16
[(SA404)]	
ES25M40@SOP8[150 mil] [(SA602A)]	ES25M40@SOP8[208 mil]
[(SA605A)]	
ES25M80	ES25M80@SOP16
[(SA404)]	
ES25M80@SOP8[150 mil] [(SA602A)]	ES25M80@SOP8[208 mil]
[(SA605A)]	
ES25P16@SOP8 [(SA605A)]	ES25P40@SOP8
[(SA605A)]	
ES25P80@SOP8 [(SA605A)]	
ES29LV160DB@FBGA48 [(SA642G-B026A-T048F001Y)]	



ES29LV160DB@PSOP44 [ ( SA638 ) ]  
ES29LV160DB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV160DT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV160DT@PSOP44 [ ( SA638 ) ]  
ES29LV160DT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV160EB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV160EB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV160ET@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV160ET@TSOP48 [ ( SA247-B005 ) ]  
ES29LV160FB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV160FB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV160FT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV160FT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320DB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320DB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320DT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320DT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320EB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320EB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320ET@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320ET@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320FB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320FB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV320FT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV320FT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV400DB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV400DB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV400DT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV400DT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV400EB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV400EB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV400ET@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV400ET@TSOP48 [ ( SA247-B005 ) ]  
ES29LV800DB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV800DB@PSOP44 [ ( SA638 ) ]  
ES29LV800DB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV800DT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV800DT@PSOP44 [ ( SA638 ) ]  
ES29LV800DT@TSOP48 [ ( SA247-B005 ) ]  
ES29LV800EB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV800EB@TSOP48 [ ( SA247-B005 ) ]  
ES29LV800ET@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
ES29LV800ET@TSOP48 [ ( SA247-B005 ) ]

**EXEL****E (E) PROM/FRAM/NVRAM**

XL24C01A	
XL24C02	
XL24C04	
XL24C16	
XL24C16@SOIC8 [(SA602A)]	
XL24C32	
XL28C256	XL28C256@PLCC32
[(SA015A1T)]	
XL28C256@TSOP28 [(SA430T)]	
XL9010	
XL9010(F) [(SA602A)]	
XL9020	
XL9020(F) [(SA602A)]	
XL9040	
XL9040(F) [(SA602A)]	
XL9346	
XL9346@SOIC8 [(SA602A)]	
XL93CS56	
XL93CS56@SOIC8 [(SA602A)]	XL93CS56@TSSOP8
[(SA026)]	
XL93CS66	XL93CS66@SOIC8
[(SA602A)]	
XL93CS66@TSSOP8 [(SA026)]	
XL93LC46	
XL93LC46@SOIC8 [(SA602A)]	
XL93LC46A	
XL93LC46A@SOIC8 [(SA602A)]	
XL93LC56	
XL93LC56@SOIC8 [(SA602A)]	
XL93LC56A	
XL93LC56A@SOIC8 [(SA602A)]	
XL93LC66A	
XL93LC66A@SOIC8 [(SA602A)]	
XL9764	
XLE28C16A	XLE28C16A@PLCC32
[(SA015A1T)]	
XLE28C16B	XLE28C16B@PLCC32

[ (SA015A1T) ]	
XLE28C16B@SOIC24 [ (SA404) ]	
XLM28C16A	
XLM28C16A@PLCC32 [ (SA015A1T) ]	
XLM46C15	
XLM46P15	
XLS2804A	
XLS2816A	XLS2816A@PLCC32
[ (SA015A1T) ]	
XLS2817A	
XLS28C16A	
XLS28C16A@PLCC32 [ (SA015A1T) ]	
XLS28C16B	
XLS28C16B@PLCC32 [ (SA015A1T) ]	XLS28C16B@SOIC24
[ (SA404) ]	
XLS28C64B	XLS28C64B@PLCC32
[ (SA015A1T) ]	
XLS28C64B@SOIC28 [ (SA404) ]	
XLS46C15	
XLS46P15	
XLS93C46	
XLS93C46@SOIC8 [ (SA602A) ]	
XLS93C56	
XLS93C56@SOIC8 [ (SA602A) ]	
XLS93C66	
XLS93C66@SOIC8 [ (SA602A) ]	
XLS93CS46	
XLS93CS46@SOIC8 [ (SA602A) ]	XLS93CS46@TSSOP8
[ (SA026) ]	
XLS93LC06	XLS93LC06@SOIC8
[ (SA602A) ]	
XLS93LC66	XLS93LC66@SOIC8
[ (SA602A) ]	

**PLD**

XLE78C800P-25	XLE78C800P-
35	
XLE78C800P-45	XLE78C800S-
25	
XLE78C800S-35	XLE78C800S-
45	

XLM78C800S-35  
45  
XLS78C800P-25  
35  
XLS78C800P-45  
25  
XLS78C800S-35  
45

XLM78C800S-  
  
XLS78C800P-  
  
XLS78C800S-  
  
XLS78C800S-

## FAIRCHILD

### E (E) PROM/FRAM/NVRAM

FM24C02(M8)@SOIC8 [(SA602A)]  
[(SA026)]  
FM24C02(N)  
[(SA602A)]  
FM24C03(MT8)@TSSOP8 [(SA026)]  
(N)  
FM24C04(M8)@SOIC8 [(SA602A)]  
[(SA026)]  
FM24C04(N)  
[(SA602A)]  
FM24C05(MT8)@TSSOP8 [(SA026)]  
(N)  
FM24C08(M8)@SOIC8 [(SA602A)]  
[(SA026)]  
FM24C08(N)  
[(SA602A)]  
FM24C09(MT8)@TSSOP8 [(SA026)]  
(N)  
FM24C128(MT8)@TSSOP8 [(SA026)]  
[(SA602A)]  
FM24C128(N)  
[(SA602A)]  
FM24C16(MT8)@TSSOP8 [(SA026)]  
(N)  
FM24C17(M8)@SOIC8 [(SA602A)]  
[(SA026)]  
FM24C17(N)  
[(SA602A)]  
FM24C256(N)

FM24C02(MT8)@TSSOP8  
  
FM24C03(M8)@SOIC8  
  
FM24C03  
  
FM24C04(MT8)@TSSOP8  
  
FM24C05(M8)@SOIC8  
  
FM24C05  
  
FM24C08(MT8)@TSSOP8  
  
FM24C09(M8)@SOIC8  
  
FM24C09  
  
FM24C128(MW8)@SOIC8  
  
FM24C16(M8)@SOIC8  
  
FM24C16  
  
FM24C17(MT8)@TSSOP8  
  
FM24C256(M8)@SOIC8  
  
FM24C32(M8)@SOIC8

[ (SA602A) ]	
FM24C32(N)	
FM27C010	
FM27C010@PLCC32 [ (SA015A1T) ]	FM27C010@TSOP32
[ (SA410T) ]	
FM27C040	FM27C040@PLCC32
[ (SA015A1T) ]	
FM27C040@TSOP32 [ (SA410T) ]	
FM27C256	
FM27C256@PLCC32 [ (SA015A1T) ]	
FM27C256Q	
FM27C256Q@PLCC32 [ (SA015A1T) ]	
FM27C512	
FM27C512@PLCC32 [ (SA015A1T) ]	
FM93C06(M8)(08bit)@SOIC8 [ (SA602A) ]	
FM93C06(M8)(16bit)@SOIC8 [ (SA602A) ]	
FM93C06(MT8)(08bit)@TSSOP8 [ (SA026) ]	
FM93C06(MT8)(16bit)@TSSOP8 [ (SA026) ]	
FM93C06(N)(08bit)	FM93C06(N)
(16bit)	
FM93C14(16bit)	FM93C46(M8)@SOIC8
[ (SA602A) ]	
FM93C46(MT8)@TSSOP8 [ (SA026) ]	FM93C46
(N)	
FM93C46A(M8)(08bit)@SOIC8 [ (SA602A) ]	
FM93C46A(M8)(16bit)@SOIC8 [ (SA602A) ]	
FM93C46A(MT8)(08bit)@TSSOP8 [ (SA026) ]	
FM93C46A(MT8)(16bit)@TSSOP8 [ (SA026) ]	
FM93C46A(N)(08bit)	FM93C46A(N)
(16bit)	
FM93C56(M8)@SOIC8 [ (SA602A) ]	FM93C56(MT8)@TSSOP8
[ (SA026) ]	
FM93C56(N)	
FM93C56A(M8)(08bit)@SOIC8 [ (SA602A) ]	
FM93C56A(M8)(16bit)@SOIC8 [ (SA602A) ]	
FM93C56A(MT8)(08bit)@TSSOP8 [ (SA026) ]	
FM93C56A(MT8)(16bit)@TSSOP8 [ (SA026) ]	
FM93C56A(N)(08bit)	FM93C56A(N)
(16bit)	
FM93C66(M8)@SOIC8 [ (SA602A) ]	FM93C66(MT8)@TSSOP8
[ (SA026) ]	
FM93C66(N)	
FM93C66A(M8)(08bit)@SOIC8 [ (SA602A) ]	

FM93C66A(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C66A(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C66A(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C66A(N)(08bit)	FM93C66A(N)
(16bit)	
FM93C76(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C76(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C76(N)(16bit)	
FM93C76A(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C76A(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C76A(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C76A(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C76A(N)(08bit)	FM93C76A(N)
(16bit)	
FM93C86(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C86(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C86(N)(16bit)	
FM93C86A(M8)(08bit)@SOIC8 [(SA602A)]	
FM93C86A(M8)(16bit)@SOIC8 [(SA602A)]	
FM93C86A(MT8)(08bit)@TSSOP8 [(SA026)]	
FM93C86A(MT8)(16bit)@TSSOP8 [(SA026)]	
FM93C86A(N)(08bit)	FM93C86A(N)
(16bit)	
FM93CS06(M8)@SOIC8 [(SA602A)]	FM93CS06(MT8)@TSSOP8
[(SA026)]	
FM93CS06(N)	FM93CS46(M8)@SOIC8
[(SA602A)]	
FM93CS46(MT8)@TSSOP8 [(SA026)]	FM93CS46
(N)	
FM93CS56(M8)@SOIC8 [(SA602A)]	FM93CS56(MT8)@TSSOP8
[(SA026)]	
FM93CS56(N)	FM93CS66(M8)@SOIC8
[(SA602A)]	
FM93CS66(MT8)@TSSOP8 [(SA026)]	FM93CS66
(N)	
FM93S46(M8)@SOIC8 [(SA602A)]	FM93S46(MT8)@TSSOP8
[(SA026)]	
FM93S46(N)	FM93S56(M8)@SOIC8
[(SA602A)]	
FM93S56(MT8)@TSSOP8 [(SA026)]	FM93S56
(N)	
FM93S66(M8)@SOIC8 [(SA602A)]	FM93S66(MT8)@TSSOP8
[(SA026)]	

FM93S66 (N)	
MM2716	
MM2716E	NM24C02 (M8)@SOIC8
[ (SA602A) ]	
NM24C02 (MT8)@TSSOP8 [ (SA026) ]	NM24C02
(N)	
NM24C02L (M8)@SOIC8 [ (SA602A) ]	NM24C02L (MT8)@TSSOP8
[ (SA026) ]	
NM24C02L (N)	NM24C03 (M8)@SOIC8
[ (SA602A) ]	
NM24C03 (MT8)@TSSOP8 [ (SA026) ]	NM24C03
(N)	
NM24C04 (M8)@SOIC8 [ (SA602A) ]	NM24C04 (MT8)@TSSOP8
[ (SA026) ]	
NM24C04 (N)	NM24C05 (M8)@SOIC8
[ (SA602A) ]	
NM24C05 (MT8)@TSSOP8 [ (SA026) ]	NM24C05
(N)	
NM24C08 (M8)@SOIC8 [ (SA602A) ]	NM24C08 (MT8)@TSSOP8
[ (SA026) ]	
NM24C08 (N)	NM24C09 (M8)@SOIC8
[ (SA602A) ]	
NM24C09 (MT8)@TSSOP8 [ (SA026) ]	NM24C09
(N)	
NM24C16 (M8)@SOIC8 [ (SA602A) ]	NM24C16 (MT8)@TSSOP8
[ (SA026) ]	
NM24C16 (N)	NM24C17 (M8)@SOIC8
[ (SA602A) ]	
NM24C17 (MT8)@TSSOP8 [ (SA026) ]	NM24C17
(N)	
NM24C65 (M8)SOIC8 [ (SA602A) ]	NM24C65
(N)	
NM27C010	NM27C010@PLCC32
[ (SA015A1T) ]	
NM27C010@TSOP32 [ (SA410T) ]	
NM27C020	
NM27C020@PLCC32 [ (SA015A1T) ]	NM27C020@TSOP32
[ (SA410T) ]	
NM27C020Q	NM27C020Q@PLCC32
[ (SA015A1T) ]	
NM27C020Q@TSOP32 [ (SA410T) ]	
NM27C040	
NM27C040@PLCC32 [ (SA015A1T) ]	NM27C040@TSOP32

[ (SA410T) ]	
NM27C128	NM27C128@PLCC32
[ (SA015A1T) ]	
NM27C210	NM27C210@PLCC44
[ (SA244) ]	
NM27C240	NM27C240@PLCC44
[ (SA244) ]	
NM27C256	NM27C256@PLCC32
[ (SA015A1T) ]	
NM27C512	NM27C512@PLCC32
[ (SA015A1T) ]	
NM27C64Q	NM27C64Q@PLCC32
[ (SA015A1T) ]	
NM27LC256	NM27LC256@PLCC32
[ (SA015A1T) ]	
NM27LC512	NM27LC512@PLCC32
[ (SA015A1T) ]	
NM27LV010	NM27LV010@PLCC32
[ (SA015A1T) ]	
NM27LV010@TSOP32 [ (SA410T) ]	
NM27LV210	
NM27LV210@PLCC44 [ (SA244) ]	
NM27LV512	
NM27LV512@PLCC32 [ (SA015A1T) ]	
NM27P040	
NM27P040@PLCC32 [ (SA015A1T) ]	NM27P040@TSOP32
[ (SA410T) ]	
NM27P210	NM27P210@PLCC44
[ (SA244) ]	
NM27P512	NM27P512@PLCC32
[ (SA015A1T) ]	
NM93C66(M8)(16bit)@SOIC8 [ (SA602A) ]	
NM93C66(MT8)(16bit)@TSSOP8 [ (SA026) ]	
NM93C66(N)(16bit)	NM93CS06(M8)@SOIC8
[ (SA602A) ]	
NM93CS06(MT8)@TSSOP8 [ (SA026) ]	NM93CS06
(N)	
NM93CS46(M8)@SOIC8 [ (SA602A) ]	NM93CS46(MT8)@TSSOP8
[ (SA026) ]	
NM93CS46(N)	NM93CS56(M8)@SOIC8
[ (SA602A) ]	
NM93CS56(MT8)@TSSOP8 [ (SA026) ]	NM93CS56
(N)	



NM93CS66(M8)@SOIC8 [(SA602A)]  
[(SA026)]  
NM93CS66(N)  
NMC2732  
NMC27C010  
[(SA015A1T)]  
NMC27C010@TSOP32 [(SA410T)]  
NMC27C1024  
NMC27C1024@PLCC44 [(SA244)]  
NMC27C128B  
NMC27C128B@PLCC32 [(SA015A1T)]  
NMC27C128BN  
NMC27C128BN@PLCC32 [(SA015A1T)]  
NMC27C128BQ  
NMC27C128BQ@PLCC32 [(SA015A1T)]  
NMC27C128CQ  
NMC27C16  
NMC27C16BQ  
NMC27C16BQE  
NMC27C16H  
NMC27C16HQ  
NMC27C16Q  
NMC27C256  
[(SA015A1T)]  
NMC27C256B  
[(SA015A1T)]  
NMC27C256Q  
[(SA015A1T)]  
NMC27C32  
NMC27C32B  
NMC27C32BQ  
NMC27C32E  
NMC27C32EH  
NMC27C32H  
NMC27C512  
[(SA015A1T)]  
NMC27C512A  
[(SA015A1T)]  
NMC27C512AN  
[(SA015A1T)]  
NMC27C64  
(BN)  
NMC27C64(N)

NM93CS66(MT8)@TSSOP8

NMC27C010@PLCC32

NMC27C256@PLCC32

NMC27C256B@PLCC32

NMC27C256Q@PLCC32

NMC27C512@PLCC32

NMC27C512A@PLCC32

NMC27C512AN@PLCC32

NMC27C64

NMC27CP128	
NMC87C257Q	NMC87C257Q@PLCC32
[ (SA015A1T) ]	
NMC87C257V	NMC87C257V@PLCC32
[ (SA015A1T) ]	
NMC9346(M8)(16bit)@SOIC8 [ (SA602A) ]	
NMC9346(MT8)(16bit)@TSSOP8 [ (SA026) ]	
NMC9346(N)(16bit)	
NMC93C46(M8)(16bit)@SOIC8 [ (SA602A) ]	
NMC93C46(MT8)(16bit)@TSSOP8 [ (SA026) ]	
NMC93C46(N)(16bit)	
NMC93C46A(M8)(16bit)@SOIC8 [ (SA602A) ]	
NMC93C46A(MT8)(16bit)@TSSOP8 [ (SA026) ]	
NMC93C46A(N)(16bit)	
NMC93C56(M8)(16bit)@SOIC8 [ (SA602A) ]	
NMC93C56(MT8)(16bit)@TSSOP8 [ (SA026) ]	
NMC93C56(N)(16bit)	
NMC93C66(M8)(16bit)@SOIC8 [ (SA602A) ]	
NMC93C66(MT8)(16bit)@TSSOP8 [ (SA026) ]	
NMC93C66(N)(16bit)	NMC93CS06(M8)@SOIC8
[ (SA602A) ]	
NMC93CS06(MT8)@TSSOP8 [ (SA026) ]	NMC93CS06
(N)	
NMC93CS46(M8)@SOIC8 [ (SA602A) ]	NMC93CS46(MT8)@TSSOP8
[ (SA026) ]	
NMC93CS46(N)	NMC93CS56(M8)@SOIC8
[ (SA602A) ]	
NMC93CS56(MT8)@TSSOP8 [ (SA026) ]	NMC93CS56
(N)	
NMC93CS66(M8)@SOIC8 [ (SA602A) ]	NMC93CS66(MT8)@TSSOP8
[ (SA026) ]	
NMC93CS66(N)	
NMC9817	

## DRAM & SRAM

F1600	F1600@SOJ24
[ (SA646) ]	
F1601	F1601@SOJ24
[ (SA646) ]	
F1620	
F1621	

**MICROCONTROLLER**

ACE1001(M8)@SOIC8 [(SA602A)]	ACE1001(M8X)@SOIC8
[(SA602A)]	
ACE1001(MT8)@TSSOP8 [(SA026)]	ACE1001(MT8X)@TSSOP8
[(SA026)]	
ACE1001E(M8)@SOIC8 [(SA602A)]	ACE1001E(M8X)@SOIC8
[(SA602A)]	
ACE1001E(MT8)@TSSOP8 [(SA026)]	ACE1001E(MT8X)@TSSOP8
[(SA026)]	
ACE1001L(M8)@SOIC8 [(SA602A)]	ACE1001L(M8X)@SOIC8
[(SA602A)]	
ACE1001L(MT8)@TSSOP8 [(SA026)]	ACE1001L(MT8X)@TSSOP8
[(SA026)]	
ACE1101(EMT8)@TSSOP8 [(SA026)]	ACE1101(EMT8X)@TSSOP8
[(SA026)]	
ACE1101(EN)	ACE1101
(EN14)	
ACE1101(LMT8)@TSSOP8 [(SA026)]	ACE1101(LMT8X)@TSSOP8
[(SA026)]	
ACE1101(LN)	ACE1101
(LN14)	
ACE1101(MT8)@TSSOP8 [(SA026)]	ACE1101(MT8X)@TSSOP8
[(SA026)]	
ACE1101(N)	ACE1101
(N14)	
ACE1101(VMT8)@TSSOP8 [(SA026)]	ACE1101(VMT8X)@TSSOP8
[(SA026)]	
ACE1101(VN)	ACE1101
(VN14)	
ACE1101B(EMT8)@TSSOP8 [(SA026)]	ACE1101B(EMT8X)@TSSOP8
[(SA026)]	
ACE1101B(EN)	ACE1101B
(EN14)	
ACE1101B(MT8)@TSSOP8 [(SA026)]	ACE1101B(MT8X)@TSSOP8
[(SA026)]	
ACE1101B(N)	ACE1101B
(N14)	
ACE1101B(VMT8)@TSSOP8 [(SA026)]	ACE1101B(VMT8X)@TSSOP8
[(SA026)]	
ACE1101B(VN)	ACE1101B

(VN14)	
ACE1202(dip14)	ACE1202
(dip8)	
ACE1202(M14)@SOIC14 [(SA602)]	ACE1202(M8)@SOIC8
[(SA602A)]	
ACE12022(dip14)	ACE12022
(dip8)	
ACE12022(M14)@SOIC14 [(SA602)]	ACE12022(M8)@SOIC8
[(SA602A)]	
ACE12022B(dip14)	ACE12022B
(dip8)	
ACE12022B(M14)@SOIC14 [(SA602)]	ACE12022B(M8)@SOIC8
[(SA602A)]	
ACE12022BE(dip14)	ACE12022BE
(dip8)	
ACE12022BE(M14)@SOIC14 [(SA602)]	ACE12022BE(M8)@SOIC8
[(SA602A)]	
ACE12022BV(dip14)	ACE12022BV
(dip8)	
ACE12022BV(M14)@SOIC14 [(SA602)]	ACE12022BV(M8)@SOIC8
[(SA602A)]	
ACE12022E(dip14)	ACE12022E
(dip8)	
ACE12022E(M14)@SOIC14 [(SA602)]	ACE12022E(M8)@SOIC8
[(SA602A)]	
ACE1202B(dip14)	ACE1202B
(dip8)	
ACE1202B(M14)@SOIC14 [(SA602)]	ACE1202B(M8)@SOIC8
[(SA602A)]	
ACE1202BE(dip14)	ACE1202BE
(dip8)	
ACE1202BE(M14)@SOIC14 [(SA602)]	ACE1202BE(M8)@SOIC8
[(SA602A)]	
ACE1202BV(dip14)	ACE1202BV
(dip8)	
ACE1202BV(M14)@SOIC14 [(SA602)]	ACE1202BV(M8)@SOIC8
[(SA602A)]	
ACE1202E(dip14)	ACE1202E
(dip8)	
ACE1202E(M14)@SOIC14 [(SA602)]	ACE1202E(M8)@SOIC8
[(SA602A)]	
ACE1202L(dip14)	ACE1202L
(dip8)	

ACE1202L(M14)@SOIC14 [(SA602)]  
[(SA602A)]  
ACE1202V(dip8)  
[(SA602)]  
ACE1202V(M8)@SOIC8 [(SA602A)]  
[(SA602)]  
ACE1501(EM8)@SOIC8 [(SA602A)]  
[(SA602A)]  
ACE1501(EMT)@TSOP14 [(SA026)]  
[(SA026)]  
ACE1501(EMT8X)@TSSOP8 [(SA026)]  
[(SA026)]  
ACE1501(EMX)@SOIC14 [(SA602)]  
(EN)  
ACE1501(EN14)  
[(SA602)]  
ACE1501(VM8)@SOIC8 [(SA602A)]  
[(SA602A)]  
ACE1501(VMT)@TSOP14 [(SA026)]  
[(SA026)]  
ACE1501(VMT8X)@TSSOP8 [(SA026)]  
[(SA026)]  
ACE1501(VMX)@SOIC14 [(SA602)]  
(VN)  
ACE1501(VN14)  
[(SA602)]  
ACE1502(EM8)@SOIC8 [(SA602A)]  
[(SA026)]  
ACE1502(EMT8)@TSSOP8 [(SA026)]  
(EN)  
ACE1502(EN14)  
[(SA602)]  
ACE1502(VM8)@SOIC8 [(SA602A)]  
[(SA026)]  
ACE1502(VMT8)@TSSOP8 [(SA026)]  
(VN)  
ACE1502(VN14)  
[(SA602A)]  
ACE8000(M8X)@SOIC8 [(SA602A)]  
[(SA602A)]  
ACE8000E(M8X)@SOIC8 [(SA602A)]  
[(SA602A)]  
ACE8001(M8X)@SOIC8 [(SA602A)]

ACE1202L(M8)@SOIC8  
ACE1202V(M14)@SOIC14  
ACE1501(EM)@SOIC14  
ACE1501(EM8X)@SOIC8  
ACE1501(EMT8)@TSSOP8  
ACE1501(EMTX)@TSOP14  
ACE1501  
ACE1501(VM)@SOIC14  
ACE1501(VM8X)@SOIC8  
ACE1501(VMT8)@TSSOP8  
ACE1501(VMTX)@TSOP14  
ACE1501  
ACE1502(EM)@SOIC14  
ACE1502(EMT)@TSOP14  
ACE1502  
ACE1502(VM)@SOIC14  
ACE1502(VMT)@TSOP14  
ACE1502  
ACE8000(M8)@SOIC8  
ACE8000E(M8)@SOIC8  
ACE8001(M8)@SOIC8  
ACE8001(MT8)@TSSOP8

[ (SA026) ]	
ACE8001(MT8X)@TSSOP8 [ (SA026) ]	ACE8001E(M8)@SOIC8
[ (SA602A) ]	
ACE8001E(M8X)@SOIC8 [ (SA602A) ]	ACE8001E(MT8)@TSSOP8
[ (SA026) ]	
ACE8001E(MT8X)@TSSOP8 [ (SA026) ]	FMS7401L(EM8X)@SOIC8
[ (SA602A) ]	
FMS7401L(EMT8X)@TSSOP8 [ (SA026) ]	FMS7401L(EMTX)@TSSOP14
[ (SA026) ]	
FMS7401L(EMX)@SOIC14 [ (SA602) ]	FMS7401L
(EN)	
FMS7401L(EN14)	FMS7401L
(VN)	
FMS7401L(VN14)	

## FORCE TECHNOLOGIES

### E(E) PROM/FRAM/NVRAM

FT24C01	FT24C01@SOIC8
[ (SA602A) ]	
FT24C01@TSOP8 [ (SA026) ]	
FT24C01A	
FT24C01A@SOIC8 [ (SA602A) ]	FT24C01A@TSOP8
[ (SA026) ]	
FT24C02	FT24C02@SOP8
[ (SA602A) ]	
FT24C02@TSSOP8 [ (SA026) ]	
FT24C02A	
FT24C02A@SOP8 [ (SA602A) ]	FT24C02A@TSSOP8
[ (SA026) ]	
FT24C04	FT24C04@SOP8
[ (SA602A) ]	
FT24C04@TSSOP8 [ (SA026) ]	
FT24C04A	
FT24C04A@SOP8 [ (SA602A) ]	FT24C04A@TSSOP8
[ (SA026) ]	
FT24C08	FT24C08@SOIC8
[ (SA602A) ]	
FT24C08@TSOP8 [ (SA026) ]	
FT24C08A	
FT24C08A@SOIC8 [ (SA602A) ]	FT24C08A@TSOP8

[ (SA026) ]	
FT24C128	FT24C128@SOIC8
[ (SA602A) ]	
FT24C128@TSOP8 [ (SA026) ]	
FT24C128A	
FT24C128A@SOIC8 [ (SA602A) ]	FT24C128A@TSOP8
[ (SA026) ]	
FT24C16	FT24C16@SOIC8
[ (SA602A) ]	
FT24C16@TSOP8 [ (SA026) ]	
FT24C16A	
FT24C16A@SOIC8 [ (SA602A) ]	FT24C16A@TSOP8
[ (SA026) ]	
FT24C256	FT24C256@SOIC8
[ (SA602A) ]	
FT24C256@TSOP8 [ (SA026) ]	
FT24C256A	
FT24C256A@SOIC8 [ (SA602A) ]	FT24C256A@TSOP8
[ (SA026) ]	
FT24C32	FT24C32@SOIC8
[ (SA602A) ]	
FT24C32@TSOP8 [ (SA026) ]	
FT24C32A	
FT24C32A@SOIC8 [ (SA602A) ]	FT24C32A@TSOP8
[ (SA026) ]	
FT24C64	FT24C64@SOIC8
[ (SA602A) ]	
FT24C64@TSOP8 [ (SA026) ]	
FT24C64A	
FT24C64A@SOIC8 [ (SA602A) ]	FT24C64A@TSOP8
[ (SA026) ]	
FT27C010	FT27C010@PLCC32
[ (SA015A1T) ]	
FT27C010@TSOP32 [ (SA410T) ]	
FT27C020	
FT27C020@PLCC32 [ (SA015A1T) ]	FT27C020@TSOP32
[ (SA410T) ]	
FT27C040	FT27C040@PLCC32
[ (SA015A1T) ]	
FT27C040@TSOP32 [ (SA410T) ]	
FT27C16	
FT27C256	FT27C256@PLCC32
[ (SA015A1T) ]	

FT27C64	FT27C64@PLCC32
[ (SA015A1T) ]	
FT27HC256	FT27HC256@PLCC32
[ (SA015A1T) ]	
FT27HC64	FT27HC64@PLCC32
[ (SA015A1T) ]	
FT28C010	FT28C010@JLCC32
[ (SA412A) ]	
FT28C010@PLCC32 [ (SA015A1T) ]	FT28C010@PLCC44
[ (SA244) ]	
FT28C010@TSOP32 [ (SA410T) ]	
FT28C010E	
FT28C010E@JLCC32 [ (SA412A) ]	FT28C010E@PLCC32
[ (SA015A1T) ]	
FT28C010E@PLCC44 [ (SA244) ]	FT28C010E@TSOP32
[ (SA410T) ]	
FT28C020	FT28C020@JLCC32
[ (SA412A) ]	
FT28C020@PLCC32 [ (SA015A1T) ]	FT28C020@PLCC44
[ (SA244) ]	
FT28C020@TSOP32 [ (SA410T) ]	
FT28C040	
FT28C040@JLCC32 [ (SA412A) ]	FT28C040@PLCC32
[ (SA015A1T) ]	
FT28C040@PLCC44 [ (SA244) ]	FT28C040@TSOP32
[ (SA410T) ]	
FT28C16	FT28C16@PLCC32
[ (SA015A1T) ]	
FT28C256	FT28C256@JLCC32
[ (SA412A) ]	
FT28C256@PLCC32 [ (SA015A1T) ]	FT28C256@SOIC28
[ (SA404) ]	
FT28C256@TSOP28 [ (SA430T) ]	
FT28C256B	
FT28C256B@JLCC32 [ (SA412A) ]	FT28C256B@PLCC32
[ (SA015A1T) ]	
FT28C256B@SOIC28 [ (SA404) ]	FT28C256B@TSOP28
[ (SA430T) ]	
FT28C64	FT28C64@PLCC32
[ (SA015A1T) ]	
FT28C64@SOIC28 [ (SA404) ]	FT28C64@TSOP28
[ (SA430T) ]	
FT28C64B	FT28C64B@JLCC32



[ (SA412A) ]	
FT28C64B@PLCC32 [ (SA015A1T) ]	FT28C64B@SOIC28
[ (SA404) ]	
FT28C64B@TSOP28 [ (SA430T) ]	
FT28C64X	
FT28C64X@PLCC32 [ (SA015A1T) ]	FT28C64X@SOIC28
[ (SA404) ]	
FT28C64X@TSOP28 [ (SA430T) ]	
FT28HC64	
FT28HC64@PLCC32 [ (SA015A1T) ]	FT28HC64@TSOP28
[ (SA430T) ]	
FT58C1001	FT58C1001@SSOP32
[ (SA438T) ]	
FT58C1001@VSOP32 [ (SA620) ]	

## FORWARD

### E (E) PROM / FRAM / NVRAM

24LC01	24LC01@SOIC8
[ (SA602A) ]	
24LC02	24LC02@SOIC8
[ (SA602A) ]	
24LC04	24LC04@SOIC8
[ (SA602A) ]	
24LC08	24LC08@SOIC8
[ (SA602A) ]	
24LC16	24LC16@SOIC8
[ (SA602A) ]	
24LC32	24LC32@SOIC8
[ (SA602A) ]	
24LC64	24LC64@SOIC8
[ (SA602A) ]	

## FREESCALE

### MICROCONTROLLER

68HC711E9MFN2@PLCC52 [ (SA647-B5202) ]	
68HC711E9MFNE2@PLCC52 [ (SA647-B5202) ]	

68HC711E9VFN2@PLCC52 [(SA647-B5202)]  
 68HC711E9VFNE2@PLCC52 [(SA647-B5202)]  
 DSP56F801(FA60)@TQFP48 [(SA248)]  
 DSP56F801(FA60E)@TQFP48 [(SA248)]  
 DSP56F801(FA80)@TQFP48 [(SA248)]  
 DSP56F801(FA80E)@TQFP48 [(SA248)]  
 DSP56F802(TA60)@TQFP32 [(SA663)]  
 DSP56F802(TA60E)@TQFP32 [(SA663)]  
 DSP56F802(TA80)@TQFP32 [(SA663)]  
 DSP56F802(TA80E)@TQFP32 [(SA663)]  
 MC56F8011VF AE@QFP32 [(SA663+B005)]  
 MC56F8013VF AE@QFP32 [(SA663+B005)]  
 MC56F8014VF AE@QFP32 [(SA663+B005)]  
 MC56F8023MFAE@QFP32 [(SA663+B005)]  
 MC56F8023VF AE@QFP32 [(SA663+B005)]  
 MC56F8025VLD@QFP44 [(SA245A+B005)]  
 MC56F8036MFAE@QFP48 [(SA248+B005)]  
 MC56F8036VF AE@QFP48 [(SA248+B005)]  
 MC56F8037VLH@QFP64 [(PEP+S616)]  
 MC68HC11E1@PLCC52(\*) [(SA647-B5202)]  
 MC68HC11E20@PLCC52(\*) [(SA647-B5202)]  
 MC68HC11E9@PLCC52(\*) [(SA647-B5202)]  
 MC68HC11P1@PLCC84(\*) [(SA649-B8405)]  
 MC68HC705B16N@TQFP64(\*) [(SA668+B204)]  
 MC68HC705J1A(CDW)@SOIC20 [(SA404)]  
 MC68HC705J1A(CSD)@SSOP20 [(SA626A)]  
 MC68HC705J1A(P) MC68HC705J2  
 (Emulation)  
 MC68HC705J2(Emulation)@SOIC20 [(SA404)]  
 MC68HC705J2(Emulation)@SSOP20 [(SA626A)]  
 MC68HC705J2(Native)  
 MC68HC705J2(Native)@SOIC20 [(SA404)]  
 MC68HC705J2(Native)@SSOP20 [(SA626A)]  
 MC68HC705KJ1 MC68HC705KJ1@SOIC16  
 [(SA404)]  
 MC68HC705P6(CDW)@SOIC28 [(SA404)]  
 MC68HC705P6(CP)  
 MC68HC705P6A(CDW)@SOIC28 [(SA404)]  
 MC68HC705P6A(CP)  
 MC68HC705P9  
 MC68HC705P9@SOIC28 [(SA404)]  
 MC68HC711D3  
 MC68HC711D3@PLCC44 [(SA244)] MC68HC711D3@TQFP44

[ (SA675) ]  
MC68HC711E9(4.5V)@PLCC52 [ (SA647-B5202) ]  
MC68HC711E9@PLCC52(\*) [ (SA647-B5202) ]  
MC68HC711E9CFN(4.5V)@PLCC52 [ (SA647-B5202) ]  
MC68HC711E9CFN2@PLCC52 [ (SA647-B5202) ]  
MC68HC711E9CFN3@PLCC52 [ (SA647-B5202) ]  
MC68HC711E9CFNE2@PLCC52 [ (SA647-B5202) ]  
MC68HC711E9CFNE3@PLCC52 [ (SA647-B5202) ]  
MC68HC711E9-FN@PLCC52(\*) [ (SA647-B5202) ]  
MC68HC711K4@TQFP80(\*) [ (TA031-B006) ]  
MC68HC711P2@PLCC84(\*) [ (SA649-B8405) ]  
MC68HC812A4CPV@TQFP112(\*) [ (SA719+B210) ]  
MC68HC812A4CPVE@TQFP112(\*) [ (SA719+B210) ]  
MC68HC812A4MPV@TQFP112(\*) [ (SA719+B210) ]  
MC68HC812A4MPVE@TQFP112(\*) [ (SA719+B210) ]  
MC68HC908AB32CFU@TQFP64(\*) [ (TA011-B006) ]  
MC68HC908AB32MFU@TQFP64(\*) [ (TA011-B006) ]  
MC68HC908AP16CB(S)@SDIP42 [ (SA028) ]  
MC68HC908AP16CB@SDIP42 [ (SA028) ]  
MC68HC908AP16CFA(S)@LQFP48 [ (SA248) ]  
MC68HC908AP16CFA@LQFP48 [ (SA248) ]  
MC68HC908AP16CFB(S)@TQFP44 [ (SA675) ]  
MC68HC908AP16CFB@TQFP44 [ (SA675) ]  
MC68HC908AP32CB(S)@SDIP42 [ (SA028) ]  
MC68HC908AP32CB@SDIP42 [ (SA028) ]  
MC68HC908AP32CFA(S)@LQFP48 [ (SA248) ]  
MC68HC908AP32CFA@LQFP48 [ (SA248) ]  
MC68HC908AP32CFB(S)@TQFP44 [ (SA675) ]  
MC68HC908AP32CFB@TQFP44 [ (SA675) ]  
MC68HC908AP64CB@SDIP42 [ (SA028) ]  
MC68HC908AP64CFA@LQFP48 [ (SA248) ]  
MC68HC908AP64CFB@TQFP44 [ (SA675) ]  
MC68HC908AP8CB(S)@SDIP42 [ (SA028) ]  
MC68HC908AP8CB@SDIP42 [ (SA028) ]  
MC68HC908AP8CFA(S)@LQFP48 [ (SA248) ]  
MC68HC908AP8CFA@LQFP48 [ (SA248) ]  
MC68HC908AP8CFB(S)@TQFP44 [ (SA675) ]  
MC68HC908AP8CFB@TQFP44 [ (SA675) ]  
MC68HC908AS60(CFU)@TQFP64 [ (TA011-B006) ]  
MC68HC908AS60(MFU)@TQFP64 [ (TA011-B006) ]  
MC68HC908AS60(VFU)@TQFP64 [ (TA011-B006) ]  
MC68HC908AS60A(CFU)@TQFP64 [ (TA011-B006) ]  
MC68HC908AS60A(MFU)@TQFP64 [ (TA011-B006) ]

MC68HC908AS60A(VFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ32A(CFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ32A(MFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ32A(VFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ60(CFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ60(MFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ60(VFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ60A(CFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ60A(MFU)@TQFP64 [(TA011-B006)]  
 MC68HC908AZ60A(VFU)@TQFP64 [(TA011-B006)]  
 MC68HC908BD48IB@SDIP42 [(SA028)]  
 MC68HC908BD48IFB@TQFP44 [(SA675)]  
 MC68HC908EY16CFA@TQFP32 [(SA663)]  
 MC68HC908EY16MFA@TQFP32 [(SA663)]  
 MC68HC908EY16VFA@TQFP32 [(SA663)]  
 MC68HC908EY8CFA@TQFP32 [(SA663)] MC68HC908EY8MFA@TQFP32  
 [(SA663)]  
 MC68HC908EY8VFA@TQFP32 [(SA663)]  
 MC68HC908GP32  
 MC68HC908GP32@SDIP42 [(SA028)] MC68HC908GP32@TQFP44  
 [(SA675)]  
 MC68HC908GR16CFA@TQFP48 [(SA248)]  
 MC68HC908GR16CFJ@TQFP32 [(SA663)]  
 MC68HC908GR16MFA@TQFP48 [(SA248)]  
 MC68HC908GR16MFJ@TQFP32 [(SA663)]  
 MC68HC908GR16VFA@TQFP48 [(SA248)]  
 MC68HC908GR16VFJ@TQFP32 [(SA663)]  
 MC68HC908GR4CDW@SOIC28 [(SA404)] MC68HC908GR4CFA@TQFP32  
 [(SA663)]  
 MC68HC908GR4CP MC68HC908GR4MDW@SOIC28  
 [(SA404)]  
 MC68HC908GR4MFA@TQFP32 [(SA663)]  
 MC68HC908GR4MP  
 MC68HC908GR4VDW@SOIC28 [(SA404)] MC68HC908GR4VFA@TQFP32  
 [(SA663)]  
 MC68HC908GR4VP MC68HC908GR8CDW@SOIC28  
 [(SA404)]  
 MC68HC908GR8CFA@TQFP32 [(SA663)]  
 MC68HC908GR8CP  
 MC68HC908GR8MDW@SOIC28 [(SA404)] MC68HC908GR8MFA@TQFP32  
 [(SA663)]  
 MC68HC908GR8MP MC68HC908GR8VDW@SOIC28  
 [(SA404)]

MC68HC908GR8VFA@TQFP32 [(SA663)]  
MC68HC908GR8VP  
MC68HC908GT16@SDIP42 [(SA028)] MC68HC908GT16@TQFP44  
[(SA675)]  
MC68HC908GT8CB@SDIP42 [(SA028)] MC68HC908GT8CFB@TQFP44  
[(SA675)]  
MC68HC908GZ16(CFA)@TQFP48 [(SA248)]  
MC68HC908GZ16(CFJ)@TQFP32 [(SA663)]  
MC68HC908GZ16(MFA)@TQFP48 [(SA248)]  
MC68HC908GZ16(MFJ)@TQFP32 [(SA663)]  
MC68HC908GZ16(VFA)@TQFP48 [(SA248)]  
MC68HC908GZ16(VFJ)@TQFP32 [(SA663)]  
MC68HC908GZ32(CFA)@TQFP48 [(SA248)]  
MC68HC908GZ32(CFJ)@TQFP32 [(SA663)]  
MC68HC908GZ32(MFA)@TQFP48 [(SA248)]  
MC68HC908GZ32(MFJ)@TQFP32 [(SA663)]  
MC68HC908GZ32(VFA)@TQFP48 [(SA248)]  
MC68HC908GZ32(VFJ)@TQFP32 [(SA663)]  
MC68HC908GZ48(CFA)@TQFP48 [(SA248)]  
MC68HC908GZ48(CFJ)@TQFP32 [(SA663)]  
MC68HC908GZ48(MFA)@TQFP48 [(SA248)]  
MC68HC908GZ48(MFJ)@TQFP32 [(SA663)]  
MC68HC908GZ48(VFA)@TQFP48 [(SA248)]  
MC68HC908GZ48(VFJ)@TQFP32 [(SA663)]  
MC68HC908GZ60(CFA)@TQFP48 [(SA248)]  
MC68HC908GZ60(CFJ)@TQFP32 [(SA663)]  
MC68HC908GZ60(MFA)@TQFP48 [(SA248)]  
MC68HC908GZ60(MFJ)@TQFP32 [(SA663)]  
MC68HC908GZ60(VFA)@TQFP48 [(SA248)]  
MC68HC908GZ60(VFJ)@TQFP32 [(SA663)]  
MC68HC908GZ8(CFA)@TQFP48 [(SA248)]  
MC68HC908GZ8(CFJ)@TQFP32 [(SA663)]  
MC68HC908GZ8(MFA)@TQFP48 [(SA248)]  
MC68HC908GZ8(MFJ)@TQFP32 [(SA663)]  
MC68HC908GZ8(VFA)@TQFP48 [(SA248)]  
MC68HC908GZ8(VFJ)@TQFP32 [(SA663)]  
MC68HC908JB12(DW)@SOIC28 [(SA404)]  
MC68HC908JB12(JDW)@SOIC20 [(SA404)]  
MC68HC908JB16(DW)@SOIC28 [(SA404)]  
MC68HC908JB16(FA)@QFP32 [(SA663)]  
MC68HC908JB16(JDW)@SOIC20 [(SA404)]  
MC68HC908JB8 MC68HC908JB8@SOIC20  
[(SA404)]

MC68HC908JB8@SOIC28 [(SA404)]	MC68HC908JB8@TQFP44
[(SA675)]	
MC68HC908JK1CDW@SOIC20 [(SA404)]	
MC68HC908JK1CP	
MC68HC908JK1ECDW@SOIC20 [(SA404)]	
MC68HC908JK1ECP	
MC68HC908JK1EMDW@SOIC20 [(SA404)]	
MC68HC908JK1EMP	MC68HC908JK1MDW@SOIC20
[(SA404)]	
MC68HC908JK1MP	
[(SA404)]	MC68HC908JK3CDW@SOIC20
MC68HC908JK3CP	
MC68HC908JK3ECDW@SOIC20 [(SA404)]	
MC68HC908JK3ECP	
MC68HC908JK3EMDW@SOIC20 [(SA404)]	
MC68HC908JK3EMP	MC68HC908JK3MDW@SOIC20
[(SA404)]	
MC68HC908JK3MP	
MC68HC908JK8	
MC68HC908JK8@SOIC20 [(SA404)]	MC68HC908JL3CDW@SOIC28
[(SA404)]	
MC68HC908JL3CFA@TQFP48 [(SA248)]	
MC68HC908JL3CP	
MC68HC908JL3ECDW@SOIC28 [(SA404)]	
MC68HC908JL3ECFA@TQFP48 [(SA248)]	
MC68HC908JL3ECP	
MC68HC908JL3EMDW@SOIC28 [(SA404)]	
MC68HC908JL3EMFA@TQFP48 [(SA248)]	
MC68HC908JL3EMP	MC68HC908JL3MDW@SOIC28
[(SA404)]	
MC68HC908JL3MFA@TQFP48 [(SA248)]	
MC68HC908JL3MP	
MC68HC908JL8(dip20)	MC68HC908JL8
(dip28)	
MC68HC908JL8@LQFP32 [(SA663)]	MC68HC908JL8@SDIP32
[(SA653)]	
MC68HC908JL8@SOIC20 [(SA404)]	MC68HC908JL8@SOIC28
[(SA404)]	
MC68HC908KX2(CDW)@SOIC16 [(SA404)]	
MC68HC908KX2(CP)	
MC68HC908KX2(MDW)@SOIC16 [(SA404)]	
MC68HC908KX2(MP)	
MC68HC908KX2(VDW)@SOIC16 [(SA404)]	

MC68HC908KX2 (VP)  
MC68HC908KX8 (CDW)@SOIC16 [(SA404)]  
MC68HC908KX8 (CP)  
MC68HC908KX8 (MDW)@SOIC16 [(SA404)]  
MC68HC908KX8 (MP)  
MC68HC908KX8 (VDW)@SOIC16 [(SA404)]  
MC68HC908KX8 (VP) MC68HC908LB8CDWE (S)  
@SOIC20  
MC68HC908LB8CDWE@SOIC20 [(SA404)]  
MC68HC908LB8CPE MC68HC908LB8CPE  
(S)  
MC68HC908LB8MDWE (S)@SOIC20  
MC68HC908LB8MDWE@SOIC20 [(SA404)]  
MC68HC908LB8MPE MC68HC908LB8MPE  
(S)  
MC68HC908LB8VDWE (S)@SOIC20  
MC68HC908LB8VDWE@SOIC20 [(SA404)]  
MC68HC908LB8VPE MC68HC908LB8VPE  
(S)  
MC68HC908LJ12CFU@TQFP64 (\*) [(SA757-B331)]  
MC68HC908LJ12CFUE@TQFP64 (\*) [(SA757-B331)]  
MC68HC908LJ24CFU@TQFP64 (\*) [(SA757-B331)]  
MC68HC908LJ24CFUE@TQFP64 (\*) [(SA757-B331)]  
MC68HC908LK24CFU@TQFP64 (\*) [(SA757-B331)]  
MC68HC908LK24CFUE@TQFP64 (\*) [(SA757-B331)]  
MC68HC908QB4 (CDT)@TSSOP16 [(SA026)]  
MC68HC908QB4 (CDW)@SOIC16 [(SA404)]  
MC68HC908QB4 (CP)  
MC68HC908QB4 (MDT)@TSSOP16 [(SA026)]  
MC68HC908QB4 (MDW)@SOIC16 [(SA404)]  
MC68HC908QB4 (MP)  
MC68HC908QB4 (VDT)@TSSOP16 [(SA026)]  
MC68HC908QB4 (VDW)@SOIC16 [(SA404)]  
MC68HC908QB4 (VP)  
MC68HC908QB8 (CDT)@TSSOP16 [(SA026)]  
MC68HC908QB8 (CDW)@SOIC16 [(SA404)]  
MC68HC908QB8 (CP)  
MC68HC908QB8 (MDT)@TSSOP16 [(SA026)]  
MC68HC908QB8 (MDW)@SOIC16 [(SA404)]  
MC68HC908QB8 (MP)  
MC68HC908QB8 (VDT)@TSSOP16 [(SA026)]  
MC68HC908QB8 (VDW)@SOIC16 [(SA404)]  
MC68HC908QB8 (VP)

MC68HC908QC16(CDR)@TSSOP28 [(SA643)]  
MC68HC908QC16(CDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16(CDS)@TSSOP20 [(SA643)]  
MC68HC908QC16(CDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16(CDT)@TSSOP16 [(SA643)]  
MC68HC908QC16(CDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16(CDX)@SOIC16 [(SA404)]  
MC68HC908QC16(CDXE)@SOIC16 [(SA404)]  
MC68HC908QC16(CDY)@SOIC20 [(SA404)]  
MC68HC908QC16(CDYE)@SOIC20 [(SA404)]  
MC68HC908QC16(CDZ)@SOIC28 [(SA404)]  
MC68HC908QC16(CDZE)@SOIC28 [(SA404)]  
MC68HC908QC16(MDR)@TSSOP28 [(SA643)]  
MC68HC908QC16(MDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16(MDS)@TSSOP20 [(SA643)]  
MC68HC908QC16(MDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16(MDT)@TSSOP16 [(SA643)]  
MC68HC908QC16(MDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16(MDX)@SOIC16 [(SA404)]  
MC68HC908QC16(MDXE)@SOIC16 [(SA404)]  
MC68HC908QC16(MDY)@SOIC20 [(SA404)]  
MC68HC908QC16(MDYE)@SOIC20 [(SA404)]  
MC68HC908QC16(MDZ)@SOIC28 [(SA404)]  
MC68HC908QC16(MDZE)@SOIC28 [(SA404)]  
MC68HC908QC16(VDR)@TSSOP28 [(SA643)]  
MC68HC908QC16(VDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16(VDS)@TSSOP20 [(SA643)]  
MC68HC908QC16(VDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16(VDT)@TSSOP16 [(SA643)]  
MC68HC908QC16(VDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16(VDX)@SOIC16 [(SA404)]  
MC68HC908QC16(VDXE)@SOIC16 [(SA404)]  
MC68HC908QC16(VDY)@SOIC20 [(SA404)]  
MC68HC908QC16(VDYE)@SOIC20 [(SA404)]  
MC68HC908QC16(VDZ)@SOIC28 [(SA404)]  
MC68HC908QC16(VDZE)@SOIC28 [(SA404)]  
MC68HC908QC4(CDR)@TSSOP28 [(SA643)]  
MC68HC908QC4(CDRE)@TSSOP28 [(SA643)]  
MC68HC908QC4(CDS)@TSSOP20 [(SA643)]  
MC68HC908QC4(CDSE)@TSSOP20 [(SA643)]  
MC68HC908QC4(CDT)@TSSOP16 [(SA643)]  
MC68HC908QC4(CDTE)@TSSOP16 [(SA643)]  
MC68HC908QC4(CDX)@SOIC16 [(SA404)]



MC68HC908QC4 (CDXE)@SOIC16 [ (SA404) ]  
MC68HC908QC4 (CDY)@SOIC20 [ (SA404) ]  
MC68HC908QC4 (CDYE)@SOIC20 [ (SA404) ]  
MC68HC908QC4 (CDZ)@SOIC28 [ (SA404) ]  
MC68HC908QC4 (CDZE)@SOIC28 [ (SA404) ]  
MC68HC908QC4 (MDR)@TSSOP28 [ (SA643) ]  
MC68HC908QC4 (MDRE)@TSSOP28 [ (SA643) ]  
MC68HC908QC4 (MDS)@TSSOP20 [ (SA643) ]  
MC68HC908QC4 (MDSE)@TSSOP20 [ (SA643) ]  
MC68HC908QC4 (MDT)@TSSOP16 [ (SA643) ]  
MC68HC908QC4 (MDTE)@TSSOP16 [ (SA643) ]  
MC68HC908QC4 (MDX)@SOIC16 [ (SA404) ]  
MC68HC908QC4 (MDXE)@SOIC16 [ (SA404) ]  
MC68HC908QC4 (MDY)@SOIC20 [ (SA404) ]  
MC68HC908QC4 (MDYE)@SOIC20 [ (SA404) ]  
MC68HC908QC4 (MDZ)@SOIC28 [ (SA404) ]  
MC68HC908QC4 (MDZE)@SOIC28 [ (SA404) ]  
MC68HC908QC4 (VDR)@TSSOP28 [ (SA643) ]  
MC68HC908QC4 (VDRE)@TSSOP28 [ (SA643) ]  
MC68HC908QC4 (VDS)@TSSOP20 [ (SA643) ]  
MC68HC908QC4 (VDSE)@TSSOP20 [ (SA643) ]  
MC68HC908QC4 (VDT)@TSSOP16 [ (SA643) ]  
MC68HC908QC4 (VDTE)@TSSOP16 [ (SA643) ]  
MC68HC908QC4 (VDX)@SOIC16 [ (SA404) ]  
MC68HC908QC4 (VDXE)@SOIC16 [ (SA404) ]  
MC68HC908QC4 (VDY)@SOIC20 [ (SA404) ]  
MC68HC908QC4 (VDYE)@SOIC20 [ (SA404) ]  
MC68HC908QC4 (VDZ)@SOIC28 [ (SA404) ]  
MC68HC908QC4 (VDZE)@SOIC28 [ (SA404) ]  
MC68HC908QC8 (CDR)@TSSOP28 [ (SA643) ]  
MC68HC908QC8 (CDRE)@TSSOP28 [ (SA643) ]  
MC68HC908QC8 (CDS)@TSSOP20 [ (SA643) ]  
MC68HC908QC8 (CDSE)@TSSOP20 [ (SA643) ]  
MC68HC908QC8 (CDT)@TSSOP16 [ (SA643) ]  
MC68HC908QC8 (CDTE)@TSSOP16 [ (SA643) ]  
MC68HC908QC8 (CDX)@SOIC16 [ (SA404) ]  
MC68HC908QC8 (CDXE)@SOIC16 [ (SA404) ]  
MC68HC908QC8 (CDY)@SOIC20 [ (SA404) ]  
MC68HC908QC8 (CDYE)@SOIC20 [ (SA404) ]  
MC68HC908QC8 (CDZ)@SOIC28 [ (SA404) ]  
MC68HC908QC8 (CDZE)@SOIC28 [ (SA404) ]  
MC68HC908QC8 (MDR)@TSSOP28 [ (SA643) ]  
MC68HC908QC8 (MDRE)@TSSOP28 [ (SA643) ]

MC68HC908QC8 (MDS)@TSSOP20 [(SA643)]  
MC68HC908QC8 (MDSE)@TSSOP20 [(SA643)]  
MC68HC908QC8 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QC8 (MDTE)@TSSOP16 [(SA643)]  
MC68HC908QC8 (MDX)@SOIC16 [(SA404)]  
MC68HC908QC8 (MDXE)@SOIC16 [(SA404)]  
MC68HC908QC8 (MDY)@SOIC20 [(SA404)]  
MC68HC908QC8 (MDYE)@SOIC20 [(SA404)]  
MC68HC908QC8 (MDZ)@SOIC28 [(SA404)]  
MC68HC908QC8 (MDZE)@SOIC28 [(SA404)]  
MC68HC908QC8 (VDR)@TSSOP28 [(SA643)]  
MC68HC908QC8 (VDRE)@TSSOP28 [(SA643)]  
MC68HC908QC8 (VDS)@TSSOP20 [(SA643)]  
MC68HC908QC8 (VDSE)@TSSOP20 [(SA643)]  
MC68HC908QC8 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QC8 (VDTE)@TSSOP16 [(SA643)]  
MC68HC908QC8 (VDX)@SOIC16 [(SA404)]  
MC68HC908QC8 (VDXE)@SOIC16 [(SA404)]  
MC68HC908QC8 (VDY)@SOIC20 [(SA404)]  
MC68HC908QC8 (VDYE)@SOIC20 [(SA404)]  
MC68HC908QC8 (VDZ)@SOIC28 [(SA404)]  
MC68HC908QC8 (VDZE)@SOIC28 [(SA404)]  
MC68HC908QF4 (CFJ)@TQFP32 [(SA663)]  
MC68HC908QF4 (FJ)@TQFP32 [(SA663)]  
MC68HC908QL2 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QL2 (CDW)@SOIC16 [(SA404)]  
MC68HC908QL2 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QL2 (MDW)@SOIC16 [(SA404)]  
MC68HC908QL2 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QL2 (VDW)@SOIC16 [(SA404)]  
MC68HC908QL3 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QL3 (CDW)@SOIC16 [(SA404)]  
MC68HC908QL3 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QL3 (MDW)@SOIC16 [(SA404)]  
MC68HC908QL3 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QL3 (VDW)@SOIC16 [(SA404)]  
MC68HC908QL4 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QL4 (CDW)@SOIC16 [(SA404)]  
MC68HC908QL4 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QL4 (MDW)@SOIC16 [(SA404)]  
MC68HC908QL4 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QL4 (VDW)@SOIC16 [(SA404)]  
MC68HC908QT1CDW@SOIC8 [(SA605A)]

MC68HC908QT1CP  
MC68HC908QT1MDW@SOIC8 [(SA605A)]  
MC68HC908QT1MP  
MC68HC908QT1VDW@SOIC8 [(SA605A)]  
MC68HC908QT1VP  
MC68HC908QT2CDW@SOIC8 [(SA605A)]  
MC68HC908QT2CP  
MC68HC908QT2MDW@SOIC8 [(SA605A)]  
MC68HC908QT2MP  
MC68HC908QT2VDW@SOIC8 [(SA605A)]  
MC68HC908QT2VP  
MC68HC908QT4CDW@SOIC8 [(SA605A)]  
MC68HC908QT4CP  
MC68HC908QT4MDW@SOIC8 [(SA605A)]  
MC68HC908QT4MP  
MC68HC908QT4VDW@SOIC8 [(SA605A)]  
MC68HC908QT4VP  
MC68HC908QY1CDT@TSSOP16 [(SA026)]  
MC68HC908QY1CDW@SOIC16 [(SA404)]  
MC68HC908QY1CP  
MC68HC908QY1MDT@TSSOP16 [(SA026)]  
MC68HC908QY1MDW@SOIC16 [(SA404)]  
MC68HC908QY1MP  
MC68HC908QY1VDT@TSSOP16 [(SA026)]  
MC68HC908QY1VDW@SOIC16 [(SA404)]  
MC68HC908QY1VP  
MC68HC908QY2CDT@TSSOP16 [(SA026)]  
MC68HC908QY2CDW@SOIC16 [(SA404)]  
MC68HC908QY2CP  
MC68HC908QY2MDT@TSSOP16 [(SA026)]  
MC68HC908QY2MDW@SOIC16 [(SA404)]  
MC68HC908QY2MP  
MC68HC908QY2VDT@TSSOP16 [(SA026)]  
MC68HC908QY2VDW@SOIC16 [(SA404)]  
MC68HC908QY2VP  
MC68HC908QY4CDT@TSSOP16 [(SA026)]  
MC68HC908QY4CDW@SOIC16 [(SA404)]  
MC68HC908QY4CP  
MC68HC908QY4MDT@TSSOP16 [(SA026)]  
MC68HC908QY4MDW@SOIC16 [(SA404)]  
MC68HC908QY4MP  
MC68HC908QY4VDT@TSSOP16 [(SA026)]  
MC68HC908QY4VDW@SOIC16 [(SA404)]

MC68HC908QY4VP  
MC68HC908QY8 (CDT)@TSSOP16 [(SA026)]  
MC68HC908QY8 (CDW)@SOIC16 [(SA404)]  
MC68HC908QY8 (CP)  
MC68HC908QY8 (MDT)@TSSOP16 [(SA026)]  
MC68HC908QY8 (MDW)@SOIC16 [(SA404)]  
MC68HC908QY8 (MP)  
MC68HC908QY8 (VDT)@TSSOP16 [(SA026)]  
MC68HC908QY8 (VDW)@SOIC16 [(SA404)]  
MC68HC908QY8 (VP)  
MC68HC908RF2 (CFA)@TQFP32 [(SA663)]  
MC68HC908RF2 (MFA)@TQFP32 [(SA663)]  
MC68HC908SR12 (CB)@SDIP42 [(SA028)]  
MC68HC908SR12 (CFA)@TQFP48 [(SA248)]  
MC68HC908SR12 (MB)@SDIP42 [(SA028)]  
MC68HC908SR12 (MFA)@TQFP48 [(SA248)]  
MC68HC912B32 (CFU8)@TQFP80 [(TA045-B006)]  
MC68HC912B32 (MFU8)@TQFP80 [(TA045-B006)]  
MC68HC912B32 (VFU8)@TQFP80 [(TA045-B006)]  
MC68HC912BC32 (CFU8)@TQFP80 [(TA045-B006)]  
MC68HC912BC32 (MFU8)@TQFP80 [(TA045-B006)]  
MC68HC912BC32 (VFU8)@TQFP80 [(TA045-B006)]  
MC68HCP11E1@PLCC52 (\*) [(SA647-B5202)]  
MC68HRC908JK1CDW@SOIC20 [(SA404)]  
MC68HRC908JK1CP  
MC68HRC908JK1ECDW@SOIC20 [(SA404)]  
MC68HRC908JK1ECP  
MC68HRC908JK1EMDW@SOIC20 [(SA404)]  
MC68HRC908JK1EMP  
MC68HRC908JK1MDW@SOIC20 [(SA404)]  
MC68HRC908JK1MP  
MC68HRC908JK3CDW@SOIC20 [(SA404)]  
MC68HRC908JK3CP  
MC68HRC908JK3ECDW@SOIC20 [(SA404)]  
MC68HRC908JK3ECP  
MC68HRC908JK3EMDW@SOIC20 [(SA404)]  
MC68HRC908JK3EMP  
MC68HRC908JK3MDW@SOIC20 [(SA404)]  
MC68HRC908JK3MP  
MC68HRC908JK8  
MC68HRC908JK8@SOIC20 [(SA404)]  
MC68HRC908JL3CDW@SOIC28 [(SA404)]  
MC68HRC908JL3CFA@TQFP48 [(SA248)]

MC68HRC908JL3CP

MC68HRC908JL3ECDW@SOIC28 [(SA404)]

MC68HRC908JL3ECFA@TQFP48 [(SA248)]

MC68HRC908JL3ECP

MC68HRC908JL3EMDW@SOIC28 [(SA404)]

MC68HRC908JL3EMFA@TQFP48 [(SA248)]

MC68HRC908JL3EMP

MC68HRC908JL3MDW@SOIC28 [(SA404)]

MC68HRC908JL3MFA@TQFP48 [(SA248)]

MC68HRC908JL3MP

MC68HRC908JL8

(dip20)

MC68HRC908JL8(dip28)

MC68HRC908JL8@LQFP32

[(SA663)]

MC68HRC908JL8@SDIP32 [(SA653)]

MC68HRC908JL8@SOIC20

[(SA404)]

MC68HRC908JL8@SOIC28 [(SA404)]

MC68S711E9@PLCC52(\*) [(SA647-B5202)]

MC68S711E9-FN@PLCC52(\*) [(SA647-B5202)]

MC908AB32CFUE@TQFP64(\*) [(TA011-B006)]

MC908AB32MFUE@TQFP64(\*) [(TA011-B006)]

MC908AP16CBE@SDIP42 [(SA028)]

MC908AP16CFAE@LQFP48

[(SA248)]

MC908AP16CFBE@TQFP44 [(SA675)]

MC908AP32CBE@SDIP42

[(SA028)]

MC908AP32CFAE@LQFP48 [(SA248)]

MC908AP32CFBE@TQFP44

[(SA675)]

MC908AP64CBE@SDIP42 [(SA028)]

MC908AP64CFAE@LQFP48

[(SA248)]

MC908AP64CFBE@TQFP44 [(SA675)]

MC908AP8CBE@SDIP42

[(SA028)]

MC908AP8CFAE@LQFP48 [(SA248)]

MC908AP8CFBE@TQFP44

[(SA675)]

MC908BD48IBE@SDIP42 [(SA028)]

MC908BD48IFBE@TQFP44

[(SA675)]

MC908EY16ACFJE@TQFP32 [(SA663)]

MC908EY16AKFJE@TQFP32

[(SA663)]

MC908EY16AMFJE@TQFP32 [(SA663)]

MC908EY16AVFJE@TQFP32

[(SA663)]

MC908EY8ACFJE@TQFP32 [(SA663)]

MC908EY8AKFJE@TQFP32

[(SA663)]

MC908EY8AMFJE@TQFP32 [(SA663)]

MC908EY8AVFJE@TQFP32

[(SA663)]

MC908JL16CDWE@SOIC28 [(SA404)]

MC908JL16CFJE@LQFP32

[ ( SA663 ) ]	
MC908JL16CPE	MC908JL16CSPE@SDIP32
[ ( SA653 ) ]	
MC908QT1ACDWE@SOIC8 [ ( SA605A ) ]	
MC908QT1ACPE	
MC908QT1AMDWE@SOIC8 [ ( SA605A ) ]	
MC908QT1AMPE	
MC908QT1AVDWE@SOIC8 [ ( SA605A ) ]	
MC908QT1AVPE	
MC908QT2ACDWE@SOIC8 [ ( SA605A ) ]	
MC908QT2ACPE	
MC908QT2AMDWE@SOIC8 [ ( SA605A ) ]	
MC908QT2AMPE	
MC908QT2AVDWE@SOIC8 [ ( SA605A ) ]	
MC908QT2AVPE	
MC908QT4ACDWE@SOIC8 [ ( SA605A ) ]	
MC908QT4ACPE	
MC908QT4AMDWE@SOIC8 [ ( SA605A ) ]	
MC908QT4AMPE	
MC908QT4AVDWE@SOIC8 [ ( SA605A ) ]	
MC908QT4AVPE	
MC908QY1ACDTE@TSSOP16 [ ( SA026 ) ]	MC908QY1ACDWE@SOIC16
[ ( SA404 ) ]	
MC908QY1ACPE	MC908QY1AMDTE@TSSOP16
[ ( SA026 ) ]	
MC908QY1AMDWE@SOIC16 [ ( SA404 ) ]	
MC908QY1AMPE	
MC908QY1AVDTE@TSSOP16 [ ( SA026 ) ]	MC908QY1AVDWE@SOIC16
[ ( SA404 ) ]	
MC908QY1AVPE	MC908QY2ACDTE@TSSOP16
[ ( SA026 ) ]	
MC908QY2ACDWE@SOIC16 [ ( SA404 ) ]	
MC908QY2ACPE	
MC908QY2AMDTE@TSSOP16 [ ( SA026 ) ]	MC908QY2AMDWE@SOIC16
[ ( SA404 ) ]	
MC908QY2AMPE	MC908QY2AVDTE@TSSOP16
[ ( SA026 ) ]	
MC908QY2AVDWE@SOIC16 [ ( SA404 ) ]	
MC908QY2AVPE	
MC908QY4ACDTE@TSSOP16 [ ( SA026 ) ]	MC908QY4ACDWE@SOIC16
[ ( SA404 ) ]	
MC908QY4ACPE	MC908QY4AMDTE@TSSOP16
[ ( SA026 ) ]	

MC908QY4AMDWE@SOIC16 [(SA404)]  
MC908QY4AMPE  
MC908QY4AVDTE@TSSOP16 [(SA026)]      MC908QY4AVDWE@SOIC16  
[(SA404)]  
MC908QY4AVPE  
MC912D60ACFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60ACPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60AMFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60AMPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60AVFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60AVPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60CCFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60CCPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60CMFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60CMPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60CVFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60CVPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60PCFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60PCPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60PMFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60PMPV8@TQFP112(\*) [(TA035+B084)]  
MC912D60PVFU8@TQFP80(\*) [(TA034-B006)]  
MC912D60PVPV8@TQFP112(\*) [(TA035+B084)]  
MC912DG128ACPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128AMPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128AVPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128CCPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128CMPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128CVPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128PCPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128PMPV@TQFP112(\*) [(TA035+B084)]  
MC912DG128PVPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128ACPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128AMPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128AVPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128CCPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128CMPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128CVPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128PCPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128PMPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128PVPV@TQFP112(\*) [(TA035+B084)]  
MC9RS08KA1CPC [(SA726+B179)]  
MC9RS08KA1CSC@SOIC8 [(SA602A+B179)]

MC9RS08KA2CPC [(SA726+B179)]  
MC9RS08KA2CSC@SOIC8 [(SA602A+B179)]  
MC9S08AC16CFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC16CFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC16MFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC16MFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC16VFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC16VFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC8CFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC8CFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC8MFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC8MFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC8VFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC8VFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW16CFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW16CFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW16CFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW16CPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW16MFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW16MFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW16MFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW16MPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW32CFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW32CFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW32CFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW32CPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW32MFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW32MFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW32MFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW32MPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW48CFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW48CFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW48CFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW48CPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW48MFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW48MFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW48MFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW48MPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW60CFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW60CFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW60CFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW60CPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW60MFDE@QFN48(\*) [(SA696+B198)]



MC9S08AW60MFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW60MFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW60MPUE@QFP64(\*) [(SA732+B196)]  
MC9S08GB32ACFU@LQFP64 [(TA066-B006)]  
MC9S08GB32ACFUE@LQFP64 [(TA066-B006)]  
MC9S08GB32CFU@LQFP64 [(TA066-B006)]  
MC9S08GB32CFUE@LQFP64 [(TA066-B006)]  
MC9S08GB60ACFU@LQFP64 [(TA066-B006)]  
MC9S08GB60ACFUE@LQFP64 [(TA066-B006)]  
MC9S08GB60CFU@LQFP64 [(TA066-B006)]  
MC9S08GB60CFUE@LQFP64 [(TA066-B006)]  
MC9S08GT16ACB@SDIP42 [(SA028-B167)]  
MC9S08GT16ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT16ACFC@MLF32 [(SA686-B231)]  
MC9S08GT16ACFCE@MLF32 [(SA686-B231)]  
MC9S08GT16ACFD@QFN48 [(SA696-B166)]  
MC9S08GT16AMB@SDIP42 [(SA028-B167)]  
MC9S08GT16AMFB@LQFP44 [(SA675-B168)]  
MC9S08GT16AMFC@MLF32 [(SA686-B231)]  
MC9S08GT16AMFCE@MLF32 [(SA686-B231)]  
MC9S08GT16AMFD@QFN48 [(SA696-B166)]  
MC9S08GT16CB@SDIP42 [(SA028-B167)]  
MC9S08GT16CBE@SDIP42 [(SA028-B167)]  
MC9S08GT16CFB@LQFP44 [(SA675-B168)]  
MC9S08GT16CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT16CFD@QFN48 [(SA696-B166)]  
MC9S08GT16CFDE@QFN48 [(SA696-B166)]  
MC9S08GT32ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT32ACFBE@LQFP44 [(SA675-B168)]  
MC9S08GT32ACFD@QFN48 [(SA696-B166)]  
MC9S08GT32ACFDE@QFN48 [(SA696-B166)]  
MC9S08GT32CB@SDIP42 [(SA028-B167)]  
MC9S08GT32CBE@SDIP42 [(SA028-B167)]  
MC9S08GT32CFB@LQFP44 [(SA675-B168)]  
MC9S08GT32CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT32CFD@QFN48 [(SA696-B166)]  
MC9S08GT32CFDE@QFN48 [(SA696-B166)]  
MC9S08GT60ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT60ACFBE@LQFP44 [(SA675-B168)]  
MC9S08GT60ACFD@QFN48 [(SA696-B166)]  
MC9S08GT60ACFDE@QFN48 [(SA696-B166)]  
MC9S08GT60CB@SDIP42 [(SA028-B167)]  
MC9S08GT60CBE@SDIP42 [(SA028-B167)]

MC9S08GT60CFB@LQFP44 [(SA675-B168)]  
MC9S08GT60CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT60CFD@QFN48 [(SA696-B166)]  
MC9S08GT60CFDE@QFN48 [(SA696-B166)]  
MC9S08GT8ACB@SDIP42 [(SA028-B167)]  
MC9S08GT8ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT8ACFC@MLF32 [(SA686-B231)]  
MC9S08GT8ACFCE@MLF32 [(SA686-B231)]  
MC9S08GT8ACFD@QFN48 [(SA696-B166)]  
MC9S08GT8AMB@SDIP42 [(SA028-B167)]  
MC9S08GT8AMFB@LQFP44 [(SA675-B168)]  
MC9S08GT8AMFC@MLF32 [(SA686-B231)]  
MC9S08GT8AMFCE@MLF32 [(SA686-B231)]  
MC9S08GT8AMFD@QFN48 [(SA696-B166)]  
MC9S08JM32CGTE@QFN48(\*) [(SA696+B310)]  
MC9S08JM32CLDE@QFP44(\*) [(SA245A+B4405)]  
MC9S08JM32CLHE@QFP64(\*) [(SA732+B311)]  
MC9S08JM32CQHE@TQFP64(\*) [(SA668+B311)]  
MC9S08JM60CGTE@QFN48(\*) [(SA696+B310)]  
MC9S08JM60CLDE@QFP44(\*) [(SA245A+B4405)]  
MC9S08JM60CLHE@QFP64(\*) [(SA732+B311)]  
MC9S08JM60CQHE@TQFP64(\*) [(SA668+B311)]  
MC9S08QA2CDN@SOIC8 [(SA602A+B179)]  
MC9S08QA2CDNE@SOIC8 [(SA602A+B179)]  
MC9S08QA2CFQ@DFN8 [(SA744+B248)]  
MC9S08QA2CFQE@DFN8 [(SA744+B248)]  
MC9S08QA2CPA  
MC9S08QA2CPAE  
MC9S08QA2MDN@SOIC8 [(SA602A+B179)]  
MC9S08QA2MDNE@SOIC8 [(SA602A+B179)]  
MC9S08QA2MFQ@DFN8 [(SA744+B248)]  
MC9S08QA2MFQE@DFN8 [(SA744+B248)]  
MC9S08QA2MPA  
MC9S08QA2MPAE  
MC9S08QA2VDN@SOIC8 [(SA602A+B179)]  
MC9S08QA2VDNE@SOIC8 [(SA602A+B179)]  
MC9S08QA2VFQ@DFN8 [(SA744+B248)]  
MC9S08QA2VFQE@DFN8 [(SA744+B248)]  
MC9S08QA2VPA  
MC9S08QA2VPAE  
MC9S08QA4CDN@SOIC8 [(SA602A+B179)]  
MC9S08QA4CDNE@SOIC8 [(SA602A+B179)]  
MC9S08QA4CFQ@DFN8 [(SA744+B248)]

MC9S08QA4CFQE@DFN8 [(SA744+B248)]  
 MC9S08QA4CPA  
 MC9S08QA4CPAE  
 MC9S08QA4MDN@SOIC8 [(SA602A+B179)]  
 MC9S08QA4MDNE@SOIC8 [(SA602A+B179)]  
 MC9S08QA4MFQ@DFN8 [(SA744+B248)]  
 MC9S08QA4MFQE@DFN8 [(SA744+B248)]  
 MC9S08QA4MPA  
 MC9S08QA4MPAE  
 MC9S08QA4VDN@SOIC8 [(SA602A+B179)]  
 MC9S08QA4VDNE@SOIC8 [(SA602A+B179)]  
 MC9S08QA4VFQ@DFN8 [(SA744+B248)]  
 MC9S08QA4VFQE@DFN8 [(SA744+B248)]  
 MC9S08QA4VPA  
 MC9S08QA4VPAE  
 MC9S08QD2CPC [(SA726+B179)]  
 MC9S08QD2CSC@SOIC8 [(SA602A+B179)]  
 MC9S08QD2MPC [(SA726+B179)]  
 MC9S08QD2MSC@SOIC8 [(SA602A+B179)]  
 MC9S08QD2VPC [(SA726+B179)]  
 MC9S08QD2VSC@SOIC8 [(SA602A+B179)]  
 MC9S08QD4CPC [(SA726+B179)]  
 MC9S08QD4CSC@SOIC8 [(SA602A+B179)]  
 MC9S08QD4MPC [(SA726+B179)]  
 MC9S08QD4MSC@SOIC8 [(SA602A+B179)]  
 MC9S08QD4VPC [(SA726+B179)]  
 MC9S08QD4VSC@SOIC8 [(SA602A+B179)]  
 MC9S08QG4CDNE@SOIC8 [(SA602A+B179)]  
 MC9S08QG4CDTE@TSSOP16 [(SA026+B182)]  
 MC9S08QG4CFFE@QFN16 [(SA747+B247)]  
 MC9S08QG4CFQE@DFN8 [(SA744+B248)]  
 MC9S08QG4CPAE [(SA726+B179)]  
 MC9S08QG8CDNE@SOIC8 [(SA602A+B179)]  
 MC9S08QG8CDTE@TSSOP16 [(SA026+B182)]  
 MC9S08QG8CFFE@QFN16 [(SA747+B247)]  
 MC9S08QG8CFQE@DFN8 [(SA744+B248)]  
 MC9S08QG8CPBE [(SA726+B182)]                      MC9S08RC16CFG@LQFP44  
 [(SA245A)]  
 MC9S08RC16CFJ@LQFP32 [(SA663)]                      MC9S08RC16FG@LQFP44  
 [(SA245A)]  
 MC9S08RC16FJ@LQFP32 [(SA663)]                      MC9S08RC32CFG@LQFP44  
 [(SA245A)]  
 MC9S08RC32CFJ@LQFP32 [(SA663)]                      MC9S08RC32FG@LQFP44

[ (SA245A) ]	
MC9S08RC32FJ@LQFP32 [ (SA663) ]	MC9S08RC60CFG@LQFP44
[ (SA245A) ]	
MC9S08RC60CFJ@LQFP32 [ (SA663) ]	MC9S08RC60FG@LQFP44
[ (SA245A) ]	
MC9S08RC60FJ@LQFP32 [ (SA663) ]	MC9S08RC8CFG@LQFP44
[ (SA245A) ]	
MC9S08RC8CFJ@LQFP32 [ (SA663) ]	MC9S08RC8FG@LQFP44
[ (SA245A) ]	
MC9S08RC8FJ@LQFP32 [ (SA663) ]	MC9S08RD16CDW@SOIC28
[ (SA404) ]	
MC9S08RD16CFG@LQFP44 [ (SA245A) ]	MC9S08RD16CFJ@LQFP32
[ (SA663) ]	
MC9S08RD16CP	MC9S08RD16DW@SOIC28
[ (SA404) ]	
MC9S08RD16FG@LQFP44 [ (SA245A) ]	MC9S08RD16FJ@LQFP32
[ (SA663) ]	
MC9S08RD16P	MC9S08RD32CDW@SOIC28
[ (SA404) ]	
MC9S08RD32CFG@LQFP44 [ (SA245A) ]	MC9S08RD32CFJ@LQFP32
[ (SA663) ]	
MC9S08RD32CP	MC9S08RD32DW@SOIC28
[ (SA404) ]	
MC9S08RD32FG@LQFP44 [ (SA245A) ]	MC9S08RD32FJ@LQFP32
[ (SA663) ]	
MC9S08RD32P	MC9S08RD60CDW@SOIC28
[ (SA404) ]	
MC9S08RD60CFG@LQFP44 [ (SA245A) ]	MC9S08RD60CFJ@LQFP32
[ (SA663) ]	
MC9S08RD60CP	MC9S08RD60DW@SOIC28
[ (SA404) ]	
MC9S08RD60FG@LQFP44 [ (SA245A) ]	MC9S08RD60FJ@LQFP32
[ (SA663) ]	
MC9S08RD60P	MC9S08RD8CDW@SOIC28
[ (SA404) ]	
MC9S08RD8CFG@LQFP44 [ (SA245A) ]	MC9S08RD8CFJ@LQFP32
[ (SA663) ]	
MC9S08RD8CP	MC9S08RD8DW@SOIC28
[ (SA404) ]	
MC9S08RD8FG@LQFP44 [ (SA245A) ]	MC9S08RD8FJ@LQFP32
[ (SA663) ]	
MC9S08RD8P	MC9S08RE16CFG@LQFP44
[ (SA245A) ]	

MC9S08RE16CFJ@LQFP32 [(SA663)]  
[(SA245A)]  
MC9S08RE16FJ@LQFP32 [(SA663)]  
[(SA245A)]  
MC9S08RE32CFJ@LQFP32 [(SA663)]  
[(SA245A)]  
MC9S08RE32FJ@LQFP32 [(SA663)]  
[(SA245A)]  
MC9S08RE60CFJ@LQFP32 [(SA663)]  
[(SA245A)]  
MC9S08RE60FJ@LQFP32 [(SA663)]  
[(SA245A)]  
MC9S08RE8CFJ@LQFP32 [(SA663)]  
[(SA245A)]  
MC9S08RE8FJ@LQFP32 [(SA663)]  
[(SA245A)]  
MC9S08RG32CFJ@LQFP32 [(SA663)]  
[(SA245A)]  
MC9S08RG32FJ@LQFP32 [(SA663)]  
[(SA245A)]  
MC9S08RG60CFJ@LQFP32 [(SA663)]  
[(SA245A)]  
MC9S08RG60FJ@LQFP32 [(SA663)]  
MC9S08SG4CSC@SOIC8 [(SA602A+B179)]  
MC9S08SG4CTG@TSSOP16 [(SA026+B182)]  
MC9S08SG4MSC@SOIC8 [(SA602A+B179)]  
MC9S08SG4MTG@TSSOP16 [(SA026+B182)]  
MC9S08SG4VSC@SOIC8 [(SA602A+B179)]  
MC9S08SG4VTG@TSSOP16 [(SA026+B182)]  
MC9S08SG8CSC@SOIC8 [(SA602A+B179)]  
MC9S08SG8CTG@TSSOP16 [(SA026+B182)]  
MC9S08SG8MSC@SOIC8 [(SA602A+B179)]  
MC9S08SG8MTG@TSSOP16 [(SA026+B182)]  
MC9S08SG8VSC@SOIC8 [(SA602A+B179)]  
MC9S08SG8VTG@TSSOP16 [(SA026+B182)]  
MC9S08SH4CSC@SOIC8 [(SA602A+B179)]  
MC9S08SH4CTG@TSSOP16 [(SA026+B182)]  
MC9S08SH4MSC@SOIC8 [(SA602A+B179)]  
MC9S08SH4MTG@TSSOP16 [(SA026+B182)]  
MC9S08SH4VSC@SOIC8 [(SA602A+B179)]  
MC9S08SH4VTG@TSSOP16 [(SA026+B182)]  
MC9S08SH8CSC@SOIC8 [(SA602A+B179)]  
MC9S08SH8CTG@TSSOP16 [(SA026+B182)]

MC9S08RE16FG@LQFP44  
MC9S08RE32CFG@LQFP44  
MC9S08RE32FG@LQFP44  
MC9S08RE60CFG@LQFP44  
MC9S08RE60FG@LQFP44  
MC9S08RE8CFG@LQFP44  
MC9S08RE8FG@LQFP44  
MC9S08RG32CFG@LQFP44  
MC9S08RG32FG@LQFP44  
MC9S08RG60CFG@LQFP44  
MC9S08RG60FG@LQFP44

MC9S08SH8MSC@SOIC8 [(SA602A+B179)]  
MC9S08SH8MTG@TSSOP16 [(SA026+B182)]  
MC9S08SH8VSC@SOIC8 [(SA602A+B179)]  
MC9S08SH8VTG@TSSOP16 [(SA026+B182)]  
MC9S12A128BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A64CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A64FU@TQFP80(\*) [(TA015-B006)]  
MC9S12A64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A64MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A64PV@TQFP112(\*) [(TA037-B084)]  
MC9S12A64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A64VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12C128CFA@TQFP48 [(SA248)]  
MC9S12C128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C128MFA@TQFP48 [(SA248)]  
MC9S12C128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C128VFA@TQFP48 [(SA248)]  
MC9S12C128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C32CFA16@TQFP48 [(SA248)]           MC9S12C32CFA25@TQFP48

[ ( SA248 ) ]  
MC9S12C32CFU16@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12C32CFU25@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12C32MFA16@TQFP48 [ ( SA248 ) ]            MC9S12C32MFA25@TQFP48  
[ ( SA248 ) ]  
MC9S12C32MFU16@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12C32MFU25@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12C32VFA16@TQFP48 [ ( SA248 ) ]            MC9S12C32VFA25@TQFP48  
[ ( SA248 ) ]  
MC9S12C32VFU16@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12C32VFU25@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12C64CFA@TQFP48 [ ( SA248 ) ]  
MC9S12C64CFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12C64MFA@TQFP48 [ ( SA248 ) ]  
MC9S12C64MFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12C64VFA@TQFP48 [ ( SA248 ) ]  
MC9S12C64VFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12C96CFA@TQFP48 [ ( SA248 ) ]  
MC9S12C96CFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12C96MFA@TQFP48 [ ( SA248 ) ]  
MC9S12C96MFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12C96VFA@TQFP48 [ ( SA248 ) ]  
MC9S12C96VFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12D64CFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12D64CPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12D64FU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12D64MFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12D64MPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12D64PV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12D64VFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12D64VPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DB128BCPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DB128BMPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DB128BVPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DB128CPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DB128MPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DB128VPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DG128BCFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12DG128BCPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DG128BMFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12DG128BMPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]  
MC9S12DG128BVFU@TQFP80 ( \* ) [ ( TA015-B006 ) ]  
MC9S12DG128BVPV@TQFP112 ( \* ) [ ( TA037-B084 ) ]

MC9S12DG128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128ECFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128ECPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128EMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128EMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128EVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128EVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128ECFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128ECPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128EMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128EMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128EVFU@TQFP80(\*) [(TA015-B006)]



MC9S12DJ128EVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64FU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64PV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128ECPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128EMPV@TQFP112(\*) [(TA037-B084)]

MC9S12DT128EVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DT256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DT256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DT256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12E128CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E128MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E128VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E256CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E256MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E256VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E32CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E32CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E32MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E32MFUE@TQFP80(\*) [(SA722-B239)]

MC9S12E32VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E32VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E64MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E64MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E64VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E64VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12GC128CFA@TQFP48 [(SA248)]  
MC9S12GC128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC128MFA@TQFP48 [(SA248)]  
MC9S12GC128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC128VFA@TQFP48 [(SA248)]  
MC9S12GC128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16CFA@TQFP48 [(SA248)]  
MC9S12GC16CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16MFA@TQFP48 [(SA248)]  
MC9S12GC16MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16VFA@TQFP48 [(SA248)]  
MC9S12GC16VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32CFA@TQFP48 [(SA248)]  
MC9S12GC32CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32MFA@TQFP48 [(SA248)]  
MC9S12GC32MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32VFA@TQFP48 [(SA248)]  
MC9S12GC32VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC64CFA@TQFP48 [(SA248)]  
MC9S12GC64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC64MFA@TQFP48 [(SA248)]  
MC9S12GC64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC64VFA@TQFP48 [(SA248)]  
MC9S12GC64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96CFA@TQFP48 [(SA248)]  
MC9S12GC96CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96MFA@TQFP48 [(SA248)]  
MC9S12GC96MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96VFA@TQFP48 [(SA248)]

MC9S12GC96VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12HN64CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64MAL@LQFP112(\*) [(SA719-B240)]

MC9S12HZ64MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12NE64CPV@LQFP112(\*) [(SA719-B246)]  
MC9S12NE64CPVE@LQFP112(\*) [(SA719-B246)]  
MC9S12NE64VTU@TQFP80(\*) [(TA048-B006)]  
MC9S12NE64VTUE@TQFP80(\*) [(TA048-B006)]  
MC9S12UF32PB@QFP64(\*) [(SA732+B200)]  
MC9S12UF32PBE@QFP64(\*) [(SA732+B200)]  
MC9S12UF32PU@QFP100(\*) [(SA718+B201)]  
MC9S12XA128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256VAV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256VPV@TQFP112(\*) [(TA037-B084)]

MC9S12XA512CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512VAV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128CAA@TQFP80(\*) [(TA015-B006)]

MC9S12XD128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256VfV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD64CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128MPV@TQFP112(\*) [(TA037-B084)]

MC9S12XDG128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512VFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256VFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256MAL@TQFP112(\*) [(TA037-B084)]



MC9S12XDT256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256VFN@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384CPU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384MPU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384VFN@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384VPU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512VFU@TQFP80(\*) [(TA015-B006)]

MC9S12XDT512VVFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XHZ256CAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ256CAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ256MAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ256MAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ256VAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ256VAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ384CAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ384CAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ384MAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ384MAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ384VAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ384VAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ512CAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ512CAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ512MAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ512MAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ512VAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ512VAL@TQFP112(\*) [(SA719-B264)]  
MCHC908JW32FAE@LQFP48 [(SA248+B005)]  
MCHC908JW32FC@TQFN48 [(SA696+B006)]  
P912XDG128CAA@TQFP80(\*) [(TA015-B006)]  
P912XDG128CAL@TQFP112(\*) [(TA037-B084)]  
P912XDG128CFU@TQFP80(\*) [(TA015-B006)]  
P912XDG128CPV@TQFP112(\*) [(TA037-B084)]  
P912XDG128MAA@TQFP80(\*) [(TA015-B006)]  
P912XDG128MAL@TQFP112(\*) [(TA037-B084)]  
P912XDG128MFU@TQFP80(\*) [(TA015-B006)]  
P912XDG128MPV@TQFP112(\*) [(TA037-B084)]  
P912XDG128VAA@TQFP80(\*) [(TA015-B006)]  
P912XDG128VAL@TQFP112(\*) [(TA037-B084)]  
P912XDG128VFU@TQFP80(\*) [(TA015-B006)]  
P912XDG128VPV@TQFP112(\*) [(TA037-B084)]  
P9RS08KA1CPC [(SA726+B179)]  
P9RS08KA1CSC@SOIC8 [(SA602A+B179)]  
P9RS08KA2CPC [(SA726+B179)]  
P9RS08KA2CSC@SOIC8 [(SA602A+B179)]  
PC56F8011VF AE@QFP32 [(SA663+B005)]  
PC56F8013VF AE@QFP32 [(SA663+B005)]  
PC56F8014VF AE@QFP32 [(SA663+B005)]  
PC68HC908GP32 [(SA028)]  
PC68HC908GP32@SDIP42

PC68HC908GP32@TQFP44 [ (SA675) ]  
PC9S12UF32PB@QFP64( \* ) [ (SA732+B200) ]  
PC9S12UF32PBE@QFP64( \* ) [ (SA732+B200) ]  
PC9S12UF32PU@QFP100( \* ) [ (SA718+B201) ]  
PC9S12XF128@QFP112( \* ) [ (SA719-B253) ]  
PC9S12XF128@QFP144( \* ) [ (SA681-B14411) ]  
PC9S12XF128@QFP64( \* ) [ (SA732-B252) ]  
PC9S12XF256@QFP112( \* ) [ (SA719-B253) ]  
PC9S12XF256@QFP144( \* ) [ (SA681-B14411) ]  
PC9S12XF256@QFP64( \* ) [ (SA732-B252) ]  
PC9S12XF384@QFP112( \* ) [ (SA719-B253) ]  
PC9S12XF384@QFP144( \* ) [ (SA681-B14411) ]  
PC9S12XF384@QFP64( \* ) [ (SA732-B252) ]  
PC9S12XF512@QFP112( \* ) [ (SA719-B253) ]  
PC9S12XF512@QFP144( \* ) [ (SA681-B14411) ]  
PC9S12XF512@QFP64( \* ) [ (SA732-B252) ]  
PC9S12XHZ256CAG@LQFP144( \* ) [ (SA681-B14414) ]  
PC9S12XHZ256CAL@TQFP112( \* ) [ (SA719-B264) ]  
PC9S12XHZ256MAG@LQFP144( \* ) [ (SA681-B14414) ]  
PC9S12XHZ256MAL@TQFP112( \* ) [ (SA719-B264) ]  
PC9S12XHZ256VAG@LQFP144( \* ) [ (SA681-B14414) ]  
PC9S12XHZ256VAL@TQFP112( \* ) [ (SA719-B264) ]  
PC9S12XHZ384CAG@LQFP144( \* ) [ (SA681-B14414) ]  
PC9S12XHZ384CAL@TQFP112( \* ) [ (SA719-B264) ]  
PC9S12XHZ384MAG@LQFP144( \* ) [ (SA681-B14414) ]  
PC9S12XHZ384MAL@TQFP112( \* ) [ (SA719-B264) ]  
PC9S12XHZ384VAG@LQFP144( \* ) [ (SA681-B14414) ]  
PC9S12XHZ384VAL@TQFP112( \* ) [ (SA719-B264) ]  
PC9S12XHZ512CAG@LQFP144( \* ) [ (SA681-B14414) ]  
PC9S12XHZ512CAL@TQFP112( \* ) [ (SA719-B264) ]  
PC9S12XHZ512MAG@LQFP144( \* ) [ (SA681-B14414) ]  
PC9S12XHZ512MAL@TQFP112( \* ) [ (SA719-B264) ]  
PC9S12XHZ512VAG@LQFP144( \* ) [ (SA681-B14414) ]  
PC9S12XHZ512VAL@TQFP112( \* ) [ (SA719-B264) ]  
S9S08AW16ACFT@QFN48( \* ) [ (SA696+B198) ]  
S9S08AW16ACLS@QFP44( \* ) [ (SA245+B4404) ]  
S9S08AW16AMFT@QFN48( \* ) [ (SA696+B198) ]  
S9S08AW16AMLS@QFP44( \* ) [ (SA245+B4404) ]  
S9S08AW16AVFT@QFN48( \* ) [ (SA696+B198) ]  
S9S08AW16AVLS@QFP44( \* ) [ (SA245+B4404) ]  
S9S08AW8ACFT@QFN48( \* ) [ (SA696+B198) ]  
S9S08AW8ACLS@QFP44( \* ) [ (SA245+B4404) ]  
S9S08AW8AMFT@QFN48( \* ) [ (SA696+B198) ]

S9S08AW8AMLS@QFP44(\*) [(SA245+B4404)]  
S9S08AW8AVFT@QFN48(\*) [(SA696+B198)]  
S9S08AW8AVLS@QFP44(\*) [(SA245+B4404)]  
XC68HC711D3 XC68HC711D3@PLCC44  
[(SA244)]  
XC68HC711D3@TQFP44 [(SA675)]

## Fremont Micro Devices

### E (E) PROM/FRAM/NVRAM

FT24C02 FT24C02@SOP8  
[(SA602A)]  
FT24C02@TSSOP8 [(SA026)]  
FT24C02A FT24C02A@TSSOP8  
FT24C02A@SOP8 [(SA602A)]  
[(SA026)]  
FT24C04 FT24C04@SOP8  
[(SA602A)]  
FT24C04@TSSOP8 [(SA026)]  
FT24C04A FT24C04A@TSSOP8  
FT24C04A@SOP8 [(SA602A)]  
[(SA026)]  
FT24C08 FT24C08@SOP8  
[(SA602A)]  
FT24C08@TSSOP8 [(SA026)]  
FT24C08A FT24C08A@TSSOP8  
FT24C08A@SOP8 [(SA602A)]  
[(SA026)]  
FT24C1024 FT24C1024@SOP8  
[(SA023A)]  
FT24C1024@TSSOP8 [(SA026)]  
FT24C1024A FT24C1024A@TSSOP8  
FT24C1024A@SOP8 [(SA023A)]  
[(SA026)]  
FT24C128 FT24C128@SOP8  
[(SA602A)]  
FT24C128@TSSOP8 [(SA026)]  
FT24C128A FT24C128A@TSSOP8  
FT24C128A@SOP8 [(SA602A)]  
[(SA026)]  
FT24C16 FT24C16@SOP8

[ (SA602A) ]	
FT24C16@TSSOP8 [ (SA026) ]	
FT24C16A	
FT24C16A@SOP8 [ (SA602A) ]	FT24C16A@TSSOP8
[ (SA026) ]	
FT24C256	
[ (SA602A) ]	
FT24C256@TSSOP8 [ (SA026) ]	FT24C256@SOP8
FT24C256A	
FT24C256A@SOP8 [ (SA602A) ]	FT24C256A@TSSOP8
[ (SA026) ]	
FT24C32	
[ (SA602A) ]	
FT24C32@TSSOP8 [ (SA026) ]	FT24C32@SOP8
FT24C32A	
FT24C32A@SOP8 [ (SA602A) ]	FT24C32A@TSSOP8
[ (SA026) ]	
FT24C512	
[ (SA602A) ]	
FT24C512@TSSOP8 [ (SA026) ]	FT24C512@SOP8
FT24C512A	
FT24C512A@SOP8 [ (SA602A) ]	FT24C512A@TSSOP8
[ (SA026) ]	
FT24C64	
[ (SA602A) ]	
FT24C64@TSSOP8 [ (SA026) ]	FT24C64@SOP8
FT24C64A	
FT24C64A@SOP8 [ (SA602A) ]	FT24C64A@TSSOP8
[ (SA026) ]	
FT34C02	
[ (SA602A) ]	
FT34C02@TSSOP8 [ (SA026) ]	FT34C02@SOP8
FT34C02A	
FT34C02A@SOP8 [ (SA602A) ]	FT34C02A@TSSOP8
[ (SA026) ]	
FT93C46(08bit)	
[ (SA602A) ]	
FT93C46(08bit)@TSSOP8 [ (SA026) ]	FT93C46(08bit)@SOP8
(16bit)	
FT93C46(16bit)@SOP8 [ (SA602A) ]	FT93C46
[ (SA026) ]	
FT93C46A(08bit)	
[ (SA602A) ]	
	FT93C46A(08bit)@SOP8

FT93C46A(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C46A
FT93C46A(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C46A(16bit)@TSSOP8
FT93C56(08bit) [(SA602A)]	FT93C56(08bit)@SOP8
FT93C56(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C56
FT93C56(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C56(16bit)@TSSOP8
FT93C56A(08bit) [(SA602A)]	FT93C56A(08bit)@SOP8
FT93C56A(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C56A
FT93C56A(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C56A(16bit)@TSSOP8
FT93C66(08bit) [(SA602A)]	FT93C66(08bit)@SOP8
FT93C66(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C66
FT93C66(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C66(16bit)@TSSOP8
FT93C66A(08bit) [(SA602A)]	FT93C66A(08bit)@SOP8
FT93C66A(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C66A
FT93C66A(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C66A(16bit)@TSSOP8
FT93C86(08bit) [(SA602A)]	FT93C86(08bit)@SOP8
FT93C86(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C86
FT93C86(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C86(16bit)@TSSOP8
FT93C86A(08bit) [(SA602A)]	FT93C86A(08bit)@SOP8
FT93C86A(08bit)@TSSOP8 [(SA026)] (16bit)	FT93C86A
FT93C86A(16bit)@SOP8 [(SA602A)] [(SA026)]	FT93C86A(16bit)@TSSOP8

**FUJITSU**

**E ( E ) PROM / FRAM / NVRAM**

MB84VD21081@FBGA61 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21081EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21082@FBGA61 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21082EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21083@FBGA61 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21083EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21084@FBGA61 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21084EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21091@FBGA61 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21091EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21092@FBGA61 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21092EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21093@FBGA61 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21093EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21094@FBGA61 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21094EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21181DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21181EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21181EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21182DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21182EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21182EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21183DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21183EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21183EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21184DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21184EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21184EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21191DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21191EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21191EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21192DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21192EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21192EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]

MB84VD22180FA@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22180FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22181A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22181EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22181EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22181FM@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22182A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22182EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22182EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22183A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22183EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22183EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22184EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184FM@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22190FA@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22190FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22191A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22191EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22191EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22191FM@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22192A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22192EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22192EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22193A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22193EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22193EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22194A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22194EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22194EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22194FM@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22280FE@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22282EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22283EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22284EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22290FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22292EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22293EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22294EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22386EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22387EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22388EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]



MB84VD22396EJ@FBGA71 [(SA642F-B032A-T064F001)]  
MB84VD22397EJ@FBGA71 [(SA642F-B032A-T064F001)]  
MB84VD22398EJ@FBGA71 [(SA642F-B032A-T064F001)]  
MB84VD23180FM@FBGA73 [(SA642A-B032A-Y096F001)]  
MB84VD23280EA@FBGA101 [(SA642A-B032A-Y096N001)]  
MB84VD23280EE@FBGA101 [(SA642A-B032A-Y096N001)]  
MB84VD23280FA@FBGA65 [(SA642A-B032A-Y096N001)]  
MB84VD23381EJ@FBGA101 [(SA642A-B032A-Y096N001)]  
MB84VD23381FJ@FBGA65 [(SA642A-B032A-Y096N001)]  
MB84VD23381HJ@FBGA56 [(SA642F-B032A-T064F001)]  
MB84VD23481FJ@FBGA65 [(SA642A-B032A-Y096N001)]  
MB84VF5F5FF4J2@BGA107 [(SA642D-B062A-Y088F001)]  
MB84VP23481FK@FBGA65 [(SA642JJ-B032A-W064F001Y)]  
MB84VP24481HK@FBGA73 [(SA642A-B039A-Y096F001)]  
MB84VP24491HK@FBGA73 [(SA642A-B039A-Y096F001)]  
MB85R256@SOP28 [(SA630)] MB85R256@TSOP28  
[(SA430T)]  
MB85R256A@SOP28 [(SA630)] MB85R256A@TSOP28  
[(SA430T)]  
MBM271001 MBM271001@PLCC32  
[(SA015A1T)]  
MBM271001@TSOP32 [(SA410T)]  
MBM27128  
MBM27128@PLCC32 [(SA015A1T)]  
MBM2716  
MBM2716H  
MBM27256  
MBM27256@PLCC32 [(SA015A1T)]  
MBM2732  
MBM2732A  
MBM2764  
MBM2764@PLCC32 [(SA015A1T)]  
MBM27C1000  
MBM27C1000@PLCC32 [(SA015A1T)] MBM27C1000@TSOP32  
[(SA410T)]  
MBM27C1001 MBM27C1001@PLCC32  
[(SA015A1T)]  
MBM27C1001@TSOP32 [(SA410T)]  
MBM27C1024  
MBM27C1024@PLCC44 [(SA244)]  
MBM27C1028  
MBM27C1028@PLCC32 [(SA015A1T)]  
MBM27C128

MBM27C128@PLCC32 [(SA015A1T)]  
 MBM27C128P  
 MBM27C128P@PLCC32 [(SA015A1T)]  
 MBM27C2000  
 MBM27C2000@PLCC32 [(SA015A1T)] MBM27C2000@TSOP32  
 [(SA410T)]  
 MBM27C2001 MBM27C2001@PLCC32  
 [(SA015A1T)]  
 MBM27C2001@TSOP32 [(SA410T)]  
 MBM27C2048  
 MBM27C256 MBM27C256@PLCC32  
 [(SA015A1T)]  
 MBM27C256A MBM27C256A@PLCC32  
 [(SA015A1T)]  
 MBM27C256AP MBM27C256AP@PLCC32  
 [(SA015A1T)]  
 MBM27C256H MBM27C256H@PLCC32  
 [(SA015A1T)]  
 MBM27C32A  
 MBM27C4001  
 MBM27C4001@PLCC32 [(SA015A1T)] MBM27C4001@TSOP32  
 [(SA410T)]  
 MBM27C4096  
 MBM27C512  
 MBM27C512@PLCC32 [(SA015A1T)]  
 MBM27C512P  
 MBM27C512P@PLCC32 [(SA015A1T)]  
 MBM27C64  
 MBM27C64@PLCC32 [(SA015A1T)]  
 MBM28C64  
 MBM28C65  
 MBM28F010  
 MBM28F010@PLCC32 [(SA015A1T)] MBM28F010@TSOP32  
 [(SA410T)]  
 MBM29DL161BD@FBGA48 [(SA642B-B026A-Y072F001)]  
 MBM29DL161BD@TSOP48 [(SA247-B005)]  
 MBM29DL161BE@FBGA48 [(SA642B-B026A-Y072F001)]  
 MBM29DL161TD@FBGA48 [(SA642B-B026A-Y072F001)]  
 MBM29DL161TD@TSOP48 [(SA247-B005)]  
 MBM29DL161TE@FBGA48 [(SA642B-B026A-Y072F001)]  
 MBM29DL162BD@FBGA48 [(SA642B-B026A-Y072F001)]  
 MBM29DL162BD@TSOP48 [(SA247-B005)]  
 MBM29DL162BE@FBGA48 [(SA642B-B026A-Y072F001)]

MBM29DL162BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL162TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL162TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL320BF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL320BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL320TF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL320TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL321BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL321TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL321TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL322BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL322TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL323BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323BE@TSOP48 [ ( SA247-B005 ) ]

MBM29DL323BF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL323TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL324BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL324BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL324TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL324TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL32BF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL32BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL32TF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL32TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL34BF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL34BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL34TF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL34TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL400BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL400BC@PSOP44 [ ( SA638 ) ]  
MBM29DL400BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL400BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400TC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL400TC@PSOP44 [ ( SA638 ) ]  
MBM29DL400TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL640E@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
MBM29DL640E@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL64DF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
MBM29DL64DF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800B@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL800B@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800BA@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL800BA@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800BB@PSOP44 [ ( SA638-B006 ) ]

MBM29DL800BB@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DL800BT@PSOP44 [ ( SA638-B006 ) ]  
 MBM29DL800BT@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DL800T@PSOP44 [ ( SA638-B006 ) ]  
 MBM29DL800T@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DL800TA@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
 MBM29DL800TA@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DS163BE@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
 MBM29DS163BE@TSOP48 [ ( SA247-B005 ) ]  
 MBM29DS163TE@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
 MBM29DS163TE@TSOP48 [ ( SA247-B005 ) ]  
 MBM29F001B MBM29F001B@PLCC32  
 [ ( SA015A1T ) ]  
 MBM29F001B@TSOP32 [ ( SA410T ) ]  
 MBM29F001T  
 MBM29F001T@PLCC32 [ ( SA015A1T ) ] MBM29F001T@TSOP32  
 [ ( SA410T ) ]  
 MBM29F002B MBM29F002B@PLCC32  
 [ ( SA015A1T ) ]  
 MBM29F002B@TSOP32 [ ( SA410T ) ]  
 MBM29F002NB  
 MBM29F002NB@PLCC32 [ ( SA015A1T ) ] MBM29F002NB@TSOP32  
 [ ( SA410T ) ]  
 MBM29F002NT MBM29F002NT@PLCC32  
 [ ( SA015A1T ) ]  
 MBM29F002NT@TSOP32 [ ( SA410T ) ]  
 MBM29F002T  
 MBM29F002T@PLCC32 [ ( SA015A1T ) ] MBM29F002T@TSOP32  
 [ ( SA410T ) ]  
 MBM29F010 MBM29F010@PLCC32  
 [ ( SA015A1T ) ]  
 MBM29F010@TSOP32 [ ( SA410T ) ]  
 MBM29F010A  
 MBM29F010A@PLCC32 [ ( SA015A1T ) ] MBM29F010A@TSOP32  
 [ ( SA410T ) ]  
 MBM29F016@PSOP44 [ ( SA638 ) ] MBM29F016@TSOP40  
 [ ( SA409T ) ]  
 MBM29F016@TSOP48 [ ( SA247-B005 ) ] MBM29F016A@PSOP44  
 [ ( SA638 ) ]  
 MBM29F016A@TSOP40 [ ( SA409T ) ] MBM29F016A@TSOP48 [ ( SA247-  
 B005 ) ]  
 MBM29F016B@PSOP44 [ ( SA638 ) ] MBM29F016B@TSOP40  
 [ ( SA409T ) ]

MBM29F016B@TSOP48 [ ( SA247-B005 ) ]	MBM29F017B@TSOP48 [ ( SA247-B005 ) ]
MBM29F017D@TSOP40 [ ( SA409T ) ]	MBM29F017D@TSOP48 [ ( SA247-B005 ) ]
MBM29F032B@PSOP44 [ ( SA638 ) ]	MBM29F032B@TSOP40
[ ( SA409T ) ]	
MBM29F033C@TSOP40 [ ( SA409T ) ]	
MBM29F040	
MBM29F040@PLCC32 [ ( SA015A1T ) ]	MBM29F040@TSOP32
[ ( SA410T ) ]	
MBM29F040B	MBM29F040B@PLCC32
[ ( SA015A1T ) ]	
MBM29F040B@TSOP32 [ ( SA410T ) ]	MBM29F040C@PLCC32
[ ( SA015A1T ) ]	
MBM29F040C@TSOP32 [ ( SA410T ) ]	MBM29F080@PSOP44
[ ( SA638 ) ]	
MBM29F080@TSOP40 [ ( SA409T ) ]	MBM29F080A@TSOP48 [ ( SA247-B005 ) ]
B005 ) ]	
MBM29F080B@PSOP44 [ ( SA638 ) ]	MBM29F080B@TSOP40
[ ( SA409T ) ]	
MBM29F100B@PSOP44 [ ( SA638-B006 ) ]	MBM29F100B@TSOP48 [ ( SA247-B005 ) ]
B005 ) ]	
MBM29F100T@PSOP44 [ ( SA638-B006 ) ]	MBM29F100T@TSOP48 [ ( SA247-B005 ) ]
B005 ) ]	
MBM29F160BE@TSOP48 [ ( SA247-B005 ) ]	
MBM29F160TE@TSOP48 [ ( SA247-B005 ) ]	
MBM29F200AB@PSOP44 [ ( SA638-B006 ) ]	
MBM29F200AB@TSOP48 [ ( SA247-B005 ) ]	
MBM29F200AT@PSOP44 [ ( SA638-B006 ) ]	
MBM29F200AT@TSOP48 [ ( SA247-B005 ) ]	
MBM29F200B@PSOP44 [ ( SA638-B006 ) ]	MBM29F200B@TSOP48 [ ( SA247-B005 ) ]
B005 ) ]	
MBM29F200T@PSOP44 [ ( SA638-B006 ) ]	MBM29F200T@TSOP48 [ ( SA247-B005 ) ]
B005 ) ]	
MBM29F400AB@PSOP44 [ ( SA638-B006 ) ]	
MBM29F400AB@TSOP48 [ ( SA247-B005 ) ]	
MBM29F400AT@PSOP44 [ ( SA638-B006 ) ]	
MBM29F400AT@TSOP48 [ ( SA247-B005 ) ]	
MBM29F400B@PSOP44 [ ( SA638-B006 ) ]	MBM29F400B@TSOP48 [ ( SA247-B005 ) ]
B005 ) ]	
MBM29F400BB@PSOP44 [ ( SA638-B006 ) ]	
MBM29F400BB@TSOP48 [ ( SA247-B005 ) ]	
MBM29F400BT@PSOP44 [ ( SA638-B006 ) ]	

MBM29F400BT@TSOP48 [(SA247-B005)]	
MBM29F400T@PSOP44 [(SA638-B006)]	MBM29F400T@TSOP48 [(SA247-B005)]
MBM29F800B@PSOP44 [(SA638-B006)]	MBM29F800B@TSOP48 [(SA247-B005)]
MBM29F800BA@PSOP44 [(SA638-B006)]	
MBM29F800BA@TSOP48 [(SA247-B005)]	
MBM29F800BB@PSOP44 [(SA638-B006)]	
MBM29F800BB@TSOP48 [(SA247-B005)]	
MBM29F800BT@PSOP44 [(SA638-B006)]	
MBM29F800BT@TSOP48 [(SA247-B005)]	
MBM29F800T@PSOP44 [(SA638-B006)]	MBM29F800T@TSOP48 [(SA247-B005)]
MBM29F800TA@PSOP44 [(SA638-B006)]	
MBM29F800TA@TSOP48 [(SA247-B005)]	
MBM29LL800B@TSOP48 [(SA247-B005)]	
MBM29LL800BB@TSOP48 [(SA247-B005)]	
MBM29LL800BT@TSOP48 [(SA247-B005)]	
MBM29LL800T@TSOP48 [(SA247-B005)]	
MBM29LV001B@PLCC32 [(SA015A1T)]	MBM29LV001BB@PLCC32
[(SA015A1T)]	
MBM29LV001BB@TSOP32 [(SA410T)]	MBM29LV001BC@PLCC32
[(SA015A1T)]	
MBM29LV001BC@TSOP32 [(SA410T)]	MBM29LV001BT@PLCC32
[(SA015A1T)]	
MBM29LV001BT@TSOP32 [(SA410T)]	MBM29LV001T@TSOP32
[(SA410T)]	
MBM29LV001TC@PLCC32 [(SA015A1T)]	MBM29LV001TC@TSOP32
[(SA410T)]	
MBM29LV002B@TSOP40 [(SA409T)]	MBM29LV002T@TSOP40
[(SA409T)]	
MBM29LV004B@PSOP44 [(SA638)]	MBM29LV004B@TSOP40
[(SA409T)]	
MBM29LV004BB@TSOP40 [(SA409T)]	MBM29LV004BT@TSOP40
[(SA409T)]	
MBM29LV004T@PSOP44 [(SA638)]	MBM29LV004T@TSOP40
[(SA409T)]	
MBM29LV008B@PSOP44 [(SA638)]	MBM29LV008B@TSOP40
[(SA409T)]	
MBM29LV008BB@TSOP40 [(SA409T)]	MBM29LV008BT@TSOP40
[(SA409T)]	
MBM29LV008T@PSOP44 [(SA638)]	MBM29LV008T@TSOP40
[(SA409T)]	

MBM29LV016/B@TSOP40 [(SA409T)] MBM29LV016/T@TSOP40  
 [(SA409T)]  
 MBM29LV016B@TSOP40 [(SA409T)]  
 MBM29LV017@FBGA48 [(SA642O-B026A-T064F001)]  
 MBM29LV017@TSOP40 [(SA409T)] MBM29LV017B@TSOP40  
 [(SA409T)]  
 MBM29LV017E@TSOP40 [(SA409T)] MBM29LV033C@TSOP40  
 [(SA409T)]  
 MBM29LV080@TSOP40 [(SA409T)] MBM29LV081@TSOP40  
 [(SA409T)]  
 MBM29LV081B@TSOP40 [(SA409T)] MBM29LV116B@TSOP40  
 [(SA409T)]  
 MBM29LV160B@SON46 [(SA631)] MBM29LV160B@SON46  
 (\*)  
 MBM29LV160BB@PSOP44 [(SA638-B006)]  
 MBM29LV160BB@TSOP48 [(SA247-B005)]  
 MBM29LV160BE@FBGA48 [(SA642B-B026A-Y072F001)]  
 MBM29LV160BE@TSOP48 [(SA247-B005)]  
 MBM29LV160BM@FBGA48 [(SA642B-B026A-Y072F001)]  
 MBM29LV160BM@TSOP48 [(SA247-B005)]  
 MBM29LV160BT@PSOP44 [(SA638-B006)]  
 MBM29LV160BT@TSOP48 [(SA247-B005)]  
 MBM29LV160T@SON46 [(SA631)] MBM29LV160T@SON46  
 (\*)  
 MBM29LV160TE@FBGA48 [(SA642B-B026A-Y072F001)]  
 MBM29LV160TE@TSOP48 [(SA247-B005)]  
 MBM29LV160TM@FBGA48 [(SA642B-B026A-Y072F001)]  
 MBM29LV160TM@TSOP48 [(SA247-B005)]  
 MBM29LV200B@PSOP44 [(SA638-B006)]  
 MBM29LV200B@TSOP48 [(SA247-B005)]  
 MBM29LV200BB@PSOP44 [(SA638-B006)]  
 MBM29LV200BB@TSOP48 [(SA247-B005)]  
 MBM29LV200BC@PSOP44 [(SA638)]  
 MBM29LV200BC@TSOP48 [(SA247-B005)]  
 MBM29LV200BT@PSOP44 [(SA638-B006)]  
 MBM29LV200BT@TSOP48 [(SA247-B005)]  
 MBM29LV200T@PSOP44 [(SA638-B006)]  
 MBM29LV200T@TSOP48 [(SA247-B005)]  
 MBM29LV200TC@PSOP44 [(SA638)]  
 MBM29LV200TC@TSOP48 [(SA247-B005)]  
 MBM29LV320BE@FBGA63 [(SA642B-B026A-Y072F001)]  
 MBM29LV320BE@TSOP48 [(SA247-B005)]  
 MBM29LV320TE@FBGA63 [(SA642B-B026A-Y072F001)]



MBM29LV320TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400B@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400B@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29LV400BC@PSOP44 [ ( SA638 ) ]  
MBM29LV400BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400TC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29LV400TC@PSOP44 [ ( SA638 ) ]  
MBM29LV400TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV650UE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV651UE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV652UE@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
MBM29LV800B@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800B@SON46 [ ( SA631 ) ] MBM29LV800B@SON46  
(\* )  
MBM29LV800B@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BA@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800BA@PSOP44 [ ( SA638 ) ]  
MBM29LV800BA@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800BE@PSOP44 [ ( SA638 ) ]  
MBM29LV800BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800T@SON46 [ ( SA631 ) ] MBM29LV800T@SON46  
(\* )  
MBM29LV800T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800TA@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800TA@PSOP44 [ ( SA638 ) ]  
MBM29LV800TA@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800TE@PSOP44 [ ( SA638 ) ]  
MBM29LV800TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29PDS323B@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]

MBM29PDS323T@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
 MBM29PL160BD@PSOP44 [ ( SA638 ) ]  
 MBM29PL160BD@TSOP48 [ ( SA247-B005 ) ]  
 MBM29PL160TD@PSOP44 [ ( SA638 ) ]  
 MBM29PL160TD@TSOP48 [ ( SA247-B005 ) ]  
 MBM29PL32BM@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
 MBM29PL32BM@TSOP48 [ ( SA247-B005 ) ]  
 MBM29PL32TM@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
 MBM29PL32TM@TSOP48 [ ( SA247-B005 ) ]  
 MBM29PL64LM@TSOP48 [ ( SA247-B005 ) ]  
 MBM29PL64LM@TSOP56 [ ( SA628-B067 ) ]  
 MBM29QM12DH@FBGA88 [ ( SA642J-B101A-W080F001 ) ]  
 MBM29QM12DH@TSOP56 [ ( SA628-B097 ) ]  
 MBM29SL160BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 MBM29SL160BD@TSOP48 [ ( SA247-B005 ) ]  
 MBM29SL160TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 MBM29SL160TD@TSOP48 [ ( SA247-B005 ) ]  
 MBM29SL800BB@TSOP48 [ ( SA247-B005 ) ]  
 MBM29SL800BT@TSOP48 [ ( SA247-B005 ) ]

## DRAM & SRAM

MB81C78A  
 [ ( SA630 ) ]

MB81C78A@SOIC28

## MICROCONTROLLER

MB89F202@SDIP32 [ ( SA653 ) ]	MB89F202@SSOP34
[ ( SA689 ) ]	
MB89F202RA@QFP32 [ ( SA663 ) ]	MB89F202RA@SDIP32
[ ( SA653 ) ]	
MB89F202RA@SSOP34 [ ( SA689 ) ]	MB89F482AS@LQFP44
[ ( SA245A ) ]	
MB89F482AS@SDIP42 [ ( SA028 ) ]	MB89F482AW@LQFP44
[ ( SA245A ) ]	
MB89F482AW@SDIP42 [ ( SA028 ) ]	MB89F482HS@LQFP44
[ ( SA245A ) ]	
MB89F482HS@SDIP42 [ ( SA028 ) ]	MB89F482HW@LQFP44
[ ( SA245A ) ]	
MB89F482HW@SDIP42 [ ( SA028 ) ]	
MB89F538-101PFM@TQFP64 ( * ) [ ( SA739+B255 ) ]	

MB89F538-201PFM@TQFP64(\*) [(SA739+B255)]  
 MB89F538L-101PFM@TQFP64(\*) [(SA739+B255)]  
 MB89F538L-201PFM@TQFP64(\*) [(SA739+B255)]  
 MB89P195 MB89P195(F)@SOIC28  
 [(SA630)]  
 MB89P195AP MB89P195AP(F)@SOIC28  
 [(SA630)]  
 MB89P195P MB89P195P(F)@SOIC28  
 [(SA630)]  
 MB89P475-101P-SH@SDIP48 [(SA627-B5604)]  
 MB89P475-102P-SH@SDIP48 [(SA627-B5604)]  
 MB89P475-201P-SH@SDIP48 [(SA627-B5604)]  
 MB89P475-202P-SH@SDIP48 [(SA627-B5604)]  
 MB89P485LPFM-101@TQFP64(\*) [(TA055-B006)]  
 MB89P485LPFM-102@TQFP64(\*) [(TA055-B006)]  
 MB89P485LPFM-103@TQFP64(\*) [(TA055-B006)]  
 MB89P485LPFM-104@TQFP64(\*) [(TA055-B006)]  
 MB89P485PFM-101@TQFP64(\*) [(TA055-B006)]  
 MB89P485PFM-102@TQFP64(\*) [(TA055-B006)]  
 MB89P485PFM-103@TQFP64(\*) [(TA055-B006)]  
 MB89P485PFM-104@TQFP64(\*) [(TA055-B006)]  
 MB89P935CP  
 MB89P935CP--G-SH@SDIP32 [(SA653)]  
 MB90F342A@QFP100(\*) [(TA075)] MB90F342AS@QFP100(\*)  
 [(TA075)]  
 MB90F342CA@QFP100(\*) [(TA075)] MB90F342CAS@QFP100(\*)  
 [(TA075)]  
 MB90F343A@QFP100(\*) [(TA075)] MB90F343AS@QFP100(\*)  
 [(TA075)]  
 MB90F343CA@QFP100(\*) [(TA075)] MB90F343CAS@QFP100(\*)  
 [(TA075)]  
 MB90F345A@QFP100(\*) [(TA075)] MB90F345AS@QFP100(\*)  
 [(TA075)]  
 MB90F345CA@QFP100(\*) [(TA075)] MB90F345CAS@QFP100(\*)  
 [(TA075)]  
 MB90F346A@QFP100(\*) [(TA075)] MB90F346AS@QFP100(\*)  
 [(TA075)]  
 MB90F346CA@QFP100(\*) [(TA075)] MB90F346CAS@QFP100(\*)  
 [(TA075)]  
 MB90F347@QFP100(\*) [(TA075)] MB90F347A@QFP100(\*)  
 [(TA075)]  
 MB90F347AS@QFP100(\*) [(TA075)] MB90F347C@QFP100(\*)  
 [(TA075)]

MB90F347CA@QFP100(*) [(TA075)]	MB90F347CAS@QFP100(*)
[(TA075)]	
MB90F347CS@QFP100(*) [(TA075)]	MB90F347S@QFP100(*)
[(TA075)]	
MB90F349A@QFP100(*) [(TA075)]	MB90F349AS@QFP100(*)
[(TA075)]	
MB90F349CA@QFP100(*) [(TA075)]	MB90F349CAS@QFP100(*)
[(TA075)]	
MB90F352PFM@LQFP64(*) [(SA739+B260)]	
MB90F352SPFM@LQFP64(*) [(SA739+B260)]	
MB90F372@LQFP144(*) [(SA748+B14410)]	
MB90F377@LQFP144(*) [(SA748+B14410)]	
MB90F394H@LQFP120(*) [(TA036-B006)]	
MB90F395H@LQFP120(*) [(TA036-B006)]	
MB90F423GA@TQFP100(*) [(SA718+BBBB)]	
MB90F423GB@TQFP100(*) [(SA718+BBBB)]	
MB90F423GC@TQFP100(*) [(SA718+BBBB)]	
MB90F428GA@TQFP100(*) [(SA718+BBBB)]	
MB90F428GB@TQFP100(*) [(SA718+BBBB)]	
MB90F428GC@TQFP100(*) [(SA718+BBBB)]	
MB90F455PMT@LQFP48 [(SA248)]	MB90F455SPMT@LQFP48
[(SA248)]	
MB90F456PMT@LQFP48 [(SA248)]	MB90F456SPMT@LQFP48
[(SA248)]	
MB90F457PMT@LQFP48 [(SA248)]	MB90F457SPMT@LQFP48
[(SA248)]	
MB90F462AP@SDIP64(*) [(SA752+B307)]	
MB90F462APFM@LQFP64(*) [(SA739+B245)]	
MB90F462P@SDIP64(*) [(SA752+B307)]	
MB90F462PFM@LQFP64(*) [(SA739+B245)]	
MB90F463AP@SDIP64(*) [(SA752+B307)]	
MB90F463APFM@LQFP64(*) [(SA739+B245)]	
MB90F488BPFV@TQFP100(*) [(SA773-B223A)]	
MB90F489BPFV@TQFP100(*) [(SA773-B223A)]	
MB90F497G@LQFP64(*) [(TA070)]	MB90F497G@QFP64(*)
[(TA070)]	
MB90F498G@LQFP64(*) [(TA070)]	MB90F498G@QFP64(*)
[(TA070)]	
MB90F562@LQFP64(*) [(TA070)]	MB90F562@QFP64(*)
[(TA070)]	
MB90F562B@LQFP64(*) [(TA070)]	
MB90F562B@QFP64(*) [(SA758+B322)]	
MB90F562B@SDIP64(*) [(SA752+B307)]	

MB90F583CAPFV@TQFP100(\*) [(SA718+B223)]  
MB90F583CPFV@TQFP100(\*) [(SA718+B223)]  
MB90F822PF@PQFP80(\*) [(SA756+B314)]  
MB90F823PF@PQFP80(\*) [(SA756+B314)]  
MB90F927@QFP100(\*) [(SA753+B270)]  
MB90F927S@QFP100(\*) [(SA753+B270)]  
MB90F947APF@QFP100(\*) [(SA753+B312)]  
MB90F947PF@QFP100(\*) [(SA753+B312)]  
MB90F949APF@QFP100(\*) [(SA753+B312)]  
MB90F949PF@QFP100(\*) [(SA753+B312)]  
MB95F108AHSPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108AHSPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108AHWPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108AHWPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108AKSPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108AKSPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108AKWPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108AKWPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108AMPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108AMPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108AMWPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108AMWPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108ASPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108ASPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108ATSPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108ATSPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108ATWPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108ATWPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108AWPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108AWPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108HSPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108HSPFV@LQFP64(\*) [(SA732+B259)]  
MB95F108HWPFM@LQFP64(\*) [(SA739+B259)]  
MB95F108HWPFV@LQFP64(\*) [(SA732+B259)]  
MB95F118AS@LQFP52(\*) [(SA740+B267)]  
MB95F118AW@LQFP52(\*) [(SA740+B267)]  
MB95F118HS@LQFP52(\*) [(SA740+B267)]  
MB95F118HW@LQFP52(\*) [(SA740+B267)]  
MB95F118MS@LQFP52(\*) [(SA740+B267)]  
MB95F118MW@LQFP52(\*) [(SA740+B267)]  
MB95F118NS@LQFP52(\*) [(SA740+B267)]  
MB95F118NW@LQFP52(\*) [(SA740+B267)]  
MB95F118TS@LQFP52(\*) [(SA740+B267)]

MB95F118TW@LQFP52(*) [(SA740+B267)]	
MB95F128D@LQFP100(*) [(SA718+B324)]	
MB95F128D@QFP100(*) [(SA753+B261)]	
MB95F128E@LQFP100(*) [(SA718+B324)]	
MB95F128E@QFP100(*) [(SA753+B261)]	
MB95F128H@LQFP100(*) [(SA718+B324)]	
MB95F128H@QFP100(*) [(SA753+B261)]	
MB95F128J@LQFP100(*) [(SA718+B324)]	
MB95F128J@QFP100(*) [(SA753+B261)]	
MB95F128M@LQFP100(*) [(SA718+B324)]	
MB95F128M@QFP100(*) [(SA753+B261)]	
MB95F128N@LQFP100(*) [(SA718+B324)]	
MB95F128N@QFP100(*) [(SA753+B261)]	
MB95F128T@LQFP100(*) [(SA718+B324)]	
MB95F128T@QFP100(*) [(SA753+B261)]	
MB95F133HBS@SSOP30 [(SA689)]	MB95F133HBW@SSOP30
[(SA689)]	
MB95F133HS@SOP28 [(SA630)]	MB95F133HW@SOP28
[(SA630)]	
MB95F133JBS@SSOP30 [(SA689)]	MB95F133JBW@SSOP30
[(SA689)]	
MB95F133JS@SOP28 [(SA630)]	MB95F133JW@SOP28
[(SA630)]	
MB95F133MBS@SSOP30 [(SA689)]	MB95F133MBW@SSOP30
[(SA689)]	
MB95F133MS@SOP28 [(SA630)]	MB95F133MW@SOP28
[(SA630)]	
MB95F133NBS@SSOP30 [(SA689)]	MB95F133NBW@SSOP30
[(SA689)]	
MB95F133NS@SOP28 [(SA630)]	MB95F133NW@SOP28
[(SA630)]	
MB95F133TBS@SSOP30 [(SA689)]	MB95F133TBW@SSOP30
[(SA689)]	
MB95F133TS@SOP28 [(SA630)]	MB95F133TW@SOP28
[(SA630)]	
MB95F134HBS@SSOP30 [(SA689)]	MB95F134HBW@SSOP30
[(SA689)]	
MB95F134HS@SOP28 [(SA630)]	MB95F134HW@SOP28
[(SA630)]	
MB95F134JBS@SSOP30 [(SA689)]	MB95F134JBW@SSOP30
[(SA689)]	
MB95F134JS@SOP28 [(SA630)]	MB95F134JW@SOP28
[(SA630)]	

MB95F134MBS@SSOP30 [(SA689)] [(SA689)]	MB95F134MBW@SSOP30
MB95F134MS@SOP28 [(SA630)] [(SA630)]	MB95F134MW@SOP28
MB95F134NBS@SSOP30 [(SA689)] [(SA689)]	MB95F134NBW@SSOP30
MB95F134NS@SOP28 [(SA630)] [(SA630)]	MB95F134NW@SOP28
MB95F134TBS@SSOP30 [(SA689)] [(SA689)]	MB95F134TBW@SSOP30
MB95F134TS@SOP28 [(SA630)] [(SA630)]	MB95F134TW@SOP28
MB95F136HBS@SSOP30 [(SA689)] [(SA689)]	MB95F136HBW@SSOP30
MB95F136HS@SOP28 [(SA630)] [(SA630)]	MB95F136HW@SOP28
MB95F136JBS@SSOP30 [(SA689)] [(SA689)]	MB95F136JBW@SSOP30
MB95F136JS@SOP28 [(SA630)] [(SA630)]	MB95F136JW@SOP28
MB95F136MBS@SSOP30 [(SA689)] [(SA689)]	MB95F136MBW@SSOP30
MB95F136MS@SOP28 [(SA630)] [(SA630)]	MB95F136MW@SOP28
MB95F136NBS@SSOP30 [(SA689)] [(SA689)]	MB95F136NBW@SSOP30
MB95F136NS@SOP28 [(SA630)] [(SA630)]	MB95F136NW@SOP28
MB95F136TBS@SSOP30 [(SA689)] [(SA689)]	MB95F136TBW@SSOP30
MB95F136TS@SOP28 [(SA630)] [(SA630)]	MB95F136TW@SOP28
MB95F156MPMC@LQFP52(*) [(SA740+B304)]	
MB95F156MPMT@LQFP48(*) [(SA248+B4803)]	
MB95F156NPMC@LQFP52(*) [(SA740+B304)]	
MB95F156NPMT@LQFP48(*) [(SA248+B4803)]	
MB95F168JPMC@LQFP64(*) [(SA739+B288)]	
MB95F168JPMC1@LQFP64(*) [(SA732+B288)]	
MB95F168MPMC@LQFP64(*) [(SA739+B288)]	
MB95F168MPMC1@LQFP64(*) [(SA732+B288)]	
MB95F168NPMC@LQFP64(*) [(SA739+B288)]	
MB95F168NPMC1@LQFP64(*) [(SA732+B288)]	
MB95F176JSPMC@LQFP64(*) [(SA739+B305)]	

MB95F176JSPMC1@LQFP64(\*) [(SA739+B305)]

MB95F176JWPMC@LQFP64(\*) [(SA732+B305)]

MB95F176JWPMC1@LQFP64(\*) [(SA732+B305)]

## **GENCORE**

### **MICROCONTROLLER**

GC87C520A0

[(SA244)]

GC87C520A0@TQFP44 [(SA245A)]

GC87C520G0

GC87C520G0@PLCC44 [(SA244)]

[(SA245A)]

GC87C520A0@PLCC44

GC87C520G0@TQFP44

## **GENERAL(GI)**

### **E(E) PROM/FRAM/NVRAM**

27256

27C128

27C128@PLCC32 [(SA015A1T)]

27C256

27C256@PLCC32 [(SA015A1T)]

27C512

27C513

27C64

27C64@PLCC32 [(SA015A1T)]

27HC191

27HC291

27HC64

27HC641

27HC641L

27HC64L

28C04

28C04A

28C04F

28C16

28C16A

28C16F



28C17  
28C17F  
ER5911  
ER5911@SOIC8 [(SA602A)]  
GI5911  
GI5911@SOIC8 [(SA602A)]  
GI59C11  
GI59C11@SOIC8 [(SA602A)]  
GI59C12  
GI59C12@SOIC8 [(SA602A)]  
GR27C513

## GENERIC

### E (E) PROM/FRAM/NVRAM

27128 (21V) (12.5V)	27128A
2716 (25V) (12.5V)	27256
2732 (25V) (21V)	2732A
2732B (12.5V) (12.5V)	27512
27512 (21V) (21V)	2764
2764A (12.5V) (12.5V)	27C128
27C128 (21V) (25V)	27C16
27C256 (12.5V) (25V)	27C32
27C512 (12.5V) (12.5V)	27C64
27C64 (21V)	

## GOAL

### MICROCONTROLLER

VRS1000 [ (SA244) ] VRS1000@TQFP44 [ (SA245A) ] VRS1050 VRS1050@PLCC44 [ (SA244) ] [ (SA675) ] VRS1100 [ (SA244) ] VRS1100@TQFP44 [ (SA245A) ] VRS540 VRS540@PLCC44 [ (SA244) ] [ (SA245A) ] VRS550 [ (SA244) ] VRS550@TQFP44 [ (SA245A) ] VRS560 VRS560@PLCC44 [ (SA244) ] [ (SA245A) ] VRS570 [ (SA244) ] VRS570@TQFP44 [ (SA245A) ] VRS580 VRS580@PLCC44 [ (SA244) ] [ (SA245A) ] VRS700 [ (SA244) ] VRS700@TQFP44 [ (SA245A) ] VRS900 VRS900@PLCC44 [ (SA244) ] [ (SA245A) ]	VRS1000@PLCC44    VRS1050@TQFP44  VRS1100@PLCC44   VRS540@TQFP44  VRS550@PLCC44   VRS560@TQFP44  VRS570@PLCC44   VRS580@TQFP44  VRS700@PLCC44   VRS900@TQFP44
---	---

## GREENWICH

### E (E) PROM / FRAM / NVRAM

GR27128  
GR27256  
GR27512  
GR2764

## HAIER

**MICROCONTROLLER**

HCM87CP311SP@SDIP42 [(SA028)]  
 HR6P60P2DL  
 HR6P60P2SL@SOP20 [(SA404)] HR6P60P2SL@SSOP20  
 [(SA626A)]  
 HR6P62P4D  
 HR6P62P4DH  
 HR6P62P4DHL HR6P62P4DHL  
 (INTOSC)  
 HR6P62P4SH@SOP20 [(SA404+B003)]  
 HR6P62P4SHL(INTOSC)@SOP20 [(SA404+B003)]  
 HR6P62P4SHL@SOP20 [(SA404+B003)]  
 HR6P62P4XHL(INTOSC)@SOP18 [(SA404+B003)]  
 HR6P62P4XHL@SOP18 [(SA404+B003)] HR6P62P4YHL@SOIC14  
 [(SA602)]  
 HR6P67P4D  
 HR6P67P4DL  
 HR6P67P4DL(REVERSE)  
 HR6P67P4SL(REVERSE)@SOP14 [(SA404+B003)]  
 HR6P67P4SL@SOP14 [(SA404+B003)]  
 HR6P71F8D  
 HR6P71F8D(REVERSE)  
 HR6P71F8S(REVERSE)@SOP20 [(SA404)]  
 HR6P71F8S@SOP20 [(SA404)]  
 HR6P72P4D  
 HR6P72P4DL HR6P72P4S@SOP28 [(SA404  
 +B003)]  
 HR6P72P4SL@SOP28 [(SA404+B003)]  
 HR6P73P8DB  
 HR6P73P8DBL HR6P73P8SB@SOP28 [(SA404  
 +B003)]  
 HR6P73P8SBL@SOP28 [(SA404-B003)]  
 HR6P73PGD  
 HR6P73PGDH  
 HR6P73PGDHL  
 HR6P73PGS@SOP28 [(SA404+B003)] HR6P73PGSH@SOP28 [(SA404  
 +B003)]  
 HR6P73PGSHL@SOP28 [(SA404-B003)]  
 HR6P76PGD  
 HR6P76PGDL HR6P76PGS@SOP28 [(SA404  
 +B003)]

HR6P76PGSL@SOP28 [ (SA404-B003) ]  
HR6P77PGD  
HR6P77PGDL  
+B005) ]  
HR6P77PGLL@LQFP44 [ (SA245-B005) ]  
+B006) ]  
HR6P90FGD  
[ (SA404) ]  
HR6P90FHD  
[ (SA404) ]  
HR6P91FGS@SOP32 [ (SA715) ]  
[ (SA715) ]  
HR6P92FGD  
[ (SA245A) ]  
HR6P92FHD  
[ (SA245A) ]  
HR6P95F8D  
[ (SA404) ]  
HR7T46P8V@SDIP42 [ (SA028) ]  
+B005) ]  
HR7T47P8L@LQFP44 [ (SA245A) ]  
+B005) ]

HR6P77PGL@LQFP44 [ (SA245  
HR6P78P4SL@SOP32 [ (SA715  
HR6P90FGS@SOP28  
HR6P90FHS@SOP28  
HR6P91FHS@SOP32  
HR6P92FGL@LQFP44  
HR6P92FHL@LQFP44  
HR6P95F8S@SOP28  
HR7T46PGV@SDIP42 [ (SA028  
HR7T47PGL@LQFP44 [ (SA245A

## HARRIS

### DRAM & SRAM

HM6516  
[ (SA015A1T) ]  
HM65162  
[ (SA015A1T) ]  
HM65642  
[ (SA643) ]

HM6516@PLCC32  
HM65162@PLCC32  
HM65642@TSOP28

## HITACHI

### E (E) PROM / FRAM / NVRAM

HN27128AG  
HN27128AP

HN27256G  
HN27256P  
HN27512G  
HN27512P  
HN27C101AG  
HN27C101AP  
HN27C101G  
HN27C101P  
HN27C1024HG                   HN27C1024HG@PLCC44  
[ (SA244) ]  
HN27C256AG  
HN27C256FP  
HN27C256G  
HN27C256HG  
HN27C301AG  
HN27C301AP  
HN27C301G  
HN27C301P  
HN27C4000FP  
HN27C4000G  
HN27C4001                   HN27C4001@TSOP32  
[ (SA410T) ]  
HN27C4001G  
HN27C4096A  
HN27C4096A@PLCC44 [ (SA244) ]  
HN27C4096FP  
HN27C4096FP@PLCC44 [ (SA244) ]  
HN27C4096G  
HN27C4096G@PLCC44 [ (SA244) ]  
HN27C512G  
HN27C512G@PLCC32 [ (SA015A1T) ]  
HN27C64G  
HN28F101                   HN28F101@PLCC32  
[ (SA015A1T) ]  
HN28F101@SOP32 [ (SA438T) ]                   HN28F101@TSOP32  
[ (SA410T) ]  
HN29A128A0A@CSP95 [ (SA642A-B066A-Y096N001) ]  
HN29A128A0A@TSOP48 [ (SA247-B005) ]  
HN29V128A0A@CSP95 [ (SA642A-B066A-Y096N001) ]  
HN29V128A0A@TSOP48 [ (SA247-B005) ]  
HN29V128A0E@CSP95 [ (SA642A-B066A-Y096N001) ]  
HN29V51211@TSOP48 [ (SA247-B005) ]  
HN462716G

HN462732G	HN48016
(P)	
HN4827128G	
HN4827128P	
HN482732AG	
HN482764G	
HN482764P	HN58064(FP)@SOIC28
[(SA404)]	
HN58064(P)	HN58C1001(FP)@SSOP32
[(SA438T)]	
HN58C1001(P)	HN58C1001(T)@VSOP32
[(SA620)]	
HN58C256A(FP)@SOP28 [(SA630)]	HN58C256A
(P)	
HN58C256A(T)@TSOP28 [(SA643)]	HN58C257A(T)@TSOP32
[(SA620)]	
HN58C65(FP)@SOIC28 [(SA404)]	HN58C65
(P)	
HN58C66	HN58C66@SOP28
[(SA630)]	
HN58C66@TSOP28 [(SA430T)]	
HN58V24256	
HN58V24256@SOIC8 [(SA602A)]	HN58V24256@TSSOP14
[(SA026)]	
HN58V24512	HN58V24512@SOIC8
[(SA602A)]	
HN58V256A	HN58V256A@TSOP28
[(SA430T)]	
HN58V65A	HN58V65A@SOIC28
[(SA630)]	
HN58V65A@TSOP28 [(SA430T)]	
HN58V66A	
HN58V66A@SOIC28 [(SA630)]	HN58V66A@TSOP28
[(SA430T)]	
HN58W241000	HN58W241000@SOIC8
[(SA602A)]	
HN58X2402	HN58X2402@SOIC8
[(SA602A)]	
HN58X2402@TSSOP8 [(SA026)]	
HN58X2404	
HN58X2404@SOIC8 [(SA602A)]	HN58X2404@TSSOP8
[(SA026)]	
HN58X2408	HN58X2408@SOIC8

[ ( SA602A ) ]	
HN58X2408@TSSOP8 [ ( SA026 ) ]	
HN58X24128	
HN58X24128@SOIC8 [ ( SA602A ) ]	
HN58X2416	
HN58X2416@SOIC8 [ ( SA602A ) ]	HN58X2416@TSSOP8
[ ( SA026 ) ]	
HN58X24256	
[ ( SA602A ) ]	
HN58X2432	
[ ( SA602A ) ]	
HN58X2432@TSSOP8 [ ( SA026 ) ]	
HN58X24512	
HN58X24512@SOIC8 [ ( SA602A ) ]	
HN58X2464	
HN58X2464@SOIC8 [ ( SA602A ) ]	HN58X2464@TSSOP8
[ ( SA026 ) ]	
HN58X2502@SOIC8 [ ( SA602A ) ]	HN58X2502@TSSOP8
[ ( SA026 ) ]	
HN58X2504@SOIC8 [ ( SA602A ) ]	HN58X2504@TSSOP8
[ ( SA026 ) ]	
HN58X25128@SOIC8 [ ( SA602A ) ]	HN58X25128@TSSOP14
[ ( SA026 ) ]	
HN58X25256@SOIC8 [ ( SA602A ) ]	HN58X25256@TSSOP14
[ ( SA026 ) ]	
HN58X2532@SOIC8 [ ( SA602A ) ]	HN58X2532@TSSOP8
[ ( SA026 ) ]	
HN58X2564@SOIC8 [ ( SA602A ) ]	HN58X2564@TSSOP8
[ ( SA026 ) ]	
HT29VB800@TSOP48 [ ( SA247-B005 ) ]	HT29VT800@TSOP48 [ ( SA247-B005 ) ]
HT29WB800@TSOP48 [ ( SA247-B005 ) ]	HT29WT800@TSOP48 [ ( SA247-B005 ) ]
V128128A0E@CSP95 [ ( SA642A-B105A-Y096N001 ) ]	

## DRAM & SRAM

HM6116	HM6116@PLCC32
[ ( SA015A1T ) ]	
HM6116A	HM6116A@PLCC32
[ ( SA015A1T ) ]	
HM6208	HM6208@SOJ24

[ ( SA646 ) ]	
HM6208H	HM6208H@SOJ24
[ ( SA646 ) ]	
HM62256	HM62256@TSOP28
[ ( SA643 ) ]	
HM62256B	HM62256B@TSOP28
[ ( SA643 ) ]	
HM624256	HM624256@SOJ28
[ ( SA646 ) ]	
HM6264A	HM6264A@TSOP28
[ ( SA643 ) ]	
HM6267	
HM6268	
HM628128	HM628128@TSOP32
[ ( SA410T ) ]	
HM628128A	HM628128A@TSOP32
[ ( SA410T ) ]	
HM62832	HM62832@TSOP28
[ ( SA643 ) ]	
HM62832H	HM62832H@TSOP28
[ ( SA643 ) ]	
HM628512	HM628512@TSOP32
[ ( SA729 ) ]	
HM6287	
HM6287HP	
HM6288	HM6288@SOJ22
[ ( SA646 ) ]	
HM65256B	HM65256B@TSOP28
[ ( SA643 ) ]	
HM658128	HM658128@TSOP32
[ ( SA410T ) ]	
HM66204	HM66204@TSOP32
[ ( SA410T ) ]	
HM6707	HM6707@SOJ24
[ ( SA646 ) ]	
HM6707A	HM6707A@SOJ24
[ ( SA646 ) ]	
HM6708	HM6708@SOJ24
[ ( SA646 ) ]	
HM6708A	HM6708A@SOJ24
[ ( SA646 ) ]	
HM6716	HM6716@PLCC32
[ ( SA015A1T ) ]	



HM6787	
HM6787HP	
HM6788	HM6788@SOJ22
[ (SA646) ]	
HM6788H	HM6788H@SOJ22
[ (SA646) ]	
HM6788HA	HM6788HA@SOJ22
[ (SA646) ]	

## MICROCONTROLLER

HD4074344@SDIP28 [ (SA022A) ]	HD4074344@SOIC28
[ (SA404) ]	
HD4074394@SDIP28 [ (SA022A) ]	HD4074394@SOIC28
[ (SA404) ]	
HD63701X0C@SDIP64(*) [ (SA752+B265) ]	
HD63701X0P@SDIP64(*) [ (SA752+B265) ]	
HD63701Y0C@SDIP64(*) [ (SA752+B265) ]	
HD63701Y0P@SDIP64(*) [ (SA752+B265) ]	
HD637A01X0C@SDIP64(*) [ (SA752+B265) ]	
HD637A01X0P@SDIP64(*) [ (SA752+B265) ]	
HD637A01Y0C@SDIP64(*) [ (SA752+B265) ]	
HD637A01Y0P@SDIP64(*) [ (SA752+B265) ]	
HD637B01X0C@SDIP64(*) [ (SA752+B265) ]	
HD637B01X0P@SDIP64(*) [ (SA752+B265) ]	
HD637B01Y0C@SDIP64(*) [ (SA752+B265) ]	
HD637B01Y0P@SDIP64(*) [ (SA752+B265) ]	
HD6472357F@PQFP128(*) [ (SA720+B262) ]	
HD6472655F@PQFP128(*) [ (SA720+B175) ]	
HD6472655TE@TQFP128(*) [ (SA721+B174) ]	
HD6472655VF@PQFP128(*) [ (SA720+B175) ]	
HD6472655VTE@TQFP128(*) [ (SA721+B174) ]	
HD6473228P@SDIP64(*) [ (SA736-B229) ]	
HD6473238P@SDIP64(*) [ (SA736-B229) ]	
HD6473258P@SDIP64(*) [ (SA736-B229) ]	
HD6473308@PLCC84(*) [ (SA649-B8406) ]	
HD64738024F(FP-80B)(*) [ (TA006-B006) ]	
HD64738024H(FP-80A)(*) [ (TA008-B006) ]	
HD64738024W(TFP-80C)(*) [ (TA007-B006) ]	
HD6473877H@TQFP100(*) [ (SA718+B202) ]	
HD6475328@PLCC84(*) [ (SA649-B8404) ]	
HD6475348@PLCC84(*) [ (SA649-B8404) ]	

HD6477034F@QFP112(\*) [(SA738+B213)]  
HD64F2110BFA@QFP100 [(SA718-B299)]  
HD64F2110BTE@QFP100 [(SA718-B299)]  
HD64F2110BVFA@QFP100 [(SA718-B299)]  
HD64F2110BVTE@QFP100 [(SA718-B299)]  
HD64F2140BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2140BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2141BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2141BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2142RFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2142RTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2142RVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2142RVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144AFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144ATE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144AVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144AVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144FA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144TE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144VFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144VTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2145BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2145BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147AFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147ATE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147AVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147AVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147NFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147NTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147NVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147NVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148AFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148ATE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148AVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148AVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148FA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148TE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148VFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148VTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]

HD64F2149YFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2149YTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2166VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2167VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2168VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2177VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2280@PQFP100(\*) [(TA046-B006)]  
HD64F2282@PQFP100(\*) [(TA046-B006)]  
HD64F2326VF@PQFP128(\*) [(SA720+B281)]  
HD64F2326VTE@TQFP120(\*) [(SA721+B282)]  
HD64F2328BVF@PQFP128(\*) [(SA720+B281)]  
HD64F2328BVTE@TQFP120(\*) [(SA721+B282)]  
HD64F2328VF@PQFP128(\*) [(SA720+B281)]  
HD64F2328VTE@TQFP120(\*) [(SA721+B282)]  
HD64F2329BVF@PQFP128(\*) [(SA720+B281)]  
HD64F2329BVTE@TQFP120(\*) [(SA721+B282)]  
HD64F2329EVF@PQFP128(\*) [(SA720+B281)]  
HD64F2329EVTE@TQFP120(\*) [(SA721+B282)]  
HD64F2329VF@PQFP128(\*) [(SA720+B281)]  
HD64F2329VTE@TQFP120(\*) [(SA721+B282)]  
HD64F2338VF@TQFP144(\*) [(SA681+B14415)]  
HD64F2339EVF@TQFP144(\*) [(SA681+B14415)]  
HD64F2339VF@TQFP144(\*) [(SA681+B14415)]  
HD64F2357F@PQFP128(\*) [(SA720+B193)]  
HD64F2357TE@QFP120(\*) [(SA721+B194)]  
HD64F2377@TQFP144(\*) [(SA681-B14408)]  
HD64F2377R@TQFP144(\*) [(SA681-B14408)]  
HD64F2378@TQFP144(\*) [(SA681-B14408)]  
HD64F2378R@TQFP144(\*) [(SA681-B14408)]  
HD64F2398F@PQFP128(\*) [(SA720+B193)]  
HD64F2398TE@QFP120(\*) [(SA721+B194)]  
HD64F2505FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2506FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2551FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2552FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2556FC20@QFP144(\*) [(SA681+B14403)]  
HD64F2612FA20@TQFP80(\*) [(SA722+B176)]  
HD64F2615F20@TQFP80(\*) [(SA722+B176)]  
HD64F2615F24@TQFP80(\*) [(SA722+B176)]  
HD64F2646RFC20@QFP144(\*) [(SA681+B14404)]  
HD64F2648RFC20@QFP144(\*) [(SA681+B14404)]  
HD64F2649FC20@QFP144(\*) [(SA681+B14404)]  
HD64F2667VFQ33@QFP144(\*) [(SA681+B14402)]

HD64F3024F@TQFP100(\*) [(TA029-B006)]  
HD64F3024FP@PQFP100(\*) [(TA030-B006)]  
HD64F3024TE@TQFP100(\*) [(TA029-B006)]  
HD64F3026F@TQFP100(\*) [(TA029-B006)]  
HD64F3026FP@PQFP100(\*) [(TA030-B006)]  
HD64F3026TE@TQFP100(\*) [(TA029-B006)]  
HD64F3048BF@TQFP100(\*) [(TA029-B006)]  
HD64F3048BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3048BVF@TQFP100(\*) [(TA029-B006)]  
HD64F3048BVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3048F@TQFP100(\*) [(TA067+B006)]  
HD64F3048TF@TQFP100(\*) [(TA067+B006)]  
HD64F3048VF@TQFP100(\*) [(TA067+B006)]  
HD64F3048VTF@TQFP100(\*) [(TA067+B006)]  
HD64F3052BF@TQFP100(\*) [(TA029-B006)]  
HD64F3052BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3052BVF@TQFP100(\*) [(TA029-B006)]  
HD64F3052BVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3052F@TQFP100(\*) [(TA029-B006)]  
HD64F3052TE@TQFP100(\*) [(TA029-B006)]  
HD64F3062BF@TQFP100(\*) [(TA029-B006)]  
HD64F3062BFP@PQFP100(\*) [(TA030-B006)]  
HD64F3062BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3062F@TQFP100(\*) [(TA029-B006)]  
HD64F3062FP@PQFP100(\*) [(TA030-B006)]  
HD64F3062RF@TQFP100(\*) [(TA029-B006)]  
HD64F3062RFP@PQFP100(\*) [(TA030-B006)]  
HD64F3062RTE@TQFP100(\*) [(TA029-B006)]  
HD64F3062RVF@TQFP100(\*) [(TA029-B006)]  
HD64F3062RVFP@PQFP100(\*) [(TA030-B006)]  
HD64F3062RVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3062TE@TQFP100(\*) [(TA029-B006)]  
HD64F3064BF@TQFP100(\*) [(TA029-B006)]  
HD64F3064BFP@PQFP100(\*) [(TA030-B006)]  
HD64F3064BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3064F@TQFP100(\*) [(TA029-B006)]  
HD64F3064FP@PQFP100(\*) [(TA030-B006)]  
HD64F3064TE@TQFP100(\*) [(TA029-B006)]  
HD64F3067F@TQFP100(\*) [(TA029-B006)]  
HD64F3067FP@PQFP100(\*) [(TA030-B006)]  
HD64F3067RF@TQFP100(\*) [(TA029-B006)]  
HD64F3067RFP@PQFP100(\*) [(TA030-B006)]  
HD64F3067RTE@TQFP100(\*) [(TA029-B006)]

HD64F3067RVF@TQFP100(\*) [(TA029-B006)]  
 HD64F3067RVFP@PQFP100(\*) [(TA030-B006)]  
 HD64F3067RVTE@TQFP100(\*) [(TA029-B006)]  
 HD64F3067TE@TQFP100(\*) [(TA029-B006)]  
 HD64F3068F@TQFP100(\*) [(TA029-B006)]  
 HD64F3068TE@TQFP100(\*) [(TA029-B006)]  
 HD64F3069F@TQFP100(\*) [(SA718+B271)]  
 HD64F3069RF@TQFP100(\*) [(SA718+B271)]  
 HD64F3069RTE@TQFP100(\*) [(SA718+B271)]  
 HD64F3069TE@TQFP100(\*) [(SA718+B271)]  
 HD64F3334YCP16@PLCC84(\*) [(SA649-B8402)]  
 HD64F3334YF16@TQFP80(\*) [(TA018-B006)]  
 HD64F3334YFLH16@TQFP80(\*) [(TA018-B006)]  
 HD64F3334YTF16@TQFP80(\*) [(TA019-B006)]  
 HD64F3334YTFLH16@TQFP80(\*) [(TA019-B006)]  
 HD64F3337YCP16@PLCC84(\*) [(SA649-B8402)]  
 HD64F3337YF16@TQFP80(\*) [(TA018-B006)]  
 HD64F3337YFLH16@TQFP80(\*) [(TA018-B006)]  
 HD64F3337YTF16@TQFP80(\*) [(TA019-B006)]  
 HD64F3337YTFLH16@TQFP80(\*) [(TA019-B006)]  
 HD64F3394YCP16@PLCC84(\*) [(SA649-B8402)]  
 HD64F3394YF16@TQFP80(\*) [(TA018-B006)]  
 HD64F3394YFLH16@TQFP80(\*) [(TA018-B006)]  
 HD64F3394YTF16@TQFP80(\*) [(TA019-B006)]  
 HD64F3394YTFLH16@TQFP80(\*) [(TA019-B006)]  
 HD64F3397CP17@PLCC84(\*) [(SA649-B8402)]  
 HD64F3397F17@TQFP80(\*) [(TA018-B006)]  
 HD64F3397FLH17@TQFP80(\*) [(TA018-B006)]  
 HD64F3397TF17@TQFP80(\*) [(TA019-B006)]  
 HD64F3397TFLH17@TQFP80(\*) [(TA019-B006)]  
 HD64F3434F@QFP100(\*) [(SA718+B306)]  
 HD64F3434TF@QFP100(\*) [(SA718+B306)]  
 HD64F3437F@QFP100(\*) [(SA718+B306)]  
 HD64F3437TF@QFP100(\*) [(SA718+B306)]  
 HD64F36012FX@TQFP48 [(SA671)] HD64F36012FY@TQFP48  
 [(SA248)]  
 HD64F36012GFP@TQFP64 [(SA732+B313)]  
 HD64F36012GFX@TQFP48 [(SA671)] HD64F36012GFY@TQFP48  
 [(SA248)]  
 HD64F36014FX@TQFP48 [(SA671)] HD64F36014FY@TQFP48  
 [(SA248)]  
 HD64F36014GFP@TQFP64 [(SA732+B313)]  
 HD64F36014GFX@TQFP48 [(SA671)] HD64F36014GFY@TQFP48

[ (SA248) ]  
HD64F36022FX@TQFP48 [ (SA671) ] HD64F36022FY@TQFP48  
[ (SA248) ]  
HD64F36022GFP@TQFP64 [ (SA732+B313) ]  
HD64F36022GFX@TQFP48 [ (SA671) ] HD64F36022GFY@TQFP48  
[ (SA248) ]  
HD64F36024FX@TQFP48 [ (SA671) ] HD64F36024FY@TQFP48  
[ (SA248) ]  
HD64F36024GFP@TQFP64 [ (SA732+B313) ]  
HD64F36024GFX@TQFP48 [ (SA671) ] HD64F36024GFY@TQFP48  
[ (SA248) ]  
HD64F36034FZ@TQFP64( \* ) [ (TA043-B006) ]  
HD64F36034GFZ@TQFP64( \* ) [ (TA043-B006) ]  
HD64F36034GH@TQFP64( \* ) [ (TA042-B006) ]  
HD64F36034H@TQFP64( \* ) [ (TA042-B006) ]  
HD64F36037FZ@TQFP64( \* ) [ (TA043-B006) ]  
HD64F36037GFZ@TQFP64( \* ) [ (TA043-B006) ]  
HD64F36037GH@TQFP64( \* ) [ (TA042-B006) ]  
HD64F36037H@TQFP64( \* ) [ (TA042-B006) ]  
HD64F36054FZ@TQFP64( \* ) [ (TA043-B006) ]  
HD64F36054GFZ@TQFP64( \* ) [ (TA043-B006) ]  
HD64F36054GH@TQFP64( \* ) [ (TA042-B006) ]  
HD64F36054H@TQFP64( \* ) [ (TA042-B006) ]  
HD64F36057FZ@TQFP64( \* ) [ (TA043-B006) ]  
HD64F36057GFZ@TQFP64( \* ) [ (TA043-B006) ]  
HD64F36057GH@TQFP64( \* ) [ (TA042-B006) ]  
HD64F36057H@TQFP64( \* ) [ (TA042-B006) ]  
HD64F36064GFP@TQFP64( \* ) [ (TA043-B006) ]  
HD64F36064GH@TQFP64( \* ) [ (TA042-B006) ]  
HD64F36074GFZ@QFP64( \* ) [ (SA757-B235) ]  
HD64F36074GFZW@QFP64( \* ) [ (SA757-B235) ]  
HD64F36074GH@QFP64( \* ) [ (SA757-B235) ]  
HD64F36074GHW@QFP64( \* ) [ (SA757-B235) ]  
HD64F36074LFZ@LQFP64( \* ) [ (SA732-B235) ]  
HD64F36074LFZW@LQFP64( \* ) [ (SA732-B235) ]  
HD64F36074LH@LQFP64( \* ) [ (SA732-B235) ]  
HD64F36074LHW@LQFP64( \* ) [ (SA732-B235) ]  
HD64F36077GFZ@QFP64( \* ) [ (SA757-B235) ]  
HD64F36077GFZW@QFP64( \* ) [ (SA757-B235) ]  
HD64F36077GH@QFP64( \* ) [ (SA757-B235) ]  
HD64F36077GHW@QFP64( \* ) [ (SA757-B235) ]  
HD64F36077LFZ@LQFP64( \* ) [ (SA732-B235) ]  
HD64F36077LFZW@LQFP64( \* ) [ (SA732-B235) ]

HD64F36077LH@LQFP64(\*) [(SA732-B235)]  
HD64F36077LHW@LQFP64(\*) [(SA732-B235)]  
HD64F36078GFZ@QFP64(\*) [(SA757-B235)]  
HD64F36078GFZW@QFP64(\*) [(SA757-B235)]  
HD64F36078GH@QFP64(\*) [(SA757-B235)]  
HD64F36078GHW@QFP64(\*) [(SA757-B235)]  
HD64F36078LFZ@LQFP64(\*) [(SA732-B235)]  
HD64F36078LFZW@LQFP64(\*) [(SA732-B235)]  
HD64F36078LH@LQFP64(\*) [(SA732-B235)]  
HD64F36078LHW@LQFP64(\*) [(SA732-B235)]  
HD64F36079GFZ@QFP64(\*) [(SA757-B235)]  
HD64F36079GFZW@QFP64(\*) [(SA757-B235)]  
HD64F36079GH@QFP64(\*) [(SA757-B235)]  
HD64F36079GHW@QFP64(\*) [(SA757-B235)]  
HD64F36079LFZ@LQFP64(\*) [(SA732-B235)]  
HD64F36079LFZW@LQFP64(\*) [(SA732-B235)]  
HD64F36079LH@LQFP64(\*) [(SA732-B235)]  
HD64F36079LHW@LQFP64(\*) [(SA732-B235)]  
HD64F3642AH@QFP64(\*) [(SA668+B275)]  
HD64F3642AP@SDIP64(\*) [(SA736+B274)]  
HD64F3642AW@QFP80(\*) [(SA731+B276)]  
HD64F3643H@QFP64(\*) [(SA668+B275)]  
HD64F3643P@SDIP64(\*) [(SA736+B274)]  
HD64F3643W@QFP80(\*) [(SA731+B276)]  
HD64F3644H@QFP64(\*) [(SA668+B275)]  
HD64F3644P@SDIP64(\*) [(SA736+B274)]  
HD64F3644W@QFP80(\*) [(SA731+B276)]  
HD64F3664BP@SDIP42 [(SA028)]  
HD64F3664FP@TQFP64(\*) [(SA732+B224)]  
HD64F3664FX@TQFP48 [(SA671)] HD64F3664FY@TQFP48  
[(SA248)]  
HD64F3684FP@TQFP64(\*) [(TA043-B006)]  
HD64F3684GFP@TQFP64(\*) [(TA043-B006)]  
HD64F3684GH@TQFP64(\*) [(TA042-B006)]  
HD64F3684H@TQFP64(\*) [(TA042-B006)]  
HD64F3687FP@TQFP64(\*) [(TA043-B006)]  
HD64F3687GFP@TQFP64(\*) [(TA043-B006)]  
HD64F3687GH@TQFP64(\*) [(TA042-B006)]  
HD64F3687H@TQFP64(\*) [(TA042-B006)]  
HD64F36902G@LQFP32 [(SA663)] HD64F36902G@SOP32  
[(SA682)]  
HD64F36912G@LQFP32 [(SA663)] HD64F36912G@SOP32  
[(SA682)]

HD64F3694FX@TQFP48 [(SA671)]	HD64F3694FY@TQFP48
[(SA248)]	
HD64F3694GFX@TQFP48 [(SA671)]	HD64F3694GFY@TQFP48
[(SA248)]	
HD64F38024F(FP-80B)@PQFP80(*) [(TA003-B006)]	
HD64F38024H(FP-80A)@TQFP80(*) [(TA005-B006)]	
HD64F38024RF(FP-80B)@PQFP80(*) [(TA003-B006)]	
HD64F38024RH(FP-80A)@TQFP80(*) [(TA005-B006)]	
HD64F38024RW(TFP-80C)@TQFP80(*) [(TA004-B006)]	
HD64F38024W(TFP-80C)@TQFP80(*) [(TA004-B006)]	
HD64F38124F(FP-80B)@PQFP80(*) [(TA003-B006)]	
HD64F38124H(FP-80A)@TQFP80(*) [(TA005-B006)]	
HD64F38124W(TFP-80C)@TQFP80(*) [(TA004-B006)]	
HD64F39802G@SDIP32 [(SA653)]	
HD64F7044F@QFP112(*) [(SA755+B278)]	
HD64F7046F@QFP80(*) [(TA014+B006)]	
HD64F7047@QFP100(*) [(SA718+B172)]	

## HOLTEK

### E ( E ) PROM / FRAM / NVRAM

HT24C01	HT24C01@SOIC8
[(SA602A)]	
HT24C02	HT24C02@SOIC8
[(SA602A)]	
HT24C04	HT24C04@SOIC8
[(SA602A)]	
HT24C08	
HT24C16	
HT24LC01	HT24LC01@SOIC8
[(SA602A)]	
HT24LC01@TSSOP8 [(SA026)]	
HT24LC02	
HT24LC02@SOIC8 [(SA602A)]	HT24LC02@TSSOP8
[(SA026)]	
HT24LC04	HT24LC04@SOIC8
[(SA602A)]	
HT24LC08	HT24LC08@SOIC8
[(SA602A)]	
HT24LC16	HT24LC16@SOIC8
[(SA602A)]	



HT24LC32 [ (SA602A) ]	HT24LC32@SOIC8
HT24LC64 [ (SA602A) ]	HT24LC64@SOIC8
HT25LC512@SOIC8 [ (SA602A) ]	
HT27C010 HT27C010@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	HT27C010@TSOP32
HT27C020 [ (SA015A1T) ]	HT27C020@PLCC32
HT27C020@TSOP32 [ (SA410T) ]	
HT27C040 HT27C040@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	HT27C040@TSOP32
HT27C4096 [ (SA244) ]	HT27C4096@PLCC44
HT27C512 [ (SA015A1T) ]	HT27C512@PLCC32
HT27C512@TSOP28 [ (SA430T) ]	
HT27LC010 HT27LC010@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	HT27LC010@TSOP32
HT27LC020 [ (SA015A1T) ]	HT27LC020@PLCC32
HT27LC020@TSOP32 [ (SA410T) ]	
HT27LC040 HT27LC040@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	HT27LC040@TSOP32
HT27LC4096 [ (SA244) ]	HT27LC4096@PLCC44
HT27LC512 [ (SA015A1T) ]	HT27LC512@PLCC32
HT27LC512@TSOP28 [ (SA430T) ] (16bit)	HT93C46
HT93C46(16bit)@SOP8-A [ (SA602A) ] [ (SA602A) ]	HT93C46(16bit)@SOP8-B
HT93C46(16bit)@TSSOP8 [ (SA026) ] (16bit)	HT93C56
HT93C56(16bit)@SOP8-A [ (SA602A) ] [ (SA602A) ]	HT93C56(16bit)@SOP8-B
HT93C56(16bit)@TSSOP8 [ (SA026) ] (16bit)	HT93C66
HT93C66(16bit)@SOP8-A [ (SA602A) ]	HT93C66(16bit)@SOP8-B

[ (SA602A) ]

HT93C66(16bit)@TSSOP8 [ (SA026) ]  
(08bit)

HT93LC46A

HT93LC46A(08bit)@SOP8-A [ (SA602A) ]

HT93LC46A(08bit)@SOP8-B [ (SA602A) ]

HT93LC46A(08bit)@TSSOP8 [ (SA026) ]

HT93LC46A(16bit)

HT93LC46A(16bit)@SOP8-A [ (SA602A) ]

HT93LC46A(16bit)@SOP8-B [ (SA602A) ]

HT93LC46A(16bit)@TSSOP8 [ (SA026) ]

HT93LC46B(08bit)

HT93LC46B(08bit)@SOP8-A [ (SA602A) ]

HT93LC46B(08bit)@SOP8-B [ (SA602A) ]

HT93LC46B(08bit)@TSSOP8 [ (SA026) ]

HT93LC46B(16bit)

HT93LC46B(16bit)@SOP8-A [ (SA602A) ]

HT93LC46B(16bit)@SOP8-B [ (SA602A) ]

HT93LC46B(16bit)@TSSOP8 [ (SA026) ]

HT93LC56A(08bit)

HT93LC56A(08bit)@SOP8-A [ (SA602A) ]

HT93LC56A(08bit)@SOP8-B [ (SA602A) ]

HT93LC56A(08bit)@TSSOP8 [ (SA026) ]

HT93LC56A(16bit)

HT93LC56A(16bit)@SOP8-A [ (SA602A) ]

HT93LC56A(16bit)@SOP8-B [ (SA602A) ]

HT93LC56A(16bit)@TSSOP8 [ (SA026) ]

HT93LC56B(08bit)

HT93LC56B(08bit)@SOP8-A [ (SA602A) ]

HT93LC56B(08bit)@SOP8-B [ (SA026) ]

HT93LC56B(08bit)@TSSOP8 [ (SA026) ]

HT93LC56B(16bit)

HT93LC56B(16bit)@SOP8-A [ (SA602A) ]

HT93LC56B(16bit)@SOP8-B [ (SA602A) ]

HT93LC56B(16bit)@TSSOP8 [ (SA026) ]

HT93LC66A(08bit)

HT93LC66A(08bit)@SOP8-A [ (SA602A) ]

HT93LC66A(08bit)@SOP8-B [ (SA602A) ]

HT93LC66A(08bit)@TSSOP8 [ (SA026) ]

HT93LC66A(16bit)

HT93LC66A(16bit)@SOP8-A [ (SA602A) ]

HT93LC66A(16bit)@SOP8-B [ (SA602A) ]

HT93LC66A(16bit)@TSSOP8 [ (SA026) ]

HT93LC66B(08bit)

HT93LC66B(08bit)@SOP8-A [(SA602A)]	
HT93LC66B(08bit)@SOP8-B [(SA026)]	
HT93LC66B(08bit)@TSSOP8 [(SA026)]	
HT93LC66B(16bit)	
HT93LC66B(16bit)@SOP8-A [(SA602A)]	
HT93LC66B(16bit)@SOP8-B [(SA602A)]	
HT93LC66B(16bit)@TSSOP8 [(SA026)]	
HT93LC76(08bit)	
HT93LC76(08bit)@SOP8-A [(SA602A)]	
HT93LC76(08bit)@SOP8-B [(SA602A)]	
HT93LC76(08bit)@TSSOP8 [(SA026)]	HT93LC76
(16bit)	
HT93LC76(16bit)@SOP8-A [(SA602A)]	
HT93LC76(16bit)@SOP8-B [(SA602A)]	
HT93LC76(16bit)@TSSOP8 [(SA026)]	HT93LC86
(08bit)	
HT93LC86(08bit)@SOP8-A [(SA602A)]	
HT93LC86(08bit)@SOP8-B [(SA602A)]	
HT93LC86(08bit)@TSSOP8 [(SA026)]	HT93LC86
(16bit)	
HT93LC86(16bit)@SOP8-A [(SA602A)]	
HT93LC86(16bit)@SOP8-B [(SA602A)]	
HT93LC86(16bit)@TSSOP8 [(SA026)]	

## MICROCONTROLLER

HT46R22	HT46R22@SOP24
[(SA404)]	
HT46R23(dip24)	HT46R23
(dip28)	
HT46R23@SOP24 [(SA404)]	HT46R23@SOP28
[(SA404)]	
HT46R24	HT46R24@SOP28
[(SA404)]	
HT46R24@SSOP48 [(SA669)]	HT46R46
(dip18)	
HT46R46(dip20)	HT46R46@SOP18
[(SA404)]	
HT46R46@SOP20 [(SA404)]	HT46R46E
(dip18)	
HT46R46E@SOP18 [(SA404)]	HT46R46-
H	

HT46R46-H@SOP18 [(SA404)] (dip18)	HT46R47
HT46R47(dip20) [(SA404)]	HT46R47@SOP18
HT46R47@SOP20 [(SA404)] [(SA674)]	HT46R47@SSOP20
HT46R47E(dip18) [(SA404)]	HT46R47E@SOP18
HT46R47-H [(SA404)]	HT46R47-H@SOP18
HT46R48(dip20) (dip24)	HT46R48
HT46R48@SOP20 [(SA404)] [(SA404)]	HT46R48@SOP24
HT46R48@SSOP24 [(SA674)] (dip24)	HT46R48E
HT46R48E@SOP24 [(SA404)] [(SA674)]	HT46R48E@SSOP24
HT46R51A(dip18) [(SA404)]	HT46R51A@SOP20
HT46R51A@SSOP20 [(SA674)] (dip18)	HT46R52A
HT46R52A@SOP20 [(SA404)] [(SA674)]	HT46R52A@SSOP20
HT46R53A(dip28) [(SA404)]	HT46R53A@SOP28
HT46R54A(dip28) [(SA404)]	HT46R54A@SOP28
HT46R65@PQFP100 [(PEP+S427)] [(SA669)]	HT46R65@SSOP56
HT46R71D@SSOP48 [(SA669)]	
HT46RB70	
HT46RB70@SOP28 [(SA404)] [(SA669)]	HT46RB70@SSOP48
HT46RU22(dip24) [(SA404)]	HT46RU22@SOP24
HT46RU22@SSOP24 [(SA674)] [(SA245)]	HT47R10A@QFP44
HT48R05A [(SA026)]	HT48R05A@SOP16
HT48R05A@SOP18 [(SA404)]	
HT48R06A	
HT48R06A@SOP16 [(SA026)]	HT48R06A@SOP18

[(SA404)]	
HT48R07A	HT48R07A@SOP24
[(SA404)]	
HT48R07A@SSOP24 [(SA674)]	
HT48R08A	
HT48R08A@SOP16 [(SA026)]	HT48R08A@SOP18
[(SA404)]	
HT48R09A	HT48R09A@SOP24
[(SA404)]	
HT48R09A@SSOP24 [(SA674)]	
HT48R10A	
HT48R10A@SOP24 [(SA404)]	HT48R30A
(dip24)	
HT48R30A(dip28)	HT48R30A@SOP24
[(SA404)]	
HT48R30A@SOP28 [(SA404)]	
HT48R50A	
HT48R50A@SOP28 [(SA404)]	HT48R50A@SSOP48
[(SA669)]	
HT48R52A@QFP44 [(SA245A)]	HT48R70A@SSOP48
[(SA669)]	
HT48RA0-1	HT48RA0-1@SOP24
[(SA404)]	
HT48RA0-2	HT48RA0-2@SOP20
[(SA404)]	
HT48RA0-2@SSOP20 [(SA674)]	HT48RA0-
3	
HT48RA0-3@SOP20 [(SA404)]	HT48RA1@SOP28
[(SA404)]	
HT48RA1@SSOP28 [(SA626A)]	HT48RA3
(dip28)	
HT48RA3@SOP28 [(SA404)]	HT48RA3@SSOP28
[(SA626A)]	
HT48RA5(dip28)	HT48RA5@SOP28
[(SA404)]	
HT48RA5@SSOP28 [(SA626A)]	
HT48RB50	
HT48RB50@SOP28 [(SA404)]	HT48RB50@SSOP48
[(SA669)]	
HT48RB8@SOP28 [(SA404)]	HT48RB8@SSOP48
[(SA669)]	
HT49R30A@SSOP48 [(SA669)]	HT49R50A@SSOP48
[(SA669)]	

HT49RV5@SSOP56 [(SA669)]	HT82A821R@SOP24
[(SA404)]	
HT82A821R@SSOP24 [(SA674)]	HT82A822R@SSOP48
[(SA669)]	
HT82A832R@QFP48 [(SA248)]	HT82A832R@SSOP48
[(SA669)]	
HT82K68E	HT82K68E@SOP20
[(SA404)]	
HT82K68E@SOP28 [(SA404)]	HT82K68E@SSOP48
[(SA669)]	
HT82K94E@SSOP48 [(SA669)]	HT82K96E
(dip20)	
HT82K96E(dip40)	HT82K96E@SOP20
[(SA404)]	
HT82K96E@SOP28 [(SA404)]	HT82K96E@SSOP48
[(SA669)]	
HT82M99E(dip18)	HT82M99E
(dip20)	
HT82M99E@SOP18 [(SA404)]	HT82M99E@SOP20
[(SA404)]	
HT82M9AE@SOP20 [(SA404)]	HT82M9AE@SOP24
[(SA404)]	
HT82M9AE@SSOP20 [(SA674)]	HT82M9AE@SSOP24
[(SA674)]	
HT82M9BE@SOP24 [(SA404)]	HT82M9BE@SOP28
[(SA404)]	
HT82M9BE@SSOP24 [(SA674)]	HT82M9BE@SSOP28
[(SA626A)]	
HT95A100@SOP28 [(SA404)]	HT95A10P@SOP28
[(SA404)]	
HT95A200@SSOP48 [(SA669)]	HT95A20P@SSOP48
[(SA669)]	
HT95A300@SSOP48 [(SA669)]	HT95A30P@SSOP48
[(SA669)]	

## HONGKONG

### E(E) PROM/FRAM/NVRAM

HK1215  
HK1225  
HK1235

HK1245  
HK1255  
HK1265  
HK1275  
HK1285  
HK1295  
HK12A5  
HK12B5  
OKS1225  
OKS1235  
OKS1245  
OKS1255  
OKS1265  
OKS1275  
OKS1285  
OKS1295  
OKS12A5  
OKS12B5

## **HYNIX**

### **E ( E ) PROM / FRAM / NVRAM**

H8BCS0SI0MAP@FBGA149 [ ( SA700I-B308-T149F001Y ) ]  
H8BCS0SJ0MCP@FBGA137 [ ( SA700E-B327A-M137F001Y ) ]  
HY2764  
HY27C64A  
HY27SF081G2A@FBGA63 [ ( SA642KK-B026A-W048F001Y ) ]  
HY27UA081G1M@TSOP48 [ ( SA247-B005 ) ]  
HY27UF081G2A@FBGA63 [ ( SA642KK-B026-W048F001Y ) ]  
HY27UF081G2A@TSOP48 [ ( SA247-B005 ) ]  
HY27UF081G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UF082G2A@TSOP48 [ ( SA247-B005 ) ]  
HY27UF082G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UF084G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UG082G2M@TSOP48 [ ( SA247-B005 ) ]  
HY27UG088G5M@TSOP48 [ ( SA247+B005 ) ]  
HY27US08121A@FBGA63 [ ( SA642KK-B026-W048F001Y ) ]  
HY27US08121A@TSOP48 [ ( SA247-B005 ) ]  
HY27US08121B@TSOP48 [ ( SA247-B005 ) ]  
HY27US08121M@TSOP48 [ ( SA247-B005 ) ]  
HY27US08281A@TSOP48 [ ( SA247-B005 ) ]

HY27US08561A@FBGA63 [ ( SA642KK-B026A-W048F001Y ) ]  
 HY27US08561A@TSOP48 [ ( SA247-B005 ) ]  
 HY27US08561M@TSOP48 [ ( SA247-B005 ) ]  
 HY27UT084G2M@TSOP48 [ ( SA247-B005 ) ]  
 HY27UT088G2M@TSOP48 [ ( SA247-B005 ) ]  
 HY27UU088G5M@TSOP48 [ ( SA247+B005 ) ]  
 HY27UV08BG5M@TSOP48 [ ( SA247-B005 ) ]  
 HY29DL162BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29DL162BT@TSOP48 [ ( SA247-B005 ) ]  
 HY29DL162TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29DL162TT@TSOP48 [ ( SA247-B005 ) ]  
 HY29DL163BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29DL163BT@TSOP48 [ ( SA247-B005 ) ]  
 HY29DL163TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29DL163TT@TSOP48 [ ( SA247-B005 ) ]  
 HY29DS162BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29DS162BT@TSOP48 [ ( SA247-B005 ) ]  
 HY29DS162TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29DS162TT@TSOP48 [ ( SA247-B005 ) ]  
 HY29DS163BF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29DS163BT@TSOP48 [ ( SA247-B005 ) ]  
 HY29DS163TF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
 HY29DS163TT@TSOP48 [ ( SA247-B005 ) ]  
 HY29F002T HY29F002T@PLCC32  
 [ ( SA015A1T ) ]  
 HY29F002T@TSOP32 [ ( SA410T ) ]  
 HY29F040  
 HY29F040@PLCC32 [ ( SA015A1T ) ] HY29F040@TSOP32  
 [ ( SA410T ) ]  
 HY29F040A HY29F040A@PLCC32  
 [ ( SA015A1T ) ]  
 HY29F040A@TSOP32 [ ( SA410T ) ] HY29F080@TSOP40  
 [ ( SA409T ) ]  
 HY29F200B@PSOP44 [ ( SA638-B006 ) ] HY29F200B@TSOP48 [ ( SA247-  
 B005 ) ]  
 HY29F200T@PSOP44 [ ( SA638-B006 ) ] HY29F200T@TSOP48 [ ( SA247-  
 B005 ) ]  
 HY29F400ABG@PSOP44 [ ( SA638 ) ]  
 HY29F400ABT@TSOP48 [ ( SA247-B005 ) ]  
 HY29F400ATG@PSOP44 [ ( SA638 ) ]  
 HY29F400ATT@TSOP48 [ ( SA247-B005 ) ]  
 HY29F400BG@PSOP44 [ ( SA638 ) ] HY29F400BT@TSOP48 [ ( SA247-  
 B005 ) ]



HY29F400TG@PSOP44 [ (SA638) ]                      HY29F400TT@TSOP48 [ (SA247-  
 B005) ]  
 HY29F800ABG@PSOP44 [ (SA638) ]  
 HY29F800ABT@TSOP48 [ (SA247-B005) ]  
 HY29F800ATG@PSOP44 [ (SA638) ]  
 HY29F800ATT@TSOP48 [ (SA247-B005) ]  
 HY29F800BG@PSOP44 [ (SA638) ]                      HY29F800BT@TSOP48 [ (SA247-  
 B005) ]  
 HY29F800TG@PSOP44 [ (SA638) ]                      HY29F800TT@TSOP48 [ (SA247-  
 B005) ]  
 HY29LV160BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29LV160BT@TSOP48 [ (SA247-B005) ]  
 HY29LV160TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29LV160TT@TSOP48 [ (SA247-B005) ]  
 HY29LV320BF@FBGA48 [ (SA642E-B026A-T072F001) ]  
 HY29LV320BF@FBGA63 [ (SA642E-B026A-T072F001) ]  
 HY29LV320BT@TSOP48 [ (SA247-B005) ]  
 HY29LV320TF@FBGA48 [ (SA642E-B026A-T072F001) ]  
 HY29LV320TF@FBGA63 [ (SA642E-B026A-T072F001) ]  
 HY29LV320TT@TSOP48 [ (SA247-B005) ]  
 HY29LV400BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29LV400BT@TSOP48 [ (SA247-B005) ]  
 HY29LV400TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29LV400TT@TSOP48 [ (SA247-B005) ]  
 HY29LV800BF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29LV800BG@PSOP44 [ (SA638) ]  
 HY29LV800BT@TSOP48 [ (SA247-B005) ]  
 HY29LV800TF@FBGA48 [ (SA642F-B026A-T064F001) ]  
 HY29LV800TG@PSOP44 [ (SA638) ]  
 HY29LV800TT@TSOP48 [ (SA247-B005) ]  
 HY93C46    HY93C46@SOIC8  
 [ (SA602A) ]  
 HY93C56    HY93C56@SOIC8  
 [ (SA602A) ]  
 HY93C66    HY93C66@SOIC8  
 [ (SA602A) ]  
 HY93C76    HY93C76@SOIC8  
 [ (SA602A) ]  
 HY93C86    HY93C86@SOIC8  
 [ (SA602A) ]  
 HYC0SEH0AF3P@FBGA137 [ (SA700E-B153A-M137F001Y) ]  
 HYC0SEH0MF3P@FBGA137 [ (SA700E-B153A-M137F001Y) ]  
 HYC0UEE0MF2P@FBGA107 [ (SA642V-B133-T096F001Y) ]

HYC0UEF0AF3P@FBGA137 [(SA700E-B153A-M137F001Y)]  
 HYC0UEF0MF3P@FBGA137 [(SA700E-B153A-M137F001Y)]  
 HYC0UEH0MF3P@FBGA137 [(SA700E-B153A-M137F001Y)]  
 HYD0SFE0BF1P@BGA149 [(SA700I-B308-T149F001Y)]  
 HYD0SFG0MF1P@BGA149 [(SA700I-B308-T149F001Y)]  
 HYG0SEG0MF2P@FBGA107 [(SA642V-B133-T096F001Y)]  
 HYG0SGH0MF3P@FBGA137 [(SA700E-B153A-M137F001Y)]  
 HYG0SGJ0MF3P@FBGA137 [(SA700E-B153A-M137F001Y)]  
 HYG0UEG0MF2P@FBGA107 [(SA642V-B133-T096F001Y)]  
 HYG0UGH0MF3P@FBGA137 [(SA700E-B153A-M137F001Y)]  
 HYH0SSJ0MF3P@FBGA137 [(SA700E-B327A-M137F001Y)]  
 HYI0UGG0AF1P@FBGA149 [(SA700I-B295-T149F001Y)]  
 HYI0UIJ0MF3P@FBGA137 [(SA700E-B153A-M137F001Y)]

## DRAM & SRAM

HY62256A [(SA643)]	HY62256A@TSOP28
HY6264A [(SA643)]	HY6264A@TSOP28
HY628100A [(SA438T)]	HY628100A@SOP32
HY628100A@TSOP32 [(SA410T)]	
HY628100B HY628100B@SOP32 [(SA438T)]	HY628100B@TSOP32
HY628400 [(SA438T)]	HY628400@SOP32
HY628400@TSOP32 [(SA410T)]	
HY628400A HY628400A@SOP32 [(SA438T)]	HY628400A@TSOP32
HY62CT08081E [(SA438T)]	HY62CT08081E@SOP28
HY62CT08081E@TSOP28 [(SA643)]	
HY62KT08081E HY62KT08081E@SOP28 [(SA438T)]	HY62KT08081E@TSOP28
HY62U8100B [(SA438T)]	HY62U8100B@SOP32
HY62U8100B@TSOP32 [(SA410T)]	
HY62U8200B	

HY62U8200B@SOP32 [(SA438T)]  
[(SA410T)]  
HY62U8400A  
[(SA438T)]  
HY62U8400A@TSOP32 [(SA410T)]  
HY62UT08081E  
HY62UT08081E@SOP28 [(SA438T)]  
[(SA643)]  
HY62V8100B  
[(SA438T)]  
HY62V8100B@TSOP32 [(SA410T)]  
HY62V8200B  
HY62V8200B@SOP32 [(SA438T)]  
[(SA410T)]  
HY62V8400A  
[(SA438T)]  
HY62V8400A@TSOP32 [(SA410T)]  
HY62VT08081E  
HY62VT08081E@SOP28 [(SA438T)]  
[(SA643)]  
HY62WT08081E  
[(SA438T)]  
HY62WT08081E@TSOP28 [(SA643)]

HY62U8200B@TSOP32  
  
HY62U8400A@SOP32  
  
HY62UT08081E@TSOP28  
  
HY62V8100B@SOP32  
  
HY62V8200B@TSOP32  
  
HY62V8400A@SOP32  
  
HY62VT08081E@TSOP28  
  
HY62WT08081E@SOP28

## MICROCONTROLLER

GMS97C1051  
[(SA404)]  
GMS97C2051  
[(SA404)]  
GMS97C51  
[(SA244)]  
GMS97C51@TQFP44 [(SA245A)]  
GMS97C52  
GMS97C52@PLCC44 [(SA244)]  
[(SA245A)]  
GMS97C54  
[(SA244)]  
GMS97C54@TQFP44 [(SA245A)]  
GMS97C56  
GMS97C56@PLCC44 [(SA244)]  
[(SA245A)]

GMS97C1051@SOIC20  
  
GMS97C2051@SOIC20  
  
GMS97C51@PLCC44  
  
GMS97C52@TQFP44  
  
GMS97C54@PLCC44  
  
GMS97C56@TQFP44

GMS97C58 [ ( SA244 ) ]	GMS97C58@PLCC44
GMS97C58@TQFP44 [ ( SA245A ) ]	
GMS97L1051 GMS97L1051@SOIC20 [ ( SA404 ) ]	
GMS97L2051 GMS97L2051@SOIC20 [ ( SA404 ) ]	
GMS97L51 GMS97L51@PLCC44 [ ( SA244 ) ]	GMS97L51@TQFP44
[ ( SA245A ) ]	
GMS97L52 [ ( SA244 ) ]	GMS97L52@PLCC44
GMS97L52@TQFP44 [ ( SA245A ) ]	
GMS97L54 GMS97L54@PLCC44 [ ( SA244 ) ]	GMS97L54@TQFP44
[ ( SA245A ) ]	
GMS97L56 [ ( SA244 ) ]	GMS97L56@PLCC44
GMS97L56@TQFP44 [ ( SA245A ) ]	
GMS97L58 GMS97L58@PLCC44 [ ( SA244 ) ]	GMS97L58@TQFP44
[ ( SA245A ) ]	
GMS99C52 [ ( SA244 ) ]	GMS99C52@PLCC44
GMS99C52@TQFP44 [ ( SA245A ) ]	
GMS99C58 GMS99C58@PLCC44 [ ( SA244 ) ]	GMS99C58@TQFP44
[ ( SA245A ) ]	
HMS99C52 [ ( SA244 ) ]	HMS99C52@PLCC44
HMS99C52@TQFP44 [ ( SA245A ) ]	
HMS99C58 HMS99C58@PLCC44 [ ( SA244 ) ]	HMS99C58@TQFP44
[ ( SA245A ) ]	

## **HYNIX-CUSTOMER**

### **E ( E ) PROM / FRAM / NVRAM**

HY27UF081G2A ( DD ) @ TSOP48 [ ( SA247 - B005 ) ]  
HY27UF081G2A ( DD5 ) @ TSOP48 [ ( SA247 + B005 ) ]  
HY27UF081G2A ( MLT ) @ TSOP48 [ ( SA247 - B005 ) ]

HY27UF081G2A(TZ)@TSOP48 [(SA247-B005)]  
HY27UF081G2A(ZX)@TSOP48 [(SA247-B005)]  
HY27UF082G2A(MLT)@TSOP48 [(SA247-B005)]  
HY27UF082G2M(ZX)@TSOP48 [(SA247-B005)]  
HY27UG088G5M(KD)@TSOP48 [(SA247+B005)]  
HY27UG088G5M(MLT)@TSOP48 [(SA247-B005)]  
HY27US08121A(ASUS)@TSOP48 [(SA247-B005)]  
HY27US08121A(DD)@TSOP48 [(SA247-B005)]  
HY27US08121A(MLTATL)@TSOP48 [(SA247-B005)]  
HY27US08121A(XJ)@TSOP48 [(SA247-B005)]  
HY27US08121B(LG)@TSOP48 [(SA247-B005)]  
HY27US08281A(WS)@TSOP48 [(SA247-B005)]  
HY27UT088G2M(OMB)@TSOP48 [(SA247-B005)]

## HYUNDAI

### E ( E ) PROM / FRAM / NVRAM

HY2764  
HY27C64A  
HY29DL162BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DL162BT@TSOP48 [(SA247-B005)]  
HY29DL162TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DL162TT@TSOP48 [(SA247-B005)]  
HY29DL163BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DL163BT@TSOP48 [(SA247-B005)]  
HY29DL163TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DL163TT@TSOP48 [(SA247-B005)]  
HY29DS162BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DS162BT@TSOP48 [(SA247-B005)]  
HY29DS162TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DS162TT@TSOP48 [(SA247-B005)]  
HY29DS163BF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DS163BT@TSOP48 [(SA247-B005)]  
HY29DS163TF@FBGA48 [(SA642F-B026A-T064F001)]  
HY29DS163TT@TSOP48 [(SA247-B005)]  
HY29F002T HY29F002T@PLCC32  
[(SA015A1T)]  
HY29F002T@TSOP32 [(SA410T)]  
HY29F040  
HY29F040@PLCC32 [(SA015A1T)] HY29F040@TSOP32  
[(SA410T)]

HY29F040A [ (SA015A1T) ]	HY29F040A@PLCC32
HY29F040A@TSOP32 [ (SA410T) ] [ (SA409T) ]	HY29F080@TSOP40
HY29F200B@PSOP44 [ (SA638-B006) ] B005) ]	HY29F200B@TSOP48 [ (SA247-
HY29F200T@PSOP44 [ (SA638-B006) ] B005) ]	HY29F200T@TSOP48 [ (SA247-
HY29F400ABG@PSOP44 [ (SA638) ]	
HY29F400ABT@TSOP48 [ (SA247-B005) ]	
HY29F400ATG@PSOP44 [ (SA638) ]	
HY29F400ATT@TSOP48 [ (SA247-B005) ]	
HY29F400BG@PSOP44 [ (SA638) ] B005) ]	HY29F400BT@TSOP48 [ (SA247-
HY29F400TG@PSOP44 [ (SA638) ] B005) ]	HY29F400TT@TSOP48 [ (SA247-
HY29F800ABG@PSOP44 [ (SA638) ]	
HY29F800ABT@TSOP48 [ (SA247-B005) ]	
HY29F800ATG@PSOP44 [ (SA638) ]	
HY29F800ATT@TSOP48 [ (SA247-B005) ]	
HY29F800BG@PSOP44 [ (SA638) ] B005) ]	HY29F800BT@TSOP48 [ (SA247-
HY29F800TG@PSOP44 [ (SA638) ] B005) ]	HY29F800TT@TSOP48 [ (SA247-
HY29LV160BF@FBGA48 [ (SA642F-B026A-T064F001) ]	
HY29LV160BT@TSOP48 [ (SA247-B005) ]	
HY29LV160TF@FBGA48 [ (SA642F-B026A-T064F001) ]	
HY29LV160TT@TSOP48 [ (SA247-B005) ]	
HY29LV320BF@FBGA48 [ (SA642E-B026A-T072F001) ]	
HY29LV320BF@FBGA63 [ (SA642E-B026A-T072F001) ]	
HY29LV320BT@TSOP48 [ (SA247-B005) ]	
HY29LV320TF@FBGA48 [ (SA642E-B026A-T072F001) ]	
HY29LV320TF@FBGA63 [ (SA642E-B026A-T072F001) ]	
HY29LV320TT@TSOP48 [ (SA247-B005) ]	
HY29LV400BF@FBGA48 [ (SA642F-B026A-T064F001) ]	
HY29LV400BT@TSOP48 [ (SA247-B005) ]	
HY29LV400TF@FBGA48 [ (SA642F-B026A-T064F001) ]	
HY29LV400TT@TSOP48 [ (SA247-B005) ]	
HY29LV800BF@FBGA48 [ (SA642F-B026A-T064F001) ]	
HY29LV800BG@PSOP44 [ (SA638) ]	
HY29LV800BT@TSOP48 [ (SA247-B005) ]	
HY29LV800TF@FBGA48 [ (SA642F-B026A-T064F001) ]	
HY29LV800TG@PSOP44 [ (SA638) ]	

HY29LV800TT@TSOP48 [ (SA247-B005) ]  
 HY93C46  
 [ (SA602A) ]  
 HY93C56  
 [ (SA602A) ]  
 HY93C66  
 [ (SA602A) ]  
 HY93C76  
 [ (SA602A) ]  
 HY93C86  
 [ (SA602A) ]

HY93C46@SOIC8  
 HY93C56@SOIC8  
 HY93C66@SOIC8  
 HY93C76@SOIC8  
 HY93C86@SOIC8

## DRAM & SRAM

HY62256A  
 [ (SA643) ]  
 HY6264A  
 [ (SA643) ]  
 HY628100A  
 [ (SA438T) ]  
 HY628100A@TSOP32 [ (SA410T) ]  
 HY628100B  
 HY628100B@SOP32 [ (SA438T) ]  
 [ (SA410T) ]  
 HY628400  
 [ (SA438T) ]  
 HY628400@TSOP32 [ (SA410T) ]  
 HY628400A  
 HY628400A@SOP32 [ (SA438T) ]  
 [ (SA410T) ]  
 HY62CT08081E  
 [ (SA438T) ]  
 HY62CT08081E@TSOP28 [ (SA643) ]  
 HY62KT08081E  
 HY62KT08081E@SOP28 [ (SA438T) ]  
 [ (SA643) ]  
 HY62U8100B  
 [ (SA438T) ]  
 HY62U8100B@TSOP32 [ (SA410T) ]  
 HY62U8200B  
 HY62U8200B@SOP32 [ (SA438T) ]  
 [ (SA410T) ]

HY62256A@TSOP28  
 HY6264A@TSOP28  
 HY628100A@SOP32  
 HY628100B@TSOP32  
 HY628400@SOP32  
 HY628400A@TSOP32  
 HY62CT08081E@SOP28  
 HY62KT08081E@TSOP28  
 HY62U8100B@SOP32  
 HY62U8200B@TSOP32

HY62U8400A  
[ (SA438T) ]  
HY62U8400A@TSOP32 [ (SA410T) ]  
HY62UT08081E  
HY62UT08081E@SOP28 [ (SA438T) ]  
[ (SA643) ]  
HY62V8100B  
[ (SA438T) ]  
HY62V8100B@TSOP32 [ (SA410T) ]  
HY62V8200B  
HY62V8200B@SOP32 [ (SA438T) ]  
[ (SA410T) ]  
HY62V8400A  
[ (SA438T) ]  
HY62V8400A@TSOP32 [ (SA410T) ]  
HY62VT08081E  
HY62VT08081E@SOP28 [ (SA438T) ]  
[ (SA643) ]  
HY62WT08081E  
[ (SA438T) ]  
HY62WT08081E@TSOP28 [ (SA643) ]

HY62U8400A@SOP32  
  
HY62UT08081E@TSOP28  
  
HY62V8100B@SOP32  
  
HY62V8200B@TSOP32  
  
HY62V8400A@SOP32  
  
HY62VT08081E@TSOP28  
  
HY62WT08081E@SOP28

## MICROCONTROLLER

GMS97C1051  
[ (SA404) ]  
GMS97C2051  
[ (SA404) ]  
GMS97C51  
[ (SA244) ]  
GMS97C51@TQFP44 [ (SA245A) ]  
GMS97C52  
GMS97C52@PLCC44 [ (SA244) ]  
[ (SA245A) ]  
GMS97C54  
[ (SA244) ]  
GMS97C54@TQFP44 [ (SA245A) ]  
GMS97C56  
GMS97C56@PLCC44 [ (SA244) ]  
[ (SA245A) ]  
GMS97C58  
[ (SA244) ]

GMS97C1051@SOIC20  
  
GMS97C2051@SOIC20  
  
GMS97C51@PLCC44  
  
GMS97C52@TQFP44  
  
GMS97C54@PLCC44  
  
GMS97C56@TQFP44  
  
GMS97C58@PLCC44



GMS97C58@TQFP44 [(SA245A)]	
GMS97L1051	
GMS97L1051@SOIC20 [(SA404)]	
GMS97L2051	
GMS97L2051@SOIC20 [(SA404)]	
GMS97L51	
GMS97L51@PLCC44 [(SA244)]	GMS97L51@TQFP44
[(SA245A)]	
GMS97L52	GMS97L52@PLCC44
[(SA244)]	
GMS97L52@TQFP44 [(SA245A)]	
GMS97L54	
GMS97L54@PLCC44 [(SA244)]	GMS97L54@TQFP44
[(SA245A)]	
GMS97L56	GMS97L56@PLCC44
[(SA244)]	
GMS97L56@TQFP44 [(SA245A)]	
GMS97L58	
GMS97L58@PLCC44 [(SA244)]	GMS97L58@TQFP44
[(SA245A)]	
GMS99C52	GMS99C52@PLCC44
[(SA244)]	
GMS99C52@TQFP44 [(SA245A)]	
GMS99C58	
GMS99C58@PLCC44 [(SA244)]	GMS99C58@TQFP44
[(SA245A)]	
HMS99C52	HMS99C52@PLCC44
[(SA244)]	
HMS99C52@TQFP44 [(SA245A)]	
HMS99C58	
HMS99C58@PLCC44 [(SA244)]	HMS99C58@TQFP44
[(SA245A)]	

## ICE

### E (E) PROM/FRAM/NVRAM

ICE25P05	ICE25P05@SOIC8
[(SA602A)]	
ICE27C010	ICE27C010@PLCC32
[(SA015A1T)]	
ICE27C010@TSOP32 [(SA410T)]	

ICE27C020	
ICE27C020@PLCC32 [(SA015A1T)]	ICE27C020@TSOP32
[(SA410T)]	
ICE27C512	ICE27C512@PLCC32
[(SA015A1T)]	
ICE27C512@TSOP28 [(SA430T)]	
ICE27LC010	
ICE27LC010@PLCC32 [(SA015A1T)]	ICE27LC010@TSOP32
[(SA410T)]	
ICE27LC020	ICE27LC020@PLCC32
[(SA015A1T)]	
ICE27LC020@TSOP32 [(SA410T)]	
ICE27LC512	
ICE27LC512@PLCC32 [(SA015A1T)]	ICE27LC512@TSOP28
[(SA430T)]	
ICE28LF010	ICE28LF010@PLCC32
[(SA015A1T)]	
ICE37C512	ICE37C512@PLCC32
[(SA015A1T)]	
ICE37C512@TSOP32 [(SA410T)]	
ICE37LC512	
ICE37LC512@PLCC32 [(SA015A1T)]	ICE37LC512@TSOP32
[(SA410T)]	

## ICMIC

### E (E) PROM/FRAM/NVRAM

X76F101	X76F101@SOIC8
[(SA602A)]	
X76F400@SOIC8 [(SA602A)]	X76F400@TSSOP8
[(SA026)]	

## ICSI

### E (E) PROM/FRAM/NVRAM

IC71V08F32AS04@FBGA64 [(SA642A-B032A-Y096F001)]	
IC71V08F32AS04@FBGA73 [(SA642A-B032A-Y096F001)]	
IC71V08F32AS08@FBGA64 [(SA642A-B032A-Y096F001)]	

IC71V08F32AS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32BS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32BS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32BS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32BS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32CS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32CS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32CS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32CS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32DS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32DS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32DS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32DS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32ES04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32ES04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32ES08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32ES08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32FS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32FS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32FS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V08F32FS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32AS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32AS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32AS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32AS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32BS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32BS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32BS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32BS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32CS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32CS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32CS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32CS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32DS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32DS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32DS08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32DS08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32ES04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32ES04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32ES08@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32ES08@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32FS04@FBGA64 [ ( SA642A-B032A-Y096F001 ) ]  
IC71V16F32FS04@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]

IC71V16F32FS08@FBGA64 [ (SA642A-B032A-Y096F001) ]  
 IC71V16F32FS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IC71V16F32GS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IC71V16F32GS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IC71V16F32HS04@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IC71V16F32HS08@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IC71V16F64IP16@FBGA73 [ (SA642A-B032A-Y096F001) ]  
 IC71V16F64IS08@FBGA73 [ (SA642A-B032A-Y096F001) ]

## MICROCONTROLLER

IC89LV51A [ (SA244) ]	IC89LV51A@PLCC44
IC89LV51A@TQFP44 [ (SA245A) ]	
IC89LV52A IC89LV52A@PLCC44 [ (SA244) ] [ (SA245A) ]	IC89LV52A@TQFP44
IS89C51A [ (SA244) ]	IS89C51A@PLCC44
IS89C51A@TQFP44 [ (SA245A) ]	
IS89C52A IS89C52A@PLCC44 [ (SA244) ] [ (SA245A) ]	IS89C52A@TQFP44
IS89C54 [ (SA244) ]	IS89C54@PLCC44
IS89C54@TQFP44 [ (SA245A) ]	
IS89C58 IS89C58@PLCC44 [ (SA244) ] [ (SA245A) ]	IS89C58@TQFP44
IS89C64 [ (SA244) ]	IS89C64@PLCC44
IS89C64@TQFP44 [ (SA245A) ]	
IS89E54 IS89E54@PLCC44 [ (SA244) ] [ (SA245A) ]	IS89E54@TQFP44
IS89E58 [ (SA244) ]	IS89E58@PLCC44
IS89E58@TQFP44 [ (SA245A) ]	
IS89E64 IS89E64@PLCC44 [ (SA244) ] [ (SA245A) ]	IS89E64@TQFP44

**ICT****E (E) PROM/FRAM/NVRAM**

27CX010	27CX010@PLCC32
[ (SA015A1T) ]	
27CX010@TSOP32 [ (SA410T) ]	
27CX161	
27CX162	
27CX256	
27CX321	
27CX322	
27CX641	
27CX642	
93C46	93C46@SOIC8
[ (SA602A) ]	
93C46A	93C46A@SOIC8
[ (SA602A) ]	
93C56A	93C56A@SOIC8
[ (SA602A) ]	
93C66A	93C66A@SOIC8
[ (SA602A) ]	
93CX46	93CX46@SOIC8
[ (SA602A) ]	
93CX56	93CX56@SOIC8
[ (SA602A) ]	
93CX66	93CX66@SOIC8
[ (SA602A) ]	

**PLD**

PA7024	PA7024 (J) @PLCC28
[ (SA008A) ]	
PA7024 (JN) @PLCC28 [ (SA008A) ]	PA7024@SOIC24
[ (SA404) ]	
PA7128	PA7128@PLCC28
[ (SA008A) ]	
PA7128@SOIC28 [ (SA404) ]	
PA7140	
PA7140@PLCC44 [ (SA244) ]	PA7140@TQFP44
[ (SA245A) ]	

PA7536	PA7536@PLCC28
[ (SA008A) ]	
PA7536@SOIC28 [ (SA404) ]	
PA7540	
PA7540(J)@PLCC28 [ (SA008A) ]	PA7540(JN)@PLCC28
[ (SA008A) ]	
PA7572	PA7572@PLCC44
[ (SA244) ]	
PA7572@TQFP44 [ (SA245A) ]	
PEEL18CV8Z	
PEEL18CV8Z@PLCC20 [ (SA001A) ]	PEEL18CV8Z@SOIC20
[ (SA404) ]	
PEEL18CV8Z@TSOP20 [ (SA026) ]	
PEEL18LV8Z	
PEEL18LV8Z@PLCC20 [ (SA001A) ]	PEEL18LV8Z@SOIC20
[ (SA404) ]	
PEEL18LV8Z@TSOP20 [ (SA026) ]	
PEEL22CV10	
PEEL22CV10@PLCC28 [ (SA008A) ]	
PEEL22CV10A	
PEEL22CV10A@PLCC28 [ (SA008A) ]	PEEL22CV10A@SOIC24
[ (SA404) ]	
PEEL22CV10A@TSOP24 [ (SA026) ]	PEEL22CV10A
+	
PEEL22CV10A+@PLCC28 [ (SA008A) ]	PEEL22CV10A+@SOIC24
[ (SA404) ]	
PEEL22CV10A+@TSOP24 [ (SA026) ]	PEEL22CV10A+
+	
PEEL22CV10A++@PLCC28 [ (SA008A) ]	PEEL22CV10A++@SOIC24
[ (SA404) ]	
PEEL22CV10A++@TSOP24 [ (SA026) ]	
PEEL22CV10AZ	
PEEL22CV10AZ@PLCC28 [ (SA008A) ]	PEEL22CV10AZ@SOIC24
[ (SA404) ]	
PEEL22CV10AZ@TSOP24 [ (SA026) ]	PEEL22CV10AZ
+	
PEEL22CV10AZ+@PLCC28 [ (SA008A) ]	PEEL22CV10AZ+@SOIC24
[ (SA404) ]	
PEEL22CV10AZ+@TSOP24 [ (SA026) ]	PEEL22CV10AZ+
+	
PEEL22CV10AZ++@PLCC28 [ (SA008A) ]	PEEL22CV10AZ++@SOIC24
[ (SA404) ]	
PEEL22CV10AZ++@TSOP24 [ (SA026) ]	

PEEL22LV10AZ

PEEL22LV10AZ@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22LV10AZ@TSOP24 [(SA026)]

+

PEEL22LV10AZ+@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22LV10AZ+@TSOP24 [(SA026)]

+

PEEL22LV10AZ++@PLCC28 [(SA008A)]  
[(SA404)]

PEEL22LV10AZ++@TSOP24 [(SA026)]

PEEL22LV10AZ@SOIC24

PEEL22LV10AZ

PEEL22LV10AZ+@SOIC24

PEEL22LV10AZ+

PEEL22LV10AZ++@SOIC24

## IMT

### E ( E ) PROM / FRAM / NVRAM

IM29F001B

[(SA015A1T)]

IM29F001B@TSOP32 [(SA410T)]

[(SA620)]

IM29F001T

[(SA015A1T)]

IM29F001T@TSOP32 [(SA410T)]

[(SA620)]

IM29F002B

[(SA015A1T)]

IM29F002B@TSOP32 [(SA410T)]

[(SA620)]

IM29F002T

[(SA015A1T)]

IM29F002T@TSOP32 [(SA410T)]

[(SA620)]

IM29F004B

[(SA015A1T)]

IM29F004B@TSOP32 [(SA410T)]

[(SA620)]

IM29F004T

[(SA015A1T)]

IM29F004T@TSOP32 [(SA410T)]

[(SA620)]

IM29LV004B

IM29F001B@PLCC32

IM29F001B@VSOP32

IM29F001T@PLCC32

IM29F001T@VSOP32

IM29F002B@PLCC32

IM29F002B@VSOP32

IM29F002T@PLCC32

IM29F002T@VSOP32

IM29F004B@PLCC32

IM29F004B@VSOP32

IM29F004T@PLCC32

IM29F004T@VSOP32

IM29LV004B@PLCC32

[ (SA015A1T) ]	
IM29LV004B@TSOP32 [ (SA410T) ]	IM29LV004B@VSOP32
[ (SA620) ]	
IM29LV004T	IM29LV004T@PLCC32
[ (SA015A1T) ]	
IM29LV004T@TSOP32 [ (SA410T) ]	IM29LV004T@VSOP32
[ (SA620) ]	
IM29LV400B@PSOP44 [ (SA638) ]	IM29LV400B@TSOP48 [ (SA247- B005) ]
IM29LV400T@PSOP44 [ (SA638) ]	IM29LV400T@TSOP48 [ (SA247- B005) ]

## INFINEON

### MICROCONTROLLER

SAF-XC846-1FR@TSSOP38 [ (SA693) ]

SAF-XC856CLM-13FFI@QFP64 (\*) [ (SA732+B227) ]

SAF-XC856CLM-16FFI@QFP64 (\*) [ (SA732+B227) ]

SAF-XC856CLM-9FFI@QFP64 (\*) [ (SA732+B227) ]

SAF-XC856LM-13FFI@QFP64 (\*) [ (SA732+B227) ]

SAF-XC856LM-16FFI@QFP64 (\*) [ (SA732+B227) ]

SAF-XC856LM-9FFI@QFP64 (\*) [ (SA732+B227) ]

SAF-XC866-1FR@TSSOP38 [ (SA693) ]

SAF-XC866-2FR(A STEP)@TSSOP38 [ (SA693) ]

SAF-XC866-2FR(BB STEP)@TSSOP38 [ (SA693) ]

SAF-XC866-4FR(A STEP)@TSSOP38 [ (SA693) ]

SAF-XC866-4FR(BB STEP)@TSSOP38 [ (SA693) ]

SAF-XC866L-2FR(A STEP)@TSSOP38 [ (SA693) ]

SAF-XC866L-2FR(BB STEP)@TSSOP38 [ (SA693) ]

SAF-XC866L-4FR(A STEP)@TSSOP38 [ (SA693) ]

SAF-XC866L-4FR(BB STEP)@TSSOP38 [ (SA693) ]

SAF-XC878-13FFI(3.3v)@QFP64 (\*) [ (SA732+B227) ]

SAF-XC878-13FFI(5v)@QFP64 (\*) [ (SA732+B227) ]

SAF-XC878-16FFI(3.3v)@QFP64 (\*) [ (SA732+B227) ]

SAF-XC878-16FFI(5v)@QFP64 (\*) [ (SA732+B227) ]

SAF-XC878CM-13FFI(3.3v)@QFP64 (\*) [ (SA732+B227) ]

SAF-XC878CM-13FFI(5v)@QFP64 (\*) [ (SA732+B227) ]

SAF-XC878CM-16FFI(3.3v)@QFP64 (\*) [ (SA732+B227) ]

SAF-XC878CM-16FFI(5v)@QFP64 (\*) [ (SA732+B227) ]

SAF-XC878M-13FFI(3.3v)@QFP64 (\*) [ (SA732+B227) ]

SAF-XC878M-13FFI(5v)@QFP64 (\*) [ (SA732+B227) ]



SAF-XC878M-16FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC878M-16FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC886-6FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886-6FFA(5v)@QFP48 [(SA248)]  
SAF-XC886-6FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886-6FFI(5v)@QFP48 [(SA248)]  
SAF-XC886-8FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886-8FFA(5v)@QFP48 [(SA248)]  
SAF-XC886-8FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886-8FFI(5v)@QFP48 [(SA248)]  
SAF-XC886C-6FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886C-6FFA(5v)@QFP48 [(SA248)]  
SAF-XC886C-6FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886C-6FFI(5v)@QFP48 [(SA248)]  
SAF-XC886C-8FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886C-8FFA(5v)@QFP48 [(SA248)]  
SAF-XC886C-8FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886C-8FFI(5v)@QFP48 [(SA248)]  
SAF-XC886CLM-6FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886CLM-6FFA(5v)@QFP48 [(SA248)]  
SAF-XC886CLM-6FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886CLM-6FFI(5v)@QFP48 [(SA248)]  
SAF-XC886CLM-8FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886CLM-8FFA(5v)@QFP48 [(SA248)]  
SAF-XC886CLM-8FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886CLM-8FFI(5v)@QFP48 [(SA248)]  
SAF-XC886CM-6FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886CM-6FFA(5v)@QFP48 [(SA248)]  
SAF-XC886CM-6FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886CM-6FFI(5v)@QFP48 [(SA248)]  
SAF-XC886CM-8FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886CM-8FFA(5v)@QFP48 [(SA248)]  
SAF-XC886CM-8FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886CM-8FFI(5v)@QFP48 [(SA248)]  
SAF-XC886LM-6FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886LM-6FFA(5v)@QFP48 [(SA248)]  
SAF-XC886LM-6FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886LM-6FFI(5v)@QFP48 [(SA248)]  
SAF-XC886LM-8FFA(3.3v)@QFP48 [(SA248)]  
SAF-XC886LM-8FFA(5v)@QFP48 [(SA248)]  
SAF-XC886LM-8FFI(3.3v)@QFP48 [(SA248)]  
SAF-XC886LM-8FFI(5v)@QFP48 [(SA248)]  
SAF-XC888-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]

SAF-XC888-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888C-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CLM-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888CM-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAF-XC888LM-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC846-1FR@TSSOP38 [(SA693)]           SAK-XC866-1FR@TSSOP38  
[(SA693)]  
SAK-XC866-2FR(A STEP)@TSSOP38 [(SA693)]  
SAK-XC866-2FR(BB STEP)@TSSOP38 [(SA693)]

SAK-XC866-4FR(A STEP)@TSSOP38 [(SA693)]  
SAK-XC866-4FR(BB STEP)@TSSOP38 [(SA693)]  
SAK-XC866L-2FR(A STEP)@TSSOP38 [(SA693)]  
SAK-XC866L-2FR(BB STEP)@TSSOP38 [(SA693)]  
SAK-XC866L-4FR(A STEP)@TSSOP38 [(SA693)]  
SAK-XC866L-4FR(BB STEP)@TSSOP38 [(SA693)]  
SAK-XC886-6FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886-6FFA(5v)@QFP48 [(SA248)]  
SAK-XC886-6FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886-6FFI(5v)@QFP48 [(SA248)]  
SAK-XC886-8FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886-8FFA(5v)@QFP48 [(SA248)]  
SAK-XC886-8FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886-8FFI(5v)@QFP48 [(SA248)]  
SAK-XC886C-6FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886C-6FFA(5v)@QFP48 [(SA248)]  
SAK-XC886C-6FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886C-6FFI(5v)@QFP48 [(SA248)]  
SAK-XC886C-8FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886C-8FFA(5v)@QFP48 [(SA248)]  
SAK-XC886C-8FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886C-8FFI(5v)@QFP48 [(SA248)]  
SAK-XC886CLM-6FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886CLM-6FFA(5v)@QFP48 [(SA248)]  
SAK-XC886CLM-6FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886CLM-6FFI(5v)@QFP48 [(SA248)]  
SAK-XC886CLM-8FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886CLM-8FFA(5v)@QFP48 [(SA248)]  
SAK-XC886CLM-8FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886CLM-8FFI(5v)@QFP48 [(SA248)]  
SAK-XC886CM-6FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886CM-6FFA(5v)@QFP48 [(SA248)]  
SAK-XC886CM-6FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886CM-6FFI(5v)@QFP48 [(SA248)]  
SAK-XC886CM-8FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886CM-8FFA(5v)@QFP48 [(SA248)]  
SAK-XC886CM-8FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886CM-8FFI(5v)@QFP48 [(SA248)]  
SAK-XC886LM-6FFA(3.3v)@QFP48 [(SA248)]  
SAK-XC886LM-6FFA(5v)@QFP48 [(SA248)]  
SAK-XC886LM-6FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886LM-6FFI(5v)@QFP48 [(SA248)]  
SAK-XC886LM-8FFA(3.3v)@QFP48 [(SA248)]

SAK-XC886LM-8FFA(5v)@QFP48 [(SA248)]  
SAK-XC886LM-8FFI(3.3v)@QFP48 [(SA248)]  
SAK-XC886LM-8FFI(5v)@QFP48 [(SA248)]  
SAK-XC888-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888C-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888C-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888C-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888C-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888C-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888C-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888C-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888C-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CLM-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CLM-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CLM-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CLM-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CLM-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CLM-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CLM-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CLM-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CM-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CM-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CM-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CM-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CM-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CM-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CM-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888CM-8FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888LM-6FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888LM-6FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888LM-6FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888LM-6FFI(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888LM-8FFA(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888LM-8FFA(5v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888LM-8FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
SAK-XC888LM-8FFI(5v)@QFP64(\*) [(SA732+B227)]

SAX-XC878-13FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878-13FFI(5v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878-16FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878-16FFI(5v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878C-13FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878C-13FFI(5v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878C-16FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878C-16FFI(5v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878CM-13FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878CM-13FFI(5v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878CM-16FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878CM-16FFI(5v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878L-13FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878L-13FFI(5v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878L-16FFI(3.3v)@QFP64(\*) [(SA732+B227)]  
 SAX-XC878L-16FFI(5v)@QFP64(\*) [(SA732+B227)]

## INTEL

### E(E) PROM/FRAM/NVRAM

27010	27010@PLCC32
[(SA015A1T)]	
27010@TSOP32 [(SA410T)]	
27128	
27128A	
27128B	
2716	
27210	
27256	
2732	
2732A	
27512	
2764	
2764A	
27C010	27C010@PLCC32
[(SA015A1T)]	
27C010@TSOP32 [(SA410T)]	
27C010A	
27C010A@PLCC32 [(SA015A1T)]	27C010A@TSOP32
[(SA410T)]	
27C020	27C020@PLCC32

[ (SA015A1T) ]  
27C020@TSOP32 [ (SA410T) ]  
27C040  
27C040@PLCC32 [ (SA015A1T) ] 27C040@TSOP32  
[ (SA410T) ]  
27C100 27C100@PLCC32  
[ (SA015A1T) ]  
27C100@TSOP32 [ (SA410T) ]  
27C128  
27C128@PLCC32 [ (SA015A1T) ]  
27C210  
27C210@PLCC44 [ (SA244) ]  
27C220  
27C220@PLCC44 [ (SA244) ]  
27C240  
27C240@PLCC44 [ (SA244) ]  
27C256  
27C256@PLCC32 [ (SA015A1T) ]  
27C400  
27C400@PLCC44 [ (SA244) ]  
27C512  
27C512@PLCC32 [ (SA015A1T) ]  
27C64  
27C64@PLCC32 [ (SA015A1T) ]  
27C800  
27S512  
2816A  
2817A  
2864A  
68C257 68C257@PLCC32  
[ (SA015A1T) ]  
87C256  
87C257  
87C257@PLCC32 [ (SA015A1T) ]  
87C64  
D27011  
D27513  
D27C011  
D27C513  
D28F256  
D28F256A  
D28F512  
DA28F016SA@SSOP56 [ (SA629A-B013) ]

DA28F016SV@SSOP56 [(SA629A-B013)]  
DA28F320J5(low)@SSOP56 [(SA629-B013)]  
DA28F320J5@SSOP56 [(SA629A-B013)]  
DA28F320J5A(low)@SSOP56 [(SA629-B013)]  
DA28F320J5A@SSOP56 [(SA629A-B013)]  
DA28F640J5@SSOP56 [(SA629A-B013)]  
DA28F640J5A@SSOP56 [(SA629A-B013)]  
DD28F032SA@TSOP56 [(SA628-B011)]  
DT28F016SA@SSOP56 [(SA629A-B013)]  
DT28F016SA@TSOP56 [(SA628-B011)]  
DT28F016SV@SSOP56 [(SA629A-B013)]  
DT28F016SV@TSOP56 [(SA628-B011)]  
DT28F160F3B@SSOP56 [(SA629A-B015)]  
DT28F160F3T@SSOP56 [(SA629A-B015)]  
DT28F160S3@SSOP56 [(SA629A-B013)]  
DT28F160S5@SSOP56 [(SA629A-B013)]  
DT28F320J5@SSOP56 [(SA629A-B013)]  
DT28F320J5A@SSOP56 [(SA629A-B013)]  
DT28F320S3@SSOP56 [(SA629A-B013)]  
DT28F320S5@SSOP56 [(SA629A-B013)]  
DT28F640J5@SSOP56 [(SA629A-B013)]  
DT28F640J5A@SSOP56 [(SA629A-B013)]  
DT28F800F3B@SSOP56 [(SA629A-B015)]  
DT28F800F3T@SSOP56 [(SA629A-B015)]  
E28F001BX-B@TSOP32 [(SA410T)] E28F001BX-T@TSOP32  
[(SA410T)]  
E28F002BCT@TSOP40 [(SA409T)] E28F002BEB@TSOP40  
[(SA409T)]  
E28F002BET@TSOP40 [(SA409T)] E28F002BLB@TSOP40  
[(SA409T)]  
E28F002BLT@TSOP40 [(SA409T)] E28F002BVB@TSOP40  
[(SA409T)]  
E28F002BVT@TSOP40 [(SA409T)] E28F002BXB@TSOP40  
[(SA409T)]  
E28F002BXT@TSOP40 [(SA409T)] E28F004B5B@TSOP40  
[(SA409T)]  
E28F004B5T@TSOP40 [(SA409T)] E28F004BEB@TSOP40  
[(SA409T)]  
E28F004BET@TSOP40 [(SA409T)] E28F004BLB@TSOP40  
[(SA409T)]  
E28F004BLT@TSOP40 [(SA409T)] E28F004BVB@TSOP40  
[(SA409T)]  
E28F004BVT@TSOP40 [(SA409T)] E28F004BXB@TSOP40

[ (SA409T) ]	
E28F004BXT@TSOP40 [ (SA409T) ]	E28F004S3@TSOP40
[ (SA409T) ]	
E28F004S5@TSOP40 [ (SA409T) ]	E28F004SC@TSOP40
[ (SA409T) ]	
E28F008BEB@TSOP40 [ (SA409T) ]	E28F008BET@TSOP40
[ (SA409T) ]	
E28F008BLB@TSOP40 [ (SA409T) ]	E28F008BLT@TSOP40
[ (SA409T) ]	
E28F008BVB@TSOP40 [ (SA409T) ]	E28F008BVT@TSOP40
[ (SA409T) ]	
E28F008BXB@TSOP40 [ (SA409T) ]	E28F008BXT@TSOP40
[ (SA409T) ]	
E28F008S3@TSOP40 [ (SA409T) ]	E28F008S5@TSOP40
[ (SA409T) ]	
E28F008SA@TSOP40 [ (SA409T) ]	E28F008SA-L@TSOP40
[ (SA409T) ]	
E28F008SC@TSOP40 [ (SA409T) ]	E28F010@TSOP32
[ (SA410T) ]	
E28F016S3@TSOP40 [ (SA409T) ]	E28F016S5@TSOP40
[ (SA409T) ]	
E28F016SA@TSOP56 [ (SA628-B011) ]	E28F016SC@TSOP40
[ (SA409T) ]	
E28F016SV@TSOP56 [ (SA628-B011) ]	E28F020@TSOP32
[ (SA410T) ]	
E28F128J3A@TSOP56 [ (SA628-B018) ]	E28F200B5B@TSOP48 [ (SA247-
B005) ]	
E28F200B5T@TSOP48 [ (SA247-B005) ]	E28F200BVB@TSOP56 [ (SA628-
B012) ]	
E28F200BVT@TSOP56 [ (SA628-B012) ]	E28F200BXB@TSOP56 [ (SA628-
B012) ]	
E28F200BXT@TSOP56 [ (SA628-B012) ]	E28F200CVB@TSOP48 [ (SA247-
B005) ]	
E28F200CVT@TSOP48 [ (SA247-B005) ]	E28F256@TSOP32
[ (SA410T) ]	
E28F256A@TSOP32 [ (SA410T) ]	E28F320J3A@TSOP56 [ (SA628-
B018) ]	
E28F320J5(low)@TSOP56 [ (SA628-B011) ]	
E28F320J5@TSOP56 [ (SA628-B011) ]	
E28F320J5A(low)@TSOP56 [ (SA628-B011) ]	
E28F320J5A@TSOP56 [ (SA628-B011) ]	E28F400B5B@TSOP48 [ (SA247-
B005) ]	
E28F400B5T@TSOP48 [ (SA247-B005) ]	E28F400BVB@TSOP56 [ (SA628-



B012) ]  
 E28F400BVT@TSOP56 [ (SA628-B012) ]      E28F400BXB@TSOP56 [ (SA628-B012) ]  
 B012) ]  
 E28F400BXT@TSOP56 [ (SA628-B012) ]      E28F400CVB@TSOP48 [ (SA247-B005) ]  
 B005) ]  
 E28F400CVT@TSOP48 [ (SA247-B005) ]      E28F512@TSOP32  
 [ (SA410T) ]  
 E28F640J3A@TSOP56 [ (SA628-B018) ]      E28F800B5B@TSOP48 [ (SA247-B005) ]  
 B005) ]  
 E28F800B5T@TSOP48 [ (SA247-B005) ]      E28F800CEB@TSOP48 [ (SA247-B005) ]  
 B005) ]  
 E28F800CET@TSOP48 [ (SA247-B005) ]      E28F800CVB@TSOP48 [ (SA247-B005) ]  
 B005) ]  
 E28F800CVT@TSOP48 [ (SA247-B005) ]      E82802AA@TSOP40  
 [ (SA409T) ]  
 E82802AB@TSOP40 [ (SA409T) ]      E82802AC@TSOP40  
 [ (SA409T) ]  
 F28F010@TSOP32 [ (SA410T) ]      F28F020@TSOP32  
 [ (SA410T) ]  
 F28F256@TSOP32 [ (SA410T) ]      F28F256A@TSOP32  
 [ (SA410T) ]  
 F28F512@TSOP32 [ (SA410T) ]  
 G28F640J5@uBGA56 [ (SA644A-B028A-Y072F001Y) ]  
 G28F640J5A@uBGA56 [ (SA644A-B028A-Y072F001Y) ]  
 GE28F008B3BA@uBGA48 [ (SA634) ]      GE28F008B3TA@uBGA48  
 [ (SA634) ]  
 GE28F128K18C@FBGA56 [ (SA656D-B085A-T056F001Y) ]  
 GE28F128K3C@FBGA56 [ (SA656D-B085A-T056F001Y) ]  
 GE28F128L18B@VFBGA56 [ (SA644A-B025B-Y072F001) ]  
 GE28F128L18T@VFBGA56 [ (SA644A-B025B-Y072F001) ]  
 GE28F128L30B@VFBGA56 [ (SA644A-B025B-Y072F001) ]  
 GE28F128L30T@VFBGA56 [ (SA644A-B025B-Y072F001) ]  
 GE28F128W18BC(NO EFP)@VFBGA56 [ (SA656A-B085A-Y056F001) ]  
 GE28F128W18BC@VFBGA56 [ (SA656A-B085A-Y056F001) ]  
 GE28F128W18BD(NO EFP)@VFBGA56 [ (SA656E-B085A-W056F001) ]  
 GE28F128W18BD@VFBGA56 [ (SA656E-B085A-W056F001) ]  
 GE28F128W18TC(NO EFP)@VFBGA56 [ (SA656A-B085A-Y056F001) ]  
 GE28F128W18TC@VFBGA56 [ (SA656A-B085A-Y056F001) ]  
 GE28F128W18TD(NO EFP)@VFBGA56 [ (SA656E-B085A-W056F001) ]  
 GE28F128W18TD@VFBGA56 [ (SA656E-B085A-W056F001) ]  
 GE28F128W30BC(NO EFP)@VFBGA56 [ (SA656A-B085A-Y056F001) ]  
 GE28F128W30BC@VFBGA56 [ (SA656A-B085A-Y056F001) ]  
 GE28F128W30BD(NO EFP)@VFBGA56 [ (SA656E-B085A-W056F001) ]

GE28F128W30BD@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W30TC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W30TC@VFBGA56 [(SA656A-B085A-Y056F001)]  
GE28F128W30TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F128W30TD@VFBGA56 [(SA656E-B085A-W056F001)]  
GE28F160B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3TC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160B3TD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F160C3BC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F160C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F160C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F160C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F160C3TC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F160C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F160C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F160C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F256K18C@FBGA79 [(SA656B-B103A-T063F001Y)]  
GE28F256K3C@FBGA79 [(SA656B-B103A-T063F001Y)]  
GE28F256L18B@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F256L18T@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F256L30B@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F256L30T@VFBGA79 [(SA656B-B103A-T063F001)]  
GE28F320B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F320B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F320B3TC@uBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320B3TD@uBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3BC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3TC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F320C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320J3A@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320J3C@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F320W18BC(NO EFP)@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18BC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]

GE28F320W18TC(NO EFP)@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W18TC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F320W30BC(NO EFP)@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W30BC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W30TC(NO EFP)@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F320W30TC@VFBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640B3BC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F640B3TC@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F640C3BC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F640C3BC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F640C3TC(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F640C3TC@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F640J3C@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F640K18C@FBGA56 [(SA644A-B025B-Y072F001Y)]  
GE28F640K3C@FBGA56 [(SA644A-B025B-Y072F001Y)]  
GE28F640L18B@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640L18T@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640L30B@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640L30T@VFBGA56 [(SA644A-B025A-Y056F001)]  
GE28F640W18BC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18BC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18TC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18TC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
GE28F640W30BC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30BC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30TC(NO EFP)@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F640W30TC@uBGA56 [(SA644A-B025B-Y072F001)]  
GE28F800B3BA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F800B3TA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GE28F800C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F800C3BA@VFBGA48 [(SA634A-B005A-Y048F001)]  
GE28F800C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GE28F800C3TA@VFBGA48 [(SA634A-B005A-Y048F001)]  
GT28F016C3BA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F016C3TA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F032C3BA@FBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F032C3TA@FBGA48 [(SA634A-B005A-Y048F001Y)]

GT28F128W30BC(NO EFP)@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30BC@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30BD(NO EFP)@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30BD@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30TC(NO EFP)@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30TC@uBGA56 [(SA656A-B085A-Y056F001)]  
GT28F128W30TD(NO EFP)@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F128W30TD@uBGA56 [(SA656E-B085A-W056F001)]  
GT28F160B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3BA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160B3TA@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F160C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F160C3BA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F160C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F160C3TA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F320B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F320B3T@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F320C3BA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F320C3BA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F320C3TA(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
GT28F320C3TA@uBGA48 [(SA634A-B005A-Y048F001)]  
GT28F800B3B@uBGA48 [(SA634A-B005A-Y048F001Y)]  
GT28F800B3T@uBGA48 [(SA634A-B005A-Y048F001Y)]  
JS28F128J3C@TSOP56 [(SA628-B018)]  
JS28F128J3D@TSOP56 [(SA628-B018)]  
JS28F128P30B@TSOP56 [(SA628-B131)]  
JS28F128P30T@TSOP56 [(SA628-B131)]  
JS28F128P33B@TSOP56 [(SA628-B131)]  
JS28F128P33T@TSOP56 [(SA628-B131)]  
JS28F160B3BD@TSOP48 [(SA247-B005)]  
JS28F160B3TD@TSOP48 [(SA247-B005)]  
JS28F160C3BD@TSOP48 [(SA247-B005)]  
JS28F160C3TD@TSOP48 [(SA247-B005)]  
JS28F256P30B@TSOP56 [(SA628-B131)]  
JS28F256P30T@TSOP56 [(SA628-B131)]  
JS28F256P33B@TSOP56 [(SA628-B131)]  
JS28F256P33T@TSOP56 [(SA628-B131)]  
JS28F320B3BD@TSOP48 [(SA247-B005)]  
JS28F320B3TD@TSOP48 [(SA247-B005)]  
JS28F320C3BD@TSOP48 [(SA247-B005)]  
JS28F320C3TD@TSOP48 [(SA247-B005)]  
JS28F320J3C@TSOP56 [(SA628-B018)]

JS28F320J3D@TSOP56 [(SA628-B018)]  
 JS28F640J3C@TSOP56 [(SA628-B018)]  
 JS28F640J3D@TSOP56 [(SA628-B018)]  
 JS28F640P30B(Low)@TSOP56 [(SA628-B131)]  
 JS28F640P30B@TSOP56 [(SA628-B131)]  
 JS28F640P30T@TSOP56 [(SA628-B131)]  
 JS28F640P33B@TSOP56 [(SA628-B131)]  
 JS28F640P33T@TSOP56 [(SA628-B131)]  
 JS28F800C3BD@TSOP48 [(SA247-B005)]  
 JS28F800C3TD@TSOP48 [(SA247-B005)]  
 JZ48F4000L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 JZ48F4000L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 JZ48F4000L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 JZ48F4000L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 LZ38F4060L0YBB0@FBGA103 [(SA664F-B157A-W108F001Y)]  
 LZ38F4060L0YTB0@FBGA103 [(SA664F-B157A-W108F001Y)]  
 M28F010 M28F010@PLCC32  
 [(SA015A1T)]  
 M28F010@TSOP32 [(SA410T)] N28F001BN-B@PLCC32  
 [(SA015A1T)]  
 N28F001BN-T@PLCC32 [(SA015A1T)] N28F001BX-B@PLCC32  
 [(SA015A1T)]  
 N28F001BX-T@PLCC32 [(SA015A1T)] N28F010@PLCC32  
 [(SA015A1T)]  
 N28F020@PLCC32 [(SA015A1T)] N28F256@PLCC32  
 [(SA015A1T)]  
 N28F256A@PLCC32 [(SA015A1T)] N28F512@PLCC32  
 [(SA015A1T)]  
 N82802AA@PLCC32 [(SA015A1T)] N82802AB@PLCC32  
 [(SA015A1T)]  
 N82802AC@PLCC32 [(SA015A1T)]  
 NZ48F4000L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 NZ48F4000L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 NZ48F4000L0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 NZ48F4000L0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
 P27011  
 P27128A  
 P27128A@PLCC32 [(SA015A1T)]  
 P27128B  
 P27128B@PLCC32 [(SA015A1T)]  
 P27256  
 P27256@PLCC32 [(SA015A1T)]  
 P27512

P27513	
P2764A	
P2764A@PLCC32 [(SA015A1T)]	
P27C011	
P27C128	P27C128@PLCC32
[(SA015A1T)]	
P27C256	P27C256@PLCC32
[(SA015A1T)]	
P27C513	
P27C64	
P27C64@PLCC32 [(SA015A1T)]	P28F001BX-
B	
P28F001BX-T	P28F002BCT@TSOP40
[(SA409T)]	
P28F010	
P28F020	
P28F256	
P28F256A	
P28F512	
P87C64	
P87C64@PLCC32 [(SA015A1T)]	PA28F004S3@PSOP44
[(SA638)]	
PA28F004S5@PSOP44 [(SA638)]	PA28F004SC@PSOP44
[(SA638)]	
PA28F008S3@PSOP44 [(SA638)]	PA28F008S5@PSOP44
[(SA638)]	
PA28F008SA@PSOP44 [(SA638)]	PA28F008SA-L@PSOP44
[(SA638)]	
PA28F008SC@PSOP44 [(SA638)]	PA28F016S3@PSOP44
[(SA638)]	
PA28F016S5@PSOP44 [(SA638)]	PA28F016SC@PSOP44
[(SA638)]	
PA28F200B5B@PSOP44 [(SA638)]	PA28F200B5T@PSOP44
[(SA638)]	
PA28F200BVB@PSOP44 [(SA638)]	PA28F200BVT@PSOP44
[(SA638)]	
PA28F200BXB@PSOP44 [(SA638)]	PA28F200BXT@PSOP44
[(SA638)]	
PA28F400B5B@PSOP44 [(SA638)]	PA28F400B5T@PSOP44
[(SA638)]	
PA28F400BVB@PSOP44 [(SA638)]	PA28F400BVT@PSOP44
[(SA638)]	
PA28F400BXB@PSOP44 [(SA638)]	PA28F400BXT@PSOP44

[ (SA638) ]  
PA28F800B5B@PSOP44 [ (SA638) ] PA28F800B5T@PSOP44  
[ (SA638) ]  
PA28F800BVB@PSOP44 [ (SA638) ] PA28F800BVT@PSOP44  
[ (SA638) ]  
PC28F128J3C@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
PC28F128J3D@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
PC28F128P30B@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F128P30T@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F128P33B@EBGA64 [ (SA655K-B122A-T064F001Y) ]  
PC28F128P33T@EBGA64 [ (SA655K-B122A-T064F001Y) ]  
PC28F160C3BD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
PC28F160C3TD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
PC28F256P30B@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F256P30T@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F256P33B@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F256P33T@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F320C3BD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
PC28F320C3TD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
PC28F320J3C@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
PC28F320J3D@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
PC28F640J3C@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
PC28F640J3D@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
PC28F640P30B@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F640P30T@EBGA64 [ (SA655G-B122A-T064F001Y) ]  
PC28F640P33B@EBGA64 [ (SA655K-B122A-T064F001Y) ]  
PC28F640P33T@EBGA64 [ (SA655K-B122A-T064F001Y) ]  
PC28F800C3BD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
PC28F800C3TD@FBGA64 [ (SA655J-B037A-T064F001Y) ]  
PC48F3300J0Z00S@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
PF38F1020W0YBQ1@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1020W0YTQ1@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030C0ZBL0@FBGA72 [ (SA642R-B041A-T096F001Y) ]  
PF38F1030C0ZTL0@FBGA72 [ (SA642R-B041A-T096F001Y) ]  
PF38F1030W0YBQ2@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YBQE@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YBQF@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YCQ3@FBGA88 [ (SA642R-B180A-T096F001Y) ]  
PF38F1030W0YCQE@FBGA88 [ (SA642R-B180A-T096F001Y) ]  
PF38F1030W0YTQ2@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YTQE@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YTQF@FBGA88 [ (SA642R-B112A-T096F001Y) ]  
PF38F1030W0YUQ3@FBGA88 [ (SA642R-B180A-T096F001Y) ]

PF38F1030W0YUQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F1030W0ZBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F1030W0ZTQ0 ( SLOW ) @FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F1030W0ZTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2020W0ZBQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2020W0ZTQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YBQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YBQE@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YBQF@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YCQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2030W0YCQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2030W0YTQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YTQE@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YTQF@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0YUQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2030W0YUQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2030W0ZBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2030W0ZTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2040W0YBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2040W0YCQ1@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YCQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YCQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F2040W0YUQ1@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YUQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0YUQE@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F2040W0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F2040W0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3040L0YBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F3040L0YBQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0YBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F3040L0YCQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3040L0YCQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3040L0YTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0YTQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0YTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
PF38F3040L0YUQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3040L0YUQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3040L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3040L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3040L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]



PF38F3040L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3040M0Y0CE@FBGA107 [ ( SA664F-B148A-W108F001N ) ]  
PF38F3040M0Y1QE@FBGA88 [ ( SA642R-B303A-T096F001Y ) ]  
PF38F3040M0Y3QE@FBGA88 [ ( SA642R-B303A-T096F001Y ) ]  
PF38F3050L0YBQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0YBQ2@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0YCYQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3050L0YCYQ2@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3050L0YCYQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3050L0YTYQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0YTYQ2@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0YUQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3050L0YUQ2@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3050L0YUQ3@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F3050L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3050L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
PF38F3050L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F3050M0Y0QE@FBGA88 [ ( SA642R-B300A-T096F001Y ) ]  
PF38F3350LLZDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
PF38F3350W0ZDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
PF38F3350WWZDQ1@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
PF38F4040L0YCYQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F4040L0YUQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
PF38F4050L0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YBQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YCYQ0@FBGA88 [ ( SA642A-B180A-Y096F001Y ) ]  
PF38F4050L0YCYQ3@FBGA88 [ ( SA642A-B180A-Y096F001Y ) ]  
PF38F4050L0YCYQ4@FBGA88 [ ( SA642A-B180A-Y096F001Y ) ]  
PF38F4050L0YTYQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YTYQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YTYQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0YUQ0@FBGA88 [ ( SA642A-B180A-Y096F001Y ) ]  
PF38F4050L0YUQ3@FBGA88 [ ( SA642A-B180A-Y096F001Y ) ]  
PF38F4050L0YUQ4@FBGA88 [ ( SA642A-B180A-Y096F001Y ) ]  
PF38F4050L0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4050M0Y0C0@FBGA107 [ ( SA664F-B148A-W108F001N ) ]  
PF38F4050M0Y0Q0@FBGA88 [ ( SA642R-B300A-T096F001Y ) ]  
PF38F4050M0Y0QE@FBGA88 [ ( SA642R-B300A-T096F001Y ) ]

PF38F4055L0YBQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4055L0YTQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
PF38F4060L0YBB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4060L0YBB1@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4060L0YTB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4060L0YTB1@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4060M0Y0BE@FBGA105 [ ( SA664F-B298A-W108F001Y ) ]  
PF38F4060M0Y0C0@FBGA107 [ ( SA664F-B148A-W108F001N ) ]  
PF38F4070V0YBPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
PF38F4350LLYBQ1@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4350LLYBQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4350LLYTQ1@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4350LLYTQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LLYBQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LLYTQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LVYBQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LVYBQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LVYTQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4450LVYTQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4455LLYBQ0@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4455LLYBQ1@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4455LLYBQ2@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4455LLYTQ0@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4455LLYTQ1@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4455LLYTQ2@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4460EEYBQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4460EEYTQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
PF38F4460LLYBB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4462LLYDB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
PF38F4466LVYBQ0@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4466LVYTQ0@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
PF38F4470LLYBH0@FBGA137 [ ( SA678B-B159A-P137F001Y ) ]  
PF38F4470LLYFH0@FBGA137 [ ( SA678B-B159A-P137F001Y ) ]  
PF38F4470LLYGH0@FBGA137 [ ( SA678B-B159A-P137F001Y ) ]  
PF38F4470LLYTH0@FBGA137 [ ( SA678B-B159A-P137F001Y ) ]  
PF38F4470VVUBPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
PF38F4470VVUTPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
PF38F4476VVUBPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
PF38F4476VVUTPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
PF38F5050M0Y0C0@FBGA107 [ ( SA664F-B148A-W108F001N ) ]  
PF38F5060M0Y0BE@FBGA105 [ ( SA664F-B298A-W108F001Y ) ]  
PF38F5060M0Y0C0@FBGA107 [ ( SA664F-B148A-W108F001N ) ]  
PF38F5060M0Y0CE@FBGA107 [ ( SA664F-B148A-W108F001N ) ]

PF38F5070M0Y0B0@FBGA105 [(SA664F-B298A-W108F001Y)]  
PF38F5070M0Y0BE@FBGA105 [(SA664F-B298A-W108F001Y)]  
PF38F5070M0Y0CE@FBGA107 [(SA664F-B148A-W108F001N)]  
PF38F5080M0Y0B0@FBGA105 [(SA664F-B298A-W108F001Y)]  
PF48F2000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F2000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F2000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F2000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F3000L0YBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF48F3000L0YTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF48F3000L0ZBQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF48F3000L0ZTQ0@FBGA88 [(SA642I-B112A-W080F001)]  
PF48F3000M0Y0QE@FBGA88 [(SA642R-B300A-T096F001Y)]  
PF48F3000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F3000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F3000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F3000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F3000W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF48F3000W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF48F3000W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF48F3000W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
PF48F3300W0YBQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
PF48F3300W0YDQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
PF48F3300W0YTQ0@FBGA88 [(SA642R-B137A-T096F001Y)]  
PF48F4000L0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF48F4000L0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
PF48F4000M0Y0CE@FBGA107 [(SA664F-B148A-W108F001N)]  
PF48F4000P0XBQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F4000P0XTQ0@FBGA88 [(SA642A-B217A-Y096F001Y)]  
PF48F4000P0ZBQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F4000P0ZTQ0@FBGA88 [(SA642A-B138A-Y096F001Y)]  
PF48F4040LVYBQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F4040LVYBQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F4040LVYTQ0(BEEP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F4040LVYTQ0(BP)@FBGA88 [(SA642A-B113A-Y096F001)]  
PF48F5000M0Y0BE@FBGA105 [(SA664F-B298A-W108F001Y)]  
PF48F5000M0Y0C0@FBGA107 [(SA664F-B148A-W108F001N)]  
PF48F5000M0Y1B0@FBGA105 [(SA664F-B301A-W108F001N)]  
PH28F128W18BC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18BC@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18BD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F128W18BD@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F128W18TC(NO EFP)@VFBGA56 [(SA656A-B085A-Y056F001)]

PH28F128W18TC@VFBGA56 [(SA656A-B085A-Y056F001)]  
PH28F128W18TD(NO EFP)@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F128W18TD@VFBGA56 [(SA656E-B085A-W056F001)]  
PH28F160B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
PH28F160B3TD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
PH28F160C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F160C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F160C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F160C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320B3BD@uBGA48 [(SA634A-B005A-Y048F001Y)]  
PH28F320B3TD@uBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320C3BD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F320C3BD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320C3TD(Moto)@VFBGA48 [(SA714A-B026A-M046F001Y)]  
PH28F320C3TD@VFBGA48 [(SA634A-B005A-Y048F001)]  
PH28F320W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F320W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F320W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F320W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F640W18BD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F640W18BE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F640W18TD@VFBGA56 [(SA656C-B104A-T056F001Y)]  
PH28F640W18TE@VFBGA56 [(SA656C-B104A-T056F001Y)]  
QB25F016S33B60@SOIC8 [(SA605A)] QB25F016S33T60@SOIC8  
[(SA605A)]  
QB25F160S33B60@SOIC16 [(SA404)] QB25F160S33T60@SOIC16  
[(SA404)]  
QB25F320S33B60@SOIC16 [(SA404)] QB25F320S33T60@SOIC16  
[(SA404)]  
QB25F640S33B60@SOIC16 [(SA404)] QB25F640S33T60@SOIC16  
[(SA404)]  
QH25F016S33B60@SOIC8 [(SA605A)] QH25F016S33T60@SOIC8  
[(SA605A)]  
QH25F160S33B60@SOIC16 [(SA404)] QH25F160S33T60@SOIC16  
[(SA404)]  
QH25F320S33B60@SOIC16 [(SA404)] QH25F320S33T60@SOIC16  
[(SA404)]  
QH25F640S33B60@SOIC16 [(SA404)] QH25F640S33T60@SOIC16  
[(SA404)]  
RC28F128J3A@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F128J3C@FBGA64 [(SA655A-B054A-T064F001)]  
RC28F128J3D@FBGA64 [(SA655A-B054A-T064F001Y)]  
RC28F128K18C@FBGA64 [(SA655G-B122A-T064F001Y)]

RC28F128K3C@FBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F128P30B@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F128P30T@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F128P33B@EBGA64 [ ( SA655K-B122A-T064F001Y ) ]  
RC28F128P33T@EBGA64 [ ( SA655K-B122A-T064F001Y ) ]  
RC28F160C3BA@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F160C3BC@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F160C3BD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F160C3TA@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F160C3TC@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F160C3TD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F256J3A@FBGA96 [ ( SA642A-B273-Y096N001N ) ]  
RC28F256J3C@FBGA64 [ ( SA655M-B054A-T064F001Y ) ]  
RC28F256K18C@FBGA64 [ ( SA655L-B286A-T064F001Y ) ]  
RC28F256K3C@FBGA64 [ ( SA655L-B286A-T064F001Y ) ]  
RC28F256P30B@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F256P30T@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F256P33B@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F256P33T@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F320C3BA@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320C3BC@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320C3BD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320C3TA@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320C3TC@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320C3TD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F320J3A@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
RC28F320J3C@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
RC28F320J3D@FBGA64 [ ( SA655A-B054A-T064F001Y ) ]  
RC28F640C3BC@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F640C3TC@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F640J3A@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
RC28F640J3C@FBGA64 [ ( SA655A-B054A-T064F001 ) ]  
RC28F640J3D@FBGA64 [ ( SA655A-B054A-T064F001Y ) ]  
RC28F640K18C@FBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F640K3C@FBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F640P30B@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F640P30T@EBGA64 [ ( SA655G-B122A-T064F001Y ) ]  
RC28F640P33B@EBGA64 [ ( SA655K-B122A-T064F001Y ) ]  
RC28F640P33T@EBGA64 [ ( SA655K-B122A-T064F001Y ) ]  
RC28F800C3BA@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F800C3BD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F800C3TA@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]  
RC28F800C3TD@FBGA64 [ ( SA655J-B037A-T064F001Y ) ]

RC48F3300J0Z00S@FBGA64 [(SA655A-B054A-T064F001Y)]  
RD28F1602C3B@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F1602C3T@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F1604C3B@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F1604C3T@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F3204C3B@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F3204C3T@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F3204W18B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W18B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W18T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W18T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3204W30T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F3208C3B@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F3208C3T@FBGA72 [(SA642E-B041A-T072F001)]  
RD28F6408W18B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W18B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W18T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W18T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30B(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30B@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30T(NO EFP)@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD28F6408W30T@FBGA96 [(SA642L-B082A-W080F001Y)]  
RD38F1010C0ZB@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1010C0ZT@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1010W0YTL0@FBGA67 [(SA642E-B041A-T072F001N)]  
RD38F1020C0ZB@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1020C0ZT@FBGA72 [(SA642E-B041A-T072F001)]  
RD38F1020W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YBQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1020W0YTQ1@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0YBQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0YTQ2@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0ZBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F1030W0ZTQ0@FBGA88 [(SA642R-B112A-T096F001Y)]  
RD38F2010W0YBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2010W0YTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2010W0ZBQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2010W0ZTQ0@FBGA88 [(SA642A-B112A-Y096F001Y)]  
RD38F2020W0YBQ0@FBGA88 [(SA642R-B112A-T096F001Y)]

RD38F2020W0YTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2020W0ZBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2020W0ZBQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2020W0ZTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2020W0ZTQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0YBQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0YBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0YBQE@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0YBQF@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0YTQ1@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0YTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0YTQE@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0YTQF@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0ZBQ0 (NO EFP)@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0ZBQ1 (NO EFP)@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0ZBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2030W0ZTQ0 (NO EFP)@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0ZTQ1 (NO EFP)@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2030W0ZTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F2040W0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2040W0YBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2040W0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2040W0YTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2040W0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2040W0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F2220WWYBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2220WWYDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2220WWYTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2220WWZBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2220WWZDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2220WWZTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2230WWYBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2230WWYDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2230WWYTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2230WWZBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2230WWZDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2230WWZTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]

RD38F2240WWYBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2240WWYDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2240WWYTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2240WWZBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2240WWZDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F2240WWZDQ1@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]  
RD38F2240WWZTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD38F3040L0YBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3040L0YBQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3040L0YBQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F3040L0YCQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
RD38F3040L0YTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3040L0YTQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3040L0YTQ2@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD38F3040L0YUQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
RD38F3040L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3040L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0YBQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0YBQ2@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0YCQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
RD38F3050L0YTQ1@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0YTQ2@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0YUQ0@FBGA88 [ ( SA642R-B180A-T096F001Y ) ]  
RD38F3050L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F3050L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD38F3050L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F3340LLYDQ1@FBGA88 [ ( SA642A-B091A-Y096F001 ) ]  
RD38F3350LLZDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD38F3350W0ZDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD38F3350WWZDQ1@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD38F4050L0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YBQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YCQ0@FBGA88 [ ( SA642A-B180A-Y096F001Y ) ]  
RD38F4050L0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YTQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0YUQ0@FBGA88 [ ( SA642A-B180A-Y096F001Y ) ]  
RD38F4050L0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0ZBQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4050L0ZTQ1@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]



RD38F4055L0YBQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4055L0YTQ2@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4055L0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4055L0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD38F4070V0YBPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
RD38F4350LLYBQ1@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4350LLYTQ1@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4450LVYBQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4450LVYBQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4450LVYTQ0@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4450LVYTQ2@FBGA88 [ ( SA642A-B125A-Y096F001Y ) ]  
RD38F4455LLYBQ0@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
RD38F4455LLYBQ1@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
RD38F4455LLYBQ2@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
RD38F4455LLYTQ0@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
RD38F4455LLYTQ1@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
RD38F4455LLYTQ2@FBGA88 [ ( SA642A-B125A-Y096N001N ) ]  
RD38F4460LVYBB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
RD38F4460LVYGB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
RD38F4460LVYTB0@FBGA103 [ ( SA664F-B157A-W108F001Y ) ]  
RD38F4470LLYBH0@FBGA137 [ ( SA678B-B159A-P137F001Y ) ]  
RD38F4470LLYFH0@FBGA137 [ ( SA678B-B159A-P137F001Y ) ]  
RD38F4470LLYGH0@FBGA137 [ ( SA678B-B159A-P137F001Y ) ]  
RD38F4470LLYTH0@FBGA137 [ ( SA678B-B159A-P137F001Y ) ]  
RD38F4470VVUBPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
RD38F4470VVUTPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
RD38F4476VVUBPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
RD38F4476VVUTPD@FBGA137 [ ( SA678B-B162A-P137F001Y ) ]  
RD48F2000L0YBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F2000L0YTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F2000L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F2000L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F2000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F2000P0XTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F2000P0ZBQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F2000P0ZTQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F2000W0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F2000W0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F2000W0ZBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F2000W0ZTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F2100W0YBQ0@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]  
RD48F2100W0YDQE@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]  
RD48F2100W0YTQ0@FBGA88 [ ( SA642A-B113A-Y096F001Y ) ]

RD48F2200W0YBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0YDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0YTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0ZBQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0ZDQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F2200W0ZTQ0@FBGA88 [ ( SA642A-B081A-Y096F001 ) ]  
RD48F3000L0YBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F3000L0YTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F3000L0ZBQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F3000L0ZTQ0@FBGA88 [ ( SA642I-B112A-W080F001 ) ]  
RD48F3000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F3000P0XTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F3000P0ZBQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F3000P0ZTQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F3000W0YBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD48F3000W0YTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD48F3000W0ZBQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD48F3000W0ZTQ0@FBGA88 [ ( SA642R-B112A-T096F001Y ) ]  
RD48F3300W0YBQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD48F3300W0YDQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD48F3300W0YTQ0@FBGA88 [ ( SA642R-B137A-T096F001Y ) ]  
RD48F4000L0YBQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F4000L0YTQ0@FBGA88 [ ( SA642A-B112A-Y096F001Y ) ]  
RD48F4000P0XBQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F4000P0XTQ0@FBGA88 [ ( SA642A-B217A-Y096F001Y ) ]  
RD48F4000P0ZBQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F4000P0ZTQ0@FBGA88 [ ( SA642A-B138A-Y096F001Y ) ]  
RD48F4040LVYBQ0 (BEEP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVYBQ0 (BP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVYTQ0 (BEEP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVYTQ0 (BP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVZBQ0 (BEEP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVZBQ0 (BP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVZTQ0 (BEEP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
RD48F4040LVZTQ0 (BP)@FBGA88 [ ( SA642A-B113A-Y096F001 ) ]  
TB28F004S3@PSOP44 [ ( SA638 ) ] TB28F004S5@PSOP44  
[ ( SA638 ) ]  
TB28F004SC@PSOP44 [ ( SA638 ) ] TB28F008S3@PSOP44  
[ ( SA638 ) ]  
TB28F008S5@PSOP44 [ ( SA638 ) ] TB28F008SA@PSOP44  
[ ( SA638 ) ]  
TB28F008SA-L@PSOP44 [ ( SA638 ) ] TB28F008SC@PSOP44  
[ ( SA638 ) ]

TB28F016S3@PSOP44 [(SA638)] [(SA638)]	TB28F016S5@PSOP44
TB28F016SC@PSOP44 [(SA638)] [(SA638)]	TB28F200B5B@PSOP44
TB28F200B5T@PSOP44 [(SA638)] [(SA638)]	TB28F200BVB@PSOP44
TB28F200BVT@PSOP44 [(SA638)] [(SA638)]	TB28F200BXB@PSOP44
TB28F200BXT@PSOP44 [(SA638)] [(SA638)]	TB28F400B5B@PSOP44
TB28F400B5T@PSOP44 [(SA638)] [(SA638)]	TB28F400BVB@PSOP44
TB28F400BVT@PSOP44 [(SA638)] [(SA638)]	TB28F400BXB@PSOP44
TB28F400BXT@PSOP44 [(SA638)] [(SA638)]	TB28F800B5B@PSOP44
TB28F800B5T@PSOP44 [(SA638)] [(SA638)]	TB28F800BVB@PSOP44
TB28F800BVT@PSOP44 [(SA638)] [(SA409T)]	TE28F002BEB@TSOP40
TE28F002BET@TSOP40 [(SA409T)] [(SA409T)]	TE28F002BVB@TSOP40
TE28F002BVT@TSOP40 [(SA409T)] [(SA409T)]	TE28F002BXB@TSOP40
TE28F002BXT@TSOP40 [(SA409T)] [(SA409T)]	TE28F004BEB@TSOP40
TE28F004BET@TSOP40 [(SA409T)] [(SA409T)]	TE28F004BVB@TSOP40
TE28F004BVT@TSOP40 [(SA409T)] [(SA409T)]	TE28F004BXB@TSOP40
TE28F004BXT@TSOP40 [(SA409T)] [(SA409T)]	TE28F004S3@TSOP40
TE28F004S5@TSOP40 [(SA409T)] [(SA409T)]	TE28F004SC@TSOP40
TE28F008B3B@TSOP40 [(SA409T)] [(SA409T)]	TE28F008B3BA@TSOP40
TE28F008B3T@TSOP40 [(SA409T)] [(SA409T)]	TE28F008B3TA@TSOP40
TE28F008BEB@TSOP40 [(SA409T)] [(SA409T)]	TE28F008BET@TSOP40
TE28F008BVB@TSOP40 [(SA409T)] [(SA409T)]	TE28F008BVT@TSOP40
TE28F008C3BA@TSOP40 [(SA409T)]	TE28F008C3TA@TSOP40

[ (SA409T) ]	
TE28F008S3@TSOP40 [ (SA409T) ]	TE28F008S5@TSOP40
[ (SA409T) ]	
TE28F008SA@TSOP40 [ (SA409T) ]	TE28F008SA-L@TSOP40
[ (SA409T) ]	
TE28F008SC@TSOP40 [ (SA409T) ]	TE28F016B3B@TSOP40
[ (SA409T) ]	
TE28F016B3T@TSOP40 [ (SA409T) ]	TE28F016C3BA@TSOP40
[ (SA409T) ]	
TE28F016C3TA@TSOP40 [ (SA409T) ]	TE28F016S3@TSOP40
[ (SA409T) ]	
TE28F016S5@TSOP40 [ (SA409T) ]	TE28F016SC@TSOP40
[ (SA409T) ]	
TE28F128J3C@TSOP56 [ (SA628-B018) ]	
TE28F128J3D@TSOP56 [ (SA628-B018) ]	
TE28F128P30B@TSOP56 [ (SA628-B131) ]	
TE28F128P30T@TSOP56 [ (SA628-B131) ]	
TE28F128P33B@TSOP56 [ (SA628-B131) ]	
TE28F128P33T@TSOP56 [ (SA628-B131) ]	
TE28F160B3B@TSOP48 [ (SA247-B005) ]	
TE28F160B3BA@TSOP48 [ (SA247-B005) ]	
TE28F160B3BC@TSOP48 [ (SA247-B005) ]	
TE28F160B3BD@TSOP48 [ (SA247-B005) ]	
TE28F160B3T@TSOP48 [ (SA247-B005) ]	
TE28F160B3TA@TSOP48 [ (SA247-B005) ]	
TE28F160B3TC@TSOP48 [ (SA247-B005) ]	
TE28F160B3TD@TSOP48 [ (SA247-B005) ]	
TE28F160C3BA@TSOP48 [ (SA247-B005) ]	
TE28F160C3BC@TSOP48 [ (SA247-B005) ]	
TE28F160C3BD@TSOP48 [ (SA247-B005) ]	
TE28F160C3TA@TSOP48 [ (SA247-B005) ]	
TE28F160C3TC@TSOP48 [ (SA247-B005) ]	
TE28F160C3TD@TSOP48 [ (SA247-B005) ]	
TE28F160F3B@TSOP56 [ (SA628-B014) ]	
TE28F160F3T@TSOP56 [ (SA628-B014) ]	
TE28F160S3@TSOP56 [ (SA628-B011) ]	TE28F160S5@TSOP56 [ (SA628-
B011) ]	
TE28F200B5B@TSOP48 [ (SA247-B005) ]	
TE28F200B5T@TSOP48 [ (SA247-B005) ]	
TE28F200BVB@TSOP56 [ (SA628-B012) ]	
TE28F200BVT@TSOP56 [ (SA628-B012) ]	
TE28F200BXB@TSOP56 [ (SA628-B012) ]	
TE28F200BXT@TSOP56 [ (SA628-B012) ]	

TE28F200CEB@TSOP56 [ (SA628-B012) ]  
TE28F200CET@TSOP56 [ (SA628-B012) ]  
TE28F200CVB@TSOP48 [ (SA247-B005) ]  
TE28F200CVT@TSOP48 [ (SA247-B005) ]  
TE28F256J3C@TSOP56 [ (SA628-B018) ]  
TE28F256P30B@TSOP56 [ (SA628-B131) ]  
TE28F256P30T@TSOP56 [ (SA628-B131) ]  
TE28F256P33B@TSOP56 [ (SA628-B131) ]  
TE28F256P33T@TSOP56 [ (SA628-B131) ]  
TE28F320B3B@TSOP48 [ (SA247-B005) ]  
TE28F320B3BA@TSOP48 [ (SA247-B005) ]  
TE28F320B3BC@TSOP48 [ (SA247-B005) ]  
TE28F320B3BD@TSOP48 [ (SA247-B005) ]  
TE28F320B3T@TSOP48 [ (SA247-B005) ]  
TE28F320B3TA@TSOP48 [ (SA247-B005) ]  
TE28F320B3TC@TSOP48 [ (SA247-B005) ]  
TE28F320B3TD@TSOP48 [ (SA247-B005) ]  
TE28F320C3BA@TSOP48 [ (SA247-B005) ]  
TE28F320C3BC@TSOP48 [ (SA247-B005) ]  
TE28F320C3BD@TSOP48 [ (SA247-B005) ]  
TE28F320C3TA@TSOP48 [ (SA247-B005) ]  
TE28F320C3TC@TSOP48 [ (SA247-B005) ]  
TE28F320C3TD@TSOP48 [ (SA247-B005) ]  
TE28F320J3C@TSOP56 [ (SA628-B018) ]  
TE28F320J3D@TSOP56 [ (SA628-B018) ]  
TE28F400B3B@TSOP48 [ (SA247-B005) ]  
TE28F400B3T@TSOP48 [ (SA247-B005) ]  
TE28F400B5B@TSOP48 [ (SA247-B005) ]  
TE28F400B5T@TSOP48 [ (SA247-B005) ]  
TE28F400BVB@TSOP56 [ (SA628-B012) ]  
TE28F400BVT@TSOP56 [ (SA628-B012) ]  
TE28F400BXB@TSOP56 [ (SA628-B012) ]  
TE28F400BXT@TSOP56 [ (SA628-B012) ]  
TE28F400CEB@TSOP48 [ (SA247-B005) ]  
TE28F400CET@TSOP48 [ (SA247-B005) ]  
TE28F400CVB@TSOP48 [ (SA247-B005) ]  
TE28F400CVT@TSOP48 [ (SA247-B005) ]  
TE28F640B3BC@TSOP48 [ (SA247-B005) ]  
TE28F640B3TC@TSOP48 [ (SA247-B005) ]  
TE28F640C3BC@TSOP48 [ (SA247-B005) ]  
TE28F640C3TC@TSOP48 [ (SA247-B005) ]  
TE28F640J3C@TSOP56 [ (SA628-B018) ]  
TE28F640J3D@TSOP56 [ (SA628-B018) ]

TE28F640P30B@TSOP56 [ ( SA628-B131 ) ]  
 TE28F640P30T@TSOP56 [ ( SA628-B131 ) ]  
 TE28F640P33B@TSOP56 [ ( SA628-B131 ) ]  
 TE28F640P33T@TSOP56 [ ( SA628-B131 ) ]  
 TE28F800B3B@TSOP48 [ ( SA247-B005 ) ]  
 TE28F800B3BA@TSOP48 [ ( SA247-B005 ) ]  
 TE28F800B3T@TSOP48 [ ( SA247-B005 ) ]  
 TE28F800B3TA@TSOP48 [ ( SA247-B005 ) ]  
 TE28F800B5B@TSOP48 [ ( SA247-B005 ) ]  
 TE28F800B5T@TSOP48 [ ( SA247-B005 ) ]  
 TE28F800C3BA@TSOP48 [ ( SA247-B005 ) ]  
 TE28F800C3BD@TSOP48 [ ( SA247-B005 ) ]  
 TE28F800C3TA@TSOP48 [ ( SA247-B005 ) ]  
 TE28F800C3TD@TSOP48 [ ( SA247-B005 ) ]  
 TE28F800CEB@TSOP48 [ ( SA247-B005 ) ]  
 TE28F800CET@TSOP48 [ ( SA247-B005 ) ]  
 TE28F800CVB@TSOP48 [ ( SA247-B005 ) ]  
 TE28F800CVT@TSOP48 [ ( SA247-B005 ) ]  
 TE28F800F3B@TSOP56 [ ( SA628-B014 ) ]  
 TE28F800F3T@TSOP56 [ ( SA628-B014 ) ]

## PLD

5C031 [ ( SA001A ) ]	5C031@PLCC20
5C032 [ ( SA001A ) ]	5C032@PLCC20
5C090 [ ( SA244 ) ]	5C090@PLCC44
85C090 [ ( SA244 ) ]	85C090-P44
85C220 [ ( SA001A ) ]	85C220@PLCC20
IPLD910 [ ( SA244 ) ]	IPLD910-P44

## MICROCONTROLLER

8751BH [ ( SA244 ) ]	8751BH@PLCC44
8752BH	8752BH@PLCC44

[ (SA244) ]	
8796BH@PLCC68 ( * ) [ (SA648-B6803) ]	8796JF@PLCC68 ( * ) [ (SA648-B6803) ]
8797BH@PGA68 ( * ) [ (SA650-B6804) ]	8797BH@PLCC68 ( * ) [ (SA648-B6803) ]
8797JF@PGA68 ( * ) [ (SA650-B6804) ]	8797JF@PLCC68 ( * ) [ (SA648-B6803) ]
87C151SA	87C151SA@PLCC44
[ (SA244) ]	
87C151SB	87C151SB@PLCC44
[ (SA244) ]	
87C196CA@PLCC68 ( * ) [ (SA648-B6805) ]	
87C196JQ@PLCC52 ( * ) [ (SA647-B5201) ]	
87C196JR@PLCC52 ( * ) [ (SA647-B5201) ]	
87C196JT@PLCC52 ( * ) [ (SA647-B5201) ]	
87C196JV@PLCC52 ( * ) [ (SA647-B5201) ]	
87C196KB@PGA68 ( * ) [ (S667+B309) ]	
87C196KB@PLCC68 ( * ) [ (SA648-B6801) ]	
87C196KC@PGA68 ( * ) [ (S667+B309) ]	
87C196KC@PLCC68 ( * ) [ (SA648-B6801) ]	
87C196KD@PGA68 ( * ) [ (S667+B309) ]	
87C196KD@PLCC68 ( * ) [ (SA648-B6801) ]	
87C196KQ@PLCC68 ( * ) [ (SA648-B6802) ]	
87C196KR@PLCC68 ( * ) [ (SA648-B6802) ]	
87C196KS@PLCC68 ( * ) [ (SA648-B6802) ]	
87C196KT@PLCC68 ( * ) [ (SA648-B6802) ]	
87C196LA@PLCC52 ( * ) [ (SA647-B5201) ]	
87C196MC@PLCC84 ( * ) [ (SA649-B8401) ]	
87C196MC@PQFP80 ( * ) [ (TA026-B006) ]	
87C196MC@SDIP64 ( * ) [ (SA651) ]	
87C196MH@PLCC84 ( * ) [ (SA649-B8401) ]	
87C196MH@PQFP80 ( * ) [ (TA026-B006) ]	
87C196MH@SDIP64 ( * ) [ (SA651) ]	
87C251SA	
87C251SA@PLCC44 [ (SA244) ]	
87C251SB	
87C251SB@PLCC44 [ (SA244) ]	
87C251SP	
87C251SP@PLCC44 [ (SA244) ]	
87C251SQ	
87C251SQ@PLCC44 [ (SA244) ]	
87C51	
87C51@PLCC44 [ (SA244) ]	87C51@TQFP44

[ (SA245A) ]  
87C51FA 87C51FA@PLCC44  
[ (SA244) ]  
87C51FA@TQFP44 [ (SA245A) ]  
87C51FB  
87C51FB@PLCC44 [ (SA244) ] 87C51FB@TQFP44  
[ (SA245A) ]  
87C51FC 87C51FC@PLCC44  
[ (SA244) ]  
87C51FC@TQFP44 [ (SA245A) ]  
87C51RA  
87C51RA@PLCC44 [ (SA244) ] 87C51RA@TQFP44  
[ (SA245A) ]  
87C51RB 87C51RB@PLCC44  
[ (SA244) ]  
87C51RB@TQFP44 [ (SA245A) ]  
87C51RC  
87C51RC@PLCC44 [ (SA244) ] 87C51RC@TQFP44  
[ (SA245A) ]  
87C52 87C52@PLCC44  
[ (SA244) ]  
87C52@TQFP44 [ (SA245A) ]  
87C54  
87C54@PLCC44 [ (SA244) ] 87C54@TQFP44  
[ (SA245A) ]  
87C58 87C58@PLCC44  
[ (SA244) ]  
87C58@TQFP44 [ (SA245A) ] 87L51FA@PLCC44  
[ (SA244) ]  
87L51FA@TQFP44 [ (SA245A) ] 87L51FB@PLCC44  
[ (SA244) ]  
87L51FB@TQFP44 [ (SA245A) ] 87L51FC@PLCC44  
[ (SA244) ]  
87L51FC@TQFP44 [ (SA245A) ] 87L52@PLCC44  
[ (SA244) ]  
87L52@TQFP44 [ (SA245A) ] 87L54@PLCC44  
[ (SA244) ]  
87L54@TQFP44 [ (SA245A) ] 87L58@PLCC44  
[ (SA244) ]  
87L58@TQFP44 [ (SA245A) ]

## INTEL-CUSTOMER



**E ( E ) PROM / FRAM / NVRAM**

TE28F800C3TD@TSOP48 [ ( SA247-B005 ) ]

**INTELSIL**

**E ( E ) PROM / FRAM / NVRAM**

HS-6617RH

[ ( SA404 ) ]

HS-6617RH-T

[ ( SA404 ) ]

HS-6883RH

[ ( SA404 ) ]

HS-6883RH-T

[ ( SA404 ) ]

HS-6617RH@SOIC24

HS-6617RH-T@SOIC24

HS-6883RH@SOIC24

HS-6883RH-T@SOIC24

**ISSI**

**E ( E ) PROM / FRAM / NVRAM**

IS24C01

[ ( SA666 ) ]

IS24C01@SOIC8 [ ( SA602A ) ]

[ ( SA026 ) ]

IS24C01B

[ ( SA666 ) ]

IS24C01B@SOIC8 [ ( SA602A ) ]

[ ( SA026 ) ]

IS24C02

[ ( SA666 ) ]

IS24C02@SOIC8 [ ( SA602A ) ]

[ ( SA026 ) ]

IS24C02A

IS24C02A@DFN8

IS24C02A@MSOP8 [ ( SA666 ) ]

[ ( SA602A ) ]

IS24C02A@TSSOP8 [ ( SA026 ) ]

IS24C02B

IS24C01@MSOP8

IS24C01@TSSOP8

IS24C01B@MSOP8

IS24C01B@TSSOP8

IS24C02@MSOP8

IS24C02@TSSOP8

IS24C02A@SOIC8

IS24C02B@DFN8 [ (SA666) ]	IS24C02B@MSOP8
IS24C02B@SOIC8 [ (SA602A) ] [ (SA026) ]	IS24C02B@TSSOP8
IS24C04 [ (SA666) ]	IS24C04@MSOP8
IS24C04@SOIC8 [ (SA602A) ] [ (SA026) ]	IS24C04@TSSOP8
IS24C04A IS24C04A@DFN8	
IS24C04A@MSOP8 [ (SA666) ] [ (SA602A) ]	IS24C04A@SOIC8
IS24C04A@TSSOP8 [ (SA026) ]	
IS24C08 IS24C08@MSOP8 [ (SA666) ] [ (SA602A) ]	IS24C08@SOIC8
IS24C08@TSSOP8 [ (SA026) ]	
IS24C08A IS24C08A@DFN8	
[ (SA666) ]	IS24C08A@MSOP8
IS24C08A@SOIC8 [ (SA602A) ] [ (SA026) ]	IS24C08A@TSSOP8
IS24C128 [ (SA602A) ]	IS24C128@SOIC8
IS24C128@TSSOP14 [ (SA026) ]	
IS24C16 IS24C16@MSOP8 [ (SA666) ] [ (SA602A) ]	IS24C16@SOIC8
IS24C16@TSSOP8 [ (SA026) ]	
IS24C16A IS24C16A@MSOP8 [ (SA666) ] [ (SA602A) ]	IS24C16A@SOIC8
IS24C16A@TSSOP8 [ (SA026) ]	
IS24C256 IS24C256@SOIC8 [ (SA602A) ] [ (SA026) ]	IS24C256@TSSOP14
IS24C256A [ (SA602A) ]	IS24C256A@SOIC8
IS24C256A@TSSOP14 [ (SA026) ]	
IS24C32 IS24C32@SOIC8 [ (SA602A) ] [ (SA026) ]	IS24C32@TSSOP8
IS24C32A	IS24C32A@MSOP8

[ (SA666) ]	
IS24C32A@SOIC8 [ (SA602A) ]	IS24C32A@TSSOP8
[ (SA026) ]	
IS24C32B	IS24C32B@SOIC8
[ (SA602A) ]	
IS24C32B@TSSOP8 [ (SA026) ]	
IS24C64	
IS24C64@SOIC8 [ (SA602A) ]	IS24C64@TSSOP8
[ (SA026) ]	
IS24C64A	IS24C64A@MSOP8
[ (SA666) ]	
IS24C64A@SOIC8 [ (SA602A) ]	IS24C64A@TSSOP8
[ (SA026) ]	
IS24C64B	IS24C64B@SOIC8
[ (SA602A) ]	
IS24C64B@TSSOP8 [ (SA026) ]	
IS24L128	
IS24L128@SOIC8(150mil) [ (SA602A) ]	
IS24L128@SOIC8(200mil) [ (SA605A) ]	
IS24L256	
IS24L256@SOIC8(150mil) [ (SA602A) ]	
IS24L256@SOIC8(200mil) [ (SA605A) ]	
IS25C01	IS25C01@SOIC8
[ (SA602A) ]	
IS25C01@TSSOP8 [ (SA026) ]	
IS25C02	
IS25C02@SOIC8 [ (SA602A) ]	IS25C02@TSSOP8
[ (SA026) ]	
IS25C04	IS25C04@SOIC8
[ (SA602A) ]	
IS25C04@TSSOP8 [ (SA026) ]	
IS25C08	
IS25C08@SOIC8 [ (SA602A) ]	IS25C08@TSSOP8
[ (SA026) ]	
IS25C128@SOIC8 [ (SA602A) ]	IS25C128@TSSOP8
[ (SA026) ]	
IS25C16	IS25C16@SOIC8
[ (SA602A) ]	
IS25C16@TSSOP8 [ (SA026) ]	IS25C256@SOIC8
[ (SA602A) ]	
IS25C256@TSSOP8 [ (SA026) ]	
IS25C32A	
IS25C32A@SOIC8 [ (SA602A) ]	IS25C32A@TSSOP8

[ (SA026) ]	
IS25C64A	IS25C64A@SOIC8
[ (SA602A) ]	
IS25C64A@TSSOP8 [ (SA026) ]	
IS27C010	
IS27C010@PLCC32 [ (SA015A1T) ]	IS27C010@TSOP32
[ (SA410T) ]	
IS27C020	IS27C020@PLCC32
[ (SA015A1T) ]	
IS27C020@TSOP32 [ (SA410T) ]	
IS27C256	
IS27C256@PLCC32 [ (SA015A1T) ]	
IS27C512	
IS27C512@PLCC32 [ (SA015A1T) ]	IS27C512@TSOP28
[ (SA430T) ]	
IS27HC010	IS27HC010@PLCC32
[ (SA015A1T) ]	
IS27HC010@TSOP32 [ (SA410T) ]	
IS27HC020	
IS27HC020@PLCC32 [ (SA015A1T) ]	IS27HC020@TSOP32
[ (SA410T) ]	
IS27HC256	IS27HC256@PLCC32
[ (SA015A1T) ]	
IS27HC512	IS27HC512@PLCC32
[ (SA015A1T) ]	
IS27HC512@TSOP28 [ (SA430T) ]	
IS27LV010	
IS27LV010@PLCC32 [ (SA015A1T) ]	IS27LV010@TSOP32
[ (SA410T) ]	
IS27LV512	IS27LV512@PLCC32
[ (SA015A1T) ]	
IS27LV512@TSOP28 [ (SA430T) ]	
IS28F010	
IS28F010@PLCC32 [ (SA015A1T) ]	IS28F010@TSOP32
[ (SA410T) ]	
IS28F010A	IS28F010A@PLCC32
[ (SA015A1T) ]	
IS28F010A@TSOP32 [ (SA410T) ]	
IS28F020	
IS28F020@PLCC32 [ (SA015A1T) ]	IS28F020@TSOP32
[ (SA410T) ]	
IS29F010	IS29F010@PLCC32
[ (SA015A1T) ]	

IS29F010@TSOP32 [(SA410T)]  
IS34C02  
IS34C02@MSOP8 [(SA666)] IS34C02@SOIC8  
[(SA602A)]  
IS34C02@TSSOP8 [(SA026)]  
IS34C02B@DFN8  
IS34C02B@TSSOP8 [(SA026)]  
IS71V08F32AS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32BS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32CS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32DS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32ES08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32ESB08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32EST08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32FS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32GSB08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F32GST08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V08F64GS08@FBGA101 [(SA642C-B032A-Y056F001)]  
IS71V08F64GS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32AS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32B04@FBGA56 [(SA642A-B032A-Y096F001)]  
IS71V16F32B04@FBGA59 [(SA642A-B032A-Y096F001)]  
IS71V16F32BS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32CS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32DS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32ES08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32ESB08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32EST08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32FS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32GSB08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32GST08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71V16F32T04@FBGA56 [(SA642A-B032A-Y096F001)]  
IS71V16F32T04@FBGA59 [(SA642A-B032A-Y096F001)]  
IS71V16F64GS08@FBGA101 [(SA642C-B032A-Y056F001)]  
IS71V16F64GS08@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71VPCF32AS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71VPCF32BS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71VPCF32CS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71VPCF32DS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71VPCF32ES04@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71VPCF32FS04@FBGA73 [(SA642A-B032A-Y096F001)]  
IS71VPCF64GS08@FBGA73 [(SA642C-B032A-Y056F001)]  
IS75V16F64GS16@FBGA65 [(SA642C-B032A-Y056F001)]

IS75V16F64GS32@FBGA65 [(SA642C-B032A-Y056F001)]	
IS93C46	IS93C46@SOIC8
[(SA602A)]	
IS93C46A(08bit)	IS93C46A(08bit)@SOIC8
[(SA602A)]	
IS93C46A(08bit)@TSSOP8 [(SA026)]	IS93C46A
(16bit)	
IS93C46A(16bit)@SOIC8 [(SA602A)]	IS93C46A(16bit)@TSSOP8
[(SA026)]	
IS93C46B	IS93C46B@SOIC8
[(SA602A)]	
IS93C46B@TSSOP8 [(SA026)]	IS93C46D
(08bit)	
IS93C46D(08bit)@SOIC8 [(SA602A)]	IS93C46D(08bit)@TSSOP8
[(SA026)]	
IS93C46D(16bit)	IS93C46D(16bit)@SOIC8
[(SA602A)]	
IS93C46D(16bit)@TSSOP8 [(SA026)]	
IS93C56	
IS93C56@SOIC8 [(SA602A)]	IS93C56A
(08bit)	
IS93C56A(08bit)@SOIC8 [(SA602A)]	IS93C56A(08bit)@TSSOP8
[(SA026)]	
IS93C56A(16bit)	IS93C56A(16bit)@SOIC8
[(SA602A)]	
IS93C56A(16bit)@TSSOP8 [(SA026)]	
IS93C66	
IS93C66@SOIC8 [(SA602A)]	IS93C66A
(08bit)	
IS93C66A(08bit)@SOIC8 [(SA602A)]	IS93C66A(08bit)@TSSOP8
[(SA026)]	
IS93C66A(16bit)	IS93C66A(16bit)@SOIC8
[(SA602A)]	
IS93C66A(16bit)@TSSOP8 [(SA026)]	IS93C76A
(08bit)	
IS93C76A(08bit)@SOIC8 [(SA602A)]	IS93C76A(08bit)@TSSOP8
[(SA026)]	
IS93C76A(16bit)	IS93C76A(16bit)@SOIC8
[(SA602A)]	
IS93C76A(16bit)@TSSOP8 [(SA026)]	IS93C86A
(08bit)	
IS93C86A(08bit)@SOIC8 [(SA602A)]	IS93C86A(08bit)@TSSOP8
[(SA026)]	

IS93C86A(16bit)  
 [(SA602A)]  
 IS93C86A(16bit)@TSSOP8 [(SA026)]

IS93C86A(16bit)@SOIC8

## DRAM & SRAM

IS61C1024  
 [(SA646)]  
 IS61C1024(400m)@SOJ32 [(SA661)]  
 [(SA410T)]  
 IS61C1024L  
 [(SA646)]  
 IS61C1024L(400m)@SOJ32 [(SA661)]  
 [(SA410T)]  
 IS61C256AH  
 [(SA646)]  
 IS61C256AH@TSOP28 [(SA430T)]  
 IS61C512  
 IS61C512(300m)@SOJ32 [(SA646)]  
 [(SA661)]  
 IS61C512@TSOP32 [(SA410T)]  
 IS61C64AH  
 IS61C64AH@SOJ28 [(SA646)]  
 [(SA430T)]  
 IS61LV256  
 [(SA646)]  
 IS61LV256@TSOP28 [(SA430T)]  
 IS61M256  
 IS61M256@SOJ28 [(SA646)]  
 [(SA430T)]  
 IS62C1024  
 [(SA646)]  
 IS62C1024(400m)@SOJ32 [(SA661)]  
 [(SA410T)]  
 IS62C256  
 [(SA646)]  
 IS62C256@TSOP28 [(SA430T)]  
 IS62C512  
 IS62C512(300m)@SOJ32 [(SA646)]  
 [(SA661)]  
 IS62C512@TSOP32 [(SA410T)]  
 IS62C64

IS61C1024(300m)@SOJ32  
 IS61C1024@TSOP32  
 IS61C1024L(300m)@SOJ32  
 IS61C1024L@TSOP32  
 IS61C256AH@SOJ28  
 IS61C512(400m)@SOJ32  
 IS61C64AH@TSOP28  
 IS61LV256@SOJ28  
 IS61M256@TSOP28  
 IS62C1024(300m)@SOJ32  
 IS62C1024@TSOP32  
 IS62C256@SOJ28  
 IS62C512(400m)@SOJ32

IS62C64@SOJ28 [(SA646)]  
[(SA430T)]  
IS62LV256  
[(SA646)]  
IS62LV256@TSOP28 [(SA430T)]

IS62C64@TSOP28  
  
IS62LV256@SOJ28

## MICROCONTROLLER

IS89C51A  
[(SA244)]  
IS89C51A@TQFP44 [(SA245A)]  
IS89C52A  
IS89C52A@PLCC44 [(SA244)]  
[(SA245A)]

IS89C51A@PLCC44  
  
  
IS89C52A@TQFP44

## ITHINKO

### MICROCONTROLLER

AX5012  
[(SA404)]  
AX5012(5.5V)@SOP24 [(SA404)]  
[(SA404)]  
AX5012@SOP24 [(SA404)]  
AX5012@SOP32

AX5012(5.0V)@SOP24  
  
AX5012(6.0V)@SOP24

## LATTICE

### PLD

GAL16LV8  
[(SA001A)]  
GAL16LV8C  
[(SA001A)]  
GAL16LV8D  
[(SA001A)]  
GAL16LV8Z  
[(SA001A)]  
GAL16LV8ZD

GAL16LV8@PLCC20  
  
GAL16LV8C@PLCC20  
  
GAL16LV8D@PLCC20  
  
GAL16LV8Z@PLCC20  
  
GAL16LV8ZD@PLCC20



[ (SA001A) ]	
GAL16V8	GAL16V8@PLCC20
[ (SA001A) ]	
GAL16V8@SOIC20 [ (SA404) ]	
GAL16V8A	
GAL16V8A@PLCC20 [ (SA001A) ]	GAL16V8A@SOIC20
[ (SA404) ]	
GAL16V8B	GAL16V8B@PLCC20
[ (SA001A) ]	
GAL16V8B@SOIC20 [ (SA404) ]	
GAL16V8C	
GAL16V8C@PLCC20 [ (SA001A) ]	GAL16V8C@SOIC20
[ (SA404) ]	
GAL16V8D	GAL16V8D@PLCC20
[ (SA001A) ]	
GAL16V8D@SOIC20 [ (SA404) ]	
GAL16V8Z	
GAL16V8Z@PLCC20 [ (SA001A) ]	GAL16V8Z@SOIC20
[ (SA404) ]	
GAL18V10	GAL18V10@PLCC20
[ (SA001A) ]	
GAL18V10B	GAL18V10B@PLCC20
[ (SA001A) ]	
GAL20LV8	GAL20LV8@PLCC28
[ (SA008A) ]	
GAL20LV8Z	GAL20LV8Z@PLCC28
[ (SA008A) ]	
GAL20LV8ZD	GAL20LV8ZD@PLCC28
[ (SA008A) ]	
GAL20RA10	GAL20RA10@PLCC28
[ (SA008A) ]	
GAL20RA10B	GAL20RA10B@PLCC28
[ (SA008A) ]	
GAL20V8	GAL20V8@PLCC28
[ (SA008A) ]	
GAL20V8A	GAL20V8A@PLCC28
[ (SA008A) ]	
GAL20V8B	GAL20V8B@PLCC28
[ (SA008A) ]	
GAL20V8C	GAL20V8C@PLCC28
[ (SA008A) ]	
GAL20V8Z	GAL20V8Z@PLCC28
[ (SA008A) ]	

GAL20XV10 [ (SA008A) ]	GAL20XV10@PLCC28
GAL20XV10B [ (SA008A) ]	GAL20XV10B@PLCC28
GAL22LV10C [ (SA008A) ]	GAL22LV10C@PLCC28
GAL22LV10C@SOIC24 [ (SA404) ] [ (SA643) ]	GAL22LV10C@TSOP24
GAL22LV10D [ (SA008A) ]	GAL22LV10D@PLCC28
GAL22LV10D@SOIC24 [ (SA404) ] [ (SA643) ]	GAL22LV10D@TSOP24
GAL22LV10Z [ (SA008A) ]	GAL22LV10Z@PLCC28
GAL22LV10Z@SOIC24 [ (SA404) ] [ (SA643) ]	GAL22LV10Z@TSOP24
GAL22LV10ZD [ (SA008A) ]	GAL22LV10ZD@PLCC28
GAL22LV10ZD@SOIC24 [ (SA404) ] [ (SA643) ]	GAL22LV10ZD@TSOP24
GAL22V10 [ (SA008A) ]	GAL22V10@PLCC28
GAL22V10@SOIC24 [ (SA404) ]	
GAL22V10A GAL22V10A@PLCC28 [ (SA008A) ] [ (SA404) ]	GAL22V10A@SOIC24
GAL22V10B [ (SA008A) ]	GAL22V10B@PLCC28
GAL22V10B@SOIC24 [ (SA404) ]	
GAL22V10BQ GAL22V10BQ@PLCC28 [ (SA008A) ] [ (SA404) ]	GAL22V10BQ@SOIC24
GAL22V10C [ (SA008A) ]	GAL22V10C@PLCC28
GAL22V10C@SOIC24 [ (SA404) ]	
GAL22V10D GAL22V10D@PLCC28 [ (SA008A) ] [ (SA404) ]	GAL22V10D@SOIC24
GAL26CLV12 [ (SA008A) ]	GAL26CLV12@PLCC28
GAL26CLV12@SOIC28 [ (SA404) ] [ (SA643) ]	GAL26CLV12@TSOP28
GAL26CLV12B	GAL26CLV12B@PLCC28

[ (SA008A) ]	
GAL26CLV12B@SOIC28 [ (SA404) ]	GAL26CLV12B@TSOP28
[ (SA643) ]	
GAL26CLV12C	GAL26CLV12C@PLCC28
[ (SA008A) ]	
GAL26CLV12C@SOIC28 [ (SA404) ]	GAL26CLV12C@TSOP28
[ (SA643) ]	
GAL26CLV12D	GAL26CLV12D@PLCC28
[ (SA008A) ]	
GAL26CLV12D@SOIC28 [ (SA404) ]	GAL26CLV12D@TSOP28
[ (SA643) ]	
GAL26CLV12Z	GAL26CLV12Z@PLCC28
[ (SA008A) ]	
GAL26CLV12Z@SOIC28 [ (SA404) ]	GAL26CLV12Z@TSOP28
[ (SA643) ]	
GAL26CLV12ZD	GAL26CLV12ZD@PLCC28
[ (SA008A) ]	
GAL26CLV12ZD@SOIC28 [ (SA404) ]	GAL26CLV12ZD@TSOP28
[ (SA643) ]	
GAL26CV12	GAL26CV12@PLCC28
[ (SA008A) ]	
GAL26CV12B	GAL26CV12B@PLCC28
[ (SA008A) ]	
GAL26CV12C	GAL26CV12C@PLCC28
[ (SA008A) ]	
GAL26V12C	GAL26V12C@PLCC28
[ (SA008A) ]	
ispGAL22LV10	ispGAL22LV10(ISP) [ISP-
HEADER01]	
ispGAL22LV10@PLCC28 [ (SA008A) ]	
ispGAL22LV10@PLCC28(ISP) [ISP-HEADER01]	
ispGAL22LV10@SSOP28 [ (SA626A) ]	
ispGAL22LV10@SSOP28(ISP) [ISP-HEADER01]	
ispGAL22LV10A	
ispGAL22LV10A(ISP) [ISP-HEADER01]	
ispGAL22LV10A@PLCC28 [ (SA008A) ]	
ispGAL22LV10A@PLCC28(ISP) [ISP-HEADER01]	
ispGAL22LV10A@SSOP28 [ (SA626A) ]	
ispGAL22LV10A@SSOP28(ISP) [ISP-HEADER01]	
ispGAL22LV10B	
ispGAL22LV10B(ISP) [ISP-HEADER01]	
ispGAL22LV10B@PLCC28 [ (SA008A) ]	
ispGAL22LV10B@PLCC28(ISP) [ISP-HEADER01]	

ispGAL22LV10B@SSOP28 [(SA626A)]  
ispGAL22LV10B@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22LV10C  
ispGAL22LV10C(ISP) [ISP-HEADER01]  
ispGAL22LV10C@PLCC28 [(SA008A)]  
ispGAL22LV10C@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10C@SSOP28 [(SA626A)]  
ispGAL22LV10C@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22LV10D  
ispGAL22LV10D(ISP) [ISP-HEADER01]  
ispGAL22LV10D@PLCC28 [(SA008A)]  
ispGAL22LV10D@PLCC28(ISP) [ISP-HEADER01]  
ispGAL22LV10D@SSOP28 [(SA626A)]  
ispGAL22LV10D@SSOP28(ISP) [ISP-HEADER01]  
ispGAL22V10AB@PLCC28 [(SA008A)]      ispGAL22V10AB@QFN32  
[(SA686)]  
ispGAL22V10AC@PLCC28 [(SA008A)]      ispGAL22V10AC@QFN32  
[(SA686)]  
ispGAL22V10AV@PLCC28 [(SA008A)]      ispGAL22V10AV@QFN32  
[(SA686)]  
ispGAL22V10C(UES)@PLCC28 [(SA008A)]  
ispGAL22V10C@PLCC28 [(SA008A)]      ispLSI1016@PLCC44  
[(SA244)]  
ispLSI1016@TQFP44 [(SA245A)]      ispLSI1016E@PLCC44  
[(SA244)]  
ispLSI1016E@TQFP44 [(SA245A)]      ispLSI1016EA@PLCC44  
[(SA244)]  
ispLSI1016EA@TQFP44 [(SA245A)]      ispLSI2032@PLCC44  
[(SA244)]  
ispLSI2032@TQFP44 [(SA245A)]      ispLSI2032A@PLCC44  
[(SA244)]  
ispLSI2032A@TQFP44 [(SA245A)]      ispLSI2032A@TQFP48  
[(SA248)]  
ispLSI2032E@PLCC44 [(SA244)]      ispLSI2032E@TQFP44  
[(SA245A)]  
ispLSI2032E@TQFP48 [(SA248)]      ispLSI2032V@PLCC44  
[(SA244)]  
ispLSI2032V@TQFP44 [(SA245A)]      ispLSI2032V@TQFP48  
[(SA248)]  
ispLSI2032VE@PLCC44 [(SA244)]      ispLSI2032VE@TQFP44  
[(SA245A)]  
ispLSI2064A@PLCC44 [(SA244)]      ispLSI2064A@TQFP44  
[(SA245A)]

ispLSI2064V@PLCC44 [(SA244)]	ispLSI2064V@TQFP44
[(SA245A)]	
ispLSI2064VE@PLCC44 [(SA244)]	ispLSI2064VE@TQFP44
[(SA245A)]	
LC4032B@TQFP44 [(SA245A)]	LC4032B@TQFP48
[(SA248)]	
LC4032C@TQFP44 [(SA245A)]	LC4032C@TQFP48
[(SA248)]	
LC4032V@TQFP44 [(SA245A)]	LC4032V@TQFP48
[(SA248)]	
LC4032ZC@csBGA56 [(SA699+B161)]	LC4032ZC@TQFP48
[(SA248)]	
LC4064B@TQFP100(*) [(TA074+B006)]	
LC4064B@TQFP44 [(SA245A)]	LC4064B@TQFP48
[(SA248)]	
LC4064C@TQFP100(*) [(TA074+B006)]	
LC4064C@TQFP44 [(SA245A)]	LC4064C@TQFP48
[(SA248)]	
LC4064V@TQFP100(*) [(TA074+B006)]	
LC4064V@TQFP44 [(SA245A)]	LC4064V@TQFP48
[(SA248)]	
LC4064ZC@csBGA56 [(SA699+B161)]	
LC4064ZC@TQFP100(*) [(TA074+B006)]	
LC4064ZC@TQFP48 [(SA248)]	
LC4128B@TQFP100(*) [(TA074+B006)]	
LC4128B@TQFP128(*) [(SA721+B195)]	
LC4128C@TQFP100(*) [(TA074+B006)]	
LC4128C@TQFP128(*) [(SA721+B195)]	
LC4128V@TQFP100(*) [(TA074+B006)]	
LC4128V@TQFP128(*) [(SA721+B195)]	
LC4128V@TQFP144(*) [(SA681+B14406)]	
LC4128ZC@TQFP100(*) [(TA074+B006)]	
LC4128ZC@TQFP128(*) [(SA721+B195)]	
LC4256B(128I/O)@FBGA256A [(SA800+B269)]	
LC4256B(160I/O)@FBGA256B [(SA800+B269)]	
LC4256B@TQFP100(*) [(TA074+B006)]	
LC4256C(128I/O)@FBGA256A [(SA800+B269)]	
LC4256C(160I/O)@FBGA256B [(SA800+B269)]	
LC4256C@TQFP100(*) [(TA074+B006)]	
LC4256V(128I/O)@FBGA256A [(SA800+B269)]	
LC4256V(160I/O)@FBGA256B [(SA800+B269)]	
LC4256V@TQFP100(*) [(TA074+B006)]	
LC4256V@TQFP144(*) [(SA681+B14406)]	

LC4256ZC@TQFP100(\*) [(TA074+B006)]  
LC4384B@FBGA256 [(SA800+B269)] LC4384C@FBGA256 [(SA800+B269)]  
LC4384V@FBGA256 [(SA800+B269)] LC4512B@FBGA256 [(SA800+B269)]  
LC4512C@FBGA256 [(SA800+B269)] LC4512V@FBGA256 [(SA800+B269)]  
LCMXO1200C-FT256(\*) [(SA800-B208)]  
LCMXO1200C-FT256(ISP) [ISP-HEADER01]  
LCMXO1200C-FT324(ISP) [ISP-HEADER01]  
LCMXO1200C-FTN256(\*) [(SA800-B208)]  
LCMXO1200C-FTN256(ISP) [ISP-HEADER01]  
LCMXO1200C-FTN324(ISP) [ISP-HEADER01]  
LCMXO1200C-M100(ISP) [ISP-HEADER01]  
LCMXO1200C-M132(ISP) [ISP-HEADER01]  
LCMXO1200C-MN100(ISP) [ISP-HEADER01]  
LCMXO1200C-MN132(ISP) [ISP-HEADER01]  
LCMXO1200C-T100(ISP) [ISP-HEADER01]  
LCMXO1200C-T144(\*) [(SA681+B14417)]  
LCMXO1200C-T144(ISP) [ISP-HEADER01]  
LCMXO1200C-TN100(ISP) [ISP-HEADER01]  
LCMXO1200C-TN144(\*) [(SA681+B14417)]  
LCMXO1200C-TN144(ISP) [ISP-HEADER01]  
LCMXO1200E-FT256(\*) [(SA800-B208)]  
LCMXO1200E-FT256(ISP) [ISP-HEADER01]  
LCMXO1200E-FT324(ISP) [ISP-HEADER01]  
LCMXO1200E-FTN256(\*) [(SA800-B208)]  
LCMXO1200E-FTN256(ISP) [ISP-HEADER01]  
LCMXO1200E-FTN324(ISP) [ISP-HEADER01]  
LCMXO1200E-M100(ISP) [ISP-HEADER01]  
LCMXO1200E-M132(ISP) [ISP-HEADER01]  
LCMXO1200E-MN100(ISP) [ISP-HEADER01]  
LCMXO1200E-MN132(ISP) [ISP-HEADER01]  
LCMXO1200E-T100(ISP) [ISP-HEADER01]  
LCMXO1200E-T144(\*) [(SA681+B14417)]  
LCMXO1200E-T144(ISP) [ISP-HEADER01]  
LCMXO1200E-TN100(ISP) [ISP-HEADER01]  
LCMXO1200E-TN144(\*) [(SA681+B14417)]  
LCMXO1200E-TN144(ISP) [ISP-HEADER01]  
LCMXO22800C-FT256(\*) [(SA800-B208)]  
LCMXO22800C-FTN256(\*) [(SA800-B208)]  
LCMXO22800E-FT256(\*) [(SA800-B208)]  
LCMXO22800E-FTN256(\*) [(SA800-B208)]

LCMXO2280C-FT256(ISP) [ISP-HEADER01]  
LCMXO2280C-FT324(ISP) [ISP-HEADER01]  
LCMXO2280C-FTN256(ISP) [ISP-HEADER01]  
LCMXO2280C-FTN324(ISP) [ISP-HEADER01]  
LCMXO2280C-M100(ISP) [ISP-HEADER01]  
LCMXO2280C-M132(ISP) [ISP-HEADER01]  
LCMXO2280C-MN100(ISP) [ISP-HEADER01]  
LCMXO2280C-MN132(ISP) [ISP-HEADER01]  
LCMXO2280C-T100(ISP) [ISP-HEADER01]  
LCMXO2280C-T144(\*) [(SA681+B14417)]  
LCMXO2280C-T144(ISP) [ISP-HEADER01]  
LCMXO2280C-TN100(ISP) [ISP-HEADER01]  
LCMXO2280C-TN144(\*) [(SA681+B14417)]  
LCMXO2280C-TN144(ISP) [ISP-HEADER01]  
LCMXO2280E-FT256(ISP) [ISP-HEADER01]  
LCMXO2280E-FT324(ISP) [ISP-HEADER01]  
LCMXO2280E-FTN256(ISP) [ISP-HEADER01]  
LCMXO2280E-FTN324(ISP) [ISP-HEADER01]  
LCMXO2280E-M100(ISP) [ISP-HEADER01]  
LCMXO2280E-M132(ISP) [ISP-HEADER01]  
LCMXO2280E-MN100(ISP) [ISP-HEADER01]  
LCMXO2280E-MN132(ISP) [ISP-HEADER01]  
LCMXO2280E-T100(ISP) [ISP-HEADER01]  
LCMXO2280E-T144(\*) [(SA681+B14417)]  
LCMXO2280E-T144(ISP) [ISP-HEADER01]  
LCMXO2280E-TN100(ISP) [ISP-HEADER01]  
LCMXO2280E-TN144(\*) [(SA681+B14417)]  
LCMXO2280E-TN144(ISP) [ISP-HEADER01]  
LCMXO256C-FT256(ISP) [ISP-HEADER01]  
LCMXO256C-FT324(ISP) [ISP-HEADER01]  
LCMXO256C-FTN256(ISP) [ISP-HEADER01]  
LCMXO256C-FTN324(ISP) [ISP-HEADER01]  
LCMXO256C-M100(ISP) [ISP-HEADER01]  
LCMXO256C-M132(ISP) [ISP-HEADER01]  
LCMXO256C-MN100(ISP) [ISP-HEADER01]  
LCMXO256C-MN132(ISP) [ISP-HEADER01]  
LCMXO256C-T100(ISP) [ISP-HEADER01]  
LCMXO256C-T144(\*) [(SA681+B14417)]  
LCMXO256C-T144(ISP) [ISP-HEADER01]  
LCMXO256C-TN100(ISP) [ISP-HEADER01]  
LCMXO256C-TN144(\*) [(SA681+B14417)]  
LCMXO256C-TN144(ISP) [ISP-HEADER01]  
LCMXO256E-FT256(ISP) [ISP-HEADER01]

LCMXO256E-FT324(ISP) [ISP-HEADER01]  
LCMXO256E-FTN256(ISP) [ISP-HEADER01]  
LCMXO256E-FTN324(ISP) [ISP-HEADER01]  
LCMXO256E-M100(ISP) [ISP-HEADER01]  
LCMXO256E-M132(ISP) [ISP-HEADER01]  
LCMXO256E-MN100(ISP) [ISP-HEADER01]  
LCMXO256E-MN132(ISP) [ISP-HEADER01]  
LCMXO256E-T100(ISP) [ISP-HEADER01]  
LCMXO256E-T144(\*) [(SA681+B14417)]  
LCMXO256E-T144(ISP) [ISP-HEADER01]  
LCMXO256E-TN100(ISP) [ISP-HEADER01]  
LCMXO256E-TN144(\*) [(SA681+B14417)]  
LCMXO256E-TN144(ISP) [ISP-HEADER01]  
LCMXO640C-FT256(\*) [(SA800-B208)]  
LCMXO640C-FT256(ISP) [ISP-HEADER01]  
LCMXO640C-FT324(ISP) [ISP-HEADER01]  
LCMXO640C-FTN256(\*) [(SA800-B208)]  
LCMXO640C-FTN256(ISP) [ISP-HEADER01]  
LCMXO640C-FTN324(ISP) [ISP-HEADER01]  
LCMXO640C-M100(ISP) [ISP-HEADER01]  
LCMXO640C-M132(ISP) [ISP-HEADER01]  
LCMXO640C-MN100(ISP) [ISP-HEADER01]  
LCMXO640C-MN132(ISP) [ISP-HEADER01]  
LCMXO640C-T100(ISP) [ISP-HEADER01]  
LCMXO640C-T144(\*) [(SA681+B14417)]  
LCMXO640C-T144(ISP) [ISP-HEADER01]  
LCMXO640C-TN100(ISP) [ISP-HEADER01]  
LCMXO640C-TN144(\*) [(SA681+B14417)]  
LCMXO640C-TN144(ISP) [ISP-HEADER01]  
LCMXO640E-FT256(\*) [(SA800-B208)]  
LCMXO640E-FT256(ISP) [ISP-HEADER01]  
LCMXO640E-FT324(ISP) [ISP-HEADER01]  
LCMXO640E-FTN256(\*) [(SA800-B208)]  
LCMXO640E-FTN256(ISP) [ISP-HEADER01]  
LCMXO640E-FTN324(ISP) [ISP-HEADER01]  
LCMXO640E-M100(ISP) [ISP-HEADER01]  
LCMXO640E-M132(ISP) [ISP-HEADER01]  
LCMXO640E-MN100(ISP) [ISP-HEADER01]  
LCMXO640E-MN132(ISP) [ISP-HEADER01]  
LCMXO640E-T100(ISP) [ISP-HEADER01]  
LCMXO640E-T144(\*) [(SA681+B14417)]  
LCMXO640E-T144(ISP) [ISP-HEADER01]  
LCMXO640E-TN100(ISP) [ISP-HEADER01]



LCMXO640E-TN144(\*) [(SA681+B14417)]  
LCMXO640E-TN144(ISP) [ISP-HEADER01]  
LFXP10C-3F256C [(SA800A+B184)]  
LFXP10C-3F256C(ISP) [ISP-HEADER01]  
LFXP10C-3F256I [(SA800A+B184)]  
LFXP10C-3F256I(ISP) [ISP-HEADER01]  
LFXP10C-3F388C(ISP) [ISP-HEADER01]  
LFXP10C-3F388I(ISP) [ISP-HEADER01]  
LFXP10C-3FN256C [(SA800A+B184)]  
LFXP10C-3FN256C(ISP) [ISP-HEADER01]  
LFXP10C-3FN256I [(SA800A+B184)]  
LFXP10C-3FN256I(ISP) [ISP-HEADER01]  
LFXP10C-3FN388C(ISP) [ISP-HEADER01]  
LFXP10C-3FN388I(ISP) [ISP-HEADER01]  
LFXP10C-4F256C [(SA800A+B184)]  
LFXP10C-4F256C(ISP) [ISP-HEADER01]  
LFXP10C-4F256I [(SA800A+B184)]  
LFXP10C-4F256I(ISP) [ISP-HEADER01]  
LFXP10C-4F388C(ISP) [ISP-HEADER01]  
LFXP10C-4F388I(ISP) [ISP-HEADER01]  
LFXP10C-4FN256C [(SA800A+B184)]  
LFXP10C-4FN256C(ISP) [ISP-HEADER01]  
LFXP10C-4FN256I [(SA800A+B184)]  
LFXP10C-4FN256I(ISP) [ISP-HEADER01]  
LFXP10C-4FN388C(ISP) [ISP-HEADER01]  
LFXP10C-4FN388I(ISP) [ISP-HEADER01]  
LFXP10C-5F256C [(SA800A+B184)]  
LFXP10C-5F256C(ISP) [ISP-HEADER01]  
LFXP10C-5F256I [(SA800A+B184)]  
LFXP10C-5F256I(ISP) [ISP-HEADER01]  
LFXP10C-5F388C(ISP) [ISP-HEADER01]  
LFXP10C-5F388I(ISP) [ISP-HEADER01]  
LFXP10C-5FN256C [(SA800A+B184)]  
LFXP10C-5FN256C(ISP) [ISP-HEADER01]  
LFXP10C-5FN256I [(SA800A+B184)]  
LFXP10C-5FN256I(ISP) [ISP-HEADER01]  
LFXP10C-5FN388C(ISP) [ISP-HEADER01]  
LFXP10C-5FN388I(ISP) [ISP-HEADER01]  
LFXP10E-3F256C [(SA800A+B184)]  
LFXP10E-3F256C(ISP) [ISP-HEADER01]  
LFXP10E-3F256I [(SA800A+B184)]  
LFXP10E-3F256I(ISP) [ISP-HEADER01]  
LFXP10E-3F388C(ISP) [ISP-HEADER01]

LFXP10E-3F388I(ISP) [ISP-HEADER01]  
LFXP10E-3FN256C [(SA800A+B184)]  
LFXP10E-3FN256C(ISP) [ISP-HEADER01]  
LFXP10E-3FN256I [(SA800A+B184)]  
LFXP10E-3FN256I(ISP) [ISP-HEADER01]  
LFXP10E-3FN388C(ISP) [ISP-HEADER01]  
LFXP10E-3FN388I(ISP) [ISP-HEADER01]  
LFXP10E-4F256C [(SA800A+B184)]  
LFXP10E-4F256C(ISP) [ISP-HEADER01]  
LFXP10E-4F256I [(SA800A+B184)]  
LFXP10E-4F256I(ISP) [ISP-HEADER01]  
LFXP10E-4F388C(ISP) [ISP-HEADER01]  
LFXP10E-4F388I(ISP) [ISP-HEADER01]  
LFXP10E-4FN256C [(SA800A+B184)]  
LFXP10E-4FN256C(ISP) [ISP-HEADER01]  
LFXP10E-4FN256I [(SA800A+B184)]  
LFXP10E-4FN256I(ISP) [ISP-HEADER01]  
LFXP10E-4FN388C(ISP) [ISP-HEADER01]  
LFXP10E-4FN388I(ISP) [ISP-HEADER01]  
LFXP10E-5F256C [(SA800A+B184)]  
LFXP10E-5F256C(ISP) [ISP-HEADER01]  
LFXP10E-5F256I [(SA800A+B184)]  
LFXP10E-5F256I(ISP) [ISP-HEADER01]  
LFXP10E-5F388C(ISP) [ISP-HEADER01]  
LFXP10E-5F388I(ISP) [ISP-HEADER01]  
LFXP10E-5FN256C [(SA800A+B184)]  
LFXP10E-5FN256C(ISP) [ISP-HEADER01]  
LFXP10E-5FN256I [(SA800A+B184)]  
LFXP10E-5FN256I(ISP) [ISP-HEADER01]  
LFXP10E-5FN388C(ISP) [ISP-HEADER01]  
LFXP10E-5FN388I(ISP) [ISP-HEADER01]  
LFXP15C-3F256C [(SA800A+B184)]  
LFXP15C-3F256C(ISP) [ISP-HEADER01]  
LFXP15C-3F256I [(SA800A+B184)]  
LFXP15C-3F256I(ISP) [ISP-HEADER01]  
LFXP15C-3F388C(ISP) [ISP-HEADER01]  
LFXP15C-3F388I(ISP) [ISP-HEADER01]  
LFXP15C-3F484C(ISP) [ISP-HEADER01]  
LFXP15C-3F484I(ISP) [ISP-HEADER01]  
LFXP15C-3FN256C [(SA800A+B184)]  
LFXP15C-3FN256C(ISP) [ISP-HEADER01]  
LFXP15C-3FN256I [(SA800A+B184)]  
LFXP15C-3FN256I(ISP) [ISP-HEADER01]

LFXP15C-3FN388C(ISP) [ISP-HEADER01]  
LFXP15C-3FN388I(ISP) [ISP-HEADER01]  
LFXP15C-3FN484C(ISP) [ISP-HEADER01]  
LFXP15C-3FN484I(ISP) [ISP-HEADER01]  
LFXP15C-4F256C [(SA800A+B184)]  
LFXP15C-4F256C(ISP) [ISP-HEADER01]  
LFXP15C-4F256I [(SA800A+B184)]  
LFXP15C-4F256I(ISP) [ISP-HEADER01]  
LFXP15C-4F388C(ISP) [ISP-HEADER01]  
LFXP15C-4F388I(ISP) [ISP-HEADER01]  
LFXP15C-4F484C(ISP) [ISP-HEADER01]  
LFXP15C-4F484I(ISP) [ISP-HEADER01]  
LFXP15C-4FN256C [(SA800A+B184)]  
LFXP15C-4FN256C(ISP) [ISP-HEADER01]  
LFXP15C-4FN256I [(SA800A+B184)]  
LFXP15C-4FN256I(ISP) [ISP-HEADER01]  
LFXP15C-4FN388C(ISP) [ISP-HEADER01]  
LFXP15C-4FN388I(ISP) [ISP-HEADER01]  
LFXP15C-4FN484C(ISP) [ISP-HEADER01]  
LFXP15C-4FN484I(ISP) [ISP-HEADER01]  
LFXP15C-5F256C [(SA800A+B184)]  
LFXP15C-5F256C(ISP) [ISP-HEADER01]  
LFXP15C-5F256I [(SA800A+B184)]  
LFXP15C-5F256I(ISP) [ISP-HEADER01]  
LFXP15C-5F388C(ISP) [ISP-HEADER01]  
LFXP15C-5F388I(ISP) [ISP-HEADER01]  
LFXP15C-5F484C(ISP) [ISP-HEADER01]  
LFXP15C-5F484I(ISP) [ISP-HEADER01]  
LFXP15C-5FN256C [(SA800A+B184)]  
LFXP15C-5FN256C(ISP) [ISP-HEADER01]  
LFXP15C-5FN256I [(SA800A+B184)]  
LFXP15C-5FN256I(ISP) [ISP-HEADER01]  
LFXP15C-5FN388C(ISP) [ISP-HEADER01]  
LFXP15C-5FN388I(ISP) [ISP-HEADER01]  
LFXP15C-5FN484C(ISP) [ISP-HEADER01]  
LFXP15C-5FN484I(ISP) [ISP-HEADER01]  
LFXP15E-3F256C [(SA800A+B184)]  
LFXP15E-3F256C(ISP) [ISP-HEADER01]  
LFXP15E-3F256I [(SA800A+B184)]  
LFXP15E-3F256I(ISP) [ISP-HEADER01]  
LFXP15E-3F388C(ISP) [ISP-HEADER01]  
LFXP15E-3F388I(ISP) [ISP-HEADER01]  
LFXP15E-3F484C(ISP) [ISP-HEADER01]

LFXP15E-3F484I(ISP) [ISP-HEADER01]  
LFXP15E-3FN256C [(SA800A+B184)]  
LFXP15E-3FN256C(ISP) [ISP-HEADER01]  
LFXP15E-3FN256I [(SA800A+B184)]  
LFXP15E-3FN256I(ISP) [ISP-HEADER01]  
LFXP15E-3FN388C(ISP) [ISP-HEADER01]  
LFXP15E-3FN388I(ISP) [ISP-HEADER01]  
LFXP15E-3FN484C(ISP) [ISP-HEADER01]  
LFXP15E-3FN484I(ISP) [ISP-HEADER01]  
LFXP15E-4F256C [(SA800A+B184)]  
LFXP15E-4F256C(ISP) [ISP-HEADER01]  
LFXP15E-4F256I [(SA800A+B184)]  
LFXP15E-4F256I(ISP) [ISP-HEADER01]  
LFXP15E-4F388C(ISP) [ISP-HEADER01]  
LFXP15E-4F388I(ISP) [ISP-HEADER01]  
LFXP15E-4F484C(ISP) [ISP-HEADER01]  
LFXP15E-4F484I(ISP) [ISP-HEADER01]  
LFXP15E-4FN256C [(SA800A+B184)]  
LFXP15E-4FN256C(ISP) [ISP-HEADER01]  
LFXP15E-4FN256I [(SA800A+B184)]  
LFXP15E-4FN256I(ISP) [ISP-HEADER01]  
LFXP15E-4FN388C(ISP) [ISP-HEADER01]  
LFXP15E-4FN388I(ISP) [ISP-HEADER01]  
LFXP15E-4FN484C(ISP) [ISP-HEADER01]  
LFXP15E-4FN484I(ISP) [ISP-HEADER01]  
LFXP15E-5F256C [(SA800A+B184)]  
LFXP15E-5F256C(ISP) [ISP-HEADER01]  
LFXP15E-5F256I [(SA800A+B184)]  
LFXP15E-5F256I(ISP) [ISP-HEADER01]  
LFXP15E-5F388C(ISP) [ISP-HEADER01]  
LFXP15E-5F388I(ISP) [ISP-HEADER01]  
LFXP15E-5F484C(ISP) [ISP-HEADER01]  
LFXP15E-5F484I(ISP) [ISP-HEADER01]  
LFXP15E-5FN256C [(SA800A+B184)]  
LFXP15E-5FN256C(ISP) [ISP-HEADER01]  
LFXP15E-5FN256I [(SA800A+B184)]  
LFXP15E-5FN256I(ISP) [ISP-HEADER01]  
LFXP15E-5FN388C(ISP) [ISP-HEADER01]  
LFXP15E-5FN388I(ISP) [ISP-HEADER01]  
LFXP15E-5FN484C(ISP) [ISP-HEADER01]  
LFXP15E-5FN484I(ISP) [ISP-HEADER01]  
LFXP20C-3F256C [(SA800A+B184)]  
LFXP20C-3F256C(ISP) [ISP-HEADER01]

LFXP20C-3F256I [(SA800A+B184)]  
LFXP20C-3F256I(ISP) [ISP-HEADER01]  
LFXP20C-3F388C(ISP) [ISP-HEADER01]  
LFXP20C-3F388I(ISP) [ISP-HEADER01]  
LFXP20C-3F484C(ISP) [ISP-HEADER01]  
LFXP20C-3F484I(ISP) [ISP-HEADER01]  
LFXP20C-3FN256C [(SA800A+B184)]  
LFXP20C-3FN256C(ISP) [ISP-HEADER01]  
LFXP20C-3FN256I [(SA800A+B184)]  
LFXP20C-3FN256I(ISP) [ISP-HEADER01]  
LFXP20C-3FN388C(ISP) [ISP-HEADER01]  
LFXP20C-3FN388I(ISP) [ISP-HEADER01]  
LFXP20C-3FN484C(ISP) [ISP-HEADER01]  
LFXP20C-3FN484I(ISP) [ISP-HEADER01]  
LFXP20C-4F256C [(SA800A+B184)]  
LFXP20C-4F256C(ISP) [ISP-HEADER01]  
LFXP20C-4F256I [(SA800A+B184)]  
LFXP20C-4F256I(ISP) [ISP-HEADER01]  
LFXP20C-4F388C(ISP) [ISP-HEADER01]  
LFXP20C-4F388I(ISP) [ISP-HEADER01]  
LFXP20C-4F484C(ISP) [ISP-HEADER01]  
LFXP20C-4F484I(ISP) [ISP-HEADER01]  
LFXP20C-4FN256C [(SA800A+B184)]  
LFXP20C-4FN256C(ISP) [ISP-HEADER01]  
LFXP20C-4FN256I [(SA800A+B184)]  
LFXP20C-4FN256I(ISP) [ISP-HEADER01]  
LFXP20C-4FN388C(ISP) [ISP-HEADER01]  
LFXP20C-4FN388I(ISP) [ISP-HEADER01]  
LFXP20C-4FN484C(ISP) [ISP-HEADER01]  
LFXP20C-4FN484I(ISP) [ISP-HEADER01]  
LFXP20C-5F256C [(SA800A+B184)]  
LFXP20C-5F256C(ISP) [ISP-HEADER01]  
LFXP20C-5F256I [(SA800A+B184)]  
LFXP20C-5F256I(ISP) [ISP-HEADER01]  
LFXP20C-5F388C(ISP) [ISP-HEADER01]  
LFXP20C-5F388I(ISP) [ISP-HEADER01]  
LFXP20C-5F484C(ISP) [ISP-HEADER01]  
LFXP20C-5F484I(ISP) [ISP-HEADER01]  
LFXP20C-5FN256C [(SA800A+B184)]  
LFXP20C-5FN256C(ISP) [ISP-HEADER01]  
LFXP20C-5FN256I [(SA800A+B184)]  
LFXP20C-5FN256I(ISP) [ISP-HEADER01]  
LFXP20C-5FN388C(ISP) [ISP-HEADER01]

LFXP20C-5FN388I (ISP) [ISP-HEADER01]  
LFXP20C-5FN484C (ISP) [ISP-HEADER01]  
LFXP20C-5FN484I (ISP) [ISP-HEADER01]  
LFXP20E-3F256C [(SA800A+B184)]  
LFXP20E-3F256C (ISP) [ISP-HEADER01]  
LFXP20E-3F256I [(SA800A+B184)]  
LFXP20E-3F256I (ISP) [ISP-HEADER01]  
LFXP20E-3F388C (ISP) [ISP-HEADER01]  
LFXP20E-3F388I (ISP) [ISP-HEADER01]  
LFXP20E-3F484C (ISP) [ISP-HEADER01]  
LFXP20E-3F484I (ISP) [ISP-HEADER01]  
LFXP20E-3FN256C [(SA800A+B184)]  
LFXP20E-3FN256C (ISP) [ISP-HEADER01]  
LFXP20E-3FN256I [(SA800A+B184)]  
LFXP20E-3FN256I (ISP) [ISP-HEADER01]  
LFXP20E-3FN388C (ISP) [ISP-HEADER01]  
LFXP20E-3FN388I (ISP) [ISP-HEADER01]  
LFXP20E-3FN484C (ISP) [ISP-HEADER01]  
LFXP20E-3FN484I (ISP) [ISP-HEADER01]  
LFXP20E-4F256C [(SA800A+B184)]  
LFXP20E-4F256C (ISP) [ISP-HEADER01]  
LFXP20E-4F256I [(SA800A+B184)]  
LFXP20E-4F256I (ISP) [ISP-HEADER01]  
LFXP20E-4F388C (ISP) [ISP-HEADER01]  
LFXP20E-4F388I (ISP) [ISP-HEADER01]  
LFXP20E-4F484C (ISP) [ISP-HEADER01]  
LFXP20E-4F484I (ISP) [ISP-HEADER01]  
LFXP20E-4FN256C [(SA800A+B184)]  
LFXP20E-4FN256C (ISP) [ISP-HEADER01]  
LFXP20E-4FN256I [(SA800A+B184)]  
LFXP20E-4FN256I (ISP) [ISP-HEADER01]  
LFXP20E-4FN388C (ISP) [ISP-HEADER01]  
LFXP20E-4FN388I (ISP) [ISP-HEADER01]  
LFXP20E-4FN484C (ISP) [ISP-HEADER01]  
LFXP20E-4FN484I (ISP) [ISP-HEADER01]  
LFXP20E-5F256C [(SA800A+B184)]  
LFXP20E-5F256C (ISP) [ISP-HEADER01]  
LFXP20E-5F256I [(SA800A+B184)]  
LFXP20E-5F256I (ISP) [ISP-HEADER01]  
LFXP20E-5F388C (ISP) [ISP-HEADER01]  
LFXP20E-5F388I (ISP) [ISP-HEADER01]  
LFXP20E-5F484C (ISP) [ISP-HEADER01]  
LFXP20E-5F484I (ISP) [ISP-HEADER01]

LFXP20E-5FN256C [(SA800A+B184)]  
LFXP20E-5FN256C(ISP) [ISP-HEADER01]  
LFXP20E-5FN256I [(SA800A+B184)]  
LFXP20E-5FN256I(ISP) [ISP-HEADER01]  
LFXP20E-5FN388C(ISP) [ISP-HEADER01]  
LFXP20E-5FN388I(ISP) [ISP-HEADER01]  
LFXP20E-5FN484C(ISP) [ISP-HEADER01]  
LFXP20E-5FN484I(ISP) [ISP-HEADER01]  
LFXP3C-3Q208C(ISP) [ISP-HEADER01]  
LFXP3C-3Q208I(ISP) [ISP-HEADER01]  
LFXP3C-3QN208C(ISP) [ISP-HEADER01]  
LFXP3C-3QN208I(ISP) [ISP-HEADER01]  
LFXP3C-3T100C(ISP) [ISP-HEADER01]  
LFXP3C-3T100I(ISP) [ISP-HEADER01]  
LFXP3C-3T144C(ISP) [ISP-HEADER01]  
LFXP3C-3T144I(ISP) [ISP-HEADER01]  
LFXP3C-3TN100C(ISP) [ISP-HEADER01]  
LFXP3C-3TN100I(ISP) [ISP-HEADER01]  
LFXP3C-3TN144C(ISP) [ISP-HEADER01]  
LFXP3C-3TN144I(ISP) [ISP-HEADER01]  
LFXP3C-4Q208C(ISP) [ISP-HEADER01]  
LFXP3C-4Q208I(ISP) [ISP-HEADER01]  
LFXP3C-4QN208C(ISP) [ISP-HEADER01]  
LFXP3C-4QN208I(ISP) [ISP-HEADER01]  
LFXP3C-4T100C(ISP) [ISP-HEADER01]  
LFXP3C-4T100I(ISP) [ISP-HEADER01]  
LFXP3C-4T144C(ISP) [ISP-HEADER01]  
LFXP3C-4T144I(ISP) [ISP-HEADER01]  
LFXP3C-4TN100C(ISP) [ISP-HEADER01]  
LFXP3C-4TN100I(ISP) [ISP-HEADER01]  
LFXP3C-4TN144C(ISP) [ISP-HEADER01]  
LFXP3C-4TN144I(ISP) [ISP-HEADER01]  
LFXP3C-5Q208C(ISP) [ISP-HEADER01]  
LFXP3C-5Q208I(ISP) [ISP-HEADER01]  
LFXP3C-5QN208C(ISP) [ISP-HEADER01]  
LFXP3C-5QN208I(ISP) [ISP-HEADER01]  
LFXP3C-5T100C(ISP) [ISP-HEADER01]  
LFXP3C-5T100I(ISP) [ISP-HEADER01]  
LFXP3C-5T144C(ISP) [ISP-HEADER01]  
LFXP3C-5T144I(ISP) [ISP-HEADER01]  
LFXP3C-5TN100C(ISP) [ISP-HEADER01]  
LFXP3C-5TN100I(ISP) [ISP-HEADER01]  
LFXP3C-5TN144C(ISP) [ISP-HEADER01]

LFXP3C-5TN144I (ISP) [ISP-HEADER01]  
LFXP3E-3Q208C (ISP) [ISP-HEADER01]  
LFXP3E-3Q208I (ISP) [ISP-HEADER01]  
LFXP3E-3QN208C (ISP) [ISP-HEADER01]  
LFXP3E-3QN208I (ISP) [ISP-HEADER01]  
LFXP3E-3T100C (ISP) [ISP-HEADER01]  
LFXP3E-3T100I (ISP) [ISP-HEADER01]  
LFXP3E-3T144C (ISP) [ISP-HEADER01]  
LFXP3E-3T144I (ISP) [ISP-HEADER01]  
LFXP3E-3TN100C (ISP) [ISP-HEADER01]  
LFXP3E-3TN100I (ISP) [ISP-HEADER01]  
LFXP3E-3TN144C (ISP) [ISP-HEADER01]  
LFXP3E-3TN144I (ISP) [ISP-HEADER01]  
LFXP3E-4Q208C (ISP) [ISP-HEADER01]  
LFXP3E-4Q208I (ISP) [ISP-HEADER01]  
LFXP3E-4QN208C (ISP) [ISP-HEADER01]  
LFXP3E-4QN208I (ISP) [ISP-HEADER01]  
LFXP3E-4T100C (ISP) [ISP-HEADER01]  
LFXP3E-4T100I (ISP) [ISP-HEADER01]  
LFXP3E-4T144C (ISP) [ISP-HEADER01]  
LFXP3E-4T144I (ISP) [ISP-HEADER01]  
LFXP3E-4TN100C (ISP) [ISP-HEADER01]  
LFXP3E-4TN100I (ISP) [ISP-HEADER01]  
LFXP3E-4TN144C (ISP) [ISP-HEADER01]  
LFXP3E-4TN144I (ISP) [ISP-HEADER01]  
LFXP3E-5Q208C (ISP) [ISP-HEADER01]  
LFXP3E-5Q208I (ISP) [ISP-HEADER01]  
LFXP3E-5QN208C (ISP) [ISP-HEADER01]  
LFXP3E-5QN208I (ISP) [ISP-HEADER01]  
LFXP3E-5T100C (ISP) [ISP-HEADER01]  
LFXP3E-5T100I (ISP) [ISP-HEADER01]  
LFXP3E-5T144C (ISP) [ISP-HEADER01]  
LFXP3E-5T144I (ISP) [ISP-HEADER01]  
LFXP3E-5TN100C (ISP) [ISP-HEADER01]  
LFXP3E-5TN100I (ISP) [ISP-HEADER01]  
LFXP3E-5TN144C (ISP) [ISP-HEADER01]  
LFXP3E-5TN144I (ISP) [ISP-HEADER01]  
LFXP6C-3F256C [(SA800A+B184)]  
LFXP6C-3F256C (ISP) [ISP-HEADER01]  
LFXP6C-3F256I [(SA800A+B184)]  
LFXP6C-3F256I (ISP) [ISP-HEADER01]  
LFXP6C-3FN256C [(SA800A+B184)]  
LFXP6C-3FN256C (ISP) [ISP-HEADER01]



LFXP6C-3FN256I [(SA800A+B184)]  
LFXP6C-3FN256I(ISP) [ISP-HEADER01]  
LFXP6C-3Q208C(ISP) [ISP-HEADER01]  
LFXP6C-3Q208I(ISP) [ISP-HEADER01]  
LFXP6C-3QN208C(ISP) [ISP-HEADER01]  
LFXP6C-3QN208I(ISP) [ISP-HEADER01]  
LFXP6C-3T144C(\*) [(SA681+B14407)]  
LFXP6C-3T144C(ISP) [ISP-HEADER01]  
LFXP6C-3T144I(\*) [(SA681+B14407)]  
LFXP6C-3T144I(ISP) [ISP-HEADER01]  
LFXP6C-3TN144C(\*) [(SA681+B14407)]  
LFXP6C-3TN144C(ISP) [ISP-HEADER01]  
LFXP6C-3TN144I(\*) [(SA681+B14407)]  
LFXP6C-3TN144I(ISP) [ISP-HEADER01]  
LFXP6C-4F256C [(SA800A+B184)]  
LFXP6C-4F256C(ISP) [ISP-HEADER01]  
LFXP6C-4F256I [(SA800A+B184)]  
LFXP6C-4F256I(ISP) [ISP-HEADER01]  
LFXP6C-4FN256C [(SA800A+B184)]  
LFXP6C-4FN256C(ISP) [ISP-HEADER01]  
LFXP6C-4FN256I [(SA800A+B184)]  
LFXP6C-4FN256I(ISP) [ISP-HEADER01]  
LFXP6C-4Q208C(ISP) [ISP-HEADER01]  
LFXP6C-4Q208I(ISP) [ISP-HEADER01]  
LFXP6C-4QN208C(ISP) [ISP-HEADER01]  
LFXP6C-4QN208I(ISP) [ISP-HEADER01]  
LFXP6C-4T144C(ISP) [ISP-HEADER01]  
LFXP6C-4T144I(ISP) [ISP-HEADER01]  
LFXP6C-4TN144C(ISP) [ISP-HEADER01]  
LFXP6C-4TN144I(ISP) [ISP-HEADER01]  
LFXP6C-5F256C [(SA800A+B184)]  
LFXP6C-5F256C(ISP) [ISP-HEADER01]  
LFXP6C-5F256I [(SA800A+B184)]  
LFXP6C-5F256I(ISP) [ISP-HEADER01]  
LFXP6C-5FN256C [(SA800A+B184)]  
LFXP6C-5FN256C(ISP) [ISP-HEADER01]  
LFXP6C-5FN256I [(SA800A+B184)]  
LFXP6C-5FN256I(ISP) [ISP-HEADER01]  
LFXP6C-5Q208C(ISP) [ISP-HEADER01]  
LFXP6C-5Q208I(ISP) [ISP-HEADER01]  
LFXP6C-5QN208C(ISP) [ISP-HEADER01]  
LFXP6C-5QN208I(ISP) [ISP-HEADER01]  
LFXP6C-5T144C(ISP) [ISP-HEADER01]

LFXP6C-5T144I(ISP) [ISP-HEADER01]  
LFXP6C-5TN144C(ISP) [ISP-HEADER01]  
LFXP6C-5TN144I(ISP) [ISP-HEADER01]  
LFXP6E-3F256C [(SA800A+B184)]  
LFXP6E-3F256C(ISP) [ISP-HEADER01]  
LFXP6E-3F256I [(SA800A+B184)]  
LFXP6E-3F256I(ISP) [ISP-HEADER01]  
LFXP6E-3FN256C [(SA800A+B184)]  
LFXP6E-3FN256C(ISP) [ISP-HEADER01]  
LFXP6E-3FN256I [(SA800A+B184)]  
LFXP6E-3FN256I(ISP) [ISP-HEADER01]  
LFXP6E-3Q208C(ISP) [ISP-HEADER01]  
LFXP6E-3Q208I(ISP) [ISP-HEADER01]  
LFXP6E-3QN208C(ISP) [ISP-HEADER01]  
LFXP6E-3QN208I(ISP) [ISP-HEADER01]  
LFXP6E-3T144C(ISP) [ISP-HEADER01]  
LFXP6E-3T144I(ISP) [ISP-HEADER01]  
LFXP6E-3TN144C(ISP) [ISP-HEADER01]  
LFXP6E-3TN144I(ISP) [ISP-HEADER01]  
LFXP6E-4F256C [(SA800A+B184)]  
LFXP6E-4F256C(ISP) [ISP-HEADER01]  
LFXP6E-4F256I [(SA800A+B184)]  
LFXP6E-4F256I(ISP) [ISP-HEADER01]  
LFXP6E-4FN256C [(SA800A+B184)]  
LFXP6E-4FN256C(ISP) [ISP-HEADER01]  
LFXP6E-4FN256I [(SA800A+B184)]  
LFXP6E-4FN256I(ISP) [ISP-HEADER01]  
LFXP6E-4Q208C(ISP) [ISP-HEADER01]  
LFXP6E-4Q208I(ISP) [ISP-HEADER01]  
LFXP6E-4QN208C(ISP) [ISP-HEADER01]  
LFXP6E-4QN208I(ISP) [ISP-HEADER01]  
LFXP6E-4T144C(ISP) [ISP-HEADER01]  
LFXP6E-4T144I(ISP) [ISP-HEADER01]  
LFXP6E-4TN144C(ISP) [ISP-HEADER01]  
LFXP6E-4TN144I(ISP) [ISP-HEADER01]  
LFXP6E-5F256C [(SA800A+B184)]  
LFXP6E-5F256C(ISP) [ISP-HEADER01]  
LFXP6E-5F256I [(SA800A+B184)]  
LFXP6E-5F256I(ISP) [ISP-HEADER01]  
LFXP6E-5FN256C [(SA800A+B184)]  
LFXP6E-5FN256C(ISP) [ISP-HEADER01]  
LFXP6E-5FN256I [(SA800A+B184)]  
LFXP6E-5FN256I(ISP) [ISP-HEADER01]

LFXP6E-5Q208C( ISP) [ ISP-HEADER01 ]	
LFXP6E-5Q208I( ISP) [ ISP-HEADER01 ]	
LFXP6E-5QN208C( ISP) [ ISP-HEADER01 ]	
LFXP6E-5QN208I( ISP) [ ISP-HEADER01 ]	
LFXP6E-5T144C( ISP) [ ISP-HEADER01 ]	
LFXP6E-5T144I( ISP) [ ISP-HEADER01 ]	
LFXP6E-5TN144C( ISP) [ ISP-HEADER01 ]	
LFXP6E-5TN144I( ISP) [ ISP-HEADER01 ]	
M4A3-32/32@PLCC44 [ (SA244) ]	M4A3-32/32@TQFP44
[ (SA245A) ]	
M4A3-32/32@TQFP48 [ (SA248) ]	M4A3-64/32@PLCC44
[ (SA244) ]	
M4A3-64/32@TQFP44 [ (SA245A) ]	M4A3-64/32@TQFP48
[ (SA248) ]	
M4A5-32/32@PLCC44 [ (SA244) ]	M4A5-32/32@TQFP44
[ (SA245A) ]	
M4A5-32/32@TQFP48 [ (SA248) ]	M4A5-64/32@PLCC44
[ (SA244) ]	
M4A5-64/32@TQFP44 [ (SA245A) ]	M4A5-64/32@TQFP48
[ (SA248) ]	
MACH110@PLCC44 [ (SA244) ]	
PALCE20RA10	
PALCE20RA10@PLCC28 [ (SA008A) ]	PALCE20RA10@SOIC24
[ (SA404) ]	
PALCE20RA10H	PALCE20RA10H@PLCC28
[ (SA008A) ]	
PALCE20RA10H@SOIC24 [ (SA404) ]	
PALCE20RA10Q	
PALCE20RA10Q@PLCC28 [ (SA008A) ]	PALCE20RA10Q@SOIC24
[ (SA404) ]	
PALCE22V10H	PALCE22V10H@PLCC28
[ (SA008A) ]	
PALCE22V10H@SOIC24 [ (SA404) ]	
PALCE22V10Q	
PALCE22V10Q@PLCC28 [ (SA008A) ]	PALCE22V10Q@SOIC24
[ (SA404) ]	
PALCE22V10Z	PALCE22V10Z@PLCC28
[ (SA008A) ]	
PALCE22V10Z@SOIC24 [ (SA404) ]	

**LG Semicon**

**DRAM & SRAM**

GM76C256CL [ (SA430T) ]	GM76C256CL@SSOP28
GM76C256CL@TSOP28 [ (SA630) ]	
GM76C256CLL GM76C256CLL@SSOP28 [ (SA430T) ] [ (SA630) ]	GM76C256CLL@TSOP28
GM76C8128CL [ (SA438T) ]	GM76C8128CL@SSOP32
GM76C8128CL@TSOP32 [ (SA410T) ] [ (SA620) ]	GM76C8128CL@VSOP32
GM76C8128CLL [ (SA438T) ]	GM76C8128CLL@SSOP32
GM76C8128CLL@TSOP32 [ (SA410T) ] [ (SA620) ]	GM76C8128CLL@VSOP32
GM76C88AL [ (SA430T) ]	GM76C88AL@SSOP28
GM76C88AL@TSOP28 [ (SA643) ]	
GM76U256CL GM76U256CL@SSOP28 [ (SA430T) ] [ (SA643) ]	GM76U256CL@TSOP28
GM76U256CLL [ (SA430T) ]	GM76U256CLL@SSOP28
GM76U256CLL@TSOP28 [ (SA643) ]	
GM76U8128CL GM76U8128CL@SSOP32 [ (SA438T) ] [ (SA410T) ]	GM76U8128CL@TSOP32
GM76U8128CL@VSOP32 [ (SA620) ]	
GM76U8128CLL GM76U8128CLL@SSOP32 [ (SA438T) ] [ (SA410T) ]	GM76U8128CLL@TSOP32
GM76U8128CLL@VSOP32 [ (SA620) ]	
GM76U8128DL GM76U8128DL@SSOP32 [ (SA438T) ] [ (SA410T) ]	GM76U8128DL@TSOP32
GM76U8128DL@VSOP32 [ (SA620) ]	
GM76U8128DLL GM76U8128DLL@SSOP32 [ (SA438T) ] [ (SA410T) ]	GM76U8128DLL@TSOP32
GM76U8128DLL@VSOP32 [ (SA620) ]	
GM76U8512L GM76U8512L@SSOP32 [ (SA438T) ]	GM76U8512L@TSOP32

[ (SA410T) ]	
GM76U8512L@VSOP32 [ (SA620) ]	
GM76U8512LL	
GM76U8512LL@SSOP32 [ (SA438T) ]	GM76U8512LL@TSOP32
[ (SA410T) ]	
GM76U8512LL@VSOP32 [ (SA620) ]	
GM76V256CL	
GM76V256CL@SSOP28 [ (SA430T) ]	GM76V256CL@TSOP28
[ (SA630) ]	
GM76V256CLL	
[ (SA430T) ]	
GM76V256CLL@TSOP28 [ (SA630) ]	
GM76V8128CL	
GM76V8128CL@SSOP32 [ (SA438T) ]	GM76V8128CL@TSOP32
[ (SA410T) ]	
GM76V8128CL@VSOP32 [ (SA620) ]	
GM76V8128CLL	
GM76V8128CLL@SSOP32 [ (SA438T) ]	GM76V8128CLL@TSOP32
[ (SA410T) ]	
GM76V8128CLL@VSOP32 [ (SA620) ]	
GM76V8128DL	
GM76V8128DL@SSOP32 [ (SA438T) ]	GM76V8128DL@TSOP32
[ (SA410T) ]	
GM76V8128DL@VSOP32 [ (SA620) ]	
GM76V8128DLL	
GM76V8128DLL@SSOP32 [ (SA438T) ]	GM76V8128DLL@TSOP32
[ (SA410T) ]	
GM76V8128DLL@VSOP32 [ (SA620) ]	
GM76V8512L	
GM76V8512L@SSOP32 [ (SA438T) ]	GM76V8512L@TSOP32
[ (SA410T) ]	
GM76V8512L@VSOP32 [ (SA620) ]	
GM76V8512LL	
GM76V8512LL@SSOP32 [ (SA438T) ]	GM76V8512LL@TSOP32
[ (SA410T) ]	
GM76V8512LL@VSOP32 [ (SA620) ]	
GM77C8128A	
GM77C8128A@SSOP32 [ (SA438T) ]	GM77C8128A@TSOP32
[ (SA410T) ]	
GM77C8128A@VSOP32 [ (SA620) ]	

**MICROCONTROLLER**

GMS97C1051 [ ( SA404 ) ]	GMS97C1051@SOIC20
GMS97C2051 [ ( SA404 ) ]	GMS97C2051@SOIC20
GMS97C51 [ ( SA244 ) ]	GMS97C51@PLCC44
GMS97C51@TQFP44 [ ( SA245A ) ]	
GMS97C52 GMS97C52@PLCC44 [ ( SA244 ) ]	GMS97C52@TQFP44
[ ( SA245A ) ]	
GMS97C54 [ ( SA244 ) ]	GMS97C54@PLCC44
GMS97C54@TQFP44 [ ( SA245A ) ]	
GMS97C56 GMS97C56@PLCC44 [ ( SA244 ) ]	GMS97C56@TQFP44
[ ( SA245A ) ]	
GMS97C58 [ ( SA244 ) ]	GMS97C58@PLCC44
GMS97C58@TQFP44 [ ( SA245A ) ]	
GMS97L1051 GMS97L1051@SOIC20 [ ( SA404 ) ]	
GMS97L2051 GMS97L2051@SOIC20 [ ( SA404 ) ]	
GMS97L51 GMS97L51@PLCC44 [ ( SA244 ) ]	GMS97L51@TQFP44
[ ( SA245A ) ]	
GMS97L52 [ ( SA244 ) ]	GMS97L52@PLCC44
GMS97L52@TQFP44 [ ( SA245A ) ]	
GMS97L54 GMS97L54@PLCC44 [ ( SA244 ) ]	GMS97L54@TQFP44
[ ( SA245A ) ]	
GMS97L56 [ ( SA244 ) ]	GMS97L56@PLCC44
GMS97L56@TQFP44 [ ( SA245A ) ]	
GMS97L58 GMS97L58@PLCC44 [ ( SA244 ) ]	GMS97L58@TQFP44
[ ( SA245A ) ]	
GMS99C52 [ ( SA244 ) ]	GMS99C52@PLCC44
GMS99C52@TQFP44 [ ( SA245A ) ]	
GMS99C58	

GMS99C58@PLCC44 [ (SA244) ]  
[ (SA245A) ]

GMS99C58@TQFP44

## LINKSMART

### E ( E ) PROM / FRAM / NVRAM

L24C02  
[ (SA602A) ]  
L24C02@TSOP8 [ (SA026) ]  
L24C04  
L24C04@SSOP8 [ (SA602A) ]  
[ (SA026) ]  
L29004C  
[ (SA015A1T) ]  
L29004C@TSOP32 [ (SA620) ]  
B005 ]  
L29S160F-B@TSOP48 [ (SA247-B005) ]  
[ (SA638) ]  
L29S400F@TSOP48 [ (SA247-B005) ]  
[ (SA638) ]  
L29S400F-B@TSOP48 [ (SA247-B005) ]  
B005 ]  
L29S800F-B@TSOP48 [ (SA247-B005) ]  
B005 ]  
L29W800E-B@TSOP48 [ (SA247-B005) ]  
LST28001  
LST28001@PLCC32 [ (SA015A1T) ]  
[ (SA620) ]  
LST28002  
[ (SA015A1T) ]  
LST28002@TSOP32 [ (SA620) ]  
LST28004  
LST28004@PLCC32 [ (SA015A1T) ]  
[ (SA620) ]

L24C02@SSOP8  
  
L24C04@TSOP8  
  
L29004C@PLCC32  
  
L29S160F@TSOP48 [ (SA247-  
L29S400F@PSOP44  
  
L29S400F-B@PSOP44  
  
L29S800F@TSOP48 [ (SA247-  
L29W800E@TSOP48 [ (SA247-  
  
LST28001@TSOP32  
  
LST28002@PLCC32  
  
LST28004@TSOP32

## MACRONIX

### E ( E ) PROM / FRAM / NVRAM





[ (SA438T) ]  
KH25L3205@SOP16 [ (SA404) ]  
KH25L3205@SOP16(Fast Mode) [ (SA404) ]  
KH25L3205@SOP8 [ (SA023A) ]  
KH25L3205@SOP8(Fast Mode) [ (SA023A) ]  
KH25L3205A@SON8 [ (SA684) ]  
KH25L3205A@SON8(Fast Mode) [ (SA684) ]  
KH25L3205A@SOP16 [ (SA404) ]  
KH25L3205A@SOP16(Fast Mode) [ (SA404) ]  
KH25L3205A@SOP8 [ (SA023A) ]  
KH25L3205A@SOP8(Fast Mode) [ (SA023A) ]  
KH25L3205D@SON8(Fast Mode) [ (SA683) ]  
KH25L3205D@SOP16 [ (SA404) ]  
KH25L3205D@SOP16(Fast Mode) [ (SA404) ]  
KH25L3205D@SOP8 [ (SA023A) ]  
KH25L3205D@SOP8(Fast Mode) [ (SA605B) ]  
KH25L3236DM2I@SOP8 [ (SA605B) ]                    KH25L3236DMI@SOP16  
[ (SA404) ]  
KH25L3236DZNI@WSON8 [ (SA683) ]  
KH25L4005  
KH25L4005(150mil)@SOP8 [ (SA602A) ]  
KH25L4005(150mil)@SOP8(ISP) [ ISP-HEADER01 ]  
KH25L4005(209mil)@SOP8 [ (SA023A) ]  
KH25L4005(209mil)@SOP8(ISP) [ ISP-HEADER01 ]  
KH25L4005(ISP) [ ISP-HEADER01 ]                    KH25L4005@SON8  
[ (SA683) ]  
KH25L4005@SON8(ISP) [ ISP-HEADER01 ]  
KH25L4005A  
KH25L4005A(150mil)@SOP8 [ (SA602A) ]  
KH25L4005A(150mil)@SOP8(ISP) [ ISP-HEADER01 ]  
KH25L4005A(209mil)@SOP8 [ (SA023A) ]  
KH25L4005A(209mil)@SOP8(ISP) [ ISP-HEADER01 ]  
KH25L4005A(ISP) [ ISP-HEADER01 ]                    KH25L4005A@SON8  
[ (SA683) ]  
KH25L4005A@SON8(ISP) [ ISP-HEADER01 ]  
KH25L4025A  
KH25L4025A(150mil)@SOP8 [ (SA602A) ]  
KH25L4025A(209mil)@SOP8 [ (SA023A) ]  
KH25L4025A@SON8 [ (SA683) ]                    KH25L512@SON8  
[ (SA683) ]  
KH25L512@SOP8 [ (SA602A) ]  
KH25L512A  
KH25L512A@SON8 [ (SA683) ]                    KH25L512A@SOP8

[(SA602A)]  
 KH25L6402@SOP32 [(SA438T)] KH25L6402A@SOP28  
 [(SA630)]  
 KH25L6405@SOP16 [(SA404)]  
 KH25L6405@SOP16(Fast Mode) [(SA404)]  
 KH25L6405@SOP8 [(SA023A)]  
 KH25L6405@SOP8(Fast Mode) [(SA023A)]  
 KH25L6405D@SON8(Fast Mode) [(SA684)]  
 KH25L6405D@SOP16 [(SA404)]  
 KH25L6405D@SOP16(Fast Mode) [(SA404)]  
 KH25L6405D@SOP8 [(SA023A)]  
 KH25L8005  
 KH25L8005(150mil)@SOP8 [(SA602A)]  
 KH25L8005(150mil)@SOP8(ISP) [ISP-HEADER01]  
 KH25L8005(209mil)@SOP8 [(SA023A)]  
 KH25L8005(209mil)@SOP8(ISP) [ISP-HEADER01]  
 KH25L8005(ISP) [ISP-HEADER01] KH25L8005@SON8  
 [(SA683)]  
 KH25L8005@SON8(ISP) [ISP-HEADER01]  
 KH25L802@SOP28 [(SA630)]  
 KH25L8025  
 KH25L8025(150mil)@SOP8 [(SA602A)]  
 KH25L8025(209mil)@SOP8 [(SA023A)]  
 KH25L8025@SON8 [(SA683)]  
 KH25L8036D  
 KH25L8036D@SOP16 [(SA404)]  
 KH25L8036D@SOP8[150 mil] [(SA602A)]  
 KH25L8036D@SOP8[200 mil] [(SA023A)]  
 KH25L8036D@WSON8 [(SA683)] KH29LV004CB@PLCC32  
 [(SA015A1T)]  
 KH29LV004CB@TSOP40 [(SA409T)] KH29LV004CT@PLCC32  
 [(SA015A1T)]  
 KH29LV004CT@TSOP40 [(SA409T)] KH29LV008CB@TSOP40  
 [(SA409T)]  
 KH29LV008CT@TSOP40 [(SA409T)]  
 KH29LV040C  
 KH29LV040C@PLCC32 [(SA015A1T)]  
 KH29LV160CBT@TSOP48 [(SA247-B005)]  
 KH29LV160CTT@TSOP48 [(SA247-B005)]  
 KH29LV320CBT@TSOP48 [(SA247-B005)]  
 KH29LV320CTT@TSOP48 [(SA247-B005)]  
 KH29LV320DBT@TSOP48 [(SA247-B005)]  
 KH29LV320DTT@TSOP48 [(SA247-B005)]

KH29LV400CBT@TSOP48 [(SA247-B005)]  
KH29LV400CTT@TSOP48 [(SA247-B005)]  
KH29LV640DBT@TSOP48 [(SA247-B005)]  
KH29LV640DTT@TSOP48 [(SA247-B005)]  
KH29LV800CBT@TSOP48 [(SA247-B005)]  
KH29LV800CTT@TSOP48 [(SA247-B005)]  
MX25L1005  
HEADER01] MX25L1005(ISP) [ISP-  
MX25L1005@SON8 [(SA683)]  
MX25L1005@SON8(ISP) [ISP-HEADER01]  
MX25L1005@SOP8 [(SA602A)]  
MX25L1005@SOP8(ISP) [ISP-HEADER01]  
MX25L1005A MX25L1005A@SON8  
[(SA683)]  
MX25L1005A@SOP8 [(SA602A)]  
MX25L12805D@SON8(Fast Mode) [(SA684)]  
MX25L12805D@SOP16(Fast Mode) [(SA404)]  
MX25L12805N@SOP16 [(SA404)]  
MX25L12805N@SOP16(Fast Mode) [(SA404)]  
MX25L1602@SOP28 [(SA630)] MX25L1605@SON8  
[(SA684)]  
MX25L1605@SON8(Fast Mode) [(SA684)]  
MX25L1605@SOP16 [(SA404)]  
MX25L1605@SOP16(Fast Mode) [(SA404)]  
MX25L1605A@SON8 [(SA684)]  
MX25L1605A@SON8(Fast Mode) [(SA684)]  
MX25L1605A@SOP16 [(SA404)]  
MX25L1605A@SOP16(Fast Mode) [(SA404)]  
MX25L1605A@SOP8 [(SA023A)]  
MX25L1605A@SOP8(Fast Mode) [(SA023A)]  
MX25L1605D@SON8 [(SA684)]  
MX25L1605D@SON8(Fast Mode) [(SA683)]  
MX25L1605D@SOP16 [(SA404)]  
MX25L1605D@SOP16(Fast Mode) [(SA404)]  
MX25L1605D@SOP8(150)(Fast Mode) [(SA602A)]  
MX25L1605D@SOP8(200)(Fast Mode) [(SA605B)]  
MX25L1635DM1I@SOP8 [(SA602A)] MX25L1635DM2I@SOP8  
[(SA605B)]  
MX25L1635DMI@SOP16 [(SA404)] MX25L1635DZNI@WSON8  
[(SA683)]  
MX25L1636DM1I@SOP8 [(SA602A)] MX25L1636DM2I@SOP8  
[(SA605B)]  
MX25L1636DMI@SOP16 [(SA404)] MX25L1636DZNI@WSON8

[(SA683)]  
 MX25L2005 MX25L2005(ISP) [ISP-  
 HEADER01]  
 MX25L2005@SON8 [(SA683)]  
 MX25L2005@SON8(ISP) [ISP-HEADER01]  
 MX25L2005@SOP8 [(SA602A)]  
 MX25L2005@SOP8(ISP) [ISP-HEADER01]  
 MX25L2025 MX25L2025@SON8  
 [(SA683)]  
 MX25L2025@SOP8 [(SA602A)] MX25L3202@SOP32  
 [(SA438T)]  
 MX25L3205@SOP16 [(SA404)]  
 MX25L3205@SOP16(Fast Mode) [(SA404)]  
 MX25L3205@SOP8 [(SA023A)]  
 MX25L3205@SOP8(Fast Mode) [(SA023A)]  
 MX25L3205A@SON8 [(SA684)]  
 MX25L3205A@SON8(Fast Mode) [(SA684)]  
 MX25L3205A@SOP16 [(SA404)]  
 MX25L3205A@SOP16(Fast Mode) [(SA404)]  
 MX25L3205A@SOP16(Parallel Mode) [(SA404)]  
 MX25L3205A@SOP8 [(SA023A)]  
 MX25L3205A@SOP8(Fast Mode) [(SA023A)]  
 MX25L3205D@SON8(Fast Mode) [(SA683)]  
 MX25L3205D@SOP16 [(SA404)]  
 MX25L3205D@SOP16(Fast Mode) [(SA404)]  
 MX25L3205D@SOP8 [(SA023A)]  
 MX25L3205D@SOP8(Fast Mode) [(SA605B)]  
 MX25L3235DM2I@SOP8 [(SA605B)] MX25L3235DMI@SOP16  
 [(SA404)]  
 MX25L3235DZNI@WSON8 [(SA683)] MX25L3236DM2I@SOP8  
 [(SA605B)]  
 MX25L3236DMI@SOP16 [(SA404)] MX25L3236DZNI@WSON8  
 [(SA683)]  
 MX25L4005  
 MX25L4005(150mil)@SOP8 [(SA602A)]  
 MX25L4005(150mil)@SOP8(ISP) [ISP-HEADER01]  
 MX25L4005(209mil)@SOP8 [(SA023A)]  
 MX25L4005(209mil)@SOP8(ISP) [ISP-HEADER01]  
 MX25L4005(ISP) [ISP-HEADER01] MX25L4005@SON8  
 [(SA683)]  
 MX25L4005@SON8(ISP) [ISP-HEADER01]  
 MX25L4005A  
 MX25L4005A(150mil)@SOP8 [(SA602A)]

MX25L4005A(150mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L4005A(209mil)@SOP8 [(SA023A)]  
MX25L4005A(209mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L4005A(ISP) [ISP-HEADER01] MX25L4005A@SON8  
[(SA683)]  
MX25L4005A@SON8(ISP) [ISP-HEADER01]  
MX25L4025A  
MX25L4025A(150mil)@SOP8 [(SA602A)]  
MX25L4025A(209mil)@SOP8 [(SA023A)]  
MX25L4025A@SON8 [(SA683)] MX25L512@SON8  
[(SA683)]  
MX25L512@SOP8 [(SA602A)]  
MX25L512A  
MX25L512A@SON8 [(SA683)] MX25L512A@SOP8  
[(SA602A)]  
MX25L6402@SOP32 [(SA438T)] MX25L6402A@SOP28  
[(SA630)]  
MX25L6405@SOP16 [(SA404)]  
MX25L6405@SOP16(Fast Mode) [(SA404)]  
MX25L6405@SOP8 [(SA023A)]  
MX25L6405@SOP8(Fast Mode) [(SA023A)]  
MX25L6405D@SON8(Fast Mode) [(SA684)]  
MX25L6405D@SOP16 [(SA404)]  
MX25L6405D@SOP16(Fast Mode) [(SA404)]  
MX25L6405D@SOP8 [(SA023A)]  
MX25L8005  
MX25L8005(150mil)@SOP8 [(SA602A)]  
MX25L8005(150mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L8005(209mil)@SOP8 [(SA023A)]  
MX25L8005(209mil)@SOP8(ISP) [ISP-HEADER01]  
MX25L8005(ISP) [ISP-HEADER01] MX25L8005@SON8  
[(SA683)]  
MX25L8005@SON8(ISP) [ISP-HEADER01]  
MX25L802@SOP28 [(SA630)]  
MX25L8025  
MX25L8025(150mil)@SOP8 [(SA602A)]  
MX25L8025(209mil)@SOP8 [(SA023A)]  
MX25L8025@SON8 [(SA683)]  
MX25L8036D  
MX25L8036D@SOP16 [(SA602A)]  
MX25L8036D@SOP8[150 mil] [(SA602A)]  
MX25L8036D@SOP8[200 mil] [(SA023A)]  
MX25L8036D@WSON8 [(SA683)]

MX26C1000B  
 MX26C1000B@PLCC32 [(SA015A1T)] MX26C1000B@SOIC32  
 [(SA603)]  
 MX26C1000B@TSOP32 [(SA410T)]  
 MX26C2000B  
 MX26C2000B@PLCC32 [(SA015A1T)] MX26C2000B@SOIC32  
 [(SA603)]  
 MX26C2000B@TSOP32 [(SA410T)]  
 MX26C512A  
 MX26C512A@PLCC32 [(SA015A1T)] MX26C512A@SOIC28  
 [(SA630)]  
 MX26C512A@TSOP28 [(SA430T)]  
 MX26F128J3TC@TSOP56 [(SA628-B018)]  
 MX26F128J3XC@CSP64 [(SA655A-B054A-T064F001)]  
 MX26F640J3TC@TSOP56 [(SA628-B018)]  
 MX26F640J3XC@CSP64 [(SA655A-B054A-T064F001)]  
 MX26L12711MC@PSOP44 [(SA638)] MX26L12811MC@PSOP44  
 [(SA638)]  
 MX26L6419T@TSOP48 [(SA247-B005)] MX26L6420@PSOP44  
 [(SA638)]  
 MX26L6420@TSOP48 [(SA247-B005)] MX26LV004B@PLCC32  
 [(SA015A1T)]  
 MX26LV004B@TSOP40 [(SA409T)] MX26LV004T@PLCC32  
 [(SA015A1T)]  
 MX26LV004T@TSOP40 [(SA409T)] MX26LV008B@TSOP40  
 [(SA409T)]  
 MX26LV008T@TSOP40 [(SA409T)]  
 MX26LV040(QC)@PLCC32 [(SA015A1T)]  
 MX26LV040(TC)@TSOP32 [(SA410T)]  
 MX26LV160BT@TSOP48 [(SA247-B005)]  
 MX26LV160BX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
 MX26LV160BX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
 MX26LV160TT@TSOP48 [(SA247-B005)]  
 MX26LV160TX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
 MX26LV160TX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
 MX26LV400BT@TSOP48 [(SA247-B005)]  
 MX26LV400BX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
 MX26LV400BX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
 MX26LV400TT@TSOP48 [(SA247-B005)]  
 MX26LV400TX(0.3)@CSP48 [(SA642G-B026A-T048F001)]  
 MX26LV400TX(0.4)@CSP48 [(SA642G-B026A-T048F001)]  
 MX26LV800BM@PSOP44 [(SA638)]  
 MX26LV800BT@TSOP48 [(SA247-B005)]

MX26LV800BX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]	
MX26LV800BX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]	
MX26LV800TM@PSOP44 [(SA638)]	
MX26LV800TT@TSOP48 [(SA247-B005)]	
MX26LV800TX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]	
MX26LV800TX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]	
MX27C1000	MX27C1000@PLCC32
[(SA015A1T)]	
MX27C1000@SOIC32 [(SA603)]	MX27C1000@TSOP32
[(SA410T)]	
MX27C1000A	MX27C1000A@PLCC32
[(SA015A1T)]	
MX27C1000A@SOIC32 [(SA603)]	MX27C1000A@TSOP32
[(SA410T)]	
MX27C1001	MX27C1001@PLCC32
[(SA015A1T)]	
MX27C1001@SOIC32 [(SA603)]	MX27C1001@TSOP32
[(SA410T)]	
MX27C1024	MX27C1024@PLCC44
[(SA244)]	
MX27C1024@TSOP40 [(SA409T)]	
MX27C1024A	
MX27C1024A@PLCC44 [(SA244)]	MX27C1024A@TSOP40
[(SA409T)]	
MX27C1024B	MX27C1024B@PLCC44
[(SA244)]	
MX27C1024B@TSOP40 [(SA409T)]	
MX27C1100	
MX27C2000	MX27C2000@PLCC32
[(SA015A1T)]	
MX27C2000@SOIC32 [(SA603)]	MX27C2000@TSOP32
[(SA410T)]	
MX27C2000A	MX27C2000A@PLCC32
[(SA015A1T)]	
MX27C2000A@SOIC32 [(SA603)]	MX27C2000A@TSOP32
[(SA410T)]	
MX27C2048	MX27C2048@PLCC44
[(SA244)]	
MX27C2048@TSOP40 [(SA409T)]	
MX27C2100	
MX27C256	MX27C256@PLCC32
[(SA015A1T)]	
MX27C4000	MX27C4000@PLCC32

[ (SA015A1T) ]	
MX27C4000@SOIC32 [ (SA603) ]	MX27C4000@TSOP32
[ (SA410T) ]	
MX27C4000A	MX27C4000A@PLCC32
[ (SA015A1T) ]	
MX27C4000A@SOIC32 [ (SA603) ]	MX27C4000A@TSOP32
[ (SA410T) ]	
MX27C4096	MX27C4096@PLCC44
[ (SA244) ]	
MX27C4100	
MX27C4111	
MX27C512	MX27C512@PLCC32
[ (SA015A1T) ]	
MX27C516	MX27C516@PLCC44
[ (SA244) ]	
MX27C516@TSOP40 [ (SA409T) ]	
MX27C8000	
MX27C8000@PLCC32 [ (SA015A1T) ]	MX27C8000@SOIC32
[ (SA603) ]	
MX27C8000@TSOP32 [ (SA410T) ]	
MX27C8000A	
MX27C8000A@PLCC32 [ (SA015A1T) ]	MX27C8000A@SOIC32
[ (SA603) ]	
MX27C8000A@TSOP32 [ (SA410T) ]	
MX27C8100	
MX27C8100@PSOP44 [ (SA638) ]	
MX27C8111	
MX27C8111@PSOP44 [ (SA638) ]	
MX27L1000	
MX27L1000@PLCC32 [ (SA015A1T) ]	MX27L1000@TSOP32
[ (SA410T) ]	
MX27L2000	MX27L2000@PLCC32
[ (SA015A1T) ]	
MX27L2000@TSOP32 [ (SA410T) ]	
MX27L256	
MX27L256@PLCC32 [ (SA015A1T) ]	MX27L256@TSOP32
[ (SA430T) ]	
MX27L4000	MX27L4000@PLCC32
[ (SA015A1T) ]	
MX27L4000@TSOP32 [ (SA410T) ]	
MX27L4096	
MX27L4096@PLCC44 [ (SA244) ]	
MX27L512	



MX27L512@PLCC32 [(SA015A1T)]	MX27L512@TSOP28
[(SA430T)]	
MX28F002B@TSOP40 [(SA409T)]	MX28F002T@TSOP40
[(SA409T)]	
MX28F1000	MX28F1000@PLCC32
[(SA015A1T)]	
MX28F1000@SOP32 [(SA603)]	MX28F1000@TSOP32
[(SA410T)]	
MX28F1000P	MX28F1000P@PLCC32
[(SA015A1T)]	
MX28F1000P@TSOP32 [(SA410T)]	
MX28F160C3BT@TSOP48 [(SA247-B005)]	
MX28F160C3BX@uBGA48 [(SA634A-B005A-Y048F001)]	
MX28F160C3TT@TSOP48 [(SA247-B005)]	
MX28F160C3TX@uBGA48 [(SA634A-B005A-Y048F001)]	
MX28F2000	MX28F2000@PLCC32
[(SA015A1T)]	
MX28F2000@TSOP32 [(SA410T)]	
MX28F2000P	
MX28F2000P@PLCC32 [(SA015A1T)]	MX28F2000P@TSOP32
[(SA410T)]	
MX28F2100B@PSOP44 [(SA638)]	MX28F2100B@TSOP48 [(SA247-
B005)]	
MX28F2100T@PSOP44 [(SA638)]	MX28F2100T@TSOP48 [(SA247-
B005)]	
MX28F4000	MX28F4000@PLCC32
[(SA015A1T)]	
MX28F4000@TSOP32 [(SA410T)]	
MX28F640C3BT@TSOP48 [(SA247-B005)]	
MX28F640C3BX@uBGA48 [(SA634A-B005A-Y048F001)]	
MX28F640C3TT@TSOP48 [(SA247-B005)]	
MX28F640C3TX@uBGA48 [(SA634A-B005A-Y048F001)]	
MX29F001B	MX29F001B@PLCC32
[(SA015A1T)]	
MX29F001B@TSOP32 [(SA410T)]	
MX29F001T	
MX29F001T@PLCC32 [(SA015A1T)]	MX29F001T@TSOP32
[(SA410T)]	
MX29F002B	MX29F002B@PLCC32
[(SA015A1T)]	
MX29F002B@TSOP32 [(SA410T)]	
MX29F002NB	
MX29F002NB@PLCC32 [(SA015A1T)]	MX29F002NB@TSOP32

[ (SA410T) ]	
MX29F002NT	MX29F002NT@PLCC32
[ (SA015A1T) ]	
MX29F002NT@TSOP32 [ (SA410T) ]	
MX29F002T	
MX29F002T@PLCC32 [ (SA015A1T) ]	MX29F002T@TSOP32
[ (SA410T) ]	
MX29F004B	MX29F004B@PLCC32
[ (SA015A1T) ]	
MX29F004B@TSOP32 [ (SA410T) ]	
MX29F004T	
MX29F004T@PLCC32 [ (SA015A1T) ]	MX29F004T@TSOP32
[ (SA410T) ]	
MX29F016@PSOP44 [ (SA638) ]	MX29F016@TSOP40
[ (SA409T) ]	
MX29F016@TSOP48 [ (SA247-B005) ]	
MX29F022B	
MX29F022B@PLCC32 [ (SA015A1T) ]	MX29F022B@TSOP32
[ (SA410T) ]	
MX29F022NB	MX29F022NB@PLCC32
[ (SA015A1T) ]	
MX29F022NB@TSOP32 [ (SA410T) ]	
MX29F022NT	
MX29F022NT@PLCC32 [ (SA015A1T) ]	MX29F022NT@TSOP32
[ (SA410T) ]	
MX29F022T	MX29F022T@PLCC32
[ (SA015A1T) ]	
MX29F022T@TSOP32 [ (SA410T) ]	
MX29F040	
MX29F040@PLCC32 [ (SA015A1T) ]	MX29F040@TSOP32
[ (SA410T) ]	
MX29F040C	MX29F040C@PLCC32
[ (SA015A1T) ]	
MX29F040C@TSOP32 [ (SA410T) ]	MX29F080@PSOP44
[ (SA638) ]	
MX29F080@TSOP40 [ (SA409T) ]	MX29F100B@PSOP44 [ (SA638-B006) ]
B006) ]	
MX29F100B@TSOP48 [ (SA247-B005) ]	MX29F100T@PSOP44 [ (SA638-B006) ]
B006) ]	
MX29F100T@TSOP48 [ (SA247-B005) ]	MX29F1610@PSOP44
[ (SA638) ]	
MX29F1610@TSOP48 [ (SA247-B005) ]	MX29F1610A@PSOP44
[ (SA638) ]	

MX29F1610A@TSOP48 [(SA247-B005)] MX29F1610B@TSOP48 [(SA247-B005)]  
MX29F1611@PSOP44 [(SA638)]  
MX29F1615  
MX29F200B@PSOP44 [(SA638-B006)] MX29F200B@TSOP48 [(SA247-B005)]  
MX29F200CB@PSOP44 [(SA638)] MX29F200CB@TSOP48 [(SA247-B005)]  
MX29F200CT@PSOP44 [(SA638)] MX29F200CT@TSOP48 [(SA247-B005)]  
MX29F200T@PSOP44 [(SA638-B006)] MX29F200T@TSOP48 [(SA247-B005)]  
MX29F4000 MX29F400B@PSOP44 [(SA638-B006)]  
MX29F400B@TSOP48 [(SA247-B005)] MX29F400CB@PSOP44 [(SA638)]  
MX29F400CB@TSOP48 [(SA247-B005)] MX29F400CT@PSOP44 [(SA638)]  
MX29F400CT@TSOP48 [(SA247-B005)] MX29F400T@PSOP44 [(SA638-B006)]  
MX29F400T@TSOP48 [(SA247-B005)] MX29F800B@PSOP44 [(SA638-B006)]  
MX29F800B@TSOP48 [(SA247-B005)] MX29F800T@PSOP44 [(SA638-B006)]  
MX29F800T@TSOP48 [(SA247-B005)] MX29L1611@PSOP44 [(SA638)]  
MX29L1611@TSOP48 [(SA247-B005)]  
MX29L1611G  
MX29L3211@PSOP44 [(SA638)] MX29L3211@TSOP48 [(SA247-B005)]  
MX29LA128MB@TSOP56 [(SA628-B102)]  
MX29LA128MT@TSOP56 [(SA628-B102)]  
MX29LA129MH@TSOP56 [(SA628-B018)]  
MX29LA129ML@TSOP56 [(SA628-B018)]  
MX29LA320MB@CFBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LA320MB@TSOP48 [(SA247-B005)]  
MX29LA320MT@CFBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LA320MT@TSOP48 [(SA247-B005)]  
MX29LA321MB@FBGA64 [(SA655A-B054A-T064F001Y)]  
MX29LA321MB@TSOP56 [(SA628-B018)]  
MX29LA321MH@FBGA64 [(SA655A-B054A-T064F001Y)]  
MX29LA321MH@TSOP56 [(SA628-B018)]  
MX29LA321ML@FBGA64 [(SA655A-B054A-T064F001Y)]

MX29LA321ML@TSOP56 [ (SA628-B018) ]  
MX29LA321MT@FBGA64 [ (SA655A-B054A-T064F001Y) ]  
MX29LA321MT@TSOP56 [ (SA628-B018) ]  
MX29LV002CB@PLCC32 [ (SA015A1T) ]           MX29LV002CB@TSOP32  
[ (SA410T) ]  
MX29LV002CT@PLCC32 [ (SA015A1T) ]           MX29LV002CT@TSOP32  
[ (SA410T) ]  
MX29LV002NCB@PLCC32 [ (SA015A1T) ]           MX29LV002NCB@TSOP32  
[ (SA410T) ]  
MX29LV002NCT@PLCC32 [ (SA015A1T) ]           MX29LV002NCT@TSOP32  
[ (SA410T) ]  
MX29LV004B@PLCC32 [ (SA015A1T) ]           MX29LV004B@TSOP40  
[ (SA409T) ]  
MX29LV004CB@PLCC32 [ (SA015A1T) ]           MX29LV004CB@TSOP40  
[ (SA409T) ]  
MX29LV004CT@PLCC32 [ (SA015A1T) ]           MX29LV004CT@TSOP40  
[ (SA409T) ]  
MX29LV004T@PLCC32 [ (SA015A1T) ]           MX29LV004T@TSOP40  
[ (SA409T) ]  
MX29LV008B@TSOP40 [ (SA409T) ]           MX29LV008BB@TSOP40  
[ (SA409T) ]  
MX29LV008BT@TSOP40 [ (SA409T) ]           MX29LV008CB@TSOP40  
[ (SA409T) ]  
MX29LV008CT@TSOP40 [ (SA409T) ]           MX29LV008T@TSOP40  
[ (SA409T) ]  
MX29LV017AT@TSOP40 [ (SA409T) ]  
MX29LV017AX@CSP48 [ (SA642G-B026A-T048F001) ]  
MX29LV017BT@TSOP40 [ (SA409T) ]  
MX29LV017BX@CSP48 [ (SA642G-B026A-T048F001) ]  
MX29LV033T@TSOP40 [ (SA409T) ]           MX29LV040@PLCC32  
[ (SA015A1T) ]  
MX29LV040@TSOP32 [ (SA410T) ]           MX29LV040C@PLCC32  
[ (SA015A1T) ]  
MX29LV040C@TSOP32 [ (SA410T) ]  
MX29LV065BT@TSOP48 [ (SA247-B005) ]  
MX29LV065BXB@FBGA63 [ (SA642M-B026A-W048F001) ]  
MX29LV065M@TSOP48 [ (SA247-B005) ]           MX29LV081@TSOP40  
[ (SA409T) ]  
MX29LV128DB@TSOP48 [ (SA247-B005) ]  
MX29LV128DB@TSOP56 [ (SA628-B102) ]  
MX29LV128DT@TSOP48 [ (SA247-B005) ]  
MX29LV128DT@TSOP56 [ (SA628-B102) ]  
MX29LV128MB@TSOP56 [ (SA628-B102) ]

MX29LV128MH@TSOP56 [(SA628-B102)]  
MX29LV128ML@TSOP56 [(SA628-B102)]  
MX29LV128MT@TSOP56 [(SA628-B102)]  
MX29LV160AB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160AB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160AB@PSOP44 [(SA638)]  
MX29LV160AB@TSOP48 [(SA247-B005)]  
MX29LV160AT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160AT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160AT@PSOP44 [(SA638)]  
MX29LV160AT@TSOP48 [(SA247-B005)]  
MX29LV160B(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160B(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160B@PSOP44 [(SA638)]                   MX29LV160B@TSOP48 [(SA247-B005)]  
MX29LV160BB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BB@PSOP44 [(SA638)]  
MX29LV160BB@TSOP48 [(SA247-B005)]  
MX29LV160BT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160BT@PSOP44 [(SA638)]  
MX29LV160BT@TSOP48 [(SA247-B005)]  
MX29LV160CBM@PSOP44 [(SA638)]  
MX29LV160CBT@TSOP48 [(SA247-B005)]  
MX29LV160CBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160CBXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160CTM@PSOP44 [(SA638)]  
MX29LV160CTT@TSOP48 [(SA247-B005)]  
MX29LV160CTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160DBT@TSOP48 [(SA247-B005)]  
MX29LV160DBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160DTT@TSOP48 [(SA247-B005)]  
MX29LV160DTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV160T(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160T(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV160T@PSOP44 [(SA638)]                   MX29LV160T@TSOP48 [(SA247-B005)]  
MX29LV320ABT@TSOP48 [(SA247-B005)]  
MX29LV320ABXB@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320ABXE@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV320ATT@TSOP48 [(SA247-B005)]

MX29LV320ATXB@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV320ATXE@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV320BT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320BXB@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV320BXE@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV320CBB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320CBE@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320CBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320CTB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320CTE@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320CTT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320DBB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320DBE@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320DBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320DTB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320DTE@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320DTT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320MB@CFBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320MB@PSOP44 [ ( SA638 ) ]  
MX29LV320MB@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320MH@TSOP56 [ ( SA628-B067 ) ]  
MX29LV320ML@TSOP56 [ ( SA628-B067 ) ]  
MX29LV320MT@CFBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV320MT@PSOP44 [ ( SA638 ) ]  
MX29LV320MT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320TT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV320TXB@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV320TXE@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV321DBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV321DBXB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV321DTT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV321DTXB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV400B@PSOP44 [ ( SA638 ) ]                      MX29LV400B@TSOP48 [ ( SA247-B005 ) ]  
MX29LV400BX(0.3)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV400BX(0.4)@CSP48 [ ( SA642B-B026A-Y072F001 ) ]  
MX29LV400CBM@PSOP44 [ ( SA638 ) ]  
MX29LV400CBT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV400CBXB(0.3)@CSP48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV400CBXE(0.4)@CSP48 [ ( SA642G-B026A-T048F001Y ) ]  
MX29LV400CTM@PSOP44 [ ( SA638 ) ]  
MX29LV400CTT@TSOP48 [ ( SA247-B005 ) ]  
MX29LV400CTXB(0.3)@CSP48 [ ( SA642G-B026A-T048F001Y ) ]

MX29LV400CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV400T@PSOP44 [(SA638)] MX29LV400T@TSOP48 [(SA247-B005)]  
MX29LV400TX(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV400TX(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV640BBT@TSOP48 [(SA247-B005)]  
MX29LV640BBXB@FBGA63 [(SA642M-B026A-W048F001Y)]  
MX29LV640BT@TSOP48 [(SA247-B005)]  
MX29LV640BTT@TSOP48 [(SA247-B005)]  
MX29LV640BTXB@FBGA63 [(SA642M-B026A-W048F001Y)]  
MX29LV640BUT@TSOP48 [(SA247-B005)]  
MX29LV640BUXB@FBGA63 [(SA642M-B026A-W048F001)]  
MX29LV640BXB@FBGA63 [(SA642C-B026A-Y056F001)]  
MX29LV640BXC@FBGA64 [(SA655A-B044A-T064F001)]  
MX29LV640DBT@TSOP48 [(SA247-B005)]  
MX29LV640DBX@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV640DTT@TSOP48 [(SA247-B005)]  
MX29LV640DTX@FBGA48 [(SA642G-B026A-T048F001Y)]  
MX29LV640MB@FBGA63 [(SA642M-B026A-W048F001Y)]  
MX29LV640MB@TSOP48 [(SA247-B005)]  
MX29LV640MH@FBGA64 [(SA655F-B099A-W064F001Y)]  
MX29LV640MH@TSOP56 [(SA628-B067)]  
MX29LV640ML@FBGA64 [(SA655F-B099A-W064F001Y)]  
MX29LV640ML@TSOP56 [(SA628-B067)]  
MX29LV640MT@FBGA63 [(SA642M-B026A-W048F001Y)]  
MX29LV640MT@TSOP48 [(SA247-B005)]  
MX29LV640TT@TSOP48 [(SA247-B005)]  
MX29LV640TXB@FBGA63 [(SA642C-B026A-Y056F001)]  
MX29LV640TXC@FBGA64 [(SA655A-B044A-T064F001)]  
MX29LV641MH@TSOP48 [(SA247-B005)]  
MX29LV641ML@TSOP48 [(SA247-B005)]  
MX29LV800AB(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800AB(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800AB@PSOP44 [(SA638)]  
MX29LV800AB@TSOP48 [(SA247-B005)]  
MX29LV800AT(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800AT(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800AT@PSOP44 [(SA638)]  
MX29LV800AT@TSOP48 [(SA247-B005)]  
MX29LV800B(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800B(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800B@PSOP44 [(SA638)] MX29LV800B@TSOP48 [(SA247-B005)]

MX29LV800CBM@PSOP44 [(SA638)]  
MX29LV800CBT(Low)@TSOP48 [(SA247-B005)]  
MX29LV800CBT@TSOP48 [(SA247-B005)]  
MX29LV800CBXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800CBXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800CTM@PSOP44 [(SA638)]  
MX29LV800CTT(Low)@TSOP48 [(SA247-B005)]  
MX29LV800CTT@TSOP48 [(SA247-B005)]  
MX29LV800CTXB(0.3)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800CTXE(0.4)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29LV800T(0.3)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800T(0.4)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LV800T@PSOP44 [(SA638)]                      MX29LV800T@TSOP48 [(SA247-B005)]  
MX29LW160BT@TSOP48 [(SA247-B005)]  
MX29LW160BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW160BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW160TT@TSOP48 [(SA247-B005)]  
MX29LW160TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW160TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW161BT@TSOP48 [(SA247-B005)]  
MX29LW161BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW161BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW161TT@TSOP48 [(SA247-B005)]  
MX29LW161TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW161TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW320BT@TSOP48 [(SA247-B005)]  
MX29LW320BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW320BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW320TT@TSOP48 [(SA247-B005)]  
MX29LW320TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW320TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW321BT@TSOP48 [(SA247-B005)]  
MX29LW321BXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW321BXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29LW321TT@TSOP48 [(SA247-B005)]  
MX29LW321TXA(0.75)@CSP48 [(SA634A-B005A-Y048F001)]  
MX29LW321TXB(0.80)@CSP48 [(SA642B-B026A-Y072F001)]  
MX29SL800CB@TSOP48 [(SA247-B005)]  
MX29SL800CBXB(0.30)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29SL800CBXE(0.40)@CSP48 [(SA642G-B026A-T048F001Y)]  
MX29SL800CBXH(0.30)@CSP48 [(SA716A-B119B-M048F001Y)]  
MX29SL800CT@TSOP48 [(SA247-B005)]



MX29SL800CTXB(0.30)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29SL800CTXE(0.40)@CSP48 [(SA642G-B026A-T048F001Y)]  
 MX29SL800CTXH(0.30)@CSP48 [(SA716A-B119B-M048F001Y)]  
 MX69F1602C3BX@FBGA72 [(SA642E-B041A-T072F001)]  
 MX69F1602C3TX@FBGA72 [(SA642E-B041A-T072F001)]  
 MX69F1604C3BX@FBGA72 [(SA642E-B041A-T072F001)]  
 MX69F1604C3TX@FBGA72 [(SA642E-B041A-T072F001)]  
 MX69LW162BxB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW162TXB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW164BxB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW164TXB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW322BxB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW322TXB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW324BxB@CSP69 [(SA642A-B032A-Y096F001)]  
 MX69LW324TXB@CSP69 [(SA642A-B032A-Y096F001)]

## MICROCONTROLLER

MX10E8050I  
 [(SA244)]  
 MX10E8050I@TQFP44 [(SA245A)]  
 [(SA244)]  
 MX10EXA@TQFP44 [(SA245A)]  
 MX10F201FC@TQFP100(\*) [(TA010-B006)]  
 MX10F202FC@TQFP100(\*) [(TA010-B006)]  
 MX10FLCD  
 MX10FMAXD  
 MX10FMAXD@PLCC44 [(SA244)]  
 [(SA245A)]  
 MX10E8050I@PLCC44  
 MX10EXA@PLCC44  
 MX10FMAXD@TQFP44

## MAGNACHIP

### MICROCONTROLLER

MC80F0504  
 [(SA715)]  
 MC80F0504@SSOP16 [(SA626A)]  
 MC80F0504[153mil]@SOP16 [(SA602)]  
 MC80F0604  
 [(SA715)]  
 MC80F0604@SSOP20 [(SA626A)]  
 MC80F0504@SOP16  
 MC80F0604@SOP20

MC80F0704  
MC80F0704@QFN28 [ (SA697) ]  
[ (SA715) ]  
MC80F0708  
[ (SA697) ]  
MC80F0708@SOP28 [ (SA715) ]  
[ (SA653) ]  
MC80F0804@SOP32 [ (SA715) ]  
[ (SA653) ]  
MC80F0808@SOP32 [ (SA715) ]

MC80F0704@SOP28  
  
MC80F0708@QFN28  
  
MC80F0804@SDIP32  
  
MC80F0808@SDIP32

## MAXIM

### E (E) PROM / FRAM / NVRAM

DS1220AB  
DS1220AD  
DS1220Y  
DS1225AB  
DS1225AD  
DS1225D  
DS1225E  
DS1225Y  
DS1230AB  
DS1230W  
DS1230Y  
DS1235AB  
DS1235Y  
DS1243Y  
DS1244  
DS1244Y  
DS1245AB  
DS1245EE  
DS1245P  
DS1245W  
DS1245Y  
DS1248P  
DS1248W  
DS1248Y  
DS1249AB  
DS1249W  
DS1249Y

DS1250AB  
DS1250W  
DS1250Y  
DS1251AB  
DS1251W  
DS1251Y  
DS1256P  
DS1256W  
DS1256Y  
DS1265AB  
DS1265W  
DS1265Y  
DS1270AB  
DS1270W  
DS1270Y  
DS1284  
DS1284N  
DS1284Q@PLCC28 [(SA008A)] DS1284QN@PLCC28  
[(SA008A)]  
DS1286  
DS1286I  
DS1287  
DS1287A  
DS12887  
DS12887A  
DS12C887  
DS12C887A  
DS1386(32K) DS1386  
(8K)  
DS1485 DS1485@SOIC28  
[(SA630)]  
DS1488  
DS1553  
DS1553W  
DS1554  
DS1554W  
DS1556  
DS1642  
DS1643  
DS1644  
DS1644P [ordering number is marked above]  
DS1644PS [(PEP+S414T)]  
DS1645AB

DS1645EE	
DS1645Y	
DS1646	
DS1647	
DS1647LPM	
DS1650AB	
DS1650Y	DS1687-
3	
DS1687-5	DS17287-
3	
DS17287-5	
DS1742	
DS1742W	
DS1743	
DS1743P	
DS1743W	
DS1743WP	
DS1744	
DS1744P	
DS1744W	
DS1744WP	
DS1746	
DS1747	
DS1747P [ordering number is marked above]	
DS1747PS [(PEP+S414T)]	
DS1747W	
DS1747WP [ordering number is marked above]	
DS1747WPS [(PEP+S414T)]	DS17487-
3	
DS17487-5	DS17887-
3	
DS17887-5	DS2430A@TO-
92	
DS2430AP@TSOC6 [(SA602A)]	DS2431@TO-
92	
DS2431P@TSOC6 [(SA602A)]	DS2432P@TSOC6
[(SA602A)]	
DS2433@PR-35	DS2433S(3.9)@SOIC8
[(SA602A)]	
DS2433S(5.5)@SOIC8 [(SA605A)]	
DS2502	
DS2502P@TSOC6 [(SA602A)]	DS2502S@SOIC8
[(SA602A)]	

DS2502UNW [ (SA602A) ]	DS2502UNW@SOIC8
DS2502UNW@TSOC6 [ (SA602A) ]	
DS2506	
DS2506S@SOIC8 [ (SA023A) ]	
DS4510@uSOP10	
DS4520@TSSOP16 [ (SA026) ] [ (SA026) ]	DS4550@TSSOP20

## MICROCONTROLLER

DS87C520 [ (SA244) ]	DS87C520@PLCC44
DS87C520@TQFP44 [ (SA245A) ] A)	DS89C420 (rev.
DS89C420 (rev.A)@PLCC44 [ (SA244) ]	
DS89C420 (rev.A)@TQFP44 [ (SA245A) ]	

## MAXWELL

### E ( E ) PROM / FRAM / NVRAM

27C010T@LDFP32 [ (SA438T) ]	
28C010	
28C010@PLCC32 [ (SA015A1T) ] [ (SA438T) ]	28C010@TSOP32
28C010T [ (SA015A1T) ]	28C010T@PLCC32
28C010T@TSOP32 [ (SA438T) ]	
28C011	
28C011@PLCC32 [ (SA015A1T) ] [ (SA438T) ]	28C011@TSOP32
28C011T [ (SA015A1T) ]	28C011T@PLCC32
28C011T@TSOP32 [ (SA438T) ]	

## MEGAWIN

### E ( E ) PROM / FRAM / NVRAM

MM25SB512@SOIC8 [ (SA602A) ]  
MM29F040  
MM29F040@PLCC32 [ (SA015A1T) ] MM29F040@TSOP32  
[ (SA410T) ]  
MM29LF040 MM29LF040@PLCC32  
[ (SA015A1T) ]  
MM29LF040@TSOP32 [ (SA410T) ]

## MICROCONTROLLER

MPC89L516X2 MPC89L516X2@PLCC44  
[ (SA244) ]  
MPC89L516X2@TQFP44 [ (SA245A) ]  
MPC89L556X2  
MPC89L556X2@PLCC44 [ (SA244) ] MPC89L556X2@TQFP44  
[ (SA245A) ]

## MEMOCOM

### E ( E ) PROM / FRAM / NVRAM

KI01602AB ( Ga1 ) @FBGA66 [ ( SA642R-B023A-T096F001Y ) ]  
KI01602AB ( Gb1 ) @FBGA66 [ ( SA642E-B023A-T072001Y ) ]  
KI01602AT ( Ga1 ) @FBGA66 [ ( SA642R-B023A-T096F001Y ) ]  
KI01602AT ( Gb1 ) @FBGA66 [ ( SA642E-B023A-T072001Y ) ]  
KI01604AB ( Ga1 ) @FBGA58 [ ( SA642R-B023A-T096F001Y ) ]  
KI01604AB ( Gb1 ) @FBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
KI01604AT ( Ga1 ) @FBGA58 [ ( SA642R-B023A-T096F001Y ) ]  
KI01604AT ( Gb1 ) @FBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
KI01608AB ( Ga1 ) @FBGA58 [ ( SA642R-B023A-T096F001Y ) ]  
KI01608AB ( Gb1 ) @FBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
KI01608AT ( Ga1 ) @FBGA58 [ ( SA642R-B023A-T096F001Y ) ]  
KI01608AT ( Gb1 ) @FBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
KI03204AB ( Ga1 ) @FBGA58 [ ( SA642R-B023A-T096F001Y ) ]  
KI03204AB ( Gb1 ) @FBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
KI03204AT ( Ga1 ) @FBGA58 [ ( SA642R-B023A-T096F001Y ) ]  
KI03204AT ( Gb1 ) @FBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
KI03208AB ( Ga1 ) @FBGA58 [ ( SA642R-B023A-T096F001Y ) ]  
KI03208AB ( Gb1 ) @FBGA66 [ ( SA642E-B023A-T072F001Y ) ]  
KI03208AT ( Ga1 ) @FBGA58 [ ( SA642R-B023A-T096F001Y ) ]

KI03208AT(Gb1)@FBGA66 [(SA642E-B023A-T072F001Y)]  
 KIP2832AU(Ha1)@FBGA88 [(SA642R-B300A-T096F001Y)]  
 KIP2864AU(Ha1)@FBGA88 [(SA642R-B300A-T096F001Y)]  
 KS01602AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS01602AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS01604AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS01604AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS03204AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS03204AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS03208AB(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KS03208AT(Gh)@FBGA56 [(SA642P-B207A-W056F001Y)]  
 KSP2832AU(Hs1)@FBGA64 [(SA642A-B079-Y096F001Y)]  
 KSP2864AU(Hs1)@FBGA64 [(SA642A-B079-Y096F001Y)]

## MICON

### MICROCONTROLLER

MDT10P21(dip18) (dip20)	MDT10P21
MDT10P21(dip22) [(SA404A)]	MDT10P21@SOP18
MDT10P21@SOP20 [(SA404A)] [(SA404A)]	MDT10P21@SOP24
MDT10P22(dip18) (dip20)	MDT10P22
MDT10P22(dip22) [(SA404A)]	MDT10P22@SOP18
MDT10P22@SOP20 [(SA404A)] [(SA404A)]	MDT10P22@SOP24
MDT10P23(dip18) (dip20)	MDT10P23
MDT10P23(dip22) [(SA404A)]	MDT10P23@SOP18
MDT10P23@SOP20 [(SA404A)] [(SA404A)]	MDT10P23@SOP24
MDT10P61 [(SA404A)]	MDT10P61@SOP18
MDT10P61@SSOP20 [(SA626A)]	
MDT2005	
MDT2005@SOP18 [(SA404A)] [(SA626A)]	MDT2005@SSOP20

MDT2010 [ (SA404A) ]	MDT2010@SOP18
MDT2010@SSOP20 [ (SA626A) ]	
MDT2020 MDT2020@SOP28 [ (SA404A) ] [ (SA626A) ]	MDT2020@SSOP28
MDT2030 [ (SA404A) ]	MDT2030@SOP18
MDT2030@SSOP20 [ (SA626A) ]	
MDT2050 MDT2050@SOP18 [ (SA404A) ] [ (SA626A) ]	MDT2050@SSOP20
MDT2051 [ (SA404A) ]	MDT2051@SOP18
MDT2051@SSOP20 [ (SA626A) ]	
MDT2060 MDT2060@SOP18 [ (SA404A) ] [ (SA626A) ]	MDT2060@SSOP20

## MICROCHIP

### E (E) PROM/FRAM/NVRAM

24AA00 [ (SA602A) ]	24AA00@SOIC8
24AA00@TSSOP8 [ (SA026) ]	
24AA01 24AA01@SOIC8 [ (SA602A) ] [ (SA026) ]	24AA01@TSSOP8
24AA014 [ (SA602A) ]	24AA014@SOIC8
24AA014@TSSOP8 [ (SA026) ]	
24AA02 24AA02@DFN8 [ (SA694) ] [ (SA666) ]	24AA02@MSOP8
24AA02@SOIC8 [ (SA602A) ] [ (SA717) ]	24AA02@SOT-23-5
24AA02@TSSOP8 [ (SA026) ]	
24AA024 24AA024@DFN8 [ (SA694) ] [ (SA666) ]	24AA024@MSOP8
24AA024@SOIC8 [ (SA602A) ]	24AA024@TSSOP8



[ (SA026) ]	
24AA025	24AA025@DFN8
[ (SA694) ]	
24AA025@MSOP8 [ (SA666) ]	24AA025@SOIC8
[ (SA602A) ]	
24AA025@TSSOP8 [ (SA026) ]	
24AA04	
24AA04@SOIC8 [ (SA602A) ]	24AA04@TSSOP8
[ (SA026) ]	
24AA08	24AA08@SOIC8
[ (SA602A) ]	
24AA08@TSSOP8 [ (SA026) ]	
24AA1025	
24AA1025@SOIC8 [ (SA602A) ]	24AA1025@TSSOP8
[ (SA026) ]	
24AA128	24AA128@MSOP8
[ (SA666) ]	
24AA128@SOIC8 [ (SA602A) ]	24AA128@TSSOP14
[ (SA026) ]	
24AA128@TSSOP8 [ (SA026) ]	
24AA16	
24AA16@SOIC8 [ (SA602A) ]	24AA16@TSSOP8
[ (SA026) ]	
24AA164	24AA164@SOIC8
[ (SA602A) ]	
24AA164@TSSOP8 [ (SA026) ]	
24AA174	
24AA174@SOIC8 [ (SA602A) ]	24AA174@TSSOP8
[ (SA026) ]	
24AA256	24AA256@MSOP8
[ (SA666) ]	
24AA256@SOIC8 [ (SA605A) ]	24AA256@TSSOP14
[ (SA026) ]	
24AA256@TSSOP8 [ (SA026) ]	
24AA32	
24AA32(Rotated)@TSSOP8 [ (SA026) ]	24AA32@MSOP8
[ (SA666) ]	
24AA32@SOIC8 [ (SA602A) ]	24AA32@TSSOP8
[ (SA026) ]	
24AA32A	
24AA32A(Rotated)@TSSOP8 [ (SA026) ]	
24AA32A@MSOP8 [ (SA666) ]	24AA32A@SOIC8
[ (SA602A) ]	

24AA32A@TSSOP8 [(SA026)]	
24AA512	
24AA512@DFN8 [(SA683)]	24AA512@SOIC8
[(SA605A)]	
24AA512@TSSOP14 [(SA602)]	
24AA515	
24AA515@SOIC8 [(SA605A)]	
24AA52	
24AA52@DFN8 [(SA694)]	24AA52@MSOP8
[(SA666)]	
24AA52@SOIC8 [(SA602A)]	24AA52@TSSOP8
[(SA026)]	
24AA64	
[(SA026)]	24AA64(Rotated)@TSSOP8
24AA64@MSOP8 [(SA666)]	
[(SA602A)]	24AA64@SOIC8
24AA64@TSSOP8 [(SA026)]	
24AA65	
24AA65@SOIC8 [(SA602A)]	24AA65@TSSOP8
[(SA026)]	
24C00	
[(SA602A)]	24C00@SOIC8
24C00@TSSOP8 [(SA026)]	
24C01	
24C01A	24C01A@SOIC8
[(SA602A)]	
24C01C	24C01C@SOIC8
[(SA602A)]	
24C01C@TSSOP8 [(SA026)]	
24C02	
24C02A	24C02A@SOIC8
[(SA602A)]	
24C02C	24C02C@SOIC8
[(SA602A)]	
24C02C@TSSOP8 [(SA026)]	
24C04	
24C04A	24C04A@SOIC8
[(SA602A)]	
24C04A@TSSOP8 [(SA026)]	
24C08	
24C08@SOIC8 [(SA602A)]	
24C08B	
24C08B@SOIC8 [(SA602A)]	

24C16	
24C16@SOIC8 [(SA602A)]	
24C16B	
24C16B@SOIC8 [(SA602A)]	
24C32	
24C32@SOIC8 [(SA602A)]	
24C64	
24C64@SOIC8 [(SA602A)]	24C64@TSSOP8
[(SA026)]	
24C65	
[(SA602A)]	24C65@SOIC8
24FC1025	
[(SA602A)]	24FC1025@SOIC8
24FC1025@TSSOP8 [(SA026)]	
24FC128	
24FC128@MSOP8 [(SA666)]	24FC128@SOIC8
[(SA602A)]	
24FC128@TSSOP14 [(SA026)]	24FC128@TSSOP8
[(SA026)]	
24FC256	
[(SA666)]	24FC256@MSOP8
24FC256@SOIC8 [(SA605A)]	24FC256@TSSOP14
[(SA026)]	
24FC256@TSSOP8 [(SA026)]	
24FC32	
24FC32@SOIC8 [(SA602A)]	
24FC512	
24FC512@DFN8 [(SA683)]	24FC512@SOIC8
[(SA605A)]	
24FC512@TSSOP14 [(SA602)]	
24FC515	
24FC515@SOIC8 [(SA605A)]	
24FC65	
24FC65@SOIC8 [(SA605A)]	
24LC00	
24LC00@SOIC8 [(SA602A)]	24LC00@TSSOP8
[(SA026)]	
24LC01	
24LC014	
24LC014@SOIC8 [(SA602A)]	24LC014@TSSOP8
[(SA026)]	
24LC01B	
[(SA602A)]	24LC01B@SOIC8

24LC01B@TSSOP8 [(SA026)]	
24LC02	
24LC024	24LC024@SOIC8
[(SA602A)]	
24LC024@TSSOP8 [(SA026)]	
24LC025	
24LC025@SOIC8 [(SA602A)]	24LC025@TSSOP8
[(SA026)]	
24LC02B	24LC02B@DFN8
[(SA694)]	
24LC02B@MSOP8 [(SA666)]	24LC02B@SOIC8
[(SA602A)]	
24LC02B@SOT-23-5 [(SA717)]	24LC02B@TSSOP8
[(SA026)]	
24LC04	
24LC04B	
24LC04B@SOIC8 [(SA602A)]	24LC04B@TSSOP8
[(SA026)]	
24LC08	
24LC08B	
24LC08B@SOIC8 [(SA602A)]	24LC08B@TSSOP8
[(SA026)]	
24LC1025	24LC1025@SOIC8
[(SA602A)]	
24LC1025@TSSOP8 [(SA026)]	
24LC128	
24LC128@MSOP8 [(SA666)]	24LC128@SOIC8
[(SA605A)]	
24LC128@TSSOP14 [(SA026)]	24LC128@TSSOP8
[(SA026)]	
24LC16	24LC16@MSOP8
[(SA605A)]	
24LC16@SOIC8 [(SA602A)]	
24LC164	
24LC164@SOIC8 [(SA602A)]	
24LC16B	
24LC16B@SOIC8 [(SA602A)]	24LC16B@TSSOP8
[(SA026)]	
24LC174	24LC174@SOIC8
[(SA602A)]	
24LC21	24LC21@SOIC8
[(SA602A)]	
24LC21A	24LC21A@SOIC8

[ (SA602A) ]	
24LC22A	24LC22A@SOIC8
[ (SA602A) ]	
24LC256	24LC256@MSOP8
[ (SA666) ]	
24LC256@SOIC8 [ (SA605A) ]	24LC256@TSSOP14
[ (SA026) ]	
24LC256@TSSOP8 [ (SA026) ]	
24LC32	
24LC32@SOIC8 [ (SA602A) ]	
24LC32A	
24LC32A@SOIC8 [ (SA602A) ]	24LC32A@TSSOP8
[ (SA026) ]	
24LC512	24LC512@DFN8
[ (SA683) ]	
24LC512@SOIC8 [ (SA605A) ]	24LC512@TSSOP14
[ (SA602) ]	
24LC515	24LC515@SOIC8
[ (SA605A) ]	
24LC64	24LC64(Rotated)@TSSOP8
[ (SA026) ]	
24LC64@MSOP8 [ (SA605A) ]	24LC64@SOIC8
[ (SA602A) ]	
24LC64@TSSOP8 [ (SA026) ]	
24LC65	
24LC65@SOIC8 [ (SA602A) ]	
24LCS21	
24LCS21@SOIC8 [ (SA602A) ]	
24LCS21A	
24LCS21A@SOIC8 [ (SA602A) ]	
24LCS22	
24LCS22@SOIC8 [ (SA602A) ]	
24LCS22A	
24LCS22A@SOIC8 [ (SA602A) ]	
24LCS52	
24LCS52@DFN8 [ (SA694) ]	24LCS52@MSOP8
[ (SA666) ]	
24LCS52@SOIC8 [ (SA602A) ]	24LCS52@TSSOP8
[ (SA026) ]	
25AA010A	25AA010A@DFN8
[ (SA683) ]	
25AA010A@MSOP8 [ (SA605A) ]	25AA010A@SOIC8
[ (SA602A) ]	

25AA010A@SOT-23 [(SA698)]	25AA010A@TSSOP8
[(SA026)]	
25AA010A[X-Rotated]@TSSOP8 [(SA026)]	
25AA020A	25AA020A@DFN8
[(SA683)]	
25AA020A@MSOP8 [(SA605A)]	25AA020A@SOIC8
[(SA602A)]	
25AA020A@SOT-23 [(SA698)]	25AA020A@TSSOP8
[(SA026)]	
25AA020A[X-Rotated]@TSSOP8 [(SA026)]	
25AA040	25AA040@SOIC8
[(SA602A)]	
25AA040@TSSOP8 [(SA026)]	
25AA040A	
25AA040A@DFN8 [(SA683)]	25AA040A@MSOP8
[(SA605A)]	
25AA040A@SOIC8 [(SA602A)]	25AA040A@SOT-23
[(SA698)]	
25AA040A@TSSOP8 [(SA026)]	
25AA040A[X-Rotated]@TSSOP8 [(SA026)]	
25AA080	25AA080@SOIC8
[(SA602A)]	
25AA080A	25AA080A@MSOP8
[(SA605A)]	
25AA080A@SOIC8 [(SA602A)]	25AA080A@TSSOP8
[(SA026)]	
25AA080B	25AA080B@MSOP8
[(SA605A)]	
25AA080B@SOIC8 [(SA602A)]	25AA080B@TSSOP8
[(SA026)]	
25AA1024	25AA1024@DFN8
[(SA683)]	
25AA1024@SOIC8 [(SA602A)]	25AA1024@SOIJ8
[(SA605)]	
25AA160	25AA160@SOIC8
[(SA602A)]	
25AA160A	25AA160A@MSOP8
[(SA605A)]	
25AA160A@SOIC8 [(SA602A)]	25AA160A@TSSOP8
[(SA026)]	
25AA160B	25AA160B@MSOP8
[(SA605A)]	
25AA160B@SOIC8 [(SA602A)]	25AA160B@TSSOP8

[(SA026)]	
25AA256	25AA256@DFN8
[(SA683)]	
25AA256@SOIC8(4.0) [(SA602A)]	25AA256@SOIC8(5.4)
[(SA605A)]	
25AA256@TSSOP8 [(SA026)]	
25AA256[X-Rotated]@TSSOP8 [(SA026)]	
25AA320	25AA320@SOIC8
[(SA602A)]	
25AA320@TSSOP14 [(SA026)]	25AA320@TSSOP8
[(SA026)]	
25AA512	25AA512@DFN8
[(SA683)]	
25AA512@SOIC8 [(SA602A)]	25AA512@SOIJ8
[(SA605)]	
25AA640	25AA640@SOIC8
[(SA602A)]	
25AA640@TSSOP8 [(SA026)]	
25C040	
25C040@SOIC8 [(SA602A)]	25C040@TSSOP8
[(SA026)]	
25C080	25C080@SOIC8
[(SA602A)]	
25C160	25C160@SOIC8
[(SA602A)]	
25C320	25C320@SOIC8
[(SA602A)]	
25C320@TSSOP14 [(SA026)]	25C320@TSSOP8
[(SA026)]	
25C640	25C640@SOIC8
[(SA602A)]	
25C640@TSSOP8 [(SA026)]	
25LC010A	
25LC010A@DFN8 [(SA683)]	25LC010A@MSOP8
[(SA605A)]	
25LC010A@SOIC8 [(SA602A)]	25LC010A@SOT-23
[(SA698)]	
25LC010A@TSSOP8 [(SA026)]	
25LC010A[X-Rotated]@TSSOP8 [(SA026)]	
25LC020A	25LC020A@DFN8
[(SA683)]	
25LC020A@MSOP8 [(SA605A)]	25LC020A@SOIC8
[(SA602A)]	

25LC020A@SOT-23 [(SA698)]	25LC020A@TSSOP8
[(SA026)]	
25LC020A[X-Rotated]@TSSOP8 [(SA026)]	
25LC040	25LC040@SOIC8
[(SA602A)]	
25LC040@TSSOP8 [(SA026)]	
25LC040A	
25LC040A@DFN8 [(SA683)]	25LC040A@MSOP8
[(SA605A)]	
25LC040A@SOIC8 [(SA602A)]	25LC040A@SOT-23
[(SA698)]	
25LC040A@TSSOP8 [(SA026)]	
25LC040A[X-Rotated]@TSSOP8 [(SA026)]	
25LC080	25LC080@SOIC8
[(SA602A)]	
25LC080A	25LC080A@MSOP8
[(SA605A)]	
25LC080A@SOIC8 [(SA602A)]	25LC080A@TSSOP8
[(SA026)]	
25LC080B	25LC080B@MSOP8
[(SA605A)]	
25LC080B@SOIC8 [(SA602A)]	25LC080B@TSSOP8
[(SA026)]	
25LC1024	25LC1024@DFN8
[(SA683)]	
25LC1024@SOIC8 [(SA602A)]	25LC1024@SOIJ8
[(SA605)]	
25LC160	25LC160@SOIC8
[(SA602A)]	
25LC160A	25LC160A@MSOP8
[(SA605A)]	
25LC160A@SOIC8 [(SA602A)]	25LC160A@TSSOP8
[(SA026)]	
25LC160B	25LC160B@MSOP8
[(SA605A)]	
25LC160B@SOIC8 [(SA602A)]	25LC160B@TSSOP8
[(SA026)]	
25LC256	25LC256@DFN8
[(SA683)]	
25LC256@SOIC8(4.0) [(SA602A)]	25LC256@SOIC8(5.4)
[(SA605A)]	
25LC256@TSSOP8 [(SA026)]	
25LC256[X-Rotated]@TSSOP8 [(SA026)]	



25LC320	25LC320(SN)@SOIC8
[(SA602A)]	
25LC320@TSSOP14 [(SA026)]	25LC320@TSSOP8
[(SA026)]	
25LC512	25LC512@DFN8
[(SA683)]	
25LC512@SOIC8 [(SA602A)]	25LC512@SOIJ8
[(SA605)]	
25LC640	25LC640@SOIC8
[(SA602A)]	
25LC640@TSSOP8 [(SA026)]	
27256	
27256@PLCC32 [(SA015A1T)]	
27C128	
27C128@PLCC32 [(SA015A1T)]	
27C128A	
27C128A@PLCC32 [(SA015A1T)]	
27C256	
27C256@PLCC32 [(SA015A1T)]	
27C32A	
27C512	27C512@PLCC32
[(SA015A1T)]	
27C512A	27C512A@PLCC32
[(SA015A1T)]	
27C513	
27C64	
27C64@PLCC32 [(SA015A1T)]	27C64@SOIC28
[(SA404)]	
27HC1616	27HC1616@PLCC44
[(SA244)]	
27HC1616L	27HC1616L@PLCC44
[(SA244)]	
27HC191	27HC191@PLCC28
[(SA008A)]	
27HC191@SOIC24 [(SA404)]	
27HC256	
27HC256@PLCC32 [(SA015A1T)]	
27HC256L	
27HC256L@PLCC32 [(SA015A1T)]	
27HC291	
27HC291@PLCC28 [(SA008A)]	27HC291@SOIC24
[(SA404)]	
27HC416	

27HC64	
27HC64@PLCC32 [(SA015A1T)]	27HC64@SOIC28
[(SA404)]	
27HC641	27HC641@PLCC28
[(SA008A)]	
27HC641@SOIC24 [(SA404)]	
27HC641L	
27HC641L@PLCC28 [(SA008A)]	27HC641L@SOIC24
[(SA404)]	
27HC64L	27HC64L@PLCC32
[(SA015A1T)]	
27HC64L@SOIC28 [(SA404)]	
27LV256	
27LV256@PLCC32 [(SA015A1T)]	
27LV64	
2817	
2864	
2864@PLCC32 [(SA015A1T)]	
28C04	
28C04@PLCC32 [(SA015A1T)]	28C04@SOIC24
[(SA404)]	
28C04A	28C04A@PLCC32
[(SA015A1T)]	
28C04A@SOIC24 [(SA404)]	
28C04AF	
28C04AF@PLCC32 [(SA015A1T)]	28C04AF@SOIC24
[(SA404)]	
28C04F	28C04F@PLCC32
[(SA015A1T)]	
28C04F@SOIC24 [(SA404)]	
28C16	
28C16@PLCC32 [(SA015A1T)]	28C16@SOIC24
[(SA404)]	
28C16A	28C16A@PLCC32
[(SA015A1T)]	
28C16A@SOIC24 [(SA404)]	
28C16AF	
28C16AF@PLCC32 [(SA015A1T)]	28C16AF@SOIC24
[(SA404)]	
28C16F	28C16F@PLCC32
[(SA015A1T)]	
28C16F@SOIC24 [(SA404)]	
28C17	

28C17@PLCC32 [(SA015A1T)]	28C17@SOIC28
[(SA404)]	
28C17A	28C17A@PLCC32
[(SA015A1T)]	
28C17A@SOIC28 [(SA404)]	
28C17AF	
28C17AF@PLCC32 [(SA015A1T)]	28C17AF@SOIC28
[(SA404)]	
28C17F	28C17F@PLCC32
[(SA015A1T)]	
28C17F@SOIC28 [(SA404)]	
28C256	
28C256@PLCC32 [(SA015A1T)]	
28C256F	
28C256F@PLCC32 [(SA015A1T)]	
28C64A	
28C64A@PLCC32 [(SA015A1T)]	28C64A@SOIC28
[(SA404)]	
28C64A@TSOP32 [(SA410T)]	
28C64AF	
28C64AF@PLCC32 [(SA015A1T)]	28C64AF@SOIC28
[(SA404)]	
28LV64A	28LV64A@PLCC32
[(SA015A1T)]	
28LV64A@SOIC28 [(SA404)]	
28PC64	
28PC64@PLCC32 [(SA015A1T)]	
59C11	
59C11@SOIC8 [(SA602A)]	
85C72	
85C72@SOIC8 [(SA602A)]	
85C82	
85C82@SOIC8 [(SA602A)]	
85C92	
85C92@SOIC8 [(SA602A)]	93AA46
(08bit)	
93AA46(08bit)@SOIC8 [(SA602A)]	93AA46
(16bit)	
93AA46(16bit)@SOIC8 [(SA602A)]	93AA46A
(08bit)	
93AA46A(08bit)@DFN8 [(BBBB)]	93AA46A(08bit)@MSOP8
[(SA666)]	
93AA46A(08bit)@SOIC8 [(SA602A)]	93AA46A(08bit)@SOT-23

[(SA717)]	
93AA46A(08bit)@TSSOP8 [(SA026)]	93AA46B
(16bit)	
93AA46B(16bit)@DFN8 [(BBBB)]	93AA46B(16bit)@MSOP8
[(SA666)]	
93AA46B(16bit)@SOIC8 [(SA602A)]	93AA46B(16bit)@SOT-23
[(SA717)]	
93AA46B(16bit)@TSSOP8 [(SA026)]	93AA46C
(08bit)	
93AA46C(08bit)@DFN8 [(BBBB)]	93AA46C(08bit)@MSOP8
[(SA666)]	
93AA46C(08bit)@SOIC8 [(SA602A)]	93AA46C(08bit)@TSSOP8
[(SA026)]	
93AA46C(16bit)	93AA46C(16bit)@DFN8
[(BBBB)]	
93AA46C(16bit)@MSOP8 [(SA666)]	93AA46C(16bit)@SOIC8
[(SA602A)]	
93AA46C(16bit)@TSSOP8 [(SA026)]	93AA56
(08bit)	
93AA56(08bit)@SOIC8 [(SA602A)]	93AA56
(16bit)	
93AA56(16bit)@SOIC8 [(SA602A)]	93AA56A
(08bit)	
93AA56A(08bit)@DFN8 [(BBBB)]	93AA56A(08bit)@MSOP8
[(SA666)]	
93AA56A(08bit)@SOIC8 [(SA602A)]	93AA56A(08bit)@SOT-23
[(SA717)]	
93AA56A(08bit)@TSSOP8 [(SA026)]	93AA56B
(16bit)	
93AA56B(16bit)@DFN8 [(BBBB)]	93AA56B(16bit)@MSOP8
[(SA666)]	
93AA56B(16bit)@SOIC8 [(SA602A)]	93AA56B(16bit)@SOT-23
[(SA717)]	
93AA56B(16bit)@TSSOP8 [(SA026)]	93AA56C
(08bit)	
93AA56C(08bit)@DFN8 [(BBBB)]	93AA56C(08bit)@MSOP8
[(SA666)]	
93AA56C(08bit)@SOIC8 [(SA602A)]	93AA56C(08bit)@TSSOP8
[(SA026)]	
93AA56C(16bit)	93AA56C(16bit)@DFN8
[(BBBB)]	
93AA56C(16bit)@MSOP8 [(SA666)]	93AA56C(16bit)@SOIC8
[(SA602A)]	

93AA56C(16bit)@TSSOP8 [(SA026)] (08bit)	93AA66
93AA66(08bit)@SOIC8 [(SA602A)] (16bit)	93AA66
93AA66(16bit)@SOIC8 [(SA602A)] (08bit)	93AA66A
93AA66A(08bit)@DFN8 [(BBBB)] [(SA666)]	93AA66A(08bit)@MSOP8
93AA66A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93AA66A(08bit)@SOT-23
93AA66A(08bit)@TSSOP8 [(SA026)] (16bit)	93AA66B
93AA66B(16bit)@DFN8 [(BBBB)] [(SA666)]	93AA66B(16bit)@MSOP8
93AA66B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93AA66B(16bit)@SOT-23
93AA66B(16bit)@TSSOP8 [(SA026)] (08bit)	93AA66C
93AA66C(08bit)@DFN8 [(BBBB)] [(SA666)]	93AA66C(08bit)@MSOP8
93AA66C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93AA66C(08bit)@TSSOP8
93AA66C(16bit) [(BBBB)]	93AA66C(16bit)@DFN8
93AA66C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93AA66C(16bit)@SOIC8
93AA66C(16bit)@TSSOP8 [(SA026)] (08bit)	93AA76
93AA76(08bit)@SOIC8 [(SA602A)] (16bit)	93AA76
93AA76(16bit)@SOIC8 [(SA602A)] (08bit)	93AA76A
93AA76A(08bit)@DFN8 [(BBBB)] [(SA666)]	93AA76A(08bit)@MSOP8
93AA76A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93AA76A(08bit)@SOT-23
93AA76A(08bit)@TSSOP8 [(SA026)] (16bit)	93AA76B
93AA76B(16bit)@DFN8 [(BBBB)] [(SA666)]	93AA76B(16bit)@MSOP8
93AA76B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93AA76B(16bit)@SOT-23
93AA76B(16bit)@TSSOP8 [(SA026)]	93AA76C

(08bit)	
93AA76C(08bit)@DFN8 [(BBBB)]	93AA76C(08bit)@MSOP8
[(SA666)]	
93AA76C(08bit)@SOIC8 [(SA602A)]	93AA76C(08bit)@TSSOP8
[(SA026)]	
93AA76C(16bit)	93AA76C(16bit)@DFN8
[(BBBB)]	
93AA76C(16bit)@MSOP8 [(SA666)]	93AA76C(16bit)@SOIC8
[(SA602A)]	
93AA76C(16bit)@TSSOP8 [(SA026)]	93AA86
(08bit)	
93AA86(08bit)@SOIC8 [(SA602A)]	93AA86
(16bit)	
93AA86(16bit)@SOIC8 [(SA602A)]	93AA86A
(08bit)	
93AA86A(08bit)@DFN8 [(BBBB)]	93AA86A(08bit)@MSOP8
[(SSA666)]	
93AA86A(08bit)@SOIC8 [(SA602A)]	93AA86A(08bit)@SOT-23
[(SA717)]	
93AA86A(08bit)@TSSOP8 [(SA026)]	93AA86B
(16bit)	
93AA86B(16bit)@DFN8 [(BBBB)]	93AA86B(16bit)@MSOP8
[(SA666)]	
93AA86B(16bit)@SOIC8 [(SA602A)]	93AA86B(16bit)@SOT-23
[(SA717)]	
93AA86B(16bit)@TSSOP8 [(SA026)]	93AA86C
(08bit)	
93AA86C(08bit)@DFN8 [(BBBB)]	93AA86C(08bit)@MSOP8
[(SA666)]	
93AA86C(08bit)@SOIC8 [(SA602A)]	93AA86C(08bit)@TSSOP8
[(SA026)]	
93AA86C(16bit)	93AA86C(16bit)@DFN8
[(BBBB)]	
93AA86C(16bit)@MSOP8 [(SA666)]	93AA86C(16bit)@SOIC8
[(SA602A)]	
93AA86C(16bit)@TSSOP8 [(SA026)]	93C06
(08bit)	
93C06(08bit)@SOIC8 [(SA602A)]	93C06
(16bit)	
93C06(16bit)@SOIC8 [(SA602A)]	93C46
(08bit)	
93C46(08bit)@SOIC8 [(SA602A)]	93C46
(16bit)	

93C46(16bit)@SOIC8 [(SA602A)] (08bit)	93C46A
93C46A(08bit)@DFN8 [(BBBB)] [(SA666)]	93C46A(08bit)@MSOP8
93C46A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93C46A(08bit)@SOT-23
93C46A(08bit)@TSSOP8 [(SA026)] (16bit)	93C46B
93C46B(16bit)@DFN8 [(BBBB)] [(SA666)]	93C46B(16bit)@MSOP8
93C46B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93C46B(16bit)@SOT-23
93C46B(16bit)@TSSOP8 [(SA026)] (08bit)	93C46C
93C46C(08bit)@DFN8 [(BBBB)] [(SA666)]	93C46C(08bit)@MSOP8
93C46C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93C46C(08bit)@TSSOP8
93C46C(16bit) [(BBBB)]	93C46C(16bit)@DFN8
93C46C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93C46C(16bit)@SOIC8
93C46C(16bit)@TSSOP8 [(SA026)] (08bit)	93C56
93C56(08bit)@SOIC8 [(SA602A)] (16bit)	93C56
93C56(16bit)@SOIC8 [(SA602A)] (08bit)	93C56A
93C56A(08bit)@DFN8 [(BBBB)] [(SA666)]	93C56A(08bit)@MSOP8
93C56A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93C56A(08bit)@SOT-23
93C56A(08bit)@TSSOP8 [(SA026)] (16bit)	93C56B
93C56B(16bit)@DFN8 [(BBBB)] [(SA666)]	93C56B(16bit)@MSOP8
93C56B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93C56B(16bit)@SOT-23
93C56B(16bit)@TSSOP8 [(SA026)] (08bit)	93C56C
93C56C(08bit)@DFN8 [(BBBB)] [(SA666)]	93C56C(08bit)@MSOP8
93C56C(08bit)@SOIC8 [(SA602A)]	93C56C(08bit)@TSSOP8

[(SA026)]	
93C56C(16bit)	93C56C(16bit)@DFN8
[(BBBB)]	
93C56C(16bit)@MSOP8 [(SA666)]	93C56C(16bit)@SOIC8
[(SA602A)]	
93C56C(16bit)@TSSOP8 [(SA026)]	93C66
(08bit)	
93C66(08bit)@SOIC8 [(SA602A)]	93C66
(16bit)	
93C66(16bit)@SOIC8 [(SA602A)]	93C66A
(08bit)	
93C66A(08bit)@DFN8 [(BBBB)]	93C66A(08bit)@MSOP8
[(SA666)]	
93C66A(08bit)@SOIC8 [(SA602A)]	93C66A(08bit)@SOT-23
[(SA717)]	
93C66A(08bit)@TSSOP8 [(SA026)]	93C66B
(16bit)	
93C66B(16bit)@DFN8 [(BBBB)]	93C66B(16bit)@MSOP8
[(SA666)]	
93C66B(16bit)@SOIC8 [(SA602A)]	93C66B(16bit)@SOT-23
[(SA717)]	
93C66B(16bit)@TSSOP8 [(SA026)]	93C66C
(08bit)	
93C66C(08bit)@DFN8 [(BBBB)]	93C66C(08bit)@MSOP8
[(SA666)]	
93C66C(08bit)@SOIC8 [(SA602A)]	93C66C(08bit)@TSSOP8
[(SA026)]	
93C66C(16bit)	93C66C(16bit)@DFN8
[(BBBB)]	
93C66C(16bit)@MSOP8 [(SA666)]	93C66C(16bit)@SOIC8
[(SA602A)]	
93C66C(16bit)@TSSOP8 [(SA026)]	93C76
(08bit)	
93C76(08bit)@SOIC8 [(SA602A)]	93C76
(16bit)	
93C76(16bit)@SOIC8 [(SA602A)]	93C76A
(08bit)	
93C76A(08bit)@DFN8 [(BBBB)]	93C76A(08bit)@MSOP8
[(SA666)]	
93C76A(08bit)@SOIC8 [(SA602A)]	93C76A(08bit)@SOT-23
[(SA717)]	
93C76A(08bit)@TSSOP8 [(SA026)]	93C76B
(16bit)	



93C76B(16bit)@DFN8 [(BBBB)]	93C76B(16bit)@MSOP8
[(SA666)]	
93C76B(16bit)@SOIC8 [(SA602A)]	93C76B(16bit)@SOT-23
[(SA717)]	
93C76B(16bit)@TSSOP8 [(SA026)]	93C76C
(08bit)	
93C76C(08bit)@DFN8 [(BBBB)]	93C76C(08bit)@MSOP8
[(SA666)]	
93C76C(08bit)@SOIC8 [(SA602A)]	93C76C(08bit)@TSSOP8
[(SA026)]	
93C76C(16bit)	93C76C(16bit)@DFN8
[(BBBB)]	
93C76C(16bit)@MSOP8 [(SA666)]	93C76C(16bit)@SOIC8
[(SA602A)]	
93C76C(16bit)@TSSOP8 [(SA026)]	93C86
(08bit)	
93C86(08bit)@SOIC8 [(SA602A)]	93C86
(16bit)	
93C86(16bit)@SOIC8 [(SA602A)]	93C86A
(08bit)	
93C86A(08bit)@DFN8 [(BBBB)]	93C86A(08bit)@MSOP8
[(SSA666)]	
93C86A(08bit)@SOIC8 [(SA602A)]	93C86A(08bit)@SOT-23
[(SA717)]	
93C86A(08bit)@TSSOP8 [(SA026)]	93C86B
(16bit)	
93C86B(16bit)@DFN8 [(BBBB)]	93C86B(16bit)@MSOP8
[(SA666)]	
93C86B(16bit)@SOIC8 [(SA602A)]	93C86B(16bit)@SOT-23
[(SA717)]	
93C86B(16bit)@TSSOP8 [(SA026)]	93C86C
(08bit)	
93C86C(08bit)@DFN8 [(BBBB)]	93C86C(08bit)@MSOP8
[(SA666)]	
93C86C(08bit)@SOIC8 [(SA602A)]	93C86C(08bit)@TSSOP8
[(SA026)]	
93C86C(16bit)	93C86C(16bit)@DFN8
[(BBBB)]	
93C86C(16bit)@MSOP8 [(SA666)]	93C86C(16bit)@SOIC8
[(SA602A)]	
93C86C(16bit)@TSSOP8 [(SA026)]	93LC46
(08bit)	
93LC46(08bit)@SOIC8 [(SA602A)]	93LC46

(16bit)	
93LC46(16bit)@SOIC8 [(SA602A)]	93LC46A
(08bit)	
93LC46A(08bit)@DFN8 [(BBBB)]	93LC46A(08bit)@MSOP8
[(SA666)]	
93LC46A(08bit)@SOIC8 [(SA602A)]	93LC46A(08bit)@SOT-23
[(SA717)]	
93LC46A(08bit)@TSSOP8 [(SA026)]	93LC46B
(16bit)	
93LC46B(16bit)@DFN8 [(BBBB)]	93LC46B(16bit)@MSOP8
[(SA666)]	
93LC46B(16bit)@SOIC8 [(SA602A)]	93LC46B(16bit)@SOT-23
[(SA717)]	
93LC46B(16bit)@TSSOP8 [(SA026)]	
93LC46BX	
93LC46BX@SOIC8 [(SA602A)]	93LC46C
(08bit)	
93LC46C(08bit)@DFN8 [(BBBB)]	93LC46C(08bit)@MSOP8
[(SA666)]	
93LC46C(08bit)@SOIC8 [(SA602A)]	93LC46C(08bit)@TSSOP8
[(SA026)]	
93LC46C(16bit)	93LC46C(16bit)@DFN8
[(BBBB)]	
93LC46C(16bit)@MSOP8 [(SA666)]	93LC46C(16bit)@SOIC8
[(SA602A)]	
93LC46C(16bit)@TSSOP8 [(SA026)]	93LC56
(08bit)	
93LC56(08bit)@SOIC8 [(SA602A)]	93LC56
(16bit)	
93LC56(16bit)@SOIC8 [(SA602A)]	93LC56A
(08bit)	
93LC56A(08bit)@DFN8 [(BBBB)]	93LC56A(08bit)@MSOP8
[(SA666)]	
93LC56A(08bit)@SOIC8 [(SA602A)]	93LC56A(08bit)@SOT-23
[(SA717)]	
93LC56A(08bit)@TSSOP8 [(SA026)]	93LC56B
(16bit)	
93LC56B(16bit)@DFN8 [(BBBB)]	93LC56B(16bit)@MSOP8
[(SA666)]	
93LC56B(16bit)@SOIC8 [(SA602A)]	93LC56B(16bit)@SOT-23
[(SA717)]	
93LC56B(16bit)@TSSOP8 [(SA026)]	
93LC56BX	

93LC56BX@SOIC8 [(SA602A)] (08bit)	93LC56C
93LC56C(08bit)@DFN8 [(BBBB)] [(SA666)]	93LC56C(08bit)@MSOP8
93LC56C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93LC56C(08bit)@TSSOP8
93LC56C(16bit) [(BBBB)]	93LC56C(16bit)@DFN8
93LC56C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93LC56C(16bit)@SOIC8
93LC56C(16bit)@TSSOP8 [(SA026)] (08bit)	93LC66
93LC66(08bit)@SOIC8 [(SA602A)] (16bit)	93LC66
93LC66(16bit)@SOIC8 [(SA602A)] (08bit)	93LC66A
93LC66A(08bit)@DFN8 [(BBBB)] [(SA666)]	93LC66A(08bit)@MSOP8
93LC66A(08bit)@SOIC8 [(SA602A)] [(SA717)]	93LC66A(08bit)@SOT-23
93LC66A(08bit)@TSSOP8 [(SA026)] (16bit)	93LC66B
93LC66B(16bit)@DFN8 [(BBBB)] [(SA666)]	93LC66B(16bit)@MSOP8
93LC66B(16bit)@SOIC8 [(SA602A)] [(SA717)]	93LC66B(16bit)@SOT-23
93LC66B(16bit)@TSSOP8 [(SA026)]	
93LC66BX	
93LC66BX@SOIC8 [(SA602A)] (08bit)	93LC66C
93LC66C(08bit)@DFN8 [(BBBB)] [(SA666)]	93LC66C(08bit)@MSOP8
93LC66C(08bit)@SOIC8 [(SA602A)] [(SA026)]	93LC66C(08bit)@TSSOP8
93LC66C(16bit) [(BBBB)]	93LC66C(16bit)@DFN8
93LC66C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93LC66C(16bit)@SOIC8
93LC66C(16bit)@TSSOP8 [(SA026)] (08bit)	93LC76
93LC76(08bit)@SOIC8 [(SA602A)] (16bit)	93LC76
93LC76(16bit)@SOIC8 [(SA602A)]	93LC76A

(08bit)	
93LC76A(08bit)@DFN8 [(BBBB)]	93LC76A(08bit)@MSOP8
[(SA666)]	
93LC76A(08bit)@SOIC8 [(SA602A)]	93LC76A(08bit)@SOT-23
[(SA717)]	
93LC76A(08bit)@TSSOP8 [(SA026)]	93LC76B
(16bit)	
93LC76B(16bit)@DFN8 [(BBBB)]	93LC76B(16bit)@MSOP8
[(SA666)]	
93LC76B(16bit)@SOIC8 [(SA602A)]	93LC76B(16bit)@SOT-23
[(SA717)]	
93LC76B(16bit)@TSSOP8 [(SA026)]	93LC76C
(08bit)	
93LC76C(08bit)@DFN8 [(BBBB)]	93LC76C(08bit)@MSOP8
[(SA666)]	
93LC76C(08bit)@SOIC8 [(SA602A)]	93LC76C(08bit)@TSSOP8
[(SA026)]	
93LC76C(16bit)	93LC76C(16bit)@DFN8
[(BBBB)]	
93LC76C(16bit)@MSOP8 [(SA666)]	93LC76C(16bit)@SOIC8
[(SA602A)]	
93LC76C(16bit)@TSSOP8 [(SA026)]	93LC86
(08bit)	
93LC86(08bit)@SOIC8 [(SA602A)]	93LC86
(16bit)	
93LC86(16bit)@SOIC8 [(SA602A)]	93LC86A
(08bit)	
93LC86A(08bit)@DFN8 [(BBBB)]	93LC86A(08bit)@MSOP8
[(SSA666)]	
93LC86A(08bit)@SOIC8 [(SA602A)]	93LC86A(08bit)@SOT-23
[(SA717)]	
93LC86A(08bit)@TSSOP8 [(SA026)]	93LC86B
(16bit)	
93LC86B(16bit)@DFN8 [(BBBB)]	93LC86B(16bit)@MSOP8
[(SA666)]	
93LC86B(16bit)@SOIC8 [(SA602A)]	93LC86B(16bit)@SOT-23
[(SA717)]	
93LC86B(16bit)@TSSOP8 [(SA026)]	93LC86C
(08bit)	
93LC86C(08bit)@DFN8 [(BBBB)]	93LC86C(08bit)@MSOP8
[(SA666)]	
93LC86C(08bit)@SOIC8 [(SA602A)]	93LC86C(08bit)@TSSOP8
[(SA026)]	

93LC86C(16bit) [(BBBB)]	93LC86C(16bit)@DFN8
93LC86C(16bit)@MSOP8 [(SA666)] [(SA602A)]	93LC86C(16bit)@SOIC8
93LC86C(16bit)@TSSOP8 [(SA026)] 93LCS46	
93LCS46@SOIC14 [(SA026)] [(SA602A)]	93LCS46@SOIC8
93LCS56 [(SA026)]	93LCS56@SOIC14
93LCS56@SOIC8 [(SA602A)] 93LCS66	
93LCS66@SOIC14 [(SA026)] [(SA602A)]	93LCS66@SOIC8
ER5911 [(SA602A)]	ER5911@SOIC8
HCS101 [(SA602A)]	HCS101SN@SOIC8
HCS200 [(SA602A)]	HCS200SN@SOIC8
HCS300 [(SA602A)]	HCS300SN@SOIC8
HCS301 [(SA602A)]	HCS301SN@SOIC8
HCS320 [(SA602A)]	HCS320SN@SOIC8
HCS360 [(SA602A)]	HCS360SN@SOIC8
HCS361 [(SA602A)]	HCS361SN@SOIC8

## MICROCONTROLLER

MCP25020  
MCP25020(150mil)@SOIC14 [(SA602)]  
MCP25020(150mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25020(208mil)@SOIC14 [(SA404)]  
MCP25020(208mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25020(ISP) [ISP-HEADER01]  
MCP25025  
MCP25025(150mil)@SOIC14 [(SA602)]  
MCP25025(150mil)@SOIC14(ISP) [ISP-HEADER01]

MCP25025(208mil)@SOIC14 [(SA404)]  
MCP25025(208mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25025(ISP) [ISP-HEADER01]  
MCP25050  
MCP25050(150mil)@SOIC14 [(SA602)]  
MCP25050(150mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25050(208mil)@SOIC14 [(SA404)]  
MCP25050(208mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25050(ISP) [ISP-HEADER01]  
MCP25055  
MCP25055(150mil)@SOIC14 [(SA602)]  
MCP25055(150mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25055(208mil)@SOIC14 [(SA404)]  
MCP25055(208mil)@SOIC14(ISP) [ISP-HEADER01]  
MCP25055(ISP) [ISP-HEADER01]  
PIC10F200  
PIC10F200(ISP) [ISP-HEADER01] PIC10F200@SOT6  
[(SA717)]  
PIC10F200@SOT6(ISP) [ISP-HEADER01]  
PIC10F202 PIC10F202(ISP) [ISP-  
HEADER01]  
PIC10F202@SOT6 [(SA717)]  
PIC10F202@SOT6(ISP) [ISP-HEADER01]  
PIC10F204 PIC10F204(ISP) [ISP-  
HEADER01]  
PIC10F204@SOT6 [(SA717)]  
PIC10F204@SOT6(ISP) [ISP-HEADER01]  
PIC10F206 PIC10F206(ISP) [ISP-  
HEADER01]  
PIC10F206@SOT6 [(SA717)]  
PIC10F206@SOT6(ISP) [ISP-HEADER01]  
PIC10F220 PIC10F220(ISP) [ISP-  
HEADER01]  
PIC10F220@SOT6 [(SA717)]  
PIC10F220@SOT6(ISP) [ISP-HEADER01]  
PIC10F222 PIC10F222(ISP) [ISP-  
HEADER01]  
PIC10F222@SOT6 [(SA717)]  
PIC10F222@SOT6(ISP) [ISP-HEADER01]  
PIC12C508 PIC12C508(ISP) [ISP-  
HEADER01]  
PIC12C508@SOIC8 [(SA605A)]  
PIC12C508@SOIC8(ISP) [ISP-HEADER01]

PIC12C508A PIC12C508A(ISP) [ISP-  
HEADER01]  
PIC12C508A(SM)@SOIC8 [(SA605A)]  
PIC12C508A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C508A(SN)@SOIC8 [(SA602A)]  
PIC12C508A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509 PIC12C509(ISP) [ISP-  
HEADER01]  
PIC12C509(SM)@SOIC8 [(SA605A)]  
PIC12C509(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509(SN)@SOIC8 [(SA602A)]  
PIC12C509(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509A PIC12C509A(ISP) [ISP-  
HEADER01]  
PIC12C509A(SM)@SOIC8 [(SA605A)]  
PIC12C509A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509A(SN)@SOIC8 [(SA602A)]  
PIC12C509A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12C509A@DFN8 [(SA683)]  
PIC12C509A@DFN8(ISP) [ISP-HEADER01]  
PIC12C671 PIC12C671(ISP) [ISP-  
HEADER01]  
PIC12C671@DFN8 [(SA683)]  
PIC12C671@DFN8(ISP) [ISP-HEADER01]  
PIC12C671@SOIC8 [(SA605A)]  
PIC12C671@SOIC8(ISP) [ISP-HEADER01]  
PIC12C672 PIC12C672(ISP) [ISP-  
HEADER01]  
PIC12C672@DFN8 [(SA683)]  
PIC12C672@DFN8(ISP) [ISP-HEADER01]  
PIC12C672@SOIC8 [(SA605A)]  
PIC12C672@SOIC8(ISP) [ISP-HEADER01]  
PIC12CE518 PIC12CE518(ISP) [ISP-  
HEADER01]  
PIC12CE518@SOIC8 [(SA605A)]  
PIC12CE518@SOIC8(ISP) [ISP-HEADER01]  
PIC12CE519 PIC12CE519(ISP) [ISP-  
HEADER01]  
PIC12CE519(SM)@SOIC8 [(SA605A)]  
PIC12CE519(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12CE519(SN)@SOIC8 [(SA602A)]  
PIC12CE519(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12CE673 PIC12CE673(ISP) [ISP-

HEADER01 ]  
PIC12CE673@SOIC8 [(SA605A)]  
PIC12CE673@SOIC8(ISP) [ISP-HEADER01]  
PIC12CE674 PIC12CE674(ISP) [ISP-  
HEADER01]  
PIC12CE674@SOIC8 [(SA605A)]  
PIC12CE674@SOIC8(ISP) [ISP-HEADER01]  
PIC12F508 PIC12F508(ISP) [ISP-  
HEADER01]  
PIC12F508@MSOP8 [(SA666)]  
PIC12F508@MSOP8(ISP) [ISP-HEADER01]  
PIC12F508@SOIC8 [(SA602)]  
PIC12F508@SOIC8(ISP) [ISP-HEADER01]  
PIC12F509 PIC12F509(ISP) [ISP-  
HEADER01]  
PIC12F509@MSOP8 [(SA666)]  
PIC12F509@MSOP8(ISP) [ISP-HEADER01]  
PIC12F509@SOIC8 [(SA602)]  
PIC12F509@SOIC8(ISP) [ISP-HEADER01]  
PIC12F510 PIC12F510(ISP) [ISP-  
HEADER01]  
PIC12F510@MSOP8 [(SA666)]  
PIC12F510@MSOP8(ISP) [ISP-HEADER01]  
PIC12F510@SOIC8 [(SA605A)]  
PIC12F510@SOIC8(ISP) [ISP-HEADER01]  
PIC12F609 PIC12F609(ISP) [ISP-  
HEADER01]  
PIC12F609@DFN8 [(BBBB)]  
PIC12F609@DFN8(ISP) [ISP-HEADER01]  
PIC12F609@SOIC8 [(SA602A)]  
PIC12F609@SOIC8(ISP) [ISP-HEADER01]  
PIC12F615 PIC12F615(ISP) [ISP-  
HEADER01]  
PIC12F615@DFN8 [(BBBB)]  
PIC12F615@DFN8(ISP) [ISP-HEADER01]  
PIC12F615@SOIC8 [(SA602A)]  
PIC12F615@SOIC8(ISP) [ISP-HEADER01]  
PIC12F629 PIC12F629(ISP) [ISP-  
HEADER01]  
PIC12F629(SM)@SOIC8 [(SA605A)]  
PIC12F629(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F629(SN)@SOIC8 [(SA602A)]  
PIC12F629(SN)@SOIC8(ISP) [ISP-HEADER01]



PIC12F629@DFN8 [(SA683)]  
PIC12F629@DFN8(ISP) [ISP-HEADER01]  
PIC12F635 PIC12F635(ISP) [ISP-  
HEADER01]  
PIC12F635(MD)@DFN8 [(SA744)]  
PIC12F635(MD)@DFN8(ISP) [ISP-HEADER01]  
PIC12F635(MF)@DFN8 [(SA683)]  
PIC12F635(MF)@DFN8(ISP) [ISP-HEADER01]  
PIC12F635(SM)@SOIC8 [(SA605A)]  
PIC12F635(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F635(SN)@SOIC8 [(SA602A)]  
PIC12F635(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F675 PIC12F675(ISP) [ISP-  
HEADER01]  
PIC12F675(SM)@SOIC8 [(SA605A)]  
PIC12F675(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F675(SN)@SOIC8 [(SA602A)]  
PIC12F675(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F675@DFN8 [(SA683)]  
PIC12F675@DFN8(ISP) [ISP-HEADER01]  
PIC12F675@SSOP20 [(SA626A)]  
PIC12F675@SSOP20(ISP) [ISP-HEADER01]  
PIC12F683 PIC12F683(ISP) [ISP-  
HEADER01]  
PIC12F683(MD)@DFN8 [(SA744)]  
PIC12F683(MD)@DFN8(ISP) [ISP-HEADER01]  
PIC12F683(MF)@DFN8 [(SA683)]  
PIC12F683(MF)@DFN8(ISP) [ISP-HEADER01]  
PIC12F683(SM)@SOIC8 [(SA605A)]  
PIC12F683(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12F683(SN)@SOIC8 [(SA602A)]  
PIC12F683(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12HV609 PIC12HV609(ISP) [ISP-  
HEADER01]  
PIC12HV609@DFN8 [(BBBB)]  
PIC12HV609@DFN8(ISP) [ISP-HEADER01]  
PIC12HV609@SOIC8 [(SA602A)]  
PIC12HV609@SOIC8(ISP) [ISP-HEADER01]  
PIC12HV615 PIC12HV615(ISP) [ISP-  
HEADER01]  
PIC12HV615@DFN8 [(BBBB)]  
PIC12HV615@DFN8(ISP) [ISP-HEADER01]  
PIC12HV615@SOIC8 [(SA602A)]

PIC12HV615@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC508 PIC12LC508(ISP) [ISP-  
HEADER01]  
PIC12LC508@SOIC8 [(SA605A)]  
PIC12LC508@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC508A PIC12LC508A(ISP) [ISP-  
HEADER01]  
PIC12LC508A(SM)@SOIC8 [(SA605A)]  
PIC12LC508A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC508A(SN)@SOIC8 [(SA602A)]  
PIC12LC508A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509 PIC12LC509(ISP) [ISP-  
HEADER01]  
PIC12LC509(SM)@SOIC8 [(SA605A)]  
PIC12LC509(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509(SN)@SOIC8 [(SA602A)]  
PIC12LC509(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509A PIC12LC509A(ISP) [ISP-  
HEADER01]  
PIC12LC509A(SM)@SOIC8 [(SA605A)]  
PIC12LC509A(SM)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC509A(SN)@SOIC8 [(SA602A)]  
PIC12LC509A(SN)@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC671 PIC12LC671(ISP) [ISP-  
HEADER01]  
PIC12LC671@DFN8 [(SA683)]  
PIC12LC671@DFN8(ISP) [ISP-HEADER01]  
PIC12LC671@SOIC8 [(SA605A)]  
PIC12LC671@SOIC8(ISP) [ISP-HEADER01]  
PIC12LC672 PIC12LC672(ISP) [ISP-  
HEADER01]  
PIC12LC672@DFN8 [(SA683)]  
PIC12LC672@DFN8(ISP) [ISP-HEADER01]  
PIC12LC672@SOIC8 [(SA605A)]  
PIC12LC672@SOIC8(ISP) [ISP-HEADER01]  
PIC12LF508 PIC12LF508(ISP) [ISP-  
HEADER01]  
PIC12LF508@MSOP8 [(SA666)]  
PIC12LF508@MSOP8(ISP) [ISP-HEADER01]  
PIC12LF508@SOIC8 [(SA602)]  
PIC12LF508@SOIC8(ISP) [ISP-HEADER01]  
PIC12LF509 PIC12LF509(ISP) [ISP-  
HEADER01]

PIC12LF509@MSOP8 [(SA666)]  
 PIC12LF509@MSOP8(ISP) [ISP-HEADER01]  
 PIC12LF509@SOIC8 [(SA602)]  
 PIC12LF509@SOIC8(ISP) [ISP-HEADER01]  
 PIC14000 PIC14000(ISP) [ISP-  
 HEADER01]  
 PIC14000@SOIC28 [(SA404)]  
 PIC14000@SOIC28(ISP) [ISP-HEADER01]  
 PIC14000@SSOP28 [(SA626A)]  
 PIC14000@SSOP28(ISP) [ISP-HEADER01]  
 PIC16C432 PIC16C432(ISP) [ISP-  
 HEADER01]  
 PIC16C432@SSOP20 [(SA626A)]  
 PIC16C432@SSOP20(ISP) [ISP-HEADER01]  
 PIC16C433 PIC16C433(ISP) [ISP-  
 HEADER01]  
 PIC16C433@SOIC18 [(SA404)]  
 PIC16C433@SOIC18(ISP) [ISP-HEADER01]  
 PIC16C505 PIC16C505@SOIC14  
 [(SA602)]  
 PIC16C52 PIC16C52@SOIC18  
 [(SA404)]  
 PIC16C54 PIC16C54@SOIC18  
 [(SA404)]  
 PIC16C54A PIC16C54A@SOIC18  
 [(SA404)]  
 PIC16C54A@SSOP20 [(SA626A)]  
 PIC16C54B  
 PIC16C54B@SOIC18 [(SA404)] PIC16C54B@SSOP20  
 [(SA626A)]  
 PIC16C54C PIC16C54C@SOIC18  
 [(SA404)]  
 PIC16C54C@SSOP20 [(SA626A)]  
 PIC16C55  
 PIC16C55@SOIC28 [(SA404)]  
 PIC16C554  
 PIC16C554(ISP) [ISP-HEADER01] PIC16C554@SOIC18  
 [(SA404)]  
 PIC16C554@SOIC18(ISP) [ISP-HEADER01]  
 PIC16C554@SSOP20 [(SA626A)]  
 PIC16C554@SSOP20(ISP) [ISP-HEADER01]  
 PIC16C556 PIC16C556(ISP) [ISP-  
 HEADER01]

PIC16C556@SOIC18 [(SA404)]  
PIC16C556@SOIC18(ISP) [ISP-HEADER01]  
PIC16C558 PIC16C558(ISP) [ISP-  
HEADER01]  
PIC16C558@SOIC18 [(SA404)]  
PIC16C558@SOIC18(ISP) [ISP-HEADER01]  
PIC16C558@SSOP20 [(SA626A)]  
PIC16C558@SSOP20(ISP) [ISP-HEADER01]  
PIC16C55A PIC16C55A@SOIC28  
[(SA404)]  
PIC16C55A@SSOP28 [(SA626A)]  
PIC16C56  
PIC16C56@SOIC18 [(SA404)]  
PIC16C56A  
PIC16C56A@SOIC18 [(SA404)] PIC16C56A@SSOP20  
[(SA626A)]  
PIC16C57 PIC16C57@SOIC28  
[(SA404)]  
PIC16C57@SSOP28 [(SA626A)]  
PIC16C57C  
PIC16C57C@SOIC28 [(SA404)] PIC16C57C@SSOP28  
[(SA626A)]  
PIC16C58 PIC16C58@SOIC18  
[(SA404)]  
PIC16C58A PIC16C58A@SOIC18  
[(SA404)]  
PIC16C58A@SSOP20 [(SA626A)]  
PIC16C58B  
PIC16C58B@SOIC18 [(SA404)] PIC16C58B@SSOP20  
[(SA626A)]  
PIC16C61 PIC16C61(ISP) [ISP-  
HEADER01]  
PIC16C61@SOIC18 [(SA404)]  
PIC16C61@SOIC18(ISP) [ISP-HEADER01]  
PIC16C62 PIC16C62(ISP) [ISP-  
HEADER01]  
PIC16C62@SOIC28 [(SA404)]  
PIC16C62@SOIC28(ISP) [ISP-HEADER01]  
PIC16C62@SSOP28 [(SA626A)]  
PIC16C62@SSOP28(ISP) [ISP-HEADER01]  
PIC16C620 PIC16C620(ISP) [ISP-  
HEADER01]  
PIC16C620@SOIC18 [(SA404)]

PIC16C620@SOIC18(ISP) [ISP-HEADER01]  
PIC16C620A PIC16C620A(ISP) [ISP-  
HEADER01]  
PIC16C620A@SOIC18 [(SA404)]  
PIC16C620A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C620A@SSOP20 [(SA626A)]  
PIC16C620A@SSOP20(ISP) [ISP-HEADER01]  
PIC16C621 PIC16C621(ISP) [ISP-  
HEADER01]  
PIC16C621@SOIC18 [(SA404)]  
PIC16C621@SOIC18(ISP) [ISP-HEADER01]  
PIC16C621A PIC16C621A(ISP) [ISP-  
HEADER01]  
PIC16C621A@SOIC18 [(SA404)]  
PIC16C621A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C621A@SSOP20 [(SA626A)]  
PIC16C621A@SSOP20(ISP) [ISP-HEADER01]  
PIC16C622 PIC16C622(ISP) [ISP-  
HEADER01]  
PIC16C622@SOIC18 [(SA404)]  
PIC16C622@SOIC18(ISP) [ISP-HEADER01]  
PIC16C622A PIC16C622A(ISP) [ISP-  
HEADER01]  
PIC16C622A@SOIC18 [(SA404)]  
PIC16C622A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C622A@SSOP20 [(SA626A)]  
PIC16C622A@SSOP20(ISP) [ISP-HEADER01]  
PIC16C625 PIC16C625(ISP) [ISP-  
HEADER01]  
PIC16C625@SOIC18 [(SA404)]  
PIC16C625@SOIC18(ISP) [ISP-HEADER01]  
PIC16C62A PIC16C62A(ISP) [ISP-  
HEADER01]  
PIC16C62A@SOIC28 [(SA404)]  
PIC16C62A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C62A@SSOP28 [(SA626A)]  
PIC16C62A@SSOP28(ISP) [ISP-HEADER01]  
PIC16C62B PIC16C62B(ISP) [ISP-  
HEADER01]  
PIC16C62B@SOIC28 [(SA404)]  
PIC16C62B@SOIC28(ISP) [ISP-HEADER01]  
PIC16C62B@SSOP28 [(SA626A)]  
PIC16C62B@SSOP28(ISP) [ISP-HEADER01]



PIC16C65B@PLCC44 (ISP) [ISP-HEADER01]  
PIC16C65B@TQFP44 [(SA245A)]  
PIC16C65B@TQFP44 (ISP) [ISP-HEADER01]  
PIC16C66 PIC16C66 (ISP) [ISP-  
HEADER01]  
PIC16C66@SOIC28 [(SA404)]  
PIC16C66@SOIC28 (ISP) [ISP-HEADER01]  
PIC16C661 PIC16C661@PLCC44  
[(SA244)]  
PIC16C661@TQFP44 [(SA245A)]  
PIC16C662  
PIC16C662@PLCC44 [(SA244)] PIC16C662@TQFP44  
[(SA245A)]  
PIC16C67 PIC16C67 (ISP) [ISP-  
HEADER01]  
PIC16C67@PLCC44 [(SA244)]  
PIC16C67@PLCC44 (ISP) [ISP-HEADER01]  
PIC16C67@TQFP44 [(SA245A)]  
PIC16C67@TQFP44 (ISP) [ISP-HEADER01]  
PIC16C70 PIC16C70 (ISP) [ISP-  
HEADER01]  
PIC16C70@SOIC18 [(SA404)]  
PIC16C70@SOIC18 (ISP) [ISP-HEADER01]  
PIC16C71 PIC16C71 (ISP) [ISP-  
HEADER01]  
PIC16C71@SOIC18 [(SA404)]  
PIC16C71@SOIC18 (ISP) [ISP-HEADER01]  
PIC16C710 PIC16C710 (ISP) [ISP-  
HEADER01]  
PIC16C710@SOIC18 [(SA404)]  
PIC16C710@SOIC18 (ISP) [ISP-HEADER01]  
PIC16C710@SSOP20 [(SA626A)]  
PIC16C710@SSOP20 (ISP) [ISP-HEADER01]  
PIC16C711 PIC16C711 (ISP) [ISP-  
HEADER01]  
PIC16C711@SOIC18 [(SA404)]  
PIC16C711@SOIC18 (ISP) [ISP-HEADER01]  
PIC16C711@SSOP20 [(SA626A)]  
PIC16C711@SSOP20 (ISP) [ISP-HEADER01]  
PIC16C712 PIC16C712 (ISP) [ISP-  
HEADER01]  
PIC16C712@SOIC18 [(SA404)]  
PIC16C712@SOIC18 (ISP) [ISP-HEADER01]

PIC16C712@SSOP20 [(SA626A)]  
PIC16C712@SSOP20(ISP) [ISP-HEADER01]  
PIC16C715 PIC16C715@SOIC18  
[(SA404)]  
PIC16C715@SSOP20 [(SA626A)]  
PIC16C716  
PIC16C716(ISP) [ISP-HEADER01] PIC16C716@SOIC18  
[(SA404)]  
PIC16C716@SOIC18(ISP) [ISP-HEADER01]  
PIC16C716@SSOP20 [(SA626A)]  
PIC16C716@SSOP20(ISP) [ISP-HEADER01]  
PIC16C717 PIC16C717(ISP) [ISP-  
HEADER01]  
PIC16C717@SOIC18 [(SA404)]  
PIC16C717@SOIC18(ISP) [ISP-HEADER01]  
PIC16C717@SSOP20 [(SA626A)]  
PIC16C717@SSOP20(ISP) [ISP-HEADER01]  
PIC16C71A PIC16C71A(ISP) [ISP-  
HEADER01]  
PIC16C71A@SOIC18 [(SA404)]  
PIC16C71A@SOIC18(ISP) [ISP-HEADER01]  
PIC16C72 PIC16C72(ISP) [ISP-  
HEADER01]  
PIC16C72@SOIC28 [(SA404)]  
PIC16C72@SOIC28(ISP) [ISP-HEADER01]  
PIC16C72@SSOP28 [(SA626A)]  
PIC16C72@SSOP28(ISP) [ISP-HEADER01]  
PIC16C72A PIC16C72A(ISP) [ISP-  
HEADER01]  
PIC16C72A@SOIC28 [(SA404)]  
PIC16C72A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C72A@SSOP28 [(SA626A)]  
PIC16C72A@SSOP28(ISP) [ISP-HEADER01]  
PIC16C73 PIC16C73(ISP) [ISP-  
HEADER01]  
PIC16C73@SOIC28 [(SA404)]  
PIC16C73@SOIC28(ISP) [ISP-HEADER01]  
PIC16C73A PIC16C73A(ISP) [ISP-  
HEADER01]  
PIC16C73A@SOIC28 [(SA404)]  
PIC16C73A@SOIC28(ISP) [ISP-HEADER01]  
PIC16C73B PIC16C73B(ISP) [ISP-  
HEADER01]



PIC16C73B@SOIC28 [(SA404)]  
PIC16C73B@SOIC28(ISP) [ISP-HEADER01]  
PIC16C73B@SSOP28 [(SA626A)]  
PIC16C73B@SSOP28(ISP) [ISP-HEADER01]  
PIC16C74 PIC16C74(ISP) [ISP-  
HEADER01]  
PIC16C74@PLCC44 [(SA244)]  
PIC16C74@PLCC44(ISP) [ISP-HEADER01]  
PIC16C74@TQFP44 [(SA245A)]  
PIC16C74@TQFP44(ISP) [ISP-HEADER01]  
PIC16C745 PIC16C745(ISP) [ISP-  
HEADER01]  
PIC16C745@SOIC28 [(SA404)]  
PIC16C745@SOIC28(ISP) [ISP-HEADER01]  
PIC16C74A PIC16C74A(ISP) [ISP-  
HEADER01]  
PIC16C74A@PLCC44 [(SA244)]  
PIC16C74A@PLCC44(ISP) [ISP-HEADER01]  
PIC16C74A@TQFP44 [(SA245A)]  
PIC16C74A@TQFP44(ISP) [ISP-HEADER01]  
PIC16C74B PIC16C74B(ISP) [ISP-  
HEADER01]  
PIC16C74B@MQFP44 [(SA675)]  
PIC16C74B@MQFP44(ISP) [ISP-HEADER01]  
PIC16C74B@PLCC44 [(SA244)]  
PIC16C74B@PLCC44(ISP) [ISP-HEADER01]  
PIC16C74B@TQFP44 [(SA245A)]  
PIC16C74B@TQFP44(ISP) [ISP-HEADER01]  
PIC16C76 PIC16C76(ISP) [ISP-  
HEADER01]  
PIC16C76@SOIC28 [(SA404)]  
PIC16C76@SOIC28(ISP) [ISP-HEADER01]  
PIC16C765 PIC16C765(ISP) [ISP-  
HEADER01]  
PIC16C765@PLCC44 [(SA244)]  
PIC16C765@PLCC44(ISP) [ISP-HEADER01]  
PIC16C765@TQFP44 [(SA245A)]  
PIC16C765@TQFP44(ISP) [ISP-HEADER01]  
PIC16C77 PIC16C77(ISP) [ISP-  
HEADER01]  
PIC16C77@PLCC44 [(SA244)]  
PIC16C77@PLCC44(ISP) [ISP-HEADER01]  
PIC16C77@TQFP44 [(SA245A)]

PIC16C77@TQFP44(ISP) [ISP-HEADER01]  
PIC16C770 PIC16C770(ISP) [ISP-  
HEADER01]  
PIC16C770@SOIC20 [(SA404)]  
PIC16C770@SOIC20(ISP) [ISP-HEADER01]  
PIC16C770@SSOP20 [(SA626A)]  
PIC16C770@SSOP20(ISP) [ISP-HEADER01]  
PIC16C771 PIC16C771(ISP) [ISP-  
HEADER01]  
PIC16C771@SOIC20 [(SA404)]  
PIC16C771@SOIC20(ISP) [ISP-HEADER01]  
PIC16C771@SSOP20 [(SA626A)]  
PIC16C771@SSOP20(ISP) [ISP-HEADER01]  
PIC16C773 PIC16C773(ISP) [ISP-  
HEADER01]  
PIC16C773@SOIC28 [(SA404)]  
PIC16C773@SOIC28(ISP) [ISP-HEADER01]  
PIC16C773@SSOP28 [(SA626A)]  
PIC16C773@SSOP28(ISP) [ISP-HEADER01]  
PIC16C774 PIC16C774(ISP) [ISP-  
HEADER01]  
PIC16C774@PLCC44 [(SA244)]  
PIC16C774@PLCC44(ISP) [ISP-HEADER01]  
PIC16C774@TQFP44 [(SA675)]  
PIC16C774@TQFP44(ISP) [ISP-HEADER01]  
PIC16C781 PIC16C781(ISP) [ISP-  
HEADER01]  
PIC16C781@SOIC20 [(SA404)]  
PIC16C781@SOIC20(ISP) [ISP-HEADER01]  
PIC16C781@SSOP20 [(SA626A)]  
PIC16C781@SSOP20(ISP) [ISP-HEADER01]  
PIC16C782 PIC16C782(ISP) [ISP-  
HEADER01]  
PIC16C782@SOIC20 [(SA404)]  
PIC16C782@SOIC20(ISP) [ISP-HEADER01]  
PIC16C782@SSOP20 [(SA626A)]  
PIC16C782@SSOP20(ISP) [ISP-HEADER01]  
PIC16C84 PIC16C84(ISP) [ISP-  
HEADER01]  
PIC16C84@SOIC18 [(SA404)]  
PIC16C84@SOIC18(ISP) [ISP-HEADER01]  
PIC16C923@PLCC68(\*) [(SA648-B6807)]  
PIC16C923@PLCC68(ISP) [ISP-HEADER01]

PIC16C923@SDIP64(ISP) [ISP-HEADER01]  
PIC16C923@TQFP64(ISP) [ISP-HEADER01]  
PIC16C924@PLCC68(\*) [(SA648-B6807)]  
PIC16C924@PLCC68(ISP) [ISP-HEADER01]  
PIC16C924@SDIP64(ISP) [ISP-HEADER01]  
PIC16C924@TQFP64(ISP) [ISP-HEADER01]  
PIC16C925@PLCC68(\*) [(SA648-B6807)]  
PIC16C925@PLCC68(ISP) [ISP-HEADER01]  
PIC16C925@TQFP64(ISP) [ISP-HEADER01]  
PIC16C926@PLCC68(\*) [(SA648-B6807)]  
PIC16C926@PLCC68(ISP) [ISP-HEADER01]  
PIC16C926@TQFP64(ISP) [ISP-HEADER01]  
PIC16CE623 PIC16CE623(ISP) [ISP-  
HEADER01]  
PIC16CE623@SOIC18 [(SA404)]  
PIC16CE623@SOIC18(ISP) [ISP-HEADER01]  
PIC16CE624 PIC16CE624(ISP) [ISP-  
HEADER01]  
PIC16CE624@SOIC18 [(SA404)]  
PIC16CE624@SOIC18(ISP) [ISP-HEADER01]  
PIC16CE625 PIC16CE625(ISP) [ISP-  
HEADER01]  
PIC16CE625@SOIC18 [(SA404)]  
PIC16CE625@SOIC18(ISP) [ISP-HEADER01]  
PIC16CE625@SSOP20 [(SA626A)]  
PIC16CE625@SSOP20(ISP) [ISP-HEADER01]  
PIC16CR83 PIC16CR83(ISP) [ISP-  
HEADER01]  
PIC16CR83@SOIC18 [(SA404)]  
PIC16CR83@SOIC18(ISP) [ISP-HEADER01]  
PIC16CR84 PIC16CR84(ISP) [ISP-  
HEADER01]  
PIC16CR84@SOIC18 [(SA404)]  
PIC16CR84@SOIC18(ISP) [ISP-HEADER01]  
PIC16F505 PIC16F505(ISP) [ISP-  
HEADER01]  
PIC16F505@SOIC14 [(SA602)]  
PIC16F505@SOIC14(ISP) [ISP-HEADER01]  
PIC16F505@TSSOP14 [(SA026)]  
PIC16F505@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F506 PIC16F506(ISP) [ISP-  
HEADER01]  
PIC16F506@SOIC14 [(SA602)]

PIC16F506@SOIC14(ISP) [ISP-HEADER01]  
PIC16F506@TSSOP14 [(SA026)]  
PIC16F506@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F54 PIC16F54(ISP) [ISP-  
HEADER01]  
PIC16F54@SOIC18 [(SA404)]  
PIC16F54@SOIC18(ISP) [ISP-HEADER01]  
PIC16F54@SSOP20 [(SA626A)]  
PIC16F54@SSOP20(ISP) [ISP-HEADER01]  
PIC16F57 PIC16F57(ISP) [ISP-  
HEADER01]  
PIC16F57@SOIC28 [(SA404)]  
PIC16F57@SOIC28(ISP) [ISP-HEADER01]  
PIC16F57@SSOP28 [(SA626A)]  
PIC16F57@SSOP28(ISP) [ISP-HEADER01]  
PIC16F59 PIC16F59(ISP) [ISP-  
HEADER01]  
PIC16F59@PLCC44 [(SA244)]  
PIC16F59@PLCC44(ISP) [ISP-HEADER01]  
PIC16F59@TQFP44 [(SA245A)]  
PIC16F59@TQFP44(ISP) [ISP-HEADER01]  
PIC16F610 PIC16F610(ISP) [ISP-  
HEADER01]  
PIC16F610@QFN16 [(SA727)]  
PIC16F610@QFN16(ISP) [ISP-HEADER01]  
PIC16F610@SOIC14 [(SA602)]  
PIC16F610@SOIC14(ISP) [ISP-HEADER01]  
PIC16F610@TSSOP14 [(SA026)]  
PIC16F610@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F616 PIC16F616(ISP) [ISP-  
HEADER01]  
PIC16F616@QFN16 [(SA727)]  
PIC16F616@QFN16(ISP) [ISP-HEADER01]  
PIC16F616@SOIC14 [(SA602)]  
PIC16F616@SOIC14(ISP) [ISP-HEADER01]  
PIC16F616@TSSOP14 [(SA026)]  
PIC16F616@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F627 PIC16F627(ISP) [ISP-  
HEADER01]  
PIC16F627@SOIC18 [(SA404)]  
PIC16F627@SOIC18(ISP) [ISP-HEADER01]  
PIC16F627@SSOP20 [(SA626A)]  
PIC16F627@SSOP20(ISP) [ISP-HEADER01]

PIC16F627A PIC16F627A(ISP) [ISP-  
HEADER01]  
PIC16F627A@SOIC18 [(SA404)]  
PIC16F627A@SOIC18(ISP) [ISP-HEADER01]  
PIC16F627A@SSOP20 [(SA626A)]  
PIC16F627A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F628 PIC16F628(ISP) [ISP-  
HEADER01]  
PIC16F628@SOIC18 [(SA404)]  
PIC16F628@SOIC18(ISP) [ISP-HEADER01]  
PIC16F628@SSOP20 [(SA626A)]  
PIC16F628@SSOP20(ISP) [ISP-HEADER01]  
PIC16F628A PIC16F628A(ISP) [ISP-  
HEADER01]  
PIC16F628A@SOIC18 [(SA404)]  
PIC16F628A@SOIC18(ISP) [ISP-HEADER01]  
PIC16F628A@SSOP20 [(SA626A)]  
PIC16F628A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F630 PIC16F630(ISP) [ISP-  
HEADER01]  
PIC16F630@SOIC14 [(SA602)]  
PIC16F630@SOIC14(ISP) [ISP-HEADER01]  
PIC16F630@TSSOP14 [(SA026)]  
PIC16F630@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F631 PIC16F631(ISP) [ISP-  
HEADER01]  
PIC16F631@QFN20 [(SA692)]  
PIC16F631@QFN20(ISP) [ISP-HEADER01]  
PIC16F631@SOIC20 [(SA404)]  
PIC16F631@SOIC20(ISP) [ISP-HEADER01]  
PIC16F631@SSOP20 [(SA626A)]  
PIC16F631@SSOP20(ISP) [ISP-HEADER01]  
PIC16F636 PIC16F636(ISP) [ISP-  
HEADER01]  
PIC16F636@SOIC14 [(SA602)]  
PIC16F636@SOIC14(ISP) [ISP-HEADER01]  
PIC16F636@TSSOP14 [(SA026)]  
PIC16F636@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F639 PIC16F639(ISP) [ISP-  
HEADER01]  
PIC16F639@QFN20 [(SA692)]  
PIC16F639@QFN20(ISP) [ISP-HEADER01]  
PIC16F639@SOIC20 [(SA404)]

PIC16F639@SOIC20(ISP) [ISP-HEADER01]  
PIC16F639@SSOP20 [(SA626A)]  
PIC16F639@SSOP20(ISP) [ISP-HEADER01]  
PIC16F648A PIC16F648A(ISP) [ISP-  
HEADER01]  
PIC16F648A@SOIC18 [(SA404)]  
PIC16F648A@SOIC18(ISP) [ISP-HEADER01]  
PIC16F648A@SSOP20 [(SA626A)]  
PIC16F648A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F676 PIC16F676(ISP) [ISP-  
HEADER01]  
PIC16F676@SOIC14 [(SA602)]  
PIC16F676@SOIC14(ISP) [ISP-HEADER01]  
PIC16F676@TSSOP14 [(SA026)]  
PIC16F676@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F677 PIC16F677(ISP) [ISP-  
HEADER01]  
PIC16F677@QFN20 [(SA692)]  
PIC16F677@QFN20(ISP) [ISP-HEADER01]  
PIC16F677@SOIC20 [(SA404)]  
PIC16F677@SOIC20(ISP) [ISP-HEADER01]  
PIC16F677@SSOP20 [(SA626A)]  
PIC16F677@SSOP20(ISP) [ISP-HEADER01]  
PIC16F684 PIC16F684(ISP) [ISP-  
HEADER01]  
PIC16F684@SOIC14 [(SA602)]  
PIC16F684@SOIC14(ISP) [ISP-HEADER01]  
PIC16F684@TSSOP14 [(SA026)]  
PIC16F684@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F685 PIC16F685(ISP) [ISP-  
HEADER01]  
PIC16F685@QFN20 [(SA692)]  
PIC16F685@QFN20(ISP) [ISP-HEADER01]  
PIC16F685@SOIC20 [(SA404)]  
PIC16F685@SOIC20(ISP) [ISP-HEADER01]  
PIC16F685@SSOP20 [(SA626A)]  
PIC16F685@SSOP20(ISP) [ISP-HEADER01]  
PIC16F687 PIC16F687(ISP) [ISP-  
HEADER01]  
PIC16F687@QFN20 [(SA692)]  
PIC16F687@QFN20(ISP) [ISP-HEADER01]  
PIC16F687@SOIC20 [(SA404)]  
PIC16F687@SOIC20(ISP) [ISP-HEADER01]

PIC16F687@SSOP20 [(SA626A)]  
PIC16F687@SSOP20(ISP) [ISP-HEADER01]  
PIC16F688 PIC16F688(ISP) [ISP-  
HEADER01]  
PIC16F688@SOIC14 [(SA602)]  
PIC16F688@SOIC14(ISP) [ISP-HEADER01]  
PIC16F688@TSSOP14 [(SA026)]  
PIC16F688@TSSOP14(ISP) [ISP-HEADER01]  
PIC16F689 PIC16F689(ISP) [ISP-  
HEADER01]  
PIC16F689@QFN20 [(SA692)]  
PIC16F689@QFN20(ISP) [ISP-HEADER01]  
PIC16F689@SOIC20 [(SA404)]  
PIC16F689@SOIC20(ISP) [ISP-HEADER01]  
PIC16F689@SSOP20 [(SA626A)]  
PIC16F689@SSOP20(ISP) [ISP-HEADER01]  
PIC16F690 PIC16F690(ISP) [ISP-  
HEADER01]  
PIC16F690@QFN20 [(SA692)]  
PIC16F690@QFN20(ISP) [ISP-HEADER01]  
PIC16F690@SOIC20 [(SA404)]  
PIC16F690@SOIC20(ISP) [ISP-HEADER01]  
PIC16F690@SSOP20 [(SA626A)]  
PIC16F690@SSOP20(ISP) [ISP-HEADER01]  
PIC16F716 PIC16F716(ISP) [ISP-  
HEADER01]  
PIC16F716@SOIC18 [(SA404)]  
PIC16F716@SOIC18(ISP) [ISP-HEADER01]  
PIC16F716@SSOP20 [(SA626A)]  
PIC16F716@SSOP20(ISP) [ISP-HEADER01]  
PIC16F72 PIC16F72(ISP) [ISP-  
HEADER01]  
PIC16F72@QFN28 [(SA685-B006)]  
PIC16F72@QFN28(ISP) [ISP-HEADER01]  
PIC16F72@SOIC28 [(SA404)]  
PIC16F72@SOIC28(ISP) [ISP-HEADER01]  
PIC16F72@SSOP28 [(SA626A)]  
PIC16F72@SSOP28(ISP) [ISP-HEADER01]  
PIC16F722 PIC16F722@QFN28 [(SA685-  
B006)]  
PIC16F722@SOIC28 [(SA404)] PIC16F722@SSOP28  
[(SA626A)]  
PIC16F723 PIC16F723@QFN28 [(SA685-

B006) ]  
 PIC16F723@SOIC28 [(SA404)] PIC16F723@SSOP28  
 [(SA626A)]  
 PIC16F724 PIC16F724@QFN44  
 [(SA737)]  
 PIC16F724@TQFP44 [(SA245A)]  
 PIC16F726 PIC16F726@SOIC28  
 PIC16F726@QFN28 [(SA685-B006)]  
 [(SA404)]  
 PIC16F726@SSOP28 [(SA626A)]  
 PIC16F727 PIC16F727@TQFP44  
 PIC16F727@QFN44 [(SA737)]  
 [(SA245A)]  
 PIC16F73 PIC16F73(ISP) [ISP-  
 HEADER01]  
 PIC16F73@SOIC28 [(SA404)]  
 PIC16F73@SOIC28(ISP) [ISP-HEADER01]  
 PIC16F73@SSOP28 [(SA626A)]  
 PIC16F73@SSOP28(ISP) [ISP-HEADER01]  
 PIC16F737 PIC16F737(ISP) [ISP-  
 HEADER01]  
 PIC16F737@SOIC28 [(SA404)]  
 PIC16F737@SOIC28(ISP) [ISP-HEADER01]  
 PIC16F737@SSOP28 [(SA626A)]  
 PIC16F737@SSOP28(ISP) [ISP-HEADER01]  
 PIC16F74 PIC16F74(ISP) [ISP-  
 HEADER01]  
 PIC16F74@PLCC44 [(SA244)]  
 PIC16F74@PLCC44(ISP) [ISP-HEADER01]  
 PIC16F74@TQFP44 [(SA245A)]  
 PIC16F74@TQFP44(ISP) [ISP-HEADER01]  
 PIC16F747 PIC16F747(ISP) [ISP-  
 HEADER01]  
 PIC16F747@TQFP44 [(SA245A)]  
 PIC16F747@TQFP44(ISP) [ISP-HEADER01]  
 PIC16F76 PIC16F76(ISP) [ISP-  
 HEADER01]  
 PIC16F76@SOIC28 [(SA404)]  
 PIC16F76@SOIC28(ISP) [ISP-HEADER01]  
 PIC16F76@SSOP28 [(SA626A)]  
 PIC16F76@SSOP28(ISP) [ISP-HEADER01]  
 PIC16F767 PIC16F767(ISP) [ISP-  
 HEADER01]



PIC16F767@SOIC28 [(SA404)]  
PIC16F767@SOIC28(ISP) [ISP-HEADER01]  
PIC16F767@SSOP28 [(SA626A)]  
PIC16F767@SSOP28(ISP) [ISP-HEADER01]  
PIC16F77 PIC16F77(ISP) [ISP-  
HEADER01]  
PIC16F77@PLCC44 [(SA244)]  
PIC16F77@PLCC44(ISP) [ISP-HEADER01]  
PIC16F77@TQFP44 [(SA245A)]  
PIC16F77@TQFP44(ISP) [ISP-HEADER01]  
PIC16F777 PIC16F777(ISP) [ISP-  
HEADER01]  
PIC16F777@TQFP44 [(SA245A)]  
PIC16F777@TQFP44(ISP) [ISP-HEADER01]  
PIC16F785 PIC16F785(ISP) [ISP-  
HEADER01]  
PIC16F785@QFN20 [(SA692)]  
PIC16F785@QFN20(ISP) [ISP-HEADER01]  
PIC16F785@SOIC20 [(SA404)]  
PIC16F785@SOIC20(ISP) [ISP-HEADER01]  
PIC16F785@SSOP20 [(SA626A)]  
PIC16F785@SSOP20(ISP) [ISP-HEADER01]  
PIC16F818 PIC16F818(ISP) [ISP-  
HEADER01]  
PIC16F818@QFN28 [(SA685-B006)]  
PIC16F818@QFN28(ISP) [ISP-HEADER01]  
PIC16F818@SOIC18 [(SA404)]  
PIC16F818@SOIC18(ISP) [ISP-HEADER01]  
PIC16F818@SSOP20 [(SA626A)]  
PIC16F818@SSOP20(ISP) [ISP-HEADER01]  
PIC16F819 PIC16F819(ISP) [ISP-  
HEADER01]  
PIC16F819@QFN28 [(SA685-B006)]  
PIC16F819@QFN28(ISP) [ISP-HEADER01]  
PIC16F819@SOIC18 [(SA404)]  
PIC16F819@SOIC18(ISP) [ISP-HEADER01]  
PIC16F819@SSOP20 [(SA626A)]  
PIC16F819@SSOP20(ISP) [ISP-HEADER01]  
PIC16F83 PIC16F83(ISP) [ISP-  
HEADER01]  
PIC16F83@SOIC18 [(SA404)]  
PIC16F83@SOIC18(ISP) [ISP-HEADER01]  
PIC16F84 PIC16F84(ISP) [ISP-

HEADER01 ]  
PIC16F84@SOIC18 [(SA404)]  
PIC16F84@SOIC18(ISP) [ISP-HEADER01]  
PIC16F84A PIC16F84A(ISP) [ISP-  
HEADER01]  
PIC16F84A@SOIC18 [(SA404)]  
PIC16F84A@SOIC18(ISP) [ISP-HEADER01]  
PIC16F84A@SSOP20 [(SA626A)]  
PIC16F84A@SSOP20(ISP) [ISP-HEADER01]  
PIC16F87 PIC16F87(ISP) [ISP-  
HEADER01]  
PIC16F87@QFN28 [(SA685-B006)]  
PIC16F87@QFN28(ISP) [ISP-HEADER01]  
PIC16F87@SOIC18 [(SA404)]  
PIC16F87@SOIC18(ISP) [ISP-HEADER01]  
PIC16F87@SSOP20 [(SA626A)]  
PIC16F87@SSOP20(ISP) [ISP-HEADER01]  
PIC16F870 PIC16F870(ISP) [ISP-  
HEADER01]  
PIC16F870@SOIC28 [(SA404)]  
PIC16F870@SOIC28(ISP) [ISP-HEADER01]  
PIC16F870@SSOP28 [(SA626A)]  
PIC16F870@SSOP28(ISP) [ISP-HEADER01]  
PIC16F871 PIC16F871(ISP) [ISP-  
HEADER01]  
PIC16F871@PLCC44 [(SA244)]  
PIC16F871@PLCC44(ISP) [ISP-HEADER01]  
PIC16F871@TQFP44 [(SA245A)]  
PIC16F871@TQFP44(ISP) [ISP-HEADER01]  
PIC16F872 PIC16F872(ISP) [ISP-  
HEADER01]  
PIC16F872@SOIC28 [(SA404)]  
PIC16F872@SOIC28(ISP) [ISP-HEADER01]  
PIC16F872@SSOP28 [(SA626A)]  
PIC16F872@SSOP28(ISP) [ISP-HEADER01]  
PIC16F873 PIC16F873(ISP) [ISP-  
HEADER01]  
PIC16F873@SOIC28 [(SA404)]  
PIC16F873@SOIC28(ISP) [ISP-HEADER01]  
PIC16F873A  
PIC16F873A(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A(ISP3.3v)(HV) [ISP-HEADER01]

PIC16F873A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F873A@QFN28 [(SA697-B006)]  
PIC16F873A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F873A@SOIC28 [(SA404)]  
PIC16F873A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F873A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F873A@SSOP28 [(SA626A)]  
PIC16F873A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F873A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F873A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F873A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F874 PIC16F874(ISP) [ISP-  
HEADER01]  
PIC16F874@PLCC44 [(SA244)]  
PIC16F874@PLCC44(ISP) [ISP-HEADER01]  
PIC16F874@TQFP44 [(SA245A)]  
PIC16F874@TQFP44(ISP) [ISP-HEADER01]  
PIC16F874A  
PIC16F874A(ISP)(High-V) [ISP-HEADER01]  
PIC16F874A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F874A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F874A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F874A@PLCC44 [(SA244)]  
PIC16F874A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16F874A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F874A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F874A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F874A@TQFP44 [(SA245A)]  
PIC16F874A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F874A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F874A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F874A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876 PIC16F876(ISP) [ISP-  
HEADER01]  
PIC16F876@SOIC28 [(SA404)]  
PIC16F876@SOIC28(ISP) [ISP-HEADER01]  
PIC16F876A  
PIC16F876A(ISP)(High-V) [ISP-HEADER01]

PIC16F876A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876A@QFN28 [(SA697-B006)]  
PIC16F876A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876A@SOIC28 [(SA404)]  
PIC16F876A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F876A@SSOP28 [(SA626A)]  
PIC16F876A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877 PIC16F877(ISP) [ISP-  
HEADER01]  
PIC16F877@PLCC44 [(SA244)]  
PIC16F877@PLCC44(ISP) [ISP-HEADER01]  
PIC16F877@TQFP44 [(SA245A)]  
PIC16F877@TQFP44(ISP) [ISP-HEADER01]  
PIC16F877A  
PIC16F877A(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A(ISP)(Low-V) [ISP-HEADER01]  
PIC16F877A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F877A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877A@PLCC44 [(SA244)]  
PIC16F877A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F877A@TQFP44 [(SA245A)]  
PIC16F877A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16F877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16F88 PIC16F88(ISP) [ISP-  
HEADER01]  
PIC16F88@QFN28 [(SA685-B006)]  
PIC16F88@QFN28(ISP) [ISP-HEADER01]

PIC16F88@SOIC18 [(SA404)]  
PIC16F88@SOIC18(ISP) [ISP-HEADER01]  
PIC16F88@SSOP20 [(SA626A)]  
PIC16F88@SSOP20(ISP) [ISP-HEADER01]  
PIC16F882  
PIC16F882(ISP)(High-V) [ISP-HEADER01]  
PIC16F882(ISP)(Low-V) [ISP-HEADER01]  
PIC16F882@QFN28 [(SA697-B005)]  
PIC16F882@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F882@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F882@SOIC28 [(SA404)]  
PIC16F882@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F882@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F882@SSOP28 [(SA626A)]  
PIC16F882@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F882@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883  
PIC16F883(ISP)(High-V) [ISP-HEADER01]  
PIC16F883(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883@QFN28 [(SA697-B005)]  
PIC16F883@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F883@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883@SOIC28 [(SA404)]  
PIC16F883@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F883@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F883@SSOP28 [(SA626A)]  
PIC16F883@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F883@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884  
PIC16F884(ISP)(High-V) [ISP-HEADER01]  
PIC16F884(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884@QFN44 [(SA712)]  
PIC16F884@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC16F884@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884@QFN44(ML) [(SA737)]  
PIC16F884@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]  
PIC16F884@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC16F884@TQFP44 [(SA245A)]  
PIC16F884@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F884@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886  
PIC16F886(ISP)(High-V) [ISP-HEADER01]  
PIC16F886(ISP)(Low-V) [ISP-HEADER01]

PIC16F886@QFN28 [(SA697-B005)]  
PIC16F886@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16F886@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886@SOIC28 [(SA404)]  
PIC16F886@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16F886@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F886@SSOP28 [(SA626A)]  
PIC16F886@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16F886@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887  
PIC16F887(ISP)(High-V) [ISP-HEADER01]  
PIC16F887(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887@QFN44 [(SA712)]  
PIC16F887@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC16F887@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887@QFN44(ML) [(SA737)]  
PIC16F887@QFN44(ML)(ISP)(High-V) [ISP-HEADER01]  
PIC16F887@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC16F887@TQFP44 [(SA245A)]  
PIC16F887@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16F887@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16F913 PIC16F913(ISP) [ISP-  
HEADER01]  
PIC16F913@QFN28 [(SA697-B006)]  
PIC16F913@QFN28(ISP) [ISP-HEADER01]  
PIC16F913@SOIC28 [(SA404)]  
PIC16F913@SOIC28(ISP) [ISP-HEADER01]  
PIC16F913@SSOP28 [(SA626A)]  
PIC16F913@SSOP28(ISP) [ISP-HEADER01]  
PIC16F914 PIC16F914(ISP) [ISP-  
HEADER01]  
PIC16F914@QFN44 [(SA712)]  
PIC16F914@QFN44(ISP) [ISP-HEADER01]  
PIC16F914@QFN44(ML) [(SA737)]  
PIC16F914@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16F914@TQFP44 [(SA245A)]  
PIC16F914@TQFP44(ISP) [ISP-HEADER01]  
PIC16F916 PIC16F916(ISP) [ISP-  
HEADER01]  
PIC16F916@QFN28 [(SA697-B006)]  
PIC16F916@QFN28(ISP) [ISP-HEADER01]  
PIC16F916@SOIC28 [(SA404)]  
PIC16F916@SOIC28(ISP) [ISP-HEADER01]

PIC16F916@SSOP28 [(SA626A)]  
PIC16F916@SSOP28(ISP) [ISP-HEADER01]  
PIC16F917 PIC16F917(ISP) [ISP-  
HEADER01]  
PIC16F917@QFN44 [(SA712)]  
PIC16F917@QFN44(ISP) [ISP-HEADER01]  
PIC16F917@QFN44(ML) [(SA737)]  
PIC16F917@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16F917@TQFP44 [(SA245A)]  
PIC16F917@TQFP44(ISP) [ISP-HEADER01]  
PIC16F946@TQFP64(ISP) [ISP-HEADER01]  
PIC16HV540 PIC16HV540@SOIC18  
[(SA404)]  
PIC16HV540@SSOP20 [(SA626A)]  
PIC16HV610  
PIC16HV610(ISP) [ISP-HEADER01] PIC16HV610@QFN16  
[(SA727)]  
PIC16HV610@QFN16(ISP) [ISP-HEADER01]  
PIC16HV610@SOIC14 [(SA602)]  
PIC16HV610@SOIC14(ISP) [ISP-HEADER01]  
PIC16HV610@TSSOP14 [(SA026)]  
PIC16HV610@TSSOP14(ISP) [ISP-HEADER01]  
PIC16HV616 PIC16HV616(ISP) [ISP-  
HEADER01]  
PIC16HV616@QFN16 [(SA727)]  
PIC16HV616@QFN16(ISP) [ISP-HEADER01]  
PIC16HV616@SOIC14 [(SA602)]  
PIC16HV616@SOIC14(ISP) [ISP-HEADER01]  
PIC16HV616@TSSOP14 [(SA026)]  
PIC16HV616@TSSOP14(ISP) [ISP-HEADER01]  
PIC16HV785 PIC16HV785(ISP) [ISP-  
HEADER01]  
PIC16HV785@QFN20 [(SA692)]  
PIC16HV785@QFN20(ISP) [ISP-HEADER01]  
PIC16HV785@SOIC20 [(SA404)]  
PIC16HV785@SOIC20(ISP) [ISP-HEADER01]  
PIC16HV785@SSOP20 [(SA626A)]  
PIC16HV785@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC505 PIC16LC505@SOIC14  
[(SA602)]  
PIC16LC54A PIC16LC54A@SOIC18  
[(SA404)]  
PIC16LC54A@SSOP20 [(SA626A)]

PIC16LC54C  
PIC16LC54C@SOIC18 [(SA404)] PIC16LC54C@SSOP20  
[(SA626A)]  
PIC16LC554 PIC16LC554(ISP) [ISP-  
HEADER01]  
PIC16LC554@SOIC18 [(SA404)]  
PIC16LC554@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC558 PIC16LC558(ISP) [ISP-  
HEADER01]  
PIC16LC558@SOIC18 [(SA404)]  
PIC16LC558@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC56A PIC16LC56A@SOIC18  
[(SA404)]  
PIC16LC56A@SSOP20 [(SA626A)]  
PIC16LC58A  
PIC16LC58A@SOIC18 [(SA404)] PIC16LC58A@SSOP20  
[(SA626A)]  
PIC16LC58B PIC16LC58B@SOIC18  
[(SA404)]  
PIC16LC58B@SSOP20 [(SA626A)]  
PIC16LC620  
PIC16LC620(ISP) [ISP-HEADER01] PIC16LC620@SOIC18  
[(SA404)]  
PIC16LC620@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC620A PIC16LC620A(ISP) [ISP-  
HEADER01]  
PIC16LC620A@SOIC18 [(SA404)]  
PIC16LC620A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC620A@SSOP20 [(SA626A)]  
PIC16LC620A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC621A PIC16LC621A(ISP) [ISP-  
HEADER01]  
PIC16LC621A@SOIC18 [(SA404)]  
PIC16LC621A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC621A@SSOP20 [(SA626A)]  
PIC16LC621A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC622 PIC16LC622(ISP) [ISP-  
HEADER01]  
PIC16LC622@SOIC18 [(SA404)]  
PIC16LC622@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC62A PIC16LC62A(ISP) [ISP-  
HEADER01]  
PIC16LC62A@SOIC28 [(SA404)]



PIC16LC62A@SOIC28 (ISP) [ISP-HEADER01]  
PIC16LC62A@SSOP28 [(SA626A)]  
PIC16LC62A@SSOP28 (ISP) [ISP-HEADER01]  
PIC16LC62B PIC16LC62B (ISP) [ISP-  
HEADER01]  
PIC16LC62B@SOIC28 [(SA404)]  
PIC16LC62B@SOIC28 (ISP) [ISP-HEADER01]  
PIC16LC62B@SSOP28 [(SA626A)]  
PIC16LC62B@SSOP28 (ISP) [ISP-HEADER01]  
PIC16LC63 PIC16LC63 (ISP) [ISP-  
HEADER01]  
PIC16LC63@SOIC28 [(SA404)]  
PIC16LC63@SOIC28 (ISP) [ISP-HEADER01]  
PIC16LC63A PIC16LC63A (ISP) [ISP-  
HEADER01]  
PIC16LC63A@SOIC28 [(SA404)]  
PIC16LC63A@SOIC28 (ISP) [ISP-HEADER01]  
PIC16LC63A@SSOP28 [(SA626A)]  
PIC16LC63A@SSOP28 (ISP) [ISP-HEADER01]  
PIC16LC64A PIC16LC64A (ISP) [ISP-  
HEADER01]  
PIC16LC64A@PLCC44 [(SA244)]  
PIC16LC64A@PLCC44 (ISP) [ISP-HEADER01]  
PIC16LC64A@TQFP44 [(SA245A)]  
PIC16LC64A@TQFP44 (ISP) [ISP-HEADER01]  
PIC16LC65A PIC16LC65A (ISP) [ISP-  
HEADER01]  
PIC16LC65A@PLCC44 [(SA244)]  
PIC16LC65A@PLCC44 (ISP) [ISP-HEADER01]  
PIC16LC65A@TQFP44 [(SA245A)]  
PIC16LC65A@TQFP44 (ISP) [ISP-HEADER01]  
PIC16LC65B PIC16LC65B (ISP) [ISP-  
HEADER01]  
PIC16LC65B@PLCC44 [(SA244)]  
PIC16LC65B@PLCC44 (ISP) [ISP-HEADER01]  
PIC16LC65B@TQFP44 [(SA245A)]  
PIC16LC65B@TQFP44 (ISP) [ISP-HEADER01]  
PIC16LC66 PIC16LC66 (ISP) [ISP-  
HEADER01]  
PIC16LC66@SOIC28 [(SA404)]  
PIC16LC66@SOIC28 (ISP) [ISP-HEADER01]  
PIC16LC67 PIC16LC67 (ISP) [ISP-  
HEADER01]

PIC16LC67@PLCC44 [(SA244)]  
PIC16LC67@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC67@TQFP44 [(SA245A)]  
PIC16LC67@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC71 PIC16LC71(ISP) [ISP-  
HEADER01]  
PIC16LC71@SOIC18 [(SA404)]  
PIC16LC71@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC710 PIC16LC710(ISP) [ISP-  
HEADER01]  
PIC16LC710@SOIC18 [(SA404)]  
PIC16LC710@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC710@SSOP20 [(SA626A)]  
PIC16LC710@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC711 PIC16LC711(ISP) [ISP-  
HEADER01]  
PIC16LC711@SOIC18 [(SA404)]  
PIC16LC711@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC711@SSOP20 [(SA626A)]  
PIC16LC711@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC712 PIC16LC712(ISP) [ISP-  
HEADER01]  
PIC16LC712@SOIC18 [(SA404)]  
PIC16LC712@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC712@SSOP20 [(SA626A)]  
PIC16LC712@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC715 PIC16LC715@SOIC18  
[(SA404)]  
PIC16LC716 PIC16LC716(ISP) [ISP-  
HEADER01]  
PIC16LC716@SOIC18 [(SA404)]  
PIC16LC716@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC716@SSOP20 [(SA626A)]  
PIC16LC716@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC717 PIC16LC717(ISP) [ISP-  
HEADER01]  
PIC16LC717@SOIC18 [(SA404)]  
PIC16LC717@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC717@SSOP20 [(SA626A)]  
PIC16LC717@SSOP20(ISP) [ISP-HEADER01]  
PIC16LC72 PIC16LC72(ISP) [ISP-  
HEADER01]  
PIC16LC72@SOIC28 [(SA404)]

PIC16LC72@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC72@SSOP28 [(SA626A)]  
PIC16LC72@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC72A PIC16LC72A(ISP) [ISP-  
HEADER01]  
PIC16LC72A@SOIC28 [(SA404)]  
PIC16LC72A@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC72A@SSOP28 [(SA626A)]  
PIC16LC72A@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC73A PIC16LC73A(ISP) [ISP-  
HEADER01]  
PIC16LC73A@SOIC28 [(SA404)]  
PIC16LC73A@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC73B PIC16LC73B(ISP) [ISP-  
HEADER01]  
PIC16LC73B@SOIC28 [(SA404)]  
PIC16LC73B@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC73B@SSOP28 [(SA626A)]  
PIC16LC73B@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC74 PIC16LC74(ISP) [ISP-  
HEADER01]  
PIC16LC74@PLCC44 [(SA244)]  
PIC16LC74@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC74@TQFP44 [(SA245A)]  
PIC16LC74@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC74A PIC16LC74A(ISP) [ISP-  
HEADER01]  
PIC16LC74A@PLCC44 [(SA244)]  
PIC16LC74A@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC74A@TQFP44 [(SA245A)]  
PIC16LC74A@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC74B PIC16LC74B(ISP) [ISP-  
HEADER01]  
PIC16LC74B@MQFP44 [(SA675)]  
PIC16LC74B@MQFP44(ISP) [ISP-HEADER01]  
PIC16LC74B@PLCC44 [(SA244)]  
PIC16LC74B@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC74B@TQFP44 [(SA245A)]  
PIC16LC74B@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC76 PIC16LC76(ISP) [ISP-  
HEADER01]  
PIC16LC76@SOIC28 [(SA404)]  
PIC16LC76@SOIC28(ISP) [ISP-HEADER01]

PIC16LC77 PIC16LC77(ISP) [ISP-  
HEADER01]  
PIC16LC77@PLCC44 [(SA244)]  
PIC16LC77@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC773 PIC16LC773(ISP) [ISP-  
HEADER01]  
PIC16LC773@SOIC28 [(SA404)]  
PIC16LC773@SOIC28(ISP) [ISP-HEADER01]  
PIC16LC773@SSOP28 [(SA626A)]  
PIC16LC773@SSOP28(ISP) [ISP-HEADER01]  
PIC16LC774 PIC16LC774(ISP) [ISP-  
HEADER01]  
PIC16LC774@PLCC44 [(SA244)]  
PIC16LC774@PLCC44(ISP) [ISP-HEADER01]  
PIC16LC774@TQFP44 [(SA675)]  
PIC16LC774@TQFP44(ISP) [ISP-HEADER01]  
PIC16LC84 PIC16LC84(ISP) [ISP-  
HEADER01]  
PIC16LC84@SOIC18 [(SA404)]  
PIC16LC84@SOIC18(ISP) [ISP-HEADER01]  
PIC16LC923@PLCC68(\*) [(SA648-B6807)]  
PIC16LC923@PLCC68(ISP) [ISP-HEADER01]  
PIC16LC923@SDIP64(ISP) [ISP-HEADER01]  
PIC16LC923@TQFP64(ISP) [ISP-HEADER01]  
PIC16LC924@PLCC68(\*) [(SA648-B6807)]  
PIC16LC924@PLCC68(ISP) [ISP-HEADER01]  
PIC16LC924@SDIP64(ISP) [ISP-HEADER01]  
PIC16LC924@TQFP64(ISP) [ISP-HEADER01]  
PIC16LC925@PLCC68(\*) [(SA648-B6807)]  
PIC16LC925@PLCC68(ISP) [ISP-HEADER01]  
PIC16LC925@TQFP64(ISP) [ISP-HEADER01]  
PIC16LC926@PLCC68(\*) [(SA648-B6807)]  
PIC16LC926@PLCC68(ISP) [ISP-HEADER01]  
PIC16LC926@TQFP64(ISP) [ISP-HEADER01]  
PIC16LCE623@SOIC18 [(SA404)]  
PIC16LCE623@SOIC18(ISP) [ISP-HEADER01]  
PIC16LCE623@SSOP20 [(SA626A)]  
PIC16LCE623@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF505 PIC16LF505(ISP) [ISP-  
HEADER01]  
PIC16LF505@SOIC14 [(SA602)]  
PIC16LF505@SOIC14(ISP) [ISP-HEADER01]  
PIC16LF505@TSSOP14 [(SA026)]

PIC16LF505@TSSOP14(ISP) [ISP-HEADER01]  
PIC16LF506 PIC16LF506(ISP) [ISP-  
HEADER01]  
PIC16LF506@SOIC14 [(SA602)]  
PIC16LF506@SOIC14(ISP) [ISP-HEADER01]  
PIC16LF506@TSSOP14 [(SA026)]  
PIC16LF506@TSSOP14(ISP) [ISP-HEADER01]  
PIC16LF54 PIC16LF54(ISP) [ISP-  
HEADER01]  
PIC16LF54@SOIC18 [(SA404)]  
PIC16LF54@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF54@SSOP20 [(SA626A)]  
PIC16LF54@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF57 PIC16LF57(ISP) [ISP-  
HEADER01]  
PIC16LF57@SOIC28 [(SA404)]  
PIC16LF57@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF57@SSOP28 [(SA626A)]  
PIC16LF57@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF59 PIC16LF59(ISP) [ISP-  
HEADER01]  
PIC16LF59@PLCC44 [(SA244)]  
PIC16LF59@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF59@TQFP44 [(SA245A)]  
PIC16LF59@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF627 PIC16LF627(ISP) [ISP-  
HEADER01]  
PIC16LF627@SOIC18 [(SA404)]  
PIC16LF627@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF627@SSOP20 [(SA626A)]  
PIC16LF627@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF627A PIC16LF627A(ISP) [ISP-  
HEADER01]  
PIC16LF627A@SOIC18 [(SA404)]  
PIC16LF627A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF627A@SSOP20 [(SA626A)]  
PIC16LF627A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF628 PIC16LF628(ISP) [ISP-  
HEADER01]  
PIC16LF628@SOIC18 [(SA404)]  
PIC16LF628@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF628@SSOP20 [(SA626A)]  
PIC16LF628@SSOP20(ISP) [ISP-HEADER01]

PIC16LF628A PIC16LF628A(ISP) [ISP-  
HEADER01]  
PIC16LF628A@SOIC18 [(SA404)]  
PIC16LF628A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF628A@SSOP20 [(SA626A)]  
PIC16LF628A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF631 PIC16LF631(ISP) [ISP-  
HEADER01]  
PIC16LF631@QFN20 [(SA692)]  
PIC16LF631@QFN20(ISP) [ISP-HEADER01]  
PIC16LF631@SOIC20 [(SA404)]  
PIC16LF631@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF631@SSOP20 [(SA626A)]  
PIC16LF631@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF639 PIC16LF639(ISP) [ISP-  
HEADER01]  
PIC16LF639@QFN20 [(SA692)]  
PIC16LF639@QFN20(ISP) [ISP-HEADER01]  
PIC16LF639@SOIC20 [(SA404)]  
PIC16LF639@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF639@SSOP20 [(SA626A)]  
PIC16LF639@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF648A PIC16LF648A(ISP) [ISP-  
HEADER01]  
PIC16LF648A@SOIC18 [(SA404)]  
PIC16LF648A@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF648A@SSOP20 [(SA626A)]  
PIC16LF648A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF677 PIC16LF677(ISP) [ISP-  
HEADER01]  
PIC16LF677@QFN20 [(SA692)]  
PIC16LF677@QFN20(ISP) [ISP-HEADER01]  
PIC16LF677@SOIC20 [(SA404)]  
PIC16LF677@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF677@SSOP20 [(SA626A)]  
PIC16LF677@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF685 PIC16LF685(ISP) [ISP-  
HEADER01]  
PIC16LF685@QFN20 [(SA692)]  
PIC16LF685@QFN20(ISP) [ISP-HEADER01]  
PIC16LF685@SOIC20 [(SA404)]  
PIC16LF685@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF685@SSOP20 [(SA626A)]

PIC16LF685@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF687 PIC16LF687(ISP) [ISP-  
HEADER01]  
PIC16LF687@QFN20 [(SA692)]  
PIC16LF687@QFN20(ISP) [ISP-HEADER01]  
PIC16LF687@SOIC20 [(SA404)]  
PIC16LF687@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF687@SSOP20 [(SA626A)]  
PIC16LF687@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF689 PIC16LF689(ISP) [ISP-  
HEADER01]  
PIC16LF689@QFN20 [(SA692)]  
PIC16LF689@QFN20(ISP) [ISP-HEADER01]  
PIC16LF689@SOIC20 [(SA404)]  
PIC16LF689@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF689@SSOP20 [(SA626A)]  
PIC16LF689@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF690 PIC16LF690(ISP) [ISP-  
HEADER01]  
PIC16LF690@QFN20 [(SA692)]  
PIC16LF690@QFN20(ISP) [ISP-HEADER01]  
PIC16LF690@SOIC20 [(SA404)]  
PIC16LF690@SOIC20(ISP) [ISP-HEADER01]  
PIC16LF690@SSOP20 [(SA626A)]  
PIC16LF690@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF716 PIC16LF716(ISP) [ISP-  
HEADER01]  
PIC16LF716@SOIC18 [(SA404)]  
PIC16LF716@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF716@SSOP20 [(SA626A)]  
PIC16LF716@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF72 PIC16LF72(ISP) [ISP-  
HEADER01]  
PIC16LF72@QFN28 [(SA685-B006)]  
PIC16LF72@QFN28(ISP) [ISP-HEADER01]  
PIC16LF72@SOIC28 [(SA404)]  
PIC16LF72@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF72@SSOP28 [(SA626A)]  
PIC16LF72@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF722 PIC16LF722@QFN28 [(SA685-  
B006)]  
PIC16LF722@SOIC28 [(SA404)] PIC16LF722@SSOP28  
[(SA626A)]

PIC16LF723 B006 ]	PIC16LF723@QFN28 [ (SA685-
PIC16LF723@SOIC28 [ (SA404) ]	PIC16LF723@SSOP28
[ (SA626A) ]	
PIC16LF724	PIC16LF724@QFN44
[ (SA737) ]	
PIC16LF724@TQFP44 [ (SA245A) ]	
PIC16LF726	
PIC16LF726@QFN28 [ (SA685-B006) ]	PIC16LF726@SOIC28
[ (SA404) ]	
PIC16LF726@SSOP28 [ (SA626A) ]	
PIC16LF727	
PIC16LF727@QFN44 [ (SA737) ]	PIC16LF727@TQFP44
[ (SA245A) ]	
PIC16LF73	PIC16LF73(ISP) [ ISP-
HEADER01 ]	
PIC16LF73@SOIC28 [ (SA404) ]	
PIC16LF73@SOIC28(ISP) [ ISP-HEADER01 ]	
PIC16LF73@SSOP28 [ (SA626A) ]	
PIC16LF73@SSOP28(ISP) [ ISP-HEADER01 ]	
PIC16LF737	PIC16LF737(ISP) [ ISP-
HEADER01 ]	
PIC16LF737@SOIC28 [ (SA404) ]	
PIC16LF737@SOIC28(ISP) [ ISP-HEADER01 ]	
PIC16LF737@SSOP28 [ (SA626A) ]	
PIC16LF737@SSOP28(ISP) [ ISP-HEADER01 ]	
PIC16LF74	PIC16LF74(ISP) [ ISP-
HEADER01 ]	
PIC16LF74@PLCC44 [ (SA244) ]	
PIC16LF74@PLCC44(ISP) [ ISP-HEADER01 ]	
PIC16LF74@TQFP44 [ (SA245A) ]	
PIC16LF74@TQFP44(ISP) [ ISP-HEADER01 ]	
PIC16LF747	PIC16LF747(ISP) [ ISP-
HEADER01 ]	
PIC16LF747@TQFP44 [ (SA245A) ]	
PIC16LF747@TQFP44(ISP) [ ISP-HEADER01 ]	
PIC16LF76	PIC16LF76(ISP) [ ISP-
HEADER01 ]	
PIC16LF76@SOIC28 [ (SA404) ]	
PIC16LF76@SOIC28(ISP) [ ISP-HEADER01 ]	
PIC16LF76@SSOP28 [ (SA626A) ]	
PIC16LF76@SSOP28(ISP) [ ISP-HEADER01 ]	
PIC16LF767	PIC16LF767(ISP) [ ISP-



HEADER01 ]  
PIC16LF767@SOIC28 [ (SA404) ]  
PIC16LF767@SOIC28(ISP) [ ISP-HEADER01 ]  
PIC16LF767@SSOP28 [ (SA626A) ]  
PIC16LF767@SSOP28(ISP) [ ISP-HEADER01 ]  
PIC16LF77 PIC16LF77(ISP) [ ISP-  
HEADER01 ]  
PIC16LF77@PLCC44 [ (SA244) ]  
PIC16LF77@PLCC44(ISP) [ ISP-HEADER01 ]  
PIC16LF77@TQFP44 [ (SA245A) ]  
PIC16LF77@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16LF777 PIC16LF777(ISP) [ ISP-  
HEADER01 ]  
PIC16LF777@TQFP44 [ (SA245A) ]  
PIC16LF777@TQFP44(ISP) [ ISP-HEADER01 ]  
PIC16LF818 PIC16LF818(ISP) [ ISP-  
HEADER01 ]  
PIC16LF818@QFN28 [ (SA685-B006) ]  
PIC16LF818@QFN28(ISP) [ ISP-HEADER01 ]  
PIC16LF818@SOIC18 [ (SA404) ]  
PIC16LF818@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LF818@SSOP20 [ (SA626A) ]  
PIC16LF818@SSOP20(ISP) [ ISP-HEADER01 ]  
PIC16LF819 PIC16LF819(ISP) [ ISP-  
HEADER01 ]  
PIC16LF819@QFN28 [ (SA685-B006) ]  
PIC16LF819@QFN28(ISP) [ ISP-HEADER01 ]  
PIC16LF819@SOIC18 [ (SA404) ]  
PIC16LF819@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LF819@SSOP20 [ (SA626A) ]  
PIC16LF819@SSOP20(ISP) [ ISP-HEADER01 ]  
PIC16LF83 PIC16LF83(ISP) [ ISP-  
HEADER01 ]  
PIC16LF83@SOIC18 [ (SA404) ]  
PIC16LF83@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LF84 PIC16LF84(ISP) [ ISP-  
HEADER01 ]  
PIC16LF84@SOIC18 [ (SA404) ]  
PIC16LF84@SOIC18(ISP) [ ISP-HEADER01 ]  
PIC16LF84A PIC16LF84A(ISP) [ ISP-  
HEADER01 ]  
PIC16LF84A@SOIC18 [ (SA404) ]  
PIC16LF84A@SOIC18(ISP) [ ISP-HEADER01 ]

PIC16LF84A@SSOP20 [(SA626A)]  
PIC16LF84A@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF87 PIC16LF87(ISP) [ISP-  
HEADER01]  
PIC16LF87@QFN28 [(SA685-B006)]  
PIC16LF87@QFN28(ISP) [ISP-HEADER01]  
PIC16LF87@SOIC18 [(SA404)]  
PIC16LF87@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF87@SSOP20 [(SA626A)]  
PIC16LF87@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF870 PIC16LF870(ISP) [ISP-  
HEADER01]  
PIC16LF870@SOIC28 [(SA404)]  
PIC16LF870@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF870@SSOP28 [(SA626A)]  
PIC16LF870@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF871 PIC16LF871(ISP) [ISP-  
HEADER01]  
PIC16LF871@PLCC44 [(SA244)]  
PIC16LF871@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF871@TQFP44 [(SA245A)]  
PIC16LF871@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF872 PIC16LF872(ISP) [ISP-  
HEADER01]  
PIC16LF872@SOIC28 [(SA404)]  
PIC16LF872@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF872@SSOP28 [(SA626A)]  
PIC16LF872@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF873 PIC16LF873(ISP) [ISP-  
HEADER01]  
PIC16LF873@SOIC28 [(SA404)]  
PIC16LF873@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF873A  
PIC16LF873A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF873A@QFN28 [(SA697-B006)]  
PIC16LF873A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF873A@SOIC28 [(SA404)]

PIC16LF873A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF873A@SSOP28 [(SA626A)]  
PIC16LF873A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF873A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF873A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF873A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF874 PIC16LF874(ISP) [ISP-  
HEADER01]  
PIC16LF874@PLCC44 [(SA244)]  
PIC16LF874@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF874@TQFP44 [(SA245A)]  
PIC16LF874@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF874A  
PIC16LF874A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF874A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF874A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF874A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF874A@PLCC44 [(SA244)]  
PIC16LF874A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF874A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF874A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF874A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF874A@TQFP44 [(SA245A)]  
PIC16LF874A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF874A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF874A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF874A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876 PIC16LF876(ISP) [ISP-  
HEADER01]  
PIC16LF876@SOIC28 [(SA404)]  
PIC16LF876@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF876A  
PIC16LF876A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876A@QFN28 [(SA697-B006)]  
PIC16LF876A@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A@QFN28(ISP3.3v)(HV) [ISP-HEADER01]

PIC16LF876A@QFN28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876A@SOIC28 [(SA404)]  
PIC16LF876A@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A@SOIC28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A@SOIC28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF876A@SSOP28 [(SA626A)]  
PIC16LF876A@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC16LF876A@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF876A@SSOP28(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF876A@SSOP28(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF877 PIC16LF877(ISP) [ISP-  
HEADER01]  
PIC16LF877@PLCC44 [(SA244)]  
PIC16LF877@PLCC44(ISP) [ISP-HEADER01]  
PIC16LF877@TQFP44 [(SA245A)]  
PIC16LF877@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF877A  
PIC16LF877A(ISP)(High-V) [ISP-HEADER01]  
PIC16LF877A(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF877A(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF877A(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF877A@PLCC44 [(SA244)]  
PIC16LF877A@PLCC44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF877A@PLCC44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF877A@PLCC44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF877A@PLCC44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF877A@TQFP44 [(SA245A)]  
PIC16LF877A@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC16LF877A@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC16LF877A@TQFP44(ISP3.3v)(HV) [ISP-HEADER01]  
PIC16LF877A@TQFP44(ISP3.3v)(LV) [ISP-HEADER01]  
PIC16LF88 PIC16LF88(ISP) [ISP-  
HEADER01]  
PIC16LF88@QFN28 [(SA685-B006)]  
PIC16LF88@QFN28(ISP) [ISP-HEADER01]  
PIC16LF88@SOIC18 [(SA404)]  
PIC16LF88@SOIC18(ISP) [ISP-HEADER01]  
PIC16LF88@SSOP20 [(SA626A)]  
PIC16LF88@SSOP20(ISP) [ISP-HEADER01]  
PIC16LF913 PIC16LF913(ISP) [ISP-  
HEADER01]  
PIC16LF913@QFN28 [(SA697-B006)]

PIC16LF913@QFN28(ISP) [ISP-HEADER01]  
PIC16LF913@SOIC28 [(SA404)]  
PIC16LF913@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF913@SSOP28 [(SA626A)]  
PIC16LF913@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF914 PIC16LF914(ISP) [ISP-  
HEADER01]  
PIC16LF914@QFN44 [(SA712)]  
PIC16LF914@QFN44(ISP) [ISP-HEADER01]  
PIC16LF914@QFN44(ML) [(SA737)]  
PIC16LF914@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16LF914@TQFP44 [(SA245A)]  
PIC16LF914@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF916 PIC16LF916(ISP) [ISP-  
HEADER01]  
PIC16LF916@QFN28 [(SA697-B006)]  
PIC16LF916@QFN28(ISP) [ISP-HEADER01]  
PIC16LF916@SOIC28 [(SA404)]  
PIC16LF916@SOIC28(ISP) [ISP-HEADER01]  
PIC16LF916@SSOP28 [(SA626A)]  
PIC16LF916@SSOP28(ISP) [ISP-HEADER01]  
PIC16LF917 PIC16LF917(ISP) [ISP-  
HEADER01]  
PIC16LF917@QFN44 [(SA712)]  
PIC16LF917@QFN44(ISP) [ISP-HEADER01]  
PIC16LF917@QFN44(ML) [(SA737)]  
PIC16LF917@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC16LF917@TQFP44 [(SA245A)]  
PIC16LF917@TQFP44(ISP) [ISP-HEADER01]  
PIC16LF946@TQFP64(ISP) [ISP-HEADER01]  
PIC16LV54A PIC16LV54A@SOIC18  
[(SA404)]  
PIC16LV54A@SSOP20 [(SA626A)]  
PIC16LV58A PIC16LV58A@SSOP20  
[(SA626A)]  
PIC17C42 PIC17C42@PLCC44  
[(SA244)]  
PIC17C42@TQFP44 [(SA245A)]  
PIC17C42A PIC17C42A@TQFP44  
[(SA245A)]  
PIC17C43 PIC17C43@PLCC44

[ (SA244) ]  
 PIC17C43@TQFP44 [ (SA245A) ]  
 PIC17C44  
 PIC17C44@PLCC44 [ (SA244) ] PIC17C44@TQFP44  
 [ (SA245A) ]  
 PIC17LC42 PIC17LC42@PLCC44  
 [ (SA244) ]  
 PIC17LC42@TQFP44 [ (SA245A) ]  
 PIC17LC42A  
 PIC17LC42A@PLCC44 [ (SA244) ] PIC17LC42A@TQFP44  
 [ (SA245A) ]  
 PIC17LC43 PIC17LC43@PLCC44  
 [ (SA244) ]  
 PIC17LC43@TQFP44 [ (SA245A) ]  
 PIC17LC44  
 PIC17LC44@PLCC44 [ (SA244) ] PIC17LC44@TQFP44  
 [ (SA245A) ]  
 PIC18C242 PIC18C242@SOIC28  
 [ (SA404) ]  
 PIC18C252 PIC18C252@SOIC28  
 [ (SA404) ]  
 PIC18C442 PIC18C442@PLCC44  
 [ (SA244) ]  
 PIC18C442@TQFP44 [ (SA245A) ]  
 PIC18C452  
 PIC18C452@PLCC44 [ (SA244) ] PIC18C452@TQFP44  
 [ (SA245A) ]  
 PIC18F1220 PIC18F1220(ISP) [ ISP-  
 HEADER01 ]  
 PIC18F1220@SOIC18 [ (SA404) ]  
 PIC18F1220@SOIC18(ISP) [ ISP-HEADER01 ]  
 PIC18F1220@SSOP20 [ (SA626A) ]  
 PIC18F1220@SSOP20(ISP) [ ISP-HEADER01 ]  
 PIC18F1230 PIC18F1230(ISP) [ ISP-  
 HEADER01 ]  
 PIC18F1230@QFN28 [ (SA685-B006) ]  
 PIC18F1230@QFN28(ISP) [ ISP-HEADER01 ]  
 PIC18F1230@SOIC18 [ (SA404) ]  
 PIC18F1230@SOIC18(ISP) [ ISP-HEADER01 ]  
 PIC18F1230@SSOP20 [ (SA626A) ]  
 PIC18F1230@SSOP20(ISP) [ ISP-HEADER01 ]  
 PIC18F1320 PIC18F1320(ISP) [ ISP-  
 HEADER01 ]

PIC18F1320@SOIC18 [(SA404)]  
PIC18F1320@SOIC18(ISP) [ISP-HEADER01]  
PIC18F1320@SSOP20 [(SA626A)]  
PIC18F1320@SSOP20(ISP) [ISP-HEADER01]  
PIC18F1330 PIC18F1330(ISP) [ISP-  
HEADER01]  
PIC18F1330@QFN28 [(SA685-B006)]  
PIC18F1330@QFN28(ISP) [ISP-HEADER01]  
PIC18F1330@SOIC18 [(SA404)]  
PIC18F1330@SOIC18(ISP) [ISP-HEADER01]  
PIC18F1330@SSOP20 [(SA626A)]  
PIC18F1330@SSOP20(ISP) [ISP-HEADER01]  
PIC18F1330-ICD@QFN28 [(SA685-B006)]  
PIC18F1330-ICD@QFN28(ISP) [ISP-HEADER01]  
PIC18F2220 PIC18F2220(ISP) [ISP-  
HEADER01]  
PIC18F2220@SOIC28 [(SA404)]  
PIC18F2220@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2221  
PIC18F2221(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2221@QFN28 [(SA685-B006)]  
PIC18F2221@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2221@SOIC28 [(SA404)]  
PIC18F2221@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2320 PIC18F2320(ISP) [ISP-  
HEADER01]  
PIC18F2320@SOIC28 [(SA404)]  
PIC18F2320@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2321  
PIC18F2321(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2321@QFN28 [(SA685-B006)]  
PIC18F2321@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2321@SOIC28 [(SA404)]  
PIC18F2321@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2331 PIC18F2331(ISP) [ISP-  
HEADER01]  
PIC18F2331@SOIC28 [(SA404)]  
PIC18F2331@SOIC28(ISP) [ISP-HEADER01]  
PIC18F23K20  
PIC18F23K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F23K20@QFN28 [(SA685-B006)]  
PIC18F23K20@QFN28(ISP)(High-V) [ISP-HEADER01]

PIC18F23K20@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F23K20@SOIC28 [(SA404)]  
PIC18F23K20@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F23K20@SSOP28 [(SA626A)]  
PIC18F23K20@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F23K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2410  
PIC18F2410(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2410@QFN28 [(SA685-B006)]  
PIC18F2410@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2410@SOIC28 [(SA404)]  
PIC18F2410@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F242 PIC18F242(ISP) [ISP-  
HEADER01]  
PIC18F242@SOIC28 [(SA404)]  
PIC18F242@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2420  
PIC18F2420(ISP)(High-V) [ISP-HEADER01]  
PIC18F2420(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2420@SOIC28 [(SA404)]  
PIC18F2420@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2420@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2423  
PIC18F2423(ISP)(High-V) [ISP-HEADER01]  
PIC18F2423(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2423@QFN28 [(SA685-B006)]  
PIC18F2423@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2423@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2423@SOIC28 [(SA404)]  
PIC18F2423@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2423@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2431 PIC18F2431(ISP) [ISP-  
HEADER01]  
PIC18F2431@SOIC28 [(SA404)]  
PIC18F2431@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2439 PIC18F2439(ISP) [ISP-  
HEADER01]  
PIC18F2439@SOIC28 [(SA404)]  
PIC18F2439@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2450  
PIC18F2450(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2450@QFN28 [(SA685-B006)]



PIC18F2450@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2450@SOIC28 [(SA404)]  
PIC18F2450@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2455  
PIC18F2455(ISP)(High-V) [ISP-HEADER01]  
PIC18F2455(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2455@SOIC28 [(SA404)]  
PIC18F2455@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2455@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2458  
PIC18F2458(ISP)(High-V) [ISP-HEADER01]  
PIC18F2458(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2458@SOIC28 [(SA404)]  
PIC18F2458@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2458@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2458@SSOP28 [(SA626A)]  
PIC18F2458@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2458@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F248 PIC18F248(ISP) [ISP-  
HEADER01]  
PIC18F248@SOIC28 [(SA404)]  
PIC18F248@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2480  
PIC18F2480(ISP)(High-V) [ISP-HEADER01]  
PIC18F2480(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2480@QFN28 [(SA685-B006)]  
PIC18F2480@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2480@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2480@SOIC28 [(SA404)]  
PIC18F2480@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2480@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24J10 PIC18F24J10(ISP) [ISP-  
HEADER01]  
PIC18F24J10@QFN28 [(SA685-B006)]  
PIC18F24J10@QFN28(ISP) [ISP-HEADER01]  
PIC18F24J10@SOIC28 [(SA404)]  
PIC18F24J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18F24J10@SSOP28 [(SA626A)]  
PIC18F24J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18F24K20  
PIC18F24K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24K20@QFN28 [(SA685-B006)]

PIC18F24K20@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24K20@SOIC28 [(SA404)]  
PIC18F24K20@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F24K20@SSOP28 [(SA626A)]  
PIC18F24K20@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F24K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2510 PIC18F2510(ISP) [ISP-  
HEADER01]  
PIC18F2510@QFN28 [(SA685-B006)]  
PIC18F2510@QFN28(ISP) [ISP-HEADER01]  
PIC18F2510@SOIC28 [(SA404)]  
PIC18F2510@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2515  
PIC18F2515(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2515@SOIC28 [(SA404)]  
PIC18F2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F252 PIC18F252(ISP) [ISP-  
HEADER01]  
PIC18F252@SOIC28 [(SA404)]  
PIC18F252@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2520  
PIC18F2520(ISP)(High-V) [ISP-HEADER01]  
PIC18F2520(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2520@SOIC28 [(SA404)]  
PIC18F2520@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2523  
PIC18F2523(ISP)(High-V) [ISP-HEADER01]  
PIC18F2523(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2523@QFN28 [(SA685-B006)]  
PIC18F2523@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2523@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2523@SOIC28 [(SA404)]  
PIC18F2523@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2523@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2525  
PIC18F2525(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2525@SOIC28 [(SA404)]  
PIC18F2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2539 PIC18F2539(ISP) [ISP-  
HEADER01]

PIC18F2539@SOIC28 [(SA404)]  
PIC18F2539@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2550  
PIC18F2550(ISP)(High-V) [ISP-HEADER01]  
PIC18F2550(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2550@SOIC28 [(SA404)]  
PIC18F2550@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2553  
PIC18F2553(ISP)(High-V) [ISP-HEADER01]  
PIC18F2553(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2553@SOIC28 [(SA404)]  
PIC18F2553@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2553@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2553@SSOP28 [(SA626A)]  
PIC18F2553@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2553@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F258 PIC18F258(ISP) [ISP-  
HEADER01]  
PIC18F258@SOIC28 [(SA404)]  
PIC18F258@SOIC28(ISP) [ISP-HEADER01]  
PIC18F2580  
PIC18F2580(ISP)(High-V) [ISP-HEADER01]  
PIC18F2580(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2580@QFN28 [(SA685-B006)]  
PIC18F2580@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2580@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2580@SOIC28 [(SA404)]  
PIC18F2580@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2585  
PIC18F2585(ISP)(High-V) [ISP-HEADER01]  
PIC18F2585(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2585@SDIP28 [(SA022A)]  
PIC18F2585@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2585@SOIC28 [(SA404)]  
PIC18F2585@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25J10 PIC18F25J10(ISP) [ISP-  
HEADER01]  
PIC18F25J10@QFN28 [(SA685-B006)]  
PIC18F25J10@QFN28(ISP) [ISP-HEADER01]

PIC18F25J10@SOIC28 [(SA404)]  
PIC18F25J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18F25J10@SSOP28 [(SA626A)]  
PIC18F25J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18F25K20  
PIC18F25K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25K20@QFN28 [(SA685-B006)]  
PIC18F25K20@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25K20@SOIC28 [(SA404)]  
PIC18F25K20@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F25K20@SSOP28 [(SA626A)]  
PIC18F25K20@SSOP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F25K20@SSOP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2610  
PIC18F2610(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2610@SOIC28 [(SA404)]  
PIC18F2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2620  
PIC18F2620(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2620@SOIC28 [(SA404)]  
PIC18F2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2680  
PIC18F2680(ISP)(High-V) [ISP-HEADER01]  
PIC18F2680(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2680@SDIP28 [(SA022A)]  
PIC18F2680@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2680@SOIC28 [(SA404)]  
PIC18F2680@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2682  
PIC18F2682(ISP)(High-V) [ISP-HEADER01]  
PIC18F2682(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2682@QFN28 [(SA685)]  
PIC18F2682@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2682@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2682@SOIC28 [(SA404)]  
PIC18F2682@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2685

PIC18F2685(ISP)(High-V) [ISP-HEADER01]  
PIC18F2685(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2685@QFN28 [(SA685)]  
PIC18F2685@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2685@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F2685@SOIC28 [(SA404)]  
PIC18F2685@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18F2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4220 PIC18F4220(ISP) [ISP-  
HEADER01]  
PIC18F4220@QFN44 [(SA712)]  
PIC18F4220@QFN44(ISP) [ISP-HEADER01]  
PIC18F4220@QFN44(ML) [(SA737)]  
PIC18F4220@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4220@TQFP44 [(SA245A)]  
PIC18F4220@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4221  
PIC18F4221(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4221@QFN44 [(SA712)]  
PIC18F4221@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4221@QFN44(ML) [(SA737)]  
PIC18F4221@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4221@TQFP44 [(SA245A)]  
PIC18F4221@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4320 PIC18F4320(ISP) [ISP-  
HEADER01]  
PIC18F4320@QFN44 [(SA712)]  
PIC18F4320@QFN44(ISP) [ISP-HEADER01]  
PIC18F4320@QFN44(ML) [(SA737)]  
PIC18F4320@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4320@TQFP44 [(SA245A)]  
PIC18F4320@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4321  
PIC18F4321(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4321@QFN44 [(SA712)]  
PIC18F4321@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4321@QFN44(ML) [(SA737)]  
PIC18F4321@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4321@TQFP44 [(SA245A)]  
PIC18F4321@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4331 PIC18F4331(ISP) [ISP-  
HEADER01]  
PIC18F4331@TQFP44 [(SA245A)]

PIC18F4331@TQFP44(ISP) [ISP-HEADER01]  
PIC18F43K20  
PIC18F43K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F43K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F43K20@QFN44 [(SA712)]  
PIC18F43K20@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F43K20@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F43K20@QFN44(ML) [(SA737)]  
PIC18F43K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F43K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18F43K20@TQFP44 [(SA245A)]  
PIC18F43K20@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F43K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410  
PIC18F4410(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410@QFN44 [(SA712)]  
PIC18F4410@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410@QFN44(ML) [(SA737)]  
PIC18F4410@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4410@TQFP44 [(SA245A)]  
PIC18F4410@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F442 PIC18F442(ISP) [ISP-  
HEADER01]  
PIC18F442@PLCC44 [(SA244)]  
PIC18F442@PLCC44(ISP) [ISP-HEADER01]  
PIC18F442@TQFP44 [(SA245A)]  
PIC18F442@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4420  
PIC18F4420(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4420@QFN44 [(SA712)]  
PIC18F4420@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4420@QFN44(ML) [(SA737)]  
PIC18F4420@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4420@TQFP44 [(SA245A)]  
PIC18F4420@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423  
PIC18F4423(ISP)(High-V) [ISP-HEADER01]  
PIC18F4423(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423@QFN44 [(SA712)]  
PIC18F4423@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4423@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423@QFN44(ML) [(SA737)]  
PIC18F4423@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]

PIC18F4423@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4423@TQFP44 [(SA245A)]  
PIC18F4423@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4423@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4431 PIC18F4431(ISP) [ISP-  
HEADER01]  
PIC18F4431@TQFP44 [(SA245A)]  
PIC18F4431@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4439 PIC18F4439(ISP) [ISP-  
HEADER01]  
PIC18F4439@TQFP44 [(SA245A)]  
PIC18F4439@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4450  
PIC18F4450(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4450@QFN44 [(SA712)]  
PIC18F4450@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4450@QFN44(ML) [(SA737)]  
PIC18F4450@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4450@TQFP44 [(SA245A)]  
PIC18F4450@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455  
PIC18F4455(ISP)(High-V) [ISP-HEADER01]  
PIC18F4455(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455@QFN44 [(SA712)]  
PIC18F4455@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4455@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455@QFN44(ML) [(SA737)]  
PIC18F4455@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4455@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4455@TQFP44 [(SA245A)]  
PIC18F4455@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4455@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4458  
PIC18F4458(ISP)(High-V) [ISP-HEADER01]  
PIC18F4458(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4458@QFN44 [(SA737)]  
PIC18F4458@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4458@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4458@TQFP44 [(SA245A)]  
PIC18F4458@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4458@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F448 PIC18F448(ISP) [ISP-  
HEADER01]

PIC18F448@PLCC44 [(SA244)]  
PIC18F448@PLCC44(ISP) [ISP-HEADER01]  
PIC18F448@TQFP44 [(SA245A)]  
PIC18F448@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4480  
PIC18F4480(ISP)(High-V) [ISP-HEADER01]  
PIC18F4480(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4480@QFN44 [(SA712)]  
PIC18F4480@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4480@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4480@QFN44(ML) [(SA737)]  
PIC18F4480@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4480@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4480@TQFP44 [(SA245A)]  
PIC18F4480@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4480@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F44J10 PIC18F44J10(ISP) [ISP-  
HEADER01]  
PIC18F44J10@QFN44 [(SA712)]  
PIC18F44J10@QFN44(ISP) [ISP-HEADER01]  
PIC18F44J10@QFN44(ML) [(SA709)]  
PIC18F44J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F44J10@TQFP44 [(SA245A)]  
PIC18F44J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18F44K20  
PIC18F44K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F44K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F44K20@QFN44 [(SA712)]  
PIC18F44K20@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F44K20@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F44K20@QFN44(ML) [(SA737)]  
PIC18F44K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F44K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18F44K20@TQFP44 [(SA245A)]  
PIC18F44K20@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F44K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4510 PIC18F4510(ISP) [ISP-  
HEADER01]  
PIC18F4510@QFN44 [(SA712)]  
PIC18F4510@QFN44(ISP) [ISP-HEADER01]  
PIC18F4510@QFN44(ML) [(SA737)]  
PIC18F4510@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4510@TQFP44 [(SA245A)]



PIC18F4510@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4515  
PIC18F4515(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4515@QFN44 [(SA712)]  
PIC18F4515@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4515@QFN44(ML) [(SA737)]  
PIC18F4515@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4515@TQFP44 [(SA245A)]  
PIC18F4515@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F452 PIC18F452(ISP) [ISP-  
HEADER01]  
PIC18F452@PLCC44 [(SA244)]  
PIC18F452@PLCC44(ISP) [ISP-HEADER01]  
PIC18F452@TQFP44 [(SA245A)]  
PIC18F452@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4520 PIC18F4520(ISP) [ISP-  
HEADER01]  
PIC18F4520@QFN44 [(SA712)]  
PIC18F4520@QFN44(ISP) [ISP-HEADER01]  
PIC18F4520@QFN44(ML) [(SA737)]  
PIC18F4520@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F4520@TQFP44 [(SA245A)]  
PIC18F4520@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4523  
PIC18F4523(ISP)(High-V) [ISP-HEADER01]  
PIC18F4523(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4523@QFN44 [(SA712)]  
PIC18F4523@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4523@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4523@QFN44(ML) [(SA737)]  
PIC18F4523@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4523@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4523@TQFP44 [(SA245A)]  
PIC18F4523@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4523@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525  
PIC18F4525(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525@QFN44 [(SA712)]  
PIC18F4525@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525@QFN44(ML) [(SA737)]  
PIC18F4525@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4525@TQFP44 [(SA245A)]  
PIC18F4525@TQFP44(ISP)(Low-V) [ISP-HEADER01]

PIC18F4539 PIC18F4539(ISP) [ISP-  
HEADER01]  
PIC18F4539@TQFP44 [(SA245A)]  
PIC18F4539@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4550  
PIC18F4550(ISP)(High-V) [ISP-HEADER01]  
PIC18F4550(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4550@QFN44 [(SA712)]  
PIC18F4550@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4550@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4550@QFN44(ML) [(SA737)]  
PIC18F4550@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4550@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4550@TQFP44 [(SA245A)]  
PIC18F4550@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4550@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4553  
PIC18F4553(ISP)(High-V) [ISP-HEADER01]  
PIC18F4553(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4553@QFN44 [(SA737)]  
PIC18F4553@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4553@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4553@TQFP44 [(SA245A)]  
PIC18F4553@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4553@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F458 PIC18F458(ISP) [ISP-  
HEADER01]  
PIC18F458@PLCC44 [(SA244)]  
PIC18F458@PLCC44(ISP) [ISP-HEADER01]  
PIC18F458@TQFP44 [(SA245A)]  
PIC18F458@TQFP44(ISP) [ISP-HEADER01]  
PIC18F4580  
PIC18F4580(ISP)(High-V) [ISP-HEADER01]  
PIC18F4580(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4580@QFN44 [(SA712)]  
PIC18F4580@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4580@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4580@QFN44(ML) [(SA737)]  
PIC18F4580@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4580@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4580@TQFP44 [(SA245A)]  
PIC18F4580@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4580@TQFP44(ISP)(Low-V) [ISP-HEADER01]

PIC18F4585  
PIC18F4585(ISP)(High-V) [ISP-HEADER01]  
PIC18F4585(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585@QFN44 [(SA712)]  
PIC18F4585@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4585@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585@QFN44(ML) [(SA737)]  
PIC18F4585@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4585@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4585@TQFP44 [(SA245A)]  
PIC18F4585@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F45J10 PIC18F45J10(ISP) [ISP-  
HEADER01]  
PIC18F45J10@QFN44 [(SA712)]  
PIC18F45J10@QFN44(ISP) [ISP-HEADER01]  
PIC18F45J10@QFN44(ML) [(SA709)]  
PIC18F45J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18F45J10@TQFP44 [(SA245A)]  
PIC18F45J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18F45K20  
PIC18F45K20(ISP)(High-V) [ISP-HEADER01]  
PIC18F45K20(ISP)(Low-V) [ISP-HEADER01]  
PIC18F45K20@QFN44 [(SA712)]  
PIC18F45K20@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F45K20@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F45K20@QFN44(ML) [(SA737)]  
PIC18F45K20@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F45K20@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18F45K20@TQFP44 [(SA245A)]  
PIC18F45K20@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F45K20@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610  
PIC18F4610(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610@QFN44 [(SA712)]  
PIC18F4610@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610@QFN44(ML) [(SA737)]  
PIC18F4610@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4610@TQFP44 [(SA245A)]  
PIC18F4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620  
PIC18F4620(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620@QFN44 [(SA712)]

PIC18F4620@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620@QFN44(ML) [(SA737)]  
PIC18F4620@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4620@TQFP44 [(SA245A)]  
PIC18F4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680  
PIC18F4680(ISP)(High-V) [ISP-HEADER01]  
PIC18F4680(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680@QFN44 [(SA712)]  
PIC18F4680@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4680@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680@QFN44(ML) [(SA737)]  
PIC18F4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4680@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4680@TQFP44 [(SA245A)]  
PIC18F4680@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682  
PIC18F4682(ISP)(High-V) [ISP-HEADER01]  
PIC18F4682(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682@QFN44 [(SA712)]  
PIC18F4682@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4682@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682@QFN44(ML) [(SA737)]  
PIC18F4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4682@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4682@TQFP44 [(SA245A)]  
PIC18F4682@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685  
PIC18F4685(ISP)(High-V) [ISP-HEADER01]  
PIC18F4685(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685@QFN44 [(SA712)]  
PIC18F4685@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4685@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685@QFN44(ML) [(SA737)]  
PIC18F4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18F4685@QFN44(ML)(ISP)(Low-V) [ISP-HEADER01]  
PIC18F4685@TQFP44 [(SA245A)]  
PIC18F4685@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18F4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6310@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6390@TQFP64(ISP) [ISP-HEADER01]

PIC18F6393@TQFP64(ISP) [ISP-HEADER01]  
PIC18F63J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F63J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6410@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6490@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6493@TQFP64(ISP) [ISP-HEADER01]  
PIC18F64J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F64J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6520@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6525@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6527@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6527@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6585@PLCC68(ISP) [ISP-HEADER01]  
PIC18F6585@TQFP64(ISP) [ISP-HEADER01]  
PIC18F65J10@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F65J10@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F65J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F65J15@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F65J15@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F65J50@TQFP64(ISP) [ISP-HEADER01]  
PIC18F65J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6620@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6621@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6622@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6622@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6627@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6627@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F6680@PLCC68(ISP) [ISP-HEADER01]  
PIC18F6680@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J10@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F66J10@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F66J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J15@TQFP64(ISP)(Disable) [ISP-HEADER01]  
PIC18F66J15@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F66J16@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J50@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J55@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J60@TQFP64(ISP) [ISP-HEADER01]  
PIC18F66J65@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6720@TQFP64(ISP) [ISP-HEADER01]  
PIC18F6722@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18F6722@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18F67J10@TQFP64(ISP)(Disable) [ISP-HEADER01]

PIC18F67J10@TQFP64(ISP)(Enable) [ISP-HEADER01]  
PIC18F67J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18F67J50@TQFP64(ISP) [ISP-HEADER01]  
PIC18F67J60@TQFP64(ISP) [ISP-HEADER01]  
PIC18F8310@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8390@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8393@TQFP80(ISP) [ISP-HEADER01]  
PIC18F83J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F83J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8410@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8490@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8493@TQFP80(ISP) [ISP-HEADER01]  
PIC18F84J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F84J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8520@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8525@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8527@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8527@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F8585@TQFP80(ISP) [ISP-HEADER01]  
PIC18F85J10@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F85J10@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F85J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F85J15@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F85J15@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F85J50@TQFP80(ISP) [ISP-HEADER01]  
PIC18F85J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8620@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8621@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8622@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F8627@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F8680@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J10@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F86J10@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F86J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J15@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F86J15@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F86J16@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J50@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J55@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J60@TQFP80(ISP) [ISP-HEADER01]  
PIC18F86J65@TQFP80(ISP) [ISP-HEADER01]

PIC18F8720@TQFP80(ISP) [ISP-HEADER01]  
PIC18F8722@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18F8722@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18F87J10@TQFP80(ISP)(Disable) [ISP-HEADER01]  
PIC18F87J10@TQFP80(ISP)(Enable) [ISP-HEADER01]  
PIC18F87J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18F87J50@TQFP80(ISP) [ISP-HEADER01]  
PIC18F87J60@TQFP80(ISP) [ISP-HEADER01]  
PIC18F96J60@TQFP100(ISP) [ISP-HEADER01]  
PIC18F96J65@TQFP100(ISP) [ISP-HEADER01]  
PIC18F97J60@TQFP100(ISP) [ISP-HEADER01]  
PIC18LC452 PIC18LC452@PLCC44  
[(SA244)]  
PIC18LC452@TQFP44 [(SA245A)]  
PIC18LF1220  
PIC18LF1220(ISP) [ISP-HEADER01] PIC18LF1220@SOIC18  
[(SA404)]  
PIC18LF1220@SOIC18(ISP) [ISP-HEADER01]  
PIC18LF1220@SSOP20 [(SA626A)]  
PIC18LF1220@SSOP20(ISP) [ISP-HEADER01]  
PIC18LF1320 PIC18LF1320(ISP) [ISP-  
HEADER01]  
PIC18LF1320@SOIC18 [(SA404)]  
PIC18LF1320@SOIC18(ISP) [ISP-HEADER01]  
PIC18LF1320@SSOP20 [(SA626A)]  
PIC18LF1320@SSOP20(ISP) [ISP-HEADER01]  
PIC18LF2220 PIC18LF2220(ISP) [ISP-  
HEADER01]  
PIC18LF2220@SOIC28 [(SA404)]  
PIC18LF2220@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2221  
PIC18LF2221(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2221@QFN28 [(SA685-B006)]  
PIC18LF2221@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2221@SOIC28 [(SA404)]  
PIC18LF2221@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2320 PIC18LF2320(ISP) [ISP-  
HEADER01]  
PIC18LF2320@SOIC28 [(SA404)]  
PIC18LF2320@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2321  
PIC18LF2321(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2321@QFN28 [(SA685-B006)]

PIC18LF2321@QFN28 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF2321@SOIC28 [(SA404)]  
PIC18LF2321@SOIC28 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF2331 PIC18LF2331 (ISP) [ISP-  
HEADER01]  
PIC18LF2331@SOIC28 [(SA404)]  
PIC18LF2331@SOIC28 (ISP) [ISP-HEADER01]  
PIC18LF2410  
PIC18LF2410 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF2410@QFN28 [(SA685-B006)]  
PIC18LF2410@QFN28 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF2410@SOIC28 [(SA404)]  
PIC18LF2410@SOIC28 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF242 PIC18LF242 (ISP) [ISP-  
HEADER01]  
PIC18LF242@SOIC28 [(SA404)]  
PIC18LF242@SOIC28 (ISP) [ISP-HEADER01]  
PIC18LF2420  
PIC18LF2420 (ISP) (High-V) [ISP-HEADER01]  
PIC18LF2420 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF2420@SOIC28 [(SA404)]  
PIC18LF2420@SOIC28 (ISP) (High-V) [ISP-HEADER01]  
PIC18LF2420@SOIC28 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF2431 PIC18LF2431 (ISP) [ISP-  
HEADER01]  
PIC18LF2431@SOIC28 [(SA404)]  
PIC18LF2431@SOIC28 (ISP) [ISP-HEADER01]  
PIC18LF2439 PIC18LF2439 (ISP) [ISP-  
HEADER01]  
PIC18LF2439@SOIC28 [(SA404)]  
PIC18LF2439@SOIC28 (ISP) [ISP-HEADER01]  
PIC18LF2450  
PIC18LF2450 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF2450@QFN28 [(SA685-B006)]  
PIC18LF2450@QFN28 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF2450@SOIC28 [(SA404)]  
PIC18LF2450@SOIC28 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF2455  
PIC18LF2455 (ISP) (High-V) [ISP-HEADER01]  
PIC18LF2455 (ISP) (Low-V) [ISP-HEADER01]  
PIC18LF2455@SOIC28 [(SA404)]  
PIC18LF2455@SOIC28 (ISP) (High-V) [ISP-HEADER01]  
PIC18LF2455@SOIC28 (ISP) (Low-V) [ISP-HEADER01]



PIC18LF248 PIC18LF248(ISP) [ISP-  
HEADER01]  
PIC18LF248@SOIC28 [(SA404)]  
PIC18LF248@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2480  
PIC18LF2480(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2480(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2480@QFN28 [(SA685-B006)]  
PIC18LF2480@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2480@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2480@SOIC28 [(SA404)]  
PIC18LF2480@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2480@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF24J10 PIC18LF24J10(ISP) [ISP-  
HEADER01]  
PIC18LF24J10@QFN28 [(SA685-B006)]  
PIC18LF24J10@QFN28(ISP) [ISP-HEADER01]  
PIC18LF24J10@SOIC28 [(SA404)]  
PIC18LF24J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF24J10@SSOP28 [(SA626A)]  
PIC18LF24J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18LF2510 PIC18LF2510(ISP) [ISP-  
HEADER01]  
PIC18LF2510@QFN28 [(SA685-B006)]  
PIC18LF2510@QFN28(ISP) [ISP-HEADER01]  
PIC18LF2510@SOIC28 [(SA404)]  
PIC18LF2510@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2515  
PIC18LF2515(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2515@SOIC28 [(SA404)]  
PIC18LF2515@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF252 PIC18LF252(ISP) [ISP-  
HEADER01]  
PIC18LF252@SOIC28 [(SA404)]  
PIC18LF252@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2520  
PIC18LF2520(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2520(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2520@SOIC28 [(SA404)]  
PIC18LF2520@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2520@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2525  
PIC18LF2525(ISP)(Low-V) [ISP-HEADER01]

PIC18LF2525@SOIC28 [(SA404)]  
PIC18LF2525@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2539 PIC18LF2539(ISP) [ISP-  
HEADER01]  
PIC18LF2539@SOIC28 [(SA404)]  
PIC18LF2539@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2550  
PIC18LF2550(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2550(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2550@SOIC28 [(SA404)]  
PIC18LF2550@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2550@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF258 PIC18LF258(ISP) [ISP-  
HEADER01]  
PIC18LF258@SOIC28 [(SA404)]  
PIC18LF258@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF2580  
PIC18LF2580(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2580(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2580@QFN28 [(SA685-B006)]  
PIC18LF2580@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2580@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2580@SOIC28 [(SA404)]  
PIC18LF2580@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2580@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2585  
PIC18LF2585(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2585@SDIP28 [(SA022A)]  
PIC18LF2585@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2585@SOIC28 [(SA404)]  
PIC18LF2585@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2585@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF25J10 PIC18LF25J10(ISP) [ISP-  
HEADER01]  
PIC18LF25J10@QFN28 [(SA685-B006)]  
PIC18LF25J10@QFN28(ISP) [ISP-HEADER01]  
PIC18LF25J10@SOIC28 [(SA404)]  
PIC18LF25J10@SOIC28(ISP) [ISP-HEADER01]  
PIC18LF25J10@SSOP28 [(SA626A)]  
PIC18LF25J10@SSOP28(ISP) [ISP-HEADER01]  
PIC18LF2610

PIC18LF2610(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2610@SOIC28 [(SA404)]  
PIC18LF2610@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2620  
PIC18LF2620(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2620@SOIC28 [(SA404)]  
PIC18LF2620@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2680  
PIC18LF2680(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2680(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2680@SDIP28 [(SA022A)]  
PIC18LF2680@SDIP28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2680@SDIP28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2680@SOIC28 [(SA404)]  
PIC18LF2680@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2680@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2682  
PIC18LF2682(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2682(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2682@QFN28 [(SA685)]  
PIC18LF2682@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2682@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2682@SOIC28 [(SA404)]  
PIC18LF2682@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2682@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2685  
PIC18LF2685(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2685(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2685@QFN28 [(SA685)]  
PIC18LF2685@QFN28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2685@QFN28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF2685@SOIC28 [(SA404)]  
PIC18LF2685@SOIC28(ISP)(High-V) [ISP-HEADER01]  
PIC18LF2685@SOIC28(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4220 PIC18LF4220(ISP) [ISP-  
HEADER01]  
PIC18LF4220@QFN44 [(SA712)]  
PIC18LF4220@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4220@QFN44(ML) [(SA737)]  
PIC18LF4220@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4220@TQFP44 [(SA245A)]  
PIC18LF4220@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4221

PIC18LF4221(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4221@QFN44 [(SA712)]  
PIC18LF4221@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4221@QFN44(ML) [(SA737)]  
PIC18LF4221@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4221@TQFP44 [(SA245A)]  
PIC18LF4221@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4320 PIC18LF4320(ISP) [ISP-  
HEADER01]  
PIC18LF4320@QFN44 [(SA712)]  
PIC18LF4320@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4320@QFN44(ML) [(SA737)]  
PIC18LF4320@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4320@TQFP44 [(SA245A)]  
PIC18LF4320@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4321  
PIC18LF4321(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4321@QFN44 [(SA712)]  
PIC18LF4321@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4321@QFN44(ML) [(SA737)]  
PIC18LF4321@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4321@TQFP44 [(SA245A)]  
PIC18LF4321@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4331 PIC18LF4331(ISP) [ISP-  
HEADER01]  
PIC18LF4331@TQFP44 [(SA245A)]  
PIC18LF4331@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4410  
PIC18LF4410(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4410@QFN44 [(SA712)]  
PIC18LF4410@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4410@QFN44(ML) [(SA737)]  
PIC18LF4410@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4410@TQFP44 [(SA245A)]  
PIC18LF4410@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF442 PIC18LF442(ISP) [ISP-  
HEADER01]  
PIC18LF442@PLCC44 [(SA244)]  
PIC18LF442@PLCC44(ISP) [ISP-HEADER01]  
PIC18LF442@TQFP44 [(SA245A)]  
PIC18LF442@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4420  
PIC18LF4420(ISP)(Low-V) [ISP-HEADER01]

PIC18LF4420@QFN44 [(SA712)]  
PIC18LF4420@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4420@QFN44(ML) [(SA737)]  
PIC18LF4420@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4420@TQFP44 [(SA245A)]  
PIC18LF4420@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4431 PIC18LF4431(ISP) [ISP-  
HEADER01]  
PIC18LF4431@TQFP44 [(SA245A)]  
PIC18LF4431@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4439 PIC18LF4439(ISP) [ISP-  
HEADER01]  
PIC18LF4439@TQFP44 [(SA245A)]  
PIC18LF4439@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4450  
PIC18LF4450(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4450@QFN44 [(SA712)]  
PIC18LF4450@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4450@QFN44(ML) [(SA737)]  
PIC18LF4450@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4450@TQFP44 [(SA245A)]  
PIC18LF4450@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4455  
PIC18LF4455(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4455(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4455@QFN44 [(SA712)]  
PIC18LF4455@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4455@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4455@QFN44(ML) [(SA737)]  
PIC18LF4455@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4455@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4455@TQFP44 [(SA245A)]  
PIC18LF4455@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4455@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF448 PIC18LF448(ISP) [ISP-  
HEADER01]  
PIC18LF448@PLCC44 [(SA244)]  
PIC18LF448@PLCC44(ISP) [ISP-HEADER01]  
PIC18LF448@TQFP44 [(SA245A)]  
PIC18LF448@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4480  
PIC18LF4480(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4480(ISP)(Low-V) [ISP-HEADER01]

PIC18LF4480@QFN44 [(SA712)]  
PIC18LF4480@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4480@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4480@QFN44(ML) [(SA737)]  
PIC18LF4480@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4480@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4480@TQFP44 [(SA245A)]  
PIC18LF4480@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4480@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF44J10 PIC18LF44J10(ISP) [ISP-  
HEADER01]  
PIC18LF44J10@QFN44 [(SA712)]  
PIC18LF44J10@QFN44(ISP) [ISP-HEADER01]  
PIC18LF44J10@QFN44(ML) [(SA709)]  
PIC18LF44J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF44J10@TQFP44 [(SA245A)]  
PIC18LF44J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4510 PIC18LF4510(ISP) [ISP-  
HEADER01]  
PIC18LF4510@QFN44 [(SA712)]  
PIC18LF4510@QFN44(ISP) [ISP-HEADER01]  
PIC18LF4510@QFN44(ML) [(SA737)]  
PIC18LF4510@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4510@TQFP44 [(SA245A)]  
PIC18LF4510@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4515  
PIC18LF4515(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4515@QFN44 [(SA712)]  
PIC18LF4515@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4515@QFN44(ML) [(SA737)]  
PIC18LF4515@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4515@TQFP44 [(SA245A)]  
PIC18LF4515@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF452 PIC18LF452(ISP) [ISP-  
HEADER01]  
PIC18LF452@PLCC44 [(SA244)]  
PIC18LF452@PLCC44(ISP) [ISP-HEADER01]  
PIC18LF452@TQFP44 [(SA245A)]  
PIC18LF452@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4520 PIC18LF4520(ISP) [ISP-  
HEADER01]  
PIC18LF4520@QFN44 [(SA712)]  
PIC18LF4520@QFN44(ISP) [ISP-HEADER01]

PIC18LF4520@QFN44(ML) [(SA737)]  
PIC18LF4520@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF4520@TQFP44 [(SA245A)]  
PIC18LF4520@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4525  
PIC18LF4525(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4525@QFN44 [(SA712)]  
PIC18LF4525@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4525@QFN44(ML) [(SA737)]  
PIC18LF4525@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4525@TQFP44 [(SA245A)]  
PIC18LF4525@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4539 PIC18LF4539(ISP) [ISP-  
HEADER01]  
PIC18LF4539@TQFP44 [(SA245A)]  
PIC18LF4539@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4550  
PIC18LF4550(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4550(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4550@QFN44 [(SA712)]  
PIC18LF4550@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4550@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4550@QFN44(ML) [(SA737)]  
PIC18LF4550@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4550@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4550@TQFP44 [(SA245A)]  
PIC18LF4550@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4550@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF458 PIC18LF458(ISP) [ISP-  
HEADER01]  
PIC18LF458@PLCC44 [(SA244)]  
PIC18LF458@PLCC44(ISP) [ISP-HEADER01]  
PIC18LF458@TQFP44 [(SA245A)]  
PIC18LF458@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4580  
PIC18LF4580(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4580(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4580@QFN44 [(SA712)]  
PIC18LF4580@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4580@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4580@QFN44(ML) [(SA737)]  
PIC18LF4580@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4580@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]

PIC18LF4580@TQFP44 [(SA245A)]  
PIC18LF4580@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4580@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4585  
PIC18LF4585(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4585(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4585@QFN44 [(SA712)]  
PIC18LF4585@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4585@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4585@QFN44(ML) [(SA737)]  
PIC18LF4585@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4585@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4585@TQFP44 [(SA245A)]  
PIC18LF4585@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4585@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF45J10 PIC18LF45J10(ISP) [ISP-  
HEADER01]  
PIC18LF45J10@QFN44 [(SA712)]  
PIC18LF45J10@QFN44(ISP) [ISP-HEADER01]  
PIC18LF45J10@QFN44(ML) [(SA709)]  
PIC18LF45J10@QFN44(ML)(ISP) [ISP-HEADER01]  
PIC18LF45J10@TQFP44 [(SA245A)]  
PIC18LF45J10@TQFP44(ISP) [ISP-HEADER01]  
PIC18LF4610  
PIC18LF4610(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4610@QFN44 [(SA712)]  
PIC18LF4610@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4610@QFN44(ML) [(SA737)]  
PIC18LF4610@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4610@TQFP44 [(SA245A)]  
PIC18LF4610@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4620  
PIC18LF4620(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4620@QFN44 [(SA712)]  
PIC18LF4620@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4620@QFN44(ML) [(SA737)]  
PIC18LF4620@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4620@TQFP44 [(SA245A)]  
PIC18LF4620@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4680  
PIC18LF4680(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4680(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4680@QFN44 [(SA712)]



PIC18LF4680@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4680@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4680@QFN44(ML) [(SA737)]  
PIC18LF4680@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4680@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4680@TQFP44 [(SA245A)]  
PIC18LF4680@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4680@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4682  
PIC18LF4682(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4682(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4682@QFN44 [(SA712)]  
PIC18LF4682@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4682@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4682@QFN44(ML) [(SA737)]  
PIC18LF4682@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4682@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4682@TQFP44 [(SA245A)]  
PIC18LF4682@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4682@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4685  
PIC18LF4685(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4685(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4685@QFN44 [(SA712)]  
PIC18LF4685@QFN44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4685@QFN44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF4685@QFN44(ML) [(SA737)]  
PIC18LF4685@QFN44(ML)(ISP)(H-V) [ISP-HEADER01]  
PIC18LF4685@QFN44(ML)(ISP)(L-V) [ISP-HEADER01]  
PIC18LF4685@TQFP44 [(SA245A)]  
PIC18LF4685@TQFP44(ISP)(High-V) [ISP-HEADER01]  
PIC18LF4685@TQFP44(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6310@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6390@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6393@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF63J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF63J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6410@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6490@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6493@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF64J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF64J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6520@TQFP64(ISP) [ISP-HEADER01]

PIC18LF6525@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6527@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18LF6527@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6585@PLCC68(ISP) [ISP-HEADER01]  
PIC18LF6585@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF65J11@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF65J90@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6620@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6621@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6622@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18LF6622@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6627@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18LF6627@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF6680@PLCC68(ISP) [ISP-HEADER01]  
PIC18LF6680@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6720@TQFP64(ISP) [ISP-HEADER01]  
PIC18LF6722@TQFP64(ISP)(High-V) [ISP-HEADER01]  
PIC18LF6722@TQFP64(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF8310@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8390@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8393@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF83J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF83J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8410@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8490@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8493@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF84J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF84J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8520@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8525@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8527@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8527@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF8585@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF85J11@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF85J90@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8620@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8621@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8622@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8622@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF8627@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8627@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC18LF8680@TQFP80(ISP) [ISP-HEADER01]  
PIC18LF8720@TQFP80(ISP) [ISP-HEADER01]

PIC18LF8722@TQFP80(ISP)(High-V) [ISP-HEADER01]  
PIC18LF8722@TQFP80(ISP)(Low-V) [ISP-HEADER01]  
PIC30F2010 PIC30F2010(ISP) [ISP-  
HEADER01]  
PIC30F2010@SDIP28 [(SA022A)]  
PIC30F2010@SDIP28(ISP) [ISP-HEADER01]  
PIC30F2010@SOIC28 [(SA404)]  
PIC30F2010@SOIC28(ISP) [ISP-HEADER01]  
PIC30F2011(ISP) [ISP-HEADER01]  
PIC30F2011@QFN28(ISP) [ISP-HEADER01]  
PIC30F2011@SDIP18(ISP) [ISP-HEADER01]  
PIC30F2011@SOIC18(ISP) [ISP-HEADER01]  
PIC30F2012(ISP) [ISP-HEADER01]  
PIC30F2012@QFN28(ISP) [ISP-HEADER01]  
PIC30F2012@SDIP28(ISP) [ISP-HEADER01]  
PIC30F2012@SOIC28(ISP) [ISP-HEADER01]  
PIC30F3010(ISP) [ISP-HEADER01]  
PIC30F3010@QFN44(ISP) [ISP-HEADER01]  
PIC30F3010@SDIP28(ISP) [ISP-HEADER01]  
PIC30F3010@SOIC28(ISP) [ISP-HEADER01]  
PIC30F3011(ISP) [ISP-HEADER01]  
PIC30F3011@QFN44(ISP) [ISP-HEADER01]  
PIC30F3011@QFP44(ISP) [ISP-HEADER01]  
PIC30F3012(ISP) [ISP-HEADER01]  
PIC30F3012@QFN44(ISP) [ISP-HEADER01]  
PIC30F3012@SDIP18(ISP) [ISP-HEADER01]  
PIC30F3012@SOIC18(ISP) [ISP-HEADER01]  
PIC30F3013(ISP) [ISP-HEADER01]  
PIC30F3013@QFN44(ISP) [ISP-HEADER01]  
PIC30F3013@SDIP28(ISP) [ISP-HEADER01]  
PIC30F3013@SOIC28(ISP) [ISP-HEADER01]  
PIC30F3014(ISP) [ISP-HEADER01]  
PIC30F3014@QFN44(ISP) [ISP-HEADER01]  
PIC30F3014@QFP44(ISP) [ISP-HEADER01]  
PIC30F4011(ISP) [ISP-HEADER01]  
PIC30F4011@QFN44(ISP) [ISP-HEADER01]  
PIC30F4011@QFP44(ISP) [ISP-HEADER01]  
PIC30F4012(ISP) [ISP-HEADER01]  
PIC30F4012@QFN44(ISP) [ISP-HEADER01]  
PIC30F4012@SDIP28(ISP) [ISP-HEADER01]  
PIC30F4012@SOIC28(ISP) [ISP-HEADER01]  
PIC30F4013(ISP) [ISP-HEADER01]  
PIC30F4013@QFN44(ISP) [ISP-HEADER01]

PIC30F4013@QFP44 (ISP) [ISP-HEADER01]  
 PIC30F5011@QFP64 (ISP) [ISP-HEADER01]  
 PIC30F5013@QFP80 (ISP) [ISP-HEADER01]  
 PIC30F5015@QFP64 (ISP) [ISP-HEADER01]  
 PIC30F5016@QFP80 (ISP) [ISP-HEADER01]  
 PIC30F6010@QFP80 (ISP) [ISP-HEADER01]  
 PIC30F6010A@QFP80 (ISP) [ISP-HEADER01]  
 PIC30F6010A@TQFP80 (ISP) [ISP-HEADER01]  
 PIC30F6011@QFP64 (ISP) [ISP-HEADER01]  
 PIC30F6011A@QFP64 (ISP) [ISP-HEADER01]  
 PIC30F6012@QFP64 (ISP) [ISP-HEADER01]  
 PIC30F6012A@QFP64 (ISP) [ISP-HEADER01]  
 PIC30F6013@QFP80 (ISP) [ISP-HEADER01]  
 PIC30F6013A@QFP80 (ISP) [ISP-HEADER01]  
 PIC30F6014@QFP80 (ISP) [ISP-HEADER01]  
 PIC30F6014A@QFP80 (ISP) [ISP-HEADER01]  
 PIC30F6014A@TQFP80 (ISP) [ISP-HEADER01]  
 PIC30F6015@QFP64 (ISP) [ISP-HEADER01]  
 PS200 PS200 (ISP) [ISP-  
 HEADER01]  
 PS200@SOIC20 [(SA404)] PS200@SOIC20 (ISP) [ISP-  
 HEADER01]  
 PS200@SSOP20 [(SA626A)] PS200@SSOP20 (ISP) [ISP-  
 HEADER01]  
 rfPIC12C509AF@SSOP20 [(SA626A)]  
 rfPIC12C509AF@SSOP20 (ISP) [ISP-HEADER01]  
 rfPIC12C509AG@SOIC18 [(SA404)]  
 rfPIC12C509AG@SOIC18 (ISP) [ISP-HEADER01]  
 rfPIC12LC509AF@SSOP20 [(SA626A)]  
 rfPIC12LC509AF@SSOP20 (ISP) [ISP-HEADER01]  
 rfPIC12LC509AG@SOIC18 [(SA404)]  
 rfPIC12LC509AG@SOIC18 (ISP) [ISP-HEADER01]

## MICRON

### E (E) PROM / FRAM / NVRAM

MT28F002B1VG-B@TSOP40 [(SA409T)] MT28F002B1VG-T@TSOP40  
 [(SA409T)]  
 MT28F002B3VG-B@TSOP40 [(SA409T)] MT28F002B3VG-T@TSOP40  
 [(SA409T)]  
 MT28F002B5VG-B@TSOP40 [(SA409T)] MT28F002B5VG-T@TSOP40

[ (SA409T) ]  
 MT28F002C1VG-T@TSOP40 [ (SA409T) ] MT28F002C5VG-T@TSOP40  
 [ (SA409T) ]  
 MT28F002VG-B@TSOP40 [ (SA409T) ] MT28F002VG-T@TSOP40  
 [ (SA409T) ]  
 MT28F004B1VG-B@TSOP40 [ (SA409T) ] MT28F004B1VG-T@TSOP40  
 [ (SA409T) ]  
 MT28F004B3VG-B@TSOP40 [ (SA409T) ] MT28F004B3VG-T@TSOP40  
 [ (SA409T) ]  
 MT28F004B5VG-B@TSOP40 [ (SA409T) ] MT28F004B5VG-T@TSOP40  
 [ (SA409T) ]  
 MT28F004VG-B@TSOP40 [ (SA409T) ] MT28F004VG-T@TSOP40  
 [ (SA409T) ]  
 MT28F008B1VG-B@TSOP40 [ (SA409T) ] MT28F008B1VG-T@TSOP40  
 [ (SA409T) ]  
 MT28F008B3VG-B@TSOP40 [ (SA409T) ] MT28F008B3VG-T@TSOP40  
 [ (SA409T) ]  
 MT28F008B5VG-B@TSOP40 [ (SA409T) ] MT28F008B5VG-T@TSOP40  
 [ (SA409T) ]  
 MT28F016S3VG@TSOP40 [ (SA409T) ] MT28F016S5VG@TSOP40  
 [ (SA409T) ]  
 MT28F1284W18BQ@VFBGA56 [ (SA656D-B085A-Y056F001Y) ]  
 MT28F1284W18TQ@VFBGA56 [ (SA656D-B085A-Y056F001Y) ]  
 MT28F128J3A(FW203)(I.)@FBGA64 [ (SA655A-B054A-T064F001) ]  
 MT28F128J3A(FW501)(I.)@FBGA64 [ (SA655A-B054A-T064F001) ]  
 MT28F128J3A(FW502)(M.)@FBGA64 [ (SA655A-B054A-T064F001) ]  
 MT28F128J3A(FW503)(M.)@FBGA64 [ (SA655A-B054A-T064F001) ]  
 MT28F128J3A(INTEL)@TSOP56 [ (SA628-B018) ]  
 MT28F128J3A(MICRON)@TSOP56 [ (SA628-B018) ]  
 MT28F200B1SGB@PSOP44 [ (SA638) ] MT28F200B1SGT@PSOP44  
 [ (SA638) ]  
 MT28F200B1WGB@TSOP48 [ (SA247-B005) ]  
 MT28F200B1WGT@TSOP48 [ (SA247-B005) ]  
 MT28F200B3SGB@PSOP44 [ (SA638) ] MT28F200B3SGT@PSOP44  
 [ (SA638) ]  
 MT28F200B3WGB@TSOP48 [ (SA247-B005) ]  
 MT28F200B3WGT@TSOP48 [ (SA247-B005) ]  
 MT28F200B5SGB@PSOP44 [ (SA638) ] MT28F200B5SGT@PSOP44  
 [ (SA638) ]  
 MT28F200B5WGB@TSOP48 [ (SA247-B005) ]  
 MT28F200B5WGT@TSOP48 [ (SA247-B005) ]  
 MT28F320J3A(FW201)(I.)@FBGA64 [ (SA655A-B054A-T064F001) ]  
 MT28F320J3A(FW204)(M.)@FBGA64 [ (SA655A-B054A-T064F001) ]

MT28F320J3A(FW207)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F320J3A(FW208)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F320J3A(INTEL)@TSOP56 [(SA628-B018)]  
MT28F320J3A(MICRON)@TSOP56 [(SA628-B018)]  
MT28F400B1SGB@PSOP44 [(SA638)] MT28F400B1SGT@PSOP44  
[(SA638)]  
MT28F400B1WGB@TSOP48 [(SA247-B005)]  
MT28F400B1WGT@TSOP48 [(SA247-B005)]  
MT28F400B3SGB@PSOP44 [(SA638)] MT28F400B3SGT@PSOP44  
[(SA638)]  
MT28F400B3WGB@TSOP48 [(SA247-B005)]  
MT28F400B3WGT@TSOP48 [(SA247-B005)]  
MT28F400B5SGB@PSOP44 [(SA638)] MT28F400B5SGT@PSOP44  
[(SA638)]  
MT28F400B5WGB@TSOP48 [(SA247-B005)]  
MT28F400B5WGT@TSOP48 [(SA247-B005)]  
MT28F640J3A(FW202)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW205)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW206)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW209)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW505)(I.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(FW506)(M.)@FBGA64 [(SA655A-B054A-T064F001)]  
MT28F640J3A(INTEL)@TSOP56 [(SA628-B018)]  
MT28F640J3A(MICRON)@TSOP56 [(SA628-B018)]  
MT28F800B1SGB@PSOP44 [(SA638)] MT28F800B1SGT@PSOP44  
[(SA638)]  
MT28F800B1WGB@TSOP48 [(SA247-B005)]  
MT28F800B1WGT@TSOP48 [(SA247-B005)]  
MT28F800B3SGB@PSOP44 [(SA638)] MT28F800B3SGT@PSOP44  
[(SA638)]  
MT28F800B3WGB@TSOP48 [(SA247-B005)]  
MT28F800B3WGT@TSOP48 [(SA247-B005)]  
MT28F800B5SGB@PSOP44 [(SA638)] MT28F800B5SGT@PSOP44  
[(SA638)]  
MT28F800B5WGB@TSOP48 [(SA247-B005)]  
MT28F800B5WGT@TSOP48 [(SA247-B005)]  
MT29F1G08ABAWP@TSOP48 [(SA247-B005)]  
MT29F1G16ABAWP@TSOP48 [(SA247-B005)]  
MT29F2G08AAAWG@TSOP48 [(SA247-B005)]  
MT29F2G08AABWP@TSOP48 [(SA247-B005)]  
MT29F2G08AACWP@TSOP48 [(SA247-B005)]  
MT29F4G08AAAWP@TSOP48 [(SA247-B005)]  
MT29F4G08BAB@TSOP48 [(SA247-B005)]

MT29F8G08DAA@TSOP48 [ ( SA247-B005 ) ]

## DRAM & SRAM

MTSRAM@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]

## MICRONAS

### MICROCONTROLLER

SDA555XFL@SDIP52( \* ) [ ( SA627-B5603 ) ]

## MICRON-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

MT29F4G08AAAWP ( sony ) @TSOP48 [ ( SA247+B005 ) ]

## mitsubishi

### E ( E ) PROM / FRAM / NVRAM

M5L27128K

M5L2716

M5L27256K

M5L2732

M5L2732A

M5L27512

M5L27512K

M5L2764K

M5L27C512A

M5M27128P

M5M27256P

M5M27512P

M5M2764P

M5M27C100K

M5M27C100K@PLCC32 [ ( SA015A1T ) ]

M5M27C100K@TSOP32

[ ( SA410T ) ]

M5M27C100P [ (SA015A1T) ]	M5M27C100P@PLCC32
M5M27C100P@TSOP32 [ (SA410T) ]	
M5M27C101JK	
M5M27C101JK@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	M5M27C101JK@TSOP32
M5M27C101K [ (SA015A1T) ]	
M5M27C101K@TSOP32 [ (SA410T) ]	M5M27C101K@PLCC32
M5M27C101P	
M5M27C101P@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	M5M27C101P@TSOP32
M5M27C102K [ (SA244) ]	M5M27C102K@PLCC44
M5M27C102P [ (SA244) ]	M5M27C102P@PLCC44
M5M27C128K	
M5M27C201K	
M5M27C201K@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	M5M27C201K@TSOP32
M5M27C202K [ (SA244) ]	M5M27C202K@PLCC44
M5M27C256 (K) (P)	M5M27C256
M5M27C256A (FP) (K)	M5M27C256A
M5M27C256A (P)	
M5M27C401K	
M5M27C401K@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	M5M27C401K@TSOP32
M5M27C402K (FP)	M5M27C512
M5M27C512A (FP) (K)	M5M27C512A
M5M27C512A (P)	
M5M28F101	
M5M28F101@PLCC32 [ (SA015A1T) ] [ (SA438T) ]	M5M28F101@SOP32
M5M28F101@TSOP32 [ (SA410T) ]	
M5M28F101A	
M5M28F101A@PLCC32 [ (SA015A1T) ] [ (SA438T) ]	M5M28F101A@SOIC32
M5M28F101A@TSOP32 [ (SA410T) ]	



M5M29FB160A@TSOP48 [(SA247-B005)]  
M5M29FB800(FP)@PSOP44 [(SA638)]  
M5M29FB800(VP)@TSOP48 [(SA247-B005)]  
M5M29FT160A@TSOP48 [(SA247-B005)]  
M5M29FT800(FP)@PSOP44 [(SA638)]  
M5M29FT800(VP)@TSOP48 [(SA247-B005)]  
M5M29GB160B(VP)@TSOP48 [(SA247-B005)]  
M5M29GB320(VP)@TSOP48 [(SA247-B005)]  
M5M29GB320(WG)@CBGA48 [(SA642B-B026A-Y072F001)]  
M5M29GT160B(VP)@TSOP48 [(SA247-B005)]  
M5M29GT320(VP)@TSOP48 [(SA247-B005)]  
M5M29GT320(WG)@CBGA48 [(SA642B-B026A-Y072F001)]  
M5M29JB160A@TSOP48 [(SA247-B005)]  
M5M29JT160A@TSOP48 [(SA247-B005)]  
M6M80011A M6M80011A@SOIC10  
[(SA023A)]  
M6M80011A@SOIC16 [(SA023A)]  
M6M80021 M6M80021@SOIC16  
M6M80021@SOIC10 [(SA023A)]  
[(SA023A)]  
M6M80041 M6M80041@SOIC10  
[(SA023A)]  
M6MG3B641S16TP@TSOP52 [(SA657-B036)]  
M6MG3T641S16TP@TSOP52 [(SA657-B036)]  
M6MGB321S4TP@TSOP52 [(SA657-B036)]  
M6MGB321S8TP@TSOP52 [(SA657-B036)]  
M6MGB32BS4WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGB32BS8WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGB331S8KT@TSOP52 [(SA657-B036)]  
M6MGB33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGB641S16TP@TSOP52 [(SA657-B036)]  
M6MGB641S4TP@TSOP52 [(SA657-B036)]  
M6MGB641S8TP@TSOP52 [(SA657-B036)]  
M6MGB64BS4WG@CSP67 [(SA642F-B023A-T064F001)]  
M6MGB64BS8WG@CSP67 [(SA642F-B023A-T064F001)]  
M6MGD137W33(WG)@CSP72 [(SA642F-B056A-T064F001)]  
M6MGE157S4KT@TSOP52 [(SA657-B055)]  
M6MGT321S4TP@TSOP52 [(SA657-B036)]  
M6MGT321S8TP@TSOP52 [(SA657-B036)]  
M6MGT32BS4WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGT32BS8WG@CSP66 [(SA642F-B023A-T064F001)]  
M6MGT331S8KT@TSOP52 [(SA657-B036)]  
M6MGT33BS8AWG@CSP66 [(SA642F-B023A-T064F001)]

M6MGT641S16TP@TSOP52 [(SA657-B036)]  
M6MGT641S4TP@TSOP52 [(SA657-B036)]  
M6MGT641S8TP@TSOP52 [(SA657-B036)]  
M6MGT64BS4WG@CSP67 [(SA642F-B023A-T064F001)]  
M6MGT64BS8WG@CSP67 [(SA642F-B023A-T064F001)]

## MICROCONTROLLER

M30240EFCFP@QFP80(Renesas) [(PCA7302E1F-80)]  
M30280F6HP@QFP80(\*) [(SA731-B230)]  
M30280F8HP@QFP80(\*) [(SA731-B230)]  
M30280FAHP@QFP80(\*) [(SA731-B230)]  
M30280FATHP@QFP80(\*) [(SA731-B230)]  
M30280FAVHP@QFP80(\*) [(SA731-B230)]  
M30280FCHP@QFP80(\*) [(SA731-B230)]  
M30281F6HP@QFP64(\*) [(SA732-B315)]  
M30281F8HP@QFP64(\*) [(SA732-B315)]  
M30281FAHP@QFP64(\*) [(SA732-B315)]  
M30281FATHP@QFP64(\*) [(SA732-B315)]  
M30281FAVHP@QFP64(\*) [(SA732-B315)]  
M30281FCHP@QFP64(\*) [(SA732-B315)]  
M30290FAHP@QFP80(\*) [(SA731-B230)]  
M30290FATHP@QFP80(\*) [(SA731-B230)]  
M30290FAVHP@QFP80(\*) [(SA731-B230)]  
M30290FCHP@QFP80(\*) [(SA731-B230)]  
M30290FCTHP@QFP80(\*) [(SA731-B230)]  
M30290FCVHP@QFP80(\*) [(SA731-B230)]  
M30620EFCFP@QFP100(Renesas) [(PCA7412F-100)]  
M30620ECFS@QFN100(Renesas) [(PCA7412L-100)]  
M30620ECGP@LQFP100(Renesas) [(PCA7412G-100)]  
M30620FCAFP@PQFP100(\*) [(TA012-B006)]  
M30620FCAGP@TQFP100(\*) [(TA013-B006)]  
M30620FCFP@PQFP100(\*) [(TA012-B006)]  
M30620FCPGP@TQFP100(\*) [(TA013-B006)]  
M30621ECGP@QFP80(Renesas) [(PCA7413F-80)]  
M30622ECTFP@QFP100(Renesas) [(PCA7412F-100)]  
M30622F8PFP@PQFP100(\*) [(TA012-B006)]  
M30622F8PGP@TQFP100(\*) [(TA013-B006)]  
M30623ECTGP@QFP80(Renesas) [(PCA7413F-80)]  
M30624FGAFP@PQFP100(\*) [(TA012-B006)]  
M30624FGAGP@TQFP100(\*) [(TA013-B006)]  
M30624FGPFP@PQFP100(\*) [(TA012-B006)]

M30624FGPGP@TQFP100(\*) [(TA013-B006)]  
M30626FHFP@PQFP100(\*) [(TA012-B006)]  
M30626FHFGP@TQFP100(\*) [(TA013-B006)]  
M30627FHFGP@PQFP128(\*) [(SA720-B228)]  
M3062LFGFP@PQFP100(\*) [(TA012-B006)]  
M3062LFGPGP@TQFP100(\*) [(TA013-B006)]  
M306N4FCFP@PQFP100(\*) [(TA012-B006)]  
M306N4FCGP@QFP100(\*) [(TA013-B006)]  
M306N4FCTFP@PQFP100(\*) [(TA012-B006)]  
M306N4FCTGP@QFP100(\*) [(TA013-B006)]  
M306N4FCVFP@PQFP100(\*) [(TA012-B006)]  
M306N4FCVGP@QFP100(\*) [(TA013-B006)]  
M306N4FGFP@PQFP100(\*) [(TA012-B006)]  
M306N4FGGP@QFP100(\*) [(TA013-B006)]  
M306N4FGTFP@PQFP100(\*) [(TA012-B006)]  
M306N4FGTGP@QFP100(\*) [(TA013-B006)]  
M306N4FGVFP@PQFP100(\*) [(TA012-B006)]  
M306N4FGVGP@QFP100(\*) [(TA013-B006)]  
M306N5FCFP@PQFP100(\*) [(TA012-B006)]  
M306N5FCGP@QFP100(\*) [(TA013-B006)]  
M306N5FCTFP@PQFP100(\*) [(TA012-B006)]  
M306N5FCTGP@QFP100(\*) [(TA013-B006)]  
M306N5FCVFP@PQFP100(\*) [(TA012-B006)]  
M306N5FCVGP@QFP100(\*) [(TA013-B006)]  
M306NKFHGP@QFP100(\*) [(TA013-B006)]  
M306NKFHTGP@QFP100(\*) [(TA013-B006)]  
M306NKFHVGP@QFP100(\*) [(TA013-B006)]  
M306NKFJGP@QFP100(\*) [(TA013-B006)]  
M306NKFJTGP@QFP100(\*) [(TA013-B006)]  
M306NKFJVGP@QFP100(\*) [(TA013-B006)]  
M306NLFHGP@QFP100(\*) [(TA013-B006)]  
M306NLFHTGP@QFP100(\*) [(TA013-B006)]  
M306NLFHVGP@QFP100(\*) [(TA013-B006)]  
M306NLFJGP@QFP100(\*) [(TA013-B006)]  
M306NLFJTGP@QFP100(\*) [(TA013-B006)]  
M306NLFJVGP@QFP100(\*) [(TA013-B006)]  
M306NMFHGP@QFP128(\*) [(SA720-B228)]  
M306NMFHTGP@QFP128(\*) [(SA720-B228)]  
M306NMFHVGP@QFP128(\*) [(SA720-B228)]  
M306NMFJGP@QFP128(\*) [(SA720-B228)]  
M306NMFJTGP@QFP128(\*) [(SA720-B228)]  
M306NMFJVGP@QFP128(\*) [(SA720-B228)]  
M306NNFHGP@QFP128(\*) [(SA720-B228)]

M306NNFHVGP@QFP128(\*) [(SA720-B228)]  
M306NNFJGP@QFP128(\*) [(SA720-B228)]  
M306NNFJTGP@QFP128(\*) [(SA720-B228)]  
M306NNFJVGP@QFP128(\*) [(SA720-B228)]  
M306NNTFHGP@QFP128(\*) [(SA720-B228)]  
M306V0EEFP@QFP100(Renesas) [(PCA7412F-100)]  
M306V0EEFS@QFN100(Renesas) [(PCA7412L-100)]  
M306V2EEFP@QFP100(Renesas) [(PCA7412F-100)]  
M306V2EEFS@QFN100(Renesas) [(PCA7412L-100)]  
M34282E2GP [(SA026)] M34283G2GP  
[(SA026)]  
M34283G2GP(ISP) [ISP-HEADER01] M34508G4FP  
[(SA023A)]  
M34508G4GP [(SA026)] M34508G4HFP  
[(SA023A)]  
M34508G4HGP [(SA026)] M34509G4FP [(SA711-  
B005)]  
M34509G4HFP [(SA711-B005)]  
M34513E4FP@LQFP32(Renesas) [(PCA7442FPG02)]  
M34513E4SP@SDIP32(Renesas) [(PCA7442SP)]  
M34513E8FP@LQFP32(Renesas) [(PCA7442FPG02)]  
M34514E8FP@SSOP42(Renesas) [(PCA7441)]  
M34518E8FP@LQFP32(Renesas) [(PCA7442FPG02)]  
M34518E8SP@SDIP32(Renesas) [(PCA7442SP)]  
M34519E8FP@SSOP42(Renesas) [(PCA7441)]  
M34524EDFP@QFP64(Renesas) [(PCA7448)]  
M34551E8FP@QFP48(Renesas) [(PCA7414)]  
M34554EDFP@QFP64(Renesas) [(PCA7448)]  
M34570E8FP@SSOP36(Renesas) [(PCA7425)]  
M34570EDFP@SSOP36(Renesas) [(PCA7425)]  
M34583EDFP@LQFP32(Renesas) [(PCA7442FPG02)]  
M34584EDFP@SSOP42(Renesas) [(PCA7441)]  
M37136@SDIP52(\*) [(SA627-B5602)]  
M37150EFP@SSOP42(Renesas) [(PCA7450FP)]  
M37151EFP@SSOP42(Renesas) [(PCA7450FP)]  
M37160EFP@SSOP42(Renesas) [(PCA7450FP)]  
M37161EFP@SSOP42(Renesas) [(PCA7450FP)]  
M37516E6HKP@QFN44(Renesas) [(PCA7446)]  
M37516E6HP@LQFP48(Renesas) [(PCA7419)]  
M37540E2FP@SSOP36(Renesas) [(PCA7435FPG02)]  
M37540E2GP@LQFP32(Renesas) [(PCA7435GPG03)]  
M37540E2SP@SDIP32(Renesas) [(PCA7435SPG02)]  
M37540E8FP@SSOP36(Renesas) [(PCA7435FPG02)]

M37540E8GP@LQFP32 (Renesas) [(PCA7435GPG03)]  
M37540E8SP@SDIP32 (Renesas) [(PCA7435SPG02)]  
M37544G2A(GP)@LQFP32 [(SA663)]  
M37544G2A(GP)@LQFP32 (ISP) [ISP-HEADER01]  
M37544G2A(SP)@SDIP32 [(SA653)]  
M37544G2A(SP)@SDIP32 (ISP) [ISP-HEADER01]  
M37545G4(GP)@LQFP32 [(SA663)] M37545G6(GP)@LQFP32  
[(SA663)]  
M37545G8(GP)@LQFP32 [(SA663)] M37546G2(FP)@SSOP36  
[(SA645)]  
M37546G2(FP)@SSOP36 (ISP) [ISP-HEADER01]  
M37546G2(GP)@LQFP32 [(SA663)]  
M37546G2(GP)@LQFP32 (ISP) [ISP-HEADER01]  
M37546G2(SP)@SDIP32 [(SA653)]  
M37546G2(SP)@SDIP32 (ISP) [ISP-HEADER01]  
M37546G4(FP)@SSOP36 [(SA645)]  
M37546G4(FP)@SSOP36 (ISP) [ISP-HEADER01]  
M37546G4(GP)@LQFP32 [(SA663)]  
M37546G4(GP)@LQFP32 (ISP) [ISP-HEADER01]  
M37546G4(SP)@SDIP32 [(SA653)]  
M37546G4(SP)@SDIP32 (ISP) [ISP-HEADER01]  
M37547G2(FP)@SSOP36 [(SA645)]  
M37547G2(FP)@SSOP36 (ISP) [ISP-HEADER01]  
M37547G4(FP)@SSOP36 [(SA645)]  
M37547G4(FP)@SSOP36 (ISP) [ISP-HEADER01]  
M37548G1(FP)@TSSOP20 [(SA026)] M37548G2(FP)@TSSOP20  
[(SA026)]  
M37548G3(FP)@TSSOP20 [(SA026)] M37549G1FP@SDIP24  
[(SA653)]  
M37549G2FP@SDIP24 [(SA653)] M37549G3FP@SDIP24  
[(SA653)]  
M37560EFDFP@QFP100 (Renesas) [(PCA4738F-100A)]  
M37560EFFFP@QFN100 (Renesas) [(PCA4738L-100A)]  
M37560EFFFP@QFP100 (Renesas) [(PCA4738F-100A)]  
M37560EFGP@LQFP100 (Renesas) [(PCA4738G-100A)]  
M37630E4FP@QFP44 (Renesas) [(PCA7430)]  
M37630E4FS@QFN80 (Renesas) [(PCA7431)]  
M37640E8FP@QFP80 (Renesas) [(PCA7440FP)]  
M37640E8FS@QFN80 (Renesas) [(PCA7440FS)]  
M37733EHBFP@QFP80 (Renesas) [(PCA4774G05)]  
M37733EHBFS@QFN80 (Renesas) [(PCA4708G05)]  
M37735EHBFP@QFP80 (Renesas) [(PCA4774G05)]  
M37735EHBFS@QFN80 (Renesas) [(PCA4708G05)]

M37736EHBGP@QFP100(Renesas) [(PCA7422GPG02)]  
M37736EHBGS@QFN100(Renesas) [(PCA7422GSG02)]  
M37751E6CFP@QFP80(Renesas) [(PCA4774G05)]  
M37751E6CFS@QFN80(Renesas) [(PCA4708G05)]  
M37751F6CFP@QFP80(Renesas) [(PCA4774G05)]  
M38027E8DFP@QFP64(Mitsubishi) [(PCA4738F-64A)]  
M38027E8DSP@DIP64(Mitsubishi) [(BBBB)]  
M38027E8DXXXFP@QFP64(Mitsubishi) [(PCA4738F-64A)]  
M38027E8DXXXSP@DIP64(Mitsubishi) [(BBBB)]  
M38027E8FS@LCC64(Mitsubishi) [(BBBB)]  
M38027E8SP@DIP64(Mitsubishi) [(BBBB)]  
M38027E8SS@DIP64(Mitsubishi) [(BBBB)]  
M38027E8-XXXFP@QFP64(Mitsubishi) [(PCA4738F-64A)]  
M38027E8-XXXSP@DIP64(Mitsubishi) [(BBBB)]  
M38027M8-XXXFP@QFP64(Mitsubishi) [(PCA4738F-64A)]  
M38039FFFP@QFP64(Renesas) [(PCA4738FF-64)]  
M38039FFHP@LQFP64(Renesas) [(PCA4738HF-64)]  
M38039FFSP@SDIP64(Renesas) [(PCA4738SF-64)]  
M38049FFFP@QFP64(Renesas) [(PCA4738FF-64)]  
M38049FFHP@LQFP64(Renesas) [(PCA4738HF-64)]  
M38049FFSP@SDIP64(Renesas) [(PCA4738SF-64)]  
M38223E4FP@QFP80(Renesas) [(PCA4738F-80A)]  
M38223E4FS@QFN80(Renesas) [(PCA4738L-80A)]  
M38223E4GP@QFP80(Renesas) [(PCA4738G-80A)]  
M38223E4HP@LQFP80(Renesas) [(PCA4738H-80A)]  
M38227ECFP@QFP80(Renesas) [(PCA4738F-80A)]  
M38227ECFS@QFN80(Renesas) [(PCA4738L-80A)]  
M38227EHP@LQFP80(Renesas) [(PCA4738H-80A)]  
M38234G4(FP)@PQFP80 [(SA730+B191)]  
M38234G4(HP)@TQFP80 [(SA731+B192)]  
M38235G6(FP)@PQFP80 [(SA730+B191)]  
M38235G6(HP)@TQFP80 [(SA731+B192)]  
M38238G8(FP)@PQFP80 [(SA730+B191)]  
M38238G8(HP)@TQFP80 [(SA731+B192)]  
M38239GC(FP)@PQFP80 [(SA730+B191)]  
M38239GC(HP)@TQFP80 [(SA731+B192)]  
M3823AGF(FP)@PQFP80 [(SA730+B191)]  
M3823AGF(HP)@TQFP80 [(SA731+B192)]  
M38267E8FP@QFP100(Renesas) [(PCA4738F-100A)]  
M38267E8GP@LQFP100(Renesas) [(PCA4738G-100A)]  
M3826AEFFP@QFP100(Renesas) [(PCA4738F-100A)]  
M3826AEFFS@QFN100(Renesas) [(PCA4738L-100A)]  
M3826AEFGP@LQFP100(Renesas) [(PCA4738G-100A)]

M38503G4A(FP)@SSOP42 [(SA645)] M38503G4A(SP)@SDIP42  
[(SA028)]  
M38504E6FP@SSOP42(Renesas) [(PCA4738F-42A)]  
M38504E6SP@SDIP42(Renesas) [(PCA4738S-42A)]  
M38504E6SS@SDIP42(Renesas) [(PCA4738S-42A)]  
M38507F8(FP)@SSOP42 [(SA645)] M38507F8(SP)@SDIP42  
[(SA028)]  
M38514E6FP@SSOP42(Renesas) [(PCA4738F-42A)]  
M38514E6SP@SDIP42(Renesas) [(PCA4738S-42A)]  
M38514E6SS@SDIP42(Renesas) [(PCA4738S-42A)]  
M38588G6(FP)@SSOP42 [(SA645)] M38588G6(SP)@SDIP42  
[(SA028)]  
M38588G8(FP)@SSOP42 [(SA645)] M38588G8(SP)@SDIP42  
[(SA028)]  
M38588GC(FP)@SSOP42 [(SA645)] M38588GC(SP)@SDIP42  
[(SA028)]  
M38867E8AFS@QFN80(Renesas) [(PCA4738L-80A)]  
M38867E8AHP@LQFP80(Renesas) [(PCA4738H-80A)]  
M38869FFAGP@QFP80(Renesas) [(PCA4738GF-80)]  
M38869FFAHP@LQFP80(Renesas) [(PCA4738HF-80)]  
M38B79FFFP@QFP100(Renesas) [(PCA7438FF-100)]  
M38C13E6FP@LQFP64(Renesas) [(PCA7438F-64A)]  
M38C13E6HP@QFP64(Renesas) [(PCA7438H-64A)]  
M38C89EFFP@LQFP144(Renesas) [(PCA7447FP)]  
M3NN00FETGP@QFP100(\*) [(TA013-B006)]  
R5F21102DFP@TQFP32 [(SA663+B005)]  
R5F21102DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21102FP@TQFP32 [(SA663+B005)]  
R5F21102FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21103DFP@TQFP32 [(SA663+B005)]  
R5F21103DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21103FP@TQFP32 [(SA663+B005)]  
R5F21103FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21104DFP@TQFP32 [(SA663+B005)]  
R5F21104DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21104FP@TQFP32 [(SA663+B005)]  
R5F21104FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21112DFP@TQFP32 [(SA663+B005)]  
R5F21112DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21112FP@TQFP32 [(SA663+B005)]  
R5F21112FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21113DFP@TQFP32 [(SA663+B005)]  
R5F21113DFP@TQFP32(ISP) [ISP-HEADER01]

R5F21113FP@TQFP32 [(SA663+B005)]  
R5F21113FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21114DFP@TQFP32 [(SA663+B005)]  
R5F21114DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21114FP@TQFP32 [(SA663+B005)]  
R5F21114FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21122DFP@TQFP32 [(SA663+B005)]  
R5F21122DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21122FP@TQFP32 [(SA663+B005)]  
R5F21122FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21123DFP@TQFP32 [(SA663+B005)]  
R5F21123DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21123FP@TQFP32 [(SA663+B005)]  
R5F21123FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21124DFP@TQFP32 [(SA663+B005)]  
R5F21124DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21124FP@TQFP32 [(SA663+B005)]  
R5F21124FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21132DFP@TQFP32 [(SA663+B005)]  
R5F21132DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21132FP@TQFP32 [(SA663+B005)]  
R5F21132FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133DFP@TQFP32 [(SA663+B005)]  
R5F21133DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133FP@TQFP32 [(SA663+B005)]  
R5F21133FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21134DFP@TQFP32 [(SA663+B005)]  
R5F21134DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21134FP@TQFP32 [(SA663+B005)]  
R5F21134FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20 [(SA725+B005)]  
R5F21181DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20(single wire) [(SA725+B005)]  
R5F21181DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21181DSP@TSSOP20 [(SA026+B001)]  
R5F21181DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21181DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21181DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21181SP@TSSOP20 [(SA026+B001)]  
R5F21181SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(single wire) [(SA026+B001)]



R5F21181SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182DD@SDIP20 [(SA725+B005)]  
R5F21182DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(single wire) [(SA725+B005)]  
R5F21182DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21182DSP@TSSOP20 [(SA026+B001)]  
R5F21182DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21182DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182NP@QFN28 [(SA697+B006)]  
R5F21182NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(single wire) [(SA697+B006)]  
R5F21182NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(UART mode) [(SA697+B006)]  
R5F21182SP@TSSOP20 [(SA026+B001)]  
R5F21182SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21182SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21182SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183DD@SDIP20 [(SA725+B005)]  
R5F21183DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(single wire) [(SA725+B005)]  
R5F21183DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21183DSP@TSSOP20 [(SA026+B001)]  
R5F21183DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21183DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183NP@QFN28 [(SA697+B006)]  
R5F21183NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(single wire) [(SA697+B006)]  
R5F21183NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(UART mode) [(SA697+B006)]  
R5F21183SP@TSSOP20 [(SA026+B001)]  
R5F21183SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21183SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184DD@SDIP20 [(SA725+B005)]

R5F21184DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(single wire) [(SA725+B005)]  
R5F21184DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21184DSP@TSSOP20 [(SA026+B001)]  
R5F21184DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21184DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184NP@QFN28 [(SA697+B006)]  
R5F21184NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(single wire) [(SA697+B006)]  
R5F21184NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(UART mode) [(SA697+B006)]  
R5F21184SP@TSSOP20 [(SA026+B001)]  
R5F21184SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21184SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191DD@SDIP20 [(SA725+B005)]  
R5F21191DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(single wire) [(SA725+B005)]  
R5F21191DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21191DSP@TSSOP20 [(SA026+B001)]  
R5F21191DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191SP@TSSOP20 [(SA026+B001)]  
R5F21191SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192DD@SDIP20 [(SA725+B005)]  
R5F21192DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(single wire) [(SA725+B005)]  
R5F21192DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21192DSP@TSSOP20 [(SA026+B001)]  
R5F21192DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192DSP@TSSOP20(UART ISP) [ISP-HEADER01]

R5F21192DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192NP@QFN28 [(SA697+B006)]  
R5F21192NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(single wire) [(SA697+B006)]  
R5F21192NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(UART mode) [(SA697+B006)]  
R5F21192SP@TSSOP20 [(SA026+B001)]  
R5F21192SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193DD@SDIP20 [(SA725+B005)]  
R5F21193DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(single wire) [(SA725+B005)]  
R5F21193DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21193DSP@TSSOP20 [(SA026+B001)]  
R5F21193DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193NP@QFN28 [(SA697+B006)]  
R5F21193NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(single wire) [(SA697+B006)]  
R5F21193NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(UART mode) [(SA697+B006)]  
R5F21193SP@TSSOP20 [(SA026+B001)]  
R5F21193SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194DD@SDIP20 [(SA725+B005)]  
R5F21194DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(single wire) [(SA725+B005)]  
R5F21194DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21194DSP@TSSOP20 [(SA026+B001)]  
R5F21194DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194NP@QFN28 [(SA697+B006)]  
R5F21194NP@QFN28(single ISP) [ISP-HEADER01]

R5F21194NP@QFN28(single wire) [(SA697+B006)]  
R5F21194NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(UART mode) [(SA697+B006)]  
R5F21194SP@TSSOP20 [(SA026+B001)]  
R5F21194SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1DD@SDIP20 [(SA725+B005)]  
R5F211A1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(single wire) [(SA725+B005)]  
R5F211A1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A1DSP@TSSOP20 [(SA026+B001)]  
R5F211A1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1SP@TSSOP20 [(SA026+B001)]  
R5F211A1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2DD@SDIP20 [(SA725+B005)]  
R5F211A2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(single wire) [(SA725+B005)]  
R5F211A2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A2DSP@TSSOP20 [(SA026+B001)]  
R5F211A2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2NP@QFN28 [(SA697+B006)]  
R5F211A2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(single wire) [(SA697+B006)]  
R5F211A2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A2SP@TSSOP20 [(SA026+B001)]  
R5F211A2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(UART mode) [(SA026+B001)]

R5F211A3DD@SDIP20 [(SA725+B005)]  
R5F211A3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(single wire) [(SA725+B005)]  
R5F211A3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A3DSP@TSSOP20 [(SA026+B001)]  
R5F211A3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3NP@QFN28 [(SA697+B006)]  
R5F211A3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(single wire) [(SA697+B006)]  
R5F211A3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A3SP@TSSOP20 [(SA026+B001)]  
R5F211A3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4DD@SDIP20 [(SA725+B005)]  
R5F211A4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(single wire) [(SA725+B005)]  
R5F211A4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A4DSP@TSSOP20 [(SA026+B001)]  
R5F211A4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4NP@QFN28 [(SA697+B006)]  
R5F211A4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(single wire) [(SA697+B006)]  
R5F211A4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A4SP@TSSOP20 [(SA026+B001)]  
R5F211A4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1DD@SDIP20 [(SA725+B005)]  
R5F211B1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(single wire) [(SA725+B005)]

R5F211B1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B1DSP@TSSOP20 [(SA026+B001)]  
R5F211B1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1SP@TSSOP20 [(SA026+B001)]  
R5F211B1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2DD@SDIP20 [(SA725+B005)]  
R5F211B2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B2DSP@TSSOP20 [(SA026+B001)]  
R5F211B2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2NP@QFN28 [(SA697+B006)]  
R5F211B2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(single wire) [(SA697+B006)]  
R5F211B2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B2SP@TSSOP20 [(SA026+B001)]  
R5F211B2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3DD@SDIP20 [(SA725+B005)]  
R5F211B3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B3DSP@TSSOP20 [(SA026+B001)]  
R5F211B3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3NP@QFN28 [(SA697+B006)]

R5F211B3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(single wire) [(SA697+B006)]  
R5F211B3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B3SP@TSSOP20 [(SA026+B001)]  
R5F211B3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4DD@SDIP20 [(SA725+B005)]  
R5F211B4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B4DSP@TSSOP20 [(SA026+B001)]  
R5F211B4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4NP@QFN28 [(SA697+B006)]  
R5F211B4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(single wire) [(SA697+B006)]  
R5F211B4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B4SP@TSSOP20 [(SA026+B001)]  
R5F211B4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21244SDFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21244SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21244SDFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21244SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21244SDFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21244SNFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21244SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21244SNFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21244SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21244SNFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21246SDFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21246SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21246SDFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21246SDFP@TQFP52(UART ISP) [ISP-HEADER01]

R5F21246SDFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21246SNFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21246SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21246SNFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21246SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21246SNFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21247SDFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21247SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21247SDFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21247SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21247SDFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21247SNFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21247SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21247SNFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21247SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21247SNFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21248SDFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21248SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21248SDFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21248SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21248SDFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21248SNFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21248SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21248SNFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21248SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21248SNFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21254SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21254SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21254SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21254SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21256SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21256SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21256SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21256SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21257SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32 [(SA663)]



R5F21262DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(single wire) [(SA663)]  
R5F21262DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(UART mode) [(SA663)]  
R5F21262JFP@QFP32 [(SA663)]  
R5F21262JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(single wire) [(SA663)]  
R5F21262JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(UART mode) [(SA663)]  
R5F21262KFP@QFP32 [(SA663)]  
R5F21262KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262KFP@QFP32(single wire) [(SA663)]  
R5F21262KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262KFP@QFP32(UART mode) [(SA663)]  
R5F21262NFP@QFP32 [(SA663)]  
R5F21262NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(single wire) [(SA663)]  
R5F21262NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(UART mode) [(SA663)]  
R5F21262SDFP@QFP32 [(SA663)]  
R5F21262SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(single wire) [(SA663)]  
R5F21262SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(UART mode) [(SA663)]  
R5F21262SJFP@QFP32 [(SA663)]  
R5F21262SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(single wire) [(SA663)]  
R5F21262SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(UART mode) [(SA663)]  
R5F21262SKFP@QFP32 [(SA663)]  
R5F21262SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(single wire) [(SA663)]  
R5F21262SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(UART mode) [(SA663)]  
R5F21262SNFP@QFP32 [(SA663)]  
R5F21262SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(single wire) [(SA663)]  
R5F21262SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(UART mode) [(SA663)]  
R5F21264DFP@QFP32 [(SA663)]  
R5F21264DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264DFP@QFP32(single wire) [(SA663)]  
R5F21264DFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21264DFP@QFP32(UART mode) [(SA663)]  
R5F21264JFP@QFP32 [(SA663)]  
R5F21264JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(single wire) [(SA663)]  
R5F21264JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(UART mode) [(SA663)]  
R5F21264KFP@QFP32 [(SA663)]  
R5F21264KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(single wire) [(SA663)]  
R5F21264KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(UART mode) [(SA663)]  
R5F21264NFP@QFP32 [(SA663)]  
R5F21264NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264NFP@QFP32(single wire) [(SA663)]  
R5F21264NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264NFP@QFP32(UART mode) [(SA663)]  
R5F21264SDFP@QFP32 [(SA663)]  
R5F21264SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SDFP@QFP32(single wire) [(SA663)]  
R5F21264SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SDFP@QFP32(UART mode) [(SA663)]  
R5F21264SJFP@QFP32 [(SA663)]  
R5F21264SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(single wire) [(SA663)]  
R5F21264SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(UART mode) [(SA663)]  
R5F21264SKFP@QFP32 [(SA663)]  
R5F21264SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(single wire) [(SA663)]  
R5F21264SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(UART mode) [(SA663)]  
R5F21264SNFP@QFP32 [(SA663)]  
R5F21264SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(single wire) [(SA663)]  
R5F21264SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(UART mode) [(SA663)]  
R5F21265DFP@QFP32 [(SA663)]  
R5F21265DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(single wire) [(SA663)]  
R5F21265DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(UART mode) [(SA663)]  
R5F21265JFP@QFP32 [(SA663)]  
R5F21265JFP@QFP32(single ISP) [ISP-HEADER01]

R5F21265JFP@QFP32(single wire) [(SA663)]  
R5F21265JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(UART mode) [(SA663)]  
R5F21265KFP@QFP32 [(SA663)]  
R5F21265KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(single wire) [(SA663)]  
R5F21265KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(UART mode) [(SA663)]  
R5F21265NFP@QFP32 [(SA663)]  
R5F21265NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(single wire) [(SA663)]  
R5F21265NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(UART mode) [(SA663)]  
R5F21265SDFP@QFP32 [(SA663)]  
R5F21265SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(single wire) [(SA663)]  
R5F21265SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(UART mode) [(SA663)]  
R5F21265SJFP@QFP32 [(SA663)]  
R5F21265SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(single wire) [(SA663)]  
R5F21265SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(UART mode) [(SA663)]  
R5F21265SKFP@QFP32 [(SA663)]  
R5F21265SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(single wire) [(SA663)]  
R5F21265SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(UART mode) [(SA663)]  
R5F21265SNFP@QFP32 [(SA663)]  
R5F21265SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(single wire) [(SA663)]  
R5F21265SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(UART mode) [(SA663)]  
R5F21266DFP@QFP32 [(SA663)]  
R5F21266DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(single wire) [(SA663)]  
R5F21266DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(UART mode) [(SA663)]  
R5F21266JFP@QFP32 [(SA663)]  
R5F21266JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(single wire) [(SA663)]  
R5F21266JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(UART mode) [(SA663)]

R5F21266KFP@QFP32 [(SA663)]  
R5F21266KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(single wire) [(SA663)]  
R5F21266KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(UART mode) [(SA663)]  
R5F21266NFP@QFP32 [(SA663)]  
R5F21266NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(single wire) [(SA663)]  
R5F21266NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(UART mode) [(SA663)]  
R5F21266SDFP@QFP32 [(SA663)]  
R5F21266SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(single wire) [(SA663)]  
R5F21266SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(UART mode) [(SA663)]  
R5F21266SJFP@QFP32 [(SA663)]  
R5F21266SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(single wire) [(SA663)]  
R5F21266SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(UART mode) [(SA663)]  
R5F21266SKFP@QFP32 [(SA663)]  
R5F21266SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(single wire) [(SA663)]  
R5F21266SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(UART mode) [(SA663)]  
R5F21266SNFP@QFP32 [(SA663)]  
R5F21266SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(single wire) [(SA663)]  
R5F21266SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(UART mode) [(SA663)]  
R5F21272DFP@QFP32 [(SA663)]  
R5F21272DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272DFP@QFP32(single wire) [(SA663)]  
R5F21272DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272DFP@QFP32(UART mode) [(SA663)]  
R5F21272JFP@QFP32 [(SA663)]  
R5F21272JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(single wire) [(SA663)]  
R5F21272JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(UART mode) [(SA663)]  
R5F21272KFP@QFP32 [(SA663)]  
R5F21272KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272KFP@QFP32(single wire) [(SA663)]

R5F21272KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272KFP@QFP32(UART mode) [(SA663)]  
R5F21272NFP@QFP32 [(SA663)]  
R5F21272NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(single wire) [(SA663)]  
R5F21272NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(UART mode) [(SA663)]  
R5F21272SDFP@QFP32 [(SA663)]  
R5F21272SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(single wire) [(SA663)]  
R5F21272SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(UART mode) [(SA663)]  
R5F21272SJFP@QFP32 [(SA663)]  
R5F21272SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(single wire) [(SA663)]  
R5F21272SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(UART mode) [(SA663)]  
R5F21272SKFP@QFP32 [(SA663)]  
R5F21272SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(single wire) [(SA663)]  
R5F21272SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(UART mode) [(SA663)]  
R5F21272SNFP@QFP32 [(SA663)]  
R5F21272SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(single wire) [(SA663)]  
R5F21272SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(UART mode) [(SA663)]  
R5F21274DFP@QFP32 [(SA663)]  
R5F21274DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(single wire) [(SA663)]  
R5F21274DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(UART mode) [(SA663)]  
R5F21274JFP@QFP32 [(SA663)]  
R5F21274JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(single wire) [(SA663)]  
R5F21274JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(UART mode) [(SA663)]  
R5F21274KFP@QFP32 [(SA663)]  
R5F21274KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(single wire) [(SA663)]  
R5F21274KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(UART mode) [(SA663)]  
R5F21274NFP@QFP32 [(SA663)]

R5F21274NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(single wire) [(SA663)]  
R5F21274NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(UART mode) [(SA663)]  
R5F21274SDFP@QFP32 [(SA663)]  
R5F21274SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(single wire) [(SA663)]  
R5F21274SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(UART mode) [(SA663)]  
R5F21274SJFP@QFP32 [(SA663)]  
R5F21274SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SJFP@QFP32(single wire) [(SA663)]  
R5F21274SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SJFP@QFP32(UART mode) [(SA663)]  
R5F21274SKFP@QFP32 [(SA663)]  
R5F21274SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SKFP@QFP32(single wire) [(SA663)]  
R5F21274SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SKFP@QFP32(UART mode) [(SA663)]  
R5F21274SNFP@QFP32 [(SA663)]  
R5F21274SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SNFP@QFP32(single wire) [(SA663)]  
R5F21274SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SNFP@QFP32(UART mode) [(SA663)]  
R5F21275DFP@QFP32 [(SA663)]  
R5F21275DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275DFP@QFP32(single wire) [(SA663)]  
R5F21275DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275DFP@QFP32(UART mode) [(SA663)]  
R5F21275JFP@QFP32 [(SA663)]  
R5F21275JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(single wire) [(SA663)]  
R5F21275JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(UART mode) [(SA663)]  
R5F21275KFP@QFP32 [(SA663)]  
R5F21275KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(single wire) [(SA663)]  
R5F21275KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(UART mode) [(SA663)]  
R5F21275NFP@QFP32 [(SA663)]  
R5F21275NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275NFP@QFP32(single wire) [(SA663)]  
R5F21275NFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21275NFP@QFP32(UART mode) [(SA663)]  
R5F21275SDFP@QFP32 [(SA663)]  
R5F21275SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(single wire) [(SA663)]  
R5F21275SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(UART mode) [(SA663)]  
R5F21275SJFP@QFP32 [(SA663)]  
R5F21275SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(single wire) [(SA663)]  
R5F21275SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(UART mode) [(SA663)]  
R5F21275SKFP@QFP32 [(SA663)]  
R5F21275SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SKFP@QFP32(single wire) [(SA663)]  
R5F21275SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SKFP@QFP32(UART mode) [(SA663)]  
R5F21275SNFP@QFP32 [(SA663)]  
R5F21275SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SNFP@QFP32(single wire) [(SA663)]  
R5F21275SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SNFP@QFP32(UART mode) [(SA663)]  
R5F21276DFP@QFP32 [(SA663)]  
R5F21276DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(single wire) [(SA663)]  
R5F21276DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(UART mode) [(SA663)]  
R5F21276JFP@QFP32 [(SA663)]  
R5F21276JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(single wire) [(SA663)]  
R5F21276JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(UART mode) [(SA663)]  
R5F21276KFP@QFP32 [(SA663)]  
R5F21276KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(single wire) [(SA663)]  
R5F21276KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(UART mode) [(SA663)]  
R5F21276NFP@QFP32 [(SA663)]  
R5F21276NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(single wire) [(SA663)]  
R5F21276NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(UART mode) [(SA663)]  
R5F21276SDFP@QFP32 [(SA663)]  
R5F21276SDFP@QFP32(single ISP) [ISP-HEADER01]

R5F21276SDFP@QFP32(single wire) [(SA663)]  
R5F21276SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SDFP@QFP32(UART mode) [(SA663)]  
R5F21276SJFP@QFP32 [(SA663)]  
R5F21276SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(single wire) [(SA663)]  
R5F21276SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(UART mode) [(SA663)]  
R5F21276SKFP@QFP32 [(SA663)]  
R5F21276SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(single wire) [(SA663)]  
R5F21276SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(UART mode) [(SA663)]  
R5F21276SNFP@QFP32 [(SA663)]  
R5F21276SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(single wire) [(SA663)]  
R5F21276SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(UART mode) [(SA663)]  
R5F21282DSP@SOIC20 [(SA026)]  
R5F21282DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(single wire) [(SA026)]  
R5F21282DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(UART mode) [(SA026)]  
R5F21282JSP@SOIC20 [(SA026)]  
R5F21282JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(single wire) [(SA026)]  
R5F21282JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(UART mode) [(SA026)]  
R5F21282KSP@SOIC20 [(SA026)]  
R5F21282KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(single wire) [(SA026)]  
R5F21282KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(UART mode) [(SA026)]  
R5F21282NSP@SOIC20 [(SA026)]  
R5F21282NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(single wire) [(SA026)]  
R5F21282NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(UART mode) [(SA026)]  
R5F21282SDSP@SOIC20 [(SA026)]  
R5F21282SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(single wire) [(SA026)]  
R5F21282SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(UART mode) [(SA026)]



R5F21282SJSP@SOIC20 [(SA026)]  
R5F21282SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(single wire) [(SA026)]  
R5F21282SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(UART mode) [(SA026)]  
R5F21282SKSP@SOIC20 [(SA026)]  
R5F21282SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(single wire) [(SA026)]  
R5F21282SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(UART mode) [(SA026)]  
R5F21282SNSP@SOIC20 [(SA026)]  
R5F21282SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(single wire) [(SA026)]  
R5F21282SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(UART mode) [(SA026)]  
R5F21284DSP@SOIC20 [(SA026)]  
R5F21284DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(single wire) [(SA026)]  
R5F21284DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(UART mode) [(SA026)]  
R5F21284JSP@SOIC20 [(SA026)]  
R5F21284JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(single wire) [(SA026)]  
R5F21284JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(UART mode) [(SA026)]  
R5F21284KSP@SOIC20 [(SA026)]  
R5F21284KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(single wire) [(SA026)]  
R5F21284KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(UART mode) [(SA026)]  
R5F21284NSP@SOIC20 [(SA026)]  
R5F21284NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(single wire) [(SA026)]  
R5F21284NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(UART mode) [(SA026)]  
R5F21284SDSP@SOIC20 [(SA026)]  
R5F21284SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(single wire) [(SA026)]  
R5F21284SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(UART mode) [(SA026)]  
R5F21284SJSP@SOIC20 [(SA026)]  
R5F21284SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(single wire) [(SA026)]

R5F21284SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(UART mode) [(SA026)]  
R5F21284SKSP@SOIC20 [(SA026)]  
R5F21284SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(single wire) [(SA026)]  
R5F21284SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(UART mode) [(SA026)]  
R5F21284SNSP@SOIC20 [(SA026)]  
R5F21284SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(single wire) [(SA026)]  
R5F21284SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(UART mode) [(SA026)]  
R5F21292DSP@SOIC20 [(SA026)]  
R5F21292DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(single wire) [(SA026)]  
R5F21292DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(UART mode) [(SA026)]  
R5F21292JSP@SOIC20 [(SA026)]  
R5F21292JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(single wire) [(SA026)]  
R5F21292JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(UART mode) [(SA026)]  
R5F21292KSP@SOIC20 [(SA026)]  
R5F21292KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(single wire) [(SA026)]  
R5F21292KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(UART mode) [(SA026)]  
R5F21292NSP@SOIC20 [(SA026)]  
R5F21292NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(single wire) [(SA026)]  
R5F21292NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(UART mode) [(SA026)]  
R5F21292SDSP@SOIC20 [(SA026)]  
R5F21292SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(single wire) [(SA026)]  
R5F21292SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(UART mode) [(SA026)]  
R5F21292SJSP@SOIC20 [(SA026)]  
R5F21292SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(single wire) [(SA026)]  
R5F21292SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(UART mode) [(SA026)]  
R5F21292SKSP@SOIC20 [(SA026)]

R5F21292SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(single wire) [(SA026)]  
R5F21292SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(UART mode) [(SA026)]  
R5F21292SNSP@SOIC20 [(SA026)]  
R5F21292SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(single wire) [(SA026)]  
R5F21292SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(UART mode) [(SA026)]  
R5F21294DSP@SOIC20 [(SA026)]  
R5F21294DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294DSP@SOIC20(single wire) [(SA026)]  
R5F21294DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294DSP@SOIC20(UART mode) [(SA026)]  
R5F21294JSP@SOIC20 [(SA026)]  
R5F21294JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(single wire) [(SA026)]  
R5F21294JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(UART mode) [(SA026)]  
R5F21294KSP@SOIC20 [(SA026)]  
R5F21294KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(single wire) [(SA026)]  
R5F21294KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(UART mode) [(SA026)]  
R5F21294NSP@SOIC20 [(SA026)]  
R5F21294NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(single wire) [(SA026)]  
R5F21294NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(UART mode) [(SA026)]  
R5F21294SDSP@SOIC20 [(SA026)]  
R5F21294SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(single wire) [(SA026)]  
R5F21294SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(UART mode) [(SA026)]  
R5F21294SJSP@SOIC20 [(SA026)]  
R5F21294SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SJSP@SOIC20(single wire) [(SA026)]  
R5F21294SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SJSP@SOIC20(UART mode) [(SA026)]  
R5F21294SKSP@SOIC20 [(SA026)]  
R5F21294SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SKSP@SOIC20(single wire) [(SA026)]  
R5F21294SKSP@SOIC20(UART ISP) [ISP-HEADER01]

R5F21294SKSP@SOIC20(UART mode) [(SA026)]  
R5F21294SNSP@SOIC20 [(SA026)]  
R5F21294SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(single wire) [(SA026)]  
R5F21294SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(UART mode) [(SA026)]  
R5F212A7SDFA@TQFP64 [(SA768+B251)]  
R5F212A7SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212A7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A7SDFP@TQFP64 [(SA732+B251)]  
R5F212A7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212A7SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212A7SNFA@TQFP64 [(SA768+B251)]  
R5F212A7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212A7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A7SNFP@TQFP64 [(SA732+B251)]  
R5F212A7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212A7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212A8SDFA@TQFP64 [(SA768+B251)]  
R5F212A8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212A8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A8SDFP@TQFP64 [(SA732+B251)]  
R5F212A8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212A8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212A8SNFA@TQFP64 [(SA768+B251)]  
R5F212A8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212A8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A8SNFP@TQFP64 [(SA732+B251)]  
R5F212A8SNFP@TQFP64(single ISP) [ISP-HEADER01]

R5F212A8SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212A8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212AASDFA@TQFP64 [(SA768+B251)]  
R5F212AASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212AASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212AASDFP@TQFP64 [(SA732+B251)]  
R5F212AASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212AASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212AASNFA@TQFP64 [(SA768+B251)]  
R5F212AASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212AASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212AASNFP@TQFP64 [(SA732+B251)]  
R5F212AASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212AASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212ACSDFA@TQFP64 [(SA768+B251)]  
R5F212ACSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212ACSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212ACSDFP@TQFP64 [(SA732+B251)]  
R5F212ACSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212ACSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212ACSNFA@TQFP64 [(SA768+B251)]  
R5F212ACSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212ACSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212ACSNFP@TQFP64 [(SA732+B251)]  
R5F212ACSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212ACSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(UART mode) [(SA732+B251)]

R5F212B7SDFA@TQFP64 [(SA768+B251)]  
R5F212B7SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B7SDFP@TQFP64 [(SA732+B251)]  
R5F212B7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B7SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B7SNFA@TQFP64 [(SA768+B251)]  
R5F212B7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B7SNFP@TQFP64 [(SA732+B251)]  
R5F212B7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B8SDFA@TQFP64 [(SA768+B251)]  
R5F212B8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B8SDFP@TQFP64 [(SA732+B251)]  
R5F212B8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B8SNFA@TQFP64 [(SA768+B251)]  
R5F212B8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B8SNFP@TQFP64 [(SA732+B251)]  
R5F212B8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BASDFA@TQFP64 [(SA768+B251)]  
R5F212BASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(single wire) [(SA768+B251)]

R5F212BASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BASDFP@TQFP64 [(SA732+B251)]  
R5F212BASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BASNFA@TQFP64 [(SA768+B251)]  
R5F212BASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BASNFP@TQFP64 [(SA732+B251)]  
R5F212BASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BCSDFA@TQFP64 [(SA768+B251)]  
R5F212BCSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BCSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BCSDFP@TQFP64 [(SA732+B251)]  
R5F212BCSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BCSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BCSNFA@TQFP64 [(SA768+B251)]  
R5F212BCSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BCSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BCSNFP@TQFP64 [(SA732+B251)]  
R5F212BCSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BCSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212C7SDFP@TQFP80 [(SA731+B249)]  
R5F212C7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212C7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212C7SNFP@TQFP80 [(SA731+B249)]

R5F212C7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212C7SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212C8SDFP@TQFP80 [(SA731+B249)]  
R5F212C8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212C8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212C8SNFP@TQFP80 [(SA731+B249)]  
R5F212C8SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212C8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CASDFP@TQFP80 [(SA731+B249)]  
R5F212CASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212CASDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CASNFP@TQFP80 [(SA731+B249)]  
R5F212CASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212CASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CCSDFP@TQFP80 [(SA731+B249)]  
R5F212CCSDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212CCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CCSNFP@TQFP80 [(SA731+B249)]  
R5F212CCSNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CCSNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212CCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D7SDFP@TQFP80 [(SA731+B249)]  
R5F212D7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D7SNFP@TQFP80 [(SA731+B249)]  
R5F212D7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D7SNFP@TQFP80(UART ISP) [ISP-HEADER01]



R5F212D7SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D8SDFP@TQFP80 [(SA731+B249)]  
R5F212D8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D8SNFP@TQFP80 [(SA731+B249)]  
R5F212D8SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D8SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DASDFP@TQFP80 [(SA731+B249)]  
R5F212DASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DASDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DASDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DASNFP@TQFP80 [(SA731+B249)]  
R5F212DASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DCSDFP@TQFP80 [(SA731+B249)]  
R5F212DCSDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DCSDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DCSNFP@TQFP80 [(SA731+B249)]  
R5F212DCSNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212G4SDFP@QFP32 [(SA663)]  
R5F212G4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SDFP@QFP32(single wire) [(SA663)]  
R5F212G4SNFP@QFP32 [(SA663)]  
R5F212G4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SNFP@QFP32(single wire) [(SA663)]  
R5F212G5SDFP@QFP32 [(SA663)]  
R5F212G5SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SDFP@QFP32(single wire) [(SA663)]  
R5F212G5SNFP@QFP32 [(SA663)]  
R5F212G5SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SNFP@QFP32(single wire) [(SA663)]

R5F212G6SDFP@QFP32 [(SA663)]  
R5F212G6SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SDFP@QFP32(single wire) [(SA663)]  
R5F212G6SNFP@QFP32 [(SA663)]  
R5F212G6SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SNFP@QFP32(single wire) [(SA663)]  
R5F212H1SDSP@TSSOP20 [(SA026+B001)]  
R5F212H1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SDSP@TSSOP20(single wire [(SA026+B001)]  
R5F212H1SNSP@TSSOP20 [(SA026+B001)]  
R5F212H1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SNSP@TSSOP20(single wire [(SA026+B001)]  
R5F212H2SDSP@TSSOP20 [(SA725+B005)]  
R5F212H2SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H2SDSP@TSSOP20(single wire [(SA026+B001)]  
R5F212H2SNSP@TSSOP20 [(SA725+B005)]  
R5F212H2SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H2SNSP@TSSOP20(single wire [(SA026+B001)]  
R5F212J0SDSP@TSSOP20 [(SA026+B001)]  
R5F212J0SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SDSP@TSSOP20(single wire [(SA026+B001)]  
R5F212J0SNSP@TSSOP20 [(SA026+B001)]  
R5F212J0SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SNSP@TSSOP20(single wire [(SA026+B001)]  
R5F212J1SDSP@TSSOP20 [(SA026+B001)]  
R5F212J1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SDSP@TSSOP20(single wire [(SA026+B001)]  
R5F212J1SNSP@TSSOP20 [(SA026+B001)]  
R5F212J1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SNSP@TSSOP20(single wire [(SA026+B001)]  
R5F212K2SDFP@QFP32 [(SA663+B005)]  
R5F212K2SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K2SDFP@QFP32(single wire) [(SA663+B005)]  
R5F212K2SNFP@QFP32 [(SA663+B005)]  
R5F212K2SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K2SNFP@QFP32(single wire) [(SA663+B005)]  
R5F212K4SDFP@QFP32 [(SA663+B005)]  
R5F212K4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K4SDFP@QFP32(single wire) [(SA663+B005)]  
R5F212K4SNFP@QFP32 [(SA663+B005)]  
R5F212K4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K4SNFP@QFP32(single wire) [(SA663+B005)]  
R5F212L2SDFP@QFP32 [(SA663+B005)]

R5F212L2SDFP@QFP32(single ISP) [ISP-HEADER01]  
 R5F212L2SDFP@QFP32(single wire) [(SA663+B005)]  
 R5F212L2SNFP@QFP32 [(SA663+B005)]  
 R5F212L2SNFP@QFP32(single ISP) [ISP-HEADER01]  
 R5F212L2SNFP@QFP32(single wire) [(SA663+B005)]  
 R5F212L4SDFP@QFP32 [(SA663+B005)]  
 R5F212L4SDFP@QFP32(single ISP) [ISP-HEADER01]  
 R5F212L4SDFP@QFP32(single wire) [(SA663+B005)]  
 R5F212L4SNFP@QFP32 [(SA663+B005)]  
 R5F212L4SNFP@QFP32(single ISP) [ISP-HEADER01]  
 R5F212L4SNFP@QFP32(single wire) [(SA663+B005)]

## MOSEL-VITELIC

### E (E) PROM/FRAM/NVRAM

V29C31004B [(SA015A1T)]	V29C31004B@PLCC32
V29C31004B@TSOP32 [(SA410T)]	
V29C31004T	
V29C31004T@PLCC32 [(SA015A1T)]	V29C31004T@TSOP32
[(SA410T)]	
V29C51000B [(SA015A1T)]	V29C51000B@PLCC32
V29C51000T [(SA015A1T)]	V29C51000T@PLCC32
V29C51001B [(SA015A1T)]	V29C51001B@PLCC32
V29C51001B@TSOP32 [(SA410T)]	
V29C51001T	
V29C51001T@PLCC32 [(SA015A1T)]	V29C51001T@TSOP32
[(SA410T)]	
V29C51002B [(SA015A1T)]	V29C51002B@PLCC32
V29C51002B@TSOP32 [(SA410T)]	
V29C51002T	
V29C51002T@PLCC32 [(SA015A1T)]	V29C51002T@TSOP32
[(SA410T)]	
V29C51004B [(SA015A1T)]	V29C51004B@PLCC32
V29C51004B@TSOP32 [(SA410T)]	
V29C51004T	

V29C51004T@PLCC32 [ (SA015A1T) ]  
[ (SA410T) ]  
V29LC51000  
[ (SA015A1T) ]  
V29LC51001  
[ (SA015A1T) ]  
V29LC51002  
[ (SA015A1T) ]

V29C51004T@TSOP32  
V29LC51000@PLCC32  
V29LC51001@PLCC32  
V29LC51002@PLCC32

## MICROCONTROLLER

MSU1958  
[ (SA244) ]  
MSU1958@TQFP44 [ (SA245A) ]  
MSU2952  
MSU2952@PLCC44 [ (SA244) ]  
[ (SA245A) ]  
MSU2958  
[ (SA244) ]  
MSU2958@TQFP44 [ (SA245A) ]  
MSU2964  
MSU2964@PLCC44 [ (SA244) ]  
[ (SA245A) ]

MSU1958@PLCC44  
MSU2952@TQFP44  
MSU2958@PLCC44  
MSU2964@TQFP44

## MOSTEK

### E ( E ) PROM / FRAM / NVRAM

ET2716  
ETC2716  
ETC2732  
MK2716  
MK2764  
MK48C02  
MK48C12  
MK48T02  
MK48T08  
MK48T12  
MK48T12B  
MK48T18  
MK48Z02

MK48Z08  
MK48Z12  
MK48Z12B  
MK48Z18

## MOTOROLA

### E ( E ) PROM / FRAM / NVRAM

MC68764  
MC68766  
MCM2716

### DRAM & SRAM

MCM2018A [ ( SA015A1T ) ]	MCM2018A@PLCC32
MCM60256A [ ( SA630 ) ]	MCM60256A@SOIC28
MCM60256AC [ ( SA630 ) ]	MCM60256AC@SOIC28
MCM60256AV [ ( SA630 ) ]	MCM60256AV@SOIC28
MCM60L256A [ ( SA630 ) ]	MCM60L256A@SOIC28
MCM60L256AC [ ( SA630 ) ]	MCM60L256AC@SOIC28
MCM60L256AV [ ( SA630 ) ]	MCM60L256AV@SOIC28
MCM6206 [ ( SA630 ) ]	MCM6206@SOIC28
MCM6206C [ ( SA630 ) ]	MCM6206C@SOIC28
MCM6207 [ ( SA646 ) ]	MCM6207@SOJ24
MCM6207C [ ( SA646 ) ]	MCM6207C@SOJ24
MCM6208 [ ( SA646 ) ]	MCM6208@SOJ24
MCM6208C [ ( SA646 ) ]	MCM6208C@SOJ24

MCM6209	MCM6209@SOJ28
[ ( SA646 ) ]	
MCM6209C	MCM6209C@SOJ28
[ ( SA646 ) ]	
MCM6229	MCM6229 ( 300m ) @SOJ28
[ ( SA646 ) ]	
MCM6229 ( 400m ) @SOJ28	[ ( SA661 ) ]
MCM6229A	
MCM6229A ( 300m ) @SOJ28	[ ( SA646 ) ]
[ ( SA661 ) ]	
MCM6264	MCM6264@SOIC28
[ ( SA630 ) ]	
MCM6264C	MCM6264C@SOIC28
[ ( SA630 ) ]	
MCM6268	
MCM6269	
MCM6287	MCM6287@SOJ24
[ ( SA646 ) ]	
MCM6288	MCM6288@SOJ22
[ ( SA646 ) ]	
MCM6288B	MCM6288B@SOJ22
[ ( SA646 ) ]	
MCM6288C	MCM6288C@SOJ22
[ ( SA646 ) ]	
MCM6290	MCM6290@SOJ24
[ ( SA646 ) ]	
MCM6290B	MCM6290B@SOJ24
[ ( SA646 ) ]	
MCM6290C	MCM6290C@SOJ24
[ ( SA646 ) ]	
MCM62L07	MCM62L07@SOJ24
[ ( SA646 ) ]	
MCM62L08	MCM62L08@SOJ24
[ ( SA646 ) ]	
MCM62L09	MCM62L09@SOJ28
[ ( SA646 ) ]	
MCM6706	MCM6706@SOIC28
[ ( SA630 ) ]	
MCM6706A	MCM6706A@SOJ28
[ ( SA646 ) ]	
MCM6708A	MCM6708A@SOJ24
[ ( SA646 ) ]	
MCM6709A	MCM6709A@SOJ28



MC68HC705P6(CP)  
MC68HC705P6A(CDW)@SOIC28 [(SA404)]  
MC68HC705P6A(CP)  
MC68HC705P9  
MC68HC705P9@SOIC28 [(SA404)]  
MC68HC711D3  
MC68HC711D3@PLCC44 [(SA244)]                   MC68HC711D3@TQFP44  
[(SA675)]  
MC68HC711E9(4.5V)@PLCC52 [(SA647-B5202)]  
MC68HC711E9@PLCC52(\*) [(SA647-B5202)]  
MC68HC711E9CFN(4.5V)@PLCC52 [(SA647-B5202)]  
MC68HC711E9CFN2@PLCC52(\*) [(SA647-B5202)]  
MC68HC711E9CFN3@PLCC52(\*) [(SA647-B5202)]  
MC68HC711E9CFNE2@PLCC52(\*) [(SA647-B5202)]  
MC68HC711E9CFNE3@PLCC52(\*) [(SA647-B5202)]  
MC68HC711E9-FN@PLCC52(\*) [(SA647-B5202)]  
MC68HC711K4@TQFP80(\*) [(TA031-B006)]  
MC68HC711P2@PLCC84(\*) [(SA649-B8405)]  
MC68HC812A4CPV@TQFP112(\*) [(SA719+B210)]  
MC68HC812A4CPVE@TQFP112(\*) [(SA719+B210)]  
MC68HC812A4MPV@TQFP112(\*) [(SA719+B210)]  
MC68HC812A4MPVE@TQFP112(\*) [(SA719+B210)]  
MC68HC908AB32CFU@TQFP64(\*) [(TA011-B006)]  
MC68HC908AB32MFU@TQFP64(\*) [(TA011-B006)]  
MC68HC908AP16CB(S)@SDIP42 [(SA028)]  
MC68HC908AP16CB@SDIP42 [(SA028)]  
MC68HC908AP16CFA(S)@LQFP48 [(SA248)]  
MC68HC908AP16CFA@LQFP48 [(SA248)]  
MC68HC908AP16CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP16CFB@TQFP44 [(SA675)]  
MC68HC908AP32CB(S)@SDIP42 [(SA028)]  
MC68HC908AP32CB@SDIP42 [(SA028)]  
MC68HC908AP32CFA(S)@LQFP48 [(SA248)]  
MC68HC908AP32CFA@LQFP48 [(SA248)]  
MC68HC908AP32CFB(S)@TQFP44 [(SA675)]  
MC68HC908AP32CFB@TQFP44 [(SA675)]  
MC68HC908AP64CB@SDIP42 [(SA028)]  
MC68HC908AP64CFA@LQFP48 [(SA248)]  
MC68HC908AP64CFB@TQFP44 [(SA675)]  
MC68HC908AP8CB(S)@SDIP42 [(SA028)]  
MC68HC908AP8CB@SDIP42 [(SA028)]  
MC68HC908AP8CFA(S)@LQFP48 [(SA248)]  
MC68HC908AP8CFA@LQFP48 [(SA248)]



MC68HC908AP8CFB(S)@TQFP44 [(SA675)]  
 MC68HC908AP8CFB@TQFP44 [(SA675)]  
 MC68HC908AS60(CFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AS60(MFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AS60(VFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AS60A(CFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AS60A(MFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AS60A(VFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ32A(CFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ32A(MFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ32A(VFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ60(CFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ60(MFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ60(VFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ60A(CFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ60A(MFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908AZ60A(VFU)@TQFP64(\*) [(TA011-B006)]  
 MC68HC908BD48IB@SDIP42 [(SA028)]  
 MC68HC908BD48IFB@TQFP44 [(SA675)]  
 MC68HC908EY16CFA@TQFP32 [(SA663)]  
 MC68HC908EY16MFA@TQFP32 [(SA663)]  
 MC68HC908EY16VFA@TQFP32 [(SA663)]  
 MC68HC908EY8CFA@TQFP32 [(SA663)]      MC68HC908EY8MFA@TQFP32  
 [(SA663)]  
 MC68HC908EY8VFA@TQFP32 [(SA663)]  
 MC68HC908GP32  
 MC68HC908GP32@SDIP42 [(SA028)]      MC68HC908GP32@TQFP44  
 [(SA675)]  
 MC68HC908GR16CFA@TQFP48 [(SA248)]  
 MC68HC908GR16CFJ@TQFP32 [(SA663)]  
 MC68HC908GR16MFA@TQFP48 [(SA248)]  
 MC68HC908GR16MFJ@TQFP32 [(SA663)]  
 MC68HC908GR16VFA@TQFP48 [(SA248)]  
 MC68HC908GR16VFJ@TQFP32 [(SA663)]  
 MC68HC908GR4CDW@SOIC28 [(SA404)]      MC68HC908GR4CFA@TQFP32  
 [(SA663)]  
 MC68HC908GR4CP      MC68HC908GR4MDW@SOIC28  
 [(SA404)]  
 MC68HC908GR4MFA@TQFP32 [(SA663)]  
 MC68HC908GR4MP  
 MC68HC908GR4VDW@SOIC28 [(SA404)]      MC68HC908GR4VFA@TQFP32  
 [(SA663)]  
 MC68HC908GR4VP      MC68HC908GR8CDW@SOIC28

[ ( SA404 ) ]  
MC68HC908GR8CFA@TQFP32 [ ( SA663 ) ]  
MC68HC908GR8CP  
MC68HC908GR8MDW@SOIC28 [ ( SA404 ) ] MC68HC908GR8MFA@TQFP32  
[ ( SA663 ) ]  
MC68HC908GR8MP MC68HC908GR8VDW@SOIC28  
[ ( SA404 ) ]  
MC68HC908GR8VFA@TQFP32 [ ( SA663 ) ]  
MC68HC908GR8VP  
MC68HC908GT16@SDIP42 [ ( SA028 ) ] MC68HC908GT16@TQFP44  
[ ( SA675 ) ]  
MC68HC908GT8CB@SDIP42 [ ( SA028 ) ] MC68HC908GT8CFB@TQFP44  
[ ( SA675 ) ]  
MC68HC908GZ16 ( CFA ) @TQFP48 [ ( SA248 ) ]  
MC68HC908GZ16 ( CFJ ) @TQFP32 [ ( SA663 ) ]  
MC68HC908GZ16 ( MFA ) @TQFP48 [ ( SA248 ) ]  
MC68HC908GZ16 ( MFJ ) @TQFP32 [ ( SA663 ) ]  
MC68HC908GZ16 ( VFA ) @TQFP48 [ ( SA248 ) ]  
MC68HC908GZ16 ( VFJ ) @TQFP32 [ ( SA663 ) ]  
MC68HC908GZ32 ( CFA ) @TQFP48 [ ( SA248 ) ]  
MC68HC908GZ32 ( CFJ ) @TQFP32 [ ( SA663 ) ]  
MC68HC908GZ32 ( MFA ) @TQFP48 [ ( SA248 ) ]  
MC68HC908GZ32 ( MFJ ) @TQFP32 [ ( SA663 ) ]  
MC68HC908GZ32 ( VFA ) @TQFP48 [ ( SA248 ) ]  
MC68HC908GZ32 ( VFJ ) @TQFP32 [ ( SA663 ) ]  
MC68HC908GZ48 ( CFA ) @TQFP48 [ ( SA248 ) ]  
MC68HC908GZ48 ( CFJ ) @TQFP32 [ ( SA663 ) ]  
MC68HC908GZ48 ( MFA ) @TQFP48 [ ( SA248 ) ]  
MC68HC908GZ48 ( MFJ ) @TQFP32 [ ( SA663 ) ]  
MC68HC908GZ48 ( VFA ) @TQFP48 [ ( SA248 ) ]  
MC68HC908GZ48 ( VFJ ) @TQFP32 [ ( SA663 ) ]  
MC68HC908GZ60 ( CFA ) @TQFP48 [ ( SA248 ) ]  
MC68HC908GZ60 ( CFJ ) @TQFP32 [ ( SA663 ) ]  
MC68HC908GZ60 ( MFA ) @TQFP48 [ ( SA248 ) ]  
MC68HC908GZ60 ( MFJ ) @TQFP32 [ ( SA663 ) ]  
MC68HC908GZ60 ( VFA ) @TQFP48 [ ( SA248 ) ]  
MC68HC908GZ60 ( VFJ ) @TQFP32 [ ( SA663 ) ]  
MC68HC908GZ8 ( CFA ) @TQFP48 [ ( SA248 ) ]  
MC68HC908GZ8 ( CFJ ) @TQFP32 [ ( SA663 ) ]  
MC68HC908GZ8 ( MFA ) @TQFP48 [ ( SA248 ) ]  
MC68HC908GZ8 ( MFJ ) @TQFP32 [ ( SA663 ) ]  
MC68HC908GZ8 ( VFA ) @TQFP48 [ ( SA248 ) ]  
MC68HC908GZ8 ( VFJ ) @TQFP32 [ ( SA663 ) ]

MC68HC908JB12(DW)@SOIC28 [(SA404)]	
MC68HC908JB12(JDW)@SOIC20 [(SA404)]	
MC68HC908JB16(DW)@SOIC28 [(SA404)]	
MC68HC908JB16(FA)@QFP32 [(SA663)]	
MC68HC908JB16(JDW)@SOIC20 [(SA404)]	
MC68HC908JB8	MC68HC908JB8@SOIC20
[(SA404)]	
MC68HC908JB8@SOIC28 [(SA404)]	MC68HC908JB8@TQFP44
[(SA675)]	
MC68HC908JK1CDW@SOIC20 [(SA404)]	
MC68HC908JK1CP	
MC68HC908JK1ECDW@SOIC20 [(SA404)]	
MC68HC908JK1ECP	
MC68HC908JK1EMDW@SOIC20 [(SA404)]	
MC68HC908JK1EMP	MC68HC908JK1MDW@SOIC20
[(SA404)]	
MC68HC908JK1MP	MC68HC908JK3CDW@SOIC20
[(SA404)]	
MC68HC908JK3CP	
MC68HC908JK3ECDW@SOIC20 [(SA404)]	
MC68HC908JK3ECP	
MC68HC908JK3EMDW@SOIC20 [(SA404)]	
MC68HC908JK3EMP	MC68HC908JK3MDW@SOIC20
[(SA404)]	
MC68HC908JK3MP	
MC68HC908JK8	
MC68HC908JK8@SOIC20 [(SA404)]	MC68HC908JL3CDW@SOIC28
[(SA404)]	
MC68HC908JL3CFA@TQFP48 [(SA248)]	
MC68HC908JL3CP	
MC68HC908JL3ECDW@SOIC28 [(SA404)]	
MC68HC908JL3ECFA@TQFP48 [(SA248)]	
MC68HC908JL3ECP	
MC68HC908JL3EMDW@SOIC28 [(SA404)]	
MC68HC908JL3EMFA@TQFP48 [(SA248)]	
MC68HC908JL3EMP	MC68HC908JL3MDW@SOIC28
[(SA404)]	
MC68HC908JL3MFA@TQFP48 [(SA248)]	
MC68HC908JL3MP	
MC68HC908JL8(dip20)	MC68HC908JL8
(dip28)	
MC68HC908JL8@LQFP32 [(SA663)]	MC68HC908JL8@SDIP32
[(SA653)]	

MC68HC908JL8@SOIC20 [(SA404)]	MC68HC908JL8@SOIC28
[(SA404)]	
MC68HC908KX2(CDW)@SOIC16 [(SA404)]	
MC68HC908KX2(CP)	
MC68HC908KX2(MDW)@SOIC16 [(SA404)]	
MC68HC908KX2(MP)	
MC68HC908KX2(VDW)@SOIC16 [(SA404)]	
MC68HC908KX2(VP)	
MC68HC908KX8(CDW)@SOIC16 [(SA404)]	
MC68HC908KX8(CP)	
MC68HC908KX8(MDW)@SOIC16 [(SA404)]	
MC68HC908KX8(MP)	
MC68HC908KX8(VDW)@SOIC16 [(SA404)]	
MC68HC908KX8(VP)	MC68HC908LB8CDWE(S)
@SOIC20	
MC68HC908LB8CDWE@SOIC20 [(SA404)]	
MC68HC908LB8CPE	MC68HC908LB8CPE
(S)	
MC68HC908LB8MDWE(S)@SOIC20	
MC68HC908LB8MDWE@SOIC20 [(SA404)]	
MC68HC908LB8MPE	MC68HC908LB8MPE
(S)	
MC68HC908LB8VDWE(S)@SOIC20	
MC68HC908LB8VDWE@SOIC20 [(SA404)]	
MC68HC908LB8VPE	MC68HC908LB8VPE
(S)	
MC68HC908LJ12CFU@TQFP64(*) [(SA757-B331)]	
MC68HC908LJ12CFUE@TQFP64(*) [(SA757-B331)]	
MC68HC908LJ24CFU@TQFP64(*) [(SA757-B331)]	
MC68HC908LJ24CFUE@TQFP64(*) [(SA757-B331)]	
MC68HC908LK24CFU@TQFP64(*) [(SA757-B331)]	
MC68HC908LK24CFUE@TQFP64(*) [(SA757-B331)]	
MC68HC908QB4(CDT)@TSSOP16 [(SA026)]	
MC68HC908QB4(CDW)@SOIC16 [(SA404)]	
MC68HC908QB4(CP)	
MC68HC908QB4(MDT)@TSSOP16 [(SA026)]	
MC68HC908QB4(MDW)@SOIC16 [(SA404)]	
MC68HC908QB4(MP)	
MC68HC908QB4(VDT)@TSSOP16 [(SA026)]	
MC68HC908QB4(VDW)@SOIC16 [(SA404)]	
MC68HC908QB4(VP)	
MC68HC908QB8(CDT)@TSSOP16 [(SA026)]	
MC68HC908QB8(CDW)@SOIC16 [(SA404)]	

MC68HC908QB8 (CP)  
MC68HC908QB8 (MDT)@TSSOP16 [(SA026)]  
MC68HC908QB8 (MDW)@SOIC16 [(SA404)]  
MC68HC908QB8 (MP)  
MC68HC908QB8 (VDT)@TSSOP16 [(SA026)]  
MC68HC908QB8 (VDW)@SOIC16 [(SA404)]  
MC68HC908QB8 (VP)  
MC68HC908QC16 (CDR)@TSSOP28 [(SA643)]  
MC68HC908QC16 (CDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16 (CDS)@TSSOP20 [(SA643)]  
MC68HC908QC16 (CDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QC16 (CDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16 (CDX)@SOIC16 [(SA404)]  
MC68HC908QC16 (CDXE)@SOIC16 [(SA404)]  
MC68HC908QC16 (CDY)@SOIC20 [(SA404)]  
MC68HC908QC16 (CDYE)@SOIC20 [(SA404)]  
MC68HC908QC16 (CDZ)@SOIC28 [(SA404)]  
MC68HC908QC16 (CDZE)@SOIC28 [(SA404)]  
MC68HC908QC16 (MDR)@TSSOP28 [(SA643)]  
MC68HC908QC16 (MDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16 (MDS)@TSSOP20 [(SA643)]  
MC68HC908QC16 (MDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QC16 (MDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16 (MDX)@SOIC16 [(SA404)]  
MC68HC908QC16 (MDXE)@SOIC16 [(SA404)]  
MC68HC908QC16 (MDY)@SOIC20 [(SA404)]  
MC68HC908QC16 (MDYE)@SOIC20 [(SA404)]  
MC68HC908QC16 (MDZ)@SOIC28 [(SA404)]  
MC68HC908QC16 (MDZE)@SOIC28 [(SA404)]  
MC68HC908QC16 (VDR)@TSSOP28 [(SA643)]  
MC68HC908QC16 (VDRE)@TSSOP28 [(SA643)]  
MC68HC908QC16 (VDS)@TSSOP20 [(SA643)]  
MC68HC908QC16 (VDSE)@TSSOP20 [(SA643)]  
MC68HC908QC16 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QC16 (VDTE)@TSSOP16 [(SA643)]  
MC68HC908QC16 (VDX)@SOIC16 [(SA404)]  
MC68HC908QC16 (VDXE)@SOIC16 [(SA404)]  
MC68HC908QC16 (VDY)@SOIC20 [(SA404)]  
MC68HC908QC16 (VDYE)@SOIC20 [(SA404)]  
MC68HC908QC16 (VDZ)@SOIC28 [(SA404)]  
MC68HC908QC16 (VDZE)@SOIC28 [(SA404)]

MC68HC908QC4 (CDR)@TSSOP28 [(SA643)]  
MC68HC908QC4 (CDRE)@TSSOP28 [(SA643)]  
MC68HC908QC4 (CDS)@TSSOP20 [(SA643)]  
MC68HC908QC4 (CDSE)@TSSOP20 [(SA643)]  
MC68HC908QC4 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QC4 (CDTE)@TSSOP16 [(SA643)]  
MC68HC908QC4 (CDX)@SOIC16 [(SA404)]  
MC68HC908QC4 (CDXE)@SOIC16 [(SA404)]  
MC68HC908QC4 (CDY)@SOIC20 [(SA404)]  
MC68HC908QC4 (CDYE)@SOIC20 [(SA404)]  
MC68HC908QC4 (CDZ)@SOIC28 [(SA404)]  
MC68HC908QC4 (CDZE)@SOIC28 [(SA404)]  
MC68HC908QC4 (MDR)@TSSOP28 [(SA643)]  
MC68HC908QC4 (MDRE)@TSSOP28 [(SA643)]  
MC68HC908QC4 (MDS)@TSSOP20 [(SA643)]  
MC68HC908QC4 (MDSE)@TSSOP20 [(SA643)]  
MC68HC908QC4 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QC4 (MDTE)@TSSOP16 [(SA643)]  
MC68HC908QC4 (MDX)@SOIC16 [(SA404)]  
MC68HC908QC4 (MDXE)@SOIC16 [(SA404)]  
MC68HC908QC4 (MDY)@SOIC20 [(SA404)]  
MC68HC908QC4 (MDYE)@SOIC20 [(SA404)]  
MC68HC908QC4 (MDZ)@SOIC28 [(SA404)]  
MC68HC908QC4 (MDZE)@SOIC28 [(SA404)]  
MC68HC908QC4 (VDR)@TSSOP28 [(SA643)]  
MC68HC908QC4 (VDRE)@TSSOP28 [(SA643)]  
MC68HC908QC4 (VDS)@TSSOP20 [(SA643)]  
MC68HC908QC4 (VDSE)@TSSOP20 [(SA643)]  
MC68HC908QC4 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QC4 (VDTE)@TSSOP16 [(SA643)]  
MC68HC908QC4 (VDX)@SOIC16 [(SA404)]  
MC68HC908QC4 (VDXE)@SOIC16 [(SA404)]  
MC68HC908QC4 (VDY)@SOIC20 [(SA404)]  
MC68HC908QC4 (VDYE)@SOIC20 [(SA404)]  
MC68HC908QC4 (VDZ)@SOIC28 [(SA404)]  
MC68HC908QC4 (VDZE)@SOIC28 [(SA404)]  
MC68HC908QC8 (CDR)@TSSOP28 [(SA643)]  
MC68HC908QC8 (CDRE)@TSSOP28 [(SA643)]  
MC68HC908QC8 (CDS)@TSSOP20 [(SA643)]  
MC68HC908QC8 (CDSE)@TSSOP20 [(SA643)]  
MC68HC908QC8 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QC8 (CDTE)@TSSOP16 [(SA643)]  
MC68HC908QC8 (CDX)@SOIC16 [(SA404)]

MC68HC908QC8 (CDXE)@SOIC16 [(SA404)]  
MC68HC908QC8 (CDY)@SOIC20 [(SA404)]  
MC68HC908QC8 (CDYE)@SOIC20 [(SA404)]  
MC68HC908QC8 (CDZ)@SOIC28 [(SA404)]  
MC68HC908QC8 (CDZE)@SOIC28 [(SA404)]  
MC68HC908QC8 (MDR)@TSSOP28 [(SA643)]  
MC68HC908QC8 (MDRE)@TSSOP28 [(SA643)]  
MC68HC908QC8 (MDS)@TSSOP20 [(SA643)]  
MC68HC908QC8 (MDSE)@TSSOP20 [(SA643)]  
MC68HC908QC8 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QC8 (MDTE)@TSSOP16 [(SA643)]  
MC68HC908QC8 (MDX)@SOIC16 [(SA404)]  
MC68HC908QC8 (MDXE)@SOIC16 [(SA404)]  
MC68HC908QC8 (MDY)@SOIC20 [(SA404)]  
MC68HC908QC8 (MDYE)@SOIC20 [(SA404)]  
MC68HC908QC8 (MDZ)@SOIC28 [(SA404)]  
MC68HC908QC8 (MDZE)@SOIC28 [(SA404)]  
MC68HC908QC8 (VDR)@TSSOP28 [(SA643)]  
MC68HC908QC8 (VDRE)@TSSOP28 [(SA643)]  
MC68HC908QC8 (VDS)@TSSOP20 [(SA643)]  
MC68HC908QC8 (VDSE)@TSSOP20 [(SA643)]  
MC68HC908QC8 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QC8 (VDTE)@TSSOP16 [(SA643)]  
MC68HC908QC8 (VDX)@SOIC16 [(SA404)]  
MC68HC908QC8 (VDXE)@SOIC16 [(SA404)]  
MC68HC908QC8 (VDY)@SOIC20 [(SA404)]  
MC68HC908QC8 (VDYE)@SOIC20 [(SA404)]  
MC68HC908QC8 (VDZ)@SOIC28 [(SA404)]  
MC68HC908QC8 (VDZE)@SOIC28 [(SA404)]  
MC68HC908QF4 (CFJ)@TQFP32 [(SA663)]  
MC68HC908QF4 (FJ)@TQFP32 [(SA663)]  
MC68HC908QL2 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QL2 (CDW)@SOIC16 [(SA404)]  
MC68HC908QL2 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QL2 (MDW)@SOIC16 [(SA404)]  
MC68HC908QL2 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QL2 (VDW)@SOIC16 [(SA404)]  
MC68HC908QL3 (CDT)@TSSOP16 [(SA643)]  
MC68HC908QL3 (CDW)@SOIC16 [(SA404)]  
MC68HC908QL3 (MDT)@TSSOP16 [(SA643)]  
MC68HC908QL3 (MDW)@SOIC16 [(SA404)]  
MC68HC908QL3 (VDT)@TSSOP16 [(SA643)]  
MC68HC908QL3 (VDW)@SOIC16 [(SA404)]

MC68HC908QL4(CDT)@TSSOP16 [(SA643)]  
MC68HC908QL4(CDW)@SOIC16 [(SA404)]  
MC68HC908QL4(MDT)@TSSOP16 [(SA643)]  
MC68HC908QL4(MDW)@SOIC16 [(SA404)]  
MC68HC908QL4(VDT)@TSSOP16 [(SA643)]  
MC68HC908QL4(VDW)@SOIC16 [(SA404)]  
MC68HC908QT1CDW@SOIC8 [(SA605A)]  
MC68HC908QT1CP  
MC68HC908QT1MDW@SOIC8 [(SA605A)]  
MC68HC908QT1MP  
MC68HC908QT1VDW@SOIC8 [(SA605A)]  
MC68HC908QT1VP  
MC68HC908QT2CDW@SOIC8 [(SA605A)]  
MC68HC908QT2CP  
MC68HC908QT2MDW@SOIC8 [(SA605A)]  
MC68HC908QT2MP  
MC68HC908QT2VDW@SOIC8 [(SA605A)]  
MC68HC908QT2VP  
MC68HC908QT4CDW@SOIC8 [(SA605A)]  
MC68HC908QT4CP  
MC68HC908QT4MDW@SOIC8 [(SA605A)]  
MC68HC908QT4MP  
MC68HC908QT4VDW@SOIC8 [(SA605A)]  
MC68HC908QT4VP  
MC68HC908QY1CDT@TSSOP16 [(SA026)]  
MC68HC908QY1CDW@SOIC16 [(SA404)]  
MC68HC908QY1CP  
MC68HC908QY1MDT@TSSOP16 [(SA026)]  
MC68HC908QY1MDW@SOIC16 [(SA404)]  
MC68HC908QY1MP  
MC68HC908QY1VDT@TSSOP16 [(SA026)]  
MC68HC908QY1VDW@SOIC16 [(SA404)]  
MC68HC908QY1VP  
MC68HC908QY2CDT@TSSOP16 [(SA026)]  
MC68HC908QY2CDW@SOIC16 [(SA404)]  
MC68HC908QY2CP  
MC68HC908QY2MDT@TSSOP16 [(SA026)]  
MC68HC908QY2MDW@SOIC16 [(SA404)]  
MC68HC908QY2MP  
MC68HC908QY2VDT@TSSOP16 [(SA026)]  
MC68HC908QY2VDW@SOIC16 [(SA404)]  
MC68HC908QY2VP  
MC68HC908QY4CDT@TSSOP16 [(SA026)]



MC68HC908QY4CDW@SOIC16 [(SA404)]  
MC68HC908QY4CP  
MC68HC908QY4MDT@TSSOP16 [(SA026)]  
MC68HC908QY4MDW@SOIC16 [(SA404)]  
MC68HC908QY4MP  
MC68HC908QY4VDT@TSSOP16 [(SA026)]  
MC68HC908QY4VDW@SOIC16 [(SA404)]  
MC68HC908QY4VP  
MC68HC908QY8(CDT)@TSSOP16 [(SA026)]  
MC68HC908QY8(CDW)@SOIC16 [(SA404)]  
MC68HC908QY8(CP)  
MC68HC908QY8(MDT)@TSSOP16 [(SA026)]  
MC68HC908QY8(MDW)@SOIC16 [(SA404)]  
MC68HC908QY8(MP)  
MC68HC908QY8(VDT)@TSSOP16 [(SA026)]  
MC68HC908QY8(VDW)@SOIC16 [(SA404)]  
MC68HC908QY8(VP)  
MC68HC908RF2(CFA)@TQFP32 [(SA663)]  
MC68HC908RF2(MFA)@TQFP32 [(SA663)]  
MC68HC908SR12(CB)@SDIP42 [(SA028)]  
MC68HC908SR12(CFA)@TQFP48 [(SA248)]  
MC68HC908SR12(MB)@SDIP42 [(SA028)]  
MC68HC908SR12(MFA)@TQFP48 [(SA248)]  
MC68HC912B32(CFU8)@TQFP80(\*) [(TA045-B006)]  
MC68HC912B32(MFU8)@TQFP80(\*) [(TA045-B006)]  
MC68HC912B32(VFU8)@TQFP80(\*) [(TA045-B006)]  
MC68HC912BC32(CFU8)@TQFP80(\*) [(TA045-B006)]  
MC68HC912BC32(MFU8)@TQFP80(\*) [(TA045-B006)]  
MC68HC912BC32(VFU8)@TQFP80(\*) [(TA045-B006)]  
MC68HCP11E1@PLCC52(\*) [(SA647-B5202)]  
MC68HRC908JK1CDW@SOIC20 [(SA404)]  
MC68HRC908JK1CP  
MC68HRC908JK1ECDW@SOIC20 [(SA404)]  
MC68HRC908JK1ECP  
MC68HRC908JK1EMDW@SOIC20 [(SA404)]  
MC68HRC908JK1EMP  
MC68HRC908JK1MDW@SOIC20 [(SA404)]  
MC68HRC908JK1MP  
MC68HRC908JK3CDW@SOIC20 [(SA404)]  
MC68HRC908JK3CP  
MC68HRC908JK3ECDW@SOIC20 [(SA404)]  
MC68HRC908JK3ECP  
MC68HRC908JK3EMDW@SOIC20 [(SA404)]

MC68HRC908JK3EMP	
MC68HRC908JK3MDW@SOIC20 [(SA404)]	
MC68HRC908JK3MP	
MC68HRC908JK8	
MC68HRC908JK8@SOIC20 [(SA404)]	
MC68HRC908JL3CDW@SOIC28 [(SA404)]	
MC68HRC908JL3CFA@TQFP48 [(SA248)]	
MC68HRC908JL3CP	
MC68HRC908JL3ECDW@SOIC28 [(SA404)]	
MC68HRC908JL3ECFA@TQFP48 [(SA248)]	
MC68HRC908JL3ECP	
MC68HRC908JL3EMDW@SOIC28 [(SA404)]	
MC68HRC908JL3EMFA@TQFP48 [(SA248)]	
MC68HRC908JL3EMP	
MC68HRC908JL3MDW@SOIC28 [(SA404)]	
MC68HRC908JL3MFA@TQFP48 [(SA248)]	
MC68HRC908JL3MP	MC68HRC908JL8
(dip20)	
MC68HRC908JL8(dip28)	MC68HRC908JL8@LQFP32
[(SA663)]	
MC68HRC908JL8@SDIP32 [(SA653)]	MC68HRC908JL8@SOIC20
[(SA404)]	
MC68HRC908JL8@SOIC28 [(SA404)]	
MC68S711E9@PLCC52(*) [(SA647-B5202)]	
MC68S711E9-FN@PLCC52(*) [(SA647-B5202)]	
MC908AB32CFUE@TQFP64(*) [(TA011-B006)]	
MC908AB32MFUE@TQFP64(*) [(TA011-B006)]	
MC908AP16CBE@SDIP42 [(SA028)]	MC908AP16CFAE@LQFP48
[(SA248)]	
MC908AP16CFBE@TQFP44 [(SA675)]	MC908AP32CBE@SDIP42
[(SA028)]	
MC908AP32CFAE@LQFP48 [(SA248)]	MC908AP32CFBE@TQFP44
[(SA675)]	
MC908AP64CBE@SDIP42 [(SA028)]	MC908AP64CFAE@LQFP48
[(SA248)]	
MC908AP64CFBE@TQFP44 [(SA675)]	MC908AP8CBE@SDIP42
[(SA028)]	
MC908AP8CFAE@@LQFP48 [(SA248)]	MC908AP8CFBE@TQFP44
[(SA675)]	
MC908BD48IBE@SDIP42 [(SA028)]	MC908BD48IFBE@TQFP44
[(SA675)]	
MC908EY16ACFJE@TQFP32 [(SA663)]	MC908EY16AKFJE@TQFP32
[(SA663)]	

MC908EY16AMFJE@TQFP32 [(SA663)]	MC908EY16AVFJE@TQFP32
[(SA663)]	
MC908EY8ACFJE@TQFP32 [(SA663)]	MC908EY8AKFJE@TQFP32
[(SA663)]	
MC908EY8AMFJE@TQFP32 [(SA663)]	MC908EY8AVFJE@TQFP32
[(SA663)]	
MC908JL16CDWE@SOIC28 [(SA404)]	MC908JL16CFJE@LQFP32
[(SA663)]	
MC908JL16CPE	MC908JL16CSPE@SDIP32
[(SA653)]	
MC908QT1ACDWE@SOIC8 [(SA605A)]	
MC908QT1ACPE	
MC908QT1AMDWE@SOIC8 [(SA605A)]	
MC908QT1AMPE	
MC908QT1AVDWE@SOIC8 [(SA605A)]	
MC908QT1AVPE	
MC908QT2ACDWE@SOIC8 [(SA605A)]	
MC908QT2ACPE	
MC908QT2AMDWE@SOIC8 [(SA605A)]	
MC908QT2AMPE	
MC908QT2AVDWE@SOIC8 [(SA605A)]	
MC908QT2AVPE	
MC908QT4ACDWE@SOIC8 [(SA605A)]	
MC908QT4ACPE	
MC908QT4AMDWE@SOIC8 [(SA605A)]	
MC908QT4AMPE	
MC908QT4AVDWE@SOIC8 [(SA605A)]	
MC908QT4AVPE	
MC908QY1ACDTE@TSSOP16 [(SA026)]	MC908QY1ACDWE@SOIC16
[(SA404)]	
MC908QY1ACPE	MC908QY1AMDTE@TSSOP16
[(SA026)]	
MC908QY1AMDWE@SOIC16 [(SA404)]	
MC908QY1AMPE	
MC908QY1AVDTE@TSSOP16 [(SA026)]	MC908QY1AVDWE@SOIC16
[(SA404)]	
MC908QY1AVPE	MC908QY2ACDTE@TSSOP16
[(SA026)]	
MC908QY2ACDWE@SOIC16 [(SA404)]	
MC908QY2ACPE	
MC908QY2AMDTE@TSSOP16 [(SA026)]	MC908QY2AMDWE@SOIC16
[(SA404)]	
MC908QY2AMPE	MC908QY2AVDTE@TSSOP16

[ ( SA026 ) ]  
MC908QY2AVDWE@SOIC16 [ ( SA404 ) ]  
MC908QY2AVPE  
MC908QY4ACDTE@TSSOP16 [ ( SA026 ) ]            MC908QY4ACDWE@SOIC16  
[ ( SA404 ) ]  
MC908QY4ACPE    MC908QY4AMDTE@TSSOP16  
[ ( SA026 ) ]  
MC908QY4AMDWE@SOIC16 [ ( SA404 ) ]  
MC908QY4AMPE  
MC908QY4AVDTE@TSSOP16 [ ( SA026 ) ]            MC908QY4AVDWE@SOIC16  
[ ( SA404 ) ]  
MC908QY4AVPE  
MC912D60ACFU8@TQFP80 ( \* ) [ ( TA034-B006 ) ]  
MC912D60ACPV8@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912D60AMFU8@TQFP80 ( \* ) [ ( TA034-B006 ) ]  
MC912D60AMPV8@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912D60AVFU8@TQFP80 ( \* ) [ ( TA034-B006 ) ]  
MC912D60AVPV8@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912D60CCFU8@TQFP80 ( \* ) [ ( TA034-B006 ) ]  
MC912D60CCPV8@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912D60CMFU8@TQFP80 ( \* ) [ ( TA034-B006 ) ]  
MC912D60CMPV8@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912D60CVFU8@TQFP80 ( \* ) [ ( TA034-B006 ) ]  
MC912D60CVPV8@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912D60PCFU8@TQFP80 ( \* ) [ ( TA034-B006 ) ]  
MC912D60PCPV8@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912D60PMFU8@TQFP80 ( \* ) [ ( TA034-B006 ) ]  
MC912D60PMPV8@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912D60PVFU8@TQFP80 ( \* ) [ ( TA034-B006 ) ]  
MC912D60PVPV8@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912DG128ACPV@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912DG128AMPV@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912DG128AVPV@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912DG128CCPV@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912DG128CMPV@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912DG128CVPV@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912DG128PCPV@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912DG128PMPV@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912DG128PVPV@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912DT128ACPV@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912DT128AMPV@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912DT128AVPV@TQFP112 ( \* ) [ ( TA035+B084 ) ]  
MC912DT128CCPV@TQFP112 ( \* ) [ ( TA035+B084 ) ]

MC912DT128CMPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128CVPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128PCPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128PMPV@TQFP112(\*) [(TA035+B084)]  
MC912DT128PVPV@TQFP112(\*) [(TA035+B084)]  
MC9RS08KA1CPC [(SA726+B179)]  
MC9RS08KA1CSC@SOIC8 [(SA602A+B179)]  
MC9RS08KA2CPC [(SA726+B179)]  
MC9RS08KA2CSC@SOIC8 [(SA602A+B179)]  
MC9S08AC16CFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC16CFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC16MFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC16MFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC16VFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC16VFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC8CFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC8CFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC8MFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC8MFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AC8VFD@QFN48(\*) [(SA696+B198)]  
MC9S08AC8VFG@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW16CFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW16CFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW16CFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW16CPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW16MFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW16MFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW16MFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW16MPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW32CFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW32CFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW32CFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW32CPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW32MFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW32MFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW32MFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW32MPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW48CFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW48CFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW48CFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW48CPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW48MFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW48MFGE@LQFP44(\*) [(SA245+B4404)]

MC9S08AW48MFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW48MPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW60CFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW60CFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW60CFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW60CPUE@QFP64(\*) [(SA732+B196)]  
MC9S08AW60MFDE@QFN48(\*) [(SA696+B198)]  
MC9S08AW60MFGE@LQFP44(\*) [(SA245+B4404)]  
MC9S08AW60MFUE@LQFP64(\*) [(SA757+B196)]  
MC9S08AW60MPUE@QFP64(\*) [(SA732+B196)]  
MC9S08GB32ACFU@LQFP64 [(TA066-B006)]  
MC9S08GB32ACFUE@LQFP64 [(TA066-B006)]  
MC9S08GB32CFU@LQFP64 [(TA066-B006)]  
MC9S08GB32CFUE@LQFP64 [(TA066-B006)]  
MC9S08GB60ACFU@LQFP64 [(TA066-B006)]  
MC9S08GB60ACFUE@LQFP64 [(TA066-B006)]  
MC9S08GB60CFU@LQFP64 [(TA066-B006)]  
MC9S08GB60CFUE@LQFP64 [(TA066-B006)]  
MC9S08GT16ACB@SDIP42 [(SA028-B167)]  
MC9S08GT16ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT16ACFC@MLF32 [(SA686-B231)]  
MC9S08GT16ACFCE@MLF32 [(SA686-B231)]  
MC9S08GT16ACFD@QFN48 [(SA696-B166)]  
MC9S08GT16AMB@SDIP42 [(SA028-B167)]  
MC9S08GT16AMFB@LQFP44 [(SA675-B168)]  
MC9S08GT16AMFC@MLF32 [(SA686-B231)]  
MC9S08GT16AMFCE@MLF32 [(SA686-B231)]  
MC9S08GT16AMFD@QFN48 [(SA696-B166)]  
MC9S08GT16CB@SDIP42 [(SA028-B167)]  
MC9S08GT16CBE@SDIP42 [(SA028-B167)]  
MC9S08GT16CFB@LQFP44 [(SA675-B168)]  
MC9S08GT16CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT16CFD@QFN48 [(SA696-B166)]  
MC9S08GT16CFDE@QFN48 [(SA696-B166)]  
MC9S08GT32ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT32ACFBE@LQFP44 [(SA675-B168)]  
MC9S08GT32ACFD@QFN48 [(SA696-B166)]  
MC9S08GT32ACFDE@QFN48 [(SA696-B166)]  
MC9S08GT32CB@SDIP42 [(SA028-B167)]  
MC9S08GT32CBE@SDIP42 [(SA028-B167)]  
MC9S08GT32CFB@LQFP44 [(SA675-B168)]  
MC9S08GT32CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT32CFD@QFN48 [(SA696-B166)]

MC9S08GT32CFDE@QFN48 [(SA696-B166)]  
MC9S08GT60ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT60ACFBE@LQFP44 [(SA675-B168)]  
MC9S08GT60ACFD@QFN48 [(SA696-B166)]  
MC9S08GT60ACFDE@QFN48 [(SA696-B166)]  
MC9S08GT60CB@SDIP42 [(SA028-B167)]  
MC9S08GT60CBE@SDIP42 [(SA028-B167)]  
MC9S08GT60CFB@LQFP44 [(SA675-B168)]  
MC9S08GT60CFBE@LQFP44 [(SA675-B168)]  
MC9S08GT60CFD@QFN48 [(SA696-B166)]  
MC9S08GT60CFDE@QFN48 [(SA696-B166)]  
MC9S08GT8ACB@SDIP42 [(SA028-B167)]  
MC9S08GT8ACFB@LQFP44 [(SA675-B168)]  
MC9S08GT8ACFC@MLF32 [(SA686-B231)]  
MC9S08GT8ACFCE@MLF32 [(SA686-B231)]  
MC9S08GT8ACFD@QFN48 [(SA696-B166)]  
MC9S08GT8AMB@SDIP42 [(SA028-B167)]  
MC9S08GT8AMFB@LQFP44 [(SA675-B168)]  
MC9S08GT8AMFC@MLF32 [(SA686-B231)]  
MC9S08GT8AMFCE@MLF32 [(SA686-B231)]  
MC9S08GT8AMFD@QFN48 [(SA696-B166)]  
MC9S08JM32CGTE@QFN48(\*) [(SA696+B310)]  
MC9S08JM32CLDE@QFP44(\*) [(SA245A+B4405)]  
MC9S08JM32CLHE@QFP64(\*) [(SA732+B311)]  
MC9S08JM32CQHE@TQFP64(\*) [(SA668+B311)]  
MC9S08JM60CGTE@QFN48(\*) [(SA696+B310)]  
MC9S08JM60CLDE@QFP44(\*) [(SA245A+B4405)]  
MC9S08JM60CLHE@QFP64(\*) [(SA732+B311)]  
MC9S08JM60CQHE@TQFP64(\*) [(SA668+B311)]  
MC9S08QA2CDN@SOIC8 [(SA602A+B179)]  
MC9S08QA2CDNE@SOIC8 [(SA602A+B179)]  
MC9S08QA2CFQ@DFN8 [(SA744+B248)]  
MC9S08QA2CFQE@DFN8 [(SA744+B248)]  
MC9S08QA2CPA  
MC9S08QA2CPAE  
MC9S08QA2MDN@SOIC8 [(SA602A+B179)]  
MC9S08QA2MDNE@SOIC8 [(SA602A+B179)]  
MC9S08QA2MFQ@DFN8 [(SA744+B248)]  
MC9S08QA2MFQE@DFN8 [(SA744+B248)]  
MC9S08QA2MPA  
MC9S08QA2MPAE  
MC9S08QA2VDN@SOIC8 [(SA602A+B179)]  
MC9S08QA2VDNE@SOIC8 [(SA602A+B179)]

MC9S08QA2VFQ@DFN8 [ (SA744+B248) ]  
MC9S08QA2VFQE@DFN8 [ (SA744+B248) ]  
MC9S08QA2VPA  
MC9S08QA2VPAE  
MC9S08QA4CDN@SOIC8 [ (SA602A+B179) ]  
MC9S08QA4CDNE@SOIC8 [ (SA602A+B179) ]  
MC9S08QA4CFQ@DFN8 [ (SA744+B248) ]  
MC9S08QA4CFQE@DFN8 [ (SA744+B248) ]  
MC9S08QA4CPA  
MC9S08QA4CPAE  
MC9S08QA4MDN@SOIC8 [ (SA602A+B179) ]  
MC9S08QA4MDNE@SOIC8 [ (SA602A+B179) ]  
MC9S08QA4MFQ@DFN8 [ (SA744+B248) ]  
MC9S08QA4MFQE@DFN8 [ (SA744+B248) ]  
MC9S08QA4MPA  
MC9S08QA4MPAE  
MC9S08QA4VDN@SOIC8 [ (SA602A+B179) ]  
MC9S08QA4VDNE@SOIC8 [ (SA602A+B179) ]  
MC9S08QA4VFQ@DFN8 [ (SA744+B248) ]  
MC9S08QA4VFQE@DFN8 [ (SA744+B248) ]  
MC9S08QA4VPA  
MC9S08QA4VPAE  
MC9S08QD2CPC [ (SA726+B179) ]  
MC9S08QD2CSC@SOIC8 [ (SA602A+B179) ]  
MC9S08QD2MPC [ (SA726+B179) ]  
MC9S08QD2MSC@SOIC8 [ (SA602A+B179) ]  
MC9S08QD2VPC [ (SA726+B179) ]  
MC9S08QD2VSC@SOIC8 [ (SA602A+B179) ]  
MC9S08QD4CPC [ (SA726+B179) ]  
MC9S08QD4CSC@SOIC8 [ (SA602A+B179) ]  
MC9S08QD4MPC [ (SA726+B179) ]  
MC9S08QD4MSC@SOIC8 [ (SA602A+B179) ]  
MC9S08QD4VPC [ (SA726+B179) ]  
MC9S08QD4VSC@SOIC8 [ (SA602A+B179) ]  
MC9S08QG4CDNE@SOIC8 [ (SA602A+B179) ]  
MC9S08QG4CDTE@TSSOP16 [ (SA026+B182) ]  
MC9S08QG4CFFE@QFN16 [ (SA747+B247) ]  
MC9S08QG4CFQE@DFN8 [ (SA744+B248) ]  
MC9S08QG4CPAE [ (SA726+B179) ]  
MC9S08QG8CDNE@SOIC8 [ (SA602A+B179) ]  
MC9S08QG8CDTE@TSSOP16 [ (SA026+B182) ]  
MC9S08QG8CFFE@QFN16 [ (SA747+B247) ]  
MC9S08QG8CFQE@DFN8 [ (SA744+B248) ]



MC9S08QG8CPBE [(SA726+B182)]	MC9S08RC16CFG@LQFP44
[(SA245A)]	
MC9S08RC16CFJ@LQFP32 [(SA663)]	MC9S08RC16FG@LQFP44
[(SA245A)]	
MC9S08RC16FJ@LQFP32 [(SA663)]	MC9S08RC32CFG@LQFP44
[(SA245A)]	
MC9S08RC32CFJ@LQFP32 [(SA663)]	MC9S08RC32FG@LQFP44
[(SA245A)]	
MC9S08RC32FJ@LQFP32 [(SA663)]	MC9S08RC60CFG@LQFP44
[(SA245A)]	
MC9S08RC60CFJ@LQFP32 [(SA663)]	MC9S08RC60FG@LQFP44
[(SA245A)]	
MC9S08RC60FJ@LQFP32 [(SA663)]	MC9S08RC8CFG@LQFP44
[(SA245A)]	
MC9S08RC8CFJ@LQFP32 [(SA663)]	MC9S08RC8FG@LQFP44
[(SA245A)]	
MC9S08RC8FJ@LQFP32 [(SA663)]	MC9S08RD16CDW@SOIC28
[(SA404)]	
MC9S08RD16CFG@LQFP44 [(SA245A)]	MC9S08RD16CFJ@LQFP32
[(SA663)]	
MC9S08RD16CP	MC9S08RD16DW@SOIC28
[(SA404)]	
MC9S08RD16FG@LQFP44 [(SA245A)]	MC9S08RD16FJ@LQFP32
[(SA663)]	
MC9S08RD16P	MC9S08RD32CDW@SOIC28
[(SA404)]	
MC9S08RD32CFG@LQFP44 [(SA245A)]	MC9S08RD32CFJ@LQFP32
[(SA663)]	
MC9S08RD32CP	MC9S08RD32DW@SOIC28
[(SA404)]	
MC9S08RD32FG@LQFP44 [(SA245A)]	MC9S08RD32FJ@LQFP32
[(SA663)]	
MC9S08RD32P	MC9S08RD60CDW@SOIC28
[(SA404)]	
MC9S08RD60CFG@LQFP44 [(SA245A)]	MC9S08RD60CFJ@LQFP32
[(SA663)]	
MC9S08RD60CP	MC9S08RD60DW@SOIC28
[(SA404)]	
MC9S08RD60FG@LQFP44 [(SA245A)]	MC9S08RD60FJ@LQFP32
[(SA663)]	
MC9S08RD60P	MC9S08RD8CDW@SOIC28
[(SA404)]	
MC9S08RD8CFG@LQFP44 [(SA245A)]	MC9S08RD8CFJ@LQFP32

[ ( SA663 ) ]	
MC9S08RD8CP	MC9S08RD8DW@SOIC28
[ ( SA404 ) ]	
MC9S08RD8FG@LQFP44 [ ( SA245A ) ]	MC9S08RD8FJ@LQFP32
[ ( SA663 ) ]	
MC9S08RD8P	MC9S08RE16CFG@LQFP44
[ ( SA245A ) ]	
MC9S08RE16CFJ@LQFP32 [ ( SA663 ) ]	MC9S08RE16FG@LQFP44
[ ( SA245A ) ]	
MC9S08RE16FJ@LQFP32 [ ( SA663 ) ]	MC9S08RE32CFG@LQFP44
[ ( SA245A ) ]	
MC9S08RE32CFJ@LQFP32 [ ( SA663 ) ]	MC9S08RE32FG@LQFP44
[ ( SA245A ) ]	
MC9S08RE32FJ@LQFP32 [ ( SA663 ) ]	MC9S08RE60CFG@LQFP44
[ ( SA245A ) ]	
MC9S08RE60CFJ@LQFP32 [ ( SA663 ) ]	MC9S08RE60FG@LQFP44
[ ( SA245A ) ]	
MC9S08RE60FJ@LQFP32 [ ( SA663 ) ]	MC9S08RE8CFG@LQFP44
[ ( SA245A ) ]	
MC9S08RE8CFJ@LQFP32 [ ( SA663 ) ]	MC9S08RE8FG@LQFP44
[ ( SA245A ) ]	
MC9S08RE8FJ@LQFP32 [ ( SA663 ) ]	MC9S08RG32CFG@LQFP44
[ ( SA245A ) ]	
MC9S08RG32CFJ@LQFP32 [ ( SA663 ) ]	MC9S08RG32FG@LQFP44
[ ( SA245A ) ]	
MC9S08RG32FJ@LQFP32 [ ( SA663 ) ]	MC9S08RG60CFG@LQFP44
[ ( SA245A ) ]	
MC9S08RG60CFJ@LQFP32 [ ( SA663 ) ]	MC9S08RG60FG@LQFP44
[ ( SA245A ) ]	
MC9S08RG60FJ@LQFP32 [ ( SA663 ) ]	
[ ( SA245A ) ]	
MC9S08SG4CSC@SOIC8 [ ( SA602A+B179 ) ]	
MC9S08SG4CTG@TSSOP16 [ ( SA026+B182 ) ]	
MC9S08SG4MSC@SOIC8 [ ( SA602A+B179 ) ]	
MC9S08SG4MTG@TSSOP16 [ ( SA026+B182 ) ]	
MC9S08SG4VSC@SOIC8 [ ( SA602A+B179 ) ]	
MC9S08SG4VTG@TSSOP16 [ ( SA026+B182 ) ]	
MC9S08SG8CSC@SOIC8 [ ( SA602A+B179 ) ]	
MC9S08SG8CTG@TSSOP16 [ ( SA026+B182 ) ]	
MC9S08SG8MSC@SOIC8 [ ( SA602A+B179 ) ]	
MC9S08SG8MTG@TSSOP16 [ ( SA026+B182 ) ]	
MC9S08SG8VSC@SOIC8 [ ( SA602A+B179 ) ]	
MC9S08SG8VTG@TSSOP16 [ ( SA026+B182 ) ]	
MC9S08SH4CSC@SOIC8 [ ( SA602A+B179 ) ]	

MC9S08SH4CTG@TSSOP16 [(SA026+B182)]  
MC9S08SH4MSC@SOIC8 [(SA602A+B179)]  
MC9S08SH4MTG@TSSOP16 [(SA026+B182)]  
MC9S08SH4VSC@SOIC8 [(SA602A+B179)]  
MC9S08SH4VTG@TSSOP16 [(SA026+B182)]  
MC9S08SH8CSC@SOIC8 [(SA602A+B179)]  
MC9S08SH8CTG@TSSOP16 [(SA026+B182)]  
MC9S08SH8MSC@SOIC8 [(SA602A+B179)]  
MC9S08SH8MTG@TSSOP16 [(SA026+B182)]  
MC9S08SH8VSC@SOIC8 [(SA602A+B179)]  
MC9S08SH8VTG@TSSOP16 [(SA026+B182)]  
MC9S12A128BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A64CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A64FU@TQFP80(\*) [(TA015-B006)]  
MC9S12A64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A64MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12A64PV@TQFP112(\*) [(TA037-B084)]  
MC9S12A64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12A64VPV@TQFP112(\*) [(TA037-B084)]

MC9S12C128CFA@TQFP48 [(SA248)]  
MC9S12C128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C128MFA@TQFP48 [(SA248)]  
MC9S12C128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C128VFA@TQFP48 [(SA248)]  
MC9S12C128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C32CFA16@TQFP48 [(SA248)] MC9S12C32CFA25@TQFP48  
[(SA248)]  
MC9S12C32CFU16@TQFP80(\*) [(TA015-B006)]  
MC9S12C32CFU25@TQFP80(\*) [(TA015-B006)]  
MC9S12C32MFA16@TQFP48 [(SA248)] MC9S12C32MFA25@TQFP48  
[(SA248)]  
MC9S12C32MFU16@TQFP80(\*) [(TA015-B006)]  
MC9S12C32MFU25@TQFP80(\*) [(TA015-B006)]  
MC9S12C32VFA16@TQFP48 [(SA248)] MC9S12C32VFA25@TQFP48  
[(SA248)]  
MC9S12C32VFU16@TQFP80(\*) [(TA015-B006)]  
MC9S12C32VFU25@TQFP80(\*) [(TA015-B006)]  
MC9S12C64CFA@TQFP48 [(SA248)]  
MC9S12C64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C64MFA@TQFP48 [(SA248)]  
MC9S12C64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C64VFA@TQFP48 [(SA248)]  
MC9S12C64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C96CFA@TQFP48 [(SA248)]  
MC9S12C96CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C96MFA@TQFP48 [(SA248)]  
MC9S12C96MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12C96VFA@TQFP48 [(SA248)]  
MC9S12C96VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12D64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12D64CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12D64FU@TQFP80(\*) [(TA015-B006)]  
MC9S12D64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12D64MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12D64PV@TQFP112(\*) [(TA037-B084)]  
MC9S12D64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12D64VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DB128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DB128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DB128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DB128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DB128MPV@TQFP112(\*) [(TA037-B084)]

MC9S12DB128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128ECFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128ECPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128EMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128EMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128EVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128EVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256CVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DG256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DG256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128BVPV@TQFP112(\*) [(TA037-B084)]

MC9S12DJ128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128ECFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128ECPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128EMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128EMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128EVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128EVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256BVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CCFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CMFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256CVFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64FU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64PV@TQFP112(\*) [(TA037-B084)]  
MC9S12DJ64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DJ64VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DP256CMPV@TQFP112(\*) [(TA037-B084)]

MC9S12DP256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128ECPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128EMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128EVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256BVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CCPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DT256CMPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256CVPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DT256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12DT256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12DT256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12E128CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E128MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E128VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E128VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E128VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E128VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E256CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E256MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E256VFU@TQFP80(\*) [(SA722-B239)]

MC9S12E256VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E256VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E256VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E32CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E32CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E32MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E32MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E32VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E32VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64CPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64CPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E64MFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E64MFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64MPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64MPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12E64VFU@TQFP80(\*) [(SA722-B239)]  
MC9S12E64VFUE@TQFP80(\*) [(SA722-B239)]  
MC9S12E64VPV@TQFP112(\*) [(SA719-B241)]  
MC9S12E64VPVE@TQFP112(\*) [(SA719-B241)]  
MC9S12GC128CFA@TQFP48 [(SA248)]  
MC9S12GC128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC128MFA@TQFP48 [(SA248)]  
MC9S12GC128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC128VFA@TQFP48 [(SA248)]  
MC9S12GC128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16CFA@TQFP48 [(SA248)]  
MC9S12GC16CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16MFA@TQFP48 [(SA248)]  
MC9S12GC16MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC16VFA@TQFP48 [(SA248)]  
MC9S12GC16VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32CFA@TQFP48 [(SA248)]  
MC9S12GC32CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32MFA@TQFP48 [(SA248)]  
MC9S12GC32MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC32VFA@TQFP48 [(SA248)]  
MC9S12GC32VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC64CFA@TQFP48 [(SA248)]  
MC9S12GC64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC64MFA@TQFP48 [(SA248)]  
MC9S12GC64MFU@TQFP80(\*) [(TA015-B006)]



MC9S12GC64VFA@TQFP48 [(SA248)]  
MC9S12GC64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96CFA@TQFP48 [(SA248)]  
MC9S12GC96CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96MFA@TQFP48 [(SA248)]  
MC9S12GC96MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12GC96VFA@TQFP48 [(SA248)]  
MC9S12GC96VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12HN64CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HN64VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HN64VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ128VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ128VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ256VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ256VFU@TQFP80(\*) [(SA722-B238)]

MC9S12HZ256VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64CAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64CAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64CFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64CPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64MAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64MAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64MFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64MPV@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64VAA@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64VAL@LQFP112(\*) [(SA719-B240)]  
MC9S12HZ64VFU@TQFP80(\*) [(SA722-B238)]  
MC9S12HZ64VPV@LQFP112(\*) [(SA719-B240)]  
MC9S12NE64CPV@LQFP112(\*) [(SA719-B246)]  
MC9S12NE64CPVE@LQFP112(\*) [(SA719-B246)]  
MC9S12NE64VTU@TQFP80(\*) [(TA048-B006)]  
MC9S12NE64VTUE@TQFP80(\*) [(TA048-B006)]  
MC9S12UF32PB@QFP64(\*) [(SA732+B200)]  
MC9S12UF32PBE@QFP64(\*) [(SA732+B200)]  
MC9S12UF32PU@QFP100(\*) [(SA718+B201)]  
MC9S12XA128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256MFV@LQFP144(\*) [(SA681-B14412)]

MC9S12XA256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA256VFB@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XA512VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XA512VFB@LQFP144(\*) [(SA681-B14412)]  
MC9S12XA512VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256MAL@TQFP112(\*) [(TA037-B084)]

MC9S12XB256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XB256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XB256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XD256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD256VFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XD256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XD64CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XD64VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128CAA@TQFP80(\*) [(TA015-B006)]

MC9S12XDG128CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDG128VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDG128VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDP512VFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDP512VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDQ256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDQ256VFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDQ256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256CAG@LQFP144(\*) [(SA681-B14412)]

MC9S12XDT256CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT256VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT256VFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT256VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384CPU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384MAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384MPU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT384VFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT384VPU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT384VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512CAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512CAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512CAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512CFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512CFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512CPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512MAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512MAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512MAL@TQFP112(\*) [(TA037-B084)]

MC9S12XDT512MFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512MFV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512MPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512VAA@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512VAG@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512VAL@TQFP112(\*) [(TA037-B084)]  
MC9S12XDT512VFU@TQFP80(\*) [(TA015-B006)]  
MC9S12XDT512VJV@LQFP144(\*) [(SA681-B14412)]  
MC9S12XDT512VPV@TQFP112(\*) [(TA037-B084)]  
MC9S12XHZ256CAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ256CAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ256MAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ256MAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ256VAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ256VAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ384CAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ384CAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ384MAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ384MAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ384VAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ384VAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ512CAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ512CAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ512MAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ512MAL@TQFP112(\*) [(SA719-B264)]  
MC9S12XHZ512VAG@LQFP144(\*) [(SA681-B14414)]  
MC9S12XHZ512VAL@TQFP112(\*) [(SA719-B264)]  
MCHC908JW32FAE@LQFP48 [(SA248+B005)]  
MCHC908JW32FC@TQFN48 [(SA696+B006)]  
P912XDG128CAA@TQFP80(\*) [(TA015-B006)]  
P912XDG128CAL@TQFP112(\*) [(TA037-B084)]  
P912XDG128CFU@TQFP80(\*) [(TA015-B006)]  
P912XDG128CPV@TQFP112(\*) [(TA037-B084)]  
P912XDG128MAA@TQFP80(\*) [(TA015-B006)]  
P912XDG128MAL@TQFP112(\*) [(TA037-B084)]  
P912XDG128MFU@TQFP80(\*) [(TA015-B006)]  
P912XDG128MPV@TQFP112(\*) [(TA037-B084)]  
P912XDG128VAA@TQFP80(\*) [(TA015-B006)]  
P912XDG128VAL@TQFP112(\*) [(TA037-B084)]  
P912XDG128VFU@TQFP80(\*) [(TA015-B006)]  
P912XDG128VPV@TQFP112(\*) [(TA037-B084)]  
P9RS08KA1CPC [(SA726+B179)]  
P9RS08KA1CSC@SOIC8 [(SA602A+B179)]

P9RS08KA2CPC [(SA726+B179)]  
P9RS08KA2CSC@SOIC8 [(SA602A+B179)]  
PC56F8011VF AE@QFP32 [(SA663+B005)]  
PC56F8013VF AE@QFP32 [(SA663+B005)]  
PC56F8014VF AE@QFP32 [(SA663+B005)]  
PC68HC908GP32 PC68HC908GP32@SDIP42  
[(SA028)]  
PC68HC908GP32@TQFP44 [(SA675)]  
PC9S12UF32PB@QFP64(\*) [(SA732+B200)]  
PC9S12UF32PBE@QFP64(\*) [(SA732+B200)]  
PC9S12UF32PU@QFP100(\*) [(SA718+B201)]  
PC9S12XF128@QFP112(\*) [(SA719-B253)]  
PC9S12XF128@QFP144(\*) [(SA681-B14411)]  
PC9S12XF128@QFP64(\*) [(SA732-B252)]  
PC9S12XF256@QFP112(\*) [(SA719-B253)]  
PC9S12XF256@QFP144(\*) [(SA681-B14411)]  
PC9S12XF256@QFP64(\*) [(SA732-B252)]  
PC9S12XF384@QFP112(\*) [(SA719-B253)]  
PC9S12XF384@QFP144(\*) [(SA681-B14411)]  
PC9S12XF384@QFP64(\*) [(SA732-B252)]  
PC9S12XF512@QFP112(\*) [(SA719-B253)]  
PC9S12XF512@QFP144(\*) [(SA681-B14411)]  
PC9S12XF512@QFP64(\*) [(SA732-B252)]  
PC9S12XHZ256CAG@LQFP144(\*) [(SA681-B14414)]  
PC9S12XHZ256CAL@TQFP112(\*) [(SA719-B264)]  
PC9S12XHZ256MAG@LQFP144(\*) [(SA681-B14414)]  
PC9S12XHZ256MAL@TQFP112(\*) [(SA719-B264)]  
PC9S12XHZ256VAG@LQFP144(\*) [(SA681-B14414)]  
PC9S12XHZ256VAL@TQFP112(\*) [(SA719-B264)]  
PC9S12XHZ384CAG@LQFP144(\*) [(SA681-B14414)]  
PC9S12XHZ384CAL@TQFP112(\*) [(SA719-B264)]  
PC9S12XHZ384MAG@LQFP144(\*) [(SA681-B14414)]  
PC9S12XHZ384MAL@TQFP112(\*) [(SA719-B264)]  
PC9S12XHZ384VAG@LQFP144(\*) [(SA681-B14414)]  
PC9S12XHZ384VAL@TQFP112(\*) [(SA719-B264)]  
PC9S12XHZ512CAG@LQFP144(\*) [(SA681-B14414)]  
PC9S12XHZ512CAL@TQFP112(\*) [(SA719-B264)]  
PC9S12XHZ512MAG@LQFP144(\*) [(SA681-B14414)]  
PC9S12XHZ512MAL@TQFP112(\*) [(SA719-B264)]  
PC9S12XHZ512VAG@LQFP144(\*) [(SA681-B14414)]  
PC9S12XHZ512VAL@TQFP112(\*) [(SA719-B264)]  
S9S08AW16ACFT@QFN48(\*) [(SA696+B198)]  
S9S08AW16ACLS@QFP44(\*) [(SA245+B4404)]



S9S08AW16AMFT@QFN48(\*) [(SA696+B198)]  
 S9S08AW16AMLS@QFP44(\*) [(SA245+B4404)]  
 S9S08AW16AVFT@QFN48(\*) [(SA696+B198)]  
 S9S08AW16AVLS@QFP44(\*) [(SA245+B4404)]  
 S9S08AW8ACFT@QFN48(\*) [(SA696+B198)]  
 S9S08AW8ACLS@QFP44(\*) [(SA245+B4404)]  
 S9S08AW8AMFT@QFN48(\*) [(SA696+B198)]  
 S9S08AW8AMLS@QFP44(\*) [(SA245+B4404)]  
 S9S08AW8AVFT@QFN48(\*) [(SA696+B198)]  
 S9S08AW8AVLS@QFP44(\*) [(SA245+B4404)]  
 XC68HC711D3 XC68HC711D3@PLCC44  
 [(SA244)]  
 XC68HC711D3@TQFP44 [(SA675)]

## MYSON

### MICROCONTROLLER

CS8954F@PQFP44 [(SA675)] [(SA244)]	CS8954MV@PLCC44
CS8955F@PQFP44 [(SA675)] [(SA248)]	CS8955G@LQFP48
CS8955HF@PQFP44 [(SA675)] [(SA248)]	CS8955HG@LQFP48
CS8955HN [(SA244)]	CS8955HV@PLCC44
CS8955N [(SA244)]	CS8955V@PLCC44
MTV212MN32	
MTV212MN64I	
MTV212MS32@SDIP42 [(SA028)] [(SA028)]	MTV212MS64I@SDIP42
MTV212MV32@PLCC44 [(SA244)] [(SA244)]	MTV212MV64I@PLCC44
MTV230GMF@TQFP44 [(SA245A)] [(SA028)]	MTV230GMS@SDIP42
MTV230GMV@PLCC44 [(SA244)] [(SA245A)]	MTV230MF@TQFP44
MTV230MS@SDIP42 [(SA028)] [(SA244)]	MTV230MV@PLCC44
MTV230PMF@TQFP44 [(SA245A)] [(SA028)]	MTV230PMS@SDIP42

MTV230PMV@PLCC44 [ (SA244) ]                      MTV312MN64 (AG  
VERSION)  
MTV312MN64 (AJ VERSION)  
MTV312MS64 (AG VERSION)@SDIP42 [ (SA028) ]  
MTV312MS64 (AJ VERSION)@SDIP42 [ (SA028) ]  
MTV312MV64 (AG VERSION)@PLCC44 [ (SA244) ]  
MTV312MV64 (AJ VERSION)@PLCC44 [ (SA244) ]  
MTV412MF128@PQFP44 [ (SA245A) ]                      MTV412MS128@SDIP42  
[ (SA028) ]  
MTV412MV128@PLCC44 [ (SA244) ]                      MTV416GMF@TQFP44  
[ (SA675) ]  
MTV416GMG@TQFP48 [ (SA248) ]                      MTV416GMV@PLCC44  
[ (SA244) ]  
MTV416MF@TQFP44 [ (SA675) ]                      MTV416MG@TQFP48  
[ (SA248) ]  
MTV416MV@PLCC44 [ (SA244) ]                      MTV416PMF@TQFP44  
[ (SA675) ]  
MTV416PMG@TQFP48 [ (SA248) ]                      MTV416PMV@PLCC44  
[ (SA244) ]  
MTV512MF (A1 VERSION)@TQFP44 [ (SA245A) ]  
MTV512MF (A3 VERSION)@TQFP44 [ (SA245A) ]  
MTV512MV (A1 VERSION)@PLCC44 [ (SA244) ]  
MTV512MV (A3 VERSION)@PLCC44 [ (SA244) ]

## MYSON-CUSTOMER

### MICROCONTROLLER

MTV416GMV@PLCC44 [ (SA245) ]

## NEC

### E (E) PROM / FRAM / NVRAM

D2716D  
uPD271000  
uPD271000@PLCC32 [ (SA015A1T) ]                      uPD271000@TSOP32  
[ (SA410T) ]  
uPD27128    uPD27128  
(C)

uPD27128(D)	
uPD2716	
uPD27256	uPD27256
(C)	
uPD27256(D)	
uPD27256A	
uPD27256A(C)	uPD27256A
(D)	
uPD2732	
uPD2732A	
uPD27512	
uPD27512ACT	
uPD27512AD	
uPD2764	
uPD2764C	
uPD2764D	
uPD27C1000	uPD27C1000@PLCC32
[ (SA015A1T) ]	
uPD27C1000@TSOP32 [ (SA410T) ]	
uPD27C1000A	
uPD27C1000A@PLCC32 [ (SA015A1T) ]	uPD27C1000A@TSOP32
[ (SA410T) ]	
uPD27C1000AD	uPD27C1000AD@PLCC32
[ (SA015A1T) ]	
uPD27C1000AD@TSOP32 [ (SA410T) ]	
uPD27C1001	
uPD27C1001@PLCC32 [ (SA015A1T) ]	uPD27C1001@TSOP32
[ (SA410T) ]	
uPD27C1001A	uPD27C1001A@PLCC32
[ (SA015A1T) ]	
uPD27C1001A@TSOP32 [ (SA410T) ]	
uPD27C1001D	
uPD27C1001D@PLCC32 [ (SA015A1T) ]	uPD27C1001D@TSOP32
[ (SA410T) ]	
uPD27C1024	
uPD27C1024A	
uPD27C2001	uPD27C2001@PLCC32
[ (SA015A1T) ]	
uPD27C2001@TSOP32 [ (SA410T) ]	
uPD27C2001D	
uPD27C2001D@PLCC32 [ (SA015A1T) ]	uPD27C2001D@TSOP32
[ (SA410T) ]	
uPD27C210	

uPD27C256  
 uPD27C256A  
 uPD27C400  
 uPD27C4001 uPD27C4001@PLCC32  
 [ (SA015A1T) ]  
 uPD27C4001@TSOP32 [ (SA410T) ]  
 uPD27C4096  
 uPD27C512 uPD27C64  
 (C)  
 uPD27C64(D)  
 uPD27C8000  
 uPD27C8001 uPD27C8001@PLCC32  
 [ (SA015A1T) ]  
 uPD27C8001@TSOP32 [ (SA410T) ]  
 uPD28C04  
 uPD28C04@SOIC24 [ (SA404) ]  
 uPD28C05  
 uPD28C05@SOIC24 [ (SA404) ]  
 uPD28C256  
 uPD28C64 uPD28C64@SOIC28  
 [ (SA404) ]  
 uPD29F008CB@TSOP40 [ (SA409T) ] uPD29F008CT@TSOP40  
 [ (SA409T) ]

## DRAM & SRAM

PD4361B PD4361B@SOJ24  
 [ (SA646) ]

## MICROCONTROLLER

uPD78F0138M1GK@TQFP64(\*) [ (SA739+B222) ]  
 uPD78F0138M2GK@TQFP64(\*) [ (SA739+B222) ]  
 uPD78F0138M3GK@TQFP64(\*) [ (SA739+B222) ]  
 uPD78F0138M4GK@TQFP64(\*) [ (SA739+B222) ]  
 uPD78F0138M5GK@TQFP64(\*) [ (SA739+B222) ]  
 uPD78F0138M6GK@TQFP64(\*) [ (SA739+B222) ]  
 uPD78F0500FC@FLGA36 [ (4X4BGA) ] uPD78F0500MC(A)@SSOP30  
 [ (SA689) ]  
 uPD78F0500MC@SSOP30 [ (SA689) ] uPD78F0501FC@FLGA36  
 [ (4X4BGA) ]

uPD78F0501MC(A)@SSOP30 [(SA689)] uPD78F0501MC@SSOP30  
[(SA689)]  
uPD78F0502FC@FLGA36 [(4X4BGA)] uPD78F0502MC(A)@SSOP30  
[(SA689)]  
uPD78F0502MC@SSOP30 [(SA689)] uPD78F0503DFC@FLGA36  
[(4X4BGA)]  
uPD78F0503DMC(A)@SSOP30 [(SA689)] uPD78F0503FC@FLGA36  
uPD78F0503DMC@SSOP30 [(SA689)] uPD78F0503MC@SSOP30  
[(4X4BGA)]  
uPD78F0503MC(A)@SSOP30 [(SA689)] uPD78F0503MC@SSOP30  
[(SA689)]  
uPD78F0511GA(A)@TQFP48 [(SA248)]  
uPD78F0511GA(A2)@TQFP48 [(SA248)]  
uPD78F0511GA@TQFP48 [(SA248)]  
uPD78F0511GB(A)@TQFP44 [(SA245A)]  
uPD78F0511GB(A2)@TQFP44 [(SA245A)]  
uPD78F0511GB@TQFP44 [(SA245A)] uPD78F0511MC@SSOP38  
[(SA689)]  
uPD78F0512GA(A)@TQFP48 [(SA248)]  
uPD78F0512GA(A2)@TQFP48 [(SA248)]  
uPD78F0512GA@TQFP48 [(SA248)]  
uPD78F0512GB(A)@TQFP44 [(SA245A)]  
uPD78F0512GB(A2)@TQFP44 [(SA245A)]  
uPD78F0512GB@TQFP44 [(SA245A)] uPD78F0512MC@SSOP38  
[(SA689)]  
uPD78F0513DGA(A)@TQFP48 [(SA248)]  
uPD78F0513DGA(A2)@TQFP48 [(SA248)]  
uPD78F0513DGA@TQFP48 [(SA248)]  
uPD78F0513DGB(A)@TQFP44 [(SA245A)]  
uPD78F0513DGB(A2)@TQFP44 [(SA245A)]  
uPD78F0513DGB@TQFP44 [(SA245A)] uPD78F0513DMC@SSOP38  
[(SA689)]  
uPD78F0513GA(A)@TQFP48 [(SA248)]  
uPD78F0513GA(A2)@TQFP48 [(SA248)]  
uPD78F0513GA@TQFP48 [(SA248)]  
uPD78F0513GB(A)@TQFP44 [(SA245A)]  
uPD78F0513GB(A2)@TQFP44 [(SA245A)]  
uPD78F0513GB@TQFP44 [(SA245A)] uPD78F0513MC@SSOP38  
[(SA689)]  
uPD78F0514GA(A)@TQFP48 [(SA248)]  
uPD78F0514GA(A2)@TQFP48 [(SA248)]  
uPD78F0514GA@TQFP48 [(SA248)]  
uPD78F0514GB(A)@TQFP44 [(SA245A)]

uPD78F0514GB(A2)@TQFP44 [(SA245A)]  
uPD78F0514GB@TQFP44 [(SA245A)] uPD78F0514MC@SSOP38  
[(SA689)]  
uPD78F0515GA(A)@TQFP48 [(SA248)]  
uPD78F0515GA(A2)@TQFP48 [(SA248)]  
uPD78F0515GA@TQFP48 [(SA248)]  
uPD78F0515GB(A)@TQFP44 [(SA245A)]  
uPD78F0515GB(A2)@TQFP44 [(SA245A)]  
uPD78F0515GB@TQFP44 [(SA245A)] uPD78F0515MC@SSOP38  
[(SA689)]  
uPD78F0546GC(A)@LQFP80(\*) [(SA722+B219)]  
uPD78F0546GC@LQFP80(\*) [(SA722+B219)]  
uPD78F0546GK(A)@LQFP80(\*) [(SA731+B219)]  
uPD78F0546GK@LQFP80(\*) [(SA731+B219)]  
uPD78F0822B(A)@LQFP100(\*) [(SA718+B221)]  
uPD78F0822B@LQFP100(\*) [(SA718+B221)]  
uPD78F9026@SDIP42 [(SA028)] uPD78F9026@TQFP44  
[(SA245A)]  
uPD78F9026A@SDIP42 [(SA028)] uPD78F9026A@TQFP44  
[(SA245A)]  
uPD78F9026B@SDIP42 [(SA028)] uPD78F9026B@TQFP44  
[(SA245A)]  
uPD78F9046@SDIP42 [(SA028)] uPD78F9046@TQFP44  
[(SA245A)]  
uPD78F9046A@SDIP42 [(SA028)] uPD78F9046A@TQFP44  
[(SA245A)]  
uPD78F9046B@SDIP42 [(SA028)] uPD78F9046B@TQFP44  
[(SA245A)]  
uPD78F9076@SSOP30 [(SA689)] uPD78F9076A@SSOP30  
[(SA689)]  
uPD78F9076AMC@SSOP30 [(SA689)] uPD78F9076MC@SSOP30  
[(SA689)]  
uPD78P054FGC@QFP80(\*) [(SA722+B328)]  
uPD78P054FGK@TQFP80(\*) [(SA731+B218)]  
uPD78P054GC@QFP80(\*) [(SA722+B328)]  
uPD78P054GK@TQFP80(\*) [(SA731+B218)]  
uPD78P054YGC@QFP80(\*) [(SA722+B328)]  
uPD78P054YGK@TQFP80(\*) [(SA731+B218)]  
uPD78P058FGC@QFP80(\*) [(SA722+B328)]  
uPD78P058FGK@TQFP80(\*) [(SA731+B218)]  
uPD78P058GC@QFP80(\*) [(SA722+B328)]  
uPD78P058GK@TQFP80(\*) [(SA731+B218)]  
uPD78P058YGC@QFP80(\*) [(SA722+B328)]

uPD78P058YGK@TQFP80(\*) [(SA731+B218)]  
 uPD78P083@SDIP42 [(SA028)] uPD78P083@TQFP44  
 [(SA245A)]  
 uPD78P083A@SDIP42 [(SA028)] uPD78P083A@TQFP44  
 [(SA245A)]  
 uPD78P9014CT@SDIP28 [(SA022A)] uPD78P9014GT@SOIC28  
 [(SA404)]

## NEXFLASH

### E (E) PROM/FRAM/NVRAM

NX25B40(Bottom Boot)@MLP8 [(SA683)]  
 NX25B40(Bottom Boot)@SOIC8 [(SA602A)]  
 NX25B40(Top Boot)@MLP8 [(SA683)]  
 NX25B40(Top Boot)@SOIC8 [(SA602A)]  
 NX25P10@MLP8 [(SA683)] NX25P10@SOIC8  
 [(SA602A)]  
 NX25P16@MLP8 [(SA683)] NX25P16@MLP8(ISP) [ISP-  
 HEADER01]  
 NX25P16@SOIC16 [(SA404)]  
 NX25P16@SOIC16(ISP) [ISP-HEADER01]  
 NX25P16@SOIC8 [(SA023A)]  
 NX25P16@SOIC8(ISP) [ISP-HEADER01]  
 NX25P20@MLP8 [(SA683)] NX25P20@SOIC8  
 [(SA602A)]  
 NX25P32@MLP8 [(SA683)] NX25P32@MLP8(ISP) [ISP-  
 HEADER01]  
 NX25P32@SOIC16 [(SA404)]  
 NX25P32@SOIC16(ISP) [ISP-HEADER01]  
 NX25P40@MLP8 [(SA683)] NX25P40@SOIC8  
 [(SA602A)]  
 NX25P64@MLP8 [(SA683)] NX25P64@MLP8(ISP) [ISP-  
 HEADER01]  
 NX25P64@SOIC16 [(SA404)]  
 NX25P64@SOIC16(ISP) [ISP-HEADER01]  
 NX25P80@MLP8 [(SA683)] NX25P80@SOIC8  
 [(SA602A)]  
 NX29F010 NX29F010@PLCC32  
 [(SA015A1T)]  
 NX29F010@TSOP32 [(SA410T)]

## NJRC

### E ( E ) PROM / FRAM / NVRAM

NJU26040V  
[ ( SA626A ) ]

NJU26040V@SSOP32

## NOVATEK

### MICROCONTROLLER

NT68F631@PLCC44 [ ( SA244 ) ]  
[ ( SA028 ) ]

NT68F631@SDIP42

NT68F631ALG@PLCC44 [ ( SA244 ) ]  
[ ( SA028 ) ]

NT68F631AUG@SDIP42

NT68F631L@PLCC44 [ ( SA244 ) ]  
[ ( SA244 ) ]

NT68F631LG@PLCC44

NT68F631U@SDIP42 [ ( SA028 ) ]  
[ ( SA028 ) ]

NT68F631UG@SDIP42

NT68F632@PLCC44 [ ( SA244 ) ]  
[ ( SA028 ) ]

NT68F632@SDIP42

NT68F632ALG@PLCC44 [ ( SA244 ) ]  
[ ( SA028 ) ]

NT68F632AUG@SDIP42

NT68F632L@PLCC44 [ ( SA244 ) ]  
[ ( SA244 ) ]

NT68F632LG@PLCC44

NT68F632U@SDIP42 [ ( SA028 ) ]  
[ ( SA028 ) ]

NT68F632UG@SDIP42

NT68F633@PLCC44 [ ( SA244 ) ]  
[ ( SA028 ) ]

NT68F633@SDIP42

NT68F633L@PLCC44 [ ( SA244 ) ]  
[ ( SA244 ) ]

NT68F633LG@PLCC44

NT68F633U@SDIP42 [ ( SA028 ) ]  
[ ( SA028 ) ]

NT68F633UG@SDIP42

NT68F636@PLCC44 [ ( SA244 ) ]  
[ ( SA028 ) ]

NT68F636@SDIP42

NT68F636L@PLCC44 [ ( SA244 ) ]  
[ ( SA244 ) ]

NT68F636LG@PLCC44

NT68F636U@SDIP42 [ ( SA028 ) ]  
[ ( SA028 ) ]

NT68F636UG@SDIP42

NT68F63L(0444)@PLCC44 [ ( SA244 ) ]

NT68F63L(0444)@SDIP42



[ (SA028) ]	
NT68F63L(0448)@PLCC44 [ (SA244) ]	NT68F63L(0448)@SDIP42
[ (SA028) ]	
NT68F63L(0523)@PLCC44 [ (SA244) ]	NT68F63L(0523)@SDIP42
[ (SA028) ]	
NT68F63L@PLCC44 [ (SA244) ]	NT68F63LA@PLCC44
[ (SA244) ]	
NT68F63LG@PLCC44 [ (SA244) ]	NT68F63LGG@PLCC44
[ (SA244) ]	
NT68F63U@SDIP42 [ (SA028) ]	NT68F63UA@SDIP42
[ (SA028) ]	
NT68F63UG@SDIP42 [ (SA028) ]	NT68F63UGG@SDIP42
[ (SA028) ]	

## NSC

### E (E) PROM/FRAM/NVRAM

2864	
MM2716	
MM2716E	
NM24C02	
NM24C02@SOIC8 [ (SA602A) ]	NM24C02@TSOP8
[ (SA026) ]	
NM24C02L	NM24C02L@SOIC8
[ (SA602A) ]	
NM24C02L@TSOP8 [ (SA026) ]	
NM24C03	
NM24C03@SOIC8 [ (SA602A) ]	NM24C03@TSOP8
[ (SA026) ]	
NM24C04	NM24C04@SOIC8
[ (SA602A) ]	
NM24C04@TSOP8 [ (SA026) ]	
NM24C05	
NM24C05@SOIC8 [ (SA602A) ]	NM24C05@TSOP8
[ (SA026) ]	
NM24C08	NM24C08@SOIC8
[ (SA602A) ]	
NM24C09	NM24C09@SOIC8
[ (SA602A) ]	
NM24C16	NM24C16@SOIC8
[ (SA602A) ]	

NM24C17	NM24C17@SOIC8
[ (SA602A) ]	
NM25C04	NM25C04@SOIC16
[ (SA602) ]	
NM25C04@SOIC8 [ (SA602A) ]	NM25C04@TSSOP14
[ (SA026) ]	
NM25C04@TSSOP8 [ (SA026) ]	
NM27C010	
NM27C010@PLCC32 [ (SA015A1T) ]	NM27C010@TSOP32
[ (SA410T) ]	
NM27C010Q	NM27C010Q@PLCC32
[ (SA015A1T) ]	
NM27C010Q@TSOP32 [ (SA410T) ]	
NM27C020	
NM27C020@PLCC32 [ (SA015A1T) ]	NM27C020@TSOP32
[ (SA410T) ]	
NM27C020Q	NM27C020Q@PLCC32
[ (SA015A1T) ]	
NM27C020Q@TSOP32 [ (SA410T) ]	
NM27C040	
NM27C040@PLCC32 [ (SA015A1T) ]	NM27C040@TSOP32
[ (SA410T) ]	
NM27C1023	
NM27C128	
NM27C128@PLCC32 [ (SA015A1T) ]	
NM27C210	
NM27C210@PLCC44 [ (SA244) ]	
NM27C210Q	
NM27C210Q@PLCC44 [ (SA244) ]	
NM27C240	
NM27C240@PLCC44 [ (SA244) ]	
NM27C256	
NM27C256@PLCC32 [ (SA015A1T) ]	
NM27C400	
NM27C512	NM27C512@PLCC32
[ (SA015A1T) ]	
NM27C512Q	NM27C512Q@PLCC32
[ (SA015A1T) ]	
NM27C64Q	NM27C64Q@PLCC32
[ (SA015A1T) ]	
NM27CP256	NM27CP256@PLCC32
[ (SA015A1T) ]	
NM27LC010	NM27LC010@PLCC32

[ (SA015A1T) ]	
NM27LC010@TSOP32 [ (SA410T) ]	
NM27LC256	
NM27LC256@PLCC32 [ (SA015A1T) ]	
NM27LC512	
NM27LC512@PLCC32 [ (SA015A1T) ]	
NM27LC64	
NM27LC64@PLCC32 [ (SA015A1T) ]	
NM27LV010	
NM27LV010@PLCC32 [ (SA015A1T) ]	NM27LV010@TSOP32
[ (SA410T) ]	
NM27LV210	NM27LV210@PLCC44
[ (SA244) ]	
NM27LV512	NM27LV512@PLCC32
[ (SA015A1T) ]	
NM27LV512@TSOP32 [ (SA410T) ]	
NM27P040	
NM27P040@PLCC32 [ (SA015A1T) ]	NM27P040@TSOP32
[ (SA410T) ]	
NM27P210	NM27P210@PLCC44
[ (SA244) ]	
NM27P512	NM27P512@PLCC32
[ (SA015A1T) ]	
NM59C11	NM59C11@SOIC8
[ (SA602A) ]	
NM93C06(08bit)	NM93C06(08bit)@SOIC8
[ (SA602A) ]	
NM93C06(16bit)	NM93C06(16bit)@SOIC8
[ (SA602A) ]	
NM93C46	NM93C46@SOIC8
[ (SA602A) ]	
NM93C46A(08bit)	NM93C46A(08bit)@SOIC8
[ (SA602A) ]	
NM93C46A(16bit)	NM93C46A(16bit)@SOIC8
[ (SA602A) ]	
NM93C46AL(08bit)	
NM93C46AL(08bit)@SOIC8 [ (SA602A) ]	
NM93C46AL(16bit)	
NM93C46AL(16bit)@SOIC8 [ (SA602A) ]	
NM93C46ALZ(08bit)	
NM93C46ALZ(08bit)@SOIC8 [ (SA602A) ]	
NM93C46ALZ(16bit)	
NM93C46ALZ(16bit)@SOIC8 [ (SA602A) ]	

NM93C46L	NM93C46L@SOIC8
[ (SA602A) ]	
NM93C46LZ	NM93C46LZ@SOIC8
[ (SA602A) ]	
NM93C56	NM93C56@SOIC8
[ (SA602A) ]	
NM93C56A(08bit)	NM93C56A(08bit)@SOIC8
[ (SA602A) ]	
NM93C56A(16bit)	NM93C56A(16bit)@SOIC8
[ (SA602A) ]	
NM93C56AL(08bit)	
NM93C56AL(08bit)@SOIC8 [ (SA602A) ]	
NM93C56AL(16bit)	
NM93C56AL(16bit)@SOIC8 [ (SA602A) ]	
NM93C56ALZ(08bit)	
NM93C56ALZ(08bit)@SOIC8 [ (SA602A) ]	
NM93C56ALZ(16bit)	
NM93C56ALZ(16bit)@SOIC8 [ (SA602A) ]	
NM93C56L	NM93C56L@SOIC8
[ (SA602A) ]	
NM93C56LZ	NM93C56LZ@SOIC8
[ (SA602A) ]	
NM93C66	NM93C66@SOIC8
[ (SA602A) ]	
NM93C66A	NM93C66A
(08bit)	
NM93C66A(08bit)@SOIC8 [ (SA602A) ]	NM93C66A@SOIC8
[ (SA602A) ]	
NM93C66AL(08bit)	
NM93C66AL(08bit)@SOIC8 [ (SA602A) ]	
NM93C66AL(16bit)	
NM93C66AL(16bit)@SOIC8 [ (SA602A) ]	
NM93C66ALZ(08bit)	
NM93C66ALZ(08bit)@SOIC8 [ (SA602A) ]	
NM93C66ALZ(16bit)	
NM93C66ALZ(16bit)@SOIC8 [ (SA602A) ]	
NM93C66L	NM93C66L@SOIC8
[ (SA602A) ]	
NM93C66LZ	NM93C66LZ@SOIC8
[ (SA602A) ]	
NM93C86(16bit)	NM93C86(16bit)@SOIC8
[ (SA602A) ]	
NM93C86A	NM93C86A

(08bit)

NM93C86A(08bit)@SOIC8 [(SA602A)]  
[(SA602A)]

NM93C86A@SOIC8

NM93C86AL(08bit)

NM93C86AL(08bit)@SOIC8 [(SA602A)]

NM93C86AL(16bit)

NM93C86AL(16bit)@SOIC8 [(SA602A)]

NM93C86ALZ(08bit)

NM93C86ALZ(08bit)@SOIC8 [(SA602A)]

NM93C86ALZ(16bit)

NM93C86ALZ(16bit)@SOIC8 [(SA602A)]

NM93C86L

NM93C86L@SOIC8

[(SA602A)]

NM93C86LZ

NM93C86LZ@SOIC8

[(SA602A)]

NM93CS06(M8)@SOIC8 [(SA602A)]

NM93CS06(MT8)@TSSOP8

[(SA026)]

NM93CS06(N)

NM93CS46(M8)@SOIC8

[(SA602A)]

NM93CS46(MT8)@TSSOP8 [(SA026)]

NM93CS46

(N)

NM93CS56(M8)@SOIC8 [(SA602A)]

NM93CS56(MT8)@TSSOP8

[(SA026)]

NM93CS56(N)

NM93CS66(M8)@SOIC8

[(SA602A)]

NM93CS66(MT8)@TSSOP8 [(SA026)]

NM93CS66

(N)

NMC2732

NMC2732B

NMC2732H

NMC27C010

NMC27C010@PLCC32 [(SA015A1T)]

NMC27C010@TSOP32

[(SA410T)]

NMC27C1024

NMC27C1024@PLCC44

[(SA244)]

NMC27C128B

NMC27C128B@PLCC32

[(SA015A1T)]

NMC27C128BN

NMC27C128BN@PLCC32

[(SA015A1T)]

NMC27C128BQ

NMC27C128BQ@PLCC32

[(SA015A1T)]

NMC27C128CQ

NMC27C128Q

NMC27C16  
NMC27C16BQ  
NMC27C16BQE  
NMC27C16H  
NMC27C16HQ  
NMC27C16Q  
NMC27C210 NMC27C210@PLCC44  
[ ( SA244 ) ]  
NMC27C210Q NMC27C210Q@PLCC44  
[ ( SA244 ) ]  
NMC27C256B NMC27C256B@PLCC32  
[ ( SA015A1T ) ]  
NMC27C256BN  
NMC27C256BQE  
NMC27C256BQM  
NMC27C256Q  
NMC27C256Q@PLCC32 [ ( SA015A1T ) ]  
NMC27C32  
NMC27C32B  
NMC27C32BQ  
NMC27C32E  
NMC27C32EH  
NMC27C32H  
NMC27C512  
NMC27C512@PLCC32 [ ( SA015A1T ) ]  
NMC27C512A  
NMC27C512A@PLCC32 [ ( SA015A1T ) ]  
NMC27C512AN  
NMC27C512AN@PLCC32 [ ( SA015A1T ) ]  
NMC27C64  
NMC27C64@PLCC32 [ ( SA015A1T ) ]  
NMC27C64BN  
NMC27C64N  
NMC27CP128  
NMC27CP256  
NMC27CP64  
NMC59C11 NMC59C11@SOIC8  
[ ( SA602A ) ]  
NMC87C257Q  
NMC87C257Q@PLCC32  
NMC87C257V  
NMC87C257V@PLCC32  
NMC9306 NMC9306@SOIC8

[ ( SA602A ) ]	
NMC9307	NMC9307@SOIC8
[ ( SA602A ) ]	
NMC9346	NMC9346@SOIC8
[ ( SA602A ) ]	
NMC93C56	NMC93C56@SOIC14
[ ( SA602 ) ]	
NMC93C56@SOIC8 [ ( SA602A ) ]	
NMC93C66	
NMC93C66@SOIC14 [ ( SA602 ) ]	
NMC93C86A	
NMC93C86A@SOIC14 [ ( SA602 ) ]	NMC93C86A@SOIC8
[ ( SA602A ) ]	
NMC93CS06 ( M14 ) @SOIC14 [ ( SA602 ) ]	NMC93CS06
( N )	
NMC93CS46 ( M14 ) @SOIC14 [ ( SA602 ) ]	NMC93CS46
( N )	
NMC93CS56 ( M14 ) @SOIC14 [ ( SA602 ) ]	NMC93CS56
( N )	
NMC93CS66 ( M14 ) @SOIC14 [ ( SA602 ) ]	NMC93CS66
( N )	
NMC93S06 ( M14 ) @SOIC14 [ ( SA602 ) ]	NMC93S06
( N )	
NMC9817	
NMC9817A	
NS2816A	
NS9816A	

## PLD

GAL16V8	GAL16V8@PLCC20
[ ( SA001A ) ]	
GAL16V8A	GAL16V8A@PLCC20
[ ( SA001A ) ]	
GAL20V8	GAL20V8@PLCC28
[ ( SA008A ) ]	
GAL20V8A	GAL20V8A@PLCC28
[ ( SA008A ) ]	
GAL20V8QS	GAL20V8QS@PLCC28
[ ( SA008A ) ]	

## NTE

### E ( E ) PROM / FRAM / NVRAM

NTE2532  
NTE2532A  
NTE25L32

## NUMONYX

### E ( E ) PROM / FRAM / NVRAM

M25PX32@SOIC16 [ ( SA404 ) ] [ ( SA023A ) ]	M25PX32@SOIC8
M25PX32@VFQFPN8 [ ( SA683 ) ] [ ( SA404 ) ]	M25PX64@SOIC16
M25PX64@VDFPN8 [ ( SA684 ) ]	

## NXP

### MICROCONTROLLER

LPC2101FBD48@LQFP48 ( \* ) [ ( SA248-B4801 ) ]  
LPC2102FBD48@LQFP48 ( \* ) [ ( SA248-B4801 ) ]  
LPC2103FA44@PLCC44 ( \* ) [ ( SA244-B4403 ) ]  
LPC2103FBD48@LQFP48 ( \* ) [ ( SA248-B4801 ) ]  
LPC2104BBD48@LQFP48 ( \* ) [ ( SA248-B4801 ) ]  
LPC2105BBD48@LQFP48 ( \* ) [ ( SA248-B4801 ) ]  
LPC2106BBD48@LQFP48 ( \* ) [ ( SA248-B4801 ) ]  
LPC2114FBD64@LQFP64 ( \* ) [ ( TA027-B4801 ) ]  
LPC2119FBD64@LQFP64 ( \* ) [ ( TA027-B4801 ) ]  
LPC2124FBD64@LQFP64 ( \* ) [ ( TA027-B4801 ) ]  
LPC2129FBD64@LQFP64 ( \* ) [ ( TA027-B4801 ) ]  
LPC2131FBD64@LQFP64 ( \* ) [ ( TA027-B4801 ) ]  
LPC2131FBD64@LQFP64 ( \*\* ) [ ( SA732-B330 ) ]  
LPC2132FBD64@LQFP64 ( \* ) [ ( TA027-B4801 ) ]  
LPC2132FBD64@LQFP64 ( \*\* ) [ ( SA732-B330 ) ]  
LPC2134FBD64@LQFP64 ( \* ) [ ( TA027-B4801 ) ]  
LPC2134FBD64@LQFP64 ( \*\* ) [ ( SA732-B330 ) ]  
LPC2136FBD64@LQFP64 ( \* ) [ ( TA027-B4801 ) ]



LPC2136FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2138FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2138FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2141FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2142FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2144FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2146FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2148FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2194HBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2212HBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2214FBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2292HBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2294HBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2364@LQFP100(\*) [(SA718+B243)]  
 LPC2366@LQFP100(\*) [(SA718+B243)]  
 LPC2368@LQFP100(\*) [(SA718+B243)]  
 P83C660X2@PLCC44 [(SA244)] P83C660X2@TQFP44  
 [(SA245A)]  
 P83C661X2@PLCC44 [(SA244)] P83C661X2@TQFP44  
 [(SA245A)]  
 P87C51 P87C51@PLCC44  
 [(SA244)]  
 P87C51@TQFP44 [(SA245A)]  
 P87C51FA P87C51FA@TQFP44  
 P87C51FA@PLCC44 [(SA244)]  
 [(SA245A)]  
 P87C51FB P87C51FB@PLCC44  
 [(SA244)]  
 P87C51FB@TQFP44 [(SA245A)]  
 P87C51FC P87C51FC@TQFP44  
 P87C51FC@PLCC44 [(SA244)]  
 [(SA245A)]  
 P87C51MA2@PLCC44 [(SA244)] P87C51MB2@PLCC44  
 [(SA244)]  
 P87C51MC2@PLCC44 [(SA244)] P87C51RA  
 +  
 P87C51RA+@PLCC44 [(SA244)] P87C51RA+@TQFP44  
 [(SA245A)]  
 P87C51RA2 P87C51RA2@PLCC44  
 [(SA244)]  
 P87C51RA2@TQFP44 [(SA245A)] P87C51RB  
 +  
 P87C51RB+@PLCC44 [(SA244)] P87C51RB+@TQFP44

[ (SA245A) ]	
P87C51RB2	P87C51RB2@PLCC44
[ (SA244) ]	
P87C51RB2@TQFP44 [ (SA245A) ]	P87C51RC
+	
P87C51RC+@PLCC44 [ (SA244) ]	P87C51RC+@TQFP44
[ (SA245A) ]	
P87C51RC2	P87C51RC2@PLCC44
[ (SA244) ]	
P87C51RC2@TQFP44 [ (SA245A) ]	P87C51RD
+	
P87C51RD+@PLCC44 [ (SA244) ]	P87C51RD+@TQFP44
[ (SA245A) ]	
P87C51RD2	P87C51RD2@PLCC44
[ (SA244) ]	
P87C51RD2@TQFP44 [ (SA245A) ]	
P87C51SB	
P87C51SB@PLCC44 [ (SA244) ]	P87C51SB@TQFP44
[ (SA245A) ]	
P87C51SF	P87C51SF@PLCC44
[ (SA244) ]	
P87C51SF@TQFP44 [ (SA245A) ]	
P87C51UB	
P87C51UB@PLCC44 [ (SA244) ]	P87C51UB@TQFP44
[ (SA245A) ]	
P87C51UF	P87C51UF@PLCC44
[ (SA244) ]	
P87C51UF@TQFP44 [ (SA245A) ]	
P87C51X2	
P87C51X2@PLCC44 [ (SA244) ]	P87C51X2@TQFP44
[ (SA245A) ]	
P87C52	P87C52@PLCC44
[ (SA244) ]	
P87C52@TQFP44 [ (SA245A) ]	
P87C524	
P87C524@PLCC44 [ (SA244) ]	P87C524@TQFP44
[ (SA245A) ]	
P87C528	P87C528@PLCC44
[ (SA244) ]	
P87C528@TQFP44 [ (SA245A) ]	
P87C52SB	
P87C52SB@PLCC44 [ (SA244) ]	P87C52SB@TQFP44
[ (SA245A) ]	

P87C52SF [ (SA244) ]	P87C52SF@PLCC44
P87C52SF@TQFP44 [ (SA675) ]	
P87C52UB P87C52UB@PLCC44 [ (SA244) ] [ (SA245A) ]	P87C52UB@TQFP44
P87C52UF [ (SA244) ]	P87C52UF@PLCC44
P87C52UF@TQFP44 [ (SA245A) ]	
P87C52X2 P87C52X2@PLCC44 [ (SA244) ] [ (SA245A) ]	P87C52X2@TQFP44
P87C54 [ (SA244) ]	P87C54@PLCC44
P87C54@TQFP44 [ (SA245A) ]	
P87C54SB P87C54SB@PLCC44 [ (SA244) ] [ (SA245A) ]	P87C54SB@TQFP44
P87C54SF [ (SA244) ]	P87C54SF@PLCC44
P87C54SF@TQFP44 [ (SA245A) ]	
P87C54UB P87C54UB@PLCC44 [ (SA244) ] [ (SA245A) ]	P87C54UB@TQFP44
P87C54UF [ (SA244) ]	P87C54UF@PLCC44
P87C54UF@TQFP44 [ (SA245A) ]	
P87C54X2 P87C54X2@PLCC44 [ (SA244) ] [ (SA245A) ]	P87C54X2@TQFP44
P87C550 [ (SA244) ]	P87C550@PLCC44
P87C552@PLCC68 ( * ) [ (SA648-B6806) ]	
P87C554@PLCC68 ( * ) [ (SA648-B6806) ]	
P87C575 [ (SA244) ]	P87C575@PLCC44
P87C575@TQFP44 [ (SA245A) ]	
P87C576 P87C576@PLCC44 [ (SA244) ] [ (SA245A) ]	P87C576@TQFP44
P87C58 [ (SA244) ]	P87C58@PLCC44
P87C58@TQFP44 [ (SA245A) ]	

P87C58SB

P87C58SB@PLCC44 [(SA244)]

[(SA245A)]

P87C58UB

[(SA244)]

P87C58UB@TQFP44 [(SA245A)]

P87C58X2

P87C58X2@PLCC44 [(SA244)]

[(SA245A)]

P87C591@PLCC44 [(SA244)]

[(SA245A)]

P87C652

[(SA244)]

P87C652@TQFP44 [(SA245A)]

P87C654

P87C654@PLCC44 [(SA244)]

[(SA245A)]

P87C660X2@PLCC44 [(SA244)]

[(SA245A)]

P87C661X2@PLCC44 [(SA244)]

[(SA245A)]

P87C748

[(SA008A)]

P87C749

[(SA008A)]

P87C750

[(SA008A)]

P87C750@SSOP24 [(SA626A)]

P87C751

P87C751@PLCC28 [(SA008A)]

[(SA626A)]

P87C752

[(SA008A)]

P87C752@SSOP28 [(SA626A)]

P87C754

P87C754@PLCC28 [(SA008A)]

[(SA626A)]

P87CL52X2

[(SA244)]

P87CL52X2@TQFP44 [(SA245A)]

P87CL54X2

P87CL54X2@PLCC44 [(SA244)]

[(SA245A)]

P87C58SB@TQFP44

P87C58UB@PLCC44

P87C58X2@TQFP44

P87C591@TQFP44

P87C652@PLCC44

P87C654@TQFP44

P87C660X2@TQFP44

P87C661X2@TQFP44

P87C748@PLCC28

P87C749@PLCC28

P87C750@PLCC28

P87C751@SSOP24

P87C752@PLCC28

P87C754@SSOP28

P87CL52X2@PLCC44

P87CL54X2@TQFP44

P87L51FA P87L51FA@PLCC44  
[ (SA244) ]  
P87L51FA@TQFP44 [ (SA245A) ]  
P87L51FB P87L51FB@TQFP44  
P87L51FB@PLCC44 [ (SA244) ]  
[ (SA245A) ]  
P87LPC759 P87LPC759 (ISP) [ ISP-  
HEADER01 ]  
P87LPC760 P87LPC760 (ISP) [ ISP-  
HEADER01 ]  
P87LPC760@TSSOP14 [ (SA026) ]  
P87LPC760@TSSOP14 (ISP) [ ISP-HEADER01 ]  
P87LPC761 P87LPC761 (ISP) [ ISP-  
HEADER01 ]  
P87LPC762 P87LPC762 (ISP) [ ISP-  
HEADER01 ]  
P87LPC762@PLCC44 [ (SA244) ]  
P87LPC762@PLCC44 (ISP) [ ISP-HEADER01 ]  
P87LPC762@SOIC20 [ (SA404) ]  
P87LPC762@SOIC20 (ISP) [ ISP-HEADER01 ]  
P87LPC764 P87LPC764 (ISP) [ ISP-  
HEADER01 ]  
P87LPC764@PLCC44 [ (SA244) ]  
P87LPC764@PLCC44 (ISP) [ ISP-HEADER01 ]  
P87LPC764@SOIC20 [ (SA404) ]  
P87LPC764@SOIC20 (ISP) [ ISP-HEADER01 ]  
P87LPC764@TSSOP20 [ (SA643) ]  
P87LPC764@TSSOP20 (ISP) [ ISP-HEADER01 ]  
P87LPC767 P87LPC767 (ISP) [ ISP-  
HEADER01 ]  
P87LPC767@PLCC44 [ (SA244) ]  
P87LPC767@PLCC44 (ISP) [ ISP-HEADER01 ]  
P87LPC767@SOIC20 [ (SA404) ]  
P87LPC767@SOIC20 (ISP) [ ISP-HEADER01 ]  
P87LPC768 P87LPC768 (ISP) [ ISP-  
HEADER01 ]  
P87LPC768@SOIC20 [ (SA404) ]  
P87LPC768@SOIC20 (ISP) [ ISP-HEADER01 ]  
P87LPC769 P87LPC769 (ISP) [ ISP-  
HEADER01 ]  
P87LPC769@PLCC44 [ (SA244) ]  
P87LPC769@PLCC44 (ISP) [ ISP-HEADER01 ]  
P87LPC769@SOIC20 [ (SA404) ]

P87LPC769@SOIC20 (ISP) [ISP-HEADER01]  
 P87LPC778 P87LPC778 (ISP) [ISP-  
 HEADER01]  
 P87LPC778@TSSOP20 [(SA026)]  
 P87LPC778@TSSOP20 (ISP) [ISP-HEADER01]  
 P87LPC779 P87LPC779 (ISP) [ISP-  
 HEADER01]  
 P87LPC779@TSSOP20 [(SA643)]  
 P87LPC779@TSSOP20 (ISP) [ISP-HEADER01]  
 P89C138 P89C138@PLCC44  
 [(SA244)]  
 P89C138@TQFP44 [(SA245A)]  
 P89C238 P89C238@TQFP44  
 P89C238@PLCC44 [(SA244)]  
 [(SA245A)]  
 P89C51B P89C51B@PLCC44  
 [(SA244)]  
 P89C51B@TQFP44 [(SA245A)]  
 + P89C51RA  
 P89C51RA+@PLCC44 [(SA244)] P89C51RA+@TQFP44  
 [(SA245A)]  
 P89C51RA2B P89C51RA2B@PLCC44  
 [(SA244)]  
 P89C51RA2B@TQFP44 [(SA245A)]  
 + P89C51RB  
 P89C51RB+@PLCC44 [(SA244)] P89C51RB+@TQFP44  
 [(SA245A)]  
 P89C51RB2B P89C51RB2B@PLCC44  
 [(SA244)]  
 P89C51RB2B@TQFP44 [(SA245A)]  
 P89C51RB2H P89C51RB2H@TQFP44  
 P89C51RB2H@PLCC44 [(SA244)]  
 [(SA245A)]  
 P89C51RC+ P89C51RC+@PLCC44  
 [(SA244)]  
 P89C51RC+@TQFP44 [(SA245A)]  
 P89C51RC2B P89C51RC2B@TQFP44  
 P89C51RC2B@PLCC44 [(SA244)]  
 [(SA245A)]  
 P89C51RC2H P89C51RC2H@PLCC44  
 [(SA244)]  
 P89C51RC2H@TQFP44 [(SA245A)]  
 + P89C51RD

P89C51RD+@PLCC44 [(SA244)]	P89C51RD+@TQFP44
[(SA245A)]	
P89C51RD2B	P89C51RD2B@PLCC44
[(SA244)]	
P89C51RD2B@TQFP44 [(SA245A)]	
P89C51RD2H	
P89C51RD2H@PLCC44 [(SA244)]	P89C51RD2H@TQFP44
[(SA245A)]	
P89C51UB	P89C51UB@PLCC44
[(SA244)]	
P89C51UB@TQFP44 [(SA245A)]	
P89C51UF	
P89C51UF@PLCC44 [(SA244)]	P89C51UF@TQFP44
[(SA245A)]	
P89C51X2	P89C51X2@PLCC44
[(SA244)]	
P89C51X2@TQFP44 [(SA245A)]	
P89C51X2B	
P89C51X2B@PLCC44 [(SA244)]	P89C51X2B@TQFP44
[(SA245A)]	
P89C51X2F	P89C51X2F@PLCC44
[(SA244)]	
P89C51X2F@TQFP44 [(SA245A)]	
P89C52	
P89C52@PLCC44 [(SA244)]	P89C52@TQFP44
[(SA245A)]	
P89C52B	P89C52B@PLCC44
[(SA244)]	
P89C52B@TQFP44 [(SA245A)]	
P89C52UB	
P89C52UB@PLCC44 [(SA244)]	P89C52UB@TQFP44
[(SA245A)]	
P89C52UF	P89C52UF@PLCC44
[(SA244)]	
P89C52UF@TQFP44 [(SA245A)]	
P89C52X2	
P89C52X2@PLCC44 [(SA244)]	P89C52X2@TQFP44
[(SA245A)]	
P89C52X2B	P89C52X2B@PLCC44
[(SA244)]	
P89C52X2B@TQFP44 [(SA245A)]	
P89C52X2F	
P89C52X2F@PLCC44 [(SA244)]	P89C52X2F@TQFP44

[ ( SA245A ) ]	
P89C536@PLCC44 [ ( SA244 ) ]	P89C538@PLCC44
[ ( SA244 ) ]	
P89C54	P89C54@PLCC44
[ ( SA244 ) ]	
P89C54@TQFP44 [ ( SA245A ) ]	
P89C54B	
P89C54B@PLCC44 [ ( SA244 ) ]	P89C54B@TQFP44
[ ( SA245A ) ]	
P89C54UB	P89C54UB@PLCC44
[ ( SA244 ) ]	
P89C54UB@TQFP44 [ ( SA245A ) ]	
P89C54UF	
P89C54UF@PLCC44 [ ( SA244 ) ]	P89C54UF@TQFP44
[ ( SA245A ) ]	
P89C54X2	P89C54X2@PLCC44
[ ( SA244 ) ]	
P89C54X2@TQFP44 [ ( SA245A ) ]	
P89C54X2B	
P89C54X2B@PLCC44 [ ( SA244 ) ]	P89C54X2B@TQFP44
[ ( SA245A ) ]	
P89C54X2F	P89C54X2F@PLCC44
[ ( SA244 ) ]	
P89C54X2F@TQFP44 [ ( SA245A ) ]	
P89C58	
P89C58@PLCC44 [ ( SA244 ) ]	P89C58@TQFP44
[ ( SA245A ) ]	
P89C58B	P89C58B@PLCC44
[ ( SA244 ) ]	
P89C58B@TQFP44 [ ( SA245A ) ]	
P89C58UB	
P89C58UB@PLCC44 [ ( SA244 ) ]	P89C58UB@TQFP44
[ ( SA245A ) ]	
P89C58UF	P89C58UF@PLCC44
[ ( SA244 ) ]	
P89C58UF@TQFP44 [ ( SA245A ) ]	
P89C58X2	
P89C58X2@PLCC44 [ ( SA244 ) ]	P89C58X2@TQFP44
[ ( SA245A ) ]	
P89C58X2B	P89C58X2B@PLCC44
[ ( SA244 ) ]	
P89C58X2B@TQFP44 [ ( SA245A ) ]	
P89C58X2F	



P89C58X2F@PLCC44 [(SA244)]  
[(SA245A)]  
P89C60X2  
[(SA244)]  
P89C60X2@TQFP44 [(SA245A)]  
P89C61X2  
P89C61X2@PLCC44 [(SA244)]  
[(SA245A)]  
P89C660  
[(SA244)]  
P89C660@TQFP44 [(SA245A)]  
P89C662  
P89C662@PLCC44 [(SA244)]  
[(SA245A)]  
P89C664  
[(SA244)]  
P89C664@TQFP44 [(SA245A)]  
P89C668  
P89C668@PLCC44 [(SA244)]  
[(SA245A)]  
P89C669  
[(SA245A)]  
P89C669@PLCC44 [(SA244)]  
P89C738  
P89C738@PLCC44 [(SA244)]  
[(SA245A)]  
P89C838  
[(SA244)]  
P89C838@TQFP44 [(SA245A)]  
[(SA244)]  
P89CV51RB2@TQFP44 [(SA245A)]  
[(SA244)]  
P89CV51RC2@TQFP44 [(SA245A)]  
[(SA244)]  
P89CV51RD2@TQFP44 [(SA245A)]  
[(SA602A)]  
P89LPC901(FD)(ISP) [ISP-HEADER01]  
P89LPC901(FN)  
P89LPC901(FN)(ISP) [ISP-HEADER01]  
P89LPC902(FD) [(SA602A)]  
P89LPC902(FD)(ISP) [ISP-HEADER01]  
P89LPC902(FN)  
P89LPC902(FN)(ISP) [ISP-HEADER01]

P89C58X2F@TQFP44  
  
P89C60X2@PLCC44  
  
P89C61X2@TQFP44  
  
P89C660@PLCC44  
  
P89C662@TQFP44  
  
P89C664@PLCC44  
  
P89C668@TQFP44  
  
P89C669@LQFP44  
  
P89C738@TQFP44  
  
P89C838@PLCC44  
  
P89CV51RB2@PLCC44  
  
P89CV51RC2@PLCC44  
  
P89CV51RD2@PLCC44  
  
P89LPC901(FD)

P89LPC903(FD) [(SA602A)]  
P89LPC903(FD)(ISP) [ISP-HEADER01]  
P89LPC904(FD) [(SA605A)]  
P89LPC904(FD)(ISP) [ISP-HEADER01]  
P89LPC904(FN)  
P89LPC904(FN)(ISP) [ISP-HEADER01]  
P89LPC906(FD) [(SA605A)]  
P89LPC906(FD)(ISP) [ISP-HEADER01]  
P89LPC907(FD) [(SA605A)]  
P89LPC907(FD)(ISP) [ISP-HEADER01]  
P89LPC908(FD) [(SA605A)]  
P89LPC908(FD)(ISP) [ISP-HEADER01]  
P89LPC9102(FTK)@HVSON10 [(SA695A)]  
P89LPC9102(FTK)@HVSON10(ISP) [ISP-HEADER01]  
P89LPC9103(FTK)@HVSON10 [(SA695A)]  
P89LPC9103(FTK)@HVSON10(ISP) [ISP-HEADER01]  
P89LPC9107(FDH)@TSSOP14 [(SA643)]  
P89LPC9107(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC9107(FN)  
P89LPC9107(FN)(ISP) [ISP-HEADER01]  
P89LPC912(FDH)@TSSOP14 [(SA643)]  
P89LPC912(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC913(FDH)@TSSOP14 [(SA643)]  
P89LPC913(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC914(FDH)@TSSOP14 [(SA643)]  
P89LPC914(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC915(FDH)@TSSOP14 [(SA643)]  
P89LPC915(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC916(FDH)@TSSOP16 [(SA643)]  
P89LPC916(FDH)@TSSOP16(ISP) [ISP-HEADER01]  
P89LPC917(FDH)@TSSOP16 [(SA643)]  
P89LPC917(FDH)@TSSOP16(ISP) [ISP-HEADER01]  
P89LPC920(FDH)@TSSOP20 [(SA643)]  
P89LPC920(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC920(FN)  
P89LPC920(FN)(ISP) [ISP-HEADER01]  
P89LPC921(FDH)@TSSOP20 [(SA643)]  
P89LPC921(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC921(FN)  
P89LPC921(FN)(ISP) [ISP-HEADER01]  
P89LPC922(FDH)@TSSOP20 [(SA643)]  
P89LPC922(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC922(FN)

P89LPC922(FN)(ISP) [ISP-HEADER01]  
P89LPC9221(FDH)@TSSOP20 [(SA643)]  
P89LPC9221(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC9221(FN)  
P89LPC9221(FN)(ISP) [ISP-HEADER01]  
P89LPC924(FDH)@TSSOP20 [(SA643)]  
P89LPC924(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC924(FN)  
P89LPC924(FN)(ISP) [ISP-HEADER01]  
P89LPC925(FDH)@TSSOP20 [(SA643)]  
P89LPC925(FDH)@TSSOP20(ISP) [ISP-HEADER01]  
P89LPC925(FN)  
P89LPC925(FN)(ISP) [ISP-HEADER01]  
P89LPC930(BA)@PLCC28 [(SA008A)]  
P89LPC930(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC930(BDH)@TSSOP28 [(SA643)]  
P89LPC930(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC931(BA)@PLCC28 [(SA008A)]  
P89LPC931(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC931(BDH)@TSSOP28 [(SA643)]  
P89LPC931(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932(BA)@PLCC28 [(SA008A)] P89LPC932(BDH)@TSSOP28  
[(SA643)]  
P89LPC932A1(BA)@PLCC28 [(SA008A)]  
P89LPC932A1(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC932A1(BDH)@TSSOP28 [(SA643)]  
P89LPC932A1(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932A1(FDH)@TSSOP28 [(SA643)]  
P89LPC932A1(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC932A1(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC932A1(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC933(BDH)@TSSOP28 [(SA643)]  
P89LPC933(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC933(FDH)@TSSOP28 [(SA643)]  
P89LPC933(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC934(BDH)@TSSOP28 [(SA643)]  
P89LPC934(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC934(FDH)@TSSOP28 [(SA643)]  
P89LPC934(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(BA)@PLCC28 [(SA008A)]  
P89LPC935(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(BDH)@TSSOP28 [(SA643)]  
P89LPC935(BDH)@TSSOP28(ISP) [ISP-HEADER01]

P89LPC935(FA)@PLCC28 [(SA008A)]  
P89LPC935(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(FDH)@TSSOP28 [(SA643)]  
P89LPC935(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC935(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93501(BA)@PLCC28 [(SA008A)]  
P89LPC93501(BDH)@TSSOP28 [(SA643)]  
P89LPC93501(FA)@PLCC28 [(SA008A)]  
P89LPC93501(FDH)@TSSOP28 [(SA643)]  
P89LPC93501(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9351(BA)@PLCC28 [(SA008A)]  
P89LPC9351(BDH)@TSSOP28 [(SA643)]  
P89LPC9351(FA)@PLCC28 [(SA008A)]  
P89LPC9351(FDH)@TSSOP28 [(SA643)]  
P89LPC9351(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC936(FA)@PLCC28 [(SA008A)]  
P89LPC936(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC936(FDH)@TSSOP28 [(SA643)]  
P89LPC936(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC938(FA)@PLCC28 [(SA008A)]  
P89LPC938(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC938(FDH)@TSSOP28 [(SA643)]  
P89LPC938(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC938(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC938(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93801(BA)@PLCC28 [(SA008A)]  
P89LPC93801(BDH)@TSSOP28 [(SA643)]  
P89LPC93801(FA)@PLCC28 [(SA008A)]  
P89LPC93801(FDH)@TSSOP28 [(SA643)]  
P89LPC93801(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9381(BA)@PLCC28 [(SA008A)]  
P89LPC9381(BDH)@TSSOP28 [(SA643)]  
P89LPC9381(FA)@PLCC28 [(SA008A)]  
P89LPC9381(FDH)@TSSOP28 [(SA643)]  
P89LPC9381(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9401(FBD)@LQFP64(ISP) [ISP-HEADER01]  
P89LPC9408(FBD)@LQFP64(ISP) [ISP-HEADER01]  
P89LPC952@LQFP44 [(SA245A)]  
P89LPC952@LQFP44(ISP) [ISP-HEADER01]  
P89LPC952@LQFP48 [(SA248)]  
P89LPC952@LQFP48(ISP) [ISP-HEADER01]  
P89LPC952@PLCC44 [(SA244)]

P89LPC952@PLCC44 (ISP) [ISP-HEADER01]  
 P89LPC954@LQFP44 [(SA245A)]  
 P89LPC954@LQFP44 (ISP) [ISP-HEADER01]  
 P89LPC954@LQFP48 [(SA248)]  
 P89LPC954@LQFP48 (ISP) [ISP-HEADER01]  
 P89LPC954@PLCC44 [(SA244)]  
 P89LPC954@PLCC44 (ISP) [ISP-HEADER01]  
 P89LV51RB2 P89LV51RB2@PLCC44  
 [(SA244)]  
 P89LV51RB2@TQFP44 [(SA245A)]  
 P89LV51RC2  
 P89LV51RC2@PLCC44 [(SA244)] P89LV51RC2@TQFP44  
 [(SA245A)]  
 P89LV51RD2 P89LV51RD2  
 (new)  
 P89LV51RD2(new)@PLCC44 [(SA244)]  
 P89LV51RD2(new)@TQFP44 [(SA245A)]  
 P89LV51RD2@PLCC44 [(SA244)] P89LV51RD2@TQFP44  
 [(SA245A)]  
 P89LV51RD2BA(new)@PLCC44 [(SA244)]  
 P89LV51RD2BA@PLCC44 [(SA244)]  
 P89LV51RD2BBC(new)@TQFP44 [(SA245A)]  
 P89LV51RD2BBC@TQFP44 [(SA245A)]  
 P89LV51RD2BN  
 P89LV51RD2BN(new)  
 P89LV51RD2FA(new)@PLCC44 [(SA244)]  
 P89LV51RD2FA@PLCC44 [(SA244)]  
 P89LV51RD2FBC(new)@TQFP44 [(SA245A)]  
 P89LV51RD2FBC@TQFP44 [(SA245A)]  
 P89LV51RD2FN  
 P89LV51RD2FN(new)  
 P89V51RB2  
 P89V51RB2@PLCC44 [(SA244)] P89V51RB2@TQFP44  
 [(SA245A)]  
 P89V51RC2 P89V51RC2@PLCC44  
 [(SA244)]  
 P89V51RC2@TQFP44 [(SA245A)]  
 P89V51RD2  
 P89V51RD2(new) P89V51RD2(new)@PLCC44  
 [(SA244)]  
 P89V51RD2(new)@TQFP44 [(SA245A)] P89V51RD2@PLCC44  
 [(SA244)]  
 P89V51RD2@TQFP44 [(SA245A)]

P89V51RD2BA(new)@PLCC44 [(SA244)]  
P89V51RD2BA@PLCC44 [(SA244)]  
P89V51RD2BBC(new)@TQFP44 [(SA245A)]  
P89V51RD2BBC@TQFP44 [(SA245A)]  
P89V51RD2BN  
P89V51RD2BN(new)  
P89V51RD2FA(new)@PLCC44 [(SA244)]  
P89V51RD2FA@PLCC44 [(SA244)]  
P89V51RD2FBC(new)@TQFP44 [(SA245A)]  
P89V51RD2FBC@TQFP44 [(SA245A)]  
P89V51RD2FN  
P89V51RD2FN(new)  
P89V52X2  
P89V52X2(ISP) [ISP-HEADER01] P89V52X2@PLCC44  
[(SA244)]  
P89V52X2@PLCC44(ISP) [ISP-HEADER01]  
P89V52X2@TQFP44 [(SA245A)]  
P89V52X2@TQFP44(ISP) [ISP-HEADER01]  
P89V660@PLCC44 [(SA244)] P89V660@TQFP44  
[(SA245A)]  
P89V662@PLCC44 [(SA244)] P89V662@TQFP44  
[(SA245A)]  
P89V664@PLCC44 [(SA244)] P89V664@TQFP44  
[(SA245A)]  
PXAC37@PLCC44 [(SA244)] PXAC37@TQFP44  
[(SA245A)]  
PXAG17@PLCC44 [(SA244)] PXAG17@TQFP44  
[(SA245A)]  
PXAG27@PLCC44 [(SA244)] PXAG27@TQFP44  
[(SA245A)]  
PXAG37@PLCC44 [(SA244)] PXAG37@TQFP44  
[(SA245A)]  
PXAG39@PLCC44 [(SA244)] PXAG39@TQFP44  
[(SA245A)]  
PXAG49@PLCC44 [(SA244)] PXAG49@TQFP44  
[(SA245A)]  
UOCIIIN1A-128K@QIP90 [(TA025)]  
UOCIIIN1A-128K@QIP90(facedown) [(TA021A)]  
UOCIIIN1A-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1A-128K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1A-256K@QIP90 [(TA025)]  
UOCIIIN1A-256K@QIP90(facedown) [(TA021A)]  
UOCIIIN1A-256K@TQFP128 [(TA023-B115)]

UOCIIIN1A-256K@TQFP128 (facedown) [(TA024-B115)]  
UOCIIIN1B-128K@QIP90 [(TA025)]  
UOCIIIN1B-128K@QIP90 (facedown) [(TA021A)]  
UOCIIIN1B-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1B-128K@TQFP128 (facedown) [(TA024-B115)]  
UOCIIIN1B-256K@QIP90 [(TA025)]  
UOCIIIN1B-256K@QIP90 (facedown) [(TA021A)]  
UOCIIIN1B-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1B-256K@TQFP128 (facedown) [(TA024-B115)]  
UOCIIIN1D-128K@QIP90 [(TA025)]  
UOCIIIN1D-128K@QIP90 (facedown) [(TA021A)]  
UOCIIIN1D-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1D-128K@TQFP128 (facedown) [(TA024-B115)]  
UOCIIIN1D-256K@QIP90 [(TA025)]  
UOCIIIN1D-256K@QIP90 (facedown) [(TA021A)]  
UOCIIIN1D-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1D-256K@TQFP128 (facedown) [(TA024-B115)]  
UOCIIIN1E-128K@QIP90 [(TA025)]  
UOCIIIN1E-128K@QIP90 (facedown) [(TA021A)]  
UOCIIIN1E-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1E-128K@TQFP128 (facedown) [(TA024-B115)]  
UOCIIIN1E-256K@QIP90 [(TA025)]  
UOCIIIN1E-256K@QIP90 (facedown) [(TA021A)]  
UOCIIIN1E-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1E-256K@TQFP128 (facedown) [(TA024-B115)]  
UOCIIIN1F-128K@QIP90 [(TA025)]  
UOCIIIN1F-128K@QIP90 (facedown) [(TA021A)]  
UOCIIIN1F-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1F-128K@TQFP128 (facedown) [(TA024-B115)]  
UOCIIIN1F-256K@QIP90 [(TA025)]  
UOCIIIN1F-256K@QIP90 (facedown) [(TA021A)]  
UOCIIIN1F-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1F-256K@TQFP128 (facedown) [(TA024-B115)]

**OKI**

**E (E) PROM/FRAM/NVRAM**

MR27C1602B  
[(SA638)]  
MR27V1602D  
[(SA638)]

MR27C1602B@PSOP44  
  
MR27V1602D@PSOP44

MR27V1602D@TSOP44 [ ( SA645 ) ] B005 ) ]	MR27V1602D@TSOP48 [ ( SA247-
MR27V1602E [ ( SA638 ) ]	MR27V1602E@PSOP44
MR27V1602E@TSOP44 [ ( SA645 ) ] B005 ) ]	MR27V1602E@TSOP48 [ ( SA247-
MR27V1602F [ ( SA638 ) ]	MR27V1602F@PSOP44
MR27V1602F@TSOP44 [ ( SA645 ) ] B005 ) ]	MR27V1602F@TSOP48 [ ( SA247-
MR27V1652D [ ( SA638 ) ]	MR27V1652D@PSOP44
MR27V1652D@TSOP44 [ ( SA645 ) ] B005 ) ]	MR27V1652D@TSOP48 [ ( SA247-
MR27V3202F@TSOP44 [ ( SA645 ) ] B005 ) ]	MR27V3202F@TSOP48 [ ( SA247-
MR27V401D [ ( SA638 ) ]	MR27V401D@PSOP32
MR27V401D@TSOP32 [ ( SA620 ) ]	
MR27V401E MR27V401E@PSOP32 [ ( SA638 ) ] [ ( SA620 ) ]	MR27V401E@TSOP32
MR27V402D [ ( SA661 ) ]	MR27V402D@PSOP40
MR27V402D@TSOP44 [ ( SA645 ) ]	
MR27V402E MR27V402E@PSOP40 [ ( SA661 ) ] [ ( SA645 ) ]	MR27V402E@TSOP44
MR27V6402D@PSOP44 [ ( SA638 ) ] [ ( SA645 ) ]	MR27V6402D@TSOP44
MR27V6402D@TSOP48 [ ( SA247-B005 ) ] [ ( SA638 ) ]	MR27V6402G@PSOP44
MR27V6402G@TSOP44 [ ( SA645 ) ] B005 ) ]	MR27V6402G@TSOP48 [ ( SA247-
MR27V802D [ ( SA638 ) ]	MR27V802D@PSOP44
MR27V802D@TSOP44 [ ( SA645 ) ] [ ( SA638 ) ]	MR27V802F@PSOP44
MR27V802F@TSOP44 [ ( SA645 ) ] B005 ) ]	MR27V802F@TSOP48 [ ( SA247-
MR27V852D [ ( SA638 ) ]	MR27V852D@PSOP44
MR27V852D@TSOP44 [ ( SA645 ) ]	



MR27V852E	
MR27V852E@SOJ42 [(SA661)]	MSM16812
(08bit)	
MSM16812(08bit)@SOIC8 [(SA602A)]	
MSM271000	
MSM271000@PLCC32 [(SA015A1T)]	MSM271000@TSOP32
[(SA410T)]	
MSM27128	
MSM27128A	
MSM27128AS	MSM27128AZB-
RS	
MSM2716	
MSM27256	
MSM27256AS	MSM27256ZB-
RS	
MSM2732	
MSM2732A	
MSM27512	
MSM27512AS	
MSM27512ZB-RS	
MSM2764	
MSM2764A	
MSM2764AS	
MSM2764AZB-RS	
MSM2764RS	
MSM27C1024	
MSM27C1024AS	
MSM27C128	MSM27C128AZB-
RS	
MSM27C1602CZ	MSM27C1602CZ@PSOP44
[(SA638)]	
MSM27C1602CZ@TSOP48 [(SA247-B005)]	
MSM27C1652CZ	MSM27C1652CZ@PSOP44
[(SA638)]	
MSM27C1652CZ@TSOP48 [(SA247-B005)]	
MSM27C256	
MSM27C256A	
MSM27C256H	
MSM27C256HZB	
MSM27C256ZB	
MSM27C64AS	
MSM27C802CZ	MSM27C802CZ@PSOP44
[(SA638)]	

MSM27C802CZ@TSOP44 [ (SA645) ]  
MSM27C852CZ  
MSM27C852CZ@PSOP44 [ (SA638) ]  
[ (SA645) ]  
MSM2816A(RS)  
MSM28C16A

MSM27C852CZ@TSOP44

## DRAM & SRAM

MSM51256  
[ (SA630) ]  
MSM51257AL  
[ (SA630) ]  
MSM51257ALL  
[ (SA630) ]  
MSM5165AL  
[ (SA630) ]  
MSM5188  
[ (SA646) ]

MSM51256@SOIC28

MSM51257AL@SOIC28

MSM51257ALL@SOIC28

MSM5165AL@SOIC28

MSM5188@SOJ22

## PARALLAX

### MICROCONTROLLER

SX20AC/SS/G@SSOP20 [ (SA626A) ]  
[ (SA626A) ]  
SX28AC/DP  
G  
SX28AC/SS/G@SSOP28 [ (SA626A) ]  
[ (SA626A) ]  
SX48BD/G@TQFP48 [ (SA248) ]  
[ (SA248) ]

SX20AC/SS@SSOP20

SX28AC/DP/

SX28AC/SS@SSOP28

SX48BD@TQFP48

## PFLASH(MSTAR)

### E (E) PROM/FRAM/NVRAM

PS25LV010A@SOIC8 [ (SA602A) ]  
[ (SA683) ]

PS25LV010A@WSON8

PS25LV020@SOIC8 [ (SA602A) ]  
 [ (SA683) ]  
 PS25LV040@SOIC8 [ (SA605A) ]  
 [ (SA683) ]  
 PS25LV080@SOIC8 [ (SA605A) ]  
 [ (SA683) ]

PS25LV020@WSON8  
 PS25LV040@WSON8  
 PS25LV080@WSON8

## PHILIPS

### E ( E ) PROM / FRAM / NVRAM

27C010  
 [ (SA015A1T) ]  
 27C010@TSOP32 [ (SA410T) ]  
 27C040  
 27C040@PLCC32 [ (SA015A1T) ]  
 [ (SA410T) ]  
 27C210  
 [ (SA244) ]  
 27C240  
 [ (SA244) ]  
 27C256  
 [ (SA015A1T) ]  
 27C32  
 27C512  
 27C512@PLCC32 [ (SA015A1T) ]  
 27C64  
 27C64@PLCC32 [ (SA015A1T) ]  
 27C64A  
 27C64A@PLCC32 [ (SA015A1T) ]  
 27C64AF  
 27C64AF@PLCC32 [ (SA015A1T) ]  
 27HC641  
 27HC641@PLCC28 [ (SA008A) ]  
 27PC32  
 PCA24S08@SOIC8 [ (SA602A) ]  
 [ (SA026) ]  
 PCA8574 (P)  
 [ (SA404) ]  
 PCA8574 (TS)@SSOP20 [ (SA026) ]  
 (P)  
 PCA8574A (T)@SOIC16 [ (SA404) ]

27C010@PLCC32  
 27C040@TSOP32  
 27C210@PLCC44  
 27C240@PLCC44  
 27C256@PLCC32  
 PCA24S08@TSSOP8  
 PCA8574 (T)@SOIC16  
 PCA8574A  
 PCA8574A (TS)@SSOP20

[ ( SA026 ) ]	
PCA8581	PCA8581@SOIC8
[ ( SA602A ) ]	
PCA8581C	PCA8581C@SOIC8
[ ( SA602A ) ]	
PCA8582A	PCA8582A@SOIC8
[ ( SA602A ) ]	
PCA8582B	PCA8582B@SOIC8
[ ( SA602A ) ]	
PCA8582C	PCA8582C@SOIC8
[ ( SA602A ) ]	
PCA8582D	PCA8582D@SOIC8
[ ( SA602A ) ]	
PCA8582E	PCA8582E@SOIC8
[ ( SA602A ) ]	
PCA9500@HQVFN16	PCA9500@SOIC16
[ ( SA404 ) ]	
PCA9500@TSSOP16 [ ( SA026 ) ]	
PCA9501@HQVFN20	
PCA9501@SOIC20 [ ( SA404 ) ]	PCA9501@TSSOP20
[ ( SA026 ) ]	
PCA9561D@SOP20 [ ( SA404 ) ]	PCA9561W@TSSOP20
[ ( SA026 ) ]	
PCD8581	PCD8581@SOIC8
[ ( SA602A ) ]	
PCD8581C	PCD8581C@SOIC8
[ ( SA602A ) ]	
PCD8582A	PCD8582A@SOIC8
[ ( SA602A ) ]	
PCD8582B	PCD8582B@SOIC8
[ ( SA602A ) ]	
PCD8582C	PCD8582C@SOIC8
[ ( SA602A ) ]	
PCD8582D	PCD8582D@SOIC8
[ ( SA602A ) ]	
PCD8582E	PCD8582E@SOIC8
[ ( SA602A ) ]	
PCF85102C	PCF85102C@SOIC8
[ ( SA602A ) ]	
PCF85103C	PCF85103C@SOIC8
[ ( SA602A ) ]	
PCF85116	PCF85116@SOIC8
[ ( SA602A ) ]	

PCF8581	PCF8581@SOIC8
[ (SA602A) ]	
PCF8581C	PCF8581C@SOIC8
[ (SA602A) ]	
PCF8582A	PCF8582A@SOIC8
[ (SA602A) ]	
PCF8582B	PCF8582B@SOIC8
[ (SA602A) ]	
PCF8582C	PCF8582C@SOIC8
[ (SA602A) ]	
PCF8582D	PCF8582D@SOIC8
[ (SA602A) ]	
PCF8582E	PCF8582E@SOIC8
[ (SA602A) ]	
PCF8594	PCF8594@SOIC8
[ (SA626A) ]	
PCF8594C	PCF8594C@SOIC8
[ (SA626A) ]	
PCF8594D	PCF8594D@SOIC8
[ (SA626A) ]	
PCF8594E	PCF8594E@SOIC8
[ (SA626A) ]	
PCF8598	PCF8598@SOIC8
[ (SA626A) ]	
PCF8598C	PCF8598C@SOIC8
[ (SA626A) ]	
PCF8598D	PCF8598D@SOIC8
[ (SA626A) ]	
PCF8598E	PCF8598E@SOIC8
[ (SA626A) ]	

## MICROCONTROLLER

LPC2101FBD48@LQFP48 ( \* ) [ (SA248-B4801) ]  
LPC2102FBD48@LQFP48 ( \* ) [ (SA248-B4801) ]  
LPC2103FA44@PLCC44 ( \* ) [ (SA244-B4403) ]  
LPC2103FBD48@LQFP48 ( \* ) [ (SA248-B4801) ]  
LPC2104BBD48@LQFP48 ( \* ) [ (SA248-B4801) ]  
LPC2105BBD48@LQFP48 ( \* ) [ (SA248-B4801) ]  
LPC2106BBD48@LQFP48 ( \* ) [ (SA248-B4801) ]  
LPC2114FBD64@LQFP64 ( \* ) [ (TA027-B4801) ]  
LPC2119FBD64@LQFP64 ( \* ) [ (TA027-B4801) ]

LPC2124FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2129FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2131FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2131FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2132FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2132FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2134FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2134FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2136FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2136FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2138FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2138FBD64@LQFP64(\*\*) [(SA732-B330)]  
 LPC2141FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2142FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2144FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2146FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2148FBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2194HBD64@LQFP64(\*) [(TA027-B4801)]  
 LPC2212HBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2214FBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2292HBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2294HBD144@LQFP144(\*) [(TA044-B4802)]  
 LPC2364@LQFP100(\*) [(SA718+B243)]  
 LPC2366@LQFP100(\*) [(SA718+B243)]  
 LPC2368@LQFP100(\*) [(SA718+B243)]  
 P83C660X2@PLCC44 [(SA244)] P83C660X2@TQFP44  
 [(SA245A)]  
 P83C661X2@PLCC44 [(SA244)] P83C661X2@TQFP44  
 [(SA245A)]  
 P87C51 P87C51@PLCC44  
 [(SA244)]  
 P87C51@TQFP44 [(SA245A)]  
 P87C51FA P87C51FA@TQFP44  
 P87C51FA@PLCC44 [(SA244)]  
 [(SA245A)]  
 P87C51FB P87C51FB@PLCC44  
 [(SA244)]  
 P87C51FB@TQFP44 [(SA245A)]  
 P87C51FC P87C51FC@TQFP44  
 P87C51FC@PLCC44 [(SA244)]  
 [(SA245A)]  
 P87C51MA2@PLCC44 [(SA244)] P87C51MB2@PLCC44  
 [(SA244)]

P87C51MC2@PLCC44 [(SA244)]	P87C51RA
+	
P87C51RA+@PLCC44 [(SA244)]	P87C51RA+@TQFP44
[(SA245A)]	
P87C51RA2	P87C51RA2@PLCC44
[(SA244)]	
P87C51RA2@TQFP44 [(SA245A)]	P87C51RB
+	
P87C51RB+@PLCC44 [(SA244)]	P87C51RB+@TQFP44
[(SA245A)]	
P87C51RB2	P87C51RB2@PLCC44
[(SA244)]	
P87C51RB2@TQFP44 [(SA245A)]	P87C51RC
+	
P87C51RC+@PLCC44 [(SA244)]	P87C51RC+@TQFP44
[(SA245A)]	
P87C51RC2	P87C51RC2@PLCC44
[(SA244)]	
P87C51RC2@TQFP44 [(SA245A)]	P87C51RD
+	
P87C51RD+@PLCC44 [(SA244)]	P87C51RD+@TQFP44
[(SA245A)]	
P87C51RD2	P87C51RD2@PLCC44
[(SA244)]	
P87C51RD2@TQFP44 [(SA245A)]	
P87C51SB	
P87C51SB@PLCC44 [(SA244)]	P87C51SB@TQFP44
[(SA245A)]	
P87C51SF	P87C51SF@PLCC44
[(SA244)]	
P87C51SF@TQFP44 [(SA245A)]	
P87C51UB	
P87C51UB@PLCC44 [(SA244)]	P87C51UB@TQFP44
[(SA245A)]	
P87C51UF	P87C51UF@PLCC44
[(SA244)]	
P87C51UF@TQFP44 [(SA245A)]	
P87C51X2	
P87C51X2@PLCC44 [(SA244)]	P87C51X2@TQFP44
[(SA245A)]	
P87C52	P87C52@PLCC44
[(SA244)]	
P87C52@TQFP44 [(SA245A)]	

P87C524	
P87C524@PLCC44 [(SA244)]	P87C524@TQFP44
[(SA245A)]	
P87C528	P87C528@PLCC44
[(SA244)]	
P87C528@TQFP44 [(SA245A)]	
P87C52SB	
P87C52SB@PLCC44 [(SA244)]	P87C52SB@TQFP44
[(SA245A)]	
P87C52SF	P87C52SF@PLCC44
[(SA244)]	
P87C52SF@TQFP44 [(SA675)]	
P87C52UB	
P87C52UB@PLCC44 [(SA244)]	P87C52UB@TQFP44
[(SA245A)]	
P87C52UF	P87C52UF@PLCC44
[(SA244)]	
P87C52UF@TQFP44 [(SA245A)]	
P87C52X2	
P87C52X2@PLCC44 [(SA244)]	P87C52X2@TQFP44
[(SA245A)]	
P87C54	P87C54@PLCC44
[(SA244)]	
P87C54@TQFP44 [(SA245A)]	
P87C54SB	
P87C54SB@PLCC44 [(SA244)]	P87C54SB@TQFP44
[(SA245A)]	
P87C54SF	P87C54SF@PLCC44
[(SA244)]	
P87C54SF@TQFP44 [(SA245A)]	
P87C54UB	
P87C54UB@PLCC44 [(SA244)]	P87C54UB@TQFP44
[(SA245A)]	
P87C54UF	P87C54UF@PLCC44
[(SA244)]	
P87C54UF@TQFP44 [(SA245A)]	
P87C54X2	
P87C54X2@PLCC44 [(SA244)]	P87C54X2@TQFP44
[(SA245A)]	
P87C550	P87C550@PLCC44
[(SA244)]	
P87C552@PLCC68(*) [(SA648-B6806)]	
P87C554@PLCC68(*) [(SA648-B6806)]	



P87C575 [ (SA244) ] P87C575@TQFP44 [ (SA245A) ] P87C576 P87C576@PLCC44 [ (SA244) ] [ (SA245A) ] P87C58 [ (SA244) ] P87C58@TQFP44 [ (SA245A) ] P87C58SB P87C58SB@PLCC44 [ (SA244) ] [ (SA245A) ] P87C58UB [ (SA244) ] P87C58UB@TQFP44 [ (SA245A) ] P87C58X2 P87C58X2@PLCC44 [ (SA244) ] [ (SA245A) ] P87C591@PLCC44 [ (SA244) ] [ (SA245A) ] P87C652 [ (SA244) ] P87C652@TQFP44 [ (SA245A) ] P87C654 P87C654@PLCC44 [ (SA244) ] [ (SA245A) ] P87C660X2@PLCC44 [ (SA244) ] [ (SA245A) ] P87C661X2@PLCC44 [ (SA244) ] [ (SA245A) ] P87C748 [ (SA008A) ] P87C749 [ (SA008A) ] P87C750 [ (SA008A) ] P87C750@SSOP24 [ (SA626A) ] P87C751 P87C751@PLCC28 [ (SA008A) ] [ (SA626A) ] P87C752 [ (SA008A) ] P87C752@SSOP28 [ (SA626A) ]	P87C575@PLCC44   P87C576@TQFP44  P87C58@PLCC44   P87C58SB@TQFP44  P87C58UB@PLCC44   P87C58X2@TQFP44  P87C591@TQFP44  P87C652@PLCC44   P87C654@TQFP44  P87C660X2@TQFP44  P87C661X2@TQFP44  P87C748@PLCC28  P87C749@PLCC28  P87C750@PLCC28  P87C751@SSOP24  P87C752@PLCC28
--	--

P87C754	
P87C754@PLCC28 [(SA008A)]	P87C754@SSOP28
[(SA626A)]	
P87CL52X2	P87CL52X2@PLCC44
[(SA244)]	
P87CL52X2@TQFP44 [(SA245A)]	
P87CL54X2	
P87CL54X2@PLCC44 [(SA244)]	P87CL54X2@TQFP44
[(SA245A)]	
P87L51FA	P87L51FA@PLCC44
[(SA244)]	
P87L51FA@TQFP44 [(SA245A)]	
P87L51FB	
P87L51FB@PLCC44 [(SA244)]	P87L51FB@TQFP44
[(SA245A)]	
P87LPC759	P87LPC759(ISP) [ISP-
HEADER01]	
P87LPC760	P87LPC760(ISP) [ISP-
HEADER01]	
P87LPC760@TSSOP14 [(SA026)]	
P87LPC760@TSSOP14(ISP) [ISP-HEADER01]	
P87LPC761	P87LPC761(ISP) [ISP-
HEADER01]	
P87LPC762	P87LPC762(ISP) [ISP-
HEADER01]	
P87LPC762@PLCC44 [(SA244)]	
P87LPC762@PLCC44(ISP) [ISP-HEADER01]	
P87LPC762@SOIC20 [(SA404)]	
P87LPC762@SOIC20(ISP) [ISP-HEADER01]	
P87LPC764	P87LPC764(ISP) [ISP-
HEADER01]	
P87LPC764@PLCC44 [(SA244)]	
P87LPC764@PLCC44(ISP) [ISP-HEADER01]	
P87LPC764@SOIC20 [(SA404)]	
P87LPC764@SOIC20(ISP) [ISP-HEADER01]	
P87LPC764@TSSOP20 [(SA643)]	
P87LPC764@TSSOP20(ISP) [ISP-HEADER01]	
P87LPC767	P87LPC767(ISP) [ISP-
HEADER01]	
P87LPC767@PLCC44 [(SA244)]	
P87LPC767@PLCC44(ISP) [ISP-HEADER01]	
P87LPC767@SOIC20 [(SA404)]	
P87LPC767@SOIC20(ISP) [ISP-HEADER01]	

P87LPC768 HEADER01 ]	P87LPC768(ISP) [ISP-
P87LPC768@SOIC20 [(SA404)]	
P87LPC768@SOIC20(ISP) [ISP-HEADER01 ]	
P87LPC769 HEADER01 ]	P87LPC769(ISP) [ISP-
P87LPC769@PLCC44 [(SA244)]	
P87LPC769@PLCC44(ISP) [ISP-HEADER01 ]	
P87LPC769@SOIC20 [(SA404)]	
P87LPC769@SOIC20(ISP) [ISP-HEADER01 ]	
P87LPC778 HEADER01 ]	P87LPC778(ISP) [ISP-
P87LPC778@TSSOP20 [(SA026)]	
P87LPC778@TSSOP20(ISP) [ISP-HEADER01 ]	
P87LPC779 HEADER01 ]	P87LPC779(ISP) [ISP-
P87LPC779@TSSOP20 [(SA643)]	
P87LPC779@TSSOP20(ISP) [ISP-HEADER01 ]	
P89C138 [(SA244)]	P89C138@PLCC44
P89C138@TQFP44 [(SA245A)]	
P89C238 [(SA244)]	P89C238@TQFP44
P89C238@PLCC44 [(SA244)]	
P89C238@PLCC44 [(SA245A)]	
P89C51B [(SA244)]	P89C51B@PLCC44
P89C51B@TQFP44 [(SA245A)]	P89C51RA
+	
P89C51RA+@PLCC44 [(SA244)]	P89C51RA+@TQFP44
P89C51RA+@PLCC44 [(SA245A)]	
P89C51RA2B [(SA244)]	P89C51RA2B@PLCC44
P89C51RA2B@TQFP44 [(SA245A)]	P89C51RB
+	
P89C51RB+@PLCC44 [(SA244)]	P89C51RB+@TQFP44
P89C51RB+@PLCC44 [(SA245A)]	
P89C51RB2B [(SA244)]	P89C51RB2B@PLCC44
P89C51RB2B@TQFP44 [(SA245A)]	
P89C51RB2H [(SA244)]	P89C51RB2H@TQFP44
P89C51RB2H@PLCC44 [(SA244)]	
P89C51RB2H@PLCC44 [(SA245A)]	
P89C51RC+	P89C51RC+@PLCC44

[ (SA244) ]  
P89C51RC+@TQFP44 [ (SA245A) ]  
P89C51RC2B  
P89C51RC2B@PLCC44 [ (SA244) ] P89C51RC2B@TQFP44  
[ (SA245A) ]  
P89C51RC2H P89C51RC2H@PLCC44  
[ (SA244) ]  
P89C51RC2H@TQFP44 [ (SA245A) ] P89C51RD  
+  
P89C51RD+@PLCC44 [ (SA244) ] P89C51RD+@TQFP44  
[ (SA245A) ]  
P89C51RD2B P89C51RD2B@PLCC44  
[ (SA244) ]  
P89C51RD2B@TQFP44 [ (SA245A) ]  
P89C51RD2H  
P89C51RD2H@PLCC44 [ (SA244) ] P89C51RD2H@TQFP44  
[ (SA245A) ]  
P89C51UB P89C51UB@PLCC44  
[ (SA244) ]  
P89C51UB@TQFP44 [ (SA245A) ]  
P89C51UF  
P89C51UF@PLCC44 [ (SA244) ] P89C51UF@TQFP44  
[ (SA245A) ]  
P89C51X2 P89C51X2@PLCC44  
[ (SA244) ]  
P89C51X2@TQFP44 [ (SA245A) ]  
P89C51X2B  
P89C51X2B@PLCC44 [ (SA244) ] P89C51X2B@TQFP44  
[ (SA245A) ]  
P89C51X2F P89C51X2F@PLCC44  
[ (SA244) ]  
P89C51X2F@TQFP44 [ (SA245A) ]  
P89C52  
P89C52@PLCC44 [ (SA244) ] P89C52@TQFP44  
[ (SA245A) ]  
P89C52B P89C52B@PLCC44  
[ (SA244) ]  
P89C52B@TQFP44 [ (SA245A) ]  
P89C52UB  
P89C52UB@PLCC44 [ (SA244) ] P89C52UB@TQFP44  
[ (SA245A) ]  
P89C52UF P89C52UF@PLCC44  
[ (SA244) ]

P89C52UF@TQFP44 [(SA245A)]	
P89C52X2	
P89C52X2@PLCC44 [(SA244)]	P89C52X2@TQFP44
[(SA245A)]	
P89C52X2B	
[(SA244)]	P89C52X2B@PLCC44
P89C52X2B@TQFP44 [(SA245A)]	
P89C52X2F	
P89C52X2F@PLCC44 [(SA244)]	P89C52X2F@TQFP44
[(SA245A)]	
P89C536@PLCC44 [(SA244)]	P89C538@PLCC44
[(SA244)]	
P89C54	
[(SA244)]	P89C54@PLCC44
P89C54@TQFP44 [(SA245A)]	
P89C54B	
P89C54B@PLCC44 [(SA244)]	P89C54B@TQFP44
[(SA245A)]	
P89C54UB	
[(SA244)]	P89C54UB@PLCC44
P89C54UB@TQFP44 [(SA245A)]	
P89C54UF	
P89C54UF@PLCC44 [(SA244)]	P89C54UF@TQFP44
[(SA245A)]	
P89C54X2	
[(SA244)]	P89C54X2@PLCC44
P89C54X2@TQFP44 [(SA245A)]	
P89C54X2B	
P89C54X2B@PLCC44 [(SA244)]	P89C54X2B@TQFP44
[(SA245A)]	
P89C54X2F	
[(SA244)]	P89C54X2F@PLCC44
P89C54X2F@TQFP44 [(SA245A)]	
P89C58	
P89C58@PLCC44 [(SA244)]	P89C58@TQFP44
[(SA245A)]	
P89C58B	
[(SA244)]	P89C58B@PLCC44
P89C58B@TQFP44 [(SA245A)]	
P89C58UB	
P89C58UB@PLCC44 [(SA244)]	P89C58UB@TQFP44
[(SA245A)]	
P89C58UF	
	P89C58UF@PLCC44

[ ( SA244 ) ]	
P89C58UF@TQFP44 [ ( SA245A ) ]	
P89C58X2	
P89C58X2@PLCC44 [ ( SA244 ) ]	P89C58X2@TQFP44
[ ( SA245A ) ]	
P89C58X2B	P89C58X2B@PLCC44
[ ( SA244 ) ]	
P89C58X2B@TQFP44 [ ( SA245A ) ]	
P89C58X2F	
P89C58X2F@PLCC44 [ ( SA244 ) ]	P89C58X2F@TQFP44
[ ( SA245A ) ]	
P89C60X2	P89C60X2@PLCC44
[ ( SA244 ) ]	
P89C60X2@TQFP44 [ ( SA245A ) ]	
P89C61X2	
P89C61X2@PLCC44 [ ( SA244 ) ]	P89C61X2@TQFP44
[ ( SA245A ) ]	
P89C660	P89C660@PLCC44
[ ( SA244 ) ]	
P89C660@TQFP44 [ ( SA245A ) ]	
P89C662	
P89C662@PLCC44 [ ( SA244 ) ]	P89C662@TQFP44
[ ( SA245A ) ]	
P89C664	P89C664@PLCC44
[ ( SA244 ) ]	
P89C664@TQFP44 [ ( SA245A ) ]	
P89C668	
P89C668@PLCC44 [ ( SA244 ) ]	P89C668@TQFP44
[ ( SA245A ) ]	
P89C669	P89C669@LQFP44
[ ( SA245A ) ]	
P89C669@PLCC44 [ ( SA244 ) ]	
P89C738	
P89C738@PLCC44 [ ( SA244 ) ]	P89C738@TQFP44
[ ( SA245A ) ]	
P89C838	P89C838@PLCC44
[ ( SA244 ) ]	
P89C838@TQFP44 [ ( SA245A ) ]	P89CV51RB2@PLCC44
[ ( SA244 ) ]	
P89CV51RB2@TQFP44 [ ( SA245A ) ]	P89CV51RC2@PLCC44
[ ( SA244 ) ]	
P89CV51RC2@TQFP44 [ ( SA245A ) ]	P89CV51RD2@PLCC44
[ ( SA244 ) ]	

P89CV51RD2@TQFP44 [(SA245A)] P89LPC901(FD)  
[(SA602A)]  
P89LPC901(FD)(ISP) [ISP-HEADER01]  
P89LPC901(FN)  
P89LPC901(FN)(ISP) [ISP-HEADER01]  
P89LPC902(FD) [(SA602A)]  
P89LPC902(FD)(ISP) [ISP-HEADER01]  
P89LPC902(FN)  
P89LPC902(FN)(ISP) [ISP-HEADER01]  
P89LPC903(FD) [(SA602A)]  
P89LPC903(FD)(ISP) [ISP-HEADER01]  
P89LPC904(FD) [(SA605A)]  
P89LPC904(FD)(ISP) [ISP-HEADER01]  
P89LPC904(FN)  
P89LPC904(FN)(ISP) [ISP-HEADER01]  
P89LPC906(FD) [(SA605A)]  
P89LPC906(FD)(ISP) [ISP-HEADER01]  
P89LPC907(FD) [(SA605A)]  
P89LPC907(FD)(ISP) [ISP-HEADER01]  
P89LPC908(FD) [(SA605A)]  
P89LPC908(FD)(ISP) [ISP-HEADER01]  
P89LPC9102(FTK)@HVSON10 [(SA695A)]  
P89LPC9102(FTK)@HVSON10(ISP) [ISP-HEADER01]  
P89LPC9103(FTK)@HVSON10 [(SA695A)]  
P89LPC9103(FTK)@HVSON10(ISP) [ISP-HEADER01]  
P89LPC9107(FDH)@TSSOP14 [(SA643)]  
P89LPC9107(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC9107(FN)  
P89LPC9107(FN)(ISP) [ISP-HEADER01]  
P89LPC912(FDH)@TSSOP14 [(SA643)]  
P89LPC912(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC913(FDH)@TSSOP14 [(SA643)]  
P89LPC913(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC914(FDH)@TSSOP14 [(SA643)]  
P89LPC914(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC915(FDH)@TSSOP14 [(SA643)]  
P89LPC915(FDH)@TSSOP14(ISP) [ISP-HEADER01]  
P89LPC916(FDH)@TSSOP16 [(SA643)]  
P89LPC916(FDH)@TSSOP16(ISP) [ISP-HEADER01]  
P89LPC917(FDH)@TSSOP16 [(SA643)]  
P89LPC917(FDH)@TSSOP16(ISP) [ISP-HEADER01]  
P89LPC920(FDH)@TSSOP20 [(SA643)]  
P89LPC920(FDH)@TSSOP20(ISP) [ISP-HEADER01]

P89LPC920 (FN)  
P89LPC920 (FN) (ISP) [ISP-HEADER01]  
P89LPC921 (FDH)@TSSOP20 [(SA643)]  
P89LPC921 (FDH)@TSSOP20 (ISP) [ISP-HEADER01]  
P89LPC921 (FN)  
P89LPC921 (FN) (ISP) [ISP-HEADER01]  
P89LPC922 (FDH)@TSSOP20 [(SA643)]  
P89LPC922 (FDH)@TSSOP20 (ISP) [ISP-HEADER01]  
P89LPC922 (FN)  
P89LPC922 (FN) (ISP) [ISP-HEADER01]  
P89LPC9221 (FDH)@TSSOP20 [(SA643)]  
P89LPC9221 (FDH)@TSSOP20 (ISP) [ISP-HEADER01]  
P89LPC9221 (FN)  
P89LPC9221 (FN) (ISP) [ISP-HEADER01]  
P89LPC924 (FDH)@TSSOP20 [(SA643)]  
P89LPC924 (FDH)@TSSOP20 (ISP) [ISP-HEADER01]  
P89LPC924 (FN)  
P89LPC924 (FN) (ISP) [ISP-HEADER01]  
P89LPC925 (FDH)@TSSOP20 [(SA643)]  
P89LPC925 (FDH)@TSSOP20 (ISP) [ISP-HEADER01]  
P89LPC925 (FN)  
P89LPC925 (FN) (ISP) [ISP-HEADER01]  
P89LPC930 (BA)@PLCC28 [(SA008A)]  
P89LPC930 (BA)@PLCC28 (ISP) [ISP-HEADER01]  
P89LPC930 (BDH)@TSSOP28 [(SA643)]  
P89LPC930 (BDH)@TSSOP28 (ISP) [ISP-HEADER01]  
P89LPC931 (BA)@PLCC28 [(SA008A)]  
P89LPC931 (BA)@PLCC28 (ISP) [ISP-HEADER01]  
P89LPC931 (BDH)@TSSOP28 [(SA643)]  
P89LPC931 (BDH)@TSSOP28 (ISP) [ISP-HEADER01]  
P89LPC932 (BA)@PLCC28 [(SA008A)] P89LPC932 (BDH)@TSSOP28  
[(SA643)]  
P89LPC932A1 (BA)@PLCC28 [(SA008A)]  
P89LPC932A1 (BA)@PLCC28 (ISP) [ISP-HEADER01]  
P89LPC932A1 (BDH)@TSSOP28 [(SA643)]  
P89LPC932A1 (BDH)@TSSOP28 (ISP) [ISP-HEADER01]  
P89LPC932A1 (FDH)@TSSOP28 [(SA643)]  
P89LPC932A1 (FDH)@TSSOP28 (ISP) [ISP-HEADER01]  
P89LPC932A1 (FHN)@HVQFN28 [(SA685-B006)]  
P89LPC932A1 (FHN)@HVQFN28 (ISP) [ISP-HEADER01]  
P89LPC933 (BDH)@TSSOP28 [(SA643)]  
P89LPC933 (BDH)@TSSOP28 (ISP) [ISP-HEADER01]  
P89LPC933 (FDH)@TSSOP28 [(SA643)]



P89LPC933(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC934(BDH)@TSSOP28 [(SA643)]  
P89LPC934(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC934(FDH)@TSSOP28 [(SA643)]  
P89LPC934(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(BA)@PLCC28 [(SA008A)]  
P89LPC935(BA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(BDH)@TSSOP28 [(SA643)]  
P89LPC935(BDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(FA)@PLCC28 [(SA008A)]  
P89LPC935(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC935(FDH)@TSSOP28 [(SA643)]  
P89LPC935(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC935(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC935(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93501(BA)@PLCC28 [(SA008A)]  
P89LPC93501(BDH)@TSSOP28 [(SA643)]  
P89LPC93501(FA)@PLCC28 [(SA008A)]  
P89LPC93501(FDH)@TSSOP28 [(SA643)]  
P89LPC93501(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9351(BA)@PLCC28 [(SA008A)]  
P89LPC9351(BDH)@TSSOP28 [(SA643)]  
P89LPC9351(FA)@PLCC28 [(SA008A)]  
P89LPC9351(FDH)@TSSOP28 [(SA643)]  
P89LPC9351(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC936(FA)@PLCC28 [(SA008A)]  
P89LPC936(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC936(FDH)@TSSOP28 [(SA643)]  
P89LPC936(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC938(FA)@PLCC28 [(SA008A)]  
P89LPC938(FA)@PLCC28(ISP) [ISP-HEADER01]  
P89LPC938(FDH)@TSSOP28 [(SA643)]  
P89LPC938(FDH)@TSSOP28(ISP) [ISP-HEADER01]  
P89LPC938(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC938(FHN)@HVQFN28(ISP) [ISP-HEADER01]  
P89LPC93801(BA)@PLCC28 [(SA008A)]  
P89LPC93801(BDH)@TSSOP28 [(SA643)]  
P89LPC93801(FA)@PLCC28 [(SA008A)]  
P89LPC93801(FDH)@TSSOP28 [(SA643)]  
P89LPC93801(FHN)@HVQFN28 [(SA685-B006)]  
P89LPC9381(BA)@PLCC28 [(SA008A)]  
P89LPC9381(BDH)@TSSOP28 [(SA643)]  
P89LPC9381(FA)@PLCC28 [(SA008A)]

P89LPC9381(FDH)@TSSOP28 [(SA643)]  
 P89LPC9381(FHN)@HVQFN28 [(SA685-B006)]  
 P89LPC9401(FBD)@LQFP64(ISP) [ISP-HEADER01]  
 P89LPC9408(FBD)@LQFP64(ISP) [ISP-HEADER01]  
 P89LPC952@LQFP44 [(SA245A)]  
 P89LPC952@LQFP44(ISP) [ISP-HEADER01]  
 P89LPC952@LQFP48 [(SA248)]  
 P89LPC952@LQFP48(ISP) [ISP-HEADER01]  
 P89LPC952@PLCC44 [(SA244)]  
 P89LPC952@PLCC44(ISP) [ISP-HEADER01]  
 P89LPC954@LQFP44 [(SA245A)]  
 P89LPC954@LQFP44(ISP) [ISP-HEADER01]  
 P89LPC954@LQFP48 [(SA248)]  
 P89LPC954@LQFP48(ISP) [ISP-HEADER01]  
 P89LPC954@PLCC44 [(SA244)]  
 P89LPC954@PLCC44(ISP) [ISP-HEADER01]  
 P89LV51RB2 P89LV51RB2@PLCC44  
 [(SA244)]  
 P89LV51RB2@TQFP44 [(SA245A)]  
 P89LV51RC2  
 P89LV51RC2@PLCC44 [(SA244)] P89LV51RC2@TQFP44  
 [(SA245A)]  
 P89LV51RD2 P89LV51RD2  
 (new)  
 P89LV51RD2(new)@PLCC44 [(SA244)]  
 P89LV51RD2(new)@TQFP44 [(SA245A)]  
 P89LV51RD2@PLCC44 [(SA244)] P89LV51RD2@TQFP44  
 [(SA245A)]  
 P89LV51RD2BA(new)@PLCC44 [(SA244)]  
 P89LV51RD2BA@PLCC44 [(SA244)]  
 P89LV51RD2BBC(new)@TQFP44 [(SA245A)]  
 P89LV51RD2BBC@TQFP44 [(SA245A)]  
 P89LV51RD2BN  
 P89LV51RD2BN(new)  
 P89LV51RD2FA(new)@PLCC44 [(SA244)]  
 P89LV51RD2FA@PLCC44 [(SA244)]  
 P89LV51RD2FBC(new)@TQFP44 [(SA245A)]  
 P89LV51RD2FBC@TQFP44 [(SA245A)]  
 P89LV51RD2FN  
 P89LV51RD2FN(new)  
 P89V51RB2  
 P89V51RB2@PLCC44 [(SA244)] P89V51RB2@TQFP44  
 [(SA245A)]

P89V51RC2 [ (SA244) ]	P89V51RC2@PLCC44
P89V51RC2@TQFP44 [ (SA245A) ]	
P89V51RD2 P89V51RD2 (new) [ (SA244) ]	P89V51RD2 (new)@PLCC44
P89V51RD2 (new)@TQFP44 [ (SA245A) ] [ (SA244) ]	P89V51RD2@PLCC44
P89V51RD2@TQFP44 [ (SA245A) ]	
P89V51RD2BA (new)@PLCC44 [ (SA244) ]	
P89V51RD2BA@PLCC44 [ (SA244) ]	
P89V51RD2BBC (new)@TQFP44 [ (SA245A) ]	
P89V51RD2BBC@TQFP44 [ (SA245A) ]	
P89V51RD2BN P89V51RD2BN (new)	
P89V51RD2FA (new)@PLCC44 [ (SA244) ]	
P89V51RD2FA@PLCC44 [ (SA244) ]	
P89V51RD2FBC (new)@TQFP44 [ (SA245A) ]	
P89V51RD2FBC@TQFP44 [ (SA245A) ]	
P89V51RD2FN P89V51RD2FN (new)	
P89V52X2 P89V52X2 (ISP) [ ISP-HEADER01 ] [ (SA244) ]	P89V52X2@PLCC44
P89V52X2@PLCC44 (ISP) [ ISP-HEADER01 ]	
P89V52X2@TQFP44 [ (SA245A) ]	
P89V52X2@TQFP44 (ISP) [ ISP-HEADER01 ]	
P89V660@PLCC44 [ (SA244) ] [ (SA245A) ]	P89V660@TQFP44
P89V662@PLCC44 [ (SA244) ] [ (SA245A) ]	P89V662@TQFP44
P89V664@PLCC44 [ (SA244) ] [ (SA245A) ]	P89V664@TQFP44
PXAC37@PLCC44 [ (SA244) ] [ (SA245A) ]	PXAC37@TQFP44
PXAG17@PLCC44 [ (SA244) ] [ (SA245A) ]	PXAG17@TQFP44
PXAG27@PLCC44 [ (SA244) ] [ (SA245A) ]	PXAG27@TQFP44
PXAG37@PLCC44 [ (SA244) ] [ (SA245A) ]	PXAG37@TQFP44
PXAG39@PLCC44 [ (SA244) ] [ (SA245A) ]	PXAG39@TQFP44

PXAG49@PLCC44 [(SA244)] PXAG49@TQFP44  
[(SA245A)]  
UOCIIIN1A-128K@QIP90 [(TA025)]  
UOCIIIN1A-128K@QIP90(facedown) [(TA021A)]  
UOCIIIN1A-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1A-128K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1A-256K@QIP90 [(TA025)]  
UOCIIIN1A-256K@QIP90(facedown) [(TA021A)]  
UOCIIIN1A-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1A-256K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1B-128K@QIP90 [(TA025)]  
UOCIIIN1B-128K@QIP90(facedown) [(TA021A)]  
UOCIIIN1B-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1B-128K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1B-256K@QIP90 [(TA025)]  
UOCIIIN1B-256K@QIP90(facedown) [(TA021A)]  
UOCIIIN1B-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1B-256K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1D-128K@QIP90 [(TA025)]  
UOCIIIN1D-128K@QIP90(facedown) [(TA021A)]  
UOCIIIN1D-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1D-128K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1D-256K@QIP90 [(TA025)]  
UOCIIIN1D-256K@QIP90(facedown) [(TA021A)]  
UOCIIIN1D-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1D-256K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1E-128K@QIP90 [(TA025)]  
UOCIIIN1E-128K@QIP90(facedown) [(TA021A)]  
UOCIIIN1E-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1E-128K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1E-256K@QIP90 [(TA025)]  
UOCIIIN1E-256K@QIP90(facedown) [(TA021A)]  
UOCIIIN1E-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1E-256K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1F-128K@QIP90 [(TA025)]  
UOCIIIN1F-128K@QIP90(facedown) [(TA021A)]  
UOCIIIN1F-128K@TQFP128 [(TA023-B115)]  
UOCIIIN1F-128K@TQFP128(facedown) [(TA024-B115)]  
UOCIIIN1F-256K@QIP90 [(TA025)]  
UOCIIIN1F-256K@QIP90(facedown) [(TA021A)]  
UOCIIIN1F-256K@TQFP128 [(TA023-B115)]  
UOCIIIN1F-256K@TQFP128(facedown) [(TA024-B115)]

**PJ****E (E) PROM/FRAM/NVRAM**

PJ24C02  
 [ (SA602A) ]  
 PJ24C02@TSSOP8 [ (SA026) ]

PJ24C02@SOIC8

**PMC****E (E) PROM/FRAM/NVRAM**

PM24C64  
 [ (SA602A) ]  
 PM24C64@TSOP8 [ (SA026) ]  
 [ (SA023A) ]  
 PM25LV010(Q)@WSON8 [ (SA683) ]  
 [ (SA602A) ]  
 PM25LV010A@SOIC8 [ (SA602A) ]  
 [ (SA683) ]  
 PM25LV016@SOIC8 [ (SA605A) ]  
 [ (SA683) ]  
 PM25LV016A@SOIC8 [ (SA605A) ]  
 [ (SA683) ]  
 PM25LV020(B)@SOIC8 [ (SA023A) ]  
 [ (SA683) ]  
 PM25LV020(S)@SOIC8 [ (SA602A) ]  
 [ (SA023A) ]  
 PM25LV040(Q)@WSON8 [ (SA683) ]  
 [ (SA602A) ]  
 PM25LV080@SOIC8 [ (SA605A) ]  
 [ (SA683) ]  
 PM25LV080A@SOIC8 [ (SA605A) ]  
 [ (SA683) ]  
 PM25LV512(B)@SOIC8 [ (SA023A) ]  
 [ (SA683) ]  
 PM25LV512(S)@SOIC8 [ (SA602A) ]  
 PM29F002B  
 PM29F002B@PLCC32 [ (SA015A1T) ]  
 PM29F002T  
 PM29F002T@PLCC32 [ (SA015A1T) ]

PM24C64@SOIC8  
 PM25LV010(B)@SOIC8  
 PM25LV010(S)@SOIC8  
 PM25LV010A@WSON8  
 PM25LV016@WSON8  
 PM25LV016A@WSON8  
 PM25LV020(Q)@WSON8  
 PM25LV040(B)@SOIC8  
 PM25LV040(S)@SOIC8  
 PM25LV080@WSON8  
 PM25LV080A@WSON8  
 PM25LV512(Q)@WSON8

PM29F004B  
PM29F004B@PLCC32 [(SA015A1T)]  
PM29F004T  
PM29F004T@PLCC32 [(SA015A1T)]  
PM29LV002B  
PM29LV002B@PLCC32 [(SA015A1T)]  
[(SA620)]  
PM29LV002T  
[(SA015A1T)]  
PM29LV002T@VSOP32 [(SA620)]  
[(SA015A1T)]  
PM29LV004B@VSOP32 [(SA620)]  
[(SA015A1T)]  
PM29LV004T@VSOP32 [(SA620)]  
[(SA015A1T)]  
PM29LV104RB@VSOP32 [(SA620)]  
[(SA015A1T)]  
PM29LV104RT@VSOP32 [(SA620)]  
PM37LV512  
PM37LV512@PLCC32 [(SA015A1T)]  
[(SA620)]  
PM39F010  
[(SA015A1T)]  
PM39F010@VSOP32 [(SA620)]  
PM39F020  
PM39F020@PLCC32 [(SA015A1T)]  
[(SA620)]  
PM39F040  
[(SA015A1T)]  
PM39F040@VSOP32 [(SA620)]  
[(SA015A1T)]  
PM39LV010@VSOP32 [(SA620)]  
[(SA015A1T)]  
PM39LV010R@VSOP32 [(SA620)]  
[(SA015A1T)]  
PM39LV020@VSOP32 [(SA620)]  
[(SA015A1T)]  
PM39LV040@VSOP32 [(SA620)]  
[(SA015A1T)]  
PM39LV512@VSOP32 [(SA620)]  
[(SA015A1T)]  
PM39LV512R@VSOP32 [(SA620)]  
[(SA015A1T)]  
PM49FL002T@PLCC32

PM29LV002B@VSOP32  
PM29LV002T@PLCC32  
PM29LV004B@PLCC32  
PM29LV004T@PLCC32  
PM29LV104RB@PLCC32  
PM29LV104RT@PLCC32  
PM37LV512@VSOP32  
PM39F010@PLCC32  
PM39F020@VSOP32  
PM39F040@PLCC32  
PM39LV010@PLCC32  
PM39LV010R@PLCC32  
PM39LV020@PLCC32  
PM39LV040@PLCC32  
PM39LV512@PLCC32  
PM39LV512R@PLCC32



[ ( SA015A1T ) ]  
PT29C040  
[ ( SA015A1T ) ]

PT29C040@PLCC32

## MICROCONTROLLER

PT89316  
[ ( SA244 ) ]  
PT89316@TQFP44 [ ( SA245A ) ]  
PT8932  
PT8932@PLCC44 [ ( SA244 ) ]  
[ ( SA245 ) ]  
PT8936  
[ ( SA244 ) ]  
PT8936@TQFP44 [ ( SA245A ) ]  
PT8956  
PT8956@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]

PT89316@PLCC44

PT8932@TQFP44

PT8936@PLCC44

PT8956@TQFP44

## QIXIN

### MICROCONTROLLER

LS2051  
[ ( SA404 ) ]

LS2051@SOIC20

## Quick Pulse

### E ( E ) PROM / FRAM / NVRAM

27010  
27011  
27040  
27128A  
27210  
27256  
27512  
2764A



**RAMTRON****E ( E ) PROM / FRAM / NVRAM**

FM1208 [ ( SA404 ) ]	FM1208@SOIC24
FM1608 [ ( SA404 ) ]	FM1608@SOIC28
FM1808 [ ( SA404 ) ]	FM1808@SOIC28
FM18L08 [ ( SA404 ) ]	FM18L08@SOIC28
FM24164 [ ( SA602A ) ]	FM24164@SOIC8
FM24C04 ( P ) [ ( SA602A ) ]	FM24C04 ( S ) @SOP8
FM24C04A ( P ) [ ( SA602A ) ]	FM24C04A ( S ) @SOP8
FM24C16 ( P ) [ ( SA602A ) ]	FM24C16 ( S ) @SOP8
FM24C16A ( P ) [ ( SA602A ) ]	FM24C16A ( S ) @SOP8
FM24C256@SOIC8 [ ( SA605A ) ] [ ( SA602A ) ]	FM24C512@SOIC8
FM24C64 [ ( SA602A ) ]	FM24C64@SOIC8
FM24CL04 [ ( SA602A ) ]	FM24CL04@SOIC8
FM24CL16 [ ( SA602A ) ]	FM24CL16@SOIC8
FM24CL64@SOIC8 [ ( SA602A ) ]	
FM25040	
FM25040@SOIC8 [ ( SA602A ) ]	
FM25160	
FM25160@SOIC8 [ ( SA602A ) ]	
FM25640	
FM25640@SOIC8 [ ( SA602A ) ]	
FM25C160	
FM25C160@SOIC8 [ ( SA602A ) ] [ ( SA602A ) ]	FM25CL04@SOIC8
FM25CL64 [ ( SA602A ) ]	FM25CL64@SOIC8

FM25L16	FM25L16@SOIC8
[ (SA602A) ]	
FM25L256	FM25L256@SOIC8
[ (SA602A) ]	
FM25L256@TDFN8 [ (BBBB) ]	
FM25L512	
FM25L512@SOIC8 [ (SA602A) ]	FM25W256@SOIC8
[ (SA602A) ]	
FM30C256@SOIC20 [ (SA404) ]	FM3104@SOIC14
[ (SA602) ]	
FM3116@SOIC14 [ (SA602) ]	FM31256@SOIC14
[ (SA602) ]	
FM3164@SOIC14 [ (SA602) ]	FM32256G@SOIC14
[ (SA602) ]	
FM32256S@SOIC14 [ (SA602) ]	FM3264G@SOIC14
[ (SA602) ]	
FM3264S@SOIC14 [ (SA602) ]	
FM3808	
FM3808@TSOP32 [ (SA620) ]	

## MICROCONTROLLER

VMX51C900	VMX51C900@PLCC44
[ (SA244) ]	
VMX51C900@TQFP44 [ (SA245A) ]	
VRS1000	
VRS1000@PLCC44 [ (SA244) ]	VRS1000@TQFP44
[ (SA245A) ]	
VRS1100	VRS1100@PLCC44
[ (SA244) ]	
VRS1100@TQFP44 [ (SA245A) ]	
VRS51C1000	
VRS51C1000@PLCC44 [ (SA244) ]	VRS51C1000@TQFP44
[ (SA245A) ]	
VRS51C1100	VRS51C1100@PLCC44
[ (SA244) ]	
VRS51C1100@TQFP44 [ (SA245A) ]	
VRS51C540	
VRS51C540@PLCC44 [ (SA244) ]	VRS51C540@TQFP44
[ (SA245A) ]	
VRS51C550	VRS51C550@PLCC44
[ (SA244) ]	

VRS51C550@TQFP44 [(SA245A)]	
VRS51C560	
VRS51C560@PLCC44 [(SA244)]	VRS51C560@TQFP44
[(SA245A)]	
VRS51C570	
[(SA244)]	VRS51C570@PLCC44
VRS51C570@TQFP44 [(SA245A)]	
VRS51C580	
VRS51C580@PLCC44 [(SA244)]	VRS51C580@TQFP44
[(SA245A)]	
VRS51C700	
[(SA244)]	VRS51C700@PLCC44
VRS51C700@TQFP44 [(SA245A)]	
VRS51L1050	
VRS51L1050@PLCC44 [(SA244)]	VRS51L1050@TQFP44
[(SA245A)]	
VRS51L540	
[(SA244)]	VRS51L540@PLCC44
VRS51L540@TQFP44 [(SA245A)]	
VRS51L550	
VRS51L550@PLCC44 [(SA244)]	VRS51L550@TQFP44
[(SA245A)]	
VRS51L560	
[(SA244)]	VRS51L560@PLCC44
VRS51L560@TQFP44 [(SA245A)]	
VRS51L570	
VRS51L570@PLCC44 [(SA244)]	VRS51L570@TQFP44
[(SA245A)]	
VRS51L580	
[(SA244)]	VRS51L580@PLCC44
VRS51L580@TQFP44 [(SA245A)]	
VRS51X540	
VRS51X540@PLCC44 [(SA244)]	VRS51X540@TQFP44
[(SA245A)]	
VRS51X550	
[(SA244)]	VRS51X550@PLCC44
VRS51X550@TQFP44 [(SA245A)]	
VRS51X560	
VRS51X560@PLCC44 [(SA244)]	VRS51X560@TQFP44
[(SA245A)]	
VRS51X570	
[(SA244)]	VRS51X570@PLCC44
VRS51X570@TQFP44 [(SA245A)]	

VRS51X580	VRS51X580@TQFP44
VRS51X580@PLCC44 [(SA244)]	
[(SA245A)]	
VRS540	VRS540@PLCC44
[(SA244)]	
VRS540@TQFP44 [(SA245A)]	
VRS550	
VRS550@PLCC44 [(SA244)]	VRS550@TQFP44
[(SA245A)]	
VRS560	VRS560@PLCC44
[(SA244)]	
VRS560@TQFP44 [(SA245A)]	
VRS570	
VRS570@PLCC44 [(SA244)]	VRS570@TQFP44
[(SA245A)]	
VRS580	VRS580@PLCC44
[(SA244)]	
VRS580@TQFP44 [(SA245A)]	
VRS700	
VRS700@PLCC44 [(SA244)]	VRS700@TQFP44
[(SA245A)]	
VRS900	VRS900@PLCC44
[(SA244)]	
VRS900@TQFP44 [(SA245A)]	

## RATO

### E(E) PROM/FRAM/NVRAM

RT24A02	RT24A02@SOIC8
[(SA602A)]	
RT24A02@TSSOP8 [(SA026)]	
RT24A04	
RT24A04@SOIC8 [(SA602A)]	RT24A04@TSSOP8
[(SA026)]	
RT24A08	RT24A08@SOIC8
[(SA602A)]	
RT24A08@TSSOP8 [(SA026)]	
RT24A16	
RT24A16@SOIC8 [(SA602A)]	RT24A16@TSSOP8
[(SA026)]	
RT93C46B(16bit)	RT93C46B(16bit)@SOIC8

[ (SA602A) ]  
 RT93C46B(16bit)@TSSOP8 [ (SA026) ]  
 (08bit)  
 RT93LC46(08bit)@SOIC8 [ (SA602A) ]  
 [ (SA026) ]  
 RT93LC46(16bit)  
 [ (SA602A) ]  
 RT93LC46(16bit)@TSSOP8 [ (SA026) ]

RT93LC46  
 RT93LC46(08bit)@TSSOP8  
 RT93LC46(16bit)@SOIC8

## RAYDIUM

### E (E) PROM/FRAM/NVRAM

RM24C02@SOP8 [ (SA602A) ]  
 [ (SA602A) ]  
 RM24C08@SOP8 [ (SA602A) ]  
 [ (SA602A) ]  
 RM24C16@SOP8 [ (SA602A) ]  
 [ (SA602A) ]  
 RM24C64@SOP8 [ (SA602A) ]

RM24C04@SOP8  
 RM24C128@SOP8  
 RM24C32@SOP8

## RENESAS

### E (E) PROM/FRAM/NVRAM

HN58C256A(FP)@SOP28 [ (SA630) ]  
 (P)  
 HN58C256A(T)@TSOP28 [ (SA643) ]  
 [ (SA620) ]  
 HN58V24256  
 [ (SA602A) ]  
 HN58V24256@TSSOP14 [ (SA026) ]  
 HN58V24512  
 HN58V24512@SOIC8 [ (SA602A) ]  
 HN58W241000  
 HN58W241000@SOIC8 [ (SA602A) ]  
 HN58X2402  
 HN58X2402@SOIC8 [ (SA602A) ]  
 [ (SA026) ]  
 HN58X2404

HN58C256A  
 HN58C257A(T)@TSOP32  
 HN58V24256@SOIC8  
 HN58X2402@TSSOP8  
 HN58X2404@SOIC8

[ (SA602A) ]  
HN58X2404@TSSOP8 [ (SA026) ]  
HN58X2408  
HN58X2408@SOIC8 [ (SA602A) ] HN58X2408@TSSOP8  
[ (SA026) ]  
HN58X24128 HN58X24128@SOIC8  
[ (SA602A) ]  
HN58X2416 HN58X2416@SOIC8  
[ (SA602A) ]  
HN58X2416@TSSOP8 [ (SA026) ]  
HN58X24256  
HN58X24256@SOIC8 [ (SA602A) ]  
HN58X2432  
HN58X2432@SOIC8 [ (SA602A) ] HN58X2432@TSSOP8  
[ (SA026) ]  
HN58X24512 HN58X24512@SOIC8  
[ (SA602A) ]  
HN58X2464 HN58X2464@SOIC8  
[ (SA602A) ]  
HN58X2464@TSSOP8 [ (SA026) ] HN58X2502@SOIC8  
[ (SA602A) ]  
HN58X2502@TSSOP8 [ (SA026) ] HN58X2504@SOIC8  
[ (SA602A) ]  
HN58X2504@TSSOP8 [ (SA026) ] HN58X25128@SOIC8  
[ (SA602A) ]  
HN58X25128@TSSOP14 [ (SA026) ] HN58X25256@SOIC8  
[ (SA602A) ]  
HN58X25256@TSSOP14 [ (SA026) ] HN58X2532@SOIC8  
[ (SA602A) ]  
HN58X2532@TSSOP8 [ (SA026) ] HN58X2564@SOIC8  
[ (SA602A) ]  
HN58X2564@TSSOP8 [ (SA026) ]  
M5L2732  
M5L2732A  
M5M29KB331(AVP)@TSOP48 [ (SA247-B005) ]  
M5M29KB641(AVP)@TSOP48 [ (SA247-B005) ]  
M5M29KE131BTP@TSOP52 [ (SA657-B117) ]  
M5M29KE131BV@TSOP48 [ (SA247-B005) ]  
M5M29KT331(AVP)@TSOP48 [ (SA247-B005) ]  
M5M29KT641(AVP)@TSOP48 [ (SA247-B005) ]  
M6MG3B641S16TP@TSOP52 [ (SA657-B036) ]  
M6MG3T641S16TP@TSOP52 [ (SA657-B036) ]  
M6MGB321S4TP@TSOP52 [ (SA657-B036) ]

M6MGB321S8TP@TSOP52 [ (SA657-B036) ]  
 M6MGB32BS4WG@CSP66 [ (SA642F-B023A-T064F001) ]  
 M6MGB32BS8WG@CSP66 [ (SA642F-B023A-T064F001) ]  
 M6MGB331S8KT@TSOP52 [ (SA657-B036) ]  
 M6MGB33BS8AWG@CSP66 [ (SA642F-B023A-T064F001) ]  
 M6MGB641S16TP@TSOP52 [ (SA657-B036) ]  
 M6MGB641S4TP@TSOP52 [ (SA657-B036) ]  
 M6MGB641S8TP@TSOP52 [ (SA657-B036) ]  
 M6MGB647M34CKT@TSOP52 [ (SA657-B036) ]  
 M6MGB64BM17AWG@CSP67 [ (SA642F-B064A-T064F001) ]  
 M6MGB64BM34CDG@CSP88 [ (SA642CC-B124A-W080F001N) ]  
 M6MGB64BM34CWG@CSP67 [ (SA642F-B064A-T064F001) ]  
 M6MGB64BS4WG@CSP67 [ (SA642F-B023A-T064F001) ]  
 M6MGB64BS8WG@CSP67 [ (SA642F-B023A-T064F001) ]  
 M6MGD137W33(WG)@CSP72 [ (SA642F-B056A-T064F001) ]  
 M6MGD13TW34DWG@CSP72 [ (SA642F-B064A-T064F001) ]  
 M6MGE157S4KT@TSOP52 [ (SA657-B055) ]  
 M6MGT321S4TP@TSOP52 [ (SA657-B036) ]  
 M6MGT321S8TP@TSOP52 [ (SA657-B036) ]  
 M6MGT32BS4WG@CSP66 [ (SA642F-B023A-T064F001) ]  
 M6MGT32BS8WG@CSP66 [ (SA642F-B023A-T064F001) ]  
 M6MGT331S8KT@TSOP52 [ (SA657-B036) ]  
 M6MGT33BS8AWG@CSP66 [ (SA642F-B023A-T064F001) ]  
 M6MGT641S16TP@TSOP52 [ (SA657-B036) ]  
 M6MGT641S4TP@TSOP52 [ (SA657-B036) ]  
 M6MGT641S8TP@TSOP52 [ (SA657-B036) ]  
 M6MGT647M34CKT@TSOP52 [ (SA657-B036) ]  
 M6MGT64BM17AWG@CSP67 [ (SA642F-B064A-T064F001) ]  
 M6MGT64BM34CDG@CSP88 [ (SA642CC-B124A-W080F001N) ]  
 M6MGT64BM34CWG@CSP67 [ (SA642F-B064A-T064F001) ]  
 M6MGT64BS4WG@CSP67 [ (SA642F-B023A-T064F001) ]  
 M6MGT64BS8WG@CSP67 [ (SA642F-B023A-T064F001) ]

## DRAM & SRAM

R1LV0408C@SOP32 [ (SA438T) ]                      R1LV0408C@STSOP32  
 [ (SA620) ]  
 R1LV0408C@TSOP32 [ (SA410T) ]

## MICROCONTROLLER

HD4074344@SDIP28 [(SA022A)] HD4074344@SOIC28  
[(SA404)]  
HD4074394@SDIP28 [(SA022A)] HD4074394@SOIC28  
[(SA404)]  
HD6472357F@PQFP128(\*) [(SA720+B262)]  
HD6472655F@PQFP128(\*) [(SA720+B175)]  
HD6472655TE@TQFP128(\*) [(SA721+B174)]  
HD6472655VF@PQFP128(\*) [(SA720+B175)]  
HD6472655VTE@TQFP128(\*) [(SA721+B174)]  
HD6473228P@SDIP64(\*) [(SA736-B229)]  
HD6473238P@SDIP64(\*) [(SA736-B229)]  
HD6473258P@SDIP64(\*) [(SA736-B229)]  
HD6473308@PLCC84(\*) [(SA649-B8406)]  
HD64738024F(FP-80B)(\*) [(TA006-B006)]  
HD64738024H(FP-80A)(\*) [(TA008-B006)]  
HD64738024W(TFP-80C)(\*) [(TA007-B006)]  
HD6473877H@TQFP100(\*) [(SA718+B202)]  
HD6475328@PLCC84(\*) [(SA649-B8404)]  
HD6475348@PLCC84(\*) [(SA649-B8404)]  
HD6477034F@QFP112(\*) [(SA738+B213)]  
HD64F2110BFA@QFP100(\*) [(SA718-B299)]  
HD64F2110BTE@QFP100(\*) [(SA718-B299)]  
HD64F2110BVFA@QFP100(\*) [(SA718-B299)]  
HD64F2110BVTE@QFP100(\*) [(SA718-B299)]  
HD64F2140BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2140BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2141BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2141BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2142RFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2142RTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2142RVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2142RVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144AFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144ATE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144AVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144AVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144FA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144TE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144VFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2144VTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2145BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2145BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147AFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]



HD64F2147ATE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147AVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147AVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147NFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147NTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147NVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2147NVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148AFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148ATE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148AVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148AVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BVFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148BVTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148FA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148TE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148VFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2148VTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2149YFA@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2149YTE@TQFP100(\*) [(SA718+B187 or TA068+B006)]  
HD64F2166VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2167VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2168VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2177VTE33@TQFP144(\*) [(TA047-B084)]  
HD64F2280@PQFP100(\*) [(TA046-B006)]  
HD64F2282@PQFP100(\*) [(TA046-B006)]  
HD64F2326VF@PQFP128(\*) [(SA720+B281)]  
HD64F2326VTE@TQFP120(\*) [(SA721+B282)]  
HD64F2328BVF@PQFP128(\*) [(SA720+B281)]  
HD64F2328BVTE@TQFP120(\*) [(SA721+B282)]  
HD64F2328VF@PQFP128(\*) [(SA720+B281)]  
HD64F2328VTE@TQFP120(\*) [(SA721+B282)]  
HD64F2329BVF@PQFP128(\*) [(SA720+B281)]  
HD64F2329BVTE@TQFP120(\*) [(SA721+B282)]  
HD64F2329EVF@PQFP128(\*) [(SA720+B281)]  
HD64F2329EVTE@TQFP120(\*) [(SA721+B282)]  
HD64F2329VF@PQFP128(\*) [(SA720+B281)]  
HD64F2329VTE@TQFP120(\*) [(SA721+B282)]  
HD64F2338VF@TQFP144(\*) [(SA681+B14415)]  
HD64F2339EVF@TQFP144(\*) [(SA681+B14415)]  
HD64F2339VF@TQFP144(\*) [(SA681+B14415)]  
HD64F2357F@PQFP128(\*) [(SA720+B193)]

HD64F2357TE@QFP120(\*) [(SA721+B194)]  
HD64F2377@TQFP144(\*) [(SA681-B14408)]  
HD64F2377R@TQFP144(\*) [(SA681-B14408)]  
HD64F2378@TQFP144(\*) [(SA681-B14408)]  
HD64F2378R@TQFP144(\*) [(SA681-B14408)]  
HD64F2398F@PQFP128(\*) [(SA720+B193)]  
HD64F2398TE@QFP120(\*) [(SA721+B194)]  
HD64F2505FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2506FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2551FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2552FC26@QFP144(\*) [(SA681+B14403)]  
HD64F2556FC20@QFP144(\*) [(SA681+B14403)]  
HD64F2612FA20@TQFP80(\*) [(SA722+B176)]  
HD64F2615F20@TQFP80(\*) [(SA722+B176)]  
HD64F2615F24@TQFP80(\*) [(SA722+B176)]  
HD64F2646RFC20@QFP144(\*) [(SA681+B14404)]  
HD64F2648RFC20@QFP144 [(SA681+B14404)]  
HD64F2649FC20@QFP144(\*) [(SA681+B14404)]  
HD64F2667VFQ33@QFP144(\*) [(SA681+B14402)]  
HD64F3024F@TQFP100(\*) [(TA029-B006)]  
HD64F3024FP@PQFP100(\*) [(TA030-B006)]  
HD64F3024TE@TQFP100(\*) [(TA029-B006)]  
HD64F3026F@TQFP100(\*) [(TA029-B006)]  
HD64F3026FP@PQFP100(\*) [(TA030-B006)]  
HD64F3026TE@TQFP100(\*) [(TA029-B006)]  
HD64F3048BF@TQFP100(\*) [(TA029-B006)]  
HD64F3048BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3048BVF@TQFP100(\*) [(TA029-B006)]  
HD64F3048BVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3048F@TQFP100(\*) [(TA067+B006)]  
HD64F3048TF@TQFP100(\*) [(TA067+B006)]  
HD64F3048VF@TQFP100(\*) [(TA067+B006)]  
HD64F3048VTF@TQFP100(\*) [(TA067+B006)]  
HD64F3052BF@TQFP100(\*) [(TA029-B006)]  
HD64F3052BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3052BVF@TQFP100(\*) [(TA029-B006)]  
HD64F3052BVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3052F@TQFP100(\*) [(TA029-B006)]  
HD64F3052TE@TQFP100(\*) [(TA029-B006)]  
HD64F3062BF@TQFP100(\*) [(TA029-B006)]  
HD64F3062BFP@PQFP100(\*) [(TA030-B006)]  
HD64F3062BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3062F@TQFP100(\*) [(TA029-B006)]

HD64F3062FP@PQFP100(\*) [(TA030-B006)]  
HD64F3062RF@TQFP100(\*) [(TA029-B006)]  
HD64F3062RFP@PQFP100(\*) [(TA030-B006)]  
HD64F3062RTE@TQFP100(\*) [(TA029-B006)]  
HD64F3062RVF@TQFP100(\*) [(TA029-B006)]  
HD64F3062RVFP@PQFP100(\*) [(TA030-B006)]  
HD64F3062RVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3062TE@TQFP100(\*) [(TA029-B006)]  
HD64F3064BF@TQFP100(\*) [(TA029-B006)]  
HD64F3064BFP@PQFP100(\*) [(TA030-B006)]  
HD64F3064BTE@TQFP100(\*) [(TA029-B006)]  
HD64F3064F@TQFP100(\*) [(TA029-B006)]  
HD64F3064FP@PQFP100(\*) [(TA030-B006)]  
HD64F3064TE@TQFP100(\*) [(TA029-B006)]  
HD64F3067F@TQFP100(\*) [(TA029-B006)]  
HD64F3067FP@PQFP100(\*) [(TA030-B006)]  
HD64F3067RF@TQFP100(\*) [(TA029-B006)]  
HD64F3067RFP@PQFP100(\*) [(TA030-B006)]  
HD64F3067RTE@TQFP100(\*) [(TA029-B006)]  
HD64F3067RVF@TQFP100(\*) [(TA029-B006)]  
HD64F3067RVFP@PQFP100(\*) [(TA030-B006)]  
HD64F3067RVTE@TQFP100(\*) [(TA029-B006)]  
HD64F3067TE@TQFP100(\*) [(TA029-B006)]  
HD64F3068F@TQFP100(\*) [(TA029-B006)]  
HD64F3068TE@TQFP100(\*) [(TA029-B006)]  
HD64F3069F@TQFP100(\*) [(SA718+B271)]  
HD64F3069RF@TQFP100(\*) [(SA718+B271)]  
HD64F3069RTE@TQFP100(\*) [(SA718+B271)]  
HD64F3069TE@TQFP100(\*) [(SA718+B271)]  
HD64F3334YCP16@PLCC84(\*) [(SA649-B8402)]  
HD64F3334YF16@TQFP80(\*) [(TA018-B006)]  
HD64F3334YFLH16@TQFP80(\*) [(TA018-B006)]  
HD64F3334YTF16@TQFP80(\*) [(TA019-B006)]  
HD64F3334YTFLH16@TQFP80(\*) [(TA019-B006)]  
HD64F3337YCP16@PLCC84(\*) [(SA649-B8402)]  
HD64F3337YF16@TQFP80(\*) [(TA018-B006)]  
HD64F3337YFLH16@TQFP80(\*) [(TA018-B006)]  
HD64F3337YTF16@TQFP80(\*) [(TA019-B006)]  
HD64F3337YTFLH16@TQFP80(\*) [(TA019-B006)]  
HD64F3394YCP16@PLCC84(\*) [(SA649-B8402)]  
HD64F3394YF16@TQFP80(\*) [(TA018-B006)]  
HD64F3394YFLH16@TQFP80(\*) [(TA018-B006)]  
HD64F3394YTF16@TQFP80(\*) [(TA019-B006)]

HD64F3394YTF16@TQFP80(\*) [(TA019-B006)]  
HD64F3397CP17@PLCC84(\*) [(SA649-B8402)]  
HD64F3397F17@TQFP80(\*) [(TA018-B006)]  
HD64F3397FLH17@TQFP80(\*) [(TA018-B006)]  
HD64F3397TF17@TQFP80(\*) [(TA019-B006)]  
HD64F3397TFLH17@TQFP80(\*) [(TA019-B006)]  
HD64F3434F@QFP100(\*) [(SA718+B306)]  
HD64F3434TF@QFP100(\*) [(SA718+B306)]  
HD64F3437F@QFP100(\*) [(SA718+B306)]  
HD64F3437TF@QFP100(\*) [(SA718+B306)]  
HD64F36012FX@TQFP48 [(SA671)] HD64F36012FY@TQFP48  
[(SA248)]  
HD64F36012GFP@TQFP64(\*) [(SA732+B313)]  
HD64F36012GFX@TQFP48 [(SA671)] HD64F36012GFY@TQFP48  
[(SA248)]  
HD64F36014FX@TQFP48 [(SA671)] HD64F36014FY@TQFP48  
[(SA248)]  
HD64F36014GFP@TQFP64(\*) [(SA732+B313)]  
HD64F36014GFX@TQFP48 [(SA671)] HD64F36014GFY@TQFP48  
[(SA248)]  
HD64F36022FX@TQFP48 [(SA671)] HD64F36022FY@TQFP48  
[(SA248)]  
HD64F36022GFP@TQFP64(\*) [(SA732+B313)]  
HD64F36022GFX@TQFP48 [(SA671)] HD64F36022GFY@TQFP48  
[(SA248)]  
HD64F36024FX@TQFP48 [(SA671)] HD64F36024FY@TQFP48  
[(SA248)]  
HD64F36024GFP@TQFP64(\*) [(SA732+B313)]  
HD64F36024GFX@TQFP48 [(SA671)] HD64F36024GFY@TQFP48  
[(SA248)]  
HD64F36034FZ@TQFP64(\*) [(TA043-B006)]  
HD64F36034GFZ@TQFP64(\*) [(TA043-B006)]  
HD64F36034GH@TQFP64(\*) [(TA042-B006)]  
HD64F36034H@TQFP64(\*) [(TA042-B006)]  
HD64F36037FZ@TQFP64(\*) [(TA043-B006)]  
HD64F36037GFZ@TQFP64(\*) [(TA043-B006)]  
HD64F36037GH@TQFP64(\*) [(TA042-B006)]  
HD64F36037H@TQFP64(\*) [(TA042-B006)]  
HD64F36054FZ@TQFP64(\*) [(TA043-B006)]  
HD64F36054GFZ@TQFP64(\*) [(TA043-B006)]  
HD64F36054GH@TQFP64(\*) [(TA042-B006)]  
HD64F36054H@TQFP64(\*) [(TA042-B006)]  
HD64F36057FZ@TQFP64(\*) [(TA043-B006)]

HD64F36057GFZ@TQFP64(\*) [(TA043-B006)]  
HD64F36057GH@TQFP64(\*) [(TA042-B006)]  
HD64F36057H@TQFP64(\*) [(TA042-B006)]  
HD64F36064GFP@TQFP64(\*) [(TA043-B006)]  
HD64F36064GH@TQFP64(\*) [(TA042-B006)]  
HD64F36074GFZ@QFP64(\*) [(SA757-B235)]  
HD64F36074GFZW@QFP64(\*) [(SA757-B235)]  
HD64F36074GH@QFP64(\*) [(SA757-B235)]  
HD64F36074GHW@QFP64(\*) [(SA757-B235)]  
HD64F36074LFZ@LQFP64(\*) [(SA732-B235)]  
HD64F36074LFZW@LQFP64(\*) [(SA732-B235)]  
HD64F36074LH@LQFP64(\*) [(SA732-B235)]  
HD64F36074LHW@LQFP64(\*) [(SA732-B235)]  
HD64F36077GFZ@QFP64(\*) [(SA757-B235)]  
HD64F36077GFZW@QFP64(\*) [(SA757-B235)]  
HD64F36077GH@QFP64(\*) [(SA757-B235)]  
HD64F36077GHW@QFP64(\*) [(SA757-B235)]  
HD64F36077LFZ@LQFP64(\*) [(SA732-B235)]  
HD64F36077LFZW@LQFP64(\*) [(SA732-B235)]  
HD64F36077LH@LQFP64(\*) [(SA732-B235)]  
HD64F36077LHW@LQFP64(\*) [(SA732-B235)]  
HD64F36078GFZ@QFP64(\*) [(SA757-B235)]  
HD64F36078GFZW@QFP64(\*) [(SA757-B235)]  
HD64F36078GH@QFP64(\*) [(SA757-B235)]  
HD64F36078GHW@QFP64(\*) [(SA757-B235)]  
HD64F36078LFZ@LQFP64(\*) [(SA732-B235)]  
HD64F36078LFZW@LQFP64(\*) [(SA732-B235)]  
HD64F36078LH@LQFP64(\*) [(SA732-B235)]  
HD64F36078LHW@LQFP64(\*) [(SA732-B235)]  
HD64F36079GFZ@QFP64(\*) [(SA757-B235)]  
HD64F36079GFZW@QFP64(\*) [(SA757-B235)]  
HD64F36079GH@QFP64(\*) [(SA757-B235)]  
HD64F36079GHW@QFP64(\*) [(SA757-B235)]  
HD64F36079LFZ@LQFP64(\*) [(SA732-B235)]  
HD64F36079LFZW@LQFP64(\*) [(SA732-B235)]  
HD64F36079LH@LQFP64(\*) [(SA732-B235)]  
HD64F36079LHW@LQFP64(\*) [(SA732-B235)]  
HD64F3642AH@QFP64(\*) [(SA668+B275)]  
HD64F3642AP@SDIP64(\*) [(SA736+B274)]  
HD64F3642AW@QFP80(\*) [(SA731+B276)]  
HD64F3643H@QFP64(\*) [(SA668+B275)]  
HD64F3643P@SDIP64(\*) [(SA736+B274)]  
HD64F3643W@QFP80(\*) [(SA731+B276)]

HD64F3644H@QFP64(\*) [(SA668+B275)]  
 HD64F3644P@SDIP64(\*) [(SA736+B274)]  
 HD64F3644W@QFP80(\*) [(SA731+B276)]  
 HD64F3664BP@SDIP42 [(SA028)]  
 HD64F3664FP@TQFP64(\*) [(SA732+B224)]  
 HD64F3664FX@TQFP48 [(SA671)] HD64F3664FY@TQFP48  
 [(SA248)]  
 HD64F3684FP@TQFP64(\*) [(TA043-B006)]  
 HD64F3684GFP@TQFP64(\*) [(TA043-B006)]  
 HD64F3684GH@TQFP64(\*) [(TA042-B006)]  
 HD64F3684H@TQFP64(\*) [(TA042-B006)]  
 HD64F3687FP@TQFP64(\*) [(TA043-B006)]  
 HD64F3687GFP@TQFP64(\*) [(TA043-B006)]  
 HD64F3687GH@TQFP64(\*) [(TA042-B006)]  
 HD64F3687H@TQFP64(\*) [(TA042-B006)]  
 HD64F36902G@LQFP32 [(SA663)] HD64F36902G@SOP32  
 [(SA682)]  
 HD64F36912G@LQFP32 [(SA663)] HD64F36912G@SOP32  
 [(SA682)]  
 HD64F3694FX@TQFP48 [(SA671)] HD64F3694FY@TQFP48  
 [(SA248)]  
 HD64F3694GFX@TQFP48 [(SA671)] HD64F3694GFY@TQFP48  
 [(SA248)]  
 HD64F38024F(FP-80B)@PQFP80(\*) [(TA003-B006)]  
 HD64F38024H(FP-80A)@TQFP80(\*) [(TA005-B006)]  
 HD64F38024RF(FP-80B)@PQFP80(\*) [(TA003-B006)]  
 HD64F38024RH(FP-80A)@TQFP80(\*) [(TA005-B006)]  
 HD64F38024RW(TFP-80C)@TQFP80(\*) [(TA004-B006)]  
 HD64F38024W(TFP-80C)@TQFP80(\*) [(TA004-B006)]  
 HD64F38124F(FP-80B)@PQFP80(\*) [(TA003-B006)]  
 HD64F38124H(FP-80A)@TQFP80(\*) [(TA005-B006)]  
 HD64F38124W(TFP-80C)@TQFP80(\*) [(TA004-B006)]  
 HD64F39802G@SDIP32 [(SA653)]  
 HD64F7044F@QFP112(\*) [(SA755+B278)]  
 HD64F7046F@QFP80(\*) [(TA014+B006)]  
 HD64F7047@QFP100(\*) [(SA718+B172)]  
 M30280F6HP@QFP80 [(SA731-B230)] M30280F8HP@QFP80 [(SA731-  
 B230)]  
 M30280FAHP@QFP80 [(SA731-B230)] M30280FATHP@QFP80 [(SA731-  
 B230)]  
 M30280FAVHP@QFP80 [(SA731-B230)] M30280FCHP@QFP80 [(SA731-  
 B230)]  
 M30281F6HP@QFP64 [(SA732-B315)] M30281F8HP@QFP64 [(SA732-

B315) ]  
M30281FAHP@QFP64 [ (SA732-B315) ] M30281FATHP@QFP64 [ (SA732-B315) ]  
M30281FAVHP@QFP64 [ (SA732-B315) ] M30281FCHP@QFP64 [ (SA732-B315) ]  
M30290FAHP@QFP80 [ (SA731-B230) ] M30290FATHP@QFP80 [ (SA731-B230) ]  
M30290FAVHP@QFP80 [ (SA731-B230) ] M30290FCHP@QFP80 [ (SA731-B230) ]  
M30290FCTHP@QFP80 [ (SA731-B230) ] M30290FCVHP@QFP80 [ (SA731-B230) ]  
M30620FCAFP@PQFP100(\*) [ (TA012-B006) ]  
M30620FCAGP@TQFP100(\*) [ (TA013-B006) ]  
M30620FCFP@PQFP100(\*) [ (TA012-B006) ]  
M30620FCGPG@TQFP100(\*) [ (TA013-B006) ]  
M30622F8PFP@PQFP100(\*) [ (TA012-B006) ]  
M30622F8PGP@TQFP100(\*) [ (TA013-B006) ]  
M30624FGAFP@PQFP100(\*) [ (TA012-B006) ]  
M30624FGAGP@TQFP100(\*) [ (TA013-B006) ]  
M30624FGFP@PQFP100(\*) [ (TA012-B006) ]  
M30624FGGPG@TQFP100(\*) [ (TA013-B006) ]  
M30626FHFP@PQFP100(\*) [ (TA012-B006) ]  
M30626FHGPG@TQFP100(\*) [ (TA013-B006) ]  
M30627FHGPG@PQFP128(\*) [ (SA720-B228) ]  
M3062LFGFP@PQFP100(\*) [ (TA012-B006) ]  
M3062LFGGPG@TQFP100(\*) [ (TA013-B006) ]  
M306N4FCFP@PQFP100(\*) [ (TA012-B006) ]  
M306N4FCGP@QFP100(\*) [ (TA013-B006) ]  
M306N4FCTFP@PQFP100(\*) [ (TA012-B006) ]  
M306N4FCTGP@QFP100(\*) [ (TA013-B006) ]  
M306N4FCVFP@PQFP100(\*) [ (TA012-B006) ]  
M306N4FCVGP@QFP100(\*) [ (TA013-B006) ]  
M306N4FGFP@PQFP100(\*) [ (TA012-B006) ]  
M306N4FGGP@QFP100(\*) [ (TA013-B006) ]  
M306N4FGTFP@PQFP100(\*) [ (TA012-B006) ]  
M306N4FGTGP@QFP100(\*) [ (TA013-B006) ]  
M306N4FGVFP@PQFP100(\*) [ (TA012-B006) ]  
M306N4FGVGP@QFP100(\*) [ (TA013-B006) ]  
M306N5FCFP@PQFP100(\*) [ (TA012-B006) ]  
M306N5FCGP@QFP100(\*) [ (TA013-B006) ]  
M306N5FCTFP@PQFP100(\*) [ (TA012-B006) ]  
M306N5FCTGP@QFP100(\*) [ (TA013-B006) ]  
M306N5FCVFP@PQFP100(\*) [ (TA012-B006) ]

M306N5FCVGP@QFP100(\*) [(TA013-B006)]  
M306NKFHGP@QFP100(\*) [(TA013-B006)]  
M306NKFHTGP@QFP100(\*) [(TA013-B006)]  
M306NKFHVGP@QFP100(\*) [(TA013-B006)]  
M306NKFJGP@QFP100(\*) [(TA013-B006)]  
M306NKFJTGP@QFP100(\*) [(TA013-B006)]  
M306NKFJVGP@QFP100(\*) [(TA013-B006)]  
M306NLFHGP@QFP100(\*) [(TA013-B006)]  
M306NLFHTGP@QFP100(\*) [(TA013-B006)]  
M306NLFHVGP@QFP100(\*) [(TA013-B006)]  
M306NLFJGP@QFP100(\*) [(TA013-B006)]  
M306NLFJTGP@QFP100(\*) [(TA013-B006)]  
M306NLFJVGP@QFP100(\*) [(TA013-B006)]  
M306NMFHGP@QFP128(\*) [(SA720-B228)]  
M306NMFHTGP@QFP128(\*) [(SA720-B228)]  
M306NMFHVGP@QFP128(\*) [(SA720-B228)]  
M306NMFJGP@QFP128(\*) [(SA720-B228)]  
M306NMFJTGP@QFP128(\*) [(SA720-B228)]  
M306NMFJVGP@QFP128(\*) [(SA720-B228)]  
M306NNFHGP@QFP128(\*) [(SA720-B228)]  
M306NNFHVGP@QFP128(\*) [(SA720-B228)]  
M306NNFJGP@QFP128(\*) [(SA720-B228)]  
M306NNFJTGP@QFP128(\*) [(SA720-B228)]  
M306NNFJVGP@QFP128(\*) [(SA720-B228)]  
M306NNTFHGP@QFP128(\*) [(SA720-B228)]  
M34282E2GP [(SA026)] M34283G2GP  
[(SA026)]  
M34283G2GP(ISP) [ISP-HEADER01] M34508G4FP  
[(SA023A)]  
M34508G4GP [(SA026)] M34508G4HFP  
[(SA023A)]  
M34508G4HGP [(SA026)] M34509G4FP [(SA711-  
B005)]  
M34509G4HFP [(SA711-B005)] M37544G2A(GP)@LQFP32  
[(SA663)]  
M37544G2A(GP)@LQFP32(ISP) [ISP-HEADER01]  
M37544G2A(SP)@SDIP32 [(SA653)]  
M37544G2A(SP)@SDIP32(ISP) [ISP-HEADER01]  
M37545G4(GP)@LQFP32 [(SA663)] M37545G6(GP)@LQFP32  
[(SA663)]  
M37545G8(GP)@LQFP32 [(SA663)] M37546G2(FP)@SSOP36  
[(SA645)]  
M37546G2(FP)@SSOP36(ISP) [ISP-HEADER01]



M37546G2(GP)@LQFP32 [(SA663)]  
M37546G2(GP)@LQFP32(ISP) [ISP-HEADER01]  
M37546G2(SP)@SDIP32 [(SA653)]  
M37546G2(SP)@SDIP32(ISP) [ISP-HEADER01]  
M37546G4(FP)@SSOP36 [(SA645)]  
M37546G4(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37546G4(GP)@LQFP32 [(SA663)]  
M37546G4(GP)@LQFP32(ISP) [ISP-HEADER01]  
M37546G4(SP)@SDIP32 [(SA653)]  
M37546G4(SP)@SDIP32(ISP) [ISP-HEADER01]  
M37547G2(FP)@SSOP36 [(SA645)]  
M37547G2(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37547G4(FP)@SSOP36 [(SA645)]  
M37547G4(FP)@SSOP36(ISP) [ISP-HEADER01]  
M37548G1(FP)@TSSOP20 [(SA026)] M37548G2(FP)@TSSOP20  
[(SA026)]  
M37548G3(FP)@TSSOP20 [(SA026)] M37549G1FP@SDIP24  
[(SA653)]  
M37549G2FP@SDIP24 [(SA653)] M37549G3FP@SDIP24  
[(SA653)]  
M38234G4(FP)@PQFP80 [(SA730+B191)]  
M38234G4(HP)@TQFP80 [(SA731+B192)]  
M38235G6(FP)@PQFP80 [(SA730+B191)]  
M38235G6(HP)@TQFP80 [(SA731+B192)]  
M38238G8(FP)@PQFP80 [(SA730+B191)]  
M38238G8(HP)@TQFP80 [(SA731+B192)]  
M38239GC(FP)@PQFP80 [(SA730+B191)]  
M38239GC(HP)@TQFP80 [(SA731+B192)]  
M3823AGF(FP)@PQFP80 [(SA730+B191)]  
M3823AGF(HP)@TQFP80 [(SA731+B192)]  
M38503G4A(FP)@SSOP42 [(SA645)] M38503G4A(SP)@SDIP42  
[(SA028)]  
M38507F8(FP)@SSOP42 [(SA645)] M38507F8(SP)@SDIP42  
[(SA028)]  
M38588G6(FP)@SSOP42 [(SA645)] M38588G6(SP)@SDIP42  
[(SA028)]  
M38588G8(FP)@SSOP42 [(SA645)] M38588G8(SP)@SDIP42  
[(SA028)]  
M38588GC(FP)@SSOP42 [(SA645)] M38588GC(SP)@SDIP42  
[(SA028)]  
M3NN00FETGP@QFP100(\*) [(TA013-B006)]  
R5F21102DFP@TQFP32 [(SA663+B005)]  
R5F21102DFP@TQFP32(ISP) [ISP-HEADER01]

R5F21102FP@TQFP32 [(SA663+B005)]  
R5F21102FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21103DFP@TQFP32 [(SA663+B005)]  
R5F21103DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21103FP@TQFP32 [(SA663+B005)]  
R5F21103FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21104DFP@TQFP32 [(SA663+B005)]  
R5F21104DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21104FP@TQFP32 [(SA663+B005)]  
R5F21104FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21112DFP@TQFP32 [(SA663+B005)]  
R5F21112DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21112FP@TQFP32 [(SA663+B005)]  
R5F21112FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21113DFP@TQFP32 [(SA663+B005)]  
R5F21113DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21113FP@TQFP32 [(SA663+B005)]  
R5F21113FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21114DFP@TQFP32 [(SA663+B005)]  
R5F21114DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21114FP@TQFP32 [(SA663+B005)]  
R5F21114FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21122DFP@TQFP32 [(SA663+B005)]  
R5F21122DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21122FP@TQFP32 [(SA663+B005)]  
R5F21122FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21123DFP@TQFP32 [(SA663+B005)]  
R5F21123DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21123FP@TQFP32 [(SA663+B005)]  
R5F21123FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21124DFP@TQFP32 [(SA663+B005)]  
R5F21124DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21124FP@TQFP32 [(SA663+B005)]  
R5F21124FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21132DFP@TQFP32 [(SA663+B005)]  
R5F21132DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21132FP@TQFP32 [(SA663+B005)]  
R5F21132FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133DFP@TQFP32 [(SA663+B005)]  
R5F21133DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21133FP@TQFP32 [(SA663+B005)]  
R5F21133FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21134DFP@TQFP32 [(SA663+B005)]

R5F21134DFP@TQFP32(ISP) [ISP-HEADER01]  
R5F21134FP@TQFP32 [(SA663+B005)]  
R5F21134FP@TQFP32(ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20 [(SA725+B005)]  
R5F21181DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20(single wire) [(SA725+B005)]  
R5F21181DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21181DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21181DSP@TSSOP20 [(SA026+B001)]  
R5F21181DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21181DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21181DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21181SP@TSSOP20 [(SA026+B001)]  
R5F21181SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21181SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21181SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182DD@SDIP20 [(SA725+B005)]  
R5F21182DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(single wire) [(SA725+B005)]  
R5F21182DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21182DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21182DSP@TSSOP20 [(SA026+B001)]  
R5F21182DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21182DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21182DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21182NP@QFN28 [(SA697+B006)]  
R5F21182NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(single wire) [(SA697+B006)]  
R5F21182NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21182NP@QFN28(UART mode) [(SA697+B006)]  
R5F21182SP@TSSOP20 [(SA026+B001)]  
R5F21182SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21182SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21182SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21182SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183DD@SDIP20 [(SA725+B005)]  
R5F21183DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(single wire) [(SA725+B005)]  
R5F21183DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21183DD@SDIP20(UART mode) [(SA725+B005)]

R5F21183DSP@TSSOP20 [(SA026+B001)]  
R5F21183DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21183DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21183NP@QFN28 [(SA697+B006)]  
R5F21183NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(single wire) [(SA697+B006)]  
R5F21183NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21183NP@QFN28(UART mode) [(SA697+B006)]  
R5F21183SP@TSSOP20 [(SA026+B001)]  
R5F21183SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21183SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21183SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184DD@SDIP20 [(SA725+B005)]  
R5F21184DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(single wire) [(SA725+B005)]  
R5F21184DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21184DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21184DSP@TSSOP20 [(SA026+B001)]  
R5F21184DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21184DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21184NP@QFN28 [(SA697+B006)]  
R5F21184NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(single wire) [(SA697+B006)]  
R5F21184NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21184NP@QFN28(UART mode) [(SA697+B006)]  
R5F21184SP@TSSOP20 [(SA026+B001)]  
R5F21184SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21184SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21184SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191DD@SDIP20 [(SA725+B005)]  
R5F21191DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(single wire) [(SA725+B005)]  
R5F21191DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21191DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21191DSP@TSSOP20 [(SA026+B001)]  
R5F21191DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(single wire) [(SA026+B001)]

R5F21191DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21191SP@TSSOP20 [(SA026+B001)]  
R5F21191SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21191SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21191SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192DD@SDIP20 [(SA725+B005)]  
R5F21192DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(single wire) [(SA725+B005)]  
R5F21192DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21192DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21192DSP@TSSOP20 [(SA026+B001)]  
R5F21192DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21192NP@QFN28 [(SA697+B006)]  
R5F21192NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(single wire) [(SA697+B006)]  
R5F21192NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21192NP@QFN28(UART mode) [(SA697+B006)]  
R5F21192SP@TSSOP20 [(SA026+B001)]  
R5F21192SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21192SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21192SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193DD@SDIP20 [(SA725+B005)]  
R5F21193DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(single wire) [(SA725+B005)]  
R5F21193DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21193DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21193DSP@TSSOP20 [(SA026+B001)]  
R5F21193DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21193NP@QFN28 [(SA697+B006)]  
R5F21193NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(single wire) [(SA697+B006)]  
R5F21193NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21193NP@QFN28(UART mode) [(SA697+B006)]  
R5F21193SP@TSSOP20 [(SA026+B001)]

R5F21193SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21193SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21193SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194DD@SDIP20 [(SA725+B005)]  
R5F21194DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(single wire) [(SA725+B005)]  
R5F21194DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F21194DD@SDIP20(UART mode) [(SA725+B005)]  
R5F21194DSP@TSSOP20 [(SA026+B001)]  
R5F21194DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21194NP@QFN28 [(SA697+B006)]  
R5F21194NP@QFN28(single ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(single wire) [(SA697+B006)]  
R5F21194NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F21194NP@QFN28(UART mode) [(SA697+B006)]  
R5F21194SP@TSSOP20 [(SA026+B001)]  
R5F21194SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(single wire) [(SA026+B001)]  
R5F21194SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F21194SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1DD@SDIP20 [(SA725+B005)]  
R5F211A1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(single wire) [(SA725+B005)]  
R5F211A1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A1DSP@TSSOP20 [(SA026+B001)]  
R5F211A1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A1SP@TSSOP20 [(SA026+B001)]  
R5F211A1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2DD@SDIP20 [(SA725+B005)]  
R5F211A2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A2DD@SDIP20(single wire) [(SA725+B005)]  
R5F211A2DD@SDIP20(UART ISP) [ISP-HEADER01]

R5F211A2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A2DSP@TSSOP20 [(SA026+B001)]  
R5F211A2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A2NP@QFN28 [(SA697+B006)]  
R5F211A2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(single wire) [(SA697+B006)]  
R5F211A2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A2NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A2SP@TSSOP20 [(SA026+B001)]  
R5F211A2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3DD@SDIP20 [(SA725+B005)]  
R5F211A3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(single wire) [(SA725+B005)]  
R5F211A3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A3DSP@TSSOP20 [(SA026+B001)]  
R5F211A3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A3NP@QFN28 [(SA697+B006)]  
R5F211A3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(single wire) [(SA697+B006)]  
R5F211A3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A3SP@TSSOP20 [(SA026+B001)]  
R5F211A3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4DD@SDIP20 [(SA725+B005)]  
R5F211A4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(single wire) [(SA725+B005)]  
R5F211A4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211A4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211A4DSP@TSSOP20 [(SA026+B001)]  
R5F211A4DSP@TSSOP20(single ISP) [ISP-HEADER01]

R5F211A4DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211A4NP@QFN28 [(SA697+B006)]  
R5F211A4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(single wire) [(SA697+B006)]  
R5F211A4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211A4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211A4SP@TSSOP20 [(SA026+B001)]  
R5F211A4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211A4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211A4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1DD@SDIP20 [(SA725+B005)]  
R5F211B1DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B1DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B1DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B1DSP@TSSOP20 [(SA026+B001)]  
R5F211B1DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B1SP@TSSOP20 [(SA026+B001)]  
R5F211B1SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B1SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B1SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2DD@SDIP20 [(SA725+B005)]  
R5F211B2DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B2DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B2DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B2DSP@TSSOP20 [(SA026+B001)]  
R5F211B2DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B2NP@QFN28 [(SA697+B006)]  
R5F211B2NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(single wire) [(SA697+B006)]  
R5F211B2NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B2NP@QFN28(UART mode) [(SA697+B006)]



R5F211B2SP@TSSOP20 [(SA026+B001)]  
R5F211B2SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B2SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B2SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3DD@SDIP20 [(SA725+B005)]  
R5F211B3DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B3DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B3DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B3DSP@TSSOP20 [(SA026+B001)]  
R5F211B3DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B3NP@QFN28 [(SA697+B006)]  
R5F211B3NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(single wire) [(SA697+B006)]  
R5F211B3NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B3NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B3SP@TSSOP20 [(SA026+B001)]  
R5F211B3SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B3SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B3SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4DD@SDIP20 [(SA725+B005)]  
R5F211B4DD@SDIP20(single ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(single wire) [(SA725+B005)]  
R5F211B4DD@SDIP20(UART ISP) [ISP-HEADER01]  
R5F211B4DD@SDIP20(UART mode) [(SA725+B005)]  
R5F211B4DSP@TSSOP20 [(SA026+B001)]  
R5F211B4DSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(single wire) [(SA026+B001)]  
R5F211B4DSP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4DSP@TSSOP20(UART mode) [(SA026+B001)]  
R5F211B4NP@QFN28 [(SA697+B006)]  
R5F211B4NP@QFN28(single ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(single wire) [(SA697+B006)]  
R5F211B4NP@QFN28(UART ISP) [ISP-HEADER01]  
R5F211B4NP@QFN28(UART mode) [(SA697+B006)]  
R5F211B4SP@TSSOP20 [(SA026+B001)]  
R5F211B4SP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(single wire) [(SA026+B001)]

R5F211B4SP@TSSOP20(UART ISP) [ISP-HEADER01]  
R5F211B4SP@TSSOP20(UART mode) [(SA026+B001)]  
R5F21244SDFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21244SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21244SDFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21244SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21244SDFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21244SNFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21244SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21244SNFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21244SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21244SNFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21246SDFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21246SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21246SDFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21246SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21246SDFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21246SNFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21246SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21246SNFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21246SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21246SNFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21247SDFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21247SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21247SDFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21247SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21247SDFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21247SNFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21247SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21247SNFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21247SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21247SNFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21248SDFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21248SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21248SDFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21248SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21248SDFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21248SNFP@TQFP52(parallel)(\*) [(SA740+B225)]  
R5F21248SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21248SNFP@TQFP52(single)(\*) [(SA740+B225)]  
R5F21248SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21248SNFP@TQFP52(UART)(\*) [(SA740+B225)]  
R5F21254SDFP@TQFP52(single ISP) [ISP-HEADER01]

R5F21254SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21254SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21254SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21256SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21256SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21256SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21256SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21257SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21257SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SDFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(single ISP) [ISP-HEADER01]  
R5F21258SNFP@TQFP52(UART ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32 [(SA663)]  
R5F21262DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(single wire) [(SA663)]  
R5F21262DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262DFP@QFP32(UART mode) [(SA663)]  
R5F21262JFP@QFP32 [(SA663)]  
R5F21262JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(single wire) [(SA663)]  
R5F21262JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262JFP@QFP32(UART mode) [(SA663)]  
R5F21262KFP@QFP32 [(SA663)]  
R5F21262KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262KFP@QFP32(single wire) [(SA663)]  
R5F21262KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262KFP@QFP32(UART mode) [(SA663)]  
R5F21262NFP@QFP32 [(SA663)]  
R5F21262NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(single wire) [(SA663)]  
R5F21262NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262NFP@QFP32(UART mode) [(SA663)]  
R5F21262SDFP@QFP32 [(SA663)]  
R5F21262SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(single wire) [(SA663)]  
R5F21262SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SDFP@QFP32(UART mode) [(SA663)]  
R5F21262SJFP@QFP32 [(SA663)]  
R5F21262SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(single wire) [(SA663)]

R5F21262SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SJFP@QFP32(UART mode) [(SA663)]  
R5F21262SKFP@QFP32 [(SA663)]  
R5F21262SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(single wire) [(SA663)]  
R5F21262SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SKFP@QFP32(UART mode) [(SA663)]  
R5F21262SNFP@QFP32 [(SA663)]  
R5F21262SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(single wire) [(SA663)]  
R5F21262SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21262SNFP@QFP32(UART mode) [(SA663)]  
R5F21264DFP@QFP32 [(SA663)]  
R5F21264DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264DFP@QFP32(single wire) [(SA663)]  
R5F21264DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264DFP@QFP32(UART mode) [(SA663)]  
R5F21264JFP@QFP32 [(SA663)]  
R5F21264JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(single wire) [(SA663)]  
R5F21264JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264JFP@QFP32(UART mode) [(SA663)]  
R5F21264KFP@QFP32 [(SA663)]  
R5F21264KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(single wire) [(SA663)]  
R5F21264KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264KFP@QFP32(UART mode) [(SA663)]  
R5F21264NFP@QFP32 [(SA663)]  
R5F21264NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264NFP@QFP32(single wire) [(SA663)]  
R5F21264NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264NFP@QFP32(UART mode) [(SA663)]  
R5F21264SDFP@QFP32 [(SA663)]  
R5F21264SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SDFP@QFP32(single wire) [(SA663)]  
R5F21264SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SDFP@QFP32(UART mode) [(SA663)]  
R5F21264SJFP@QFP32 [(SA663)]  
R5F21264SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(single wire) [(SA663)]  
R5F21264SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SJFP@QFP32(UART mode) [(SA663)]  
R5F21264SKFP@QFP32 [(SA663)]

R5F21264SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(single wire) [(SA663)]  
R5F21264SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SKFP@QFP32(UART mode) [(SA663)]  
R5F21264SNFP@QFP32 [(SA663)]  
R5F21264SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(single wire) [(SA663)]  
R5F21264SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21264SNFP@QFP32(UART mode) [(SA663)]  
R5F21265DFP@QFP32 [(SA663)]  
R5F21265DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(single wire) [(SA663)]  
R5F21265DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265DFP@QFP32(UART mode) [(SA663)]  
R5F21265JFP@QFP32 [(SA663)]  
R5F21265JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(single wire) [(SA663)]  
R5F21265JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265JFP@QFP32(UART mode) [(SA663)]  
R5F21265KFP@QFP32 [(SA663)]  
R5F21265KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(single wire) [(SA663)]  
R5F21265KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265KFP@QFP32(UART mode) [(SA663)]  
R5F21265NFP@QFP32 [(SA663)]  
R5F21265NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(single wire) [(SA663)]  
R5F21265NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265NFP@QFP32(UART mode) [(SA663)]  
R5F21265SDFP@QFP32 [(SA663)]  
R5F21265SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(single wire) [(SA663)]  
R5F21265SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SDFP@QFP32(UART mode) [(SA663)]  
R5F21265SJFP@QFP32 [(SA663)]  
R5F21265SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(single wire) [(SA663)]  
R5F21265SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SJFP@QFP32(UART mode) [(SA663)]  
R5F21265SKFP@QFP32 [(SA663)]  
R5F21265SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SKFP@QFP32(single wire) [(SA663)]  
R5F21265SKFP@QFP32(UART ISP) [ISP-HEADER01]

R5F21265SKFP@QFP32(UART mode) [(SA663)]  
R5F21265SNFP@QFP32 [(SA663)]  
R5F21265SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(single wire) [(SA663)]  
R5F21265SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21265SNFP@QFP32(UART mode) [(SA663)]  
R5F21266DFP@QFP32 [(SA663)]  
R5F21266DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(single wire) [(SA663)]  
R5F21266DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266DFP@QFP32(UART mode) [(SA663)]  
R5F21266JFP@QFP32 [(SA663)]  
R5F21266JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(single wire) [(SA663)]  
R5F21266JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266JFP@QFP32(UART mode) [(SA663)]  
R5F21266KFP@QFP32 [(SA663)]  
R5F21266KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(single wire) [(SA663)]  
R5F21266KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266KFP@QFP32(UART mode) [(SA663)]  
R5F21266NFP@QFP32 [(SA663)]  
R5F21266NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(single wire) [(SA663)]  
R5F21266NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266NFP@QFP32(UART mode) [(SA663)]  
R5F21266SDFP@QFP32 [(SA663)]  
R5F21266SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(single wire) [(SA663)]  
R5F21266SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SDFP@QFP32(UART mode) [(SA663)]  
R5F21266SJFP@QFP32 [(SA663)]  
R5F21266SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(single wire) [(SA663)]  
R5F21266SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SJFP@QFP32(UART mode) [(SA663)]  
R5F21266SKFP@QFP32 [(SA663)]  
R5F21266SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(single wire) [(SA663)]  
R5F21266SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SKFP@QFP32(UART mode) [(SA663)]  
R5F21266SNFP@QFP32 [(SA663)]  
R5F21266SNFP@QFP32(single ISP) [ISP-HEADER01]

R5F21266SNFP@QFP32(single wire) [(SA663)]  
R5F21266SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21266SNFP@QFP32(UART mode) [(SA663)]  
R5F21272DFP@QFP32 [(SA663)]  
R5F21272DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272DFP@QFP32(single wire) [(SA663)]  
R5F21272DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272DFP@QFP32(UART mode) [(SA663)]  
R5F21272JFP@QFP32 [(SA663)]  
R5F21272JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(single wire) [(SA663)]  
R5F21272JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272JFP@QFP32(UART mode) [(SA663)]  
R5F21272KFP@QFP32 [(SA663)]  
R5F21272KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272KFP@QFP32(single wire) [(SA663)]  
R5F21272KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272KFP@QFP32(UART mode) [(SA663)]  
R5F21272NFP@QFP32 [(SA663)]  
R5F21272NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(single wire) [(SA663)]  
R5F21272NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272NFP@QFP32(UART mode) [(SA663)]  
R5F21272SDFP@QFP32 [(SA663)]  
R5F21272SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(single wire) [(SA663)]  
R5F21272SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SDFP@QFP32(UART mode) [(SA663)]  
R5F21272SJFP@QFP32 [(SA663)]  
R5F21272SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(single wire) [(SA663)]  
R5F21272SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SJFP@QFP32(UART mode) [(SA663)]  
R5F21272SKFP@QFP32 [(SA663)]  
R5F21272SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(single wire) [(SA663)]  
R5F21272SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SKFP@QFP32(UART mode) [(SA663)]  
R5F21272SNFP@QFP32 [(SA663)]  
R5F21272SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(single wire) [(SA663)]  
R5F21272SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21272SNFP@QFP32(UART mode) [(SA663)]

R5F21274DFP@QFP32 [(SA663)]  
R5F21274DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(single wire) [(SA663)]  
R5F21274DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274DFP@QFP32(UART mode) [(SA663)]  
R5F21274JFP@QFP32 [(SA663)]  
R5F21274JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(single wire) [(SA663)]  
R5F21274JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274JFP@QFP32(UART mode) [(SA663)]  
R5F21274KFP@QFP32 [(SA663)]  
R5F21274KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(single wire) [(SA663)]  
R5F21274KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274KFP@QFP32(UART mode) [(SA663)]  
R5F21274NFP@QFP32 [(SA663)]  
R5F21274NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(single wire) [(SA663)]  
R5F21274NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274NFP@QFP32(UART mode) [(SA663)]  
R5F21274SDFP@QFP32 [(SA663)]  
R5F21274SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(single wire) [(SA663)]  
R5F21274SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SDFP@QFP32(UART mode) [(SA663)]  
R5F21274SJFP@QFP32 [(SA663)]  
R5F21274SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SJFP@QFP32(single wire) [(SA663)]  
R5F21274SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SJFP@QFP32(UART mode) [(SA663)]  
R5F21274SKFP@QFP32 [(SA663)]  
R5F21274SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SKFP@QFP32(single wire) [(SA663)]  
R5F21274SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SKFP@QFP32(UART mode) [(SA663)]  
R5F21274SNFP@QFP32 [(SA663)]  
R5F21274SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21274SNFP@QFP32(single wire) [(SA663)]  
R5F21274SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21274SNFP@QFP32(UART mode) [(SA663)]  
R5F21275DFP@QFP32 [(SA663)]  
R5F21275DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275DFP@QFP32(single wire) [(SA663)]



R5F21275DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275DFP@QFP32(UART mode) [(SA663)]  
R5F21275JFP@QFP32 [(SA663)]  
R5F21275JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(single wire) [(SA663)]  
R5F21275JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275JFP@QFP32(UART mode) [(SA663)]  
R5F21275KFP@QFP32 [(SA663)]  
R5F21275KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(single wire) [(SA663)]  
R5F21275KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275KFP@QFP32(UART mode) [(SA663)]  
R5F21275NFP@QFP32 [(SA663)]  
R5F21275NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275NFP@QFP32(single wire) [(SA663)]  
R5F21275NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275NFP@QFP32(UART mode) [(SA663)]  
R5F21275SDFP@QFP32 [(SA663)]  
R5F21275SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(single wire) [(SA663)]  
R5F21275SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SDFP@QFP32(UART mode) [(SA663)]  
R5F21275SJFP@QFP32 [(SA663)]  
R5F21275SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(single wire) [(SA663)]  
R5F21275SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SJFP@QFP32(UART mode) [(SA663)]  
R5F21275SKFP@QFP32 [(SA663)]  
R5F21275SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SKFP@QFP32(single wire) [(SA663)]  
R5F21275SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SKFP@QFP32(UART mode) [(SA663)]  
R5F21275SNFP@QFP32 [(SA663)]  
R5F21275SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21275SNFP@QFP32(single wire) [(SA663)]  
R5F21275SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21275SNFP@QFP32(UART mode) [(SA663)]  
R5F21276DFP@QFP32 [(SA663)]  
R5F21276DFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(single wire) [(SA663)]  
R5F21276DFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276DFP@QFP32(UART mode) [(SA663)]  
R5F21276JFP@QFP32 [(SA663)]

R5F21276JFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(single wire) [(SA663)]  
R5F21276JFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276JFP@QFP32(UART mode) [(SA663)]  
R5F21276KFP@QFP32 [(SA663)]  
R5F21276KFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(single wire) [(SA663)]  
R5F21276KFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276KFP@QFP32(UART mode) [(SA663)]  
R5F21276NFP@QFP32 [(SA663)]  
R5F21276NFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(single wire) [(SA663)]  
R5F21276NFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276NFP@QFP32(UART mode) [(SA663)]  
R5F21276SDFP@QFP32 [(SA663)]  
R5F21276SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SDFP@QFP32(single wire) [(SA663)]  
R5F21276SDFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SDFP@QFP32(UART mode) [(SA663)]  
R5F21276SJFP@QFP32 [(SA663)]  
R5F21276SJFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(single wire) [(SA663)]  
R5F21276SJFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SJFP@QFP32(UART mode) [(SA663)]  
R5F21276SKFP@QFP32 [(SA663)]  
R5F21276SKFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(single wire) [(SA663)]  
R5F21276SKFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SKFP@QFP32(UART mode) [(SA663)]  
R5F21276SNFP@QFP32 [(SA663)]  
R5F21276SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(single wire) [(SA663)]  
R5F21276SNFP@QFP32(UART ISP) [ISP-HEADER01]  
R5F21276SNFP@QFP32(UART mode) [(SA663)]  
R5F21282DSP@SOIC20 [(SA026)]  
R5F21282DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(single wire) [(SA026)]  
R5F21282DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282DSP@SOIC20(UART mode) [(SA026)]  
R5F21282JSP@SOIC20 [(SA026)]  
R5F21282JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282JSP@SOIC20(single wire) [(SA026)]  
R5F21282JSP@SOIC20(UART ISP) [ISP-HEADER01]

R5F21282JSP@SOIC20(UART mode) [(SA026)]  
R5F21282KSP@SOIC20 [(SA026)]  
R5F21282KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(single wire) [(SA026)]  
R5F21282KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282KSP@SOIC20(UART mode) [(SA026)]  
R5F21282NSP@SOIC20 [(SA026)]  
R5F21282NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(single wire) [(SA026)]  
R5F21282NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282NSP@SOIC20(UART mode) [(SA026)]  
R5F21282SDSP@SOIC20 [(SA026)]  
R5F21282SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(single wire) [(SA026)]  
R5F21282SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SDSP@SOIC20(UART mode) [(SA026)]  
R5F21282SJSP@SOIC20 [(SA026)]  
R5F21282SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(single wire) [(SA026)]  
R5F21282SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SJSP@SOIC20(UART mode) [(SA026)]  
R5F21282SKSP@SOIC20 [(SA026)]  
R5F21282SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(single wire) [(SA026)]  
R5F21282SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SKSP@SOIC20(UART mode) [(SA026)]  
R5F21282SNSP@SOIC20 [(SA026)]  
R5F21282SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(single wire) [(SA026)]  
R5F21282SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21282SNSP@SOIC20(UART mode) [(SA026)]  
R5F21284DSP@SOIC20 [(SA026)]  
R5F21284DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(single wire) [(SA026)]  
R5F21284DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284DSP@SOIC20(UART mode) [(SA026)]  
R5F21284JSP@SOIC20 [(SA026)]  
R5F21284JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(single wire) [(SA026)]  
R5F21284JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284JSP@SOIC20(UART mode) [(SA026)]  
R5F21284KSP@SOIC20 [(SA026)]  
R5F21284KSP@SOIC20(single ISP) [ISP-HEADER01]

R5F21284KSP@SOIC20(single wire) [(SA026)]  
R5F21284KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284KSP@SOIC20(UART mode) [(SA026)]  
R5F21284NSP@SOIC20 [(SA026)]  
R5F21284NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(single wire) [(SA026)]  
R5F21284NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284NSP@SOIC20(UART mode) [(SA026)]  
R5F21284SDSP@SOIC20 [(SA026)]  
R5F21284SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(single wire) [(SA026)]  
R5F21284SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SDSP@SOIC20(UART mode) [(SA026)]  
R5F21284SJSP@SOIC20 [(SA026)]  
R5F21284SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(single wire) [(SA026)]  
R5F21284SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SJSP@SOIC20(UART mode) [(SA026)]  
R5F21284SKSP@SOIC20 [(SA026)]  
R5F21284SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(single wire) [(SA026)]  
R5F21284SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SKSP@SOIC20(UART mode) [(SA026)]  
R5F21284SNSP@SOIC20 [(SA026)]  
R5F21284SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(single wire) [(SA026)]  
R5F21284SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21284SNSP@SOIC20(UART mode) [(SA026)]  
R5F21292DSP@SOIC20 [(SA026)]  
R5F21292DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(single wire) [(SA026)]  
R5F21292DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292DSP@SOIC20(UART mode) [(SA026)]  
R5F21292JSP@SOIC20 [(SA026)]  
R5F21292JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(single wire) [(SA026)]  
R5F21292JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292JSP@SOIC20(UART mode) [(SA026)]  
R5F21292KSP@SOIC20 [(SA026)]  
R5F21292KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(single wire) [(SA026)]  
R5F21292KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292KSP@SOIC20(UART mode) [(SA026)]

R5F21292NSP@SOIC20 [(SA026)]  
R5F21292NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(single wire) [(SA026)]  
R5F21292NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292NSP@SOIC20(UART mode) [(SA026)]  
R5F21292SDSP@SOIC20 [(SA026)]  
R5F21292SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(single wire) [(SA026)]  
R5F21292SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SDSP@SOIC20(UART mode) [(SA026)]  
R5F21292SJSP@SOIC20 [(SA026)]  
R5F21292SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(single wire) [(SA026)]  
R5F21292SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SJSP@SOIC20(UART mode) [(SA026)]  
R5F21292SKSP@SOIC20 [(SA026)]  
R5F21292SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(single wire) [(SA026)]  
R5F21292SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SKSP@SOIC20(UART mode) [(SA026)]  
R5F21292SNSP@SOIC20 [(SA026)]  
R5F21292SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(single wire) [(SA026)]  
R5F21292SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21292SNSP@SOIC20(UART mode) [(SA026)]  
R5F21294DSP@SOIC20 [(SA026)]  
R5F21294DSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294DSP@SOIC20(single wire) [(SA026)]  
R5F21294DSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294DSP@SOIC20(UART mode) [(SA026)]  
R5F21294JSP@SOIC20 [(SA026)]  
R5F21294JSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(single wire) [(SA026)]  
R5F21294JSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294JSP@SOIC20(UART mode) [(SA026)]  
R5F21294KSP@SOIC20 [(SA026)]  
R5F21294KSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(single wire) [(SA026)]  
R5F21294KSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294KSP@SOIC20(UART mode) [(SA026)]  
R5F21294NSP@SOIC20 [(SA026)]  
R5F21294NSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(single wire) [(SA026)]

R5F21294NSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294NSP@SOIC20(UART mode) [(SA026)]  
R5F21294SDSP@SOIC20 [(SA026)]  
R5F21294SDSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(single wire) [(SA026)]  
R5F21294SDSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SDSP@SOIC20(UART mode) [(SA026)]  
R5F21294SJSP@SOIC20 [(SA026)]  
R5F21294SJSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SJSP@SOIC20(single wire) [(SA026)]  
R5F21294SJSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SJSP@SOIC20(UART mode) [(SA026)]  
R5F21294SKSP@SOIC20 [(SA026)]  
R5F21294SKSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SKSP@SOIC20(single wire) [(SA026)]  
R5F21294SKSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SKSP@SOIC20(UART mode) [(SA026)]  
R5F21294SNSP@SOIC20 [(SA026)]  
R5F21294SNSP@SOIC20(single ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(single wire) [(SA026)]  
R5F21294SNSP@SOIC20(UART ISP) [ISP-HEADER01]  
R5F21294SNSP@SOIC20(UART mode) [(SA026)]  
R5F212A7SDFA@TQFP64 [(SA768+B251)]  
R5F212A7SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212A7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A7SDFP@TQFP64 [(SA732+B251)]  
R5F212A7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212A7SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212A7SNFA@TQFP64 [(SA768+B251)]  
R5F212A7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212A7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A7SNFP@TQFP64 [(SA732+B251)]  
R5F212A7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A7SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212A7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A7SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212A8SDFA@TQFP64 [(SA768+B251)]

R5F212A8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212A8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A8SDFP@TQFP64 [(SA732+B251)]  
R5F212A8SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212A8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212A8SNFA@TQFP64 [(SA768+B251)]  
R5F212A8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212A8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212A8SNFP@TQFP64 [(SA732+B251)]  
R5F212A8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212A8SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212A8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212A8SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212AASDFA@TQFP64 [(SA768+B251)]  
R5F212AASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212AASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212AASDFP@TQFP64 [(SA732+B251)]  
R5F212AASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212AASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212AASNFA@TQFP64 [(SA768+B251)]  
R5F212AASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212AASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212AASNFP@TQFP64 [(SA732+B251)]  
R5F212AASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212AASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212AASNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212ACSDFA@TQFP64 [(SA768+B251)]  
R5F212ACSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212ACSDFA@TQFP64(UART ISP) [ISP-HEADER01]

R5F212ACSDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212ACSDFP@TQFP64 [(SA732+B251)]  
R5F212ACSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212ACSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212ACSNFA@TQFP64 [(SA768+B251)]  
R5F212ACSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212ACSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212ACSNFP@TQFP64 [(SA732+B251)]  
R5F212ACSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212ACSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212ACSNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B7SDFA@TQFP64 [(SA768+B251)]  
R5F212B7SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B7SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B7SDFP@TQFP64 [(SA732+B251)]  
R5F212B7SDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B7SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B7SNFA@TQFP64 [(SA768+B251)]  
R5F212B7SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B7SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B7SNFP@TQFP64 [(SA732+B251)]  
R5F212B7SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B7SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B7SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B8SDFA@TQFP64 [(SA768+B251)]  
R5F212B8SDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B8SDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B8SDFP@TQFP64 [(SA732+B251)]  
R5F212B8SDFP@TQFP64(single ISP) [ISP-HEADER01]



R5F212B8SDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B8SDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212B8SNFA@TQFP64 [(SA768+B251)]  
R5F212B8SNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212B8SNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212B8SNFP@TQFP64 [(SA732+B251)]  
R5F212B8SNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212B8SNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212B8SNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BASDFA@TQFP64 [(SA768+B251)]  
R5F212BASDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BASDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BASDFP@TQFP64 [(SA732+B251)]  
R5F212BASDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BASDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASDFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BASNFA@TQFP64 [(SA768+B251)]  
R5F212BASNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BASNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BASNFP@TQFP64 [(SA732+B251)]  
R5F212BASNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BASNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BASNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212BCSDFA@TQFP64 [(SA768+B251)]  
R5F212BCSDFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BCSDFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BCSDFP@TQFP64 [(SA732+B251)]  
R5F212BCSDFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BCSDFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSDFP@TQFP64(UART mode) [(SA732+B251)]

R5F212BCSNFA@TQFP64 [(SA768+B251)]  
R5F212BCSNFA@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(single wire) [(SA768+B251)]  
R5F212BCSNFA@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFA@TQFP64(UART mode) [(SA768+B251)]  
R5F212BCSNFP@TQFP64 [(SA732+B251)]  
R5F212BCSNFP@TQFP64(single ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(single wire) [(SA732+B251)]  
R5F212BCSNFP@TQFP64(UART ISP) [ISP-HEADER01]  
R5F212BCSNFP@TQFP64(UART mode) [(SA732+B251)]  
R5F212C7SDFP@TQFP80 [(SA731+B249)]  
R5F212C7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212C7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C7SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212C7SNFP@TQFP80 [(SA731+B249)]  
R5F212C7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212C7SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C7SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212C8SDFP@TQFP80 [(SA731+B249)]  
R5F212C8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212C8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212C8SNFP@TQFP80 [(SA731+B249)]  
R5F212C8SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212C8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212C8SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CASDFP@TQFP80 [(SA731+B249)]  
R5F212CASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212CASDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CASNFP@TQFP80 [(SA731+B249)]  
R5F212CASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212CASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CASNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CCSDFP@TQFP80 [(SA731+B249)]  
R5F212CCSDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(single wire) [(SA731+B249)]

R5F212CCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212CCSNFP@TQFP80 [(SA731+B249)]  
R5F212CCSNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212CCSNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212CCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212CCSNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D7SDFP@TQFP80 [(SA731+B249)]  
R5F212D7SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D7SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D7SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D7SNFP@TQFP80 [(SA731+B249)]  
R5F212D7SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D7SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D7SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D7SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D8SDFP@TQFP80 [(SA731+B249)]  
R5F212D8SDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D8SDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212D8SNFP@TQFP80 [(SA731+B249)]  
R5F212D8SNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212D8SNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212D8SNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212D8SNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DASDFP@TQFP80 [(SA731+B249)]  
R5F212DASDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DASDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DASDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DASNFP@TQFP80 [(SA731+B249)]  
R5F212DASNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DASNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DASNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DCSDFP@TQFP80 [(SA731+B249)]  
R5F212DCSDFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DCSDFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DCSDFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSDFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212DCSNFP@TQFP80 [(SA731+B249)]

R5F212DCSNFP@TQFP80(single ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(single wire) [(SA731+B249)]  
R5F212DCSNFP@TQFP80(UART ISP) [ISP-HEADER01]  
R5F212DCSNFP@TQFP80(UART mode) [(SA731+B249)]  
R5F212G4SDFP@QFP32 [(SA663)]  
R5F212G4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SDFP@QFP32(single wire) [(SA663)]  
R5F212G4SNFP@QFP32 [(SA663)]  
R5F212G4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G4SNFP@QFP32(single wire) [(SA663)]  
R5F212G5SDFP@QFP32 [(SA663)]  
R5F212G5SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SDFP@QFP32(single wire) [(SA663)]  
R5F212G5SNFP@QFP32 [(SA663)]  
R5F212G5SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G5SNFP@QFP32(single wire) [(SA663)]  
R5F212G6SDFP@QFP32 [(SA663)]  
R5F212G6SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SDFP@QFP32(single wire) [(SA663)]  
R5F212G6SNFP@QFP32 [(SA663)]  
R5F212G6SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212G6SNFP@QFP32(single wire) [(SA663)]  
R5F212H1SDSP@TSSOP20 [(SA026+B001)]  
R5F212H1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SDSP@TSSOP20(single wire [(SA026+B001)])  
R5F212H1SNSP@TSSOP20 [(SA026+B001)]  
R5F212H1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H1SNSP@TSSOP20(single wire [(SA026+B001)])  
R5F212H2SDSP@TSSOP20 [(SA725+B005)]  
R5F212H2SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H2SDSP@TSSOP20(single wire [(SA026+B001)])  
R5F212H2SNSP@TSSOP20 [(SA725+B005)]  
R5F212H2SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212H2SNSP@TSSOP20(single wire [(SA026+B001)])  
R5F212J0SDSP@TSSOP20 [(SA026+B001)]  
R5F212J0SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SDSP@TSSOP20(single wire [(SA026+B001)])  
R5F212J0SNSP@TSSOP20 [(SA026+B001)]  
R5F212J0SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J0SNSP@TSSOP20(single wire [(SA026+B001)])  
R5F212J1SDSP@TSSOP20 [(SA026+B001)]  
R5F212J1SDSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SDSP@TSSOP20(single wire [(SA026+B001)])

R5F212J1SNSP@TSSOP20 [(SA026+B001)]  
R5F212J1SNSP@TSSOP20(single ISP) [ISP-HEADER01]  
R5F212J1SNSP@TSSOP20(single wire [(SA026+B001)])  
R5F212K2SDFP@QFP32 [(SA663+B005)]  
R5F212K2SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K2SDFP@QFP32(single wire [(SA663+B005)])  
R5F212K2SNFP@QFP32 [(SA663+B005)]  
R5F212K2SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K2SNFP@QFP32(single wire [(SA663+B005)])  
R5F212K4SDFP@QFP32 [(SA663+B005)]  
R5F212K4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K4SDFP@QFP32(single wire [(SA663+B005)])  
R5F212K4SNFP@QFP32 [(SA663+B005)]  
R5F212K4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212K4SNFP@QFP32(single wire [(SA663+B005)])  
R5F212L2SDFP@QFP32 [(SA663+B005)]  
R5F212L2SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L2SDFP@QFP32(single wire [(SA663+B005)])  
R5F212L2SNFP@QFP32 [(SA663+B005)]  
R5F212L2SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L2SNFP@QFP32(single wire [(SA663+B005)])  
R5F212L4SDFP@QFP32 [(SA663+B005)]  
R5F212L4SDFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L4SDFP@QFP32(single wire [(SA663+B005)])  
R5F212L4SNFP@QFP32 [(SA663+B005)]  
R5F212L4SNFP@QFP32(single ISP) [ISP-HEADER01]  
R5F212L4SNFP@QFP32(single wire [(SA663+B005)])

## **RICOH**

### **E ( E ) PROM / FRAM / NVRAM**

RD27C256  
RD27C32  
RD27C64

## **ROCKWELL**

### **E ( E ) PROM / FRAM / NVRAM**

R2764  
R2764C  
R2764P  
R27C64  
R2816  
R5213  
R52B13  
R52B33

## ROHM

### E (E) PROM / FRAM / NVRAM

BR24C01@SOP8 [ (SA602A) ] [ (SA026) ]	BR24C01@TSSOP8
BR24C01@TSSOP8 (3*3mm) [ (SA666) ]	
BR24C01A	
BR24C01A(F) [ (SA602A) ] [ (SA602A) ]	BR24C01A(FJ)
BR24C01A(FV) [ (SA026) ]	
BR24C02	
BR24C02(F) [ (SA602A) ] [ (SA602A) ]	BR24C02(FJ)
BR24C02(FV) [ (SA026) ] [ (SA602A) ]	BR24C02@SOP8
BR24C02@TSSOP8 [ (SA026) ] [ (SA666) ]	BR24C02@TSSOP8 (3*3mm)
BR24C04 [ (SA602A) ]	BR24C04(F)
BR24C04(FJ) [ (SA602A) ] [ (SA026) ]	BR24C04(FV)
BR24C04@SOP8 [ (SA602A) ] [ (SA026) ]	BR24C04@TSSOP8
BR24C04@TSSOP8 (3*3mm) [ (SA666) ]	
BR24C08	
BR24C08(F) [ (SA602A) ] [ (SA602A) ]	BR24C08(FJ)
BR24C08(FV) [ (SA026) ] [ (SA602A) ]	BR24C08@SOP8
BR24C08@TSSOP8 [ (SA026) ] [ (SA666) ]	BR24C08@TSSOP8 (3*3mm)
BR24C16	BR24C16(F)

[ (SA602A) ]	
BR24C16 (FJ) [ (SA602A) ]	BR24C16 (FV)
[ (SA026) ]	
BR24C21	BR24C21 (F)
[ (SA602A) ]	
BR24C21 (FJ) [ (SA602A) ]	BR24C21 (FV)
[ (SA026) ]	
BR24C32	BR24C32 (F)
[ (SA602A) ]	
BR24C64	BR24C64 (F)
[ (SA602A) ]	
BR24E16	BR24E16 (F)
[ (SA602A) ]	
BR24E16 (FJ) [ (SA602A) ]	BR24E16 (FV)
[ (SA026) ]	
BR24L01A	BR24L01A (F)
[ (SA602A) ]	
BR24L01A (FJ) [ (SA602A) ]	BR24L01A (FV)
[ (SA026) ]	
BR24L01A (FVM) [ (SA666) ]	
BR24L02	
BR24L02 (F) [ (SA602A) ]	BR24L02 (FJ)
[ (SA602A) ]	
BR24L02 (FV) [ (SA026) ]	BR24L02 (FVM)
[ (SA666) ]	
BR24L04	BR24L04 (F)
[ (SA602A) ]	
BR24L04 (FJ) [ (SA602A) ]	BR24L04 (FV)
[ (SA026) ]	
BR24L04 (FVM) [ (SA666) ]	
BR24L08	
BR24L08 (F) [ (SA602A) ]	BR24L08 (FJ)
[ (SA602A) ]	
BR24L08 (FV) [ (SA026) ]	BR24L08 (FVM)
[ (SA666) ]	
BR24L16	BR24L16 (F)
[ (SA602A) ]	
BR24L16 (FJ) [ (SA602A) ]	BR24L16 (FV)
[ (SA026) ]	
BR24L16 (FVM) [ (SA666) ]	
BR24L32	
BR24L32 (F) [ (SA602A) ]	BR24L32 (FJ)
[ (SA602A) ]	

BR24L32(FV) [(SA026)]	
BR24L64	
BR24L64(F) [(SA602A)]	BR24L64(FJ)
[(SA602A)]	
BR24L64(FV) [(SA026)]	BR25010@SOIC8
[(SA602A)]	
BR25010@TSSOP8 [(SA026)]	BR25020@SOIC8
[(SA602A)]	
BR25020@TSSOP8 [(SA026)]	BR25040@SOIC8
[(SA602A)]	
BR25040@TSSOP8 [(SA026)]	BR25080@SOIC8
[(SA602A)]	
BR25080@TSSOP8 [(SA026)]	BR25160@SOIC8
[(SA602A)]	
BR25160@TSSOP8 [(SA026)]	BR25320@SOIC8
[(SA602A)]	
BR25L010	BR25L010(F)
[(SA602A)]	
BR25L010(FJ) [(SA602A)]	BR25L010(FV)
[(SA026)]	
BR25L010(FVM) [(SA666)]	
BR25L020	
BR25L020(F) [(SA602A)]	BR25L020(FJ)
[(SA602A)]	
BR25L020(FV) [(SA026)]	BR25L020(FVM)
[(SA666)]	
BR25L040	BR25L040(F)
[(SA602A)]	
BR25L040(FJ) [(SA602A)]	BR25L040(FV)
[(SA026)]	
BR25L040(FVM) [(SA666)]	
BR25L080	
BR25L080(F) [(SA602A)]	BR25L080(FJ)
[(SA602A)]	
BR25L080(FV) [(SA026)]	
BR25L160	
BR25L160(F) [(SA602A)]	BR25L160(FJ)
[(SA602A)]	
BR25L160(FV) [(SA026)]	
BR25L320	
BR25L320(F) [(SA602A)]	BR25L320(FJ)
[(SA602A)]	
BR25L320(FV) [(SA026)]	



BR25L640	
BR25L640(F) [(SA602A)]	BR25L640(FJ)
[(SA602A)]	
BR25L640(FV) [(SA026)]	
BR34L02	
BR34L02(F) [(SA602A)]	BR34L02(FJ)
[(SA602A)]	
BR34L02(FV) [(SA026)]	BR34L02(FVM)
[(SA666)]	
BR9010	BR9010(F)
[(SA602A)]	
BR9010(FV) [(SA026)]	BR9010(RFV)
[(SA026)]	
BR9010(RFVM) [(SA666)]	
BR9016	
BR9016(F) [(SA602A)]	BR9016(RFV)
[(SA026)]	
BR9016A(F) [(SA602A)]	BR9016A(RFV)
[(SA026)]	
BR9016A(RFVM) [(SA666)]	
BR9020	
BR9020(F) [(SA602A)]	BR9020(FV)
[(SA026)]	
BR9020(RFV) [(SA026)]	BR9020(RFVM)
[(SA666)]	
BR9040	BR9040(F)
[(SA602A)]	
BR9040(FV) [(SA026)]	BR9040(RFV)
[(SA026)]	
BR9040(RFVM) [(SA666)]	
BR9080	
BR9080(F) [(SA602A)]	BR9080(RFV)
[(SA026)]	
BR9080A	BR9080A(F)
[(SA602A)]	
BR9080A(FV) [(SA026)]	BR9080A(RFV)
[(SA026)]	
BR9080A(RFVM) [(SA666)]	BR93A46(F)
[(SA602A)]	
BR93A46(FJ) [(SA602A)]	BR93A46(RF)
[(SA602A)]	
BR93A46(RFJ) [(SA602A)]	BR93A56(F)
[(SA602A)]	

BR93A56 (FJ) [(SA602A)]	BR93A56 (RF)
[(SA602A)]	
BR93A56 (RFJ) [(SA602A)]	BR93A66 (F)
[(SA602A)]	
BR93A66 (FJ) [(SA602A)]	BR93A66 (RF)
[(SA602A)]	
BR93A66 (RFJ) [(SA602A)]	BR93A86 (F)
[(SA602A)]	
BR93A86 (FJ) [(SA602A)]	BR93A86 (RF)
[(SA602A)]	
BR93A86 (RFJ) [(SA602A)]	
BR93C46	
BR93C46 (F) [(SA602A)]	BR93C46 (FJ)
[(SA602A)]	
BR93C46 (FV) [(SA026)]	BR93C46 (RF)
[(SA602A)]	
BR93C46 (RFJ) [(SA602A)]	
BR93C56	
BR93C56 (F) [(SA602A)]	BR93C56 (FJ)
[(SA602A)]	
BR93C56 (FV) [(SA026)]	BR93C56 (RF)
[(SA602A)]	
BR93C56 (RFJ) [(SA602A)]	
BR93C66	
BR93C66 (F) [(SA602A)]	BR93C66 (FJ)
[(SA602A)]	
BR93C66 (FV) [(SA026)]	BR93C66 (RF)
[(SA602A)]	
BR93C66 (RFJ) [(SA602A)]	BR93H46 (RF)
[(SA602A)]	
BR93H46 (RFJ) [(SA602A)]	BR93H56 (RF)
[(SA602A)]	
BR93H56 (RFJ) [(SA602A)]	BR93H66 (RF)
[(SA602A)]	
BR93H66 (RFJ) [(SA602A)]	BR93H76 (RF)
[(SA602A)]	
BR93H76 (RFJ) [(SA602A)]	BR93H86 (RF)
[(SA602A)]	
BR93H86 (RFJ) [(SA602A)]	
BR93L46	
BR93L46 (F) [(SA602A)]	BR93L46 (FJ)
[(SA602A)]	
BR93L46 (FV) [(SA026)]	BR93L46 (RF)

[ (SA602A) ]	
BR93L46 (RFJ) [ (SA602A) ]	
BR93L56	
BR93L56 (F) [ (SA602A) ]	BR93L56 (FJ)
[ (SA602A) ]	
BR93L56 (FV) [ (SA026) ]	BR93L56 (RF)
[ (SA602A) ]	
BR93L56 (RFJ) [ (SA602A) ]	
BR93L66	
BR93L66 (F) [ (SA602A) ]	BR93L66 (FJ)
[ (SA602A) ]	
BR93L66 (FV) [ (SA026) ]	BR93L66 (RF)
[ (SA602A) ]	
BR93L66 (RFJ) [ (SA602A) ]	BR93L76 (F)
[ (SA602A) ]	
BR93L76 (FJ) [ (SA602A) ]	BR93L76 (RF)
[ (SA602A) ]	
BR93L76 (RFJ) [ (SA602A) ]	BR93L76 (RFV)
[ (SA026A) ]	
BR93L76 (RFVJ) [ (SA666A) ]	BR93L76 (RFVM)
[ (SA666A) ]	
BR93L76 (RFVT) [ (SA026A) ]	BR93L86 (F)
[ (SA602A) ]	
BR93L86 (FJ) [ (SA602A) ]	BR93L86 (RF)
[ (SA602A) ]	
BR93L86 (RFJ) [ (SA602A) ]	BR93L86 (RFV)
[ (SA026A) ]	
BR93L86 (RFVJ) [ (SA666A) ]	BR93L86 (RFVM)
[ (SA666A) ]	
BR93L86 (RFVT) [ (SA026A) ]	
BR93LC46	
BR93LC46 (F) [ (SA602A) ]	BR93LC46 (FJ)
[ (SA602A) ]	
BR93LC46 (FV) [ (SA026) ]	BR93LC46 (RF)
[ (SA602A) ]	
BR93LC46 (RFJ) [ (SA602A) ]	
BR93LC56	
BR93LC56 (F) [ (SA602A) ]	BR93LC56 (FJ)
[ (SA602A) ]	
BR93LC56 (FV) [ (SA026) ]	BR93LC56 (RF)
[ (SA602A) ]	
BR93LC56 (RFJ) [ (SA602A) ]	
BR93LC66	

BR93LC66(F) [(SA602A)]	BR93LC66(FJ)
[(SA602A)]	
BR93LC66(FV) [(SA026)]	BR93LC66(RF)
[(SA602A)]	
BR93LC66(RFJ) [(SA602A)]	BR93LL46(F)
[(SA602A)]	
BR93LL46(FV) [(SA026)]	BR95010(3*3)@TSSOP8
[(SA666)]	
BR95010@SO8 [(SA602A)]	BR95010@TSSOP8
[(SA026)]	
BR95020(3*3)@TSSOP8 [(SA666)]	BR95020@SO8
[(SA602A)]	
BR95020@TSSOP8 [(SA026)]	BR95040(3*3)@TSSOP8
[(SA666)]	
BR95040@SO8 [(SA602A)]	BR95040@TSSOP8
[(SA026)]	
BR95080@SO8 [(SA602A)]	BR95080@TSSOP8
[(SA026)]	
BR95160@SO8 [(SA602A)]	BR95160@TSSOP8
[(SA026)]	

## SAIFUN

### E(E) PROM/FRAM/NVRAM

SA24C1024	SA24C1024@SOIC8
[(SA602A)]	
SA24C512	SA24C512@SOIC8
[(SA602A)]	
SA24C512@TSSOP8 [(SA026)]	SA25C1024
(H)	
SA25C1024(H)@CSP8 [(SA683)]	SA25C1024(H)@SOIC8
[(SA602A)]	
SA25C1024(L)	SA25C1024(L)@CSP8
[(SA683)]	
SA25C1024(L)@SOIC8 [(SA602A)]	SA25C512
(H)	
SA25C512(H)@CSP8 [(SA683)]	SA25C512(H)@SOIC8
[(SA602A)]	
SA25C512(L)	SA25C512(L)@CSP8
[(SA683)]	
SA25C512(L)@SOIC8 [(SA602A)]	

SA25F005  
SA25F005@MLF8 [ (SA683) ] SA25F005@SOIC8  
[ (SA602A) ]  
SA25F010 SA25F010@MLF8  
[ (SA683) ]  
SA25F010@SOIC8 [ (SA602A) ]  
SA25F020  
SA25F020@MLF8 [ (SA683) ] SA25F020@SOIC8  
[ (SA602A) ]  
SA25F040 SA25F040@MLF8  
[ (SA683) ]  
SA25F040@SOIC8 [ (SA602A) ]  
SA25F080  
SA25F080@MLF8 [ (SA683) ] SA25F080@SOIC8  
[ (SA602A) ]  
SA25F160 SA25F160(ISP) [ISP-  
HEADER01]  
SA25F160@MLF8 [ (SA683) ]  
SA25F160@MLF8(ISP) [ISP-HEADER01]  
SA25F160@SOIC16 [ (SA602) ]  
SA25F160@SOIC16(ISP) [ISP-HEADER01]

## SAMSUNG

### E ( E ) PROM / FRAM / NVRAM

K5A3240CBM@TFBGA69 [ (SA642A-B032A-Y096F001Y) ]  
K5A3240CTM@TFBGA69 [ (SA642A-B032A-Y096F001Y) ]  
K5A3240YBB@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3240YBC@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3240YTB@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3240YTC@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3280YBB@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3280YBC@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3280YTB@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3280YTC@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3281CBM@TFBGA69 [ (SA642A-B032A-Y096F001Y) ]  
K5A3281CTM@TFBGA69 [ (SA642A-B032A-Y096F001Y) ]  
K5A3340YBB@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3340YBC@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3340YTB@TBGA69 [ (SA642A-B032A-Y096F001) ]  
K5A3340YTC@TBGA69 [ (SA642A-B032A-Y096F001) ]

K5A3380YBB@TBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
K5A3380YBC@TBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
K5A3380YTB@TBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
K5A3380YTC@TBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
K5A6317CBM@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
K5A6317CTM@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
K5D1212DCM@FBGA149 [ ( SA664G-B143A-Y144F001Y ) ]  
K5D1213ACM@FBGA137 [ ( SA700E-B153A-M137F001Y ) ]  
K5D1257ACB-D090@FBGA107 [ ( SA642V-B133-T096F001Y ) ]  
K5D1257DCA-D090@FBGA107 [ ( SA642V-B133-T096F001Y ) ]  
K5D1257DCMD090@FBGA107 [ ( SA642V-B133-T096F001Y ) ]  
K5D1258ACB@FBGA137 [ ( SA700G-B153A-Y137F001Y ) ]  
K5D1258DCM@FBGA137 [ ( SA700E-B153A-M137F001Y ) ]  
K5D1G12DCM@FBGA107 [ ( SA642V-B133-T096F001Y ) ]  
K5D1G13ACD@FBGA137 [ ( SA700E-B153A-M137F001Y ) ]  
K5D1G13ACH@FBGA137 [ ( SA700E-B153A-M137F001Y ) ]  
K5D1G58ACA@FBGA137 [ ( SA700E-B153A-M137F001Y ) ]  
K5D5613HCMD075@FBGA137 [ ( SA700E-B153-M137F001Y ) ]  
K5D5613VCMD075@FBGA137 [ ( SA700E-B153-M137F001Y ) ]  
K5D5629ACCD090@FBGA107 [ ( SA642V-B133-T096F001Y ) ]  
K5D5657ACAD090@FBGA107 [ ( SA642V-B133-T096F001Y ) ]  
K5D5657ACBD090@FBGA107 [ ( SA642V-B133-T096F001Y ) ]  
K5D5657DCAD090@FBGA107 [ ( SA642V-B133-T096F001Y ) ]  
K5E1257ACM@FBGA107 [ ( SA642V-B133-T096F001Y ) ]  
K5E1G12ACC@FBGA107 [ ( SA642V-B133-T096F001Y ) ]  
K5J6316CBM@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
K5J6316CTM@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
K5J6332CBM@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
K5J6332CTM@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
K5L2731CAA@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
K5L2731CAM@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
K5L2763CAA@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
K5L2763CAM@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
K5L2864ABM@FBGA115 [ ( SA664A-B189A-W115F001Y ) ]  
K5L2864ATM@FBGA115 [ ( SA664A-B189A-W115F001Y ) ]  
K5L2931CAM@FBGA73 [ ( SA642A-B079A-Y096F001Y ) ]  
K5L3216CAM@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
K5L3316CAM@FBGA69 [ ( SA642A-B032A-Y096F001Y ) ]  
K5L6331CAA@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
K5L6631CAA@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
K8D1716UBC@FBGA48 [ ( SA642N-B026A-W048F001N ) ]  
K8D1716UBC@TSOP48 [ ( SA247-B005 ) ]  
K8D1716UTC@FBGA48 [ ( SA642N-B026A-W048F001N ) ]

K8D1716UTC@TSOP48 [ ( SA247-B005 ) ]  
K8D3216UBC@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
K8D3216UBC@TSOP48 [ ( SA247-B005 ) ]  
K8D3216UTC@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
K8D3216UTC@TSOP48 [ ( SA247-B005 ) ]  
K8D3316UBC@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
K8D3316UBC@TSOP48 [ ( SA247-B005 ) ]  
K8D3316UTC@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
K8D3316UTC@TSOP48 [ ( SA247-B005 ) ]  
K8D6316UBM@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
K8D6316UBM@TSOP48 [ ( SA247-B005 ) ]  
K8D6316UTM@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
K8D6316UTM@TSOP48 [ ( SA247-B005 ) ]  
K8P3215UQB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
K8P3215UQB@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
K8P3215UQB@TSOP48 [ ( SA247-B005 ) ]      K8P5615UQA@TSOP56 [ ( SA628-B102 ) ]  
K8P6415UQB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
K8P6415UQB@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
K8P6415UQB@TSOP48 [ ( SA247-B005 ) ]      K8Q2815UQB@TSOP56 [ ( SA628+B102 ) ]  
K9F1208R0C@FBGA63 [ ( SA642LL-B280-M063F001N ) ]  
K9F1208U0A@TSOP48 [ ( SA247-B005 ) ]  
K9F1208U0B@FBGA63 [ ( SA642LL-B026-M063F001N ) ]  
K9F1208U0B@TSOP48 [ ( SA247-B005 ) ]  
K9F1208U0C@FBGA63 [ ( SA642LL-B026-M063F001N ) ]  
K9F1208U0C@TSOP48 [ ( SA247-B005 ) ]      K9F1208U0M@TSOP48 [ ( SA247-B005 ) ]  
K9F1216U0A@TSOP48 [ ( SA247-B005 ) ]      K9F1G08Q0M@TSOP48 [ ( SA247-B005 ) ]  
K9F1G08R0A-JIB0@FBGA63 [ ( SA642V-B026-T096F001 ) ]  
K9F1G08R0B@FBGA63 [ ( SA642KK-B026A-W048F001Y ) ]  
K9F1G08U0A@FBGA63 [ ( SA642NN-B026A-W063F001Y ) ]  
K9F1G08U0A@TSOP48 [ ( SA247-B005 ) ]      K9F1G08U0B@TSOP48 [ ( SA247-B005 ) ]  
K9F1G08U0M@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16D0M(PCB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16D0M(PIB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16D0M(YCB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16D0M(YIB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16Q0M(PCB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16Q0M(PIB0)@TSOP48 [ ( SA247-B005 ) ]  
K9F1G16Q0M(YCB0)@TSOP48 [ ( SA247-B005 ) ]

K9F1G16Q0M(YIB0)@TSOP48 [(SA247-B005)]  
K9F1G16U0M(PCB0)@TSOP48 [(SA247-B005)]  
K9F1G16U0M(PIB0)@TSOP48 [(SA247-B005)]  
K9F1G16U0M(YCB0)@TSOP48 [(SA247-B005)]  
K9F1G16U0M(YIB0)@TSOP48 [(SA247-B005)]  
K9F2808U0C@TSOP48 [(SA247-B005)]  
K9F2G08R0A@FBGA63 [(SA642V-B280A-T096F001)]  
K9F2G08U0A@TSOP48 [(SA247-B005)] K9F2G08U0M@TSOP48 [(SA247-B005)]  
K9F4008W0A@TSOP44 [(SA645)] K9F4G08U0A@TSOP48 [(SA247-B005)]  
K9F4G08U0M@TSOP48 [(SA247-B005)]  
K9F5608R0D@FBGA63 [(SA642KK-B026-W048F001Y)]  
K9F5608U0B(partition)@TSOP48 [(SA247-B005)]  
K9F5608U0B@TSOP48 [(SA247-B005)]  
K9F5608U0C(partition)@FBGA63 [(SA642KK-B026-W048F001Y)]  
K9F5608U0C(partition)@TSOP48 [(SA247-B005)]  
K9F5608U0C@FBGA63 [(SA642KK-B026-W048F001Y)]  
K9F5608U0C@TSOP48 [(SA247-B005)]  
K9F5608U0D(partition)@FBGA63 [(SA642KK-B026-W048F001Y)]  
K9F5608U0D(partition)@TSOP48 [(SA247-B005)]  
K9F5608U0D@FBGA63 [(SA642KK-B026-W048F001Y)]  
K9F5608U0D@TSOP48 [(SA247-B005)] K9F6408U0C@TSOP44 [(SA645-B005)]  
K9F8G08U0A@TSOP48 [(SA247-B005)] K9F8G08U0M@TSOP48 [(SA247-B005)]  
K9G4G08U0A@TSOP48 [(SA247-B005)] K9G8G08U0M@TSOP48 [(SA247-B005)]  
K9GAG08U0M@TSOP48 [(SA247-B005)] K9HBG08U1M@TSOP48 [(SA247-B005)]  
K9K1208D0C@FBGA63 [(SA642KK-B026-W048F001Y)]  
K9K1208U0A@TSOP48 [(SA247-B005)] K9K1208U0M@TSOP48 [(SA247-B005)]  
K9K1216Q0C@FBGA63 [(SA664A-B114-W115F001)]  
K9K1G08U0B-JIB0@FBGA63 [(SA642LL-B026A-M063F001Y)]  
K9K1G08U0M@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(PCB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(PIB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(YCB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(YIB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M@TSOP48 [(SA247-B005)]  
K9K2G08U0M(PCB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08U0M(PIB0)(no ST)@TSOP48 [(SA247-B005)]



K9K2G08U0M(YCB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08U0M(YIB0)(no ST)@TSOP48 [(SA247-B005)]  
K9K2G08U0M@TSOP48 [(SA247-B005)] K9K4G08Q0M@TSOP48 [(SA247-B005)]  
K9K4G08U0M@TSOP48 [(SA247-B005)]  
K9K4G16Q0M(PCB0)@TSOP48 [(SA247-B005)]  
K9K4G16Q0M(PIB0)@TSOP48 [(SA247-B005)]  
K9K4G16Q0M(YCB0)@TSOP48 [(SA247-B005)]  
K9K4G16Q0M(YIB0)@TSOP48 [(SA247-B005)]  
K9K4G16U0M(PCB0)@TSOP48 [(SA247-B005)]  
K9K4G16U0M(PIB0)@TSOP48 [(SA247-B005)]  
K9K4G16U0M(YCB0)@TSOP48 [(SA247-B005)]  
K9K4G16U0M(YIB0)@TSOP48 [(SA247-B005)]  
K9K8G08U0A@TSOP48 [(SA247-B005)] K9L8G08U0M@TSOP48 [(SA247-B005)]  
K9LAG08U0M@TSOP48 [(SA247-B005)] K9LAG08U1M@TSOP48 [(SA247-B005)]  
K9T1G08U0M@TSOP48 [(SA247-B005)]  
K9W8G08U1M(PCB0)@TSOP48 [(SA247-B005)]  
K9W8G08U1M(PIB0)@TSOP48 [(SA247-B005)]  
K9WAG08U1A@TSOP48 [(SA247+B005)]  
KAD060300B@TBGA69 [(SA642A-B039A-Y096F001)]  
KAD060300C@TBGA69 [(SA642A-B039A-Y096F001)]  
KAD060700D@TBGA69 [(SA642A-B039A-Y096F001Y)]  
KAD070300B@TBGA69 [(SA642A-B039A-Y096F001)]  
KAD070300C@TBGA69 [(SA642A-B039A-Y096F001)]  
KAD070700D@TBGA69 [(SA642A-B039A-Y096F001Y)]  
KAD090300B@TBGA69 [(SA642A-B039A-Y096F001)]  
KAD100300B@TBGA69 [(SA642A-B039A-Y096F001)]  
KAG00K007A-DGG5@FBGA107 [(SA642V-B133-T096F001Y)]  
KAL00R00KM-DG55@FBGA137 [(SA700B-B153A-P137F001Y)]  
KAL00T00UM@FBGA137 [(SA700C-B153A-M137F001Y)]  
KAL00X00UA-DJYY@FBGA137 [(SA700E-B153A-M137F001Y)]  
KAL00X00UM-DJYY@FBGA137 [(SA700E-B153A-M137F001Y)]  
KBE00500AM-D437@FBGA137 [(SA700E-B153A-M137F001Y)]  
KBE00F003A-D411@FBGA107 [(SA642V-B133-T096F001Y)]  
KBE00G005M-D411@FBGA137 [(SA700E-B153A-M137F001Y)]  
KBE00S005M-D411@FBGA137 [(SA700D-B153A-Y130F001Y)]  
KBE00S00AM-D411@FBGA137 [(SA700D-B153A-Y130F001Y)]  
KFG1216Q2B-DEB8@FBGA63 [(SA664L-B266-W063F001Y)]  
KFG1216U2A-DIB5@FBGA63 [(SA664L-B266-W063F001Y)]  
KFG1216U2A-DIB6@FBGA63 [(SA664L-B266-W063F001Y)]  
KFG1216U2B-DIB5@FBGA63 [(SA664L-B266-W063F001Y)]

KFG1216U2B-DIB6@FBGA63 [ (SA664L-B266-W063F001Y) ]	
KFG5616D1M@FBGA63 [ (SA642A-B026A-Y096N001) ]	
KFG5616Q1M@FBGA63 [ (SA642A-B026A-Y096N001) ]	
KFG5616U1M@FBGA63 [ (SA642A-B026A-Y096N001) ]	
KM2816A	
KM2816AI	
KM2817A	
KM2817AI	
KM2864A	
KM2864AH	
KM2865A	
KM2865AH	
KM28C16	KM28C16@PLCC32
[ (SA015A1T) ]	
KM28C16I	KM28C16I@PLCC32
[ (SA015A1T) ]	
KM28C17	KM28C17@PLCC32
[ (SA015A1T) ]	
KM28C17I	KM28C17I@PLCC32
[ (SA015A1T) ]	
KM28C256	KM28C256@PLCC32
[ (SA015A1T) ]	
KM28C256I	KM28C256I@PLCC32
[ (SA015A1T) ]	
KM28C64	KM28C64@PLCC32
[ (SA015A1T) ]	
KM28C64A	KM28C64A@PLCC32
[ (SA015A1T) ]	
KM28C64B	KM28C64B@PLCC32
[ (SA015A1T) ]	
KM28C64I	KM28C64I@PLCC32
[ (SA015A1T) ]	
KM28C65	KM28C65@PLCC32
[ (SA015A1T) ]	
KM28C65A	KM28C65A@PLCC32
[ (SA015A1T) ]	
KM28C65I	KM28C65I@PLCC32
[ (SA015A1T) ]	
KM29U128T@TSOP48 [ (SA247-B005) ]	KM29W32000AIT@TSOP44
[ (SA645) ]	
KM29W32000AT@TSOP44 (DWB) [ (SA645) ]	
KM29W32000AT@TSOP44 (ZMQ) [ (SA645) ]	
KM93C06 (08bit)	KM93C06

(16bit)	
KM93C06(G)(08bit)@SOIC8 [(SA602A)]	
KM93C06(G)(16bit)@SOIC8 [(SA602A)]	
KM93C06(GD)(08bit)@SOIC8 [(SA602A)]	
KM93C06(GD)(16bit)@SOIC8 [(SA602A)]	
KM93C07(08bit)	KM93C07
(16bit)	
KM93C07(G)(08bit)@SOIC8 [(SA602A)]	
KM93C07(G)(16bit)@SOIC8 [(SA602A)]	
KM93C07(GD)(08bit)@SOIC8 [(SA602A)]	
KM93C07(GD)(16bit)@SOIC8 [(SA602A)]	
KM93C46V	KM93C46V(G)@SOIC8
[(SA602A)]	
KM93C46V(GD)@SOIC8 [(SA602A)]	
KM93C47V	
KM93C47V(G)@SOIC8 [(SA602A)]	KM93C47V(GD)@SOIC8
[(SA602A)]	
KM93C56V	KM93C56V(G)@SOIC8
[(SA602A)]	
KM93C56V(GD)@SOIC8 [(SA602A)]	
KM93C57V	
KM93C57V(G)@SOIC8 [(SA602A)]	KM93C57V(GD)@SOIC8
[(SA602A)]	
KM93C66V	KM93C66V(G)@SOIC8
[(SA602A)]	
KM93C66V(GD)@SOIC8 [(SA602A)]	
KM93C67V	
KM93C67V(G)@SOIC8 [(SA602A)]	KM93C67V(GD)@SOIC8
[(SA602A)]	
KS24C010	KS24C010@SOIC8
[(SA602A)]	
KS24C010@TSSOP8 [(SA026)]	
KS24C011	
KS24C011@SOIC8 [(SA602A)]	KS24C011@TSSOP8
[(SA026)]	
KS24C020	KS24C020@SOIC8
[(SA602A)]	
KS24C020@TSSOP8 [(SA026)]	
KS24C021	
KS24C021@SOIC8 [(SA602A)]	KS24C021@TSSOP8
[(SA026)]	
KS24C040	KS24C040@SOIC8
[(SA602A)]	

KS24C040@TSSOP8 [(SA026)]	
KS24C041	
KS24C041@SOIC8 [(SA602A)]	KS24C041@TSSOP8
[(SA026)]	
KS24C080	
[(SA602A)]	KS24C080@SOIC8
KS24C080@TSSOP8 [(SA026)]	
KS24C081	
KS24C081@SOIC8 [(SA602A)]	KS24C081@TSSOP8
[(SA026)]	
S524A40X10	
[(SA602A)]	S524A40X10@SOP8
S524A40X10@TSSOP8 [(SA026)]	
S524A40X11	
S524A40X11@SOP8 [(SA602A)]	S524A40X11@TSSOP8
[(SA026)]	
S524A40X20	
[(SA602A)]	S524A40X20@SOP8
S524A40X20@TSSOP8 [(SA026)]	
S524A40X21	
S524A40X21@SOP8 [(SA602A)]	S524A40X21@TSSOP8
[(SA026)]	
S524A40X40	
[(SA602A)]	S524A40X40@SOP8
S524A40X40@TSSOP8 [(SA026)]	
S524A40X41	
S524A40X41@SOP8 [(SA602A)]	S524A40X41@TSSOP8
[(SA026)]	
S524A60X51	
[(SA602A)]	S524A60X51@SOP8
S524A60X51@TSSOP8 [(SA026)]	
S524A60X81	
S524A60X81@SOP8 [(SA602A)]	S524A60X81@TSSOP8
[(SA026)]	
S524AB0X91	
[(SA602A)]	S524AB0X91@SOP8
S524AB0X91@TSSOP8 [(SA026)]	
S524AB0XB1	
S524AB0XB1@SOP8 [(SA602A)]	S524AB0XB1@TSSOP8
[(SA026)]	
S524AD0XD1	
[(SA602A)]	S524AD0XD1@SOP8
S524AD0XD1@TSSOP8 [(SA026)]	

S524AD0XF1	
S524AD0XF1@SOP8 [(SA602A)]	S524AD0XF1@TSSOP8
[(SA026)]	
S524C20D11	
S524C20D11@SOP8 [(SA602A)]	S524C20D11@SOP8
[(SA026)]	
S524C20D11@TSSOP8 [(SA026)]	
S524C20D21	
S524C20D21@SOP8 [(SA602A)]	S524C20D21@TSSOP8
[(SA026)]	
S524C80D41	
S524C80D41@SOP8 [(SA602A)]	S524C80D41@SOP8
[(SA026)]	
S524C80D41@TSSOP8 [(SA026)]	
S524C80D81	
S524C80D81@SOP8 [(SA602A)]	S524C80D81@TSSOP8
[(SA026)]	
S524L50X51	
S524L50X51@SOP8 [(SA602A)]	S524L50X51@SOP8
[(SA026)]	
S524L50X51@TSSOP8 [(SA026)]	
S524LB0X91	
S524LB0X91@SOP8 [(SA602A)]	S524LB0X91@TSSOP8
[(SA026)]	
S524LB0XB1	
S524LB0XB1@SOP8 [(SA602A)]	S524LB0XB1@SOP8
[(SA026)]	
S524LB0XB1@TSSOP8 [(SA026)]	

## DRAM & SRAM

KM61257	
KM61257@SOJ24 [(SA646)]	KM61257@SOJ24
KM61257L	
KM61257L@SOJ24 [(SA646)]	KM61257L@SOJ24
KM6165	
KM6165@SOJ24 [(SA646)]	KM6165@SOJ24
KM6165L	
KM6165L@SOJ24 [(SA646)]	KM6165L@SOJ24
KM62256A	
KM62256A@SOIC28 [(SA630)]	KM62256A@SOIC28
KM62256AL	
KM62256AL@SOIC28 [(SA630)]	KM62256AL@SOIC28
KM6264A	
KM6264A@SOIC28 [(SA630)]	KM6264A@SOIC28
KM6264AL	
KM6264AL@SOIC28	KM6264AL@SOIC28

[ ( SA630 ) ]  
KM64257  
[ ( SA646 ) ]  
KM64257L  
[ ( SA646 ) ]  
KM6465LP  
[ ( SA646 ) ]  
KM6465P  
KM68257LP  
KM68257LP@SOIC28 [ ( SA630 ) ]  
KM68257P  
KM68257P@SOIC28 [ ( SA630 ) ]  
KM6865LP  
KM6865LP@SOIC28 [ ( SA630 ) ]  
KM6865P  
KM6865P@SOIC28 [ ( SA630 ) ]

KM64257@SOJ24  
KM64257L@SOJ24  
KM6465LP@SOJ22

## PLD

CPL16L8 [ ( SA001A ) ]	CPL16L8@PLCC20
CPL16L8L [ ( SA001A ) ]	CPL16L8L@PLCC20
CPL16R4 [ ( SA001A ) ]	CPL16R4@PLCC20
CPL16R4L [ ( SA001A ) ]	CPL16R4L@PLCC20
CPL16R6 [ ( SA001A ) ]	CPL16R6@PLCC20
CPL16R6L [ ( SA001A ) ]	CPL16R6L@PLCC20
CPL16R8 [ ( SA001A ) ]	CPL16R8@PLCC20
CPL16R8L [ ( SA001A ) ]	CPL16R8L@PLCC20

## MICROCONTROLLER

S3F84I8@QFP44 [ ( SA245A ) ] [ ( SA028 ) ]	S3F84I8@SDIP42
S3F84I9@QFP44 [ ( SA245A ) ]	S3F84I9@SDIP42

[ (SA028) ]	
S3F84P4	S3F84P4@SOP8 [ (SA602A
+B003) ]	
S3F9444	S3F9444@SOP8 [ (SA602A
+B003) ]	
S3F9454(dip16)	S3F9454
(dip20)	
S3F9454@SOP20 [ (SA404+B005) ]	S3F9488@QFP44
[ (SA245A) ]	
S3F9488@SDIP32 [ (SA653) ]	S3F9488@SDIP42
[ (SA028) ]	
S3F9488@SOP32 [ (SA630) ]	S3F9498@SDIP30
[ (SA653) ]	
S3F9498@SDIP32 [ (SA653) ]	S3F9498@SOP28
[ (SA630) ]	
S3F9498@SOP32 [ (SA630) ]	S3P414@QFP44
[ (SA675) ]	
S3P434@QFP44 [ (SA675) ]	S3P7048@QFP44
[ (SA675) ]	
S3P7048@SDIP42 [ (SA028) ]	S3P70F4@SDIP30
[ (SA653) ]	
S3P70F4@SOP32 [ (SA630) ]	S3P7414@SDIP42
[ (SA028) ]	
S3P7424@SDIP30 [ (SA653) ]	S3P7424@SOP28
[ (SA630) ]	
S3P7434@SDIP42 [ (SA028) ]	S3P7528@QFP44
[ (SA675) ]	
S3P7528@SDIP42 [ (SA028) ]	S3P7538@SDIP30
[ (SA653) ]	
S3P7538@SOP32 [ (SA630) ]	S3P9428@SDIP30
[ (SA653) ]	
S3P9428@SOP28 [ (SA630) ]	S3P9428@SOP32
[ (SA630) ]	
S3P9434(dip16)	S3P9434
(dip18)	
S3P9434(dip20)	S3P9434@SOP20
[ (SA404) ]	

## SAMSUNG-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

K5D1G13ACD(Y-G8)@FBGA137 [(SA700E-B153A-M137F001Y)]  
K5D1G13ACD(Y-M8)@FBGA137 [(SA700E-B153A-M137F001Y)]  
K5D1G58ACA(YYD)@FBGA137 [(SA700E-B153A-M137F001Y)]  
K9F1208U0A(DD)@TSOP48 [(SA247-B005)]  
K9F1208U0A(MLTATL)@TSOP48 [(SA247-B005)]  
K9F1208U0B(DD)@TSOP48 [(SA247-B005)]  
K9F1208U0B(HC)@TSOP48 [(SA247-B005)]  
K9F1208U0B(LM)@TSOP48 [(SA247-B005)]  
K9F1208U0M(DD)@TSOP48 [(SA247-B005)]  
K9F1208U0M(YCB0)@TSOP48 [(SA247-B005)]  
K9F1208U0M(YIB0)@TSOP48 [(SA247-B005)]  
K9F1G08Q0M(YCB0)@TSOP48 [(SA247-B005)]  
K9F1G08Q0M(YIB0)@TSOP48 [(SA247-B005)]  
K9F1G08U0A(DD)@TSOP48 [(SA247-B005)]  
K9F1G08U0A(MLTATL)@TSOP48 [(SA247-B005)]  
K9F1G08U0A(TZ)@TSOP48 [(SA247-B005)]  
K9F1G08U0B(TZ)@TSOP48 [(SA247-B005)]  
K9F1G08U0M(DD5)@TSOP48 [(SA247+B005)]  
K9F1G08U0M(YCB0)@TSOP48 [(SA247-B005)]  
K9F1G08U0M(YIB0)@TSOP48 [(SA247-B005)]  
K9F1G16D0M(PCB0)@TSOP48 [(SA247-B005)]  
K9F1G16D0M(PIB0)@TSOP48 [(SA247-B005)]  
K9F1G16D0M(YCB0)@TSOP48 [(SA247-B005)]  
K9F1G16D0M(YIB0)@TSOP48 [(SA247-B005)]  
K9F1G16Q0M(PCB0)@TSOP48 [(SA247-B005)]  
K9F1G16Q0M(PIB0)@TSOP48 [(SA247-B005)]  
K9F1G16Q0M(YCB0)@TSOP48 [(SA247-B005)]  
K9F1G16Q0M(YIB0)@TSOP48 [(SA247-B005)]  
K9F1G16U0M(PCB0)@TSOP48 [(SA247-B005)]  
K9F1G16U0M(PIB0)@TSOP48 [(SA247-B005)]  
K9F1G16U0M(YCB0)@TSOP48 [(SA247-B005)]  
K9F1G16U0M(YIB0)@TSOP48 [(SA247-B005)]  
K9F2G08U0A(MLTATL)@TSOP48 [(SA247-B005)]  
K9F2G08U0A(YYD)@TSOP48 [(SA247-B005)]  
K9F2G08U0A(ZX)@TSOP48 [(SA247-B005)]  
K9F2G08U0M(PCB0)(DD)@TSOP48 [(SA247-B005)]  
K9F2G08U0M(ShangHai)@TSOP48 [(SA247-B005)]  
K9F2G08U0M(YYD)@TSOP48 [(SA247-B005)]  
K9F4G08U0A(JB)@TSOP48 [(SA247+B005)]  
K9F4G08U0A(MLTATL)@TSOP48 [(SA247-B005)]  
K9F4G08U0A(WS)@TSOP48 [(SA247-B005)]  
K9F4G08U0M(DD5)@TSOP48 [(SA247+B005)]  
K9F4G08U0M(PCB0)(DD)@TSOP48 [(SA247-B005)]



K9F4G08U0M(SH-EV)@TSOP48 [(SA247-B005)]  
K9F5608U0B(DD)@TSOP48 [(SA247-B005)]  
K9F5608U0B(QJ)@TSOP48 [(SA247-B005)]  
K9F5608U0C(DD)@TSOP48 [(SA247-B005)]  
K9F5608U0D(ASUS)@TSOP48 [(SA245-B005)]  
K9F5608U0D(DD)@TSOP48 [(SA247-B005)]  
K9F5608U0D(RS)@TSOP48 [(SA247-B005)]  
K9F6408U0B(SH51)@TSOP44 [(SA645-B005)]  
K9F6408U0C(SH51)@TSOP44 [(SA645-B005)]  
K9F8G08U0A(ZX)@TSOP48 [(SA247-B005)]  
K9G4G08U0A(OMB)@TSOP48 [(SA247-B005)]  
K9G8G08U0M(DD)@TSOP48 [(SA247-B005)]  
K9G8G08U0M(DD5)@TSOP48 [(SA247-B005)]  
K9G8G08U0M(KD)@TSOP48 [(SA247-B005)]  
K9GAG08U0M(DD)@TSOP48 [(SA247-B005)]  
K9GAG08U0M(DD5)@TSOP48 [(SA247-B005)]  
K9K1208D0C(XM)@FBGA63 [(SA664A-B114-W115F001)]  
K9K1G08U0A(MLTATL)@TSOP48 [(SA247-B005)]  
K9K1G08U0B-JIB0(Wistron)@FBGA63 [(SA642LL-B026A-M063F001Y)]  
K9K1G08U0M@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(PCB0)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(PIB0)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(YCB0)@TSOP48 [(SA247-B005)]  
K9K2G08Q0M(YIB0)@TSOP48 [(SA247-B005)]  
K9K2G08U0M(PCB0)@TSOP48 [(SA247-B005)]  
K9K2G08U0M(PIB0)@TSOP48 [(SA247-B005)]  
K9K2G08U0M(YCB0)@TSOP48 [(SA247-B005)]  
K9K2G08U0M(YIB0)@TSOP48 [(SA247-B005)]  
K9K4G08U0M(YYD)@TSOP48 [(SA247-B005)]  
K9K8G08U0A(AMOI)@TSOP48 [(SA247+B005)]  
K9K8G08U0A(DD)@TSOP48 [(SA247-B005)]  
K9K8G08U0A(DD5)@TSOP48 [(SA247+B005)]  
K9K8G08U0A(FX)@TSOP48 [(SA247+B005)]  
K9K8G08U0A(MLTATL)@TSOP48 [(SA247-B005)]  
K9K8G08U0A(SY)@TSOP48 [(SA247+B005)]  
K9LAG08U0M(DD)@TSOP48 [(SA247-B005)]  
K9LAG08U0M(KD)@TSOP48 [(SA247-B005)]  
K9NBG08U5M(DD)@TSOP48 [(SA247-B005)]  
K9W8G08U1M(DD)@TSOP48 [(SA247-B005)]  
K9WAG08U1A(DD)@TSOP48 [(SA247-B005)]  
K9WAG08U1A(JB)@TSOP48 [(SA247+B005)]  
K9WAG08U1A(MLT)@TSOP48 [(SA247+B005)]  
K9WAG08U1M(DD5)@TSOP48 [(SA247+B005)]

KAD070300C@TBGA69 [ (SA642A-B039A-Y096F001) ]  
KBE00F003A-D411(AMOI)@FBGA107 [ (SA642V-B133-T096F001Y) ]  
KM29W32000AT(SH51)@TSOP44 [ (SA645-B005) ]

## SANYO

### E ( E ) PROM / FRAM / NVRAM

LE24C041 [ (SA654) ]	LE24C041@MFP8
LE24C042 [ (SA654) ]	LE24C042@MFP8
LE24C081 [ (SA654) ]	LE24C081@MFP8
LE24C082 [ (SA654) ]	LE24C082@MFP8
LE24C161 [ (SA654) ]	LE24C161@MFP8
LE24C162 [ (SA654) ]	LE24C162@MFP8
LE24C322@MFP8 [ (SA654) ] [ (SA698) ]	LE24C322@WLP6
LE24L322@MFP8 [ (SA654) ] [ (SA654) ]	LE25FU106BMA@MFP8
LE25FU106BTT@MSOP8 [ (SA654) ] [ (SA602A) ]	LE25FU406BMA@MFP8
LE25FU406BTT@MSOP8 [ (SA654) ] [ (SA654) ]	LE25FV055T@MSOP8
LE25FV101T@MSOP8 [ (SA654) ] [ (SA654) ]	LE25FV105T@MSOP8
LE25FV201T@MSOP8 [ (SA654) ] [ (SA654) ]	LE25FV401T@MSOP8
LE25FV411T@MSOP8 [ (SA654) ] [ (SA620) ]	LE25FV451T@VSOP32
LE25FW056FN@VSON8 [ (SA683) ] [ (SA602A) ]	LE25FW056MA@MFP8
LE25FW106M@SOP8 [ (SA602A) ] [ (SA654) ]	LE25FW106T@MSOP8
LE25FW1606FN@VSON8 [ (SA683) ] [ (SA654) ]	LE25FW203ATT@MSOP8
LE25FW206M@SOP8 [ (SA602A) ] [ (SA654) ]	LE25FW206T@MSOP8

LE25FW406BMA@MFP8 [(SA602A)]	LE25FW406BTT@MSOP8
[(SA654)]	
LE25FW406M@SOP8 [(SA602A)]	LE25FW406T@MSOP8
[(SA654)]	
LE25FW806M@SOP8 [(SA602A)]	LE25FW806T@MSOP8
[(SA654)]	
LE26CW006@WLP6 [(SA698)]	LE28BW168T@TSOP48 [(SA247-
B005)]	
LE28C1001AM@SOP32 [(SA687)]	LE28C1001AT@TSOP32
[(SA410T)]	
LE28C1001ATS@VSOP32 [(SA620)]	LE28C1001DT@TSOP32
[(SA410T)]	
LE28C1001DTS@VSOP32 [(SA620)]	LE28CV1001AT@TSOP32
[(SA410T)]	
LE28CV1001ATS@VSOP32 [(SA620)]	LE28CV1001DT@TSOP32
[(SA410T)]	
LE28CV1001DTS@VSOP32 [(SA620)]	LE28CW1001DT@TSOP32
[(SA410T)]	
LE28CW1001DTS@VSOP32 [(SA620)]	
LE28DW1621T@FBGA63 [(SA642A-B026A-Y096F001)]	
LE28DW1621T@TSOP48 [(SA247-B005)]	
LE28DW8102T@TSOP48 [(SA637)]	
LE28DW8163T@TSOP48 [(SA247-B005)]	
LE28F1101T@TSOP40 [(SA623)]	LE28F1601T@TSOP40
[(SA409T)]	
LE28F2001ATS@TSOP32 [(SA410T)]	LE28F4001ATS@TSOP32
[(SA410T)]	
LE28F4001M@SSOP32 [(SA438T)]	LE28F8001T@TSOP40
[(SA409T)]	
LE28FU4101T@TSOP48 [(SA247-B005)]	
LE28FV1101T@TSOP40 [(SA623)]	LE28FV1601T@TSOP40
[(SA409T)]	
LE28FV2001ATS@TSOP32 [(SA410T)]	LE28FV4001ATS@TSOP32
[(SA410T)]	
LE28FV4001CTS@TSOP32 [(SA410T)]	LE28FV4001M@SSOP32
[(SA438T)]	
LE28FV4001T@TSOP40 [(SA409T)]	
LE28FV4101T@TSOP48 [(SA247-B005)]	
LE28FV8001T@TSOP40 [(SA409T)]	
LE28FW1633FB@FBGA48 [(SA642G-B026A-T048F001Y)]	
LE28FW1633FT@FBGA48 [(SA642G-B026A-T048F001Y)]	
LE28FW1633TB@TSOP48 [(SA247-B005)]	
LE28FW1633TT@TSOP48 [(SA247-B005)]	

LE28FW4101T@TSOP48 [ (SA247-B005) ]  
LE28FW8201T@TSOP48 [ (SA247-B005) ]  
LE28FW8203TB@FBGA48 [ (SA642B-B026A-Y072F001) ]  
LE28FW8203TB@TSOP48 [ (SA247-B005) ]  
LE28FW8203TT@FBGA48 [ (SA642B-B026A-Y072F001) ]  
LE28FW8203TT@TSOP48 [ (SA247-B005) ]

## SCENIX

### MICROCONTROLLER

SX20AC/SS/G@SSOP20 [ (SA626A) ] [ (SA626A) ]	SX20AC/SS@SSOP20
SX28AC/DP G	SX28AC/DP/
SX28AC/SS/G@SSOP28 [ (SA626A) ] [ (SA626A) ]	SX28AC/SS@SSOP28
SX48BD/G@TQFP48 [ (SA248) ] [ (SA248) ]	SX48BD@TQFP48

## SEEQ

### E (E) PROM / FRAM / NVRAM

27128  
27256  
2764  
27C256  
2804  
2804A  
2816A  
2816AH  
5213  
52B13  
52B13H  
52B23  
52B23H  
52B33  
52B33H  
5516A

5516AH  
5517A  
5517AH  
DE2817A  
DE2817A@PLCC32 [(SA015A1T)]  
DE2817AH  
DE2817AH@PLCC32 [(SA015A1T)]  
DQ2817A  
DQ2817A@PLCC32 [(SA015A1T)]  
DQ2817AH  
DQ2817AH@PLCC32 [(SA015A1T)]  
DQ2864  
DQ2864@PLCC32 [(SA015A1T)]  
DQ2864H  
DQ2864H@PLCC32 [(SA015A1T)]  
DQ28C256  
DQ28C256@PLCC32 [(SA015A1T)]  
DQ28C64  
DQ28C64@PLCC32 [(SA015A1T)]  
DQ28C64A  
DQ28C64A@PLCC32 [(SA015A1T)]  
DQ28C65  
DQ28C65@PLCC32 [(SA015A1T)]  
DQ52B13  
DQ52B13H  
E28C64  
E28C64@PLCC32 [(SA015A1T)]  
E52B13  
E52B13H  
E52B23  
E52B23H  
E52B33  
E52B33H  
M28C64  
M28C64@PLCC32 [(SA015A1T)]  
M52B13  
M52B13H  
M52B23  
M52B23H  
M52B33  
M52B33H  
PQ2864  
PQ2864@PLCC32 [(SA015A1T)]

PQ2864H  
 PQ2864H@PLCC32 [ (SA015A1T) ]  
 PQ28C64  
 PQ28C64@PLCC32 [ (SA015A1T) ]  
 PQ28C65  
 PQ28C65@PLCC32 [ (SA015A1T) ]

## SEIKO

### E ( E ) PROM / FRAM / NVRAM

S-22H10 [ (SA404) ]	S-22H10@SOP18
S-22H12 [ (SA404) ]	S-22H12@SOP18
S-22S10 [ (SA404) ]	S-22S10@SOP18
S-22S12 [ (SA404) ]	S-22S12@SOP18
S-24C01A(DP) (DPA)	S-24C01A
S-24C01A(FJA)@SOIC8 [ (SA602A) ] (DP)	S-24C01B
S-24C01B(FJ)@SOIC8 [ (SA602A) ] (DP)	S-24C02A
S-24C02A(DPA) [ (SA602A) ]	S-24C02A(FJA)@SOIC8
S-24C02B(DP) [ (SA602A) ]	S-24C02B(FJ)@SOIC8
S-24C04A(DP) (DPA)	S-24C04A
S-24C04A(FJA)@SOIC8 [ (SA602A) ] (DP)	S-24C04B
S-24C04B(FJ)@SOIC8 [ (SA602A) ] (DPA)	S-24C08A
S-24C08A(FJA)@SOIC8 [ (SA602A) ] (DPA)	S-24C16A
S-24C16A(FJA)@SOIC8 [ (SA602A) ] (DP)	S-24CS01A
S-24CS01A(FJ)@SOIC8 [ (SA602A) ] [ (SA026) ]	S-24CS01A(FT)@TSSOP8
S-24CS02A(DP)	S-24CS02A(FJ)@SOIC8

[ ( SA602A ) ]	
S-24CS02A ( FT ) @ TSSOP8 [ ( SA026 ) ]	S-24CS04A
( DP )	
S-24CS04A ( FJ ) @ SOIC8 [ ( SA602A ) ]	S-24CS04A ( FT ) @ TSSOP8
[ ( SA026 ) ]	
S-24CS08A ( DP )	S-24CS08A ( FJ ) @ SOIC8
[ ( SA602A ) ]	
S-24CS08A ( FT ) @ TSSOP8 [ ( SA026 ) ]	S-24CS16A
( DP )	
S-24CS16A ( FJ ) @ SOIC8 [ ( SA602A ) ]	S-24CS16A ( FT ) @ TSSOP8
[ ( SA026 ) ]	
S-24CS64A ( FJ ) @ SOIC8 [ ( SA602A ) ]	S-24CS64A ( FT ) @ TSSOP8
[ ( SA026 ) ]	
S-2817A @ SOP28 [ ( SA630 ) ]	S-29130A ( DFJA ) @ SOIC8
[ ( SA602A ) ]	
S-29130A ( DPA )	S-29130A ( FJA ) @ SOIC8
[ ( SA602A ) ]	
S-29131A ( DPA )	S-29131A ( FJA ) @ SOIC8
[ ( SA602A ) ]	
S-29190A ( DPA )	S-29190A ( FJA ) @ SOIC8
[ ( SA602A ) ]	
S-29191A ( DPA )	S-29191A ( FJA ) @ SOIC8
[ ( SA602A ) ]	
S-29194A ( DPA )	S-29194A ( FJA ) @ SOIC8
[ ( SA602A ) ]	
S-29220A ( DFJA ) @ SOIC8 [ ( SA602A ) ]	S-29220A
( DPA )	
S-29220A ( FJA ) @ SOIC8 [ ( SA602A ) ]	S-29221A
( DPA )	
S-29221A ( FJA ) @ SOIC8 [ ( SA602A ) ]	S-29230A ( DFJA ) @ SOIC8
[ ( SA602A ) ]	
S-29230A ( DPA )	S-29230A ( FJA ) @ SOIC8
[ ( SA602A ) ]	
S-29231A ( DPA )	S-29231A ( FJA ) @ SOIC8
[ ( SA602A ) ]	
S-29290A ( DPA )	S-29290A ( FJA ) @ SOIC8
[ ( SA602A ) ]	
S-29291A ( DPA )	S-29291A ( FJA ) @ SOIC8
[ ( SA602A ) ]	
S-29294A ( DPA )	S-29294A ( FJA ) @ SOIC8
[ ( SA602A ) ]	
S-29330A ( DFJA ) @ SOIC8 [ ( SA602A ) ]	S-29330A
( DPA )	

S-29330A(FJA)@SOIC8 [(SA602A)] (DPA)	S-29331A
S-29331A(FJA)@SOIC8 [(SA602A)] (DPA)	S-29390A
S-29390A(FJA)@SOIC8 [(SA602A)] (DPA)	S-29391A
S-29391A(FJA)@SOIC8 [(SA602A)] (DPA)	S-29394A
S-29394A(FJA)@SOIC8 [(SA602A)] 29430A	S-
S-29430A@SOIC8 [(SA602A)] 29530A	S-
S-29530A@SOIC8 [(SA602A)] 29630A	S-
S-29630A@SOIC8 [(SA602A)] [(SA602A)]	S-29L130A(DFE)@SOIC8
S-29L130A(FE)@SOIC8 [(SA602A)] [(SA026)]	S-29L130A(FS)@SSOP8
S-29L131A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29L131A(FS)@SSOP8
S-29L194A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29L194A(FS)@TSSOP8
S-29L220A(DFE)@SOIC8 [(SA602A)] [(SA602A)]	S-29L220A(FE)@SOIC8
S-29L220A(FS)@SSOP8 [(SA026)] [(SA602A)]	S-29L221A(DFE)@SOIC8
S-29L221A(FS)@SSOP8 [(SA026)] [(SA602A)]	S-29L294A(DFE)@SOIC8
S-29L294A(FS)@TSSOP8 [(SA026)] [(SA602A)]	S-29L330A(DFE)@SOIC8
S-29L330A(FE)@SOIC8 [(SA602A)] [(SA026)]	S-29L330A(FS)@SSOP8
S-29L331A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29L331A(FS)@SSOP8
S-29L394A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29L394A(FS)@TSSOP8
S-29U130A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29U130A(FS)@SSOP8
S-29U131A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29U131A(FS)@SSOP8
S-29U194A(DFE)@SOIC8 [(SA602A)] [(SA026)]	S-29U194A(FS)@TSSOP8
S-29U220A(DFE)@SOIC8 [(SA602A)]	S-29U220A(FS)@SSOP8



[ (SA026) ]	
S-29U221A(DFE)@SOIC8 [ (SA602A) ]	S-29U221A(FS)@SSOP8
[ (SA026) ]	
S-29U294A(DFE)@SOIC8 [ (SA602A) ]	S-29U294A(FS)@TSSOP8
[ (SA026) ]	
S-29U330A(DFE)@SOIC8 [ (SA602A) ]	S-29U330A(FS)@SSOP8
[ (SA026) ]	
S-29U331A(DFE)@SOIC8 [ (SA602A) ]	S-29U331A(FS)@SSOP8
[ (SA026) ]	
S-29U394A(DFE)@SOIC8 [ (SA602A) ]	S-29U394A(FS)@TSSOP8
[ (SA026) ]	
S-29Z330A(DFJA)@SOIC8 [ (SA602A) ]	S-29Z330A(FS)@SSOP8
[ (SA026) ]	
S-29Z430A(DFJA)@SOIC8 [ (SA602A) ]	S-29Z430A(FS)@SSOP8
[ (SA026) ]	
S-93A46A(D0A)@SOIC8 [ (SA602A) ]	S-93A56A(D0A)@SOIC8
[ (SA602A) ]	
S-93A66A(D0A)@SOIC8 [ (SA602A) ]	S-93A66A(FJ)@SOIC8
[ (SA602A) ]	
S-93C46A(DFJ)@SOIC8 [ (SA602A) ]	S-93C46A
(DP)	
S-93C46A(FJ)@SOIC8 [ (SA602A) ]	S-93C46A(FT)@TSSOP8
[ (SA026) ]	
S-93C46B(DP)	S-93C46B(FJ)@SOIC8
[ (SA602A) ]	
S-93C46B(FT)@TSSOP8 [ (SA026) ]	S-93C56A(DFJ)@SOIC8
[ (SA602A) ]	
S-93C56A(DP)	S-93C56A(FJ)@SOIC8
[ (SA602A) ]	
S-93C56A(FT)@TSSOP8 [ (SA026) ]	S-93C56B
(DP)	
S-93C56B(FJ)@SOIC8 [ (SA602A) ]	S-93C56B(FT)@TSSOP8
[ (SA026) ]	
S-93C66A(DFJ)@SOIC8 [ (SA602A) ]	S-93C66A
(DP)	
S-93C66A(FJ)@SOIC8 [ (SA602A) ]	S-93C66A(FT)@TSSOP8
[ (SA026) ]	
S-93C66B(DP)	S-93C66B(FJ)@SOIC8
[ (SA602A) ]	
S-93C66B(FT)@TSSOP8 [ (SA026) ]	S-93C76A
(DP)	
S-93C76A(FJ)@SOIC8 [ (SA602A) ]	S-93C76A(FT)@TSSOP8
[ (SA026) ]	

S-93C86A(DP)  
[ (SA602A) ]  
S-93C86A(FT)@TSSOP8 [ (SA026) ]  
[ (SA602A) ]  
S-93C86B@TSSOP8 [ (SA026) ]  
[ (SA602A) ]  
S-93L56A(D0I)@SOIC8 [ (SA602A) ]  
[ (SA602A) ]  
S-93L76A(D0I)@SOIC8 [ (SA602A) ]

S-93C86A(FJ)@SOIC8  
  
S-93C86B@SOIC8  
  
S-93L46A(D0I)@SOIC8  
  
S-93L66A(D0I)@SOIC8

## SGS-THOMSON

### E (E) PROM / FRAM / NVRAM

ET2716  
ETC2716  
ETC2732  
M24128  
M24128@SOIC8 [ (SA602A) ]  
M24164  
M24164@SOIC8 [ (SA602A) ]  
M24256  
M24256[3.9]@SOIC8 [ (SA602A) ]  
[ (SA605A) ]  
M24512  
[ (SA605A) ]  
M24512@TSOP8 [ (SA026) ]  
M24C04  
M24C04@SOIC8 [ (SA602A) ]  
M24C08  
M24C08@SOIC8 [ (SA602A) ]  
M24C08W  
M24C08W@SOIC8 [ (SA602A) ]  
[ (SA026) ]  
M24C64(BN)  
[ (SA026) ]  
M24C64(DW)@TSSOP8 [ (SA602A) ]  
[ (SA605A) ]  
M24C64(MW)@SOIC8 [ (SA602A) ]  
M27128A  
M2716  
M27256

M24256[5.5]@SOIC8

M24512@SOIC8

M24C08W@TSOP8

M24C64(DL)@TSSOP14

M24C64(MN)@SOIC8

M27256A	
M2732A	
M27512	
M2764	
M2764A	
M27C1000	
M27C1000@PLCC32 [(SA015A1T)]	M27C1000@TSOP32
[(SA410T)]	
M27C1001	M27C1001@PLCC32
[(SA015A1T)]	
M27C1001@TSOP32 [(SA410T)]	
M27C1024	
M27C1024@PLCC44 [(SA244)]	
M27C160	
M27C160@PLCC44 [(SA244)]	M27C160@PSOP44
[(SA638)]	
M27C2001	M27C2001@PLCC32
[(SA015A1T)]	
M27C2001@TSOP32 [(SA410T)]	
M27C202	
M27C202@PLCC44 [(SA244)]	M27C202@TSOP40
[(SA409T)]	
M27C256B	M27C256B@PLCC32
[(SA015A1T)]	
M27C400	
M27C4001	
M27C4001@PLCC32 [(SA015A1T)]	M27C4001@TSOP32
[(SA410T)]	
M27C4002	M27C4002@PLCC44
[(SA244)]	
M27C405	M27C405@PLCC32
[(SA015A1T)]	
M27C405@TSOP32 [(SA410T)]	
M27C512	
M27C512@PLCC32 [(SA015A1T)]	
M27C516	
M27C516@PLCC44 [(SA244)]	
M27C64A	
M27C64A@PLCC32 [(SA015A1T)]	
M27C800	
M27C800@PLCC44 [(SA244)]	M27C800@PSOP44
[(SA638)]	
M27C801	M27C801@PLCC32

[ (SA015A1T) ]	
M27C801@TSOP32 [ (SA410T) ]	
M27HC641	
M27HC641@PLCC28 [ (SA008A) ]	
M27HC642	
M27HC642@PLCC28 [ (SA008A) ]	
M27V101	
M27V101@PLCC32 [ (SA015A1T) ]	M27V101@TSOP32
[ (SA410T) ]	
M27V201	
[ (SA015A1T) ]	
M27V201@TSOP32 [ (SA410T) ]	M27V201@PLCC32
M27V401	
M27V401@PLCC32 [ (SA015A1T) ]	M27V401@TSOP32
[ (SA410T) ]	
M27V402	
[ (SA244) ]	
M27V402@TSOP40 [ (SA409T) ]	M27V402@PLCC44
M27V512	
M27V512@PLCC32 [ (SA015A1T) ]	M27V512@TSOP28
[ (SA430T) ]	
M27V800	
[ (SA244) ]	
M27V801	
[ (SA015A1T) ]	
M27V801@TSOP32 [ (SA410T) ]	M27V801@PLCC32
M27W201	
M27W201@PLCC32 [ (SA015A1T) ]	M27W201@TSOP32
[ (SA410T) ]	
M28010	
[ (SA015A1T) ]	
M28010@TSOP32 [ (SA410T) ]	M28010@PLCC32
[ (SA015A1T) ]	
M28C64C	
[ (SA015A1T) ]	
M28C64C@SOIC28 [ (SA404) ]	M28C64C@PLCC32
[ (SA430T) ]	
M28F101	
[ (SA015A1T) ]	
M28F101@TSOP32 [ (SA410T) ]	M28F101@PLCC32
M28F102	
M28F102@PLCC44 [ (SA244) ]	M28F102@TSOP40
[ (SA409T) ]	

M28F201 [ (SA015A1T) ]	M28F201@PLCC32
M28F201@TSOP32 [ (SA410T) ] [ (SA409T) ]	M28F211@TSOP40
M28F220@PSOP44 [ (SA638) ] B005) ]	M28F220@TSOP48 [ (SA247-
M28F256 [ (SA015A1T) ]	M28F256@PLCC32
M28F256@TSOP32 [ (SA410T) ] [ (SA409T) ]	M28F411@TSOP40
M28F512 [ (SA015A1T) ]	M28F512@PLCC32
M28F512@TSOP32 [ (SA410T) ]	
M29F002B M29F002B@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	M29F002B@TSOP32
M29F002T [ (SA015A1T) ]	M29F002T@PLCC32
M29F002T@TSOP32 [ (SA410T) ]	
M29F040 M29F040@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	M29F040@TSOP32
M29F040B [ (SA015A1T) ]	M29F040B@PLCC32
M29F040B@TSOP32 [ (SA410T) ]	M29F100B@PSOP44 [ (SA638-
M29F100B@TSOP48 [ (SA247-B005) ] B006) ]	M29F100T@PSOP44 [ (SA638-
M29F100T@TSOP48 [ (SA247-B005) ] [ (SA244) ]	M29F102B@PLCC44
M29F102B@TSOP40 [ (SA623) ] [ (SA244) ]	M29F102BB@PLCC44
M29F102BB@TSOP40 [ (SA623) ] B006) ]	M29F200B@PSOP44 [ (SA638-
M29F200B@TSOP48 [ (SA247-B005) ] B006) ]	M29F200T@PSOP44 [ (SA638-
M29F200T@TSOP48 [ (SA247-B005) ] B006) ]	M29F400B@PSOP44 [ (SA638-
M29F400B@TSOP48 [ (SA247-B005) ] B006) ]	M29F400T@PSOP44 [ (SA638-
M29F400T@TSOP48 [ (SA247-B005) ] [ (SA015A1T) ]	M29V040@PLCC32
M29V040@TSOP32 [ (SA410T) ]	M29W008B@TSOP40

[ (SA409T) ]	
M29W008T@TSOP40 [ (SA409T) ]	M29W040@PLCC32
[ (SA015A1T) ]	
M29W040@TSOP32 [ (SA410T) ]	M29W400B@PSOP44
[ (SA638) ]	
M29W400B@TSOP48 [ (SA247-B005) ]	M29W400T@PLCC44
[ (SA638) ]	
M29W400T@TSOP48 [ (SA247-B005) ]	M29W512B@PLCC32
[ (SA015A1T) ]	
M29W512B@TSOP32 [ (SA620) ]	M29W800B@PSOP44
[ (SA638) ]	
M29W800B@TSOP48 [ (SA247-B005) ]	M29W800T@PSOP44
[ (SA638) ]	
M29W800T@TSOP48 [ (SA247-B005) ]	
M48T35	
M48T35@SOIC28 [ (SA404) ]	
M48T35Y	
M48T35Y@SOIC28 [ (SA404) ]	
M48T59	
M48T59@SOIC28 [ (SA404) ]	
M48T59Y	
M48T59Y@SOIC28 [ (SA404) ]	
M48Z128	
M48Z128Y	
M48Z30	
M48Z30Y	
M48Z32	
M48Z32Y	M50FW080@PLCC32
[ (SA015A1T) ]	
M50FW080@TSOP40 [ (SA409T) ]	M50FW080@VSOP32
[ (SA620) ]	
M87C257	M87C257@PLCC32
[ (SA015A1T) ]	
M93C06(08bit)	M93C06(08bit)@SOIC8
[ (SA602A) ]	
M93C06(16bit)	M93C06(16bit)@SOIC8
[ (SA602A) ]	
M93S46	M93S46@SOIC8
[ (SA602A) ]	
M93S46@TSSOP8 [ (SA026) ]	
M95P02	
M95P02@SOIC8 [ (SA602A) ]	
M95P04	

M95P04@SOIC8 [ (SA602A) ]

M95P08

M95P08@SOIC8 [ (SA602A) ]

MK48C02

MK48C02B

MK48C12

MK48C12B

MK48T02

MK48T02B

MK48T08

MK48T12

MK48T12B

MK48T18

MK48Z02

MK48Z02B

MK48Z08

MK48Z12

MK48Z12B

MK48Z18

MKI48Z02

MKI48Z02B

MKI48Z12

MKI48Z12B

MKI48Z18

ST24C01

[ (SA602A) ]

ST24C02A

[ (SA602A) ]

ST24C16

[ (SA602A) ]

ST24W01

[ (SA602A) ]

ST24W02

[ (SA602A) ]

ST24W04C

[ (SA602A) ]

ST27128A

ST27256

ST2764A

ST27C256

ST93C06(08bit)

[ (SA602A) ]

ST93C06(16bit)

ST24C01@SOIC8

ST24C02A@SOIC8

ST24C16@SOIC8

ST24W01@SOIC8

ST24W02@SOIC8

ST24W04C@SOIC8

ST93C06(08bit)@SOIC8

ST93C06(16bit)@SOIC8

[ ( SA602A ) ]

ST93CS46

ST93CS46@SOIC8

[ ( SA602A ) ]

TS27C256

TS27C64

TS27C64@PLCC32 [ ( SA015A1T ) ]

TS27C64A

TS27C64A@PLCC32 [ ( SA015A1T ) ]

TS28C16A

TS28C17A

## PLD

GAL16V8

GAL16V8A

GAL20V8

GAL20V8A

## SHARP

### E ( E ) PROM / FRAM / NVRAM

LH28F002SCHN@PSOP44 [ ( SA638 ) ]

LH28F002SCHT@TSOP40

[ ( SA409T ) ]

LH28F002SCN@PSOP44 [ ( SA638 ) ]

LH28F002SCT@TSOP40

[ ( SA409T ) ]

LH28F004BVE ( BT ) @TSOP40 [ ( SA409T ) ]

LH28F004BVE ( TT ) @TSOP40 [ ( SA409T ) ]

LH28F004BVHS ( BT ) @VSOP40 [ ( SA623 ) ]

LH28F004BVHS ( TT ) @VSOP40 [ ( SA623 ) ]

LH28F004BVT ( BT ) @TSOP40 [ ( SA409T ) ]

LH28F004BVT ( TT ) @TSOP40 [ ( SA409T ) ]

LH28F004SCHN@PSOP44 [ ( SA638 ) ]

LH28F004SCHS@VSOP40

[ ( SA623 ) ]

LH28F004SCHT@TSOP40 [ ( SA409T ) ]

LH28F004SCN@PSOP44

[ ( SA638 ) ]

LH28F004SCS@VSOP40 [ ( SA623 ) ]

LH28F004SCT@TSOP40

[ ( SA409T ) ]

LH28F008BJT ( BTLZ1 ) @TSOP40 [ ( SA409T ) ]

LH28F008BJT ( TB ) @TSOP40 [ ( SA409T ) ]

LH28F008BJT ( TT ) @TSOP40 [ ( SA409T ) ]



LH28F008BJT(TTLZ2)@TSOP40 [(SA409T)]  
LH28F008BVT(BT)@TSOP40 [(SA409T)]  
LH28F008BVT(TT)@TSOP40 [(SA409T)]  
LH28F008SAN@PSOP44 [(SA638)] LH28F008SAR@RTSOP40  
[(SA409T)]  
LH28F008SAT@TSOP40 [(SA409T)]  
LH28F008SCH(L85)@RTSOP40 [(SA409T)]  
LH28F008SCH-L@TSOP40 [(SA409T)] LH28F008SCHN@PSOP44  
[(SA638)]  
LH28F008SCH-V@TSOP40 [(SA409T)]  
LH28F008SCH-ZU-120@TSOP40 [(SA409T)]  
LH28F008SCN@PSOP44 [(SA638)] LH28F008SCN-L@PSOP44  
[(SA638)]  
LH28F008SCT@TSOP40 [(SA409T)] LH28F008SCT-L@TSOP40  
[(SA409T)]  
LH28F008SCT-V@TSOP40 [(SA409T)] LH28F008SCV@TSOP40  
[(SA409T)]  
LH28F016SA@TSOP56 [(SA628-B011)] LH28F016SC@PSOP44  
[(SA638)]  
LH28F016SCR(L95)@RTSOP40 [(SA409T)]  
LH28F016SCT-L95@TSOP40 [(SA409T)]  
LH28F016SUT@TSOP56 [(SA628-B011)]  
LH28F128BFHBD@CSP72 [(SA642E-B052A-T072F001)]  
LH28F128BFHE@TSOP48 [(SA247-B005)]  
LH28F128BFHT(PBTL70\_75A)@TSOP56 [(SA628-B045)]  
LH28F128BFHT(PTTL70\_75A)@TSOP56 [(SA628-B045)]  
LH28F128BFHT(PWTL80)@TSOP56 [(SA628-B045)]  
LH28F128BFND@PSOP44 [(SA638)]  
LH28F128SPHTD@TSOP56 [(SA628-B018)]  
LH28F160BGB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F160BGB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F160BGE(B)@TSOP48 [(SA247-B005)]  
LH28F160BGE(T)@TSOP48 [(SA247-B005)]  
LH28F160BJBB@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F160BJBT@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F160BJD  
LH28F160BJEB@TSOP48 [(SA247-B005)]  
LH28F160BJET@TSOP48 [(SA247-B005)]  
LH28F160BJHBB@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F160BJHBT@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F160BJHEB@TSOP48 [(SA247-B005)]  
LH28F160BJHET@TSOP48 [(SA247-B005)]  
LH28F160BVE(BTL)@TSOP48 [(SA247-B005)]

LH28F160BVE(TTL)@TSOP48 [(SA247-B005)]  
LH28F160BVEB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F160BVEB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F160BVHE(BTL)@TSOP48 [(SA247-B005)]  
LH28F160BVHE(TTL)@TSOP48 [(SA247-B005)]  
LH28F160S3HNS@SSOP56 [(SA629A-B013)]  
LH28F160S3HT@TSOP56 [(SA628-B011)]  
LH28F160S3NS@SSOP56 [(SA629A-B013)]  
LH28F160S3T@TSOP56 [(SA628-B011)]  
LH28F160S5HNS@SSOP56 [(SA629A-B013)]  
LH28F160S5HT@TSOP56 [(SA628-B011)]  
LH28F160S5NS@SSOP56 [(SA629A-B013)]  
LH28F160S5T@TSOP56 [(SA628-B011)]  
LH28F160SKT@TSOP56 [(SA628-B011)]  
LH28F320BFE(PB)@TSOP48 [(SA247-B005)]  
LH28F320BFE(PT)@TSOP48 [(SA247-B005)]  
LH28F320BFHB(PB)@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F320BFHB(PT)@FBGA48 [(SA642B-B029A-Y072F001)]  
LH28F320BFHE(PB)@TSOP48 [(SA247-B005)]  
LH28F320BFHE(PBTLZ2)@TSOP48 [(SA247-B005)]  
LH28F320BFHE(PT)@TSOP48 [(SA247-B005)]  
LH28F320BFHE(PTTLZ1)@TSOP48 [(SA247-B005)]  
LH28F320BFHG(PBTLZL)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BFHG(PBTLZN)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BFHG(PTTLZ3)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BFHG(PTTLZK)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BFHG(PTTLZM)@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F320BJD  
LH28F320BJE(PB)(OTP)@TSOP48 [(SA247-B005)]  
LH28F320BJE(PB)@TSOP48 [(SA247-B005)]  
LH28F320BJE(PT)(OTP)@TSOP48 [(SA247-B005)]  
LH28F320BJE(PT)@TSOP48 [(SA247-B005)]  
LH28F320BJHE(PB)(OTP)@TSOP48 [(SA247-B005)]  
LH28F320BJHE(PT)(OTP)@TSOP48 [(SA247-B005)]  
LH28F320BJN@PSOP44 [(SA638)]  
LH28F320S3HNS@SSOP56 [(SA629A-B013)]  
LH28F320S3HT@TSOP56 [(SA628-B011)]  
LH28F320S3NS@SSOP56 [(SA629A-B013)]  
LH28F320S3T@TSOP56 [(SA628-B011)]  
LH28F320S3TD@TSOP56 [(SA628-B011)]  
LH28F320S5HNS@SSOP56 [(SA629A-B013)]  
LH28F320S5HT@TSOP56 [(SA628-B011)]  
LH28F320S5NS@SSOP56 [(SA629A-B013)]

LH28F320S5T@TSOP56 [(SA628-B011)]  
LH28F320SKTD@TSOP56 [(SA628-B011)]  
LH28F400BGB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BGB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BGE(B)@TSOP48 [(SA247-B005)]  
LH28F400BGE(T)@TSOP48 [(SA247-B005)]  
LH28F400BGHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BGHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BGHE(B)@TSOP48 [(SA247-B005)]  
LH28F400BGHE(T)@TSOP48 [(SA247-B005)]  
LH28F400BGN(B)@PSOP44 [(SA638)]            LH28F400BGN(T)@PSOP44  
[(SA638)]  
LH28F400BVB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BVB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BVE(B)@TSOP48 [(SA247-B005)]  
LH28F400BVE(T)@TSOP48 [(SA247-B005)]  
LH28F400BVHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BVHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F400BVHE(B)@TSOP48 [(SA247-B005)]  
LH28F400BVHE(T)@TSOP48 [(SA247-B005)]  
LH28F400BVN(B)@PSOP44 [(SA638)]            LH28F400BVN(T)@PSOP44  
[(SA638)]  
LH28F640BFE(PB)@TSOP48 [(SA247-B005)]  
LH28F640BFE(PT)@TSOP48 [(SA247-B005)]  
LH28F640BFHB(PB)@FBGA60 [(SA642B-B029A-Y072F001)]  
LH28F640BFHB(PT)@FBGA60 [(SA642B-B029A-Y072F001)]  
LH28F640BFHE(PB)@TSOP48 [(SA247-B005)]  
LH28F640BFHE(PT)@TSOP48 [(SA247-B005)]  
LH28F640BFHE(PTTLHIA)@TSOP48 [(SA247-B005)]  
LH28F640BFHG@FBGA48 [(SA634A-B005A-Y048F001)]  
LH28F640BNHG@CSP56 [(SA644A-B025A-Y056F001)]  
LH28F640SPHT@TSOP56 [(SA628-B018)]  
LH28F800BGB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BGB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BGE(B)@TSOP48 [(SA247-B005)]  
LH28F800BGE(T)@TSOP48 [(SA247-B005)]  
LH28F800BGHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BGHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
LH28F800BGHE(B)@TSOP48 [(SA247-B005)]  
LH28F800BGHE(T)@TSOP48 [(SA247-B005)]  
LH28F800BGN(B)@PSOP44 [(SA638)]            LH28F800BGN(T)@PSOP44  
[(SA638)]  
LH28F800BH-B@TSOP48 [(SA247-B005)]

LH28F800BJE(PB)(OTP)@TSOP48 [(SA247-B005)]  
 LH28F800BJE(PB)@TSOP48 [(SA247-B005)]  
 LH28F800BJE(PT)(OTP)@TSOP48 [(SA247-B005)]  
 LH28F800BJE(PT)@TSOP48 [(SA247-B005)]  
 LH28F800BJHE(PB)(OTP)@TSOP48 [(SA247-B005)]  
 LH28F800BJHE(PT)(OTP)@TSOP48 [(SA247-B005)]  
 LH28F800BJHG(PB)(OTP)@CSP48 [(SA634A-B005A-Y048F001)]  
 LH28F800BVB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F800BVB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F800BV-B@TSOP48 [(SA247-B005)]  
 LH28F800BVE(B)@TSOP48 [(SA247-B005)]  
 LH28F800BVE(T)@TSOP48 [(SA247-B005)]  
 LH28F800BVE(TV85)@TSOP48 [(SA247-B005)]  
 LH28F800BVHB(B)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F800BVHB(T)@CSP48 [(SA642B-B029A-Y072F001)]  
 LH28F800BVHB@TSOP48 [(SA247-B005)]  
 LH28F800BVHE(B)@TSOP48 [(SA247-B005)]  
 LH28F800BVHE(T)@TSOP48 [(SA247-B005)]  
 LH28F800BVHT@TSOP48 [(SA247-B005)]  
 LH28F800BVN(B)@PSOP44 [(SA638)]            LH28F800BVN(T)@PSOP44  
 [(SA638)]  
 LH28F800BVN(TV85)@PSOP44 [(SA638)]  
 LH28F800BV-T@TSOP48 [(SA247-B005)]  
 LH28F800SG(L100)@TSOP48 [(SA247)]  
 LH28F800SG(L120)@TSOP48 [(SA247)]  
 LH28F800SG(L70)@TSOP48 [(SA247)]            LH28F800SG(L80)@TSOP48  
 [(SA247)]  
 LH28F800SG(L85)@TSOP48 [(SA247)]  
 LH28F800SGH(L100)@TSOP48 [(SA247)]  
 LH28F800SGH(L120)@TSOP48 [(SA247)]  
 LH28F800SGH(L70)@TSOP48 [(SA247)]  
 LH28F800SGH(L80)@TSOP48 [(SA247)]  
 LH28F800SGH(L85)@TSOP48 [(SA247)]  
 LH28F800SUT@TSOP56 [(SA628-B011)]  
 LHF00L03@PLCC32 [(SA015A1T)]            LHF00L04@TSOP40  
 [(SA409T)]  
 LHF00L06@TSOP40 [(SA409T)]            LHF00L07@PLCC32  
 [(SA015A1T)]  
 LHF00L08(LH28F320T)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 LHF00L09(LH28F320B)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 LHF00L10(LH28F320T)@FBGA48 [(SA634A-B005A-Y048F001Y)]  
 LHF00L11(LH28F320B)@FBGA48 [(SA634A-B005A-Y048F001Y)]  
 LHF00L12(LH28F320T)@TSOP48 [(SA247-B005)]

LHF00L13(LH28F320B)@TSOP48 [(SA247-B005)]  
LHF00L14(LH28F320T)@TSOP48 [(SA247-B005)]  
LHF00L15(LH28F320B)@TSOP48 [(SA247-B005)]  
LHF00L24(LH28F160T)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
LHF00L25(LH28F160B)@FBGA48 [(SA642Z-B026A-W048F001Y)]  
LHF00L28(LH28F160T)@TSOP48 [(SA247-B005)]  
LHF00L29(LH28F160B)@TSOP48 [(SA247-B005)]  
LHF00L30(LH28F160T)@TSOP48 [(SA247-B005)]  
LHF00L31(LH28F160B)@TSOP48 [(SA247-B005)]  
LRS1311@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1311A@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1315@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1316@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1317@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1320@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1320A@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1329@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1329A@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1330A@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1331@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1331B@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1331C@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1336@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1339@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1341@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1342@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1348B@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1350@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1356@FBGA72 [(SA642E-B069A-T072F001)]  
LRS1360@FBGA72 [(SA642B-B023A-Y072F001)]  
LRS1360C@FBGA72 [(SA642B-B023A-Y072F001)]  
LRS1370@FBGA72 [(SA642B-B023A-Y072F001)]  
LRS1370B@FBGA72 [(SA642B-B023A-Y072F001)]  
LRS1380@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1381@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1382@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1383@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1383C@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1383F@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1384@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1385@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1386@FBGA72 [(SA642E-B023A-T072F001)]  
LRS1387@FBGA72 [(SA642E-B023A-T072F001)]

LRS1391@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1392A@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1393A@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1393C@FBGA72 [ ( SA642E-B023A-T072F001N ) ]  
LRS1395@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1396@TSOP56 [ ( SA628-B178 ) ]  
LRS13A0@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS13A1@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS13A2@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS13A3@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS13A4@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS13A5@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS13A6@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS13A8@TSOP56 [ ( SA628-B216 ) ]  
LRS1805A@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1806A@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1806F@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]  
LRS1807A@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1808A@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1811@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1812@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1816@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1816A@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1822@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1825@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1826@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1826A@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1827@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1828@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1829@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1832@FBGA72 [ ( SA642E-B052A-T072F001 ) ]  
LRS1844@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1845@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1850@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1851@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1852@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1853@FBGA72 [ ( SA642E-B023A-T072F001 ) ]  
LRS1871@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]  
LRS1872@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]  
LRS1875@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]  
LRS1876@FBGA72 [ ( SA642B-B023A-Y072F001Y ) ]  
LRS18B0@FBGA72 [ ( SA642E-B141A-T072F001Y ) ]  
LRS18BK@FBGA88 [ ( SA642A-B091A-Y096F001 ) ]

LRS18BL@FBGA88 [ ( SA642A-B091A-Y096F001 ) ]

LRS18BS@FBGA72 [ ( SA642B-B023A-Y072F001 ) ]

## SHARP-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

LH28F640BFHE ( PT ) @ TSOP48 [ ( SA247-B005 ) ]

## SIEMENS

### E ( E ) PROM / FRAM / NVRAM

SDA2526 [ ( SA602A ) ]	SDA2526@SOIC8
SDA2546 [ ( SA602A ) ]	SDA2546@SOIC8
SDA25X26 [ ( SA602A ) ]	SDA25X26@SOIC8
SDA25X46 [ ( SA602A ) ]	SDA25X46@SOIC8
SDE2526 [ ( SA602A ) ]	SDE2526@SOIC8
SDE2546 [ ( SA602A ) ]	SDE2546@SOIC8
SDE25X26 [ ( SA602A ) ]	SDE25X26@SOIC8
SDE25X46 [ ( SA602A ) ]	SDE25X46@SOIC8
SLA24C01 [ ( SA602A ) ]	SLA24C01@SOIC8
SLA24C02 [ ( SA602A ) ]	SLA24C02@SOIC8
SLA24C04 [ ( SA602A ) ]	SLA24C04@SOIC8
SLA24C08 [ ( SA602A ) ]	SLA24C08@SOIC8
SLA24C16 [ ( SA602A ) ]	SLA24C16@SOIC8
SLA24C164	SLA24C164@SOIC8

[ (SA602A) ]	
SLA24C32	SLA24C32@SOIC8
[ (SA602A) ]	
SLA24C64	SLA24C64@SOIC8
[ (SA602A) ]	
SLA25010	SLA25010@SOIC8
[ (SA602A) ]	
SLA25020	SLA25020@SOIC8
[ (SA602A) ]	
SLA25040	SLA25040@SOIC8
[ (SA602A) ]	
SLA25080	SLA25080@SOIC8
[ (SA602A) ]	
SLA25160	SLA25160@SOIC8
[ (SA602A) ]	
SLE24C01	SLE24C01@SOIC8
[ (SA602A) ]	
SLE24C02	SLE24C02@SOIC8
[ (SA602A) ]	
SLE24C04	SLE24C04@SOIC8
[ (SA602A) ]	
SLE24C08	SLE24C08@SOIC8
[ (SA602A) ]	
SLE24C16	SLE24C16@SOIC8
[ (SA602A) ]	
SLE24C164	SLE24C164@SOIC8
[ (SA602A) ]	
SLE24C32	SLE24C32@SOIC8
[ (SA602A) ]	
SLE24C64	SLE24C64@SOIC8
[ (SA602A) ]	
SLE25010	SLE25010@SOIC8
[ (SA602A) ]	
SLE25020	SLE25020@SOIC8
[ (SA602A) ]	
SLE25040	SLE25040@SOIC8
[ (SA602A) ]	
SLE25080	SLE25080@SOIC8
[ (SA602A) ]	
SLE25160	SLE25160@SOIC8
[ (SA602A) ]	



**SIGNETICS****E ( E ) PROM / FRAM / NVRAM**

27C010 [ ( SA015A1T ) ]	27C010@PLCC32
27C010@TSOP32 [ ( SA410T ) ]	
27C040 27C040@PLCC32 [ ( SA015A1T ) ]	27C040@TSOP32
[ ( SA410T ) ]	
27C210 [ ( SA244 ) ]	27C210@PLCC44
27C240 [ ( SA244 ) ]	27C240@PLCC44
27C256 [ ( SA015A1T ) ]	27C256@PLCC32
27C512 [ ( SA015A1T ) ]	27C512@PLCC32
27C64A [ ( SA015A1T ) ]	27C64A@PLCC32
27HC641 [ ( SA008A ) ]	27HC641@PLCC28
27HC642 [ ( SA008A ) ]	27HC642@PLCC28
PCA8582A [ ( SA602A ) ]	PCA8582A@SOIC8
PCA8582B [ ( SA602A ) ]	PCA8582B@SOIC8
PCA8582C [ ( SA602A ) ]	PCA8582C@SOIC8
PCA8582D [ ( SA602A ) ]	PCA8582D@SOIC8
PCA8582E [ ( SA602A ) ]	PCA8582E@SOIC8
PCD8582A [ ( SA602A ) ]	PCD8582A@SOIC8
PCD8582B [ ( SA602A ) ]	PCD8582B@SOIC8
PCD8582C [ ( SA602A ) ]	PCD8582C@SOIC8
PCD8582D [ ( SA602A ) ]	PCD8582D@SOIC8
PCD8582E	PCD8582E@SOIC8

[ (SA602A) ]	
PCF8582A	PCF8582A@SOIC8
[ (SA602A) ]	
PCF8582B	PCF8582B@SOIC8
[ (SA602A) ]	
PCF8582C	PCF8582C@SOIC8
[ (SA602A) ]	
PCF8582D	PCF8582D@SOIC8
[ (SA602A) ]	
PCF8582E	PCF8582E@SOIC8
[ (SA602A) ]	
PCF8594	PCF8594@SOIC8
[ (SA626A) ]	
PCF8594C	PCF8594C@SOIC8
[ (SA626A) ]	
PCF8594D	PCF8594D@SOIC8
[ (SA626A) ]	
PCF8594E	PCF8594E@SOIC8
[ (SA626A) ]	
PCF8598	PCF8598@SOIC8
[ (SA626A) ]	
PCF8598C	PCF8598C@SOIC8
[ (SA626A) ]	
PCF8598D	PCF8598D@SOIC8
[ (SA626A) ]	
PCF8598E	PCF8598E@SOIC8
[ (SA626A) ]	

## MICROCONTROLLER

S87C51	S87C51@PLCC44
[ (SA244) ]	
S87C51@TQFP44 [ (SA245A) ]	
S87C51FA	
S87C51FA@PLCC44 [ (SA244) ]	S87C51FA@TQFP44
[ (SA245A) ]	
S87C51FB	S87C51FB@PLCC44
[ (SA244) ]	
S87C51FB@TQFP44 [ (SA245A) ]	
S87C51FC	
S87C51FC@PLCC44 [ (SA244) ]	S87C51FC@TQFP44
[ (SA245A) ]	

S87C52 [ (SA244) ] S87C52@TQFP44 [ (SA245A) ] S87C524 S87C524@PLCC44 [ (SA244) ] [ (SA245A) ] S87C528 [ (SA244) ] S87C528@TQFP44 [ (SA245A) ] S87C54 S87C54@PLCC44 [ (SA244) ] [ (SA245A) ] S87C550 [ (SA244) ] S87C552@PLCC68 ( * ) [ (SA648-B6806) ] S87C554@PLCC68 ( * ) [ (SA648-B6806) ] S87C575 [ (SA244) ] S87C575@TQFP44 [ (SA245A) ] S87C576 S87C576@PLCC44 [ (SA244) ] [ (SA245A) ] S87C58 [ (SA244) ] S87C58@TQFP44 [ (SA245A) ] [ (SA244) ] S87C591@TQFP44 [ (SA245A) ] S87C652 S87C652@PLCC44 [ (SA244) ] [ (SA245A) ] S87C654 [ (SA244) ] S87C654@TQFP44 [ (SA245A) ] S87C748 S87C748@PLCC28 [ (SA008A) ] S87C749 S87C749@PLCC28 [ (SA008A) ] S87C750 S87C750@PLCC28 [ (SA008A) ] [ (SA626A) ] S87C751 [ (SA008A) ] S87C751@SSOP24 [ (SA626A) ]	S87C52@PLCC44    S87C524@TQFP44  S87C528@PLCC44   S87C54@TQFP44  S87C550@PLCC44   S87C575@PLCC44   S87C576@TQFP44  S87C58@PLCC44  S87C591@PLCC44   S87C652@TQFP44  S87C654@PLCC44      S87C750@SSOP24  S87C751@PLCC28
---	---

S87C752

S87C752@PLCC28 [(SA008A)]  
[(SA626A)]

S87C752@SSOP28

S87C754

[(SA008A)]

S87C754@PLCC28

S87C754@SSOP28 [(SA626A)]

S87L51FA

S87L51FA@PLCC44 [(SA244)]  
[(SA245A)]

S87L51FA@TQFP44

S87L51FB

[(SA244)]

S87L51FB@PLCC44

S87L51FB@TQFP44 [(SA245A)]

## Silicon Laboratories

### MICROCONTROLLER

C8051F001@TQFP48 [(SA248)]  
[(SA663)]

C8051F002@TQFP32

C8051F006@TQFP48 [(SA248)]  
[(SA663)]

C8051F007@TQFP32

C8051F011@TQFP48 [(SA248)]  
[(SA663)]

C8051F012@TQFP32

C8051F016@TQFP48 [(SA248)]  
[(SA663)]

C8051F017@TQFP32

C8051F019@TQFP48 [(SA248)]

C8051F020@TQFP100(ISP) [ISP-HEADER01]

C8051F021@TQFP64(\*) [(TA050-B005)]

C8051F021@TQFP64(ISP) [ISP-HEADER01]

C8051F022@TQFP100(ISP) [ISP-HEADER01]

C8051F023@TQFP64(\*) [(TA050-B005)]

C8051F023@TQFP64(ISP) [ISP-HEADER01]

C8051F040@TQFP100(ISP) [ISP-HEADER01]

C8051F041@TQFP64(\*) [(TA050-B005)]

C8051F041@TQFP64(ISP) [ISP-HEADER01]

C8051F042@TQFP100(ISP) [ISP-HEADER01]

C8051F043@TQFP64(\*) [(TA050-B005)]

C8051F043@TQFP64(ISP) [ISP-HEADER01]

C8051F044@TQFP100(ISP) [ISP-HEADER01]

C8051F045@TQFP64(\*) [(TA050-B005)]

C8051F045@TQFP64(ISP) [ISP-HEADER01]

C8051F046@TQFP100(ISP) [ISP-HEADER01]

C8051F047@TQFP64(*) [(TA050-B005)]	
C8051F047@TQFP64(ISP) [ISP-HEADER01]	
C8051F206@TQFP48 [(SA248)]	C8051F220@TQFP48
[(SA248)]	
C8051F221@TQFP32 [(SA663)]	C8051F226@TQFP48
[(SA248)]	
C8051F230@TQFP48 [(SA248)]	C8051F231@TQFP32
[(SA663)]	
C8051F236@TQFP48 [(SA248)]	C8051F300
[(SA695A)]	
C8051F301 [(SA695A)]	C8051F302
[(SA695A)]	
C8051F303 [(SA695A)]	C8051F304
[(SA695A)]	
C8051F305 [(SA695A)]	C8051F310@TQFP32
[(SA663)]	
C8051F310-GQ@TQFP32 [(SA663)]	C8051F311@QFN28 [(SA697-
B006)]	
C8051F311-GM@QFN28 [(SA697-B006)]	
C8051F312@TQFP32 [(SA663)]	C8051F312-GQ@TQFP32
[(SA663)]	
C8051F313@QFN28 [(SA697-B006)]	
C8051F313-GM@QFN28 [(SA697-B006)]	
C8051F314@TQFP32 [(SA663)]	C8051F314-GQ@TQFP32
[(SA663)]	
C8051F315@QFN28 [(SA697-B006)]	
C8051F315-GM@QFN28 [(SA697-B006)]	
C8051F316-GM@QFN24 [(SA710-B006)]	
C8051F317-GM@QFN24 [(SA710-B006)]	
C8051F320@TQFP32 [(SA663)]	C8051F321@QFN28 [(SA697-
B006)]	
C8051F326@QFN28 [(SA697-B006)]	
C8051F326-GQ@QFN28 [(SA697-B006)]	
C8051F327@QFN28 [(SA697-B006)]	
C8051F327-GQ@QFN28 [(SA697-B006)]	
C8051F330@MLP20 [(SA692)]	
C8051F330D	
C8051F331@MLP20 [(SA692)]	C8051F332-GM@MLP20
[(SA692)]	
C8051F333-GM@MLP20 [(SA692)]	C8051F334-GM@MLP20
[(SA692)]	
C8051F335-GM@MLP20 [(SA692)]	C8051F336-GM@QFN20
[(SA692)]	

C8051F337-GM@QFN20 [(SA692)]	C8051F338-GM@QFN24
[(SA710)]	
C8051F339-GM@QFN24 [(SA710)]	C8051F340-GQ@TQFP48
[(SA248)]	
C8051F341-GQ@TQFP48 [(SA248)]	C8051F342-GQ@LQFP32
[(SA663)]	
C8051F343-GQ@LQFP32 [(SA663)]	C8051F344-GQ@TQFP48
[(SA248)]	
C8051F345-GQ@TQFP48 [(SA248)]	C8051F346-GQ@LQFP32
[(SA663)]	
C8051F347-GQ@LQFP32 [(SA663)]	C8051F350-GQ@LQFP32
[(SA663)]	
C8051F351-GM@QFN28 [(SA697-B006)]	
C8051F352-GQ@LQFP32 [(SA663)]	
C8051F353-GM@QFN28 [(SA697-B006)]	
C8051F360@QFP48 [(SA248)]	C8051F361@QFP32
[(SA663)]	
C8051F362@QFN28 [(SA697)]	C8051F363@QFP48
[(SA248)]	
C8051F364@QFP32 [(SA663)]	C8051F365@QFN28
[(SA697)]	
C8051F366@QFP32 [(SA663)]	C8051F367@QFN28
[(SA697)]	
C8051F368@QFP32 [(SA663)]	C8051F369@QFN28
[(SA697)]	
C8051F410-GQ@LQFP32 [ordering number is marked above]	
C8051F411-GM@QFN28 [ordering number is marked above]	
C8051F412-GQ@LQFP32 [ordering number is marked above]	
C8051F413-GM@QFN28 [ordering number is marked above]	
C8051F520-IM@QFN10 [(SA695A)]	C8051F521-IM@QFN10
[(SA695A)]	
C8051F523-IM@QFN10 [(SA695A)]	C8051F524-IM@QFN10
[(SA695A)]	
C8051F526-IM@QFN10 [(SA695A)]	C8051F527-IM@QFN10
[(SA695A)]	
C8051F530-IM@QFN20 [(SA692)]	C8051F530-IT@TSSOP20
[(SA026)]	
C8051F531-IM@QFN20 [(SA692)]	C8051F531-IT@TSSOP20
[(SA026)]	
C8051F533-IM@QFN20 [(SA692)]	C8051F533-IT@TSSOP20
[(SA026)]	
C8051F534-IM@QFN20 [(SA692)]	C8051F534-IT@TSSOP20
[(SA026)]	

C8051F536-IM@QFN20 [(SA692)]	C8051F536-IT@TSSOP20
[(SA026)]	
C8051F537-IM@QFN20 [(SA692)]	C8051F537-IT@TSSOP20
[(SA026)]	
C8051T600@QFN11 [(SA695A)]	C8051T600@SOIC14
[(SA602)]	
C8051T601@QFN11 [(SA695A)]	C8051T601@SOIC14
[(SA602)]	
C8051T602@SOIC14 [(SA602)]	C8051T603@SOIC14
[(SA602)]	
C8051T604@QFN11 [(SA695A)]	C8051T604@SOIC14
[(SA602)]	
C8051T605@QFN11 [(SA695A)]	C8051T605@SOIC14
[(SA602)]	
SI8250@LQFP32 [(SA663)]	SI8250@QFN28
[(SA697)]	
SI8251@LQFP32 [(SA663)]	SI8251@QFN28
[(SA697)]	
SI8252@LQFP32 [(SA663)]	SI8252@QFN28
[(SA697)]	

## SILICON7

### E (E) PROM/FRAM/NVRAM

SV4E1602UBA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E1602UTA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E1604UBA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E1604UTA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E1608UBA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E1608UTA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E3204UBA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E3204UTA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E3208UBA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E3208UTA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E3216UBA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4E3216UTA@FBGA56 [(SA642P-B079A-W056F001Y)]
SV4F1602UBA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F1602UTA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F1604UBA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F1604UTA@FBGA66 [(SA642R-B041A-T096F001Y)]
SV4F1608UBA@FBGA66 [(SA642R-B041A-T096F001Y)]

SV4F1608UTA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3204UBA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3204UTA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3208UBA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3208UTA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3216UBA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV4F3216UTA@FBGA66 [ (SA642R-B041A-T096F001Y) ]  
SV5C2832UCR@FBGA72 [ (SA642E-B052A-T072F001) ]  
SV5C3238UBA(NO EFP)@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV5C3238UBA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV5C3238UTA(NO EFP)@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV5C3238UTA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV5C6416UBB(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UBB@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UBR(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UBR@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UTB(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UTB@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UTR(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6416UTR@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6432UBR(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5C6432UTR(NO EFP)@FBGA72 [ (SA642E-B065A-T072F001) ]  
SV5D2832UCA@FBGA88 [ (SA642A-B081A-Y096F001) ]  
SV6C2832UBA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6C2832UTA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6C6416UBA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6C6416UTA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6C6432UBA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6C6432UTA@FBGA72 [ (SA642E-B023A-T072F001Y) ]  
SV6D2832UBA@FBGA88 [ (SA642A-B124A-Y096F001Y) ]  
SV6D2832UTA@FBGA88 [ (SA642A-B124A-Y096F001Y) ]  
SV7C1602UBA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV7C1602UTA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV7C1604UBA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV7C1604UTA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV7C1608UBA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV7C1608UTA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV7C3204UBA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV7C3204UTA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV7C3208UBA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV7C3208UTA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV7C3216UBA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]  
SV7C3216UTA@FBGA72 [ (SA642A-B023A-Y096F001Y) ]



SV7E1602UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E1602UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E1604UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E1604UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E1608UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E1608UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E3204UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E3204UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E3208UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E3208UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E3216UBA@FBGA56 [(SA642A-B032A-Y096F001Y)]  
 SV7E3216UTA@FBGA56 [(SA642A-B032A-Y096F001Y)]

## SIMTEK

### E (E) PROM / FRAM / NVRAM

STK10C48  
 STK10C48@SOIC28(300 mil) [(SA404)]  
 STK10C48@SOIC28(350 mil) [(SA630)]  
 STK10C68 STK10C68@PLCC28  
 [(SA008A)]  
 STK10C68@SOIC28(350 mil) [(SA630)]  
 STK11C48  
 STK11C48@SOIC28(300 mil) [(SA404)]  
 STK11C48@SOIC28(350 mil) [(SA630)]  
 STK11C68 STK11C68@PLCC28  
 [(SA008A)]  
 STK11C68@SOIC28(350 mil) [(SA630)]  
 STK11C88 STK11C88  
 (3V)  
 STK11C88(3V)@SOIC28(300 mil) [(SA404)]  
 STK11C88(3V)@SOIC28(350 mil) [(SA630)]  
 STK11C88@SOIC28(300 mil) [(SA404)]  
 STK11C88@SOIC28(350 mil) [(SA630)]  
 STK12C68 STK12C68@PLCC28  
 [(SA008A)]  
 STK12C68@SOIC28(350 mil) [(SA630)]  
 STK14C88 STK14C88  
 (3V)  
 STK14C88(3V)@PLCC32 [(SA015A1T)]  
 STK14C88(3V)@SOIC32(300 mil) [(SA715)]

STK14C88(3V)@SOIC32(350 mil) [(SA630)]  
STK14C88@PLCC32 [(SA015A1T)]  
STK14C88@SOIC32(300 mil) [(SA715)]  
STK14C88@SOIC32(350 mil) [(SA630)]  
STK14CA8 STK14CA8@SOIC32  
[(SA715)]  
STK14CA8@SSOP48 [(SA669)] STK14D88@SOIC32  
[(SA715)]  
STK14D88@SSOP48 [(SA669)]  
STK15C68  
STK15C68@SOIC28(350 mil) [(SA630)]  
STK15C88  
STK15C88@SOIC28(300 mil) [(SA404)]  
STK15C88@SOIC28(350 mil) [(SA630)]  
STK16C68  
STK16C88  
STK16C88(3V)  
STK16CA8  
STK20C04  
STK22C48  
STK22C48@SOIC28(300 mil) [(SA404)]  
STK22C48@SOIC28(350 mil) [(SA630)]  
STK25C48

## **SIRF**

### **E (E) PROM/FRAM/NVRAM**

GSC3F(LP)-7979@FBGA140 [(SA678G-B190A-M140F001Y)]  
GSC3F-7879@FBGA140 [(SA678G-B190A-M140F001Y)]

## **SMOS**

### **E (E) PROM/FRAM/NVRAM**

SPM27128  
SPM27128C  
SPM27C256  
SPM27C64  
SPM27C64H

**SONIX****MICROCONTROLLER**

SN8P1504 [ (SA404) ]	SN8P1504@SOP18
SN8P1504@SOP28 [ (SA404) ]	
SN8P1506	
SN8P1507@TQFP44 [ (SA245A) ]	
SN8P1602	
SN8P1602@SOP18 [ (SA404) ]	SN8P1602@SSOP20 [ (SA674-
B005) ]	
SN8P1603	SN8P1603@SOP18
[ (SA404) ]	
SN8P1603@SSOP20 [ (SA674-B005) ]	
SN8P1604	
SN8P1604@SOP28 [ (SA404) ]	
SN8P1702	
SN8P1702@SOP18 [ (SA404) ]	SN8P1702@SSOP20 [ (SA674-
B005) ]	
SN8P1704A	SN8P1704A@SOP28
[ (SA404) ]	
SN8P1704B	SN8P1704B@SOP28
[ (SA404) ]	
SN8P1706A	
SN8P1706B	
SN8P1707A	SN8P1707A@TQFP44
[ (SA245A) ]	
SN8P1707B@TQFP44 [ (SA245A) ]	
SN8P1708A	
SN8P1708A@SSOP48 [ (SA669) ]	
SN8P1708B	
SN8P1708B@SSOP48 [ (SA669) ]	
SN8P1714	
SN8P1714@SOP18 [ (SA404) ]	SN8P1714@SOP28
[ (SA404) ]	
SN8P1716	SN8P1717@TQFP44
[ (SA245A) ]	
SN8P2501AP	SN8P2501AS@SOP14
[ (SA602) ]	
SN8P2501AX@TSSOP16 [ (SA026) ]	

SN8P2501BP	
SN8P2501BS@SOP14 [(SA602)]	SN8P2501BX@TSSOP16
[(SA026)]	
SN8P2602AP	SN8P2602AS@SOP18
[(SA023A)]	
SN8P2602AX@SSOP20 [(SA674)]	
SN8P2602BP	
SN8P2602BS@SOP18 [(SA023A)]	SN8P2602BX@SSOP20
[(SA674)]	
SN8P2603AP	SN8P2603AS@SOP18
[(SA023A)]	
SN8P2603AX@SSOP20 [(SA674)]	
SN8P2603BP	
SN8P2603BS@SOP18 [(SA023A)]	SN8P2603BX@SSOP20
[(SA674)]	
SN8P26042AP	SN8P26042AS@SOP20
[(SA023A)]	
SN8P26042AX@SSOP20 [(SA674)]	
SN8P26042BP	
SN8P26042BS@SOP20 [(SA023A)]	SN8P26042BX@SSOP20
[(SA674)]	
SN8P26042P	SN8P26042S@SOP20
[(SA023A)]	
SN8P26042X@SSOP20 [(SA674)]	
SN8P2604AK	
SN8P2604AS@SOP28 [(SA404)]	SN8P2604AX@SSOP28
[(SA626A)]	
SN8P2604BK	SN8P2604BS@SOP28
[(SA404)]	
SN8P2604BX@SSOP28 [(SA626A)]	
SN8P2604K	
SN8P2604S@SOP28 [(SA404)]	SN8P2604X@SSOP28
[(SA626A)]	
SN8P2606P	
SN8P2608P	
SN8P2608X@SSOP48 [(SA669)]	
SN8P2622P	
SN8P2622S@SOP18 [(SA023A)]	SN8P2622X@SSOP20
[(SA674)]	
SN8P2624K	SN8P2624S@SOP28
[(SA404)]	
SN8P2624X@SSOP28 [(SA626A)]	SN8P2704AK@SDIP28
[(SA653)]	

SN8P2704AP

[ (SA723) ]

SN8P2705AP

[ (SA687) ]

SN8P2706AP

[ (SA245A) ]

SN8P2708AP

[ (SA248) ]

SN8P2708AX@TSOP48 [ (SA669) ]

SN8P2722P

SN8P2722S@SOP20 [ (SA023A) ]

[ (SA674) ]

SN8P2704AS@SOP28

SN8P2705AS@SOP32

SN8P2707AQ@QFP44

SN8P2708AQ@LQFP48

SN8P2722X@SSOP20

## SONY

### E ( E ) PROM / FRAM / NVRAM

CXK1011M@SOIC8 [ (SA602A) ]

CXK1011P

CXK1012P

CXK1013P

CXK1023P

CXK27C4001

### DRAM & SRAM

CXK581000

[ (SA630) ]

CXK581000@SOIC32

## SPACE ELECTRONICS[SEi]

### E ( E ) PROM / FRAM / NVRAM

28C010

[ (SA015A1T) ]

28C010@TSOP32 [ (SA410T) ]

28C010T

28C010T@PLCC32 [ (SA015A1T) ]

[ (SA410T) ]

28C010@PLCC32

28C010T@TSOP32

28C011	28C011@PLCC32
[ (SA015A1T) ]	
28C011@TSOP32 [ (SA410T) ]	
28C011T	
28C011T@PLCC32 [ (SA015A1T) ]	28C011T@TSOP32
[ (SA410T) ]	

## SPANSION

### E ( E ) PROM / FRAM / NVRAM

AM29BL162CB@SSOP56 [ (SA629A-B022) ]  
 AM29BL802CB@SSOP56 [ (SA629A-B022) ]  
 AM29DL161DB@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29DL161DB@FBGA63 [ (SA642C-B026A-Y056F001) ]  
 AM29DL161DB@FBGA64 [ (SA655A-B044A-T064N001) ]  
 AM29DL161DB@TSOP48 [ (SA247-B005) ]  
 AM29DL161DB@VFBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29DL161DT@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29DL161DT@FBGA63 [ (SA642C-B026A-Y056F001) ]  
 AM29DL161DT@FBGA64 [ (SA655A-B044A-T064N001) ]  
 AM29DL161DT@TSOP48 [ (SA247-B005) ]  
 AM29DL161DT@VFBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29DL162CB@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29DL162CB@TSOP48 [ (SA247-B005) ]  
 AM29DL162CT@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29DL162CT@TSOP48 [ (SA247-B005) ]  
 AM29DL162DB@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29DL162DB@FBGA63 [ (SA642C-B026A-Y056F001) ]  
 AM29DL162DB@FBGA64 [ (SA655A-B044A-T064N001) ]  
 AM29DL162DB@TSOP48 [ (SA247-B005) ]  
 AM29DL162DB@VFBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29DL162DT@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29DL162DT@FBGA63 [ (SA642C-B026A-Y056F001) ]  
 AM29DL162DT@FBGA64 [ (SA655A-B044A-T064N001) ]  
 AM29DL162DT@TSOP48 [ (SA247-B005) ]  
 AM29DL162DT@VFBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29DL163CB@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29DL163CB@TSOP48 [ (SA247-B005) ]  
 AM29DL163CT@FBGA48 [ (SA642B-B026A-Y072F001) ]  
 AM29DL163CT@TSOP48 [ (SA247-B005) ]  
 AM29DL163DB@FBGA48 [ (SA642B-B026A-Y072F001) ]

AM29DL163DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL163DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL163DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL163DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL163DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL163DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL163DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL164DB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL164DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DB@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL164DT@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29DL164DT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL164DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL164DT@VFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GB@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL320GB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL320GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL320GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL320GT@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL320GT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL320GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL321CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL321CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322CB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322CT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL322DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL322GB@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]

AM29DL322GB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL322GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL322GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL322GT@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL322GT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL322GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323CB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323CT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL323DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323GB@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL323GB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL323GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL323GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL323GT@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL323GT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL323GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324CB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324CT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324DB@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL324DB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324DT@FBGA63 [ ( SA642E-B026A-T056N001 ) ]  
AM29DL324DT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324GB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL324GB@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL324GB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL324GB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL324GT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29DL324GT@FBGA63 [ ( SA642A-B026A-Y096F001 ) ]  
AM29DL324GT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29DL324GT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL400BB@PSOP44 [ ( SA638-B006 ) ]  
AM29DL400BB@TSOP48 [ ( SA247-B005 ) ]  
AM29DL400BT@PLCC44 [ ( SA638-B006 ) ]  
AM29DL400BT@TSOP48 [ ( SA247-B005 ) ]  
AM29DL640D@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]



AM29DL640D@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL640G@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
 AM29DL640G@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
 AM29DL640G@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL642G@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
 AM29DL800B@PSOP44 [ ( SA638-B006 ) ]      AM29DL800B@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL800BB@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
 AM29DL800BB@PSOP44 [ ( SA638 ) ]  
 AM29DL800BB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL800BT@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
 AM29DL800BT@PSOP44 [ ( SA638 ) ]  
 AM29DL800BT@TSOP48 [ ( SA247-B005 ) ]  
 AM29DL800T@PSOP44 [ ( SA638-B006 ) ]      AM29DL800T@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS163CB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS163CT@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS163DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DS163DB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS163DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DS163DT@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS323DB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DS323DB@TSOP48 [ ( SA247-B005 ) ]  
 AM29DS323DT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
 AM29DS323DT@TSOP48 [ ( SA247-B005 ) ]  
 AM29F002B      AM29F002B@PLCC32  
 [ ( SA015A1T ) ]  
 AM29F002B@TSOP32 [ ( SA410T ) ]  
 AM29F002BB  
 AM29F002BB@PLCC32 [ ( SA015A1T ) ]      AM29F002BB@TSOP32  
 [ ( SA410T ) ]  
 AM29F002BT      AM29F002BT@PLCC32  
 [ ( SA015A1T ) ]  
 AM29F002BT@TSOP32 [ ( SA410T ) ]  
 AM29F002NB  
 AM29F002NB@PLCC32 [ ( SA015A1T ) ]      AM29F002NB@TSOP32  
 [ ( SA410T ) ]  
 AM29F002NBB      AM29F002NBB@PLCC32  
 [ ( SA015A1T ) ]  
 AM29F002NBB@TSOP32 [ ( SA410T ) ]  
 AM29F002NBT  
 AM29F002NBT@PLCC32 [ ( SA015A1T ) ]      AM29F002NBT@TSOP32  
 [ ( SA410T ) ]

AM29F002NT [ (SA015A1T) ]	AM29F002NT@PLCC32
AM29F002NT@TSOP32 [ (SA410T) ]	
AM29F002T AM29F002T@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AM29F002T@TSOP32
AM29F004BB@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AM29F004BB@TSOP32
AM29F004BT@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AM29F004BT@TSOP32
AM29F010 [ (SA015A1T) ]	AM29F010@PLCC32
AM29F010@TSOP32 [ (SA410T) ]	
AM29F010A AM29F010A@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AM29F010A@TSOP32
AM29F010B [ (SA015A1T) ]	AM29F010B@PLCC32
AM29F010B@TSOP32 [ (SA410T) ] [ (SA638) ]	AM29F016@PSOP44
AM29F016@TSOP40 [ (SA409T) ] B005) ]	AM29F016@TSOP48 [ (SA247-
AM29F016B@PSOP44 [ (SA638) ] [ (SA409T) ]	AM29F016B@TSOP40
AM29F016B@TSOP48 [ (SA247-B005) ]	
AM29F016D(REVERSE)@TSOP48 [ (SA247-B005) ]	
AM29F016D@PSOP44 [ (SA638) ] [ (SA409T) ]	AM29F016D@TSOP40
AM29F016D@TSOP48 [ (SA247-B005) ] B005) ]	AM29F017B@TSOP48 [ (SA247-
AM29F017D@TSOP40 [ (SA409T) ] B005) ]	AM29F017D@TSOP48 [ (SA247-
AM29F032B@PSOP44 [ (SA638) ] [ (SA409T) ]	AM29F032B@TSOP40
AM29F040 [ (SA015A1T) ]	AM29F040@PLCC32
AM29F040@TSOP32 [ (SA410T) ]	
AM29F040A AM29F040A@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	AM29F040A@TSOP32
AM29F040B AM29F040B(Reverse)@TSOP32 [ (SA410T) ]	
AM29F040B@PLCC32 [ (SA015A1T) ]	AM29F040B@TSOP32

[ (SA410T) ]	
AM29F080@PSOP44 [ (SA638) ]	AM29F080@TSOP40
[ (SA409T) ]	
AM29F080B@PSOP44 [ (SA638) ]	AM29F080B@TSOP40
[ (SA409T) ]	
AM29F100BE@PSOP44 [ (SA638-B006) ]	AM29F100BE@TSOP48 [ (SA247-
B005) ]	
AM29F100BS@PSOP44 [ (SA638-B006) ]	AM29F100BS@TSOP48 [ (SA247-
B005) ]	
AM29F100TE@PSOP44 [ (SA638-B006) ]	AM29F100TE@TSOP48 [ (SA247-
B005) ]	
AM29F100TS@PSOP44 [ (SA638-B006) ]	AM29F100TS@TSOP48 [ (SA247-
B005) ]	
AM29F160DB@TSOP48 [ (SA247-B005) ]	AM29F160DT@TSOP48 [ (SA247-
B005) ]	
AM29F200AB@PSOP44 [ (SA638-B006) ]	AM29F200AB@TSOP48 [ (SA247-
B005) ]	
AM29F200AT@PSOP44 [ (SA638-B006) ]	AM29F200AT@TSOP48 [ (SA247-
B005) ]	
AM29F200BB@PSOP44 [ (SA638-B006) ]	AM29F200BB@TSOP48 [ (SA247-
B005) ]	
AM29F200BE@PSOP44 [ (SA638-B006) ]	AM29F200BE@TSOP48 [ (SA247-
B005) ]	
AM29F200BS@PSOP44 [ (SA638-B006) ]	AM29F200BS@TSOP48 [ (SA247-
B005) ]	
AM29F200BT@PSOP44 [ (SA638-B006) ]	AM29F200BT@TSOP48 [ (SA247-
B005) ]	
AM29F200TE@PSOP44 [ (SA638-B006) ]	AM29F200TE@TSOP48 [ (SA247-
B005) ]	
AM29F200TS@PSOP44 [ (SA638-B006) ]	AM29F200TS@TSOP48 [ (SA247-
B005) ]	
AM29F400AB@PSOP44 [ (SA638-B006) ]	AM29F400AB@TSOP48 [ (SA247-
B005) ]	
AM29F400AT@PSOP44 [ (SA638-B006) ]	AM29F400AT@TSOP48 [ (SA247-
B005) ]	
AM29F400BB@PSOP44 [ (SA638-B006) ]	AM29F400BB@TSOP48 [ (SA247-
B005) ]	
AM29F400BBE@PSOP44 [ (SA638-B006) ]	
AM29F400BBE@TSOP48 [ (SA247-B005) ]	
AM29F400BBF@PSOP44 [ (SA638-B006) ]	
AM29F400BBF@TSOP48 [ (SA247-B005) ]	
AM29F400BBS@PSOP44 [ (SA638-B006) ]	
AM29F400BBS@TSOP48 [ (SA247-B005) ]	

AM29F400BE@PSOP44 [ (SA638-B006) ]	AM29F400BE@TSOP48 [ (SA247-B005) ]
AM29F400BF@PSOP44 [ (SA638-B006) ]	AM29F400BF@TSOP48 [ (SA247-B005) ]
AM29F400BS@PSOP44 [ (SA638-B006) ]	AM29F400BS@TSOP48 [ (SA247-B005) ]
AM29F400BT@PSOP44 [ (SA638-B006) ]	AM29F400BT@TSOP48 [ (SA247-B005) ]
AM29F400BTE@PSOP44 [ (SA638-B006) ]	
AM29F400BTE@TSOP48 [ (SA247-B005) ]	
AM29F400BTF@PSOP44 [ (SA638-B006) ]	
AM29F400BTF@TSOP48 [ (SA247-B005) ]	
AM29F400BTS@PSOP44 [ (SA638-B006) ]	
AM29F400BTS@TSOP48 [ (SA247-B005) ]	
AM29F800B@PSOP44 [ (SA638-B006) ]	AM29F800B@TSOP48 [ (SA247-B005) ]
AM29F800BB@PSOP44 [ (SA638-B006) ]	AM29F800BB@TSOP48 [ (SA247-B005) ]
AM29F800BBF@PSOP44 [ (SA638-B006) ]	
AM29F800BBF@TSOP48 [ (SA247-B005) ]	
AM29F800BF@PSOP44 [ (SA638-B006) ]	AM29F800BF@TSOP48 [ (SA247-B005) ]
AM29F800BT@PSOP44 [ (SA638-B006) ]	AM29F800BT@TSOP48 [ (SA247-B005) ]
AM29F800BTF@PSOP44 [ (SA638-B006) ]	
AM29F800BTF@TSOP48 [ (SA247-B005) ]	
AM29F800T@PSOP44 [ (SA638-B006) ]	AM29F800T@TSOP48 [ (SA247-B005) ]
AM29F800TB@PSOP44 [ (SA638-B006) ]	AM29F800TB@TSOP48 [ (SA247-B005) ]
AM29F800TF@PSOP44 [ (SA638-B006) ]	AM29F800TF@TSOP48 [ (SA247-B005) ]
AM29LL800B@TSOP48 [ (SA247-B005) ]	
AM29LL800BB@TSOP48 [ (SA247-B005) ]	
AM29LL800BT@TSOP48 [ (SA247-B005) ]	
AM29LL800T@TSOP48 [ (SA247-B005) ]	AM29LV001BB@PLCC32
[ (SA015A1T) ]	
AM29LV001BB@TSOP32 [ (SA410T) ]	AM29LV001BT@PLCC32
[ (SA015A1T) ]	
AM29LV001BT@TSOP32 [ (SA410T) ]	AM29LV002@TSOP40
[ (SA409T) ]	
AM29LV002B@TSOP40 [ (SA409T) ]	AM29LV002BB@TSOP40
[ (SA409T) ]	

AM29LV002BT@TSOP40 [ (SA409T) ] [ (SA638) ]	AM29LV004B@PSOP44
AM29LV004B@TSOP40 [ (SA409T) ] [ (SA409T) ]	AM29LV004BB@TSOP40
AM29LV004BT@TSOP40 [ (SA409T) ] [ (SA638) ]	AM29LV004T@PSOP44
AM29LV004T@TSOP40 [ (SA409T) ] [ (SA638) ]	AM29LV008B@PSOP44
AM29LV008B@TSOP40 [ (SA409T) ] [ (SA409T) ]	AM29LV008BB@TSOP40
AM29LV008BT@TSOP40 [ (SA409T) ] [ (SA638) ]	AM29LV008T@PSOP44
AM29LV008T@TSOP40 [ (SA409T) ] [ (SA015A1T) ]	AM29LV010B@PLCC32
AM29LV010B@TSOP32 [ (SA410T) ] [ (SA409T) ]	AM29LV017B@TSOP40
AM29LV017D@FBGA48 [ (SA642B-B026A-Y072F001) ]	
AM29LV017D@TSOP40 [ (SA409T) ] [ (SA015A1T) ]	AM29LV020B@PLCC32
AM29LV020B@TSOP32 [ (SA410T) ]	
AM29LV033C@FBGA63 [ (SA642A-B026A-Y096N001) ]	
AM29LV033C@TSOP40 [ (SA409T) ]	
AM29LV033MU@FBGA48 [ (SA642B-B026A-Y072F001) ]	
AM29LV033MU@TSOP40 [ (SA409T) ] [ (SA015A1T) ]	AM29LV040B@PLCC32
AM29LV040B@TSOP32 [ (SA410T) ] [ (SA015A1T) ]	AM29LV040E@PLCC32
AM29LV040E@TSOP32 [ (SA410T) ] [ (SA015A1T) ]	AM29LV040J@PLCC32
AM29LV040J@TSOP32 [ (SA410T) ]	
AM29LV065D@FBGA63 [ (SA642C-B026A-Y056F001) ]	
AM29LV065D@TSOP48 [ (SA247-B005) ]	
AM29LV065MU@FBGA63 [ (SA642C-B026A-Y056F001) ]	
AM29LV065MU@TSOP48 [ (SA247-B005) ]	
AM29LV080@TSOP40 [ (SA409T) ] [ (SA409T) ]	AM29LV081@TSOP40
AM29LV081B@TSOP40 [ (SA409T) ] [ (SA409T) ]	AM29LV116BB@TSOP40
AM29LV116BT@TSOP40 [ (SA409T) ] [ (SA409T) ]	AM29LV116DB@TSOP40
AM29LV116DT@TSOP40 [ (SA409T) ]	
AM29LV128MH@FBGA64 [ (SA655F-B099A-W064F001Y) ]	
AM29LV128MH@TSOP56 [ (SA628-B067) ]	

AM29LV128ML@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
AM29LV128ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV160BB@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
AM29LV160BB@PSOP44 [ ( SA638 ) ]  
AM29LV160BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160BT@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
AM29LV160BT@PSOP44 [ ( SA638 ) ]  
AM29LV160BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160DB(REVERSE)@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160DB@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
AM29LV160DB@PSOP44 [ ( SA638 ) ]  
AM29LV160DB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160DT(REVERSE)@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160DT@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
AM29LV160DT@PSOP44 [ ( SA638 ) ]  
AM29LV160DT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160MB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29LV160MB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV160MB@PSOP44 [ ( SA638 ) ]  
AM29LV160MB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV160MT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29LV160MT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV160MT@PSOP44 [ ( SA638 ) ]  
AM29LV160MT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200B@PSOP44 [ ( SA638-B006 ) ]      AM29LV200B@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BB@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BE@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BE@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BF@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BF@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BS@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BS@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200BT@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200T@PSOP44 [ ( SA638-B006 ) ]      AM29LV200T@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TE@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200TE@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TF@PSOP44 [ ( SA638-B006 ) ]  
AM29LV200TF@TSOP48 [ ( SA247-B005 ) ]  
AM29LV200TS@PSOP44 [ ( SA638-B006 ) ]

AM29LV200TS@TSOP48 [ ( SA247-B005 ) ]  
AM29LV256MH@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
AM29LV256MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV256ML@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
AM29LV256ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320DB@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29LV320DB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320DT@FBGA48 [ ( SA642E-B026A-T072F001 ) ]  
AM29LV320DT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320FB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320FT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320MB@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AM29LV320MB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV320MB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV320MH@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV320MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320ML@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV320ML@TSOP56 [ ( SA628-B067 ) ]  
AM29LV320MT@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
AM29LV320MT@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV320MT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400B@PSOP44 [ ( SA638-B006 ) ]      AM29LV400B@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400BB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29LV400BB@PSOP44 [ ( SA638-B006 ) ]  
AM29LV400BB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400BT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29LV400BT@PSOP44 [ ( SA638-B006 ) ]  
AM29LV400BT@TSOP48 [ ( SA247-B005 ) ]  
AM29LV400T@PSOP44 [ ( SA638-B006 ) ]      AM29LV400T@TSOP48 [ ( SA247-B005 ) ]  
AM29LV640DH@SSOP56 [ ( SA629A-B020 ) ]  
AM29LV640DL@SSOP56 [ ( SA629A-B020 ) ]  
AM29LV640DU@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640DU@FBGA64 [ ( SA655D-B044A-W064F001 ) ]  
AM29LV640GU@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
AM29LV640GU@FBGA64 [ ( SA655D-B044A-W064F001 ) ]  
AM29LV640MB@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
AM29LV640MB@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV640MB@TSOP48 [ ( SA247-B005 ) ]  
AM29LV640MH@FBGA64 [ ( SA655A-B044A-T064N001 ) ]  
AM29LV640MH@TSOP56 [ ( SA628-B067 ) ]  
AM29LV640ML@FBGA64 [ ( SA655A-B044A-T064N001 ) ]

AM29LV640ML@TSOP56 [ (SA628-B067) ]  
AM29LV640MT@FBGA63 [ (SA642C-B026A-Y056F001) ]  
AM29LV640MT@FBGA64 [ (SA655A-B044A-T064N001) ]  
AM29LV640MT@TSOP48 [ (SA247-B005) ]  
AM29LV640MU@FBGA63 [ (SA642C-B026A-Y056F001) ]  
AM29LV640MU@FBGA64 [ (SA655A-B044A-T064N001) ]  
AM29LV641DH@TSOP48 [ (SA247-B005) ]  
AM29LV641DHR@TSOP48 [ (SA247-B005) ]  
AM29LV641DL@TSOP48 [ (SA247-B005) ]  
AM29LV641DLR@TSOP48 [ (SA247-B005) ]  
AM29LV641GH@TSOP48 [ (SA247-B005) ]  
AM29LV641GHR@TSOP48 [ (SA247-B005) ]  
AM29LV641GL@TSOP48 [ (SA247-B005) ]  
AM29LV641GLR@TSOP48 [ (SA247-B005) ]  
AM29LV641MH@TSOP48 [ (SA247-B005) ]  
AM29LV641ML@TSOP48 [ (SA247-B005) ]  
AM29LV642G@FBGA64 [ (SA655A-B038A-T064N001) ]  
AM29LV652D@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
AM29LV800B@PSOP44 [ (SA638-B006) ]      AM29LV800B@TSOP48 [ (SA247-B005) ]  
AM29LV800BB@FBGA48 [ (SA642N-B026A-W048F001Y) ]  
AM29LV800BB@PSOP44 [ (SA638-B006) ]  
AM29LV800BB@TSOP48 [ (SA247-B005) ]  
AM29LV800BT@FBGA48 [ (SA642N-B026A-W048F001Y) ]  
AM29LV800BT@PSOP44 [ (SA638-B006) ]  
AM29LV800BT@TSOP48 [ (SA247-B005) ]  
AM29LV800DB(WB)@FBGA48 [ (SA642N-B026A-W048F001Y) ]  
AM29LV800DB(WC)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
AM29LV800DB@PSOP44 [ (SA638) ]  
AM29LV800DB@TSOP48 [ (SA247-B005) ]  
AM29LV800DT(WB)@FBGA48 [ (SA642N-B026A-W048F001Y) ]  
AM29LV800DT(WC)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
AM29LV800DT@PSOP44 [ (SA638) ]  
AM29LV800DT@TSOP48 [ (SA247-B005) ]  
AM29LV800T@PSOP44 [ (SA638-B006) ]      AM29LV800T@TSOP48 [ (SA247-B005) ]  
AM29N163DT@FBGA47 [ (SA733A-B206A-M056F001N) ]  
AM29N323DT@FBGA47 [ (SA733A-B206A-M056F001N) ]  
AM29N643GT@FBGA44 [ (SA733A-B206A-M056F001Y) ]  
AM29PDS322DB@FBGA48 [ (SA642E-B026A-T072F001) ]  
AM29PDS322DT@FBGA48 [ (SA642E-B026A-T072F001) ]  
AM29PL160CB@PSOP44 [ (SA638-B006) ]  
AM29PL160CB@TSOP48 [ (SA247-B005) ]



AM29PL160CT@PSOP44 [ ( SA638-B006 ) ]  
AM29PL160CT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL160CB@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29SL160CB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL160CT@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
AM29SL160CT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL400CB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL400CT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800BB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800BT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800CB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800CT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800DB@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800DBUF@FBGA48 [ ( SA716A-B119B-M048F001Y ) ]  
AM29SL800DBVG@FBGA48 [ ( SA716A-B119B-M048F001Y ) ]  
AM29SL800DBVU@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
AM29SL800DBWA@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29SL800DBWC@FBGA48 [ ( SA642R-B026A-W080F001N ) ]  
AM29SL800DT@TSOP48 [ ( SA247-B005 ) ]  
AM29SL800DTUF@FBGA48 [ ( SA716A-B119B-M048F001Y ) ]  
AM29SL800DTV@FBGA48 [ ( SA716A-B119B-M048F001Y ) ]  
AM29SL800DTVU@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
AM29SL800DTWA@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
AM29SL800DTWC@FBGA48 [ ( SA642R-B026A-W080F001N ) ]  
DS42514 ( AM29DL163DB ) @FBGA69 [ ( SA642B-B032A-Y072F001 ) ]  
DS42515 ( AM29DL164 ) @FBGA69 [ ( SA642B-B032A-Y072F001 ) ]  
DS42516 ( AM29DL324 ) @FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
DS42546 ( AM29DL163 ) @FBGA69 [ ( SA642B-B032A-Y072F001 ) ]  
DS42553 ( AM29DL323 ) @FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
DS42585 ( AM29DL323D ) @FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
DS42587 ( AM29DL324D ) @FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
DS42629 ( AM29DL640G ) @VFBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
DS42677 ( AM29LV128MH/L ) @FBGA88 [ ( SA642A-B058A-Y096N001 ) ]  
DS42678 ( AM29LV320MT ) @FBGA67 [ ( SA642E-B041A-T072F001 ) ]  
DS42689 ( AM29LV320MT ) @FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
DS42690 ( AM29LV320MB ) @FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
DS42695 ( AM29LV320MT ) @FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
DS42696 ( AM29LV320MB ) @FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
DS42701 ( AM29LV640MU ) @FBGA88 [ ( SA642W-B116A-W088F001Y ) ]  
DS42725 ( AM50DL128CH ) @FBGA88 [ ( SA642A-B062A-Y096F001 ) ]  
DS42772A ( AM29LV640M ) @FBGA88 [ ( SA642W-B116A-W088F001Y ) ]  
M420000070 ( AM42BDS6408HE8 ) @BGA89 [ ( SA642A-B072A-Y096F001 ) ]  
M420000071 ( AM42BDS6408HE9 ) @BGA89 [ ( SA642A-B072A-Y096F001 ) ]

M420000072 (AM42BDS6408HD8)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000073 (AM42BDS6408HD9)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000074 (AM42BDS6408HE3)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000075 (AM42BDS6408HE4)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000076 (AM42BDS6408HD3)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M420000077 (AM42BDS6408HD4)@BGA89 [ (SA642A-B072A-Y096F001) ]  
M490000030 (AM49PDL129BH)@FBGA73 [ (SA642A-B039A-Y096F001) ]  
M490000031 (AM49PDL129BH)@FBGA73 [ (SA642A-B039A-Y096F001) ]  
M4900000K (AM49PDL129AH)@FBGA73 [ (SA642A-B039A-Y096F001) ]  
M4900000L (AM49PDL129AH)@FBGA73 [ (SA642A-B039A-Y096F001) ]  
MB84VD21081@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21081EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21082@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21082EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21083@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21083EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21084@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21084EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21091@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21091EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21092@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21092EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21093@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21093EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21094@FBGA61 [ (SA642C-B032A-Y056F001) ]  
MB84VD21094EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21181DA@FBGA69 [ (SA642C-B032A-Y056F001) ]  
MB84VD21181EG@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21181EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21182DA@FBGA69 [ (SA642C-B032A-Y056F001) ]  
MB84VD21182EG@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21182EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21183DA@FBGA69 [ (SA642C-B032A-Y056F001) ]  
MB84VD21183EG@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21183EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21184DA@FBGA69 [ (SA642C-B032A-Y056F001) ]  
MB84VD21184EG@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21184EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21191DA@FBGA69 [ (SA642C-B032A-Y056F001) ]  
MB84VD21191EG@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21191EM@FBGA56 [ (SA642C-B032A-Y056F001) ]  
MB84VD21192DA@FBGA69 [ (SA642C-B032A-Y056F001) ]  
MB84VD21192EG@FBGA56 [ (SA642C-B032A-Y056F001) ]

MB84VD21192EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21193EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194DA@FBGA69 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194EG@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD21194EM@FBGA56 [ ( SA642C-B032A-Y056F001 ) ]  
MB84VD22180FA@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22180FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22181A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22181EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22181EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22181FM@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22182A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22182EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22182EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22183A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22183EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22183EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22184EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22184FM@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22190FA@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22190FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22191A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22191EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22191EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22191FM@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22192A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22192EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22192EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22193A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22193EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22193EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22194A@FBGA77 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD22194EC@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22194EE@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD22194FM@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22280FE@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22282EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22283EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22284EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]

MB84VD22290FM@FBGA59 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22292EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22293EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22294EE@FBGA71 [ ( SA642E-B032A-T072F001 ) ]  
MB84VD22386EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22387EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22388EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22396EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22397EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD22398EJ@FBGA71 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD23180FM@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
MB84VD23280EA@FBGA101 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23280EE@FBGA101 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23280FA@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23381EJ@FBGA101 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23381FJ@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VD23381HJ@FBGA56 [ ( SA642F-B032A-T064F001 ) ]  
MB84VD23481FJ@FBGA65 [ ( SA642A-B032A-Y096N001 ) ]  
MB84VF5F5FF4J2@BGA107 [ ( SA642D-B062A-Y088F001 ) ]  
MB84VP23481FK@FBGA65 [ ( SA642JJ-B032A-W064F001Y ) ]  
MB84VP24481HK@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
MB84VP24491HK@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
MBM29DL161BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL161BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL161BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL161TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL161TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL161TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL162BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL162TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL162TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL162TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL163TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL163TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]

MBM29DL163TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL164TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL164TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL320BF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL320BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL320TF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL320TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL321BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL321TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL321TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL321TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL322BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL322TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL322TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL322TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL323BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323BF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL323TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL323TF@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL323TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324BD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL324BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL324BE@TSOP48 [ ( SA247-B005 ) ]

MBM29DL324TD@FBGA63 [ ( SA642E-B026A-T072N001 ) ]  
MBM29DL324TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL324TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29DL324TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL32BF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL32BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL32TF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL32TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL34BF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL34BF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL34TF@FBGA48 [ ( SA642N-B026A-W048F001 ) ]  
MBM29DL34TF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL400BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL400BC@PSOP44 [ ( SA638 ) ]  
MBM29DL400BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL400BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL400TC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL400TC@PSOP44 [ ( SA638 ) ]  
MBM29DL400TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL640E@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
MBM29DL640E@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL64DF@FBGA48 [ ( SA642F-B026A-T064F001 ) ]  
MBM29DL64DF@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800B@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL800B@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800BA@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL800BA@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL800BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL800BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800T@PSOP44 [ ( SA638-B006 ) ]  
MBM29DL800T@TSOP48 [ ( SA247-B005 ) ]  
MBM29DL800TA@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29DL800TA@TSOP48 [ ( SA247-B005 ) ]  
MBM29DS163BE@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
MBM29DS163BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29DS163TE@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
MBM29DS163TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29F001B MBM29F001B@PLCC32

[ ( SA015A1T ) ]	
MBM29F001B@TSOP32 [ ( SA410T ) ]	
MBM29F001T	
MBM29F001T@PLCC32 [ ( SA015A1T ) ]	MBM29F001T@TSOP32
[ ( SA410T ) ]	
MBM29F002B	MBM29F002B@PLCC32
[ ( SA015A1T ) ]	
MBM29F002B@TSOP32 [ ( SA410T ) ]	
MBM29F002NB	
MBM29F002NB@PLCC32 [ ( SA015A1T ) ]	MBM29F002NB@TSOP32
[ ( SA410T ) ]	
MBM29F002NT	MBM29F002NT@PLCC32
[ ( SA015A1T ) ]	
MBM29F002NT@TSOP32 [ ( SA410T ) ]	
MBM29F002T	
MBM29F002T@PLCC32 [ ( SA015A1T ) ]	MBM29F002T@TSOP32
[ ( SA410T ) ]	
MBM29F010	MBM29F010@PLCC32
[ ( SA015A1T ) ]	
MBM29F010@TSOP32 [ ( SA410T ) ]	
MBM29F010A	
MBM29F010A@PLCC32 [ ( SA015A1T ) ]	MBM29F010A@TSOP32
[ ( SA410T ) ]	
MBM29F016@PSOP44 [ ( SA638 ) ]	MBM29F016@TSOP40
[ ( SA409T ) ]	
MBM29F016@TSOP48 [ ( SA247-B005 ) ]	MBM29F016A@PSOP44
[ ( SA638 ) ]	
MBM29F016A@TSOP40 [ ( SA409T ) ]	MBM29F016A@TSOP48 [ ( SA247-
B005 ) ]	
MBM29F016B@PSOP44 [ ( SA638 ) ]	MBM29F016B@TSOP40
[ ( SA409T ) ]	
MBM29F016B@TSOP48 [ ( SA247-B005 ) ]	MBM29F017B@TSOP48 [ ( SA247-
B005 ) ]	
MBM29F017D@TSOP40 [ ( SA409T ) ]	MBM29F017D@TSOP48 [ ( SA247-
B005 ) ]	
MBM29F032B@PSOP44 [ ( SA638 ) ]	MBM29F032B@TSOP40
[ ( SA409T ) ]	
MBM29F033C@TSOP40 [ ( SA409T ) ]	
MBM29F040	
MBM29F040@PLCC32 [ ( SA015A1T ) ]	MBM29F040@TSOP32
[ ( SA410T ) ]	
MBM29F040B	MBM29F040B@PLCC32
[ ( SA015A1T ) ]	

MBM29F040B@TSOP32 [ (SA410T) ] [ (SA015A1T) ]	MBM29F040C@PLCC32
MBM29F040C@TSOP32 [ (SA410T) ] [ (SA638) ]	MBM29F080@PSOP44
MBM29F080@TSOP40 [ (SA409T) ] B005) ]	MBM29F080A@TSOP48 [ (SA247-
MBM29F080B@PSOP44 [ (SA638) ] [ (SA409T) ]	MBM29F080B@TSOP40
MBM29F100B@PSOP44 [ (SA638-B006) ] B005) ]	MBM29F100B@TSOP48 [ (SA247-
MBM29F100T@PSOP44 [ (SA638-B006) ] B005) ]	MBM29F100T@TSOP48 [ (SA247-
MBM29F160BE@TSOP48 [ (SA247-B005) ]	
MBM29F160TE@TSOP48 [ (SA247-B005) ]	
MBM29F200AB@PSOP44 [ (SA638-B006) ]	
MBM29F200AB@TSOP48 [ (SA247-B005) ]	
MBM29F200AT@PSOP44 [ (SA638-B006) ]	
MBM29F200AT@TSOP48 [ (SA247-B005) ]	
MBM29F200B@PSOP44 [ (SA638-B006) ] B005) ]	MBM29F200B@TSOP48 [ (SA247-
MBM29F200T@PSOP44 [ (SA638-B006) ] B005) ]	MBM29F200T@TSOP48 [ (SA247-
MBM29F400AB@PSOP44 [ (SA638-B006) ]	
MBM29F400AB@TSOP48 [ (SA247-B005) ]	
MBM29F400AT@PSOP44 [ (SA638-B006) ]	
MBM29F400AT@TSOP48 [ (SA247-B005) ]	
MBM29F400B@PSOP44 [ (SA638-B006) ] B005) ]	MBM29F400B@TSOP48 [ (SA247-
MBM29F400BB@PSOP44 [ (SA638-B006) ]	
MBM29F400BB@TSOP48 [ (SA247-B005) ]	
MBM29F400BT@PSOP44 [ (SA638-B006) ]	
MBM29F400BT@TSOP48 [ (SA247-B005) ]	
MBM29F400T@PSOP44 [ (SA638-B006) ] B005) ]	MBM29F400T@TSOP48 [ (SA247-
MBM29F800B@PSOP44 [ (SA638-B006) ] B005) ]	MBM29F800B@TSOP48 [ (SA247-
MBM29F800BB@PSOP44 [ (SA638-B006) ]	
MBM29F800BB@TSOP48 [ (SA247-B005) ]	
MBM29F800BT@PSOP44 [ (SA638-B006) ]	
MBM29F800BT@TSOP48 [ (SA247-B005) ]	
MBM29F800T@PSOP44 [ (SA638-B006) ] B005) ]	MBM29F800T@TSOP48 [ (SA247-
MBM29LL800B@TSOP48 [ (SA247-B005) ]	



MBM29LL800BB@TSOP48 [(SA247-B005)]	
MBM29LL800BT@TSOP48 [(SA247-B005)]	
MBM29LL800T@TSOP48 [(SA247-B005)]	
MBM29LV001B@PLCC32 [(SA015A1T)]	MBM29LV001BB@PLCC32
[(SA015A1T)]	
MBM29LV001BB@TSOP32 [(SA410T)]	MBM29LV001BC@PLCC32
[(SA015A1T)]	
MBM29LV001BC@TSOP32 [(SA410T)]	MBM29LV001BT@PLCC32
[(SA015A1T)]	
MBM29LV001BT@TSOP32 [(SA410T)]	MBM29LV001T@TSOP32
[(SA410T)]	
MBM29LV001TC@PLCC32 [(SA015A1T)]	MBM29LV001TC@TSOP32
[(SA410T)]	
MBM29LV002B@TSOP40 [(SA409T)]	MBM29LV002T@TSOP40
[(SA409T)]	
MBM29LV004B@PSOP44 [(SA638)]	MBM29LV004B@TSOP40
[(SA409T)]	
MBM29LV004BB@TSOP40 [(SA409T)]	MBM29LV004BT@TSOP40
[(SA409T)]	
MBM29LV004T@PSOP44 [(SA638)]	MBM29LV004T@TSOP40
[(SA409T)]	
MBM29LV008B@PSOP44 [(SA638)]	MBM29LV008B@TSOP40
[(SA409T)]	
MBM29LV008BB@TSOP40 [(SA409T)]	MBM29LV008BT@TSOP40
[(SA409T)]	
MBM29LV008T@PSOP44 [(SA638)]	MBM29LV008T@TSOP40
[(SA409T)]	
MBM29LV016/B@TSOP40 [(SA409T)]	MBM29LV016/T@TSOP40
[(SA409T)]	
MBM29LV016B@TSOP40 [(SA409T)]	
MBM29LV017@FBGA48 [(SA6420-B026A-T064F001)]	
MBM29LV017@TSOP40 [(SA409T)]	MBM29LV017B@TSOP40
[(SA409T)]	
MBM29LV017E@TSOP40 [(SA409T)]	MBM29LV033C@TSOP40
[(SA409T)]	
MBM29LV080@TSOP40 [(SA409T)]	MBM29LV081@TSOP40
[(SA409T)]	
MBM29LV081B@TSOP40 [(SA409T)]	MBM29LV116B@TSOP40
[(SA409T)]	
MBM29LV160B@SON46 [(SA631)]	MBM29LV160B@SON46
(*)	
MBM29LV160BB@PSOP44 [(SA638-B006)]	
MBM29LV160BB@TSOP48 [(SA247-B005)]	

MBM29LV160BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV160BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV160BM@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV160BM@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV160BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV160BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV160T@SON46 [ ( SA631 ) ] MBM29LV160T@SON46  
( \* )  
MBM29LV160TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV160TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV160TM@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV160TM@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200B@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV200B@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV200BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200BC@PSOP44 [ ( SA638 ) ]  
MBM29LV200BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV200BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV200T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV200TC@PSOP44 [ ( SA638 ) ]  
MBM29LV200TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV320BE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV320BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV320TE@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV320TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400B@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400B@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29LV400BC@PSOP44 [ ( SA638 ) ]  
MBM29LV400BC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV400T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV400TC@FBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
MBM29LV400TC@PSOP44 [ ( SA638 ) ]  
MBM29LV400TC@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV650UE@TSOP48 [ ( SA247-B005 ) ]

MBM29LV651UE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV652UE@FBGA63 [ ( SA642C-B026A-Y056F001 ) ]  
MBM29LV800B@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800B@SON46 [ ( SA631 ) ] MBM29LV800B@SON46  
( \* )  
MBM29LV800B@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BA@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800BA@PSOP44 [ ( SA638 ) ]  
MBM29LV800BA@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BB@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800BE@PSOP44 [ ( SA638 ) ]  
MBM29LV800BE@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800BT@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800BT@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800T@PSOP44 [ ( SA638-B006 ) ]  
MBM29LV800T@SON46 [ ( SA631 ) ] MBM29LV800T@SON46  
( \* )  
MBM29LV800T@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800TA@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800TA@PSOP44 [ ( SA638 ) ]  
MBM29LV800TA@TSOP48 [ ( SA247-B005 ) ]  
MBM29LV800TE@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29LV800TE@PSOP44 [ ( SA638 ) ]  
MBM29LV800TE@TSOP48 [ ( SA247-B005 ) ]  
MBM29PDS323B@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29PDS323T@FBGA63 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29PL160BD@PSOP44 [ ( SA638 ) ]  
MBM29PL160BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL160TD@PSOP44 [ ( SA638 ) ]  
MBM29PL160TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL32BM@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
MBM29PL32BM@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL32TM@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
MBM29PL32TM@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL64LM@TSOP48 [ ( SA247-B005 ) ]  
MBM29PL64LM@TSOP56 [ ( SA628-B067 ) ]  
MBM29QM12DH@FBGA88 [ ( SA642J-B101A-W080F001 ) ]  
MBM29QM12DH@TSOP56 [ ( SA628-B097 ) ]  
MBM29SL160BD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
MBM29SL160BD@TSOP48 [ ( SA247-B005 ) ]  
MBM29SL160TD@FBGA48 [ ( SA642B-B026A-Y072F001 ) ]

MBM29SL160TD@TSOP48 [ ( SA247-B005 ) ]  
MBM29SL800BB@TSOP48 [ ( SA247-B005 ) ]  
MBM29SL800BT@TSOP48 [ ( SA247-B005 ) ]  
PDL127H53V(AM29PDL127H53)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL127H63V(AM29PDL127H63)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL127H68V(AM29PDL127H68)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL127H88V(AM29PDL127H88)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL129H53V(AM29PDL129H53)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL129H63V(AM29PDL129H63)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL129H68V(AM29PDL129H68)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PDL129H88V(AM29PDL129H88)@FBGA80 [ ( SA642A-B070A-Y096N001 ) ]  
PL032J55BAI12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J55BAI15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J55BAW12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J55BAW15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J55BFI12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J55BFI15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J55BFW12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J55BFW15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J60BAI12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J60BAI15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J60BAW12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J60BAW15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J60BFI12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J60BFI15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J60BFW12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J60BFW15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J70BAI12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J70BAI15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J70BAW12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J70BAW15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J70BFI12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J70BFI15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL032J70BFW12(S29PL032J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL032J70BFW15(S29PL032J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL064J55BAI12(S29PL064J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL064J55BAI15(S29PL064J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL064J55BAW12(S29PL064J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL064J55BAW15(S29PL064J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL064J55BFI12(S29PL064J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL064J55BFI15(S29PL064J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
PL064J55BFW12(S29PL064J)@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
PL064J55BFW15(S29PL064J)@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]

PL064J60BAI12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J60BAI15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J60BAW12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J60BAW15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J60BFI12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J60BFI15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J60BFW12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J60BFW15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J70BAI12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J70BAI15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J70BAW12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J70BAW15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J70BFI12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J70BFI15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL064J70BFW12 (S29PL064J)@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
PL064J70BFW15 (S29PL064J)@FBGA56 [ (SA642P-B079A-W056F001Y) ]  
PL127J55BAI00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J55BAI02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J55BAW00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J55BAW02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J55BFI00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J55BFI02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J55BFW00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J55BFW02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J60BAI00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J60BAI02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J60BAW00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J60BAW02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J60BFI00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J60BFI02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J60BFW00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J60BFW02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J65BAI00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J65BAI01 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J65BAI02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J65BAW00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J65BAW01 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J65BAW02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J65BFI00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J65BFI01 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J65BFI02 (S29PL127J)@FBGA64 [ (SA642A-B039A-Y096F001Y) ]  
PL127J65BFW00 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]  
PL127J65BFW01 (S29PL127J)@FBGA80 [ (SA642B-B070A-T072F001Y) ]

PL127J65BFW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
 PL127J70BAI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
 PL127J70BAI01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
 PL127J70BAI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
 PL127J70BAW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
 PL127J70BAW01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
 PL127J70BAW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
 PL127J70BFI00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
 PL127J70BFI01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
 PL127J70BFI02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
 PL127J70BFW00(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
 PL127J70BFW01(S29PL127J)@FBGA80 [(SA642B-B070A-T072F001Y)]  
 PL127J70BFW02(S29PL127J)@FBGA64 [(SA642A-B039A-Y096F001Y)]  
 S19MN02GP30TFP00@TSOP48 [(SA247-B005)]  
 S19MN256P30TFP00@TSOP48 [(SA247-B005)]  
 S19MN512P30TFP00@TSOP48 [(SA247-B005)]  
 S25FL001D@SOIC8 [(SA602A)] S25FL001D@USON8  
 [(SA683)]  
 S25FL002A@SOIC8 [(SA605A)] S25FL002A@USON8  
 [(SA683)]  
 S25FL002D@SOIC8 [(SA602A)] S25FL002D@USON8  
 [(SA683)]  
 S25FL004A@SOIC8 [(SA605A)] S25FL004A@USON8  
 [(SA683)]  
 S25FL004D@SOIC8 [(SA602A)] S25FL004D@USON8  
 [(SA683)]  
 S25FL008A@SOIC8 [(SA605A)] S25FL008A@USON8  
 [(SA683)]  
 S25FL008D@SOIC8 [(SA602A)] S25FL008D@USON8  
 [(SA683)]  
 S25FL016A@SOIC16 [(SA404)]  
 S25FL016A@SOIC16(ISP) [ISP-HEADER01]  
 S25FL016A@SOIC8 [(SA605A)]  
 S25FL016A@SOIC8(ISP) [ISP-HEADER01]  
 S25FL016A@WSON8 [(SA684)]  
 S25FL016A@WSON8(ISP) [ISP-HEADER01]  
 S25FL020A@SOIC8(4.0) [(SA602A)] S25FL020A@SOIC8(5.4)  
 [(SA605A)]  
 S25FL020A@USON8 [(SA683)] S25FL032A@SOIC16  
 [(SA404)]  
 S25FL032A@SOIC16(ISP) [ISP-HEADER01]  
 S25FL032A@WSON8 [(SA684)]  
 S25FL032A@WSON8(ISP) [ISP-HEADER01]

S25FL040A(Bottom Boot)@SOP8(4.0) [(SA602A)]  
 S25FL040A(Bottom Boot)@SOP8(5.4) [(SA605A)]  
 S25FL040A(Bottom Boot)@USON8 [(SA683)]  
 S25FL040A(Top Boot)@SOP8(4.0) [(SA602A)]  
 S25FL040A(Top Boot)@SOP8(5.4) [(SA605A)]  
 S25FL040A(Top Boot)@USON8 [(SA683)]  
 S25FL040A@SOP8(4.0) [(SA602A)] S25FL040A@SOP8(5.4)  
 [(SA605A)]  
 S25FL040A@USON8 [(SA683)] S25FL064A@SOIC16  
 [(SA404)]  
 S25FL064A@SOIC16(ISP) [ISP-HEADER01]  
 S25FL064A@WSON8 [(SA684)]  
 S25FL064A@WSON8(ISP) [ISP-HEADER01]  
 S25FL080A@SOIC8(4.0) [(SA602A)] S25FL080A@SOIC8(5.4)  
 [(SA605A)]  
 S25FL080A@USON8 [(SA683)]  
 S25FL128P(256 KB)@SOIC16 [(SA404)]  
 S25FL128P(256 KB)@SOIC16(ISP) [ISP-HEADER01]  
 S25FL128P(256 KB)@WSON8 [(SA684)]  
 S25FL128P(256 KB)@WSON8(ISP) [ISP-HEADER01]  
 S25FL128P(64 KB)@SOIC16 [(SA404)]  
 S25FL128P(64 KB)@SOIC16(ISP) [ISP-HEADER01]  
 S25FL128P(64 KB)@WSON8 [(SA684)]  
 S25FL128P(64 KB)@WSON8(ISP) [ISP-HEADER01]  
 S25FLK05D@SOIC8 [(SA602A)] S25FLK05D@USON8  
 [(SA683)]  
 S29AD016DBFA01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AD016DBFA02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AD016DBFB01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AD016DBFB02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AD016DBFI01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AD016DBFI02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AD016DBFV01@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AD016DBFV02@FBGA48 [(SA642Z-B026A-W048F001Y)]  
 S29AD016DMFA01@PSOP44 [(SA638)] S29AD016DMFA02@PSOP44  
 [(SA638)]  
 S29AD016DMFB01@PSOP44 [(SA638)] S29AD016DMFB02@PSOP44  
 [(SA638)]  
 S29AD016DMFI01@PSOP44 [(SA638)] S29AD016DMFI02@PSOP44  
 [(SA638)]  
 S29AD016DMFV01@PSOP44 [(SA638)] S29AD016DMFV02@PSOP44  
 [(SA638)]  
 S29AD016DTFA01@TSOP48 [(SA247-B005)]

S29AD016DTFA02@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFB01@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFB02@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFV01@TSOP48 [ ( SA247-B005 ) ]  
S29AD016DTFV02@TSOP48 [ ( SA247-B005 ) ]  
S29AL002BBAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL002BBAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL002BBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL002BBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL002BMAI01@PSOP44 [ ( SA638 ) ] S29AL002BMAI02@PSOP44  
[ ( SA638 ) ]  
S29AL002BMFI01@PSOP44 [ ( SA638 ) ] S29AL002BMFI02@PSOP44  
[ ( SA638 ) ]  
S29AL002BTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL002BTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL002BTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL002BTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL004BBAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004BBAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004BBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004BBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004BMAI01@PSOP44 [ ( SA638 ) ] S29AL004BMAI02@PSOP44  
[ ( SA638 ) ]  
S29AL004BMFI01@PSOP44 [ ( SA638 ) ] S29AL004BMFI02@PSOP44  
[ ( SA638 ) ]  
S29AL004BTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL004BTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL004BTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL004BTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL004DBAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBAN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBAN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBANR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBANR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFNR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL004DBFNR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]



S29AL004DMAI01@PSOP44	[ ( SA638 ) ]	S29AL004DMAI02@PSOP44
[ ( SA638 ) ]		
S29AL004DMAN01@PSOP44	[ ( SA638 ) ]	S29AL004DMAN02@PSOP44
[ ( SA638 ) ]		
S29AL004DMANR1@PSOP44	[ ( SA638 ) ]	S29AL004DMANR2@PSOP44
[ ( SA638 ) ]		
S29AL004DMFI01@PSOP44	[ ( SA638 ) ]	S29AL004DMFI02@PSOP44
[ ( SA638 ) ]		
S29AL004DMFN01@PSOP44	[ ( SA638 ) ]	S29AL004DMFN02@PSOP44
[ ( SA638 ) ]		
S29AL004DMFNR1@PSOP44	[ ( SA638 ) ]	S29AL004DMFNR2@PSOP44
[ ( SA638 ) ]		
S29AL004DTAI01@TSOP48	[ ( SA247-B005 ) ]	
S29AL004DTAI02@TSOP48	[ ( SA247-B005 ) ]	
S29AL004DTAN01@TSOP48	[ ( SA247-B005 ) ]	
S29AL004DTAN02@TSOP48	[ ( SA247-B005 ) ]	
S29AL004DTANR1@TSOP48	[ ( SA247-B005 ) ]	
S29AL004DTANR2@TSOP48	[ ( SA247-B005 ) ]	
S29AL004DTFI01@TSOP48	[ ( SA247-B005 ) ]	
S29AL004DTFI02@TSOP48	[ ( SA247-B005 ) ]	
S29AL004DTFN01@TSOP48	[ ( SA247-B005 ) ]	
S29AL004DTFN02@TSOP48	[ ( SA247-B005 ) ]	
S29AL004DTFNR1@TSOP48	[ ( SA247-B005 ) ]	
S29AL004DTFNR2@TSOP48	[ ( SA247-B005 ) ]	
S29AL008DBAI01@FBGA48	[ ( SA642Z-B026A-W048F001Y ) ]	
S29AL008DBAI02@FBGA48	[ ( SA642Z-B026A-W048F001Y ) ]	
S29AL008DBAN01@FBGA48	[ ( SA642Z-B026A-W048F001Y ) ]	
S29AL008DBAN02@FBGA48	[ ( SA642Z-B026A-W048F001Y ) ]	
S29AL008DBANR1@FBGA48	[ ( SA642Z-B026A-W048F001Y ) ]	
S29AL008DBANR2@FBGA48	[ ( SA642Z-B026A-W048F001Y ) ]	
S29AL008DBFI01@FBGA48	[ ( SA642Z-B026A-W048F001Y ) ]	
S29AL008DBFI02@FBGA48	[ ( SA642Z-B026A-W048F001Y ) ]	
S29AL008DBFN01@FBGA48	[ ( SA642Z-B026A-W048F001Y ) ]	
S29AL008DBFN02@FBGA48	[ ( SA642Z-B026A-W048F001Y ) ]	
S29AL008DBFNR1@FBGA48	[ ( SA642Z-B026A-W048F001Y ) ]	
S29AL008DBFNR2@FBGA48	[ ( SA642Z-B026A-W048F001Y ) ]	
S29AL008DMAI01@PSOP44	[ ( SA638 ) ]	S29AL008DMAI02@PSOP44
[ ( SA638 ) ]		
S29AL008DMAN01@PSOP44	[ ( SA638 ) ]	S29AL008DMAN02@PSOP44
[ ( SA638 ) ]		
S29AL008DMANR1@PSOP44	[ ( SA638 ) ]	S29AL008DMANR2@PSOP44
[ ( SA638 ) ]		
S29AL008DMFI01@PSOP44	[ ( SA638 ) ]	S29AL008DMFI02@PSOP44

[ ( SA638 ) ]  
S29AL008DMFN01@PSOP44 [ ( SA638 ) ] S29AL008DMFN02@PSOP44  
[ ( SA638 ) ]  
S29AL008DMFNR1@PSOP44 [ ( SA638 ) ] S29AL008DMFNR2@PSOP44  
[ ( SA638 ) ]  
S29AL008DTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTAN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTAN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTANR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTANR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFNR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL008DTFNR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DBAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBAN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBAN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBFN01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DBFN02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29AL016DMAI01@PSOP44 [ ( SA638 ) ] S29AL016DMAI02@PSOP44  
[ ( SA638 ) ]  
S29AL016DMAN01@PSOP44 [ ( SA638 ) ] S29AL016DMAN02@PSOP44  
[ ( SA638 ) ]  
S29AL016DMFI01@PSOP44 [ ( SA638 ) ] S29AL016DMFI02@PSOP44  
[ ( SA638 ) ]  
S29AL016DMFN01@PSOP44 [ ( SA638 ) ] S29AL016DMFN02@PSOP44  
[ ( SA638 ) ]  
S29AL016DTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTAN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTAN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTFN01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016DTFN02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MBAI01@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBAI02@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]

S29AL016MBAIR1@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBAIR2@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBFI01@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBFI02@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBFIR1@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MBFIR2@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
S29AL016MFAI01@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFAI02@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFAIR1@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFAIR2@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFFI01@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFFI02@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFFIR1@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MFFIR2@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29AL016MTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTAIR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTAIR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTFIR1@TSOP48 [ ( SA247-B005 ) ]  
S29AL016MTFIR2@TSOP48 [ ( SA247-B005 ) ]  
S29AL032DBAI00@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DBAI03@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DBAI04@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DBFI00@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DBFI03@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DBFI04@FBGA48 [ ( SA642Y-B026A-W048F001N ) ]  
S29AL032DTAI00@TSOP40 [ ( SA409T ) ]  
S29AL032DTAI03@TSOP48 [ ( SA247-B005 ) ]  
S29AL032DTAI04@TSOP48 [ ( SA247-B005 ) ]  
S29AL032DTFI00@TSOP40 [ ( SA409T ) ]  
S29AL032DTFI03@TSOP48 [ ( SA247-B005 ) ]  
S29AL032DTFI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ABAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAI03@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAI04@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAIR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAIR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAIR3@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAIR4@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABAIW1@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]

S29GL016ABAIW2@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S29GL016ABFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFI03@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFI04@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFIR1@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFIR2@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFIR3@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFIR4@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL016ABFIW1@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S29GL016ABFIW2@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S29GL016AFAI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFAI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFAIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFAIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFAIR3@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFAIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFIR3@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016AFFIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL016ATAI01@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAI02@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAIR1@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAIR2@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATAIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATFI01@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATFI02@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATFI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATFI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATFIR1@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATFIR2@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATFIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL016ATFIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL032ABAIR3@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL032ABAIR4 (Normal) @FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL032ABAIR4@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29GL032ABAIW3@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]

S29GL032ABAIW4@FBGA56 [ (SA642P-B032A-W056F001Y) ]  
S29GL032ABFIR3@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
S29GL032ABFIR4@FBGA48 [ (SA642Z-B026A-W048F001Y) ]  
S29GL032ABFIW3@FBGA56 [ (SA642P-B032A-W056F001Y) ]  
S29GL032ABFIW4@FBGA56 [ (SA642P-B032A-W056F001Y) ]  
S29GL032AFAIR1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFAIR2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFAIR3@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFAIR4@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFAIS1 (29LV320MT)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFAIS2 (29LV320MB)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFAIS3 (29LV320MT)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
S29GL032AFAIS4 (29LV320MB)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
S29GL032AFFIR1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFFIR2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFFIR3@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFFIR4@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFFIS1 (29LV320MT)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFFIS2 (29LV320MB)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL032AFFIS3 (29LV320MT)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
S29GL032AFFIS4 (29LV320MB)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
S29GL032ATAIR1@TSOP56 [ (SA628-B102) ]  
S29GL032ATAIR2@TSOP56 [ (SA628-B102) ]  
S29GL032ATAIR3@TSOP48 [ (SA247-B005) ]  
S29GL032ATAIR4@TSOP48 [ (SA247-B005) ]  
S29GL032ATFIR1@TSOP56 [ (SA628-B102) ]  
S29GL032ATFIR2@TSOP56 [ (SA628-B102) ]  
S29GL032ATFIR3@TSOP48 [ (SA247-B005) ]  
S29GL032ATFIR4 (Normal)@TSOP48 [ (SA247-B005) ]  
S29GL032ATFIR4@TSOP48 [ (SA247-B005) ]  
S29GL032MBACR0 (Mirror)@FBGA48 [ (SA642AA-B026A-W064F001N) ]  
S29GL032MBACR0@FBGA48 [ (SA642AA-B026A-W064F001N) ]  
S29GL032MBACR3 (Mirror)@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
S29GL032MBACR3@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
S29GL032MBACR4 (Mirror)@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
S29GL032MBACR4@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
S29GL032MBAIR0 (Mirror)@FBGA48 [ (SA642AA-B026A-W064F001N) ]  
S29GL032MBAIR0@FBGA48 [ (SA642AA-B026A-W064F001N) ]  
S29GL032MBAIR3 (Mirror)@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
S29GL032MBAIR3@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
S29GL032MBAIR4 (Mirror)@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
S29GL032MBAIR4@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
S29GL032MBAIR5@FBGA48 [ (SA642G-B026A-T048F001Y) ]

S29GL032MBAIR6@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFCR0@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFCR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR3@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFCR4@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR0(Mirror)@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFIR0@FBGA48 [(SA642AA-B026A-W064F001N)]  
S29GL032MBFIR3(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR3@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR4(Mirror)@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR4@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR5@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MBFIR6@FBGA48 [(SA642G-B026A-T048F001Y)]  
S29GL032MFACR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFACS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFACS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFACS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFACS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFAIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFAIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFAIS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFAIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFAIS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFCR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR2@FBGA64 [(SA655D-B044A-W064F001Y)]

S29GL032MFFCR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFCS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFCS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFCS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFCS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL032MFFIS1(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFIS2(29LV320MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032MFFIS3(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MFFIS4(29LV320MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL032MTACR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTACR0@TSOP40 [(SA409T)]  
S29GL032MTACR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTACR1@TSOP56 [(SA628-B067)]  
S29GL032MTACR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTACR2@TSOP56 [(SA628-B067)]  
S29GL032MTACR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTACR3@TSOP48 [(SA247-B005)]  
S29GL032MTACR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTACR4@TSOP48 [(SA247-B005)]  
S29GL032MTAIR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTAIR0@TSOP40 [(SA409T)]  
S29GL032MTAIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTAIR1@TSOP56 [(SA628-B067)]  
S29GL032MTAIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTAIR2@TSOP56 [(SA628-B067)]  
S29GL032MTAIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTAIR3@TSOP48 [(SA247-B005)]  
S29GL032MTAIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTAIR4@TSOP48 [(SA247-B005)]  
S29GL032MTFCR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTFCR0@TSOP40 [(SA409T)]  
S29GL032MTFCR1(Mirror)@TSOP56 [(SA628-B067)]

S29GL032MTFCR1@TSOP56 [(SA628-B067)]  
S29GL032MTFCR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFCR2@TSOP56 [(SA628-B067)]  
S29GL032MTFCR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFCR3@TSOP48 [(SA247-B005)]  
S29GL032MTFCR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFCR4@TSOP48 [(SA247-B005)]  
S29GL032MTFIR0(Mirror)@TSOP40 [(SA409T)]  
S29GL032MTFIR0@TSOP40 [(SA409T)]  
S29GL032MTFIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFIR1@TSOP56 [(SA628-B067)]  
S29GL032MTFIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL032MTFIR2@TSOP56 [(SA628-B067)]  
S29GL032MTFIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFIR3@TSOP48 [(SA247-B005)]  
S29GL032MTFIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL032MTFIR4@TSOP48 [(SA247-B005)]  
S29GL032NBAI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBAI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFIO3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFIO4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NBFIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL032NFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAI03@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAI04@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL032NFAIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL032NFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIO1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIO2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIO3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL032NFFIO4@FBGA64 [(SA655F-B099A-W064F001Y)]



S29GL032NFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIR3@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL032NFFIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL032NFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL032NTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTAI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTAI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTAI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTAIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTAIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTAIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTAIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTFI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTFIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTFIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL032NTFIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL032NTFIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL064ABAIR3@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
S29GL064ABAIR4@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
S29GL064ABAIR5@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
S29GL064ABFIR3@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
S29GL064ABFIR4@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
S29GL064ABFIR5@FBGA48 [ ( SA642B-B026A-Y072F001N ) ]  
S29GL064AFAIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFAIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFAIR3@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFAIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFAIR5@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFAIS1 ( 29LV640MT )@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064AFAIS2 ( 29LV640MB )@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]

S29GL064AFAIS3 (29LV640MT)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
S29GL064AFAIS4 (29LV640MB)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
S29GL064AFFIR1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFFIR2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFFIR3@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFFIR4@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFFIR5@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFFIS1 (29LV640MT)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFFIS2 (29LV640MB)@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL064AFFIS3 (29LV640MT)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
S29GL064AFFIS4 (29LV640MB)@FBGA64 [ (SA655E-B090A-T064F001Y) ]  
S29GL064ATAIR1@TSOP56 [ (SA628-B102) ]  
S29GL064ATAIR2@TSOP56 [ (SA628-B102) ]  
S29GL064ATAIR3@TSOP48 [ (SA247-B005) ]  
S29GL064ATAIR4@TSOP48 [ (SA247-B005) ]  
S29GL064ATAIR6@TSOP48 [ (SA247-B005) ]  
S29GL064ATAIR7@TSOP48 [ (SA247-B005) ]  
S29GL064ATAIR8@TSOP48 [ (SA247-B005) ]  
S29GL064ATAIR9@TSOP48 [ (SA247-B005) ]  
S29GL064ATFIR1@TSOP56 [ (SA628-B102) ]  
S29GL064ATFIR2@TSOP56 [ (SA628-B102) ]  
S29GL064ATFIR3@TSOP48 [ (SA247-B005) ]  
S29GL064ATFIR4@TSOP48 [ (SA247-B005) ]  
S29GL064ATFIR6@TSOP48 [ (SA247-B005) ]  
S29GL064ATFIR7@TSOP48 [ (SA247-B005) ]  
S29GL064ATFIR8@TSOP48 [ (SA247-B005) ]  
S29GL064ATFIR9@TSOP48 [ (SA247-B005) ]  
S29GL064MBAIR0 (Mirror)@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBAIR0@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBAIR3 (Mirror)@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBAIR3@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBAIR4 (Mirror)@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBAIR4@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBAIR5 (Mirror)@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBAIR5@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBFIR0 (Mirror)@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBFIR0@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBFIR3 (Mirror)@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBFIR3@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBFIR4 (Mirror)@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBFIR4@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBFIR5 (Mirror)@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
S29GL064MBFIR5@FBGA63 [ (SA642M-B026A-W048F001Y) ]

S29GL064MFAIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR5(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIR5@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFAIS1(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFAIS2(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFAIS3(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MFAIS4(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MFFIR1(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR1@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR2(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR2@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR3(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR3@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR4(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR4@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR5(Mirror)@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIR5@FBGA64 [(SA655D-B044A-W064F001Y)]  
S29GL064MFFIS1(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFFIS2(29LV640MT)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFFIS2(Normal)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064MFFIS3(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MFFIS4(29LV640MT)@FBGA64 [(SA655E-B090A-T064F001Y)]  
S29GL064MTAIR0(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR0@TSOP48 [(SA247-B005)]  
S29GL064MTAIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL064MTAIR1@TSOP56 [(SA628-B067)]  
S29GL064MTAIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL064MTAIR2@TSOP56 [(SA628-B067)]  
S29GL064MTAIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR3@TSOP48 [(SA247-B005)]  
S29GL064MTAIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR4@TSOP48 [(SA247-B005)]  
S29GL064MTAIR6(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR6@TSOP48 [(SA247-B005)]  
S29GL064MTAIR7(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTAIR7@TSOP48 [(SA247-B005)]

S29GL064MTFIR0(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR0@TSOP48 [(SA247-B005)]  
S29GL064MTFIR1(Mirror)@TSOP56 [(SA628-B067)]  
S29GL064MTFIR1@TSOP56 [(SA628-B067)]  
S29GL064MTFIR2(Mirror)@TSOP56 [(SA628-B067)]  
S29GL064MTFIR2@TSOP56 [(SA628-B067)]  
S29GL064MTFIR3(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR3@TSOP48 [(SA247-B005)]  
S29GL064MTFIR4(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR4@TSOP48 [(SA247-B005)]  
S29GL064MTFIR6(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR6@TSOP48 [(SA247-B005)]  
S29GL064MTFIR7(Mirror)@TSOP48 [(SA247-B005)]  
S29GL064MTFIR7@TSOP48 [(SA247-B005)]  
S29GL064NBAI03@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBAI04@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBAIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBAIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIO3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIO4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIR3@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NBFIR4@FBGA48 [(SA642Z-B026A-W048F001Y)]  
S29GL064NFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAI03@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAI04@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIR4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL064NFAIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL064NFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIO1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIO2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIO3@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIO4@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL064NFFIR3@FBGA64 [(SA655F-B099A-W064F001Y)]

S29GL064NFFIR4@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL064NFFIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL064NFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL064NTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAI06@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAI07@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIR6@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIR7@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTAIV6@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTAIV7@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTFI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTFI03@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI04 ( Low )@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI04@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI06@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFI07@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTFIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTFIR3@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFIR4@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFIR6@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFIR7@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTFIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL064NTFIV6@TSOP48 [ ( SA247-B005 ) ]  
S29GL064NTFIV7@TSOP48 [ ( SA247-B005 ) ]  
S29GL128MFAIR1@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29GL128MFAIR2@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29GL128MFFIR1@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]

S29GL128MFFIR2@FBGA64 [ ( SA655D-B044A-W064F001Y ) ]  
S29GL128MTAIR1@TSOP56 [ ( SA628-B067 ) ]  
S29GL128MTAIR2@TSOP56 [ ( SA628-B067 ) ]  
S29GL128MTFIR1@TSOP56 [ ( SA628-B067 ) ]  
S29GL128MTFIR2@TSOP56 [ ( SA628-B067 ) ]  
S29GL128NFAI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIIH@FBGA64 [ ( SA655E-B129A-T056F001Y ) ]  
S29GL128NFAIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128NFAIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128NFAIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAW01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAW02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFAWIH@FBGA64 [ ( SA655E-B129A-T056F001Y ) ]  
S29GL128NFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIIH@FBGA64 [ ( SA655E-B129A-T056F001Y ) ]  
S29GL128NFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128NFFIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL128NFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFW01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NFFW02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL128NTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAW01@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTAW02@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL128NTFIR1@TSOP56 [ ( SA628-B102 ) ]

S29GL128NTFIR2@TSOP56 [ (SA628-B102) ]  
S29GL128NTFIV1@TSOP56 [ (SA628-B102) ]  
S29GL128NTFIV2@TSOP56 [ (SA628-B102) ]  
S29GL128NTFW01@TSOP56 [ (SA628-B102) ]  
S29GL128NTFW02@TSOP56 [ (SA628-B102) ]  
S29GL128PFAI01@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL128PFAI02@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL128PFAIR1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL128PFAIR2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL128PFAIS1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL128PFAIS2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL128PFAIS3@FBGA64 [ (SA655E-B129A-T064F001Y) ]  
S29GL128PFAIS4@FBGA64 [ (SA655E-B129A-T064F001Y) ]  
S29GL128PFAIV1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL128PFAIV2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL128PFFI01@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL128PFFI02@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL128PFFIR1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL128PFFIR2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL128PFFIS1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL128PFFIS2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL128PFFIS3@FBGA64 [ (SA655E-B129A-T064F001Y) ]  
S29GL128PFFIS4@FBGA64 [ (SA655E-B129A-T064F001Y) ]  
S29GL128PFFIV1@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL128PFFIV2@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL128PTAI01@TSOP56 [ (SA628-B102) ]  
S29GL128PTAI02@TSOP56 [ (SA628-B102) ]  
S29GL128PTAIR1@TSOP56 [ (SA628-B102) ]  
S29GL128PTAIR2@TSOP56 [ (SA628-B102) ]  
S29GL128PTAIV1@TSOP56 [ (SA628-B102) ]  
S29GL128PTAIV2@TSOP56 [ (SA628-B102) ]  
S29GL128PTFI01@TSOP56 [ (SA628-B102) ]  
S29GL128PTFI02@TSOP56 [ (SA628-B102) ]  
S29GL128PTFIR1@TSOP56 [ (SA628-B102) ]  
S29GL128PTFIR2@TSOP56 [ (SA628-B102) ]  
S29GL128PTFIV1@TSOP56 [ (SA628-B102) ]  
S29GL128PTFIV2@TSOP56 [ (SA628-B102) ]  
S29GL256MR1@FBGA64 [ (SA655C-B099A-W064F001Y) ]  
S29GL256MR1@TSOP56 [ (SA628-B067) ]  
S29GL256MR2@FBGA64 [ (SA655C-B099A-W064F001Y) ]  
S29GL256MR2@TSOP56 [ (SA628-B067) ]  
S29GL256NFAI01@FBGA64 [ (SA655F-B099A-W064F001Y) ]  
S29GL256NFAI02@FBGA64 [ (SA655F-B099A-W064F001Y) ]

S29GL256NFAIIH@FBGA64 [(SA655E-B129A-T056F001Y)]  
S29GL256NFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFAIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256NFAIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256NFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFFI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFFIIH@FBGA64 [(SA655E-B129A-T056F001Y)]  
S29GL256NFFIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFFIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFFIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFFIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFFIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256NFFIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256NFFIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NFFIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256NTAI01@TSOP56 [(SA628-B102)]  
S29GL256NTAI02@TSOP56 [(SA628-B102)]  
S29GL256NTAIR1@TSOP56 [(SA628-B102)]  
S29GL256NTAIR2@TSOP56 [(SA628-B102)]  
S29GL256NTAIV1@TSOP56 [(SA628-B102)]  
S29GL256NTAIV2@TSOP56 [(SA628-B102)]  
S29GL256NTFI01@TSOP56 [(SA628-B102)]  
S29GL256NTFI02@TSOP56 [(SA628-B102)]  
S29GL256NTFIR1@TSOP56 [(SA628-B102)]  
S29GL256NTFIR2@TSOP56 [(SA628-B102)]  
S29GL256NTFIV1@TSOP56 [(SA628-B102)]  
S29GL256NTFIV2@TSOP56 [(SA628-B102)]  
S29GL256PFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAI02@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAIR1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAIR2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAIS1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAIS2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAIS3@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256PFAIS4@FBGA64 [(SA655E-B129A-T064F001Y)]  
S29GL256PFAIV1@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFAIV2@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PFFI01@FBGA64 [(SA655F-B099A-W064F001Y)]



S29GL256PFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFIR1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFIR2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFIS3@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL256PFFIS4@FBGA64 [ ( SA655E-B129A-T064F001Y ) ]  
S29GL256PFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL256PTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTAI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTAIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTAIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFIR1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFIR2@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL256PTFIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NFA01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFA02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFAIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFAIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFAV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFAV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFF01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFF02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFFIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFFV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NFFV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512NTA01@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTA02@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTAV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTAV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTF01@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTF02@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTFV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL512NTFV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PFAI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFAI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]

S29GL512PFAIR1@FBGA64 [ ( SA655F-B287A-W064F001Y ) ]  
S29GL512PFAIR2@FBGA64 [ ( SA655F-B287A-W064F001Y ) ]  
S29GL512PFAIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFAIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFFI01@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFFI02@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFFIR1@FBGA64 [ ( SA655F-B287A-W064F001Y ) ]  
S29GL512PFFIR2@FBGA64 [ ( SA655F-B287A-W064F001Y ) ]  
S29GL512PFFIS1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFFIS2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFFIV1@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PFFIV2@FBGA64 [ ( SA655F-B099A-W064F001Y ) ]  
S29GL512PTAI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTAI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTAIR1@TSOP56 [ ( SA628-B257 ) ]  
S29GL512PTAIR2@TSOP56 [ ( SA628-B257 ) ]  
S29GL512PTAIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTAIV2@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTFI01@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTFI02@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTFIR1@TSOP56 [ ( SA628-B257 ) ]  
S29GL512PTFIR2@TSOP56 [ ( SA628-B257 ) ]  
S29GL512PTFIV1@TSOP56 [ ( SA628-B102 ) ]  
S29GL512PTFIV2@TSOP56 [ ( SA628-B102 ) ]  
S29JL032HBAI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI21@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI22@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI31@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI32@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI41@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBAI42@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI01@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI02@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI21@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI22@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI31@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI32@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI41@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HBFI42@FBGA48 [ ( SA642Z-B026A-W048F001Y ) ]  
S29JL032HTAI01@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI02@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI21@TSOP48 [ ( SA247-B005 ) ]

S29JL032HTAI22@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI31@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI32@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI41@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTAI42@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI01@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI02@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI21@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI22@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI31@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI32@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI41@TSOP48 [ ( SA247-B005 ) ]  
S29JL032HTFI42@TSOP48 [ ( SA247-B005 ) ]  
S29JL064HBAI00@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
S29JL064HBFI00@FBGA63 [ ( SA642M-B026A-W048F001Y ) ]  
S29JL064HTAI00@TSOP48 [ ( SA247-B005 ) ]  
S29JL064HTAN00@TSOP48 [ ( SA247-B005 ) ]  
S29JL064HTFI00@TSOP48 [ ( SA247-B005 ) ]  
S29JL064HTFN00@TSOP48 [ ( SA247-B005 ) ]  
S29NS016J0LBFW00@FBGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29NS016J0LBJW00@FBGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29NS016J0PBFW00@FBGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29NS016J0PBJW00@FBGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29NS032J0LBFW00@FBGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29NS032J0LBJW00@FBGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29NS032J0PBFW00@FBGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29NS032J0PBJW00@FBGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29NS064J0LBAW00@FBGA44 [ ( SA733A-B206A-M056F001Y ) ]  
S29NS064J0LBFW00@FBGA44 [ ( SA733A-B206A-M056F001Y ) ]  
S29NS064J0LBJW00@FBGA44 [ ( SA733A-B206A-M056F001Y ) ]  
S29NS064J0PBAW00@FBGA44 [ ( SA733A-B206A-M056F001Y ) ]  
S29NS064J0PBFW00@FBGA44 [ ( SA733A-B206A-M056F001Y ) ]  
S29NS064J0PBJW00@FBGA44 [ ( SA733A-B206A-M056F001Y ) ]  
S29NS128J0LBAW00@FBGA48 [ ( SA733A-B206A-M056F001N ) ]  
S29NS128J0LBFW00@FBGA48 [ ( SA733A-B206A-M056F001N ) ]  
S29NS128J0LBJW00@FBGA48 [ ( SA733A-B206A-M056F001N ) ]  
S29NS128J0PBAW00@FBGA48 [ ( SA733A-B206A-M056F001N ) ]  
S29NS128J0PBFW00@FBGA48 [ ( SA733A-B206A-M056F001N ) ]  
S29NS128J0PBJW00@FBGA48 [ ( SA733A-B206A-M056F001N ) ]  
S29PL127J55TAI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J55TAW13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J55TFI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J55TFW13@TSOP56 [ ( SA628-B097 ) ]

S29PL127J60TAI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J60TAW13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J60TFI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J60TFW13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J70TAI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J70TAW13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J70TFI13@TSOP56 [ ( SA628-B097 ) ]  
S29PL127J70TFW13@TSOP56 [ ( SA628-B097 ) ]  
S29VS016K0PBJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS016K0PBJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS016KAABJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS016KAABJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS032K0PBJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS032K0PBJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS032KAABJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS032KAABJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS064K0PBJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS064K0PBJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS064KAABJW00@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29VS064KAABJW01@BGA44 [ ( SA733B-B206A-M044F001Y ) ]  
S29WS064J0PBAI00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAI01@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAI02@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAI03@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAW00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAW01@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAW02@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBAW03@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBFI00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBFI01@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBFW00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0PBFW01@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0SBAI00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0SBAI01@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0SBAI02@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0SBAI03@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0SBAW00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0SBAW01@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0SBAW02@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0SBAW03@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0SBFI00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0SBFI01@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J0SBFW00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]

S29WS064J0SBFW01@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J1ABAI00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J1ABAI01@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J1ABAW00@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS064J1ABAW01@FBGA80 [ ( SA642T-B093A-W080F001Y ) ]  
S29WS128J0PBAI00@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBAI01@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBAI02@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBAI03@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBAI10@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBAI11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBAW00@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBAW01@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBAW02@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBAW03@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBAW10@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBAW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBFI00@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBFI01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBFI10@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBFI11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBFW00@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBFW10@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0PBFW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBAI00@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBAI01@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBAI02@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBAI03@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBAW00@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBAW01@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBAW02@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBAW03@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBFI00@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBFI01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBFW00@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J0SBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J1ABAI00@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J1ABAI01@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J1ABAW00@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128J1ABAW01@FBGA80 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0LBAW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0LBAW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]

S29WS128N0LBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0LBFW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0PBAW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0PBAW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0PBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS128N0PBFW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0LBAW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0LBAW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0LBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0LBFW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0PBAW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0PBAW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0PBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0PBFW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0SBAW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0SBAW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0SBFW01@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S29WS256N0SBFW11@FBGA84 [ ( SA642A-B093A-Y096F001Y ) ]  
S30ML01GP30TFE00@TSOP48 [ ( SA247-B005 ) ]  
S30ML01GP30TFE50@TSOP48 [ ( SA247-B005 ) ]  
S30ML01GP50TFE01@TSOP48 [ ( SA247-B005 ) ]  
S30ML01GP50TFE51@TSOP48 [ ( SA247-B005 ) ]  
S30ML02GP30TFE00@TSOP48 [ ( SA247-B005 ) ]  
S30ML02GP30TFE50@TSOP48 [ ( SA247-B005 ) ]  
S30ML02GP50TFE01@TSOP48 [ ( SA247-B005 ) ]  
S30ML02GP50TFE51@TSOP48 [ ( SA247-B005 ) ]  
S30ML128P30TFE00@TSOP48 [ ( SA247-B005 ) ]  
S30ML128P30TFE50@TSOP48 [ ( SA247-B005 ) ]  
S30ML128P50TFE01@TSOP48 [ ( SA247+B005 ) ]  
S30ML128P50TFE51@TSOP48 [ ( SA247+B005 ) ]  
S30ML256P30TFE00@TSOP48 [ ( SA247-B005 ) ]  
S30ML256P30TFE50@TSOP48 [ ( SA247-B005 ) ]  
S30ML256P50TFE01@TSOP48 [ ( SA247+B005 ) ]  
S30ML256P50TFE51@TSOP48 [ ( SA247+B005 ) ]  
S30ML512P50TFE01@TSOP48 [ ( SA247+B005 ) ]  
S30ML512P50TFE51@TSOP48 [ ( SA247+B005 ) ]  
S30MS01GP25TFW00@TSOP48 [ ( SA247-B005 ) ]  
S30MS01GP25TFW010@TSOP48 [ ( SA247-B005 ) ]  
S30MS01GP25TFW50@TSOP48 [ ( SA247-B005 ) ]  
S30MS01GP25TFW510@TSOP48 [ ( SA247-B005 ) ]  
S70PL254J00BAW91@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BAW93@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BAWA1@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]

S70PL254J00BAWA3@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BFW91@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BFW93@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BFWA1@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL254J00BFWA3@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S70PL512N00HAW53@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S70PL512N00HFW53@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71AL016D02BAWB@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D02BAWT@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D02BFWB@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D02BFWT@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D04BAWB@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D04BAWT@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D04BFWB@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71AL016D04BFWT@FBGA56 [ ( SA642P-B032A-W056F001Y ) ]  
S71GL016A40BAW1J@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL016A40BAW3J@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL016A40BFW1J@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL016A40BFW3J@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A08BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A08BAW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A08BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A08BFW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A40BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A40BAW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A40BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A40BFW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A80BAW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A80BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A80BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032A80BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032AA0BAW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032AA0BAW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032AA0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032AA0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032M40BAIBQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAIFQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAIKQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAIPQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAWBQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAWFQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAWKQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BAWPQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]

S71GL032M40BFIBQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFIFQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFIKQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFIPQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFWBQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFWFQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFWKQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032M40BFWPQ@FBGA56 [ ( SA642B-B032A-Y072F001 ) ]  
S71GL032N40BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032N40BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032N80BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032N80BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032NA0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL032NA0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A08BAI0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A08BAI0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A08BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A08BAW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A08BFI0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A08BFI0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A08BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A08BFW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A0ABAI0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A0ABAI0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A0ABAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A0ABAW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A0ABFI0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A0ABFI0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A0ABFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A0ABFW0F@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BAI0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BAI0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BAW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BFI0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BFI0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064A80BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAI0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAI0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAI0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAI0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]



S71GL064AA0BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BAW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFI0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFI0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFI0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFI0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064AA0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NA0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NA0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NB0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL064NB0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71GL128NB0BAEAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAEAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAEAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAEAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAW9J@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9K@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9N@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9T@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9Y@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BAWAJ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAK@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAN@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAP@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BAWEJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BAWEZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]

S71GL128NB0BFEBT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFEAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFEBY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFEBZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFW9J@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9K@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9N@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9T@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9Y@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71GL128NB0BFWAJ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAK@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAN@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAP@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NB0BFWEJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFWEK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFWEN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFWEP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFWET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFWEU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFW EY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NB0BFW EZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL128NC0BAEAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAEAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAEAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BAZAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFEBT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFEAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFEBY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFEBZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL128NC0BFWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]

S71GL128NC0BFWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAJ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAK@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAN@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAP@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BAWEJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BAWEZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFWAJ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAK@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAN@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAP@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NB0BFW EJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW EK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW EN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW EP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW ET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW EU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW EY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NB0BFW EZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL256NC0BAEAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAEAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAEAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAEAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAWAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAWAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAWAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BAWAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BF EAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BF EAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]

S71GL256NC0BF EAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BF EAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BF WAT@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BF WAU@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BF WAY@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL256NC0BF WAZ@FBGA84 [ ( SA642A-B108A-Y096F001 ) ]  
S71GL512NB0BAWEJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BAWEZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFWEJ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFWEK@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFWEN@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFWEP@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFWET@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFWEU@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFWEY@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71GL512NB0BFWEZ@FBGA84 [ ( SA642A-B108A-Y096N001 ) ]  
S71JL064H80BAW01 ( DL6408H )@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW02 ( DL6408H )@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW03 ( DL6408H )@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW04 ( DL6408H )@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW10 ( DL6408H )@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW11 ( DL6408H )@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064H80BAW12 ( DL6408H )@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HA0BAW01 ( DL640AH )@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HA0BAW02 ( DL640AH )@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HA0BAW10 ( DL640AH )@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HA0BAW11 ( DL640AH )@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HA0BAW12 ( DL640AH )@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HB0BAW00 ( DL640AH )@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HB0BAW01 ( DL640AH )@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL064HB0BAW02 ( DL640AH )@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
S71JL128HB0BAW00 ( DL128BH )@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
S71JL128HB0BAW01 ( DL128BH )@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
S71JL128HB0BAW02 ( DL128BH )@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
S71JL128HB0BAW03 ( DL128BH )@FBGA73 [ ( SA642A-B039A-Y096F001 ) ]  
S71JL128HC0BAW00 ( DL128CH )@FBGA73 [ ( SA642A-B062A-Y096F001 ) ]  
S71JL128HC0BAW01 ( DL128CH )@FBGA73 [ ( SA642A-B062A-Y096F001 ) ]

S71JL128HC0BAW02(DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]  
S71JL128HC0BAW03(DL128CH)@FBGA73 [(SA642A-B062A-Y096F001)]  
S71NS032J80BJWRA@FBGA56 [(SA733A-B212A-M056F001Y)]  
S71NS032JA0BJWRT@FBGA56 [(SA733A-B212A-M056F001Y)]  
S71NS064JA0BAW01@FBGA44 [(SA733A-B206A-M056F001Y)]  
S71NS064JA0BAW11@FBGA44 [(SA733A-B206A-M056F001Y)]  
S71NS064JA0BAW21@FBGA44 [(SA733A-B206A-M056F001Y)]  
S71NS064JA0BFW01@FBGA44 [(SA733A-B206A-M056F001Y)]  
S71NS064JA0BFW11@FBGA44 [(SA733A-B206A-M056F001Y)]  
S71NS064JA0BFW21@FBGA44 [(SA733A-B212A-M056F001Y)]  
S71NS064JA0BJWRN@FBGA56 [(SA733A-B206A-M056F001Y)]  
S71NS128JA0BAW01@FBGA48 [(SA733A-B206A-M056F001N)]  
S71NS128JA0BAW11@FBGA48 [(SA733A-B206A-M056F001N)]  
S71NS128JA0BAW21@FBGA48 [(SA733A-B206A-M056F001N)]  
S71NS128JA0BFW01@FBGA48 [(SA733A-B206A-M056F001N)]  
S71NS128JA0BFW11@FBGA48 [(SA733A-B206A-M056F001N)]  
S71NS128JA0BFW21@FBGA48 [(SA733A-B206A-M056F001N)]  
S71PL032J04BAI0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BAI0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BAW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BFI0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BFI0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BFW0F@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J04BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BAE0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BAW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J08BFW0B@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J40BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J40BAW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J40BAW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J40BFI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J40BFW07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J40BFW0K@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J80BAI05@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J80BAI07@FBGA56 [(SA642P-B079A-W056F001Y)]  
S71PL032J80BAW05@FBGA56 [(SA642P-B079A-W056F001Y)]

S71PL032J80BAW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BAWQ7@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BAWQF@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BFI05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BFI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BFW05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BFW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BFWQ7@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032J80BFWQF@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BAE07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BAE0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BAI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BAI0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BAW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BAW0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BAW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BAWQF@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BFI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BFI0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BFW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BFW0F@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL032JA0BFWQF@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BAI0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BAI0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BAI0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BAI0U@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BAW0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BAW0U@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BFI0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BFI0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BFI0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BFI0U@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J08BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J0ABAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J0ABAW0S@FBGA56 [ ( SA642P-B079A-W056F001Y) ]

S71PL064J0ABFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J0ABFW0S@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BAI05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BAI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BAI0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BAW05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BAW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BAW0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BFI05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BFI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BFI0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BFW05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BFW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BFW0K@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064J80BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAI05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAI0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAI0Z@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAW05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAW0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BAW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BFI05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BFI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BFI0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BFI0Z@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BFW05@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BFW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BFW0P@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JA0BFW0Z@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JB0BAI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JB0BAI0U@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JB0BAIQB@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JB0BAW07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JB0BAW0B@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JB0BAW0U@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JB0BAWQB@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JB0BFI07@FBGA56 [ ( SA642P-B079A-W056F001Y) ]  
S71PL064JB0BFI0U@FBGA56 [ ( SA642P-B079A-W056F001Y) ]

S71PL064JB0BFIQB@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BFW07@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BFW0B@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BFW0U@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL064JB0BFWQB@FBGA56 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JA0BAI9P@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JA0BAI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JA0BAW9P@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JA0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JA0BFI9P@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JA0BFI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JA0BFW9P@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JA0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BAI97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BAI9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BAI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BAIQB@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127JB0BAW97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BAW9B@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BAW9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BAWQB@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127JB0BFI97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BFI9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BFI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BFIQB@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127JB0BFW97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BFW9B@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JB0BFW9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JB0BFWQB@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127JC0BAI97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JC0BAI9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BAI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BAW97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JC0BAW9B@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JC0BAW9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BFI97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JC0BFI9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BFI9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BFW97@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]  
S71PL127JC0BFW9B@FBGA64 [ ( SA642P-B079A-W056F001Y ) ]



S71PL127JC0BFW9U@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127JC0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL127NB0HAW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NB0HAW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NB0HFW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NB0HFW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NC0HAW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NC0HAW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NC0HFW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL127NC0HFW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JA0BAW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JA0BFW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BAW9B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BAW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BAW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BFW9B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BFW9P@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BFW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JB0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BAW9B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BAW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BAW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BFW9B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BFW9U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129JC0BFW9Z@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NB0HAW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NB0HAW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NB0HFW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NB0HFW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NC0HAW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NC0HAW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NC0HFW4B@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL129NC0HFW4U@FBGA64 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL191HB0BAI10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HB0BAW10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HB0BFI10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HB0BFW10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HC0BAI10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HC0BAW10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HC0BFI10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL191HC0BFW10@FBGA73 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL193HB0BAI10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]

S71PL193HB0BAW10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HB0BFI10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HB0BFW10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HC0BAI10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HC0BAW10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HC0BFI10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL193HC0BFW10@FBGA73 [ ( SA664J-B236A-M116F001Y ) ]  
S71PL254HC0BAW00@FBGA84 [ ( SA642A-B079A-Y096N001 ) ]  
S71PL254JB0BAIT7@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BAITU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BAWT7@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BAWTU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BFIT7@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BFITU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BFWT7@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JB0BFWTU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BAITU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BAITZ@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BAWTU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BAWTZ@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BFITU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BFITZ@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BFWTU@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JC0BFWTZ@FBGA84 [ ( SA642A-B079A-Y096F001 ) ]  
S71PL254JD0BAWTB@FBGA84 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL254JD0BFWTB@FBGA84 [ ( SA642A-B079A-Y096F001Y ) ]  
S71PL256NC0HAW5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256NC0HAW5U@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256NC0HFW5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256NC0HFW5U@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256ND0GAW5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256ND0GFW5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256ND0HAW5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL256ND0HFW5B@FBGA84 [ ( SA642A-B108A-Y096F001Y ) ]  
S71PL258HC0BAW00@FBGA84 [ ( SA642A-B088A-Y096N001 ) ]  
S71PL512ND0JAW5B@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71PL512ND0JFW5B@FBGA84 [ ( SA642A-B158A-Y096F001Y ) ]  
S71VS032K80ZJK01@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032K80ZJK03@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032KA0ZJK09@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032KA0ZJK0B@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032KA0ZJK11@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032KA0ZJK13@BGA44 [ ( SA733D-B212A-M044F001Y ) ]

S71VS032KA0ZJK19@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS032KA0ZJK1B@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK01@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK03@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK09@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK0B@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK11@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK13@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK19@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71VS064KA0ZJK1B@BGA44 [ ( SA733D-B212A-M044F001Y ) ]  
S71WS064JA0BAI2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JA0BAI2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JA0BAW2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JA0BAW2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JA0BFI2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JA0BFI2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JA0BFW2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JA0BFW2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JB0BAI2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JB0BAI2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JB0BAW2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JB0BAW2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JB0BFI2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JB0BFI2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS064JB0BFW2A@FBGA80 [ ( SA642T-B134A-W080F001Y ) ]  
S71WS064JB0BFW2Y@FBGA80 [ ( SA642T-B086A-W080F001Y ) ]  
S71WS128JA0BAIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JA0BAIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JA0BAWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JA0BAWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JA0BFIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JA0BFIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JA0BFWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JA0BFWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JB0BAIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JB0BAIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JB0BAIAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JB0BAWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JB0BAWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JB0BAWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JB0BFIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JB0BFIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JB0BFIAJ@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]

S71WS128JB0BFWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JB0BFWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JB0BFWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JC0BAE9A@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BAIA6@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BAIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BAIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JC0BAIAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JC0BAWA6@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BAWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BAWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JC0BAWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JC0BFE9A@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BFIA6@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BFIAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BFIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JC0BFIAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128JC0BFWA6@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BFWAA@FBGA84 [ ( SA642A-B134A-Y096F001Y ) ]  
S71WS128JC0BFWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS128JC0BFWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS128NB0BAWAH@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BAWAJ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BAWAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BAWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BAWAN@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BAWAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BFWAH@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BFWAJ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BFWAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BFWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BFWAN@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NB0BFWAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAH@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAJ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAN@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BAWAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BFWAH@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BFWAJ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BFWAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BFWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]

S71WS128NC0BFWAN@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS128NC0BFWAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256JC0BAIA6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAIAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BAIT6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAITJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAITY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BAWA6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BAWT6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAWTJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BAWTY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BFIA6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFIAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFIAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BFIT6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFITJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFITY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BFWA6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFWAJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFWAY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256JC0BFWT6@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFWTJ@FBGA84 [ ( SA642A-B109A-Y096F001 ) ]  
S71WS256JC0BFWTY@FBGA84 [ ( SA642A-B086A-Y096F001 ) ]  
S71WS256NC0BAIAB@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAIAF@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAIAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAIAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAIAU@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAIAZ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWA2@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWA3@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWA6@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWA7@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAA@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAB@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAE@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAF@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAH@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAJ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]

S71WS256NC0BAWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAN@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAU@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BAWAZ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFIAB@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFIAF@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFIAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFIAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFIAU@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFIAZ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWA2@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWA3@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWA6@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWA7@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAA@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAB@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAE@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAF@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAH@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAJ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAK@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAM@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAN@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAP@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAU@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256NC0BFWAZ@FBGA84 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS256ND0BAIE3@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAIE7@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAIEK@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAIEP@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAIEU@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAIEZ@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWE3@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWE7@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWEK@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWEP@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWEU@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWEZ@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWYH@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWYJ@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWYK@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWYM@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]

S71WS256ND0BAWYN@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BAWYP@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFIE3@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFIE7@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFIEK@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFIEP@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFIEU@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFIEZ@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWE3@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWE7@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWEK@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWEP@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWEU@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWEZ@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYH@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYJ@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYK@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYM@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYN@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS256ND0BFWYP@FBGA84 [ ( SA642CC-B139A-W080F001Y ) ]  
S71WS512NC0BAIAB@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAIAF@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAIAK@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAIAP@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAIAU@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAIAZ@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAB@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAF@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAK@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAP@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAU@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWAZ@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWTA@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWTE@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWTH@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWTJ@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWTM@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BAWTN@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFIAB@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFIAF@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFIK@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFIAIP@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]  
S71WS512NC0BFIAU@FBGA88 [ ( SA642A-B139A-Y096F001Y ) ]

S71WS512NC0BFIAZ@FBGA88 [ ( SA642A-B139A-Y096F001Y) ]  
S71WS512NC0BFWAB@FBGA88 [ ( SA642A-B139A-Y096F001Y) ]  
S71WS512NC0BFWAF@FBGA88 [ ( SA642A-B139A-Y096F001Y) ]  
S71WS512NC0BFWAK@FBGA88 [ ( SA642A-B139A-Y096F001Y) ]  
S71WS512NC0BFWAP@FBGA88 [ ( SA642A-B139A-Y096F001Y) ]  
S71WS512NC0BFWAU@FBGA88 [ ( SA642A-B139A-Y096F001Y) ]  
S71WS512NC0BFWAZ@FBGA88 [ ( SA642A-B139A-Y096F001Y) ]  
S71WS512NC0BFWTA@FBGA88 [ ( SA642A-B139A-Y096F001Y) ]  
S71WS512NC0BFWTE@FBGA88 [ ( SA642A-B139A-Y096F001Y) ]  
S71WS512NC0BFWTH@FBGA88 [ ( SA642A-B139A-Y096F001Y) ]  
S71WS512NC0BFWTJ@FBGA88 [ ( SA642A-B139A-Y096F001Y) ]  
S71WS512NC0BFWTM@FBGA88 [ ( SA642A-B139A-Y096F001Y) ]  
S71WS512NC0BFWTN@FBGA88 [ ( SA642A-B139A-Y096F001Y) ]  
S71WS512ND0BAIE3@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BAIE7@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BAIEK@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BAIEP@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BAWE2@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BAWE3@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BAWE6@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BAWE7@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BAWEH@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BAWEJ@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BAWEK@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BAWEM@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BAWEN@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BAWEP@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BFIE3@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BFIE7@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BFIEK@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BFIEP@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BFWE2@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BFWE3@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BFWE6@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BFWE7@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BFWEH@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BFWEJ@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BFWEK@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BFWEM@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BFWEN@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S71WS512ND0BFWEP@FBGA88 [ ( SA642CC-B139A-W080F001Y) ]  
S75PL127JBDBAWKB@FBGA84 [ ( SA642CC-B135A-W080F001Y) ]  
S75PL127JBDBAWKU@FBGA84 [ ( SA642CC-B135A-W080F001Y) ]



S75PL127JBDBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBDBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCDBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCDBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCDBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCDBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCEBAWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCEBAWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCEBFWKB@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JCEBFWKU@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S98NS032JA0FW001@FBGA88 [(SA642A-B180A-Y096F001Y)]  
S98PL191JD0AQ001@FBGA115 [(SA664A-B160A-W115F001Y)]  
S98PL191JD0FQ001@FBGA115 [(SA664A-B160A-W115F001Y)]  
S98PL191JDFAQ001(Nor)@FBGA115 [(SA664A-B160A-W115F001Y)]  
S98PL191JDFFQ001(Nor)@FBGA115 [(SA664A-B160A-W115F001Y)]  
S98WS128NB0-001@FBGA88 [(SA642A-B124A-Y096F001Y)]  
S98WS256NEFFW001(Nor)@FBGA115 [(SA642A-B139A-Y096N001N)]  
S98WS512N0GFW002(Nor)@FBGA115 [(SA664J-B165A-M116F001Y)]  
S98WS512N0GFW003(Nor)@FBGA115 [(SA664J-B165A-M116F001Y)]  
S99-50001(S29WS256N)@FBGA88 [(SA642A-B094A-Y096F001Y)]  
S99-50003(S29WS256N)@FBGA88 [(SA642A-B094A-Y096F001Y)]  
S99-50005(2\*S29WS128H)@FBGA88 [(SA642A-B123A-Y096F001Y)]  
S99-50011(2\*S29WS256N)@FBGA103 [(SA664H-B157A-W115F001N)]  
S99-50019(S29GL128N)@FBGA88 [(SA642W-B199A-W088F001Y)]  
S99-50031(AM29BDS320)@FBGA56 [(SA644B-B025B-Y056F001Y)]  
S99-50034-9N(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]  
S99-50034-9P(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]  
S99-50034-9Y(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]  
S99-50034-9Z(S29GL128N)@FBGA64 [(SA642A-B039A-Y096F001)]  
S99-50048(S29GL064N)@FBGA64 [(SA655E-B129A-T056F001Y)]  
S99-50052(S29GL128N)@FBGA64 [(SA655E-B129A-T056F001Y)]  
S99-50057(S29GL032A)@FBGA88 [(SA642W-B116A-W088F001Y)]  
S99-50059(S29GL064A)@FBGA88 [(SA642A-B116A-Y096N001N)]  
S99-50063(High)@FBGA137 [(SA678A-B151A-Y129F001Y)]  
S99-50063(Low)@FBGA137 [(SA678A-B150A-Y129F001Y)]  
S99-50066(S29GL032M)@FBGA88 [(SA642A-B116A-Y096N001N)]  
S99-50073(S29WS256N)@FBGA88 [(SA642A-B124A-Y096F001Y)]  
S99-50074(2\*S29WS128J)@FBGA88 [(SA642A-B121A-Y096F001Y)]  
S99-50076(S29WS256N)@FBGA103 [(SA664H-B157A-W115F001N)]

S99-50080(S71PL064JB0)@FBGA56 [(SA642P-B079A-W056F001Y)]  
S99-50080-LF(S71PL064JB0)@FBGA56 [(SA642P-B079A-W056F001Y)]  
S99-50085(S29WS256N)@FBGA88 [(SA642A-B112A-Y096F001Y)]  
S99-50087(S29WS128J)@FBGA88 [(SA642A-B154A-Y096F001Y)]  
S99-50089(2\*S29WS128J)@FBGA88 [(SA642A-B121A-Y096F001Y)]  
S99-50109(2\*S29WS256N)@FBGA88 [(SA642A-B138A-Y096F001Y)]  
S99-50111(S29AL016DFFI02)@FBGA64 [(SA655F-B099A-W064F001Y)]  
S99-50121-9Y@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S99-50121-9Y-LF@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S99-50121-9Z@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S99-50121-9Z-LF@FBGA64 [(SA642A-B039A-Y096F001Y)]  
S99-50134(S29GL128N)@FBGA88 [(SA642R-B199A-T096F001Y)]  
S99-50158(S29PL320J)@FBGA67 [(SA642A-B041A-Y096F001Y)]  
S99-50158-LF(S29PL320J)@FBGA67 [(SA642A-B041A-Y096F001Y)]  
S99-50183(S29GL256N)@FBGA64 [(SA655E-B129A-T056F001Y)]  
S99PL128JC0BAWFC0@FBGA84 [(SA642A-B062A-Y096F001Y)]  
S99PL128JC0BAWNB0@FBGA84 [(SA642A-B062A-Y096F001Y)]  
S99PL128JC0BAWT10@FBGA84 [(SA642A-B062A-Y096F001Y)]  
S99PL128JC0BAWUB0@FBGA84 [(SA642A-B062A-Y096F001Y)]  
S99PL193JB0BAEFC@FBGA73 [(SA664J-B236A-M116F001Y)]  
S99PL193JB0BAEUC@FBGA73 [(SA664J-B236A-M116F001Y)]  
S99PL193JB0BAWFC@FBGA73 [(SA664J-B236A-M116F001Y)]  
S99PL193JB0BAWUC@FBGA73 [(SA664J-B236A-M116F001Y)]  
S99PL193JC0BAEFC@FBGA73 [(SA664J-B236A-M116F001Y)]  
S99PL193JC0BAEUC@FBGA73 [(SA664J-B236A-M116F001Y)]  
S99PL193JC0BAWFC@FBGA73 [(SA664J-B236A-M116F001Y)]  
S99PL193JC0BAWUC@FBGA73 [(SA664J-B236A-M116F001Y)]  
S99WS256NC0BAWA3@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S99WS256NC0BAWA7@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S99WS256NC0BFWA3@FBGA84 [(SA642A-B139A-Y096F001Y)]  
S99WS256NC0BFWA7@FBGA84 [(SA642A-B139A-Y096F001Y)]

## SPANSION-CUSTOMER

### E (E) PROM/FRAM/NVRAM

41F60(S29WS256N)@FBGA88 [(SA642A-B124A-Y096F001Y)]  
52H70(S29WS128J)@FBGA88 [(SA642A-B154A-Y096F001Y)]  
S71PL129JB0BFW9U(ZX)@FBGA64 [(SA642A-B079A-Y096F001Y)]  
S75PL127JBEBAWKB(DX)@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBAWKU(DX)@FBGA84 [(SA642CC-B135A-W080F001Y)]  
S75PL127JBEBFWKB(DX)@FBGA84 [(SA642CC-B135A-W080F001Y)]

S75PL127JBEBFWKU(DX)@FBGA84 [(SA642CC-B135A-W080F001Y)]

## SSSC

### MICROCONTROLLER

SSU7301  
[(SA244)]  
SSU7301@TQFP44 [(SA245A)]

SSU7301@PLCC44

## SST

### E(E) PROM/FRAM/NVRAM

SST25LF010@SOIC8(4.0) [(SA602A)]  
[(SA605B)]

SST25LF010@SOIC8(5.4)

SST25LF010@WSON8 [(SA683)]

SST25LF010A@SOIC8(4.0) [(SA602A)]

SST25LF010A@SOIC8(5.4) [(SA605B)]

SST25LF010A@WSON8 [(SA683)]

SST25LF016A@SOIC8(4.0) [(SA602A)]

SST25LF016A@SOIC8(5.4) [(SA605A)]

SST25LF016A@WSON8 [(SA683)]

SST25LF016B@SOIC8(4.0) [(SA602A)]

SST25LF016B@SOIC8(5.4) [(SA605A)]

SST25LF016B@WSON8 [(SA683)]

SST25LF020@SOIC8(4.0)

[(SA602A)]

SST25LF020@SOIC8(5.4) [(SA605B)]

SST25LF020@WSON8

[(SA683)]

SST25LF020A@SOIC8(4.0) [(SA602A)]

SST25LF020A@SOIC8(5.4) [(SA605B)]

SST25LF020A@WSON8 [(SA683)]

SST25LF040@SOIC8(4.0)

[(SA602A)]

SST25LF040@SOIC8(5.4) [(SA605B)]

SST25LF040@WSON8

[(SA683)]

SST25LF040A@SOIC8(4.0) [(SA602A)]

SST25LF040A@SOIC8(5.4) [(SA605B)]

SST25LF040A@WSON8 [(SA683)]

SST25LF080@SOIC8(4.0)

[(SA602A)]

SST25LF080@SOIC8(5.4) [(SA605B)]

SST25LF080@WSON8

[ (SA683) ]	
SST25LF080A@SOIC8(4.0) [ (SA602A) ]	
SST25LF080A@SOIC8(5.4) [ (SA605B) ]	
SST25LF080A@WSON8 [ (SA683) ]	SST25VF010@SOIC8(4.0)
[ (SA602A) ]	
SST25VF010@SOIC8(5.4) [ (SA605B) ]	SST25VF010@WSON8
[ (SA683) ]	
SST25VF010A@SOIC8(4.0) [ (SA602A) ]	
SST25VF010A@SOIC8(5.4) [ (SA605B) ]	
SST25VF010A@WSON8 [ (SA683) ]	
SST25VF016B@SOIC8(4.0) [ (SA602A) ]	
SST25VF016B@SOIC8(5.4) [ (SA605A) ]	
SST25VF016B@WSON8 [ (SA683) ]	SST25VF020@SOIC8(4.0)
[ (SA602A) ]	
SST25VF020@SOIC8(5.4) [ (SA605B) ]	SST25VF020@WSON8
[ (SA683) ]	
SST25VF032B@SOIC8(4.0) [ (SA602A) ]	
SST25VF032B@SOIC8(5.4) [ (SA605A) ]	
SST25VF032B@WSON8 [ (SA683) ]	SST25VF040@SOIC8(4.0)
[ (SA602A) ]	
SST25VF040@SOIC8(5.4) [ (SA605B) ]	SST25VF040@WSON8
[ (SA683) ]	
SST25VF040B@SOIC8(4.0) [ (SA602A) ]	
SST25VF040B@SOIC8(5.4) [ (SA605A) ]	
SST25VF040B@WSON8 [ (SA683) ]	SST25VF080@SOIC8(4.0)
[ (SA602A) ]	
SST25VF080@SOIC8(5.4) [ (SA605B) ]	SST25VF080@WSON8
[ (SA683) ]	
SST25VF080B@SOIC8(4.0) [ (SA602A) ]	
SST25VF080B@SOIC8(5.4) [ (SA605A) ]	
SST25VF080B@WSON8 [ (SA683) ]	SST25VF512@SOIC8(4.0)
[ (SA602A) ]	
SST25VF512@SOIC8(5.4) [ (SA605B) ]	SST25VF512@WSON8
[ (SA683) ]	
SST25VF512A@SOIC8(4.0) [ (SA602A) ]	
SST25VF512A@SOIC8(5.4) [ (SA605B) ]	
SST25VF512A@WSON8 [ (SA683) ]	SST25WF010@SOIC8
[ (SA602A) ]	
SST25WF020@SOIC8 [ (SA602A) ]	SST25WF040@SOIC8
[ (SA602A) ]	
SST25WF080@SOIC8 [ (SA602A) ]	SST25WF512@SOIC8
[ (SA602A) ]	
SST27SF010	SST27SF010@PLCC32

[ ( SA015A1T ) ]	
SST27SF010@TSOP32 [ ( SA410T ) ]	
SST27SF020	
SST27SF020@PLCC32 [ ( SA015A1T ) ]	SST27SF020@TSOP32
[ ( SA410T ) ]	
SST27SF256	
[ ( SA015A1T ) ]	
SST27SF256@VSOP32 [ ( SA620 ) ]	SST27SF256@PLCC32
SST27SF512	
SST27SF512@PLCC32 [ ( SA015A1T ) ]	SST27SF512@VSOP32
[ ( SA620 ) ]	
SST27VF010	
[ ( SA015A1T ) ]	
SST27VF010@TSOP32 [ ( SA410T ) ]	SST27VF010@PLCC32
SST27VF020	
SST27VF020@PLCC32 [ ( SA015A1T ) ]	SST27VF020@TSOP32
[ ( SA410T ) ]	
SST27VF040	
[ ( SA015A1T ) ]	
SST27VF040@TSOP32 [ ( SA410T ) ]	SST27VF040@PLCC32
SST27VF256	
SST27VF256@PLCC32 [ ( SA015A1T ) ]	SST27VF256@VSOP32
[ ( SA620 ) ]	
SST27VF512	
[ ( SA015A1T ) ]	
SST27VF512@VSOP32 [ ( SA620 ) ]	SST27VF512@PLCC32
SST28EE011	
SST28EE011@PLCC32 [ ( SA015A1T ) ]	SST28EE011@TSOP32
[ ( SA410T ) ]	
SST28LE011	
[ ( SA015A1T ) ]	
SST28LE011@TSOP32 [ ( SA410T ) ]	SST28LE011@PLCC32
SST28LF040	
SST28LF040@PLCC32 [ ( SA015A1T ) ]	SST28LF040@TSOP32
[ ( SA410T ) ]	
SST28SF040	
[ ( SA015A1T ) ]	
SST28SF040@TSOP32 [ ( SA410T ) ]	SST28SF040@PLCC32
SST28SF040A	
SST28SF040A@PLCC32 [ ( SA015A1T ) ]	SST28SF040A@TSOP32
[ ( SA410T ) ]	
SST28VE011	
[ ( SA015A1T ) ]	
	SST28VE011@PLCC32

SST28VE011@TSOP32 [ (SA410T) ]	
SST28VF040	
SST28VF040@PLCC32 [ (SA015A1T) ]	SST28VF040@TSOP32
[ (SA410T) ]	
SST28VF040A	
[ (SA015A1T) ]	SST28VF040A@PLCC32
SST28VF040A@TSOP32 [ (SA410T) ]	
SST29EE010	
SST29EE010@PLCC32 [ (SA015A1T) ]	SST29EE010@TSOP32
[ (SA410T) ]	
SST29EE020	
[ (SA015A1T) ]	SST29EE020@PLCC32
SST29EE020@TSOP32 [ (SA410T) ]	
SST29EE512	
SST29EE512@PLCC32 [ (SA015A1T) ]	SST29EE512@TSOP32
[ (SA410T) ]	
SST29LE010	
[ (SA015A1T) ]	SST29LE010@PLCC32
SST29LE010@TSOP32 [ (SA410T) ]	
SST29LE020	
SST29LE020@PLCC32 [ (SA015A1T) ]	SST29LE020@TSOP32
[ (SA410T) ]	
SST29LE512	
[ (SA015A1T) ]	SST29LE512@PLCC32
SST29LE512@TSOP32 [ (SA410T) ]	
SST29SF010	
SST29SF010@PLCC32 [ (SA015A1T) ]	SST29SF010@VSOP32
[ (SA620) ]	
SST29SF020	
[ (SA015A1T) ]	SST29SF020@PLCC32
SST29SF020@VSOP32 [ (SA620) ]	
SST29SF040	
SST29SF040@PLCC32 [ (SA015A1T) ]	SST29SF040@VSOP32
[ (SA620) ]	
SST29SF512	
[ (SA015A1T) ]	SST29SF512@PLCC32
SST29SF512@VSOP32 [ (SA620) ]	
SST29VE010	
SST29VE010@PLCC32 [ (SA015A1T) ]	SST29VE010@TSOP32
[ (SA410T) ]	
SST29VE020	
[ (SA015A1T) ]	SST29VE020@PLCC32
SST29VE020@TSOP32 [ (SA410T) ]	

SST29VE512  
 SST29VE512@PLCC32 [ (SA015A1T) ]                    SST29VE512@TSOP32  
 [ (SA410T) ]  
 SST29VF010    SST29VF010@PLCC32  
 [ (SA015A1T) ]  
 SST29VF010@VSOP32 [ (SA620) ]  
 SST29VF020  
 SST29VF020@PLCC32 [ (SA015A1T) ]                    SST29VF020@VSOP32  
 [ (SA620) ]  
 SST29VF040    SST29VF040@PLCC32  
 [ (SA015A1T) ]  
 SST29VF040@VSOP32 [ (SA620) ]  
 SST29VF512  
 SST29VF512@PLCC32 [ (SA015A1T) ]                    SST29VF512@VSOP32  
 [ (SA620) ]  
 SST31LF021@VSOP32 [ (SA620) ]                    SST31LF041@VSOP40  
 [ (SA623) ]  
 SST31LF041A@VSOP32 [ (SA620) ]                    SST31LF043@VSOP40  
 [ (SA623) ]  
 SST31LF043A@VSOP32 [ (SA620) ]  
 SST32HF162@LFBGA48 [ (SA655E-B026A-T064F001) ]  
 SST32HF162@LFBGA48(SST adapter)                    SST32HF162@TSOP48 [ (SA247-  
 B005) ]  
 SST32HF1621C@LFBGA62 [ (SA642R-B083A-T096F001Y) ]  
 SST32HF1621C@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
 SST32HF1622C@LFBGA62 [ (SA642R-B083A-T096F001Y) ]  
 SST32HF1622C@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
 SST32HF164@LFBGA48 [ (SA655E-B026A-T064F001) ]  
 SST32HF164@LFBGA48(SST adapter)                    SST32HF164@TSOP48 [ (SA247-  
 B005) ]  
 SST32HF1641@LFBGA62 [ (SA642R-B023A-T096F001Y) ]  
 SST32HF1641@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
 SST32HF1641C@LFBGA62 [ (SA642R-B023A-T096F001Y) ]  
 SST32HF1641C@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
 SST32HF1642@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
 SST32HF1642@FBGA63 [ (SA642R-B032A-T096F001Y) ]  
 SST32HF1642C@FBGA62 [ (SA642R-B023A-T096F001Y) ]  
 SST32HF1642C@FBGA63 [ (SA642R-B032A-T096F001Y) ]  
 SST32HF1681@LFBGA62 [ (SA642R-B083A-T096F001Y) ]  
 SST32HF1681@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
 SST32HF1682@LFBGA62 [ (SA642R-B083A-T096F001Y) ]  
 SST32HF1682@LFBGA63 [ (SA642R-B032A-T096F001Y) ]  
 SST32HF200@LFBGA48 [ (SA642B-B026A-Y072F001) ]

SST32HF201@LFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST32HF202@LFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST32HF324@LFBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST32HF324@LFBGA63 [ ( SA642E-B032A-T072F001 ) ]  
SST32HF324@TFBGA63 [ ( SA642E-B032A-T072F001 ) ]  
SST32HF3241@LFBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF3241@LFBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF3241C@LFBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF3241C@LFBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF3242@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF3242@FBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF3242C@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF3242C@FBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF3244C@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF324C@LFBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST32HF324C@LFBGA63 [ ( SA642E-B032A-T072F001 ) ]  
SST32HF324C@TFBGA63 [ ( SA642E-B032A-T072F001 ) ]  
SST32HF328@LFBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST32HF328@LFBGA63 [ ( SA642E-B032A-T072F001 ) ]  
SST32HF328@TFBGA63 [ ( SA642E-B032A-T072F001 ) ]  
SST32HF3281@LFBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF3281@LFBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF3281C@LFBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF3281C@LFBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF3282@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF3282@FBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF3282C@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF3282C@FBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF3284@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF328C@LFBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST32HF328C@LFBGA63 [ ( SA642E-B032A-T072F001 ) ]  
SST32HF328C@TFBGA63 [ ( SA642E-B032A-T072F001 ) ]  
SST32HF32A1@LFBGA62 [ ( SA642R-B083A-T096F001Y ) ]  
SST32HF32A1@LFBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF32A4@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF400@LFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST32HF401@LFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST32HF402@LFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST32HF64161@LFBGA64 [ ( SA642R-B083A-T096F001Y ) ]  
SST32HF64161C@LFBGA64 [ ( SA642R-B083A-T096F001Y ) ]  
SST32HF6481@LFBGA64 [ ( SA642R-B083A-T096F001Y ) ]  
SST32HF6481C@LFBGA64 [ ( SA642R-B083A-T096F001Y ) ]  
SST32HF6482@FBGA63 [ ( SA642R-B032A-T096F001Y ) ]



SST32HF6482@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF6482C@FBGA63 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF6482C@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF64A1@FBGA63 [ ( SA642I-B032A-W080F001Y ) ]  
SST32HF64A1@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF64A2@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST32HF64A2@FBGA63 [ ( SA642I-B032A-W080F001Y ) ]  
SST32HF64A2@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF64B1@FBGA63 [ ( SA642I-B032A-W080F001Y ) ]  
SST32HF64B1@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF64B2@FBGA63 [ ( SA642I-B032A-W080F001Y ) ]  
SST32HF64B2@FBGA64 [ ( SA642R-B023A-T096F001Y ) ]  
SST32HF800@LFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST32HF802@LBGA48 [ ( SA655E-B026A-T064F001 ) ]  
SST32HF802@LFBGA48 [ ( SA642B-B026A-Y072F001 ) ]  
SST32HF802@LFBGA48 ( SST adapter )  
SST34HF1601B@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1601B@TSOP48 [ ( SA247-B005 ) ]  
SST34HF1601C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1601C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1602C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1602C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1621@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1621A@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1621A@LFBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF1621C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1621C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1621S@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1622@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1622C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1622C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1622S@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF162C@LBGA48 [ ( SA655E-B026A-T064F001 ) ]  
SST34HF162G@LBGA48 [ ( SA655E-B026A-T064F001 ) ]  
SST34HF162G@LFBGA48 [ ( SA642G-B026A-T048F001 ) ]  
SST34HF1641@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1641A@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1641A@LFBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF1641C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1641C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1641D@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1641D@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1641J@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]

SST34HF1641J@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF1641S@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1642@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1642C@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1642C@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1642D@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1642D@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1642S@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF164C@LBGA48 [ ( SA655E-B026A-T064F001 ) ]  
SST34HF164G@LBGA48 [ ( SA655E-B026A-T064F001 ) ]  
SST34HF164G@LFBGA48 [ ( SA642G-B026A-T048F001 ) ]  
SST34HF1681@LFBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1681@LFBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF1681D@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1681D@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF1681J@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF1681J@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF1682D@FBGA56 [ ( SA642E-B032A-T072F001 ) ]  
SST34HF1682D@FBGA62 [ ( SA642E-B023A-T072F001 ) ]  
SST34HF3243C@FBGA56 [ ( SA642I-B032A-W080F001Y ) ]  
SST34HF3243C@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF3244@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF3244@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF3244C@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF3244C@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF3282@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF3282@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF3283@FBGA56 [ ( SA642I-B032A-W080F001Y ) ]  
SST34HF3283@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF3284@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF3284@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST34HF32A4@FBGA56 [ ( SA642R-B032A-T096F001Y ) ]  
SST34HF32A4@FBGA62 [ ( SA642R-B023A-T096F001Y ) ]  
SST36VF1601(B3K)@TFBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
SST36VF1601(BK)@TFBGA48 [ ( SA642R-B026A-T096F001Y ) ]  
SST36VF1601@TSOP48 [ ( SA247-B005 ) ]  
SST36VF1601C@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
SST36VF1601C@TSOP48 [ ( SA247-B005 ) ]  
SST36VF1601E@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
SST36VF1601E@TSOP48 [ ( SA247-B005 ) ]  
SST36VF1601G@LFBGA56 [ ( SA642A-B032A ) ]  
SST36VF1601G@TFBGA48 [ ( SA642G-B026A-T048F001 ) ]  
SST36VF1601G@TSOP48 [ ( SA247-B005 ) ]

SST36VF1602(B3K)@TFBGA48 [(SA642G-B026A-T048F001Y)]  
 SST36VF1602(BK)@TFBGA48 [(SA642R-B026A-T096F001Y)]  
 SST36VF1602@TSOP48 [(SA247-B005)]  
 SST36VF1602C@FBGA48 [(SA642G-B026A-T048F001)]  
 SST36VF1602C@TSOP48 [(SA247-B005)]  
 SST36VF1602E@FBGA48 [(SA642G-B026A-T048F001)]  
 SST36VF1602E@TSOP48 [(SA247-B005)]  
 SST36VF1602G@LFBGA56 [(SA642A-B032A)]  
 SST36VF1602G@TFBGA48 [(SA642G-B026A-T048F001)]  
 SST36VF1602G@TSOP48 [(SA247-B005)]  
 SST36VF3203@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST36VF3203@TSOP48 [(SA247-B005)]  
 SST36VF3204@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST36VF3204@TSOP48 [(SA247-B005)]  
 SST37VF010 [(SA015A1T)] SST37VF010@PLCC32  
 SST37VF010@VSOP32 [(SA620)]  
 SST37VF020 [(SA015A1T)] SST37VF020@VSOP32  
 [(SA620)]  
 SST37VF040 [(SA015A1T)] SST37VF040@PLCC32  
 [(SA015A1T)]  
 SST37VF040@VSOP32 [(SA620)]  
 SST37VF512 [(SA015A1T)] SST37VF512@VSOP32  
 [(SA620)]  
 SST39LF010@PLCC32 [(SA015A1T)]  
 SST39LF010@TFBGA48 [(SA642G-B026A-T048F001)]  
 SST39LF010@VSOP32 [(SA620)]  
 SST39LF010@WFBGA48 [(SA716A-B120A-M048F001Y)]  
 SST39LF016@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39LF016@TSOP40 [(SA409T)] SST39LF020@PLCC32  
 [(SA015A1T)]  
 SST39LF020@TFBGA48 [(SA642G-B026A-T048F001)]  
 SST39LF020@VSOP32 [(SA620)]  
 SST39LF020@WFBGA48 [(SA716A-B120A-M048F001Y)]  
 SST39LF040@PLCC32 [(SA015A1T)] SST39LF040@VSOP32  
 [(SA620)]  
 SST39LF080@FBGA48 [(SA642G-B026A-T048F001Y)]  
 SST39LF080@TSOP40 [(SA409T)] SST39LF080Q@TSOP40  
 [(SA409T)]  
 SST39LF100@FBGA48 [(SA642B-B026A-Y072F001)]  
 SST39LF100@VSOP40 [(SA623)]

SST39LF160@TFBGA48 [ (SA642B-B026A-Y072F001) ]  
 SST39LF160@TSOP48 [ (SA247-B005) ]  
 SST39LF200A@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
 SST39LF200A@TSOP48 [ (SA247-B005) ]  
 SST39LF200A@WFBGA48 [ (SA716B-B119B-T048F001Y) ]  
 SST39LF400A@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
 SST39LF400A@TSOP48 [ (SA247-B005) ]  
 SST39LF400A@WFBGA48 [ (SA716B-B119B-T048F001Y) ]  
 SST39LF512@PLCC32 [ (SA015A1T) ]                   SST39LF512@VSOP32  
 [ (SA620) ]  
 SST39LF800A@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
 SST39LF800A@TSOP48 [ (SA247-B005) ]  
 SST39LF800A@WFBGA48 [ (SA716B-B119B-T048F001Y) ]  
 SST39LH010   SST39LH010@PLCC32  
 [ (SA015A1T) ]  
 SST39LH010@TSOP32 [ (SA410T) ]  
 SST39LH040  
 SST39LH040@PLCC32 [ (SA015A1T) ]                   SST39LH040@TSOP32  
 [ (SA410T) ]  
 SST39LH512   SST39LH512@PLCC32  
 [ (SA015A1T) ]  
 SST39LH512@TSOP32 [ (SA410T) ]  
 SST39SF010  
 SST39SF010@PLCC32 [ (SA015A1T) ]                   SST39SF010@VSOP32  
 [ (SA620) ]  
 SST39SF010A                                       SST39SF010A@PLCC32  
 [ (SA015A1T) ]  
 SST39SF010A@VSOP32 [ (SA620) ]  
 SST39SF020  
 SST39SF020@PLCC32 [ (SA015A1T) ]                   SST39SF020@VSOP32  
 [ (SA620) ]  
 SST39SF020A                                       SST39SF020A@PLCC32  
 [ (SA015A1T) ]  
 SST39SF020A@VSOP32 [ (SA620) ]  
 SST39SF020P  
 SST39SF020P@PLCC32 [ (SA015A1T) ]                   SST39SF020P@VSOP32  
 [ (SA620) ]  
 SST39SF040                                       SST39SF040@PLCC32  
 [ (SA015A1T) ]  
 SST39SF040@VSOP32 [ (SA620) ]  
 SST39SF040P  
 SST39SF040P@PLCC32 [ (SA015A1T) ]                   SST39SF040P@VSOP32  
 [ (SA620) ]

SST39SF512 SST39SF512@PLCC32  
[ (SA015A1T) ]  
SST39SF512@VSOP32 [ (SA620) ]  
SST39SF512A  
SST39SF512A@PLCC32 [ (SA015A1T) ] SST39SF512A@VSOP32  
[ (SA620) ]  
SST39VF010 SST39VF010@PLCC32  
[ (SA015A1T) ]  
SST39VF010@TFBGA48 [ (SA642G-B026A-T048F001) ]  
SST39VF010@VSOP32 [ (SA620) ]  
SST39VF016@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39VF016@TSOP40 [ (SA409T) ] SST39VF016Q@TSOP40  
[ (SA409T) ]  
SST39VF020 SST39VF020@PLCC32  
[ (SA015A1T) ]  
SST39VF020@TFBGA48 [ (SA642G-B026A-T048F001) ]  
SST39VF020@VSOP32 [ (SA620) ]  
SST39VF020P  
SST39VF020P@PLCC32 [ (SA015A1T) ] SST39VF020P@VSOP32  
[ (SA620) ]  
SST39VF040 SST39VF040@PLCC32  
[ (SA015A1T) ]  
SST39VF040@VSOP32 [ (SA620) ]  
SST39VF040P  
SST39VF040P@PLCC32 [ (SA015A1T) ] SST39VF040P@VSOP32  
[ (SA620) ]  
SST39VF080@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39VF080@TSOP40 [ (SA409T) ] SST39VF080Q@TSOP40  
[ (SA409T) ]  
SST39VF088@TSOP48 [ (SA247-B005) ]  
SST39VF100@FBGA48 [ (SA642B-B026A-Y072F001) ]  
SST39VF100@VSOP40 [ (SA623) ]  
SST39VF160@TFBGA48 [ (SA642B-B026A-Y072F001) ]  
SST39VF160@TSOP48 [ (SA247-B005) ]  
SST39VF1601@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39VF1601@TSOP48 [ (SA247-B005) ]  
SST39VF1602@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39VF1602@TSOP48 [ (SA247-B005) ]  
SST39VF160Q@TSOP48 [ (SA247-B005) ]  
SST39VF1681@TFBGA48 [ (SA642B-B026A-Y072F001) ]  
SST39VF1681@TSOP48 [ (SA247-B005) ]  
SST39VF1682@TFBGA48 [ (SA642B-B026A-Y072F001) ]  
SST39VF1682@TSOP48 [ (SA247-B005) ]

SST39VF200A@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39VF200A@TSOP48 [ (SA247-B005) ]  
SST39VF200A@WFBGA48 [ (SA716B-B119B-T048F001Y) ]  
SST39VF320@TFBGA48 [ (SA642G-B026A-T048F001) ]  
SST39VF320@TSOP48 [ (SA247-B005) ]  
SST39VF3201@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39VF3201@TSOP48 [ (SA247-B005) ]  
SST39VF3202@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39VF3202@TSOP48 [ (SA247-B005) ]  
SST39VF400@TSOP48 [ (SA247-B005) ]  
SST39VF400A(Low)@TSOP48 [ (SA247) ]  
SST39VF400A@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39VF400A@TSOP48 [ (SA247-B005) ]  
SST39VF400A@WFBGA48 [ (SA716B-B119B-T048F001Y) ]  
SST39VF400Q@TSOP48 [ (SA247-B005) ]  
SST39VF512 SST39VF512@PLCC32  
[ (SA015A1T) ]  
SST39VF512@VSOP32 [ (SA620) ]  
SST39VF6401@TFBGA48 [ (SA642R-B026A-T096F001Y) ]  
SST39VF6401@TSOP48 [ (SA247-B005) ]  
SST39VF6401B@FBGA48 [ (SA642R-B026A-T096F001Y) ]  
SST39VF6401B@TSOP48 [ (SA247-B005) ]  
SST39VF6402@TFBGA48 [ (SA642R-B026A-T096F001Y) ]  
SST39VF6402@TSOP48 [ (SA247-B005) ]  
SST39VF6402B@FBGA48 [ (SA642R-B026A-T096F001Y) ]  
SST39VF6402B@TSOP48 [ (SA247-B005) ]  
SST39VF800@TSOP48 [ (SA247-B005) ]  
SST39VF800A@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39VF800A@TSOP48 [ (SA247-B005) ]  
SST39VF800A@WFBGA48 [ (SA716B-B119B-T048F001Y) ]  
SST39VF800Q@TSOP48 [ (SA247-B005) ]  
SST39WF1601@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39WF1601@WFBGA48 [ (SA716C-B119A-T048F001Y) ]  
SST39WF1602@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39WF1602@WFBGA48 [ (SA716C-B119A-T048F001Y) ]  
SST39WF400A@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39WF400A@WFBGA48 [ (SA716B-B119B-T048F001Y) ]  
SST39WF800A(M2)@WFBGA48 [ (SA716A-B119B-M048F001Y) ]  
SST39WF800A(Y1)@WFBGA48 [ (SA716B-B119B-T048F001Y) ]  
SST39WF800A@TFBGA48 [ (SA642G-B026A-T048F001Y) ]  
SST39WF800B(M2)@WFBGA48 [ (SA716A-B119B-M048F001Y) ]  
SST39WF800B(Y1)@WFBGA48 [ (SA716B-B119B-T048F001Y) ]  
SST39WF800B@TFBGA48 [ (SA642G-B026A-T048F001Y) ]

SST45LF010@SOIC8 [(SA602A)] [(SA683)]	SST45LF010@WSON8
SST45VF010@SOIC8 [(SA602A)] [(SA602A)]	SST45VF020@SOIC8
SST45VF512@SOIC8 [(SA602A)] [(SA015A1T)]	SST49LF002@PLCC32
SST49LF002@VSOP32 [(SA620)] [(SA015A1T)]	SST49LF002A@PLCC32
SST49LF002A@VSOP32 [(SA620)] [(SA015A1T)]	SST49LF002B@PLCC32
SST49LF003A@PLCC32 [(SA015A1T)] [(SA620)]	SST49LF003A@VSOP32
SST49LF003B@PLCC32 [(SA015A1T)] [(SA015A1T)]	SST49LF004@PLCC32
SST49LF004@VSOP32 [(SA620)] [(SA015A1T)]	SST49LF004A@PLCC32
SST49LF004A@VSOP32 [(SA620)] [(SA015A1T)]	SST49LF004B@PLCC32
SST49LF004B@VSOP32 [(SA620)] [(SA409T)]	SST49LF004B@VSOP40
SST49LF004C@PLCC32 [(SA015A1T)] [(SA620)]	SST49LF004C@VSOP32
SST49LF008@PLCC32 [(SA015A1T)] [(SA620)]	SST49LF008@VSOP32
SST49LF008A@PLCC32 [(SA015A1T)] [(SA409T)]	SST49LF008A@TSOP40
SST49LF008A@VSOP32 [(SA620)] [(SA015A1T)]	SST49LF008C@PLCC32
SST49LF008C@VSOP32 [(SA620)] [(SA015A1T)]	SST49LF016C@PLCC32
SST49LF016C@TSOP40 [(SA409T)] [(SA620)]	SST49LF016C@VSOP32
SST49LF020@PLCC32 [(SA015A1T)] [(SA620)]	SST49LF020@VSOP32
SST49LF020A@PLCC32 [(SA015A1T)] [(SA620)]	SST49LF020A@VSOP32
SST49LF030A@PLCC32 [(SA015A1T)] [(SA620)]	SST49LF030A@VSOP32
SST49LF040@PLCC32 [(SA015A1T)] [(SA620)]	SST49LF040@VSOP32
SST49LF040A@PLCC32 [(SA015A1T)] [(SA620)]	SST49LF040A@VSOP32
SST49LF040B@PLCC32 [(SA015A1T)]	SST49LF040B@TSOP40

[ (SA409T) ]	
SST49LF040B@VSOP32 [ (SA620) ]	SST49LF080A@PLCC32
[ (SA015A1T) ]	
SST49LF080A@VSOP32 [ (SA620) ]	SST49LF160C@PLCC32
[ (SA015A1T) ]	
SST49LF160C@TSOP32 [ (SA620) ]	

## MICROCONTROLLER

SST65P542R@SOIC28 [ (SA404) ]	
SST89C54	
SST89C54@PLCC44 [ (SA244) ]	SST89C54@TQFP44
[ (SA245A) ]	
SST89C58	
[ (SA244) ]	SST89C58@PLCC44
SST89C58@TQFP44 [ (SA245A) ]	SST89C58RC@PLCC44
[ (SA244) ]	
SST89C58RC@TQFP44 [ (SA245A) ]	SST89C58RC@WQFN40
[ (SA750) ]	
SST89E516RD	
[ (SA244) ]	SST89E516RD@PLCC44
SST89E516RD@TQFP44 [ (SA245A) ]	
SST89E516RD2	
SST89E516RD2@PLCC44 [ (SA244) ]	SST89E516RD2@TQFP44
[ (SA245A) ]	
SST89E52RC	
[ (SA244) ]	SST89E52RC@PLCC44
SST89E52RC@TQFP44 [ (SA245A) ]	
SST89E52RD	
SST89E52RD@PLCC44 [ (SA244) ]	SST89E52RD@TQFP44
[ (SA245A) ]	
SST89E52RD2	
[ (SA244) ]	SST89E52RD2@PLCC44
SST89E52RD2@TQFP44 [ (SA245A) ]	
SST89E54RC	
SST89E54RC@PLCC44 [ (SA244) ]	SST89E54RC@TQFP44
[ (SA245A) ]	
SST89E54RD	
[ (SA244) ]	SST89E54RD@PLCC44
SST89E54RD@TQFP44 [ (SA245A) ]	
SST89E54RD2	
SST89E54RD2@PLCC44 [ (SA244) ]	SST89E54RD2@TQFP44



[ ( SA245A ) ]	
SST89E554RC	SST89E554RC@PLCC44
[ ( SA244 ) ]	
SST89E554RC@TQFP44 [ ( SA245A ) ]	
SST89E564RD	
SST89E564RD@PLCC44 [ ( SA244 ) ]	SST89E564RD@TQFP44
[ ( SA245A ) ]	
SST89E58RD	SST89E58RD@PLCC44
[ ( SA244 ) ]	
SST89E58RD@TQFP44 [ ( SA245A ) ]	
SST89E58RD2	
SST89E58RD2@PLCC44 [ ( SA244 ) ]	SST89E58RD2@TQFP44
[ ( SA245A ) ]	
SST89V516RD	SST89V516RD@PLCC44
[ ( SA244 ) ]	
SST89V516RD@TQFP44 [ ( SA245A ) ]	
SST89V516RD2	
SST89V516RD2@PLCC44 [ ( SA244 ) ]	SST89V516RD2@TQFP44
[ ( SA245A ) ]	
SST89V52RD	SST89V52RD@PLCC44
[ ( SA244 ) ]	
SST89V52RD@TQFP44 [ ( SA245A ) ]	
SST89V52RD2	
SST89V52RD2@PLCC44 [ ( SA244 ) ]	SST89V52RD2@TQFP44
[ ( SA245A ) ]	
SST89V54RD2	SST89V54RD2@PLCC44
[ ( SA244 ) ]	
SST89V54RD2@TQFP44 [ ( SA245A ) ]	
SST89V554RC	
SST89V554RC@PLCC44 [ ( SA244 ) ]	SST89V554RC@TQFP44
[ ( SA245A ) ]	
SST89V564RD	SST89V564RD@PLCC44
[ ( SA244 ) ]	
SST89V564RD@TQFP44 [ ( SA245A ) ]	
SST89V58RD2	
SST89V58RD2@PLCC44 [ ( SA244 ) ]	SST89V58RD2@TQFP44
[ ( SA245A ) ]	

**ST****E ( E ) PROM / FRAM / NVRAM**

ET2716	
ETC2716	
ETC2732	
M24128	
M24128@MLP8 [(SA724)]	M24128@SOIC8
[(SA602A)]	
M24128@TSOP8 [(SA026)]	
M24164	
M24164@SOIC8 [(SA602A)]	
M24256	
M24256@MLP8 [(SA724)]	M24256@TSOP8
[(SA026)]	
M24256[3.9]@SOIC8 [(SA602A)]	M24256[5.5]@SOIC8
[(SA605A)]	
M24512	M24512@SOIC8
[(SA605A)]	
M24512@TSOP8 [(SA026)]	
M24C01	
M24C01@MLP8 [(SA724)]	M24C01@SOIC8
[(SA602A)]	
M24C01R	M24C01R@MLP8
[(SA724)]	
M24C01R@SOIC8 [(SA602A)]	M24C01R@TSOP8
[(SA026)]	
M24C01W	M24C01W@MLP8
[(SA724)]	
M24C01W@SOIC8 [(SA602A)]	M24C01W@TSOP8
[(SA026)]	
M24C02	M24C02@MLP8
[(SA724)]	
M24C02@SOIC8 [(SA602A)]	
M24C02R	
M24C02R@MLP8 [(SA724)]	M24C02R@SOIC8
[(SA602A)]	
M24C02R@TSOP8 [(SA026)]	
M24C02W	
M24C02W@MLP8 [(SA724)]	M24C02W@SOIC8
[(SA602A)]	
M24C02W@TSOP8 [(SA026)]	
M24C04	
M24C04@MLP8 [(SA724)]	M24C04@SOIC8
[(SA602A)]	
M24C04R	M24C04R@MLP8

[ (SA724) ]	
M24C04R@SOIC8 [ (SA602A) ]	M24C04R@TSOP8
[ (SA026) ]	
M24C04W	M24C04W@MLP8
[ (SA724) ]	
M24C04W@SOIC8 [ (SA602A) ]	M24C04W@TSOP8
[ (SA026) ]	
M24C08	M24C08@MLP8
[ (SA724) ]	
M24C08@MSOP8 [ (SA695A) ]	M24C08@SOIC8
[ (SA602A) ]	
M24C08@TSOP8 [ (SA026) ]	
M24C08R	
M24C08R@MLP8 [ (SA724) ]	M24C08R@MSOP8
[ (SA695A) ]	
M24C08R@SOIC8 [ (SA602A) ]	M24C08R@TSOP8
[ (SA026) ]	
M24C08W	M24C08W@MLP8
[ (SA724) ]	
M24C08W@MSOP8 [ (SA695A) ]	M24C08W@SOIC8
[ (SA602A) ]	
M24C08W@TSOP8 [ (SA026) ]	M24C128
(BN)	
M24C128(MN)@SOIC8 [ (SA605A) ]	M24C128(MW)@SOIC8
[ (SA602A) ]	
M24C128@MLP8 [ (SA724) ]	M24C128B
(BN)	
M24C128B(MN)@SOIC8 [ (SA605A) ]	M24C128B(MW)@SOIC8
[ (SA602A) ]	
M24C128B@MLP8 [ (SA724) ]	
M24C16	
M24C16@MLP8 [ (SA724) ]	M24C16@SOIC8
[ (SA602A) ]	
M24C16R	M24C16R@MLP8
[ (SA724) ]	
M24C16R@SOIC8 [ (SA602A) ]	M24C16R@TSOP8
[ (SA026) ]	
M24C16W	M24C16W@MLP8
[ (SA724) ]	
M24C16W@SOIC8 [ (SA602A) ]	M24C16W@TSOP8
[ (SA026) ]	
M24C256(BN)	M24C256(MN)@SOIC8
[ (SA605A) ]	

M24C256(MW)@SOIC8 [(SA602A)]  
[(SA724)]  
M24C256A(BN)  
[(SA605A)]  
M24C256A(MW)@SOIC8 [(SA602A)]  
[(SA724)]  
M24C256B(BN)  
[(SA605A)]  
M24C256B(MW)@SOIC8 [(SA602A)]  
[(SA724)]  
M24C256W(BN)  
[(SA605A)]  
M24C256W(MW)@SOIC8 [(SA602A)]  
[(SA724)]  
M24C32(BN)  
[(SA026)]  
M24C32(DW)@TSSOP8 [(SA602A)]  
[(SA605A)]  
M24C32(MW)@SOIC8 [(SA602A)]  
[(SA724)]  
M24C32W(BN)  
[(SA026)]  
M24C32W(DW)@TSSOP8 [(SA602A)]  
[(SA605A)]  
M24C32W(MW)@SOIC8 [(SA602A)]  
[(SA724)]  
M24C64(BN)  
[(SA026)]  
M24C64(DW)@TSSOP8 [(SA602A)]  
[(SA605A)]  
M24C64(MW)@SOIC8 [(SA602A)]  
[(SA724)]  
M24C64W(BN)  
[(SA026)]  
M24C64W(DW)@TSSOP8 [(SA602A)]  
[(SA605A)]  
M24C64W(MW)@SOIC8 [(SA602A)]  
[(SA724)]  
M24CL04B  
[(SA724)]  
M24CL04B@SOIC8 [(SA602A)]  
[(SA026)]  
M24E16

M24C256@MLP8  
M24C256A(MN)@SOIC8  
M24C256A@MLP8  
M24C256B(MN)@SOIC8  
M24C256B@MLP8  
M24C256W(MN)@SOIC8  
M24C256W@MLP8  
M24C32(DL)@TSSOP14  
M24C32(MN)@SOIC8  
M24C32@MLP8  
M24C32W(DL)@TSSOP14  
M24C32W(MN)@SOIC8  
M24C32W@MLP8  
M24C64(DL)@TSSOP14  
M24C64(MN)@SOIC8  
M24C64@MLP8  
M24C64W(DL)@TSSOP14  
M24C64W(MN)@SOIC8  
M24C64W@MLP8  
M24CL04B@MLP8  
M24CL04B@TSOP8  
M24E32

(BN)

M24E32(DW)@TSSOP8 [(SA602A)] M24E32(MN)@SOIC8  
 [(SA605A)]

M24E32(MW)@SOIC8 [(SA602A)]

M24W01

M24W01@SOIC8 [(SA602A)]

M24W02

M24W02@SOIC8 [(SA602A)]

M24W04

M24W04@SOIC8 [(SA602A)]

M24W08

M24W08@SOIC8 [(SA602A)]

M24W16

M24W16@SOIC8 [(SA602A)]

M25C01

M25C02

M25C04

M25C08

M25C16

M25E16 M25P05@SOIC8  
 [(SA602A)]

M25P05@VQFPN8 [(SA684)] M25P05-A@SOIC8  
 [(SA602A)]

M25P05-A@TSSOP8 [(SA605A)] M25P05-A@VDFPN8  
 [(SA684)]

M25P10@SOIC8 [(SA602A)] M25P10@VQFPN8  
 [(SA684)]

M25P10-A@SOIC8 [(SA602A)] M25P10-A@VFQFPN8  
 [(SA684)]

M25P128@SOIC16 [(SA404)]

M25P128@SOIC16(ISP) [ISP-HEADER01]

M25P128@VDFPN8 [(SA684)]

M25P128@VDFPN8(ISP) [ISP-HEADER01]

M25P16@SOIC16 [(SA404)]

M25P16@SOIC16(ISP) [ISP-HEADER01]

M25P16@SOIC8(150mil) [(SA602A)]

M25P16@SOIC8(150mil)(ISP) [ISP-HEADER01]

M25P16@SOIC8(200mil) [(SA605A)]

M25P16@SOIC8(200mil)(ISP) [ISP-HEADER01]

M25P16@VDFPN8 [(SA684)]

M25P16@VDFPN8(ISP) [ISP-HEADER01]

M25P16@VFQFPN8 [(SA683)]

M25P16@VFQFPN8(ISP) [ISP-HEADER01]



M25PX32@VFQFPN8 [(SA683)]	M25PX64@SOIC16
[(SA404)]	
M25PX64@VDFPN8 [(SA684)]	
M25W01	
M25W02	
M25W04	
M25W08	
M25W16	
M25W166	
M27128A	
M2716	
M2716F1	
M27256	
M27256A	
M2732A	
M27512	
M2764	
M2764A	
M27C1000	M27C1000@PLCC32
[(SA015A1T)]	
M27C1000@TSOP32 [(SA410T)]	
M27C1001	
M27C1001@PLCC32 [(SA015A1T)]	M27C1001@TSOP32
[(SA410T)]	
M27C1024	M27C1024@PLCC44
[(SA244)]	
M27C128B	
M27C16	
M27C160	M27C160@PLCC44
[(SA244)]	
M27C160@PSOP44 [(SA638)]	
M27C160K	
M27C160K@PLCC44 [(SA244)]	M27C160K@PSOP44
[(SA638)]	
M27C2001	M27C2001@PLCC32
[(SA015A1T)]	
M27C2001@TSOP32 [(SA410T)]	
M27C202	
M27C202@PLCC44 [(SA244)]	M27C202@TSOP40
[(SA409T)]	
M27C256B	M27C256B@PLCC32
[(SA015A1T)]	
M27C32	

M27C322	
M27C322@SDIP42 [(SA028)]	
M27C400	
M27C4001	M27C4001@PLCC32
[(SA015A1T)]	
M27C4001@TSOP32 [(SA410T)]	
M27C4002	
M27C4002@PLCC44 [(SA244)]	
M27C405	
M27C405@PLCC32 [(SA015A1T)]	M27C405@TSOP32
[(SA410T)]	
M27C512	M27C512@PLCC32
[(SA015A1T)]	
M27C513	
M27C516	
M27C516@PLCC44 [(SA244)]	
M27C64A	
M27C64A@PLCC32 [(SA015A1T)]	
M27C800	
M27C800@PLCC44 [(SA244)]	M27C800@PSOP44
[(SA638)]	
M27C801	M27C801@PLCC32
[(SA015A1T)]	
M27C801@TSOP32 [(SA410T)]	
M27HC641	
M27HC641@PLCC28 [(SA008A)]	
M27HC642	
M27HC642@PLCC28 [(SA008A)]	
M27V101	
M27V101@PLCC32 [(SA015A1T)]	M27V101@TSOP32
[(SA410T)]	
M27V102	M27V102@PLCC44
[(SA244)]	
M27V160	M27V160@PLCC44
[(SA244)]	
M27V160@PSOP44 [(SA638)]	
M27V160K	
M27V160K@PLCC44 [(SA244)]	M27V160K@PSOP44
[(SA638)]	
M27V201	M27V201@PLCC32
[(SA015A1T)]	
M27V201@TSOP32 [(SA410T)]	
M27V256	



M27V322	M27V322@SDIP42
[ (SA028) ]	
M27V401	M27V401@PLCC32
[ (SA015A1T) ]	
M27V401@TSOP32 [ (SA410T) ]	
M27V402	
M27V402@PLCC44 [ (SA244) ]	M27V402@TSOP40
[ (SA409T) ]	
M27V405	M27V405@PLCC32
[ (SA015A1T) ]	
M27V405@TSOP32 [ (SA410T) ]	
M27V512	
M27V512@PLCC32 [ (SA015A1T) ]	M27V512@TSOP28
[ (SA430T) ]	
M27V800	M27V800@PLCC44
[ (SA244) ]	
M27V801	M27V801@PLCC32
[ (SA015A1T) ]	
M27V801@TSOP32 [ (SA410T) ]	M27W016@PSOP44
[ (SA638) ]	
M27W016@TSOP48 [ (SA247-B005) ]	M27W032@PSOP44
[ (SA638) ]	
M27W032@TSOP48 [ (SA247-B005) ]	M27W064@PSOP44
[ (SA638) ]	
M27W064@TSOP48 [ (SA247-B005) ]	
M27W101	
M27W101@PLCC32 [ (SA015A1T) ]	M27W101@TSOP32
[ (SA410T) ]	
M27W102	M27W102@PLCC44
[ (SA244) ]	
M27W160	M27W160@PLCC44
[ (SA244) ]	
M27W160@PSOP44 [ (SA638) ]	
M27W201	
M27W201@PLCC32 [ (SA015A1T) ]	M27W201@TSOP32
[ (SA410T) ]	
M27W202	M27W202@PLCC44
[ (SA244) ]	
M27W202@TSOP40 [ (SA409T) ]	
M27W400	
M27W400@PLCC44 [ (SA244) ]	
M27W401	
M27W401@PLCC32 [ (SA015A1T) ]	M27W401@TSOP32

[ (SA410T) ]	
M27W402	M27W402@PLCC44
[ (SA244) ]	
M27W402@TSOP40 [ (SA409T) ]	
M27W512	
M27W512@PLCC32 [ (SA015A1T) ]	M27W512@TSOP28
[ (SA430T) ]	
M27W800	M27W800@PLCC44
[ (SA244) ]	
M27W801	M27W801@PLCC32
[ (SA015A1T) ]	
M27W801@TSOP32 [ (SA410T) ]	
M28010	
M28010@PLCC32 [ (SA015A1T) ]	M28010@TSOP32
[ (SA410T) ]	
M28010R	M28010R@PLCC32
[ (SA015A1T) ]	
M28010R@TSOP32 [ (SA410T) ]	
M28010W	
M28010W@PLCC32 [ (SA015A1T) ]	M28010W@TSOP32
[ (SA410T) ]	
M28256	M28256@PLCC32
[ (SA015A1T) ]	
M28256@TSOP28 [ (SA430T) ]	
M28C010	
M28C010@PLCC32 [ (SA015A1T) ]	M28C010@TSOP32
[ (SA410T) ]	
M28C010R	M28C010R@PLCC32
[ (SA015A1T) ]	
M28C010R@TSOP32 [ (SA410T) ]	
M28C010W	
M28C010W@PLCC32 [ (SA015A1T) ]	M28C010W@TSOP32
[ (SA410T) ]	
M28C16@PLCC32 [ (SA015A1T) ]	M28C17@SOIC28
[ (SA404) ]	
M28C64	M28C64@PLCC32
[ (SA015A1T) ]	
M28C64@TSOP28 [ (SA430T) ]	
M28C64C	
M28C64C@PLCC32 [ (SA015A1T) ]	M28C64C@SOIC28
[ (SA404) ]	
M28C64C@TSOP28 [ (SA430T) ]	
M28C64X	

M28C64X@PLCC32 [ (SA015A1T) ]	M28C64X@TSOP28
[ (SA430T) ]	
M28F101	M28F101@PLCC32
[ (SA015A1T) ]	
M28F101@TSOP32 [ (SA410T) ]	
M28F102	
M28F102@PLCC44 [ (SA244) ]	M28F102@TSOP40
[ (SA409T) ]	
M28F151	M28F151@PLCC32
[ (SA015A1T) ]	
M28F151@TSOP32 [ (SA410T) ]	
M28F201	
M28F201@PLCC32 [ (SA015A1T) ]	M28F201@TSOP32
[ (SA410T) ]	
M28F211@TSOP40 [ (SA409T) ]	M28F220@PSOP44
[ (SA638) ]	
M28F220@TSOP48 [ (SA247-B005) ]	M28F221@TSOP40
[ (SA409T) ]	
M28F256	M28F256@PLCC32
[ (SA015A1T) ]	
M28F256@TSOP32 [ (SA410T) ]	M28F411@TSOP40
[ (SA409T) ]	
M28F421@TSOP40 [ (SA409T) ]	
M28F512	
M28F512@PLCC32 [ (SA015A1T) ]	M28F512@TSOP32
[ (SA410T) ]	
M28LV64	M28LV64@PLCC32
[ (SA015A1T) ]	
M28LV64@TSOP28 [ (SA430T) ]	
M28R400CB@FBGA48 [ (SA634A-B005A-Y048F001) ]	
M28R400CT@FBGA48 [ (SA634A-B005A-Y048F001) ]	
M28V411@TSOP40 [ (SA409T) ]	M28V421@TSOP40
[ (SA409T) ]	
M28W160B@FBGA48 [ (SA634A-B005A-Y048F001) ]	
M28W160B@TSOP48 [ (SA247-B005) ]	
M28W160BB@FBGA48 [ (SA634A-B005A-Y048F001) ]	
M28W160BB@TSOP48 [ (SA247-B005) ]	
M28W160BT@FBGA48 [ (SA634A-B005A-Y048F001) ]	
M28W160BT@TSOP48 [ (SA247-B005) ]	
M28W160CB@FBGA48 [ (SA634A-B005A-Y048F001) ]	
M28W160CB@TSOP48 [ (SA247-B005) ]	
M28W160CT@FBGA48 [ (SA634A-B005A-Y048F001) ]	
M28W160CT@TSOP48 [ (SA247-B005) ]	

M28W160ECB@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
M28W160ECB@TSOP48 [ ( SA247-B005 ) ]  
M28W160ECT@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
M28W160ECT@TSOP48 [ ( SA247-B005 ) ]  
M28W160ESB@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W160EST@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W160T@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W160T@TSOP48 [ ( SA247-B005 ) ]  
M28W320CB@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W320CB@TSOP48 [ ( SA247-B005 ) ]  
M28W320CT@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W320CT@TSOP48 [ ( SA247-B005 ) ]  
M28W320ECB@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W320ECB@TSOP48 [ ( SA247-B005 ) ]  
M28W320ECT@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W320ECT@TSOP48 [ ( SA247-B005 ) ]  
M28W320FCB@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
M28W320FCB@TSOP48 [ ( SA247-B005 ) ]  
M28W320FCT@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
M28W320FCT@TSOP48 [ ( SA247-B005 ) ]  
M28W320FSB@FBGA47 [ ( SA714B-B026A-T048F001Y ) ]  
M28W320FSB@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W320FST@FBGA47 [ ( SA714B-B026A-T048F001Y ) ]  
M28W320FST@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W320FSU(Double)@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W320FSU@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W320HSB@FBGA47 [ ( SA714B-B026A-T048F001Y ) ]  
M28W320HSB@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W320HST@FBGA47 [ ( SA714B-B026A-T048F001Y ) ]  
M28W320HST@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W320HSU(Double)@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W320HSU@FBGA47 [ ( SA714B-B026A-T048F001Y ) ]  
M28W320HSU@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W640ECB@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W640ECB@TSOP48 [ ( SA247-B005 ) ]  
M28W640ECT@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W640ECT@TSOP48 [ ( SA247-B005 ) ]  
M28W640FCB@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
M28W640FCB@TSOP48 [ ( SA247-B005 ) ]  
M28W640FCT@FBGA48 [ ( SA634A-B005A-Y048F001Y ) ]  
M28W640FCT@TSOP48 [ ( SA247-B005 ) ]  
M28W640FSB@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W640FST@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]

M28W640FSU@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W640HSB@FBGA48 [ ( SA714B-B026A-T048F001Y ) ]  
M28W640HSB@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W640HST@FBGA48 [ ( SA714B-B026A-T048F001Y ) ]  
M28W640HST@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W640HSU@FBGA48 [ ( SA714B-B026A-T048F001Y ) ]  
M28W640HSU@FBGA64 [ ( SA655E-B090A-T064F001Y ) ]  
M28W800B@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800B@TSOP48 [ ( SA247-B005 ) ]  
M28W800BB@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800BB@TSOP48 [ ( SA247-B005 ) ]  
M28W800BT@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800BT@TSOP48 [ ( SA247-B005 ) ]  
M28W800CB@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800CB@TSOP48 [ ( SA247-B005 ) ]  
M28W800CT@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800CT@TSOP48 [ ( SA247-B005 ) ]  
M28W800T@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
M28W800T@TSOP48 [ ( SA247-B005 ) ]  
M29DW128F@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29DW128F@TSOP56 [ ( SA628-B102 ) ]  
M29DW323DB@TFBGA48 [ ( SA642E-B026A-T072F001 ) ]  
M29DW323DB@TFBGA63 [ ( SA642E-B026A-T072F001 ) ]  
M29DW323DB@TSOP48 [ ( SA247-B005 ) ]  
M29DW323DT@TFBGA48 [ ( SA642E-B026A-T072F001 ) ]  
M29DW323DT@TFBGA63 [ ( SA642E-B026A-T072F001 ) ]  
M29DW323DT@TSOP48 [ ( SA247-B005 ) ]  
M29DW324DB@TFBGA48 [ ( SA642E-B026A-T072F001 ) ]  
M29DW324DB@TFBGA63 [ ( SA642E-B026A-T072F001 ) ]  
M29DW324DB@TSOP48 [ ( SA247-B005 ) ]  
M29DW324DT@TFBGA48 [ ( SA642E-B026A-T072F001 ) ]  
M29DW324DT@TFBGA63 [ ( SA642E-B026A-T072F001 ) ]  
M29DW324DT@TSOP48 [ ( SA247-B005 ) ]  
M29DW640D@FBGA63 [ ( SA642E-B026A-T072F001N ) ]  
M29DW640D@TSOP48 [ ( SA247-B005 ) ]  
M29DW640F@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29DW640F@TSOP48 [ ( SA247-B005 ) ]  
M29DW641F@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29DW641F@TSOP48 [ ( SA247-B005 ) ]  
M29F002B  
M29F002B@PLCC32 [ ( SA015A1T ) ]                      M29F002B@TSOP32  
[ ( SA410T ) ]  
M29F002BB    M29F002BB@PLCC32

[ (SA015A1T) ]	
M29F002BB@TSOP32 [ (SA410T) ]	
M29F002BNT	
M29F002BNT@PLCC32 [ (SA015A1T) ]	M29F002BNT@TSOP32
[ (SA410T) ]	
M29F002BT	
[ (SA015A1T) ]	
M29F002BT@TSOP32 [ (SA410T) ]	M29F002BT@PLCC32
M29F002T	
M29F002T@PLCC32 [ (SA015A1T) ]	M29F002T@TSOP32
[ (SA410T) ]	
M29F010B	
[ (SA015A1T) ]	
M29F010B@TSOP32 [ (SA410T) ]	M29F010B@PLCC32
[ (SA638) ]	
M29F016B@TSOP40 [ (SA409T) ]	M29F016B@PSOP44
[ (SA638) ]	
M29F016D@TSOP40 [ (SA409T) ]	M29F016D@PSOP44
[ (SA409T) ]	
M29F040	
[ (SA015A1T) ]	
M29F040@TSOP32 [ (SA410T) ]	M29F040@PLCC32
M29F040B	
M29F040B@PLCC32 [ (SA015A1T) ]	M29F040B@TSOP32
[ (SA410T) ]	
M29F080A@PSOP44 [ (SA638) ]	M29F080A@TSOP40
[ (SA409T) ]	
M29F080D@PSOP44 [ (SA638) ]	M29F080D@TSOP40
[ (SA409T) ]	
M29F100B@PSOP44 [ (SA638-B006) ]	M29F100B@TSOP48 [ (SA247-
B005) ]	
M29F100T@PSOP44 [ (SA638-B006) ]	M29F100T@TSOP48 [ (SA247-
B005) ]	
M29F102B@PLCC44 [ (SA244) ]	M29F102B@TSOP40
[ (SA623) ]	
M29F102BB@PLCC44 [ (SA244) ]	M29F102BB@TSOP40
[ (SA623) ]	
M29F160BB@TSOP48 [ (SA247-B005) ]	M29F160BT@TSOP48 [ (SA247-
B005) ]	
M29F200B@PSOP44 [ (SA638-B006) ]	M29F200B@TSOP48 [ (SA247-
B005) ]	
M29F200BB@PSOP44 [ (SA638-B006) ]	M29F200BB@TSOP48 [ (SA247-
B005) ]	

M29F200BT@PSOP44 [ (SA638-B006) ]	M29F200BT@TSOP48 [ (SA247-B005) ]
M29F200T@PSOP44 [ (SA638-B006) ]	M29F200T@TSOP48 [ (SA247-B005) ]
M29F400B@PSOP44 [ (SA638-B006) ]	M29F400B@TSOP48 [ (SA247-B005) ]
M29F400BB@PSOP44 [ (SA638-B006) ]	M29F400BB@TSOP48 [ (SA247-B005) ]
M29F400BT@PSOP44 [ (SA638-B006) ]	M29F400BT@TSOP48 [ (SA247-B005) ]
M29F400T@PSOP44 [ (SA638-B006) ]	M29F400T@TSOP48 [ (SA247-B005) ]
M29F512B@PLCC32 [ (SA015A1T) ]	M29F512B@TSOP32
[ (SA620) ]	
M29F800AB@PSOP44 [ (SA638-B006) ]	M29F800AB@TSOP48 [ (SA247-B005) ]
M29F800AT@PSOP44 [ (SA638-B006) ]	M29F800AT@TSOP48 [ (SA247-B005) ]
M29F800DB@PSOP44 [ (SA638) ]	M29F800DB@TSOP48 [ (SA247-B005) ]
M29F800DT@PSOP44 [ (SA638) ]	M29F800DT@TSOP48 [ (SA247-B005) ]
M29KW016E@PSOP44 [ (SA638) ]	
M29KW016E@TFBGA48 [ (SA642E-B026A-T072F001) ]	
M29KW016E@TSOP48 [ (SA247-B005) ]	
M29KW032E@TFBGA48 [ (SA642E-B026A-T072F001) ]	
M29KW032E@TSOP48 [ (SA247-B005) ]	
M29KW064E@TFBGA48 [ (SA642E-B026A-T072F001) ]	
M29KW064E@TSOP48 [ (SA247-B005) ]	M29V040@PLCC32
[ (SA015A1T) ]	
M29V040@TSOP32 [ (SA410T) ]	M29W004B@TSOP40
[ (SA409T) ]	
M29W004BB@TSOP40 [ (SA409T) ]	M29W004BT@TSOP40
[ (SA409T) ]	
M29W004T@TSOP40 [ (SA409T) ]	M29W008AB@TSOP40
[ (SA409T) ]	
M29W008AT@TSOP40 [ (SA409T) ]	M29W008B@TSOP40
[ (SA409T) ]	
M29W008T@TSOP40 [ (SA409T) ]	M29W010B@PLCC32
[ (SA015A1T) ]	
M29W010B@TSOP32 [ (SA410T) ]	
M29W017D@TFBGA48 [ (SA642B-B026A-Y072F001) ]	
M29W017D@TSOP40 [ (SA409T) ]	

M29W022BB  
M29W022BB@PLCC32 [ (SA015A1T) ] M29W022BB@TSOP32  
[ (SA410T) ]  
M29W022BT M29W022BT@PLCC32  
[ (SA015A1T) ]  
M29W022BT@TSOP32 [ (SA410T) ] M29W040@PLCC32  
[ (SA015A1T) ]  
M29W040@TSOP32 [ (SA410T) ] M29W040B@PLCC32  
[ (SA015A1T) ]  
M29W040B@TSOP32 [ (SA410T) ] M29W102BB@TSOP40  
[ (SA623) ]  
M29W102BT@TSOP40 [ (SA623) ] M29W116BB@TSOP40  
[ (SA409T) ]  
M29W116BT@TSOP40 [ (SA409T) ]  
M29W128FH@FBGA64 [ (SA655E-B099A-T064F001Y) ]  
M29W128FH@TSOP56 [ (SA628-B102) ]  
M29W128FL@FBGA64 [ (SA655E-B099A-T064F001Y) ]  
M29W128FL@TSOP56 [ (SA628-B102) ]  
M29W128GH@FBGA64 [ (SA655E-B099A-T064F001Y) ]  
M29W128GH@TSOP56 [ (SA628-B102) ]  
M29W128GL@FBGA64 [ (SA655E-B099A-T064F001Y) ]  
M29W128GL@TSOP56 [ (SA628-B102) ]  
M29W160BB@LBGA48 [ (SA642G-B026A-T048F001Y) ]  
M29W160BB@PSOP44 [ (SA638) ] M29W160BB@TSOP48 [ (SA247-  
B005) ]  
M29W160BT@LBGA48 [ (SA642G-B026A-T048F001Y) ]  
M29W160BT@PSOP44 [ (SA638) ] M29W160BT@TSOP48 [ (SA247-  
B005) ]  
M29W160DB@LBGA48 [ (SA642G-B026A-T048F001Y) ]  
M29W160DB@PSOP44 [ (SA638) ] M29W160DB@TSOP48 [ (SA247-  
B005) ]  
M29W160DT@LBGA48 [ (SA642G-B026A-T048F001Y) ]  
M29W160DT@PSOP44 [ (SA638) ] M29W160DT@TSOP48 [ (SA247-  
B005) ]  
M29W160EB@LBGA48 [ (SA642G-B026A-T048F001Y) ]  
M29W160EB@PSOP44 [ (SA638) ] M29W160EB@TSOP48 [ (SA247-  
B005) ]  
M29W160ET@LBGA48 [ (SA642G-B026A-T048F001Y) ]  
M29W160ET@PSOP44 [ (SA638) ] M29W160ET@TSOP48 [ (SA247-  
B005) ]  
M29W160FB@TSOP48 [ (SA247-B005) ] M29W160FT@TSOP48 [ (SA247-  
B005) ]  
M29W200BB@PSOP44 [ (SA638) ] M29W200BB@TSOP48 [ (SA247-



B005) ]  
 M29W200BT@PSOP44 [ ( SA638 ) ] M29W200BT@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W320DB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W320DB@FBGA63 [ ( SA642DD-B026A-W063F001Y ) ]  
 M29W320DB@TSOP48 [ ( SA247-B005 ) ]  
 M29W320DT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W320DT@FBGA63 [ ( SA642DD-B026A-W063F001Y ) ]  
 M29W320DT@TSOP48 [ ( SA247-B005 ) ]  
 M29W320EB@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
 M29W320EB@TSOP48 [ ( SA247-B005 ) ]  
 M29W320ET@FBGA48 [ ( SA642G-B026A-T048F001 ) ]  
 M29W320ET@TSOP48 [ ( SA247-B005 ) ] M29W400B@PSOP44  
 [ ( SA638 ) ]  
 M29W400B@TSOP48 [ ( SA247-B005 ) ]  
 M29W400BB@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W400BB@PSOP44 [ ( SA638 ) ] M29W400BB@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W400BT@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W400BT@PSOP44 [ ( SA638 ) ] M29W400BT@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W400DB( ZA )@LBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
 M29W400DB( ZE )@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W400DB@PSOP44 [ ( SA638 ) ] M29W400DB@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W400DT( ZA )@LBGA48 [ ( SA642N-B026A-W048F001Y ) ]  
 M29W400DT( ZE )@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W400DT@PSOP44 [ ( SA638 ) ] M29W400DT@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W400T@PSOP44 [ ( SA638 ) ] M29W400T@TSOP48 [ ( SA247-  
 B005 ) ]  
 M29W512B@PLCC32 [ ( SA015A1T ) ] M29W512B@TSOP32  
 [ ( SA620 ) ]  
 M29W640DB@FBGA63 [ ( SA642E-B026A-T072F001 ) ]  
 M29W640DB@TSOP48 [ ( SA247-B005 ) ]  
 M29W640DT@FBGA63 [ ( SA642E-B026A-T072F001 ) ]  
 M29W640DT@TSOP48 [ ( SA247-B005 ) ]  
 M29W640FB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W640FB@TSOP48 [ ( SA247-B005 ) ]  
 M29W640FT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W640FT@TSOP48 [ ( SA247-B005 ) ]  
 M29W640GB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
 M29W640GB@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]

M29W640GB@TSOP48 [ ( SA247-B005 ) ]            M29W640GB@TSOP56 [ ( SA628-B102 ) ]  
M29W640GH@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W640GH@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W640GH@TSOP48 [ ( SA247-B005 ) ]            M29W640GH@TSOP56 [ ( SA628-B102 ) ]  
M29W640GL@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W640GL@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W640GL@TSOP48 [ ( SA247-B005 ) ]            M29W640GL@TSOP56 [ ( SA628-B102 ) ]  
M29W640GSB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W640GSB@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W640GSB@TSOP48 [ ( SA247-B005 ) ]            M29W640GSB@TSOP56 [ ( SA628-B102 ) ]  
M29W640GSH@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W640GSH@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W640GSH@TSOP48 [ ( SA247-B005 ) ]            M29W640GSH@TSOP56 [ ( SA628-B102 ) ]  
M29W640GSL@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W640GSL@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W640GSL@TSOP48 [ ( SA247-B005 ) ]            M29W640GSL@TSOP56 [ ( SA628-B102 ) ]  
M29W640GST@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W640GST@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W640GST@TSOP48 [ ( SA247-B005 ) ]            M29W640GST@TSOP56 [ ( SA628-B102 ) ]  
M29W640GT@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W640GT@FBGA64 [ ( SA655E-B099A-T064F001Y ) ]  
M29W640GT@TSOP48 [ ( SA247-B005 ) ]            M29W640GT@TSOP56 [ ( SA628-B102 ) ]  
M29W641DH@TSOP48 [ ( SA247-B005 ) ]            M29W641DL@TSOP48 [ ( SA247-B005 ) ]  
M29W641DU@FBGA63 [ ( SA642E-B026A-T072F001 ) ]  
M29W800AB@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W800AB@PSOP44 [ ( SA638 ) ]            M29W800AB@TSOP48 [ ( SA247-B005 ) ]  
M29W800AT@LBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W800AT@PSOP44 [ ( SA638 ) ]            M29W800AT@TSOP48 [ ( SA247-B005 ) ]  
M29W800B@PSOP44 [ ( SA638 ) ]            M29W800B@TSOP48 [ ( SA247-B005 ) ]  
M29W800DB@FBGA48 [ ( SA642G-B026A-T048F001Y ) ]  
M29W800DB@PSOP44 [ ( SA638 ) ]            M29W800DB@TSOP48 [ ( SA247-

B005) ]  
M29W800DT@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
M29W800DT@PSOP44 [ (SA638) ] M29W800DT@TSOP48 [ (SA247-  
B005) ]  
M29W800T@PSOP44 [ (SA638) ] M29W800T@TSOP48 [ (SA247-  
B005) ]  
M30L0R7000B0@FBGA88 [ (SA642R-B124A-T096F001Y) ]  
M30L0R7000T0@FBGA88 [ (SA642R-B124A-T096F001Y) ]  
M30L0R8000B0@FBGA88 [ (SA642R-B124A-T096F001Y) ]  
M30L0R8000T0@FBGA88 [ (SA642R-B124A-T096F001Y) ]  
M30W0R6600T0@LFBGA88 [ (SA642A-B061A-Y096F001) ]  
M30WR128B@LFBGA88 [ (SA642A-B061A-Y096F001) ]  
M34C02 M34C02@MSOP8  
[ (SA666) ]  
M34C02@SOIC8 [ (SA602A) ] M34C02@TSOP8  
[ (SA026) ]  
M34D32 M34D32@SOIC8  
[ (SA602A) ]  
M34D32@TSSOP8 [ (SA026) ]  
M34D64 M34D64@TSSOP8  
M34D64@SOIC8 [ (SA602A) ]  
[ (SA026) ]  
M34E02 M34E02@MSOP8  
[ (SA666) ]  
M34E02@SOIC8 [ (SA602A) ] M34E02@TSOP8  
[ (SA026) ]  
M35080 M35080@SOIC8  
[ (SA602A) ]  
M36A0W5020B0@FBGA66 [ (SA642E-B023A-T072F001Y) ]  
M36A0W5020T0@FBGA66 [ (SA642E-B023A-T072F001Y) ]  
M36A0W5030B0@FBGA66 [ (SA642E-B023A-T072F001Y) ]  
M36A0W5030T0@FBGA66 [ (SA642E-B023A-T072F001Y) ]  
M36A0W5040B0@FBGA66 [ (SA642E-B023A-T072F001Y) ]  
M36A0W5040T0@FBGA66 [ (SA642E-B023A-T072F001Y) ]  
M36D0R5030B0(EFP)@FBGA67 [ (SA642E-B023A-T072F001Y) ]  
M36D0R5030B0(Q\_Word)@FBGA67 [ (SA642E-B023A-T072F001Y) ]  
M36D0R5030T0(EFP)@FBGA67 [ (SA642E-B023A-T072F001Y) ]  
M36D0R5030T0(Q\_Word)@FBGA67 [ (SA642E-B023A-T072F001Y) ]  
M36D0R5040B0(EFP)@FBGA67 [ (SA642E-B023A-T072F001Y) ]  
M36D0R5040B0(Q\_Word)@FBGA67 [ (SA642E-B023A-T072F001Y) ]  
M36D0R5040T0(EFP)@FBGA67 [ (SA642E-B023A-T072F001Y) ]  
M36D0R5040T0(Q\_Word)@FBGA67 [ (SA642E-B023A-T072F001Y) ]  
M36D0R6040B0(EFP)@FBGA72 [ (SA642E-B023A-T072F001Y) ]

M36D0R6040B0(Q\_Word)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36D0R6040T0(EFP)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36D0R6040T0(Q\_Word)@FBGA72 [(SA642E-B023A-T072F001Y)]  
M36DR232A@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36DR232B@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36DR432AD@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36DR432BD@FBGA66 [(SA642E-B023A-T072F001Y)]  
M36L0R7040B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7040T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050L1@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R7050L2@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R7050T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7050U1@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R7050U2@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R7060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7060L1@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R7060T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R7060U1@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R8060B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060L0@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0R8060T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0R8060U0@FBGA88 [(SA642R-B180A-T096F001Y)]  
M36L0T7040B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7040T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7050T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T7060T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8050B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8050T1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060B1@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36L0T8060T1@FBGA88 [(SA642R-B124A-T096F001Y)]

M36LLR8760B1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8760D1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8760M1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8760T1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8860B1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8860D1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8860M1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8860T1@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870B0@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870B1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
M36LLR8870D0@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870D1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
M36LLR8870M0@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870M1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
M36LLR8870T0@FBGA88 [(SA642R-B113A-T096F001Y)]  
M36LLR8870T1@FBGA88 [(SA642A-B113A-Y096F001Y)]  
M36W0R5020B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5020B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5020T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5020T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5030B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5030B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5030T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5030T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5040B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5040B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5040L3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R5040T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5040T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R5040U3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6030B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6030B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6030T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6030T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040B1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0R6040L3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6040T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6040T1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0R6040U3@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6050B0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]

M36W0R6050B0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050B1@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050L0@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0R6050T0(EFP)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050T0(Q\_Word)@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050T1@FBGA88 [(SA642R-B107A-T096F001Y)]  
M36W0R6050U0@FBGA88 [(SA642R-B180-T096F001Y)]  
M36W0T5040B1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T5040T1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040B0@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040B1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040T0@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T6040T1@FBGA88 [(SA642R-B112A-T096F001Y)]  
M36W0T7050B0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36W0T7050T0@FBGA88 [(SA642R-B124A-T096F001Y)]  
M36W216BI@LFBGA66 [(SA642E-B041A-T072F001)]  
M36W216TI@LFBGA66 [(SA642E-B041A-T072F001)]  
M36W432BG@LFBGA66 [(SA642E-B041A-T072F001)]  
M36W432TG@LFBGA66 [(SA642E-B041A-T072F001)]  
M36W864BE@LFBGA67 [(SA642E-B041A-T072F001)]  
M36W864TE@LFBGA67 [(SA642E-B041A-T072F001)]  
M36WWR6650B0@LFBGA88 [(SA642A-B076A-Y096F001)]  
M36WWR6650D0@LFBGA88 [(SA642A-B076A-Y096F001)]  
M36WWR6650T0@LFBGA88 [(SA642A-B076A-Y096F001)]  
M45PE10@SOIC8 [(SA602A)] M45PE10@VQFPN8  
[(SA683)]  
M45PE16@SOIC8 [(SA023A)] M45PE16@VQFPN8  
[(SA683)]  
M45PE20@SOIC8 [(SA602A)]  
M45PE20@SOIC8(ISP) [ISP-HEADER01]  
M45PE20@VQFPN8 [(SA683)]  
M45PE20@VQFPN8(ISP) [ISP-HEADER01]  
M45PE40@SOIC8 [(SA023A)]  
M45PE40@SOIC8(ISP) [ISP-HEADER01]  
M45PE40@VQFPN8 [(SA683)]  
M45PE40@VQFPN8(ISP) [ISP-HEADER01]  
M45PE80@SOIC16 [(SA023A)]  
M45PE80@SOIC16(ISP) [ISP-HEADER01]  
M45PE80@SOIC8 [(SA023A)]  
M45PE80@SOIC8(ISP) [ISP-HEADER01]  
M45PE80@VQFPN8 [(SA683)]  
M45PE80@VQFPN8(ISP) [ISP-HEADER01]  
M48C02

M48C02B

M48C12

M48C12B

M48T02

M48T02B

M48T08

M48T12

M48T128V

M48T128Y

M48T129V

M48T129Y

M48T12B

M48T18

M48T30

M48T30Y

M48T32

M48T32Y

M48T35

M48T35@SOIC28

[ (SA404) ]

M48T35AV

M48T35AV@SOIC28

[ (SA630) ]

M48T35AY

M48T35AY@SOIC28

[ (SA630) ]

M48T35Y

M48T35Y@SOIC28

[ (SA404) ]

M48T512AV

M48T512AY

M48T512V

M48T512Y

M48T559

M48T559@SOIC28

[ (SA630) ]

M48T559Y

M48T559Y@SOIC28

[ (SA630) ]

M48T58

M48T58@SOIC28

[ (SA404) ]

M48T58Y

M48T58Y@SOIC28

[ (SA404) ]

M48T59

M48T59@SOIC28

[ (SA404) ]

M48T59V

M48T59V@SOIC28

[ (SA404) ]

M48T59Y

M48T59Y@SOIC28

[ (SA404) ]

M48Z02  
M48Z02B  
M48Z08  
M48Z12  
M48Z128  
M48Z128V  
M48Z128Y  
M48Z129V  
M48Z129Y  
M48Z12B  
M48Z18  
M48Z30  
M48Z30Y  
M48Z32  
M48Z32Y  
M48Z35  
M48Z35@SOIC28 [(SA630)]  
M48Z35Y  
M48Z35Y@SOIC28 [(SA630)]  
M48Z512AV  
M48Z512AY  
M48Z512V  
M48Z512Y  
M48Z58  
M48Z58@SOIC28 [(SA404)]  
M48Z58Y  
M48Z58Y@SOIC28 [(SA404)]  
M48Z59  
M48Z59@SOIC28 [(SA404)]  
M48Z59W  
M48Z59W@SOIC28 [(SA404)]  
M48Z59Y  
M48Z59Y@SOIC28 [(SA404)]  
[(SA015A1T)] M50FLW040A@PLCC32  
M50FLW040A@TSOP40 [(SA409T)] M50FLW040A@VSOP32  
[(SA620)]  
M50FLW040B@PLCC32 [(SA015A1T)] M50FLW040B@TSOP40  
[(SA409T)]  
M50FLW040B@VSOP32 [(SA620)] M50FLW080A@PLCC32  
[(SA015A1T)]  
M50FLW080A@TSOP40 [(SA409T)] M50FLW080A@VSOP32  
[(SA620)]  
M50FLW080B@PLCC32 [(SA015A1T)] M50FLW080B@TSOP40



[ (SA409T) ]  
 M50FLW080B@VSOP32 [ (SA620) ] M50FW002@PLCC32  
 [ (SA015A1T) ]  
 M50FW016@TSOP40 [ (SA409T) ] M50FW020@PLCC32  
 [ (SA015A1T) ]  
 M50FW040@PLCC32 [ (SA015A1T) ] M50FW040@TSOP40  
 [ (SA409T) ]  
 M50FW080@PLCC32 [ (SA015A1T) ] M50FW080@TSOP40  
 [ (SA409T) ]  
 M50FW080@VSOP32 [ (SA620) ] M50LPW002@PLCC32  
 [ (SA015A1T) ]  
 M50LPW012@PLCC32 [ (SA015A1T) ] M50LPW020@PLCC32  
 [ (SA015A1T) ]  
 M50LPW040@PLCC32 [ (SA015A1T) ] M50LPW040@TSOP40  
 [ (SA409T) ]  
 M50LPW041@PLCC32 [ (SA015A1T) ] M50LPW041@TSOP40  
 [ (SA409T) ]  
 M50LPW080@PLCC32 [ (SA015A1T) ] M50LPW080@TSOP40  
 [ (SA409T) ]  
 M50LPW116@TSOP40 [ (SA409T) ]  
 M58LR128FB@VFBGA56 [ (SA644A-B025B-Y072F001) ]  
 M58LR128FT@VFBGA56 [ (SA644A-B025B-Y072F001) ]  
 M58LR128GB@VFBGA56 [ (SA644A-B025B-Y072F001) ]  
 M58LR128GL@FBGA44 [ (SA733A-B206A-M056F001Y) ]  
 M58LR128GT@VFBGA56 [ (SA644A-B025B-Y072F001) ]  
 M58LR128GU@FBGA44 [ (SA733A-B206A-M056F001Y) ]  
 M58LR256GL@FBGA44 [ (SA733C-B206A-M056F001N) ]  
 M58LR256GU@FBGA44 [ (SA733C-B206A-M056F001N) ]  
 M58LT128GB@FBGA56 [ (SA644A-B025B-Y072F001Y) ]  
 M58LT128GSB@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
 M58LT128GST@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
 M58LT128GT@FBGA56 [ (SA644A-B025B-Y072F001Y) ]  
 M58LT128HSB@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
 M58LT128HST@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
 M58LT256GB@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
 M58LT256GT@FBGA64 [ (SA655E-B130A-T056F001Y) ]  
 M58LW032A@TSOP56 [ (SA628-B031) ]  
 M58LW032C@FBGA64 [ (SA655A-B054A-T064F001) ]  
 M58LW032C@TSOP56 [ (SA628-B031) ]  
 M58LW032D@FBGA64 [ (SA655A-B054A-T064F001) ]  
 M58LW032D@TSOP56 [ (SA628-B018) ]  
 M58LW064C@FBGA64 [ (SA655A-B054A-T064F001) ]  
 M58LW064C@TSOP56 [ (SA628-B063) ]

M58LW064D@FBGA64 [(SA655A-B054A-T064F001)]  
M58LW064D@TSOP56 [(SA628-B018)] M58LW128A@TSOP56 [(SA628-B018)]  
M58WR016QB(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR016QB(Q\_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR016QL@FBGA44 [(SA733A-B206A-M056F001N)]  
M58WR016QT(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR016QT(Q\_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR016QU@FBGA44 [(SA733A-B206A-M056F001N)]  
M58WR032EB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032EB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032ET(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032ET(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032FB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032FB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032FT(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032FT(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR032HB@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032HT@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QB(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QB(Q\_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QL@FBGA44 [(SA733A-B206A-M056F001N)]  
M58WR032QT(EFP)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QT(Q\_Word)@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR032QU@FBGA44 [(SA733A-B206A-M056F001N)]  
M58WR064EB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064EB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064ET(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064ET(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FT(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064FT(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR064HB@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR064HT@FBGA56 [(SA656C-B104A-T056F001Y)]  
M58WR128FB(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR128FB(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR128FT(EFP)@FBGA56 [(SA644A-B025B-Y072F001)]  
M58WR128FT(Q\_Word)@FBGA56 [(SA644A-B025B-Y072F001)]  
M59DR008E@FBGA48 [(SA634A-B005-Y048F001Y)]  
M59DR008E@TSOP48 [(SA247-B005)]  
M59DR008F@FBGA48 [(SA634A-B005-Y048F001Y)]  
M59DR008F@TSOP48 [(SA247-B005)]

M59DR016C@FBGA48 [(SA634A-B005A-Y048N001N)]	
M59DR016D@FBGA48 [(SA634A-B005A-Y048N001N)]	
M59PW016@PSOP44 [(SA638)]	M59PW016@SDIP42
[(SA028)]	
M59PW016@TSOP48 [(SA247-B005)]	M59PW032@PSOP44
[(SA638)]	
M59PW032@PSOP44(Fast) [(SA638+B006)]	
M59PW032@TSOP48 [(SA247-B005)]	M59PW064@PSOP44
[(SA638)]	
M59PW1282@PSOP44 [(SA638)]	
M72DW64000B@FBGA73 [(SA642A-B032A-Y096F001Y)]	
M72DW75000C@FBGA73 [(SA642A-B039A-Y096F001Y)]	
M72DW75001C@FBGA73 [(SA642A-B032A-Y096F001Y)]	
M72DW76001D@FBGA73 [(SA642A-B032A-Y096F001Y)]	
M76DW52003BA@FBGA73 [(SA642A-B032A-Y096F001Y)]	
M76DW52003TA@FBGA73 [(SA642A-B032A-Y096F001Y)]	
M76DW52004BA@FBGA73 [(SA642A-B032A-Y096F001Y)]	
M76DW52004TA@FBGA73 [(SA642A-B032A-Y096F001Y)]	
M76DW62000A@FBGA73 [(SA642A-B032A-Y096F001Y)]	
M76DW63000A@FBGA73 [(SA642A-B032A-Y096F001Y)]	
M87C257	M87C257@PLCC32
[(SA015A1T)]	
M93C06(08bit)	M93C06(08bit)@SOIC8
[(SA602A)]	
M93C06(16bit)	M93C06(16bit)@SOIC8
[(SA602A)]	
M93C46(08bit)	M93C46(08bit)@MLP8
[(SA694)]	
M93C46(08bit)@MSOP8 [(SA666)]	M93C46(08bit)@SOIC8
[(SA602A)]	
M93C46(08bit)@TSSOP8 [(SA026)]	M93C46
(16bit)	
M93C46(16bit)@MLP8 [(SA694)]	M93C46(16bit)@MSOP8
[(SA666)]	
M93C46(16bit)@SOIC8 [(SA602A)]	M93C46(16bit)@TSSOP8
[(SA026)]	
M93C46R(08bit)	M93C46R(08bit)@MLP8
[(SA694)]	
M93C46R(08bit)@MSOP8 [(SA666)]	M93C46R(08bit)@SOIC8
[(SA602A)]	
M93C46R(08bit)@TSSOP8 [(SA026)]	M93C46R
(16bit)	
M93C46R(16bit)@MLP8 [(SA694)]	M93C46R(16bit)@MSOP8

[ (SA666) ]	
M93C46R(16bit)@SOIC8 [ (SA602A) ]	M93C46R(16bit)@TSSOP8
[ (SA026) ]	
M93C46W(08bit)	M93C46W(08bit)@MLP8
[ (SA694) ]	
M93C46W(08bit)@MSOP8 [ (SA666) ]	M93C46W(08bit)@SOIC8
[ (SA602A) ]	
M93C46W(08bit)@TSSOP8 [ (SA026) ]	M93C46W
(16bit)	
M93C46W(16bit)@MLP8 [ (SA694) ]	M93C46W(16bit)@MSOP8
[ (SA666) ]	
M93C46W(16bit)@SOIC8 [ (SA602A) ]	M93C46W(16bit)@TSSOP8
[ (SA026) ]	
M93C56(08bit)	M93C56(08bit)@MLP8
[ (SA694) ]	
M93C56(08bit)@MSOP8 [ (SA666) ]	M93C56(08bit)@SOIC8
[ (SA602A) ]	
M93C56(08bit)@TSSOP8 [ (SA026) ]	M93C56
(16bit)	
M93C56(16bit)@MLP8 [ (SA694) ]	M93C56(16bit)@MSOP8
[ (SA666) ]	
M93C56(16bit)@SOIC8 [ (SA602A) ]	M93C56(16bit)@TSSOP8
[ (SA026) ]	
M93C56R(08bit)	M93C56R(08bit)@MLP8
[ (SA694) ]	
M93C56R(08bit)@MSOP8 [ (SA666) ]	M93C56R(08bit)@SOIC8
[ (SA602A) ]	
M93C56R(08bit)@TSSOP8 [ (SA026) ]	M93C56R
(16bit)	
M93C56R(16bit)@MLP8 [ (SA694) ]	M93C56R(16bit)@MSOP8
[ (SA666) ]	
M93C56R(16bit)@SOIC8 [ (SA602A) ]	M93C56R(16bit)@TSSOP8
[ (SA026) ]	
M93C56W(08bit)	M93C56W(08bit)@MLP8
[ (SA694) ]	
M93C56W(08bit)@MSOP8 [ (SA666) ]	M93C56W(08bit)@SOIC8
[ (SA602A) ]	
M93C56W(08bit)@TSSOP8 [ (SA026) ]	M93C56W
(16bit)	
M93C56W(16bit)@MLP8 [ (SA694) ]	M93C56W(16bit)@MSOP8
[ (SA666) ]	
M93C56W(16bit)@SOIC8 [ (SA602A) ]	M93C56W(16bit)@TSSOP8
[ (SA026) ]	

M93C66(08bit) [(SA694)]	M93C66(08bit)@MLP8
M93C66(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C66(08bit)@SOIC8
M93C66(08bit)@TSSOP8 [(SA026)] (16bit)	M93C66
M93C66(16bit)@MLP8 [(SA694)] [(SA666)]	M93C66(16bit)@MSOP8
M93C66(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C66(16bit)@TSSOP8
M93C66R(08bit) [(SA694)]	M93C66R(08bit)@MLP8
M93C66R(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C66R(08bit)@SOIC8
M93C66R(08bit)@TSSOP8 [(SA026)] (16bit)	M93C66R
M93C66R(16bit)@MLP8 [(SA694)] [(SA666)]	M93C66R(16bit)@MSOP8
M93C66R(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C66R(16bit)@TSSOP8
M93C66W(08bit) [(SA694)]	M93C66W(08bit)@MLP8
M93C66W(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C66W(08bit)@SOIC8
M93C66W(08bit)@TSSOP8 [(SA026)] (16bit)	M93C66W
M93C66W(16bit)@MLP8 [(SA694)] [(SA666)]	M93C66W(16bit)@MSOP8
M93C66W(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C66W(16bit)@TSSOP8
M93C76(08bit) [(SA694)]	M93C76(08bit)@MLP8
M93C76(08bit)@MSOP8 [(SA666)] [(SA602A)]	M93C76(08bit)@SOIC8
M93C76(08bit)@TSSOP8 [(SA026)] (16bit)	M93C76
M93C76(16bit)@MLP8 [(SA694)] [(SA666)]	M93C76(16bit)@MSOP8
M93C76(16bit)@SOIC8 [(SA602A)] [(SA026)]	M93C76(16bit)@TSSOP8
M93C76R(08bit) [(SA694)]	M93C76R(08bit)@MLP8
M93C76R(08bit)@MSOP8 [(SA666)]	M93C76R(08bit)@SOIC8

[ (SA602A) ]	
M93C76R(08bit)@TSSOP8 [ (SA026) ]	M93C76R
(16bit)	
M93C76R(16bit)@MLP8 [ (SA694) ]	M93C76R(16bit)@MSOP8
[ (SA666) ]	
M93C76R(16bit)@SOIC8 [ (SA602A) ]	M93C76R(16bit)@TSSOP8
[ (SA026) ]	
M93C76W(08bit)	M93C76W(08bit)@MLP8
[ (SA694) ]	
M93C76W(08bit)@MSOP8 [ (SA666) ]	M93C76W(08bit)@SOIC8
[ (SA602A) ]	
M93C76W(08bit)@TSSOP8 [ (SA026) ]	M93C76W
(16bit)	
M93C76W(16bit)@MLP8 [ (SA694) ]	M93C76W(16bit)@MSOP8
[ (SA666) ]	
M93C76W(16bit)@SOIC8 [ (SA602A) ]	M93C76W(16bit)@TSSOP8
[ (SA026) ]	
M93C86(08bit)	M93C86(08bit)@MLP8
[ (SA694) ]	
M93C86(08bit)@MSOP8 [ (SA666) ]	M93C86(08bit)@SOIC8
[ (SA602A) ]	
M93C86(08bit)@TSSOP8 [ (SA026) ]	M93C86
(16bit)	
M93C86(16bit)@MLP8 [ (SA694) ]	M93C86(16bit)@MSOP8
[ (SA666) ]	
M93C86(16bit)@SOIC8 [ (SA602A) ]	M93C86(16bit)@TSSOP8
[ (SA026) ]	
M93C86R(08bit)	M93C86R(08bit)@MLP8
[ (SA694) ]	
M93C86R(08bit)@MSOP8 [ (SA666) ]	M93C86R(08bit)@SOIC8
[ (SA602A) ]	
M93C86R(08bit)@TSSOP8 [ (SA026) ]	M93C86R
(16bit)	
M93C86R(16bit)@MLP8 [ (SA694) ]	M93C86R(16bit)@MSOP8
[ (SA666) ]	
M93C86R(16bit)@SOIC8 [ (SA602A) ]	M93C86R(16bit)@TSSOP8
[ (SA026) ]	
M93C86W(08bit)	M93C86W(08bit)@MLP8
[ (SA694) ]	
M93C86W(08bit)@MSOP8 [ (SA666) ]	M93C86W(08bit)@SOIC8
[ (SA602A) ]	
M93C86W(08bit)@TSSOP8 [ (SA026) ]	M93C86W
(16bit)	

M93C86W(16bit)@MLP8 [(SA694)]	M93C86W(16bit)@MSOP8
[(SA666)]	
M93C86W(16bit)@SOIC8 [(SA602A)]	M93C86W(16bit)@TSSOP8
[(SA026)]	
M93CS566	M93CS566@SOIC8
[(SA602A)]	
M93S46	M93S46@SOIC8
[(SA602A)]	
M93S46@TSSOP8 [(SA026)]	
M93S46R	
M93S46R@SOIC8 [(SA602A)]	M93S46R@TSSOP8
[(SA026)]	
M93S46W	M93S46W@SOIC8
[(SA602A)]	
M93S46W@TSSOP8 [(SA026)]	
M93S56	
M93S56@SOIC8 [(SA602A)]	M93S56@TSSOP8
[(SA026)]	
M93S56R	M93S56R@SOIC8
[(SA602A)]	
M93S56R@TSSOP8 [(SA026)]	
M93S56W	
M93S56W@SOIC8 [(SA602A)]	M93S56W@TSSOP8
[(SA026)]	
M93S66	M93S66@SOIC8
[(SA602A)]	
M93S66@TSSOP8 [(SA026)]	
M93S66R	
M93S66R@SOIC8 [(SA602A)]	M93S66R@TSSOP8
[(SA026)]	
M93S66W	M93S66W@SOIC8
[(SA602A)]	
M93S66W@TSSOP8 [(SA026)]	
M95010	
M95010(ISP) [ISP-HEADER01]	M95010@SOIC8
[(SA602A)]	
M95010@SOIC8(ISP) [ISP-HEADER01]	M95010@TSSOP8
[(SA026)]	
M95010@TSSOP8(ISP) [ISP-HEADER01]	
M95020	M95020(ISP) [ISP-
HEADER01]	
M95020@SOIC8 [(SA602A)]	M95020@SOIC8(ISP) [ISP-
HEADER01]	

M95020@TSSOP8 [(SA026)]  
M95020@TSSOP8(ISP) [ISP-HEADER01]  
M95040 M95040(ISP) [ISP-  
HEADER01]  
M95040@SOIC8 [(SA602A)] M95040@SOIC8(ISP) [ISP-  
HEADER01]  
M95040@TSSOP8 [(SA026)]  
M95040@TSSOP8(ISP) [ISP-HEADER01]  
M95080 M95080(ISP) [ISP-  
HEADER01]  
M95080@SOIC8 [(SA602A)] M95080@SOIC8(ISP) [ISP-  
HEADER01]  
M95080@TSSOP14 [(SA026)]  
M95080@TSSOP14(ISP) [ISP-HEADER01]  
M95080@TSSOP8 [(SA026)]  
M95080@TSSOP8(ISP) [ISP-HEADER01]  
M95128 M95128(ISP) [ISP-  
HEADER01]  
M95128@TSSOP14 [(SA026)]  
M95128@TSSOP14(ISP) [ISP-HEADER01]  
M95128@TSSOP8 [(SA026)]  
M95128@TSSOP8(ISP) [ISP-HEADER01]  
M95128[150mil]@SOIC8 [(SA602A)]  
M95128[150mil]@SOIC8(ISP) [ISP-HEADER01]  
M95128[200mil]@SOIC8 [(SA023A)]  
M95128[200mil]@SOIC8(ISP) [ISP-HEADER01]  
M95160 M95160(ISP) [ISP-  
HEADER01]  
M95160@SOIC8 [(SA602A)] M95160@SOIC8(ISP) [ISP-  
HEADER01]  
M95160@TSSOP14 [(SA026)]  
M95160@TSSOP14(ISP) [ISP-HEADER01]  
M95160@TSSOP8 [(SA026)]  
M95160@TSSOP8(ISP) [ISP-HEADER01]  
M95256 M95256(ISP) [ISP-  
HEADER01]  
M95256@TSSOP14 [(SA026)]  
M95256@TSSOP14(ISP) [ISP-HEADER01]  
M95256@TSSOP8 [(SA026)]  
M95256@TSSOP8(ISP) [ISP-HEADER01]  
M95256[150mil]@SOIC8 [(SA602A)]  
M95256[150mil]@SOIC8(ISP) [ISP-HEADER01]  
M95256[200mil]@SOIC8 [(SA023A)]



M95256[200mil]@SOIC8(ISP) [ISP-HEADER01]  
M95320 M95320(ISP) [ISP-  
HEADER01]  
M95320@SOIC8 [(SA602A)] M95320@SOIC8(ISP) [ISP-  
HEADER01]  
M95320@TSSOP14 [(SA026)]  
M95320@TSSOP14(ISP) [ISP-HEADER01]  
M95320@TSSOP8 [(SA026)]  
M95320@TSSOP8(ISP) [ISP-HEADER01]  
M95512@SOIC8 [(SA602A)] M95512@SOIC8(ISP) [ISP-  
HEADER01]  
M95512@TSSOP8 [(SA026)]  
M95512@TSSOP8(ISP) [ISP-HEADER01]  
M95640 M95640(ISP) [ISP-  
HEADER01]  
M95640@SOIC8 [(SA602A)] M95640@SOIC8(ISP) [ISP-  
HEADER01]  
M95640@TSSOP14 [(SA026)]  
M95640@TSSOP14(ISP) [ISP-HEADER01]  
M95640@TSSOP8 [(SA026)]  
M95640@TSSOP8(ISP) [ISP-HEADER01]  
M95M01[150mil]@SOIC8 [(SA602A)]  
M95P02  
M95P02@SOIC8 [(SA602A)]  
M95P04  
M95P04@SOIC8 [(SA602A)]  
M95P08  
M95P08@SOIC8 [(SA602A)]  
MK48C02  
MK48C02B  
MK48C12  
MK48C12B  
MK48T02  
MK48T02B  
MK48T08  
MK48T12  
MK48T12B  
MK48T18  
MK48T32  
MK48T32Y  
MK48T35  
MK48T35@SOIC28 [(SA630)]  
MK48T35Y

MK48T35Y@SOIC28 [(SA630)]  
MK48T512V  
MK48T512Y  
MK48Z02  
MK48Z02B  
MK48Z08  
MK48Z12  
MK48Z12B  
MK48Z18  
MK48Z32  
MK48Z32Y  
MK48Z35  
MK48Z35@SOIC28 [(SA630)]  
MK48Z35Y  
MK48Z35Y@SOIC28 [(SA630)]  
MK48Z512V  
MK48Z512Y  
MKI48Z02  
MKI48Z02B  
MKI48Z12  
MKI48Z12B  
MKI48Z18  
NAND01GR3B2BZA6@FBGA63 [(SA642KK-B280-W048F001Y)]  
NAND01GW3A0AN6@TSOP48 [(SA247-B005)]  
NAND01GW3B2AN6E@TSOP48 [(SA247-B005)]  
NAND01GW3B2BN6E@TSOP48 [(SA247-B005)]  
NAND01GW3B2BZA6@FBGA63 [(SA642KK-B026-W048F001Y)]  
NAND01GW3M2AZC5E@FBGA137 [(SA700E-B153A-M137F001Y)]  
NAND02GR3B2CZA6E@FBGA63 [(SA642NN-B026A-W063F001Y)]  
NAND02GW3B2AN6@TSOP48 [(SA247-B005)]  
NAND02GW3B2CN6@TSOP48 [(SA247-B005)]  
NAND02GW3B2CZA6E@FBGA63 [(SA642NN-B026A-W063F001Y)]  
NAND04GW3B2BN6@TSOP48 [(SA247-B005)]  
NAND04GW3C2AN1@TSOP48 [(SA247-B005)]  
NAND08GW3B2AN6@TSOP48 [(SA247-B005)]  
NAND128W3A0AN6@TSOP48 [(SA247-B005)]  
NAND128W3A2BN6@TSOP48 [(SA247-B005)]  
NAND256R3A2AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
NAND256R3A2BZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
NAND256W3A0AN6@TSOP48 [(SA247-B005)]  
NAND256W3A0AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
NAND256W3A2AZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
NAND256W3A2BN6@TSOP48 [(SA247-B005)]

NAND256W3A2BZA6E@VFBGA55 [(SA642R-B026-T096F001Y)]  
 NAND512R3A2AZB6@TFBGA63 [(SA642KK-B026-W048F001Y)]  
 NAND512R3A2AZB6E@TFBGA55 [(SA642R-B026-T096F001Y)]  
 NAND512R3A2CZA6E@TFBGA63 [(SA642KK-B026-W048F001Y)]  
 NAND512R3M0AZB5@FBGA107 [(SA642V-B133-T096F001Y)]  
 NAND512W3A0AN6@TSOP48 [(SA247-B005)]  
 NAND512W3A2BN6@TSOP48 [(SA247-B005)]  
 NAND512W3A2CN6@TSOP48 [(SA247-B005)]  
 NAND512W3A2CZA6E@TFBGA63 [(SA642KK-B026-W048F001Y)]  
 NAND98R3M0AZBB5@FBGA107 [(SA642V-B133-T096F001Y)]  
 NAND99R4M2AZBA5@BGA149 [(SA664G-B279-Y149F001Y)]  
 NANDA9R4N2AZBA5@FBGA149 [(SA664G-B279-Y149F001Y)]  
 NANDC9R4N0AZBA5E@FBGA149 [(SA664G-B279-Y149F001Y)]  
 ST24C01 ST24C01@SOIC8  
 [(SA602A)]  
 ST24C02A ST24C02A@SOIC8  
 [(SA602A)]  
 ST24C16 ST24C16@SOIC8  
 [(SA602A)]  
 ST24FC21 ST24FC21@SOIC8  
 [(SA602A)]  
 ST24FW21 ST24FW21@SOIC8  
 [(SA602A)]  
 ST24LC21B ST24LC21B@SOIC8  
 [(SA602A)]  
 ST24LW21 ST24LW21@SOIC8  
 [(SA602A)]  
 ST24W01 ST24W01@SOIC8  
 [(SA602A)]  
 ST24W02 ST24W02@SOIC8  
 [(SA602A)]  
 ST24W04C ST24W04C@SOIC8  
 [(SA602A)]  
 ST26C201 ST26C201@PLCC32  
 [(SA015A1T)]  
 ST26C201@TSOP32 [(SA410T)]  
 ST27128A  
 ST27256  
 ST2764A  
 ST27C256 ST93C06  
 (08bit)  
 ST93C06(08bit)@SOIC8 [(SA602A)] ST93C06  
 (16bit)

ST93C06(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C46
ST93C46(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C46
ST93C46(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C46A
ST93C46A(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C46A
ST93C46A(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C46C
ST93C46C(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C46C
ST93C46C(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C46T
ST93C46T(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C46T
ST93C46T(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C47C
ST93C47C(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C47C
ST93C47C(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C47T
ST93C47T(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C47T
ST93C47T(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C56
ST93C56(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C56
ST93C56(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C56B
ST93C56B(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C56B
ST93C56B(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C56C
ST93C56C(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C56C
ST93C56C(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C57C
ST93C57C(08bit)@SOIC8 [(SA602A)] (16bit)	ST93C57C
ST93C57C(16bit)@SOIC8 [(SA602A)] (08bit)	ST93C66
ST93C66(08bit)@SOIC8 [(SA602A)]	ST93C66

(16bit)	
ST93C66(16bit)@SOIC8 [(SA602A)]	ST93C67
(08bit)	
ST93C67(08bit)@SOIC8 [(SA602A)]	ST93C67
(16bit)	
ST93C67(16bit)@SOIC8 [(SA602A)]	ST93C76
(08bit)	
ST93C76(08bit)@SOIC8 [(SA602A)]	ST93C76
(16bit)	
ST93C76(16bit)@SOIC8 [(SA602A)]	ST93C86
(08bit)	
ST93C86(08bit)@SOIC8 [(SA602A)]	ST93C86
(16bit)	
ST93C86(16bit)@SOIC8 [(SA602A)]	
ST93CS46	
ST93CS46@SOIC8 [(SA602A)]	
ST93CS47	
ST93CS47@SOIC8 [(SA602A)]	
ST93CS56	
ST93CS56@SOIC8 [(SA602A)]	
ST93CS566	
ST93CS566@SOIC8 [(SA602A)]	
ST93CS57	
ST93CS57@SOIC8 [(SA602A)]	
ST93CS66	
ST93CS66@SOIC14 [(SA602)]	
ST93CS67	
ST93CS67@SOIC14 [(SA602)]	
TS27C256	
TS27C64	TS27C64@PLCC32
[(SA015A1T)]	
TS27C64A	TS27C64A@PLCC32
[(SA015A1T)]	
TS28C16A	
TS28C17A	

## MICROCONTROLLER

PSD813F1@TQFP52(*) [(TA071+B006)]
PSD813F1V@TQFP52(*) [(TA071+B006)]
PSD813F2@TQFP52(*) [(TA071+B006)]
PSD813F2V@TQFP52(*) [(TA071+B006)]

PSD813F3@TQFP52(*) [(TA071+B006)]	
PSD813F3V@TQFP52(*) [(TA071+B006)]	
PSD813F4@TQFP52(*) [(TA071+B006)]	
PSD813F4V@TQFP52(*) [(TA071+B006)]	
PSD813F5@TQFP52(*) [(TA071+B006)]	
PSD813F5V@TQFP52(*) [(TA071+B006)]	
PSD833F2@TQFP52(*) [(TA071+B006)]	
PSD833F2V@TQFP52(*) [(TA071+B006)]	
PSD853F2@TQFP52(*) [(TA071+B006)]	
PSD853F2V@TQFP52(*) [(TA071+B006)]	
ST62E01	ST62E01@SOIC16
[(SA404)]	
ST62E01CF1	
ST62E18CF1	
ST62E20	ST62E20@SOIC20
[(SA404)]	
ST62E20CF1	
ST62E25	
ST62E25@SOIC28 [(SA404)]	
ST62E25CF1	
ST62E28CF1	
ST62E30BF1	
ST62E32BF1@SDIP42 [(SA028)]	
ST62E60B	
ST62E60B@SOIC20 [(SA404)]	
ST62E62CF1	
ST62E65B	ST62E65B@SOIC28
[(SA404)]	
ST62E65CF1	
ST62T00	
ST62T00@SOIC16 [(SA404)]	ST62T00C
(B6)	
ST62T00C(M6)@SOIC16 [(SA404)]	ST62T00C(N6)@SSOP16
[(SA626A)]	
ST62T01	ST62T01@SOIC16
[(SA404)]	
ST62T01C(B3)	ST62T01C
(B6)	
ST62T01C(M3)@SOIC16 [(SA404)]	ST62T01C(M6)@SOIC16
[(SA404)]	
ST62T01C(N3)@SSOP16 [(SA626A)]	ST62T01C(N6)@SSOP16
[(SA626A)]	
ST62T03	ST62T03@SOIC16

[ (SA404) ]	
ST62T03C(B6)	ST62T03C(M3)@SOIC16
[ (SA404) ]	
ST62T03C(M6)@SOIC16 [ (SA404) ]	ST62T03C(N6)@SSOP16
[ (SA626A) ]	
ST62T08	ST62T08@SOIC20
[ (SA404) ]	
ST62T08C(B6)	ST62T08C(M6)@SOIC20
[ (SA404) ]	
ST62T09	ST62T09@SOIC20
[ (SA404) ]	
ST62T09C(B3)	ST62T09C
(B6)	
ST62T09C(M3)@SOIC20 [ (SA404) ]	ST62T09C(M6)@SOIC20
[ (SA404) ]	
ST62T10	ST62T10@SOIC20
[ (SA404) ]	
ST62T10C(B6)	ST62T10C(M6)@SOIC20
[ (SA404) ]	
ST62T15	ST62T15@SOIC28
[ (SA404) ]	
ST62T15C(B6)	ST62T15C(M6)@SOIC28
[ (SA404) ]	
ST62T18C(B6)	ST62T18C(M3)@SOIC20
[ (SA404) ]	
ST62T18C(M6)@SOIC20 [ (SA404) ]	
ST62T20	
ST62T20@SOIC20 [ (SA404) ]	ST62T20C
(B3)	
ST62T20C(B6)	ST62T20C(M3)@SOIC20
[ (SA404) ]	
ST62T20C(M6)@SOIC20 [ (SA404) ]	
ST62T25	
ST62T25@SOIC28 [ (SA404) ]	ST62T25C
(B3)	
ST62T25C(B6)	ST62T25C(M3)@SOIC28
[ (SA404) ]	
ST62T25C(M6)@SOIC28 [ (SA404) ]	ST62T25C(N6)@SSOP28
[ (SA626A) ]	
ST62T28C(B6)	ST62T28C(M3)@SOIC28
[ (SA404) ]	
ST62T28C(M6)@SOIC28 [ (SA404) ]	ST62T28C(N6)@SSOP28
[ (SA626A) ]	

ST62T30B(B3)	ST62T30B
(B6)	
ST62T30B(M6)@SOIC28 [(SA404)]	ST62T32B(B6)@SDIP42
[(SA028)]	
ST62T52C(B6)	ST62T52C(M3)@SOIC16
[(SA404)]	
ST62T52C(M6)@SOIC16 [(SA404)]	ST62T52C(N3)@SSOP16
[(SA626A)]	
ST62T52C(N6)@SSOP16 [(SA626A)]	
ST62T53B	
ST62T53B@SOIC20 [(SA404)]	ST62T53C
(B6)	
ST62T53C(M6)@SOIC20 [(SA404)]	ST62T55C
(B6)	
ST62T55C(M6)@SOIC28 [(SA404)]	ST62T55C(N6)@SSOP28
[(SA626A)]	
ST62T60B	ST62T60B@SOIC20
[(SA404)]	
ST62T60C6	ST62T62C
(B6)	
ST62T62C(M3)@SOIC16 [(SA404)]	ST62T62C(M6)@SOIC16
[(SA404)]	
ST62T62C(N3)@SSOP16 [(SA626A)]	ST62T62C(N6)@SSOP16
[(SA626A)]	
ST62T63B	ST62T63B@SOIC20
[(SA404)]	
ST62T63C(B6)	ST62T63C(M6)@SOIC20
[(SA404)]	
ST62T65B	ST62T65B@SOIC28
[(SA404)]	
ST62T65C(B3)	ST62T65C
(B6)	
ST62T65C(M3)@SOIC28 [(SA404)]	ST62T65C(M6)@SOIC28
[(SA404)]	
ST62T65C(N6)@SSOP28 [(SA626A)]	ST63E73@SDIP42
[(SA028)]	
ST63T73@SDIP42 [(SA028)]	ST72C104G1B@SDIP32
[(SA653)]	
ST72C104G1M@SOIC28 [(SA404)]	ST72C104G2B@SDIP32
[(SA653)]	
ST72C104G2M@SOIC28 [(SA404)]	ST72C124J2B@SDIP42
[(SA028)]	
ST72C124J2T@TQFP44 [(SA245A)]	ST72C124J4B@SDIP42



[ (SA028) ]	
ST72C124J4T@TQFP44 [ (SA245A) ]	ST72C215G1B@SDIP32
[ (SA653) ]	
ST72C215G1M@SOIC28 [ (SA404) ]	ST72C215G2B@SDIP32
[ (SA653) ]	
ST72C215G2M@SOIC28 [ (SA404) ]	ST72C216G1B@SDIP32
[ (SA653) ]	
ST72C216G1M@SOIC28 [ (SA404) ]	ST72C216G2B@SDIP32
[ (SA653) ]	
ST72C216G2M@SOIC28 [ (SA404) ]	ST72C254G1B@SDIP32
[ (SA653) ]	
ST72C254G1M@SOIC28 [ (SA404) ]	ST72C254G2B@SDIP32
[ (SA653) ]	
ST72C254G2M@SOIC28 [ (SA404) ]	ST72C314J2B@SDIP42
[ (SA028) ]	
ST72C314J2T@TQFP44 [ (SA245A) ]	ST72C314J4B@SDIP42
[ (SA028) ]	
ST72C314J4T@TQFP44 [ (SA245A) ]	ST72C334J2B@SDIP42
[ (SA028) ]	
ST72C334J2T@TQFP44 [ (SA245A) ]	ST72C334J4B@SDIP42
[ (SA028) ]	
ST72C334J4T@TQFP44 [ (SA245A) ]	ST72F260G1B6@SDIP32
[ (SA653) ]	
ST72F260G1M6@SOIC28 [ (SA404) ]	ST72F262G1B6@SDIP32
[ (SA653) ]	
ST72F262G1M6@SOIC28 [ (SA404) ]	ST72F262G2B6@SDIP32
[ (SA653) ]	
ST72F262G2M6@SOIC28 [ (SA404) ]	ST72F264G1B6@SDIP32
[ (SA653) ]	
ST72F264G1M6@SOIC28 [ (SA404) ]	ST72F264G2B6@SDIP32
[ (SA653) ]	
ST72F264G2H1@LFBGA36 [ (SA642G-B026A-T048F001N) ]	
ST72F264G2H6@LFBGA36 [ (SA642G-B026A-T048F001N) ]	
ST72F264G2M6@SOIC28 [ (SA404) ]	ST72F321BJ7T6@TQFP44
[ (SA245A) ]	
ST72F321BJ7TA@TQFP44 [ (SA245A) ]	ST72F321BJ9T6@TQFP44
[ (SA245A) ]	
ST72F321BJ9TA@TQFP44 [ (SA245A) ]	ST72F321BJ9TC@TQFP44
[ (SA245A) ]	
ST72F321J7T6@TQFP44 [ (SA245A) ]	ST72F321J7TA@TQFP44
[ (SA245A) ]	
ST72F321J9T6@TQFP44 [ (SA245A) ]	ST72F321J9TA@TQFP44
[ (SA245A) ]	

ST72F321J9TC@TQFP44 [(SA245A)]	ST72F324BJ2B5@SDIP42
[(SA028)]	
ST72F324BJ2B6@SDIP42 [(SA028)]	ST72F324BJ2T3@TQFP44
[(SA245A)]	
ST72F324BJ2T5@TQFP44 [(SA245A)]	ST72F324BJ2T6@TQFP44
[(SA245A)]	
ST72F324BJ4B5@SDIP42 [(SA028)]	ST72F324BJ4B6@SDIP42
[(SA028)]	
ST72F324BJ4T3@TQFP44 [(SA245A)]	ST72F324BJ4T6@TQFP44
[(SA245A)]	
ST72F324BJ6B5@SDIP42 [(SA028)]	ST72F324BJ6B6@SDIP42
[(SA028)]	
ST72F324BJ6T3@TQFP44 [(SA245A)]	ST72F324BJ6T6@TQFP44
[(SA245A)]	
ST72F324BK2B5@SDIP32 [(SA653)]	ST72F324BK2B6@SDIP32
[(SA653)]	
ST72F324BK2T3@TQFP32 [(SA663)]	ST72F324BK2T5@TQFP32
[(SA663)]	
ST72F324BK2T6@TQFP32 [(SA663)]	ST72F324BK4B5@SDIP32
[(SA653)]	
ST72F324BK4B6@SDIP32 [(SA653)]	ST72F324BK4T3@TQFP32
[(SA663)]	
ST72F324BK4T6@TQFP32 [(SA663)]	ST72F324BK6B5@SDIP32
[(SA653)]	
ST72F324BK6B6@SDIP32 [(SA653)]	ST72F324BK6T3@TQFP32
[(SA663)]	
ST72F324BK6T6@TQFP32 [(SA663)]	ST72F324J2B5@SDIP42
[(SA028)]	
ST72F324J2B5@SDIP42(ISP) [ISP-HEADER01]	
ST72F324J2T6@TQFP44 [(SA245A)]	
ST72F324J2T6@TQFP44(ISP) [ISP-HEADER01]	
ST72F324J2TA@TQFP44 [(SA245A)]	
ST72F324J2TA@TQFP44(ISP) [ISP-HEADER01]	
ST72F324J4B5@SDIP42 [(SA028)]	
ST72F324J4B5@SDIP42(ISP) [ISP-HEADER01]	
ST72F324J4T6@TQFP44 [(SA245A)]	
ST72F324J4T6@TQFP44(ISP) [ISP-HEADER01]	
ST72F324J4TA@TQFP44 [(SA245A)]	
ST72F324J4TA@TQFP44(ISP) [ISP-HEADER01]	
ST72F324J6B5@SDIP42 [(SA028)]	
ST72F324J6B5@SDIP42(ISP) [ISP-HEADER01]	
ST72F324J6T3@TQFP44 [(SA245A)]	
ST72F324J6T3@TQFP44(ISP) [ISP-HEADER01]	

ST72F324J6T5@TQFP44 [(SA245A)]  
ST72F324J6T5@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J6T6@TQFP44 [(SA245A)]  
ST72F324J6T6@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J6TA@TQFP44 [(SA245A)]  
ST72F324J6TA@TQFP44(ISP) [ISP-HEADER01]  
ST72F324J6TC@TQFP44 [(SA245A)]  
ST72F324J6TC@TQFP44(ISP) [ISP-HEADER01]  
ST72F324K2B5@SDIP32 [(SA653)]  
ST72F324K2B5@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K2B6@SDIP32 [(SA653)]  
ST72F324K2B6@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K2T6@TQFP32 [(SA663)]  
ST72F324K2T6@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K2TA@TQFP32 [(SA663)]  
ST72F324K2TA@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K4B5@SDIP32 [(SA653)]  
ST72F324K4B5@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K4B6@SDIP32 [(SA653)]  
ST72F324K4B6@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K4T6@TQFP32 [(SA663)]  
ST72F324K4T6@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K4TA@TQFP32 [(SA663)]  
ST72F324K4TA@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K6B5@SDIP32 [(SA653)]  
ST72F324K6B5@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K6B6@SDIP32 [(SA653)]  
ST72F324K6B6@SDIP32(ISP) [ISP-HEADER01]  
ST72F324K6T5@TQFP32 [(SA663)]  
ST72F324K6T5@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K6T6@TQFP32 [(SA663)]  
ST72F324K6T6@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K6TA@TQFP32 [(SA663)]  
ST72F324K6TA@TQFP32(ISP) [ISP-HEADER01]  
ST72F324K6TC@TQFP32 [(SA663)]  
ST72F324K6TC@TQFP32(ISP) [ISP-HEADER01]  
ST72F324LJ2T5@TQFP44 [(SA245A)]  
ST72F324LJ2T5@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LJ2T6@TQFP44 [(SA245A)]  
ST72F324LJ2T6@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LJ4T5@TQFP44 [(SA245A)]  
ST72F324LJ4T5@TQFP44(ISP) [ISP-HEADER01]  
ST72F324LJ4T6@TQFP44 [(SA245A)]

ST72F324LJ4T6@TQFP44 (ISP) [ISP-HEADER01]  
ST72F324LJ6T5@TQFP44 [(SA245A)]  
ST72F324LJ6T5@TQFP44 (ISP) [ISP-HEADER01]  
ST72F324LJ6T6@TQFP44 [(SA245A)]  
ST72F324LJ6T6@TQFP44 (ISP) [ISP-HEADER01]  
ST72F324LJ6TA@TQFP44 [(SA245A)]  
ST72F324LJ6TA@TQFP44 (ISP) [ISP-HEADER01]  
ST72F324LK2T5@TQFP32 [(SA663)]  
ST72F324LK2T5@TQFP32 (ISP) [ISP-HEADER01]  
ST72F324LK2T6@TQFP32 [(SA663)]  
ST72F324LK2T6@TQFP32 (ISP) [ISP-HEADER01]  
ST72F324LK4T5@TQFP32 [(SA663)]  
ST72F324LK4T5@TQFP32 (ISP) [ISP-HEADER01]  
ST72F324LK4T6@TQFP32 [(SA663)]  
ST72F324LK4T6@TQFP32 (ISP) [ISP-HEADER01]  
ST72F324LK6B5@SDIP32 [(SA653)]  
ST72F324LK6B5@SDIP32 (ISP) [ISP-HEADER01]  
ST72F324LK6T5@TQFP32 [(SA663)]  
ST72F324LK6T5@TQFP32 (ISP) [ISP-HEADER01]  
ST72F324LK6T6@TQFP32 [(SA663)]  
ST72F324LK6T6@TQFP32 (ISP) [ISP-HEADER01]  
ST72F324LK6TA@TQFP32 [(SA663)]  
ST72F324LK6TA@TQFP32 (ISP) [ISP-HEADER01]  
ST72F325C4T6@TQFP48 [(SA248)] ST72F325C6T6@TQFP48  
[(SA248)]  
ST72F325C7T6@TQFP48 [(SA248)] ST72F325C9T6@TQFP48  
[(SA248)]  
ST72F325J4T6@TQFP44 [(SA245A)] ST72F325J6B5@SDIP42  
[(SA028)]  
ST72F325J6B6@SDIP42 [(SA028)]  
ST72F325J6B6@SDIP42 (ISP) [ISP-HEADER01]  
ST72F325J6T6@TQFP44 [(SA245A)] ST72F325J7T6@TQFP44  
[(SA245A)]  
ST72F325J9T6@TQFP44 [(SA245A)] ST72F325K4B5@SDIP32  
[(SA653)]  
ST72F325K4T6@TQFP32 [(SA663)] ST72F325K6B5@SDIP32  
[(SA653)]  
ST72F325K6B6@SDIP32 [(SA653)]  
ST72F325K6B6@SDIP32 (ISP) [ISP-HEADER01]  
ST72F325K6T6@TQFP32 [(SA663)] ST72F32AJ1B5@SDIP42  
[(SA028)]  
ST72F32AJ1B6@SDIP42 [(SA028)] ST72F32AJ1T5@TQFP44  
[(SA245A)]

ST72F32AJ1T6@TQFP44 [(SA245A)]	ST72F32AJ2B5@SDIP42
[(SA028)]	
ST72F32AJ2B6@SDIP42 [(SA028)]	ST72F32AJ2T5@TQFP44
[(SA245A)]	
ST72F32AJ2T6@TQFP44 [(SA245A)]	ST72F32AJ2TA@TQFP44
[(SA245A)]	
ST72F32AJ2TB@TQFP44 [(SA245A)]	ST72F32AJ2TC@TQFP44
[(SA245A)]	
ST72F32AK1B5@SDIP32 [(SA653)]	ST72F32AK1B6@SDIP32
[(SA653)]	
ST72F32AK1T5@TQFP32 [(SA663)]	ST72F32AK1T6@TQFP32
[(SA663)]	
ST72F32AK2B5@SDIP32 [(SA653)]	ST72F32AK2B6@SDIP32
[(SA653)]	
ST72F32AK2T5@TQFP32 [(SA663)]	ST72F32AK2T6@TQFP32
[(SA663)]	
ST72F32AK2TA@TQFP32 [(SA663)]	ST72F32AK2TB@TQFP32
[(SA663)]	
ST72F32AK2TC@TQFP32 [(SA663)]	ST72F361K4T3@TQFP32
[(SA663)]	
ST72F361K4T6@TQFP32 [(SA663)]	ST72F361K4TA@TQFP32
[(SA663)]	
ST72F361K4TC@TQFP32 [(SA663)]	ST72F361K6T3@TQFP32
[(SA663)]	
ST72F361K6T6@TQFP32 [(SA663)]	ST72F361K6TA@TQFP32
[(SA663)]	
ST72F361K6TC@TQFP32 [(SA663)]	ST72F361K7T3@TQFP32
[(SA663)]	
ST72F361K7T6@TQFP32 [(SA663)]	ST72F361K7TA@TQFP32
[(SA663)]	
ST72F361K7TC@TQFP32 [(SA663)]	ST72F361K9T3@TQFP32
[(SA663)]	
ST72F361K9T6@TQFP32 [(SA663)]	ST72F361K9TA@TQFP32
[(SA663)]	
ST72F361K9TC@TQFP32 [(SA663)]	ST72F561J4T3@TQFP44
[(SA245A)]	
ST72F561J4T6@TQFP44 [(SA245A)]	ST72F561J4TA@TQFP44
[(SA245A)]	
ST72F561J4TC@TQFP44 [(SA245A)]	ST72F561J6T3@TQFP44
[(SA245A)]	
ST72F561J6T6@TQFP44 [(SA245A)]	ST72F561J6TA@TQFP44
[(SA245A)]	
ST72F561J6TC@TQFP44 [(SA245A)]	ST72F561J7T3@TQFP44

[(SA245A)]  
 ST72F561J7T6@TQFP44 [(SA245A)] ST72F561J7TA@TQFP44  
 [(SA245A)]  
 ST72F561J7TC@TQFP44 [(SA245A)] ST72F561J9T3@TQFP44  
 [(SA245A)]  
 ST72F561J9T6@TQFP44 [(SA245A)] ST72F561J9TA@TQFP44  
 [(SA245A)]  
 ST72F561J9TC@TQFP44 [(SA245A)] ST72F561K4T3@TQFP32  
 [(SA663)]  
 ST72F561K4T6@TQFP32 [(SA663)] ST72F561K4TA@TQFP32  
 [(SA663)]  
 ST72F561K4TC@TQFP32 [(SA663)] ST72F561K6T3@TQFP32  
 [(SA663)]  
 ST72F561K6T6@TQFP32 [(SA663)] ST72F561K6TA@TQFP32  
 [(SA663)]  
 ST72F561K6TC@TQFP32 [(SA663)] ST72F561K7T3@TQFP32  
 [(SA663)]  
 ST72F561K7T6@TQFP32 [(SA663)] ST72F561K7TA@TQFP32  
 [(SA663)]  
 ST72F561K7TC@TQFP32 [(SA663)] ST72F561K9T3@TQFP32  
 [(SA663)]  
 ST72F561K9T6@TQFP32 [(SA663)] ST72F561K9TA@TQFP32  
 [(SA663)]  
 ST72F561K9TC@TQFP32 [(SA663)] ST72F60D4U1@QFN40  
 [(SA750)]  
 ST72F60D4U1@QFN40 (ISP) [ISP-HEADER01]  
 ST72F60D6U1@QFN40 [(SA750)]  
 ST72F60D6U1@QFN40 (ISP) [ISP-HEADER01]  
 ST72F60E1M1@SOIC24 [(SA404)]  
 ST72F60E1M1@SOIC24 (ISP) [ISP-HEADER01]  
 ST72F60E2M1@SOIC24 [(SA404)]  
 ST72F60E2M1@SOIC24 (ISP) [ISP-HEADER01]  
 ST72F60E4M1@SOIC24 [(SA404)]  
 ST72F60E4M1@SOIC24 (ISP) [ISP-HEADER01]  
 ST72F60E6M1@SOIC24 [(SA404)]  
 ST72F60E6M1@SOIC24 (ISP) [ISP-HEADER01]  
 ST72F60K1U1@QFN40 [(SA750)]  
 ST72F60K1U1@QFN40 (ISP) [ISP-HEADER01]  
 ST72F60K2U1@QFN40 [(SA750)]  
 ST72F60K2U1@QFN40 (ISP) [ISP-HEADER01]  
 ST72F621J4B1@SDIP42 [(SA028)] ST72F621J4T1@TQFP44  
 [(SA245A)]  
 ST72F621K4B1@SDIP32 [(SA653)] ST72F621L4M1@SOIC34

[ (SA658) ]  
ST72F622L2M1@SOIC34 [ (SA658) ]  
ST72F623F2B1  
ST72F623F2M1@SOIC20 [ (SA404) ] ST72F63BD4U1@QFN40  
[ (SA750) ]  
ST72F63BD4U1@QFN40(ISP) [ ISP-HEADER01 ]  
ST72F63BD6U1@QFN40 [ (SA750) ]  
ST72F63BD6U1@QFN40(ISP) [ ISP-HEADER01 ]  
ST72F63BE1M1@SOP24 [ (SA404) ]  
ST72F63BE1M1@SOP24(ISP) [ ISP-HEADER01 ]  
ST72F63BE2M1@SOP24 [ (SA404) ]  
ST72F63BE2M1@SOP24(ISP) [ ISP-HEADER01 ]  
ST72F63BE4M1@SOP24 [ (SA404) ]  
ST72F63BE4M1@SOP24(ISP) [ ISP-HEADER01 ]  
ST72F63BE6M1@SOP24 [ (SA404) ]  
ST72F63BE6M1@SOP24(ISP) [ ISP-HEADER01 ]  
ST72F63BH1T1@QFP48 [ (SA248) ]  
ST72F63BH1T1@QFP48(ISP) [ ISP-HEADER01 ]  
ST72F63BH2T1@QFP48 [ (SA248) ]  
ST72F63BH2T1@QFP48(ISP) [ ISP-HEADER01 ]  
ST72F63BH4T1@QFP48 [ (SA248) ]  
ST72F63BH4T1@QFP48(ISP) [ ISP-HEADER01 ]  
ST72F63BH6T1@QFP48 [ (SA248) ]  
ST72F63BH6T1@QFP48(ISP) [ ISP-HEADER01 ]  
ST72F63BK1B1@SOIC34 [ (SA653) ]  
ST72F63BK1B1@SOIC34(ISP) [ ISP-HEADER01 ]  
ST72F63BK1M1@SOIC34 [ (SA658) ]  
ST72F63BK1M1@SOIC34(ISP) [ ISP-HEADER01 ]  
ST72F63BK1U1@QFN40 [ (SA750) ]  
ST72F63BK1U1@QFN40(ISP) [ ISP-HEADER01 ]  
ST72F63BK2B1@SOIC34 [ (SA653) ]  
ST72F63BK2B1@SOIC34(ISP) [ ISP-HEADER01 ]  
ST72F63BK2M1@SOIC34 [ (SA658) ]  
ST72F63BK2M1@SOIC34(ISP) [ ISP-HEADER01 ]  
ST72F63BK2U1@QFN40 [ (SA750) ]  
ST72F63BK2U1@QFN40(ISP) [ ISP-HEADER01 ]  
ST72F63BK4B1@SOIC34 [ (SA653) ]  
ST72F63BK4B1@SOIC34(ISP) [ ISP-HEADER01 ]  
ST72F63BK4M1@SOIC34 [ (SA658) ]  
ST72F63BK4M1@SOIC34(ISP) [ ISP-HEADER01 ]  
ST72F63BK6B1@SOIC34 [ (SA653) ]  
ST72F63BK6B1@SOIC34(ISP) [ ISP-HEADER01 ]  
ST72F63BK6M1@SOIC34 [ (SA658) ]

ST72F63BK6M1@SOIC34(ISP) [ISP-HEADER01]  
ST72T101G1B@SDIP32 [(SA653)] ST72T101G1M@SOIC28  
[(SA404)]  
ST72T101G2B@SDIP32 [(SA653)] ST72T101G2M@SOIC28  
[(SA404)]  
ST72T121J2B@SDIP42 [(SA028)] ST72T121J2T@TQFP44  
[(SA245A)]  
ST72T121J4B@SDIP42 [(SA028)] ST72T121J4T@TQFP44  
[(SA245A)]  
ST72T141K2B@SDIP32 [(SA653)] ST72T141K2M@SSOP34  
[(SA658)]  
ST72T212G2B@SDIP32 [(SA653)] ST72T212G2M@SOIC28  
[(SA404)]  
ST72T213G1B@SDIP32 [(SA653)] ST72T213G1M@SOIC28  
[(SA404)]  
ST72T251G1B@SDIP32 [(SA653)] ST72T251G1M@SOIC28  
[(SA404)]  
ST72T251G2B@SDIP32 [(SA653)] ST72T251G2M@SOIC28  
[(SA404)]  
ST72T272K4B@SDIP32 [(SA653)] ST72T272K4M@SSOP34  
[(SA658)]  
ST72T311J2B@SDIP42 [(SA028)] ST72T311J2T@TQFP44  
[(SA245A)]  
ST72T311J4B@SDIP42 [(SA028)] ST72T311J4T@TQFP44  
[(SA245A)]  
ST72T331J2B@SDIP42 [(SA028)] ST72T331J2T@TQFP44  
[(SA245A)]  
ST72T331J4B@SDIP42 [(SA028)] ST72T331J4T@TQFP44  
[(SA245A)]  
ST72T371N4B@SDIP56(\*) [(SA627-B5601)]  
ST72T372J4B@SDIP42 [(SA028)] ST72T631K4B1@SDIP32  
[(SA653)]  
ST72T631K4M1@SSOP34 [(SA658)] ST72T632K2B1@SDIP32  
[(SA653)]  
ST72T632K2M1@SSOP34 [(SA658)] ST72T633K1B1@SDIP32  
[(SA653)]  
ST72T633K1M1@SSOP34 [(SA658)]  
ST72T671N6B@SDIP56(\*) [(SA627-B5601)]  
ST72T751N9B@SDIP56(\*) [(SA627-B5601)]  
ST72T752J6B@SDIP42 [(SA028)] ST72T753L6M@SSOP34  
[(SA658)]  
ST72T771N9B@SDIP56(\*) [(SA627-B5601)]  
ST7FDALIF2M6@SOIC20 [(SA404)]



ST7FDALIF2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLI49MK1B6@SDIP32 [(SA653)] ST7FLI49MK1T6@TQFP32  
[(SA663)]  
ST7FLIT10BF0B3  
ST7FLIT10BF0B6  
ST7FLIT10BF0M3@SOIC20 [(SA404)] ST7FLIT10BF0M6@SOIC20  
[(SA404)]  
ST7FLIT10BF1B3  
ST7FLIT10BF1B6  
ST7FLIT10BF1M3@SOIC20 [(SA404)] ST7FLIT10BF1M6@SOIC20  
[(SA404)]  
ST7FLIT10BY0B3  
ST7FLIT10BY0B6  
ST7FLIT10BY0M3@SOIC16 [(SA602)] ST7FLIT10BY0M6@SOIC16  
[(SA602)]  
ST7FLIT10BY1B3  
ST7FLIT10BY1B6  
ST7FLIT10BY1M3@SOIC16 [(SA602)] ST7FLIT10BY1M6@SOIC16  
[(SA602)]  
ST7FLIT15BF0B3  
ST7FLIT15BF0B6  
ST7FLIT15BF0M3@SOIC20 [(SA404)] ST7FLIT15BF0M6@SOIC20  
[(SA404)]  
ST7FLIT15BF1B3  
ST7FLIT15BF1B6  
ST7FLIT15BF1M3@SOIC20 [(SA404)] ST7FLIT15BF1M6@SOIC20  
[(SA404)]  
ST7FLIT15BF1U6TR@QFN20 [(BBBB)]  
ST7FLIT15BY0B3  
ST7FLIT15BY0B6 ST7FLIT15BY0M3@SOIC16  
[(SA602)]  
ST7FLIT15BY0M6@SOIC16 [(SA602)]  
ST7FLIT15BY1B3  
ST7FLIT15BY1B6 ST7FLIT15BY1M3@SOIC16  
[(SA602)]  
ST7FLIT15BY1M6@SOIC16 [(SA602)]  
ST7FLIT19BF0B3  
ST7FLIT19BF0B6 ST7FLIT19BF0M3@SOIC20  
[(SA404)]  
ST7FLIT19BF0M6@SOIC20 [(SA404)]  
ST7FLIT19BF1B3  
ST7FLIT19BF1B6 ST7FLIT19BF1M3@SOIC20  
[(SA404)]

ST7FLIT19BF1M6@SOIC20 [(SA404)] ST7FLIT19BF1U6TR@QFN20  
[(BBBB)]  
ST7FLIT19BY0B3  
ST7FLIT19BY0B6  
ST7FLIT19BY0M3@SOIC16 [(SA602)] ST7FLIT19BY0M6@SOIC16  
[(SA602)]  
ST7FLIT19BY1B3  
ST7FLIT19BY1B6  
ST7FLIT19BY1M3@SOIC16 [(SA602)] ST7FLIT19BY1M6@SOIC16  
[(SA602)]  
ST7FLITE02B6 ST7FLITE02B6(ISP) [ISP-  
HEADER01]  
ST7FLITE02M6@SOIC16 [(SA602)]  
ST7FLITE02M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE02Y0B6  
ST7FLITE02Y0B6(ISP) [ISP-HEADER01]  
ST7FLITE02Y0M6@SOIC16 [(SA602)]  
ST7FLITE02Y0M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE05B6 ST7FLITE05B6(ISP) [ISP-  
HEADER01]  
ST7FLITE05M6@SOIC16 [(SA602)]  
ST7FLITE05M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE05Y0B6  
ST7FLITE05Y0B6(ISP) [ISP-HEADER01]  
ST7FLITE05Y0M6@SOIC16 [(SA602)]  
ST7FLITE05Y0M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE09B6 ST7FLITE09B6(ISP) [ISP-  
HEADER01]  
ST7FLITE09M6@SOIC16 [(SA602)]  
ST7FLITE09M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE09Y0B6  
ST7FLITE09Y0B6(ISP) [ISP-HEADER01]  
ST7FLITE09Y0M6@SOIC16 [(SA602)]  
ST7FLITE09Y0M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITE10F1B6  
ST7FLITE10F1B6(ISP) [ISP-HEADER01]  
ST7FLITE10F1M6@SOIC20 [(SA404)]  
ST7FLITE10F1M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE15F1B6  
ST7FLITE15F1B6(ISP) [ISP-HEADER01]  
ST7FLITE15F1M6@SOIC20 [(SA404)]  
ST7FLITE15F1M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE19F1B6

ST7FLITE19F1B6(ISP) [ISP-HEADER01]  
ST7FLITE19F1M6@SOIC20 [(SA404)]  
ST7FLITE19F1M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE20F2B6  
ST7FLITE20F2B6(ISP) [ISP-HEADER01]  
ST7FLITE20F2M6@SOIC20 [(SA404)]  
ST7FLITE20F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE25F2B6  
ST7FLITE25F2B6(ISP) [ISP-HEADER01]  
ST7FLITE25F2M6@SOIC20 [(SA404)]  
ST7FLITE25F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE29F2B6  
ST7FLITE29F2B6(ISP) [ISP-HEADER01]  
ST7FLITE29F2M6@SOIC20 [(SA404)]  
ST7FLITE29F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE30F2B6  
ST7FLITE30F2B6(ISP) [ISP-HEADER01]  
ST7FLITE30F2M6@SOIC20 [(SA404)]  
ST7FLITE30F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE35F2B6  
ST7FLITE35F2B6(ISP) [ISP-HEADER01]  
ST7FLITE35F2M6@SOIC20 [(SA404)]  
ST7FLITE35F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE39F2B6  
ST7FLITE39F2B6(ISP) [ISP-HEADER01]  
ST7FLITE39F2M6@SOIC20 [(SA404)]  
ST7FLITE39F2M6@SOIC20(ISP) [ISP-HEADER01]  
ST7FLITE49  
ST7FLITE49@QFN40  
[(SA750)]  
ST7FLITE49@TQFP32 [(SA663)]  
ST7FLITEBC  
ST7FLITEBCM6@SOIC16 [(SA602)]  
ST7FLITES0  
ST7FLITES0@SOIC16 [(SA602)]  
ST7FLITES2B6  
ST7FLITES2B6(ISP) [ISP-HEADER01] ST7FLITES2M6@SOIC16  
[(SA602)]  
ST7FLITES2M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITES2Y0B6  
ST7FLITES2Y0B6(ISP) [ISP-HEADER01]  
ST7FLITES2Y0M6@SOIC16 [(SA602)]  
ST7FLITES2Y0M6@SOIC16(ISP) [ISP-HEADER01]  
ST7FLITES5B6  
ST7FLITES5B6(ISP) [ISP-

HEADER01 ]

ST7FLITES5M6@SOIC16 [(SA602)]

ST7FLITES5M6@SOIC16(ISP) [ISP-HEADER01]

ST7FLITES5Y0B6

ST7FLITES5Y0B6(ISP) [ISP-HEADER01]

ST7FLITES5Y0M6@SOIC16 [(SA602)]

ST7FLITES5Y0M6@SOIC16(ISP) [ISP-HEADER01]

ST7FLITEUS2B6

ST7FLITEUS2M6@SOIC8

[(SA602A)]

ST7FLITEUS2M6TR@SOIC8 [(SA602A)]

ST7FLITEUS2U6TR@DFN8

[(BBBB)]

ST7FLITEUS5B6

ST7FLITEUS5M6@SOIC8

[(SA602A)]

ST7FLITEUS5M6TR@SOIC8 [(SA602A)]

ST7FLITEUS5U6TR@DFN8

[(BBBB)]

ST7FLU05B6

ST7FLU05BAE

ST7FLU05BATRE

ST7FLU05BCE

ST7FLU05BCTRE

ST7FLU05M6@SOIC8

[(SA602A)]

ST7FLU05MAE@SOIC8 [(SA602A)]

ST7FLU05MATRE@SOIC8

[(SA602A)]

ST7FLU05MCE@SOIC8 [(SA602A)]

ST7FLU05MCTRE@SOIC8

[(SA602A)]

ST7FLU09B6

ST7FLU09BAE

ST7FLU09BATRE

ST7FLU09BCE

ST7FLU09BCTRE

ST7FLU09M6@SOIC8

[(SA602A)]

ST7FLU09MAE@SOIC8 [(SA602A)]

ST7FLU09MATRE@SOIC8

[(SA602A)]

ST7FLU09MCE@SOIC8 [(SA602A)]

ST7FLU09MCTRE@SOIC8

[(SA602A)]

ST7FLUS5B6

ST7FLUS5BAE

ST7FLUS5BATRE

ST7FLUS5BCE

ST7FLUS5BCTRE

ST7FLUS5M6@SOIC8

[(SA602A)]

ST7FLUS5MAE@SOIC8 [(SA602A)]

ST7FLUS5MATRE@SOIC8

[(SA602A)]

ST7FLUS5MCE@SOIC8 [(SA602A)] ST7FLUS5MCTRE@SOIC8  
[(SA602A)]  
ST7FMC1K2B6@SDIP32 [(SA653)]  
ST7FMC1K2B6@SDIP32(ISP) [ISP-HEADER01]  
ST7FMC1K2T3@TQFP32 [(SA663)]  
ST7FMC1K2T3@TQFP32(ISP) [ISP-HEADER01]  
ST7FMC1K2T6@TQFP32 [(SA663)]  
ST7FMC1K2T6@TQFP32(ISP) [ISP-HEADER01]  
ST7FMC1K2TC@TQFP32 [(SA663)]  
ST7FMC1K2TC@TQFP32(ISP) [ISP-HEADER01]  
ST7FMC1K4T6@TQFP32 [(SA663)]  
ST7FMC1K4T6@TQFP32(ISP) [ISP-HEADER01]  
ST7FMC1K6TC@TQFP32 [(SA663)]  
ST7FMC1K6TC@TQFP32(ISP) [ISP-HEADER01]  
ST7FMC2M9T6@LQFP80(ISP) [ISP-HEADER01]  
ST7FMC2S4T3@TQFP44 [(SA245A)]  
ST7FMC2S4T3@TQFP44(ISP) [ISP-HEADER01]  
ST7FMC2S4T6@TQFP44 [(SA245A)]  
ST7FMC2S4T6@TQFP44(ISP) [ISP-HEADER01]  
ST7FMC2S4TC@TQFP44 [(SA245A)]  
ST7FMC2S4TC@TQFP44(ISP) [ISP-HEADER01]  
ST7FMC2S5T6@TQFP44 [(SA245A)]  
ST7FMC2S5T6@TQFP44(ISP) [ISP-HEADER01]  
ST7FMC2S5TC@TQFP44 [(SA245A)]  
ST7FMC2S5TC@TQFP44(ISP) [ISP-HEADER01]  
ST7FMC2S6T3@TQFP44 [(SA245A)]  
ST7FMC2S6T3@TQFP44(ISP) [ISP-HEADER01]  
ST7FMC2S6T6@TQFP44 [(SA245A)]  
ST7FMC2S6T6@TQFP44(ISP) [ISP-HEADER01]  
ST7FMC2S6TC@TQFP44 [(SA245A)]  
ST7FMC2S6TC@TQFP44(ISP) [ISP-HEADER01]  
ST7FOXF1B6 ST7FOXF1M6@SOIC20  
[(SA404)]  
ST7FOXF2B6 ST7FOXF2M6@SOIC20  
[(SA404)]  
ST7FOXK1B6@SDIP32 [(SA653)] ST7FOXK1T6@QFP32  
[(SA663)]  
ST7FOXK2B6@SDIP32 [(SA653)] ST7FOXK2T6@QFP32  
[(SA663)]  
ST7FSCR1E4M1@SOIC24(\*) [(SA404-B140)]  
ST7FSCR1R4T1@TQFP64(\*) [(TA032-B006)]

# STC

## MICROCONTROLLER

STC89C516RD [ (SA244) ]	STC89C516RD@PLCC44
STC89C516RD@TQFP44 [ (SA245A) ]	
STC89C58RD STC89C58RD@PLCC44 [ (SA244) ] [ (SA245A) ]	STC89C58RD@TQFP44
STC89LE516AD [ (SA244) ]	STC89LE516AD@PLCC44
STC89LE516AD@TQFP44 [ (SA245A) ]	
STC89LE516X2 STC89LE516X2@PLCC44 [ (SA244) ] [ (SA245A) ]	STC89LE516X2@TQFP44
STC89LE52AD [ (SA244) ]	STC89LE52AD@PLCC44
STC89LE52AD@TQFP44 [ (SA675) ]	
STC89LE54AD STC89LE54AD@PLCC44 [ (SA244) ] [ (SA675) ]	STC89LE54AD@TQFP44
STC89LE556AD [ (SA244) ]	STC89LE556AD@PLCC44
STC89LE556AD@TQFP44 [ (SA245A) ]	
STC89LE556X2 STC89LE556X2@PLCC44 [ (SA244) ] [ (SA245A) ]	STC89LE556X2@TQFP44
STC89LE58AD [ (SA244) ]	STC89LE58AD@PLCC44
STC89LE58AD@TQFP44 [ (SA675) ]	
STC89LV516RD STC89LV516RD@PLCC44 [ (SA244) ] [ (SA245A) ]	STC89LV516RD@TQFP44
STC89LV58RD [ (SA244) ]	STC89LV58RD@PLCC44
STC89LV58RD@TQFP44 [ (SA245A) ]	

# ST-CUSTOMER

## E ( E ) PROM / FRAM / NVRAM

M28W160ECB(Moto)@FBGA48 [(SA714A-B026A-M046F001Y)]  
 M28W160ECT(Moto)@FBGA48 [(SA714A-B026A-M046F001Y)]  
 M36L0R7050B0\_B1(HZ)@FBGA88 [(SA642R-B124A-T096F001Y)]  
 M36L0R7050T0\_T1(HZ)@FBGA88 [(SA642R-B124A-T096F001Y)]  
 M36L0R8060B3(HZ)@FBGA88 [(SA642A-B124A-Y096F001Y)]  
 M36L0R8060B5ZAQ(HZ)@FBGA88 [(SA642A-B124A-Y096F001Y)]  
 M58LR128FB\_GB(HZ)@VFBGA56 [(SA644A-B025B-Y072F001)]  
 M58LR128FT\_GT(HZ)@VFBGA56 [(SA644A-B025B-Y072F001)]  
 NAND01GW3B2BZA6(ASUS)@FBGA63 [(SA642KK-B026-W048F001Y)]  
 NAND04GW3B2BN6(WS)@TSOP48 [(SA247-B005)]  
 NAND512R3A2(MLT)@FBGA63 [(SA642KK-B026-W0638F001Y)]  
 NANDA9R4N2AZBA5(UT)@FBGA149 [(SA664G-B279-Y149F001Y)]

## SUMMIT

### E (E) PROM/FRAM/NVRAM

S24022 [(SA602A)]	S24022@SOIC8
S24023 [(SA602A)]	S24023@SOIC8
S24042 [(SA602A)]	S24042@SOIC8
S24043 [(SA602A)]	S24043@SOIC8
S24162 [(SA602A)]	S24162@SOIC8
S24VP02 [(SA602A)]	S24VP02@SOIC8
S24VP04 [(SA602A)]	S24VP04@SOIC8
S24VP08 [(SA602A)]	S24VP08@SOIC8
S24VP16 [(SA602A)]	S24VP16@SOIC8
S93462(08bit) [(SA602A)]	S93462(08bit)@SOIC8
S93462(16bit) [(SA602A)]	S93462(16bit)@SOIC8
S93463(08bit) [(SA602A)]	S93463(08bit)@SOIC8

S93463(16bit) [(SA602A)]	S93463(16bit)@SOIC8
S93662(08bit) [(SA602A)]	S93662(08bit)@SOIC8
S93662(16bit) [(SA602A)]	S93662(16bit)@SOIC8
S93663(08bit) [(SA602A)]	S93663(08bit)@SOIC8
S93663(16bit) [(SA602A)]	S93663(16bit)@SOIC8
S93WD462(08bit) [(SA602A)]	S93WD462(08bit)@SOIC8
S93WD462(16bit) [(SA602A)]	S93WD462(16bit)@SOIC8
S93WD463(08bit) [(SA602A)]	S93WD463(08bit)@SOIC8
S93WD463(16bit) [(SA602A)]	S93WD463(16bit)@SOIC8
S93WD662(08bit) [(SA602A)]	S93WD662(08bit)@SOIC8
S93WD662(16bit) [(SA602A)]	S93WD662(16bit)@SOIC8
S93WD663(08bit) [(SA602A)]	S93WD663(08bit)@SOIC8
S93WD663(16bit) [(SA602A)]	S93WD663(16bit)@SOIC8

## MICROCONTROLLER

I-SMM465F-249@TQFP48 (ISP) [ISP-HEADER01]	
SMM465F-249@TQFP48 [(SA248)]	SMM665BFC-266@TQFP48
[(SA248)]	
SMM665BFC-266@TQFP48 (ISP) [ISP-HEADER01]	

## SUNPLUS

### E ( E ) PROM / FRAM / NVRAM

SPHE6400A [(SA602A)]	SPHE6400A@SOIC8
-------------------------	-----------------



**MICROCONTROLLER**

SPMC65P2102A(dip18)  
SPMC65P2102A(dip18)(ISP) [ISP-HEADER01]  
SPMC65P2102A@SOP18 [(SA404)]  
SPMC65P2102A@SOP18(ISP) [ISP-HEADER01]  
SPMC65P2104A(dip18)  
SPMC65P2104A(dip18)(ISP) [ISP-HEADER01]  
SPMC65P2104A@SOP18 [(SA404)]  
SPMC65P2104A@SOP18(ISP) [ISP-HEADER01]  
SPMC65P2202A(dip16)  
SPMC65P2202A(dip16)(ISP) [ISP-HEADER01]  
SPMC65P2202A(dip20)  
SPMC65P2202A(dip20)(ISP) [ISP-HEADER01]  
SPMC65P2202A@SOP16 [(SA404)]  
SPMC65P2202A@SOP16(ISP) [ISP-HEADER01]  
SPMC65P2202A@SOP20 [(SA404)]  
SPMC65P2202A@SOP20(ISP) [ISP-HEADER01]  
SPMC65P2204A(dip16)  
SPMC65P2204A(dip16)(ISP) [ISP-HEADER01]  
SPMC65P2204A(dip20)  
SPMC65P2204A(dip20)(ISP) [ISP-HEADER01]  
SPMC65P2204A@SOP16 [(SA404)]  
SPMC65P2204A@SOP16(ISP) [ISP-HEADER01]  
SPMC65P2204A@SOP20 [(SA404)]  
SPMC65P2204A@SOP20(ISP) [ISP-HEADER01]  
SPMC65P2404A(dip20)  
SPMC65P2404A(dip20)(ISP) [ISP-HEADER01]  
SPMC65P2404A(dip28)  
SPMC65P2404A(dip28)(ISP) [ISP-HEADER01]  
SPMC65P2404A@SOP20 [(SA404)]  
SPMC65P2404A@SOP20(ISP) [ISP-HEADER01]  
SPMC65P2404A@SOP28 [(SA404)]  
SPMC65P2404A@SOP28(ISP) [ISP-HEADER01]  
SPMC65P2408A(dip28)  
SPMC65P2408A(dip28)(ISP) [ISP-HEADER01]  
SPMC65P2408A(dip32)  
SPMC65P2408A(dip32)(ISP) [ISP-HEADER01]  
SPMC65P2408A@SOP28 [(SA404)]  
SPMC65P2408A@SOP28(ISP) [ISP-HEADER01]  
SPMC65P2408A@SOP32 [(SA603)]  
SPMC65P2408A@SOP32(ISP) [ISP-HEADER01]

**SYNCMOS****E (E) PROM/FRAM/NVRAM**

F29C31004B [ (SA015A1T) ]	F29C31004B@PLCC32
F29C31004B@TSOP32 [ (SA410T) ]	
F29C31004T	
F29C31004T@PLCC32 [ (SA015A1T) ]	F29C31004T@TSOP32
[ (SA410T) ]	
F29C51000B [ (SA015A1T) ]	F29C51000B@PLCC32
F29C51000T	
[ (SA015A1T) ]	F29C51000T@PLCC32
F29C51001B [ (SA015A1T) ]	F29C51001B@PLCC32
F29C51001B@TSOP32 [ (SA410T) ]	
F29C51001T	
F29C51001T@PLCC32 [ (SA015A1T) ]	F29C51001T@TSOP32
[ (SA410T) ]	
F29C51002B [ (SA015A1T) ]	F29C51002B@PLCC32
F29C51002B@TSOP32 [ (SA410T) ]	
F29C51002T	
F29C51002T@PLCC32 [ (SA015A1T) ]	F29C51002T@TSOP32
[ (SA410T) ]	
F29C51004B [ (SA015A1T) ]	F29C51004B@PLCC32
F29C51004B@TSOP32 [ (SA410T) ]	
F29C51004T	
F29C51004T@PLCC32 [ (SA015A1T) ]	F29C51004T@TSOP32
[ (SA410T) ]	
F29LC51000 [ (SA015A1T) ]	F29LC51000@PLCC32
F29LC51001 [ (SA015A1T) ]	F29LC51001@PLCC32
F29LC51002 [ (SA015A1T) ]	F29LC51002@PLCC32
S29C31001B [ (SA015A1T) ]	S29C31001B@PLCC32
S29C31001B@TSOP32 [ (SA410T) ]	

S29C31001T	
S29C31001T@PLCC32 [(SA015A1T)]	S29C31001T@TSOP32
[(SA410T)]	
S29C31002B	S29C31002B@PLCC32
[(SA015A1T)]	
S29C31002B@TSOP32 [(SA410T)]	
S29C31002T	
S29C31002T@PLCC32 [(SA015A1T)]	S29C31002T@TSOP32
[(SA410T)]	
S29C31004B	S29C31004B@PLCC32
[(SA015A1T)]	
S29C31004B@TSOP32 [(SA410T)]	
S29C31004T	
S29C31004T@PLCC32 [(SA015A1T)]	S29C31004T@TSOP32
[(SA410T)]	
S29C51001B	S29C51001B@PLCC32
[(SA015A1T)]	
S29C51001B@TSOP32 [(SA410T)]	
S29C51001T	
S29C51001T@PLCC32 [(SA015A1T)]	S29C51001T@TSOP32
[(SA410T)]	
S29C51002B	S29C51002B@PLCC32
[(SA015A1T)]	
S29C51002B@TSOP32 [(SA410T)]	
S29C51002T	
S29C51002T@PLCC32 [(SA015A1T)]	S29C51002T@TSOP32
[(SA410T)]	
S29C51004B	S29C51004B@PLCC32
[(SA015A1T)]	
S29C51004B@TSOP32 [(SA410T)]	
S29C51004T	
S29C51004T@PLCC32 [(SA015A1T)]	S29C51004T@TSOP32
[(SA410T)]	

## MICROCONTROLLER

MSU1958	MSU1958@PLCC44
[(SA244)]	
MSU1958@TQFP44 [(SA245A)]	
MSU2952	
MSU2952@PLCC44 [(SA244)]	MSU2952@TQFP44
[(SA245A)]	

MSU2964	MSU2964@PLCC44
[ ( SA244 ) ]	
MSU2964@TQFP44 [ ( SA245A ) ]	
SM2958	
SM2958@PLCC44 [ ( SA244 ) ]	SM2958@TQFP44
[ ( SA245A ) ]	
SM2965	SM2965@PLCC44
[ ( SA244 ) ]	
SM2965@TQFP44 [ ( SA245A ) ]	
SM59064	
SM59064@PLCC44 [ ( SA244 ) ]	SM59064@TQFP44
[ ( SA245A ) ]	
SM59128C	SM59128C@PLCC44
[ ( SA244 ) ]	
SM59128C@TQFP44 [ ( SA245A ) ]	
SM59128L	
SM59128L@PLCC44 [ ( SA244 ) ]	SM59128L@TQFP44
[ ( SA245A ) ]	
SM59164	SM59164@PLCC44
[ ( SA244 ) ]	
SM59164@TQFP44 [ ( SA245A ) ]	
SM59264	
SM59264@PLCC44 [ ( SA244 ) ]	SM59264@TQFP44
[ ( SA245A ) ]	
SM5964	SM5964@PLCC44
[ ( SA244 ) ]	
SM5964@TQFP44 [ ( SA245A ) ]	
SM5964A	
SM5964A@PLCC44 [ ( SA244 ) ]	SM5964A@TQFP44
[ ( SA245A ) ]	
SM5964AC	SM5964AC@PLCC44
[ ( SA244 ) ]	
SM5964AC@TQFP44 [ ( SA245A ) ]	
SM5964AL	
SM5964AL@PLCC44 [ ( SA244 ) ]	SM5964AL@TQFP44
[ ( SA245A ) ]	
SM5964C	SM5964C@PLCC44
[ ( SA244 ) ]	
SM5964C@TQFP44 [ ( SA245A ) ]	
SM5964D0	
SM5964D0@PLCC44 [ ( SA244 ) ]	SM5964D0@TQFP44
[ ( SA245A ) ]	
SM5964D0A	SM5964D0A@PLCC44

[ ( SA244 ) ]  
SM5964D0A@TQFP44 [ ( SA245A ) ]  
SM5964D1A  
SM5964D1A@PLCC44 [ ( SA244 ) ] SM5964D1A@TQFP44  
[ ( SA245A ) ]  
SM59D02G2C SM59D02G2C( ISP ) [ ISP-  
HEADER01 ]  
SM59D02G2C@LQFP44 [ ( SA675-B005 ) ]  
SM59D02G2C@LQFP44( ISP ) [ ISP-HEADER01 ]  
SM59D02G2C@PLCC44 [ ( SA244-B002 ) ]  
SM59D02G2C@PLCC44( ISP ) [ ISP-HEADER01 ]  
SM59D02G2L SM59D02G2L( ISP ) [ ISP-  
HEADER01 ]  
SM59D02G2L@LQFP44 [ ( SA675-B005 ) ]  
SM59D02G2L@LQFP44( ISP ) [ ISP-HEADER01 ]  
SM59D02G2L@PLCC44 [ ( SA244-B002 ) ]  
SM59D02G2L@PLCC44( ISP ) [ ISP-HEADER01 ]  
SM59D03G2C SM59D03G2C( ISP ) [ ISP-  
HEADER01 ]  
SM59D03G2C@LQFP44 [ ( SA675-B005 ) ]  
SM59D03G2C@LQFP44( ISP ) [ ISP-HEADER01 ]  
SM59D03G2C@PLCC44 [ ( SA244-B002 ) ]  
SM59D03G2C@PLCC44( ISP ) [ ISP-HEADER01 ]  
SM59D03G2L SM59D03G2L( ISP ) [ ISP-  
HEADER01 ]  
SM59D03G2L@LQFP44 [ ( SA675-B005 ) ]  
SM59D03G2L@LQFP44( ISP ) [ ISP-HEADER01 ]  
SM59D03G2L@PLCC44 [ ( SA244-B002 ) ]  
SM59D03G2L@PLCC44( ISP ) [ ISP-HEADER01 ]  
SM59D04G2C SM59D04G2C( ISP ) [ ISP-  
HEADER01 ]  
SM59D04G2C@LQFP44 [ ( SA675-B005 ) ]  
SM59D04G2C@LQFP44( ISP ) [ ISP-HEADER01 ]  
SM59D04G2C@PLCC44 [ ( SA244-B002 ) ]  
SM59D04G2C@PLCC44( ISP ) [ ISP-HEADER01 ]  
SM59D04G2L SM59D04G2L( ISP ) [ ISP-  
HEADER01 ]  
SM59D04G2L@LQFP44 [ ( SA675-B005 ) ]  
SM59D04G2L@LQFP44( ISP ) [ ISP-HEADER01 ]  
SM59D04G2L@PLCC44 [ ( SA244-B002 ) ]  
SM59D04G2L@PLCC44( ISP ) [ ISP-HEADER01 ]  
SM59R08A2@TQFP64( \* ) [ ( SA732-B292 ) ]  
SM59R16A2@TQFP64( \* ) [ ( SA732-B292 ) ]

SM7908	SM7908@PLCC44
[ (SA244) ]	
SM7908@TQFP44 [ (SA245A) ]	
SM79108	
SM79108@PLCC44 [ (SA244) ]	SM79108@TQFP44
[ (SA245A) ]	
SM79164	SM79164@PLCC44
[ (SA244) ]	
SM79164@TQFP44 [ (SA245A) ]	
SM79164L	
SM79164L@PLCC44 [ (SA244) ]	SM79164L@TQFP44
[ (SA245A) ]	
SM79164V	SM79164V@PLCC44
[ (SA244) ]	
SM79164V@TQFP44 [ (SA245A) ]	
SM7932	
SM7932@PLCC44 [ (SA244) ]	SM7932@TQFP44
[ (SA245A) ]	
SM7964	SM7964@PLCC44
[ (SA244) ]	
SM7964@TQFP44 [ (SA245A) ]	
SM894051	
SM894051@SOIC20 [ordering number is marked above]	
SM8951	SM8951@PLCC44
[ (SA244) ]	
SM8951@TQFP44 [ (SA245A) ]	
SM89516	
SM89516@PLCC44 [ (SA244) ]	SM89516@TQFP44
[ (SA245A) ]	
SM89516A	SM89516A@PLCC44
[ (SA244) ]	
SM89516A@TQFP44 [ (SA245A) ]	
SM89516AL	
SM89516AL@PLCC44 [ (SA244) ]	SM89516AL@TQFP44
[ (SA245A) ]	
SM89516B	SM89516B@PLCC44
[ (SA244) ]	
SM89516B@TQFP44 [ (SA245A) ]	
SM89516BL	
SM89516BL@PLCC44 [ (SA244) ]	SM89516BL@TQFP44
[ (SA245A) ]	
SM89516L	SM89516L@PLCC44
[ (SA244) ]	

SM89516L@TQFP44 [(SA245A)]  
SM8951A  
SM8951A@PLCC44 [(SA244)]  
[(SA245A)]  
SM8951AL  
[(SA244)]  
SM8951AL@TQFP44 [(SA245A)]  
SM8951B  
SM8951B@PLCC44 [(SA244)]  
[(SA245A)]  
SM8951BL  
[(SA244)]  
SM8951BL@TQFP44 [(SA245A)]  
SM8951L  
SM8951L@PLCC44 [(SA244)]  
[(SA245A)]  
SM8952  
[(SA244)]  
SM8952@TQFP44 [(SA245A)]  
SM8952A  
SM8952A@PLCC44 [(SA244)]  
[(SA245A)]  
SM8952AL  
[(SA244)]  
SM8952AL@TQFP44 [(SA245A)]  
SM8952B  
SM8952B@PLCC44 [(SA244)]  
[(SA245A)]  
SM8952BL  
[(SA244)]  
SM8952BL@TQFP44 [(SA245A)]  
SM8952L  
SM8952L@PLCC44 [(SA244)]  
[(SA245A)]  
SM8954  
[(SA244)]  
SM8954@TQFP44 [(SA245A)]  
SM8954A  
SM8954A@PLCC44 [(SA244)]  
[(SA245A)]  
SM8954AL  
[(SA244)]  
SM8954AL@TQFP44 [(SA245A)]

SM8951A@TQFP44  
SM8951AL@PLCC44  
SM8951B@TQFP44  
SM8951BL@PLCC44  
SM8951L@TQFP44  
SM8952@PLCC44  
SM8952A@TQFP44  
SM8952AL@PLCC44  
SM8952B@TQFP44  
SM8952BL@PLCC44  
SM8952L@TQFP44  
SM8954@PLCC44  
SM8954A@TQFP44  
SM8954AL@PLCC44

SM8954B	
SM8954B@PLCC44 [(SA244)]	SM8954B@TQFP44
[(SA245A)]	
SM8954BL	SM8954BL@PLCC44
[(SA244)]	
SM8954BL@TQFP44 [(SA245A)]	
SM8954L	
SM8954L@PLCC44 [(SA244)]	SM8954L@TQFP44
[(SA245A)]	
SM8958	SM8958@PLCC44
[(SA244)]	
SM8958@TQFP44 [(SA245A)]	
SM8958A	
SM8958A@PLCC44 [(SA244)]	SM8958A@TQFP44
[(SA245A)]	
SM8958AL	SM8958AL@PLCC44
[(SA244)]	
SM8958AL@TQFP44 [(SA245A)]	
SM8958B	
SM8958B@PLCC44 [(SA244)]	SM8958B@TQFP44
[(SA245A)]	
SM8958BL	SM8958BL@PLCC44
[(SA244)]	
SM8958BL@TQFP44 [(SA245A)]	
SM8958L	
SM8958L@PLCC44 [(SA244)]	SM8958L@TQFP44
[(SA245A)]	
SM89S16R1C	SM89S16R1C@PLCC44
[(SA244)]	
SM89S16R1C@TQFP44 [(SA245A)]	
SM89T04R1C	
SM89T04R1C@PLCC44 [(SA244)]	SM89T04R1C@TQFP44
[(SA245A)]	
SM89T04R1L	SM89T04R1L@PLCC44
[(SA244)]	
SM89T04R1L@TQFP44 [(SA245A)]	
SM89T08R1C	
SM89T08R1C@PLCC44 [(SA244)]	SM89T08R1C@TQFP44
[(SA245A)]	
SM89T08R1L	SM89T08R1L@PLCC44
[(SA244)]	
SM89T08R1L@TQFP44 [(SA245A)]	
SM89T16R1C	



SM89T16R1C@PLCC44 [ (SA244) ]  
[ (SA245A) ]  
SM89T16R1L  
[ (SA244) ]  
SM89T16R1L@TQFP44 [ (SA245A) ]

SM89T16R1C@TQFP44

SM89T16R1L@PLCC44

## SYNERTEK

### E ( E ) PROM / FRAM / NVRAM

SY2716

## SYNTEK

### MICROCONTROLLER

STK6011BP1-3V@PLCC44 [ (SA244) ]  
[ (SA244) ]

STK6011BP5-3V@TQFP44 [ (SA245A) ]  
[ (SA248) ]

STK6011P1-3V@PLCC44 [ (SA244) ]  
[ (SA244) ]

STK6011P3-3V@SDIP42 [ (SA028) ]  
[ (SA028) ]

STK6011P5-3V@PQFP44 [ (SA245A) ]  
[ (SA245A) ]

STK6011P7-3V  
5V

STK6011P9-3V@LQFP48 [ (SA248) ]  
[ (SA244) ]

STK6012BP22-5V@PLCC44 [ (SA244) ]  
[ (SA245A) ]

STK6012P10-5V@LQFP48 [ (SA248) ]  
[ (SA244) ]

STK6012P2-5V@PLCC44 [ (SA244) ]  
[ (SA028) ]

STK6012P4-5V@SDIP42 [ (SA028) ]  
[ (SA245A) ]

STK6012P6-5V@PQFP44 [ (SA245A) ]  
3V

STK6011BP21-5V@PLCC44

STK6011P10-5V@LQFP48

STK6011P2-5V@PLCC44

STK6011P4-5V@SDIP42

STK6011P6-5V@PQFP44

STK6011P8-

STK6012BP1-3V@PLCC44

STK6012BP5-3V@TQFP44

STK6012P1-3V@PLCC44

STK6012P3-3V@SDIP42

STK6012P5-3V@PQFP44

STK6012P7-

STK6012P8-5V

[ (SA248) ]

STK6012P9-3V@LQFP48

## TECHCODE

### MICROCONTROLLER

T89C516

[ (SA244) ]

T89C516@TQFP44 [ (SA245A) ]

T89C52

T89C52@PLCC44 [ (SA244) ]

[ (SA245A) ]

T89C58

[ (SA244) ]

T89C58@TQFP44 [ (SA245A) ]

T89C516@PLCC44

T89C52@TQFP44

T89C58@PLCC44

## TEKMOS

### E ( E ) PROM / FRAM / NVRAM

TK17LV040@PLCC20 [ (SA001A) ]

## TEMIC

### MICROCONTROLLER

T89C51RD2

[ (SA244) ]

T89C51RD2@TQFP44 [ (SA245A) ]

T89F64

T89F64@PLCC44 [ (SA244) ]

[ (SA245A) ]

TS87C51RB2

[ (SA244) ]

TS87C51RB2@TQFP44 [ (SA245A) ]

TS87C51RC2

TS87C51RC2@PLCC44 [ (SA244) ]

[ (SA245A) ]

T89C51RD2@PLCC44

T89F64@TQFP44

TS87C51RB2@PLCC44

TS87C51RC2@TQFP44

TS87C51RD2 [ (SA244) ]	TS87C51RD2@PLCC44
TS87C51RD2@TQFP44 [ (SA245A) ]	
TS87C51U2 TS87C51U2@PLCC44 [ (SA244) ] [ (SA245A) ]	TS87C51U2@TQFP44
TS87C52X2 [ (SA244) ]	TS87C52X2@PLCC44
TS87C52X2@TQFP44 [ (SA245A) ]	
TS87C54X2 TS87C54X2@PLCC44 [ (SA244) ] [ (SA245A) ]	TS87C54X2@TQFP44
TS87C58X2 [ (SA244) ]	TS87C58X2@PLCC44
TS87C58X2@TQFP44 [ (SA245A) ]	
TSC71RBX2 TSC71RBX2@PLCC44 [ (SA244) ] [ (SA245A) ]	TSC71RBX2@TQFP44
TSC71RCX2 [ (SA244) ]	TSC71RCX2@PLCC44
TSC71RCX2@TQFP44 [ (SA245A) ]	
TSC71RDX2 TSC71RDX2@PLCC44 [ (SA244) ] [ (SA245A) ]	TSC71RDX2@TQFP44
TSC87251A1@PLCC44 [ (SA244) ]	
TSC87251G1 TSC87251G1@PLCC44 [ (SA244) ]	
TSC87251G1A TSC87251G1A@PLCC44 [ (SA244) ]	
TSC87251G2D TSC87251G2D@PLCC44 [ (SA244) ] [ (SA245A) ]	TSC87251G2D@TQFP44
TSC87C51 [ (SA244) ]	TSC87C51@PLCC44
TSC87C51@TQFP44 [ (SA245A) ]	
TSC87C52 TSC87C52@PLCC44 [ (SA244) ] [ (SA245A) ]	TSC87C52@TQFP44
TSC87C54 [ (SA244) ]	TSC87C54@PLCC44
TSC87C54@TQFP44 [ (SA245A) ]	
TSC87C58 TSC87C58@PLCC44 [ (SA244) ]	TSC87C58@TQFP44

[ (SA245A) ]

**TEST-LOGIC****MICROCONTROLLER**

TL1008 [ (SA244) ]	TL1008@PLCC44
TL1008@TQFP44 [ (SA245A) ]	
TL2008 TL2008@PLCC44 [ (SA244) ] [ (SA245A) ]	TL2008@TQFP44
TL20164 [ (SA244) ]	TL20164@PLCC44
TL20164@TQFP44 [ (SA245A) ]	
TL20164A TL20164A@PLCC44 [ (SA244) ] [ (SA245A) ]	TL20164A@TQFP44
TL20164L [ (SA244) ]	TL20164L@PLCC44
TL20164L@TQFP44 [ (SA245A) ]	
TL2032 TL2032@PLCC44 [ (SA244) ] [ (SA245A) ]	TL2032@TQFP44
TL2054A [ (SA244) ]	TL2054A@PLCC44
TL2054A@TQFP44 [ (SA245A) ]	
TL2064 TL2064@PLCC44 [ (SA244) ] [ (SA245A) ]	TL2064@TQFP44
TL40516 [ (SA244) ]	TL40516@PLCC44
TL40516@TQFP44 [ (SA245A) ]	
TL40516A TL40516A@PLCC44 [ (SA244) ] [ (SA245A) ]	TL40516A@TQFP44
TL40516B [ (SA244) ]	TL40516B@PLCC44
TL40516B@TQFP44 [ (SA245A) ]	
TL4054 TL4054@PLCC44 [ (SA244) ] [ (SA245A) ]	TL4054@TQFP44

TL4058  
[ ( SA244 ) ]  
TL4058@TQFP44 [ ( SA245A ) ]  
TL4058A  
TL4058A@PLCC44 [ ( SA244 ) ]  
[ ( SA245A ) ]

TL4058@PLCC44

TL4058A@TQFP44

## TI

### E ( E ) PROM / FRAM / NVRAM

BQ4010  
BQ4010Y  
BQ4011  
BQ4011Y  
BQ4013  
BQ4013Y  
BQ4014  
BQ4014Y  
BQ4015  
BQ4015Y  
SMJ2516  
SMJ2532  
SMJ2532A  
SMJ2564  
SMJ2564@PLCC32 [ ( SA015A1T ) ]  
SMJ2716  
SMJ27C256  
[ ( SA015A1T ) ]  
SMJ27C512  
[ ( SA015A1T ) ]  
TMS2516  
TMS2516JLW  
TMS2532  
TMS2532A  
TMS2564  
[ ( SA015A1T ) ]  
TMS25L32  
TMS27128  
TMS27128A  
TMS2716  
TMS2732

SMJ27C256@PLCC32

SMJ27C512@PLCC32

TMS2564@PLCC32

TMS2732A	
TMS2764	
TMS27C010	
TMS27C010@PLCC32 [(SA015A1T)]	TMS27C010@TSOP32
[(SA410T)]	
TMS27C010A	TMS27C010A@PLCC32
[(SA015A1T)]	
TMS27C010A@TSOP32 [(SA410T)]	
TMS27C020	
TMS27C020@PLCC32 [(SA015A1T)]	TMS27C020@TSOP32
[(SA410T)]	
TMS27C040	TMS27C040@PLCC32
[(SA015A1T)]	
TMS27C040@TSOP32 [(SA410T)]	
TMS27C128	
TMS27C128@PLCC32 [(SA015A1T)]	
TMS27C2001	
TMS27C2001@PLCC32 [(SA015A1T)]	TMS27C2001@TSOP32
[(SA410T)]	
TMS27C210	TMS27C210@PLCC44
[(SA244)]	
TMS27C210A	TMS27C210A@PLCC44
[(SA244)]	
TMS27C240	TMS27C240@PLCC44
[(SA244)]	
TMS27C256	TMS27C256@PLCC32
[(SA015A1T)]	
TMS27C291	TMS27C291@PLCC28
[(SA008A)]	
TMS27C292	TMS27C292@PLCC28
[(SA008A)]	
TMS27C32	
TMS27C512	
TMS27C512@PLCC32 [(SA015A1T)]	
TMS27C64	
TMS27LV010A	TMS27LV010A@PLCC32
[(SA015A1T)]	
TMS27LV010A@TSOP32 [(SA410T)]	
TMS27P32A	
TMS27P64	
TMS27PC010	
TMS27PC010@PLCC32 [(SA015A1T)]	TMS27PC010@TSOP32
[(SA410T)]	

TMS27PC010A [ (SA015A1T) ]	TMS27PC010A@PLCC32
TMS27PC010A@TSOP32 [ (SA410T) ]	
TMS27PC020 TMS27PC020@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	TMS27PC020@TSOP32
TMS27PC040 [ (SA015A1T) ]	TMS27PC040@PLCC32
TMS27PC040@TSOP32 [ (SA410T) ]	
TMS27PC128 TMS27PC128@PLCC32 [ (SA015A1T) ]	
TMS27PC210 TMS27PC210@PLCC44 [ (SA244) ]	
TMS27PC210A TMS27PC210A@PLCC44 [ (SA244) ]	
TMS27PC240 TMS27PC240@PLCC44 [ (SA244) ]	
TMS27PC256 TMS27PC256@PLCC32 [ (SA015A1T) ]	
TMS27PC291 TMS27PC291@PLCC28 [ (SA008A) ]	
TMS27PC32 TMS27PC32A	
TMS27PC512 TMS27PC512@PLCC32 [ (SA015A1T) ]	
TMS27PC64	
TMS28F010 [ (SA015A1T) ]	TMS28F010@PLCC32
TMS28F010@TSOP32 [ (SA410T) ]	
TMS28F020 TMS28F020@PLCC32 [ (SA015A1T) ] [ (SA410T) ]	TMS28F020@TSOP32
TMS28F200BZ-B@PSOP44 [ (SA638) ] [ (SA638) ]	TMS28F200BZ-T@PSOP44
TMS28F210 [ (SA244) ]	TMS28F210@PLCC44
TMS28F210@TSOP40 [ (SA409T) ] [ (SA638) ]	TMS28F400AF-B@PSOP44
TMS28F400AF-T@PSOP44 [ (SA638) ] [ (SA638) ]	TMS28F400AS-B@PSOP44
TMS28F400AS-T@PSOP44 [ (SA638) ] [ (SA638) ]	TMS28F400BZ-B@PSOP44
TMS28F400BZ-T@PSOP44 [ (SA638) ]	

TMS28F512  
 TMS28F512@PLCC32 [ (SA015A1T) ]                      TMS28F512@TSOP32  
 [ (SA410T) ]  
 TMS29F040    TMS29F040@PLCC32  
 [ (SA015A1T) ]  
 TMS29F040@TSOP32 [ (SA410T) ]  
 TMS29F259  
 TMS29F259@PLCC32 [ (SA015A1T) ]                      TMS29F259@TSOP32  
 [ (SA410T) ]  
 TMS29F512    TMS29F512@PLCC32  
 [ (SA015A1T) ]  
 TMS29F512@TSOP32 [ (SA410T) ]  
 TMS87C257  
 TMS87C257@PLCC32 [ (SA015A1T) ]

**PLD**

EP330    EP330@PLCC20  
 [ (SA001A) ]  
 EP910    EP910-P44  
 [ (SA244) ]

**MICROCONTROLLER**

IMSP430F2330IRHA@QFN40 (ISP) [ ISP-HEADER01 ]  
 IMSP430F2330TRHA@QFN40 (ISP) [ ISP-HEADER01 ]  
 IMSP430F2350IRHA@QFN40 (ISP) [ ISP-HEADER01 ]  
 IMSP430F2350TRHA@QFN40 (ISP) [ ISP-HEADER01 ]  
 IMSP430F2370IRHA@QFN40 (ISP) [ ISP-HEADER01 ]  
 IMSP430F2370TRHA@QFN40 (ISP) [ ISP-HEADER01 ]  
 MSP430F110@SOIC20 [ (SA404) ]                              MSP430F110@TSSOP20  
 [ (SA026) ]  
 MSP430F1101@SOIC20 [ (SA404) ]                              MSP430F1101@TSSOP20  
 [ (SA026) ]  
 MSP430F1101A@QFN24 [ (SA710) ]  
 MSP430F1101A@QFN24 (ISP) [ ISP-HEADER01 ]  
 MSP430F1101A@SOIC20 [ (SA404) ]  
 MSP430F1101A@SOIC20 (ISP) [ ISP-HEADER01 ]  
 MSP430F1101A@TSSOP20 [ (SA026) ]  
 MSP430F1101A@TSSOP20 (ISP) [ ISP-HEADER01 ]  
 MSP430F1111A@QFN24 [ (SA710) ]



MSP430F1111A@QFN24(ISP) [ISP-HEADER01]  
MSP430F1111A@SOIC20 [(SA404)]  
MSP430F1111A@SOIC20(ISP) [ISP-HEADER01]  
MSP430F1111A@TSSOP20 [(SA026)]  
MSP430F1111A@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F112@SOIC20 [(SA404)] MSP430F112@TSSOP20  
[(SA026)]  
MSP430F1121@SOIC20 [(SA404)] MSP430F1121@TSSOP20  
[(SA026)]  
MSP430F1121A@QFN24 [(SA710)]  
MSP430F1121A@QFN24(ISP) [ISP-HEADER01]  
MSP430F1121A@SOIC20 [(SA404)]  
MSP430F1121A@SOIC20(ISP) [ISP-HEADER01]  
MSP430F1121A@TSSOP20 [(SA026)]  
MSP430F1121A@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F1122@QFN32 [(SA686)] MSP430F1122@SOIC20  
[(SA404)]  
MSP430F1122@SOIC20(ISP) [ISP-HEADER01]  
MSP430F1122@TSSOP20 [(SA026)]  
MSP430F1122@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F1132@QFN32 [(SA686)] MSP430F1132@SOIC20  
[(SA404)]  
MSP430F1132@SOIC20(ISP) [ISP-HEADER01]  
MSP430F1132@TSSOP20 [(SA026)]  
MSP430F1132@TSSOP20(ISP) [ISP-HEADER01]  
MSP430F122@QFN32 [(SA686)] MSP430F122@SOIC28  
[(SA404)]  
MSP430F122@TSSOP28 [(SA643)] MSP430F122@QFN32  
[(SA686)]  
MSP430F1222@SOIC28 [(SA404)]  
MSP430F1222@SOIC28(ISP) [ISP-HEADER01]  
MSP430F1222@TSSOP28 [(SA643)]  
MSP430F1222@TSSOP28(ISP) [ISP-HEADER01]  
MSP430F123@QFN32 [(SA686)] MSP430F123@SOIC28  
[(SA404)]  
MSP430F123@TSSOP28 [(SA643)] MSP430F123@QFN32  
[(SA686)]  
MSP430F1232@SOIC28 [(SA404)]  
MSP430F1232@SOIC28(ISP) [ISP-HEADER01]  
MSP430F1232@TSSOP28 [(SA643)]  
MSP430F1232@TSSOP28(ISP) [ISP-HEADER01]  
MSP430F155@QFN64(ISP) [ISP-HEADER01]  
MSP430F155@TQFP64(ISP) [ISP-HEADER01]

MSP430F156@QFN64(ISP) [ISP-HEADER01]  
MSP430F156@TQFP64(ISP) [ISP-HEADER01]  
MSP430F157@QFN64(ISP) [ISP-HEADER01]  
MSP430F157@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1610@QFN64(ISP) [ISP-HEADER01]  
MSP430F1610@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1611@QFN64(ISP) [ISP-HEADER01]  
MSP430F1611@TQFP64(ISP) [ISP-HEADER01]  
MSP430F1612@QFN64(ISP) [ISP-HEADER01]  
MSP430F1612@TQFP64(ISP) [ISP-HEADER01]  
MSP430F167@QFN64(ISP) [ISP-HEADER01]  
MSP430F167@TQFP64(ISP) [ISP-HEADER01]  
MSP430F168@QFN64(ISP) [ISP-HEADER01]  
MSP430F168@TQFP64(ISP) [ISP-HEADER01]  
MSP430F169@QFN64(ISP) [ISP-HEADER01]  
MSP430F169@TQFP64(ISP) [ISP-HEADER01]  
MSP430F2001IN  
MSP430F2001IN(ISP) [ISP-HEADER01]  
MSP430F2001IN(SPW ISP) [ISP-HEADER01]  
MSP430F2001IN(SPW) MSP430F2001IPW@TSSOP14  
[(SA026)]  
MSP430F2001IPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2001IPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2001IPW@TSSOP14(SPW) [(SA026)]  
MSP430F2001IRSA@QFN16 [(SA727)]  
MSP430F2001IRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2001IRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2001IRSA@QFN16(SPW) [(SA727)]  
MSP430F2001TN  
MSP430F2001TN(ISP) [ISP-HEADER01]  
MSP430F2001TN(SPW ISP) [ISP-HEADER01]  
MSP430F2001TN(SPW) MSP430F2001TPW@TSSOP14  
[(SA026)]  
MSP430F2001TPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2001TPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2001TPW@TSSOP14(SPW) [(SA026)]  
MSP430F2001TRSA@QFN16 [(SA727)]  
MSP430F2001TRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2001TRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2001TRSA@QFN16(SPW) [(SA727)]  
MSP430F2002IN  
MSP430F2002IN(ISP) [ISP-HEADER01]  
MSP430F2002IN(SPW ISP) [ISP-HEADER01]

MSP430F2002IN(SPW) MSP430F2002IPW@TSSOP14  
[(SA026)]  
MSP430F2002IPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2002IPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2002IPW@TSSOP14(SPW) [(SA026)]  
MSP430F2002IRSA@QFN16 [(SA727)]  
MSP430F2002IRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2002IRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2002IRSA@QFN16(SPW) [(SA727)]  
MSP430F2002TN  
MSP430F2002TN(ISP) [ISP-HEADER01]  
MSP430F2002TN(SPW ISP) [ISP-HEADER01]  
MSP430F2002TN(SPW) MSP430F2002TPW@TSSOP14  
[(SA026)]  
MSP430F2002TPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2002TPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2002TPW@TSSOP14(SPW) [(SA026)]  
MSP430F2002TRSA@QFN16 [(SA727)]  
MSP430F2002TRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2002TRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2002TRSA@QFN16(SPW) [(SA727)]  
MSP430F2003IN  
MSP430F2003IN(ISP) [ISP-HEADER01]  
MSP430F2003IN(SPW ISP) [ISP-HEADER01]  
MSP430F2003IN(SPW) MSP430F2003IPW@TSSOP14  
[(SA026)]  
MSP430F2003IPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2003IPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2003IPW@TSSOP14(SPW) [(SA026)]  
MSP430F2003IRSA@QFN16 [(SA727)]  
MSP430F2003IRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2003IRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2003IRSA@QFN16(SPW) [(SA727)]  
MSP430F2003TN  
MSP430F2003TN(ISP) [ISP-HEADER01]  
MSP430F2003TN(SPW ISP) [ISP-HEADER01]  
MSP430F2003TN(SPW) MSP430F2003TPW@TSSOP14  
[(SA026)]  
MSP430F2003TPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2003TPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2003TPW@TSSOP14(SPW) [(SA026)]  
MSP430F2003TRSA@QFN16 [(SA727)]  
MSP430F2003TRSA@QFN16(ISP) [ISP-HEADER01]

MSP430F2003TRSA@QFN16 (SPW ISP) [ISP-HEADER01]  
MSP430F2003TRSA@QFN16 (SPW) [(SA727)]  
MSP430F2011IN  
MSP430F2011IN (ISP) [ISP-HEADER01]  
MSP430F2011IN (SPW ISP) [ISP-HEADER01]  
MSP430F2011IN (SPW) MSP430F2011IPW@TSSOP14  
[(SA026)]  
MSP430F2011IPW@TSSOP14 (ISP) [ISP-HEADER01]  
MSP430F2011IPW@TSSOP14 (SPW ISP) [ISP-HEADER01]  
MSP430F2011IPW@TSSOP14 (SPW) [(SA026)]  
MSP430F2011IRSA@QFN16 [(SA727)]  
MSP430F2011IRSA@QFN16 (ISP) [ISP-HEADER01]  
MSP430F2011IRSA@QFN16 (SPW ISP) [ISP-HEADER01]  
MSP430F2011IRSA@QFN16 (SPW) [(SA727)]  
MSP430F2011TN  
MSP430F2011TN (ISP) [ISP-HEADER01]  
MSP430F2011TN (SPW ISP) [ISP-HEADER01]  
MSP430F2011TN (SPW) MSP430F2011TPW@TSSOP14  
[(SA026)]  
MSP430F2011TPW@TSSOP14 (ISP) [ISP-HEADER01]  
MSP430F2011TPW@TSSOP14 (SPW ISP) [ISP-HEADER01]  
MSP430F2011TPW@TSSOP14 (SPW) [(SA026)]  
MSP430F2011TRSA@QFN16 [(SA727)]  
MSP430F2011TRSA@QFN16 (ISP) [ISP-HEADER01]  
MSP430F2011TRSA@QFN16 (SPW ISP) [ISP-HEADER01]  
MSP430F2011TRSA@QFN16 (SPW) [(SA727)]  
MSP430F2012IN  
MSP430F2012IN (ISP) [ISP-HEADER01]  
MSP430F2012IN (SPW ISP) [ISP-HEADER01]  
MSP430F2012IN (SPW) MSP430F2012IPW@TSSOP14  
[(SA026)]  
MSP430F2012IPW@TSSOP14 (ISP) [ISP-HEADER01]  
MSP430F2012IPW@TSSOP14 (SPW ISP) [ISP-HEADER01]  
MSP430F2012IPW@TSSOP14 (SPW) [(SA026)]  
MSP430F2012IRSA@QFN16 [(SA727)]  
MSP430F2012IRSA@QFN16 (ISP) [ISP-HEADER01]  
MSP430F2012IRSA@QFN16 (SPW ISP) [ISP-HEADER01]  
MSP430F2012IRSA@QFN16 (SPW) [(SA727)]  
MSP430F2012TN  
MSP430F2012TN (ISP) [ISP-HEADER01]  
MSP430F2012TN (SPW ISP) [ISP-HEADER01]  
MSP430F2012TN (SPW) MSP430F2012TPW@TSSOP14  
[(SA026)]

MSP430F2012TPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2012TPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2012TPW@TSSOP14(SPW) [(SA026)]  
MSP430F2012TRSA@QFN16 [(SA727)]  
MSP430F2012TRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2012TRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2012TRSA@QFN16(SPW) [(SA727)]  
MSP430F2013IN  
MSP430F2013IN(ISP) [ISP-HEADER01]  
MSP430F2013IN(SPW ISP) [ISP-HEADER01]  
MSP430F2013IN(SPW) MSP430F2013IPW@TSSOP14  
[(SA026)]  
MSP430F2013IPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2013IPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2013IPW@TSSOP14(SPW) [(SA026)]  
MSP430F2013IRSA@QFN16 [(SA727)]  
MSP430F2013IRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2013IRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2013IRSA@QFN16(SPW) [(SA727)]  
MSP430F2013TN  
MSP430F2013TN(ISP) [ISP-HEADER01]  
MSP430F2013TN(SPW ISP) [ISP-HEADER01]  
MSP430F2013TN(SPW) MSP430F2013TPW@TSSOP14  
[(SA026)]  
MSP430F2013TPW@TSSOP14(ISP) [ISP-HEADER01]  
MSP430F2013TPW@TSSOP14(SPW ISP) [ISP-HEADER01]  
MSP430F2013TPW@TSSOP14(SPW) [(SA026)]  
MSP430F2013TRSA@QFN16 [(SA727)]  
MSP430F2013TRSA@QFN16(ISP) [ISP-HEADER01]  
MSP430F2013TRSA@QFN16(SPW ISP) [ISP-HEADER01]  
MSP430F2013TRSA@QFN16(SPW) [(SA727)]  
MSP430F2101@QFN24 [(SA710-B006)] MSP430F2101@SOIC20  
[(SA404)]  
MSP430F2101@TSSOP20 [(SA643)]  
MSP430F2101@TVSOP20 [(SA713-B005)]  
MSP430F2111@QFN24 [(SA710-B006)] MSP430F2111@SOIC20  
[(SA404)]  
MSP430F2111@TSSOP20 [(SA643)]  
MSP430F2111@TVSOP20 [(SA713-B005)]  
MSP430F2121@QFN24 [(SA710-B006)] MSP430F2121@SOIC20  
[(SA404)]  
MSP430F2121@TSSOP20 [(SA643)]  
MSP430F2121@TVSOP20 [(SA713-B005)]

MSP430F2131@QFN24 [(SA710-B006)]      MSP430F2131@SOIC20  
[(SA404)]  
MSP430F2131@TSSOP20 [(SA643)]  
MSP430F2131@TVSOP20 [(SA713-B005)]  
MSP430F2232IDA@SSOP38 [(SA689)]  
MSP430F2232IDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2232IRHA@QFN40 [(SA750)]  
MSP430F2232IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2232TDA@SSOP38 [(SA689)]  
MSP430F2232TDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2232TRHA@QFN40 [(SA750)]  
MSP430F2232TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2234IDA@SSOP38 [(SA689)]  
MSP430F2234IDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2234IRHA@QFN40 [(SA750)]  
MSP430F2234IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2234TDA@SSOP38 [(SA689)]  
MSP430F2234TDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2234TRHA@QFN40 [(SA750)]  
MSP430F2234TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2252IDA@SSOP38 [(SA689)]  
MSP430F2252IDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2252IRHA@QFN40 [(SA750)]  
MSP430F2252IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2252TDA@SSOP38 [(SA689)]  
MSP430F2252TDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2252TRHA@QFN40 [(SA750)]  
MSP430F2252TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2254IDA@SSOP38 [(SA689)]  
MSP430F2254IDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2254IRHA@QFN40 [(SA750)]  
MSP430F2254IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2254TDA@SSOP38 [(SA689)]  
MSP430F2254TDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2254TRHA@QFN40 [(SA750)]  
MSP430F2254TRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2272IDA@SSOP38 [(SA689)]  
MSP430F2272IDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2272IRHA@QFN40 [(SA750)]  
MSP430F2272IRHA@QFN40(ISP) [ISP-HEADER01]  
MSP430F2272TDA@SSOP38 [(SA689)]  
MSP430F2272TDA@SSOP38(ISP) [ISP-HEADER01]  
MSP430F2272TRHA@QFN40 [(SA750)]

MSP430F2272TRHA@QFN40 (ISP) [ISP-HEADER01]  
MSP430F2274IDA@SSOP38 [(SA689)]  
MSP430F2274IDA@SSOP38 (ISP) [ISP-HEADER01]  
MSP430F2274IRHA@QFN40 [(SA750)]  
MSP430F2274IRHA@QFN40 (ISP) [ISP-HEADER01]  
MSP430F2274TDA@SSOP38 [(SA689)]  
MSP430F2274TDA@SSOP38 (ISP) [ISP-HEADER01]  
MSP430F2274TRHA@QFN40 [(SA750)]  
MSP430F2274TRHA@QFN40 (ISP) [ISP-HEADER01]  
MSP430F2330IRHA@QFN40 [(SA750)]           MSP430F2330TRHA@QFN40  
[(SA750)]  
MSP430F2350IRHA@QFN40 [(SA750)]           MSP430F2350TRHA@QFN40  
[(SA750)]  
MSP430F2370IRHA@QFN40 [(SA750)]           MSP430F2370TRHA@QFN40  
[(SA750)]  
MSP430F415@TQFP64(\*) [(SA732+B320)]  
MSP430F415@TQFP64 (ISP) [ISP-HEADER01]  
MSP430F417@TQFP64(\*) [(SA732+B320)]  
MSP430F417@TQFP64 (ISP) [ISP-HEADER01]  
MSP430F4250@QFN48 [(SA696)]           MSP430F4250@SSOP48  
[(SA669)]  
MSP430F4260@QFN48 [(SA696)]           MSP430F4260@SSOP48  
[(SA669)]  
MSP430F4270@QFN48 [(SA696)]           MSP430F4270@SSOP48  
[(SA669)]  
MSP430FE423@TQFP64(\*) [(SA732+B320)]  
MSP430FE423@TQFP64 (ISP) [ISP-HEADER01]  
MSP430FE425@TQFP64(\*) [(SA732+B320)]  
MSP430FE425@TQFP64 (ISP) [ISP-HEADER01]  
MSP430FE427@TQFP64(\*) [(SA732+B320)]  
MSP430FE427@TQFP64 (ISP) [ISP-HEADER01]  
MSP430FG437@TQFP100 (ISP) [ISP-HEADER01]  
MSP430FG437@TQFP80 (ISP) [ISP-HEADER01]  
MSP430FG438@TQFP100 (ISP) [ISP-HEADER01]  
MSP430FG438@TQFP80 (ISP) [ISP-HEADER01]  
MSP430FG439@TQFP100 (ISP) [ISP-HEADER01]  
MSP430FG439@TQFP80 (ISP) [ISP-HEADER01]  
MSP430P112                           MSP430P112@SOIC20  
[(SA404)]  
PMS430E112                           PMS430E112@SOIC20  
[(SA404)]

**TMC****E ( E ) PROM / FRAM / NVRAM**

24A01 [ ( SA602A ) ] 24A01@TSSOP8 [ ( SA026 ) ] 24A02 24A02@SOIC8 [ ( SA602A ) ] [ ( SA026 ) ] 24A04 [ ( SA602A ) ] 24A04@TSSOP8 [ ( SA026 ) ] 24A08 24A08@SOIC8 [ ( SA602A ) ] [ ( SA026 ) ] 24A16 [ ( SA602A ) ] 24A16@TSSOP8 [ ( SA026 ) ] ( 08bit ) 93LC46 ( 08bit ) @SOIC8 [ ( SA602A ) ] [ ( SA026 ) ] 93LC46 ( 16bit ) [ ( SA602A ) ] 93LC46 ( 16bit ) @TSSOP8 [ ( SA026 ) ] ( 08bit ) 93LC56 ( 08bit ) @SOIC8 [ ( SA602A ) ] [ ( SA026 ) ] 93LC56 ( 16bit ) [ ( SA602A ) ] 93LC56 ( 16bit ) @TSSOP8 [ ( SA026 ) ] 93LC57 93LC57@SOIC8 [ ( SA602A ) ] [ ( SA026 ) ] 93LC66 ( 08bit ) [ ( SA602A ) ] 93LC66 ( 08bit ) @TSSOP8 [ ( SA026 ) ] ( 16bit ) 93LC66 ( 16bit ) @SOIC8 [ ( SA602A ) ] [ ( SA026 ) ] 93LC86 ( 08bit ) [ ( SA602A ) ] 93LC86 ( 08bit ) @TSSOP8 [ ( SA026 ) ]	24A01@SOIC8    24A02@TSSOP8  24A04@SOIC8    24A08@TSSOP8  24A16@SOIC8  93LC46  93LC46 ( 08bit ) @TSSOP8  93LC46 ( 16bit ) @SOIC8  93LC56  93LC56 ( 08bit ) @TSSOP8  93LC56 ( 16bit ) @SOIC8  93LC57@TSSOP8  93LC66 ( 08bit ) @SOIC8  93LC66  93LC66 ( 16bit ) @TSSOP8  93LC86 ( 08bit ) @SOIC8  93LC86
---	--



(16bit)

93LC86(16bit)@SOIC8 [(SA602A)]  
[(SA026)]

93LC86(16bit)@TSSOP8

## TOPRO

### MICROCONTROLLER

TP2804H  
[(SA244)]  
TP2804H@TQFP44 [(SA245A)]  
TP2804L  
TP2804L@PLCC44 [(SA244)]  
[(SA245A)]  
TP2808H  
[(SA244)]  
TP2808H@TQFP44 [(SA245A)]  
TP2808L  
TP2808L@PLCC44 [(SA244)]  
[(SA245A)]

TP2804H@PLCC44  
  
TP2804L@TQFP44  
  
TP2808H@PLCC44  
  
TP2808L@TQFP44

## TOSHIBA

### E(E) PROM/FRAM/NVRAM

TC541000AF@PLCC32 [(SA015A1T)]  
TC541000AP  
TC541001AF@PLCC32 [(SA015A1T)]  
TC541001AP  
TC54256AF  
[(SA404)]  
TC54256AP  
[(SA404)]  
TC544000P  
TC54512AF  
TC54512AP  
TC571000  
TC571000AD  
TC571000D  
TC571001AD

TC54256AF@SOIC28  
  
TC54256AP@SOIC28

TC571001D  
TC571024D  
TC57256  
TC57256A  
TC57256AD  
TC57256ADI  
TC57256D  
TC574000D  
TC574096D  
TC574200D  
TC57512  
TC57512AD  
TC578200D  
TC57H1000AD  
TC57H1001AD  
TC57H256D TC58128AFT@TSOP48 [ (SA247-  
B005) ]  
TC58512FT@TSOP48 [ (SA247-B005) ]  
TC58DVG02A1FT00@TSOP48 [ (SA247-B005) ]  
TC58DVG02A2FT00@TSOP48 [ (SA247-B005) ]  
TC58DVM72A1FT00@TSOP48 [ (SA247-B005) ]  
TC58DVM72A1TG00@TSOP48 [ (SA247-B005) ]  
TC58DVM82A1FT00@TSOP48 [ (SA247-B005) ]  
TC58DVM82A1XBJ1@TFBGA56 [ (SA642U-B197-T064F001Y) ]  
TC58DVM92A1FT00@TSOP48 [ (SA247-B005) ]  
TC58F400@PSOP44 [ (SA638-B006) ] TC58F400@TSOP48 [ (SA247-  
B005) ]  
TC58F401@PSOP44 [ (SA638-B006) ] TC58F401@TSOP48 [ (SA247-  
B005) ]  
TC58FVB004FT@TSOP40 [ (SA409T) ] TC58FVB008FT@TSOP40  
[ (SA409T) ]  
TC58FVB016FT@TSOP40 [ (SA409T) ]  
TC58FVB160AFT@TSOP48 [ (SA247-B005) ]  
TC58FVB160AXB@TFBGA48 [ (SA642B\_B026A-Y072F001) ]  
TC58FVB160FT@TSOP48 [ (SA247-B005) ]  
TC58FVB321FT@TSOP48 [ (SA247-B005) ]  
TC58FVB321XB@TFBGA56 [ (SA642A-B026A-Y096F001) ]  
TC58FVB400F@PSOP44 [ (SA638) ]  
TC58FVB400FT@TSOP48 [ (SA247-B005) ]  
TC58FVB641FT@TSOP48 [ (SA247-B005) ]  
TC58FVB641XB@TFBGA63 [ (SA642A-B026A-Y096N001) ]  
TC58FVB800F@PSOP44 [ (SA638) ]  
TC58FVB800FT@TSOP48 [ (SA247-B005) ]

TC58FVM5B2AFT@TSOP48 [ (SA247-B005) ]  
TC58FVM5B2ATG@TSOP48 [ (SA247-B005) ]  
TC58FVM5B2AXB@TFBGA56 [ (SA642B-B026A-Y072F001) ]  
TC58FVM5B2AXG@TFBGA56 [ (SA642B-B026A-Y072F001) ]  
TC58FVM5B3AFT@TSOP48 [ (SA247-B005) ]  
TC58FVM5B3ATG@TSOP48 [ (SA247-B005) ]  
TC58FVM5B3AXB@TFBGA56 [ (SA642B-B026A-Y072F001) ]  
TC58FVM5B3AXG@TFBGA56 [ (SA642B-B026A-Y072F001) ]  
TC58FVM5T2AFT@TSOP48 [ (SA247-B005) ]  
TC58FVM5T2ATG@TSOP48 [ (SA247-B005) ]  
TC58FVM5T2AXB@TFBGA56 [ (SA642B-B026A-Y072F001) ]  
TC58FVM5T2AXG@TFBGA56 [ (SA642B-B026A-Y072F001) ]  
TC58FVM5T3AFT@TSOP48 [ (SA247-B005) ]  
TC58FVM5T3ATG@TSOP48 [ (SA247-B005) ]  
TC58FVM5T3AXB@TFBGA56 [ (SA642B-B026A-Y072F001) ]  
TC58FVM5T3AXG@TFBGA56 [ (SA642B-B026A-Y072F001) ]  
TC58FVM6B2AFT@TSOP48 [ (SA247-B005) ]  
TC58FVM6B2AXB@TFBGA63 [ (SA642B-B026A-Y072F001) ]  
TC58FVM6B5BTG@TSOP48 [ (SA247-B005) ]  
TC58FVM6B5BXG@TFBGA56 [ (SA642U-B026A-T064F001Y) ]  
TC58FVM6T2AFT@TSOP48 [ (SA247-B005) ]  
TC58FVM6T2AXB@TFBGA63 [ (SA642B-B026A-Y072F001) ]  
TC58FVM6T5BTG@TSOP48 [ (SA247-B005) ]  
TC58FVM6T5BXG@TFBGA56 [ (SA642U-B026A-T064F001Y) ]  
TC58FVM7B2AFT@TSOP56 [ (SA628-B045) ]  
TC58FVM7B5BTG@TSOP56 [ (SA628-B102) ]  
TC58FVM7B5BXG@FBGA80 [ (SA642R-B099A-T096F001Y) ]  
TC58FVM7T2AFT@TSOP56 [ (SA628-B045) ]  
TC58FVM7T5BTG@TSOP56 [ (SA628-B102) ]  
TC58FVM7T5BXG@FBGA80 [ (SA642R-B099A-T096F001Y) ]  
TC58FVT004FT@TSOP40 [ (SA409T) ]            TC58FVT008FT@TSOP40  
[ (SA409T) ]  
TC58FVT016FT@TSOP40 [ (SA409T) ]  
TC58FVT160AFT@TSOP48 [ (SA247-B005) ]  
TC58FVT160AXB@TFBGA48 [ (SA642B\_B026A-Y072F001) ]  
TC58FVT160FT@TSOP48 [ (SA247-B005) ]  
TC58FVT321FT@TSOP48 [ (SA247-B005) ]  
TC58FVT321XB@TFBGA56 [ (SA642A-B026A-Y096F001) ]  
TC58FVT400F@PSOP44 [ (SA638) ]  
TC58FVT400FT@TSOP48 [ (SA247-B005) ]  
TC58FVT641FT@TSOP48 [ (SA247-B005) ]  
TC58FVT641XB@TFBGA63 [ (SA642A-B026A-Y096N001) ]  
TC58FVT800F@PSOP44 [ (SA638) ]

TC58FVT800FT@TSOP48 [(SA247-B005)]  
 TC58FYB160FT@TSOP48 [(SA247-B005)]  
 TC58FYT160FT@TSOP48 [(SA247-B005)]  
 TC58NVG0S3AFT05@TSOP48 [(SA247-B005)]  
 TC58V64BFT@TSOP44 [(SA645-B005)] TC89101  
 (08bit)  
 TC89101(16bit) TC89102  
 (08bit)  
 TC89102(16bit)  
 TC89121  
 TC89121@SOIC8 [(SA602A)]  
 TC89122  
 TC89122@SOIC8 [(SA602A)]  
 TC97101  
 TC9WMA1FK@US8 [(BBBB)] TC9WMA2FK@US8  
 [(BBBB)]  
 TC9WMB1AFK@US8 [(BBBB)] TC9WMB1AFU@SM8  
 [(SA666)]  
 TC9WMB1FK@US8 [(BBBB)] TC9WMB2AFK@US8  
 [(BBBB)]  
 TC9WMB2AFU@SM8 [(SA666)] TC9WMB2FK@US8  
 [(BBBB)]  
 TC9WMB4FU@SM8 [(SA666)] TC9WMB8FU@SM8  
 [(SA666)]  
 TC9WMC1FK@US8 [(BBBB)] TC9WMC1FU@SM8  
 [(SA666)]  
 TC9WMC2FK@US8 [(BBBB)] TC9WMC2FU@SM8  
 [(SA666)]  
 TC9WMC4FK@US8 [(BBBB)] TC9WMC4FU@SM8  
 [(SA602A)]  
 TH50VPF5582ADSB@FBGA73 [(SA642E-B032A-T072F001)]  
 TH50VPF5583ADSB@FBGA73 [(SA642E-B032A-T072F001)]  
 TH50VPF5682CDSB@FBGA73 [(SA642E-B032A-T072F001)]  
 TH50VPF5683CDSB@FBGA73 [(SA642E-B032A-T072F001)]  
 TH50VPF5782AASB@FBGA73 [(SA664A-B096A-W115F001Y)]  
 TH50VPF5783AASB@FBGA73 [(SA664A-B096A-W115F001Y)]  
 TH50VPF6782AASB@FBGA73 [(SA664A-B096A-W115F001Y)]  
 TH50VPF6783AASB@FBGA73 [(SA664A-B096A-W115F001Y)]  
 TH50VSF1480AASB@FBGA65 [(SA642A-B032A-Y096N001)]  
 TH50VSF1481AASB@FBGA65 [(SA642A-B032A-Y096N001)]  
 TH50VSF2480AASB@FBGA65 [(SA642A-B032A-Y096N001)]  
 TH50VSF2481AASB@FBGA65 [(SA642A-B032A-Y096N001)]  
 TH50VSF2580AASB@FBGA69 [(SA642A-B032A-Y096F001)]

TH50VSF2581AASB@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2582AASB@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2582ADSB@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2582BDSB@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2583AASB@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2583ADSB@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2583BDSB@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2590AASB@FBGA69 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2682BDSB@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF2683BDSB@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF3580AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3581AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3582AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3582BDSB@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF3583AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3583BDSB@FBGA73 [ ( SA642A-B032A-Y096F001 ) ]  
TH50VSF3680AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3681AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3682AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3682BDSB@FBGA73 [ ( SA642E-B032A-T072F001 ) ]  
TH50VSF3683AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF3683BDSB@FBGA73 [ ( SA642E-B032A-T072F001 ) ]  
TH50VSF4682AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]  
TH50VSF4683AASB@FBGA69 [ ( SA642A-B032A-Y096N001 ) ]

TMM24128  
TMM24128A  
TMM24128AP  
TMM24256  
TMM24256A  
TMM24256AP  
TMM24256B  
TMM24512  
TMM24512A  
TMM24512P  
TMM2464AP  
TMM27128  
TMM27128A  
TMM27128ADI  
TMM27128AP  
TMM27256  
TMM27256A  
TMM27256AD  
TMM27256ADI

TMM27256BD  
TMM27256BDI  
TMM27256D  
TMM27256DI  
TMM2732  
TMM2732A  
TMM2732D  
TMM27512  
TMM27512AD  
TMM27512ADI  
TMM27512D  
TMM27512DI  
TMM2764  
TMM2764AD  
TMM2764ADI  
TMM2764AP  
TMM2764D  
TMM2764DI  
TV00560002ADBB@FBGA73 [(SA642U-B095A-W064F001Y)]  
TV00560002DDGB@FBGA81 [(SA642R-B079A-T096F001N)]  
TV00560002EDGB@FBGA81 [(SA642R-B079A-T096F001N)]  
TV00560003ADBB@FBGA73 [(SA642U-B095A-W064F001Y)]  
TV00569002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00569002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00569002BABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00569002BABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00569003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00569003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00569003BABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00569003BABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00570002AABB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV00570002ADGB@FBGA85 [(SA642A-B039A-Y096F001Y)]  
TV00570003AABB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV00570003ADGB@FBGA85 [(SA642A-B039A-Y096F001Y)]  
TV00578002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00578002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00578002CABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00578002CABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00578003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00578003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00578003CABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00578003CABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00579002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]

TV00579002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00579002AAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00579002AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00579003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00579003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00579003AAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV00579003AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0057A002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0057A002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0057A002CAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0057A002CAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0057A003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0057A003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0057A003CAGD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0057A003CAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV00670002ADGB@FBGA81 [(SA642R-B079A-T096F001N)]  
TV00670002CABB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV00670002CAGB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV00670003ADGB@FBGA81 [(SA642R-B079A-T096F001N)]  
TV00670003CABB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV00670003CAGB@FBGA73 [(SA664A-B096A-W115F001Y)]  
TV0067A002AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0067A002AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TV0067A003AABD(NAND)@FBGA107 [(SA664A-B128A-W115F001Y)]  
TV0067A003AABD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TY00679002AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TY00679003AAGD(NOR)@FBGA107 [(SA664A-B127A-W115F001Y)]  
TY80008000AMGF@FBGA149 [(SA664G-B143A-Y144F001Y)]  
TY80008000DMGF@FBGA149 [(SA664G-B143A-Y144F001Y)]  
TY80009000AMBF@FBGA149 [(SA664G-B143A-Y144F001Y)]  
TY8000A010AMGF(HZ)@BGA149 [(SA664G-B143A-Y144F001Y)]  
TY8000A010AMGF@BGA149 [(SA664G-B143A-Y144F001Y)]  
TY90009000AMGF@FBGA149 [(SA664G-B143A-Y144F001Y)]  
TY90009400BMGF(HZ)@FBGA149 [(SA664G-B143A-Y144F001Y)]  
TY90009800AOGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
TY90009800COGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
TY90009C00AOGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
TY9000A000ALHF@BGA149 [(SA664G-B279-Y149F001Y)]  
TY9000A000CMHF@BGA149 [(SA664G-B279-Y149F001Y)]  
TY9000A000EMGF@BGA149 [(SA664G-B279-Y149F001Y)]  
TY9000A000GMGF@BGA149 [(SA664G-B143A-Y144F001Y)]  
TY9000A400AMGF(HZ)@BGA149 [(SA664G-B143A-Y144F001Y)]  
TY9000A400AMGF@BGA149 [(SA664G-B143A-Y144F001Y)]

TY9000A800AOGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY9000A800EOGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY9000A800GOGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY9000A800H0GG@TFBGA225 [(SA678L-B244-M225F001Y)]  
 TY9000AC00COGG@TFBGA225 [(SA678L-B244-Y225F001Y)]  
 TY9000C010ALHF@BGA149 [(SA664G-B279-Y149F001Y)]  
 TYA000AC00EOGG@TFBGA225 [(SA678L-B294-Y225F001Y)]  
 TYA000B400ALHF@BGA149 [(SA664G-B279-Y149F001Y)]  
 TYA000BC10A0GG@FBGA225 [(SA678L-B244-Y225F001Y)]

## DRAM & SRAM

TC518128 [(SA630)]	TC518128@SOIC32
TC518129 [(SA630)]	TC518129@SOIC32
TC51832 [(SA630)]	TC51832@SOIC28
TC518512 [(SA630)]	TC518512@SOIC32
TC551001FL [(SA630)]	TC551001FL@SOIC32
TC551001PL [(SA630)]	TC551001PL@SOIC32
TC55257 [(SA630)]	TC55257@SOIC28
TC55257L [(SA630)]	TC55257L@SOIC28
TC55258 [(SA630)]	TC55258@SOIC28
TC55258L [(SA630)]	TC55258L@SOIC28
TC55328 [(SA630)]	TC55328@SOIC28
TC5561P [(SA646)]	TC5561P@SOJ24
TC5562P [(SA646)]	TC5562P@SOJ24
TC5563APL [(SA630)]	TC5563APL@SOIC28
TC5564APL [(SA630)]	TC5564APL@SOIC28



TC5565AFL [ (SA630) ]	TC5565AFL@SOIC28
TC5565APL [ (SA630) ]	TC5565APL@SOIC28
TC5588 [ (SA630) ]	TC5588@SOIC28
TC55B88 [ (SA630) ]	TC55B88@SOIC28
TMM2018 [ (SA015A1T) ]	TMM2018@PLCC32
TMM2063 [ (SA630) ]	TMM2063@SOIC28

## MICROCONTROLLER

TMP68HC11E1@PLCC52(*) [ (SA647-B5202) ]	
TMP68HC11E9@PLCC52(*) [ (SA647-B5202) ]	
TMP68HC711E9@PLCC52(*) [ (SA647-B5202) ]	
TMP86P202M@SOIC20 [ (SA023A) ]	
TMP86P202P	
TMP86P203M@SOIC20 [ (SA023A) ]	
TMP86P203P	
TMP86P807M@SOP28 [ (SA438T) ]	TMP86P807N@SDIP28
[ (SA653) ]	
TMP86PH06N@SDIP42 [ (SA028+B005) ]	TMP86PH06U@QFP44 [ (SA245A+B005) ]
TMP86PM47U@QFP44 [ (SA245A+B005) ]	
TMP86PM47UG@QFP44 [ (SA245A+B005) ]	
TMP86PS44@LQFP44 [ (SA245A) ]	TMP87P408M@SOIC28
[ (SA404) ]	
TMP87P408N@SDIP28 [ (SA022A) ]	TMP87P409M@SOIC28
[ (SA404) ]	
TMP87P409N@SDIP28 [ (SA022A) ]	TMP87P808LM@SOP28
[ (SA404) ]	
TMP87P808LM@SOP28(Toshiba) [ (BM11116) ]	
TMP87P808LN@SDIP28 [ (SA022A) ]	
TMP87P808LN@SDIP28(Toshiba) [ (BM11122) ]	
TMP87P808M@SOP28 [ (SA404) ]	
TMP87P808M@SOP28(Toshiba) [ (BM11116) ]	
TMP87P808N@SDIP28 [ (SA022A) ]	
TMP87P808N@SDIP28(Toshiba) [ (BM11122) ]	
TMP87P844N@SDIP42 [ (SA028) ]	

TMP87P844N@SDIP42(Toshiba) [(BM11108)]  
TMP87P844NG@SDIP42 [(SA028)]  
TMP87P844NG@SDIP42(Toshiba) [(BM11108)]  
TMP87PH00DF@QFP64(Toshiba) [(BM1173)]  
TMP87PH00F@QFP64(\*) [(TA022-B006)]  
TMP87PH00F@QFP64(Toshiba) [(BM1137)]  
TMP87PH00LF@QFP64(Toshiba) [(BM1173)]  
TMP87PH00N@SDIP64(\*) [(S600A-B6402)]  
TMP87PH00N@SDIP64(Toshiba) [(BM1136)]  
TMP87PH20F@QFP80(Toshiba) [(BM1138)]  
TMP87PH40AF@PQFP64(\*) [(TA022-B006)]  
TMP87PH40AF@PQFP64(Toshiba) [(BM1137)]  
TMP87PH40AN@SDIP64(\*) [(S600A-B6402)]  
TMP87PH40AN@SDIP64(Toshiba) [(BM1136)]  
TMP87PH46N@SDIP42 [(SA028)]  
TMP87PH46N@SDIP42(Toshiba) [(BM1193)]  
TMP87PH47LU@QFP44 [(SA245A)]  
TMP87PH47LU@QFP44(Toshiba) [(BM1194C)]  
TMP87PH47U@QFP44 [(SA245A)]  
TMP87PH47U@QFP44(Toshiba) [(BM1194C)]  
TMP87PM14F@QFP64(Toshiba) [(BM1199)]  
TMP87PM14N@SDIP64(Toshiba) [(BM1198)]  
TMP87PM20F@QFP80(Toshiba) [(BM1138)]  
TMP87PM29U@LQFP64(Toshiba) [(BM11117)]  
TMP87PM34AN@SDIP42(Toshiba) [(BM1183A)]  
TMP87PM36N@SDIP42(Toshiba) [(BM1183A)]  
TMP87PM40AF@PQFP64(\*) [(TA022-B006)]  
TMP87PM40AF@PQFP64(Toshiba) [(BM1137)]  
TMP87PM40AN@SDIP64(\*) [(S600A-B6402)]  
TMP87PM40AN@SDIP64(Toshiba) [(BM1136)]  
TMP87PM41F@QFP64(\*) [(TA022-B006)]  
TMP87PM41F@QFP64(Toshiba) [(BM1137)]  
TMP87PM41N@SDIP64(\*) [(S600A-B6402)]  
TMP87PM41N@SDIP64(Toshiba) [(BM1136)]  
TMP87PM41U@LQFP64(Toshiba) [(BM1121)]  
TMP87PM43N@SDIP42 [(SA028)]  
TMP87PM43N@SDIP42(Toshiba) [(BM1163)]  
TMP87PM70F@QFP80(Toshiba) [(BM1150B)]  
TMP87PM74F@QFP80(Toshiba) [(BM11120)]  
TMP87PM75F@QFP100(Toshiba) [(BM11124)]  
TMP87PM78F@QFP100(Toshiba) [(BM1188)]  
TMP87PP21DF@LQFP80(Toshiba) [(BM11105)]  
TMP87PP21F@QFP80(Toshiba) [(BM11104)]

TMP87PP23F@QFP100(Toshiba) [(BM1185A)]  
TMP87PP24F@LQFP100(Toshiba) [(BM11127)]  
TMP87PP71F@QFP80(Toshiba) [(BM11107)]  
TMP87PS38F@QFP44 [(SA679)]  
TMP87PS38F@QFP44(Toshiba) [(BM11136)]  
TMP87PS38N@SDIP42 [(SA028)]  
TMP87PS38N@SDIP42(Toshiba) [(BM11112)]  
TMP87PS39F@QFP64(Toshiba) [(BM11138)]  
TMP87PS39N@SDIP64(Toshiba) [(BM11118)]  
TMP87PS64F@QFP100(Toshiba) [(BM1185A)]  
TMP87PS71F@QFP80(Toshiba) [(BM11107)]  
TMP93PW44ADF@PQFP80 [(SA730+B263)]

## TOSHIBA-CUSTOMER

### E ( E ) PROM / FRAM / NVRAM

TC58DAM72A1F@TSOP48 [(SA247-B005)]  
TC58DVM72A1F@TSOP48 [(SA247-B005)]  
TC58DVM82A1@FBGA63 [(SA642B-B026A-Y072F001)]  
TC58DVM82A1@TSOP48 [(SA247-B005)]  
TY9000A000EMGF(YH)@BGA149 [(SA664G-B279-Y149F001Y)]

### MICROCONTROLLER

TMP87PM40AF@PQFP64(\*) [(TA022-B006)]  
TMP87PM40AN@SDIP64(\*) [(S600A-B6402)]

## TURBO IC

### E ( E ) PROM / FRAM / NVRAM

TU24C01 [(SA602A)]	TU24C01@SOIC8
TU24C02 [(SA602A)]	TU24C02@SOIC8
TU24C04 [(SA602A)]	TU24C04@SOIC8
TU24C08	TU24C08@SOIC8

[ ( SA602A ) ]	
TU24C128	TU24C128@SOIC8
[ ( SA602A ) ]	
TU24C16	TU24C16@SOIC8
[ ( SA602A ) ]	
TU24C16@TSSOP8 [ ( SA026 ) ]	
TU24C256	
TU24C256@SOIC8 [ ( SA602A ) ]	
TU24C32	
TU24C32@SOIC8 [ ( SA602A ) ]	
TU24C64	
TU24C64@SOIC8 [ ( SA602A ) ]	

## UBICOM

### MICROCONTROLLER

SX20AC/SS/G@SSOP20 [ ( SA626A ) ]	SX20AC/SS@SSOP20
[ ( SA626A ) ]	
SX28AC/DP	SX28AC/DP/
G	
SX28AC/SS/G@SSOP28 [ ( SA626A ) ]	SX28AC/SS@SSOP28
[ ( SA626A ) ]	
SX48BD/G@TQFP48 [ ( SA248 ) ]	SX48BD@TQFP48
[ ( SA248 ) ]	

## UMC

### E ( E ) PROM / FRAM / NVRAM

2732  
2764

### DRAM & SRAM

UM6116	UM6116@PLCC32
[ ( SA015A1T ) ]	
UM6116A	UM6116A@PLCC32
[ ( SA015A1T ) ]	

UM61256 [ (SA630) ]	UM61256@SOIC28
UM61257	
UM61512	
UM61512@SOIC32 [ (SA630) ]	
UM6164	
UM6164@SOIC28 [ (SA630) ]	
UM6167	
UM621024 [ (SA630) ]	UM621024@SOIC32
UM62256 [ (SA630) ]	UM62256@SOIC28
UM62256A [ (SA630) ]	UM62256A@SOIC28
UM6264 [ (SA630) ]	UM6264@SOIC28
UM6264A [ (SA630) ]	UM6264A@SOIC28

## UTRON

### E ( E ) PROM / FRAM / NVRAM

UT61256C [ (SA630) ]	UT61256C@SOIC28
UT61256C@TSOP28 [ (SA430T) ] [ (SA630) ]	UT6164C@SOIC28
UT6164C@TSOP28 [ (SA430T) ]	
UT61L256C UT61L256C@SOIC28 [ (SA630) ] [ (SA430T) ]	UT61L256C@TSOP28
UT62256C [ (SA630) ]	UT62256C@SOIC28
UT62256C@TSOP28 [ (SA430T) ]	
UT62256CE UT62256CE@SOIC28 [ (SA630) ] [ (SA430T) ]	UT62256CE@TSOP28
UT62257C [ (SA630) ]	UT62257C@SOIC28
UT62257C@TSOP28 [ (SA430T) ]	
UT6264C UT6264C@SOIC28 [ (SA630) ]	

UT62L256C  
UT62L256C@SOIC28 [(SA630)]  
[(SA430T)]  
UT62L64C  
[(SA630)]  
UT62W256C  
[(SA630)]  
UT62W256C@TSOP28 [(SA430T)]  
UT62W64C  
UT62W64C@SOIC28 [(SA630)]

UT62L256C@TSOP28  
  
UT62L64C@SOIC28  
  
UT62W256C@SOIC28

## VANTIS

### PLD

PALCE20RA10  
[(SA008A)]  
PALCE20RA10@SOIC24 [(SA404)]  
PALCE20RA10H  
PALCE20RA10H@PLCC28 [(SA008A)]  
[(SA404)]  
PALCE20RA10Q  
[(SA008A)]  
PALCE20RA10Q@SOIC24 [(SA404)]

PALCE20RA10@PLCC28  
  
  
  
PALCE20RA10H@SOIC24  
  
PALCE20RA10Q@PLCC28

## VERSACHIPS

### MICROCONTROLLER

V87C54  
[(SA244)]  
V87C54@TQFP44 [(SA245A)]  
V87C58  
V87C58@PLCC44 [(SA244)]  
[(SA245A)]

V87C54@PLCC44  
  
  
  
V87C58@TQFP44

## VLSI

### E(E) PROM/FRAM/NVRAM

VT27C128  
VT27C256  
VT27C512  
VT27C64  
VT28H64  
VT28HC64

## PLD

GAL16V8

## WELTREND

### MICROCONTROLLER

WT61P4K420@SDIP42 [(SA028)] [(SA028)]	WT61P4K421@SDIP42
WT61P4K422@SDIP42 [(SA028)] [(SA244)]	WT61P4L440@PLCC44
WT61P4N400	
WT61P4N401	
WT61P6K420@SDIP42 [(SA028)] [(SA244)]	WT61P6L440@PLCC44
WT61P6L441@PLCC44 [(SA244)] +B258)]	WT61P6S@LQFP44 [(SA245A
WT61P7@LQFP44 [(SA245)] [(SA244)]	WT61P7@PLCC44
WT61P7@TQFP48 [(SA248+B250)] +B258)]	WT61P8@LQFP44 [(SA245A
WT61P8S@LQFP44 [(SA245A+B005)] [(SA028)]	WT62P1-K42@SDIP42
WT62P1-N28(dip28) (dip40)	WT62P1-N40
WT62P1-N42(dip42) [(SA638)]	WT62P1-S44@PSOP44
WT62P2-K42@SDIP42 [(SA028)] [(SA244)]	WT62P2-L44@PLCC44
WT62P2-N40(dip40) (dip42)	WT62P2-N42
WT62P2-S44@PSOP44 [(SA638)]	WT65F1@SOIC28

[ ( SA404 ) ]  
WT65F1@TQFP48 [ ( SA248 ) ]

## WHITE ELECTRONIC DESIGNS

### E ( E ) PROM / FRAM / NVRAM

WE128K8	
WE256K8	
WE512K8	
WF256K8	
WF256K8@CLCC32 [ ( SA015A1T ) ]	WF256K8@CSOJ32
[ ( SA661 ) ]	
WF512K8	WF512K8@CLCC32
[ ( SA015A1T ) ]	
WF512K8@CSOJ32 [ ( SA661 ) ]	
WME128K8	
WME128K8@CLCC32 [ ( SA015A1T ) ]	WME128K8@CSOJ32
[ ( SA661 ) ]	
WMF128K8	WMF128K8@CLCC32
[ ( SA015A1T ) ]	
WMF128K8@CSOJ32 [ ( SA661 ) ]	
WMF256K8	
WMF256K8@CLCC32 [ ( SA015A1T ) ]	WMF256K8@CSOJ32
[ ( SA661 ) ]	
WMF512K8	WMF512K8@CLCC32
[ ( SA015A1T ) ]	
WMF512K8@CSOJ32 [ ( SA661 ) ]	
WMS128K8	
WMS128K8@CLCC32 [ ( SA015A1T ) ]	WMS128K8@CSOJ32
[ ( SA661 ) ]	
WMS256K8	WMS256K8@CLCC32
[ ( SA015A1T ) ]	
WMS256K8@CSOJ32 [ ( SA661 ) ]	
WMS512K8	
WMS512K8@CLCC32 [ ( SA015A1T ) ]	WMS512K8@CSOJ32
[ ( SA661 ) ]	

## WINBOND



**E ( E ) PROM / FRAM / NVRAM**

W15B020L	W15B020L@SOIC8
[ ( SA602A ) ]	
W15B020M	W15B020M@SOIC8
[ ( SA602A ) ]	
W15B040L	W15B040L@SOIC8
[ ( SA602A ) ]	
W15B040M	W15B040M@SOIC8
[ ( SA602A ) ]	
W19B160BB@FBGA48	[ ( SA642G-B026A-T048F001Y ) ]
W19B160BB@TSOP48	[ ( SA247-B005 ) ]
W19B160BT@FBGA48	[ ( SA642G-B026A-T048F001Y ) ]
W19B160BT@TSOP48	[ ( SA247-B005 ) ]
W19B320AB@FBGA48	[ ( SA642A-B026A-Y096F001Y ) ]
W19B320AB@TSOP48	[ ( SA247-B005 ) ]
W19B320AT@FBGA48	[ ( SA642A-B026A-Y096F001Y ) ]
W19B320AT@TSOP48	[ ( SA247-B005 ) ]
W19B320BB@FBGA48	[ ( SA642G-B026A-T048F001Y ) ]
W19B320BB@TSOP48	[ ( SA247-B005 ) ]
W19B320BT@FBGA48	[ ( SA642G-B026A-T048F001Y ) ]
W19B320BT@TSOP48	[ ( SA247-B005 ) ]
W19B320SB@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19B320SB@TSOP48	[ ( SA247-B005 ) ]
W19B320ST@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19B320ST@TSOP48	[ ( SA247-B005 ) ]
W19B322MB@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19B322MB@TSOP48	[ ( SA247-B005 ) ]
W19B322MT@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19B322MT@TSOP48	[ ( SA247-B005 ) ]
W19B323MB@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19B323MB@TSOP48	[ ( SA247-B005 ) ]
W19B323MT@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19B323MT@TSOP48	[ ( SA247-B005 ) ]
W19B324MB@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19B324MB@TSOP48	[ ( SA247-B005 ) ]
W19B324MT@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19B324MT@TSOP48	[ ( SA247-B005 ) ]
W19L320SB@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19L320SB@TSOP48	[ ( SA247-B005 ) ]
W19L320ST@FBGA48	[ ( SA642F-B026A-T064F001 ) ]
W19L320ST@TSOP48	[ ( SA247-B005 ) ]
W25B40 ( Bottom Boot ) @SOIC8	[ ( SA602A ) ]

W25B40(Bottom Boot)@WSON8 [(SA683)]	
W25B40(Top Boot)@SOIC8 [(SA602A)]	
W25B40(Top Boot)@WSON8 [(SA683)]	
W25B40A(Bottom Boot)@SOIC8 [(SA602A)]	
W25B40A(Bottom Boot)@WSON8 [(SA683)]	
W25B40A(Top Boot)@SOIC8 [(SA602A)]	
W25B40A(Top Boot)@WSON8 [(SA683)]	
W25D10 [(SA602A)]	W25D10(SN)@SOIC8
W25D10(SS)@SOIC8 [(SA023A)] [(SA683)]	W25D10(ZP)@WSON8
W25D20 [(SA602A)]	W25D20(SN)@SOIC8
W25D20(SS)@SOIC8 [(SA023A)] [(SA683)]	W25D20(ZP)@WSON8
W25D40 [(SA602A)]	W25D40(SN)@SOIC8
W25D40(SS)@SOIC8 [(SA023A)] [(SA683)]	W25D40(ZP)@WSON8
W25D80 [(SA602A)]	W25D80(SN)@SOIC8
W25D80(SS)@SOIC8 [(SA023A)] [(SA683)]	W25D80(ZP)@WSON8
W25P10@SOIC8 [(SA602A)] [(SA683)]	W25P10@WSON8
W25P16@SOIC16 [(SA404)]	
W25P16@SOIC16(ISP) [ISP-HEADER01]	
W25P16@SOIC8 [(SA023A)] HEADER01]	W25P16@SOIC8(ISP) [ISP-
W25P16@WSON8 [(SA683)] HEADER01]	W25P16@WSON8(ISP) [ISP-
W25P20@SOIC8 [(SA602A)] [(SA683)]	W25P20@WSON8
W25P32@SOIC16 [(SA404)]	
W25P32@SOIC16(ISP) [ISP-HEADER01]	
W25P32@WSON8 [(SA683)] HEADER01]	W25P32@WSON8(ISP) [ISP-
W25P40@SOIC8 [(SA602A)] [(SA683)]	W25P40@WSON8
W25P64@SOIC16 [(SA404)]	
W25P64@SOIC16(ISP) [ISP-HEADER01]	
W25P64@WSON8 [(SA683)] HEADER01]	W25P64@WSON8(ISP) [ISP-

W25P80@SOIC8 [(SA602A)]	W25P80@WSON8
[(SA683)]	
W25Q16@SOIC16 [(SA404)]	
W25Q16@SOIC16(ISP) [ISP-HEADER01]	
W25Q16@SOIC8 [(SA023A)]	W25Q16@SOIC8(ISP) [ISP-
HEADER01]	
W25Q16@WSON8 [(SA683)]	W25Q16@WSON8(ISP) [ISP-
HEADER01]	
W25Q32@SOIC16 [(SA404)]	
W25Q32@SOIC16(ISP) [ISP-HEADER01]	
W25Q32@WSON8 [(SA683)]	W25Q32@WSON8(ISP) [ISP-
HEADER01]	
W25Q80@SOIC8 [(SA602A)]	W25Q80@WSON8
[(SA683)]	
W25X10	W25X10(SN)@SOIC8
[(SA602A)]	
W25X10(SS)@SOIC8 [(SA023A)]	W25X10(ZP)@WSON8
[(SA683)]	
W25X10L	W25X10L(SN)@SOIC8
[(SA602A)]	
W25X10L(ZP)@WSON8 [(SA683)]	
W25X10V	
W25X10V(SN)@SOIC8 [(SA602A)]	W25X10V(SS)@SOIC8
[(SA023A)]	
W25X10V(ZP)@WSON8 [(SA683)]	W25X16@SOIC16
[(SA404)]	
W25X16@SOIC16(ISP) [ISP-HEADER01]	
W25X16@SOIC8 [(SA023A)]	W25X16@SOIC8(ISP) [ISP-
HEADER01]	
W25X20	W25X20(SN)@SOIC8
[(SA602A)]	
W25X20(SS)@SOIC8 [(SA023A)]	W25X20(ZP)@WSON8
[(SA683)]	
W25X20L	W25X20L(SN)@SOIC8
[(SA602A)]	
W25X20L(ZP)@WSON8 [(SA683)]	
W25X20V	
W25X20V(SN)@SOIC8 [(SA602A)]	W25X20V(SS)@SOIC8
[(SA023A)]	
W25X20V(ZP)@WSON8 [(SA683)]	W25X32@SOIC16
[(SA404)]	
W25X32@SOIC16(ISP) [ISP-HEADER01]	
W25X32@SOIC8 [(SA023A)]	W25X32@SOIC8(ISP) [ISP-

HEADER01 ]	
W25X40	W25X40 (SN)@SOIC8
[ (SA602A) ]	
W25X40(SS)@SOIC8 [ (SA023A) ]	W25X40 (ZP)@WSON8
[ (SA683) ]	
W25X40L	W25X40L (SN)@SOIC8
[ (SA602A) ]	
W25X40L(SS)@SOIC8 [ (SA023A) ]	W25X40L (ZP)@WSON8
[ (SA683) ]	
W25X40V	W25X40V (SN)@SOIC8
[ (SA602A) ]	
W25X40V(SS)@SOIC8 [ (SA023A) ]	W25X40V (ZP)@WSON8
[ (SA683) ]	
W25X64@SOIC16 [ (SA404) ]	
W25X64@SOIC16(ISP) [ ISP-HEADER01 ]	
W25X64@SOIC8 [ (SA023A) ]	W25X64@SOIC8 (ISP) [ ISP-
HEADER01 ]	
W25X80	W25X80 (SN)@SOIC8
[ (SA602A) ]	
W25X80(SS)@SOIC8 [ (SA023A) ]	W25X80 (ZP)@WSON8
[ (SA683) ]	
W25X80L	W25X80L (SS)@SOIC8
[ (SA023A) ]	
W25X80L (ZP)@WSON8 [ (SA683) ]	
W25X80V	
W25X80V (SN)@SOIC8 [ (SA602A) ]	W25X80V (SS)@SOIC8
[ (SA023A) ]	
W25X80V (ZP)@WSON8 [ (SA683) ]	
W27C01	
W27C01@PLCC32 [ (SA015A1T) ]	W27C01@VSOP32
[ (SA620) ]	
W27C010	W27C010@PLCC32
[ (SA015A1T) ]	
W27C010@SOIC32 [ (SA438T) ]	
W27C02	
W27C02@PLCC32 [ (SA015A1T) ]	W27C02@VSOP32
[ (SA620) ]	
W27C020	W27C020@PLCC32
[ (SA015A1T) ]	
W27C020M	W27C020M@PLCC32
[ (SA015A1T) ]	
W27C257	W27C257@PLCC32
[ (SA015A1T) ]	

W27C4096 [ (SA244) ]	W27C4096@PLCC44
W27C4096@TSOP40 [ (SA409T) ]	
W27C512	
W27C512@PLCC32 [ (SA015A1T) ]	W27C512@TSOP28
[ (SA430T) ]	
W27C520@SOIC20 [ (SA404) ]	W27C520@TSSOP20
[ (SA026) ]	
W27E01	W27E01@PLCC32
[ (SA015A1T) ]	
W27E01@VSOP32 [ (SA620) ]	
W27E010	
W27E010@PLCC32 [ (SA015A1T) ]	W27E010@SOIC32
[ (SA438T) ]	
W27E02	W27E02@PLCC32
[ (SA015A1T) ]	
W27E02@VSOP32 [ (SA620) ]	
W27E020	
W27E020@PLCC32 [ (SA015A1T) ]	
W27E040	
W27E040@PLCC32 [ (SA015A1T) ]	W27E040@SOIC32
[ (SA438T) ]	
W27E257	W27E257@PLCC32
[ (SA015A1T) ]	
W27E4096	W27E4096@PLCC44
[ (SA244) ]	
W27E4096@TSOP40 [ (SA409T) ]	
W27E512	
W27E512@PLCC32 [ (SA015A1T) ]	W27E512@TSOP28
[ (SA430T) ]	
W27E520@SOIC20 [ (SA404) ]	W27E520@TSSOP20
[ (SA026) ]	
W27L01	W27L01@PLCC32
[ (SA015A1T) ]	
W27L01@VSOP32 [ (SA620) ]	
W27L010	
W27L010@PLCC32 [ (SA015A1T) ]	
W27L02	
W27L02@PLCC32 [ (SA015A1T) ]	W27L02@VSOP32
[ (SA620) ]	
W27L520@SOIC20 [ (SA404) ]	W27L520@TSSOP20
[ (SA026) ]	
W28F321BB@FBGA48 [ (SA634A-B005A-Y048F001) ]	

W28F321BT@TSOP48 [ ( SA247-B005 ) ]  
W28F321TB@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
W28F321TT@TSOP48 [ ( SA247-B005 ) ]  
W28F641BB@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
W28F641BT@TSOP48 [ ( SA247-B005 ) ]  
W28F641TB@FBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
W28F641TT@TSOP48 [ ( SA247-B005 ) ]      W28J160BT@TSOP48 [ ( SA247-B005 ) ]  
W28J160TT@TSOP48 [ ( SA247-B005 ) ]  
W28J161BB@TFBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
W28J161TB@TFBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
W28J320BT@TSOP48 [ ( SA247-B005 ) ]      W28J320TT@TSOP48 [ ( SA247-B005 ) ]  
W28J321BB@TFBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
W28J321TB@TFBGA48 [ ( SA634A-B005A-Y048F001 ) ]  
W28J800BT@TSOP48 [ ( SA247-B005 ) ]      W28J800TT@TSOP48 [ ( SA247-B005 ) ]  
W28V400BT@TSOP48 [ ( SA247-B005 ) ]      W28V400TT@TSOP48 [ ( SA247-B005 ) ]  
W29C010      W29C010@PLCC32  
[ ( SA015A1T ) ]  
W29C011A      W29C011A@PLCC32  
[ ( SA015A1T ) ]  
W29C020      W29C020@PLCC32  
[ ( SA015A1T ) ]  
W29C020@SOIC32 [ ( SA438T ) ]      W29C020@TSOP32  
[ ( SA410T ) ]  
W29C020C  
W29C020C@PLCC32 [ ( SA015A1T-B001 ) ]  
W29C020C@TSOP32 [ ( SA410T-B003 ) ]      W29C020C@VSOP32 [ ( SA620-B005 ) ]  
W29C040      W29C040@PLCC32 [ ( SA015A1T-B001 ) ]  
B001 ) ]  
W29C040@TSOP32 [ ( SA410T-B003 ) ]      W29C040@VSOP32 [ ( SA620-B005 ) ]  
B005 ) ]  
W29C101      W29C101@PLCC44  
[ ( SA244 ) ]  
W29C101@TSOP40 [ ( SA409T ) ]  
W29C102  
W29C102@PLCC44 [ ( SA244 ) ]      W29C102@TSOP40  
[ ( SA409T ) ]  
W29EE010      W29EE010@PLCC32  
[ ( SA015A1T ) ]

W29EE010@SOIC32 [(SA438T)]	W29EE010@TSOP32
[(SA410T)]	
W29EE011	W29EE011@PLCC32
[(SA015A1T)]	
W29EE011@SOIC32 [(SA438T)]	
W29EE012	
W29EE012@PLCC32 [(SA015A1T)]	W29EE012@SOIC32
[(SA438T)]	
W29EE512	W29EE512@PLCC32
[(SA015A1T)]	
W29EE512@SOIC32 [(SA438T)]	W29EE512@TSOP32
[(SA410T)]	
W29F040	W29F040@PLCC32
[(SA015A1T)]	
W29F040@TSOP32 [(SA410T)]	W29F102@PLCC44
[(SA244)]	
W29F102@TSOP40 [(SA623)]	W29L102@PLCC44
[(SA244)]	
W29L102@TSOP40 [(SA623)]	
W39F010	
W39F010@PLCC32 [(SA015A1T-B001)]	
W39F010@TSOP32[12.4mm] [(SA620-B005)]	
W39F010@TSOP32[18.4mm] [(SA410T-B003)]	
W39L010@PLCC32 [(SA015A1T-B001)]	W39L010@TSOP32 [(SA620-
B005)]	
W39L020@PLCC32 [(SA015A1T-B001)]	
W39L020@TSOP32[12.4mm] [(SA620-B005)]	
W39L020@TSOP32[18.4mm] [(SA410T-B003)]	
W39L040@PLCC32 [(SA015A1T-B001)]	
W39L040@TSOP32[12.4mm] [(SA620-B005)]	
W39L040@TSOP32[18.4mm] [(SA410T-B003)]	
W39L040A	W39L040A@PLCC32
[(SA015A1T)]	
W39L040A@TSOP32 [(SA410T)]	W39L040A@VSOP32
[(SA620)]	
W39L512@PLCC32 [(SA015A1T-B001)]	W39L512@TSOP32 [(SA620-
B005)]	
W39V040AP@PLCC32 [(SA015A1T)]	W39V040AQ@VSOP32
[(SA620)]	
W39V040B(P)@PLCC32 [(SA015A1T)]	W39V040B(Q)@VSOP32
[(SA620)]	
W39V040CP@PLCC32 [(SA015A1T)]	W39V040CPZ@PLCC32
[(SA015A1T)]	

W39V040CQ@VSOP32 [(SA620)]	W39V040CQZ@VSOP32
[(SA620)]	
W39V040FAP@PLCC32 [(SA015A1T)]	W39V040FAQ@VSOP32
[(SA620)]	
W39V040FAT@TSOP40 [(SA409T)]	W39V040FB(P)@PLCC32
[(SA015A1T)]	
W39V040FB(Q)@VSOP32 [(SA620)]	W39V040FCP@PLCC32
[(SA015A1T)]	
W39V040FCPZ@PLCC32 [(SA015A1T)]	W39V040FCQ@VSOP32
[(SA620)]	
W39V040FCQZ@VSOP32 [(SA620)]	W39V080A(P)@PLCC32
[(SA015A1T)]	
W39V080A(Q)@VSOP32 [(SA620)]	W39V080A(T)@TSOP40
[(SA409T)]	
W39V080FA(P)@PLCC32 [(SA015A1T)]	W39V080FA(Q)@VSOP32
[(SA620)]	
W39V080FA(T)@TSOP40 [(SA409T)]	W45B012@PLCC32
[(SA015A1T)]	
W45B012@SON8 [(SA683)]	W45B512@PLCC32
[(SA015A1T)]	
W45B512@SON8 [(SA683)]	
W49F002	
W49F002@PLCC32 [(SA015A1T-B001)]	W49F002@TSOP32 [(SA410T-
B003)]	
W49F002B	
W49F002B@PLCC32 [(SA015A1T-B001)]	
W49F002B@TSOP32 [(SA410T-B003)]	
W49F002N	
W49F002N@PLCC32 [(SA015A1T-B001)]	
W49F002N@TSOP32 [(SA410T-B003)]	
W49F002U	
W49F002U@PLCC32 [(SA015A1T-B001)]	
W49F002U@TSOP32 [(SA410T-B003)]	
W49F020	
W49F020@PLCC32 [(SA015A1T)]	W49F020@TSOP32
[(SA410T)]	
W49F102@PLCC44 [(SA244)]	W49F102@TSOP40
[(SA623)]	
W49F201@PSOP44 [(SA638)]	W49F201@TSOP48 [(SA247-
B005)]	
W49L102@PLCC44 [(SA244)]	W49L102@TSOP40
[(SA623)]	
W49L201@PSOP44 [(SA638)]	W49L201@TSOP48 [(SA247-



B005) ]  
W49L401@PSOP44 [(SA638)]  
B005) ]  
W49L401T@PSOP44 [(SA638)]  
B005) ]  
W49V002A@PLCC32 [(SA015A1T)]  
[(SA620)]  
W49V002FA@PLCC32 [(SA015A1T)]  
[(SA620)]  
W49V002FP@PLCC32 [(SA015A1T)]  
[(SA620)]  
W49V002P@PLCC32 [(SA015A1T)]  
[(SA620)]  
W55F05  
W55F10A  
W55F20

W49L401@TSOP48 [(SA247-  
W49L401T@TSOP48 [(SA247-  
W49V002A@VSOP32  
W49V002FA@VSOP32  
W49V002FP@VSOP32  
W49V002P@VSOP32

## MICROCONTROLLER

W77E058  
[(SA244)]  
W77E058@TQFP44 [(SA245A)]  
W77E516  
W77E516@PLCC44 [(SA244)]  
[(SA245A)]  
W77E532  
[(SA244)]  
W77E532@TQFP44 [(SA245A)]  
W77E532A  
W77E532A@PLCC44 [(SA244)]  
[(SA245A)]  
W77E58  
[(SA244)]  
W77E58@TQFP44 [(SA245A)]  
W77IE58  
W77IE58@PLCC44 [(SA244)]  
[(SA245A)]  
W77L058  
[(SA244)]  
W77L058@TQFP44 [(SA245A)]  
W77L516A  
W77L516A@PLCC44 [(SA244)]

W77E058@PLCC44  
W77E516@TQFP44  
W77E532@PLCC44  
W77E532A@TQFP44  
W77E58@PLCC44  
W77IE58@TQFP44  
W77L058@PLCC44  
W77L516A@TQFP44

[ (SA245A) ]	
W77L532A	W77L532A@PLCC44
[ (SA244) ]	
W77L532A@TQFP44 [ (SA245A) ]	
W77LE516	
W77LE516@PLCC44 [ (SA244) ]	W77LE516@TQFP44
[ (SA245A) ]	
W77LE532	W77LE532@PLCC44
[ (SA244) ]	
W77LE532@TQFP44 [ (SA245A) ]	
W77LE58	
W77LE58@PLCC44 [ (SA244) ]	W77LE58@TQFP44
[ (SA245A) ]	
W78E051B	W78E051B@PLCC44
[ (SA244) ]	
W78E051B@TQFP44 [ (SA245A) ]	
W78E051C	
W78E051C@PLCC44 [ (SA244) ]	W78E051C@TQFP44
[ (SA245A) ]	
W78E052B	W78E052B@PLCC44
[ (SA244) ]	
W78E052B@TQFP44 [ (SA245A) ]	
W78E052C	
W78E052C@PLCC44 [ (SA244) ]	W78E052C@TQFP44
[ (SA245A) ]	
W78E054B	W78E054B@PLCC44
[ (SA244) ]	
W78E054B@TQFP44 [ (SA245A) ]	
W78E054C	
W78E054C@PLCC44 [ (SA244) ]	W78E054C@TQFP44
[ (SA245A) ]	
W78E058B	W78E058B@PLCC44
[ (SA244) ]	
W78E058B@TQFP44 [ (SA245A) ]	
W78E065	
W78E065@PLCC44 [ (SA244) ]	W78E065@TQFP44
[ (SA245A) ]	
W78E354(dip40)	W78E354
(dip48)	
W78E365	W78E365@PLCC44
[ (SA244) ]	
W78E365@TQFP44 [ (SA245A) ]	
W78E374B	

W78E378	
W78E378E	
W78E378P@PLCC44 [(SA244)]	
W78E51	
W78E51@PLCC44 [(SA244)]	W78E51@TQFP44
[(SA245A)]	
W78E516	W78E516@PLCC44
[(SA244)]	
W78E516@TQFP44 [(SA245A)]	
W78E516B	
W78E516B@PLCC44 [(SA244)]	W78E516B@TQFP44
[(SA245A)]	
W78E51B	W78E51B@PLCC44
[(SA244)]	
W78E51B@TQFP44 [(SA245A)]	
W78E51C	
W78E51C@PLCC44 [(SA244)]	W78E51C@TQFP44
[(SA245A)]	
W78E52	W78E52@PLCC44
[(SA244)]	
W78E52@TQFP44 [(SA245A)]	
W78E52B	
W78E52B@PLCC44 [(SA244)]	W78E52B@TQFP44
[(SA245A)]	
W78E52C	W78E52C@PLCC44
[(SA244)]	
W78E52C@TQFP44 [(SA245A)]	
W78E54	
W78E54@PLCC44 [(SA244)]	W78E54@TQFP44
[(SA245A)]	
W78E54B	W78E54B@PLCC44
[(SA244)]	
W78E54B@TQFP44 [(SA245A)]	
W78E54C	
W78E54C@PLCC44 [(SA244)]	W78E54C@TQFP44
[(SA245A)]	
W78E58	W78E58@PLCC44
[(SA244)]	
W78E58@TQFP44 [(SA245A)]	
W78E58B	
W78E58B@PLCC44 [(SA244)]	W78E58B@TQFP44
[(SA245A)]	
W78E62B	W78E62B@PLCC44

[ (SA244) ]	
W78E62B@TQFP44 [ (SA245A) ]	
W78E65	
W78E65@PLCC44 [ (SA244) ]	W78E65@TQFP44
[ (SA245A) ]	
W78E858	W78E858@PLCC44
[ (SA244) ]	
W78E858@TQFP44 [ (SA245A) ]	
W78ERD2	
W78ERD2@PLCC44 [ (SA244) ]	W78ERD2@TQFP44
[ (SA245A) ]	
W78I052	W78I052@PLCC44
[ (SA244) ]	
W78I054	W78I054@PLCC44
[ (SA244) ]	
W78IE52	W78IE52@PLCC44
[ (SA244) ]	
W78IE54	W78IE54@PLCC44
[ (SA244) ]	
W78IRD2	W78IRD2@PLCC44
[ (SA244) ]	
W78IRD2@TQFP44 [ (SA245A) ]	
W78L051	
W78L051@PLCC44 [ (SA244) ]	W78L051@TQFP44
[ (SA245A) ]	
W78L051C	W78L051C@PLCC44
[ (SA244) ]	
W78L051C@TQFP44 [ (SA245A) ]	
W78L052	
W78L052@PLCC44 [ (SA244) ]	W78L052@TQFP44
[ (SA245A) ]	
W78L052C	W78L052C@PLCC44
[ (SA244) ]	
W78L052C@TQFP44 [ (SA245A) ]	
W78L054	
W78L054@PLCC44 [ (SA244) ]	W78L054@TQFP44
[ (SA245A) ]	
W78L054C	W78L054C@PLCC44
[ (SA244) ]	
W78L054C@TQFP44 [ (SA245A) ]	
W78L058	
W78L058@PLCC44 [ (SA244) ]	W78L058@TQFP44
[ (SA245A) ]	

W78L365 [ (SA244) ]	W78L365@PLCC44
W78L365@TQFP44 [ (SA245A) ] B005 ]	W78L365@TQFP48 [ (SA248A-
W78L516 [ (SA244) ]	W78L516@PLCC44
W78L516@TQFP44 [ (SA245A) ]	
W78L812 W78L812@PLCC44 [ (SA244) ] [ (SA245A) ]	W78L812@TQFP44
W78LE365 [ (SA244) ]	W78LE365@PLCC44
W78LE365@TQFP44 [ (SA245A) ] B005 ]	W78LE365@TQFP48 [ (SA248A-
W78LE51 [ (SA244) ]	W78LE51@PLCC44
W78LE51@TQFP44 [ (SA245A) ]	
W78LE516 W78LE516@PLCC44 [ (SA244) ] [ (SA675) ]	W78LE516@TQFP44
W78LE51C [ (SA244) ]	W78LE51C@PLCC44
W78LE51C@TQFP44 [ (SA245A) ]	
W78LE52 W78LE52@PLCC44 [ (SA244) ] [ (SA245A) ]	W78LE52@TQFP44
W78LE52C [ (SA244) ]	W78LE52C@PLCC44
W78LE52C@TQFP44 [ (SA245A) ]	
W78LE54 W78LE54@PLCC44 [ (SA244) ] [ (SA245A) ]	W78LE54@TQFP44
W78LE54C [ (SA244) ]	W78LE54C@PLCC44
W78LE54C@TQFP44 [ (SA245A) ]	
W78LE58 W78LE58@PLCC44 [ (SA244) ] [ (SA245A) ]	W78LE58@TQFP44
W78LE812 [ (SA244) ]	W78LE812@PLCC44
W78LE812@TQFP44 [ (SA245A) ]	
W79E201 W79E201@PLCC44 [ (SA244) ]	W79E201@TQFP44

[(SA245A)]	
W79E2051(dip14)	W79E2051
(dip16)	
W79E2051(dip20)	W79E2051@SOP20
[(SA404A)]	
W79E2051@SSOP14 [(SA626A)]	W79E2051@SSOP16
[(SA626A)]	
W79E2051@SSOP20 [(SA626A)]	
W79E216AFG@PQFP100(*) [(SA741-B226)]	
W79E217AFG@PQFP100(*) [(SA741-B226)]	
W79E227A@LQFP48 [(SA248)]	W79E227A@PLCC44
[(SA244)]	
W79E4051(dip14)	W79E4051
(dip16)	
W79E4051(dip20)	W79E4051@SOP20
[(SA404A)]	
W79E4051@SSOP14 [(SA626A)]	W79E4051@SSOP16
[(SA626A)]	
W79E4051@SSOP20 [(SA626A)]	
W79E532	
W79E532@PLCC44 [(SA244)]	W79E532@TQFP44
[(SA245A)]	
W79E532A	W79E532A@PLCC44
[(SA244)]	
W79E532A@TQFP44 [(SA245A)]	
W79E632	
W79E632@PLCC44 [(SA244)]	W79E632@TQFP44
[(SA245A)]	
W79E633@PLCC44 [(SA244)]	
W79E648A@PLCC68(*) [(SA648-B6809)]	
W79E649A@PLCC68(*) [(SA648-B6809)]	
W79E659A@PQFP100(*) [(SA741-B233)]	
W79E801A	W79E801A@SOIC20
[(SA404)]	
W79E802A	W79E802A@SOIC20
[(SA404)]	
W79E803A	W79E803A@SOIC20
[(SA404)]	
W79E804A	W79E804A@SOIC20
[(SA404)]	
W79E821A	W79E821A@SOIC20
[(SA404)]	
W79E822A	W79E822A@SOIC20

[ (SA404) ]	
W79E822B	W79E822B@SOIC20
[ (SA404) ]	
W79E823A	W79E823A@SOIC20
[ (SA404) ]	
W79E823B	W79E823B@SOIC20
[ (SA404) ]	
W79E824A	W79E824A@SOIC20
[ (SA404) ]	
W79E825A	W79E825A@SOIC20
[ (SA404) ]	
W79E831A	W79E831A@SOIC28
[ (SA404) ]	
W79E832A	W79E832A@SOIC28
[ (SA404) ]	
W79E833A	W79E833A@SOIC28
[ (SA404) ]	
W79E834A	W79E834A@SOIC28
[ (SA404) ]	
W79L532	W79L532@PLCC44
[ (SA244) ]	
W79L532@TQFP44 [ (SA245A) ]	
W79L632	
W79L632@PLCC44 [ (SA244) ]	W79L632@TQFP44
[ (SA245A) ]	
W79L633@PLCC44 [ (SA244) ]	
W79L648A@PLCC68(*) [ (SA648-B6809) ]	
W79L649A@PLCC68(*) [ (SA648-B6809) ]	
W79L659A@PQFP100(*) [ (SA741-B233) ]	
W83L950D@TQFP80(*) [ (TA060-B006) ]	
W83L950G@TQFP80(*) [ (TA060-B006) ]	
W83L951D@LQFP128(*) [ (TA056-B006) ]	
W83L951DF@QFP128(*) [ (TA058-B084) ]	
W83L951DG@LQFP128(*) [ (TA056-B006) ]	
W83L951F@QFP128(*) [ (TA058-B084) ]	
W925EP01@PQFP100(*) [ (TA041-B006) ]	
W99100DG@TQFP48 [ (SA248A-B005) ]	

## WISTRON

### E ( E ) PROM / FRAM / NVRAM

MX29LV320CBB@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 MX29LV320CBE@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 MX29LV320CBT@TSOP48 [ (SA247-B005) ]  
 MX29LV320CTB@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 MX29LV320CTE@FBGA48 [ (SA642G-B026A-T048F001Y) ]  
 MX29LV320CTT@TSOP48 [ (SA247-B005) ]  
 MX29LV640BBT@TSOP48 [ (SA247-B005) ]  
 MX29LV640BBXB@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
 MX29LV640BT@TSOP48 [ (SA247-B005) ]  
 MX29LV640BTT@TSOP48 [ (SA247-B005) ]  
 MX29LV640BTXB@FBGA63 [ (SA642M-B026A-W048F001Y) ]  
 MX29LV640BXB@FBGA63 [ (SA642C-B026A-Y056F001) ]  
 MX29LV640BXC@FBGA64 [ (SA655A-B044A-T064F001) ]  
 MX29LV640TT@TSOP48 [ (SA247-B005) ]  
 MX29LV640TXB@FBGA63 [ (SA642C-B026A-Y056F001) ]  
 MX29LV640TXC@FBGA64 [ (SA655A-B044A-T064F001) ]  
 SST25LF016A@SOIC8 [ (SA602A) ]                      SST25LF016A@WS0N8  
 [ (SA683) ]  
 SST25LF016B@SOIC8 [ (SA602A) ]                      SST25LF016B@WS0N8  
 [ (SA683) ]  
 SST25VF016B@SOIC8 [ (SA602A) ]                      SST25VF016B@WS0N8  
 [ (SA683) ]

## MICROCONTROLLER

CY8C21334@SSOP20 [ (SA626A) ]

## WSI

### E (E) PROM / FRAM / NVRAM

WS27C010L    WS27C010L@PLCC32  
 [ (SA015A1T) ]  
 WS27C010L@TSOP32 [ (SA410T) ]  
 WS27C010R    WS27C010R@TSOP32  
 WS27C010R@PLCC32 [ (SA015A1T) ]  
 [ (SA410T) ]  
 WS27C040L    WS27C040L@PLCC32  
 [ (SA015A1T) ]  
 WS27C040L@TSOP32 [ (SA410T) ]  
 WS27C128F



WS27C128F@PLCC32 [ (SA015A1T) ]  
WS27C128L  
WS27C128L@PLCC32 [ (SA015A1T) ]  
WS27C210L  
WS27C210L@PLCC44 [ (SA244) ]  
WS27C256F  
WS27C256F@PLCC32 [ (SA015A1T) ]  
WS27C256L  
WS27C256L@PLCC32 [ (SA015A1T) ]  
WS27C512F  
WS27C512F@PLCC32 [ (SA015A1T) ]  
WS27C512L  
WS27C512L@PLCC32 [ (SA015A1T) ]  
WS27C64  
WS27C64@PLCC32 [ (SA015A1T) ]  
WS27C64F  
WS27C64F@PLCC32 [ (SA015A1T) ]  
WS27C64L  
WS27C64L@PLCC32 [ (SA015A1T) ]  
WS57C128  
WS57C128@PLCC32 [ (SA015A1T) ]  
WS57C128F  
WS57C128F@PLCC32 [ (SA015A1T) ]  
WS57C128FB  
WS57C128FB@PLCC32 [ (SA015A1T) ]  
WS57C191  
WS57C191@PLCC28 [ (SA008A) ]  
WS57C191B  
WS57C191B@PLCC28 [ (SA008A) ]  
WS57C191C  
WS57C191C@PLCC28 [ (SA008A) ]  
WS57C256F  
WS57C256F@PLCC32 [ (SA015A1T) ]  
WS57C256FB  
WS57C256FB@PLCC32 [ (SA015A1T) ]  
WS57C257  
WS57C257@PLCC44 [ (SA244) ]  
WS57C291  
WS57C291@PLCC28 [ (SA008A) ]  
WS57C291B  
WS57C291B@PLCC28 [ (SA008A) ]  
WS57C291C  
WS57C291C@PLCC28 [ (SA008A) ]

WS57C43  
WS57C43@PLCC28 [(SA008A)]  
WS57C43B  
WS57C43B@PLCC28 [(SA008A)]  
WS57C43C  
WS57C43C@PLCC28 [(SA008A)]  
WS57C45  
WS57C45@PLCC28 [(SA008A)]  
WS57C49  
WS57C49@PLCC28 [(SA008A)]  
WS57C49B  
WS57C49B@PLCC28 [(SA008A)]  
WS57C49C  
WS57C49C@PLCC28 [(SA008A)]  
WS57C51  
WS57C51@PLCC32 [(SA015A1T)]  
WS57C51B  
WS57C51B@PLCC32 [(SA015A1T)]  
WS57C51C  
WS57C51C@PLCC32 [(SA015A1T)]  
WS57C64F  
WS57C64F@PLCC32 [(SA015A1T)]  
WS57C71C  
WS57C71C@PLCC32 [(SA015A1T)]  
WS57LV191C  
WS57LV191C@PLCC28 [(SA008A)]  
WS57LV291C  
WS57LV291C@PLCC28 [(SA008A)]

## MICROCONTROLLER

PSD813F1@TQFP52(\*) [(TA071+B006)]  
PSD813F1V@TQFP52(\*) [(TA071+B006)]  
PSD813F2@TQFP52(\*) [(TA071+B006)]  
PSD813F2V@TQFP52(\*) [(TA071+B006)]  
PSD813F3@TQFP52(\*) [(TA071+B006)]  
PSD813F3V@TQFP52(\*) [(TA071+B006)]  
PSD813F4@TQFP52(\*) [(TA071+B006)]  
PSD813F4V@TQFP52(\*) [(TA071+B006)]  
PSD813F5@TQFP52(\*) [(TA071+B006)]  
PSD813F5V@TQFP52(\*) [(TA071+B006)]  
PSD833F2@TQFP52(\*) [(TA071+B006)]

PSD833F2V@TQFP52(\*) [(TA071+B006)]  
PSD853F2@TQFP52(\*) [(TA071+B006)]  
PSD853F2V@TQFP52(\*) [(TA071+B006)]

## XELTEK

### E ( E ) PROM / FRAM / NVRAM

S29GL128PFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL128PTAI01@TSOP56 [(SA628-B102)]  
S29GL256PFAI01@FBGA64 [(SA655F-B099A-W064F001Y)]  
S29GL256PTAI01@TSOP56 [(SA628-B102)]

### MICROCONTROLLER

#####1111111111111111  
#####2222222222222222  
#####3333333333333333  
#####4444444444444444  
#####9999999999999999 #####UPDATE-  
SP9000U  
ATMEGA168@TQFP32 [(SA636)] ATMEGA48@TQFP32  
[(SA636)]  
ATMEGA88@TQFP32 [(SA636)] ATMEGA8L(fast)@TQFP32  
[(SA636)]  
ATMEGA8L@TQFP32 [(SA636)]  
MK68F15P  
MK68F15S@SOP18 [(SA023A)] MK68F15X@SSOP20  
[(SA674)]  
MK68F30K MK68F30S@SOP28  
[(SA404)]  
MK68F30X@SSOP28 [(SA626A)] ST7FLI49MK1B6@SDIP32  
[(SA653)]  
ST7FLI49MK1T6@TQFP32 [(SA663)]  
ST7FLITE49  
ST7FLITE49@TQFP32 [(SA663)]

## XICOR

**E ( E ) PROM / FRAM / NVRAM**

X2004	X2004@PLCC32
[ ( SA015A1T ) ]	
X2004D	X2004D@PLCC32
[ ( SA015A1T ) ]	
X2004I	X2004I@PLCC32
[ ( SA015A1T ) ]	
X2210	X2210@SOIC16
[ ( SA404 ) ]	
X2210A	X2210A@SOIC16
[ ( SA404 ) ]	
X2210I	X2210I@SOIC16
[ ( SA404 ) ]	
X2212	X2212@SOIC20
[ ( SA404 ) ]	
X2212A	X2212A@SOIC20
[ ( SA404 ) ]	
X2212I	X2212I@SOIC20
[ ( SA404 ) ]	
X22C10	X22C10@SOIC16
[ ( SA404 ) ]	
X22C10I	X22C10I@SOIC16
[ ( SA404 ) ]	
X22C12	X22C12@SOIC20
[ ( SA404 ) ]	
X22C12I	X22C12I@SOIC20
[ ( SA404 ) ]	
X24012	X24012@SOIC8
[ ( SA602A ) ]	
X24022	X24022@SOIC8
[ ( SA602A ) ]	
X24026	X24026@SOIC8
[ ( SA602A ) ]	
X24042	X24042@SOIC8
[ ( SA602A ) ]	
X24164	X24164@SOIC8
[ ( SA602A ) ]	
X24165	X24165@SOIC8
[ ( SA602A ) ]	
X24325	X24325@SOIC8
[ ( SA602A ) ]	
X24645	X24645@SOIC8

[ (SA602A) ]	
X24C01	X24C01@MSOP8
[ (SA666) ]	
X24C01@SOIC8 [ (SA602A) ]	
X24C01A	
X24C01A@SOIC8 [ (SA602A) ]	
X24C01I	
X24C01I@SOIC8 [ (SA602A) ]	
X24C02	
X24C02@SOIC8 [ (SA602A) ]	
X24C02I	
X24C02I@SOIC8 [ (SA602A) ]	
X24C04	
X24C04@SOIC14 [ (SA602) ]	X24C04@SOIC8
[ (SA602A) ]	
X24C04I	X24C04I@SOIC14
[ (SA602) ]	
X24C04I@SOIC8 [ (SA602A) ]	
X24C08	
X24C08@SOIC14 [ (SA602) ]	X24C08@SOIC8
[ (SA602A) ]	
X24C08I	X24C08I@SOIC14
[ (SA602) ]	
X24C08I@SOIC8 [ (SA602A) ]	
X24C16	
X24C16@SOIC14 [ (SA602) ]	X24C16@SOIC8
[ (SA602A) ]	
X24C16I	X24C16I@SOIC14
[ (SA602) ]	
X24C16I@SOIC8 [ (SA602A) ]	
X24C44	
X24C44@SOIC8 [ (SA602A) ]	
X24C44I	
X24C44I@SOIC8 [ (SA602A) ]	
X24C45	
X24C45@SOIC8 [ (SA602A) ]	
X24C45I	
X24C45I@SOIC8 [ (SA602A) ]	X24F008
(3V)	
X24F008(3V)@SOIC8 [ (SA602A) ]	X24F008(3V)@TSSOP14
[ (SA602) ]	
X24F008(5V)	X24F008(5V)@SOIC8
[ (SA602A) ]	

X24F008(5V)@TSSOP14 [(SA602)] (3V)	X24F016
X24F016(3V)@SOIC8 [(SA602A)] [(SA602)]	X24F016(3V)@TSSOP14
X24F016(5V) [(SA602A)]	X24F016(5V)@SOIC8
X24F016(5V)@TSSOP14 [(SA602)] (3V)	X24F032
X24F032(3V)@SOIC8 [(SA602A)] [(SA602)]	X24F032(3V)@TSSOP14
X24F032(5V) [(SA602A)]	X24F032(5V)@SOIC8
X24F032(5V)@TSSOP14 [(SA602)] (3V)	X24F064
X24F064(3V)@SOIC8 [(SA602A)] [(SA404)]	X24F064(3V)@TSSOP20
X24F064(5V) [(SA602A)]	X24F064(5V)@SOIC8
X24F064(5V)@TSSOP20 [(SA404)]	
X25020	
X25020@SOIC8 [(SA602A)]	
X25021	
X25021@SOIC8 [(SA602A)]	
X25040	
X25040@SOIC8 [(SA602A)]	
X25041	
X25041@SOIC8 [(SA602A)]	
X25043	
X25043@MSOP8 [(SA666)] [(SA602A)]	X25043@SOIC8
X25043@TSSOP14 [(SA026)]	
X25045	
X25045@MSOP8 [(SA666)] [(SA602A)]	X25045@SOIC8
X25045@TSSOP14 [(SA026)] [(SA666)]	X25057@MSOP8
X25057@TSSOP8 [(SA026)]	
X25080	
X25080@SOIC8 [(SA602A)] [(SA026)]	X25080@TSSOP14
X25097@MSOP8 [(SA666)] [(SA602A)]	X25097@SOIC8
X25097@TSSOP8 [(SA026)]	

X25128	
X25128@SOIC16 [(SA602)]	
X25138	
X25138@SOIC14 [(SA602)]	X25138@SOIC16
[(SA602)]	
X25138@SOIC8 [(SA602A)]	X25138@TSSOP8
[(SA026)]	
X25160	X25160@SOIC8
[(SA602A)]	
X25160@TSSOP14 [(SA026)]	
X25163	
X25163@SOIC8 [(SA602A)]	X25163@TSSOP14
[(SA026)]	
X25164	X25164@SOIC8
[(SA602A)]	
X25164@TSSOP14 [(SA026)]	
X25165	
X25165@SOIC8 [(SA602A)]	X25165@TSSOP14
[(SA026)]	
X25166	X25166@SOIC8
[(SA602A)]	
X25166@TSSOP14 [(SA026)]	
X25168	
X25168@SOIC8 [(SA602A)]	X25168@TSSOP14
[(SA026)]	
X25169	X25169@SOIC8
[(SA602A)]	
X25169@TSSOP14 [(SA026)]	
X25256	
X25256@SOIC8 [(SA602A)]	X25256@TSSOP20
[(SA026)]	
X25320	X25320@SOIC8
[(SA602A)]	
X25323@SOIC8 [(SA602A)]	X25323@TSSOP14
[(SA026)]	
X25324@SOIC8 [(SA602A)]	X25324@TSSOP14
[(SA026)]	
X25325@SOIC8 [(SA602A)]	X25325@TSSOP14
[(SA026)]	
X25326@SOIC8 [(SA602A)]	X25328@SOIC8
[(SA602A)]	
X25328@TSSOP14 [(SA026)]	X25329@SOIC8
[(SA602A)]	

X25329@TSSOP14 [(SA026)]	X25330@SOIC8
[(SA602A)]	
X25330@TSSOP14 [(SA026)]	
X25401	
X25401@SOIC8 [(SA602A)]	
X25640	
X25640@SOIC14 [(SA602)]	
X25642	
X25642@SOIC14 [(SA602)]	X25642@SOIC8
[(SA602A)]	
X25642@TSSOP20 [(SA026)]	X25643@SOIC14
[(SA602)]	
X25644@SOIC14 [(SA602)]	
X25645	
X25645@SOIC14 [(SA602)]	X25645@SOIC8
[(SA602A)]	
X25645@TSSOP20 [(SA026)]	X25648@SOIC14
[(SA602)]	
X25649@SOIC14 [(SA602)]	
X25650	
X25650@SOIC14 [(SA602)]	X25650@SOIC8
[(SA602A)]	
X25650@TSSOP20 [(SA026)]	
X25C02	
X25C02@SOIC8 [(SA602A)]	X25C02@TSSOP8
[(SA026)]	
X25F008(3V)	X25F008(3V)@SOIC8
[(SA602A)]	
X25F008(3V)@TSSOP14 [(SA602)]	X25F008(3V)@TSSOP20
[(SA404)]	
X25F008(5V)	X25F008(5V)@SOIC8
[(SA602A)]	
X25F008(5V)@TSSOP14 [(SA602)]	X25F008(5V)@TSSOP20
[(SA404)]	
X25F016(3V)	X25F016(3V)@SOIC8
[(SA602A)]	
X25F016(3V)@TSSOP14 [(SA602)]	X25F016(3V)@TSSOP20
[(SA404)]	
X25F016(5V)	X25F016(5V)@SOIC8
[(SA602A)]	
X25F016(5V)@TSSOP14 [(SA602)]	X25F016(5V)@TSSOP20
[(SA404)]	
X25F032(3V)	X25F032(3V)@SOIC8



[ (SA602A) ]	
X25F032(3V)@TSSOP14 [ (SA602) ]	X25F032(3V)@TSSOP20
[ (SA404) ]	
X25F032(5V)	X25F032(5V)@SOIC8
[ (SA602A) ]	
X25F032(5V)@TSSOP14 [ (SA602) ]	X25F032(5V)@TSSOP20
[ (SA404) ]	
X25F047(3V)	X25F047(3V)@MSOP8
[ (SA666) ]	
X25F047(3V)@SOIC8 [ (SA602A) ]	X25F047(3V)@TSSOP8
[ (SA026) ]	
X25F047(5V)	X25F047(5V)@MSOP8
[ (SA666) ]	
X25F047(5V)@SOIC8 [ (SA602A) ]	X25F047(5V)@TSSOP8
[ (SA026) ]	
X25F064(3V)	X25F064(3V)@SOIC8
[ (SA602A) ]	
X25F064(3V)@TSSOP14 [ (SA602) ]	X25F064(3V)@TSSOP20
[ (SA404) ]	
X25F064(5V)	X25F064(5V)@SOIC8
[ (SA602A) ]	
X25F064(5V)@TSSOP14 [ (SA602) ]	X25F064(5V)@TSSOP20
[ (SA404) ]	
X25F087(3V)	X25F087(3V)@MSOP8
[ (SA666) ]	
X25F087(3V)@SOIC8 [ (SA602A) ]	X25F087(3V)@TSSOP8
[ (SA026) ]	
X25F087(5V)	X25F087(5V)@MSOP8
[ (SA666) ]	
X25F087(5V)@SOIC8 [ (SA602A) ]	X25F087(5V)@TSSOP8
[ (SA026) ]	
X25F128(3V)	X25F128(3V)@SOIC16
[ (SA602) ]	
X25F128(5V)	X25F128(5V)@SOIC16
[ (SA602) ]	
X28010	X28010@PLCC32
[ (SA015A1T) ]	
X28010@TSOP32 [ (SA410T) ]	
X2804A	
X2804A(I)	X2804A
(MB)	
X2816A	X2816A@PLCC32
[ (SA015A1T) ]	

X2816B	X2816B@PLCC32
[ (SA015A1T) ]	
X2816BI	X2816BI@PLCC32
[ (SA015A1T) ]	
X2816BMB	
X2816C	
X2816C@PLCC32 [ (SA015A1T) ]	
X28256	
X28256@PLCC32 [ (SA015A1T) ]	
X28256I	
X28256I@PLCC32 [ (SA015A1T) ]	
X2864A	
X2864A(I)	X2864A(I)@PLCC32
[ (SA015A1T) ]	
X2864A(M)	X2864A(M)@PLCC32
[ (SA015A1T) ]	
X2864A(MB)	X2864A(MB)@PLCC32
[ (SA015A1T) ]	
X2864A(T)	X2864A(T)@PLCC32
[ (SA015A1T) ]	
X2864A@PLCC32 [ (SA015A1T) ]	
X2864B	
X2864B(I)	X2864B(I)@PLCC32
[ (SA015A1T) ]	
X2864B(M)	X2864B(M)@PLCC32
[ (SA015A1T) ]	
X2864B@PLCC32 [ (SA015A1T) ]	
X2864H	
X2864H(I)	X2864H(I)@PLCC32
[ (SA015A1T) ]	
X2864H@PLCC32 [ (SA015A1T) ]	
X28C010	
X28C010@PLCC32 [ (SA015A1T) ]	
X28C16A	
X28C16A@PLCC32 [ (SA015A1T) ]	
X28C16B	
X28C16B@PLCC32 [ (SA015A1T) ]	
X28C16C	
X28C16C@PLCC32 [ (SA015A1T) ]	
X28C256	
X28C256@PLCC32 [ (SA015A1T) ]	X28C256@TSOP28
[ (SA430T) ]	
X28C512	X28C512@PLCC32

[ (SA015A1T) ]	
X28C513	X28C513@PLCC32
[ (SA015A1T) ]	
X28C64	X28C64@PLCC32
[ (SA015A1T) ]	
X28C64@SOIC28 [ (SA404) ]	X28C64@TSOP28
[ (SA430T) ]	
X28HC16	X28HC16@PLCC32
[ (SA015A1T) ]	
X28HC16@SOIC24 [ (SA404) ]	
X28HC256	
X28HC256@PLCC32 [ (SA015A1T) ]	X28HC256@TSOP28
[ (SA430T) ]	
X28HC64	X28HC64@PLCC32
[ (SA015A1T) ]	
X28HC64@SOIC28 [ (SA404) ]	X28HC64@TSOP28
[ (SA430T) ]	
X28LC512	X28LC512@PLCC32
[ (SA015A1T) ]	
X28LC513	X28LC513@PLCC32
[ (SA015A1T) ]	
X28VC256	X28VC256@PLCC32
[ (SA015A1T) ]	
X28VC256@TSOP28 [ (SA430T) ]	X40231@SOIC16
[ (SA404) ]	
X40233@SOIC16 [ (SA404) ]	X40235@SOIC16
[ (SA404) ]	
X40237@SOIC16 [ (SA404) ]	X40239@SOIC16
[ (SA404) ]	
X40430@SOIC14 [ (SA404) ]	X40430@TSSOP14
[ (SA026) ]	
X40431@SOIC14 [ (SA404) ]	X40431@TSSOP14
[ (SA026) ]	
X40434@SOIC14 [ (SA404) ]	X40434@TSSOP14
[ (SA026) ]	
X40435@SOIC14 [ (SA404) ]	X40435@TSSOP14
[ (SA026) ]	
X4C105@TSSOP20 [ (SA026) ]	
X5043	
X5043@MSOP8 [ (SA666) ]	X5043@SOIC8
[ (SA602A) ]	
X5043@TSSOP14 [ (SA026) ]	
X5045	

X5045@MSOP8 [(SA666)]	X5045@SOIC8
[(SA602A)]	
X5045@TSSOP14 [(SA026)]	
X5083	
X5083@SOIC8 [(SA602A)]	X5083@TSSOP8
[(SA026)]	
X5163	X5163@SOIC8
[(SA602A)]	
X5163@TSSOP14 [(SA026)]	
X51638	
X51638@SOIC8 [(SA602A)]	X51638@TSSOP14
[(SA026)]	
X5165	X5165@SOIC8
[(SA602A)]	
X5165@TSSOP14 [(SA026)]	
X5168	
X5168@SOIC8 [(SA602A)]	X5168@TSSOP14
[(SA026)]	
X5169	X5169@SOIC8
[(SA602A)]	
X5169@TSSOP14 [(SA026)]	
X5323	
X5323@SOIC8 [(SA602A)]	X5323@TSSOP14
[(SA026)]	
X5325	X5325@SOIC8
[(SA602A)]	
X5325@TSSOP14 [(SA026)]	
X5328	
X5328@SOIC8 [(SA602A)]	X5328@TSSOP14
[(SA026)]	
X5329	X5329@SOIC8
[(SA602A)]	
X5329@TSSOP14 [(SA026)]	
X5643	
X5643@SOIC14 [(SA602)]	X5643@SOIC8
[(SA602A)]	
X5643@TSSOP20 [(SA026)]	
X5645	
X5645@SOIC14 [(SA602)]	X5645@SOIC8
[(SA602A)]	
X5645@TSSOP20 [(SA026)]	
X5648	
X5648@SOIC14 [(SA602)]	

X5649	
X5649@SOIC14 [(SA602)]	
X76F041	
X76F041(3)	X76F041(3)@SOIC8
[(SA605)]	
X76F041@SOIC8 [(SA605)]	
X76F101	
X76F101@SOIC8 [(SA602A)]	X76F400@SOIC8
[(SA602A)]	
X76F400@TSSOP8 [(SA026)]	
X84041	
X84041@SOIC14 [(SA602)]	X84041@SOIC8
[(SA602A)]	
X84047	X84047@TSSOP8
[(SA026)]	
X84087	X84087@TSSOP8
[(SA026)]	
X84128	X84128@SOIC14
[(SA602)]	
X84128@TSSOP28 [(SA643)]	X84128@XBGA8
[(SA683)]	
X84129	X84129@SOIC16
[(SA602)]	
X84160	X84160@SOIC8
[(SA602A)]	
X84160@TSSOP8 [(SA026)]	
X84161	
X84161@SOIC8 [(SA602A)]	X84161@TSSOP8
[(SA026)]	
X84256	X84256@SOIC8
[(SA602A)]	
X84256@TSSOP14 [(SA026)]	X84256@XBGA8
[(SA683)]	
X84640	X84640@SOIC8
[(SA602A)]	
X84640@TSSOP20 [(SA026)]	X84640@XBGA8
[(SA683)]	
X84641	X84641@SOIC8
[(SA602A)]	
X84641@TSSOP20 [(SA026)]	X84641@XBGA8
[(SA683)]	
XD2210	XD2210@SOIC16
[(SA404)]	

XM28C010  
 XM28C020  
 XM28C040

## **XILINX**

### **E ( E ) PROM / FRAM / NVRAM**

XC1701 [ ( SA001A ) ]	XC1701@PLCC20
XC1701@PLCC44 [ ( SA244 ) ] [ ( SA404 ) ]	XC1701@SOIC20
XC1701L [ ( SA001A ) ]	XC1701L@PLCC20
XC1701L@PLCC44 [ ( SA244 ) ] [ ( SA404 ) ]	XC1701L@SOIC20
XC1702L@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	XC1702L@TQFP44
XC1704L@PLCC44 [ ( SA244 ) ] [ ( SA245A ) ]	XC1704L@TQFP44
XC17128 [ ( SA602A ) ]	XC17128@SOIC8
XC17128D [ ( SA001A ) ]	XC17128D@PLCC20
XC17128D@SOIC8 [ ( SA602A ) ] [ ( SA602A ) ]	XC17128D@VOIC8
XC17128E [ ( SA001A ) ]	XC17128E@PLCC20
XC17128E@VOIC8 [ ( SA602A ) ]	
XC17128EL XC17128EL@PLCC20 [ ( SA001A ) ] [ ( SA602A ) ]	XC17128EL@VOIC8
XC17128L [ ( SA001A ) ]	XC17128L@PLCC20
XC17128L@SOIC8 [ ( SA602A ) ] [ ( SA602A ) ]	XC17128L@VOIC8
XC17128X [ ( SA001A ) ]	XC17128X@PLCC20
XC17128X@SOIC8 [ ( SA602A ) ] [ ( SA602A ) ]	XC17128X@VOIC8
XC1718D [ ( SA001A ) ]	XC1718D@PLCC20

XC1718D@SOIC8 [(SA602A)]	XC1718D@VOIC8
[(SA602A)]	
XC1718L	XC1718L@PLCC20
[(SA001A)]	
XC1718L@SOIC8 [(SA602A)]	XC1718L@VOIC8
[(SA602A)]	
XC17256D	XC17256D@PLCC20
[(SA001A)]	
XC17256D@SOIC8 [(SA602A)]	XC17256D@VOIC8
[(SA602A)]	
XC17256E	XC17256E@PLCC20
[(SA001A)]	
XC17256E@VOIC8 [(SA602A)]	
XC17256EL	
XC17256EL@PLCC20 [(SA001A)]	XC17256EL@VOIC8
[(SA602A)]	
XC17256L	XC17256L@PLCC20
[(SA001A)]	
XC17256L@SOIC8 [(SA602A)]	XC17256L@VOIC8
[(SA602A)]	
XC17256X	XC17256X@PLCC20
[(SA001A)]	
XC17256X@SOIC8 [(SA602A)]	XC17256X@VOIC8
[(SA602A)]	
XC1736	XC1736@SOIC8
[(SA602A)]	
XC1736A	XC1736A@SOIC8
[(SA602A)]	
XC1736D	XC1736D@PLCC20
[(SA001A)]	
XC1736D@SOIC8 [(SA602A)]	XC1736D@VOIC8
[(SA602A)]	
XC1736E	XC1736E@PLCC20
[(SA001A)]	
XC1736E@SOIC8 [(SA602A)]	XC1736E@VOIC8
[(SA602A)]	
XC17512L	XC17512L@PLCC20
[(SA001A)]	
XC17512L@PLCC44 [(SA244)]	XC17512L@SOIC20
[(SA404)]	
XC1765	XC1765@SOIC8
[(SA602A)]	
XC1765D	XC1765D@PLCC20

[ (SA001A) ]	
XC1765D@SOIC8 [ (SA602A) ]	XC1765D@VOIC8
[ (SA602A) ]	
XC1765E	XC1765E@PLCC20
[ (SA001A) ]	
XC1765E@SOIC8 [ (SA602A) ]	XC1765E@VOIC8
[ (SA602A) ]	
XC1765EL	XC1765EL@PLCC20
[ (SA001A) ]	
XC1765EL@SOIC8 [ (SA602A) ]	XC1765EL@VOIC8
[ (SA602A) ]	
XC1765L	XC1765L@PLCC20
[ (SA001A) ]	
XC1765L@SOIC8 [ (SA602A) ]	XC1765L@VOIC8
[ (SA602A) ]	
XC1765X	XC1765X@PLCC20
[ (SA001A) ]	
XC1765X@SOIC8 [ (SA602A) ]	XC1765X@VOIC8
[ (SA602A) ]	
XC17S05	XC17S05@SOIC8
[ (SA602A) ]	
XC17S05XL(L)	XC17S05XL(L)@SOIC8
[ (SA602A) ]	
XC17S10	XC17S10@SOIC8
[ (SA602A) ]	
XC17S100A	XC17S100A@SOIC20
[ (SA404) ]	
XC17S100A@SOIC8 [ (SA602A) ]	XC17S100XL
(L)	
XC17S100XL(L)@SOIC20 [ (SA404) ]	XC17S10XL
(L)	
XC17S10XL(L)@SOIC8 [ (SA602A) ]	
XC17S150A	
XC17S150A@SOIC20 [ (SA404) ]	XC17S150A@SOIC8
[ (SA602A) ]	
XC17S150XL(L)	XC17S150XL(L)@SOIC20
[ (SA404) ]	
XC17S15A	XC17S15A@SOIC20
[ (SA404) ]	
XC17S15A@SOIC8 [ (SA602A) ]	
XC17S20	
XC17S20@SOIC8 [ (SA602A) ]	
XC17S200A	



XC17S200A@SOIC8 [(SA602A)]	XC17S200A@TQFP44
[(SA245A)]	
XC17S20XL(L)	XC17S20XL(L)@SOIC8
[(SA602A)]	
XC17S30	XC17S30@SOIC8
[(SA602A)]	
XC17S300A@TQFP44 [(SA245A)]	
XC17S30A	
XC17S30A@SOIC20 [(SA404)]	XC17S30A@SOIC8
[(SA602A)]	
XC17S30XL(L)	XC17S30XL(L)@SOIC8
[(SA602A)]	
XC17S40	XC17S40@SOIC20
[(SA404)]	
XC17S40XL(L)	XC17S40XL(L)@SOIC20
[(SA404)]	
XC17S50A	XC17S50A@SOIC20
[(SA404)]	
XC17S50A@SOIC8 [(SA602A)]	XC17S50XL
(L)	
XC17S50XL(L)@SOIC20 [(SA404)]	XC17V01@PLCC20
[(SA001A)]	
XC17V01@SOIC20 [(SA404)]	XC17V01@SOIC8
[(SA602A)]	
XC17V02@PLCC20 [(SA001A)]	XC17V02@PLCC44
[(SA244)]	
XC17V02@TQFP44 [(SA245A)]	XC17V04@PLCC20
[(SA001A)]	
XC17V04@PLCC44 [(SA244)]	XC17V04@TQFP44
[(SA245A)]	
XC17V08@PLCC44 [(SA244)]	XC17V08@TQFP44
[(SA245A)]	
XC17V16@PLCC44 [(SA244)]	XC17V16@TQFP44
[(SA245A)]	
XC18V01@PLCC20 [(SA001A)]	XC18V01@SOIC20
[(SA404)]	
XC18V01@TQFP44 [(SA245A)]	XC18V02@PLCC44
[(SA244)]	
XC18V02@TQFP44 [(SA245A)]	XC18V04@PLCC44
[(SA244)]	
XC18V04@TQFP44 [(SA245A)]	XC18V256@PLCC20
[(SA001A)]	
XC18V256@SOIC20 [(SA404)]	XC18V256@TQFP44

[(SA245A)]  
 XC18V512@PLCC20 [(SA001A)] XC18V512@SOIC20  
 [(SA404)]  
 XC18V512@TQFP44 [(SA245A)] XCF01S(VO)@TSSOP20  
 [(SA026)]  
 XCF01S(VOG)@TSSOP20 [(SA026)] XCF02S(VO)@TSSOP20  
 [(SA026)]  
 XCF02S(VOG)@TSSOP20 [(SA026)] XCF04S(VO)@TSSOP20  
 [(SA026)]  
 XCF04S(VOG)@TSSOP20 [(SA026)]  
 XCF08P(FS)@FBGA48 [(SA642E-B026A-T072F001N)]  
 XCF08P(FS)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]  
 XCF08P(FSG)@FBGA48 [(SA642E-B026A-T072F001N)]  
 XCF08P(FSG)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]  
 XCF08P(VO)@TSOP48 [(SA247-B005)]  
 XCF08P(VO)@TSOP48(ISP) [ISP-HEADER01]  
 XCF08P(VOG)@TSOP48 [(SA247-B005)]  
 XCF08P(VOG)@TSOP48(ISP) [ISP-HEADER01]  
 XCF16P(FS)@FBGA48 [(SA642E-B026A-T072F001N)]  
 XCF16P(FS)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]  
 XCF16P(FSG)@FBGA48 [(SA642E-B026A-T072F001N)]  
 XCF16P(FSG)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]  
 XCF16P(VO)@TSOP48 [(SA247-B005)]  
 XCF16P(VO)@TSOP48(ISP) [ISP-HEADER01]  
 XCF16P(VOG)@TSOP48 [(SA247-B005)]  
 XCF16P(VOG)@TSOP48(ISP) [ISP-HEADER01]  
 XCF32P(FS)@FBGA48 [(SA642E-B026A-T072F001N)]  
 XCF32P(FS)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]  
 XCF32P(FSG)@FBGA48 [(SA642E-B026A-T072F001N)]  
 XCF32P(FSG)@FBGA48(ISP) [(SA642E-B026A-T072F001N)]  
 XCF32P(VO)@TSOP48 [(SA247-B005)]  
 XCF32P(VO)@TSOP48(ISP) [ISP-HEADER01]  
 XCF32P(VOG)@TSOP48 [(SA247-B005)]  
 XCF32P(VOG)@TSOP48(ISP) [ISP-HEADER01]

## PLD

XC2C128@TQFP144(\*) [(SA681+B14418)]  
 XC2C256@FT256(\*) [(SA800+B177)]  
 XC2C256@TQFP144(\*) [(SA681+B14418)]  
 XC2C32@PLCC44 [(SA244)] XC2C32@QFG32  
 [(SA686)]

XC2C32@VQFP44 [(SA245A)]	XC2C32A@PLCC44
[(SA244)]	
XC2C32A@QFG32 [(SA686)]	XC2C32A@VQFP44
[(SA245A)]	
XC2C384@FT256(*) [(SA800+B177)]	
XC2C384@TQFP144(*) [(SA681+B14418)]	
XC2C64@CSP56(*) [(SA699A-B136B-W056F001Y)]	
XC2C64@PLCC44 [(SA244)]	XC2C64@VQFP100(*) [(TA063
+B006)]	
XC2C64@VQFP44 [(SA245A)]	XC2C64A@5QFG48C
[(SA696)]	
XC2C64A@5QFG48I [(SA696)]	XC2C64A@7QFG48C
[(SA696)]	
XC2C64A@7QFG48I [(SA696)]	
XC2C64A@CSP56(*) [(SA699A-B136B-W056F001Y)]	
XC2C64A@PLCC44 [(SA244)]	
XC2C64A@VQFP100(*) [(TA063+B006)]	
XC2C64A@VQFP44 [(SA245A)]	
XC95108@PQFP100(*) [(TA082+B084)]	
XC95144XL@TQFP100(*) [(SA718+B186)]	
XC95144XL@TQFP144(**) [(TA028A+B084)]	
XC95144XV@TQFP144(**) [(TA028A+B084)]	
XC95216@PQFP160(*) [(TA081+B084)]	
XC95288XL@TQFP144(**) [(TA028A+B084)]	
XC95288XV@FG256(*) [(SA800+B181)]	
XC95288XV@TQFP144(**) [(TA028A+B084)]	
XC9536@PLCC44 [(SA244)]	XC9536@TQFP44
[(SA245A)]	
XC9536XL@BCSP48	XC9536XL@PLCC44
[(SA244)]	
XC9536XL@TQFP64(*) [(TA073+B006)]	
XC9536XL@VQFP44 [(SA245A)]	
XC9536XV@BCSP48	
XC9536XV@PLCC44 [(SA244)]	XC9536XV@TQFP44
[(SA245A)]	
XC9572@PLCC44 [(SA244)]	XC9572@TQFP44
[(SA245A)]	
XC9572XL@BCSP48	XC9572XL@PLCC44
[(SA244)]	
XC9572XL@TQFP44 [(SA245A)]	
XC9572XL@TQFP64(*) [(TA073+B006)]	
XC9572XV@BCSP48	XC9572XV@PLCC44
[(SA244)]	

XC9572XV@TQFP44 [ (SA245A) ]  
[ (SA244) ]  
XCR3032XL@TQFP44 [ (SA245A) ]  
+B155 ) ]

XCR3032XL@PLCC44  
XCR3064XL@FPGA56 [ (SA699

## XILINX-CUSTOMER

### E (E) PROM / FRAM / NVRAM

XC17S100A  
[ (SA404) ]  
XC17S100A@SOIC8 [ (SA602A) ]  
XC17S150A  
XC17S150A@SOIC20 [ (SA404) ]  
[ (SA602A) ]  
XC17S15A  
[ (SA404) ]  
XC17S15A@SOIC8 [ (SA602A) ]  
XC17S200A  
XC17S200A@SOIC8 [ (SA602A) ]  
[ (SA245A) ]  
XC17S300A@TQFP44 [ (SA245A) ]  
XC17S30A  
XC17S30A@SOIC20 [ (SA404) ]  
[ (SA602A) ]  
XC17S50A  
[ (SA404) ]  
XC17S50A@SOIC8 [ (SA602A) ]  
[ (SA001A) ]  
XC17V01@SOIC20 [ (SA404) ]  
[ (SA602A) ]  
XC17V02@PLCC20 [ (SA001A) ]  
[ (SA244) ]  
XC17V02@TQFP44 [ (SA245A) ]  
[ (SA001A) ]  
XC17V04@PLCC44 [ (SA244) ]  
[ (SA245A) ]  
XC17V08@PLCC44 [ (SA244) ]  
[ (SA245A) ]  
XC17V16@PLCC44 [ (SA244) ]  
[ (SA245A) ]

XC17S100A@SOIC20  
XC17S150A@SOIC8  
XC17S15A@SOIC20  
XC17S200A@TQFP44  
XC17S30A@SOIC8  
XC17S50A@SOIC20  
XC17V01@PLCC20  
XC17V01@SOIC8  
XC17V02@PLCC44  
XC17V04@PLCC20  
XC17V04@TQFP44  
XC17V08@TQFP44  
XC17V16@TQFP44

**YMC****E (E) PROM/FRAM/NVRAM**

Y24LC01 [ (SA602A) ]	Y24LC01@SOIC8
Y24LC01@TSSOP8 [ (SA026) ]	
Y24LC02	Y24LC02@TSSOP8
Y24LC02@SOIC8 [ (SA602A) ] [ (SA026) ]	
Y24LC02A [ (SA602A) ]	Y24LC02A@SOIC8
Y24LC02A@TSSOP8 [ (SA026) ]	
Y24LC04	Y24LC04@TSSOP8
Y24LC04@SOIC8 [ (SA602A) ] [ (SA026) ]	
Y24LC08	Y24LC08@SOIC8
[ (SA602A) ]	
Y24LC08@TSSOP8 [ (SA026) ]	
Y24LC16	Y24LC16@TSSOP8
Y24LC16@SOIC8 [ (SA602A) ] [ (SA026) ]	
Y24LC32	Y24LC32@SOIC8
[ (SA602A) ]	
Y24LC32@TSSOP8 [ (SA026) ]	
Y24LC64	Y24LC64@TSSOP8
Y24LC64@SOIC8 [ (SA602A) ] [ (SA026) ]	
Y93LC46(08bit)	Y93LC46(08bit)@SOIC8
[ (SA602A) ]	
Y93LC46(08bit)@TSSOP8 [ (SA026) ] (16bit)	Y93LC46
Y93LC46(16bit)@SOIC8 [ (SA602A) ] [ (SA026) ]	Y93LC46(16bit)@TSSOP8
Y93LC66(08bit)	Y93LC66(08bit)@SOIC8
[ (SA602A) ]	
Y93LC66(08bit)@TSSOP8 [ (SA026) ] (16bit)	Y93LC66
Y93LC66(16bit)@SOIC8 [ (SA602A) ] [ (SA026) ]	Y93LC66(16bit)@TSSOP8
Y93LC86(08bit)	Y93LC86(08bit)@SOIC8
[ (SA602A) ]	

Y93LC86(08bit)@TSSOP8 [(SA026)]  
(16bit)  
Y93LC86(16bit)@SOIC8 [(SA602A)]  
[(SA026)]

Y93LC86

Y93LC86(16bit)@TSSOP8

## YSS

### E(E) PROM/FRAM/NVRAM

Y25F05@SOP8 [(SA602A)]  
[(SA683)]  
Y25F10@SOP8 [(SA602A)]  
[(SA683)]

Y25F05@VQFN8

Y25F10@VQFN8

## ZILOG

### MICROCONTROLLER

Z86733  
[(SA008A)]  
Z86733@SOIC28 [(SA404)]  
Z86743  
Z86743@PLCC44 [(SA244)]  
Z86C0208PEC  
Z86C0208PSC  
[(SA404)]  
Z86C0208SSC@SOIC18 [(SA404)]  
Z86E02  
Z86E02@SOIC18 [(SA404)]  
Z86E03  
Z86E03@SOIC18 [(SA404)]  
Z86E04  
Z86E04@SOIC18 [(SA404)]  
Z86E0412PEC  
Z86E0412PEC1903  
Z86E0412PSC1866  
Z86E0412PSC1903  
[(SA404)]  
Z86E0412SEC1903 [(SA404)]  
[(SA404)]

Z86733@PLCC28

Z86C0208SEC@SOIC18

Z86E0412SEC

Z86E0412SSC1866

Z86E0412SSC1903 [(SA404)]  
Z86E06  
Z86E06@SOIC18 [(SA404)]  
Z86E07  
Z86E07@SOIC18 [(SA404)]  
Z86E08  
Z86E08@SOIC18 [(SA404)]  
Z86E0812PEC  
Z86E0812PEC1903  
Z86E0812PSC1866  
Z86E0812PSC1903  
[(SA404)]  
Z86E0812SEC1903 [(SA404)]  
[(SA404)]  
Z86E0812SSC1903 [(SA404)]  
Z86E122  
Z86E122@SOIC20 [(SA404)]  
Z86E123  
Z86E123@SOIC20 [(SA404)]  
Z86E124  
Z86E124@SOIC20 [(SA404)]  
Z86E125  
Z86E125@SOIC20 [(SA404)]  
Z86E126  
Z86E126@SOIC20 [(SA404)]  
Z86E132  
Z86E132@SOIC28 [(SA404)]  
Z86E133  
Z86E133@SOIC28 [(SA404)]  
Z86E134  
Z86E134@SOIC28 [(SA404)]  
Z86E135  
Z86E135@SOIC28 [(SA404)]  
Z86E136  
Z86E136@SOIC28 [(SA404)]  
Z86E142  
Z86E142@TQFP44 [(SA245A)]  
Z86E143  
Z86E143@TQFP44 [(SA245A)]  
Z86E144  
Z86E144@TQFP44 [(SA245A)]  
Z86E145  
Z86E145@TQFP44 [(SA245A)]

Z86E0812SEC

Z86E0812SSC1866

Z86E146	
Z86E146@TQFP44 [(SA245A)]	
Z86E15	
Z86E21	Z86E21@PLCC44
[(SA244)]	
Z86E21@TQFP44	
Z86E23	
Z86E23@PLCC44 [(SA244)]	Z86E23@TQFP44
[(SA245A)]	
Z86E3016PEC	
Z86E3016PSC	
Z86E3016SEC@SOIC28 [(SA404)]	Z86E3016SSC@SOIC28
[(SA404)]	
Z86E3016VEC@PLCC28 [(SA008A)]	Z86E3016VSC@PLCC28
[(SA008A)]	
Z86E3016VSG@PLCC28 [(SA008A)]	
Z86E3116PEC	
Z86E3116PSC	Z86E3116SEC@SOIC28
[(SA404)]	
Z86E3116SSC@SOIC28 [(SA404)]	Z86E3116VEC@PLCC28
[(SA008A)]	
Z86E3116VSC@PLCC28 [(SA008A)]	Z86E3116VSG@PLCC28
[(SA008A)]	
Z86E33	Z86E33@PLCC28
[(SA008A)]	
Z86E33@SOIC28 [(SA404)]	
Z86E34	
Z86E34@PLCC28 [(SA008A)]	Z86E34@SOIC28
[(SA404)]	
Z86E4016FEC@TQFP44 [(SA245A)]	Z86E4016FSC@TQFP44
[(SA245A)]	
Z86E4016PEC	
Z86E4016PSC	
Z86E4016VEC@PLCC44 [(SA244)]	Z86E4016VSC@PLCC44
[(SA244)]	
Z86E4016VSG@PLCC44 [(SA244)]	
Z86E43	
Z86E43@PLCC44 [(SA244)]	Z86E43@TQFP44
[(SA245A)]	
Z86E44	Z86E44@PLCC44
[(SA244)]	
Z86E44@TQFP44 [(SA245A)]	Z86E61FSC@TQFP44
[(SA245A)]	



Z86E61PSC	Z86E61VSC@PLCC44
[ (SA244) ]	
Z86E63FSC@TQFP44 [ (SA245A) ]	
Z86E63PSC	
Z86E63VSC@PLCC44 [ (SA244) ]	
Z86E72	
Z86E72@PLCC44 [ (SA244) ]	Z86E72@TQFP44
[ (SA245A) ]	
Z86E73	Z86E73@PLCC44
[ (SA244) ]	
Z86E73@TQFP44 [ (SA245A) ]	
Z86E83	
Z86E83@PLCC28 [ (SA008A) ]	Z86E83@SOIC28
[ (SA404) ]	
Z86L0208PEC	
Z86L0208PSC	
Z86L0208SEC@SOIC18 [ (SA404) ]	Z86L0208SSC@SOIC18
[ (SA404) ]	
Z89371	Z89371@PLCC44
[ (SA244) ]	
Z89371@TQFP44 [ (SA245A) ]	
Z89371B	
Z89371B@PLCC44 [ (SA244) ]	Z89371B@TQFP44
[ (SA245A) ]	
Z8F0113HH005EC@SSOP20 [ (SA626A) ]	Z8F0113HH005EG@SSOP20
[ (SA626A) ]	
Z8F0113HH005SC@SSOP20 [ (SA626A) ]	Z8F0113HH005SG@SSOP20
[ (SA626A) ]	
Z8F0113HJ005EC@SSOP28 [ (SA626A) ]	Z8F0113HJ005EG@SSOP28
[ (SA626A) ]	
Z8F0113HJ005SC@SSOP28 [ (SA626A) ]	Z8F0113HJ005SG@SSOP28
[ (SA626A) ]	
Z8F0113PB005EC	
Z8F0113PB005EG	
Z8F0113PB005SC	
Z8F0113PB005SG	
Z8F0113PH005EC	
Z8F0113PH005EG	
Z8F0113PH005SC	
Z8F0113PH005SG	
Z8F0113PJ005EC	
Z8F0113PJ005EG	
Z8F0113PJ005SC	

Z8F0113PJ005SG

Z8F0113QB005EC@QFN8 [(SA683)]  
[(SA683)]

Z8F0113QB005SC@QFN8 [(SA683)]  
[(SA683)]

Z8F0113SB005EC@SOIC8 [(SA602A)]  
[(SA602A)]

Z8F0113SB005SC@SOIC8 [(SA602A)]  
[(SA602A)]

Z8F0113SH005EC@SOIC20 [(SA404)]  
[(SA404)]

Z8F0113SH005SC@SOIC20 [(SA404)]  
[(SA404)]

Z8F0113SJ005EC@SOIC28 [(SA404)]  
[(SA404)]

Z8F0113SJ005SC@SOIC28 [(SA404)]  
[(SA404)]

Z8F011AHH020EC@SSOP20 [(SA626A)]  
[(SA626A)]

Z8F011AHH020SC@SSOP20 [(SA626A)]  
[(SA626A)]

Z8F011AHJ020EC@SSOP28 [(SA626A)]  
[(SA626A)]

Z8F011AHJ020SC@SSOP28 [(SA626A)]  
[(SA626A)]

Z8F011APB020EC

Z8F011APB020EG

Z8F011APB020SC

Z8F011APB020SG

Z8F011APH020EC

Z8F011APH020EG

Z8F011APH020SC

Z8F011APH020SG

Z8F011APJ020EC

Z8F011APJ020EG

Z8F011APJ020SC

Z8F011APJ020SG

Z8F011AQB020EC@QFN8 [(SA683)]  
[(SA683)]

Z8F011AQB020SC@QFN8 [(SA683)]  
[(SA683)]

Z8F011ASB020EC@SOIC8 [(SA602A)]  
[(SA602A)]

Z8F0113QB005EG@QFN8

Z8F0113QB005SG@QFN8

Z8F0113SB005EG@SOIC8

Z8F0113SB005SG@SOIC8

Z8F0113SH005EG@SOIC20

Z8F0113SH005SG@SOIC20

Z8F0113SJ005EG@SOIC28

Z8F0113SJ005SG@SOIC28

Z8F011AHH020EG@SSOP20

Z8F011AHH020SG@SSOP20

Z8F011AHJ020EG@SSOP28

Z8F011AHJ020SG@SSOP28

Z8F011AQB020EG@QFN8

Z8F011AQB020SG@QFN8

Z8F011ASB020EG@SOIC8

Z8F011ASB020SC@SOIC8 [(SA602A)]	Z8F011ASB020SG@SOIC8
[(SA602A)]	
Z8F011ASH020EC@SOIC20 [(SA404)]	Z8F011ASH020EG@SOIC20
[(SA404)]	
Z8F011ASH020SC@SOIC20 [(SA404)]	Z8F011ASH020SG@SOIC20
[(SA404)]	
Z8F011ASJ020EC@SOIC28 [(SA404)]	Z8F011ASJ020EG@SOIC28
[(SA404)]	
Z8F011ASJ020SC@SOIC28 [(SA404)]	Z8F011ASJ020SG@SOIC28
[(SA404)]	
Z8F0123HH005EC@SSOP20 [(SA626A)]	Z8F0123HH005EG@SSOP20
[(SA626A)]	
Z8F0123HH005SC@SSOP20 [(SA626A)]	Z8F0123HH005SG@SSOP20
[(SA626A)]	
Z8F0123HJ005EC@SSOP28 [(SA626A)]	Z8F0123HJ005EG@SSOP28
[(SA626A)]	
Z8F0123HJ005SC@SSOP28 [(SA626A)]	Z8F0123HJ005SG@SSOP28
[(SA626A)]	
Z8F0123PB005EC	
Z8F0123PB005EG	
Z8F0123PB005SC	
Z8F0123PB005SG	
Z8F0123PH005EC	
Z8F0123PH005EG	
Z8F0123PH005SC	
Z8F0123PH005SG	
Z8F0123PJ005EC	
Z8F0123PJ005EG	
Z8F0123PJ005SC	
Z8F0123PJ005SG	
Z8F0123QB005EC@QFN8 [(SA683)]	Z8F0123QB005EG@QFN8
[(SA683)]	
Z8F0123QB005SC@QFN8 [(SA683)]	Z8F0123QB005SG@QFN8
[(SA683)]	
Z8F0123SB005EC@SOIC8 [(SA602A)]	Z8F0123SB005EG@SOIC8
[(SA602A)]	
Z8F0123SB005SC@SOIC8 [(SA602A)]	Z8F0123SB005SG@SOIC8
[(SA602A)]	
Z8F0123SH005EC@SOIC20 [(SA404)]	Z8F0123SH005EG@SOIC20
[(SA404)]	
Z8F0123SH005SC@SOIC20 [(SA404)]	Z8F0123SH005SG@SOIC20
[(SA404)]	
Z8F0123SJ005EC@SOIC28 [(SA404)]	Z8F0123SJ005EG@SOIC28

[ (SA404) ]		
Z8F0123SJ005SC@SOIC28 [ (SA404) ]		Z8F0123SJ005SG@SOIC28
[ (SA404) ]		
Z8F012AHH020EC@SSOP20 [ (SA626A) ]		Z8F012AHH020EG@SSOP20
[ (SA626A) ]		
Z8F012AHH020SC@SSOP20 [ (SA626A) ]		Z8F012AHH020SG@SSOP20
[ (SA626A) ]		
Z8F012AHJ020EC@SSOP28 [ (SA626A) ]		Z8F012AHJ020EG@SSOP28
[ (SA626A) ]		
Z8F012AHJ020SC@SSOP28 [ (SA626A) ]		Z8F012AHJ020SG@SSOP28
[ (SA626A) ]		
Z8F012APB020EC		
Z8F012APB020EG		
Z8F012APB020SC		
Z8F012APB020SG		
Z8F012APH020EC		
Z8F012APH020EG		
Z8F012APH020SC		
Z8F012APH020SG		
Z8F012APJ020EC		
Z8F012APJ020EG		
Z8F012APJ020SC		
Z8F012APJ020SG		
Z8F012AQB020EC@QFN8 [ (SA683) ]		Z8F012AQB020EG@QFN8
[ (SA683) ]		
Z8F012AQB020SC@QFN8 [ (SA683) ]		Z8F012AQB020SG@QFN8
[ (SA683) ]		
Z8F012ASB020EC@SOIC8 [ (SA602A) ]		Z8F012ASB020EG@SOIC8
[ (SA602A) ]		
Z8F012ASB020SC@SOIC8 [ (SA602A) ]		Z8F012ASB020SG@SOIC8
[ (SA602A) ]		
Z8F012ASH020EC@SOIC20 [ (SA404) ]		Z8F012ASH020EG@SOIC20
[ (SA404) ]		
Z8F012ASH020SC@SOIC20 [ (SA404) ]		Z8F012ASH020SG@SOIC20
[ (SA404) ]		
Z8F012ASJ020EC@SOIC28 [ (SA404) ]		Z8F012ASJ020EG@SOIC28
[ (SA404) ]		
Z8F012ASJ020SC@SOIC28 [ (SA404) ]		Z8F012ASJ020SG@SOIC28
[ (SA404) ]		
Z8F0130HH020EG@SSOP20 [ (SA626A) ]		Z8F0130HH020SG@SSOP20
[ (SA626A) ]		
Z8F0130HJ020EG@SSOP28 [ (SA626A) ]		Z8F0130HJ020SG@SSOP28
[ (SA626A) ]		

Z8F0130PH020EG	
Z8F0130PH020SG	
Z8F0130PJ020EG	
Z8F0130PJ020SG	
Z8F0130QH020EG@QFN20 [(SA759)]	Z8F0130QH020SG@QFN20
[(SA759)]	
Z8F0130QJ020EG@QFN28 [(SA697)]	Z8F0130QJ020SG@QFN28
[(SA697)]	
Z8F0130SH020EG@SOIC20 [(SA404)]	Z8F0130SH020SG@SOIC20
[(SA404)]	
Z8F0130SJ020EG@SOIC28 [(SA404)]	Z8F0130SJ020SG@SOIC28
[(SA404)]	
Z8F0131HH020EG@SSOP20 [(SA626A)]	Z8F0131HH020SG@SSOP20
[(SA626A)]	
Z8F0131HJ020EG@SSOP28 [(SA626A)]	Z8F0131HJ020SG@SSOP28
[(SA626A)]	
Z8F0131PH020EG	
Z8F0131PH020SG	
Z8F0131PJ020EG	
Z8F0131PJ020SG	
Z8F0131QH020EG@QFN20 [(SA759)]	Z8F0131QH020SG@QFN20
[(SA759)]	
Z8F0131QJ020EG@QFN28 [(SA697)]	Z8F0131QJ020SG@QFN28
[(SA697)]	
Z8F0131SH020EG@SOIC20 [(SA404)]	Z8F0131SH020SG@SOIC20
[(SA404)]	
Z8F0131SJ020EG@SOIC28 [(SA404)]	Z8F0131SJ020SG@SOIC28
[(SA404)]	
Z8F0213HH005EC@SSOP20 [(SA626A)]	Z8F0213HH005EG@SSOP20
[(SA626A)]	
Z8F0213HH005SC@SSOP20 [(SA626A)]	Z8F0213HH005SG@SSOP20
[(SA626A)]	
Z8F0213HJ005EC@SSOP28 [(SA626A)]	Z8F0213HJ005EG@SSOP28
[(SA626A)]	
Z8F0213HJ005SC@SSOP28 [(SA626A)]	Z8F0213HJ005SG@SSOP28
[(SA626A)]	
Z8F0213PB005EC	
Z8F0213PB005EG	
Z8F0213PB005SC	
Z8F0213PB005SG	
Z8F0213PH005EC	
Z8F0213PH005EG	
Z8F0213PH005SC	

Z8F0213PH005SG	
Z8F0213PJ005EC	
Z8F0213PJ005EG	
Z8F0213PJ005SC	
Z8F0213PJ005SG	
Z8F0213QB005EC@QFN8 [(SA683)]	Z8F0213QB005EG@QFN8
[(SA683)]	
Z8F0213QB005SC@QFN8 [(SA683)]	Z8F0213QB005SG@QFN8
[(SA683)]	
Z8F0213SB005EC@SOIC8 [(SA602A)]	Z8F0213SB005EG@SOIC8
[(SA602A)]	
Z8F0213SB005SC@SOIC8 [(SA602A)]	Z8F0213SB005SG@SOIC8
[(SA602A)]	
Z8F0213SH005EC@SOIC20 [(SA404)]	Z8F0213SH005EG@SOIC20
[(SA404)]	
Z8F0213SH005SC@SOIC20 [(SA404)]	Z8F0213SH005SG@SOIC20
[(SA404)]	
Z8F0213SJ005EC@SOIC28 [(SA404)]	Z8F0213SJ005EG@SOIC28
[(SA404)]	
Z8F0213SJ005SC@SOIC28 [(SA404)]	Z8F0213SJ005SG@SOIC28
[(SA404)]	
Z8F021AHH020EC@SSOP20 [(SA626A)]	Z8F021AHH020EG@SSOP20
[(SA626A)]	
Z8F021AHH020SC@SSOP20 [(SA626A)]	Z8F021AHH020SG@SSOP20
[(SA626A)]	
Z8F021AHJ020EC@SSOP28 [(SA626A)]	Z8F021AHJ020EG@SSOP28
[(SA626A)]	
Z8F021AHJ020SC@SSOP28 [(SA626A)]	Z8F021AHJ020SG@SSOP28
[(SA626A)]	
Z8F021APB020EC	
Z8F021APB020EG	
Z8F021APB020SC	
Z8F021APB020SG	
Z8F021APH020EC	
Z8F021APH020EG	
Z8F021APH020SC	
Z8F021APH020SG	
Z8F021APJ020EC	
Z8F021APJ020EG	
Z8F021APJ020SC	
Z8F021APJ020SG	
Z8F021AQB020EC@QFN8 [(SA683)]	Z8F021AQB020EG@QFN8
[(SA683)]	

Z8F021AQB020SC@QFN8 [(SA683)]	Z8F021AQB020SG@QFN8
[(SA683)]	
Z8F021ASB020EC@SOIC8 [(SA602A)]	Z8F021ASB020EG@SOIC8
[(SA602A)]	
Z8F021ASB020SC@SOIC8 [(SA602A)]	Z8F021ASB020SG@SOIC8
[(SA602A)]	
Z8F021ASH020EC@SOIC20 [(SA404)]	Z8F021ASH020EG@SOIC20
[(SA404)]	
Z8F021ASH020SC@SOIC20 [(SA404)]	Z8F021ASH020SG@SOIC20
[(SA404)]	
Z8F021ASJ020EC@SOIC28 [(SA404)]	Z8F021ASJ020EG@SOIC28
[(SA404)]	
Z8F021ASJ020SC@SOIC28 [(SA404)]	Z8F021ASJ020SG@SOIC28
[(SA404)]	
Z8F0223HH005EC@SSOP20 [(SA626A)]	Z8F0223HH005EG@SSOP20
[(SA626A)]	
Z8F0223HH005SC@SSOP20 [(SA626A)]	Z8F0223HH005SG@SSOP20
[(SA626A)]	
Z8F0223HJ005EC@SSOP28 [(SA626A)]	Z8F0223HJ005EG@SSOP28
[(SA626A)]	
Z8F0223HJ005SC@SSOP28 [(SA626A)]	Z8F0223HJ005SG@SSOP28
[(SA626A)]	
Z8F0223PB005EC	
Z8F0223PB005EG	
Z8F0223PB005SC	
Z8F0223PB005SG	
Z8F0223PH005EC	
Z8F0223PH005EG	
Z8F0223PH005SC	
Z8F0223PH005SG	
Z8F0223PJ005EC	
Z8F0223PJ005EG	
Z8F0223PJ005SC	
Z8F0223PJ005SG	
Z8F0223QB005EC@QFN8 [(SA683)]	Z8F0223QB005EG@QFN8
[(SA683)]	
Z8F0223QB005SC@QFN8 [(SA683)]	Z8F0223QB005SG@QFN8
[(SA683)]	
Z8F0223SB005EC@SOIC8 [(SA602A)]	Z8F0223SB005EG@SOIC8
[(SA602A)]	
Z8F0223SB005SC@SOIC8 [(SA602A)]	Z8F0223SB005SG@SOIC8
[(SA602A)]	
Z8F0223SH005EC@SOIC20 [(SA404)]	Z8F0223SH005EG@SOIC20

[ ( SA404 ) ]		
Z8F0223SH005SC@SOIC20 [ ( SA404 ) ]		Z8F0223SH005SG@SOIC20
[ ( SA404 ) ]		
Z8F0223SJ005EC@SOIC28 [ ( SA404 ) ]		Z8F0223SJ005EG@SOIC28
[ ( SA404 ) ]		
Z8F0223SJ005SC@SOIC28 [ ( SA404 ) ]		Z8F0223SJ005SG@SOIC28
[ ( SA404 ) ]		
Z8F022AHH020EC@SSOP20 [ ( SA626A ) ]		Z8F022AHH020EG@SSOP20
[ ( SA626A ) ]		
Z8F022AHH020SC@SSOP20 [ ( SA626A ) ]		Z8F022AHH020SG@SSOP20
[ ( SA626A ) ]		
Z8F022AHJ020EC@SSOP28 [ ( SA626A ) ]		Z8F022AHJ020EG@SSOP28
[ ( SA626A ) ]		
Z8F022AHJ020SC@SSOP28 [ ( SA626A ) ]		Z8F022AHJ020SG@SSOP28
[ ( SA626A ) ]		
Z8F022APB020EC		
Z8F022APB020EG		
Z8F022APB020SC		
Z8F022APB020SG		
Z8F022APH020EC		
Z8F022APH020EG		
Z8F022APH020SC		
Z8F022APH020SG		
Z8F022APJ020EC		
Z8F022APJ020EG		
Z8F022APJ020SC		
Z8F022APJ020SG		
Z8F022AQB020EC@QFN8 [ ( SA683 ) ]		Z8F022AQB020EG@QFN8
[ ( SA683 ) ]		
Z8F022AQB020SC@QFN8 [ ( SA683 ) ]		Z8F022AQB020SG@QFN8
[ ( SA683 ) ]		
Z8F022ASB020EC@SOIC8 [ ( SA602A ) ]		Z8F022ASB020EG@SOIC8
[ ( SA602A ) ]		
Z8F022ASB020SC@SOIC8 [ ( SA602A ) ]		Z8F022ASB020SG@SOIC8
[ ( SA602A ) ]		
Z8F022ASH020EC@SOIC20 [ ( SA404 ) ]		Z8F022ASH020EG@SOIC20
[ ( SA404 ) ]		
Z8F022ASH020SC@SOIC20 [ ( SA404 ) ]		Z8F022ASH020SG@SOIC20
[ ( SA404 ) ]		
Z8F022ASJ020EC@SOIC28 [ ( SA404 ) ]		Z8F022ASJ020EG@SOIC28
[ ( SA404 ) ]		
Z8F022ASJ020SC@SOIC28 [ ( SA404 ) ]		Z8F022ASJ020SG@SOIC28
[ ( SA404 ) ]		



Z8F0230HH020EG@SSOP20 [(SA626A)]	Z8F0230HH020SG@SSOP20
[(SA626A)]	
Z8F0230HJ020EG@SSOP28 [(SA626A)]	Z8F0230HJ020SG@SSOP28
[(SA626A)]	
Z8F0230PH020EG	
Z8F0230PH020SG	
Z8F0230PJ020EG	
Z8F0230PJ020SG	
Z8F0230QH020EG@QFN20 [(SA759)]	Z8F0230QH020SG@QFN20
[(SA759)]	
Z8F0230QJ020EG@QFN28 [(SA697)]	Z8F0230QJ020SG@QFN28
[(SA697)]	
Z8F0230SH020EG@SOIC20 [(SA404)]	Z8F0230SH020SG@SOIC20
[(SA404)]	
Z8F0230SJ020EG@SOIC28 [(SA404)]	Z8F0230SJ020SG@SOIC28
[(SA404)]	
Z8F0231HH020EG@SSOP20 [(SA626A)]	Z8F0231HH020SG@SSOP20
[(SA626A)]	
Z8F0231HJ020EG@SSOP28 [(SA626A)]	Z8F0231HJ020SG@SSOP28
[(SA626A)]	
Z8F0231PH020EG	
Z8F0231PH020SG	
Z8F0231PJ020EG	
Z8F0231PJ020SG	
Z8F0231QH020EG@QFN20 [(SA759)]	Z8F0231QH020SG@QFN20
[(SA759)]	
Z8F0231QJ020EG@QFN28 [(SA697)]	Z8F0231QJ020SG@QFN28
[(SA697)]	
Z8F0231SH020EG@SOIC20 [(SA404)]	Z8F0231SH020SG@SOIC20
[(SA404)]	
Z8F0231SJ020EG@SOIC28 [(SA404)]	Z8F0231SJ020SG@SOIC28
[(SA404)]	
Z8F0411HH020EC@SSOP20 [(SA626A)]	Z8F0411HH020EG@SSOP20
[(SA626A)]	
Z8F0411HH020SC@SSOP20 [(SA626A)]	Z8F0411HH020SG@SSOP20
[(SA626A)]	
Z8F0411PH020EC	
Z8F0411PH020EG	
Z8F0411PH020SC	
Z8F0411PH020SG	
Z8F0412PJ020EC	
Z8F0412PJ020EG	
Z8F0412PJ020SC	

Z8F0412PJ020SG

Z8F0412SJ020EC@SOIC28 [(SA404)]  
[(SA404)]Z8F0412SJ020SC@SOIC28 [(SA404)]  
[(SA404)]Z8F0413HH005EC@SSOP20 [(SA626A)]  
[(SA626A)]Z8F0413HH005SC@SSOP20 [(SA626A)]  
[(SA626A)]Z8F0413HJ005EC@SSOP28 [(SA626A)]  
[(SA626A)]Z8F0413HJ005SC@SSOP28 [(SA626A)]  
[(SA626A)]

Z8F0413PB005EC

Z8F0413PB005EG

Z8F0413PB005SC

Z8F0413PB005SG

Z8F0413PH005EC

Z8F0413PH005EG

Z8F0413PH005SC

Z8F0413PH005SG

Z8F0413PJ005EC

Z8F0413PJ005EG

Z8F0413PJ005SC

Z8F0413PJ005SG

Z8F0413QB005EC@QFN8 [(SA683)]  
[(SA683)]Z8F0413QB005SC@QFN8 [(SA683)]  
[(SA683)]Z8F0413SB005EC@SOIC8 [(SA602A)]  
[(SA602A)]Z8F0413SB005SC@SOIC8 [(SA602A)]  
[(SA602A)]Z8F0413SH005EC@SOIC20 [(SA404)]  
[(SA404)]Z8F0413SH005SC@SOIC20 [(SA404)]  
[(SA404)]Z8F0413SJ005EC@SOIC28 [(SA404)]  
[(SA404)]Z8F0413SJ005SC@SOIC28 [(SA404)]  
[(SA404)]Z8F041AHH020EC@SSOP20 [(SA626A)]  
[(SA626A)]

Z8F0412SJ020EG@SOIC28

Z8F0412SJ020SG@SOIC28

Z8F0413HH005EG@SSOP20

Z8F0413HH005SG@SSOP20

Z8F0413HJ005EG@SSOP28

Z8F0413HJ005SG@SSOP28

Z8F0413QB005EG@QFN8

Z8F0413QB005SG@QFN8

Z8F0413SB005EG@SOIC8

Z8F0413SB005SG@SOIC8

Z8F0413SH005EG@SOIC20

Z8F0413SH005SG@SOIC20

Z8F0413SJ005EG@SOIC28

Z8F0413SJ005SG@SOIC28

Z8F041AHH020EG@SSOP20

Z8F041AHH020SC@SSOP20 [(SA626A)]	Z8F041AHH020SG@SSOP20
[(SA626A)]	
Z8F041AHJ020EC@SSOP28 [(SA626A)]	Z8F041AHJ020EG@SSOP28
[(SA626A)]	
Z8F041AHJ020SC@SSOP28 [(SA626A)]	Z8F041AHJ020SG@SSOP28
[(SA626A)]	
Z8F041APB020EC	
Z8F041APB020EG	
Z8F041APB020SC	
Z8F041APB020SG	
Z8F041APH020EC	
Z8F041APH020EG	
Z8F041APH020SC	
Z8F041APH020SG	
Z8F041APJ020EC	
Z8F041APJ020EG	
Z8F041APJ020SC	
Z8F041APJ020SG	
Z8F041AQB020EC@QFN8 [(SA683)]	Z8F041AQB020EG@QFN8
[(SA683)]	
Z8F041AQB020SC@QFN8 [(SA683)]	Z8F041AQB020SG@QFN8
[(SA683)]	
Z8F041ASB020EC@SOIC8 [(SA602A)]	Z8F041ASB020EG@SOIC8
[(SA602A)]	
Z8F041ASB020SC@SOIC8 [(SA602A)]	Z8F041ASB020SG@SOIC8
[(SA602A)]	
Z8F041ASH020EC@SOIC20 [(SA404)]	Z8F041ASH020EG@SOIC20
[(SA404)]	
Z8F041ASH020SC@SOIC20 [(SA404)]	Z8F041ASH020SG@SOIC20
[(SA404)]	
Z8F041ASJ020EC@SOIC28 [(SA404)]	Z8F041ASJ020EG@SOIC28
[(SA404)]	
Z8F041ASJ020SC@SOIC28 [(SA404)]	Z8F041ASJ020SG@SOIC28
[(SA404)]	
Z8F0421HH020EC@SSOP20 [(SA626A)]	Z8F0421HH020EG@SSOP20
[(SA626A)]	
Z8F0421HH020SC@SSOP20 [(SA626A)]	Z8F0421HH020SG@SSOP20
[(SA626A)]	
Z8F0421PH020EC	
Z8F0421PH020EG	
Z8F0421PH020SC	
Z8F0421PH020SG	
Z8F0422PJ020EC	

Z8F0422PJ020EG

Z8F0422PJ020SC

Z8F0422PJ020SG

Z8F0422SJ020EC@SOIC28 [(SA404)]  
[(SA404)]

Z8F0422SJ020EG@SOIC28

Z8F0422SJ020SC@SOIC28 [(SA404)]  
[(SA404)]

Z8F0422SJ020SG@SOIC28

Z8F0423HH005EC@SSOP20 [(SA626A)]  
[(SA626A)]

Z8F0423HH005EG@SSOP20

Z8F0423HH005SC@SSOP20 [(SA626A)]  
[(SA626A)]

Z8F0423HH005SG@SSOP20

Z8F0423HJ005EC@SSOP28 [(SA626A)]  
[(SA626A)]

Z8F0423HJ005EG@SSOP28

Z8F0423HJ005SC@SSOP28 [(SA626A)]  
[(SA626A)]

Z8F0423HJ005SG@SSOP28

Z8F0423PB005EC

Z8F0423PB005EG

Z8F0423PB005SC

Z8F0423PB005SG

Z8F0423PH005EC

Z8F0423PH005EG

Z8F0423PH005SC

Z8F0423PH005SG

Z8F0423PJ005EC

Z8F0423PJ005EG

Z8F0423PJ005SC

Z8F0423PJ005SG

Z8F0423QB005EC@QFN8 [(SA683)]  
[(SA683)]

Z8F0423QB005EG@QFN8

Z8F0423QB005SC@QFN8 [(SA683)]  
[(SA683)]

Z8F0423QB005SG@QFN8

Z8F0423SB005EC@SOIC8 [(SA602A)]  
[(SA602A)]

Z8F0423SB005EG@SOIC8

Z8F0423SB005SC@SOIC8 [(SA602A)]  
[(SA602A)]

Z8F0423SB005SG@SOIC8

Z8F0423SH005EC@SOIC20 [(SA404)]  
[(SA404)]

Z8F0423SH005EG@SOIC20

Z8F0423SH005SC@SOIC20 [(SA404)]  
[(SA404)]

Z8F0423SH005SG@SOIC20

Z8F0423SJ005EC@SOIC28 [(SA404)]  
[(SA404)]

Z8F0423SJ005EG@SOIC28

Z8F0423SJ005SC@SOIC28 [(SA404)]  
[(SA404)]

Z8F0423SJ005SG@SOIC28

Z8F042AHH020EC@SSOP20 [(SA626A)]	Z8F042AHH020EG@SSOP20
[(SA626A)]	
Z8F042AHH020SC@SSOP20 [(SA626A)]	Z8F042AHH020SG@SSOP20
[(SA626A)]	
Z8F042AHJ020EC@SSOP28 [(SA626A)]	Z8F042AHJ020EG@SSOP28
[(SA626A)]	
Z8F042AHJ020SC@SSOP28 [(SA626A)]	Z8F042AHJ020SG@SSOP28
[(SA626A)]	
Z8F042APB020EC	
Z8F042APB020EG	
Z8F042APB020SC	
Z8F042APB020SG	
Z8F042APH020EC	
Z8F042APH020EG	
Z8F042APH020SC	
Z8F042APH020SG	
Z8F042APJ020EC	
Z8F042APJ020EG	
Z8F042APJ020SC	
Z8F042APJ020SG	
Z8F042AQB020EC@QFN8 [(SA683)]	Z8F042AQB020EG@QFN8
[(SA683)]	
Z8F042AQB020SC@QFN8 [(SA683)]	Z8F042AQB020SG@QFN8
[(SA683)]	
Z8F042ASB020EC@SOIC8 [(SA602A)]	Z8F042ASB020EG@SOIC8
[(SA602A)]	
Z8F042ASB020SC@SOIC8 [(SA602A)]	Z8F042ASB020SG@SOIC8
[(SA602A)]	
Z8F042ASH020EC@SOIC20 [(SA404)]	Z8F042ASH020EG@SOIC20
[(SA404)]	
Z8F042ASH020SC@SOIC20 [(SA404)]	Z8F042ASH020SG@SOIC20
[(SA404)]	
Z8F042ASJ020EC@SOIC28 [(SA404)]	Z8F042ASJ020EG@SOIC28
[(SA404)]	
Z8F042ASJ020SC@SOIC28 [(SA404)]	Z8F042ASJ020SG@SOIC28
[(SA404)]	
Z8F0430HH020EG@SSOP20 [(SA626A)]	Z8F0430HH020SG@SSOP20
[(SA626A)]	
Z8F0430HJ020EG@SSOP28 [(SA626A)]	Z8F0430HJ020SG@SSOP28
[(SA626A)]	
Z8F0430PH020EG	
Z8F0430PH020SG	
Z8F0430PJ020EG	

Z8F0430PJ020SG

Z8F0430QH020EG@QFN20 [(SA759)]  
[(SA759)]Z8F0430QJ020EG@QFN28 [(SA697)]  
[(SA697)]Z8F0430SH020EG@SOIC20 [(SA404)]  
[(SA404)]Z8F0430SJ020EG@SOIC28 [(SA404)]  
[(SA404)]Z8F0431HH020EG@SSOP20 [(SA626A)]  
[(SA626A)]Z8F0431HJ020EG@SSOP28 [(SA626A)]  
[(SA626A)]

Z8F0431PH020EG

Z8F0431PH020SG

Z8F0431PJ020EG

Z8F0431PJ020SG

Z8F0431QH020EG@QFN20 [(SA759)]  
[(SA759)]Z8F0431QJ020EG@QFN28 [(SA697)]  
[(SA697)]Z8F0431SH020EG@SOIC20 [(SA404)]  
[(SA404)]Z8F0431SJ020EG@SOIC28 [(SA404)]  
[(SA404)]Z8F0811HH020EC@SSOP20 [(SA626A)]  
[(SA626A)]Z8F0811HH020SC@SSOP20 [(SA626A)]  
[(SA626A)]

Z8F0811PH020EC

Z8F0811PH020EG

Z8F0811PH020SC

Z8F0811PH020SG

Z8F0812PJ020EC

Z8F0812PJ020EG

Z8F0812PJ020SC

Z8F0812PJ020SG

Z8F0812SJ020EC@SOIC28 [(SA404)]  
[(SA404)]Z8F0812SJ020SC@SOIC28 [(SA404)]  
[(SA404)]Z8F0813HH005EC@SSOP20 [(SA626A)]  
[(SA626A)]

Z8F0430QH020SG@QFN20

Z8F0430QJ020SG@QFN28

Z8F0430SH020SG@SOIC20

Z8F0430SJ020SG@SOIC28

Z8F0431HH020SG@SSOP20

Z8F0431HJ020SG@SSOP28

Z8F0431QH020SG@QFN20

Z8F0431QJ020SG@QFN28

Z8F0431SH020SG@SOIC20

Z8F0431SJ020SG@SOIC28

Z8F0811HH020EG@SSOP20

Z8F0811HH020SG@SSOP20

Z8F0812SJ020EG@SOIC28

Z8F0812SJ020SG@SOIC28

Z8F0813HH005EG@SSOP20

Z8F0813HH005SC@SSOP20 [(SA626A)]	Z8F0813HH005SG@SSOP20
[(SA626A)]	
Z8F0813HJ020EC@SSOP28 [(SA626A)]	Z8F0813HJ020EG@SSOP28
[(SA626A)]	
Z8F0813HJ020SC@SSOP28 [(SA626A)]	Z8F0813HJ020SG@SSOP28
[(SA626A)]	
Z8F0813PB005EC	
Z8F0813PB005EG	
Z8F0813PB005SC	
Z8F0813PB005SG	
Z8F0813PH005EC	
Z8F0813PH005EG	
Z8F0813PH005SC	
Z8F0813PH005SG	
Z8F0813PJ020EC	
Z8F0813PJ020EG	
Z8F0813PJ020SC	
Z8F0813PJ020SG	
Z8F0813QB005EC@QFN8 [(SA683)]	Z8F0813QB005EG@QFN8
[(SA683)]	
Z8F0813QB005SC@QFN8 [(SA683)]	Z8F0813QB005SG@QFN8
[(SA683)]	
Z8F0813SB005EC@SOIC8 [(SA602A)]	Z8F0813SB005EG@SOIC8
[(SA602A)]	
Z8F0813SB005SC@SOIC8 [(SA602A)]	Z8F0813SB005SG@SOIC8
[(SA602A)]	
Z8F0813SH005EC@SOIC20 [(SA404)]	Z8F0813SH005EG@SOIC20
[(SA404)]	
Z8F0813SH005SC@SOIC20 [(SA404)]	Z8F0813SH005SG@SOIC20
[(SA404)]	
Z8F0813SJ020EC@SOIC28 [(SA404)]	Z8F0813SJ020EG@SOIC28
[(SA404)]	
Z8F0813SJ020SC@SOIC28 [(SA404)]	Z8F0813SJ020SG@SOIC28
[(SA404)]	
Z8F081AHH005EC@SSOP20 [(SA626A)]	Z8F081AHH005EG@SSOP20
[(SA626A)]	
Z8F081AHH005SC@SSOP20 [(SA626A)]	Z8F081AHH005SG@SSOP20
[(SA626A)]	
Z8F081AHJ020EC@SSOP28 [(SA626A)]	Z8F081AHJ020EG@SSOP28
[(SA626A)]	
Z8F081AHJ020SC@SSOP28 [(SA626A)]	Z8F081AHJ020SG@SSOP28
[(SA626A)]	
Z8F081APB020EC	

Z8F081APB020EG

Z8F081APB020SC

Z8F081APB020SG

Z8F081APH005EC

Z8F081APH005EG

Z8F081APH005SC

Z8F081APH005SG

Z8F081APJ020EC

Z8F081APJ020EG

Z8F081APJ020SC

Z8F081APJ020SG

Z8F081AQB020EC@QFN8 [(SA683)]

[(SA683)]

Z8F081AQB020EG@QFN8

Z8F081AQB020SC@QFN8 [(SA683)]

[(SA683)]

Z8F081AQB020SG@QFN8

Z8F081ASB020EC@SOIC8 [(SA602A)]

[(SA602A)]

Z8F081ASB020EG@SOIC8

Z8F081ASB020SC@SOIC8 [(SA602A)]

[(SA602A)]

Z8F081ASB020SG@SOIC8

Z8F081ASH005EC@SOIC20 [(SA404)]

[(SA404)]

Z8F081ASH005EG@SOIC20

Z8F081ASH005SC@SOIC20 [(SA404)]

[(SA404)]

Z8F081ASH005SG@SOIC20

Z8F081ASJ020EC@SOIC28 [(SA404)]

[(SA404)]

Z8F081ASJ020EG@SOIC28

Z8F081ASJ020SC@SOIC28 [(SA404)]

[(SA404)]

Z8F081ASJ020SG@SOIC28

Z8F0821HH020EC@SSOP20 [(SA626A)]

[(SA626A)]

Z8F0821HH020EG@SSOP20

Z8F0821HH020SC@SSOP20 [(SA626A)]

[(SA626A)]

Z8F0821HH020SG@SSOP20

Z8F0821PH020EC

Z8F0821PH020EG

Z8F0821PH020SC

Z8F0821PH020SG

Z8F0822PJ020EC

Z8F0822PJ020EG

Z8F0822PJ020SC

Z8F0822PJ020SG

Z8F0822SJ020EC@SOIC28 [(SA404)]

[(SA404)]

Z8F0822SJ020EG@SOIC28

Z8F0822SJ020SC@SOIC28 [(SA404)]

[(SA404)]

Z8F0822SJ020SG@SOIC28



Z8F0823HH005EC@SSOP20 [(SA626A)]	Z8F0823HH005EG@SSOP20
[(SA626A)]	
Z8F0823HH005SC@SSOP20 [(SA626A)]	Z8F0823HH005SG@SSOP20
[(SA626A)]	
Z8F0823HJ020EC@SSOP28 [(SA626A)]	Z8F0823HJ020EG@SSOP28
[(SA626A)]	
Z8F0823HJ020SC@SSOP28 [(SA626A)]	Z8F0823HJ020SG@SSOP28
[(SA626A)]	
Z8F0823PB005EC	
Z8F0823PB005EG	
Z8F0823PB005SC	
Z8F0823PB005SG	
Z8F0823PH005EC	
Z8F0823PH005EG	
Z8F0823PH005SC	
Z8F0823PH005SG	
Z8F0823PJ020EC	
Z8F0823PJ020EG	
Z8F0823PJ020SC	
Z8F0823PJ020SG	
Z8F0823QB005EC@QFN8 [(SA683)]	Z8F0823QB005EG@QFN8
[(SA683)]	
Z8F0823QB005SC@QFN8 [(SA683)]	Z8F0823QB005SG@QFN8
[(SA683)]	
Z8F0823SB005EC@SOIC8 [(SA602A)]	Z8F0823SB005EG@SOIC8
[(SA602A)]	
Z8F0823SB005SC@SOIC8 [(SA602A)]	Z8F0823SB005SG@SOIC8
[(SA602A)]	
Z8F0823SH005EC@SOIC20 [(SA404)]	Z8F0823SH005EG@SOIC20
[(SA404)]	
Z8F0823SH005SC@SOIC20 [(SA404)]	Z8F0823SH005SG@SOIC20
[(SA404)]	
Z8F0823SJ020EC@SOIC28 [(SA404)]	Z8F0823SJ020EG@SOIC28
[(SA404)]	
Z8F0823SJ020SC@SOIC28 [(SA404)]	Z8F0823SJ020SG@SOIC28
[(SA404)]	
Z8F082AHH005EC@SSOP20 [(SA626A)]	Z8F082AHH005EG@SSOP20
[(SA626A)]	
Z8F082AHH005SC@SSOP20 [(SA626A)]	Z8F082AHH005SG@SSOP20
[(SA626A)]	
Z8F082AHJ020EC@SSOP28 [(SA626A)]	Z8F082AHJ020EG@SSOP28
[(SA626A)]	
Z8F082AHJ020SC@SSOP28 [(SA626A)]	Z8F082AHJ020SG@SSOP28

[ ( SA626A ) ]

Z8F082APB020EC

Z8F082APB020EG

Z8F082APB020SC

Z8F082APB020SG

Z8F082APH005EC

Z8F082APH005EG

Z8F082APH005SC

Z8F082APH005SG

Z8F082APJ020EC

Z8F082APJ020EG

Z8F082APJ020SC

Z8F082APJ020SG

Z8F082AQB020EC@QFN8 [ ( SA683 ) ]

[ ( SA683 ) ]

Z8F082AQB020SC@QFN8 [ ( SA683 ) ]

[ ( SA683 ) ]

Z8F082ASB020EC@SOIC8 [ ( SA602A ) ]

[ ( SA602A ) ]

Z8F082ASB020SC@SOIC8 [ ( SA602A ) ]

[ ( SA602A ) ]

Z8F082ASH005EC@SOIC20 [ ( SA404 ) ]

[ ( SA404 ) ]

Z8F082ASH005SC@SOIC20 [ ( SA404 ) ]

[ ( SA404 ) ]

Z8F082ASJ020EC@SOIC28 [ ( SA404 ) ]

[ ( SA404 ) ]

Z8F082ASJ020SC@SOIC28 [ ( SA404 ) ]

[ ( SA404 ) ]

Z8F0830HH020EG@SSOP20 [ ( SA626A ) ]

[ ( SA626A ) ]

Z8F0830HJ020EG@SSOP28 [ ( SA626A ) ]

[ ( SA626A ) ]

Z8F0830PH020EG

Z8F0830PH020SG

Z8F0830PJ020EG

Z8F0830PJ020SG

Z8F0830QH020EG@QFN20 [ ( SA759 ) ]

[ ( SA759 ) ]

Z8F0830QJ020EG@QFN28 [ ( SA697 ) ]

[ ( SA697 ) ]

Z8F0830SH020EG@SOIC20 [ ( SA404 ) ]

[ ( SA404 ) ]

Z8F082AQB020EG@QFN8

Z8F082AQB020SG@QFN8

Z8F082ASB020EG@SOIC8

Z8F082ASB020SG@SOIC8

Z8F082ASH005EG@SOIC20

Z8F082ASH005SG@SOIC20

Z8F082ASJ020EG@SOIC28

Z8F082ASJ020SG@SOIC28

Z8F0830HH020SG@SSOP20

Z8F0830HJ020SG@SSOP28

Z8F0830QH020SG@QFN20

Z8F0830QJ020SG@QFN28

Z8F0830SH020SG@SOIC20

Z8F0830SJ020EG@SOIC28 [(SA404)]	Z8F0830SJ020SG@SOIC28
[(SA404)]	
Z8F0831HH020EG@SSOP20 [(SA626A)]	Z8F0831HH020SG@SSOP20
[(SA626A)]	
Z8F0831HJ020EG@SSOP28 [(SA626A)]	Z8F0831HJ020SG@SSOP28
[(SA626A)]	
Z8F0831PH020EG	
Z8F0831PH020SG	
Z8F0831PJ020EG	
Z8F0831PJ020SG	
Z8F0831QH020EG@QFN20 [(SA759)]	Z8F0831QH020SG@QFN20
[(SA759)]	
Z8F0831QJ020EG@QFN28 [(SA697)]	Z8F0831QJ020SG@QFN28
[(SA697)]	
Z8F0831SH020EG@SOIC20 [(SA404)]	Z8F0831SH020SG@SOIC20
[(SA404)]	
Z8F0831SJ020EG@SOIC28 [(SA404)]	Z8F0831SJ020SG@SOIC28
[(SA404)]	
Z8F1232HH020EG@SSOP20 [(SA626A)]	Z8F1232HH020SG@SSOP20
[(SA626A)]	
Z8F1232HJ020EG@SSOP28 [(SA626A)]	Z8F1232HJ020SG@SSOP28
[(SA626A)]	
Z8F1232PH020EG	
Z8F1232PH020SG	
Z8F1232PJ020EG	
Z8F1232PJ020SG	
Z8F1232QH020EG@QFN20 [(SA759)]	Z8F1232QH020SG@QFN20
[(SA759)]	
Z8F1232QJ020EG@QFN28 [(SA697)]	Z8F1232QJ020SG@QFN28
[(SA697)]	
Z8F1232SH020EG@SOIC20 [(SA404)]	Z8F1232SH020SG@SOIC20
[(SA404)]	
Z8F1232SJ020EG@SOIC28 [(SA404)]	Z8F1232SJ020SG@SOIC28
[(SA404)]	
Z8F1233HH020EG@SSOP20 [(SA626A)]	Z8F1233HH020SG@SSOP20
[(SA626A)]	
Z8F1233HJ020EG@SSOP28 [(SA626A)]	Z8F1233HJ020SG@SSOP28
[(SA626A)]	
Z8F1233PH020EG	
Z8F1233PH020SG	
Z8F1233PJ020EG	
Z8F1233PJ020SG	
Z8F1233QH020EG@QFN20 [(SA759)]	Z8F1233QH020SG@QFN20

[(SA759)]	
Z8F1233QJ020EG@QFN28 [(SA697)]	Z8F1233QJ020SG@QFN28
[(SA697)]	
Z8F1233SH020EG@SOIC20 [(SA404)]	Z8F1233SH020SG@SOIC20
[(SA404)]	
Z8F1233SJ020EG@SOIC28 [(SA404)]	Z8F1233SJ020SG@SOIC28
[(SA404)]	
Z8F4801AN@TQFP44 [(SA245A)]	
Z8F4801PM	
Z8F4801VN@PLCC44 [(SA244)]	Z8F6401AN@TQFP44
[(SA245A)]	
Z8F6401PM	Z8F6401VN@PLCC44
[(SA244)]	
Z8F6421AN020EC@LQFP44 [(SA245A)]	Z8F6421AN020SC@LQFP44
[(SA245A)]	
Z8F6421PM020EC	
Z8F6421PM020SC	
Z8F6421VN020EC@PLCC44 [(SA244)]	Z8F6421VN020SC@PLCC44
[(SA244)]	
Z8FMC04100AKEG@QFP32 [(SA663)]	Z8FMC04100AKSG@QFP32
[(SA663)]	
Z8FMC04100QKEG@QFN32 [(SA686)]	Z8FMC04100QKSG@QFN32
[(SA686)]	
Z8FMC08100AKEG@QFP32 [(SA663)]	Z8FMC08100AKSG@QFP32
[(SA663)]	
Z8FMC08100QKEG@QFN32 [(SA686)]	Z8FMC08100QKSG@QFN32
[(SA686)]	
Z8FMC16100AKEG@QFP32 [(SA663)]	Z8FMC16100AKSG@QFP32
[(SA663)]	
Z8FMC16100QKEG@QFN32 [(SA686)]	Z8FMC16100QKSG@QFN32
[(SA686)]	
ZGP323HAH2004C@SSOP20 [(SA626A)]	ZGP323HAH2004G@SSOP20
[(SA626A)]	
ZGP323HAH2008C@SSOP20 [(SA626A)]	ZGP323HAH2008G@SSOP20
[(SA626A)]	
ZGP323HAH2016C@SSOP20 [(SA626A)]	ZGP323HAH2016G@SSOP20
[(SA626A)]	
ZGP323HAH2032C@SSOP20 [(SA626A)]	ZGP323HAH2032G@SSOP20
[(SA626A)]	
ZGP323HAH2804C@SSOP28 [(SA626A)]	ZGP323HAH2804G@SSOP28
[(SA626A)]	
ZGP323HAH2808C@SSOP28 [(SA626A)]	ZGP323HAH2808G@SSOP28
[(SA626A)]	

ZGP323HAH2816C@SSOP28 [(SA626A)]	ZGP323HAH2816G@SSOP28
[(SA626A)]	
ZGP323HAH2832C@SSOP28 [(SA626A)]	ZGP323HAH2832G@SSOP28
[(SA626A)]	
ZGP323HAH4804C@SSOP48 [(SA669)]	ZGP323HAH4804G@SSOP48
[(SA669)]	
ZGP323HAH4808C@SSOP48 [(SA669)]	ZGP323HAH4808G@SSOP48
[(SA669)]	
ZGP323HAH4816C@SSOP48 [(SA669)]	ZGP323HAH4816G@SSOP48
[(SA669)]	
ZGP323HAH4832C@SSOP48 [(SA669)]	ZGP323HAH4832G@SSOP48
[(SA669)]	
ZGP323HAP2004C	
ZGP323HAP2004G	
ZGP323HAP2008C	
ZGP323HAP2008G	
ZGP323HAP2016C	
ZGP323HAP2016G	
ZGP323HAP2032C	
ZGP323HAP2032G	
ZGP323HAP2804C	
ZGP323HAP2804G	
ZGP323HAP2808C	
ZGP323HAP2808G	
ZGP323HAP2816C	
ZGP323HAP2816G	
ZGP323HAP2832C	
ZGP323HAP2832G	
ZGP323HAP4004C	
ZGP323HAP4004G	
ZGP323HAP4008C	
ZGP323HAP4008G	
ZGP323HAP4016C	
ZGP323HAP4016G	
ZGP323HAP4032C	
ZGP323HAP4032G	
ZGP323HAS2004C@SOIC20 [(SA404)]	ZGP323HAS2004G@SOIC20
[(SA404)]	
ZGP323HAS2008C@SOIC20 [(SA404)]	ZGP323HAS2008G@SOIC20
[(SA404)]	
ZGP323HAS2016C@SOIC20 [(SA404)]	ZGP323HAS2016G@SOIC20
[(SA404)]	
ZGP323HAS2032C@SOIC20 [(SA404)]	ZGP323HAS2032G@SOIC20

[ ( SA404 ) ]		
ZGP323HAS2804C@SOIC28 [ ( SA404 ) ]		ZGP323HAS2804G@SOIC28
[ ( SA404 ) ]		
ZGP323HAS2808C@SOIC28 [ ( SA404 ) ]		ZGP323HAS2808G@SOIC28
[ ( SA404 ) ]		
ZGP323HAS2816C@SOIC28 [ ( SA404 ) ]		ZGP323HAS2816G@SOIC28
[ ( SA404 ) ]		
ZGP323HAS2832C@SOIC28 [ ( SA404 ) ]		ZGP323HAS2832G@SOIC28
[ ( SA404 ) ]		
ZGP323HEH2004C@SSOP20 [ ( SA626A ) ]		ZGP323HEH2004G@SSOP20
[ ( SA626A ) ]		
ZGP323HEH2008C@SSOP20 [ ( SA626A ) ]		ZGP323HEH2008G@SSOP20
[ ( SA626A ) ]		
ZGP323HEH2016C@SSOP20 [ ( SA626A ) ]		ZGP323HEH2016G@SSOP20
[ ( SA626A ) ]		
ZGP323HEH2032C@SSOP20 [ ( SA626A ) ]		ZGP323HEH2032G@SSOP20
[ ( SA626A ) ]		
ZGP323HEH2804C@SSOP28 [ ( SA626A ) ]		ZGP323HEH2804G@SSOP28
[ ( SA626A ) ]		
ZGP323HEH2808C@SSOP28 [ ( SA626A ) ]		ZGP323HEH2808G@SSOP28
[ ( SA626A ) ]		
ZGP323HEH2816C@SSOP28 [ ( SA626A ) ]		ZGP323HEH2816G@SSOP28
[ ( SA626A ) ]		
ZGP323HEH2832C@SSOP28 [ ( SA626A ) ]		ZGP323HEH2832G@SSOP28
[ ( SA626A ) ]		
ZGP323HEH4804C@SSOP48 [ ( SA669 ) ]		ZGP323HEH4804G@SSOP48
[ ( SA669 ) ]		
ZGP323HEH4808C@SSOP48 [ ( SA669 ) ]		ZGP323HEH4808G@SSOP48
[ ( SA669 ) ]		
ZGP323HEH4816C@SSOP48 [ ( SA669 ) ]		ZGP323HEH4816G@SSOP48
[ ( SA669 ) ]		
ZGP323HEH4832C@SSOP48 [ ( SA669 ) ]		ZGP323HEH4832G@SSOP48
[ ( SA669 ) ]		
ZGP323HEP2004C		
ZGP323HEP2004G		
ZGP323HEP2008C		
ZGP323HEP2008G		
ZGP323HEP2016C		
ZGP323HEP2016G		
ZGP323HEP2032C		
ZGP323HEP2032G		
ZGP323HEP2804C		
ZGP323HEP2804G		

ZGP323HEP2808C  
ZGP323HEP2808G  
ZGP323HEP2816C  
ZGP323HEP2816G  
ZGP323HEP2832C  
ZGP323HEP2832G  
ZGP323HEP4004C  
ZGP323HEP4004G  
ZGP323HEP4008C  
ZGP323HEP4008G  
ZGP323HEP4016C  
ZGP323HEP4016G  
ZGP323HEP4032C  
ZGP323HEP4032G

ZGP323HES2004C@SOIC20 [(SA404)]  
[(SA404)]  
ZGP323HES2008C@SOIC20 [(SA404)]  
[(SA404)]  
ZGP323HES2016C@SOIC20 [(SA404)]  
[(SA404)]  
ZGP323HES2032C@SOIC20 [(SA404)]  
[(SA404)]  
ZGP323HES2804C@SOIC28 [(SA404)]  
[(SA404)]  
ZGP323HES2808C@SOIC28 [(SA404)]  
[(SA404)]  
ZGP323HES2816C@SOIC28 [(SA404)]  
[(SA404)]  
ZGP323HES2832C@SOIC28 [(SA404)]  
[(SA404)]  
ZGP323HSH2004C@SSOP20 [(SA626A)]  
[(SA626A)]  
ZGP323HSH2008C@SSOP20 [(SA626A)]  
[(SA626A)]  
ZGP323HSH2016C@SSOP20 [(SA626A)]  
[(SA626A)]  
ZGP323HSH2032C@SSOP20 [(SA626A)]  
[(SA626A)]  
ZGP323HSH2804C@SSOP28 [(SA626A)]  
[(SA626A)]  
ZGP323HSH2808C@SSOP28 [(SA626A)]  
[(SA626A)]  
ZGP323HSH2816C@SSOP28 [(SA626A)]

ZGP323HES2004G@SOIC20  
ZGP323HES2008G@SOIC20  
ZGP323HES2016G@SOIC20  
ZGP323HES2032G@SOIC20  
ZGP323HES2804G@SOIC28  
ZGP323HES2808G@SOIC28  
ZGP323HES2816G@SOIC28  
ZGP323HES2832G@SOIC28  
ZGP323HSH2004G@SSOP20  
ZGP323HSH2008G@SSOP20  
ZGP323HSH2016G@SSOP20  
ZGP323HSH2032G@SSOP20  
ZGP323HSH2804G@SSOP28  
ZGP323HSH2808G@SSOP28  
ZGP323HSH2816G@SSOP28

[ ( SA626A ) ]		
ZGP323HSH2832C@SSOP28 [ ( SA626A ) ]		ZGP323HSH2832G@SSOP28
[ ( SA626A ) ]		
ZGP323HSH4804C@SSOP48 [ ( SA669 ) ]		ZGP323HSH4804G@SSOP48
[ ( SA669 ) ]		
ZGP323HSH4808C@SSOP48 [ ( SA669 ) ]		ZGP323HSH4808G@SSOP48
[ ( SA669 ) ]		
ZGP323HSH4816C@SSOP48 [ ( SA669 ) ]		ZGP323HSH4816G@SSOP48
[ ( SA669 ) ]		
ZGP323HSH4832C@SSOP48 [ ( SA669 ) ]		ZGP323HSH4832G@SSOP48
[ ( SA669 ) ]		
ZGP323HSP2004C		
ZGP323HSP2004G		
ZGP323HSP2008C		
ZGP323HSP2008G		
ZGP323HSP2016C		
ZGP323HSP2016G		
ZGP323HSP2032C		
ZGP323HSP2032G		
ZGP323HSP2804C		
ZGP323HSP2804G		
ZGP323HSP2808C		
ZGP323HSP2808G		
ZGP323HSP2816C		
ZGP323HSP2816G		
ZGP323HSP2832C		
ZGP323HSP2832G		
ZGP323HSP4004C		
ZGP323HSP4004G		
ZGP323HSP4008C		
ZGP323HSP4008G		
ZGP323HSP4016C		
ZGP323HSP4016G		
ZGP323HSP4032C		
ZGP323HSP4032G		
ZGP323HSS2004C@SOIC20 [ ( SA404 ) ]		ZGP323HSS2004G@SOIC20
[ ( SA404 ) ]		
ZGP323HSS2008C@SOIC20 [ ( SA404 ) ]		ZGP323HSS2008G@SOIC20
[ ( SA404 ) ]		
ZGP323HSS2016C@SOIC20 [ ( SA404 ) ]		ZGP323HSS2016G@SOIC20
[ ( SA404 ) ]		
ZGP323HSS2032C@SOIC20 [ ( SA404 ) ]		ZGP323HSS2032G@SOIC20
[ ( SA404 ) ]		



ZGP323HSS2804C@SOIC28 [(SA404)]	ZGP323HSS2804G@SOIC28
[(SA404)]	
ZGP323HSS2808C@SOIC28 [(SA404)]	ZGP323HSS2808G@SOIC28
[(SA404)]	
ZGP323HSS2816C@SOIC28 [(SA404)]	ZGP323HSS2816G@SOIC28
[(SA404)]	
ZGP323HSS2832C@SOIC28 [(SA404)]	ZGP323HSS2832G@SOIC28
[(SA404)]	
ZGP323LAH2004C@SSOP20 [(SA626A)]	ZGP323LAH2004G@SSOP20
[(SA626A)]	
ZGP323LAH2008C@SSOP20 [(SA626A)]	ZGP323LAH2008G@SSOP20
[(SA626A)]	
ZGP323LAH2016C@SSOP20 [(SA626A)]	ZGP323LAH2016G@SSOP20
[(SA626A)]	
ZGP323LAH2032C@SSOP20 [(SA626A)]	ZGP323LAH2032G@SSOP20
[(SA626A)]	
ZGP323LAH2804C@SSOP28 [(SA626A)]	ZGP323LAH2804G@SSOP28
[(SA626A)]	
ZGP323LAH2808C@SSOP28 [(SA626A)]	ZGP323LAH2808G@SSOP28
[(SA626A)]	
ZGP323LAH2816C@SSOP28 [(SA626A)]	ZGP323LAH2816G@SSOP28
[(SA626A)]	
ZGP323LAH2832C@SSOP28 [(SA626A)]	ZGP323LAH2832G@SSOP28
[(SA626A)]	
ZGP323LAH4804C@SSOP48 [(SA669)]	ZGP323LAH4804G@SSOP48
[(SA669)]	
ZGP323LAH4808C@SSOP48 [(SA669)]	ZGP323LAH4808G@SSOP48
[(SA669)]	
ZGP323LAH4816C@SSOP48 [(SA669)]	ZGP323LAH4816G@SSOP48
[(SA669)]	
ZGP323LAH4832C@SSOP48 [(SA669)]	ZGP323LAH4832G@SSOP48
[(SA669)]	
ZGP323LAP2004C	
ZGP323LAP2004G	
ZGP323LAP2008C	
ZGP323LAP2008G	
ZGP323LAP2016C	
ZGP323LAP2016G	
ZGP323LAP2032C	
ZGP323LAP2032G	
ZGP323LAP2804C	
ZGP323LAP2804G	
ZGP323LAP2808C	

ZGP323LAP2808G

ZGP323LAP2816C

ZGP323LAP2816G

ZGP323LAP2832C

ZGP323LAP2832G

ZGP323LAP4004C

ZGP323LAP4004G

ZGP323LAP4008C

ZGP323LAP4008G

ZGP323LAP4016C

ZGP323LAP4016G

ZGP323LAP4032C

ZGP323LAP4032G

ZGP323LAS2004C@SOIC20 [ ( SA404 ) ]  
[ ( SA404 ) ]

ZGP323LAS2004G@SOIC20

ZGP323LAS2008C@SOIC20 [ ( SA404 ) ]  
[ ( SA404 ) ]

ZGP323LAS2008G@SOIC20

ZGP323LAS2016C@SOIC20 [ ( SA404 ) ]  
[ ( SA404 ) ]

ZGP323LAS2016G@SOIC20

ZGP323LAS2032C@SOIC20 [ ( SA404 ) ]  
[ ( SA404 ) ]

ZGP323LAS2032G@SOIC20

ZGP323LAS2804C@SOIC28 [ ( SA404 ) ]  
[ ( SA404 ) ]

ZGP323LAS2804G@SOIC28

ZGP323LAS2808C@SOIC28 [ ( SA404 ) ]  
[ ( SA404 ) ]

ZGP323LAS2808G@SOIC28

ZGP323LAS2816C@SOIC28 [ ( SA404 ) ]  
[ ( SA404 ) ]

ZGP323LAS2816G@SOIC28

ZGP323LAS2832C@SOIC28 [ ( SA404 ) ]  
[ ( SA404 ) ]

ZGP323LAS2832G@SOIC28

ZGP323LEH2004C@SSOP20 [ ( SA626A ) ]  
[ ( SA626A ) ]

ZGP323LEH2004G@SSOP20

ZGP323LEH2008C@SSOP20 [ ( SA626A ) ]  
[ ( SA626A ) ]

ZGP323LEH2008G@SSOP20

ZGP323LEH2016C@SSOP20 [ ( SA626A ) ]  
[ ( SA626A ) ]

ZGP323LEH2016G@SSOP20

ZGP323LEH2032C@SSOP20 [ ( SA626A ) ]  
[ ( SA626A ) ]

ZGP323LEH2032G@SSOP20

ZGP323LEH2804C@SSOP28 [ ( SA626A ) ]  
[ ( SA626A ) ]

ZGP323LEH2804G@SSOP28

ZGP323LEH2808C@SSOP28 [ ( SA626A ) ]  
[ ( SA626A ) ]

ZGP323LEH2808G@SSOP28

ZGP323LEH2816C@SSOP28 [ ( SA626A ) ]  
[ ( SA626A ) ]

ZGP323LEH2816G@SSOP28

ZGP323LEH2832C@SSOP28 [(SA626A)]	ZGP323LEH2832G@SSOP28
[(SA626A)]	
ZGP323LEH4804C@SSOP48 [(SA669)]	ZGP323LEH4804G@SSOP48
[(SA669)]	
ZGP323LEH4808C@SSOP48 [(SA669)]	ZGP323LEH4808G@SSOP48
[(SA669)]	
ZGP323LEH4816C@SSOP48 [(SA669)]	ZGP323LEH4816G@SSOP48
[(SA669)]	
ZGP323LEH4832C@SSOP48 [(SA669)]	ZGP323LEH4832G@SSOP48
[(SA669)]	
ZGP323LEP2004C	
ZGP323LEP2004G	
ZGP323LEP2008C	
ZGP323LEP2008G	
ZGP323LEP2016C	
ZGP323LEP2016G	
ZGP323LEP2032C	
ZGP323LEP2032G	
ZGP323LEP2804C	
ZGP323LEP2804G	
ZGP323LEP2808C	
ZGP323LEP2808G	
ZGP323LEP2816C	
ZGP323LEP2816G	
ZGP323LEP2832C	
ZGP323LEP2832G	
ZGP323LEP4004C	
ZGP323LEP4004G	
ZGP323LEP4008C	
ZGP323LEP4008G	
ZGP323LEP4016C	
ZGP323LEP4016G	
ZGP323LEP4032C	
ZGP323LEP4032G	
ZGP323LES2004C@SOIC20 [(SA404)]	ZGP323LES2004G@SOIC20
[(SA404)]	
ZGP323LES2008C@SOIC20 [(SA404)]	ZGP323LES2008G@SOIC20
[(SA404)]	
ZGP323LES2016C@SOIC20 [(SA404)]	ZGP323LES2016G@SOIC20
[(SA404)]	
ZGP323LES2032C@SOIC20 [(SA404)]	ZGP323LES2032G@SOIC20
[(SA404)]	
ZGP323LES2804C@SOIC28 [(SA404)]	ZGP323LES2804G@SOIC28

[ ( SA404 ) ]		
ZGP323LES2808C@SOIC28 [ ( SA404 ) ]		ZGP323LES2808G@SOIC28
[ ( SA404 ) ]		
ZGP323LES2816C@SOIC28 [ ( SA404 ) ]		ZGP323LES2816G@SOIC28
[ ( SA404 ) ]		
ZGP323LES2832C@SOIC28 [ ( SA404 ) ]		ZGP323LES2832G@SOIC28
[ ( SA404 ) ]		
ZGP323LSH2004C@SSOP20 [ ( SA626A ) ]		ZGP323LSH2004G@SSOP20
[ ( SA626A ) ]		
ZGP323LSH2008C@SSOP20 [ ( SA626A ) ]		ZGP323LSH2008G@SSOP20
[ ( SA626A ) ]		
ZGP323LSH2016C@SSOP20 [ ( SA626A ) ]		ZGP323LSH2016G@SSOP20
[ ( SA626A ) ]		
ZGP323LSH2032C@SSOP20 [ ( SA626A ) ]		ZGP323LSH2032G@SSOP20
[ ( SA626A ) ]		
ZGP323LSH2804C@SSOP28 [ ( SA626A ) ]		ZGP323LSH2804G@SSOP28
[ ( SA626A ) ]		
ZGP323LSH2808C@SSOP28 [ ( SA626A ) ]		ZGP323LSH2808G@SSOP28
[ ( SA626A ) ]		
ZGP323LSH2816C@SSOP28 [ ( SA626A ) ]		ZGP323LSH2816G@SSOP28
[ ( SA626A ) ]		
ZGP323LSH2832C@SSOP28 [ ( SA626A ) ]		ZGP323LSH2832G@SSOP28
[ ( SA626A ) ]		
ZGP323LSH4804C@SSOP48 [ ( SA669 ) ]		ZGP323LSH4804G@SSOP48
[ ( SA669 ) ]		
ZGP323LSH4808C@SSOP48 [ ( SA669 ) ]		ZGP323LSH4808G@SSOP48
[ ( SA669 ) ]		
ZGP323LSH4816C@SSOP48 [ ( SA669 ) ]		ZGP323LSH4816G@SSOP48
[ ( SA669 ) ]		
ZGP323LSH4832C@SSOP48 [ ( SA669 ) ]		ZGP323LSH4832G@SSOP48
[ ( SA669 ) ]		
ZGP323LSK2032E		
ZGP323LSK2032G		
ZGP323LSK2832E		
ZGP323LSK2832G		
ZGP323LSK4032E		
ZGP323LSK4032G		
ZGP323LSP2004C		
ZGP323LSP2004G		
ZGP323LSP2008C		
ZGP323LSP2008G		
ZGP323LSP2016C		
ZGP323LSP2016G		

ZGP323LSP2032C  
 ZGP323LSP2032G  
 ZGP323LSP2804C  
 ZGP323LSP2804G  
 ZGP323LSP2808C  
 ZGP323LSP2808G  
 ZGP323LSP2816C  
 ZGP323LSP2816G  
 ZGP323LSP2832C  
 ZGP323LSP2832G  
 ZGP323LSP4004C  
 ZGP323LSP4004G  
 ZGP323LSP4008C  
 ZGP323LSP4008G  
 ZGP323LSP4016C  
 ZGP323LSP4016G  
 ZGP323LSP4032C  
 ZGP323LSP4032G

ZGP323LSS2004C@SOIC20 [ ( SA404 ) ]  
 [ ( SA404 ) ]

ZGP323LSS2004G@SOIC20

ZGP323LSS2008C@SOIC20 [ ( SA404 ) ]  
 [ ( SA404 ) ]

ZGP323LSS2008G@SOIC20

ZGP323LSS2016C@SOIC20 [ ( SA404 ) ]  
 [ ( SA404 ) ]

ZGP323LSS2016G@SOIC20

ZGP323LSS2032C@SOIC20 [ ( SA404 ) ]  
 [ ( SA404 ) ]

ZGP323LSS2032G@SOIC20

ZGP323LSS2804C@SOIC28 [ ( SA404 ) ]  
 [ ( SA404 ) ]

ZGP323LSS2804G@SOIC28

ZGP323LSS2808C@SOIC28 [ ( SA404 ) ]  
 [ ( SA404 ) ]

ZGP323LSS2808G@SOIC28

ZGP323LSS2816C@SOIC28 [ ( SA404 ) ]  
 [ ( SA404 ) ]

ZGP323LSS2816G@SOIC28

ZGP323LSS2832C@SOIC28 [ ( SA404 ) ]  
 [ ( SA404 ) ]

ZGP323LSS2832G@SOIC28

ZLP12840H2028C@SSOP20 [ ( SA626A ) ]  
 [ ( SA626A ) ]

ZLP12840H2028G@SSOP20

ZLP12840H2032C@SSOP20 [ ( SA626A ) ]  
 [ ( SA626A ) ]

ZLP12840H2032G@SSOP20

ZLP12840H2064C@SSOP20 [ ( SA626A ) ]  
 [ ( SA626A ) ]

ZLP12840H2064G@SSOP20

ZLP12840H2096C@SSOP20 [ ( SA626A ) ]  
 [ ( SA626A ) ]

ZLP12840H2096G@SSOP20

ZLP12840H2828C@SSOP28 [ ( SA626A ) ]

ZLP12840H2828G@SSOP28

[ ( SA626A ) ]		
ZLP12840H2832C@SSOP28 [ ( SA626A ) ]		ZLP12840H2832G@SSOP28
[ ( SA626A ) ]		
ZLP12840H2864C@SSOP28 [ ( SA626A ) ]		ZLP12840H2864G@SSOP28
[ ( SA626A ) ]		
ZLP12840H2896C@SSOP28 [ ( SA626A ) ]		ZLP12840H2896G@SSOP28
[ ( SA626A ) ]		
ZLP12840P2028C		
ZLP12840P2028G		
ZLP12840P2032C		
ZLP12840P2032G		
ZLP12840P2064C		
ZLP12840P2064G		
ZLP12840P2096C		
ZLP12840P2096G		
ZLP12840P2828C		
ZLP12840P2828G		
ZLP12840P2832C		
ZLP12840P2832G		
ZLP12840P2864C		
ZLP12840P2864G		
ZLP12840P2896C		
ZLP12840P2896G		
ZLP12840S2028C@SOIC20 [ ( SA404 ) ]		ZLP12840S2028G@SOIC20
[ ( SA404 ) ]		
ZLP12840S2032C@SOIC20 [ ( SA404 ) ]		ZLP12840S2032G@SOIC20
[ ( SA404 ) ]		
ZLP12840S2064C@SOIC20 [ ( SA404 ) ]		ZLP12840S2064G@SOIC20
[ ( SA404 ) ]		
ZLP12840S2096C@SOIC20 [ ( SA404 ) ]		ZLP12840S2096G@SOIC20
[ ( SA404 ) ]		
ZLP12840S2828C@SOIC28 [ ( SA404 ) ]		ZLP12840S2828G@SOIC28
[ ( SA404 ) ]		
ZLP12840S2832C@SOIC28 [ ( SA404 ) ]		ZLP12840S2832G@SOIC28
[ ( SA404 ) ]		
ZLP12840S2864C@SOIC28 [ ( SA404 ) ]		ZLP12840S2864G@SOIC28
[ ( SA404 ) ]		
ZLP12840S2896C@SOIC28 [ ( SA404 ) ]		ZLP12840S2896G@SOIC28
[ ( SA404 ) ]		
ZLP32300H2004C@SSOP20 [ ( SA626A ) ]		ZLP32300H2004G@SSOP20
[ ( SA626A ) ]		
ZLP32300H2008C@SSOP20 [ ( SA626A ) ]		ZLP32300H2008G@SSOP20
[ ( SA626A ) ]		

ZLP32300H2016C@SSOP20 [(SA626A)]	ZLP32300H2016G@SSOP20
[(SA626A)]	
ZLP32300H2032C@SSOP20 [(SA626A)]	ZLP32300H2032G@SSOP20
[(SA626A)]	
ZLP32300H2804C@SSOP28 [(SA626A)]	ZLP32300H2804G@SSOP28
[(SA626A)]	
ZLP32300H2808C@SSOP28 [(SA626A)]	ZLP32300H2808G@SSOP28
[(SA626A)]	
ZLP32300H2816C@SSOP28 [(SA626A)]	ZLP32300H2816G@SSOP28
[(SA626A)]	
ZLP32300H2832C@SSOP28 [(SA626A)]	ZLP32300H2832G@SSOP28
[(SA626A)]	
ZLP32300H4804C@SSOP48 [(SA669)]	ZLP32300H4804G@SSOP48
[(SA669)]	
ZLP32300H4808C@SSOP48 [(SA669)]	ZLP32300H4808G@SSOP48
[(SA669)]	
ZLP32300H4816C@SSOP48 [(SA669)]	ZLP32300H4816G@SSOP48
[(SA669)]	
ZLP32300H4832C@SSOP48 [(SA669)]	ZLP32300H4832G@SSOP48
[(SA669)]	
ZLP32300P2004C	
ZLP32300P2004G	
ZLP32300P2008C	
ZLP32300P2008G	
ZLP32300P2016C	
ZLP32300P2016G	
ZLP32300P2032C	
ZLP32300P2032G	
ZLP32300P2804C	
ZLP32300P2804G	
ZLP32300P2808C	
ZLP32300P2808G	
ZLP32300P2816C	
ZLP32300P2816G	
ZLP32300P2832C	
ZLP32300P2832G	
ZLP32300P4004C	
ZLP32300P4004G	
ZLP32300P4008C	
ZLP32300P4008G	
ZLP32300P4016C	
ZLP32300P4016G	
ZLP32300P4032C	

ZLP32300P4032G

ZLP32300S2004C@SOIC20 [(SA404)]  
[(SA404)]ZLP32300S2008C@SOIC20 [(SA404)]  
[(SA404)]ZLP32300S2016C@SOIC20 [(SA404)]  
[(SA404)]ZLP32300S2032C@SOIC20 [(SA404)]  
[(SA404)]ZLP32300S2804C@SOIC28 [(SA404)]  
[(SA404)]ZLP32300S2808C@SOIC28 [(SA404)]  
[(SA404)]ZLP32300S2816C@SOIC28 [(SA404)]  
[(SA404)]ZLP32300S2832C@SOIC28 [(SA404)]  
[(SA404)]

ZLP32300S2004G@SOIC20

ZLP32300S2008G@SOIC20

ZLP32300S2016G@SOIC20

ZLP32300S2032G@SOIC20

ZLP32300S2804G@SOIC28

ZLP32300S2808G@SOIC28

ZLP32300S2816G@SOIC28

ZLP32300S2832G@SOIC28

**ZMD****E ( E ) PROM / FRAM / NVRAM**

U62256

U6264

U6264@SOIC28 [(SA630)]

U6264A

U6264A@SOIC28 [(SA630)]  
[(SA630)]U62H256S@SOIC28 [(SA630)]  
[(SA630)]

U630H16

[(SA630)]

U630H64

[(SA630)]

U631H16

[(SA404)]

U631H16@SOIC28 [(SA630)]

U631H256

U631H256@SOIC28 [(SA630)]

U631H64

U631H64@SOIC28 [(SA630)]

U632H16

U62H256A@SOIC28

U62H64SA@SOIC28

U630H16@SOIC28

U630H64@SOIC28

U631H16@SOIC24



U632H16@SOIC28 [(SA630)]

U632H64

U632H64@SOIC28 [(SA630)]

U634H256

U634H256@SOIC32 [(SA630)]

U635H16

U635H16@SOIC24 [(SA404)]

U635H256

U635H256@SOIC28 [(SA630)]

U635H64

U635H64@SOIC28 [(SA630)]

U63716

U637256

U63764

U637H256

UL62H256A@SOIC28

[(SA630)]

UL631H256@SOIC28 [(SA630)]

UL631H256@TSOP32

[(SA410T)]

UL634H256@SOIC32 [(SA630)]

UL634H256@TSOP32

[(SA410T)]

UL635H256@SOIC28 [(SA630)]

UL635H256@TSOP32

[(SA410T)]