



Quick Start

See user manual in CD-ROM or from www.xeltek.com for system requirements and detailed installation instructions.

Warning:

- Install software before connecting programming hardware to computer.
- If a stand-alone programmer is connected to a PC, do not press any built-in keypad buttons of the programmer. The keypad is used only for stand-alone programming with a compact flash (CF) or SD card inserted.

Software Installation

1. Select the software to setup your SuperPro programmer either from the CD-ROM (included) or by downloading from <http://www.xeltek.com/SuperPro-Software-Download-Center/>. **We recommend downloading the latest Xeltek software online.**
2. If the setup program does not start automatically, run **SETUP.EXE** located in the root directory.
3. Follow the Install Wizard instructions to complete installation. On Windows Vista, the system may display a warning dialog box. Select "**Install this driver software anyway**".

Hardware & Driver Installation

If hardware is connected before software installation, the system opens the Found New Hardware Wizard. Select Cancel to make sure the system does not install the wrong driver. Return to the Software Setup process before connecting the hardware.

1. Make sure all programs are closed during the installation process.
2. Connect the programmer module to the computer via the USB port.
3. Turn the programmer power switch on. The system should automatically initiates New Hardware Wizard, which locates the driver from the software recently installed.
4. After opening the software application, the system automatically starts initialization. If it does not, make sure the programmer is securely connected to the computer and that the power switch is on.